

Changes for the Better

MITSUBISHI CNC

EZMotion-NC E60/E68 Series

ALARM/PARAMETER MANUAL

EZMotion, MELDAS and MELSEC are registered trademarks of Mitsubishi Electric Corporation.

Other company and product names that appear in this manual are trademarks or registered trademarks of the respective companies.





PREFACE

This manual is the alarm/parameter guide required to use the EZMotion-NC E60/E68 Series. This manual is prepared on the assumption that your machine is provided with all of the EZMotion-NC E60/E68 Series functions. Confirm the functions available for your NC before proceeding to operation by referring to the specification issued by the machine manufacturer.

Notes on Reading This Manual

- (1) This manual explains general parameters as viewed from the NC.
For information about each machine tool, refer to manuals issued from the machine manufacturer. If the descriptions relating to "restrictions" and "allowable conditions" conflict between this manual and the machine manufacturer's instruction manual, the later has priority over the former.
- (2) This manual is intended to contain as much descriptions as possible even about special operations. The operations to which no reference is made in this manual should be considered impossible.

Caution

-  If the descriptions relating to the "restrictions" and "allowable conditions" conflict between this manual and the machine manufacturer's instruction manual, the latter has priority over the former.
-  The operations to which no reference is made in this manual should be considered impossible.
-  This manual is compiled on the assumption that your machine is provided with all functions. Confirm the functions available for your machine before proceeding to operation by referring to the specification issued by the machine manufacturer.
-  In some NC system versions, there may be cases that different pictures appear on the screen, the machine operates in a different way or some function is not activated.

Precautions for Safety

Always read the specifications issued by the machine maker, this manual, related manuals and attached documents before installation, operation, programming, maintenance or inspection to ensure correct use. Understand this numerical controller, safety items and cautions before using the unit. This manual ranks the safety precautions into "DANGER", "WARNING" and "CAUTION".




When the user may be subject to imminent fatalities or major injuries if handling is mistaken.



When the user may be subject to fatalities or major injuries if handling is mistaken.



When the user may be subject to injuries or when physical damage may occur if handling is mistaken.

Note that even items ranked as "  CAUTION", may lead to major results depending on the situation. In any case, important information that must always be observed is described.







Not applicable in this manual.




Not applicable in this manual.



1. Items related to product and manual

-  If the descriptions relating to the "restrictions" and "allowable conditions" conflict between this manual and the machine manufacturer's instruction manual, the latter has priority over the former.
-  The operations to which no reference is made in this manual should be considered impossible.
-  This manual is compiled on the assumption that your machine is provided with all functions. Confirm the functions available for your machine before proceeding to operation by referring to the specification issued by the machine manufacturer.
-  In some NC system versions, there may be cases that different pictures appear on the screen, the machine operates in a different way on some function is not activated.

2. Items related to faults and abnormalities




-  If the BATTERY LOW alarm is output, save the machining programs, tool data and parameters to an input/output device, and then replace the battery. If the BATTERY alarm occurs, the machining programs, tool data and parameters may be damaged. After replacing the battery, reload each data item.

[Continued on next page]




 **CAUTION**

[Continued]

3. Items related to maintenance

-  Do not replace the battery while the power is ON.
-  Do not short-circuit, charge, heat, incinerate or disassemble the battery.
-  Dispose of the spent battery according to local laws.

4. Items related to servo parameters and spindle parameters

-  With the MDS-C1 Series, only the serial encoder is compatible as the motor side detector. The OHE/OHA type detector cannot be used as the motor side detector.
-  Do not adjust or change the parameter settings greatly as operation could become unstable.
-  In the explanation on bits, set all bits not used, including blank bits, to "0".

CONTENTS

I EXPLANATION OF ALARMS

1. LIST OF ALARMS	1
1.1 Operation Alarms.....	1
1.2 Stop Codes	9
1.3 Servo/Spindle Alarms.....	14
1.4 MCP Alarm.....	23
1.5 System Alarms	26
1.6 Absolute Position Detection System Alarms.....	30
1.7 Messages During Emergency Stop.....	33
1.8 Auxiliary Axis Alarms	35
1.9 Computer Link Errors.....	42
1.10 User PLC Alarms.....	43
2. OPERATION MESSAGES ON SETTING AND DISPLAY UNIT.....	44
2.1 Operation Errors	44
2.2 Operator Messages.....	55
2.2.1 Search and operation related.....	55
2.2.2 MDI/editing related	56
2.2.3 Data input/output related	57
2.2.4 S-analog output adjustment related	58
2.2.5 Auxiliary axis.....	58
2.2.6 Parameter backup related.....	58
2.2.7 Others.....	59
3. PROGRAM ERROR.....	60

II EXPLANATION OF PARAMETERS

1. SCREEN CONFIGURATION.....	1
1.1 Screen Transition Charts	1
2. MACHINING PARAMETERS	3
2.1 Process Parameters.....	3
2.2 Control Parameters	9
2.3 Axis Parameters	11
2.4 Barrier Data.....	13
2.5 Tool Measurement Parameters.....	15
3. I/O PARAMETERS.....	16
3.1 Base Parameters	16
3.2 I/O Device Parameters	17
3.3 Computer Link Parameters	19
4. SETUP PARAMETERS.....	21
5. BASE SPECIFICATIONS PARAMETERS.....	22
6. AXIS SPECIFICATIONS PARAMETERS	82
6.1 Axis Specifications Parameters	82
6.2 Zero Point Return Parameters	89
6.3 Absolute Position Parameters	92
6.4 Axis Specifications Parameters 2	94
7. SERVO PARAMETERS	99
7.1 MDS-B-SVJ2.....	102
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)	129
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible).....	163

7.4 MDS-R-Vx.....	193
7.5 Supplement.....	211
7.5.1 D/A output specifications.....	211
7.5.2 Electronic gears.....	220
7.5.3 Lost motion compensation	221
8. SPINDLE PARAMETERS	222
8.1 Spindle Base Specifications Parameters	222
8.2 MDS-B-SPJ2	230
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH	250
8.4 Supplement.....	284
8.4.1 D/A output specifications.....	284
9. MACHINE ERROR COMPENSATION.....	287
9.1 Function Outline.....	287
9.2 Setting Compensation Data.....	291
9.3 Example in Using a Linear Axis as the Base Axis.....	293
9.4 Example in Using a Rotation Axis as the Base Axis.....	297
10. PLC CONSTANTS	298
10.1 PLC Timer	298
10.2 PLC Counter	298
10.3 PLC Constants	299
10.4 Selecting the PLC Bit.....	299
11. MACRO LIST	302
12. POSITION SWITCH	304
12.1 Outline of Function	304
12.2 Canceling the Position Switch	306
13. AUXILIARY AXIS PARAMETER	307

I EXPLANATION OF ALARMS

1. LIST OF ALARMS

1.1 Operation Alarm

(The bold characters are the messages displayed on the screen.)

M01 OPERATION ERROR		Alarms occurring due to incorrect operation by the operator during NC operation and those by machine trouble are displayed.
Error No.	Details	Remedy
0001	DOG OVERRUN (Dog overrun) When returning to the reference point, the near-point detection limit switch did not stop over the dog, but overran the dog.	<ul style="list-style-type: none"> • Increase the length of the near-point dog. • Reduce the reference point return speed.
0002	Z-AX NO CRSS One of the axes did not pass the Z-phase during the initial reference point return after the power was turned ON.	<ul style="list-style-type: none"> • Move the detector one rotation or more in the opposite direction of the reference point, and repeat reference point return.
0003	INVALID RET (Invalid return) When manually returning to the reference point, the return direction differs from the axis movement direction selected with the AXIS SELECTION key.	<ul style="list-style-type: none"> • The selection of the AXIS SELECTION key's +/- direction is incorrect. The error is canceled by feeding the axis in the correct direction.
0004	EXT INTRLK (External interlock) The external interlock function has activated (the input signal is "OFF") and one of the axes has entered the interlock state.	<ul style="list-style-type: none"> • As the interlock function has activated, release it before resuming operation. • Check the sequence on the machine side. • Check for broken wires in the interlock signal line.
0005	INTRL INTRLK (Internal interlock) The internal interlock state has been entered. The absolute position detector axis has been removed. A command for the manual/automatic simultaneous valid axis was issued from the automatic mode.	<ul style="list-style-type: none"> • The servo OFF function is valid, so release it first. • An axis that can be removed has been issued, so perform the correct operations. • The command is issued in the same direction as the direction where manual skip turned ON, so perform the correct operations. • During the manual/automatic simultaneous mode, the axis commanded in the automatic mode became the manual operation axis. Turn OFF the manual/automatic valid signal for the commanded axis. • Turn ON the power again, and perform absolute position initialization.

1. LIST OF ALARMS
1.1 Operation Alarm

Error No.	Details	Remedy
0006	H/W STRK END (H/W stroke end) The stroke end function has activated (the input signal is "OFF") and one of the axes is in the stroke end status.	<ul style="list-style-type: none"> • Move the machine manually. • Check for broken wires in the stroke end signal wire. • Check for trouble in the limit switch.
0007	S/W STRK END (S/W stroke end) The stored stroke limit I, II, IIB, IB or IC function has activated.	<ul style="list-style-type: none"> • Move it manually. • If the stored stroke limit in the parameter is incorrectly set, correct it.
0008	Chuck/tail-stock barrier stroke end axis found The chuck/tail-stock barrier function turned ON, and an axis entered the stroke end state.	<ul style="list-style-type: none"> • Reset the alarm with reset, and move the machine in the reverse direction.
0009	Reference point return number illegal Return to the No. 2 reference point was performed before return to the No. 1 reference point was completed.	<ul style="list-style-type: none"> • Execute No. 1 reference point return.
0019	Sensor signal illegal ON The sensor signal was already ON when the tool measurement mode (TLM) signal was validated. The sensor signal turned ON when there was no axis movement after the tool measurement mode (TLM) signal was validated. The sensor signal turned ON at a position within 100 μ m from the final entry start position.	<ul style="list-style-type: none"> • Turn the tool measurement mode signal input OFF, and move the axis in a safe direction. • The operation alarm will turn OFF even when the sensor signal is turned OFF. <p>Note) When the tool measurement mode signal input is turned OFF, the axis can be moved in either direction. Pay attention to the movement direction.</p>
0020	Reference point return illegal Return to the reference point was performed before the coordinates had not been established.	<ul style="list-style-type: none"> • Execute reference point return
0024	Zero point return disabled during absolute position detection alarm A zero point return signal was input during an absolute position detection alarm.	<ul style="list-style-type: none"> • Reset the absolute position detection alarm, and then perform zero point return.
0025	Zero point return disabled during zero point initialization A zero point return signal was input during zero point initialization of the absolute position detection system.	<ul style="list-style-type: none"> • Complete zero point initialization, and then perform zero point return.

1. LIST OF ALARMS
1.1 Operation Alarm

Error No.	Details	Remedy
0050	<p>Chopping axis zero point return incomplete The chopping axis has not completed zero point return before entering the chopping mode. All axes interlock will be applied.</p>	<ul style="list-style-type: none"> • Reset or turn the chopping signal OFF, and then carry out zero point return.
0051	<p>Synchronization error too large The synchronization error of the master and slave axes exceeded the allowable value under synchronous control. A deviation exceeding the synchronization error limit value was found with the synchronization deviation detection.</p>	<ul style="list-style-type: none"> • Select the correction mode and move one of the axes in the direction in which the errors are reduced. • Increase the allowable value or reset it to 0 (check disabled). • When using simple C-axis synchronous control, set the contents of the R435 register to 0. • Check the parameter (#2024 synerr).
0101	<p>NOT OP MODE (Not operation mode)</p>	<ul style="list-style-type: none"> • Check for a broken wire in the input mode signal wire. • Check for trouble in the mode selector switch. • Check the sequence program.
0102	<p>OVERRIDE ZERO (Override zero) The cutting feed override switch on the machine operation panel is set to zero.</p>	<ul style="list-style-type: none"> • Set the switch to a value other than zero to release the error. • If the switch is set to a value other than zero, check for a short circuit in the signal wire. • Check the sequence program.
0103	<p>EX F SPD ZRO (External feed speed zero) The manual feed speed switch on the machine operation panel is set to zero when the machine is in the jog mode or automatic dry run mode. The "Manual feedrate B speed" is set to zero during the jog mode when manual feedrate B is valid. The "each axis manual feedrate B speed" is set to zero during the jog mode when each axis manual feedrate B is valid.</p>	<ul style="list-style-type: none"> • Set the switch to a value other than zero to release the error. • If the switch is set to a value other than zero, check for a short circuit in the signal wire. • Check the sequence program.
0104	<p>F1 SPD ZRO (F1-digit speed zero) The F1-digit feedrate is set to zero when the F1-digit feed command is being executed.</p>	<ul style="list-style-type: none"> • Set the F1-digit feedrate on the setup parameter screen.

1. LIST OF ALARMS
1.1 Operation Alarm

Error No.	Details	Remedy
0105	SPINDLE STP (Spindle stop) The spindle stopped during the synchronous feed command.	<ul style="list-style-type: none"> • Rotate the spindle. • If the workpiece is not being cut, start dry run. • Check for a broken wire in the spindle encoder cable. • Check the connections for the spindle encoder connectors. • Check the spindle encoder pulse.
0106	HNDL FD NOW (Handle feed axis No. illegal) An axis not found in the specifications was designated for handle feed or the handle feed axis was not selected.	<ul style="list-style-type: none"> • Check for broken wires in the handle feed axis selection signal wire. • Check the sequence program. • Check the No. of axes listed in the specifications.
0107	SPDL RPM EXS (Spindle rotation speed excessive) The spindle rotation speed exceeded the axis clamp speed during the thread cutting command.	<ul style="list-style-type: none"> • Lower the commanded spindle rotation speed.
0108	Fixed point mode feed axis No. illegal: An axis not found in the specifications was designated for the fixed point mode feed or the fixed point mode feedrate is illegal.	<ul style="list-style-type: none"> • Check for broken wires in the fixed mode feed axis selection signal wire and fixed point mode feedrate wire. • Check the fixed point mode feed specifications.
0109	BLK ST INTLK (Block start interlock) An interlock signal that locks the start of the block has been input.	<ul style="list-style-type: none"> • Check the sequence program.
0110	CTBL ST INTLK (Cutting block start interlock) An interlock signal that locks the start of the cutting block has been input.	<ul style="list-style-type: none"> • Check the sequence program.
0111	Restart switch ON The restart switch was turned ON before the restart search was completed, and the manual mode was selected.	<ul style="list-style-type: none"> • Search the block to be restarted. • Turn OFF the restart switch.
0112	Program Check Mode The automatic start button was pressed during program check or in program check mode.	<ul style="list-style-type: none"> • Press the reset button to cancel the program check mode.
0113	Automatic start during buffer correction The automatic start button was pressed during buffer correction.	<ul style="list-style-type: none"> • Press the automatic start button after buffer correction is completed.

1. LIST OF ALARMS
1.1 Operation Alarm

Error No.	Details	Remedy
0115	RESETTING The automatic start button was pressed during resetting or tape rewinding.	<ul style="list-style-type: none"> • When rewinding the tape, wait for the winding to end, or press the reset button to stop the winding, and then press the automatic start button. • During resetting, wait for resetting to end, and then press the automatic start button.
0117	PLAYBACK NOT POSSIBLE The playback switch was turned ON during editing or full-character mode (9-inch).	<ul style="list-style-type: none"> • During editing, cancel the function by pressing the input or previous screen key, and then turn ON the playback switch. • Set the edit screen (9-inch) to the half-character mode, and then turn ON the playback switch.
0118	Block joint turn stop during normal line control The turning angle at the block joint exceeded the limit during normal line control. Normal line control type I The normal line control axis turning speed (#1523 C_feed) has not been set. Normal line control type II When turning in the inside of the arc, the parameter "#8041 C-rot.R" setting value is larger than the arc radius.	<ul style="list-style-type: none"> • Check the program. • Set the normal line control axis turning speed. (Parameter "#1523 C_feed") • Set the C axis turning diameter smaller than the arc radius, or check the setting value of the C axis turning diameter. (Parameter "#8041 C rot. R")
0120	Synchronization correction mode ON The synchronous correction mode switch was pressed in a non-handle mode.	<ul style="list-style-type: none"> • Select the handle or manual feed mode. • Turn OFF the correction mode switch.
0121	No synchronous control option R register for the synchronous control system selection was set without synchronous control specification.	<ul style="list-style-type: none"> • Check the specifications.
0123	Computer link B The cycle start was attempted before resetting was completed. The operation of the computer link B was attempted in the 2nd part system of the 2-part system.	<ul style="list-style-type: none"> • Perform the cycle start after resetting is completed. • Set 0 in #8109 HOST LINK, and then set 1 again before performing the cycle start. • The operation of the computer link B cannot be performed in the 2nd part system of the 2-part system.
0124	Simultaneous axis movement prohibited during inclined axis control valid The basic axis corresponding to the inclined axis was started simultaneously in the manual mode while the inclined axis control was valid.	<ul style="list-style-type: none"> • Turn the inclined axis and basic axis start OFF for both axes. (This also applied for manual/automatic simultaneous start.) • Invalidate the basic axis compensation, or command one axis at a time.

1. LIST OF ALARMS
1.1 Operation Alarm

Error No.	Details	Remedy
0126	Program restart machine lock Machine lock was applied on the return axis while manually returning to the restart position.	<ul style="list-style-type: none"> • Release the machine lock before resuming operations.
0150	Chopping override zero	<ul style="list-style-type: none"> • Check the chopping override (R135). • Check the rapid traverse override (R134).
0151	Command axis chopping axis A chopping axis movement command was issued from the program during the chopping mode. (This alarm will not occur when the movement amount is commanded as 0.) (All axes interlock state will be applied.)	<ul style="list-style-type: none"> • Reset, or turn OFF the chopping signal. When the chopping signal is turned OFF, the axis will return to the reference position, and then the program movement command will be executed.
0153	Bottom dead center position zero The bottom dead center position is set to the same position as the upper dead center position.	<ul style="list-style-type: none"> • Correctly set the bottom dead center position.
0154	Chopping axis handle selection axis Chopping was started when the chopping axis was selected as the handle axis.	<ul style="list-style-type: none"> • Select an axis other than the chopping axis as the handle axis, or start chopping after changing the mode to another mode.
0160	Axis with no maximum speed set for the outside of the soft limit range Returned from the outside of the soft limit range for the axis with no maximum speed set for the outside of the soft limit range.	<ul style="list-style-type: none"> • Set the maximum speed for the outside of the soft limit range. (Parameter "#2021 out_f") • Change the soft limit range. (Parameter "#2013 OT-" "#2014 OT+")
1005	An attempt was made to execute G114.* during execution of G114.*. G51.2 was commanded when the G51.2 spindle-spindle polygon machining mode was already entered with a separate system.	<ul style="list-style-type: none"> • Issue G113 to cancel G114.*. • Issue the spindle synchronous cancel signal (Y2E8: SPSYC) to cancel G114.*. • Cancel with G50.2. • Cancel with the spindle-spindle polygon cancel signal (Y359).
1007	The spindle is being used in synchronized tapping.	<ul style="list-style-type: none"> • Cancel synchronized tapping.
1026	Spindle C axis and other position control were commanded simultaneously. C axis mode command was issued for polygon machining spindle. C axis mode command was issued for synchronized tapping spindle. Polygon command was issued for synchronized tapping spindle. Spindle is being used as spindle/C axis.	<ul style="list-style-type: none"> • Cancel the C axis command. • Cancel the polygon machining command. • Cancel the C axis with servo OFF.

1. LIST OF ALARMS
1.1 Operation Alarm

Error No.	Details	Remedy
1030	<p>Synchronization mismatch Different M codes were commanded in the two systems as the synchronization M codes.</p> <p>Synchronization with the "!" code was commanded in another system during M code synchronization.</p> <p>Synchronization with the M code was commanded in another system during synchronization with the "!" code.</p>	<ul style="list-style-type: none"> • Correct the program so that the M codes match. • Correct the program so that the same synchronization codes are commanded.
1031	<p>The C axis selection signal was changed when multiple C axes could not be selected.</p> <p>An axis that cannot be controlled as the multiple C axes selection was selected.</p>	<ul style="list-style-type: none"> • Check and correct the parameters and program.
1032	<p>Tap return spindle selection illegal during multi-spindle Tap return was executed when a different spindle was selected. Cutting feed will wait until synchronization is completed.</p>	<ul style="list-style-type: none"> • Select the spindle for which tap cycle was halted before the tap return signal was turned ON.
1033	<p>Tool-spindle Synchronization IB (G51.2) cutting interlock Cutting feed will wait until synchronization is completed.</p>	<ul style="list-style-type: none"> • Wait for synchronization to end.
1034	<p>Cross machining command illegal Cross machining control exceeding the number of control axes was attempted.</p> <p>Cross machining control with duplicated axis addresses was attempted.</p>	<ul style="list-style-type: none"> • Check the parameter settings for cross machining control.
1035	<p>Cross machining control disable modal Cross machining control was commanded for a system in which cross machining control is disabled as shown below.</p> <ul style="list-style-type: none"> • During nose R compensation mode • During pole coordinate interpolation mode • During cylindrical interpolation mode • During balance cut mode • During fixed cycle machining mode • During facing turret mirror image 	<ul style="list-style-type: none"> • Check the program.

1. LIST OF ALARMS
1.1 Operation Alarm

Error No.	Details	Remedy
1036	<p>Synchronous control designation disable The synchronous control operation method selection (R435 register) was set when the mode was not the C axis mode.</p> <p>The synchronous control operation method selection (R435 register) was set in the zero point not set state.</p> <p>Mirror image disable state The external mirror image or parameter mirror image was commanded during facing turret mirror image.</p>	<ul style="list-style-type: none"> • Set the R435 register to 0. • Check the program and parameters.
1037	<p>Synchronous control was started or canceled when synchronous control could not be started or canceled.</p>	<ul style="list-style-type: none"> • Check the program and parameters.
1038	<p>A movement command was issued to a synchronous axis in synchronous control.</p>	<ul style="list-style-type: none"> • Check the program.
1106	<p>Spindle synchronous phase calculation illegal The spindle synchronization phase alignment command was issued while the spindle synchronization phase calculation request signal was ON.</p>	<ul style="list-style-type: none"> • Check the program. • Check the sequence program.

(The bold characters are the messages displayed on the screen.)

M90 PARAM SET MODE		M90 Messages output when the setup parameter lock function is enabled are displayed.
Error No.	Details	Remedy
—	<p>Setup parameter lock released The setup parameter lock is released. Automatic start is disabled when setup parameters can be set.</p>	<ul style="list-style-type: none"> • Refer to the manual issued by the machine manufacturer.

1. LIST OF ALARMS
1.2 Stop Codes

1.2 Stop Codes

These codes indicate a status that caused the controller to stop for some reason.
(The bold characters are the messages displayed on the screen.)

T01 CAN'T CYCLE ST		This indicates the state where automatic operation cannot be started when attempting to start it from the stop state.
Error No.	Details	Remedy
0101	AX IN MOTION (axis in motion) Automatic start is not possible as one of the axes is moving.	<ul style="list-style-type: none"> • Try automatic start again after all axes have stopped.
0102	READY OFF Automatic start is not possible as the NC is not ready.	<ul style="list-style-type: none"> • Another alarm has occurred. Check the details and remedy.
0103	RESET ON Automatic start is not possible as the reset signal has been input.	<ul style="list-style-type: none"> • Turn OFF the reset input signal. • Check that the reset switch is not ON constantly due to trouble. • Check the sequence program.
0104	A-OP STP SGL (Automatic operation stop signal "ON") The FEED HOLD switch on the machine operation panel is "ON" (valid).	<ul style="list-style-type: none"> • Check the FEED HOLD switch. • The feed hold switch is the B contact. • Check for broken wires in the feed hold signal wire. • Check the sequence program.
0105	H/W STRK END (H/W stroke end axis) Automatic start is not possible as one of the axes is at the stroke end.	<ul style="list-style-type: none"> • If one of the axis' ends is at the stroke end, move the axis manually. • Check for broken wire in the stroke end signal wire. • Check for trouble in the stroke end limit switch.
0106	S/W STRK END (S/W stroke end axis) Automatic start is not possible as one of the axes is at the stored stroke limit.	<ul style="list-style-type: none"> • Move the axis manually. • If an axis is not at the end, check the parameter details.
0107	NO OP MODE (NO operation mode) The operation mode has not been selected.	<ul style="list-style-type: none"> • Select the automatic operation mode. • Check for broken wires in the automatic operation mode (memory, tape, MDI) signal wire.

1. LIST OF ALARMS
1.2 Stop Codes

Error No.	Details	Remedy
0108	OP MODE DUPL (Operation mode duplicated) Two or more automatic operation modes are selected.	<ul style="list-style-type: none"> • Check for a short circuit in the mode selection signal wire (memory, tape, MDI). • Check for trouble in the switch. • Check the sequence program.
0109	OP MODE SHFT (Operation mode shift) The automatic operation mode changed to another automatic operation mode.	<ul style="list-style-type: none"> • Return to the original automatic operation mode, and start automatic start.
0110	Tape search execution Automatic start is not possible as tape search is being executed.	<ul style="list-style-type: none"> • Begin automatic start after the tape search is completed.
0112	Program restart position return incomplete Automatic start is not possible as the axis has not been returned to the restart position.	<ul style="list-style-type: none"> • Manually return to the restart position. • Turn the automatic restart valid parameter ON, and then execute automatic start.
0113	Thermal alarm Automatic start is not possible because a thermal alarm (Z53 TEMP. OVER) has occurred.	<ul style="list-style-type: none"> • The NC controller temperature has exceeded the specified temperature. • Take appropriate measures to cool the unit.
0115	In host communication Automatic start cannot be executed as the NC is communicating with the host computer.	<ul style="list-style-type: none"> • Execute automatic start after the communication with the host computer is completed.
0138	Disabled start during absolute position detection alarm A start signal was input during an absolute position detection alarm.	<ul style="list-style-type: none"> • Reset the absolute position detection alarm, and then input the start signal.
0139	Disabled start during zero point initialization A start signal was input while initializing the absolute position detector's zero point.	<ul style="list-style-type: none"> • Complete zero point initialization before inputting the start signal.
0190	Automatic start disabled Automatic start is disabled because setup parameters can be set.	<ul style="list-style-type: none"> • Refer to the manual issued by the machine manufacturer.
0191	Automatic start disabled Automatic start was caused during file deletion or writing.	<ul style="list-style-type: none"> • Cause automatic start after file deletion or writing is completed.

1. LIST OF ALARMS
1.2 Stop Codes

T02 FEED HOLD		The feed hold state been entered due to a condition in the automatic operation.
Error No.	Details	Remedy
0201	H/W STRK END (H/W stroke end axis) An axis is at the stroke end.	<ul style="list-style-type: none"> • Manually move the axis away from the stroke end limit switch. • The machining program must be corrected.
0202	S/W STRK END (S/W stroke end axis) An axis is at the stored stroke limit.	<ul style="list-style-type: none"> • Manually move the axis. • The machining program must be corrected.
0203	RESET SIGNAL ON (Reset signal on) The reset signal has been input.	<ul style="list-style-type: none"> • The program execution position has returned to the start of the program. Execute automatic operation from the start of the machining program.
0204	AUTO OP STOP (Automatic operation stop) The FEED HOLD switch is "ON".	<ul style="list-style-type: none"> • Resume automatic operation by pressing the "CYCLE START" switch.
0205	AUTO MD CHING (Automatic mode change) The operation mode changed to another mode during automatic operation.	<ul style="list-style-type: none"> • Return to the original automatic operation mode, and resume automatic operation by pressing the "CYCLE START" switch.
0206	Acceleration and deceleration time constants too large The acceleration and deceleration time constants are too large. (This problem occurs at the same time as system alarm Z59.)	<ul style="list-style-type: none"> • Increase the set value of the parameter "#1206 G1bF". • Decrease the set value of the parameter "#1207 G1btL". • Lower the cutting speed.
0215	Absolute position detection alarm stop An absolute position detection alarm occurred.	<ul style="list-style-type: none"> • Reset the absolute position detection alarm.

1. LIST OF ALARMS
1.2 Stop Codes

T03 BLOCK STOP		This indicates that automatic operation stopped after executing one block of the program.
Error No.	Details	Remedy
0301	SNGL BLK ON (Single block on) The SINGLE BLOCK switch on the machine operation panel is ON. The single block or machine lock switch changed.	<ul style="list-style-type: none"> Automatic operation can be resumed by turning the CYCLE START switch ON.
0302	User macro stop The block stop command was issued in the user macro program.	<ul style="list-style-type: none"> Automatic operation can be resumed by turning the CYCLE START switch ON.
0303	Mode change The automatic mode changed to another automatic mode.	<ul style="list-style-type: none"> Return to the original automatic operation mode, and resume automatic operation by turning the CYCLE START switch ON.
0304	MDI completion The last block of MDI was completed.	<ul style="list-style-type: none"> Set MDI again, and turn the CYCLE START switch ON to resume MDI operation.
0305	Block start interlock The interlock signal that locks the block start is entered.	<ul style="list-style-type: none"> Check the sequence program.
0306	Block cutting start interlock The interlock signal that locks the block cutting start is entered.	<ul style="list-style-type: none"> Check the sequence program.
0310	Offset change of inclined Z-axis during program operation Whether to validate the offset of the inclined Z-axis switched during program operation.	<ul style="list-style-type: none"> Automatic operation can be restarted by turning ON the cycle start switch.

T04 COLLATION STOP		Collation stop was applied during automatic operation.
Error No.	Details	Remedy
0401	Collation stop occurred.	<ul style="list-style-type: none"> Automatic operation can be restarted with automatic start.


1. LIST OF ALARMS
1.2 Stop Codes

T10 FIN WAIT	This indicates the operation state when an alarm did not occur during automatic operation, and nothing seems to have happened.																																																																																																																																																							
Error No.	Details																																																																																																																																																							
<p>0□□□</p> <p>The error number is displayed while each of the completion wait modes listed in the table below is ON. It disappears when the mode is canceled.</p> <div style="text-align: center;"> </div> <table border="1" data-bbox="383 739 622 1064"> <thead> <tr> <th>Alarm No.</th> <th>Unclamp signal wait <small>Note 2)</small></th> <th>In dwell execution</th> </tr> </thead> <tbody> <tr><td>0</td><td></td><td></td></tr> <tr><td>1</td><td></td><td>×</td></tr> <tr><td>8</td><td>×</td><td></td></tr> <tr><td>9</td><td>×</td><td>×</td></tr> </tbody> </table> <table border="1" data-bbox="694 739 1324 1646"> <thead> <tr> <th>Alarm No.</th> <th>Door open <small>Note 1)</small></th> <th>Waiting for spindle position to be looped</th> <th>Alarm No.</th> <th>Waiting for spindle orientation to complete</th> <th>Waiting for cutting speed deceleration</th> <th>Waiting for rapid traverse deceleration</th> <th>Waiting for MSTB completion</th> </tr> </thead> <tbody> <tr><td>0</td><td></td><td></td><td>0</td><td></td><td></td><td></td><td></td></tr> <tr><td>1</td><td></td><td>×</td><td>1</td><td></td><td></td><td></td><td>×</td></tr> <tr><td>8</td><td>×</td><td></td><td>2</td><td></td><td></td><td>×</td><td></td></tr> <tr><td>9</td><td>×</td><td>×</td><td>3</td><td></td><td></td><td>×</td><td>×</td></tr> <tr><td></td><td></td><td></td><td>4</td><td></td><td>×</td><td></td><td></td></tr> <tr><td></td><td></td><td></td><td>5</td><td></td><td>×</td><td></td><td>×</td></tr> <tr><td></td><td></td><td></td><td>6</td><td></td><td>×</td><td>×</td><td></td></tr> <tr><td></td><td></td><td></td><td>7</td><td></td><td>×</td><td>×</td><td>×</td></tr> <tr><td></td><td></td><td></td><td>8</td><td>×</td><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td><td>9</td><td>×</td><td></td><td></td><td>×</td></tr> <tr><td></td><td></td><td></td><td>A</td><td>×</td><td></td><td>×</td><td></td></tr> <tr><td></td><td></td><td></td><td>B</td><td>×</td><td></td><td>×</td><td>×</td></tr> <tr><td></td><td></td><td></td><td>C</td><td>×</td><td>×</td><td></td><td></td></tr> <tr><td></td><td></td><td></td><td>D</td><td>×</td><td>×</td><td></td><td>×</td></tr> <tr><td></td><td></td><td></td><td>E</td><td>×</td><td>×</td><td>×</td><td></td></tr> <tr><td></td><td></td><td></td><td>F</td><td>×</td><td>×</td><td>×</td><td>×</td></tr> </tbody> </table>	Alarm No.	Unclamp signal wait <small>Note 2)</small>	In dwell execution	0			1		×	8	×		9	×	×	Alarm No.	Door open <small>Note 1)</small>	Waiting for spindle position to be looped	Alarm No.	Waiting for spindle orientation to complete	Waiting for cutting speed deceleration	Waiting for rapid traverse deceleration	Waiting for MSTB completion	0			0					1		×	1				×	8	×		2			×		9	×	×	3			×	×				4		×						5		×		×				6		×	×					7		×	×	×				8	×							9	×			×				A	×		×					B	×		×	×				C	×	×						D	×	×		×				E	×	×	×					F	×	×	×	×	<p>Note 1: This mode is enabled by the door interlock function.</p> <p>Note 2: The system is waiting for the index table indexing unclamp signal to turn ON or OFF</p>
Alarm No.	Unclamp signal wait <small>Note 2)</small>	In dwell execution																																																																																																																																																						
0																																																																																																																																																								
1		×																																																																																																																																																						
8	×																																																																																																																																																							
9	×	×																																																																																																																																																						
Alarm No.	Door open <small>Note 1)</small>	Waiting for spindle position to be looped	Alarm No.	Waiting for spindle orientation to complete	Waiting for cutting speed deceleration	Waiting for rapid traverse deceleration	Waiting for MSTB completion																																																																																																																																																	
0			0																																																																																																																																																					
1		×	1				×																																																																																																																																																	
8	×		2			×																																																																																																																																																		
9	×	×	3			×	×																																																																																																																																																	
			4		×																																																																																																																																																			
			5		×		×																																																																																																																																																	
			6		×	×																																																																																																																																																		
			7		×	×	×																																																																																																																																																	
			8	×																																																																																																																																																				
			9	×			×																																																																																																																																																	
			A	×		×																																																																																																																																																		
			B	×		×	×																																																																																																																																																	
			C	×	×																																																																																																																																																			
			D	×	×		×																																																																																																																																																	
			E	×	×	×																																																																																																																																																		
			F	×	×	×	×																																																																																																																																																	

1. LIST OF ALARMS
1.3 Servo Alarms

1.3 Servo/Spindle Alarms

This section describes alarms occurred by the errors in the servo system such as the drive unit, motor and encoder, etc. The alarm message, alarm No. and axis name will display on the alarm message screen. The axis where the alarm occurred and the alarm No. will also display on the servo monitor screen and the spindle monitor screen respectively. If several alarms have occurred, up to two errors per axis will display on the servo monitor screen and the spindle monitor screen respectively.
(The bold characters are the messages displayed on the screen.)



(Note 1) The alarm class and alarm reset class combinations are preset.
(Refer to the separate table for S02, S51 and S52.)

Alarm class	Alarm reset class	Resetting methods
S01	PR	After removing the cause of the alarm, reset the alarm by turning the NC power ON again.
S03	NR	After removing the cause of the alarm, reset the alarm by inputting the NC RESET key.
S04	AR	After removing the cause of the alarm, reset the alarm by turning the drive unit power ON again.

(Note 2) The resetting method may change according to the alarm class.
For example, even if "S03 SERVO ALARM: NR" is displayed, it may be necessary to turn the NC power ON again.

Alarm No.	Name	Meaning
10	Insufficient voltage	Insufficient PN bus voltage was detected in main circuit.
11	Axis selection error	Setting of the axis No. selection switch is incorrect.
12	Memory error 1	A CPU error or an internal memory error was detected during the power ON self-check.
13	Software processing error 1	Software processing has not finished within the specified time.
14	Software processing error 2	Software processing has not finished within the specified time.
15	Memory error 2	A CPU error or an internal memory error was detected during the power ON self-check.
16	Magnetic pole position detection error	Initial magnetic pole for motor control has not been formed yet.
17	A/D converter error	An error was detected in the A/D converter for detecting current FB.
18	Motor side detector: Initial communication error	Initial communication with the motor end detector failed.
19	Detector communication error in synchronous control	Initial communication with the motor end detector on master axis failed when setting closed-loop current synchronous control. Or the communication was interrupted.

1. LIST OF ALARMS

1.3 Servo Alarms

Alarm No.	Name	Meaning
1A	Machine side detector: Initial communication error	Initial communication with the linear scale or the ball screw end detector failed.
1B	Machine side detector: CPU error 1	CPU initial error was detected in the linear scale or in the ball screw end detector.
1C	Machine side detector: EEPROM/LED error	An error was detected in the stored data of the linear scale memory. Or the LED deterioration was detected in the ball screw end detector.
1D	Machine side detector: Data error	An error data was detected in the linear scale or in the ball screw end detector.
1E	Machine side detector: Memory error	An internal memory error was detected in the linear scale.
1F	Machine side detector: Communication error	An error was detected in communication data with the linear scale or the ball screw end detector. Or the communication was interrupted.
20	Motor side detector: No signal	No signals were detected in A,B,Z-phase or U,V,W-phase of the pulse motor end detector in a servo system, or in Z-phase of PLG in a spindle system.
21	Machine side detector: No signal	No signals were detected in A,B,Z-phase of the pulse linear scale or the ball screw end detector in a servo system. Or no encoder signals were detected in a spindle system.
22	LSI error	LSI operation error was detected in the drive unit.
23	Excessive speed error 1	A difference between the speed command and speed feedback was continuously exceeding 50 r/min for longer than the setting time.
24	Grounding	The motor power cable is in contact with FG (Frame Ground).
25	Absolute position data lost	The absolute position was lost, as the backup battery voltage dropped in the absolute position detector.
26	Unused axis error	A power module error occurred in the axis whose axis No. selection switch was set to "F"(free axis).
27	Machine side detector: CPU error 2	A CPU error was detected in the linear scale.
28	Machine side detector: Overspeed	The specified max. speed was detected in the linear scale.
29	Machine side detector: Absolute position data error	An error was detected in the absolute position detection circuit of the linear scale.
2A	Machine side detector: Relative position data error	An error was detected in the relative position detection circuit of the linear scale.
2B	Motor side detector: CPU error 1	A CPU initial error was detected in the motor end detector or in the linear scale of a linear servo system.
2C	Motor side detector: EEPROM/LED error	The LED deterioration was detected in the motor end detector. Or an error was detected in the stored data of the linear scale memory of a linear servo system.

1. LIST OF ALARMS

1.3 Servo Alarms

Alarm No.	Name	Meaning
2D	Motor side detector: Data error	A data error was detected in the motor end detector or in the linear scale of a linear servo system.
2E	Motor side detector: Memory error	An internal memory error was detected in the linear scale of a linear servo system.
2F	Motor side detector: Communication error	An error was detected in communication data with the motor end detector or with the linear scale of a linear servo system. Or the communication was interrupted.
30	Over regeneration	Over-regeneration detection level became over 100%. The regenerative resistor is overloaded.
31	Overspeed	The motor was detected to rotate at a speed exceeding the allowable speed.
32	Power module overcurrent	Overcurrent protection function in the power module has started its operation.
33	Overvoltage	PN bus voltage in main circuit exceeded the allowable value.
34	NC-DRV communication: CRC error	An error was detected in the data received from the CNC.
35	NC command error	The travel command data that was received from the CNC was excessive.
36	NC-DRV communication: Communication error	The communication with the CNC was interrupted.
37	Initial parameter error	An incorrect parameter was detected among the parameters received from the CNC at the power ON.
38	NC-DRV communication: Protocol error 1	An error was detected in the communication frames received from the CNC.
39	NC-DRV communication: Protocol error 2	An error was detected in the axis information data received from the CNC.
3A	Overcurrent	Excessive current was detected in the motor drive current.
3B	Power module overheat	Thermal protection function in the power module has started its operation.
3C	Regeneration circuit error	An error was detected in the regenerative transistor or in the regenerative resistor.
3D	Spindle speed blocked	The spindle motor failed to rotate faster than 45 r/min, even when the max. torque command was given.
3E	Spindle speed overrun	1. The spindle motor speed feedback was detected to be accelerated exceeding the commanded speed. 2. The spindle motor was detected to be rotated at a speed exceeding the parameter value, while the speed command was "0" (including the case of operation stoppage during the position control).
3F	Excessive speed error 2	A difference between the speed command and speed feedback was detected to exceed the setting amount or setting time in a constant speed operation.

1. LIST OF ALARMS

1.3 Servo Alarms

Alarm No.	Name	Meaning
40	Detector selection unit switching error	An error was detected in the motor switching signals that were received from the detector selection unit, while controlling one drive unit and two motors.
41	Detector selection unit communication error	An error was detected in the communication with the detector selection unit, while controlling one drive unit and two motors.
42	Feedback error 1	An error was detected in the feedback signals of the pulse motor end detector in a servo system, or in PLG's feedback signals in a spindle system.
43	Feedback error 2	Excessive difference was detected in position data between the motor end detector and the machine end detector in a servo system. In a spindle system, an error was detected in the encoder feedback signals.
44	Inappropriate coil selected for C axis	When using a coil changeover motor, C-axis was controlled while the high-speed coil was selected.
45	Fan stop	A cooling fan built in the drive unit stopped, and the loads on the unit exceeded the specified value.
46	Motor overheat	Thermal protection function of the motor or in the detector, has started its operation.
47	Regenerative resistor overheat	Thermal protection function of the regenerative resistor, has started its operation.
48	Motor side detector: CPU error 2	A CPU error was detected in the linear scale of a linear servo system.
49	Motor side detector: Overspeed	The specified max. speed was detected in the linear scale of the linear servo system.
4A	Motor side detector: Absolute position data error	An error was detected in the absolute position detection circuit in the linear scale of a linear servo system.
4B	Motor side detector: Relative position data error	An error was detected in the relative position detection circuit in the linear scale of a linear servo system.
4C	Current error at magnetic pole detection	A current error was detected in the IPM spindle motor when the initial magnetic pole was being formed.
4E	NC command mode error	The mode outside the specification was input in spindle control mode selection.
4F	Instantaneous power interruption	The power was momentarily interrupted.
50	Overload 1	Overload detection level became over 100%. The motor or the drive unit is overloaded.
51	Overload 2	Current command of more than 95% of the unit's max. current was being continuously given for longer than 1 second in a servo system. In a spindle system, the load over the continuous rating was being applied for longer than 30 minutes.
52	Excessive error 1	A difference between the actual and theoretical motor positions during servo ON exceeded the setting value in a servo system. In a spindle system, a difference between the position command and position feedback exceeded the setting value.

1. LIST OF ALARMS
1.3 Servo Alarms

Alarm No.	Name	Meaning
53	Excessive error 2	A difference between the actual and theoretical motor positions during servo OFF exceeded the setting value.
54	Excessive error 3	When an excessive error 1 occurred, detection of the motor current failed.
55	External emergency stop error	There is no contactor shutoff command, even after 30 seconds has passed since the external emergency stop was input.
57	Option error	An invalid option function was selected.
58	Collision detection 1: G0	When collision detection function was valid, the disturbance torque in rapid traverse (G0) exceeded the collision detection level.
59	Collision detection 1: G1	When collision detection function was valid, the disturbance torque in cutting feed (G1) exceeded the collision detection level.
5A	Collision detection 2	When collision detection function was valid, the command torque reached the max. motor torque.
5C	Orientation feedback error	After orientation was achieved, a difference between the command and feedback exceeded the parameter setting.
5D	Speed monitoring: Input mismatch	As for door state signal of speed monitoring control, a mismatch between the external input signal and the control signal received from the CNC was detected.
5E	Speed monitoring: Feedback speed error	In speed monitoring control, the spindle speed was exceeding the setting speed with the door open.
5F	External contactor error	A contact of the external contactor is welding. Or the contactor fails to be ON during ready ON.
61	Power module overcurrent	Overcurrent protection function in the power module has started its operation.
62	Frequency error	The input power supply frequency increased above the specification range.
63	Supplementary regeneration error	The supplementary regenerative transistor is being ON.
65	Rush relay error	A resistor relay for rush short circuit fails to be ON.
67	Phase interruption	An open-phase condition was detected in input power supply circuit.
68	Watchdog	The system does not operate correctly.
69	Grounding	The motor power cable is in contact with FG (Frame Ground).
6A	External contactor welding	A contact of the external contactor is welding.
6B	Rush relay welding	A resistor relay for rush short circuit fails to be OFF.
6C	Main circuit error	An error was detected in charging operation of the main circuit capacitor.
6D	Parameter error	The capacity of the power supply unit and the regenerative resistor type that was set in the parameter are mismatched.
6E	Memory error	An internal memory error was detected.
6F	Power supply error	A power supply unit is not connected. Or an error was detected in A/D converter of the power supply unit.
71	Instantaneous power interruption	The power was momentarily interrupted.

1. LIST OF ALARMS

1.3 Servo Alarms

Alarm No.	Name	Meaning
73	Over regeneration	Over-regeneration detection level became over 100%. The regenerative resistor is overloaded.
74	Regenerative resistor overheat	Thermal protection function of the regenerative resistor, has started its operation.
75	Overvoltage	PN bus voltage in main circuit exceeded the allowable value.
76	External emergency stop setting error	As for the external emergency stop settings, the setting on the rotary switch and the parameter setting are mismatched.
77	Power module overheat	Thermal protection function in the power module has started its operation.
7F	Drive unit power supply restart request	A mismatch of program mode selection was detected. Turn the drive unit power ON again.
80	Detector converting unit 1: Connection error	A connection error was detected between the analog output linear scale and the unit MDS-B-HR that is used in a linear servo system.
81	Detector converting unit 1: Communication error	A communication error was detected between the serial output linear scale and the unit MDS-B-HR that is used in a linear servo system.
83	Detector converting unit 1: Judgment error	Judgment of the linear scale analog frequency failed in the unit MDS-B-HR that is used in a linear servo system.
84	Detector converting unit 1: CPU error	A CPU error was detected in the unit MDS-B-HR that is used in a linear servo system.
85	Detector converting unit 1: Data error	A data error was detected in the unit MDS-B-HR that is used in a linear servo system.
86	Detector converting unit 1: Magnetic pole error	An error was detected in the magnetic pole of the unit MDS-B-HR that is used in a linear servo system.
88	Watchdog	The system does not operate correctly.
89	Detector converting unit 2: Connection error	A connection error was detected between the analog output linear scale and the unit MDS-B-HR in a servo system. In a spindle system, the initial communication with MDS-B-PJEX failed.
8A	Detector converting unit 2: Communication error	An error was detected in the communication with the serial output linear scale of the unit MDS-B-HR in a servo system. In a spindle system, an error was detected in the communication with MDS-B-PJEX.
8B	Detector converting unit 2: Automatic tuning error	An abnormal signal was detected from PLG in automatic PLG tuning.
8C	Detector converting unit 2: Judgment error	The detector type outside the specification was designated in MDS-B-PJEX.
8D	Detector converting unit 2: CPU error	A CPU error was detected in the unit MDS-B-HR in a servo system, or in the unit MDS-B-PJEX in a spindle system.
8E	Detector converting unit 2: Data error	A data error was detected in the unit MDS-B-HR.

1. LIST OF ALARMS

1.3 Servo Alarms

Alarm No.	Details	Remedy
S02 INIT PARAM ERR <u>AAAA</u> □	<p>Axis name — Servo : Axis name Spindle : "S", "T"</p> <p>Alarm No. (parameter No.)</p>	
<p>An error was found in the parameters transmitted from the controller to the drive unit when the power was turned ON. Remove the cause of the alarm, and then reset the alarm by turning the controller power OFF once.</p>		
2201 - 2265	The servo parameter setting data is illegal. The alarm No. is the No. of the servo parameter where the error occurred.	Check the descriptions for the appropriate parameters and correct them.
2269	The CNC setting maximum rapid traverse rate value is incorrect.	Check the setting of related parameter "#2001 rapid" and turn the power ON again.
2271	The CNC setting maximum cutting speed setting value is incorrect.	Check the setting of related parameter "#2002 clamp" and turn the power ON again.
2281 - 2300	The servo parameter setting data is illegal. The alarm No. is the No. of the servo parameter where the error occurred.	Check the descriptions for the appropriate parameters and correct them.
2301	The number of constants to be used in the following functions is too large: <ul style="list-style-type: none"> • Electronic gears • Position loop gain • Speed feedback conversion 	Check that all the related parameters are specified correctly. sv001:PC1, sv002:PC2, sv003:PGN1 sv018:PIT, sv019:RNG1, sv020:RNG2
2302	Parameters for absolute position detection are set to ON while other than an absolute position detector is connected. Set the parameters for absolute position detection to OFF. To detect an absolute position, replace the incremental specification detector with an absolute position detector.	Check that all the related parameters are specified correctly. sv017:SPEC, sv025:MTYP
2303	No servo option is found. The closed loop (including the ball screw-side detector) or dual feedback control function is an option.	Check that all the related parameters are specified correctly. sv025:MTYP/pen sv017:SPEC/dfbx
2304	No servo option is found. The SHG control function is an option.	Check that all the related parameters are specified correctly. sv057:SHGC sv058:SHGCsp
2305	No servo option is found. The adaptive filtering function is an option.	Check that all the related parameters are specified correctly. sv027:SSF1/aflt
2306	The servo option is not available. The MP scale absolute position function is an option.	Check that the related parameter is specified correctly. s017:SPEC
2308	The valid/invalid setting of the 4th or 5th notch filter is changed from the initial setting.	Check the following parameter setting status. s087:FHz4 s088:FHz5
3201 – 3584	Parameter error A parameter value not within the tolerable range was set. The alarm No. is the No. of the spindle parameter where the error occurred.	Confirm the spindle parameter for the No. displayed as an error.

1. LIST OF ALARMS
1.3 Servo Alarms

S51 PARAMETER ERROR		
<p>Warning appears if a parameter set outside the tolerable range is set. Illegal settings will be ignored. This alarm will be reset when the correct value is set.</p>		
Alarm No.	Details	Remedy
2201 – 2300	Servo parameter setting data is illegal. The alarm No. is the No. of the servo parameter where the warning occurred.	Check the descriptions for the appropriate parameters and correct them.
3201 – 3584	Parameter warning A parameter value not within the tolerable range was set. The alarm No. is the No. of the spindle where the warning occurred.	Confirm the details of the spindle parameter for which the No. is displayed.

S52 SERVO WARNING		
<p>The drive unit warning is displayed.</p>		
Alarm No.	Name	Meaning
90	Detector: Initial communication error	Initial communication with the absolute position linear scale failed.
91	Detector: Communication error	An error was detected in the communication with the detector in absolute position detection system.
92	Detector: Protocol error	A data error was detected in absolute position detection system.
93	Initial absolute position fluctuation	The position data have fluctuated during the absolute position initializing.
96	Scale feedback error	An excessive deviation was detected between the motor side detector and MP scale feedback data in a MP scale absolute position detection system.
97	Scale offset error	An error was detected in the offset data received from the MP scale in a MP scale absolute position detection system.
9B	Detector converting unit: Magnetic pole shift warning	An error was detected in the shift distance of the magnetic pole in a linear servo system.

1. LIST OF ALARMS
1.3 Servo Alarms

Alarm No.	Name	Meaning
9C	Detector converting unit: Magnetic pole warning	A data error was detected in the magnetic pole of MDS-B-HR after passing Z-phase in a linear servo system.
9E	Absolute position detector: Revolution counter error	An error was detected in the revolution counter of the absolute position detector. The absolute position data cannot be compensated.
9F	Battery voltage drop	The battery voltage that is supplied to the absolute position detector dropped. The absolute position data is retained.
A6	Fan stop warning	A cooling fan built in the drive unit stopped.
A8	Turret indexing warning	The designated position shift amount of turret indexing is outside the setting range.
A9	Orientation feedback warning	As an orientation feedback error occurred, the retrial has been conducted.
E0	Over regeneration warning	Over-regeneration detection level exceeded 80%.
E1	Overload warning	Overload detection level exceeded 80%.
E2	Continuous high-speed revolution warning	The motor was continuously rotated at a speed exceeding the rated speed.
E3	Absolute position counter warning	Deviation between the absolute and relative position data was detected.
E4	Set parameter warning	A parameter setting was outside the setting range.
E6	Control axis detachment warning	Control axis detachment was commanded.
E7	In NC emergency stop state	Emergency stop was input from the CNC.
E8	Excessive supplementary regeneration frequency	Regeneration that are beyond the power supply limitation has frequently occurred.
E9	Instantaneous power interruption warning	The power was momentarily interrupted.
EA	In external emergency stop state	External emergency stop signal was input.
EB	Over regeneration warning	Over-regeneration detection level exceeded 80%.

1. LIST OF ALARMS
1.4 MCP Alarm

1.4 MCP Alarm

An error has occurred in the drive unit and other interfaces. (The bold characters are the messages displayed on the screen.)

Y02 SYSTEM ALARM		An error occurred in the data transmitted between the MCP and drive unit after the power was turned ON.	
Error No.	Details		Remedy
0050	Background error		The software or hardware may be damaged. Contact the service center.
0051	0000	CRC error (10 times/910.2 ms)	<p>A communication error has occurred between the controller and drive unit.</p> <ul style="list-style-type: none"> • Take measures against noise. • Check that the communication cable connector between the controller and drive unit and one between the drive units are tight. • Check whether the communication cable between the controller and drive unit and one between the drive units are disconnected. • A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and report to the Service Center.
	0001	CRC error (2 continuous times)	
	0002	Reception timing error (2 continuous times)	
	xx03	Data ID error (2 continuous times) xx: Axis No.	
xx04	No. of reception frames error (2 continuous times) xx: Axis No.		

Y03 AMP. UNEQUIPPED		Check the drive unit mounting state.	
The drive unit is not correctly connected		<ul style="list-style-type: none"> • Check the end of the cable wiring. • Check the cable for broken wires. • Check the connector insertion. • The drive unit input power is not being input. • The drive unit axis No. switch is illegal. 	
Error No.	Details		
Alphabet (axis name)	Servo axis drive unit not mounted		
1 – 2	PLC axis drive unit not mounted		
S	No.1 spindle axis drive unit not mounted		
T	No.2 spindle axis drive unit not mounted		

Y05 INIT PARAM ERR		<p style="text-align: center;">□□□□ ↑ □□□□ : Error parameter number</p>	
Details		Remedy	
There is a problem in the value set for the number of axes or the number of systems.		<p>Check the value set for the corresponding parameters.</p> <p>#1001 SYS_ON #1002 axisno #1039 spinno etc.</p>	

1. LIST OF ALARMS
1.4 MCP Alarm


Y06 mcp_no ERROR		There are differences in the MCP and axis parameters when the NC power is turned ON.
Error No.	Details	Remedy
0001	There is a skipped number in the channels.	Check the values set for the following parameters. #1021 mcp_no #3031 smcp_no #3032 mbmcp_no
0002	The random layout setting is duplicated.	
0003	The drive unit fixed setting "0000" and random layout setting "****" are both set.	
0004	The spindle/C axis "#3031 mcp_no" and "#3032 smcp_no" are set to the same values.	
0005	An arbitrary layout is set when "#1154 pddor" = 1 in 2-part system.	
0006	The channel No. parameter is not within the setting range.	

Y51 PARAMETER ERROR		An error occurred in a parameter that causes an alarm while the control axis was operating.
Error No.	Details	Remedy
1	LN FEED ABNL (Linear feed abnormal) The time constant has not been set or the setting exceeded the setting range.	• Check "#2004 G0tL".
2	CT FEED ABNL (Cutting feed abnormal) The time constant has not been set or the setting exceeded the setting range.	• Check "#2007 G1tL".
3	DLY F-F ABNL (Delayed fast feed abnormal) The time constant has not been set or the setting exceeded the setting range.	• Check "#2005 G0t1".
4	DLY CUTG ABNL (Delayed cutting feed abnormal) The time constant has not been set or the setting exceeded the setting range.	• Check "#2008 G1t1".
9	GRID SPACE ERROR	• Check "#2029 grspc".
12	SYNCHRONOUS TAP CYCLE ACCELERATION/DECELERATION TIME CONSTANT ERROR The time constant has not been set or the setting exceeded the setting range.	• Check spindle parameters #3017 stapt1 to #3020 stapt4.
15	LN SKIP ABNL (Linear skip abnormal) The time constant has not been set or the setting exceeded the setting range.	• Check "#2102 skip_tL".
16	DLY SKIP ABNL (Delayed skip abnormal) The time constant has not been set or the setting exceeded the setting range.	• Check "#2103 skip_t1".
17	"#1205 G0bdcc" for the 2nd system is set to acceleration/deceleration before G0 interpolation.	• Check "#1205 G0bdcc".
101	ROTARY AXIS GEAR RATIO EXCESSIVE (ABSOLUTE POSITION DETECTION)	• Check "#2201 PC1" and "#2202 PC2".

1. LIST OF ALARMS
1.4 MCP Alarm

Y90 SP. NON SIGNAL

(Alarm No.)



Alarm No.	Z open phase	B open phase	A open phase
1			×
2		×	
3		×	×
4	×		
5	×		×
6	×	×	
7	×	×	×

Alarm No.	Details	Remedy
0001 – 0007	There is an error in the spindle encoder signal. The data transmission to the drive unit is stopped when this error occurs.	<ul style="list-style-type: none"> Check the spindle encoder's feedback cable and the encoder.

1. LIST OF ALARMS
1.5 System Alarms

1.5 System Alarms

The following messages are displayed with the register at the time when the error occurred if the system stops due to a system error.

Message	Details	Remedy
Parity error	RAM error	<ul style="list-style-type: none"> Write down the displayed register, and contact the service center.
Bus error	A non-existing memory was accessed.	
Zero divide	The division with a 0 denominator was attempted.	
Watch dog error	The software process is not functioning correctly.	
Illegal exception	The alarm was caused by an illegal software function not listed above.	
Address error	An illegal memory was accessed.	
Illegal instruction	The software process is not functioning correctly.	
Stack overflow		

Z31 DATA SERVER ERROR □□□□	
↑ Warning No.	
Warning No.	Explanation
0001	Socket open error (socket)
0002	Socket bind error (bind)
0003	Connection wait queue error (listen)
0004	Connection request acceptance error (accept)
0005	Data receive error (socket error)
0006	Data receive error (data shortage or disconnection)
0007	Data receive error (socket error)
0008	Data receive error (data shortage or disconnection)
000A	Socket close error (close)

Note: If warning No. 0001, 0002, 0003, or 000A is displayed, set the parameters, then turn power OFF and turn it ON again.

Message	Details	Remedy
Z40 FORMAT NOT MET	This appears when the parameter MemVal is formatted at 0, and MemVal is set to 1.	<ul style="list-style-type: none"> Either return the MemVal setting, or format and restart.

1. LIST OF ALARMS
1.5 System Alarms

The bold characters are the messages displayed on the screen.

Message	Details	Remedy
Z51 EE ROM ERROR 000x	<p>This occurs when the parameters were not correctly written into the EEROM.</p> <p>Formatting of the machine manufacturer macro program area did not end correctly.</p> <p>The machine manufacturer macro program was not written into the FROM correctly.</p> <p><Type> Z51 ROM error 0001: Open error Z51 ROM error 0002: Erase error Z51 ROM error 0003: Write error Z51 ROM error 0004: Verify error</p>	<ul style="list-style-type: none"> • If the same alarm is output by the same operation, the cause is an H/W fault. Contact the Service Center. • Reformat the area. • Write to the FROM again.
Z52 BATTERY FAULT	The voltage of the battery inserted in the NC control unit has dropped. (The battery used to save the internal data)	<ul style="list-style-type: none"> • Replace the battery of the NC control unit. • After treating the battery, check the machining program.
Z53 TEMP. OVER	The controller or operation board temperature has risen above the designated value. (Note 1)	<ul style="list-style-type: none"> • Cooling measures are required. Turn OFF the controller power, or lower the temperature with a cooler, etc.
Z55 RIO NOT CONNECT	<p>This occurs when an error occurs in the communication between the controller and remote I/O unit.</p> <ul style="list-style-type: none"> • Cable breakage • Remote I/O unit fault • Power supply to remote I/O unit fault <p>(Note 2)</p>	<ul style="list-style-type: none"> • Check and replace the cables. • Replace the remote I/O unit. • Check the power supply. (existence of supply, voltage)
Z57 SYSTEM WARNING	The program memory capacity setting value cannot be formatted.	<p>Check the state of the following items.</p> <ul style="list-style-type: none"> • Program memory capacity
Z58 ROM WR UNFIN	The machine manufacturer macro program was not written to the FROM after being registered, edited, copied, condensed, merged, the number changed, or deleted.	<ul style="list-style-type: none"> • Write the machine manufacturer macro program to the FROM. * If the operations, such as editing, done while the NC power was OFF can be invalidated, or if no specification for FROM writing is available, the program does not need to be written to the FROM.

1. LIST OF ALARMS
1.5 System Alarms

Message	Details	Remedy
Z59 TIME CONSTANT	Acceleration and deceleration time constants are too large. (This alarm is output at the same time as "T02 FEED HOLD 0206.")	<ul style="list-style-type: none"> • Increase the value specified as the #1206 G1bF parameter. • Decrease the value specified as the #1207 G1btL parameter. • Lower the feedrate.

⚠ CAUTION

❗ If the battery low warning is issued, save the machining programs, tool data and parameters in an input/output device, and then replace the battery. When the battery alarm is issued, the machining programs, tool data and parameters may be destroyed. Reload the data after replacing the battery.


- ⚠ Do not replace the battery while the power is ON.
- ⚠ Do not short circuit, charge, heat, incinerate or disassemble the battery.
- ⚠ Dispose of the spent battery following local laws.

Note 1: Temperature warning

If the alarm is displayed when an overheat alarm is detected, the overheat signal will be output simultaneously. If the machine is in automatic operation, the operation will be continued, but restarting will not be possible after resetting or stopping with M02/M30. (Starting will be possible after block stop or feed hold.) The alarm will be reset and the overheat signal will turn OFF when the temperature drops below the specified temperature.

Z53 TEMP. OVER	000x ↑ 0001 : The temperature in the controller is high. 0002 : The temperature around the communication terminal (setting and display unit) is high. 0003 : The temperature in the controller and around the communication terminal (setting and display unit) is high.
----------------	--


The ambient temperature must be lowered immediately when a "Z53 TEMP.OVER" alarm occurs, but if machining must be continued, the alarm can be invalidated by turning the following parameter OFF.



1. LIST OF ALARMS
1.5 System Alarms

Note 2: RIO communication interrupt

If communication between the control unit and remote I/O unit fails, the alarm and remote I/O unit number are displayed.



(a) and (b) above indicate the following matters.

Alarm number	RIO (seventh station)	RIO (sixth station)	RIO (fifth station)	RIO (fourth station)
0				
1				X
2			X	
3			X	X
4		X		
5		X		X
6		X	X	
7		X	X	X
8	X			
9	X			X
A	X		X	
B	X		X	X
C	X	X		
D	X	X		X
E	X	X	X	
F	X	X	X	X

Alarm number	RIO (third station)	RIO (second station)	RIO (first station)	RIO (0th station)
0				
1				X
2			X	
3			X	X
4		X		
5		X		X
6		X	X	
7		X	X	X
8	X			
9	X			X
A	X		X	
B	X		X	X
C	X	X		
D	X	X		X
E	X	X	X	
F	X	X	X	X

This applies for both the remote I/O 1st system communication interrupted station and board connection remote I/O communication interrupted station.

1. LIST OF ALARMS
1.6 Absolute Position Detection System Alarms

1.6 Absolute Position Detection System Alarms

Z70 ABS. ILLEGAL □□□□ □□□□ (Error No.) (Axis name)		This error is displayed if the absolute position data is lost in the absolute position detection system.			
Error No.	Details	Remedy	Zero point initialization	Alarm reset when power is turned OFF	Servo alarm No.
0001	Zero point initialization is incomplete. Otherwise, the spindle was removed.	Complete zero point initialization.	Required	—	—
0002	The absolute position reference point data saved in the NC has been destroyed.	Input the parameters. If the reference point data cannot be restored, perform zero point initialization.	(Required)	—	—
0003	The parameters used to detect the absolute position have been changed. #1003 iunit #2201 PC1 #1016 iout #2202 PC2 #1017 rot #2218 PIT #1018 ccw #2219 RNG1 #1040 M_inch #2220 RNG2 #2049 type #2225 MTYP	Correctly set the parameters. Turn the power on again, and perform zero point initialization.	Required	—	—
0004	The zero point initialization point is not at the grid position.	Reperform zero point initialization.	Required	—	—
0005	Restoration was possible with parameter input in the above No.0002 state.	Turn the power on again, and operation will be possible.	Not required	—	—
0080	The absolute value data was lost, because the multi-rotation counter data in the detector was incorrect, etc.	Replace the detector and complete zero point initialization.	Required	—	(9E) etc.
0101	The power was turned ON again after the servo alarm No. 25 displayed.	Reperform zero point initialization.	Required	—	(25)
0106	The power was turned ON again after the servo alarm No. E3 displayed.	Reperform zero point initialization.	Required	—	(E3)

Note: To release alarm "Z70 ABS. ILLEGAL", enter the parameter data output when establishing the absolute position and turn ON the power again. For the rotation axis, however, the alarm cannot be released by entering the parameter data.

1. LIST OF ALARMS
1.6 Absolute Position Detection System Alarms

Z71 DETECTOR ERROR □□□□ □□□□ (Error No.) (Axis name)			This alarm is displayed if an error is found in the detector for the absolute position detection system.		
Error No.	Details	Remedy	Zero point initialization	Alarm reset when power is turned OFF	Servo alarm No.
0001	The backup voltage in the absolute position detector dropped.	Replace the battery, check the cable connections, and check the detector. Turn the power ON again, and perform zero point initialization.	Required	– (Z70-0101 displays after power is turned ON again.)	25
0003	Communication with the absolute position detector was not possible.	Check and replace the cables, card or detector. Turn the power ON again, and perform zero point initialization.	(Required) Only when detector is replaced.	Reset	91
0004	The absolute position data fluctuated when establishing the absolute position.	Check and replace the cables, card or detector. Turn the power ON again, and perform zero point initialization.	(Required) Only when detector is replaced.	Reset	93
0005	An error was found in the serial data from the absolute position detector.	Check and replace the cables, card or detector. Turn the power ON again, and perform zero point initialization.	(Required) Only when detector is replaced.	Reset	92
0006	Servo alarm E3 Absolute position counter warning	Operation is possible until the power is turned off.	(Required) When power is turned ON again.	Reset (Z70-0106 displays after power is turned ON again.)	E3
0007	Initial communication with the absolute position detector was not possible.	Check and replace the cables, card or detector. Turn the power ON again, and perform zero point initialization.	(Required) Only when detector is replaced.	Reset	18

1. LIST OF ALARMS
1.6 Absolute Position Detection System Alarms

Z72 COMPARE ERROR □□□□ □□□□ (Alarm No.) (Axis name)		This alarm is displayed if an error is detected when comparing the detector's absolute position and controller coordinate values in the absolute position system.
Alarm No.	Details	Remedy

Z73 ABS. WARNING □□□□ □□□□ (Warning No.) (Axis name)		This displays a warning in the absolute position detection system.
Alarm No.	Details	Remedy
0001	Servo alarm 9F Battery voltage drop	The battery voltage dropped or a cable is broken. Absolute position initialization is not required.

1. LIST OF ALARMS
1.7 Messages During Emergency Stop

1.7 Messages During Emergency Stop

EMG EMERGENCY **** Error items Refer to the explanations for details.		
Error No.	Details	Remedy
PLC	The user PLC has entered the emergency stop state during the sequence process.	<ul style="list-style-type: none"> Investigate and remove the cause of the user PLC emergency stop.
EXIN	The emergency stop input signal is significant (open).	<ul style="list-style-type: none"> Cancel the emergency stop input signal. Check the wiring to see if any wiring is broken.
SRV	An alarm occurred in the servo system causing an emergency stop.	<ul style="list-style-type: none"> Investigate and remove the cause of the servo alarm.
STOP	The user PLC (ladder sequence) is not running.	<ul style="list-style-type: none"> Check if the rotary switch CS2 on the top of the controller front panel is set to 1. Check if the PLC edit file save screen (onboard function) [4RUN/SP] (run/stop) switch is turned ON.
SPIN	Spindle drive unit not mounted The spindle drive unit is not mounted.	<ul style="list-style-type: none"> Cancel the causes of the other emergency stop. Check emergency stop signal input in the spindle drive unit.
PC_H	High-speed PC processing abnormal	<ul style="list-style-type: none"> Check the sequence program. (To stop monitoring the high-speed PC processing temporarily, set 1 in #1219 aux03 bit1. Disable the monitoring function only as a temporary measure.)
PARA	Setting of the door open II fixed device is illegal. The dog signal random assignment parameter setting is illegal.	<ul style="list-style-type: none"> Specify the #1155 DOOR_m and #1156 DOOR_s parameters correctly. (When the door open II fixed device is not used, set #1155 DOOR_m and #1156 DOOR_s to 100.) Correctly set the #2073 zrn_dog, #2074 H/W_OT+, #2075 H/W_OT-and #1226 aux 10 bit 5 parameters.
LINK	If the FROM/TO instruction is not executed within 500ms, an emergency stop occurs.	<ul style="list-style-type: none"> Try to execute the FROM or TO instruction one or more times every 500 ms. * Measure the time in which no interrupt request is issued from MELSEC and store the result in the R register. R1880: Current time-out counter R1881: Counter for maximum time-out after power-on R1882: Counter for maximum time-out after system start-up (backed up)

1. LIST OF ALARMS
1.7 Messages During Emergency Stop


Error No.	Details	Remedy
LINK	MELSEC is held in error and reset states.	<ul style="list-style-type: none"> • Check the MELSEC states.
	The contents of MELSEC-specific code area in buffer memory have been destroyed.	<ul style="list-style-type: none"> • Check the MELSEC states.
	PLC serial link communication has stopped. Note: When WAIT is entered for the PLC serial link, only the preparation sequence has been established before the communication stops. Therefore, it is supposed that the basic specification parameters related to serial link parameters #1902 and #1903 are incorrect or the #1909 set-time "Tout (ini)" is too short.	<ul style="list-style-type: none"> • Check that HR571 card wiring and external sequencer transmission are normal. • Check the diagnostic screen for link communication errors. • Check whether the basic specification parameters related to serial link parameters are specified correctly.
WAIT	The preparation sequence is not sent from the master station. Otherwise, the contents of the received preparation sequence are inconsistent with those of the parameters, so that the usual sequence cannot be started. Note: When LINK is also entered for the PLC serial link, refer to "Note" in the section, "LINK".	<ul style="list-style-type: none"> • Check that the HR571 card rotary switch and wiring and the external sequencer transmission are normal. • Check the diagnostic screen for link communication errors.
XTEN	The HR571 card operates abnormally or the rotary switch is set incorrectly.	<ul style="list-style-type: none"> • Check the HR571 card rotary switch and replace the HR571 card if required.
LAD	The user PLC (ladder sequence) has an illegal code.	<ul style="list-style-type: none"> • Check the user PLC (ladder sequence) to see if it uses illegal device numbers or constants.

1. LIST OF ALARMS
1.8 Auxiliary Axis Alarms

1.8 Auxiliary Axis Alarms

Display example

S01 AUX SERVO ALM



(1) S01 AUX SERVO ALM

Alarm information	Details		Remedy
0011	PCB error 1	An error occurred in the drive unit's internal PCB.	<ul style="list-style-type: none"> Replace servo drive unit.
0013	Software processing timeout, clock error	An error occurred in the drive unit's internal reference clock.	<ul style="list-style-type: none"> Replace servo drive unit.
0016	Motor type, detector type error	Motor type error	<ul style="list-style-type: none"> Use a correct drive unit and motor combination.
		Detector initial communication error.	<ul style="list-style-type: none"> Connect correctly. Replace the motor. Replace or repair cable.
		Detector CPU error	<ul style="list-style-type: none"> Replace the motor (detector).
0017	PCB error (A/D conversion initial error)	An error occurred in the drive unit's internal A/D converter.	<ul style="list-style-type: none"> Replace servo drive unit.
0025	Absolute position lost	An error occurred in the detector's internal absolute position data.	<ul style="list-style-type: none"> Turn the power ON for 2 to 3 minutes while the alarm is occurring, and then turn the power ON again. Replace the battery, and initialize the absolute position again.
0034	CRC error	An error occurred in the communication with the NC.	<ul style="list-style-type: none"> Take countermeasures against noise.
0036	Communication timeout, NC down	Communication with the NC was cut off.	<ul style="list-style-type: none"> Connect correctly. Turn the NC power ON. Replace the drive unit or NC.
0037	Parameter error (Regenerative resistance error)	The parameter setting value is incorrect.	<ul style="list-style-type: none"> Set the parameter correctly.
0038	Frame error	An error occurred in the communication with the NC.	<ul style="list-style-type: none"> Take countermeasures against noise.
0039	INFO error	Undefined data was transferred from the NC.	<ul style="list-style-type: none"> Change the NC software version to a compatible version.

1. LIST OF ALARMS
1.8 Auxiliary Axis Alarms

(2) S02 AUX SERVO ALM

Alarm information	Details		Remedy
0011	PCB error 1 (drive circuit error)	An error occurred in the drive unit's internal PCB.	<ul style="list-style-type: none"> • Replace servo drive unit.
0013	Software processing timeout, clock error	An error occurred in the drive unit's internal reference clock.	<ul style="list-style-type: none"> • Replace servo drive unit.
0015	EEROM error	A write error occurred to the EEROM in the drive unit.	<ul style="list-style-type: none"> • Replace servo drive unit.
0017	PCB error (A/D conversion error)	An error occurred in the drive unit's internal A/D converter.	<ul style="list-style-type: none"> • Replace servo drive unit.
0018	PCB error (LSI error)	An error occurred in the drive unit's internal LSI.	<ul style="list-style-type: none"> • Replace servo drive unit.
0020	Detector error	An error occurred in the communication between the servo drive unit and detector.	<ul style="list-style-type: none"> • Connect correctly. • Replace or repair cable.
0024	Ground fault detection	A ground fault of the output was detected when the power was turned ON.	<ul style="list-style-type: none"> • Repair the ground fault section. • Replace the cable or motor.

(3) S03 AUX SERVO ALM

Alarm information	Details		Remedy
0010	Undervoltage	The power voltage is 160V or less.	<ul style="list-style-type: none"> • Review the power supply. • Replace the servo drive unit.
0030	Regeneration error	The tolerable regeneration power of the internal regenerative resistor or external regenerative option was exceeded.	<ul style="list-style-type: none"> • Set the parameter #002 correctly. • Connect correctly. • Lower the positioning frequency. • Change the regenerative option to a larger capacity. • Lower the load. • Review the power supply.
		Regenerative transistor error	<ul style="list-style-type: none"> • Replace the servo drive unit.
0031	Overspeed	The motor's rotation speed exceeded the tolerable momentary speed.	<ul style="list-style-type: none"> • Increase the acceleration/ deceleration time constant. • Review the gear ratio. • Replace the detector.
0032	Overcurrent	A current exceeding the servo drive unit's tolerable current flowed.	<ul style="list-style-type: none"> • Repair the wiring. • Replace the servo drive unit. • Take countermeasures against noise.

1. LIST OF ALARMS
1.8 Auxiliary Axis Alarms

Alarm information	Details		Remedy
0033	Overvoltage	The voltage of the converter in the servo drive unit was 400V or more.	<ul style="list-style-type: none"> • Wire correctly. • Replace the servo drive unit. • For the internal regenerative resistor, replace the drive unit. • For the external regenerative option, replace the regenerative option.
0046	Motor overheating	An operation state causing the motor to overheat continued.	<ul style="list-style-type: none"> • Reduce the motor load. • Review the operation pattern.
0050	Overload 1	The servo drive unit or servomotor overload protection function activated.	<ul style="list-style-type: none"> • Reduce the motor load. • Review the operation pattern. • Change to a motor or drive unit with large output. • Change the setting of the automatic tuning response characteristics. • Correct the connection. • Replace the servomotor.
0051	Overload 2	The max. output current flowed for several seconds due to a machine collision or overload.	<ul style="list-style-type: none"> • Review the operation pattern. • Change the setting of the automatic tuning response characteristics. • Correct the connection. • Replace the servomotor.
0052	Excessive error	A position deflection exceeding the excessive error detection setting value occurred.	<ul style="list-style-type: none"> • Increase the acceleration/ deceleration time constant. • Increase the torque limit value. • Review the power facility capacity. • Review the operation pattern. • Replace the servomotor. • Connect correctly. • Repair or replace the cable.

1. LIST OF ALARMS
1.8 Auxiliary Axis Alarms

(4) S52 AUX SERVO WRN

Alarm information	Details		Remedy
0092	Battery voltage drop	The absolute position detection battery voltage dropped.	<ul style="list-style-type: none"> • Mount a battery. • Replace the battery and initialize the absolute position.
00E0	Over-regeneration warning	The regeneration power may have exceeded the tolerable range of the built-in regenerative resistor or external regenerative option.	<ul style="list-style-type: none"> • Lower the positioning frequency. • Change the regenerative option to a larger one. • Lower the load.
00E1	Overload warning	The overload alarm 1 could occur.	<ul style="list-style-type: none"> • Refer to the items for S03 0050.
00E3	Absolute position counter warning	There is an error in the absolute position detector internal data.	<ul style="list-style-type: none"> • Take countermeasures against noise. • Replace the servomotor.
00E9	Main circuit OFF warning	The servo ON signal was input while the main circuit power was OFF. The contactor operation is faulty.	<ul style="list-style-type: none"> • Turn ON the main circuit power.

(5) Z70 AUX POS. ERR

Alarm information	Details	Cause	Remedy
0001	Zero point initialization incomplete	The zero point (reference point) has not been initialized in the absolute position system.	<ul style="list-style-type: none"> • Initialize the zero point (reference point).
0002	Absolute position data lost	The absolute position coordinate data in the drive unit has been lost.	<ul style="list-style-type: none"> • Initialize the zero point (reference point).
0003	Absolute position system related parameter error	The absolute position system related parameters have been changed or lost.	<ul style="list-style-type: none"> • Correctly set the parameters and then initialize the zero point (reference point).

(6) Z71 AUX DETEC. ERR

Alarm information	Details	Cause	Remedy
0001	Absolute position memory battery voltage drop	The data in the detector has been lost. Battery voltage drop. Detector cable wire breakage or looseness.	<ul style="list-style-type: none"> • Check the battery and detector cable and then initialize the zero point (reference point).

1. LIST OF ALARMS
1.8 Auxiliary Axis Alarms

(7) Z73 AUX SYSTEM WRN

Alarm information	Details	Cause	Remedy
0001	Absolute position memory battery voltage warning	Battery voltage drop. Detector cable wire breakage or looseness.	<ul style="list-style-type: none"> • Check the battery and detector cable. The zero point does not need to be initialized.
0003	Absolute position counter warning	An error occurred in the detector's absolute position counter.	<ul style="list-style-type: none"> • Replace the detector.

(8) M00 AUX OPER. ALM

Alarm information	Details	Cause	Remedy
0001	Near-point dog length insufficient	When executing dog-type reference point, the zero point return speed is too fast or the dog length is too short.	<ul style="list-style-type: none"> • Lower the zero point return speed or increase the dog length.
0003	Reference point return direction illegal	When executing reference point return, the axis was moved in the opposite of the designated direction.	<ul style="list-style-type: none"> • Move the axis in the correct direction.
0004	External interlock	The axis interlock function is valid.	<ul style="list-style-type: none"> • Cancel the interlock signal
0005	Internal interlock	An interlock was established by the servo OFF function.	<ul style="list-style-type: none"> • Cancel the servo OFF.
0007	Soft limit	The soft limit was reached.	<ul style="list-style-type: none"> • Check the soft limit setting and machine position
0024	In absolute position alarm. Reference point return not possible.	Reference point return was executed during an absolute position alarm.	<ul style="list-style-type: none"> • Initialize the absolute position reference point and then fix the absolute position coordinates.
0025	In initializing absolute position. Reference point return not possible.	Reference point return was executed while initializing the absolute position.	<ul style="list-style-type: none"> • Initialize the absolute position reference point and then fix the absolute position coordinates.

1. LIST OF ALARMS
1.8 Auxiliary Axis Alarms

(9) M01 AUX OPER. ALM

Alarm information	Details	Cause	Remedy
0101	No operation mode	The operation mode is not designated, or the operation mode was changed during axis movement.	<ul style="list-style-type: none"> • Correctly designate the operation mode.
0103	Feedrate 0	The operation parameter's feedrate setting is zero. The operation parameter feedrate setting is zero. Or, the override is valid, and the override value is zero.	<ul style="list-style-type: none"> • Set a value other than zero in the feedrate setting or override value.
0160	Station No. designation illegal. Starting not possible.	A station No. exceeding the No. of indexed divisions was designated.	<ul style="list-style-type: none"> • Correctly designate the station No.
0161	Reference point return incomplete. Starting not possible.	Automatic/manual operation was started before reference point return was executed with the incremental system.	<ul style="list-style-type: none"> • Execute the reference point return.
0162	In initializing reference point. Starting not possible.	The start signal was input while initializing the absolute position reference point.	<ul style="list-style-type: none"> • Complete the absolute position reference point initialization.
0163	In absolute position alarm. Starting not possible.	The start signal was input during an absolute position alarm.	<ul style="list-style-type: none"> • Initialize the absolute position reference point and then fix the absolute position coordinates.
0164	In random positioning mode. Manual operation not possible.	The manual operation mode was started during the random positioning mode.	<ul style="list-style-type: none"> • Turn the random positioning mode OFF before switching to the manual operation mode.
0165	Uneven indexing station No. illegal. Starting not possible.	The commanded station No. was higher than 9 or the number of indexing stations during uneven indexing.	<ul style="list-style-type: none"> • Check the commanded station No. and the parameter "#100 station" setting.

1. LIST OF ALARMS
1.8 Auxiliary Axis Alarms

AUXILIARY AXIS MCP ALARMS

Y02 AUX SYSTEM ALM		An error occurred in the data transmitted between the MCP and auxiliary axis drive unit after the power was turned ON.	
Error No.	Details		Remedy
0050	Background error		The software or hardware may be damaged. Contact the service center.
0051	0000	CRC error (10 times/910.2ms)	A communication error has occurred between the controller and drive unit. <ul style="list-style-type: none"> • Take measures against noise. • Check that the communication cable connector between the controller and drive unit and one between the drive units are tight. • Check whether the communication cable between the controller and drive unit and one between the drive units are disconnected. • A drive unit may be faulty. Take a note of the 7-segment LED contents of each drive unit and report to the Service Center.
	0001	CRC error (2 continuous times)	
	0002	Reception timing error (2 continuous times)	
	××03	Data ID error (2 continuous times) ××: Axis No.	
	××04	No. of reception frames error (2 continuous times) ××: Axis No.	

Y03 AUX AMP UNEQU.		Check the auxiliary axis drive unit mounting state. <ul style="list-style-type: none"> • Check the end of the cable wiring. • Check the cable for broken wires. • Check the connector insertion. The auxiliary axis drive unit input power is not being input. The auxiliary axis drive unit axis No. switch is illegal.	
The drive unit is not correctly connected.			
Error No.	Details		
Axis No.1 to 4	bit correspondence (bit 0 : 1st axis, bit 1: 2 nd axis, bit 2: 3rd axis, bit 3: 4th axis)		

1. LIST OF ALARMS
1.9 Computer Link Errors

1.9 Computer Link Errors

Error Message	Error No.	Details	Remedy
L01 DNC ERROR	-4	Communication ends with timeout. CNC has a 248-byte receive buffer. The time during which CNC receives 248 bytes exceeds the "TIME-OUT" value set in the I/O device parameter.	<ol style="list-style-type: none"> 1) Set a greater timeout value in the input/output device parameter. 2) Recheck the HOST software as to whether or not the HOST transmits data in response to DC1 from CNC (data request). 3) Check whether or not start code of computer link parameter is set to 0.
	-10	HOST ER (CNC DR) signal is not turned ON.	<ol style="list-style-type: none"> 1) Check whether or not the cable is disconnected from the connector. 2) Check whether or not the cable is broken. 3) Check whether or not the HOST power is turned ON.
	-15	Communication ends with parity H.	<ol style="list-style-type: none"> 1) Recheck the HOST software as to whether or not the data to be transmitted to CNC is ISO code.
	-16	Communication ends with parity V.	<ol style="list-style-type: none"> 1) Recheck the data to be transmitted to CNC.
	-17	Although CNC transmits DC3 (request to stop data transfer) to the HOST, it receives data of 10 bytes or more from the HOST, thus terminates communication. When CNC is transmitting data to the HOST, it receives data of 10 bytes or more from the HOST.	<ol style="list-style-type: none"> 1) Recheck the software as to whether or not the HOST stops transmitting data within 10 bytes after receiving DC3. 2) Recheck the HOST software as to whether or not the HOST transmits data such as a command or header to CNC during receiving a work program.

1. LIST OF ALARMS
1.10 User PLC Alarms

1.10 User PLC Alarms

Message	Sub-status		Details	Remedy
	1	2		
U01 No PLC	–	–	The ladder is not a GX Developer. (Note) Emergency stop (EMG) will be applied.	Download the ladder of the format selected with the PLC environment selection parameters (bit selection #51/bit 4).
U10 Illegal PLC	0x0010	–	Scan time error The scan time is 1 second or longer.	Edit the ladder size to a smaller size.
	0x0040	–	Ladder operation mode illegal A ladder different from the designated mode was downloaded. (Note) Emergency stop (EMG) will be applied.	Download the ladder having the same format as when the power was reset or turned ON.
	0x0080	–	GX Developer ladder code error (Note) Emergency stop (EMG) will be applied.	Download the correct GX Developer format ladder.
	0x008x	–	PLC4B ladder code error An illegal circuit was found in the PLC4B ladder. bit1: PC medium-speed circuit illegal bit2: PC high-speed circuit illegal (Note) Emergency stop (EMG) will be applied.	The ladder format is illegal. (PLC4B is not available in the specification.) Create again in the GX Developer format.
	0x0400	Number of ladder steps	Software illegal interrupt The ladder process stopped abnormally due to an illegal software command code. (Note) Emergency stop (EMG) will be applied.	Turn the power ON again. If the error is not reset, download the correct ladder.
	0x1000	–	Limit value for the number of ladder steps over Limit value for the number of ladder steps has been over.	Edit the ladder size to a smaller size.
	0x800x	Number of ladder steps	Software exceptional interrupt The ladder process stopped abnormally due to a bus error, etc. ----- bit 0: BIN command operation error bit 1: BCD command operation error ----- bit6: CALL/CALLS/RET command error bit7: IRET command execution error (Note) Emergency stop (EMG) is applied for bit 6/7.	Refer to the methods for using the BCD and BIN function commands. ----- Turn the power ON again. If the error is not reset, download the correct ladder.
U50 Stop PLC			The ladder is stopped.	Start the ladder.

(Note) The number of ladder steps displayed on the screen may not match the actual number of error occurrence steps because of the ladder timing. Use this as a guideline of the occurrence place.

2. OPERATION MESSAGES ON SETTING AND DISPLAY UNIT
2.1 Operation Errors

Error No.	Error message	Details
E02	DATA OVER	△
		<ul style="list-style-type: none"> • The setting data exceeded the setting range. • The compensation data specification exceeded the range when inputting the tool offset data on tape, so that block could not be input. Press the INPUT key again while the input screen is displayed, and the input will continue from the next block. • When workpiece coordinate offsets are measured, the calculation results given by pressing the CALC key are exceeding the specified range. Correctly specify the tool length or the wear data of cutting edges used for the calculation.
E03	No. NOT FOUND	△
		<ul style="list-style-type: none"> • The corresponding setting No. (#) was not found. This error occurs if a setting No. not found on the screen was set and input, or if a variable No. not found in the specifications was set and input for the common variables. • When the tool length was measured manually, a nonexisting tool wear compensation number was specified and the sensor was turned ON. Specify the R register of the offset number correctly.
E04	DEV. NOT READY	×
		<ul style="list-style-type: none"> • The input/output unit power is not ON. • The cable is disconnected. • Setting of the transfer speed (baud rate) does not agree.

2. OPERATION MESSAGES ON SETTING AND DISPLAY UNIT
2.1 Operation Errors

Error No.	Error message	Details
E05	NOT ACCEPTABLE	×
		<ul style="list-style-type: none"> • The PLC timer cannot be set from the screen when the program is valid. (When machine parameter bit selection #6449 bit 1 is set to 1.) • The PLC counter cannot be set from the screen when the program is valid. (When machine parameter bit selection #6449 bit 0 is set to 1.) • The tool registration data setting is prohibited. (When special relay SM71 is valid by the PLC.) • Setting from the tool life management screen is prohibited. • Absolute position setting screen's #1 "ORIGIN" and #2 "ZERO" cannot be set when #0 "INIT SET" is invalid. • The total of axes set in #1001 SYS_ON, #1002 axisno is illegal. Set so that the total No. of axes is within the specifications range for the target model. • #1037 cmdtyp is not within the setting range. • The INPUT key was pressed to perform search for the program that is in background edit status on the word edit screen. • The menu keys (Replace and Insert) on the word edit screen were manipulated when a running program is displayed (PDISP signal: ON). • An attempt was made to set MDI data in an MDI setting lock state (the MDI setting lock parameter is specified with 0 and a non-MDI mode is valid). • Language data in display selection status was entered. Change the display selection status once before entering the data. (#1043 lang) • When the manual value command protection (#1228 aux12/bit7) function is valid, the first monitor screen was manipulated by manual command operation (M, S, and T keys).
E06	NO SPEC	×
		<ul style="list-style-type: none"> • The menu key for a function not in the specifications was pressed. • A parameter not in the specifications was set. • A language not selectable was selected. (#1043 lang) • A function not available with the specification was set.

2. OPERATION MESSAGES ON SETTING AND DISPLAY UNIT
2.1 Operation Errors

Error No.	Error message		Details
E07	RESET END	△	<ul style="list-style-type: none"> • The input/output operations were forcibly stopped by reset, etc. (including EMG).
E08	PHYSICAL ERR	×	<ul style="list-style-type: none"> • The input/output parameter setting or input/output unit side setting was incorrect.
E09	TIME OUT	×	<ul style="list-style-type: none"> • The input/output unit parameter "#9116 TIME-OUT SET" setting was too short. • There is no EOB code in the machining program.
E10	MEMORY OVER	×	<ul style="list-style-type: none"> • The program cannot be written because the memory capacity is exceeded. • This error occurs when the MDI data setting on the MDI screen exceeds 500 characters, or when saving MDI, editing or making a program on the edit screen, input on the data input/output screen, program copy, etc.
E11	PROG. No. DUPLI	△	<ul style="list-style-type: none"> • When registering a machining program in the memory, a program with the same No. as the designated program No. was found in the memory. Refer to the program file to find a program No. not being used, and reset the program No. • A program with the same No. as the machining program to be copied from the memory was found in the IC card. • This error occurs during MDI registration in the MDI screen or during creation of a program in the edit screen.
E12	FILE ENTRY OVER	×	<ul style="list-style-type: none"> • When registering a machining program in the memory, the No. of programs determined in the specifications is exceeded, preventing registration. This error occurs during MDI registration in the MDI screen, creation of a program in the edit screen, data input in the data input/output screen, and program copy.
E13	NB NOT FOUND	△	<ul style="list-style-type: none"> • The block with the designated sequence No. or block No. does not exist in the designated program.
E14	PROG. NOT FOUND	△	<ul style="list-style-type: none"> • The designated program is not found in the memory. • A machining program in the IC card was searched during emergency stop. • The corresponding program No. was not found with operation search in the tape or memory operation mode during graphic check.
E15	EDIT LOCK B	×	<ul style="list-style-type: none"> • An operation (edit, input/output, buffer correction, etc.) inhibited for machining program B was attempted.
E16	EDIT LOCK C	×	<ul style="list-style-type: none"> • An operation (edit, input/output, buffer correction, etc.) inhibited for machining program C was attempted.
E17	PARITY H ERR	×	<ul style="list-style-type: none"> • A parity H error was detected during data input, etc. • Check the paper tape or input device. This error may occur if the paper tape is dirtied with oil, etc.
E18	PARITY V ERR	×	<ul style="list-style-type: none"> • A parity V error was detected during data input. • Check the paper tape to see whether the number of characters in the significant information section of a block is odd. • Also check the state (cable wiring, noise measures, etc.) of the connected equipment.

2. OPERATION MESSAGES ON SETTING AND DISPLAY UNIT

2.1 Operation Errors

Error No.	Error message	Details
E20	OVER RUN ERR	× <ul style="list-style-type: none"> • The control method using the DC codes, etc., for the input/output operation is incorrect. • Check the settings of the input/output unit parameters, and the settings on the input/output unit side, and reset if necessary.
E21	PROGRAM RUNNING	× <ul style="list-style-type: none"> • Deletion of a machining program was attempted during operation. • Search was attempted during operation. • Change of data such as parameters was attempted during operation. • Start of graphic check was attempted during operation. • When using the two systems, the program being buffer corrected was running with the other system. • Erasing or inputting (IC → NC) of a program in the IC card being used was attempted. • Formatting of the IC card was attempted during automatic start. • Accessing to the host computer was attempted during automatic operation.
E22	CODE CHANGE ERR	× <ul style="list-style-type: none"> • There was an illegal code on the paper tape.
E24	PLC RUN	× <ul style="list-style-type: none"> • Data input/output or comparison was attempted when the PLC was not stopped. • Analog output adjustment was attempted when the PLC was not stopped. • An attempt was made to input or output language data during PLC execution. • When the machine manufacturer macro program memory area was set to the FROM area, formatting of the FROM area (#1060 SETUP "20") was attempted when the PLC was not stopped, writing of the machine manufacturer macro program was attempted on the PROGRAM COPY screen, or input of the macro program was attempted. (Measures) <ul style="list-style-type: none"> • Stop the PLC. • Set the control unit rotary switch (NCSYS) to 1. • Set the onboard file screen RUN/STOP setting to 1.
E25	DATA MEMORY ERR	× <ul style="list-style-type: none"> • When inputting the tool offset data onto tape, an offset type exceeding the specifications range was designated, and that block could not be input. If the INPUT key is pressed again in the input screen, the input will continue from the next block.
E26	NO CHARACTERS	Δ <ul style="list-style-type: none"> • The designated character string was not found from the block displayed on the screen to the end of the program when searching with data search in the edit screen. Press the INPUT key again' and the search will start at the head of the program.
E35	COMPARE ERROR	× <ul style="list-style-type: none"> • An inconsistency was found in the paper tape and memory data during comparison.
E40	OP MODE ERROR	× <ul style="list-style-type: none"> • Continuous or step graphic check was not possible because the operation mode was illegal.

2. OPERATION MESSAGES ON SETTING AND DISPLAY UNIT

2.1 Operation Errors

Error No.	Error message	Details
E50	FILE ERR	<div style="text-align: center;">×</div> <ul style="list-style-type: none"> • If one of these errors occurs, the editing or input/output operations cannot be continued. Contact the Service Center. As for E50, a classification No. will display at the end of the message. Inform the service center of this No. as well.
E51	FILE OPEN ERR	
E52	FILE CLOSE ERR	
E53	FILE SEEK ERR	
E54	FILE READ ERR	
E55	FILE DELETE ERR	
E56	FILE INSERT ERR	
E60	IOP ERR□□	<div style="text-align: center;">×</div> <p>A classification number is displayed after the message for E60. Refer to the section shown in parentheses, and remedy the problem.</p> <p>E60 IOP ERROR – 2 (Port already being used) E60 IOP ERROR – 4 (E09 TIME OUT) E60 IOP ERROR – 5 (E08 PHYSICAL ERR) E60 IOP ERROR – 7 (E07 RESET END) E60 IOP ERROR – 10 (E04 DEV. NOT READY) E60 IOP ERROR – 15 (E17 PARITY H ERR) E60 IOP ERROR – 16 (E18 PARITY V ERR) E60 IOP ERROR – 17 (E20 OVER RUN ERR) E60 IOP ERROR – 18 (E22 CODE CHANGE ERR) E60 IOP ERROR – 20 (framing and H/W errors)</p> <ul style="list-style-type: none"> • Setting for the bit length is incorrect. (Baud rate, stop bit, and character length) Check the setting of the I/O device system and its parameters and set it again. • Check the situations of the connected devices (cable wiring and noise measures). • Data was input/output or the tape search was executed during the host link. Set 0 in #8109 HOST LINK, and then set 1 again before performing the cycle start. (IOP error -2) • The host link parameter was turned ON during connecting to the Anshin-net. Turn the Anshin-net valid OFF. (IOP error -2) • When #10812 Anshin-net/ Machine builders network system valid is set to 1, the modem connection port of the Anshin-net or machine builders network system is occupied. • When connecting the GX Developer (when the bit selection parameter #6451 bit5 is set to 1), the port 2 of the RS232C communication port is always used. Disconnect Gx Developer from the RS232C communication port as it has only 1ch (2 ports) available. (Set #6451 bit5 to "0") (IOP error -2)

2. OPERATION MESSAGES ON SETTING AND DISPLAY UNIT

2.1 Operation Errors


Error No.	Error message	Details
E62	I/O PARAM ERR	△
		<ul style="list-style-type: none"> • The "EIA code" data set for I/O parameter is of an unusable code. • The unusable codes are those used as the EIA standard codes and the even hole codes. • System configuration data output operation was executed without using the data ASCII. Set "0" to EIA output, "1" to data ASCII in the I/O device parameters.
E64	PROGRAM No. ERR	△
		<ul style="list-style-type: none"> • The same No. as the program No. designated for program copy was found in the memory. • Restart search for the machining program of the IC card/tape was attempted in the tape mode (tape/IC card operation) without an operation search ahead of time. • During program input, the first character of the machining program block is the program No. address "O" or "L".
E65	PROG. No. DUPLI	△
		<ul style="list-style-type: none"> • During program input, the same No. as the specified program was found in the memory.
E66	NO PROG. NUMBER	△
		<ul style="list-style-type: none"> • During program input, the program No. was not found in the input source external memory device and a program No. was not designated on the screen's data setting area. Set the program No., and input again.
E69	PROG. CHECK MODE	×
		<ul style="list-style-type: none"> • Search (operation search) was attempted during program check (continuous or step). • Retry search after the program check is completed, or after resetting the program search
E70	TOOL No. DUPLI	△
		<ul style="list-style-type: none"> • A tool No. already registered was newly registered on the tool life management screen.
E71	TOOL ENTRY OVER	×
		<ul style="list-style-type: none"> • Registration of data exceeding the max. No. of registerable tools was attempted on the tool life management screen. • When inputting the tool offset data onto tape, a compensation number exceeding the specifications range was specified, and that block could not be input. If the INPUT key is pressed again in the input screen' the input will continue from the next block.
E73	CAN'T CALCULATE	×
		<ul style="list-style-type: none"> • The coordinate value of the hole center cannot be obtained. • Reset the measurement point, which must not applied to the following conditions. The measurement A point is the same as the Y coordinate of the C point. The measurement B is the same as the Y coordinate of the C point. The slope of the line through A and C point is the same as the slope of the line through B and C point.
E74	MENU IMPOSSIBLE	×
		<ul style="list-style-type: none"> • Press the operation menu "= Input" or "+ input" during the tool measurement. • Press the operation menu "= Input" or "+ input" during the manual value command mode. • Press the screen selection menu on which "↓" is displayed during the tool measurement. • Press the screen selection menu on which "↓" is displayed during the manual value command mode.

2. OPERATION MESSAGES ON SETTING AND DISPLAY UNIT

2.1 Operation Errors

Error No.	Error message	Details	
E75	TLM ILL. SIGNAL	<ul style="list-style-type: none"> • The sensor signal was already ON when the tool measurement mode (TLM) signal was validated. • After the tool measurement mode (TLM) signal was validated, the sensor signal turned ON when there was no axis movement. • The sensor signal turned ON at a position within 100μm from the final entry start position. • Turn the tool measurement mode signal input OFF, or turn the sensor signal OFF and move the axis in a safe direction. <p>Note) This display will be erased when another screen is opened. The display will not be erased even if the tool measurement mode signal input is turned OFF, or if the axis is moved in a direction away from the sensor.</p>	
E76	TOOL No. ERROR	×	<ul style="list-style-type: none"> • The offset No. to be used for workpiece coordinate system offset data measurement was invalid. Restart from tool selection. (Correctly specify the R register that contains the offset number.)
E77	AXIS No. REF-RET	×	<ul style="list-style-type: none"> • Zero point return has not been completed for the axis being measured. Return the axis to the zero point.
E78	AX UNMATCH (TLM)	×	<ul style="list-style-type: none"> • During movement of two or more axes, the sensor turned ON and the tool length was measured. Keep off from the sensor and perform the measurement for one axis at a time.
E79	NO REF-RTN (TLM)	×	<ul style="list-style-type: none"> • The sensor turned on for an axis that has not completed dog-type reference point return, and the tool length was measured. Return the axis to the zero point.
E80	TOP SEARCH ERR	×	<ul style="list-style-type: none"> • The program head search (unmodal type search) was not executed before type 2 (standard specification) restart search was executed for program restart. Set the type to unmodal, search for the head of the program, and then search for the restart block with type 2.
E81	PROGRAM ERROR	×	<ul style="list-style-type: none"> • Restart search was attempted in the tape mode (tape/IC card operation) without a search operation after a reset upon a restart search.
E82	ALREADY RESEARCH	×	<ul style="list-style-type: none"> • After completing the type 1 or type 2 search for program restart, the unmodal type, type 1 or type 2 search was attempted again. If program restart is continued (if the axis is return to the restart position with automatic or manual operations), the program will restart from the block searched for first. To search again, cancel the previous search by resetting, and then search again.
E84	CAN'T IN/OUT	×	<ul style="list-style-type: none"> • An attempt was made to input a parameter in the setup parameter locked state. Refer to the manual issued by the machine manufacturer. • When writing data to the IC card, the file name is illegal. (Exceeding 8 characters of file name + 3 characters of extension.) • Input of maintenance data from the host or IC card was attempted.

2. OPERATION MESSAGES ON SETTING AND DISPLAY UNIT
2.1 Operation Errors

Error No.	Error message	Details
E86	INPUT DATA ERR	× <ul style="list-style-type: none"> • When inputting the tool offset data, the data format was not correct, so that block could not be input. • If the INPUT key is pressed again in the input screen, the input will continue from the next block. • When data is read from parameter tape, its format is incorrect. • The format of file written to the NC memory is illegal.
E87	NOT EDIT PROG.	× <ul style="list-style-type: none"> • Playback edit was executed for a fixed cycle subprogram. Playback edit of a fixed cycle subprogram is not possible.
E88	CAN'T ADD BLOCK	× <ul style="list-style-type: none"> • Playback edit cannot be executed unless the block being edited with playback is displayed to the end (EOB) on the left side of the machining program display area. Press the cursor key , and display the whole block to the end. Then, input the data.
E91	MODE ERROR (PBK)	× <ul style="list-style-type: none"> • G90 was set when "PB_G90" was OFF. • G91 was set when "PB_G90" was ON.
E98	CAN'T RESEARCH	× <ul style="list-style-type: none"> • When restarting the program, the type 3 restart search was attempted with a program containing no T command. Check the program. • When restarting the program, the T command corresponding to the type 3 restart search was not found in the program. Check the program. • When carrying out program restart, restart search 2 was executed during MDI mode. • When carrying our program restart, type 3 restart search was attempted while the machine was at the negative (–) side of the restart limit parameters. Manually move the machine to the positive (+) side of the restart limit parameters, and search again.
E165	AUX RUNNING	× <ul style="list-style-type: none"> • The keys other than Function/Menu/Previous page/Next page were pressed in Auxiliary monitor screen during auxiliary axis operation.
E190	FORE EDITING	× <ul style="list-style-type: none"> • An attempt was made to perform background search for the program that is in foreground search status. (Word editing)
E191	NOT COM. SEARCH	× <ul style="list-style-type: none"> • Operation search was attempted in tape mode.
E200	ADJUST ERROR	× <ul style="list-style-type: none"> • The hardware status can't be read correctly, so automatic adjustment was not possible. • Check the remote I/O unit. • A Z55 RIO NOT CONNECT occurred. • Adjust manually. • Unit defect (replace unit)

2. OPERATION MESSAGES ON SETTING AND DISPLAY UNIT
2.1 Operation Errors

Error No.	Error message	Details
E201	UNIT NOT EQUIP	×
		<ul style="list-style-type: none"> • The analog output unit is not mounted. • Confirm the remote I/O unit. • Prepare a unit having analog output. • Check the connection (power and signal wires) • Unit defect (replace unit)
E301	CONNECT ERROR	×
		<ul style="list-style-type: none"> • A socket connection attempt failed during Ethernet communication. Check the host address, the setting of the port No. and that the host computer is turned ON.
E302	LOGIN ERR	×
		<ul style="list-style-type: none"> • A login attempt failed during Ethernet communication. Check the user name and password. • Check the account settings, such as the home directory.
E303	TIME OUT	×
		<ul style="list-style-type: none"> • Transmission of a file with Ethernet communication ended because of timeout.
E311	DOWNLOAD ERR	×
		<ul style="list-style-type: none"> • An attempt to read a host file failed during Ethernet communication.
E312	UPLOAD ERR	×
		<ul style="list-style-type: none"> • An attempt to write to a host file failed during Ethernet communication.
E313	NO FILE	×
		<ul style="list-style-type: none"> • Specified file (transmission source file) is not found. (Not exist in the transmission source device.)
E314	FILE DUPLICATE	×
		<ul style="list-style-type: none"> • A file having the same name as the one to be sent exists in the file destination. In the IC CARD I/O screen, overwriting is possible with "Y"+INPUT.
E315	FILE WRITE ERR	×
		<ul style="list-style-type: none"> • An attempt to write to the IC card failed.
E316	FILE READ ERR	×
		<ul style="list-style-type: none"> • An attempt to read a file from the IC card failed.
E317	MEMORY OVER	×
		<ul style="list-style-type: none"> • IC card memory is full. • NC memory is full.
E318	OVER FLOW ERR	×
		<ul style="list-style-type: none"> • A host directory contains too many files.
E319	DIRECTORY ERR	×
		<ul style="list-style-type: none"> • An attempt to move a directory failed. • In the IC card device, accessing a directory in the nineteenth layer or more was attempted.

2. OPERATION MESSAGES ON SETTING AND DISPLAY UNIT

2.1 Operation Errors

Error No.	Error message	Details
E325	FILE NUM ERR	×
		<ul style="list-style-type: none"> • Data transmission to the IC card was attempted in the state where no file could be added to the IC card directory.
E330	BACKUP FROM NG	×
		<ul style="list-style-type: none"> • The cassette was in the following state. <ul style="list-style-type: none"> Un-mounting Outside of regulation Empty data Invalid data
E331	NO EMG STOP	×
		<ul style="list-style-type: none"> • Emergency stop (EMG) was not applied, so could not be operated.
E332	RESTORE ERROR	×
		<ul style="list-style-type: none"> • The restore failed. (The error of manufacturing number.)
E350	TITLE ERROR 1	×
		<ul style="list-style-type: none"> • Data output was performed without inputting title screen customization data beforehand.
E351	TITLE ERROR 2	×
		<ul style="list-style-type: none"> • The title screen customization data which have been input is not Bitmap File for Windows. • Perform the input after converting the data into Bitmap File for Windows.
E352	TITLE ERROR 3	×
		<ul style="list-style-type: none"> • The setting of the title screen customization data which have been input is not monochrome bitmap for Bitmap File for Windows. • Perform the input after converting the data into the monochrome setting of Bitmap File for Windows.
E353	TITLE ERROR 4	×
		<ul style="list-style-type: none"> • The compression setting of the title screen customization data which have been input is not non-compression that applies to the Bitmap File for Windows. • Perform the input after saving the data with another drawing software.
E354	TITLE ERROR 5	×
		<ul style="list-style-type: none"> • The size of the customized title part is exceeding 640 pixels × 250 pixels. • Perform the input after changing the size to be 640 pixels × 250 pixels.
E355	TITLE ERROR 6	×
		<ul style="list-style-type: none"> • A communication error occurred during input/output of the bitmap data. • Check the communication cables and parameters.

2.2 Operator Messages

The following messages indicate the status of the setting and display functions, and are not operation errors. They are mainly used to show that operation is normal, and serve as guides for the following operations. There is no classification by numbers.

2.2.1 Search and operation related

Message	Message details
SEARCH EXECUTION	<ul style="list-style-type: none">• Search is being executed normally.
SEARCH COMPLET	<ul style="list-style-type: none">• Search was completed normally.
BUFFER EDIT	The buffer is being corrected. This appears when the cursor or a tab key is pressed and the buffer correction mode is entered. This is erased when INPUT is pressed.
CAN'T BUF. EDIT	Buffer correcting of a machine manufacturer macro program was attempted.
DATA PROTECTING	Buffer correcting is prohibited since the data protection key 3 is valid.

2. OPERATION MESSAGES ON SETTING AND DISPLAY UNIT
2.2 Operation Messages

2.2.2 MDI/editing related

Message	Message details
MDI NO SETTING	<ul style="list-style-type: none"> • Only display of MDI data (no execution)
MDI SETTING COMPLETE	<ul style="list-style-type: none"> • The MDI data setting has been completed (execution is now possible).
MDI ENTRY COMPLETE	<ul style="list-style-type: none"> • The MDI data was saved in the memory with the specified program No.
MDI RUNNING	<ul style="list-style-type: none"> • The NC is operating with an MDI program, and the MDI data cannot be corrected.
PUSH KEY SERCH/PROG	<ul style="list-style-type: none"> • Status in which no programs to be edited have been called on the editing screen. To edit, press the SEARCH or PROGRAM edit key.
EDITING	<ul style="list-style-type: none"> • The details of a program are being edited on the screen. Press INPUT to write the data in the memory.
PROGRAM RUNNING	<ul style="list-style-type: none"> • A machining program to be edited is currently being run with memory operation, and cannot be edited.
DELETE? (Y/N)	<ul style="list-style-type: none"> • Waiting for a key entry (whether to delete the program) in word edit status (when the background search menu is selected)
BACK GROUND EDITING	<ul style="list-style-type: none"> • Background edit mode
EDIT POSSIBLE	<ul style="list-style-type: none"> • Editing can be performed in foreground edit mode.
EDIT IMPOSSIBLE	<ul style="list-style-type: none"> • Editing cannot be performed in foreground edit mode. • This state also occurs during feed hold or fixed cycle mode (single-block stop).
WORD SEARCH FIN	<ul style="list-style-type: none"> • The word matching the search data was searched on word editing.

2. OPERATION MESSAGES ON SETTING AND DISPLAY UNIT
2.2 Operation Messages

2.2.3 Data input/output related

Message	Message details
DATA IN EXECUTION	• Data is being read without error from the paper tape.
DATA WRITING IN PROGRESS	• Data has been entered normally and the input data is being written to the ROM.
DATA IN COMPLETE	• Data has been stored without error.
COMPARE EXECUTION	• Comparison is being executed without error.
COMPARE COMPLETE	• Comparison has completed without error.
DATA OUT EXECUTION	• Data is being output without error.
DATA OUT COMPLETE	• Data has been output without error.
ERASE EXECUTION	• Data is being erased without error.
ERASE COMPLETE	• Data has been erased without error.
COPY EXECUTION	• The machining program is being copied without error.
COPY COMPLETE	• The machining program has been copied without error.
CONDENSE EXECUTION	• The machining program is being condensed without error.
CONDENSE COMPLETE	• The machining program has been condensed without error.
MERGE EXECUTION	• The machining program is being merged without error.
MERGE COMPLETE	• The machining program has been merged without error.
No. CHANGE EXECUTION	• The machining program No. is being changed without error.
No. CHANGE COMPLETE	• The machining program No. has been changed without error.

2. OPERATION MESSAGES ON SETTING AND DISPLAY UNIT
2.2 Operation Messages

2.2.4 S-analog output adjustment related

Message	Message details
ADJUST EXECUTION	<ul style="list-style-type: none"> Analog output adjustment is being executed without error.
ADJUST COMPLETE	<ul style="list-style-type: none"> Analog output adjustment has completed without error.

2.2.5 Auxiliary axis

Message	Message details
CONTINUE Y/N	<ul style="list-style-type: none"> Type "Y" or "N" to specify whether to perform operation.
BACKUP EXECUTION	<ul style="list-style-type: none"> The auxiliary axis parameters are being backed up in SRAM.
BACKUP COMPLETE	<ul style="list-style-type: none"> The backup of the auxiliary axis parameters in SRAM has been completed.
AUX. WRITING EXEC.	<ul style="list-style-type: none"> The auxiliary axis parameters in SRAM is being written to MR-J2-CT.
WRITE COMPLETE	<ul style="list-style-type: none"> The writing of the auxiliary axis parameters in SRAM to MR-J2-CT has been completed.
ABS POS RESTORED	<ul style="list-style-type: none"> The absolute position in SRAM has been restored in MR-J2-CT.

2.2.6 Parameter backup related

Message	Message details
BACKUP EXEC. Y/N	Type "Y" or "N" to specify whether to perform the operation.
BACKUP EXECUTION	The parameters are being backed up.
BACKUP COMPLTE	Backup of the parameters has been completed.
RESTORE EXEC. Y/N	Type "Y" or "N" to specify whether to perform the operation.
RESTORE EXECUTION	The parameters are being restored.
RESTORE COMPLETE	Restoration of the parameters has been completed.

2. OPERATION MESSAGES ON SETTING AND DISPLAY UNIT
2.2 Operation Messages

2.2.7 Others

Message	Message details
DATA PROTECTING	<ul style="list-style-type: none"> The data protection key is valid, and the various data cannot be set or erased, etc.
BASE PARA. SET? (Y/N)	<ul style="list-style-type: none"> Waiting for the key input of standard parameter setting (Y/N).
BASE PARA EXECUTION	<ul style="list-style-type: none"> The standard parameters are being set.
EXECUTE FORMAT? (Y/N)	<ul style="list-style-type: none"> Waiting for the key input of execute format (Y/N).
FORMAT EXECUTION	<ul style="list-style-type: none"> Formatting is being executed.
SETUP COMPLETE	<ul style="list-style-type: none"> The simple setup has been completed. Setup with #1060 SETUP "1" has been completed. Formatting with #1060 SETUP "20" has been completed.
NON SETUP	<ul style="list-style-type: none"> Completed without executing simple setup. (When "N" has been set for both "BASE PARA. SET? (Y/N)" and "EXECUTE FORMAT? (Y/N)".)
CONFIRM OPE? (Y/N)	<ul style="list-style-type: none"> Confirmation for erasing operating time or alarm history.
INPUT? (Y/N)	<ul style="list-style-type: none"> Waiting for the key input of tool length data by manual measurement.
V-ANALIZER EXEC.	<ul style="list-style-type: none"> Waveform display data cannot be output while waveform is displayed.

3. PROGRAM ERROR

(The bold characters are the message displayed in the screen.)

These alarms occur during automatic operation, and the causes of these alarms are mainly program errors which occur, for instance, when mistakes have been made in the preparation of the machining programs or when programs which conform to the specification have not been prepared.

Error No.	Details	Remedy
P 10	EXCS. AXIS No. The number of axis addresses commanded in the same block exceeds the specifications.	<ul style="list-style-type: none"> • Divide the alarm block command into two. • Check the specifications.
P 11	AXIS ADR. ERROR The axis address commanded by the program and the axis address set by the parameter do not match.	<ul style="list-style-type: none"> • Revise the axis names in the program.
P 20	DIVISION ERROR An axis command which cannot be divided by the command unit has been issued.	<ul style="list-style-type: none"> • Check the program.
P 29	NOT ACCEPT CMND The normal line control command (G40.1, G41.1, G42.1) has been issued during the modal in which the normal line control is not acceptable.	<ul style="list-style-type: none"> • Check the program.
P 30	PARITY H The number of holes per character on the paper tape is even for EIA code and odd for ISO code.	<ul style="list-style-type: none"> • Check the paper tape. • Check the tape puncher and tape reader.
P 31	PARITY V The number of characters per block on the paper tape is odd.	<ul style="list-style-type: none"> • Make the number of characters per block on the paper tape even. • Set the parameter parity V selection OFF.
P 32	ADDRESS ERROR An address not listed in the specifications has been used.	<ul style="list-style-type: none"> • Check and revise the program address. • Check and correct the parameters values. • Check the specifications.
P 33	FORMAT ERROR The command format in the program is not correct.	<ul style="list-style-type: none"> • Check the program.
P 34	G-CODE ERROR A G code not listed in the specifications has been used. An illegal G code was commanded during the coordinate rotation command (G68).	<ul style="list-style-type: none"> • Check and correct the G code address in the program.

3. PROGRAM ERROR

Error No.	Details	Remedy
P 35	CMD-VALUE OVER The setting range for the addresses has been exceeded.	<ul style="list-style-type: none"> • Check the program.
P 36	PROGRAM END ERR "EOR" has been read during tape and memory operation.	<ul style="list-style-type: none"> • Enter the M02 and M30 command at the end of the program. • Enter the M99 command at the end of the subprogram.
P 37	PROG. NO. ZERO A zero has been specified for program and sequence numbers.	<ul style="list-style-type: none"> • The program numbers are designated across a range from 1 to 99999999. • The sequence numbers are designated across a range from 1 to 99999.
P 39	NO SPEC ERR <ul style="list-style-type: none"> • A non-specified G code was specified. • The high-speed program server operation specifications are not provided. 	<ul style="list-style-type: none"> • Check the specifications.
P 40	PREREAD BL. ERR When tool radius compensation is executed, there is an error in the pre-read block and so the interference check is disabled.	<ul style="list-style-type: none"> • Reconsider the program.
P 60	OVER CMP. LENG. The commanded movement distance is excessive. (Over 2^{31})	<ul style="list-style-type: none"> • Reconsider the axis address command.
P 62	F-CMD. NOTHING <ul style="list-style-type: none"> • No feed rate command has been issued. • There is no F command in the cylindrical interpolation or pole coordinate interpolation immediately after the G95 mode is commanded. 	<ul style="list-style-type: none"> • The default movement modal command at power ON is G01. This causes the machine to move without a G01 command if a movement command is issued in the program, and an alarm results. Use an F command to specify the feedrate. • Specify F with a thread lead command.
P 65	NO G05P3 SPEC	<ul style="list-style-type: none"> • Check the high-speed mode III specifications.
P 70	ARC ERROR <ul style="list-style-type: none"> • There is an error in the arc start and end points as well as in the arc center. • The difference of the involute curve through the start point and the end point is large. • When arc was commanded, one of the two axes configuring the arc plane was a scaling valid axis. 	<ul style="list-style-type: none"> • Check the numerical values of the addresses that specify the start and end points, arc center as well as the radius in the program. • Check the "+" and "-" directions of the address numerical values.

3. PROGRAM ERROR

Error No.	Details	Remedy
P 71	ARC CENTER <ul style="list-style-type: none"> • The arc center is not sought during R-specified circular interpolation. • The curvature center of the involute curve cannot be obtained. 	<ul style="list-style-type: none"> • Check the numerical values of the addresses in the program. • Check whether the start point or end point is on the inner side of the base circle for involute interpolation. When carrying out tool radius compensation, check that the start point and end point after compensation are not on the inner side of the base circle for involute interpolation. • Check whether the start point and end point are at an even distance from the center of the base circle for involute interpolation.
P 72	NO HELICAL SPEC A helical command has been issued though it is not included in the specifications.	<ul style="list-style-type: none"> • Check the helical specifications. • An Axis 3 command was issued by the circular interpolation command. If there is no helical specification, the linear axis is moved to the next block.
P 90	NO THREAD SPEC A thread cutting command has been issued though it is not included in the specifications.	<ul style="list-style-type: none"> • Check the specifications.
P 93	SCREW PITCH ERR The screw pitch has not been set correctly when the thread cutting command is issued.	<ul style="list-style-type: none"> • Issue the thread cutting command and then set the screw pitch command properly.
P100	NO CYLIND SPEC Cylindrical interpolation was commanded when the cylindrical interpolation specifications were not provided.	<ul style="list-style-type: none"> • Check the specifications.
P111	PLANE CHG (CR) Plane selection commands (G17, G18, and G19) were issued when a coordinate rotation command (G68) was issued.	<ul style="list-style-type: none"> • Before issuing the plane selection commands, issue G68 and then G69 (coordinate rotation cancel).
P112	PLANE CHG (CC) <ul style="list-style-type: none"> • A plane selection command (G17, G18, G19) has been issued when the tool radius compensation command (G41, G42) or nose R compensation command (G41, G42, G46) is issued. • The plane selection command was issued when nose R compensation is completed, there is no axial movement command after the G40 command, and the compensation has not been canceled. 	<ul style="list-style-type: none"> • Issue the plane selection command after the tool radius compensation command or nose R compensation command has been canceled (issue axial movement command after the G40 cancel command).
P113	ILLEGAL PLANE The arc command axis is not on the selected plane.	<ul style="list-style-type: none"> • Issue arc command on the correctly selected plane.

3. PROGRAM ERROR

Error No.	Details	Remedy
P122	<p>NO AUTO C-OVR An automatic corner override command (G62) has been issued though it is not included in the specifications.</p>	<ul style="list-style-type: none"> • Check the specifications. • Delete the G62 command from the program.
P126	<p>ILL. CMD(H.A.) An illegal command was issued during the high-accuracy control mode.</p> <ul style="list-style-type: none"> • A G code group 13 command was issued during the high-accuracy control mode. • Milling, cylindrical interpolation or pole coordinate interpolation was commanded during the high-accuracy control mode. 	<ul style="list-style-type: none"> • Reconsider the program.
P130	<p>2nd AUX. ADDR The 2nd miscellaneous function address specified in the program does not match that set by the parameter.</p>	<ul style="list-style-type: none"> • Check and correct the 2nd miscellaneous function address in the program.
P131	<p>NO G96 SPEC (No constant peripheral speed) The constant peripheral speed command (G96) was issued despite the fact that such a command does not exist in the specifications.</p>	<ul style="list-style-type: none"> • Check the specifications. • Change from the constant peripheral speed command (G96) to the rotation speed command (G97).
P132	<p>SPINDLE S = 0 No spindle speed command has been specified.</p>	<ul style="list-style-type: none"> • Reconsider the program.
P133	<p>G96 P-No. ERR An invalid constant peripheral speed control axis has been specified.</p>	<ul style="list-style-type: none"> • Reconsider the parameter specified for the constant peripheral speed control axis.
P140	<p>NO T-POS OFST The position compensation command (G45 to G48) specifications are not available.</p>	<ul style="list-style-type: none"> • Check the specifications.
P141	<p>PAT-ROT ERROR Position compensation was commanded during the figure rotation or coordinate rotation command.</p>	<ul style="list-style-type: none"> • Reconsider the program.
P142	<p>T-OFFS G2 ERR A position compensation invalid arc command was commanded.</p>	<ul style="list-style-type: none"> • Reconsider the program.

3. PROGRAM ERROR

Error No.	Details	Remedy
P150	NO C-CMP SPEC <ul style="list-style-type: none"> • Even though there were no tool radius compensation specifications, tool radius compensation commands (G41 and G42) were issued. • Even though there were no nose R compensation specifications, nose R compensation commands (G41, G42, and G46) were issued. 	<ul style="list-style-type: none"> • Check the specifications.
P151	G2, 3 CMP. ERR A compensation command (G40, G41, G42, G43, G44, G46) has been issued in the arc mode (G02, G03).	<ul style="list-style-type: none"> • Issue the linear command (G01) or rapid traverse command (G00) in the compensation command block or cancel block. (Set the modal to linear interpolation.)
P152	I.S.P NOTHING In interference block processing during execution of a tool radius compensation (G41 or G42) or nose R compensation (G41, G42, or G46) command, the intersection point after one block is skipped cannot be determined.	<ul style="list-style-type: none"> • Reconsider the program.
P153	I.F ERROR An interference error has arisen while the tool radius compensation command (G41, G42) or nose R compensation command (G41, G42, G46) was being executed.	<ul style="list-style-type: none"> • Reconsider the program.
P155	F-CYC ERR (CC) A fixed cycle command has been issued in the radius compensation mode.	<ul style="list-style-type: none"> • The radius compensation mode is established when a fixed cycle command is executed and so the radius compensation cancel command (G40) should be issued.
P156	BOUND DIRECT At the start of G46 nose R compensation, the compensation direction is undefined if this shift vector is used.	<ul style="list-style-type: none"> • Change the vector to that with which the compensation direction is defined. • Exchange with a tool having a different tip point number.
P157	SIDE REVERSED During G46 nose R compensation, the compensation direction is inverted.	<ul style="list-style-type: none"> • Change the G command to that which allows inversion of the compensation direction (G00, G28, G30, G33, or G53). • Exchange with a tool having a different tip point number. • Turn ON the #8106 G46 inversion error avoidance parameter.
P158	ILLEGAL TIP P. During G46 nose R compensation, the tip point is illegal (other than 1 to 8).	<ul style="list-style-type: none"> • Change the tip point number to a legal one.

3. PROGRAM ERROR

Error No.	Details	Remedy						
P170	<p>NO CORR. No.</p> <p>The compensation number (DOO, TOO, HOO) command was not given when the radius compensation (G41, G42, G43, G46) command was issued.</p> <p>Alternatively, the compensation number is larger than the number of sets in the specifications.</p>	<ul style="list-style-type: none"> • Add the compensation number command to the compensation command block. • Check the number of compensation number sets a correct it to a compensation number command within the permitted number of compensation sets. 						
P172	<p>G10 L-No. ERR (G10 L-number error)</p> <p>The L address command is not correct when the G10 command is issued.</p>	<ul style="list-style-type: none"> • Check the address L-Number of the G10 command and correct the number. 						
P173	<p>G10 P-No. ERR (G10 compensation error)</p> <p>When the G10 command is issued, a compensation number outside the permitted number of sets in the specifications has been commanded for the compensation number command.</p>	<ul style="list-style-type: none"> • First check the number of compensation sets and then set the address P designation to within the permitted number of sets. 						
P177	<p>LIFE COUNT ACT</p> <p>Registration of tool life management data with G10 was attempted when the used data count valid signal was ON.</p>	<ul style="list-style-type: none"> • The tool life management data cannot be registered when counting the used data. Turn the used data count valid signal OFF. 						
P178	<p>LIFE DATA OVER</p> <p>The No. of registration groups, total No. of registered tools or the No. of registrations per group exceeded the specifications range.</p>	<ul style="list-style-type: none"> • Review the No. of registrations. The maximum No. of registrations is shown below. <table border="1" style="margin-left: auto; margin-right: auto;"> <tbody> <tr> <td style="text-align: center;">No. of groups</td> <td style="text-align: center;">80</td> </tr> <tr> <td style="text-align: center;">No. of tools</td> <td style="text-align: center;">80</td> </tr> <tr> <td style="text-align: center;">Per group</td> <td style="text-align: center;">16</td> </tr> </tbody> </table>	No. of groups	80	No. of tools	80	Per group	16
No. of groups	80							
No. of tools	80							
Per group	16							
P179	<p>GROUP No. ILL.</p> <ul style="list-style-type: none"> • When registering the tool life management data with G10, the group No. was commanded in duplicate. • A group No. that was not registered was designated during the T□□□□99 command. • An M code command must be issued as a single command but coexists in the same block as that of another M code command. • The M code commands set in the same group exist in the same block. 	<ul style="list-style-type: none"> • The group No. cannot be commanded in duplicate. When registering the group data, register it in group units. • Correct to the correct group No. 						
P180	<p>NO BORING CYC.</p> <p>A fixed cycle command was issued though there are not fixed cycle (G72 – G89) specifications.</p>	<ul style="list-style-type: none"> • Check the specifications. • Correct the program. 						

3. PROGRAM ERROR

Error No.	Details	Remedy
P181	<p>NO S-CMD (TAP) The spindle rotation speed command has not been issued when the hole drilling fixed cycle command is given.</p>	<ul style="list-style-type: none"> • Issue the spindle rotation speed command (S) when the hole drilling fixed cycle command G84, G74 (G84, G88) is given.
P182	<p>SYN TAP ERROR Connection to the main spindle unit was not established.</p>	<ul style="list-style-type: none"> • Check connection to the main spindle. • Check that the main spindle encoder exists.
P183	<p>PTC/THD, No. The pitch or thread number command has not been issued in the tap cycle of a hole drilling fixed cycle command.</p>	<ul style="list-style-type: none"> • Specify the pitch data and the number of threads by F or E command.
P184	<p>NO PTC/THD CMD</p> <ul style="list-style-type: none"> • The pitch or the number of threads per inch is illegal in the tap cycle of the hole drilling fixed cycle command. • The pitch is too small for the spindle rotation speed. • The thread number is too large for the spindle rotation speed. 	<ul style="list-style-type: none"> • Check the pitch or the number of threads per inch.
P190	<p>NO CUTTING CYC A lathe cutting cycle command was input although the lathe cutting cycle was undefined in the specification.</p>	<ul style="list-style-type: none"> • Check the specification. • Delete the lathe cutting cycle command.
P191	<p>TAPER LENG ERR In the lathe cutting cycle, the specified length of taper section is illegal.</p>	<ul style="list-style-type: none"> • The radius set value in the lathe cycle command must be smaller than the axis shift amount.
P192	<p>CHAMFERING ERR Chamfering in the thread cutting cycle is illegal.</p>	<ul style="list-style-type: none"> • Set a chamfering amount not exceeding the cycle.
P200	<p>NO MRC CYC SPC The fixed cycle for compound lathe I (G70 to G73) was commanded when the fixed cycle for compound lathe I specifications were not provided.</p>	<ul style="list-style-type: none"> • Check the specification.
P201	<p>PROG. ERR (MRC)</p> <ul style="list-style-type: none"> • When called with a fixed cycle for compound lathe I command, the subprogram contained at least one of the following commands: <ul style="list-style-type: none"> • Reference point return command (G27, G28, G29, G30) • Thread cutting (G33, G34) • Fixed cycle skip-function (G31) • The first move block of the finish shape program in fixed cycle for compound lathe I contains an arc command. 	<ul style="list-style-type: none"> • Delete the following G codes from this subprogram that is called with the fixed cycle for compound lathe I commands (G70 to G73): G27, G28, G29, G30, G31, G33, G34, fixed cycle G-code. • Remove G2 and G3 from the first move block of the finish shape program in fixed cycle for compound lathe I.

3. PROGRAM ERROR

Error No.	Details	Remedy
P202	BLOCK OVR (MRC) The number of blocks in the shape program of the fixed cycle for compound lathe I is over 50 or 200 (this differs according to the model).	<ul style="list-style-type: none"> Specify 50 or a less value. The number of blocks in the shape program called by the fixed cycle for compound lathe I commands (G70 to G73) must be decreased below 50 or 200 (this differs according to the model).
P203	CONF. ERR (MRC) The fixed cycle for compound lathe I (G70 to G73) shape program could not cut the work normally because it defined an abnormal shape.	<ul style="list-style-type: none"> Check the fixed cycle for compound lathe I (G70 to G73) shape program.
P204	VALUE ERR (MRC) A command value of the fixed cycle for compound lathe (G70 to G76) is illegal.	<ul style="list-style-type: none"> Check the fixed cycle for compound lathe (G70 to G76) command value.
P210	NO PAT CYC SPC A fixed cycle for compound lathe II (G74 to G76) command was input although it was undefined in the specification.	<ul style="list-style-type: none"> Check the specification.
P220	NO SPECIAL CYC No special fixed cycle specifications are available.	<ul style="list-style-type: none"> Check the specifications.
P221	NO HOLE (S_CYC) A 0 has been specified for the number of holes in special fixed cycle mode.	<ul style="list-style-type: none"> Reconsider the program.
P222	G36 ANGLE ERR A G36 command specifies 0 for angle intervals.	<ul style="list-style-type: none"> Reconsider the program.
P223	G12 G13 R ERR The radius value specified with a G12 or G13 command is below the compensation amount.	<ul style="list-style-type: none"> Reconsider the program.
P224	NO G12, G13 SPC There are no circular cutting specifications.	<ul style="list-style-type: none"> Check the specifications.
P230	NESTING OVER <ul style="list-style-type: none"> A subprogram has been called 8 or more times in succession from the subprogram. The program in the IC card contains the M198 command. The program in the IC card has been called more than once (the program in the IC card can be called only once at a time). 	<ul style="list-style-type: none"> Check the number of subprogram calls and correct the program so that it does not exceed 8 times. When using the IC card, the IC card and the number of IC card program calls.
P231	NO N-NUMBER At subprogram call time, the sequence number set at return from the subprogram or specified by GOTO, was not set.	<ul style="list-style-type: none"> Specify the sequence numbers in the call block of the subprogram. When using an IC card, check the program and its No. in the IC card.

3. PROGRAM ERROR

Error No.	Details	Remedy
P232	NO PROGRAM No. <ul style="list-style-type: none"> • The specified subprogram is not registered in the memory or IC card. • The program file name registered in the IC card and O No. do not match. 	<ul style="list-style-type: none"> • Enter the subprogram. • Check the program number in the IC card.
P241	NO VARI NUMBER The variable number commanded is higher than the numbers in the specifications.	<ul style="list-style-type: none"> • Check the specifications. • Check the program variable number.
P242	EQL. SYM. MSSG. The "=" sign has not been commanded when a variable is defined.	<ul style="list-style-type: none"> • Designate the "=" sign in the variable definition of the program.
P243	VARIABLE ERR. An invalid variable has been specified in the left or right side of an operation expression.	<ul style="list-style-type: none"> • Correct the program.
P252	PAT.&COORD-ROT A coordinate rotation related command (G68, G69) was issued during figure rotation.	<ul style="list-style-type: none"> • Reconsider the program.
P260	NO COOD-RT SPC Even though there were no coordinate rotation specifications, a coordinate rotation command was issued.	<ul style="list-style-type: none"> • Check the specifications.
P270	NO MACRO SPEC A macro specification was commanded though there are no such command specifications.	<ul style="list-style-type: none"> • Check the specifications.

3. PROGRAM ERROR

Error No.	Details	Remedy
P271	NO MACRO INT. A macro interrupt command has been issued though it is not included in the specifications.	<ul style="list-style-type: none"> • Check the specifications.
P272	MACRO ILL. A statement and a macro statement exist together in the same block.	<ul style="list-style-type: none"> • Reconsider the program and place the executable statement and macro statement in separate blocks.
P273	MACRO OVERCALL The number of macro call nests exceeded the specifications.	<ul style="list-style-type: none"> • Reconsider the program and correct it so that the macro calls do not exceed the limit imposed by the specification.
P275	MACRO ARG. EX. The number of macro call argument type II sets has exceeded the limit.	<ul style="list-style-type: none"> • Reconsider the program.
P276	CALL CANCEL A G67 command was issued though it was not during the G66 command modal.	<ul style="list-style-type: none"> • Reconsider the program. • The G67 command is the call cancel command and so the G66 command must be designated first before it is issued.
P277	MACRO ALM MESSG An alarm command has been issued in #3000.	<ul style="list-style-type: none"> • Refer to the operator messages on the DIAG screen. • Refer to the instruction manual issued by the machine manufacturer.
P280	EXC. [, The number of parentheses "[" or "]" which can be commanded in a single block has exceeded five.	<ul style="list-style-type: none"> • Reconsider the program and correct it so the number of "[" or "]" does not exceed five.
P281	[,] ILLEGAL The number of "[" and "]" parentheses commanded in a single block does not match.	<ul style="list-style-type: none"> • Reconsider the program and correct it so that "[" and "]" parentheses are paired up properly.
P282	CALC. IMPOSS. The arithmetic formula is incorrect.	<ul style="list-style-type: none"> • Reconsider the program and correct the formula.
P283	DIVIDE BY ZERO The denominator of the division is zero.	<ul style="list-style-type: none"> • Reconsider the program and correct it so that the denominator for division in the formula is not zero.
P290	IF SNT. ERROR There is an error in the IF conditional GOTO□ statement.	<ul style="list-style-type: none"> • Reconsider the program.
P291	WHILE SNT. ERR There is an error in the WHILE conditional DO□-END□ statement.	<ul style="list-style-type: none"> • Reconsider the program.
P292	SETVN SNT. ERR There is an error in the SETVN□ statement when the variable name setting was made.	<ul style="list-style-type: none"> • Reconsider the program. • The number of characters in the variable name of the SETVN statement must be 7 or less.

3. PROGRAM ERROR

Error No.	Details	Remedy
P293	DO-END EXCESS The number of □'s for DO-END□ in the WHILE conditional DO□ – END□ statement has exceed 27.	<ul style="list-style-type: none"> • Reconsider the program and correct it so that the number of 's in the DO – END statement does not exceed 27.
P294	DO-END MMC. The DO's and END's are not paired off properly.	<ul style="list-style-type: none"> • Reconsider the program and correct it so that the DO's and END's are paired off properly.
P295	WHILE/GOTO TPE There is a WHILE or GOTO statement on the tape during tape operation.	<ul style="list-style-type: none"> • During tape operation, a program which includes a WHILE or GOTO statement cannot be executed and so the memory operation mode is established instead.
P296	NO ADR (MACRO) A required address has not been specified in the user macro.	<ul style="list-style-type: none"> • Review the program.
P297	ADR-A ERR. The user macro does not use address A as a variable.	<ul style="list-style-type: none"> • Review the program.
P298	PTR OP (MACRO) User macro G200, G201, or G202 was specified during tape or MDI operation.	<ul style="list-style-type: none"> • Review the program.
P300	VER. NAME ERROR The variable names have not been commanded properly.	<ul style="list-style-type: none"> • Reconsider the variable names in the program and correct them.
P301	VAR NAME DUPLI The name of the variable has been duplicated.	<ul style="list-style-type: none"> • Correct the program so that the name is not duplicated.
P360	NO PROG.MIRR. A mirror image (G50.1 or G51.1) command has been issued though the programmable mirror image specifications are not provided.	<ul style="list-style-type: none"> • Check the specifications.
P370	NO OPOS MR SPC The facing turret mirror image specifications are not provided.	<ul style="list-style-type: none"> • Check the specifications.
P371	MIRR ILLEGAL Facing turret mirror image was commanded to an axis for which external mirror image or parameter mirror image is valid. Facing turret mirror image validating mirror image for a rotary axis was commanded.	<ul style="list-style-type: none"> • Check the program. • Check the parameters.

3. PROGRAM ERROR

Error No.	Details	Remedy
P380	NO CORNER R/C A command was issued for corner chamfering/corner rounding though there are no such specifications.	<ul style="list-style-type: none"> • Check the specifications. • Remove the corner chamfering/corner rounding command from the program.
P381	NO ARC R/C SPC Corner chamfering/corner rounding was specified in the arc interpolation block although corner chamfering/corner rounding II is unsupported.	<ul style="list-style-type: none"> • Check the specifications.
P382	CORNER NO MOVE The block next to corner chamfering/corner rounding is not a movement command.	<ul style="list-style-type: none"> • Replace the block succeeding the corner chamfering/corner rounding command by G01 command.
P383	CORNER SHORT In the corner chamfering/corner rounding command, the movement distance was shorter than the value in the corner chamfering/corner rounding command.	<ul style="list-style-type: none"> • Make the corner chamfering/corner rounding less than the movement distance since this distance is shorter than the corner chamfering/corner rounding.
P384	CORNER SHORT When the corner chamfering/corner rounding command was input, the movement distance in the following block was shorter than the length of the corner chamfering/corner rounding.	<ul style="list-style-type: none"> • Make the corner chamfering/corner rounding less than the movement distance since this distance in the following block is shorter than the corner chamfering/corner rounding.
P385	G0 G33 IN CONR A block with corner chamfering/corner rounding was given during G00 or G33 modal.	<ul style="list-style-type: none"> • Recheck the program.
P390	NO GEOMETRIC A geometric command was issued though there are no geometric specifications.	<ul style="list-style-type: none"> • Check the specifications.
P391	NO GEOMETRIC 2 There are no geometric IB specifications.	<ul style="list-style-type: none"> • Check the specifications.
P392	LES AGL (GEOMT) The angular difference between the geometric line and line is 1° or less.	<ul style="list-style-type: none"> • Correct the geometric angle.
P393	INC ERR (GEOMT) The second geometric block was specified by an incremental value.	<ul style="list-style-type: none"> • Specify this block by an absolute value.
P394	NO G01 (GEOMT) The second geometric block contains no linear command.	<ul style="list-style-type: none"> • Specify the G01 command.
P395	NO ADRS (GEOMT) The geometric format is invalid.	<ul style="list-style-type: none"> • Recheck the program.

3. PROGRAM ERROR

Error No.	Details	Remedy
P396	<p>PL CHG. (GEOMT) A plane switching command was executed during geometric command processing.</p>	<ul style="list-style-type: none"> • Execute the plane switching command before geometric command processing.
P397	<p>ARC ERR (GEOMT) In geometric IB, the circular arc end point does not contact or cross the next block start point.</p>	<ul style="list-style-type: none"> • Recheck the geometric circular arc command and the preceding and following commands.
P398	<p>NO GEOMETRIC 1B Although the geometric IB specifications are not included, a geometric command is given.</p>	<ul style="list-style-type: none"> • Check the specifications.
P421	<p>PRAM. IN ERROR</p> <ul style="list-style-type: none"> • The specified parameter number or set data is illegal. • An illegal G command address was input in parameter input mode. • A parameter input command was input during fixed cycle modal or nose R compensation. 	<ul style="list-style-type: none"> • Check the program.
P430	<p>AXIS NOT RET.</p> <ul style="list-style-type: none"> • A command was issued to move an axis, which has not returned to the reference point, away from that reference point. • A command was issued to an axis removal axis. 	<ul style="list-style-type: none"> • Execute reference point return manually. • The command was issued to an axis for which axis removal is validated so invalidate axis removal.
P431	<p>NO 2nd REF. SPC A command for second, third or fourth reference point return was issued though there are no such command specifications.</p>	<ul style="list-style-type: none"> • Check the specifications.
P434	<p>COLLATION ERR One of the axes did not return to the start position when the origin point collate command (G27) was executed.</p>	<ul style="list-style-type: none"> • Check the program.
P435	<p>G27/M ERROR An M command was issued simultaneously in the G27 command block.</p>	<ul style="list-style-type: none"> • An M code command cannot be issued in a G27 command block and so the G27 command and M code command must be placed in separate blocks.
P436	<p>G29/M ERROR An M command was issued simultaneously in the G29 command block.</p>	<ul style="list-style-type: none"> • An M code command cannot be issued in a G29 command block and so the G29 command and M code command must be placed in separate blocks.

3. PROGRAM ERROR

Error No.	Details	Remedy
P438	NOT USE (G52) A local coordinate system command was issued during execution of the G54.1 command.	<ul style="list-style-type: none"> • Review the program.
P450	NO CHUCK BARR. The chuck barrier on command (G22) was specified although the chuck barrier was undefined in the specification.	<ul style="list-style-type: none"> • Check the specification.
P460	TAPE I/O ERROR <ul style="list-style-type: none"> • An error has arisen in the tape reader or, alternatively, in the printer during macro printing. • Restart search was attempted in the tape mode (tape/IC card operation) without a search operation after a reset upon a restart search. 	<ul style="list-style-type: none"> • Check the power and cable of the connected devices. • Check the I/O device parameters. • Insert the IC card. • After reset, always perform a search operation to have the head of program indexed prior to a restart search.
P461	FILE I/O ERROR A file of the machining program cannot be read.	<ul style="list-style-type: none"> • In memory mode, the programs stored in memory may have been destroyed. Output all of the programs and tool data once and format them. • Ensure that the external device that contains the file is mounted.
P462	DNC ERROR A communication error occurred during the BTR operation.	<ul style="list-style-type: none"> • L01 DNC ERROR is displayed simultaneously, so remedy the problem according to the error No.
P480	NO MILL SPEC <ul style="list-style-type: none"> • Milling was commanded when the milling specifications were not provided. • Pole coordinate interpolation was commanded when the pole coordinate interpolation specifications were not provided. 	<ul style="list-style-type: none"> • Check the specification.
P481	MILL ILL. G <ul style="list-style-type: none"> • An illegal G code was used during the milling mode. • An illegal G code was used during cylindrical interpolation or pole coordinate interpolation. • The G07.1 command was issued during the tool radius compensation. 	<ul style="list-style-type: none"> • Check the program.

3. PROGRAM ERROR

Error No.	Details	Remedy
P482	<p>MILL ILL. AXIS</p> <ul style="list-style-type: none"> • A rotary axis was commanded during the milling mode. • Milling was executed even though an illegal value was set for the milling axis No. • Cylindrical interpolation or pole coordinate interpolation was commanded during mirror image. • Cylindrical interpolation or pole coordinate interpolation was commanded before the tool compensation was completed after the T command. • G07.1 was commanded when cylindrical interpolation was not possible (there is no rotary axis, or external mirror image is ON). • G12.1 was commanded when polar coordinate interpolation was not possible. • An axis other than a cylindrical coordinate system axis was commanded during cylindrical interpolation. 	<ul style="list-style-type: none"> • Check the machining program, parameters and PLC I/F signal.
P484	<p>MILL AXIS RET.</p> <ul style="list-style-type: none"> • Movement was commanded to an axis that had not completed reference point return during the milling mode. • Movement was commanded to an axis that had not completed reference point return during cylindrical interpolation or pole coordinate interpolation. 	<ul style="list-style-type: none"> • Carry out manual reference point return.

3. PROGRAM ERROR

Error No.	Details	Remedy
P485	<p>MILL ILL. MODAL</p> <ul style="list-style-type: none"> • The milling mode was turned ON during nose R compensation or constant surface speed control. • A T command was issued during the milling mode. • The mode was switched from milling to cutting during tool compensation. • Cylindrical interpolation or pole coordinate interpolation was commanded during the constant surface speed control mode (G96). • The command unacceptable in the cylindrical interpolation was issued. • A T command was issued during the cylindrical interpolation or pole coordinate interpolation mode. • A movement command was issued when the plane was not selected just before or after the G07.1 command. • A plane selection command was issued during the pole coordinate interpolation mode. • Cylindrical interpolation or pole coordinate interpolation was commanded during tool radius compensation. • The G16 plane in which the radius value of a cylinder is 0 was specified. • A cylindrical interpolation or pole coordinate interpolation command was issued during program coordinate rotation (G68). 	<ul style="list-style-type: none"> • Check the program. • Before issuing G12.1, issue G40 or G97. • Before issuing G12.1, issue a T command. • Before issuing G13.1, issue G40. • Specify the radius value of a cylinder other than 0, or specify the X axis's current value other than 0 before issuing G12.1/G16.
P486	<p>MILLING ERROR</p> <ul style="list-style-type: none"> • The milling command was issued during the mirror image (when parameter or external input is turned ON). • Pole coordinate interpolation, cylindrical interpolation or milling interpolation was commanded during facing turret mirror image. • The start command of the cylindrical interpolation or polar coordinate interpolation was issued during the normal line control. 	<ul style="list-style-type: none"> • Check the program.

3. PROGRAM ERROR

Error No.	Details	Remedy
P511	SYNC CODE ERR <ul style="list-style-type: none"> • Two or more synchronization M codes were commanded in the same block. • The synchronization M code and "!" code were commanded in the same block. 	<ul style="list-style-type: none"> • Check the program.
P600	NO AUTO TLM. An automatic tool length measurement command (G37) was execute though there are no such command specifications.	<ul style="list-style-type: none"> • Check the specifications.
P601	NO SKIP SPEC. A skip command (G31) was issued though there are no such command specifications.	<ul style="list-style-type: none"> • Check the specifications.
P602	NO MULTI SKIP A multiple skipping command (G31.1, G31.2 or G31.3) was issued though there are no such command specifications.	<ul style="list-style-type: none"> • Check the specifications.
P603	SKIP SPEED 0 The skip speed is 0.	<ul style="list-style-type: none"> • Specify the skip speed.
P604	TLM ILL. AXIS No axis or more than one axis was specified in the automatic tool length measurement block.	<ul style="list-style-type: none"> • Specify only one axis.
P605	T-CMD IN BLOCK The T code is in the same block as the automatic tool length measurement block.	<ul style="list-style-type: none"> • Specify this T code before the block.
P606	NO T-CMD BEFOR The T code was not yet specified in automatic tool length measurement.	<ul style="list-style-type: none"> • Specify this T code before the block.
P607	TLM ILL. SIGNAL Before the area specified by the D command or decelerating area parameter d, the measurement position arrival signal went ON. The signal remains OFF to the end.	<ul style="list-style-type: none"> • Check the program.
P608	SKIP ERROR (CC) A skip command was specified during radius compensation processing.	<ul style="list-style-type: none"> • Specify a radius compensation cancel (G40) command' or remove the skip command.


3. PROGRAM ERROR


Error No.	Details	Remedy
P610	ILLEGAL PARA. • The parameter setting is not correct.	<ul style="list-style-type: none"> • Check the program. • Check the parameter.
P612	EXP. ERROR A movement command for exponential function interpolation was issued during facing turret mirror image.	<ul style="list-style-type: none"> • Check the program.
P700	CMD-VALUE ILL. Spindle synchronization was commanded to a spindle that is not connected serially.	<ul style="list-style-type: none"> • Check the program. • Check the parameter.
P900	NO TANZ. SPEC A normal line control command (G40.1, G41.1, G42.1) was issued when the normal line control specifications were not provided.	<ul style="list-style-type: none"> • Check the specifications.
P901	TAN. AXIS G92 A coordinate system preset command (G92) was issued to a normal line control axis during normal line control.	<ul style="list-style-type: none"> • Check the program.
P902	TAN. AXIS LINE <ul style="list-style-type: none"> • The normal line control axis was set to a linear axis. • The normal line control axis was set to the linear type rotary axis II axis. • The normal line control axis has not been set. • The normal line control axis was the same as the plane selection axis. 	<ul style="list-style-type: none"> • Correct the normal line control axis.
P903	PLANE CHG (TAN) The plane selection command (G17, G18, G19) was issued during normal line control.	<ul style="list-style-type: none"> • Delete the plane selection command (G17, G18, G19) from the program for normal line control.
P990	PREPRO S/W ERR Combining commands that required pre-reading (nose R offset, corner chamfering/corner rounding, geometric I, geometric IB, and fixed cycle for compound lathe) resulted in eight or more pre-read blocks.	<ul style="list-style-type: none"> • Reduce the number of commands that require pre-reading or delete such commands.

II EXPLANATION OF PARAMETERS




1. SCREEN CONFIGURATION

1.1 Screen Transition Charts

When the function selection key  is pressed, the following menu appears:
 TOOL menu is displayed after the power is turned on. To display PARAM menu, use menu key on the TOOL screen.




PARAM menu
 No.1 to 4




TOOL menu The contents of TOOL menu depends on the system.

1. SCREEN CONFIGURATION


1.1 Screen Transition Charts

Press the menu key  to display the setup selection screen.

If the setup parameter menu opening option is specified in this screen, the setup parameters can be set up and displayed.




Setup parameter menu
No.1 to 4




Basic specification parameter #1001 to #1024	Axis specification parameter #2001 to #2012	Servo specification parameter	Basic specification parameter of spindle #3001 to #3036
·	Axis specification parameter #2013 to #2024	Servo adjustment parameter	Spindle specification parameter
·	Zero point return parameter #2025 to #2036	Servo parameter #2201 to #2212	Spindle specification parameter
#1925 to #1936	Zero point return parameter #2037 to #2048	·	Spindle offset parameter
·	Absolute position parameter #2049 to #2060	#2297 to #2300	Spindle offset parameter
·	Axis specification parameter #2061 to #2072	·	Spindle parameter #3201 to #3212
·	·	·	·
·	Axis specification parameter #2097 to #2108	·	#3573 to #3584

Setup parameter menu
No.5 to 8



Machining error correction #4000 to #4047	PLC timer #6000 to #6055	Macro list M macro #7001 to #7103	Position switch #7501 to #7734
Machining error correction #4051 to #4097	·	G macro #7201 to #7313	
Machining offset data #4101 to #4184	·	ASCII macro #7401 to #7415	
·	#6936 to #6999		
·	PLC counter #6200 to #6223		
#5109 to #5124	PLC constant #6301 to #6348		
·	#6349 to #6396		
·	Bit selection #6401 to #6460		
·	·		
·	#6581 to #6596		



2. MACHINING PARAMETERS
2.1 Process Parameters

2. MACHINING PARAMETERS

The number of digits in the decimal section of the parameters related to length is determined by the input setting unit.

The input setting unit is set with parameter "#1003 iunit".

Input setting unit	No. of digits in decimal section	Example of setting range
B	3	0 to 999.999 (mm)
C	4	0 to 99.9999 (mm)

2.1 Process Parameters

<WRK COUNT> (No. of workpieces machined)

#	Item	Contents	Setup range (unit)
8001	WRK COUNT M	Set the M code that counts the No. of workpiece repeated machining. The No. will not be counted when set to 0.	0 to 99
8002	WRK COUNT	The current machining No. is displayed. Set the initial value.	0 to 999999
8003	WRK LIMIT	Set the maximum No. of workpieces machined. A signal is output to PLC when the No. of machining times is counted to this limit.	0 to 999999

<AUTO TLM> (Automatic tool length measurement)

#	Item	Contents	Setup range (unit)
8004	SPEED	Set the feedrate during automatic tool length measurement.	1 to 60000 (mm/min)
8005	ZONE r	Set the distance between the measurement position and deceleration start point.	0 to 99999.999 (mm)
8006	ZONE d	Set the tolerable zone of the measurement position. If the sensor signal turns ON in front of d before the measurement position, or if the signal does not turn ON after d is passed, an alarm will occur.	0 to 99999.999 (mm)

<AUTO CORNER OVR> (Automatic corner override)

#	Item	Contents	Setup range (unit)
8007	OVERRIDE	Set the override value for automatic corner override.	0 to 100 (%)
8008	MAX ANGLE	Set the max. corner opening angle where deceleration should start automatically. If the angle is larger than this value, deceleration will not start.	0 to 180 (°)
8009	DSC. ZONE	Set the position where deceleration starts at the corner. Designate at which length point before the corner deceleration should start.	0 to 99999.999 (mm)

2. MACHINING PARAMETERS
2.1 Process Parameters

<T-TIP OFFSET> (Wear data input)


#	Item	Contents	Setup range (unit)
8010	ABS. MAX. (For L system only)	Set the max. value when inputting the tool wear compensation amount. A value exceeding this setting value cannot be set.	0 to 999.999 (mm)
8011	INC. MAX. (For L system only)	Set the max. value for when inputting the tool wear compensation amount in the addition mode.	0 to 999.999 (mm)

<FIXED C.> (Fixed cycle)

#	Item	Contents	Setup range (unit)
8012	G73 n (For M system only)	Set the return amount for G73 (step cycle).	0 to 99999.999 (mm)
8013	G83 n	Set the return amount for G83 (deep hole drilling cycle).	0 to 99999.999 (mm)
8014	CDZ-VALE (For L system only)	Set the screw cut up amount for G76, G78 (thread cutting cycle).	0 to 127 (0.1 lead)
8015	CDZ-ANGLE (For L system only)	Set the screw cut up angle for G76, G78 (thread cutting cycle).	0 to 89 (°)
8016	G71 MINIMUM (For L system only)	Set the minimum cut amount for the final cutting in G71, G72 (rough cutting cycle). If the final cutting amount is smaller than this value, the final cut will not be performed.	0 to 999.999 (mm)
8017	DELTA-D (For L system only)	Set the change amount to the command cut amount D for G71, G72 (rough cutting cycle). Each cut amount will be the value obtained by adding or subtracting this value from command D, and thus, the amount can be changed each cut.	0 to 999.999 (mm)
8018	G84/G74 return (For M system only)	Set up return length m at a G84/G74 pecking tap cycle. Note: Set "0" to specify a usual tap cycle.	0 to 999.999 (mm)

2. MACHINING PARAMETERS
2.1 Process Parameters

<PRECISION> (High-accuracy control)

#	Item	Contents	Setup range (unit)
8019	R COMP	<p>Set up a compensation factor for reducing a control error in the reduction of a corner roundness and arch radius.</p> <p>Indicates a maximum control error (mm) in parentheses.</p> <p>The larger the setup value, the smaller the theoretical error will be. However, since the speed at the corner goes down, the cycle time is extended.</p> <p>Coefficient = 100 – setting value</p> <p>Note: This is valid when "#8021 COMP CHANGE" is set to "0".</p>	0 to 99 (%)
8020	DCC ANGLE	<p>Set up the minimum value of an angle (external angle) that should be assumed to be a corner.</p> <p>When an inter-block angle (external angle) in high-precision mode is larger than the set value, it is determined as a corner and the speed goes down to sharpen the edge.</p> <div style="text-align: center;">  <p>If the set value is smaller than θ, the speed goes down to optimize the corner.</p> </div> <p>Note: If "0" is set, it will be handled as 5 degrees. The standard setting value is "0".</p>	<p>0 to 89 (degrees)</p> <p>0: The angle will be 5°.</p>
8021	COMP CHANGE	<p>Select whether to share or separate the compensation coefficient at the corner/curve during the high-accuracy control mode.</p> <p>0: Share (#8019 R COMP)</p> <p>1: Separate</p> <ul style="list-style-type: none"> • Corner (#8022 CORNER COMP) • Curve (#8023 CURVE COMP) 	0/1
8022	CORNER COMP	<p>Set the compensation coefficient to further reduce or increase the roundness at the corner during the high-accuracy control mode.</p> <p>Coefficient = 100 – setting value</p> <p>Note: This is valid when "#8021 COMP CHANGE" is set to "1".</p>	-1000 to 99 (%)
8023	CURVE COMP	<p>Set the compensation coefficient to further reduce or increase the radius reduction amount at the curve during the high-accuracy control mode.</p> <p>Coefficient = 100 – setting value</p> <p>Note: This is valid when "#8021 COMP CHANGE" is set to "1".</p>	-1000 to 99 (%)

2. MACHINING PARAMETERS
2.1 Process Parameters

<SPLINE> (High-accuracy spline)

#	Item	Contents	Setup range (unit)
8025	SPLINE ON (for M system only)	Not used.	
8026	CANCEL ANG. (for M system only)	Not used.	
8027	Toler-1 (for M system only)	Not used.	
8028	Toler-2 (for M system only)	Not used.	
8029	FairingL (for M system only)	Not used.	
8030	MINUTE LENGTH (for M system only)	Not used.	

<Fairing>

8033	Fairing ON (for M system only)	Not used.	
8034	AccClamp ON (for M system only)	Not used.	
8035	AccClampMag	Not used.	
8036	CordecJudge (for M system only)	Not used.	
8037	CorJudgeL (for M system only)	Not used.	

<C axis normal line>

#	Item	Contents	Setup range (unit)
8041	C-rot.R	Not used.	
8042	C-ins.R	Not used.	

2. MACHINING PARAMETERS
2.1 Process Parameters

<Fixed cycle>

#	Item	Contents	Setup range (unit)
8051	G71 THICK	Set the amount of cut-in by the rough cutting cycle (G71, G72)	0 to 99999.999 (mm)
8052	PULL UP	Set the amount of recess after cutting by the rough cutting cycle (G71, G72).	0 to 99999.999 (mm)
8053	G73 U	Set the X-axis cutting margin of the forming rough cutting cycle (G73).	-99999.999 to 99999.999 (mm)
8054	W	Set the Z-axis cutting margin of the forming rough cutting cycle (G73).	-99999.999 to 99999.999 (mm)
8055	R	Set the number of times cutting is performed by the forming rough cutting cycle (G73).	0 to 99999 (times)
8056	G74 RETRACT	Set the amount of retract (amount of cut-up) of the push-cut cycle (G74, G75).	0 to 999.999 (mm)
8057	G76 LAST-D	Set the amount of final cut-in by the composite threading cycle (G76).	0 to 99.999 (mm)
8058	TIMES	Set the number of times the amount of final cut-in (G76 finish margin) is divided in the composite threading cycle (G76).	0 to 99 (times)
8059	ANGLE	Set the angle (thread angle) of the tool nose in the composite threading cycle (G76).	0 to 99 (°)

#	Item	Contents	Setup range (unit)
8071	3-D CMP (for M system only)	Not used.	
8072	SCALING P (for M system only)	Set the scale factor for reduction or magnification for the machining program for which the G50 or G51 command is issued. This parameter is effective when the program specifies no scale factor.	0 to 99.999999
8075	SpiralEndErr (for M system only)	Not used.	
8076		Not used.	
8077		Not used.	
8078	Screen Saver	Set the time to turn the screen OFF. The screen saver will not turn ON if 0 is set. (Note) This parameter setting is valid only for the LCD display unit.	0 to 60 (min) 0: Do not turn screen OFF.
8083	G83S modeM (for M system only)	Not used.	
8084	G83S Clearanse (for M system only)	Not used.	
8085	G83S Forward F (for M system only)	Not used.	
8086	G83S Back F (for M system only)	Not used.	

2. MACHINING PARAMETERS
2.1 Process Parameters

<SSS control>

#	Item	Contents	Setup range (unit)
8090	SSS ON (for M system only)	Not used.	
8091	StdLength (for M system only)	Not used.	
8092	ClampCoeff (for M system only)	Not used.	
8093	StepLeng (for M system only)	Not used.	
8094	DccWaitAdd (for M system only)	Not used.	
8095	Tolerance (for M system only)	Not used.	

2. MACHINING PARAMETERS
2.2 Control Parameters

2.2 Control Parameters

#	Item	Contents	Setup range (unit)
8101	MACRO SINGLE	Select the control of the blocks where the user macro command continues. 0: Do not stop while macro block continues. 1: Stop every block during signal block operation.	0/1
8102	COLL. ALM OFF	Select the interference (bite) control to the workpiece from the tool diameter during tool radius compensation and nose R compensation. 0: An alarm is output and operation stops when an interference is judged. 1: Changes the path to avoid interference.	0/1
8103	COLL. CHK OFF	Select the interference (bite) control to the workpiece from the tool diameter during tool radius compensation and nose R compensation. 0: Performs interference check. 1: Does not perform interference check.	0/1
8105	EDIT LOCK B	Select the edit lock for program Nos. 8000 to 9999. 0: Program can be edited. 1: Editing of above program is prohibited.	0/1
8106	G46 NO REV-ERR (For L system only)	Select the control for the compensation direction reversal in G46 (nose R compensation). 0: An alarm is output and operation stops when the compensation direction is reversed (G41 → G42, G42 → G41). 1: An alarm does not occur when the compensation direction is reversed, and the current compensation direction is maintained.	0/1
8107	R COMPENSATION	Not used.	
8108	R COMP Select	Not used.	

2. MACHINING PARAMETERS
2.2 Control Parameters

#	Item	Contents	Setup range (unit)
8109	HOST LINK	Specify whether to enable computer link B instead of the RS-232C port. 0: Disable computer link B to enable normal RS-232C communication. 1: Enable computer link B to disable normal RS-232C communication.	0/1
8110	G71/G72 POCKET	Set the pocket machining if there is a dimple (pocket) in the rough cutting cycle (G71, G72) finishing program. 0: Pocket machining OFF 1: Pocket machining ON	0/1
8111	Milling Radius	Select the diameter and radius of the linear axis for cylindrical/polar coordinate interpolation. 0: All axes radius value command 1: Each axis setting (follows #1019 dia diameter designated axis) Note: This parameter is valid only in the cylindrical/polar coordinate interpolation mode.	0/1
8112	DECIMAL PNT-P	0: The decimal point command for G04 address P is invalidated. 1: The decimal point command for G04 address P is validated.	0/1
8113	MillingInitG16	Not used.	
8114	MillingInitG19	Not used.	

2. MACHINING PARAMETERS
2.3 Axis Parameters

2.3 Axis Parameters

Set up the parameter required for each axis.

#	Item	Contents	Setup range (unit)
8201	AX. RELEASE	Select the function to remove the control axis from the control target. 0: Control as normal. 1: Remove from control target.	0/1
8202	OT-CHECK OFF	Select the stored stroke limit II function set in #8204 and #8205. 0: Stored stroke limit II valid 1: Stored stroke limit II invalid	0/1
8203	OT-CHECK-CANCEL	When the simple absolute position method (#2049 type is 9) is selected, the stored stroke limits I, II (or IIB) and IB will be invalid until the first zero point return is executed after the power is turned ON. 0: Stored stroke limit II valid (according to #8202) 1: Stored stroke limit II invalid Note: Temporary cancel of #8203 soft limit affects all the stored stroke limits.	0/1
8204	OT-CHECK-N	This sets the coordinates of the (–) direction in the moveable range of the stored stroke limit II or the lower limit coordinates of the prohibited range of stored stroke limit IIB. If the sign and value are the same as #8205, the stored stroke limit II (or IIB) will be invalid. If the stored stroke limit IIB function is selected, the prohibited range will be between two points even when #8204 and #8205 are set in reverse. When II is selected, the entire range will be prohibited.	±99999.999 (mm)
8205	OT-CHECK-P	This sets the coordinates of the (+) direction in the moveable range of the stored stroke limit II or the upper limit coordinates of the prohibited range of stored stroke limit IIB.	±99999.999 (mm)
8206	TOOL CHG. P	Set the coordinates of the tool change position for G30. n (tool change position return). Set with coordinates in the basic machine coordinate system.	±99999.999 (mm)
8207	G76/87 IGNR (For M system only)	Select the shift operation at G76 (fine boring) and G87 (back boring).	0: Shift effective 1: No shift
8208	G76/87 (–) (For M system only)	Specifies the shift direction at G76 and G87.	0: Shift to (+) direction 1: Shift to (–) direction
8209	G60 SHIFT (For M system only)	Set the last positioning direction and distance for a G60 (uni-directional positioning) command.	±99999.999 (mm)

2. MACHINING PARAMETERS
2.3 Axis Parameters

#	Item	Contents	Setup range (unit)
8210	OT INSIDE	The stored stroke limit function to be set in #8204 and #8205 prevents the machine from moving to the inside or outside of the specified range. 0: Inhibits outside area (select stored stroke limit II.) 1: Inhibits inside area (select stored stroke limit II B.)	0/1
8211	MIRR. IMAGE	Enable or disable the parameter mirror image function. 0: Disable 1: Enable	0/1

2. MACHINING PARAMETERS
2.4 Barrier Data

2.4 Barrier Data

#	Item	Contents	Setup range (unit)
8300	P0 (For L system only)	Set the reference X-coordinates of the chuck and the tail stock barrier. Set the center coordinate (Radius value) of workpiece by the basic machine coordinate system.	±99999.999 (mm)
8301 8302 8303 8304 8305 8306	P1 P2 P3 P4 P5 P6 (For L system only)	Set the area of the chuck and tail stock barrier. (Radius value) Set the coordinate value from the center of workpiece for X-axis. Set the coordinate value by basic machine coordinate system for Z-axis.	±99999.999 (mm)
8310	Barrier ON (For L system only)	Select the validity of the chuck and tailstock barrier. 0: Invalid 1: Valid	0/1
8311 8312	P7 P8 (For L system only)	Set the area of the left spindle section. • X axis: Set the coordinate value from the workpiece center (P0). (radius value) • Z axis: Set the coordinates in the basic machine coordinate system.	±99999.999 (mm)
8313 8314	P9 P10 (For L system only)	Set the area of the right spindle section. • X axis: Set the coordinate value from the workpiece center (P0). (radius value) • Z axis: Set the coordinates in the basic machine coordinate system.	±99999.999 (mm)
8315	BARRIER TYPE (L) (For L system only)	Set the shape of the left chuck and tailstock barrier. 0: No area 1: Chuck 2: Tailstock	0/1/2
8316	BARRIER TYPE (R) (For L system only)	Set the shape of the right chuck and tailstock barrier. 0: No area 1: Chuck 2: Tailstock	0/1/2

2. MACHINING PARAMETERS
2.4 Barrier Data

#	Item	Contents	Setup range (unit)
8317	DELIV. AX. NAME (For L system only)	When the right chuck and tailstock barrier is movable, set the name of the delivery axis.	A/B/.. (axis address) 0 (cancel)
8318	STOCK ANGLE (L) (For L system only)	Set the angle for the left tailstock end section. The angle will be interpreted as 90° if there is no setting (0).	0 to 180 (°) 0: 90° default
8319	STOCK ANGLE (R) (For L system only)	Set the angle for the right tailstock end section. The angle will be interpreted as 90° if there is no setting (0).	0 to 180 (°)

2. MACHINING PARAMETERS
2.5 Tool Measurement Parameters

2.5 Tool Measurement Parameters

Set up the parameter of the tool (touch tool sensor), etc, used for measurement.

#	Item	Contents	Setup range (unit)
8701	Tool length	Set the length to the end of the touch tool.	±99999.999 (mm)
8702	Tool Dia	Set the spherical diameter of the touch tool end.	±99999.999 (mm)
8703	OFFSET X	Set the spindle center deviation amount from the touch tool center in the X axis direction.	±99999.999 (mm)
8704	Y	Set the spindle center deviation amount from the touch tool center in the Y axis direction.	±99999.999 (mm)
8705	RETURN	Set the return distance to contact the touch tool against the workpiece again.	±99999.999 (mm)
8706	FEED	Set the feedrate when contacting the touch tool against the workpiece again.	1 to 60000 (mm/min)

3. I/O PARAMETERS

Pressing the menu key  displays the I/O BASE PARAM screen.

There are basically two types of input/output parameters which must be set when inputting, outputting or referring to data, or when performing tape operation. One type is the parameters related to the input/output device. The baud rate, etc., is set according to each device. Up to five types of input/output devices can be registered. The other type of input/output parameters is the I/O base parameters which determine which device is connected to which channel per input/output application.

3.1 Base Parameters

<I/O>	#	<PORT No.>	#	<DEV. No.> <DEV. NAME>
		Specify the board No. to which the serial input/output device is connected to. <ul style="list-style-type: none"> • Set "2". 		Set the input/output device No. for each application. The device Nos. are 0 to 4 and correspond to the input/output device parameters. The device name set in the input/output device parameter is also displayed for identification.
DATA IN	9001	Specify the port for inputting the data such as machine program and parameters.	9002	Specify the No. of the device that inputs the data.
DATA OUT	9003	Specify the port for outputting the data such as machine program and parameters.	9004	Specify the No. of the device that outputs the data.
TAPE MODE	9005	Specify the input port for running with the tape mode.	9006	Specify the No. of the device to be run with the tape mode.
MACRO PRINT	9007	Specify the output port for the user macro DPRINT command.	9008	Specify the No. of the device for the DPRINT command.
PLC IN/OUT	9009	Specify the port for inputting/outputting various data with PLC.	9010	Specify the No. of the device for the PLC input/output.
REMOTE PROG IN	9011	Specify the port for inputting remote programs.	9012	Specify the number of the device used to input remote programs.
EXT UNIT	9013	Specify the port for communication with an external unit.	9014	Specify the number of the unit used for communication with an external unit

3. I/O PARAMETERS
3.2 I/O Device Parameters

3.2 I/O Device Parameters

Parameters for up to five types of input/output devices can be set in DEV <0> to <4>.

#	Item	Contents	Setup range (unit)
9101	DEVICE NAME	Set the device name corresponding to the device No. Set a simple name for quick identification.	Use alphabet characters, numerals and symbols to set a name within 3 characters.
9102	BAUD RATE	Set the serial communication speed.	0: 19200 (bps) 1: 9600 2: 4800 3: 2400 4: 1200 5: 600 6: 300 7: 150
9103	STOP BIT	Set the stop bit length used in the start-stop system.	1: 1 (bit) 2: 1.5 3: 2
9104	PARITY CHECK	Specify whether to add the parity check bit to the data during communication.	0: Parity bit not added 1: Parity bit added
9105	EVEN PARITY	Specify the odd or even parity when it is added to the data.	0: Odd parity 1: Even parity
9106	CHR. LENGTH	Set the length of the data bit.	0: 5 (bit) 1: 6 2: 7 3: 8
9107	Terminator type	The code to terminate data reading can be selected.	0 and 3: EOR 1 and 2: EOB or EOR
9108	HAND SHAKE	Specify the transmission control method. The method will be no procedure if a value except 1 to 3 is set.	1: RTS/CTS method 2: No procedure (No handshaking) 3: DC code method
9109	DC CODE PARITY	Specify the DC code when the DC code method is selected.	0: No parity to DC code (DC3 = 13H) 1: DC code with parity (DC3 = 93H)
9111	DC2/DC4 OUTPUT	Specify the DC code handling when outputting data to the output device.	DC2 / DC4 0: None / None 1: Yes / None 2: None / Yes 3: Yes / Yes
9112	CR OUTPUT	Specify whether to insert the <CR> code just before the EOB (L/F) code during output.	0: Do not add 1: Add


3. I/O PARAMETERS
3.2 I/O Device Parameters

#	Item	Contents	Setup range (unit)
9113	EIA OUTPUT	In data output mode, select the ISO or EIA code for data output. In data input mode, the ISO and EIA codes are identified automatically.	0: ISO code output 1: EIA code output
9114	FEED CHR.	Specify the length of the tape feed to be output at the start and end of the data during tape output.	0 to 999 (characters)
9115	PARITY V	Specify whether to check the parity of the No. of characters in block during data input. The No. of characters is factory-set so that the check is valid at all times.	0: Do not perform parity V check 1: Perform parity V check
9116	TIME-OUT	Set the time out time to detect an interruption in communication. Time out check will not be executed when set to 0 to 30 seconds.	0 to 30 (s)
9117	DR OFF	Specify whether to check the DR data at the data input/output.	0: DR valid 1: DR invalid
9118	DATA ASC II	0: Output in ISO/EIA code (Depends on whether #9113, #9213, #9313, #9413, or #9513 EIA output parameter is set up) 1: Output in ASC II code	0/1
9119	INPUT FORM	Specify the mode for input (collation). 0: Standard input (Data from the very first EOB is handled as significant information.) 1: EOBs following the first EOB of the input data are skipped until data other than EOB is input.	0/1
9121 9122 9123 9124 9125 9126 9127 9128	EIA CODE [] # * = : \$!	When output with EIA code, data can be output using the alternate code in which the special ISO code not included in EIA is specified. Specify the codes which do not duplicate the existing EIA codes by hexadecimal for respective special codes.	0 to FF (hexadecimal)

9201 ~	Set the same settings for device 1.	
9301 ~	Set the same settings for device 2.	
9401 ~	Set the same settings for device 3.	
9501 ~	Set the same settings for device 4.	

3. I/O PARAMETERS
3.3 Computer Link Parameters

3.3 Computer Link Parameters

#	Item	Contents	Setup range (unit)
9601	BAUD RATE	Specify the rate at which data is transferred.	0: 19200 (bps) 1: 9600 2: 4800 3: 2400 4: 1200 5: 600 6: 300 7: 110 8: 38400
9602	STOP BIT	Specify stop bit length used in start-stop mode. See "PARITY EFFECTIVE" in #9603. The number of characters is adjusted in output mode so that no problems occur if the parity check is enabled.	1: 1 2: 1.5 3: 2
9603	PARITY EFFECTIVE	<p>This parameter is set when using a parity bit separately from the data bit.</p>  <p>ON OFF</p> <p style="text-align: center;">1 character</p> <p style="text-align: center;">Start bit Data bit Parity bit Stop bit</p> <p>Set this to match the input/output device specifications.</p>	0: No parity bit used in I/O mode 1: Parity bit used in I/O mode
9604	EVEN PARITY	Specify whether even or odd parity is used when parity is used. This parameter is ignored when no parity is used.	0: Odd parity 1: Even parity
9605	CHR. LENGTH	Specify data bit length. See "PARITY EFFECTIVE" in #9603.	2: 7 3: 8
9606	HAND SHAKE	RS-232C transmission control mode DC control mode should be set for computer line B.	0: No control 1: RTS/CTS method 2: No handshaking 3: DC control mode
9607	TIME-OUT SET	Specify time-out time at which an interruption of data transfer during data input/output should be detected. If 0 is set, time infinity is specified.	0 to 999 (1/10s)
9608	DATA CODE	Specify the code to be used. See "PARITY EFFECTIVE" in #9603.	0: ASCII code 1: ISO code

3. I/O PARAMETERS
3.3 Computer Link Parameters


#	Item	Contents	Setup range (unit)
9609	LINK PARAM. 1	<p>Bit 1: DC1 output after NAK or SYN Specify whether to output the DC1 code after the NAK or SYN code is output.</p> <p>Bit 7: Enable/disable resetting Specify whether to enable resetting in the computer link.</p>	<p>0: Don't output the DC1 code. 1: Output the DC1 code.</p> <p>0: Enable resetting in the computer link. 1: Disable resetting in the computer link</p>
9610	LINK PARAM. 2	<p>Bit 2: Specify the control code parity (even parity for the control code). Set the parity in accordance with the I/O device specifications.</p> <p>Bit 3: Parity V Specify whether to enable checking of parity V in one block in data input mode.</p>	<p>0: No control code parity added 1: Control code parity added</p> <p>0: Disable 1: Enable</p>
9611	LINK PARAM. 3	Not used	
9612	LINK PARAM.4	Not used	
9613	LINK PARAM.5	Not used	
9614	START CODE	<p>Specify the code by which file data transfer begins at first. This parameter is used for a specific user, and set 0 in this parameter for normal operation.</p>	<p>0: DC1 (11H) 1: BEL (07H)</p>
9615	CTRL. CODE OUT	<p>Bit 0: NAK output Specify whether to send the NAK code to the host if a communication error occurs in computer link B.</p> <p>Bit 1: SYN output Specify whether to send the SYN code to the host if NC resetting or an emergency stop occurs in computer link B.</p> <p>Bit 3: DC3 output Specify whether to send the DC3 code to the host when communication ends in computer link B.</p>	<p>0: Do not output the NAK code. 1: Output the NAK code.</p> <p>0: Do not output the SYN code. 1: Output the SYN code.</p> <p>0: Do not output the DC3 code. 1: Output the DC3 code.</p>
9616	CTRL. INTERVAL	Not used	
9617	WAIT TIME	Not used	
9618	PACKET LENGTH	Not used	
9619	BUFFER SIZE	Not used	
9620	START SIZE	Not used	
9621	DC1 OUT SIZE	Not used	
9622	POLLING TIMER	Not used	
9623	TRANS. WAIT TMR	Not used	
9624	RETRY COUNTER	Not used	

4. SETUP PARAMETERS

Pressing the menu key  displays the OPEN SETUP PARAM screen.

The system's basic parameters are normally hidden as setup parameters to prevent mistaken operations and to simplify the display.

The setup parameters can be displayed and set by making a declaration to open the setup parameters on this screen.



- 1) Select the setup parameter.

Key-in "Y" in # (), and then press INPUT.

The basic specification parameter screen appears and the normally hidden setup parameter menu will display.

The required menu can be selected to display and set the setup parameters.

- 2) Cancel the setup parameter selection.

Key-in "N" in # (), and then press INPUT.

The setup parameter menu will disappear.

Note: The setup parameters are not displayed when the power is turned ON.

(Note 1) Refer to "5. Base Specifications Parameters" to "13. Position Switch" for details on the setup parameters.

(Note 2) Be sure to turn OFF the power supply after selecting the setup parameter.

(Note 3) If a key other than the screen changeover key is pressed when the setup parameters are locked, the message "Data Protected" will appear.

5. BASE SPECIFICATIONS PARAMETERS

5. BASE SPECIFICATIONS PARAMETERS

After setting up the parameter (PR) listed in the table, turn OFF the NC power. To validate the parameter, turn ON the power again.

(SETUP PARAM 1. 1/16)

#	Items		Details	Setting range (unit)						
1001 (PR)	SYS_ON	System validation setup	Specify the existence of the NC axis and PLC axis with 1 or 0.	0: Not used 1: Used						
1002 (PR)	axisno	Number of axes	Set the number of NC axes and PLC axes. With E68, specify 4 as the maximum value for the NC axis and 2 as that for the PLC axis so that the total of those values is 6 or less. With E60, specify 3 as the maximum value for the NC axis and 2 as that for the PLC axis so that the total of those values is 5 or less.	0 to 4						
1003 (PR)	iunit	Input setup unit	Specify the input setting unit for the NC axis and PLC axis. The parameter units will follow this.	B: 1 μm C: 0.1 μm						
1013	axname	Axis name	Specify each axis' name address with an alphabetic character. Use the characters X, Y, Z, U, V, W, A, B or C. Do not specify the same address. The PLC address does not need to be set. (The axis name is displayed as 1 and 2.)	Axis addresses such as X, Y, Z, U, V, W, A, B, and C						
1014	incax	Increment command axis name	When specifying the program movement rate's absolute or incremental method with an address, specify the incremental command axis name address with an alphabetic character. The address that can be used is the same as #1013 axname. Specify an address that is different from that #1013. Setting is not required if absolute/incremental specification with addresses is not performed (#1076 AbsInc = 0).							
1015 (PR)	cunit	Command unit	Specify the minimum unit of the program movement amount. cunit Movement amount for movement command 1 0: #1003 iunit is followed. 1: 0.0001mm (0.1 μm) 10: 0.001mm (1 μm) If there is a decimal point in the movement command, the decimal point position will be handled as 1mm regardless of this setting.	<table border="1"> <tr> <td>0</td> <td>#1003 iunit</td> </tr> <tr> <td>1</td> <td>0.1 μm</td> </tr> <tr> <td>10</td> <td>1 μm</td> </tr> </table>	0	#1003 iunit	1	0.1 μm	10	1 μm
0	#1003 iunit									
1	0.1 μm									
10	1 μm									
1016 (PR)	iout	Inch output	Specify whether the machine system (ball screw pitch, position detection unit) is an inch unit system or metric unit system.	0: Metric unit system 1: Inch unit system						

5. BASE SPECIFICATIONS PARAMETERS

#	Items		Details	Setting range (unit)
1017 (PR)	rot	Rotational axis	Specify whether the axis is a rotary axis or linear axis. For the rotary axis, the position display will be 360°, and the axis will return to 0°. If the position display is to be continuously displayed even with the rotary axis, set the axis as a linear axis	0: Linear axis 1: Rotary axis
1018 (PR)	ccw	Motor CCW	Specify the direction of the motor rotation to the command direction. 0: Rotates clockwise (looking from motor shaft) with the forward rotation command. 1: Rotates counterclockwise (looking from motor shaft) with the forward rotation command.	0: Rotates clockwise 1: Rotates counterclockwise
1019 (PR)	dia	Diameter specification axis	Specify whether the program movement amount is to be commanded with the diameter dimension or as movement amount. When the movement amount is commanded with the diameter dimensions, 5mm will be moved when the command is a movement distance of 10mm. The movement amount per pulse will also be halved during manual pulse feed. Among parameters concerning length, the tool length, the wear compensation amount and the workpiece coordinate offset are displayed in diameter value when diameter is specified, but other parameters are always displayed in radius value.	0: Command with movement amount 1: Command with diameter dimension
1020 (PR)	sp_ax	Spindle Interpolation	Specify 1 when the NC control axis is used as the spindle.	0: The NC control axis is used as the servo axis. 1: The NC control axis is used as the spindle.
1021 (PR)	mcp_no	Drive unit I/F channel No. (servo)	Using a 4-digit number, set the drive unit interface channel No. and which axis in that channel is to be used when connecting an axis drive unit. High-order two digits : Drive unit interface channel No. Low-order two digits : Axis No. When using the conventional fixed layout, set all axes to "0000".	0000 0101 to 0107 0201 to 0207
1022 (PR)	axname2	2nd axis name	Set the name of the axis displayed on the screen with two characters. (X1, Z2, etc.)	Two digits between A to Z and 1 to 9 (Setting is cleared when 0 is set)
1023 (PR)	crsadr		Not used.	
1024 (PR)	crsinc		Not used.	

5. BASE SPECIFICATIONS PARAMETERS

(SETUP PARAM 1. 2/16)

#	Items	Details	Setting range (unit)
1025	l_plane Initial plane selection	Specify the plane to be selected when the power is turned ON or reset. When 0 is specified, 1 is assumed (X-Y plane).	1: X-Y plane (G17 command state) 2: Z-X plane (G18 command state) 3: Y-Z plane (G19 command state)
1026 1027 1028	base_I Base axis I base_J Base axis J base_K Base axis K	Specify the basic axis address that composes the plane. Specify the axis address set in #1013 axname. If all three items do not need to be specified, such as for 2-axis specifications, input "0", and the parameter will be blank. Normally, when X, Y and Z are specified respectively for base_I,_J,_K, the following relation will be established: G17: X-Y G18: Z-X G19: Y-Z Specify the desired address to set an axis address other than the above.	Control axis addresses such as X, Y, and Z
1029	aux_I Flat axis I	If there is an axis parallel to #1026 base_I, specify that axis address.	Control axis addresses such as X, Y, and Z
1030	aux_J Flat axis J	If there is an axis parallel to #1027 base_J, specify that axis address.	Control axis addresses such as X, Y, and Z
1031	aux_K Flat axis K	If there is an axis parallel to #1028 base_K, specify that axis address.	Control axis addresses such as X, Y, and Z

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)																					
1037	cmdtyp Command type	<p>Specify the program G code series and compensation type.</p> <table border="1"> <thead> <tr> <th>cmdtyp</th> <th>G code series</th> <th>Compensation type</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>System 1 (for M)</td> <td>Type A (one compensation amount for one compensation number)</td> </tr> <tr> <td>2</td> <td>System 2 (for M)</td> <td>Type B (shape and wear amounts for one compensation number)</td> </tr> <tr> <td>3</td> <td>System 2 (for L)</td> <td>Type C (two kinds of compensation amount of shape and wear per compensation No.)</td> </tr> <tr> <td>4</td> <td>System 3 (for L)</td> <td>Same as above</td> </tr> <tr> <td>7</td> <td>System 6 (for special L)</td> <td>Same as above</td> </tr> <tr> <td>8</td> <td>System 7 (for special L)</td> <td>Same as above</td> </tr> </tbody> </table> <p>There are some items in the specifications that can be used or cannot be used according to the value set in this parameter. The file structure may also change depending on the compensation data type. Thus, after changing this parameter, initialize the system with #1060 SETUP.</p>	cmdtyp	G code series	Compensation type	1	System 1 (for M)	Type A (one compensation amount for one compensation number)	2	System 2 (for M)	Type B (shape and wear amounts for one compensation number)	3	System 2 (for L)	Type C (two kinds of compensation amount of shape and wear per compensation No.)	4	System 3 (for L)	Same as above	7	System 6 (for special L)	Same as above	8	System 7 (for special L)	Same as above	1 to 8
cmdtyp	G code series	Compensation type																						
1	System 1 (for M)	Type A (one compensation amount for one compensation number)																						
2	System 2 (for M)	Type B (shape and wear amounts for one compensation number)																						
3	System 2 (for L)	Type C (two kinds of compensation amount of shape and wear per compensation No.)																						
4	System 3 (for L)	Same as above																						
7	System 6 (for special L)	Same as above																						
8	System 7 (for special L)	Same as above																						
1038	plcsel Ladder selection	Specify the PLC type.	0: User custom PLC																					
1039	spinno Number of spindles	Specify the existence of a spindle.	0: No spindle 1: One spindle 2: Two spindles																					
1040 (PR)	M_inch Constant input (inch)	Specify the parameter unit system for the position and length.	0: Metric system 1: Inch system																					
1041 (PR)	I_inch Initial state (inch)	Specify the unit system for the program movement amount when the power is turned ON or reset and for position display. Designate an internal unit.	0: Metric system 1: Inch system																					
1042 (PR)	pcinch PLC axis command (inch)	Specify the unit system for the commands to the PLC axis.	0: Metric system 1: Inch system																					

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
1043	lang Select language displayed	Specify the display language. 0: Japanese display 1: English display 2: Third language displayed (Note) 3: Fourth language displayed (Note) 11: Display in German 12: Display in French 13: Display in Italian 14: Display in Spanish 15: Display in Chinese (traditional Chinese) 16: Display in Korean 17: Display in Portuguese 18: Display in Dutch 19: Display in Swedish 20: Display in Hungarian 22: Display in Chinese (simplified Chinese) Note: If no character package is available for a specified language, the screen is displayed in English.	0 to 3 11 to 22
1044 (PR)	auxno MR-J2-CT Connections	Specify the number of MR-J2-CTs connected.	0 to 4
1045 (PR)	nskno	Not used.	
1049 (PR)		Not used.	

Note: Selection of inch and metric unit

When set value of #1041 I_inch is changed, the unit of length is changed after reset.

Among parameters concerning length, following items are not changed automatically, therefore change the set values to agree with the new unit system when the unit system is changed.

5. BASE SPECIFICATIONS PARAMETERS

Tool compensation amount (Tool length compensation amount, tool wear compensation amount and tool tip compensation amount)			
Workpiece coordinate offset			
Machining parameter	#8004 SPEED	#8012 G73n	#8052 PULL UP
	#8005 ZONE r	#8013 G83n	#8053 G73U
	#8006 ZONE d	#8016 G71 MINIMUM	#8054 W
	#8009 DSC. ZONE	#8017 G71 DELTA-D	#8056 G74 RETRACT
	#8010 ABS. MAX.	#8018 G84/G74n	#8057 G76 LAST-D
	#8011 INC. MAX.	#8051 G71 THICK	
Axis parameter	#8204 OT-CHECK-N		
	#8205 OT-CHECK-P		
	#8206 TOOL CHG.P		
	#8209 G60 Shift		
Barrier data	#8300 – #8306, #8311 – #8314		
Basic specification parameter	#1084 RadErr		

#8004 SPEED is 10 inches/min. unit for the inch system.

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
1050 (PR)	MemPrg	Not used.	
1051 (PR)	MemTol	Not used.	
1052 (PR)	MemVal	Not used.	
1060	SETUP Activate setup processing	<p>Execute the functions required for initializing the system.</p> <p>1: Execute one-touch setup</p> <p>Note: Most setup parameters will be initialized with one-touch setup, so confirm the data before executing.</p> <p>This parameter will automatically be set to 0 when the power is turned ON.</p>	1

5. BASE SPECIFICATIONS PARAMETERS

(SETUP PARAM 1. 3/16)

#	Items		Details	Setting range (unit)															
1061 (PR)	intabs	Manual ABS updating	Defines whether to update the absolute position data during automatic handle interrupt. This parameter is valid only when #1145 I_abs is set to 1.	0: Do not update (shift coordinates the amount of the interruption) 1: Update (same coordinates as when interrupt did not occur will be applied.)															
1062	T_cmp	Tool offset function	Specify whether the tool length offset and wear compensation is valid during T command execution. <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: center;">Setting value</th> <th style="text-align: center;">Tool length offset</th> <th style="text-align: center;">Wear compensation</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">Valid</td> <td style="text-align: center;">Valid</td> </tr> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">Valid</td> <td style="text-align: center;">Invalid</td> </tr> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">Invalid</td> <td style="text-align: center;">Valid</td> </tr> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">Invalid</td> <td style="text-align: center;">Invalid</td> </tr> </tbody> </table>	Setting value	Tool length offset	Wear compensation	0	Valid	Valid	1	Valid	Invalid	2	Invalid	Valid	3	Invalid	Invalid	0 to 3
Setting value	Tool length offset	Wear compensation																	
0	Valid	Valid																	
1	Valid	Invalid																	
2	Invalid	Valid																	
3	Invalid	Invalid																	
1063	mandog	Manual dog-type	The initial return to the reference point is performed with dog-type return after the power is turned ON, and the coordinate system is established. Specify the manual reference point return method after the coordinate system is established with this parameter. (This setting is not required when using absolute position detection.)	0: High speed return 1: Dog-type															
1064 (PR)	svof	Error correction	Specify whether to correct the error when the servo is OFF.	0: Do not correct the error 1: Correct the error															

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
1065	JOG_H JOG response type	<p>Set up an improved JOG response type.</p> <p>0: Conventional specification The system is started and stopped by signal via ladder without reference to external input signals.</p> <p>1: Type 1 The system is started up and stopped by external signal.</p> <p>2: Type 2 The system is started up and stopped by performing the AND operation for external signals and those via ladder.</p> <p>3: Type 3 The system is started up when signals via ladder rise. It is stopped when external signals and those via ladder fall.</p> <p>4: Type 4 Zero point return mode: The system is started up and stopped by signal via ladder without reference to external input signals (conventional specification). Non-zero point return mode: The system is started up and stopped by performing AND for external signals and those via ladder (type 2).</p>	0 to 4
1066	JOG_HP Select JOG activation (+) device	Specify the number of the device that inputs +JOG activation signals. The device type is specified by JOG_D in #1071. The effective range of set values vary depending on the device type. A value outside of the effective range is invalid if specified.	X: 0000 to 013F (hexadecimal) M: 0000 to 5119 (decimal)
1067	JOG_HN Select JOG activation (-) device	Specify the number of the device that inputs -JOG activation signals. The device type is specified by JOG_D in #1071. The effective range of set values vary depending on the device type. A value outside of the effective range is invalid if specified.	X: 0000 to 013F (hexadecimal) M: 0000 to 5119 (decimal)
1068 (PR)	slavno	Not used.	

5. BASE SPECIFICATIONS PARAMETERS

#	Items		Details	Setting range (unit)
1069 (PR)	no_dsp	Axis with no counter display	Set up an axis that displays no counter. This option is valid on the counter display screen (relative value screen).	0: Displays the counter 1: Does not display the counter.
1070	axoff	Axis removal	Define an axis that enables axis removal control.	0: Disables axis removal. 1: Enables axis removal
1071 (PR)	JOG_D	±JOG activation signal device name	Specify the number of the device that inputs ±JOG activation signals. Set the JOG_HP (#1066) and JOG_HN (#1067) parameters according to this device specification parameter.	0: X device 2: M device
1072	chop_ax	Chopping axis	Designate the chopping axis.	0: Non-chopping axis 1: Chopping axis

5. BASE SPECIFICATIONS PARAMETERS

(SETUP PARAM 1. 4/16)

#	Items	Details	Setting range (unit)
1073	I_Absm	Initial absolute value	Specify the absolute value/incremental value mode for when the power is turned ON or reset. 0: Incremental value command mode 1: Absolute value command mode
1074	I_Sync	Initial synchronous feed	Specify the feedrate specification mode for when the power is turned ON or reset. 0: Asynchronous feed (feed per minute) 1: Synchronous feed (feed per rotation)
1075	I_G00	Initial G00	Specify the linear command mode for when the power is turned ON or reset. 0: Linear interpolation (G00 command state) 1: Positioning (G01 command state)
1076	AbsInc (For L system only)	ABS/INC address	The absolute value/incremental commands can be issued by using the absolute value address and incremental value address for the same axis. 0: Absolute/incremental with G command 1: Absolute/incremental with address code (The #1013 axname address will be the absolute value command, and #1014 incax address will be the incremental value command)
1077	radius	Incremental command for diameter specification axis	Specify if the diameter specification axis' (#1019 dia is set to 1) incremental value command uses the diameter value or radius value 0: Diameter value 1: Radius value
1078	Decpt2	Decimal point type 2	Specify the unit of position commands that do not have a decimal point. 0: The min. input command unit is used (follows #1015 cunit) 1: 1mm (or 1inch) unit is used (For the dwell time, 1s unit is used.)
1079	F1digit	Validate F1 digit	Specify whether to execute the F command with a 1-digit code command or with a direct numerical command. 0: Direct numerical command (command feedrate during feed per minute or rotation) 1: 1-digit code command (feedrate specified with #1185 spd_F1 – #1189 F5)
1080	Dril_Z (For D system only)	Specify boring axis	Specify a fixed cycle hole drilling axis. 0: Use an axis vertical to the selected plane as the hole drilling axis. 1: Use the Z axis as the hole drilling axis regardless of the selected plane.

5. BASE SPECIFICATIONS PARAMETERS

#	Items		Details	Setting range (unit)
1081	Gmac_P	Give priority to G code parameter	Specify the G code priority relationship during the macro call with the G command. 0: G code used in system is priority. 1: Registered G code for call out is priority.	0/1
1082	Geomet (For L system only)	Geometric	Specify whether to use the geometric I or IB function. 0: Do not use. 1: Use only geometric I. 2: Use geometric I and IB. With geometric, specific address codes are used for exclusive meanings. Thus, if A or C is used for the axis address or 2nd miscellaneous command code, the A used for the axis address may function as the geometric's angle designation. Take special care when designating the axis name, etc., when using this function.	0/1/2
1084	RadErr	Arc error	Specify the tolerable error range when a deviation occurs in the end point and center coordinate in the circular command.	0 to 1.000 (mm)
1085	G00Drn	G00 dry run	Specify whether to apply dry run (feed with manual setting speed instead of command feedrate) to the G00 command. 0: Do not apply to G00. (move at rapid traverse rate) 1: Apply to G00. (move at manual set feedrate)	0: Do not apply to G00 1: Apply to G00
1086	G0Intp	G00 non-interpolation	Specify the G00 movement path type 0: Move linearly toward the end point. (interpolation type) 1: Move to the end point of each axis at the rapid traverse feedrate for each axis. (non-interpolation)	0/1
1087	G96_G0	Constant surface speed control by rapid traverse feed command	Specify how to handle the cycle speed for the G00 command when using the constant surface speed control function. 0: Calculate the cycle speed constantly even during G00 movement. 1: Calculate the cycle speed at the block end point in the G00 command.	0/1
1088	G30SL	Disable G30 soft limit	Specify how to handle the soft limit during G30 (2nd, 3rd and 4th reference point return) movement. 0: Soft limit valid during G30 movement 1: Soft limit invalid during G30 movement	0: Soft limit valid 1: Soft limit invalid
1089	Cut_RT	Short cut for rotary axis	Specify how to handle the short cut control for the rotary axis (#1017 rot is set to 1). 0: No short cut (move toward end point) 1: Use short cut (when using the absolute value command, move in the direction where the movement amount will be 180° or less)	0: No short cut 1: Use short cut

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
1090	Lin_RT Linear rotary axis	Specify how to handle a command for the rotary axis that exceeds 360°. 0: For absolute value commands that exceed 360°, the value will be converted into a remainder of 360° and the axis will move. Example: If the command is 420°, the applied value will be 60°. 1: For absolute value commands that exceed 360°, the axis will move in the same manner as a linear axis. Example: If the command is 420°, the axis will pass the 360° position and will move to the 60° position.	0/1
1091	Mpoint Ignore middle point	Specify how to handle the middle point during G28 and G30 reference point return. 0: Move to the reference point after passing the middle point designated in the program. 1: Ignore the middle point designated in the program and move straight to the reference point.	0/1
1092	Tchg_A Replace tools for additional axis	Specify the movement of the additional axis during tool change position return. 0: The additional axis does not move with the tool change position return command. 1: After returning the standard axis with the tool change position return command, the additional axis also returns to the tool change position.	0/1
1093	Wmvfin	Not used.	
1094	TI_SBK (for L system only) Select life count for single block	Select whether to count the data units to be used for a single block when using the tool life management II function (L system). 0: Does not count the data units. 1: Count the data units.	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
1095	T0tfof TF output	Select how to handle TF for T00 command. 0: TF is output. 1: TF is not output	0/1
1096	T_Ltyp (for L system only) Tool life management type	Specify the tool life management type.	1: Life management type I 2: Life management type II
1097	T1digt Tool wear compensation number 1-digit command	Specify the No. of digits in the tool wear compensation No. in the T command. 0: The 2 high-order digits are the tool No., and the 2 low-order digits are the wear compensation No. 1: The 3 high-order digits are the tool No., and the 1 low-order digit is the wear compensation No. This parameter will be fixed to 0 when tool life management II is selected.	0/1
1098	Tlno. Tool length offset number	Specify the No. of digits in the tool length offset No. in the T command. 0: The 2 or 3 high-order digits are the tool No. The 2 or 1 low-order digits are the tool length offset and wear compensation Nos. 1: The 2 or 3 high-order digits are the tool No. and tool length offset Nos. The 2 or 1 low-order digits are the wear compensation No.	0/1
1099	Treset Cancel tool wear compensation amount	Specify how to handle tool compensation vector when resetting system. 0: Clear the tool length and wear compensation vectors when resetting. 1: Save the tool length and wear compensation vectors when resetting. When the values are cleared, the compensation will not be applied, so the axis will move the compensation amount in the next compensation operation. When the values are saved, the compensation will be applied, so the axis will shift the differential amount of the compensation amount in the next compensation operation.	0: Clear 1: Save

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
1100	Tmove Tool wear compensation	Specify the period to perform tool length offset and wear compensation. 0: Compensate when T command is executed. 1: Superimpose and compensate with the movement command in the block where the T command is located. If there is no movement command in the same block, compensation will be executed after the movement command is superimposed in the next movement command block. 2: Compensate when the T command is executed. 1: Superimpose and compensate a tool length offset with the movement command in the same block. If there is no movement command in the same block, compensation will be executed after the movement command is superimposed in the next movement command block.	0 to 2
1101	Tabsmv Tool wear compensation method	Specify the type of movement command when #1100 Tmove is set to 1. 0: Compensate regardless of the movement command type. 1: Compensate only at the movement command in the absolute value command.	0: Compensate regardless of the command type. 1: Compensate only with the absolute value command.
1102	tIm (For L system only) Manual tool length measuring system	Specify the measurement method for manual tool measurement I. 0: Align tool with reference position 1: Input measurement results	0: Reference position method 1: Measured value input method
1103	T_life Validate life management	Select the usage of the tool life management function.	0: Do not use. 1: Perform tool life management control.
1104	T_Com2 Tool command method 2	Select the command method for when #1103 T_Life is set to 1. 0: Handle the program tool command as the group No. 1: Handle the program tool command as the tool No.	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
1105	T_Sel2 Tool selection method 2	Select the tool selection method for when #1103 T_Life is set to 1. 0: Select in order of registered No. from the tools used in the same group. 1: Select the tool with the longest remaining life from tools used in the same group and the unused tools.	0/1
1106	Tcount (For L system only) Life management count	Specify the function when address N is omitted when inputting data (G10 L3 command) for tool life management function II.	0: Time specified input 1: No. of times specified input
1107	TlIfsc (For L system only) Split life management display screen	Set up the number of groups to be displayed on the tool life management II (L system) screen. 0: Displayed group count 1, maximum number of registered tools: 16 1: Displayed group count 2, maximum number of registered tools: 8 2: Displayed group count 4, maximum number of registered tools: 4	0 to 2
1108	TirectM (For L system only) Life management re-count M code	Set up the M code for tool life management II (L system) re-count.	0 to 99
1109 (PR)	subs_M Validate alternate M code	Select the user macro interrupt with the substitute M code.	0: Alternate M code invalid 1: Alternate M code valid
1110	M96_M M96 alternate M code	Specify an M code to replace M96 when #1109 subs_M is set to 1.	3 to 97 (excluding 30)
1111	M97_M M97 alternate M code	Specify an M code to replace M97 when #1109 subs_M is set to 1.	3 to 97 (excluding 30)
1112 (PR)	S_TRG Validate status trigger system	Specify the validity conditions for the user macro interrupt signal. 0: Valid when interrupt signal (UIT) turns OFF to ON. 1: Valid when interrupt signal (UIT) is ON.	0: Valid when interrupt signal (UIT) turns OFF to ON. 1: Valid when interrupt signal (UIT) is ON.
1113 (PR)	INT_2 Validate interrupt method type 2	Specify the movement after user macro interrupt signal (UIT) input. 0: Execute interrupt program without waiting for block being executed to end. 1: Execute interrupt program after completing block being executed.	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
1114	mcrint Macro argument initialization	Select whether to clear statements other than specified arguments by macro call. Also, select whether to clear local variables by power-ON and resetting. 0: Delete non-specified arguments by macro call. 1: Retain non-specified arguments by macro call. 2: Retain non-specified arguments by macro call and clear local variables by power-ON and resetting.	0/1/2
1115	thwait Waiting for thread cutting	Set the queue number during screw thread cutting when the chamfering is not valid.	0 to 99 (Approx. 4 ms.) Standard set value: 4
1116	G30SLM Invalidate soft limit (manual operation)	Enable this function when disabling the soft limit check function from the second to the fourth zero point return by manual operation.	0: Enable soft limit function. 1: Disable soft limit function.
1117	H_sens Handle response switch	Switch the handle response mode when feeding the handle. 0: Standard handle response 1: High-speed handle response	0/1
1118	mirr_A (For L system only)	Not used.	
1119	Tmiron (For L system only)	Not used.	
1120 (PR)	TofVal Change macro variable	Specify whether to change the macro variable (tool offset) numbers for shape compensation and wear compensation. 0: Do not change. (Conventional specifications) 1: Change the shape and wear compensation variable numbers each for X, Z, and R.	0/1

5. BASE SPECIFICATIONS PARAMETERS


(SETUP PARAM 1. 5/16)

#	Items	Details	Setting range (unit)	
1121	edlk_c	Edit lock C	Specify whether to prohibit editing of program Nos. 9000 to 9999. Note: If #1122 is set to 1 or 2, 1 will be set in #1121 when the power is turned ON.	0: Editing possible 1: Editing prohibited
1122 (PR)	pglk_c	Program display lock	The display and search of program Nos. 9000 to 9999 can be prohibited. Specify whether to prohibit display and search. 0: Display and search is possible. 1: Program details are not displayed. 2: Program details are not displayed, and operation search is prohibited. The program details will not be displayed, but the program No. and sequence No. will display in the prohibited state. Note: If #1122 is set to 1 or 2, 1 will be set in #1121 when the power is turned ON.	0 to 2
1123	origin	Origin zero inhibition	Select whether to use the origin zero function.	0: Use 1: Do not use
1124	ofsfix	Fix tool wear compensation number	Specify whether to automatically increment the offset No. by 1 with the input or to display the No. as it is in the setting on the tool offset screen. 0: Increment the # No. by 1 when the input key is pressed. (Same as general parameters) 1: # No. does not change even if INPUT key is pressed. When making settings in sequence, 0 is handier. When changing and setting repeatedly while adjusting one offset value, 1 is handier	0/1
1125	real_f	Actual feedrate display	Specify the feedrate display on the monitor screen.	0: Command speed 1: Real movement feedrate
1126	PB_G90	Playback G90	Specify whether the playback movement amount when performing playback editing is to be an absolute value or incremental value.	0: Incremental value 1: Absolute value
1127	DPRINT	DPRINT alignment	Specify the alignment for printing out with the DPRINT function. 0: No alignment, data is printed with left justification. 1: Align the minimum digit and output.	0/1

5. BASE SPECIFICATIONS PARAMETERS

#		Items	Details	Setting range (unit)
1128	RstVCI	Clear variables by resetting	Specify how to handle the common variables when resetting. 0: Common variables do not change after resetting. 1: Common variables #100 to 199 are cleared by resetting.	0/1
1129	PwrVCI	Clear variables by power-ON	Specify how to handle the common variables when the power is turned ON. 0: The common variables are in the same state as before turning the power OFF. 1: Common variables #100 to 199 are cleared when the power is turned ON.	0/1
1130	set_t	Display selected tool number	Specify the tool command value display on the POSITION screen. 0: T-modal value of program command is displayed. 1: Tool number sent from PLC is displayed.	0/1
1131 (PR)	Fldcc	Feed forward filter	Parameter to suppress acceleration changes with a filter when starting acceleration or deceleration Specify the parameter in bits. <div style="text-align: center;"> </div>	bit1: 7.1 (ms) bit2: 14.2 (ms) bit3: 28.4 (ms) bit4: 56.8 (ms) bit5: 113.6 (ms) If bit 1 to bit 5 are all 0 or two or more bits of bit 1 to bit 5 are 1, 3.5 ms is set up.
1132	CRT	LCD brightness control	This parameter adjusts the brightness of the LCD display unit. 3: Highest luminance (Brightest state) -3: Lowest luminance (Darkest state) Adjust this parameter to an appropriate brightness between -3 and 3.	-3 to 3


5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
1133	ofsmem Select how to set up tool wear compensation screen	Select the number stored by previous setup when selecting the tool wear compensation screen. 0: Does not display the number when selecting the screen. 1: Displays the stored number when selecting the screen.	0/1
1134	LCDneg LCD reverse display	Specify 1 to reverse the display on the monochrome LCD.	0: Normal display 1: Reverse display
1135	unt_nm Unit name	Set up a unit name. Set up the unit name with 4 or less characters consisting of both alphabets and numbers. If 0 is set up, the unit name is not displayed.	4 or less characters consisting of both alphabets and numbers
1136	optype Operation menu display valid	This parameter validates the operation menu display. Specify the setting method for the tool offset data's absolute value or incremental value. 0: Mode selection method (Conventional specification) 1: Menu selection method This parameter is valid on the following screens. • TOOL TIP OFFSET screen (L system) • TOOL DATA screen (L system) • NOSE-R screen (L system) • TOOL OFFSET screen type I (M system) • TOOL OFFSET screen type II (M system)	0/1
1137	Cntsel Coordinate value screen display counter select	Set the type of the position counter to be displayed on the COORDINATE screen. 	1st digit : 0 to 3 2nd digit: 0 to 3 (Default : 00)
1138	Prosel Select screen by parameter number:	Specify whether to enable the function to select a screen by specifying a parameter number.	0: Disable 1: Enable


5. BASE SPECIFICATIONS PARAMETERS

#	Items		Details	Setting range (unit)
1139	edtype	Edit type selection	Set up an edit type. 0: Screen edit type (M50 or equivalent operation) 1: Screen edit type (The screen of EDIT or MDI is changed automatically according to the selected operation mode.) 2: Word edit type (The screen of EDIT or MDI is changed automatically according to the selected operation mode.) 3: Screen edit type (type 0 + retaining cursor position) 4: Screen edit type (type 1 + retaining cursor position)	0/1/2/3/4
1140	Mn100	M code number	First number of M code that corresponds to setup number from 100 to 199	0 to 99999999
1141	Mn200	M code number	First number of M code that corresponds to setup number from 200 to 299	0 to 99999999
1142	Mn300	M code number	First number of M code that corresponds to setup number from 300 to 399	0 to 99999999
1143	Mn400	M code number	First number of M code that corresponds to setup number from 400 to 499	0 to 99999999
1144	mdlkof	MDI setup lock	Select whether to enable MDI setup in non-MDI mode.	0: Disable MDI setup 1: Enable MDI setup
1145	I_abs	Manual ABS parameter	Specify how to handle the absolute value data during automatic handle interrupt. 0: Absolute value data is renewed if manual ABS switch is ON. Data is not renewed if switch is OFF. 1: Follows the intabs state when #1061 intabs is valid.	0/1
1146	Sclamp	Spindle rotation speed clamp function	Specify how to handle the spindle rotation speed clamp function with the G92S command. 0: G92S command is handled as a clamp command only in the G96 state (during constant surface speed control). G92S will be handled as normal S command in G97 state (constant surface speed OFF). 1: The S command in the same block as G92 is constantly handled as a clamp command.	0/1
1147	smin_V	Minimum spindle rotation speed clamp type	Specify the type of spindle min. rotation speed clamp value. 0: Rotation speed setting 1: Output voltage coefficient setting Set the #3023 smini parameter according to this type setting.	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)	
1148	I_G611	Initial high precision	The modal state when the power is turned ON is set to the high accuracy control mode. 0: OFF 1: ON	0/1
1149	cireft	Arc deceleration speed change	Specify whether to enable deceleration at the arc entrance or exit. 0: Disable 1: Enable	0/1
1150	F1dc0	G00 feed forward filter	This parameter is used to filter acceleration changes at the start of rapid acceleration/deceleration. Specify the filters in bit units.  <p style="text-align: center;">0: Common 1: Separation</p>	bit1: 7.1 (ms) bit2: 14.2 (ms) bit3: 28.4 (ms) bit4: 56.8 (ms) bit5: 113.6 (ms) When bits 1 to 5 are all 0 or when two or more of bits 1 to 5 are 1, 3.5 (ms) is assumed.
1151	rstint	Reset initial	Specify whether to initialize (power ON state) the modals by resetting. 0: Do not initialize modal state. 1: Initialize modal state.	0/1
1152	I_G20	Initial command unit	Specify whether the default mode after power-ON or resetting, inch command or metric command mode. 0: Metric command (G21 command state) 1: Inch command (G20 command state) Valid when reset input is made. Related parameter: Bit 6 "Select setting and display unit" of #1226	0/1
1153	FixbDc	Hole bottom deceleration check	Specify whether to perform a deceleration check or in-position check at the hole bottom in the hole drilling cycle. This parameter is valid only for a hole drilling cycle in which no dwell command can be issued at the hole bottom. 0: Perform no deceleration check and in-position check. 1: Perform a deceleration check. 2: Perform an in-position check.	0 to 2

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
1154 (PR)	pdoor Door interlock II (for each system)	<p>Specify whether to control door interlock II independently for each of the two systems. When door interlock II is controlled for each system of the two systems, system 1 is connected to SV1 (channel 1) of the base I/O unit and system 2 is connected to SV2 (channel 2) of the base I/O unit.</p> <p>Base I/O unit</p>  <p>When the auxiliary axis (MR-J2-CT) is used, connect it to the SV2 side (after the spindle). This validates door interlock II of system 2.</p> <ul style="list-style-type: none"> 0: Do not use door interlock II independently for channels. 1: Use door interlock II independently for channels. (Separate systems when using two systems) 2: Use door interlock II independently for channels. (Use independently for system 1 channels) (Use both for system 2) <p>When 0 is specified for this parameter, "Signal input device 1 for door interlock II (#1155 DOOR_m)" and "Signal input device 2 for door interlock II (#1156 DOOR_s)" are valid. When 1 is specified, "Signal input device 1 for door interlock II: for each system (#1511 DOORPm)" and "Signal input device 2 for door interlock II: for each system (#1512 DOORPs)".</p>	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)	
1155	DOOR_m	Signal input device 1 for door interlock II	Set up a fixed device number (X??) for door interlock II signal input. A device number from X01 to XFF can be set up. Device number 000 is invalid. Set up device number 100 when using no fixed device number for door interlock II signal input. Related parameter: #1154 pdoor Door interlock II (for each system)	000 to 100 (Hexadecimal)
1156	DOOR_s	Device number 2 for door interlock II signal input	Set up a fixed device number (X??) for door interlock II signal input. (Set up the same value as that of #1155.) Related parameter: #1154 pdoor Door interlock II (for each system)	000 to 100 (Hexadecimal)
1157	F0atrn	F0 automatic running	Not used	
1158	F0atno	F0 automatic running program	Not used	
1165	p_trans		Not used.	
1166	fixpro	Fixed cycle editing	Select whether to use the edit, program list and data input/output functions for the fixed cycles, machine manufacturer macro programs or general programs. 0: General programs can be edited, etc. 1: The fixed cycles can be edited, etc. Password No.: The machine manufacturer macro programs can be edited, etc.	0 to 99999999
1167	e2rom		Not used.	
1168	test	Simulation test	Specify the test mode for the control unit. The test mode does not use reference point return, and tests with a hypothetical zero point return completed state. This is limited to test operation of the control unit itself, and must not be used when connected to the machine.	0: Normal operation mode 1: Test mode

5. BASE SPECIFICATIONS PARAMETERS

(SETUP PARAM 1. 6/16)

#	Items	Details	Setting range (unit)																																							
1169	system name	Not used.																																								
1170	M2name	Second miscellaneous code	Set this address code when using the 2nd miscellaneous command. Set an address with A, B and C that is not used with #1013 axname or #1014 incax.																																							
1171	taprov	Tap return override	Set the tap return override value for the synchronous tap.																																							
1172	tapovr	Tap return override	Set the override value when leaving the tap end point in the synchronous tap cycle. The setting range is 1 to 999, and the unit is %. When a value less than 100 is set, it will be judged as 100%.																																							
1173	dwlskp	G04 skip condition	Specify the skip signal for ending the G04 (dwell) command.																																							
			<p>Skip condition 0 to 7</p> <table border="1"> <thead> <tr> <th rowspan="2">Setting</th> <th colspan="3">PLC interface input signal</th> </tr> <tr> <th>Skip 3</th> <th>Skip 2</th> <th>Skip 1</th> </tr> </thead> <tbody> <tr><td>0</td><td>×</td><td>×</td><td>×</td></tr> <tr><td>1</td><td>×</td><td>×</td><td>○</td></tr> <tr><td>2</td><td>×</td><td>○</td><td>×</td></tr> <tr><td>3</td><td>×</td><td>○</td><td>○</td></tr> <tr><td>4</td><td>○</td><td>×</td><td>×</td></tr> <tr><td>5</td><td>○</td><td>×</td><td>○</td></tr> <tr><td>6</td><td>○</td><td>○</td><td>×</td></tr> <tr><td>7</td><td>○</td><td>○</td><td>○</td></tr> </tbody> </table> <p>End when ○ signal is input.</p>	Setting	PLC interface input signal			Skip 3	Skip 2	Skip 1	0	×	×	×	1	×	×	○	2	×	○	×	3	×	○	○	4	○	×	×	5	○	×	○	6	○	○	×	7	○	○	○
Setting	PLC interface input signal																																									
	Skip 3	Skip 2	Skip 1																																							
0	×	×	×																																							
1	×	×	○																																							
2	×	○	×																																							
3	×	○	○																																							
4	○	×	×																																							
5	○	×	○																																							
6	○	○	×																																							
7	○	○	○																																							
1174	skip_F	G31 skip speed	Specify the feedrate when there is no F command in the program at G31 (skip) command.																																							
1175	skip1	G31.1 skip condition	Specify the skip signal in the G31.1 to G31.3 (multi-step skip) command, and the feedrate when there is no F command in the program. Skip signal specified at G31.1																																							
1176	1f	G31.2 skip speed	Skip feedrate at G31.1																																							
1177	2	G31.2 skip condition	Skip signal specified at G31.2																																							
1178	2f	G31.2 skip speed	Skip feedrate at G31.2																																							
1179	3	G31.3 skip condition	Skip signal specified at G31.3																																							
1180	3f	G31.3 skip speed	Skip feedrate at G31.3																																							
			<p>Skip condition 0 to 7</p> <table border="1"> <thead> <tr> <th rowspan="2">Setting</th> <th colspan="3">PLC interface input signal</th> </tr> <tr> <th>Skip 3</th> <th>Skip 2</th> <th>Skip 1</th> </tr> </thead> <tbody> <tr><td>0</td><td>×</td><td>×</td><td>×</td></tr> <tr><td>1</td><td>×</td><td>×</td><td>○</td></tr> <tr><td>2</td><td>×</td><td>○</td><td>×</td></tr> <tr><td>3</td><td>×</td><td>○</td><td>○</td></tr> <tr><td>4</td><td>○</td><td>×</td><td>×</td></tr> <tr><td>5</td><td>○</td><td>×</td><td>○</td></tr> <tr><td>6</td><td>○</td><td>○</td><td>×</td></tr> <tr><td>7</td><td>○</td><td>○</td><td>○</td></tr> </tbody> </table> <p>Skip feedrate 1 to 999999 (mm/min)</p>	Setting	PLC interface input signal			Skip 3	Skip 2	Skip 1	0	×	×	×	1	×	×	○	2	×	○	×	3	×	○	○	4	○	×	×	5	○	×	○	6	○	○	×	7	○	○	○
Setting	PLC interface input signal																																									
	Skip 3	Skip 2	Skip 1																																							
0	×	×	×																																							
1	×	×	○																																							
2	×	○	×																																							
3	×	○	○																																							
4	○	×	×																																							
5	○	×	○																																							
6	○	○	×																																							
7	○	○	○																																							

5. BASE SPECIFICATIONS PARAMETERS


#	Items	Details	Setting range (unit)
1181	G96_ax Constant surface speed control	Specify the axis to be targeted for constant surface speed control. 0: Program specification will be invalidated, and the axis will always be fixed to the 1st axis. 1: 1st axis specification 2: 2nd axis specification 3: 3rd axis specification 4: 4th axis specification The program specification will be the priority for all settings other than 0.	0 to 4
1182	thr_F Thread cutting speed	Set the screw cut up speed when not using chamfering in the thread cutting cycle. 0: Cutting feed clamp feedrate 1 to 60000 mm/min: Set feedrate	0 to 60000 (mm/min)
1183	clmp_M M code for clamp	Set the M code for C-axis clamp in the hole drilling cycle.	0 to 99999999
1184	clmp_D Dwelling time after outputting M code for unclamp	Set the dwell time after outputting the M code for C-axis unclamp in the hole drilling cycle.	0.000 to 99999.999 (s)
1185	spd_F1 F1	Specify the feedrate for the F command in the F1-digit command (#1079 F1 digit is set to 1). Feedrate when F1 is issued (mm/min)	1 to 60000 (mm/min)
1186	F2 F2	Feedrate when F2 is issued (mm/min)	
1187	F3 F3	Feedrate when F3 is issued (mm/min)	
1188	F4 F4	Feedrate when F4 is issued (mm/min)	
1189	F5 F5	Feedrate when F5 is issued (mm/min)	
1190 (PR)	s_xcnt (For L system only) Validate inclined-axis control	Specify whether to disable or enable inclined-axis control. 0: Disable inclined-axis control 1: Enable inclined-axis control	0/1
1191 (PR)	s_angl (For L system only) Inclination angle	Specify the inclination angle (θ). Note: If 0 is specified for this parameter, the angle determined by three-side setting is valid.	± 80.000 ($^{\circ}$)
1192 (PR)	s_zrmv (For L system only) Compensation at origin return	Specify whether to perform compensation for the base axis corresponding to the inclined axis at original return. 0: Perform compensation. 1: Don't perform compensation.	0/1

5. BASE SPECIFICATIONS PARAMETERS

(SETUP PARAM 1. 7/15)

#	Items	Details	Setting range (unit)	
1193	inpos	The setting is selected with "#1306 InpsTyp Deceleration check specification type". 0: Deceleration check method 1 1: Validate in-position check	/	
		Deceleration check method 1	Specify the deceleration check method for G0. 0: Command deceleration check 1: In-position check	0/1
		Validate in-position check	Specify the deceleration confirmation method for the positioning or cutting command. 0: G0, G1+G9 Command deceleration check 1: G0, G1+G9 In-position check	0/1
1194	H_acdc	Time constant 0 for handle feed 0: Use time constant for G01 1: Time constant 0 (step)	Specify the time constant for the manual handle feed. 0: Use time constant for G01 1: Time constant 0 (step)	0/1
1195 1196 1197 1198	Mmac Smac Tmac M2mac	Macro call for M command Macro call for S command Macro call for T command Macro call with 2nd miscellaneous code	Specify the user macro M, S or T command macro call out. Macro call out with M command Macro call out with S command Macro call out with T command Macro call out with 2nd miscellaneous command	0: Invalid 1: Valid
1199	Sselect	Select initial spindle control	Select the initial condition of spindle control after power is turned ON. 0: 1st spindle control mode (G43.1) 1: Selected spindle control mode (G44.1) 2: All spindle simultaneously control mode (G47.1) Note: Spindle No. when G44.1 is commanded is selected with #1534 SnG44.1.	0: G43.1 1: G44.1 2: G47.1
1200 (PR)	G0_acc	Validate acceleration and deceleration with inclination angle constant G0	Set up acceleration and deceleration types when a rapid traverse command is issued 0: Acceleration and deceleration (conventional) with time constant 1: Acceleration and deceleration with inclination angle constant	0: Acceleration and deceleration with time constant 1: Acceleration and deceleration with inclination angle constant

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
1201 (PR)	G1_acc Validate acceleration and deceleration with inclination constant G1	Set up acceleration and deceleration types when a liner interpolation command is issued. 0: Acceleration and deceleration (conventional) with time constant 1: Acceleration and deceleration with inclination angle constant	0: Acceleration and deceleration with time constant 1: Acceleration and deceleration with inclination angle constant
1202	mirofs (For L system only)	Not used.	
1203	TmirS1 (For L system only)	Not used.	
1204	TmirS2 (For L system only)	Not used.	
1205	G0bdcc Acceleration and deceleration before G0 interpolation	0: G00 acceleration and deceleration are selected as those after interpolation. 1: The G00 acceleration/deceleration is the acceleration/decelerate before interpolation regardless of whether the mode is the high accuracy control mode.	0/1
1206	G1bF Maximum speed	Set up a cutting feedrate when selecting acceleration and deceleration before interpolation.	1 to 999999 (mm/min)
1207	G1btL Time constant	Set up a cutting feed time constant when selecting acceleration and deceleration before interpolation. 	1 to 5000 (ms)
1208	RCK	Not used.	

5. BASE SPECIFICATIONS PARAMETERS

#	Items		Details	Setting range (unit)																																																																
1209	cirdcc	Arc deceleration speed	Specify the deceleration speed at the arc entrance or exit.	1 to 999999 (mm/min)																																																																
1210	RstGmd	Modal G code reset	<p>Specify whether to initialize each G code group modal and the H and D codes when the system is reset. Specify the initialization items in bit correspondence.</p> <p>0. Initialize. 1: Don't initialize.</p> <p>M system</p> <table border="1" data-bbox="528 566 1150 1066"> <tr><td>0</td><td>Group 1 Move G modal</td></tr> <tr><td>1</td><td>Group 2 Flat selection modal</td></tr> <tr><td>2</td><td>Group 3 Absolute/increment command modal</td></tr> <tr><td>3</td><td></td></tr> <tr><td>4</td><td>Group 5 Feed G modal</td></tr> <tr><td>5</td><td>Group 6 Inch/metric modal</td></tr> <tr><td>6</td><td>Group 7 Radius compensation modal</td></tr> <tr><td>7</td><td>Group 8 Length compensation modal</td></tr> <tr><td>8</td><td></td></tr> <tr><td>9</td><td>Group 10 Fixed cycle return command modal</td></tr> <tr><td>A</td><td></td></tr> <tr><td>B</td><td>Group 12 Workpiece coordinate system modal</td></tr> <tr><td>C</td><td>Group 13 Cut modal</td></tr> <tr><td>D</td><td></td></tr> <tr><td>E</td><td>System reserve</td></tr> <tr><td>F</td><td></td></tr> </table> <table border="1" data-bbox="528 1140 1150 1639"> <tr><td>10</td><td>Group 17 Constant surface speed control command modal</td></tr> <tr><td>11</td><td>Group 18 pole coordinate command modal</td></tr> <tr><td>12</td><td>Group 19 G command mirror modal</td></tr> <tr><td>13</td><td>Group 20 Spindle 2 control modal</td></tr> <tr><td>14</td><td></td></tr> <tr><td>15</td><td></td></tr> <tr><td>16</td><td></td></tr> <tr><td>17</td><td></td></tr> <tr><td>18</td><td>H, D codes</td></tr> <tr><td>19</td><td>Spindle clamp rotation speed</td></tr> <tr><td>1A</td><td></td></tr> <tr><td>1B</td><td></td></tr> <tr><td>1C</td><td></td></tr> <tr><td>1D</td><td></td></tr> <tr><td>1E</td><td></td></tr> <tr><td>1F</td><td></td></tr> </table> <p>The H code indicates the tool length offset number, and the D code indicates the tool radius compensation number.</p> <p>When bit 18 is set to ON, the H and D codes and group 8 G modal area retained.</p> <p>When bit 7 is set to ON, the H code and group 8 G modal are retained.</p> <p>(To be continued to the next page)</p>	0	Group 1 Move G modal	1	Group 2 Flat selection modal	2	Group 3 Absolute/increment command modal	3		4	Group 5 Feed G modal	5	Group 6 Inch/metric modal	6	Group 7 Radius compensation modal	7	Group 8 Length compensation modal	8		9	Group 10 Fixed cycle return command modal	A		B	Group 12 Workpiece coordinate system modal	C	Group 13 Cut modal	D		E	System reserve	F		10	Group 17 Constant surface speed control command modal	11	Group 18 pole coordinate command modal	12	Group 19 G command mirror modal	13	Group 20 Spindle 2 control modal	14		15		16		17		18	H, D codes	19	Spindle clamp rotation speed	1A		1B		1C		1D		1E		1F		Specify a hexadecimal number.
0	Group 1 Move G modal																																																																			
1	Group 2 Flat selection modal																																																																			
2	Group 3 Absolute/increment command modal																																																																			
3																																																																				
4	Group 5 Feed G modal																																																																			
5	Group 6 Inch/metric modal																																																																			
6	Group 7 Radius compensation modal																																																																			
7	Group 8 Length compensation modal																																																																			
8																																																																				
9	Group 10 Fixed cycle return command modal																																																																			
A																																																																				
B	Group 12 Workpiece coordinate system modal																																																																			
C	Group 13 Cut modal																																																																			
D																																																																				
E	System reserve																																																																			
F																																																																				
10	Group 17 Constant surface speed control command modal																																																																			
11	Group 18 pole coordinate command modal																																																																			
12	Group 19 G command mirror modal																																																																			
13	Group 20 Spindle 2 control modal																																																																			
14																																																																				
15																																																																				
16																																																																				
17																																																																				
18	H, D codes																																																																			
19	Spindle clamp rotation speed																																																																			
1A																																																																				
1B																																																																				
1C																																																																				
1D																																																																				
1E																																																																				
1F																																																																				

5. BASE SPECIFICATIONS PARAMETERS

#	Items		Details	Setting range (unit)																																																																
			(Continued from the previous page) L system <table border="1" data-bbox="544 338 1166 842"> <tr><td>0</td><td>Group 1 Move G modal</td></tr> <tr><td>1</td><td>Group 2 Flat selection modal</td></tr> <tr><td>2</td><td>Group 3 Absolute/increment command modal</td></tr> <tr><td>3</td><td>Group 4 Barrier check modal</td></tr> <tr><td>4</td><td>Group 5 Feed G modal</td></tr> <tr><td>5</td><td>Group 6 Inch/metric modal</td></tr> <tr><td>6</td><td>Group 7 Nose R compensation modal</td></tr> <tr><td>7</td><td></td></tr> <tr><td>8</td><td></td></tr> <tr><td>9</td><td>Group 10 Fixed cycle return command modal</td></tr> <tr><td>A</td><td></td></tr> <tr><td>B</td><td>Group 12 Workpiece coordinate system modal</td></tr> <tr><td>C</td><td>Group 13 Cut modal</td></tr> <tr><td>D</td><td></td></tr> <tr><td>E</td><td></td></tr> <tr><td>F</td><td></td></tr> </table> <table border="1" data-bbox="544 898 1166 1402"> <tr><td>10</td><td>Group 17 Constant surface speed control command modal</td></tr> <tr><td>11</td><td>System reserve</td></tr> <tr><td>12</td><td></td></tr> <tr><td>13</td><td>Group 20 Spindle 2 control modal</td></tr> <tr><td>14</td><td>System reserve</td></tr> <tr><td>15</td><td></td></tr> <tr><td>16</td><td></td></tr> <tr><td>17</td><td></td></tr> <tr><td>18</td><td></td></tr> <tr><td>19</td><td></td></tr> <tr><td>1A</td><td></td></tr> <tr><td>1B</td><td></td></tr> <tr><td>1C</td><td></td></tr> <tr><td>1D</td><td></td></tr> <tr><td>1E</td><td></td></tr> <tr><td>1F</td><td></td></tr> </table>	0	Group 1 Move G modal	1	Group 2 Flat selection modal	2	Group 3 Absolute/increment command modal	3	Group 4 Barrier check modal	4	Group 5 Feed G modal	5	Group 6 Inch/metric modal	6	Group 7 Nose R compensation modal	7		8		9	Group 10 Fixed cycle return command modal	A		B	Group 12 Workpiece coordinate system modal	C	Group 13 Cut modal	D		E		F		10	Group 17 Constant surface speed control command modal	11	System reserve	12		13	Group 20 Spindle 2 control modal	14	System reserve	15		16		17		18		19		1A		1B		1C		1D		1E		1F		Specify a hexadecimal number.
0	Group 1 Move G modal																																																																			
1	Group 2 Flat selection modal																																																																			
2	Group 3 Absolute/increment command modal																																																																			
3	Group 4 Barrier check modal																																																																			
4	Group 5 Feed G modal																																																																			
5	Group 6 Inch/metric modal																																																																			
6	Group 7 Nose R compensation modal																																																																			
7																																																																				
8																																																																				
9	Group 10 Fixed cycle return command modal																																																																			
A																																																																				
B	Group 12 Workpiece coordinate system modal																																																																			
C	Group 13 Cut modal																																																																			
D																																																																				
E																																																																				
F																																																																				
10	Group 17 Constant surface speed control command modal																																																																			
11	System reserve																																																																			
12																																																																				
13	Group 20 Spindle 2 control modal																																																																			
14	System reserve																																																																			
15																																																																				
16																																																																				
17																																																																				
18																																																																				
19																																																																				
1A																																																																				
1B																																																																				
1C																																																																				
1D																																																																				
1E																																																																				
1F																																																																				
1211	FHtyp	Feed hold stop type	Specify the type of the external signal used for feed hold. 0: Disable the external signal. 1: Enable the external signal (contact A) 2: Enable the external signal (contact B)	0 to 2																																																																
1212	FHno	Feed hold external signal device	Specify the number (X??) of the device used to input the feed hold signal.	000 to 13F (hexadecimal)																																																																
1213	proaxy (For L system only)	Side 1 of inclination angle	Specify the length on the rectangular coordinates of the inclined axis in the triangle made up of the inclination angle.	±9999.999																																																																

5. BASE SPECIFICATIONS PARAMETERS


#	Items	Details	Setting range (unit)	
1214	macaxy (For L system only)	Side 2 of inclination angle	Specify the length of the actual base axis corresponding to the inclined axis in the triangle made up of the inclination angle.	±9999.999
1215	macaxx (For L system only)	Side 3 of inclination angle	Specify the length of the actual axis of the inclined axis in the triangle made up of the inclination angle.	±9999.999
1216	extdcc	External deceleration level	Use an upper limit value at the feedrate indicated when validating external deceleration signals. This parameter is valid when #1239 set11/bit6 is set to 0.	1 to 999999 (mm/min)

5. BASE SPECIFICATIONS PARAMETERS

(SETUP PARAM 1. 8/15)

#	Items	Details	Setting range (unit)
1217	aux01 (bit4)	Validity of title screen customization Enable or disable the title screen customization. 0: Disable 1: Enable	0/1
1218	aux02 (bit3)	Parameter input/output format Specify a parameter input/output format. 0: Type I 1: Type II (related to #1218 aux02/bit5)	0/1
	aux02 (bit4)	Tool number selection Specify the R register that contains the tool number used for automatic calculation when measuring the coordinate offset of an external workpiece. 0: Conforms to #1130 set_t. 1: Uses the tool number indicated by user PLC	0/1
	aux02 (bit5)	Parameter I/O II spindle specification address Specify the spindle specification address of parameter I/O type II. 0: C 1: T This parameter also applies to the spindle specification address for input and collation. Note: This parameter is valid only for parameter I/O type II (bit 3 of aux02 in #1218 is 1).	0/1
	aux02 (bit6)	Set No. valid when program input Specify which program No. is selected when inputting operation using "#1 MAIN PROGRAM" in Data I/O screen. 0: The No. in the input data is valid. 1: The No. set in the data setting area is valid.	0/1
	aux02 (bit7)	Input by program overwrite Select an action in the case where the input program No. already exists in the input destination when inputting the program. 0: An operation error (E65) occurs. 1: Input by overwrite. This parameter is valid for RS-232C input or remote program input.	0/1
1219	aux03 (bit1)	Stop high-speed PC monitoring function Set 1 to disable the function that stops the system when the high-speed processing time is extended. Disable the monitoring function only as a temporary measure.	0/1
	aux03 (bit2)	Improve skip coordinate accuracy 0: Skip accuracy (conventional specification) 1: Changes skip accuracy (correct a position in skip coordinates when entering skip signals).	0/1
	aux03 (bit5)	Dog-type intermediate point Select whether to move to the intermediate point during automatic dog-type reference point return. 0: Do not move to intermediate point during dog-type reference point return. 1: Move to intermediate point during dog-type reference point return.	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)	
1220	aux04 (bit 0) (For L system only)	Tool life check timing selection	Specify the life check standard applicable when the use count is incremented in tool life management II. 0: Determine that the tool life is over when the incremented use count exceeds the life count. (Use count > life count) 1: Determine that the tool life is over when the incremented use count has reached the life count. (Use count ≥ life count)	0/1 (Default: 0)
	aux04 (bit4)	Data input/ output unit selection	Specify the input/output data unit for tool data and user parameter input/output. 0: Internal unit (metric) 1: Follows command mode set with #1152 I_G20 Metric when set to 0 Inch when #1152 I_G20 is set to 1 This parameter is valid when initial metric (#1041 I_inch 0) is set and the setting and display unit is the command unit (#1226 aux10 bit6 1). In all other cases, the tool data will be input and output with the internal units.	0/1
1221	aux05 (bit7)	Current value B valid	Select the type of counter to be displayed on the POSITION screen. 0: Displays a relative value (value that includes tool length offset amount, tool radius compensation amount and workpiece coordinate offset amount) 1: Displays current value B (value that does not include tool length offset amount, tool radius compensation amount and workpiece coordinate offset amount) 	0/1
			<p>(Note1) When "#1221 aux05/bit7" is set to "1", the current value B is selected regardless of the bit type of #1287 ext23. When the current value B is valid, the counter zero or origin zero is invalid.</p>	

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)	
1222	aux06 (bit0)	Validity of tool length measurement confirmation message	0: Display no confirmation message when tool compensation data is set. 1: Display a confirmation message when tool compensation data is set.	0/1
	aux06 (bit1)	Height axis specification	When 1 is set in this parameter, the axis specified by base specification parameter #1028 base_k is measured and no other axes are measured if they move.	0/1
	aux06 (bit2)	Servo waveform display	Specify whether to enable the waveform display function. 0: Disable the waveform display function. 1: Enable the waveform display function.	0/1
	aux06 (bit3)	Enable/disable setup parameter lock	Specify whether to enable the setup parameter lock function. 0: Disable 1: Enable	0/1
	aux06 (bit4)	Minimum cut-in amount selection	Select the minimum cut-in amount command value for the compound type thread cutting cycle (G76 command) when the minimum cut-in amount (Q) does not exist in 1st block or 1st block is omitted. 0: The minimum cut-in amount (Q) is "0". 1: The minimum cut-in amount (Q) is the last command value.	0/1
	aux06 (bit5)	Fixed cycle for compound lath command format check selection	Select the operation to be made if the 1st block of the fixed cycle for compound lathe is omitted when the conventional format is selected (#1265 ext01/bit0 "0"). 0: Program error (P33) occurs. 1: Parameter setting value is used.	0/1
	aux06 (bit7)	Zero point return deceleration check method	Set the deceleration check method used during automatic reference point return. 0: In-position check 1: Commanded deceleration check	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
1223	aux07 (bit0)	Not used.	
	aux07 (bit1)	Deceleration check method 2 0: Command deceleration check in G1+G9 1: In-position check in G1+G9 The deceleration check is not performed except G1+G9. When "#1306 InpsTyp deceleration check specification type" is set to 1 (Deceleration check specification type 2), this parameter will be invalid.	0/1
	aux07 (bit2)	Synchronous tap R-point in-position check 0: Disable the synchronous tap I-point → R-point in-position check. 1: Enable the synchronous tap I-point → R-point in-position check. Note: This parameter is valid only when 1 (in-position check is valid) is set in bit 3 of #1223 aux07 (synchronous tap in-position check improvement).	0/1
	aux07 (bit3)	Synchronous tap in-position check improvement 0: Disable 1: Enable Related parameters: #1223 bit 2 Synchronous tap R-point in-position check bit 4 Synchronous tap hole bottom in-position check bit 5 Synchronous tap R-point in-position check 2	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
	aux07 (bit4)	Synchronous tap hole bottom in-position check 0: Disable the synchronous tap hole bottom in-position check. 1: Enable the synchronous tap hole bottom in-position check. Note: This parameter is valid only when 1 (in-position check is valid) is set in bit 3 of #1223 aux07 (synchronous tap in-position check improvement).	0/1
	aux07 (bit5)	Synchronous tap R-point in-position check 2 0: Disable synchronous tape R-point in-position check. 1: Enable synchronous tape R-point in-position check. Note: This parameter is valid only when 1 (in-position check is valid) is set in bit 3 of #1223 aux07 (synchronous tap in-position check improvement).	0/1
	aux07 (bit6)	Cancel synchronous tap (,S) return 0: Retains a spindle rotation speed (, S) when performing synchronous tap return. 1: Cancels a spindle rotation speed (, S) by return with G80.	0/1
	aux07 (bit7)	Synchronous tap method Specify a synchronous tap method. 0: Synchronous tap (multi-step acceleration and deceleration and rapid return) 1: Conventional type synchronous tap	0/1
1224	aux08 (bit0)	Sampling data output Set the validity of the sampling data output. 0: Sampling output invalid 1: Sampling output valid	0/1
1225	aux09 (bit0)	Not used.	
	aux09 (bit7)	Enable/disable spindle rotation speed clamp Specify whether to enable spindle rotation speed clamp by the spindle rotation speed clamp command (G92S, Q) instead of the spindle rotation speed command (R108) specified by the user ladder. 0: Enable 1: Disable	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
1226	aux10 (bit0) Tool compensation data for external workpiece coordinate offset measurement	Select the tool offset data to be used for external workpiece coordinate offset measurement. 0: Tool length data and tool nose wear data 1: Tool length data	0/1
	aux10 (bit1) Optional block skip type	Specify whether to enable optional block skipping in the middle of a block. 0: Enable block skipping only at the beginning of a block. 1: Enable block skipping at the beginning of the block and in the middle of a block.	0/1
	aux10 (bit2) Single block stop timing	Specify the time at which the single block signal is activated. 0: When the signal goes ON while automatic operation is starting, the block stops after it is finished. 1: When the signal is ON at the end of the block, the block stops.	0/1
	aux10 (bit3) C-axis reference point return type	Specify the C-axis reference point return type. 0: Origin return is performed by the G28 reference point return command or when manual reference point return is activated. The origin dog is used. 1: When the first C-axis command is issued after the C-axis mode is entered in automatic mode, reference point return is performed before execution of the block. Also, reference return is performed by the G28 reference point return command or when manual reference point return is activated. The Z phase of the encoder is used.	0/1



5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
aux10 (bit4)	S command during constant surface speed	Specify whether to output a strobe signal when the S command is issued in constant surface speed mode. 0: Output no strobe signal in constant surface speed mode. 1: Output strobe signals in constant surface speed mode.	0/1
aux10 (bit5)	Arbitrary allocation of dog signal	Specify whether to enable the arbitrary allocation parameter for the origin dog and H/W OT. 0: Disable arbitrary allocation. (Fixed device) 1: Enable arbitrary allocation. (Device specified by the parameter)	0/1
aux10 (bit6)	Setup and display unit	Specify the unit to be used as the setup/display unit or handle feed unit, the command unit or internal unit. The machining program variables (system variables for coordinate system) are changed simultaneously. 0: Internal unit 1: Unit specified by command Note 1: This parameter is valid only in initial millimeter mode (0 is set in 14041 I_inch). The internal unit is always used in initial inch mode (1 is set in 14041 I_inch). Note 2: This parameter is validated immediately after it is set. Note 3: If addition setting is performed for tool and workpiece offset data with the command unit being inch and internal unit being mm, an error may be generated. Note 4: The internal data is an internal unit determined with #1041 I_inch. Note 5: This parameter is not related to the PLC axis. Related parameter: #1152 I_G20 (Initial command unit)	0/1
aux10 (bit7)	Shorten JOG stop time	Specify whether to shorten the JOG stop time. 0: Do not shorten the JOG stop time. (Same as before) 1: Shorten the JOG stop time.	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)	
1227	aux11 (bit0)	Select PLC signal or spindle feedrate attained	Set up this option when disabling the cutting start interlock by spindle feedrate attained. 0: Cutting start interlock by PLC signal 1: Cutting start interlock by spindle feedrate attained	0/1
	aux11 (bit1)	Select H or D code	Set up this option to validate the data that is set up on the tool life management screen when issuing the H99 or D99 command. 0: The H and D codes validate the data that is set up on the management setup screen. 1: Validates the data that is set up on the management setup screen when issuing the H99 or D99 command.	0/1
	aux11 (bit2)	Measures against tool setter chattering	Select a condition where a relieving operation completes after measurement with tools. 0: Sensor signals has stopped for 500 ms or longer. 1: 100 μ s or longer has passed after sensor signals stopped.	0/1
	aux11 (bit4)	Program address check	Specify whether to simply check the program address when the machining program is executed. 0: Don't check the program address. 1: Check the program address.	0/1
	aux11 (bit5)	Spindle rotation speed clamp	Specify whether to clamp the rotation in constant surface speed mode when the spindle rotation speed clamp command is issued. 0: Clamp the rotation regardless of the constant surface speed mode. 1: Clamp the rotation only in constant surface speed mode.	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
aux11 (bit6)	Word edit menu	<p>Select the word edit menu format. Set 0 in this parameter to select the following menu format:</p>  <p>Set 1 in this parameter to select the following menu format:</p> 	0/1
aux11 (bit7)	Switch the range of tool life data to be input (For M system only)	<p>Set up the range of tool life data to be input or compared.</p> <p>0: Inputs or compares all of the data output. 1: Inputs or compares part of the data output</p> <ol style="list-style-type: none"> 1) Tool life management I data to be input or compared tool number (D), lifetime (E), life count (F), and auxiliary data (B). 2) Tool life management II data to be input or compared Group number (G), method (M), life (E/F), tool number (D), and compensation number (H) <p>Note: When the maintenance function data input/output # (99) () is set, all data will be input and compared.</p>	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)	
1228	aux12 (bit0)	Switch coordinate value screen	Set up this option to switch the coordinate value screen. 0: 80-character screen 1: 40-character screen	0/1
	aux12 (bit1)	Switch offset and parameter screen	Set up this option to switch the offset and parameter screen to the parameter screen. 0: Displays the offset and parameter screen. 1: Displays the parameter screen.	0/1
	aux12 (bit2)	Switch data protection in data transmission mode	Set up the range of data protection in data transmission mode. 0: Protects both send and receive data. 1: Protects receive data only.	0/1
	aux12 (bit3)	Nose R specification	Select whether to specify the nose R compensation by shape or wear number. 0: Specifies the nose R compensation by shape number. 1: Specifies the nose R compensation by wear number.	0/1
	aux12 (bit4)	Select operation error or stop code	Specify both block cutting start interlock and cutting start interlock as the operation error or stop code. 0: Operation error 1: Stop code	0/1
	aux12 (bit5)	Select constant surface speed coordinates	Select constant surface speed coordinates. 0: Workpiece coordinate value 1: Absolute coordinate value	0/1
	aux12 (bit6)	Switch relative values displayed	Select whether to preset the relative coordinates with workpiece coordinate preset (G92.1) or counter preset (G92). 0: Preset relative coordinates. 1: Do not preset relative coordinates.	0/1
	aux12 (bit7)	Protection with manual value command	Set up this option to protect a manual value command. 0: Does not protect the manual value command (same as before). 1: Protects the manual value command.	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)	
1229	set01 (bit0)	Subprogram interrupt	0: Specifies the user macro interrupt of macro type. 1: Specifies the user macro interrupt of sub-program type.	0/1
	set01 (bit1)	Accurate thread cutting E	0: Address E specifies the number of threads per inch for inch screw cutting. 1: Address E specifies precise reading for inch screw cutting.	0/1
	set01 (bit2)	Radius compensation type B (For M system only)	0: When the start-up and cancel commands are operated during radius compensation, their blocks are not handled by intersection operation processing; they are handled as offset vectors in the direction vertical to that of the commands. 1: When the start-up and cancel commands are operated during radius compensation, the intersection operation processing of the command block and the next block is executed.	0/1
	set01 (bit2)	Nose R compensation type B (For L system only)	0: When the start-up and cancel commands are operated during nose R and radius compensation, their blocks are not handled by intersection operation processing; they are handled as offset vectors in the direction vertical to that of the commands. 1: When the start-up and cancel commands are operated during nose R and radius compensation, the intersection operation processing of the command block and the next block is executed.	0/1
	set01 (bit3)	Initial constant surface speed	0: The initial state after power-ON is a constant surface speed control cancel mode. 1: The initial state after power-ON is a constant surface speed control mode.	0/1
	set01 (bit4)	Synchronous tap	0: Handles the G74 and G84 tap cycles as the tap cycles with a floating tap chuck. 1: Handles the G74 and G84 tap cycles as the tap cycles without a floating tap chuck.	0/1
	set01 (bit6)	Grid display selection	Select a grid type to be displayed on the servo monitor screen during dog type reference point return. 0: Selects the distance between dog OFF and zero point (including a grid mask amount). 1: Selects a value given by reducing a grid mask amount from the distance between dog OFF and zero point.	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
1230	set02	Not used.	
1231	set03 (bit1)	<p>Switch graphic coordinates</p> <p>Select whether to draw graphics with the machine coordinate value or the tool position coordinate value (position being machined, obtained by subtracting the tool compensation amount from machine coordinate values) when displaying the trace function.</p> <p>0: Machine coordinate value (same as conventional method)</p> <p>1: Tool position coordinate value</p> <p>The counter display and counter name are sequenced with this.</p>	0/1
	set03 (bit2)	<p>Switch graphic check trace</p> <p>Select whether to draw both the machine coordinate value (tool center path) and tool position coordinate value (program path) or draw only the coordinates selected with switch graphic coordinates (#1231 set03/bit1) when using the program check function.</p> <p>0: Both machine coordinates and tool position coordinates (same as conventional method)</p> <p>1: Only coordinates designated with switch graphic coordinates.</p>	0/1
	set03 (bit3)	<p>Hold display range information</p> <p>Select whether to hold the display range information (drawing position and scale value) for graphic displays.</p> <p>0: Hold.</p> <p>1: Do not hold. (Initialize each time ... same as conventional method)</p>	0/1
	set03 (bit4)	<p>Switch zero point mark display position</p> <p>Select what position the zero point mark in the graphic display indicates.</p> <p>0: Machine coordinate zero point (same as conventional method)</p> <p>1: Workpiece coordinate zero point</p>	0/1
1232	set04 (bit0)	<p>Switch load monitor</p> <p>Select whether to detect the load with the load monitor's load detection, excluding during acceleration/ deceleration.</p> <p>0: Detect also during acceleration/deceleration. (Conventional)</p> <p>1: Do not detect during acceleration/deceleration.</p>	0/1
	set04 (bit1)	<p>Program format (IC card)</p> <p>Select the format of the file output during copying (NC → IC).</p> <p>0: Add "%" to the head of the file.</p> <p>1: The head of the file is No. 0.</p>	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)	
1233	set05 (bit1)	Spindle clamp selection	Select whether to validate the spindle override for the spindle speed clamp command (G92 S?). 0: Spindle override invalid 1: Spindle override valid	0/1
1234			Not used.	
1235	set07 (bit2)	Fixed type chopping compensation valid only at start	When the fixed type compensation value is selected, the method is changed to the compensation value sequential update type after the first four cycles. 0: Method changeover invalid 1: Method changeover valid	0/1
1236	set08 (bit0)	Manual rotation axis feedrate unit	Select the unit of manual rotation axis feedrate. 0: Fixed to [°/min] 1: Same speed as before	0/1
	set08 (bit1)	Spindle speed detection	Select the pulse input source of actual spindle rotation speed output (R18/19) when spindle encoder serial connection (#3025 enc-on: 2) is selected. 0: Serial input 1: Encoder input connector	0/1
	set08 (bit2)	Current limit droop cancel invalid	Set whether to cancel the position droop when the current limit changeover signal is canceled. 0: Cancel droop. 1: Do not cancel droop.	0/1
1237 (PR)	set09 (bit0)	External workpiece offset	Set up this function to use the external workpiece coordinates by shifting them to the Z axis. 0: Does not reverse the sign of external workpiece offsets (Z shift) (same as before). 1: Reverses the sign of external workpiece offsets (Z shift). Note: When the sign of external workpiece offsets (Z shift) has been reversed, do not measure those external workpiece offsets. However, the external workpiece offsets can be measured by tool pre-setter.	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)	
1238 (PR)	set10 (bit0)	Switch G36 function	If a G code system containing the G36 (automatic tool length measurement X) function is selected, select whether to use G36 for the automatic tool length measurement or arc thread cutting (CCW) function. 0: Automatic tool length measurement 1: Arc thread cutting (CCW)	0/1
	set10 (bit7)	Switch operation alarm	Select whether to validate the NC alarm 5 (AL5) signal output. 0: NC alarm 5 (AL5) invalid All operation alarms are output to NC alarm 4 (AL4). All operation alarms are recorded in the alarm history. 1: NC alarm 5 (AL5) valid The following operation alarms are not output to NC alarm 4 (AL4). These are output to NC alarm 5 (AL5). The operation alarms output to NC alarm 5 (AL5) are not recorded in the alarm history. <ul style="list-style-type: none"> • External interlock axis found • Cutting override zero • External feedrate zero • Block start interlock • Cutting block start interlock 	0/1 (Default: 0)
1239 (PR)	set11 (bit0)	Coil switching method	0: Via PLC. (Y2D7) 1: NC internal processing. (Y2D7 is invalid.)	0/1
	set11 (bit5)	Door interlock spindle speed clamp valid	Select whether to validate the spindle clamp speed changeover function by the PLC signal. 0: Invalid 1: Valid	0/1
	set11 (bit6)	External deceleration axis compliance valid	Designate the method for setting the external deceleration speed. 0: Set speed common for all axes (#1216 extdcc external deceleration speed) 1: Set speed for each axis (#2086 exdcax external deceleration speed)	0/1
1240 (PR)	set12 (bit0)	Handle input pulse	Select the handle input pulse. 0: Handle 100 pulse (+12V) 1: Handle 400 pulse (+5V)	0/1
	set12 (bit2)	Zero point shift amount magnification	If "1" is set, the following magnification will be applied on the #2027 G28sft reference point shift amount, #2057 zero point proximity + and #2058 zero point proximity - settings. For 0.1μm : 10-fold	0/1

5. BASE SPECIFICATIONS PARAMETERS

(SETUP PARAM 1. 9/16)

#	Items	Details	Setting range (unit)	
1265 (PR)	ext01 (bit0)	Command format 1	Select the command format for the fixed cycle for compound lathe. 0: Conventional format 1: MELDAS special format (1 block command method)	0/1
	ext01 (bit1)	Command format 2	Select the command format for the lathe fixed cycle. 0: Conventional format 1: MELDAS special format	0/1
	ext01 (bit2)	Command format 3	Select the command format for the hole drilling fixed cycle. 0: Conventional format 1: MELDAS special format	0/1
1266 (PR)	ext02		Not used.	
1267 (PR)	ext03 (bit0)	G code type	Select the high-accuracy control G code. 0: G61.1 1: G08	0/1
1268 (PR)	ext04		Not used.	
1269 (PR)	ext05		Not used.	
1270 (PR)	ext06 (bit7)	Handle C axis coordinate during cylindrical interpolation	Specify whether the rotary axis coordinate before the cylindrical interpolation start command is issued is kept during the cylindrical interpolation or not. 0: Do not keep 1: Keep	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
1271 (PR)	ext07 (bit5) Cut start position (For L system only)	Specify the position from where cutting begins in a fixed cycle for compound lathe. 0: Conventional specifications The cut start position is determined by the final shaping program. 1: Extended specifications The cut start position is determined from the cycle start point.	0/1 (Default: 0)
	ext07 (bit6) Nose R compensation (For L system only)	Specify whether to apply nose R compensation to shapes in a rough cutting cycle. 0: Conventional specifications If nose R compensation is enabled for the final shaping program, the shape obtained after applying nose R compensation to the final shaping program is used as the rough cutting shape. 1: Extended specifications The shape made by the final shaping program, without nose R compensation, is used as the rough cutting shape.	0/1 (Default: 0)
	ext07 (bit7) Cut amount (For L system only)	Specify the operation to be performed when the program-specified cut amount exceeds the cut amount of the final shaping program. 0: Conventional specifications A program error occurs if the program-specified cut amount exceeds the cut amount of the final shaping program. 1: Extended specifications Rough cutting is performed by one cut if the program-specified cut amount exceeds the cut amount of the final shaping program.	0/1 (Default: 0)

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)	
1272 (PR)	ext08 (bit0)	Switch pocket machining operation	<p>0: Conventional specifications Pocket machining is selected with the H designation. The pull direction when pocket machining is ON is the Z direction.</p> <p>1: Extended specifications If there is an X and Z axis in the first movement block after the finished shape start block is started, pocket machining will start. The pull direction when pocket machining is ON is the X direction.</p>	0/1
	ext08 (bit1)	M function synchronous tap cycle	<p>Specify whether to enable the M function synchronous tap cycle.</p> <p>0: Invalid 1: Valid</p>	0/1
	ext08 (bit3)	Switch macro call function	<p>Select whether to shift the argument to the subprogram if nests are overlapped when per block call (G66.1) is commanded.</p> <p>0: Shift argument even if nests are overlapped. 1: Do not shift arguments if nests differ. (Conventional specifications)</p>	0/1
	ext08 (bit4)	Tap cycle selection	<p>Select the tap cycle.</p> <p>0: Pecking tap cycle 1: Deep hole tap cycle</p>	0/1
	ext08 (bit5)	Deep hole tap cycle override selection	<p>Select whether to validate override on the pulling operation during synchronized tapping with the deep hole tap cycle.</p> <p>0: Invalid 1: Valid</p>	0/1
	ext08 (bit6)	Switch corner chamfering/ corner R command format	<p>The corner chamfering/corner R command format is extended.</p> <p>0: Command format I (conventional format) Issue a command with comma (,C and ,R).</p> <p>1: Command format II In addition to command format I, commands can be issued with an address that does not have a comma. Corner chamfering: I/K or C, corner R: R</p>	0/1
	ext08 (bit7)	Return position after macro interrupt in fixed cycle selection	<p>Select the destination to return to after a macro interrupt in the fixed cycle.</p> <p>0: Return to block in fixed cycle. 1: Return to block after fixed cycle.</p>	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)	
1273 (PR)	ext09 (bit0)	Switch ASIN calculation results range	Select the ASIN calculation results range. 0: -90° to 90° 1: 90° to 270°	0/1
	ext09 (bit1)	Switch system variable unit	Select the unit for the system variable #3002 (time during automatic start). 0: 1ms unit 1: 1 hour unit	0/1
	ext09 (bit2)	Switch G71, G72, G73 cutting direction judgment	Select whether to determine the cutting direction with the finished shape, or according to the commanded finishing allowance and cutting allowance when the longitudinal rough cutting cycle (G71), face rough cutting cycle (G72) or closed loop cutting cycle (G73) is commanded. 0: Conventional specifications Determined according to the finished shape program. 1: Extended specifications Determined according to the finishing allowance and cutting allowance commanded in the program.	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)	
1274 (PR)	ext10 (bit7)	Word range check	Select whether to check that the operation expression of the word date in the program is enclosed in brackets ([]) when the machine program is executed. This check is also applied to the 08000 to 09999 and the machine manufacture macro program. 0: Check valid 1: Check invalid	0/1
1275 (PR)	ext11		Not used.	
1276 (PR)	ext12		Not used.	
1277 (PR)	ext13 (bit0)	Tool life management II count type 2	Specify how and when the mount or use count is incremented in tool life management II. 0: Type 1 The count is incremented when the spindle is used for cutting. 1: Type 2 The count is incremented for the tool used or mounted for one program. The increment is enabled by resetting.	0/1 (Default: 0)
1278 (PR)	ext14 (bit0)	Program restart method selection	Select the program restart method. 0: Type A 1: Type B	0/1
1279 (PR)	ext15 (bit1)	Interrupt amount during machine lock	Select the manner to handle the interruption amount during machine lock. 0: Cancel when reset. 1: Do not cancel when reset. Instead cancel during manual zero point return.	0/1
	ext15 (bit2)	Selection of cutting start interlock target block	Select whether the cutting start interlock is valid for successive cutting blocks. 0: Valid for successive cutting blocks. 1: Invalid for successive cutting blocks.	0/1
1280 (PR)	ext16		Not used.	

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)	
1281 (PR)	ext17 (bit1)	Tool offset addition axis selection	0: Follows Tchg34 1: Plane selection Base J setting name is set as the 3rd axis compensation axis.	0/1
1282 (PR)	ext18		Not used.	
1283 (PR)	ext19		Not used.	
1284 (PR)	ext20		Not used.	
1285 (PR)	ext21		Not used.	
1286 (PR)	ext22 (bit2)	0 No. for program input No.	Select the action to be taken when the same program No. is input during data input. 0: The 0 No. when the same 0 No. is input successively is handled as a character string data. 1: The 0 No. is handled as a program No. when the same 0 No. is input successively. Whether to overwrite the program or cause an error is set with #1218 bit 7 "Input by program overwrite".	0/1
	ext22 (bit3)	No 0 No. at machining program input	This setting enables the machining program input even if there is no program No. (0 No.). The program No. is fixed to 01 in this case. 0: Input disabled 1: Input enabled	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)	
1287 (PR)	ext23 (bit0)	Workpiece coordinate display	Select the mode of displaying the workpiece coordinate counter. 0: Don't update the display immediately after workpiece coordinate data is changed. 1: Update the display immediately after workpiece coordinate data is changed.	0/1
	ext23 (bit3)	Counter display expanded function selection	0: Display the command value that does not consider the tool length offset amount or workpiece coordinate offset amount. 1: The counter display expanded function is validated. (bit4 to bit7)	0/1
	ext23 (bit4)	Relative coordinate display	(M system) 0: Display the actual position including tool length offset. 1: Display the machining position in terms of a program command excluding tool length offset. (L system) 0: Display the actual position including tool shape compensation. 1: Display the machining position in terms of a program command excluding tool shape compensation.	0/1
	ext23 (bit5)	Relative coordinate display	(M system) 0: Display the actual position including tool radius compensation. 1: Display the machining position in terms of a program command excluding tool radius compensation. (L system) 0: Display the actual position including nose R compensation. 1: Display the machining position in terms of a program command excluding nose R compensation.	0/1

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)	
1288 (PR)	ext24 (bit0)	MDI program clear	Select whether to initialize the MDI buffer when MDI operation ends, the power is turned ON again, reset is input, or emergency stop is canceled. 0: Do not clear programs registered with MDI. 1: Clear programs registered with MDI, and save only % programs.	0/1
1289 (PR)	ext25		Not used.	
1290 (PR)	ext26		Not used.	
1291 (PR)	ext27		Not used.	
1292 (PR)	ext28		Not used.	
1293 (PR)	ext29		Not used.	
1294 (PR)	ext30		Not used.	
1295 (PR)	ext31		Not used.	
1296 (PR)	ext32		Not used.	
1297 (PR)	ext33		Not used.	
1298 (PR)	ext34		Not used.	
1299 (PR)	ext35		Not used.	
1300 (PR)	ext36 (bit0)	Multiple spindle control II	Select multiple spindle control I or II. 0: Multiple spindle control I 1: Multiple spindle control II (select from ladder)	0/1
	ext36 (bit7)	Spindle synchronization command method	Select the spindle synchronization command method. 0: Spindle synchronization with PLC I/F 1: Spindle synchronization with G command	0/1

5. BASE SPECIFICATIONS PARAMETERS

(SETUP PARAM 1. 10/16)

#		Items	Details	Setting range (unit)
1301	nrfchk	Origin neighboring check method	Select the high-speed check method of the origin neighboring signal. 0: Do not check positions near the origin at high speeds. (Conventional specifications) 1: Check positions near the origin at high speeds using command machine positions. 2: Check positions near the origin at high speeds using detector feedback positions.	0 to 2
1302	AutoRP	Automatic return by program restart	0: Return the system to the restart position manually and then restart the program. 1: For program restarting, the first activation automatically moves the system to the restart position.	0/1
1303 (PR)	V1comN		Not used.	
1304 (PR)	V0comN		Not used.	
1305	corjug	Corner deceleration tangent judgment	Select whether to judge corner deceleration with a polygon shape or tangent during helical interpolation. 0: Polygon judgment Helical interpolation is interpreted as polygonal, and the corner deceleration is judged with the approximate vector. 1: Tangent judgment The vector is calculated from the center of the helical interpolation, the start point and the end point, and corner deceleration is judged.	0/1
1306	InpsTyp	Deceleration check specification type	Select the parameter specification type for the G0 or G1 deceleration check. 0: Deceleration check specification type 1 G0 is specified with "#1193 inpos", and G1+G9 with "#1223 aux07/BIT1". 1: Deceleration check specification type 2 G0 or G1+G9 is specified with "#1193 inpos".	0/1
1310	WtMmin		Not used.	
1311	WtMmax		Not used.	

5. BASE SPECIFICATIONS PARAMETERS

#	Items	Details	Setting range (unit)
1312	T_base Tool life management standard number	When the T code command is issued while specifying a value that exceeds the value set in this parameter, the value obtained by subtracting the set value from the command value is used as the tool group number for tool life management. The value specified by the T code command is equal to or less than the value set in this parameter, the T code is handled as a normal T code and not subjected to tool life management. When 0 is set in this parameter, the T code command always specifies a group number. (This parameter is valid for M-system tool life management II.)	0 to 9999
1313	TapDw1 Synchronous tap hole bottom wait time	Specify the hole bottom wait time for synchronous tapping. When the P address is specified, the greater value is used as the hole bottom wait time. When an in-position check is performed at the hole bottom, dwelling for the specified time is completed after the in-position check is complete. Note: This parameter is valid only when 1 is set in #1223 aux07 bit 3 (synchronous tap in-position check improvement).	0 to 999 (ms)
1314	TapInp Synchronous tap in-position check width (tap axis)	Specify the hole bottom in-position check width for synchronous tapping. Note: This parameter is valid only when 1 is set in #1223 aux07 bit 3 (synchronous tap in-position check improvement).	1 to 32767 (1 μ m steps)
1324	Chop_R Chopping compensation value fixing method	Head number of the R register used as the compensation amount save area during fixed compensation amount method.	1900 to 2782

5. BASE SPECIFICATIONS PARAMETERS

(SETUP PARAM 1. 11/16)

#	Items	Details	Setting range (unit)
1501	polyax (For L system only)	Not used.	
1502	G0lpfg	G1 → G0 deceleration check 0: Do not perform a deceleration check when the move direction is changed from G1 to G0. 1: Perform a deceleration check when the move direction is changed from G1 to G0.	0/1
1503	G1lpfg	G1 → G1 deceleration check 0: Do not perform a deceleration check when the move direction is changed from G1 to G1. 1: Perform a deceleration check when the move direction is changed from G1 to G1.	0/1
1505	ckref2	Second origin return check Specify the trigger for a check at the specified position in manual second original return mode. 0: Completion of spindle orientation 1: Generation of second origin return interlock signal	0/1
1506	F1_FM	Not used.	
1507	F1_K	Not used.	
1510	DOOR_H	Shorten door interlock II axis stop time Specify whether to shorten the time during which the axis is stopped when the door is opened. 0: Use the conventional axis stop time. 1: Shorten the axis stop time. Note: When the door interlock II signal is input via a ladder, the conventional axis stop time is used.	0/1
1511	DOORPm	Signal input device 1 for door interlock II: for each system Specify the fixed device number (X??) for door interlock II signal input for each system. A device number from X01 to XFF can be specified. Device number 000 is invalid. Specify device number 100 when using no fixed device number for door interlock II signal input. Related parameter: #1154 pdoor (Door interlock II for each system)	000 to 100 (hexadecimal)
1512	DOORPs	Signal input device 2 for door interlock II: for each system Specify the fixed device number (X??) for door interlock II signal input for each system. (Specify the same value as that of #1155.) Related parameter: #1154 pdoor (Door interlock II for each system)	000 to 100 (hexadecimal)

5. BASE SPECIFICATIONS PARAMETERS

#	Items		Details	Setting range (unit)
1513	stapM	M code for synchronous tap selection	Select the synchronous tap mode using the miscellaneous function code of the value set in this parameter. The M function command can be issued immediately before the tap command or in the same block. This function is valid only when 1 is set in #1272 ext08/bit 1 (Enable/disable M-function synchronous tap cycle). Note: Do not use M00, 01 02, 30, 98, and 99.	0 to 99999999
1514	expLinax		Not used.	
1515	expRotax		Not used.	
1516	mill_ax	Milling axis name	Set the name of the rotary axis used in cylindrical interpolation or polar coordinate interpolation. Only one rotary axis can be set. When there is no E command in issuing the cylindrical interpolation or polar coordinate interpolation command, this parameter will be followed.	A to Z
1517	mill_C	Milling interpolation hypothetical axis name	Select the hypothetical axis command name for pole coordinate interpolation. When there is no D command in issuing the G12.1 command, this parameter will be followed. 0: Y axis command 1: Command rotary axis name.	0/1
1518	polm		Not used.	
1519	pols		Not used.	
1520 (PR)	Tchg34	Additional axis tool compensation operation	Select whether to carry out the additional axis' tool compensation function with the 3rd axis or 4th axis. 0: Select 3rd axis. 1: Select 4th axis.	0/1
1521	C_min		Not used.	
1522 (PR)	C_axis		Not used.	
1523	C_feed		Not used.	
1524	C_type		Not used.	

5. BASE SPECIFICATIONS PARAMETERS

(SETUP PARAM 1. 12/16)

#	Items	Details	Setting range (unit)																		
1525	laxlen	Not used.																			
1526	raxlen	Not used.																			
1527	flclen	Not used.																			
1528	rfclch	Not used.																			
1529	laxcmp	Not used.																			
1530	raxcmp	Not used.																			
1531	flccmp	Not used.																			
1532	G01rsm	Not used.																			
1533	millPax	Pole coordinate linear axis name Set the linear axis used for pole coordinate interpolation.	Control axis address such as X, Y or Z																		
1534	SnG44.1	Spindle No. for G44.1 command Set the selected spindle No. for the G44.1 command. <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>#1199</th> <th>#1534</th> <th>Selected spindle</th> </tr> </thead> <tbody> <tr> <td>0:G43.1</td> <td>Not used.</td> <td>1st spindle</td> </tr> <tr> <td>1:G44.1</td> <td>0</td> <td>2nd spindle</td> </tr> <tr> <td></td> <td>1</td> <td>1st spindle</td> </tr> <tr> <td></td> <td>2</td> <td>2nd spindle</td> </tr> <tr> <td>2:G47.1</td> <td>Not used.</td> <td>All spindles</td> </tr> </tbody> </table>	#1199	#1534	Selected spindle	0:G43.1	Not used.	1st spindle	1:G44.1	0	2nd spindle		1	1st spindle		2	2nd spindle	2:G47.1	Not used.	All spindles	0: 2nd spindle 1: 1st spindle 2: 2nd spindle If a spindle that does not exist is set, the 2nd spindle will be used. Note that if there is only one spindle, the 1st spindle will be used.
#1199	#1534	Selected spindle																			
0:G43.1	Not used.	1st spindle																			
1:G44.1	0	2nd spindle																			
	1	1st spindle																			
	2	2nd spindle																			
2:G47.1	Not used.	All spindles																			
1535	C_leng	Not used.																			
1537 to 1544	crsax[1] to crsax[8]	Not used.																			

(SETUP PARAM 1. 13/16)

#	Items	Details	Setting range (unit)
1549	lv0vr1	Not used.	
1550	lv0vr2	Not used.	
1551	lv0vr3	Not used.	
1552	lv0vr4	Not used.	
1553	lv0vr5	Not used.	
1554	lv0rd2	Not used.	
1555	lv0rd3	Not used.	
1556	lv0rd4	Not used.	
1557	lv0rd5	Not used.	
1558	lv0Min	Not used.	
1559	lvAMax	Not used.	
1560	lvFMin	Not used.	
1572	Cirorp	Not used.	

5. BASE SPECIFICATIONS PARAMETERS

(SETUP PARAM 1. 14/16)

#	Items	Details	Setting range (unit)
1801	Hacc_c	Not used.	
1802	Macc_c	Not used.	
1803	Lacc_c	Not used.	
1811	Hcof_A	Not used.	
1812	Hcof_B	Not used.	
1813	Mcof_A	Not used.	
1814	Mcof_B	Not used.	
1815	Lcof_A	Not used.	
1816	Lcof_B	Not used.	
1817	mag_C	Not used.	
1821	Hcof_A	Not used.	
1822	Hcof_B	Not used.	
1823	Mcof_A	Not used.	
1824	Mcof_B	Not used.	
1825	Lcof_A	Not used.	
1826	Lcof_B	Not used.	
1827	mag_C	Not used.	

(SETUP PARAM 1. 15/16)

#	Items	Details	Setting range (unit)
1901 (PR)	station addr	Not used.	
1902 (PR)	Din size	Not used.	
1903 (PR)	Dout size	Not used.	
1904 (PR)	data length	Not used.	
1905 (PR)	baud rate	Not used.	
1906 (PR)	stop bit	Not used.	
1907 (PR)	parity check	Not used.	
1908 (PR)	even parity	Not used.	
1909 (PR)	Tout (ini)	Not used.	
1910 (PR)	(run)	Not used.	
1911 (PR)	clock select	Not used.	

5. BASE SPECIFICATIONS PARAMETERS

(SETUP PARAM 1. 16/16)

#	Items	Details	Setting range (unit)
1925	EtherNet	Not used.	
1926	IP address	Not used.	
1927	Subnet mask	Not used.	
1928	Gateway address	Not used.	
1929	Port number	Not used.	
1930	Host address	Not used.	
1931	Host number	Not used.	
1932	FTP Retry	Not used.	
1933	FTP Timeout	Not used.	

6. AXIS SPECIFICATIONS PARAMETERS
6.1 Axis Specifications Parameters

6. AXIS SPECIFICATIONS PARAMETERS

6.1 Axis Specifications Parameters

After setting up the parameter (PR) listed in the table, turn OFF the NC power. To validate the parameter, turn ON the power again.




(SETUP PARAM 2. 1/8)

#	Items	Details	Setting range (unit)																																	
2001	rapid	Rapid traverse rate	Set up the rapid traverse feedrate for each axis. The maximum value to be set differs with mechanical systems.	1 to 999999 (mm/min)																																
2002	clamp	Cutting feedrate for clamp function	Define the maximum cutting feedrate for each axis. Even if the feedrate in G01 exceeds this value, the clamp will be applied at this feedrate.	1 to 999999 (mm/min)																																
2003 (PR)	smgst	Acceleration and deceleration modes	<p>Specify acceleration and deceleration control modes.</p> <table style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <tr> <td style="padding: 0 5px;">F</td><td style="padding: 0 5px;">E</td><td style="padding: 0 5px;">D</td><td style="padding: 0 5px;">C</td><td style="padding: 0 5px;">B</td><td style="padding: 0 5px;">A</td><td style="padding: 0 5px;">9</td><td style="padding: 0 5px;">8</td><td style="padding: 0 5px;">7</td><td style="padding: 0 5px;">6</td><td style="padding: 0 5px;">5</td><td style="padding: 0 5px;">4</td><td style="padding: 0 5px;">3</td><td style="padding: 0 5px;">2</td><td style="padding: 0 5px;">1</td><td style="padding: 0 5px;">0</td> </tr> <tr> <td style="border: 1px solid black; width: 20px; height: 20px;"></td><td style="border: 1px solid black; width: 20px; height: 20px;"></td><td style="border: 1px solid black; width: 20px; height: 20px;"></td><td style="border: 1px solid black; width: 20px; height: 20px;"></td><td style="border: 1px solid black; width: 20px; height: 20px;"></td><td style="border: 1px solid black; width: 20px; height: 20px; text-align: center;">OT3</td><td style="border: 1px solid black; width: 20px; height: 20px; text-align: center;">OT2</td><td style="border: 1px solid black; width: 20px; height: 20px; text-align: center;">OT1</td><td style="border: 1px solid black; width: 20px; height: 20px; text-align: center;">C3</td><td style="border: 1px solid black; width: 20px; height: 20px;"></td><td style="border: 1px solid black; width: 20px; height: 20px; text-align: center;">C1</td><td style="border: 1px solid black; width: 20px; height: 20px; text-align: center;">LC</td><td style="border: 1px solid black; width: 20px; height: 20px; text-align: center;">R3</td><td style="border: 1px solid black; width: 20px; height: 20px;"></td><td style="border: 1px solid black; width: 20px; height: 20px; text-align: center;">R1</td><td style="border: 1px solid black; width: 20px; height: 20px; text-align: center;">LR</td> </tr> </table> <p>Note: Set 0 in null bits. (Bit2 and bit6 when the acceleration/deceleration by software is selected are excluded.)</p> <p>Rapid traverse feed acceleration and deceleration types</p> <ul style="list-style-type: none"> LR Linear acceleration/ deceleration R1 Primary delay R3 Exponential acceleration and linear deceleration <p>bit0 to 3 ON Acceleration/ deceleration by software</p> <p>Cutting feed acceleration and deceleration types</p> <ul style="list-style-type: none"> LC Linear acceleration/ deceleration C1 Primary delay C3 Exponential acceleration and linear deceleration <p>bit4 to 7 ON Acceleration/ deceleration by software</p> <p>(To be continued to the next page)</p>	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0						OT3	OT2	OT1	C3		C1	LC	R3		R1	LR	Specify the modes in hexadecimal notation.
F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0																					
					OT3	OT2	OT1	C3		C1	LC	R3		R1	LR																					




6. AXIS SPECIFICATIONS PARAMETERS
6.1 Axis Specifications Parameters

#	Items	Details	Setting range (unit)																																																						
		<p>(Continued from the previous page)</p> <p><Combination of acceleration and deceleration patterns and bit patterns></p> <table border="1"> <tr> <td>Rapid traverse</td> <td>R3(bit3)</td> <td>-(bit2)</td> <td>R1(bit1)</td> <td>LR(bit0)</td> </tr> <tr> <td>Cutting feed</td> <td>C3(bit7)</td> <td>-(bit6)</td> <td>C1(bit5)</td> <td>LC(bit4)</td> </tr> <tr> <td rowspan="5">Acceleration/deceleration types</td> <td>Step</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>Linear acceleration/deceleration</td> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>Primary delay</td> <td>0</td> <td>0</td> <td>1</td> <td>0</td> </tr> <tr> <td>Exponential acceleration and linear deceleration</td> <td>1</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>Acceleration/deceleration by software</td> <td>1</td> <td>1</td> <td>1</td> <td>1</td> </tr> </table> <p>R1 > R3 when both R1 and R3 contain 1.</p> <p><Stroke end stop types></p> <table border="1"> <thead> <tr> <th>Type</th> <th>OT2</th> <th>OT3</th> </tr> </thead> <tbody> <tr> <td>Linear deceleration</td> <td>0</td> <td>0</td> </tr> <tr> <td>Position loop step stop</td> <td>1</td> <td>0</td> </tr> <tr> <td>Speed loop step stop</td> <td>0</td> <td>1</td> </tr> <tr> <td>Position loop step stop</td> <td>1</td> <td>1</td> </tr> </tbody> </table> <table border="1"> <tr> <td rowspan="2">OT1</td> <td>0</td> <td>Deceleration by G0t1</td> </tr> <tr> <td>1</td> <td>Deceleration by 2 × G0t1</td> </tr> </table> <p>OT1 is valid under the following conditions (valid for dog type zero point return):</p> <ul style="list-style-type: none"> Stop type: Linear deceleration Acceleration mode: Exponential Deceleration mode: Linear 	Rapid traverse	R3(bit3)	-(bit2)	R1(bit1)	LR(bit0)	Cutting feed	C3(bit7)	-(bit6)	C1(bit5)	LC(bit4)	Acceleration/deceleration types	Step	0	0	0	Linear acceleration/deceleration	0	0	1	Primary delay	0	0	1	0	Exponential acceleration and linear deceleration	1	0	0	0	Acceleration/deceleration by software	1	1	1	1	Type	OT2	OT3	Linear deceleration	0	0	Position loop step stop	1	0	Speed loop step stop	0	1	Position loop step stop	1	1	OT1	0	Deceleration by G0t1	1	Deceleration by 2 × G0t1	
Rapid traverse	R3(bit3)	-(bit2)	R1(bit1)	LR(bit0)																																																					
Cutting feed	C3(bit7)	-(bit6)	C1(bit5)	LC(bit4)																																																					
Acceleration/deceleration types	Step	0	0	0																																																					
	Linear acceleration/deceleration	0	0	1																																																					
	Primary delay	0	0	1	0																																																				
	Exponential acceleration and linear deceleration	1	0	0	0																																																				
	Acceleration/deceleration by software	1	1	1	1																																																				
Type	OT2	OT3																																																							
Linear deceleration	0	0																																																							
Position loop step stop	1	0																																																							
Speed loop step stop	0	1																																																							
Position loop step stop	1	1																																																							
OT1	0	Deceleration by G0t1																																																							
	1	Deceleration by 2 × G0t1																																																							

6. AXIS SPECIFICATIONS PARAMETERS
6.1 Axis Specifications Parameters

#	Items	Details	Setting range (unit)
2004	G0tL G0 time constant (linear)	<p>Set up a linear control time constant for rapid traverse acceleration and deceleration.</p> <p>The time constant is validated when LR (rapid traverse feed with linear acceleration or deceleration) or F (acceleration or deceleration by software) is selected in acceleration or deceleration mode "#2003 smgst".</p> 	1 to 4000 (ms)
2005	G0t1 G0 time constant (primary delay) Second-step time constant for acceleration and deceleration by software	<p>Set up a primary-delay time constant for rapid traverse acceleration and deceleration.</p> <p>The time constant is validated when R1 (rapid traverse feed with primary delay) or R3 (exponential acceleration and linear deceleration) is selected in acceleration or deceleration mode "#2003 smgst".</p> <p>When acceleration or deceleration by software is selected, the second-step time constant is used.</p> <p><Rapid traverse feed with primary delay></p>  <p><Rapid traverse feed with exponential acceleration and linear deceleration></p> 	1 to 5000 (ms)
2006	G0t2	Not used.	0

6. AXIS SPECIFICATIONS PARAMETERS
6.1 Axis Specifications Parameters


#	Items	Details	Setting range (unit)
2007	G1tL	<p>G1 time constant (linear)</p> <p>Set up a linear control time constant for cutting acceleration and deceleration.</p> <p>The time constant is validated when LC (cutting feed with linear acceleration and deceleration) or F (acceleration and deceleration by software) is selected in acceleration or deceleration mode "#2003 smgst".</p> 	1 to 4000 (ms)
2008	G1t1	<p>G1 time constant (primary delay)</p> <p>Set up the primary delay time constant for cutting acceleration and deceleration.</p> <p>The time constant is validated when C1 (cutting feed with the primary delay) or C3 (cutting feed with exponential acceleration and linear deceleration) is selected in acceleration or deceleration mode "#2003 smgst".</p> <p>When acceleration or deceleration by software is selected, the second stage time constant is used.</p> <p><Cutting feed with primary time constant></p>  <p><Cutting feed with exponential acceleration and linear deceleration></p> 	1 to 5000 (ms)
2009	G1t2	Not used.	0

6. AXIS SPECIFICATIONS PARAMETERS
6.1 Axis Specifications Parameters

#	Items		Details	Setting range (unit)
2010	fwd_g	Feed forward gain	Set up a feed forward gain for pre-interpolation acceleration and deceleration. The larger the set value, the smaller the theoretical control error will be. However, if a mechanical vibration occurs, the set value must be reduced.	0 to 100 (%)
2011	G0back	G0 backlash	Set up the backlash compensation amount when the direction is reversed with the movement command in rapid traverse feed mode or in manual mode.	-32768 to 32767
2012	G1back	G1 backlash	Set up the backlash compensation amount when the direction is reversed with the movement command in cutting mode.	-32768 to 32767

6. AXIS SPECIFICATIONS PARAMETERS
6.1 Axis Specifications Parameters

(SETUP PARAM 2. 2/8)

#	Items	Details	Setting range (unit)
2013 2014	OT - OT +	Soft limit I - soft limit I +	±99999.999 (mm)
<p>Set up a soft limit area with reference to the zero point of the basic mechanical coordinates.</p> <p>For the movable area of stored stroke limit 1, set the coordinate in the negative direction in #2013 and the coordinate in the positive direction in #2014.</p> <p>To narrow the available range in actual use, use the parameters #8204 OT- and #8205 OT+.</p> <p>When the same value (other than 0) is set in #2013 and #2014, this function is disabled.</p> 			
2015	t1m1-	Negative direction sensor of tool setter or TLM standard length	±99999.999 (mm)
2016	t1m1+	Positive direction sensor of tool setter	±99999.999 (mm)
2017	tap_g	Axis servo gain	1.00 to 200.00 (rad/s)
2018	no_srv	Operation with no servo control	0/1

6. AXIS SPECIFICATIONS PARAMETERS
6.1 Axis Specifications Parameters


#	Items	Details	Setting range (unit)	
2019	revnum	Return steps	Set up the steps required for reference point return for each axis. 0: Does not execute reference point return. 1 to max. number of NC axes: Sets up the steps required for reference point return.	0 to max. number of NC axes
2020	o_chkp	Spindle orientation completion check during second zero point return	Set up the distance from the second zero point to the position for checking that the spindle orientation has completed during second zero point return. If the set value is 0, the above check is omitted.	0 to 99999.999 (mm)
2021	out_f	Maximum speed outside soft limit range	Set up the maximum speed outside the soft limit range.	0 to 999999
2022	G30SLX	Validate soft limit (automatic and manual)	Set up this function to disable a soft limit check during the second to the fourth zero point return in both automatic and manual operation modes. 0: Enables soft limit check. 1: Disables soft limit check.	0/1
2023	ozfmin	Set up ATC speed lower limit	Set up the minimum speed outside the soft limit range during the second to the fourth zero point return in both automatic and manual operation modes.	0 to 999999
2024	synerr		Not used.	

6. AXIS SPECIFICATIONS PARAMETERS
6.2 Zero Point Return Parameters

6.2 Zero Point Return Parameters

After setting up the parameter (PR) listed in the table, turn OFF the NC power. To validate the parameter, turn ON the power again.

(SETUP PARAM 2. 3/8)


#	Items	Details	Setting range (unit)
2025	G28rap G28 rapid traverse rate	Set up a rapid traverse rate for dog type reference point return command.	1 to 999999 (mm/min)
2026	G28crp G28 approach speed	Set up the speed of approach to the reference point in the reference point return command. This speed is attained after the system stops with deceleration by dog detection. Note) The G28 approach speed unit is (10°/min) only when using the Z-phase type encoder (#1226 aux10 bit3=1) for the spindle/C-axis reference point return type. The same unit is used for both the micron and sub-micron specifications.	1 to 60000 (mm/min)
2027	G28sft Reference point shift distance	Set up the distance from the electrical zero-point detection position to the actual machine reference point during reference point return. Note) When #1240 set12 (bit2) is ON, a magnification (C: 10-fold) corresponding to the input setting unit (#1003 iunit) will be applied on the setting value.	0 to 65535 (μm)
2028	grmask Grid mask amount	Set up a distance where the grid point is ignored when near-point dog OFF signals are close to that grid point during reference point return.  The grid mask is valid by one grid.	0 to 65535 (μm) Even when the least setting increment is 0.1μm, set up the value in units of μm.
2029	grspc Grid interval	Set up a detector grid interval. Generally, set up the value equal to the ball screw pitch. However, if the detector grid interval is not equal to the screw pitch when measured with a linear scale, set up the detector grid interval. To reduce the grid interval, use its divisors. To use 0.001 mm as minimum setup units, set up the negative value. Example) Setup value 1 → 1.000 mm (°) -1 → 0.001 mm (°) Even when the least setting increment is 0.1μm, it will be 0.001mm if a negative value is set.	-32767 to 999 (mm)

6. AXIS SPECIFICATIONS PARAMETERS
6.2 Zero Point Return Parameters

#		Items	Details	Setting range (unit)
2030 (PR)	dir (-)	Reference point direction (-)	<p>Set which side of the near-point dog the reference point is at during reference point return. <For dog type reference point return></p> <p style="text-align: center;">Direction in which zero point is established as viewed from the near-point dog</p>	0: Positive direction 1: Negative direction
2031	noref	Axis without reference point	<p>Specify the axis that does not have a reference point. Before automatic operation starts, reference point return is not required.</p>	0: Normal controlled axis 1: Axis without reference point
2032	nochk	Whether reference point return is completed not checked	<p>The absolute and incremental commands can be executed even if dog type (or Z phase pulse system) reference point return is not completed. Specify whether to check that the reference point return is completed.</p>	0: Reference point return completion is checked. 1: Reference point return completion is not checked.
2033	zp_no	Z phase pulse system reference point return spindle encoder No.	<p>The reference point return is performed with the Z phase pulse of the spindle encoder. Set the spindle encoder No. to be used.</p>	0: Dog type 1 to 2: Spindle No.

6. AXIS SPECIFICATIONS PARAMETERS
6.2 Zero Point Return Parameters

(SETUP PARAM 2. 4/8)

#	Items	Details	Setting range (unit)
2037 2038 2039 2040	G53ofs #2_rfp #3_rfp #4_rfp	<p>Reference point #1 to #4</p> <p>Set up the position of the first, second, third, and fourth reference points from the zero point of the basic mechanical coordinates.</p> 	±999999.999 (mm)

6. AXIS SPECIFICATIONS PARAMETERS
6.3 Absolute Position Parameters

6.3 Absolute Position Parameters

(SETUP PARAM 2. 5/8)

#	Items	Details	Setting range (unit)
2049 (PR)	type Absolute position detection method	Specify the absolute position zero point alignment method. 0: Not absolute position detection 1: Stopper method (push with mechanical stopper) 2: Origin point alignment method (align with marked point) 3: Dog-type (align with dog and proximity switch) 4: Reference point alignment method II (align to alignment mark) (Type that does not return grid after reference alignment) 9: Simple absolute position (Not absolute position detection, but the position when the power is turned off is registered.) Automatic initial setting is valid only when the stopper method is selected.	0 to 9
2050	absdir Base point of Z direction	Set the direction of the absolute position reference point (grid point immediately before) seen from the machine reference point for when using reference point alignment.	0: Positive direction 1: Negative direction
2051	check Check	Set the tolerable range for the movement amount (deviation amount) when the power is turned OFF. 0: Not checked 1 to 99999.999mm: If the difference of the position when the power is turned OFF and turned ON again is larger than this value, an alarm will be output.	0 to 99999.999 (mm)
2052	absg28	Not used.	
2053	absm02	Not used.	
2054	clipush Current limit (%)	Set up the current limit value for the initial setting when detecting an absolute position with a dog-less system. The setup value is the ratio of the current limit value to the rated value.	0 to 100 (%)
2055	pushf Push speed	Set the feedrate for the automatic initial setting during stopper method.	1 to 999 (mm/min)
2056	aproch Approach	Set the approach distance for the automatic initial setting in the push method. Approach distance: After using stopper once, the tool returns this distance, and then use stopper again. When set to 0, the reference point coordinates set in #2037 G53ofs will be used as the approach start position.	0 to 999.999 (mm)

6. AXIS SPECIFICATIONS PARAMETERS
6.3 Absolute Position Parameters

#	Items	Details	Setting range (unit)
2057	nrefp Near zero point +	Set the width where the near-reference-point signal is output. (Positive direction width) When set to 0, the width is equivalent to the grid width setting. Note: When #1240 set12 (bit2) is ON, a magnification (C: 10-fold) corresponding to the input setting unit (#1003 iunit) will be applied on the setting value.	0 to 32.767 (mm)
2058	nrefn Near zero point -	Set the width where the near-reference-point signal is output. (Negative direction width) When set to 0, the width is equivalent to the grid width setting. Note: When #1240 set12 (bit2) is ON, a magnification (C: 10-fold) corresponding to the input setting unit (#1003 iunit) will be applied on the setting value.	0 to 32.767 (mm)
2059	zerbas Select zero point parameter and reference point	Specify the position to be the zero point coordinate during absolute position initial setting. 0: Position that was stopped during stopper method Specify the coordinates of the alignment mark position when using the reference point method. 1: Grid point just before stopper Specify the coordinates of the grid point just before the alignment mark.	0/1

6. AXIS SPECIFICATIONS PARAMETERS
6.4 Axis Specifications Parameters 2

6.4 Axis Specifications Parameters 2

(SETUP PARAM 2. 6/8)

#	Items	Details	Setting range (unit)
2061	OT_1B- Soft limit IB-	Set up the coordinates of the lower limit of the inhibited area of stored stroke limit IB. Specify a value in the basic mechanical coordinates system. If the same value (non-zero) with the same sign as that of #2062 OT_1B+ is specified, the stored stroke limit IB function is disabled.	±99999.999 (mm)
2062	OT_1B+ Soft limit IB+	Set up the coordinates of the upper limit of the inhibited area of stored stroke limit IB. Specify a value in the basic mechanical coordinates system.	±99999.999 (mm)
2063	OT_1B type Soft limit IB type	Select OT_1B or OT_1C in which OT_1B+/- is used in stored stroke limit I. 0: Soft limit IB valid 1: Soft limit IB invalid 2: Soft limit IC valid 3: When using the inclined axis specifications, the soft limit is checked with the program coordinate system. Note: This is invalid for axes other than the inclined axis' base axis and inclined axis.	0/1/2/3
2064		Not used.	
2065		Not used.	
2066		Not used.	
2067		Not used.	

6. AXIS SPECIFICATIONS PARAMETERS
6.4 Axis Specifications Parameters 2

#	Items		Details	Setting range (unit)
2068	G0fwdg	G00 feed forward gain	Specify the feed forward gain applicable to acceleration/deceleration before G00 interpolation. The greater the set value, the shorter the positioning time during in-position checking. If machine vibration occurs, decrease the set value.	0 to 200 (%)
2069			Not used.	
2070 (PR)	div_RT	Rotational axis division count	Specify the number of divisions of one turn of the rotational axis for purpose of control. Example: When 36 is set, one turn is supposed to be 36.000. Note 1: When 0 is set, the normal rotational axis (360.000 degrees for one turn) is assumed. Note 2: If this parameter is changed when the absolute position detection specification is used, absolute position data is lost. Initialization must be performed again.	0 to 999
2071	s_axis (For L system only)	Inclined axis selection	Select the axis subjected to inclined-axis control or the base axis corresponding to the inclined axis. 0: Axis not subjected to inclined-axis control 1: Inclined axis 2: Base axis corresponding to inclined axis Note: Set 1 or 2 for only one axis. If it is set for two or more axes, inclined-axis control does not work.	0 to 2
2072	rslimt	Restart limit	If the machine is positioned on the minus (-) side of the set value in T-command restart mode, restart search in type 3 is disabled.	±9999.999 (mm)

6. AXIS SPECIFICATIONS PARAMETERS
6.4 Axis Specifications Parameters 2

(SETUP PARAM 2. 7/8)

#	Items		Details	Setting range (unit)
2073	zrn_dog	Origin dog	Under the standard specifications, the origin dog signal is assigned to a fixed device. When it is desired to assign the origin dog signal to a position other than the fixed device, specify the input device in this parameter. Note 1: This parameter is valid when 1 is set in #1226 aux10 bit 5. Note 2: When this parameter is valid, do not set the same device number. If the same device number exists, an emergency stop occurs. However, no device number check is performed for an axis to which a signal that ignores the near-point dog signal (R157) is input.	00 to FF (HEX)
2074	H/W_OT+	H/W OT+	Under the standard specifications, the OT (+) signal is assigned to a fixed device. When it is desired to assign the OT (+) g signal to a position other than the fixed device, specify the input device in this parameter. Note 1: This parameter is valid when 1 is set in #1226 aux10 bit 5. Note 2: When this parameter is valid, do not set the same device number. If the same device number exists, an emergency stop occurs. However, no device number check is performed for an axis to which a signal that ignores the OT signal (R156) is input.	00 to FF (HEX)
2075	H/W_OT-	H/W OT-	Under the standard specifications, the OT (-) signal is assigned to a fixed device. When it is desired to assign the OT (-) g signal to a position other than the fixed device, specify the input device in this parameter. Note 1: This parameter is valid when 1 is set in #1226 aux10 bit 5. Note 2: When this parameter is valid, do not set the same device number. If the same device number exists, an emergency stop occurs. However, no device number check is performed for an axis to which a signal that ignores the OT signal (R156) is input.	00 to FF (HEX)
2076	index_x	Index table indexing axis	Specify the index table indexing axis. 0: Normal axis 1: Index table indexing axis Note: This parameter is valid only for the NC axis. The parameter is invalid if specified for the PLC axis.	0/1
2077	G0inps	G0 in-position width	When an in-position check is performed for G0, this parameter is valid. (Comparison of SV024 and this parameter, the parameter that the in-position width is wider is applied.) When 0 is set, this parameter is invalid. (Applicable only to SV024)	0 to 32767 (μm)

6. AXIS SPECIFICATIONS PARAMETERS
6.4 Axis Specifications Parameters 2

#	Items		Details	Setting range (unit)
2078	G1inps	G1 in-position width	When an in-position check is performed for G1, this parameter is valid. (Comparison of SV024 and this parameter, the parameter that the in-position width is wider is applied.) When 0 is set, this parameter is invalid. (Applicable only to SV024)	0 to 32767 (μm)
2079	chcomp	Chopping compensation coefficient	Set the coefficient applied on the compensation amount for the insufficient amount caused by servo delay during chopping.	0 to 10 (standard value: 8)
2080	chwid	Bottom dead center position width	Set the tolerance between the commanded stroke and actual stroke. During chopping, if the (command width - maximum stroke of top/bottom dead center position /2) is within this tolerance, compensation will be applied.	Least setting increment =1μm: 0 to 10000 (μm) Least setting increment =0.1μm: 0 to 10000 (0.1 μm)
2081	chclsp	Maximum chopping speed	Set the chopping axis clamp speed applied during chopping.	Least setting increment =1μm: 0 to 60000 (mm/min) Least setting increment =0.1μm: 0 to 60000 (0.1 mm)/min
2082	a_rstax	Restart position return order	Designate the order for automatically returning to the restart position. 0: Do not return. When 0 is designated for all axes, all of the axes will return simultaneously.	0 to 4
2084	G60_ax	Unidirectional positioning operation selection	Select the unidirectional positioning with G00. Select the axis for carrying out the positioning per time operation when the positioning command is issued regardless of the unidirectional positioning command and modal. 0: Carry out unidirectional positioning according to the command and modal. 1: When the positioning command (G00) is issued, carry out unidirectional positioning regardless of the command and modal. <Related parameters> #8209 G60 SHIFT: The final positioning direction and distance for the unidirectional positioning command is set for each axis. #2076 Index table indexing axis: Set the indexing axis for each axis.	0/1

6. AXIS SPECIFICATIONS PARAMETERS
6.4 Axis Specifications Parameters 2

(SETUP PARAM 2. 8/8)

#	Items	Details	Setting range (unit)
2086	exdcax External deceleration speed	Set the upper limit of the feedrate for each axis when the external deceleration signal is valid. This parameter is valid when the #1239 set11/bit6 external deceleration axis compliance valid is set to 1.	1 to 999999 (mm/min)
2087	syncnt	Not used.	
2088	bsax_sy	Not used.	
2089	bsax_pl	Not used.	
2090	plrapid	Not used.	
2091	plclamp	Not used.	
2092	plG0tL	Not used.	
2093	plG0t1	Not used.	
2094	plG1tL	Not used.	
2095	plG1t1	Not used.	
2096	crncsp Minimum corner deceleration speed	Set the minimum clamp speed for corner deceleration during the high-accuracy control mode. Normally set "0".	0 to 1000000 (mm/min)
2102	skip_tL Skip time constant linear	Set up a linear control time constant for variable speed skip acceleration and deceleration. The time constant is validated when LC (cutting feed with linear acceleration and deceleration) or F (acceleration and deceleration by software) is selected in acceleration or deceleration mode "#2003 smgst".	1 to 4000 (ms)
2103	skip_t1 Skip time constant primary delay acceleration and deceleration by software second stage	Set up a primary-delay time constant for variable speed skip acceleration and deceleration. The time constant is validated when C1 (cutting feed with primary delay) or C3 (exponential acceleration and linear deceleration) is selected in acceleration or deceleration mode "#2003 smgst". When acceleration or deceleration by software is selected, the second-step time constant is used.	1 to 5000 (ms)

7. SERVO PARAMETERS

The parameters can be changed from any screen.

The valid servo parameters will differ according to the motor type. The setting values and meanings may also differ. Follow the correspondence table given below, and set the correct parameters.

Refer to each Instruction Manual or the following manuals for details on each motor.

MELDAS AC Servo/ Spindle MDS-A Series MDS-B Series Specifications Manual	BNP-B3759
MELDAS AC Servo MDS-B-Vx Series Servo Parameters Manual	BNP-A2993
MELDAS AC Servo MDS-B-SVJ2 Series Specifications and Instruction Manual	BNP-B3937
MELDAS AC Servo/ Spindle MDS-C1 Series Specifications Manual	BNP-C3000
MELDAS AC Servo MDS-R Series Specifications and Instruction Manual	BNP-C3045

Parameter		Corresponding model			
		MDS-B-SVJ2	MDS-C1-Vx (High-gain) (MDS-B-Vx4)	MDS-C1-Vx (Standard) (MDS-B-Vx)	MDS-R-Vx
SV001	Motor side gear ratio	○	○	○	○
SV002	Machine side gear ratio	○	○	○	○
SV003	Position loop gain 1	○	○	○	○
SV004	Position loop gain 2	○	○	○	○
SV005	Speed loop gain 1	○	○	○	○
SV006	Speed loop gain 2	—	○	○	○
SV007	Speed loop delay compensation	—	○	○	○
SV008	Speed loop lead compensation	○	○	○	○
SV009	Current loop q axis lead compensation	○	○	○	○
SV010	Current loop d axis lead compensation	○	○	○	○
SV011	Current loop q axis gain	○	○	○	○
SV012	Current loop d axis gain	○	○	○	○
SV013	Current limit value	○	○	○	○
SV014	Current limit value in special control	○	○	○	○
SV015	Acceleration rate feed forward gain	○	○	○	○
SV016	Lost motion compensation 1	○	○	○	○
SV017	Servo specification selection	○	○	○	○
SV018	Ball screw pitch	○	○	○	○
SV019	Position detector resolution	○	○	○	○
SV020	Speed detector resolution	○	○	○	○
SV021	Overload detection time constant	○	○	○	○
SV022	Overload detection level	○	○	○	○
SV023	Excessive error detection width during servo ON	○	○	○	○
SV024	In-position detection width	○	○	○	○
SV025	Motor/Detector type	○	○	○	○
SV026	Excessive error detection width during servo OFF	○	○	○	○
SV027	Servo function selection 1	○	○	○	○
SV028	Linear motor magnetic pole shift length	—	—	—	—
SV029	Speed at the change of speed loop gain	—	○	○	○
SV030	Voltage dead time compensation	—/○	○/○	○/○	—/○
SV031	Overshooting compensation 1	○	○	○	○
SV032	Torque offset	○	○	○	○

7. SERVO PARAMETERS

Parameter		Corresponding model			
		MDS-B-SVJ2	MDS-C1-Vx (High-gain) (MDS-B-Vx4)	MDS-C1-Vx (Standard) (MDS-B-Vx)	MDS-R-Vx
SV033	Servo function selection 2	○	○	○	○
SV034	Servo function selection 3	○	○	○	○
SV035	Servo function selection 4	○	○	○	○
SV036	Regenerative resistor type	○	○	○	○
SV037	Load inertia scale	○	○	○	○
SV038	Notch filter frequency 1	—	○	○	○
SV039	Lost motion compensation timing	—	○	○	○
SV040	Non-sensitive band in feed forward control	-/○	○/○	○/○	-/○
SV041	Lost motion compensation 2	○	○	○	○
SV042	Overshooting compensation 2	○	○	○	○
SV043	Disturbance observer filter frequency	○	○	○	○
SV044	Disturbance observer gain	○	○	○	○
SV045	Frictional torque	-/○	○/○	○/○	-/-
SV046	Notch filter frequency 2	—	○	—	○
SV047	Inductive voltage compensation gain	○	○	○	○
SV048	Vertical axis drop prevention time	○	○	○	○
SV049	Position loop gain 1 in spindle synchronous control	○	○	○	○
SV050	Position loop gain 2 in spindle synchronous control	○	○	○	○
SV051	Dual feedback control time constant	—	○	○	○
SV052	Dual feedback control non-sensitive band	—	○	○	○
SV053	Excessive error detection width in special control	○	○	○	○
SV054	Overrun detection width in closed loop control	-/-	○/○	-/○	-/○
SV055	Max. gate off delay time after emergency stop	—	○	○	○
SV056	Deceleration time constant at emergency stop	○	○	○	○
SV057	SHG control gain	○	○	○	○
SV058	SHG control gain in spindle synchronous control	○	○	○	○
SV059	Collision detection torque estimating gain	○	○	○	—
SV060	Collision detection level	○	○	○	—
SV061	D/A output channel 1 data No.	○	○	○	○
SV062	D/A output channel 2 data No.	○	○	○	○
SV063	D/A output channel 1 output scale	○	○	○	○
SV064	D/A output channel 2 output scale	○	○	○	○
SV065	Tool end compensation spring constant	—	○	—	—
SV066	System setting parameter	—	○	—	—
⋮					
SV080		—	○	—	—

7. SERVO PARAMETERS

Parameter		Corresponding model			
		MDS-B-SVJ2	MDS-C1-Vx (High-gain) (MDS-B-Vx4)	MDS-C1-Vx (Standard) (MDS-B-Vx)	MDS-R-Vx
SV081	Servo specification selection 2	-	○	-	-
SV082	Servo function selection 5	-	○	-	-
SV083	Servo function selection 6	-	○	-	-
SV084	Servo function selection 7	-	○	-	-
SV085	Lost motion compensation spring constant	-	○	-	-
SV086	Lost motion compensation viscous coefficient	-	○	-	-
SV087	Notch filter frequency 4	-	○	-	-
SV088	Notch filter frequency 5	-	○	-	-
SV089 : SV100		-	○	-	-

7. Servo Parameters
7.1 MDS-B-SVJ2

7.1 MDS-B-SVJ2

(1) Details for servo parameters

For parameters marked with a (PR) in the table, turn the NC power OFF after setting. After the power is turned ON again, the parameter is validated.

! CAUTION

! In the explanation on bits, set all bits not used, including blank bits, to "0".

No.	Items	Details	Setting range
2201 (PR)	SV001 PC1	Motor side gear ratio	1 to 32767
2202 (PR)	SV002 PC2	Machine side gear ratio	1 to 32767
2203	SV003 PGN1	Position loop gain 1	1 to 200 (rad/s)
2204	SV004 PGN2	Position loop gain 2	0 to 999 (rad/s)
2205	SV005 VGN1	Speed loop gain	1 to 999
2206		Not used. Set to "0".	0
2207		Not used. Set to "0".	0
2208	SV008 VIA	Speed loop lead compensation	1 to 9999

7. Servo Parameters
7.1 MDS-B-SVJ2

No.	Items		Details	Setting range
2209	SV009 IQA	Current loop q axis lead compensation	Set the gain of current loop. As this setting is determined by the motor's electrical characteristics, the setting is fixed for each type of motor. Set the standard values for all the parameters depending on each motor type.	1 to 20480
2210	SV010 IDA	Current loop d axis lead compensation		1 to 20480
2211	SV011 IQG	Current loop q axis gain		1 to 2560
2212	SV012 IDG	Current loop d axis gain		1 to 2560
2213	SV013 ILMT	Current limit value	Set the normal current (torque) limit value. (Limit values for both + and - direction.) When the value is "500" (a standard setting), the maximum torque is determined by the specification of the motor.	0 to 500 (Stall [rated] current %)
2214	SV014 ILMTsp	Current limit value in special control	Set the current (torque) limit value in a special control (initial absolute position setting, stopper control, etc). (Limit values for both of the + and - directions.) Set to "500" when not using.	0 to 500 (Stall [rated] current %)
2215	SV015 FFC	Acceleration rate feed forward gain	When a relative error in the synchronous control is large, apply this parameter to the axis that is delaying. The standard setting value is "0". For the SHG control, set to "100". To adjust a relative error in acceleration/ deceleration, increase the value by 50 to 100 at a time.	0 to 999 (%)

7. Servo Parameters
7.1 MDS-B-SVJ2

No.	Items	Details	Setting range
2216	SV016 LMC1 Lost motion compensation 1	Set this when the protrusion (that occurs due to the non-sensitive band by friction, torsion, backlash, etc) at quadrant change is too large. This compensates the torque at quadrant change. This is valid only when the lost motion compensation (SV027 (SSF1/lmc)) is selected.	
		Type 1: When SV027 (SSF1)/ bit9, 8 (lmc)=01 Set the compensation amount based on the motor torque before the quadrant change. The standard setting is "100". Setting to "0" means the compensation amount is zero. Normally, use Type 2.	-1 to 200 (%)
		Type 2: When SV027 (SSF1)/ bit9, 8 (lmc)=10 Set the compensation amount based on the stall (rated) current of the motor. The standard setting is double of the friction torque. Setting to "0" means the compensation amount is zero.	-1 to 100 (Stall [rated] current %)
		When you wish different compensation amount depending on the direction When SV041 (LMC2) is "0", compensate with the value of SV016 (LMC1) in both of the + and -directions. If you wish to change the compensation amount depending on the command direction, set this and SV041 (LMC2). (SV016: + direction, SV041: - direction. However, the directions may be opposite depending on other settings.) When "-1" is set, the compensation won't be performed in the direction of the command.	

7. Servo Parameters
7.1 MDS-B-SVJ2

No.	Items	Details	Setting range																																																					
2217 (PR)	SV017 SPEC	Servo specification selection	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 12.5%; text-align: center;">F</td> <td style="width: 12.5%; text-align: center;">E</td> <td style="width: 12.5%; text-align: center;">D</td> <td style="width: 12.5%; text-align: center;">C</td> <td style="width: 12.5%; text-align: center;">B</td> <td style="width: 12.5%; text-align: center;">A</td> <td style="width: 12.5%; text-align: center;">9</td> <td style="width: 12.5%; text-align: center;">8</td> </tr> <tr> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="border: 1px solid black; text-align: center;">abs</td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; text-align: center;">vdir</td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; text-align: center;">mc</td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; text-align: center;">dmk</td> </tr> </table>	F	E	D	C	B	A	9	8									7	6	5	4	3	2	1	0	abs		vdir		mc			dmk																					
			F	E	D	C	B	A	9	8																																														
			7	6	5	4	3	2	1	0																																														
			abs		vdir		mc			dmk																																														
			<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 5%;">bit</th> <th style="width: 15%;">Meaning when "0" is set</th> <th style="width: 80%;">Meaning when "1" is set</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">dmk</td> <td>Deceleration control stop (SVJ2 standard)</td> </tr> <tr> <td style="text-align: center;">1</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">2</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">mc</td> <td>Contactor control output invalid</td> </tr> <tr> <td style="text-align: center;">4</td> <td></td> <td>Contactor control output valid</td> </tr> <tr> <td style="text-align: center;">5</td> <td style="text-align: center;">vdir</td> <td>HA053N to HA33N motor Detector installation position standard (A, C)</td> </tr> <tr> <td style="text-align: center;">6</td> <td></td> <td>HA053N to HA33N motor Detector installation position 90 degrees (B, D)</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">abs</td> <td>Incremental control</td> </tr> <tr> <td style="text-align: center;">8</td> <td></td> <td>Absolute position control</td> </tr> <tr> <td style="text-align: center;">9</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">A</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">B</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">C</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">D</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">E</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">F</td> <td></td> <td></td> </tr> </tbody> </table>			bit	Meaning when "0" is set	Meaning when "1" is set	0	dmk	Deceleration control stop (SVJ2 standard)	1			2			3	mc	Contactor control output invalid	4		Contactor control output valid	5	vdir	HA053N to HA33N motor Detector installation position standard (A, C)	6		HA053N to HA33N motor Detector installation position 90 degrees (B, D)	7	abs	Incremental control	8		Absolute position control	9			A			B			C			D			E			F		
			bit	Meaning when "0" is set	Meaning when "1" is set																																																			
			0	dmk	Deceleration control stop (SVJ2 standard)																																																			
			1																																																					
			2																																																					
3	mc	Contactor control output invalid																																																						
4		Contactor control output valid																																																						
5	vdir	HA053N to HA33N motor Detector installation position standard (A, C)																																																						
6		HA053N to HA33N motor Detector installation position 90 degrees (B, D)																																																						
7	abs	Incremental control																																																						
8		Absolute position control																																																						
9																																																								
A																																																								
B																																																								
C																																																								
D																																																								
E																																																								
F																																																								
(Note) Set to "0" for bits with no particular description.																																																								
2218 (PR)	SV018 PIT	Ball screw pitch	Set the ball screw pitch. Set to "360" for the rotary axis.																																																					
2219 (PR)	SV019 RNG1	Position detector resolution	1 to 32767 (mm/rev)																																																					
2219 (PR)	SV019 RNG1	Position detector resolution	For both parameters, set the number of pulses per one revolution of the motor detector.																																																					
2220 (PR)	SV020 RNG2	Speed detector resolution	8 to 100 (kp/rev)																																																					
2220 (PR)	SV020 RNG2	Speed detector resolution	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="width: 60%;">Motor model name</th> <th colspan="2" style="text-align: center;">Setting value</th> </tr> <tr> <th style="width: 20%;">SV019</th> <th style="width: 20%;">SV020</th> </tr> </thead> <tbody> <tr> <td>HC*-E42/A42/A47, HC*R-E42/A42/A47 HA*N-E42/A42</td> <td style="text-align: center;">100</td> <td style="text-align: center;">100</td> </tr> <tr> <td>HC*-E33/A33, HC*R-E33/A33 HA*N-E33/A33</td> <td style="text-align: center;">25</td> <td style="text-align: center;">25</td> </tr> <tr> <td>HC-SF, HC-RF</td> <td style="text-align: center;">16</td> <td style="text-align: center;">16</td> </tr> <tr> <td>HA-FF, HC-MF</td> <td style="text-align: center;">8</td> <td style="text-align: center;">8</td> </tr> </tbody> </table>	Motor model name	Setting value		SV019	SV020	HC*-E42/A42/A47, HC*R-E42/A42/A47 HA*N-E42/A42	100	100	HC*-E33/A33, HC*R-E33/A33 HA*N-E33/A33	25	25	HC-SF, HC-RF	16	16	HA-FF, HC-MF	8	8																																				
Motor model name	Setting value																																																							
	SV019	SV020																																																						
HC*-E42/A42/A47, HC*R-E42/A42/A47 HA*N-E42/A42	100	100																																																						
HC*-E33/A33, HC*R-E33/A33 HA*N-E33/A33	25	25																																																						
HC-SF, HC-RF	16	16																																																						
HA-FF, HC-MF	8	8																																																						
2221	SV021 OLT	Overload detection time constant	Set the detection time constant of Overload 1 (Alarm 50). Set to "60" as a standard. (For machine tool builder adjustment.)																																																					
2221	SV021 OLT	Overload detection time constant	1 to 300 (s)																																																					
2222	SV022 OLL	Overload detection level	Set the current detection level of Overload 1 (Alarm 50) in respect to the stall (rated) current. Set to "150" as a standard. (For machine tool builder adjustment.)																																																					
2222	SV022 OLL	Overload detection level	50 to 180 (Stall [rated] current %)																																																					

7. Servo Parameters
7.1 MDS-B-SVJ2

No.	Items	Details	Setting range
2223	SV023 OD1	<p>Excessive error detection width during servo ON</p> <p>Set the excessive error detection width when servo ON. <Standard setting value></p> $OD1=OD2= \frac{\text{Rapid traverse rate (mm/min)}}{60 \cdot PGN1} / 2 \text{ (mm)}$ <p>When "0" is set, the excessive error detection will not be performed.</p>	0 to 32767 (mm)
2224	SV024 INP	<p>In-position detection width</p> <p>Set the in-position detection width. Set the accuracy required for the machine. The lower the setting is, the higher the positioning accuracy gets, however, the cycle time (setting time) becomes longer. The standard setting is "50".</p>	0 to 32767 (μm)

7. Servo Parameters
7.1 MDS-B-SVJ2

No.	Items	Details	Setting range																																																																																																																																																																																																																																																																																																																											
2225 (PR)	SV025 MTYP	Motor/ Detector type	<table border="1" style="width:100%; text-align:center;"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td colspan="4">pen</td><td colspan="4">ent</td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td colspan="8">mtyp</td> </tr> </table>	F	E	D	C	B	A	9	8	pen				ent				7	6	5	4	3	2	1	0	mtyp																																																																																																																																																																																																																																																																																																		
			F	E	D	C	B	A	9	8																																																																																																																																																																																																																																																																																																																				
pen				ent																																																																																																																																																																																																																																																																																																																										
7	6	5	4	3	2	1	0																																																																																																																																																																																																																																																																																																																							
mtyp																																																																																																																																																																																																																																																																																																																														
<table border="1" style="width:100%;"> <thead> <tr> <th style="width:5%;">bit</th> <th style="width:95%;">Explanation</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Set the motor type.</td> </tr> <tr> <td>1</td> <td rowspan="16"> <table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th style="width:5%;">Set- ting</th> <th style="width:15%;">0x</th> <th style="width:5%;">1x</th> <th style="width:5%;">2x</th> <th style="width:5%;">3x</th> <th style="width:5%;">4x</th> <th style="width:5%;">5x</th> <th style="width:5%;">6x</th> <th style="width:15%;">7x</th> <th style="width:15%;">8x</th> </tr> </thead> <tbody> <tr> <td>x0</td> <td>HA40N</td> <td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF43</td> <td>HA43N</td> </tr> <tr> <td>x1</td> <td>HA80N</td> <td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF63</td> <td>HA83N</td> </tr> <tr> <td>x2</td> <td>HA100N</td> <td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td>HA103N</td> </tr> <tr> <td>x3</td> <td>HA200N</td> <td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x4</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x5</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x6</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x7</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x8</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x9</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>xA</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td>HA93N</td> </tr> <tr> <td>xB</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>xC</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF053</td> <td>HA053N</td> </tr> <tr> <td>xD</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF13</td> <td>HA13N</td> </tr> <tr> <td>xE</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF23</td> <td>HA23N</td> </tr> <tr> <td>xF</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF33</td> <td>HA33N</td> </tr> </tbody> </table> </td> </tr> <tr> <td colspan="3"> <table border="1" style="width:100%;"> <thead> <tr> <th style="width:5%;">Set- ting</th> <th style="width:15%;">9x</th> <th style="width:5%;">Ax</th> <th style="width:15%;">Bx</th> <th style="width:15%;">Cx</th> <th style="width:5%;">Dx</th> <th style="width:15%;">Ex</th> <th style="width:10%;">Fx</th> </tr> </thead> <tbody> <tr> <td>x0</td> <td>HC-MF43</td> <td></td> <td>HC52 or HC-SF52</td> <td>HC53 or HC-SF53</td> <td></td> <td></td> <td></td> </tr> <tr> <td>x1</td> <td>HC-MF73</td> <td></td> <td>HC102 or HC-SF102</td> <td>HC103 or HC-SF103</td> <td></td> <td>HC103R or HC-RF103</td> <td></td> </tr> <tr> <td>x2</td> <td></td> <td></td> <td>HC152 or HC-SF152</td> <td>HC153 or HC-SF153</td> <td></td> <td>HC153R or HC-RF153</td> <td></td> </tr> <tr> <td>x3</td> <td></td> <td></td> <td>HC202 or HC-SF202</td> <td>HC203 or HC-SF203</td> <td></td> <td>HC203R or HC-RF203</td> <td></td> </tr> <tr> <td>x4</td> <td></td> <td></td> <td>HC352 or HC-SF352</td> <td>HC-SF353</td> <td></td> <td></td> <td></td> </tr> <tr> <td>x5</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>x6</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>x7</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>x8</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>x9</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xA</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xB</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xC</td> <td>HC-MF053</td> <td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xD</td> <td>HC-MF13</td> <td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xE</td> <td>HC-MF23</td> <td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xF</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </tbody> </table> </td> <td></td> </tr> </tbody> </table>			bit	Explanation	0	Set the motor type.	1	<table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th style="width:5%;">Set- ting</th> <th style="width:15%;">0x</th> <th style="width:5%;">1x</th> <th style="width:5%;">2x</th> <th style="width:5%;">3x</th> <th style="width:5%;">4x</th> <th style="width:5%;">5x</th> <th style="width:5%;">6x</th> <th style="width:15%;">7x</th> <th style="width:15%;">8x</th> </tr> </thead> <tbody> <tr> <td>x0</td> <td>HA40N</td> <td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF43</td> <td>HA43N</td> </tr> <tr> <td>x1</td> <td>HA80N</td> <td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF63</td> <td>HA83N</td> </tr> <tr> <td>x2</td> <td>HA100N</td> <td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td>HA103N</td> </tr> <tr> <td>x3</td> <td>HA200N</td> <td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x4</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x5</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x6</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x7</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x8</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x9</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>xA</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td>HA93N</td> </tr> <tr> <td>xB</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>xC</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF053</td> <td>HA053N</td> </tr> <tr> <td>xD</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF13</td> <td>HA13N</td> </tr> <tr> <td>xE</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF23</td> <td>HA23N</td> </tr> <tr> <td>xF</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF33</td> <td>HA33N</td> </tr> </tbody> </table>	Set- ting	0x	1x	2x	3x	4x	5x	6x	7x	8x	x0	HA40N							HA-FF43	HA43N	x1	HA80N							HA-FF63	HA83N	x2	HA100N								HA103N	x3	HA200N									x4										x5										x6										x7										x8										x9										xA									HA93N	xB										xC								HA-FF053	HA053N	xD								HA-FF13	HA13N	xE								HA-FF23	HA23N	xF								HA-FF33	HA33N	<table border="1" style="width:100%;"> <thead> <tr> <th style="width:5%;">Set- ting</th> <th style="width:15%;">9x</th> <th style="width:5%;">Ax</th> <th style="width:15%;">Bx</th> <th style="width:15%;">Cx</th> <th style="width:5%;">Dx</th> <th style="width:15%;">Ex</th> <th style="width:10%;">Fx</th> </tr> </thead> <tbody> <tr> <td>x0</td> <td>HC-MF43</td> <td></td> <td>HC52 or HC-SF52</td> <td>HC53 or HC-SF53</td> <td></td> <td></td> <td></td> </tr> <tr> <td>x1</td> <td>HC-MF73</td> <td></td> <td>HC102 or HC-SF102</td> <td>HC103 or HC-SF103</td> <td></td> <td>HC103R or HC-RF103</td> <td></td> </tr> <tr> <td>x2</td> <td></td> <td></td> <td>HC152 or HC-SF152</td> <td>HC153 or HC-SF153</td> <td></td> <td>HC153R or HC-RF153</td> <td></td> </tr> <tr> <td>x3</td> <td></td> <td></td> <td>HC202 or HC-SF202</td> <td>HC203 or HC-SF203</td> <td></td> <td>HC203R or HC-RF203</td> <td></td> </tr> <tr> <td>x4</td> <td></td> <td></td> <td>HC352 or HC-SF352</td> <td>HC-SF353</td> <td></td> <td></td> <td></td> </tr> <tr> <td>x5</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>x6</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>x7</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>x8</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>x9</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xA</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xB</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xC</td> <td>HC-MF053</td> <td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xD</td> <td>HC-MF13</td> <td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xE</td> <td>HC-MF23</td> <td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xF</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </tbody> </table>			Set- ting	9x	Ax	Bx	Cx	Dx	Ex	Fx	x0	HC-MF43		HC52 or HC-SF52	HC53 or HC-SF53				x1	HC-MF73		HC102 or HC-SF102	HC103 or HC-SF103		HC103R or HC-RF103		x2			HC152 or HC-SF152	HC153 or HC-SF153		HC153R or HC-RF153		x3			HC202 or HC-SF202	HC203 or HC-SF203		HC203R or HC-RF203		x4			HC352 or HC-SF352	HC-SF353				x5								x6								x7								x8								x9								xA								xB								xC	HC-MF053							xD	HC-MF13							xE	HC-MF23							xF								
bit	Explanation																																																																																																																																																																																																																																																																																																																													
0	Set the motor type.																																																																																																																																																																																																																																																																																																																													
1	<table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th style="width:5%;">Set- ting</th> <th style="width:15%;">0x</th> <th style="width:5%;">1x</th> <th style="width:5%;">2x</th> <th style="width:5%;">3x</th> <th style="width:5%;">4x</th> <th style="width:5%;">5x</th> <th style="width:5%;">6x</th> <th style="width:15%;">7x</th> <th style="width:15%;">8x</th> </tr> </thead> <tbody> <tr> <td>x0</td> <td>HA40N</td> <td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF43</td> <td>HA43N</td> </tr> <tr> <td>x1</td> <td>HA80N</td> <td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF63</td> <td>HA83N</td> </tr> <tr> <td>x2</td> <td>HA100N</td> <td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td>HA103N</td> </tr> <tr> <td>x3</td> <td>HA200N</td> <td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x4</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x5</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x6</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x7</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x8</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>x9</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>xA</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td>HA93N</td> </tr> <tr> <td>xB</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td></td> <td></td> </tr> <tr> <td>xC</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF053</td> <td>HA053N</td> </tr> <tr> <td>xD</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF13</td> <td>HA13N</td> </tr> <tr> <td>xE</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF23</td> <td>HA23N</td> </tr> <tr> <td>xF</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> <td>HA-FF33</td> <td>HA33N</td> </tr> </tbody> </table>	Set- ting	0x	1x	2x	3x	4x		5x	6x	7x	8x	x0	HA40N							HA-FF43	HA43N	x1	HA80N							HA-FF63	HA83N	x2	HA100N								HA103N	x3	HA200N									x4										x5										x6										x7										x8										x9										xA									HA93N	xB										xC								HA-FF053	HA053N	xD								HA-FF13	HA13N	xE								HA-FF23	HA23N	xF								HA-FF33	HA33N																																																																																																																																																		
Set- ting		0x	1x	2x	3x	4x	5x		6x	7x	8x																																																																																																																																																																																																																																																																																																																			
x0		HA40N								HA-FF43	HA43N																																																																																																																																																																																																																																																																																																																			
x1		HA80N								HA-FF63	HA83N																																																																																																																																																																																																																																																																																																																			
x2		HA100N									HA103N																																																																																																																																																																																																																																																																																																																			
x3		HA200N																																																																																																																																																																																																																																																																																																																												
x4																																																																																																																																																																																																																																																																																																																														
x5																																																																																																																																																																																																																																																																																																																														
x6																																																																																																																																																																																																																																																																																																																														
x7																																																																																																																																																																																																																																																																																																																														
x8																																																																																																																																																																																																																																																																																																																														
x9																																																																																																																																																																																																																																																																																																																														
xA											HA93N																																																																																																																																																																																																																																																																																																																			
xB																																																																																																																																																																																																																																																																																																																														
xC									HA-FF053	HA053N																																																																																																																																																																																																																																																																																																																				
xD									HA-FF13	HA13N																																																																																																																																																																																																																																																																																																																				
xE								HA-FF23	HA23N																																																																																																																																																																																																																																																																																																																					
xF								HA-FF33	HA33N																																																																																																																																																																																																																																																																																																																					
<table border="1" style="width:100%;"> <thead> <tr> <th style="width:5%;">Set- ting</th> <th style="width:15%;">9x</th> <th style="width:5%;">Ax</th> <th style="width:15%;">Bx</th> <th style="width:15%;">Cx</th> <th style="width:5%;">Dx</th> <th style="width:15%;">Ex</th> <th style="width:10%;">Fx</th> </tr> </thead> <tbody> <tr> <td>x0</td> <td>HC-MF43</td> <td></td> <td>HC52 or HC-SF52</td> <td>HC53 or HC-SF53</td> <td></td> <td></td> <td></td> </tr> <tr> <td>x1</td> <td>HC-MF73</td> <td></td> <td>HC102 or HC-SF102</td> <td>HC103 or HC-SF103</td> <td></td> <td>HC103R or HC-RF103</td> <td></td> </tr> <tr> <td>x2</td> <td></td> <td></td> <td>HC152 or HC-SF152</td> <td>HC153 or HC-SF153</td> <td></td> <td>HC153R or HC-RF153</td> <td></td> </tr> <tr> <td>x3</td> <td></td> <td></td> <td>HC202 or HC-SF202</td> <td>HC203 or HC-SF203</td> <td></td> <td>HC203R or HC-RF203</td> <td></td> </tr> <tr> <td>x4</td> <td></td> <td></td> <td>HC352 or HC-SF352</td> <td>HC-SF353</td> <td></td> <td></td> <td></td> </tr> <tr> <td>x5</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>x6</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>x7</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>x8</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>x9</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xA</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xB</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xC</td> <td>HC-MF053</td> <td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xD</td> <td>HC-MF13</td> <td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xE</td> <td>HC-MF23</td> <td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>xF</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </tbody> </table>			Set- ting	9x	Ax	Bx	Cx	Dx	Ex	Fx	x0	HC-MF43		HC52 or HC-SF52	HC53 or HC-SF53				x1	HC-MF73		HC102 or HC-SF102	HC103 or HC-SF103		HC103R or HC-RF103		x2			HC152 or HC-SF152	HC153 or HC-SF153		HC153R or HC-RF153		x3			HC202 or HC-SF202	HC203 or HC-SF203		HC203R or HC-RF203		x4			HC352 or HC-SF352	HC-SF353				x5								x6								x7								x8								x9								xA								xB								xC	HC-MF053							xD	HC-MF13							xE	HC-MF23							xF																																																																																																																																																																																											
Set- ting	9x	Ax	Bx	Cx	Dx	Ex	Fx																																																																																																																																																																																																																																																																																																																							
x0	HC-MF43		HC52 or HC-SF52	HC53 or HC-SF53																																																																																																																																																																																																																																																																																																																										
x1	HC-MF73		HC102 or HC-SF102	HC103 or HC-SF103		HC103R or HC-RF103																																																																																																																																																																																																																																																																																																																								
x2			HC152 or HC-SF152	HC153 or HC-SF153		HC153R or HC-RF153																																																																																																																																																																																																																																																																																																																								
x3			HC202 or HC-SF202	HC203 or HC-SF203		HC203R or HC-RF203																																																																																																																																																																																																																																																																																																																								
x4			HC352 or HC-SF352	HC-SF353																																																																																																																																																																																																																																																																																																																										
x5																																																																																																																																																																																																																																																																																																																														
x6																																																																																																																																																																																																																																																																																																																														
x7																																																																																																																																																																																																																																																																																																																														
x8																																																																																																																																																																																																																																																																																																																														
x9																																																																																																																																																																																																																																																																																																																														
xA																																																																																																																																																																																																																																																																																																																														
xB																																																																																																																																																																																																																																																																																																																														
xC	HC-MF053																																																																																																																																																																																																																																																																																																																													
xD	HC-MF13																																																																																																																																																																																																																																																																																																																													
xE	HC-MF23																																																																																																																																																																																																																																																																																																																													
xF																																																																																																																																																																																																																																																																																																																														

(To be continued to the next page)

7. Servo Parameters
7.1 MDS-B-SVJ2

No.	Items	Details	Setting range																																																																																												
		(Continued from the previous page)																																																																																													
		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">bit</th> <th style="width: 10%;"></th> <th style="width: 80%;">Explanation</th> </tr> </thead> <tbody> <tr> <td>8</td> <td rowspan="4" style="text-align: center; vertical-align: middle;">ent</td> <td rowspan="4">Set the speed detector type. Set to "2".</td> </tr> <tr> <td>9</td> </tr> <tr> <td>A</td> </tr> <tr> <td>B</td> </tr> <tr> <td>C</td> <td rowspan="4" style="text-align: center; vertical-align: middle;">pen</td> <td rowspan="4">Set the position detector type. Set to "2".</td> </tr> <tr> <td>D</td> </tr> <tr> <td>E</td> </tr> <tr> <td>F</td> </tr> </tbody> </table>		bit		Explanation	8	ent	Set the speed detector type. Set to "2".	9	A	B	C	pen	Set the position detector type. Set to "2".	D	E	F																																																																													
bit		Explanation																																																																																													
8	ent	Set the speed detector type. Set to "2".																																																																																													
9																																																																																															
A																																																																																															
B																																																																																															
C	pen	Set the position detector type. Set to "2".																																																																																													
D																																																																																															
E																																																																																															
F																																																																																															
2226	SV026 OD2	Excessive error detection width during servo OFF	Set the excessive error detection width when servo ON. For the standard setting, refer to the explanation of SV023 (OD1). When "0" is set, the excessive error detection will not be performed.	0 to 32767 (mm)																																																																																											
2227	SV027 SSF1	Servo function selection 1	<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr> <td style="width: 12.5%;">F</td> <td style="width: 12.5%;">E</td> <td style="width: 12.5%;">D</td> <td style="width: 12.5%;">C</td> <td style="width: 12.5%;">B</td> <td style="width: 12.5%;">A</td> <td style="width: 12.5%;">9</td> <td style="width: 12.5%;">8</td> </tr> <tr> <td>aflt</td> <td>zrn2</td> <td></td> <td></td> <td>ovs</td> <td></td> <td>lmc</td> <td></td> </tr> <tr> <td>7</td> <td>6</td> <td>5</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> <td>0</td> </tr> <tr> <td></td> <td></td> <td>vfct</td> <td></td> <td></td> <td></td> <td></td> <td>zup</td> </tr> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">bit</th> <th style="width: 10%;"></th> <th style="width: 40%;">Meaning when "0" is set</th> <th style="width: 40%;">Meaning when "1" is set</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>zup</td> <td>Vertical axis lift-up control stop</td> <td>Vertical axis lift-up control start</td> </tr> <tr> <td>1</td> <td></td> <td></td> <td></td> </tr> <tr> <td>2</td> <td></td> <td></td> <td></td> </tr> <tr> <td>3</td> <td></td> <td></td> <td></td> </tr> <tr> <td>4</td> <td rowspan="2" style="text-align: center; vertical-align: middle;">vfct</td> <td rowspan="2">Set the jitter compensation No. of compensation pulses with a binary. 00: Jitter compensation invalid 01: Jitter compensation 1 pulse 10: Jitter compensation 2 pulses 11: Jitter compensation 3 pulses</td> <td rowspan="2"></td> </tr> <tr> <td>5</td> </tr> <tr> <td>6</td> <td></td> <td></td> <td></td> </tr> <tr> <td>7</td> <td></td> <td></td> <td></td> </tr> <tr> <td>8</td> <td rowspan="2" style="text-align: center; vertical-align: middle;">lmc</td> <td rowspan="2">Set the compensation amount with SV016 (LMC1) and SV041 (LMC2). 00: Lost motion compensation stop 01: Lost motion compensation type 1 10: Lost motion compensation type 2 11: Setting prohibited</td> <td rowspan="2"></td> </tr> <tr> <td>9</td> </tr> <tr> <td>A</td> <td rowspan="2" style="text-align: center; vertical-align: middle;">ovs</td> <td rowspan="2">Set the compensation amount with SV031 (OVS1) and SV042 (OVS2). 00: Overshooting compensation stop 01: Overshooting compensation type 1 10: Overshooting compensation type 2 11: Setting prohibited</td> <td rowspan="2"></td> </tr> <tr> <td>B</td> </tr> <tr> <td>C</td> <td></td> <td></td> <td></td> </tr> <tr> <td>D</td> <td></td> <td></td> <td></td> </tr> <tr> <td>E</td> <td>zrn2</td> <td>Set to "1".</td> <td></td> </tr> <tr> <td>F</td> <td>aflt</td> <td>Adoptive filter stops</td> <td>Adoptive filter starts</td> </tr> </tbody> </table> <p>(Note) Set to "0" for bits with no particular description.</p>		F	E	D	C	B	A	9	8	aflt	zrn2			ovs		lmc		7	6	5	4	3	2	1	0			vfct					zup	bit		Meaning when "0" is set	Meaning when "1" is set	0	zup	Vertical axis lift-up control stop	Vertical axis lift-up control start	1				2				3				4	vfct	Set the jitter compensation No. of compensation pulses with a binary. 00: Jitter compensation invalid 01: Jitter compensation 1 pulse 10: Jitter compensation 2 pulses 11: Jitter compensation 3 pulses		5	6				7				8	lmc	Set the compensation amount with SV016 (LMC1) and SV041 (LMC2). 00: Lost motion compensation stop 01: Lost motion compensation type 1 10: Lost motion compensation type 2 11: Setting prohibited		9	A	ovs	Set the compensation amount with SV031 (OVS1) and SV042 (OVS2). 00: Overshooting compensation stop 01: Overshooting compensation type 1 10: Overshooting compensation type 2 11: Setting prohibited		B	C				D				E	zrn2	Set to "1".		F	aflt	Adoptive filter stops	Adoptive filter starts
F	E	D	C	B	A	9	8																																																																																								
aflt	zrn2			ovs		lmc																																																																																									
7	6	5	4	3	2	1	0																																																																																								
		vfct					zup																																																																																								
bit		Meaning when "0" is set	Meaning when "1" is set																																																																																												
0	zup	Vertical axis lift-up control stop	Vertical axis lift-up control start																																																																																												
1																																																																																															
2																																																																																															
3																																																																																															
4	vfct	Set the jitter compensation No. of compensation pulses with a binary. 00: Jitter compensation invalid 01: Jitter compensation 1 pulse 10: Jitter compensation 2 pulses 11: Jitter compensation 3 pulses																																																																																													
5																																																																																															
6																																																																																															
7																																																																																															
8	lmc	Set the compensation amount with SV016 (LMC1) and SV041 (LMC2). 00: Lost motion compensation stop 01: Lost motion compensation type 1 10: Lost motion compensation type 2 11: Setting prohibited																																																																																													
9																																																																																															
A	ovs	Set the compensation amount with SV031 (OVS1) and SV042 (OVS2). 00: Overshooting compensation stop 01: Overshooting compensation type 1 10: Overshooting compensation type 2 11: Setting prohibited																																																																																													
B																																																																																															
C																																																																																															
D																																																																																															
E	zrn2	Set to "1".																																																																																													
F	aflt	Adoptive filter stops	Adoptive filter starts																																																																																												
2228	SV028		Not used. Set to "0".	0																																																																																											
2229	SV029		Not used. Set to "0".	0																																																																																											

7. Servo Parameters
7.1 MDS-B-SVJ2

No.	Items	Details	Setting range	
2230	SV030 IVC	Voltage dead time compensation	When 100% is set, the voltage equivalent to the logical non-energized time will be compensated. Adjust in increments of 10% from the default value 100%. If increased too much, vibration or vibration noise may be generated. When not using, set to "0".	0 to 200 (%)
2231	SV031 OVS1	Overshooting compensation 1	Set this if overshooting occurs during positioning. This compensates the motor torque during positioning. This is valid only when the overshooting compensation SV027 (SSF1/ovs) is selected. Type 1: When SV027 (SSF1)/ bit11, 10 (ovs)=01 Set the compensation amount based on the motor's stall (rated) current. Increase by 1% and determine the amount that overshooting doesn't occur. In Type 1, compensation during the feed forward control during circular cutting won't be performed. Type 2: When SV027 (SSF1)/ bit11, 10 (ovs)=10 Use this if you perform the overshooting compensation during the feed forward control during circular cutting. The setting method is the same in Type 1. When you wish different compensation amount depending on the direction When SV042 (OVS2) is "0", compensate with the value of SV031 (OVS1) in both of the + and -directions. If you wish to change the compensation amount depending on the command direction, set this and SV042 (OVS2). (SV031: + direction, SV042: - direction. However, the directions may be opposite depending on other settings.) When "-1" is set, the compensation won't be performed in the direction of the command.	-1 to 100 (Stall [rated] current %)
2232	SV032 TOF	Torque offset	Set the unbalance torque of vertical axis and inclined axis.	-100 to 100 (Stall [rated] current %)

7. Servo Parameters
7.1 MDS-B-SVJ2

No.	Items	Details	Setting range																								
2234	SV034 SSF3 Servo function selection 3	<table border="1"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td>daf2</td><td>daf1</td><td>dac2</td><td>dac1</td><td colspan="4">mon</td> </tr> </table>	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0	daf2	daf1	dac2	dac1	mon				
		F	E	D	C	B	A	9	8																		
		7	6	5	4	3	2	1	0																		
		daf2	daf1	dac2	dac1	mon																					
		bit	Meaning when "0" is set	Meaning when "1" is set																							
		0	NC servo monitor MAX current display data changeover																								
		1	Set- ting	MAX current 1	MAX current 2																						
		2	0	Max. current command value when power is turned ON (%)	Max. current command value for one second (%)																						
		3	1	Max. current command value for one second (%)	Max. current FB value for one second (%)																						
			2	Max. current FB value when power is turned ON (%)	Max. current FB value for one second (%)																						
	3	Load inertia rate (%)	-																								
	4	Adaptive filter operation frequency (Hz)	Adaptive filter operation gain (%)																								
	5	PN bus voltage (V)	Regenerative operation frequency monitor (The number of times/sec)																								
	6	Estimated max. torque for one second (%)	Max. current FB value for one second (%)																								
	7	Estimated max. torque for one second (%)	Max. disturbance torque for two seconds (%)																								
	8 to F	Setting prohibited																									
4	dac1	D/A output ch.1 overflow setting	D/A output ch.1 clamp setting																								
5	dac2	D/A output ch.2 overflow setting	D/A output ch.2 clamp setting																								
6	daf1	D/A output ch.1 no filter	D/A output ch.1 filter setting																								
7	daf2	D/A output ch.2 no filter	D/A output ch.2 filter setting																								
8																											
9																											
A																											
B																											
C																											
D																											
E																											
F																											

(Note) Set to "0" for bits with no particular description.

7. Servo Parameters
7.1 MDS-B-SVJ2

No.	Items	Details	Setting range																																																			
2235	SV035 SSF4	Servo function selection 4																																																				
		<table style="margin: auto; border-collapse: collapse;"> <tr> <td style="padding: 2px;">F</td> <td style="padding: 2px;">E</td> <td style="padding: 2px;">D</td> <td style="padding: 2px;">C</td> <td style="padding: 2px;">B</td> <td style="padding: 2px;">A</td> <td style="padding: 2px;">9</td> <td style="padding: 2px;">8</td> </tr> <tr> <td style="border: 1px solid black; text-align: center;">cl2n</td> <td colspan="2" style="border: 1px solid black; text-align: center;">clG1</td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> </tr> <tr> <td style="padding: 2px;">7</td> <td style="padding: 2px;">6</td> <td style="padding: 2px;">5</td> <td style="padding: 2px;">4</td> <td style="padding: 2px;">3</td> <td style="padding: 2px;">2</td> <td style="padding: 2px;">1</td> <td style="padding: 2px;">0</td> </tr> <tr> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> </tr> </table>	F	E	D	C	B	A	9	8	cl2n	clG1							7	6	5	4	3	2	1	0																												
F	E	D	C	B	A	9	8																																															
cl2n	clG1																																																					
7	6	5	4	3	2	1	0																																															
		<table border="1" style="margin: auto; border-collapse: collapse; width: 100%;"> <thead> <tr> <th style="width: 10%;">bit</th> <th style="width: 45%;">Meaning when "0" is set</th> <th style="width: 45%;">Meaning when "1" is set</th> </tr> </thead> <tbody> <tr><td style="text-align: center;">0</td><td></td><td></td></tr> <tr><td style="text-align: center;">1</td><td></td><td></td></tr> <tr><td style="text-align: center;">2</td><td></td><td></td></tr> <tr><td style="text-align: center;">3</td><td></td><td></td></tr> <tr><td style="text-align: center;">4</td><td></td><td></td></tr> <tr><td style="text-align: center;">5</td><td></td><td></td></tr> <tr><td style="text-align: center;">6</td><td></td><td></td></tr> <tr><td style="text-align: center;">7</td><td></td><td></td></tr> <tr><td style="text-align: center;">8</td><td></td><td></td></tr> <tr><td style="text-align: center;">9</td><td></td><td></td></tr> <tr><td style="text-align: center;">A</td><td></td><td></td></tr> <tr><td style="text-align: center;">B</td><td></td><td></td></tr> <tr> <td style="text-align: center;">C</td> <td colspan="2" rowspan="3">Collision detection method 1 Set the collision detection level during cutting feed (G1). The G1 collision detection level=SV060*clG1.</td> </tr> <tr> <td style="text-align: center;">D</td> </tr> <tr> <td style="text-align: center;">E</td> </tr> <tr> <td style="text-align: center;">F</td> <td style="text-align: center;">clG1</td> <td>When clG1=0, the collision detection method 1 during cutting feed won't function.</td> </tr> <tr> <td style="text-align: center;">F</td> <td style="text-align: center;">cl2n</td> <td>Collision detection method 2 valid</td> <td>Collision detection method 2 invalid</td> </tr> </tbody> </table>	bit	Meaning when "0" is set	Meaning when "1" is set	0			1			2			3			4			5			6			7			8			9			A			B			C	Collision detection method 1 Set the collision detection level during cutting feed (G1). The G1 collision detection level=SV060*clG1.		D	E	F	clG1	When clG1=0, the collision detection method 1 during cutting feed won't function.	F	cl2n	Collision detection method 2 valid	Collision detection method 2 invalid	
bit	Meaning when "0" is set	Meaning when "1" is set																																																				
0																																																						
1																																																						
2																																																						
3																																																						
4																																																						
5																																																						
6																																																						
7																																																						
8																																																						
9																																																						
A																																																						
B																																																						
C	Collision detection method 1 Set the collision detection level during cutting feed (G1). The G1 collision detection level=SV060*clG1.																																																					
D																																																						
E																																																						
F	clG1	When clG1=0, the collision detection method 1 during cutting feed won't function.																																																				
F	cl2n	Collision detection method 2 valid	Collision detection method 2 invalid																																																			
		(Note) Set to "0" for bits with no particular description.																																																				

7. Servo Parameters
7.1 MDS-B-SVJ2

No.	Items	Details	Setting range																																
2236 (PR)	SV036 PTYP Regenerative resistor type	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 12.5%; text-align: center;">F</td> <td style="width: 12.5%; text-align: center;">E</td> <td style="width: 12.5%; text-align: center;">D</td> <td style="width: 12.5%; text-align: center;">C</td> <td style="width: 12.5%; text-align: center;">B</td> <td style="width: 12.5%; text-align: center;">A</td> <td style="width: 12.5%; text-align: center;">9</td> <td style="width: 12.5%; text-align: center;">8</td> </tr> <tr> <td colspan="4" style="border: 1px solid black; text-align: center;">amp</td> <td colspan="4" style="border: 1px solid black; text-align: center;">rtyp</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td colspan="4" style="border: 1px solid black; text-align: center;">emgx</td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> </tr> </table>	F	E	D	C	B	A	9	8	amp				rtyp				7	6	5	4	3	2	1	0	emgx								
		F	E	D	C	B	A	9	8																										
		amp				rtyp																													
		7	6	5	4	3	2	1	0																										
		emgx																																	
		bit	Explanation																																
		0	Always set to "0(0000)".																																
		1																																	
		2																																	
		3																																	
4	Set the external emergency stop function. (Setting is prohibited for values with no description.) <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th style="width: 10%;">Set-ting</th> <th style="width: 90%;">Explanation</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>External emergency stop invalid</td> </tr> <tr> <td style="text-align: center;">4</td> <td>External emergency stop valid</td> </tr> </tbody> </table>	Set-ting	Explanation	0	External emergency stop invalid	4	External emergency stop valid																												
Set-ting		Explanation																																	
0		External emergency stop invalid																																	
4		External emergency stop valid																																	
5		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">Set-ting</th> <th style="width: 90%;">Explanation</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Drive unit standard built-in resistor (SVJ2-01 doesn't have a built-in resistor)</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Setting prohibited</td> </tr> <tr> <td style="text-align: center;">2</td> <td>MR-RB032</td> </tr> <tr> <td style="text-align: center;">3</td> <td>MR-RB12 or GZG200W390HMK</td> </tr> <tr> <td style="text-align: center;">4</td> <td>MR-RB32 or GZG200W1200HMK: 3 units connected in parallel</td> </tr> <tr> <td style="text-align: center;">5</td> <td>MR-RB30 or GZG200W390HMK: 3 units connected in parallel</td> </tr> <tr> <td style="text-align: center;">6</td> <td>MR-RB50 or GZG300W390HMK: 3 units connected in parallel</td> </tr> <tr> <td style="text-align: center;">7 to F</td> <td>Setting prohibited</td> </tr> </tbody> </table>	Set-ting	Explanation	0	Drive unit standard built-in resistor (SVJ2-01 doesn't have a built-in resistor)	1	Setting prohibited	2	MR-RB032	3	MR-RB12 or GZG200W390HMK	4	MR-RB32 or GZG200W1200HMK: 3 units connected in parallel	5	MR-RB30 or GZG200W390HMK: 3 units connected in parallel	6	MR-RB50 or GZG300W390HMK: 3 units connected in parallel	7 to F	Setting prohibited															
Set-ting	Explanation																																		
0	Drive unit standard built-in resistor (SVJ2-01 doesn't have a built-in resistor)																																		
1	Setting prohibited																																		
2	MR-RB032																																		
3	MR-RB12 or GZG200W390HMK																																		
4	MR-RB32 or GZG200W1200HMK: 3 units connected in parallel																																		
5	MR-RB30 or GZG200W390HMK: 3 units connected in parallel																																		
6	MR-RB50 or GZG300W390HMK: 3 units connected in parallel																																		
7 to F	Setting prohibited																																		
6																																			
7																																			
8	Set the regenerative resistor type. <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th style="width: 10%;">Set-ting</th> <th style="width: 90%;">Explanation</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Drive unit standard built-in resistor (SVJ2-01 doesn't have a built-in resistor)</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Setting prohibited</td> </tr> <tr> <td style="text-align: center;">2</td> <td>MR-RB032</td> </tr> <tr> <td style="text-align: center;">3</td> <td>MR-RB12 or GZG200W390HMK</td> </tr> <tr> <td style="text-align: center;">4</td> <td>MR-RB32 or GZG200W1200HMK: 3 units connected in parallel</td> </tr> <tr> <td style="text-align: center;">5</td> <td>MR-RB30 or GZG200W390HMK: 3 units connected in parallel</td> </tr> <tr> <td style="text-align: center;">6</td> <td>MR-RB50 or GZG300W390HMK: 3 units connected in parallel</td> </tr> <tr> <td style="text-align: center;">7 to F</td> <td>Setting prohibited</td> </tr> </tbody> </table>	Set-ting	Explanation	0	Drive unit standard built-in resistor (SVJ2-01 doesn't have a built-in resistor)	1	Setting prohibited	2	MR-RB032	3	MR-RB12 or GZG200W390HMK	4	MR-RB32 or GZG200W1200HMK: 3 units connected in parallel	5	MR-RB30 or GZG200W390HMK: 3 units connected in parallel	6	MR-RB50 or GZG300W390HMK: 3 units connected in parallel	7 to F	Setting prohibited																
Set-ting		Explanation																																	
0		Drive unit standard built-in resistor (SVJ2-01 doesn't have a built-in resistor)																																	
1		Setting prohibited																																	
2		MR-RB032																																	
3	MR-RB12 or GZG200W390HMK																																		
4	MR-RB32 or GZG200W1200HMK: 3 units connected in parallel																																		
5	MR-RB30 or GZG200W390HMK: 3 units connected in parallel																																		
6	MR-RB50 or GZG300W390HMK: 3 units connected in parallel																																		
7 to F	Setting prohibited																																		
9																																			
A																																			
B																																			
C	Always set to "0(0000)". <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th style="width: 10%;">Set-ting</th> <th style="width: 90%;">Explanation</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Drive unit standard built-in resistor (SVJ2-01 doesn't have a built-in resistor)</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Setting prohibited</td> </tr> <tr> <td style="text-align: center;">2</td> <td>MR-RB032</td> </tr> <tr> <td style="text-align: center;">3</td> <td>MR-RB12 or GZG200W390HMK</td> </tr> <tr> <td style="text-align: center;">4</td> <td>MR-RB32 or GZG200W1200HMK: 3 units connected in parallel</td> </tr> <tr> <td style="text-align: center;">5</td> <td>MR-RB30 or GZG200W390HMK: 3 units connected in parallel</td> </tr> <tr> <td style="text-align: center;">6</td> <td>MR-RB50 or GZG300W390HMK: 3 units connected in parallel</td> </tr> <tr> <td style="text-align: center;">7 to F</td> <td>Setting prohibited</td> </tr> </tbody> </table>	Set-ting	Explanation	0	Drive unit standard built-in resistor (SVJ2-01 doesn't have a built-in resistor)	1	Setting prohibited	2	MR-RB032	3	MR-RB12 or GZG200W390HMK	4	MR-RB32 or GZG200W1200HMK: 3 units connected in parallel	5	MR-RB30 or GZG200W390HMK: 3 units connected in parallel	6	MR-RB50 or GZG300W390HMK: 3 units connected in parallel	7 to F	Setting prohibited																
Set-ting		Explanation																																	
0		Drive unit standard built-in resistor (SVJ2-01 doesn't have a built-in resistor)																																	
1		Setting prohibited																																	
2	MR-RB032																																		
3	MR-RB12 or GZG200W390HMK																																		
4	MR-RB32 or GZG200W1200HMK: 3 units connected in parallel																																		
5	MR-RB30 or GZG200W390HMK: 3 units connected in parallel																																		
6	MR-RB50 or GZG300W390HMK: 3 units connected in parallel																																		
7 to F	Setting prohibited																																		
D																																			
E																																			
F																																			

7. Servo Parameters
7.1 MDS-B-SVJ2

No.	Items	Details	Setting range
2237	SV037 JL	Load inertia scale $SV037 (JL) = \frac{Jl+Jm}{Jm} *100$ Jm: Motor inertia Jl: Motor axis conversion load inertia	0 to 5000 (%)
2238	SV038 FHz1	Notch filter frequency 1 Set the vibration frequency to suppress if machine vibration occurs. (Valid at 72 or more) When not using, set to "0".	0 to 3000 (Hz)
2239	SV039 LMCD	Lost motion compensation timing Set this when the lost motion compensation timing does not match. Adjust by increasing the value by 10 at a time.	0 to 2000 (ms)
2240	SV040 LMCT	Non-sensitive band in feed forward control Set the non-sensitive band of the lost motion compensation and overshooting compensation during the feed forward control. When "0" is set, the actual value that will be set is 2μm. Adjust by increasing by 1μm.	0 to 100 (μm)
2241	SV041 LMC2	Lost motion compensation 2 Set this with SV016 (LMC1) only when you wish to set the lost motion compensation amount to be different depending on the command directions. Set to "0" as a standard.	-1 to 200 (Stall [rated] current %)
2242	SV042 OVS2	Overshooting compensation 2 Set this with SV031 (OVS1) only when you wish to set the overshooting compensation amount to be different depending on the command directions. Set to "0" as a standard.	-1 to 100 (Stall [rated] current %)
2243	SV043 OBS1	Disturbance observer filter frequency Set the disturbance observer filter band. The standard setting is "300". Lower the setting by 50 at a time if vibration occurs. To use the disturbance observer, also set SV037 (JL) and SV044 (OBS2). When not using, set to "0".	0 to 1000 (rad/s)
2244	SV044 OBS2	Disturbance observer gain Set the disturbance observer gain. The standard setting is "100" to "300". To use the disturbance observer, also set SV037 (JL) and SV043 (OBS1). When not using, set to "0".	0 to 1000 (%)
2245	SV045 TRUB	Frictional torque Set the frictional torque when using the collision detection function.	0 to 100 (Stall [rated] current %)
2246	SV046	Not used. Set to "0".	0
2247	SV047 EC	Inductive voltage compensation gain Set the inductive voltage compensation gain. Set to "100" as a standard. If the current FB peak exceeds the current command peak, lower the gain.	0 to 200 (%)
2248	SV048 EMGrT	Vertical axis drop prevention time Input a length of time to prevent the vertical axis from dropping by delaying Ready OFF until the brake works when the emergency stop occurs. Increase the setting by 100ms at a time and set the value where the axis does not drop.	0 to 2000 (ms)

7. Servo Parameters
7.1 MDS-B-SVJ2

No.	Items	Details	Setting range	
2249	SV049 PGN1sp	Position loop gain 1 in spindle synchronous control	Set the position loop gain during the spindle synchronous control (synchronous tapping, synchronous control with spindle/C axis). Set the same value as the value of the spindle parameter, position loop gain in synchronous control. When performing the SHG control, set this with SV050 (PGN2sp) and SV058 (SHGCsp).	1 to 200 (rad/s)
2250	PGN2sp	Position loop gain 2 in spindle synchronous control	Set this with SV049 (PGN1sp) and SV058 (SHGCsp) if you wish to perform the SHG control in the spindle synchronous control (synchronous tapping, synchronous control with spindle/C axis). When not performing the SHG control, set to "0".	0 to 999 (rad/s)
2251	SV051		Not used. Set to "0".	0
2252	SV052		Not used. Set to "0".	0
2253	SV053 OD3	Excessive error detection width in special control	Set the excessive error detection width when servo ON in a special control (initial absolute position setting, stopper control, etc.). If "0" is set, excessive error detection won't be performed when servo ON during a special control.	0 to 32767 (mm)
2254	SV054		Not used. Set to "0".	0
2255	SV055		Not used. Set to "0".	0
2256	SV056 EMGt	Deceleration time constant at emergency stop	Set the time constant used for the deceleration control at emergency stop. Set a length of time that takes from rapid traverse rate (rapid) to stopping. Normally, set the same value as the rapid traverse acceleration/deceleration time constant.	0 to 5000 (ms)
2257	SV057 SHGC	SHG control gain	When performing the SHG control, set this with S003 (PGN1) and SV004 (PGN2). When not performing the SHG control, set to "0".	0 to 999 (rad/s)
2258	SV058 SHGCsp	SHG control gain in spindle synchronous control	Set this with SV049 (PGN1sp) and SV050 (PGN2sp) if you wish to perform the SHG control in the spindle synchronous control (synchronous tapping, synchronous control with spindle/C axis). When not performing the SHG control, set to "0".	0 to 999 (rad/s)
2259	SV059 TCNV	Collision detection torque estimating gain	To use the collision detection function, set the torque estimating gain. In the case of MDS-B-SVJ2, the value is the same as the load inertia ratio that includes the motor inertia. (=SV037:JL) If acceleration/deceleration is performed after setting SV034.mon=3 and SV060=0, the load inertia ratio will be displayed on the NC monitor screen.	0 to 5000 (%)
2260	SV060 TLMT	Collision detection level	When using the collision detection function, set the collision detection level during the G0 feeding. If "0" is set, none of the collision detection function will work.	0 to 200 (Stall [rated] current %)

7. Servo Parameters
7.1 MDS-B-SVJ2

No.	Items		Details	Setting range
2261	SV061 DA1NO	D/A output channel 1 data No.	Input the data number you wish to output to D/A output channel.	0 to 102
2262	SV062 DA2NO	D/A output channel 2 data No.		
2263	SV063 DA1MPY	D/A output channel 1 output scale	When "0" is set, output is done with the standard output unit. Set other than "0" when you wish to change the unit. Set the scale with a 1/256 unit. When "256" is set, the output unit will be the same as the standard output unit.	-32768 to 32767 (Unit: 1/256)
2264	SV064 DA2MPY	D/A output channel 2 output scale		
2265	SV065		Not used. Set to "0".	0

7. Servo Parameters
7.1 MDS-B-SVJ2

(2) Initial setting value

(a) HC**/HC**R series

Motor		HC 52	HC 102*	HC 102	HC 152*	HC 152	HC 202*	HC 202	HC 352*
Drive unit capacity		06	07	10	10	20	10	20	20
SV001	PC1	-	-	-	-	-	-	-	-
SV002	PC2	-	-	-	-	-	-	-	-
SV003	PGN1	33	33	33	33	33	33	33	33
SV004	PGN2	0	0	0	0	0	0	0	0
SV005	VGN1	50	80	50	80	50	115	80	130
SV006		0	0	0	0	0	0	0	0
SV007		0	0	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364	1364	1364
SV009	IQA	8192	4096	8192	4096	8192	2048	4096	2048
SV010	IDA	8192	4096	8192	4096	8192	2048	4096	2048
SV011	IQG	512	256	384	256	384	256	384	256
SV012	IDG	512	256	384	256	384	256	384	256
SV013	ILMT	500	500	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000	0000	0000	0000
SV018	PIT	-	-	-	-	-	-	-	-
SV019	RNG1	-	-	-	-	-	-	-	-
SV020	RNG2	-	-	-	-	-	-	-	-
SV021	OLT	60	60	60	60	60	60	60	60
SV022	OLL	150	150	150	150	150	150	150	150
SV023	OD1	-	-	-	-	-	-	-	-
SV024	INP	50	50	50	50	50	50	50	50
SV025	MTYP	22B0	22B1	22B1	22B2	22B2	22B3	22B3	22B4
SV026	OD2	-	-	-	-	-	-	-	-
SV027	SSF1	4000	4000	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0	0	0
SV029		0	0	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0	0	0

7. Servo Parameters
7.1 MDS-B-SVJ2

Motor		HC 52	HC 102*	HC 102	HC 152*	HC 152	HC 202*	HC 202	HC 352*
Drive unit capacity		06	07	10	10	20	10	20	20
SV033	SSF2	0	0	0	0	0	0	0	0
SV034	SSF3	0	0	0	0	0	0	0	0
SV035	SSF4	0	0	0	0	0	0	0	0
SV036	PTYP	-	-	-	-	-	-	-	-
SV037	JL	0	0	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0	0	0
SV039	LMCD	0	0	0	0	0	0	0	0
SV040	LMCT	0	0	0	0	0	0	0	0
SV041	LMC2	0	0	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0	0	0
SV045	TRUB	0	0	0	0	0	0	0	0
SV046		0	0	0	0	0	0	0	0
SV047	EC	100	100	100	100	100	100	100	100
SV048	EMGrt	0	0	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0	0	0	0
SV051		0	0	0	0	0	0	0	0
SV052		0	0	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0	0	0
SV054		0	0	0	0	0	0	0	0
SV055		0	0	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0	0	0
SV059	TCNV	0	0	0	0	0	0	0	0
SV060	TLMT	0	0	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0	0	0
SV065		0	0	0	0	0	0	0	0

7. Servo Parameters
7.1 MDS-B-SVJ2

Motor		HC 53	HC 103	HC 153	HC 203*	HC 103R	HC 153R	HC 203R
Drive unit capacity		06	10	20	20	10	10	20
SV001	PC1	-	-	-	-	-	-	-
SV002	PC2	-	-	-	-	-	-	-
SV003	PGN1	33	33	33	33	33	33	33
SV004	PGN2	0	0	0	0	0	0	0
SV005	VGN1	80	80	80	100	10	10	10
SV006		0	0	0	0	0	0	0
SV007		0	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364	1364
SV009	IQA	4096	4096	4096	2048	8192	8192	8192
SV010	IDA	4096	4096	4096	2048	8192	8192	8192
SV011	IQG	256	256	256	200	384	384	256
SV012	IDG	256	256	256	200	384	384	256
SV013	ILMT	500	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000	0000	0000
SV018	PIT	-	-	-	-	-	-	-
SV019	RNG1	-	-	-	-	-	-	-
SV020	RNG2	-	-	-	-	-	-	-
SV021	OLT	60	60	60	60	60	60	60
SV022	OLL	150	150	150	150	150	150	150
SV023	OD1	-	-	-	-	-	-	-
SV024	INP	50	50	50	50	50	50	50
SV025	MTYP	22C0	22C1	22C2	22C3	22E1	22E2	22E3
SV026	OD2	-	-	-	-	-	-	-
SV027	SSF1	4000	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0	0
SV029		0	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0	0

7. Servo Parameters
7.1 MDS-B-SVJ2

Motor		HC 53	HC 103	HC 153	HC 203*	HC 103R	HC 153R	HC 203R
Drive unit capacity		06	10	20	20	10	10	20
SV033	SSF2	0	0	0	0	0	0	0
SV034	SSF3	0	0	0	0	0	0	0
SV035	SSF4	0	0	0	0	0	0	0
SV036	PTYP	-	-	-	-	-	-	-
SV037	JL	0	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0	0
SV039	LMCD	0	0	0	0	0	0	0
SV040	LMCT	0	0	0	0	0	0	0
SV041	LMC2	0	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0	0
SV045	TRUB	0	0	0	0	0	0	0
SV046		0	0	0	0	0	0	0
SV047	EC	100	100	100	100	100	100	100
SV048	EMGr	0	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0	0	0
SV051		0	0	0	0	0	0	0
SV052		0	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0	0
SV054		0	0	0	0	0	0	0
SV055		0	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0	0
SV059	TCNV	0	0	0	0	0	0	0
SV060	TLMT	0	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0	0
SV065		0	0	0	0	0	0	0

7. Servo Parameters
7.1 MDS-B-SVJ2

(b) HA**N series

Motor		HA 40N	HA 80N	HA 100N	HA 200N*	HA 053N	HA 13N	HA 23N	HA 33N	HA 43N	HA 83N	HA 103N*
Drive unit capacity		06	10	20	20	01	01	03	03	06	10	20
SV001	PC1	-	-	-	-	-	-	-	-	-	-	-
SV002	PC2	-	-	-	-	-	-	-	-	-	-	-
SV003	PGN1	33	33	33	33	33	33	33	33	33	33	33
SV004	PGN2	0	0	0	0	0	0	0	0	0	0	0
SV005	VGN1	90	150	150	220	35	35	35	35	120	150	180
SV006		0	0	0	0	0	0	0	0	0	0	0
SV007		0	0	0	0	0	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364	1364	1364	1364	1364	1364
SV009	IQA	2048	2048	2048	2048	2048	2048	2048	2048	2048	2048	2048
SV010	IDA	2048	2048	2048	2048	2048	2048	2048	2048	2048	2048	2048
SV011	IQG	512	512	512	200	256	256	256	256	512	512	512
SV012	IDG	512	512	512	200	256	256	256	256	512	512	512
SV013	ILMT	500	500	500	500	500	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV018	PIT	-	-	-	-	-	-	-	-	-	-	-
SV019	RNG1	-	-	-	-	-	-	-	-	-	-	-
SV020	RNG2	-	-	-	-	-	-	-	-	-	-	-
SV021	OLT	60	60	60	60	60	60	60	60	60	60	60
SV022	OLL	150	150	150	150	150	150	150	150	150	150	150
SV023	OD1	-	-	-	-	-	-	-	-	-	-	-
SV024	INP	50	50	50	50	50	50	50	50	50	50	50
SV025	MTYP	2200	2201	2202	2203	228C	228D	228E	228F	2280	2281	2282
SV026	OD2	-	-	-	-	-	-	-	-	-	-	-
SV027	SSF1	4000	4000	4000	4000	4000	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0	0	0	0	0	0
SV029		0	0	0	0	0	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0	0	0	0	0	0

7. Servo Parameters
7.1 MDS-B-SVJ2

Motor		HA 40N	HA 80N	HA 100N	HA 200N*	HA 053N	HA 13N	HA 23N	HA 33N	HA 43N	HA 83N	HA 103N*
Drive unit capacity		06	10	20	20	01	01	03	03	06	10	20
SV033	SSF2	0	0	0	0	0	0	0	0	0	0	0
SV034	SSF3	0	0	0	0	0	0	0	0	0	0	0
SV035	SSF4	0	0	0	0	0	0	0	0	0	0	0
SV036	PTYF	-	-	-	-	-	-	-	-	-	-	-
SV037	JL	0	0	0	0	0	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0	0	0	0	0	0
SV039	LMCD	0	0	0	0	0	0	0	0	0	0	0
SV040	LMCT	0	0	0	0	0	0	0	0	0	0	0
SV041	LMC2	0	0	0	0	0	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0	0	0	0	0	0
SV045	TRUB	0	0	0	0	0	0	0	0	0	0	0
SV046		0	0	0	0	0	0	0	0	0	0	0
SV047	EC	100	100	100	100	100	100	100	100	100	100	100
SV048	EMGrt	0	0	0	0	0	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0	0	0	0	0	0	0
SV051		0	0	0	0	0	0	0	0	0	0	0
SV052		0	0	0	0	0	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0	0	0	0	0	0
SV054		0	0	0	0	0	0	0	0	0	0	0
SV055		0	0	0	0	0	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0	0	0	0	0	0
SV059	TCNV	0	0	0	0	0	0	0	0	0	0	0
SV060	TLMT	0	0	0	0	0	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0	0	0	0	0	0
SV065		0	0	0	0	0	0	0	0	0	0	0

7. Servo Parameters
7.1 MDS-B-SVJ2

(c) HC-SF series

Motor		HC-SF 52	HC-SF 102	HC-SF 152	HC-SF 202	HC-SF 352	HC-SF 53	HC-SF 103	HC-SF 153	HC-SF 203	HC-SF 353
Drive unit capacity		06	07	10	10	20	06	07	10	10	20
SV001	PC1	-	-	-	-	-	-	-	-	-	-
SV002	PC2	-	-	-	-	-	-	-	-	-	-
SV003	PGN1	33	33	33	33	33	33	33	33	33	33
SV004	PGN2	0	0	0	0	0	0	0	0	0	0
SV005	VGN1	80	80	80	120	130	90	90	130	180	180
SV006		0	0	0	0	0	0	0	0	0	0
SV007		0	0	0	0	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364	1364	1364	1364	1364
SV009	IQA	8192	4096	4096	2048	2048	4096	4096	2048	2048	2048
SV010	IDA	8192	4096	4096	2048	2048	4096	4096	2048	2048	2048
SV011	IQG	500	300	300	300	250	250	250	200	200	200
SV012	IDG	500	300	300	300	250	250	250	200	200	200
SV013	ILMT	500	500	500	500	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV018	PIT	-	-	-	-	-	-	-	-	-	-
SV019	RNG1	16	16	16	16	16	16	16	16	16	16
SV020	RNG2	16	16	16	16	16	16	16	16	16	16
SV021	OLT	60	60	60	60	60	60	60	60	60	60
SV022	OLL	150	150	150	150	150	150	150	150	150	150
SV023	OD1	-	-	-	-	-	-	-	-	-	-
SV024	INP	50	50	50	50	50	50	50	50	50	50
SV025	MTYP	22B0	22B1	22B2	22B3	22B4	22C0	22C1	22C2	22C3	22C4
SV026	OD2	-	-	-	-	-	-	-	-	-	-
SV027	SSF1	4000	4000	4000	4000	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0	0	0	0	0
SV029		0	0	0	0	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0	0	0	0	0

7. Servo Parameters
7.1 MDS-B-SVJ2

Motor		HC-SF 52	HC-SF 102	HC-SF 152	HC-SF 202	HC-SF 352	HC-SF 53	HC-SF 103	HC-SF 153	HC-SF 203	HC-SF 353
Drive unit capacity		06	07	10	10	20	06	07	10	10	20
SV033	SSF2	0	0	0	0	0	0	0	0	0	0
SV034	SSF3	0	0	0	0	0	0	0	0	0	0
SV035	SSF4	0	0	0	0	0	0	0	0	0	0
SV036	PTYF	-	-	-	-	-	-	-	-	-	-
SV037	JL	0	0	0	0	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0	0	0	0	0
SV039	LMCD	0	0	0	0	0	0	0	0	0	0
SV040	LMCT	0	0	0	0	0	0	0	0	0	0
SV041	LMC2	0	0	0	0	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0	0	0	0	0
SV045	TRUB	0	0	0	0	0	0	0	0	0	0
SV046		0	0	0	0	0	0	0	0	0	0
SV047	EC	100	100	100	100	100	100	100	100	100	100
SV048	EMGrt	0	0	0	0	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0	0	0	0	0	0
SV051		0	0	0	0	0	0	0	0	0	0
SV052		0	0	0	0	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0	0	0	0	0
SV054		0	0	0	0	0	0	0	0	0	0
SV055		0	0	0	0	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0	0	0	0	0
SV059	TCNV	0	0	0	0	0	0	0	0	0	0
SV060	TLMT	0	0	0	0	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0	0	0	0	0
SV065		0	0	0	0	0	0	0	0	0	0

7. Servo Parameters
7.1 MDS-B-SVJ2

(d) HC-RF/HA-FF series

Motor		HC-RF 103	HC-RF 153	HC-RF 203	HA-FF 053	HA-FF 13	HA-FF 23	HA-FF 33	HA-FF 43	HA-FF 63
Drive unit capacity		10	10	20	01	01	03	03	04	06
SV001	PC1	-	-	-	-	-	-	-	-	-
SV002	PC2	-	-	-	-	-	-	-	-	-
SV003	PGN1	33	33	33	33	33	33	33	33	33
SV004	PGN2	0	0	0	0	0	0	0	0	0
SV005	VGN1	10	10	10	10	13	13	18	20	20
SV006		0	0	0	0	0	0	0	0	0
SV007		0	0	0	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364	1364	1364	1364
SV009	IQA	8192	8192	8192	8192	4096	4096	4096	4096	4096
SV010	IDA	8192	8192	8192	8192	4096	4096	4096	4096	4096
SV011	IQG	384	384	256	500	300	700	500	700	700
SV012	IDG	384	384	256	500	300	700	500	700	700
SV013	ILMT	500	500	500	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV018	PIT	-	-	-	-	-	-	-	-	-
SV019	RNG1	16	16	16	8	8	8	8	8	8
SV020	RNG2	16	16	16	8	8	8	8	8	8
SV021	OLT	60	60	60	60	60	60	60	60	60
SV022	OLL	150	150	150	150	150	150	150	150	150
SV023	OD1	-	-	-	-	-	-	-	-	-
SV024	INP	50	50	50	50	50	50	50	50	50
SV025	MTYP	22E1	22E2	22E3	227C	227D	227E	227F	2270	2271
SV026	OD2	-	-	-	-	-	-	-	-	-
SV027	SSF1	4000	4000	4000	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0	0	0	0
SV029		0	0	0	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0	0	0	0

7. Servo Parameters
7.1 MDS-B-SVJ2

Motor		HC-RF 103	HC-RF 153	HC-RF 203	HA-FF 053	HA-FF 13	HA-FF 23	HA-FF 33	HA-FF 43	HA-FF 63
Drive unit capacity		10	10	20	01	01	03	03	04	06
SV033	SSF2	0	0	0	0	0	0	0	0	0
SV034	SSF3	0	0	0	0	0	0	0	0	0
SV035	SSF4	0	0	0	0	0	0	0	0	0
SV036	PTYF	-	-	-	-	-	-	-	-	-
SV037	JL	0	0	0	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0	0	0	0
SV039	LMCD	0	0	0	0	0	0	0	0	0
SV040	LMCT	0	0	0	0	0	0	0	0	0
SV041	LMC2	0	0	0	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0	0	0	0
SV045	TRUB	0	0	0	0	0	0	0	0	0
SV046		0	0	0	0	0	0	0	0	0
SV047	EC	100	100	100	100	100	100	100	100	100
SV048	EMGrt	0	0	0	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0	0	0	0	0
SV051		0	0	0	0	0	0	0	0	0
SV052		0	0	0	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0	0	0	0
SV054		0	0	0	0	0	0	0	0	0
SV055		0	0	0	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0	0	0	0
SV059	TCNV	0	0	0	0	0	0	0	0	0
SV060	TLMT	0	0	0	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0	0	0	0
SV065		0	0	0	0	0	0	0	0	0

7. Servo Parameters
7.1 MDS-B-SVJ2

(e) HC-MF series

Motor		HC-MF 053	HC-MF 13	HC-MF 23	HC-MF 43	HC-MF 73
Drive unit capacity		01	01	03	04	07
SV001	PC1	-	-	-	-	-
SV002	PC2	-	-	-	-	-
SV003	PGN1	33	33	33	33	33
SV004	PGN2	0	0	0	0	0
SV005	VGN1	6	6	6	6	8
SV006		0	0	0	0	0
SV007		0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364
SV009	IQA	4096	4096	4096	4096	4096
SV010	IDA	4096	4096	4096	4096	4096
SV011	IQG	200	300	400	300	300
SV012	IDG	200	300	400	300	300
SV013	ILMT	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500
SV015	FFC	0	0	0	0	0
SV016	LMC1	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000
SV018	PIT	-	-	-	-	-
SV019	RNG1	8	8	8	8	8
SV020	RNG2	8	8	8	8	8
SV021	OLT	60	60	60	60	60
SV022	OLL	150	150	150	150	150
SV023	OD1	-	-	-	-	-
SV024	INP	50	50	50	50	50
SV025	MTYP	229C	229D	229E	2290	2291
SV026	OD2	-	-	-	-	-
SV027	SSF1	4000	4000	4000	4000	4000
SV028		0	0	0	0	0
SV029		0	0	0	0	0
SV030	IVC	0	0	0	0	0
SV031	OVS1	0	0	0	0	0
SV032	TOF	0	0	0	0	0

7. Servo Parameters
7.1 MDS-B-SVJ2

Motor		HC-MF 053	HC-MF 13	HC-MF 23	HC-MF 43	HC-MF 73
Drive unit capacity		01	01	03	04	07
SV033	SSF2	0	0	0	0	0
SV034	SSF3	0	0	0	0	0
SV035	SSF4	0	0	0	0	0
SV036	PTYP	-	-	-	-	-
SV037	JL	0	0	0	0	0
SV038	FHz1	0	0	0	0	0
SV039	LMCD	0	0	0	0	0
SV040	LMCT	0	0	0	0	0
SV041	LMC2	0	0	0	0	0
SV042	OVS2	0	0	0	0	0
SV043	OBS1	0	0	0	0	0
SV044	OBS2	0	0	0	0	0
SV045	TRUB	0	0	0	0	0
SV046		0	0	0	0	0
SV047	EC	100	100	100	100	100
SV048	EMGr	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0
SV051		0	0	0	0	0
SV052		0	0	0	0	0
SV053	OD3	0	0	0	0	0
SV054		0	0	0	0	0
SV055		0	0	0	0	0
SV056	EMGt	0	0	0	0	0
SV057	SHGC	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0
SV059	TCNV	0	0	0	0	0
SV060	TLMT	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0
SV065		0	0	0	0	0

7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

(1) Details for servo parameters

For parameters marked with a (PR) in the table, turn the NC power OFF after setting. After the power is turned ON again, the parameter is validated.

! CAUTION

! In the explanation on bits, set all bits not used, including blank bits, to "0".

No.	Items	Details	Setting range
2201 (PR)	SV001 PC1	Motor side gear ratio	1 to 32767
2202 (PR)	SV002 PC2	Machine side gear ratio	1 to 32767
2203	SV003 PGN1	Position loop gain 1	1 to 200 (In case of MDS-B-Vx4, 1 to 400) (rad/s)
2204	SV004 PGN2	Position loop gain 2	0 to 999 (rad/s)
2205	SV005 VGN1	Speed loop gain 1	1 to 999
2206	SV006 VGN2	Speed loop gain 2	-1000 to 1000

(Rated speed*1.2)

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range	
2207	SV007 VIL	Speed loop delay compensation	Set this when the limit cycle occurs in the full-closed loop, or overshooting occurs in positioning. Select the control method with SV027 (SSF1)/bit1, 0 (vcnt). Normally, use "Changeover type 2". When you set this parameter, make sure to set the torque offset (SV032 (TOF)). When not using, set to "0".	0 to 32767
		No changeover When SV027 (SSF1)/ bit1, 0 (vcnt)=00 The delay compensation control is always valid.		
		Changeover type 1 When SV027 (SSF1)/ bit1, 0 (vcnt)=01 The delay compensation control works when the command from the NC is "0". Overshooting that occurs during pulse feeding can be suppressed.		
		Changeover type 2 When SV027 (SSF1)/ bit1, 0 (vcnt)=10 The delay compensation control works when the command from the NC is "0" and the position droop is "0". Overshooting or the limit cycle that occurs during pulse feeding or positioning can be suppressed.		
2208	SV008 VIA	Speed loop lead compensation	Set the gain of the speed loop integration control. The standard setting is "1364". During the SHG control, the standard setting is "1900". Adjust the value by increasing/decreasing it by about 100 at a time. Raise this value to improve contour tracking precision in high-speed cutting. Lower this value when the position droop vibrates (10 to 20Hz).	1 to 9999
2209	SV009 IQA	Current loop q axis lead compensation	Set the gain of current loop. As this setting is determined by the motor's electrical characteristics, the setting is fixed for each type of motor.	1 to 20480 1 to 4096 (In case of MDS-B-Vx4, 1 to 8192)
2210	SV010 IDA	Current loop d axis lead compensation	Set the standard values for all the parameters depending on each motor type.	
2211	SV011 IQG	Current loop q axis gain		
2212	SV012 IDG	Current loop d axis gain		
2213	SV013 ILMT	Current limit value	Set the normal current (torque) limit value. (Limit values for both + and - direction.) When the value is "500" (a standard setting), the maximum torque is determined by the specification of the motor.	0 to 999 (Stall [rated] current %)
2214	SV014 ILMTsp	Current limit value in special control	Set the current (torque) limit value in a special control (initial absolute position setting, stopper control, etc). (Limit values for both of the + and - directions.) Set to "500" when not using.	0 to 999 (Stall [rated] current %)

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range
2215	SV015 FFC	<p>Acceleration rate feed forward gain</p> <p>When a relative error in the synchronous control is large, apply this parameter to the axis that is delaying. The standard setting value is "0". For the SHG control, set to "100".</p> <p>To adjust a relative error in acceleration/deceleration, increase the value by 50 to 100 at a time.</p>	0 to 999(%)
2216	SV016 LMC1	<p>Lost motion compensation 1</p> <p>Set this when the protrusion (that occurs due to the non-sensitive band by friction, torsion, backlash, etc) at quadrant change is too large. This compensates the torque at quadrant change. This is valid only when the lost motion compensation (SV027 (SSF1/lmc)) is selected.</p>	
		<p>Type 1: When SV027 (SSF1)/ bit9, 8 (lmc)=01</p> <p>Set the compensation amount based on the motor torque before the quadrant change. The standard setting is "100". Setting to "0" means the compensation amount is zero. Normally, use Type 2.</p>	-1 to 200 (%)
		<p>Type 2: When SV027 (SSF1)/ bit9, 8 (lmc)=10</p> <p>Set the compensation amount based on the stall (rated) current of the motor. The standard setting is double of the friction torque. Setting to "0" means the compensation amount is zero.</p>	-1 to 100 (Stall [rated] current %)
		<p>When you wish different compensation amount depending on the direction</p> <p>When SV041 (LMC2) is "0", compensate with the value of SV016 (LMC1) in both of the + and -directions. If you wish to change the compensation amount depending on the command direction, set this and SV041 (LMC2). (SV016: + direction, SV041: - direction. However, the directions may be opposite depending on other settings.)</p> <p>When "-1" is set, the compensation won't be performed in the direction of the command.</p>	

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range																																
2217 (PR)	SV017 SPEC	Servo specification selection	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 12.5%; text-align: center;">F</td> <td style="width: 12.5%; text-align: center;">E</td> <td style="width: 12.5%; text-align: center;">D</td> <td style="width: 12.5%; text-align: center;">C</td> <td style="width: 12.5%; text-align: center;">B</td> <td style="width: 12.5%; text-align: center;">A</td> <td style="width: 12.5%; text-align: center;">9</td> <td style="width: 12.5%; text-align: center;">8</td> </tr> <tr> <td colspan="4" style="text-align: center;">spm</td> <td style="text-align: center;">drvall</td> <td style="text-align: center;">drvup</td> <td style="text-align: center;">mpt3</td> <td style="text-align: center;">mp</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="text-align: center;">abs</td> <td></td> <td style="text-align: center;">vdir</td> <td style="text-align: center;">fdir</td> <td style="text-align: center;">vfb</td> <td style="text-align: center;">seqh</td> <td style="text-align: center;">dfbx</td> <td style="text-align: center;">fdir2</td> </tr> </table>	F	E	D	C	B	A	9	8	spm				drvall	drvup	mpt3	mp	7	6	5	4	3	2	1	0	abs		vdir	fdir	vfb	seqh	dfbx	fdir2
			F	E	D	C	B	A	9	8																									
			spm				drvall	drvup	mpt3	mp																									
			7	6	5	4	3	2	1	0																									
			abs		vdir	fdir	vfb	seqh	dfbx	fdir2																									
			bit	Meaning when "0" is set	Meaning when "1" is set																														
			0	fdir2 Speed feedback forward polarity	Speed feedback reverse polarity																														
			1	dfbx Dual feedback control stop	Dual feedback control start																														
			2	seqh READY/Servo ON time normal	READY/Servo ON time high speed																														
			3	vfb Speed feedback filter stop	Speed feedback filter stop (2250Hz)																														
4	fdir Position feedback forward polarity	Position feedback reverse polarity																																	
5	vdir Standard setting	HA motor (4 pole motor) Detector installation position 90 degrees (B, D)																																	
6																																			
7	abs Incremental control	Absolute position control																																	
8	mp MP scale 360P (2mm pitch)	MP scale 720P (1mm pitch)																																	
9	mpt3 MP scale ABS detection type 1, 2	MP scale ABS detection type 3																																	
A	drvup Standard setting	Possible to connect a drive unit whose capacity is 1 rank higher/lower than the standard one.																																	
B	drvall Setting for normal use	Possible to connect a drive unit with any capacity.																																	
C	spm	0 : Setting for normal use																																	
D		1 : When using the S type drive unit (Only in the case of MDS-C1-Vx)																																	
E		2 to F : Setting prohibited																																	
F																																			
(Note 1) Set to "0" for bits with no particular description. (Note 2) bit3 (vfb) is only for MDS-C1-Vx.																																			

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range																																							
2218 (PR)	SV018 PIT	Ball screw pitch	Set the ball screw pitch. Set to "360" for the rotary axis.	1 to 32767 (mm/rev)																																						
2219 (PR)	SV019 RNG1	Position detector resolution	In the case of the semi-closed loop control Set the same value as SV020 (RNG2). (Refer to the explanation of SV020.)	1 to 9999 (kp/rev)																																						
			In the case of the full-closed loop control Set the same value as SV020 (RNG2). (Refer to the explanation of SV020.)	1 to 9999 (kp/pit)																																						
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Detector model name</th> <th style="width: 30%;">Resolution</th> <th style="width: 40%;">SV019 setting</th> </tr> </thead> <tbody> <tr> <td>OHE25K-ET, OHA25K-ET</td> <td>100,000(p/rev)</td> <td>100</td> </tr> <tr> <td>OSE104-ET, OSA104-ET</td> <td>100,000(p/rev)</td> <td>100</td> </tr> <tr> <td>OSE105-ET, OSA105-ET</td> <td>1,000,000(p/rev)</td> <td>1000</td> </tr> <tr> <td>RCN723 (Heidenhain)</td> <td>8,000,000(p/rev)</td> <td>8000</td> </tr> <tr> <td>Relative position detection scale</td> <td>Refer to specification manual for each detector</td> <td>PIT/Resolution (μm)</td> </tr> <tr> <td>AT41 (Mitsutoyo)</td> <td>1 (μm/p)</td> <td>The same as SV018 (PIT)</td> </tr> <tr> <td>FME type, FLE type (Futaba)</td> <td>Refer to specification manual for each detector</td> <td>PIT/Resolution (μm)</td> </tr> <tr> <td>MP type (Mitsubishi Heavy Industries)</td> <td>Refer to specification manual for each detector</td> <td>PIT/Resolution (μm)</td> </tr> <tr> <td>AT342 (Mitsutoyo)</td> <td>0.5 (μm/p)</td> <td>Twice as big as SV018 (PIT)</td> </tr> <tr> <td>AT343 (Mitsutoyo)</td> <td>0.05 (μm/p)</td> <td>20 times as big as SV018 (PIT)</td> </tr> <tr> <td>LC191M (Heidenhain)</td> <td>Refer to specification manual for each detector</td> <td>PIT/Resolution (μm)</td> </tr> <tr> <td>LC491M (Heidenhain)</td> <td>Refer to specification manual for each detector</td> <td>PIT/Resolution (μm)</td> </tr> </tbody> </table>				Detector model name	Resolution	SV019 setting	OHE25K-ET, OHA25K-ET	100,000(p/rev)	100	OSE104-ET, OSA104-ET	100,000(p/rev)	100	OSE105-ET, OSA105-ET	1,000,000(p/rev)	1000	RCN723 (Heidenhain)	8,000,000(p/rev)	8000	Relative position detection scale	Refer to specification manual for each detector	PIT/Resolution (μm)	AT41 (Mitsutoyo)	1 (μm/p)	The same as SV018 (PIT)	FME type, FLE type (Futaba)	Refer to specification manual for each detector	PIT/Resolution (μm)	MP type (Mitsubishi Heavy Industries)	Refer to specification manual for each detector	PIT/Resolution (μm)	AT342 (Mitsutoyo)	0.5 (μm/p)	Twice as big as SV018 (PIT)	AT343 (Mitsutoyo)	0.05 (μm/p)	20 times as big as SV018 (PIT)	LC191M (Heidenhain)	Refer to specification manual for each detector	PIT/Resolution (μm)	LC491M (Heidenhain)	Refer to specification manual for each detector	PIT/Resolution (μm)
Detector model name	Resolution	SV019 setting																																								
OHE25K-ET, OHA25K-ET	100,000(p/rev)	100																																								
OSE104-ET, OSA104-ET	100,000(p/rev)	100																																								
OSE105-ET, OSA105-ET	1,000,000(p/rev)	1000																																								
RCN723 (Heidenhain)	8,000,000(p/rev)	8000																																								
Relative position detection scale	Refer to specification manual for each detector	PIT/Resolution (μm)																																								
AT41 (Mitsutoyo)	1 (μm/p)	The same as SV018 (PIT)																																								
FME type, FLE type (Futaba)	Refer to specification manual for each detector	PIT/Resolution (μm)																																								
MP type (Mitsubishi Heavy Industries)	Refer to specification manual for each detector	PIT/Resolution (μm)																																								
AT342 (Mitsutoyo)	0.5 (μm/p)	Twice as big as SV018 (PIT)																																								
AT343 (Mitsutoyo)	0.05 (μm/p)	20 times as big as SV018 (PIT)																																								
LC191M (Heidenhain)	Refer to specification manual for each detector	PIT/Resolution (μm)																																								
LC491M (Heidenhain)	Refer to specification manual for each detector	PIT/Resolution (μm)																																								
2220 (PR)	SV020 RNG2	Speed detector resolution	Set the number of pulses per one revolution of the motor end detector.	1 to 9999 (kp/rev)																																						
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 60%;">Detector model name</th> <th style="width: 40%;">SV020 setting</th> </tr> </thead> <tbody> <tr> <td>OSE104, OSA104</td> <td>100</td> </tr> <tr> <td>OSE105, OSA105</td> <td>1000</td> </tr> </tbody> </table>				Detector model name	SV020 setting	OSE104, OSA104	100	OSE105, OSA105	1000																																	
Detector model name	SV020 setting																																									
OSE104, OSA104	100																																									
OSE105, OSA105	1000																																									
2221	SV021 OLT	Overload detection time constant	Set the detection time constant of Overload 1 (Alarm 50). Set to "60" as a standard. (For machine tool builder adjustment.)	1 to 999 (s)																																						
2222	SV022 OLL	Overload detection level	Set the current detection level of Overload 1 (Alarm 50) in respect to the stall (rated) current. Set to "150" as a standard. (For machine tool builder adjustment.)	110 to 500 (Stall [rated] current %)																																						

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range
2223	SV023 OD1	<p>Excessive error detection width during servo ON</p> <p>Set the excessive error detection width when servo ON. <Standard setting value></p> $OD1=OD2= \frac{\text{Rapid traverse rate (mm/min)}}{60 \cdot PGN1} / 2 \text{ (mm)}$ <p>When "0" is set, the excessive error detection will not be performed.</p>	0 to 32767 (mm)
2224	SV024 INP	<p>In-position detection width</p> <p>Set the in-position detection width. Set the accuracy required for the machine. The lower the setting is, the higher the positioning accuracy gets, however, the cycle time (setting time) becomes longer. The standard setting is "50".</p>	0 to 32767 (μm)

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range
		(Continued from the previous page)	
		bit	Explanation
		2) When SV017/spm=1 (S type drive unit)	
		Set- ting	8x 9x Ax Bx Cx Dx Ex Fx
		x0	
		x1	
		x2	
		x3	
		x4	HC353
		x5	HC452 HC453
		x6	HC702
		x7	
		x8	
		x9	
		xA	
		xB	
		xC	
		xD	
		xE	
		xF	
8		Set the detector type.	
9		Set the position detector type for "pen", and the speed detector type for "ent". In the case of the semi-closed loop control, set the same value for "pen" and "ent".	
A	ent		
B		pen setting	ent setting Detector model name
C	pen	0	0 OSE104
D		1	1 OSA104
E		2	2 OSE105, OSA105
F		3	3
		4	Setting impossible OHE25K-ET, OSE104-ET
		5	Setting impossible OHA25K-ET, OSA104-ET
		6	Setting impossible OSE105-ET, OSA105-ET, RCN723 (Heidenhain)
		7	Setting impossible
		8	Setting impossible Relative position detection scale, MP type (Mitsubishi Heavy Industries)
		9	Setting impossible AT41 (Mitsutoyo), FME type, FLE type (Futaba)
		A	Setting impossible AT342,AT343 (Mitsutoyo), LC191M/491M (Heidenhain), MDS-B-HR
		B	Setting impossible
		C	C (Current synchronization) The setting of the slave axis in the speed/current synchronization control. When the master axis is the semi-closed control.
		D	E (Current synchronization) The setting of the slave axis in the speed/current synchronization control. When the master axis is the full-closed control. (Current synchronization control is only for MDS-C2-Vx.)
		E	Setting impossible
		F	Setting impossible

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range																																																																	
2226	SV026 OD2	Excessive error detection width during servo OFF	0 to 32767 (mm)																																																																	
2227	SV027 SSF1	Servo function selection 1	<table border="1" style="width: 100%; text-align: center;"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td>aflt</td><td>zrn2</td><td>afse</td><td></td><td>ovs</td><td></td><td>lmc</td><td></td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td>omr</td><td>zrn3</td><td>vfct</td><td></td><td></td><td>upc</td><td></td><td>vcnt</td> </tr> </table> <table border="1" style="width: 100%; text-align: center;"> <thead> <tr> <th>bit</th> <th>Meaning when "0" is set</th> <th>Meaning when "1" is set</th> </tr> </thead> <tbody> <tr> <td>0 1</td> <td colspan="2">vcnt Set the execution changeover type of the speed loop delay compensation. 00: Delay compensation changeover invalid 01: Delay compensation changeover type 1 10: Delay compensation type 2 11: Setting prohibited</td> </tr> <tr> <td>2 3</td> <td>upc Start torque compensation invalid</td> <td>Start torque compensation valid</td> </tr> <tr> <td>4 5</td> <td colspan="2">vfct Set the number of compensation pulses of the jitter compensation. 00: Jitter compensation invalid 01: Jitter compensation 1 pulse 10: Jitter compensation 2 pulses 11: Jitter compensation 3 pulses</td> </tr> <tr> <td>6</td> <td colspan="2">zrn3 ABS scale: Set to "1" in using AT342, AT343, LC191M/491M.</td> </tr> <tr> <td>7</td> <td>omr Machine end compensation invalid</td> <td>Machine end compensation valid</td> </tr> <tr> <td>8 9</td> <td colspan="2">lmc Set the compensation amount with SV016 (LMC1) and SV041 (LMC2). 00: Lost motion compensation stop 01: Lost motion compensation type 1 10: Overshooting compensation type 2 11: Setting prohibited</td> </tr> <tr> <td>A B</td> <td colspan="2">ovs Set the compensation amount with SV031 (OVS1) and SV042 (OVS2). 00: Overshooting compensation stop 01: Overshooting compensation type 1 10: Overshooting compensation type 2 11: Overshooting compensation type 3</td> </tr> <tr> <td>C D</td> <td colspan="2">afse 00: Adoptive filter sensitivity standard 11: Adoptive filter sensitivity increase (Set 2bits at a time)</td> </tr> <tr> <td>E</td> <td colspan="2">zrn2 Set to "1".</td> </tr> <tr> <td>F</td> <td>aflt Adoptive filter stop</td> <td>Adoptive filter start</td> </tr> </tbody> </table> <p>(Note) Set to "0" for bits with no particular description.</p>	F	E	D	C	B	A	9	8	aflt	zrn2	afse		ovs		lmc		7	6	5	4	3	2	1	0	omr	zrn3	vfct			upc		vcnt	bit	Meaning when "0" is set	Meaning when "1" is set	0 1	vcnt Set the execution changeover type of the speed loop delay compensation. 00: Delay compensation changeover invalid 01: Delay compensation changeover type 1 10: Delay compensation type 2 11: Setting prohibited		2 3	upc Start torque compensation invalid	Start torque compensation valid	4 5	vfct Set the number of compensation pulses of the jitter compensation. 00: Jitter compensation invalid 01: Jitter compensation 1 pulse 10: Jitter compensation 2 pulses 11: Jitter compensation 3 pulses		6	zrn3 ABS scale: Set to "1" in using AT342, AT343, LC191M/491M.		7	omr Machine end compensation invalid	Machine end compensation valid	8 9	lmc Set the compensation amount with SV016 (LMC1) and SV041 (LMC2). 00: Lost motion compensation stop 01: Lost motion compensation type 1 10: Overshooting compensation type 2 11: Setting prohibited		A B	ovs Set the compensation amount with SV031 (OVS1) and SV042 (OVS2). 00: Overshooting compensation stop 01: Overshooting compensation type 1 10: Overshooting compensation type 2 11: Overshooting compensation type 3		C D	afse 00: Adoptive filter sensitivity standard 11: Adoptive filter sensitivity increase (Set 2bits at a time)		E	zrn2 Set to "1".		F	aflt Adoptive filter stop	Adoptive filter start
F	E	D	C	B	A	9	8																																																													
aflt	zrn2	afse		ovs		lmc																																																														
7	6	5	4	3	2	1	0																																																													
omr	zrn3	vfct			upc		vcnt																																																													
bit	Meaning when "0" is set	Meaning when "1" is set																																																																		
0 1	vcnt Set the execution changeover type of the speed loop delay compensation. 00: Delay compensation changeover invalid 01: Delay compensation changeover type 1 10: Delay compensation type 2 11: Setting prohibited																																																																			
2 3	upc Start torque compensation invalid	Start torque compensation valid																																																																		
4 5	vfct Set the number of compensation pulses of the jitter compensation. 00: Jitter compensation invalid 01: Jitter compensation 1 pulse 10: Jitter compensation 2 pulses 11: Jitter compensation 3 pulses																																																																			
6	zrn3 ABS scale: Set to "1" in using AT342, AT343, LC191M/491M.																																																																			
7	omr Machine end compensation invalid	Machine end compensation valid																																																																		
8 9	lmc Set the compensation amount with SV016 (LMC1) and SV041 (LMC2). 00: Lost motion compensation stop 01: Lost motion compensation type 1 10: Overshooting compensation type 2 11: Setting prohibited																																																																			
A B	ovs Set the compensation amount with SV031 (OVS1) and SV042 (OVS2). 00: Overshooting compensation stop 01: Overshooting compensation type 1 10: Overshooting compensation type 2 11: Overshooting compensation type 3																																																																			
C D	afse 00: Adoptive filter sensitivity standard 11: Adoptive filter sensitivity increase (Set 2bits at a time)																																																																			
E	zrn2 Set to "1".																																																																			
F	aflt Adoptive filter stop	Adoptive filter start																																																																		
2228	SV028	Not used. Set to "0".	0																																																																	
2229	SV029	Speed at the change of speed loop gain	0 to 9999 (r/min)																																																																	

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range
2230	The higher order 8bits and lower order 8bits are used for different functions. "The setting value of SV030" = (Icx*256) + IVC		0 to 32767
	SV030 IVC (Low order)	Voltage dead time compensation When 100% is set, the voltage equivalent to the logical non-energized time will be compensated. When "0" is set, a 100% compensation will be performed. Adjust in increments of 10% from the default value 100%. If increased too much, vibration or vibration noise may be generated.	0 to 255 (%)
	SV030 Icx (High order)	Current bias 1 Set to "0" as a standard. Use this in combination with SV040 and the high order 8bits of SV045.	0 to 127
2231	SV031 OVS1	Overshooting compensation 1 Set this if overshooting occurs during positioning. This compensates the motor torque during positioning. This is valid only when the overshooting compensation SV027 (SSF1/ovs) is selected. Type 1: When SV027 (SSF1)/ bitB, A (ovs)=01 Set the compensation amount based on the motor's stall current. This compensates overshooting that occurs during pulse feeding. Normally, use Type 2. Type 2: When SV027 (SSF1)/ bitB, A (ovs)=10 Set the compensation amount based on the motor's stall current. Increase by 1% and determine the amount that overshooting doesn't occur. In Type 2, compensation during the feed forward control during circular cutting won't be performed. Type 3: When SV027 (SSF1)/ bitB, A (ovs)=11 Use this to perform the overshooting compensation during circular cutting or the feed forward control. The setting method is the same in Type 2. When you wish different compensation amount depending on the direction When SV042 (OVS2) is "0", compensate with the value of SV031 (OVS1) in both of the + and -directions. If you wish to change the compensation amount depending on the command direction, set this and SV042 (OVS2). (SV031: + direction, SV042: - direction. However, the directions may be opposite depending on other settings.) When "-1" is set, the compensation won't be performed in the direction of the command.	-1 to 100 (Stall [rated] current %)
2232	SV032 TOF	Torque offset Set the unbalance torque of vertical axis and inclined axis.	-100 to 100 (Stall [rated] current %)

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range																																
2233	SV033 SSF2	Servo function selection 2	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 12.5%; text-align: center;">F</td> <td style="width: 12.5%; text-align: center;">E</td> <td style="width: 12.5%; text-align: center;">D</td> <td style="width: 12.5%; text-align: center;">C</td> <td style="width: 12.5%; text-align: center;">B</td> <td style="width: 12.5%; text-align: center;">A</td> <td style="width: 12.5%; text-align: center;">9</td> <td style="width: 12.5%; text-align: center;">8</td> </tr> <tr> <td colspan="6" style="text-align: center; border: 1px solid black;">dos</td> <td style="text-align: center; border: 1px solid black;">hvx</td> <td style="text-align: center; border: 1px solid black;">svx</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td colspan="3" style="text-align: center; border: 1px solid black;">nfd2</td> <td style="text-align: center; border: 1px solid black;">nf3</td> <td colspan="3" style="text-align: center; border: 1px solid black;">nfd1</td> <td style="text-align: center; border: 1px solid black;">zck</td> </tr> </table>	F	E	D	C	B	A	9	8	dos						hvx	svx	7	6	5	4	3	2	1	0	nfd2			nf3	nfd1			zck
			F	E	D	C	B	A	9	8																									
			dos						hvx	svx																									
			7	6	5	4	3	2	1	0																									
			nfd2			nf3	nfd1			zck																									
			0	zck	Z phase check valid (Alarm 42)	Z phase check invalid																													
			1		Set the filter depth for Notch filter 1 (SV038).																														
			2	nfd1	Value	000 001 010 011 100 101 110 111																													
			3		Depth (dB)	Infntly deep -18.1 -12.0 -8.5 -6.0 -4.1 -2.5 -1.2																													
					Deep ← → Shallow																														
4	nf3	Notch filter 3 stop	Notch filter 3 start (1125Hz)																																
5		Set the operation frequency of Notch filter 2 (SV046).																																	
6	nfd2	Value	000 001 010 011 100 101 110 111																																
7		Depth (dB)	Infntly deep -18.1 -12.0 -8.5 -6.0 -4.1 -2.5 -1.2																																
		Deep ← → Shallow																																	
8	svx	Set the performance mode of the servo control.																																	
9	hvx	(Only for MDS-C1-Vx)																																	
		00: By current loop gain																																	
		01: MDS-B-Vx compatible mode selected																																	
		10: High gain mode selected																																	
		11: High gain mode selected																																	
A																																			
B																																			
C		Digital signal output selection																																	
D	dos	0 : MP scale absolute position detection, offset demand signal output																																	
E		1 : Specified speed signal output																																	
F		2 to F : Setting prohibited																																	

(Note) Set to "0" for bits with no particular description.

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range																																
2234	SV034 SSF3	Servo function selection 3	<table style="width: 100%; border-collapse: collapse; margin-bottom: 5px;"> <tr> <td style="width: 12.5%; text-align: center;">F</td> <td style="width: 12.5%; text-align: center;">E</td> <td style="width: 12.5%; text-align: center;">D</td> <td style="width: 12.5%; text-align: center;">C</td> <td style="width: 12.5%; text-align: center;">B</td> <td style="width: 12.5%; text-align: center;">A</td> <td style="width: 12.5%; text-align: center;">9</td> <td style="width: 12.5%; text-align: center;">8</td> </tr> <tr> <td colspan="8" style="text-align: center; border: 1px solid black;">ovsn</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black; text-align: center;">os2</td> <td style="border: 1px solid black; text-align: center;">zeg</td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black; text-align: center;">mohn</td> <td style="border: 1px solid black; text-align: center;">has2</td> <td style="border: 1px solid black; text-align: center;">has1</td> </tr> </table>	F	E	D	C	B	A	9	8	ovsn								7	6	5	4	3	2	1	0		os2	zeg			mohn	has2	has1
			F	E	D	C	B	A	9	8																									
			ovsn																																
			7	6	5	4	3	2	1	0																									
				os2	zeg			mohn	has2	has1																									
			bit	Meaning when "0" is set	Meaning when "1" is set																														
			0	has1	Setting for normal use (Except for HC)	HAS control 1 valid (HC: High acceleration rate support)																													
			1	has2	Setting for normal use (Except for HC)	HAS control 2 valid (HC: Overshooting support)																													
			2	mohn	MDS-B-HR motor thermal valid	MDS-B-HR motor thermal ignored																													
			3																																
4																																			
5	zeg	Z phase normal edge detection (Setting for normal use)	Z phase reverse edge detection (Valid only when SV027/bit6=1)																																
6	os2	Setting for normal use	Overspeed detection level changeover																																
7																																			
8																																			
9																																			
A																																			
B																																			
C		Set the non-sensitive band of the overshooting compensation type 3 in increments of 2μm at a time. In the feed forward control, the non-sensitive band of the model position droop is set, and overshooting of the model is ignored. Set the same value as the standard SV040.																																	
D																																			
E	ovsn																																		
F																																			
(Note) Set to "0" for bits with no particular description.																																			

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range																																
2235	SV035 SSF4	Servo function selection 4	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 12.5%; text-align: center;">F</td> <td style="width: 12.5%; text-align: center;">E</td> <td style="width: 12.5%; text-align: center;">D</td> <td style="width: 12.5%; text-align: center;">C</td> <td style="width: 12.5%; text-align: center;">B</td> <td style="width: 12.5%; text-align: center;">A</td> <td style="width: 12.5%; text-align: center;">9</td> <td style="width: 12.5%; text-align: center;">8</td> </tr> <tr> <td style="border: 1px solid black; text-align: center;">clt</td> <td colspan="3" style="border: 1px solid black; text-align: center;">clG1</td> <td style="border: 1px solid black; text-align: center;">cl2n</td> <td style="border: 1px solid black; text-align: center;">clet</td> <td colspan="2" style="border: 1px solid black; text-align: center;">cltq</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="border: 1px solid black; text-align: center;">ckab</td> <td style="border: 1px solid black; text-align: center;">iup</td> <td colspan="5" style="border: 1px solid black; text-align: center;">tdt</td> <td></td> </tr> </table>	F	E	D	C	B	A	9	8	clt	clG1			cl2n	clet	cltq		7	6	5	4	3	2	1	0	ckab	iup	tdt					
			F	E	D	C	B	A	9	8																									
			clt	clG1			cl2n	clet	cltq																										
			7	6	5	4	3	2	1	0																									
			ckab	iup	tdt																														
			bit	Meaning when "0" is set	Meaning when "1" is set																														
			0	Td creation time setting Set to "0". (For machine tool builder adjustment)																															
			1																																
			2																																
			3																																
4																																			
5	tdt																																		
6	iup	Set to "1" when using any of motors from HC152 to HC702 and from HC153 to HC453.																																	
7	ckab	Setting for normal use	No signal 2 (Alarm 21) special detection																																
8	cltq	Set the retracting torque for collision detection in respect to the maximum torque of the motor.																																	
9	00: 100% 01: 90% 10: 80% (Standard) 11: 70%																																		
A	clet	Setting for normal use	The disturbance torque peak of the latest two seconds is displayed in MPOS of the servo monitor screen.																																
B	cl2n	Collision detection method 2 valid	Collision detection method 2 invalid																																
C	Collision detection method 1																																		
D	Set the collision detection level during cutting feed (G1).																																		
E	clG1	The G1 collision detection level=SV060*clG1.																																	
F	When clG1=0, the collision detection method 1 during cutting feed won't function.																																		
F	clt	Setting for normal use	The guide value of the SV059 setting value is displayed in MPOS of the servo monitor screen.																																
(Note) bit7 (ckab) is only for MDS-C1-Vx.																																			

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range																																																																																																																
2236 (PR)	SV036 PTYP	Power supply type	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">F</td> <td style="text-align: center;">E</td> <td style="text-align: center;">D</td> <td style="text-align: center;">C</td> <td style="text-align: center;">B</td> <td style="text-align: center;">A</td> <td style="text-align: center;">9</td> <td style="text-align: center;">8</td> </tr> <tr> <td colspan="4" style="text-align: center; border: 1px solid black;">amp</td> <td colspan="4" style="text-align: center; border: 1px solid black;">rtyp</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td colspan="8" style="text-align: center; border: 1px solid black;">ptyp</td> </tr> </table>	F	E	D	C	B	A	9	8	amp				rtyp				7	6	5	4	3	2	1	0	ptyp																																																																																							
			F	E	D	C	B	A	9	8																																																																																																									
			amp				rtyp																																																																																																												
			7	6	5	4	3	2	1	0																																																																																																									
			ptyp																																																																																																																
			0	ptyp	<p>Explanation</p> <p>When the CN4 connector of the drive unit and the power supply are connected, setting below is necessary.</p> <p>To validate the external emergency stop function, add 40h.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 5%;">Set-ting</th> <th style="width: 10%;">0x</th> <th style="width: 10%;">1x</th> <th style="width: 10%;">2x</th> <th style="width: 10%;">3x</th> <th style="width: 10%;">4x</th> <th style="width: 10%;">5x</th> <th style="width: 10%;">6x</th> <th style="width: 10%;">7x</th> <th style="width: 10%;">8x</th> </tr> </thead> <tbody> <tr> <td>x0</td> <td>Not used</td> <td></td> <td></td> <td>CV-300</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>x1</td> <td></td> <td>CV-110</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-10</td> </tr> <tr> <td>x2</td> <td></td> <td></td> <td>CV-220</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-15</td> </tr> <tr> <td>x3</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-22</td> </tr> <tr> <td>x4</td> <td>CV-37</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-37</td> </tr> <tr> <td>x5</td> <td></td> <td>CV-150</td> <td></td> <td></td> <td>CV-450</td> <td>CV-550</td> <td></td> <td></td> <td></td> </tr> <tr> <td>x6</td> <td>CV-55</td> <td></td> <td>CV-260</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-55</td> </tr> <tr> <td>x7</td> <td></td> <td></td> <td></td> <td>CV-370</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>x8</td> <td>CV-75</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-75</td> </tr> <tr> <td>x9</td> <td></td> <td>CV-185</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-90</td> </tr> </tbody> </table>	Set-ting	0x	1x	2x	3x	4x	5x	6x	7x	8x	x0	Not used			CV-300						x1		CV-110							CR-10	x2			CV-220						CR-15	x3									CR-22	x4	CV-37								CR-37	x5		CV-150			CV-450	CV-550				x6	CV-55		CV-260						CR-55	x7				CV-370						x8	CV-75								CR-75	x9		CV-185							CR-90
			Set-ting			0x	1x	2x	3x	4x	5x	6x	7x	8x																																																																																																					
			x0			Not used			CV-300																																																																																																										
			x1				CV-110							CR-10																																																																																																					
			x2					CV-220						CR-15																																																																																																					
x3											CR-22																																																																																																								
x4	CV-37										CR-37																																																																																																								
x5		CV-150					CV-450	CV-550																																																																																																											
x6	CV-55		CV-260								CR-55																																																																																																								
x7						CV-370																																																																																																													
x8	CV-75								CR-75																																																																																																										
x9		CV-185							CR-90																																																																																																										
8	rtyp	<p>Set the regenerative resistor type when MDS-A-CR is used.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 5%;">Set-ting</th> <th style="width: 35%;">Regenerative resistor model name</th> <th style="width: 20%;">Resistance value</th> <th style="width: 40%;">Capacity</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>MDS-C1-CV (Setting when using power supply regeneration)</td> <td></td> <td></td> </tr> <tr> <td>1</td> <td>GZG200W260HMJ</td> <td>26Ω</td> <td>80W</td> </tr> <tr> <td>2</td> <td>GZG300W130HMJ×2</td> <td>26Ω</td> <td>150W</td> </tr> <tr> <td>3</td> <td>MR-RB30</td> <td>13Ω</td> <td>300W</td> </tr> <tr> <td>4</td> <td>MR-RB50</td> <td>13Ω</td> <td>500W</td> </tr> <tr> <td>5</td> <td>GZG200W200HMJ×3</td> <td>6.7Ω</td> <td>350W</td> </tr> <tr> <td>6</td> <td>GZG300W200HMJ×3</td> <td>6.7Ω</td> <td>500W</td> </tr> <tr> <td>7</td> <td>R-UNIT-1</td> <td>30Ω</td> <td>700W</td> </tr> <tr> <td>8</td> <td>R-UNIT-2</td> <td>15Ω</td> <td>700W</td> </tr> <tr> <td>9</td> <td>R-UNIT-3</td> <td>15Ω</td> <td>2100W</td> </tr> <tr> <td>A to F</td> <td>No setting</td> <td></td> <td></td> </tr> </tbody> </table>	Set-ting	Regenerative resistor model name	Resistance value	Capacity	0	MDS-C1-CV (Setting when using power supply regeneration)			1	GZG200W260HMJ	26Ω	80W	2	GZG300W130HMJ×2	26Ω	150W	3	MR-RB30	13Ω	300W	4	MR-RB50	13Ω	500W	5	GZG200W200HMJ×3	6.7Ω	350W	6	GZG300W200HMJ×3	6.7Ω	500W	7	R-UNIT-1	30Ω	700W	8	R-UNIT-2	15Ω	700W	9	R-UNIT-3	15Ω	2100W	A to F	No setting																																																																			
Set-ting			Regenerative resistor model name	Resistance value	Capacity																																																																																																														
0			MDS-C1-CV (Setting when using power supply regeneration)																																																																																																																
1			GZG200W260HMJ	26Ω	80W																																																																																																														
2			GZG300W130HMJ×2	26Ω	150W																																																																																																														
3			MR-RB30	13Ω	300W																																																																																																														
4			MR-RB50	13Ω	500W																																																																																																														
5			GZG200W200HMJ×3	6.7Ω	350W																																																																																																														
6			GZG300W200HMJ×3	6.7Ω	500W																																																																																																														
7			R-UNIT-1	30Ω	700W																																																																																																														
8	R-UNIT-2	15Ω	700W																																																																																																																
9	R-UNIT-3	15Ω	2100W																																																																																																																
A to F	No setting																																																																																																																		
A																																																																																																																			
B																																																																																																																			
C																																																																																																																			
D	amp	Always set to "0".																																																																																																																	
E																																																																																																																			
F																																																																																																																			

2237	SV037 JL	Load inertia scale	Set "the motor inertia + motor axis conversion load inertia" in respect to the motor inertia. $SV037 (JL) = \frac{Jl+Jm}{Jm} * 100$ Jm: Motor inertia Jl: Motor axis conversion load inertia	0 to 5000 (%)
2238	SV038 FHz1	Notch filter frequency 1	Set the vibration frequency to suppress if machine vibration occurs. (Valid at 36 or more) When not using, set to "0".	0 to 9000 (Hz)

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range
2239	SV039 LMCD	Lost motion compensation timing Set this when the lost motion compensation timing does not match. Adjust by increasing the value by 10 at a time.	0 to 2000 (ms)
2240	The higher order 8bits and lower order 8bits are used for different functions. "Setting value of SV040" = (lcy*256) + LMCT		0 to 32767
	SV040 LMCT (Low order)	Lost motion compensation non-sensitive band Set the non-sensitive band of the lost motion compensation in the feed forward control. When "0" is set, the actual value that is set is 2µm. Adjust by increasing by 1µm at a time.	0 to 100 (µm)
	SV040 lcy (High order)	Current bias 2 Normally, set to "40" if you use HC202 to HC902, HC203 to HC703. Use this in combination with SV030 and the high order 8bits of SV045.	0 to 127
2241	SV041 LMC2	Lost motion compensation 2 Set this with SV016 (LMC1) only when you wish to set the lost motion compensation amount to be different depending on the command directions. Set to "0" as a standard.	-1 to 200 (Stall [rated] current %)
2242	SV042 OVS2	Overshooting compensation 2 Set this with SV031 (OVS1) only when you wish to set the overshooting compensation amount to be different depending on the command directions. Set to "0" as a standard.	-1 to 100 (Stall [rated] current %)
2243	SV043 OBS1	Disturbance observer filter frequency Set the disturbance observer filter band. Set to "100" as a standard. To use the disturbance observer, also set SV037 (JL) and SV044 (OBS2). When not using, set to "0".	0 to 1000 (rad/s)
2244	SV044 OBS2	Disturbance observer gain Set the disturbance observer gain. The standard setting is "100" to "300". To use the disturbance observer, also set SV037 (JL) and SV043 (OBS1). When not using, set to "0".	0 to 500 (%)
2245	The higher order 8bits and lower order 8bits are used for different functions. "Setting value of SV045" = (lb1*256) + TRUB		0 to 32767
	SV045 TRUB (Low order)	Frictional torque When you use the collision detection function, set the frictional torque.	0 to 100 (Stall [rated] current %)
	SV045 lb1 (High order)	Current bias 3 Set to "0" as a standard. Use this in combination with SV030 and the high order 8bits of SV040.	0 to 127
2246	SV046 FH2	Notch filter frequency 2 Set the vibration frequency to suppress if machine vibration occurs. (Valid at 36 or more) When not using, set to "0".	0 to 9000 (Hz)
2247	SV047 EC	Inductive voltage compensation gain Set the inductive voltage compensation gain. Set to "100" as a standard. If the current FB peak exceeds the current command peak, lower the gain.	0 to 200 (%)
2248	SV048 EMGr	Vertical axis drop prevention time Input a length of time to prevent the vertical axis from dropping by delaying Ready OFF until the brake works when the emergency stop occurs. Increase the setting by 100ms at a time and set the value where the axis does not drop.	0 to 20000 (ms)

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range	
2249	SV049 PGN1sp	Position loop gain 1 in spindle synchronous control	Set the position loop gain during the spindle synchronous control (synchronous tapping, synchronous control with spindle/C axis). Set the same value as the value of the spindle parameter, position loop gain in synchronous control. When performing the SHG control, set this with SV050 (PGN2sp) and SV058 (SHGCsp).	1 to 200 (rad/s)
2250	PGN2sp	Position loop gain 2 in spindle synchronous control	Set this with SV049 (PGN1sp) and SV058 (SHGCsp) if you wish to perform the SHG control in the spindle synchronous control (synchronous tapping, synchronous control with spindle/C axis). When not performing the SHG control, set to "0".	0 to 999 (rad/s)
2251	SV051 DFBT	Dual feed back control time constant	Set the control time constant in dual feed back. When "0" is set, the actual value that is set is 1ms. The higher the time constant is, the closer it gets to the semi-closed control, so the limit of the position loop gain is raised.	0 to 9999 (ms)
2252	SV052 DFBN	Dual feedback control non-sensitive band	Set the non-sensitive band in the dual feedback control. Set to "0" as a standard.	0 to 9999 (μ m)
2253	SV053 OD3	Excessive error detection width in special control	Set the excessive error detection width when servo ON in a special control (initial absolute position setting, stopper control, etc.). If "0" is set, excessive error detection won't be performed when servo ON during a special control.	0 to 32767 (mm)

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range
2254	When SV035 (SSF4)/ bitF (ckab)=0		-1 to 32767 (mm)
	SV054 ORE	Overrun detection width in closed loop control Set the overrun detection width in the full-closed loop control. If the gap between the motor end detector and the linear scale (machine end detector) exceeds the value set by this parameter, it is judged to be overrun and Alarm 43 will be detected. When "-1" is set, the alarm detection won't be performed. When "0" is set, overrun is detected with a 2mm width.	
	When SV035 (SSF4)/ bitF (ckab)=1 (Note) This applies to only MDS-C1-Vx. The higher order 8bits and lower order 8bits are used for different functions. "Setting value of SV054" =(NSE*256)+ORE		0 to 32767
	SV054 ORE (Low order)	Overrun detection-width in closed loop control Set the overrun detection width in the full-closed loop control. If the gap between the motor end detector and the linear scale (machine end detector) exceeds the value set by this parameter, it is judged to be overrun and Alarm 43 will be detected. When "255" is set, the alarm detection won't be performed. When "0" is set, overrun is detected with a 2mm width.	0 to 255 (mm)
SV054 NSE (High order)	Special detection width for No signal 2 When SV035 (SSF4)/ bitF (ckab) =1, this setting is valid. Set the special detection width for No signal 2 (Alarm 21). When "0" is set, overrun is detected with a 15μm width.	0 to 127 (μm)	
2255	SV055 EMGx	Max. gate off delay time after emergency stop Set a length of time from the point when the emergency stop is input to the point when READY OFF is compulsorily executed. Normally, set the same value as the absolute value of SV056. In preventing the vertical axis from dropping, the gate off is delayed for the length of time set by SV048 if SV055's value is smaller than that of SV048.	0 to 20000 (ms)
2256	SV056 EMGt	Deceleration time constant at emergency stop In the vertical axis drop prevention time control, set the time constant used for the deceleration control at emergency stop. Set a length of time that takes from rapid traverse rate (rapid) to stopping. Normally, set the same value as the rapid traverse acceleration/deceleration time constant. When executing the synchronous operation, put the minus sign to the settings of both of the master axis and slave axis.	-20000 to 20000 (ms)
2257	SV057 SHGC	SHG control gain When performing the SHG control, set this with S003 (PGN1) and SV004 (PGN2). When not performing the SHG control, set to "0".	0 to 1200 (rad/s)
2258	SV058 SHGCsp	SHG control gain in spindle synchronous control Set this with SV049 (PGN1sp) and SV050 (PGN2sp) if you wish to perform the SHG control in the spindle synchronous control (synchronous tapping, synchronous control with spindle/C axis). When not performing the SHG control, set to "0".	0 to 1200 (rad/s)

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range
2259	SV059 TCNV	Collision detection torque estimating gain	-32768 to 32767
2260	SV060 TLMT	Collision detection level	0 to 999 (Stall [rated] current %)
2261	SV061 DA1NO	D/A output channel 1 data No.	-1 to 127
2262	SV062 DA2NO	D/A output channel 2 data No.	
2263	SV063 DA1MPY	D/A output channel 1 output scale	-32768 to 32767 (Unit: 1/256)
2264	SV064 DA2MPY	D/A output channel 2 output scale	
2265	SV065 TLC	Tool end compensation spring constant	-32768 to 32767
2266 to 2280	SV066 to SV080	System setting parameter	These parameters are set automatically by the NC system.

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range																																
2281 (PR)	SV081 SPEC2 Servo specification selection 2	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">F</td> <td style="text-align: center;">E</td> <td style="text-align: center;">D</td> <td style="text-align: center;">C</td> <td style="text-align: center;">B</td> <td style="text-align: center;">A</td> <td style="text-align: center;">9</td> <td style="text-align: center;">8</td> </tr> <tr> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px; text-align: center;">pabs</td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px; text-align: center;">rabs</td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> </tr> </table>	F	E	D	C	B	A	9	8									7	6	5	4	3	2	1	0				pabs			rabs		
		F	E	D	C	B	A	9	8																										
		7	6	5	4	3	2	1	0																										
					pabs			rabs																											
		bit	Meaning when "0" is set	Meaning when "1" is set																															
		0																																	
		1	rabs	Normal setting	Rotary axis machine end absolute position control																														
		2																																	
		3																																	
4	pabs	Normal setting	Speed/current synchronous control absolute position control																																
5																																			
6																																			
7																																			
8																																			
9																																			
A																																			
B																																			
C																																			
D																																			
E																																			
F																																			
(Note) Set to "0" for bits with no particular description.																																			

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range																																																																																																				
2282	SV082 SPEC5 Servo function selection 5	<table style="margin: 0 auto; border-collapse: collapse;"> <tr> <td style="border: 1px solid black; width: 20px; text-align: center;">F</td> <td style="border: 1px solid black; width: 20px; text-align: center;">E</td> <td style="border: 1px solid black; width: 20px; text-align: center;">D</td> <td style="border: 1px solid black; width: 20px; text-align: center;">C</td> <td style="border: 1px solid black; width: 20px; text-align: center;">B</td> <td style="border: 1px solid black; width: 20px; text-align: center;">A</td> <td style="border: 1px solid black; width: 20px; text-align: center;">9</td> <td style="border: 1px solid black; width: 20px; text-align: center;">8</td> </tr> <tr> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> </tr> <tr> <td style="border: 1px solid black; text-align: center;">7</td> <td style="border: 1px solid black; text-align: center;">6</td> <td style="border: 1px solid black; text-align: center;">5</td> <td style="border: 1px solid black; text-align: center;">4</td> <td style="border: 1px solid black; text-align: center;">3</td> <td style="border: 1px solid black; text-align: center;">2</td> <td style="border: 1px solid black; text-align: center;">1</td> <td style="border: 1px solid black; text-align: center;">0</td> </tr> <tr> <td style="border: 1px solid black; text-align: center;">obshi</td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; text-align: center;">lmc3</td> <td style="border: 1px solid black; text-align: center;">lmct</td> </tr> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 5%;">bit</th> <th style="width: 10%;"></th> <th style="width: 40%;">Meaning when "0" is set</th> <th style="width: 45%;">Meaning when "1" is set</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">lmct</td> <td>Setting for normal use</td> <td>Lost motion compensation 3 adjustment time measurement valid</td> </tr> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">lmc3</td> <td>Lost motion compensation 3 stop</td> <td>Lost motion compensation 3 start</td> </tr> <tr> <td style="text-align: center;">2</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">3</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">4</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">5</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">6</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">obshi</td> <td>Normal use</td> <td>Disturbance observer High-load inertia compatible control</td> </tr> <tr> <td style="text-align: center;">8</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">9</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">A</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">B</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">C</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">D</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">E</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">F</td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	F	E	D	C	B	A	9	8									7	6	5	4	3	2	1	0	obshi						lmc3	lmct	bit		Meaning when "0" is set	Meaning when "1" is set	0	lmct	Setting for normal use	Lost motion compensation 3 adjustment time measurement valid	1	lmc3	Lost motion compensation 3 stop	Lost motion compensation 3 start	2				3				4				5				6				7	obshi	Normal use	Disturbance observer High-load inertia compatible control	8				9				A				B				C				D				E				F				
F	E	D	C	B	A	9	8																																																																																																
7	6	5	4	3	2	1	0																																																																																																
obshi						lmc3	lmct																																																																																																
bit		Meaning when "0" is set	Meaning when "1" is set																																																																																																				
0	lmct	Setting for normal use	Lost motion compensation 3 adjustment time measurement valid																																																																																																				
1	lmc3	Lost motion compensation 3 stop	Lost motion compensation 3 start																																																																																																				
2																																																																																																							
3																																																																																																							
4																																																																																																							
5																																																																																																							
6																																																																																																							
7	obshi	Normal use	Disturbance observer High-load inertia compatible control																																																																																																				
8																																																																																																							
9																																																																																																							
A																																																																																																							
B																																																																																																							
C																																																																																																							
D																																																																																																							
E																																																																																																							
F																																																																																																							
(Note) Set to "0" for bits with no particular description.																																																																																																							

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range																																
2283	SV083 SSF6	Servo function selection 6	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 12.5%; text-align: center;">F</td> <td style="width: 12.5%; text-align: center;">E</td> <td style="width: 12.5%; text-align: center;">D</td> <td style="width: 12.5%; text-align: center;">C</td> <td style="width: 12.5%; text-align: center;">B</td> <td style="width: 12.5%; text-align: center;">A</td> <td style="width: 12.5%; text-align: center;">9</td> <td style="width: 12.5%; text-align: center;">8</td> </tr> <tr> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td colspan="4" style="border: 1px solid black; text-align: center;">nfd5</td> <td colspan="4" style="border: 1px solid black; text-align: center;">nfd4</td> </tr> </table>	F	E	D	C	B	A	9	8									7	6	5	4	3	2	1	0	nfd5				nfd4			
			F	E	D	C	B	A	9	8																									
			7	6	5	4	3	2	1	0																									
			nfd5				nfd4																												
			bit	Meaning when "0" is set	Meaning when "1" is set																														
			0																																
			1	Set the filter depth for Notch filter 4 (SV038).																															
			2	nfd4 Value	000 001 010 011 100 101 110 111																														
			3	Depth (dB)	Infntly deep -18.1 -12.0 -8.5 -6.0 -4.1 -2.5 -1.2																														
				Deep←	→ Shallow																														
			4																																
			5	Set the filter depth for Notch filter 5 (SV046).																															
			6	nfd5 Value	000 001 010 011 100 101 110 111																														
			7	Depth (dB)	Infntly deep -18.1 -12.0 -8.5 -6.0 -4.1 -2.5 -1.2																														
	Deep←	→ Shallow																																	
8																																			
9																																			
A																																			
B																																			
C																																			
D																																			
E																																			
F																																			
(Note) Set to "0" for bits with no particular description.																																			
2284	SV084 SSF7	Servo function selection 7	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 12.5%; text-align: center;">F</td> <td style="width: 12.5%; text-align: center;">E</td> <td style="width: 12.5%; text-align: center;">D</td> <td style="width: 12.5%; text-align: center;">C</td> <td style="width: 12.5%; text-align: center;">B</td> <td style="width: 12.5%; text-align: center;">A</td> <td style="width: 12.5%; text-align: center;">9</td> <td style="width: 12.5%; text-align: center;">8</td> </tr> <tr> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> </tr> </table>	F	E	D	C	B	A	9	8									7	6	5	4	3	2	1	0								
			F	E	D	C	B	A	9	8																									
			7	6	5	4	3	2	1	0																									
			bit	Meaning when "0" is set	Meaning when "1" is set																														
			0																																
			1																																
			2																																
			3																																
			4																																
			5																																
			6																																
			7																																
			8																																
9																																			
A																																			
B																																			
C																																			
D																																			
E																																			
F																																			
(Note) Set to "0" for bits with no particular description.																																			

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

No.	Items	Details	Setting range
2285	SV085 LMCk	Lost motion compensation spring constant	Set the machine system's spring constant when using lost motion compensation type 3. 0 to 32767
2286	SV086 LMCc	Lost motion compensation viscous coefficient	Set the machine system's viscous coefficient when using lost motion compensation type 3. 0 to 32767
2287	SV087 FH4	Notch filter frequency 4	Set the vibration frequency to suppress if machine vibration occurs. (Valid at 141 or more) When not using, set to "0". 0 to 2250 (Hz)
2288	SV088 FH5	Notch filter frequency 5	To use this function, set to not "0" (normally "1") when turning the power ON. This function cannot be used with adaptive filter. 0 to 2250 (Hz)
2289 to 2300			Not used. Set to "0". 0

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

(2) Initial setting value

(a) HC Series (Standard 2000r/min rating)

Motor		Standard HC motor 2000 r/min rating										
		HC52	HC102	HC152	HC202	HC352	HC452		HC702		HC902	
Drive unit capacity		05	10	20	20	35	45S	45	70S	70	90S	90
SV001	PC1	---	---	---	---	---	---	---	---	---	---	---
SV002	PC2	---	---	---	---	---	---	---	---	---	---	---
SV003	PGN1	47	47	47	47	47	47	47	47	47	47	47
SV004	PGN2	0	0	0	0	0	0	0	0	0	0	0
SV005	VGN1	200	200	200	200	200	200	200	200	200	200	200
SV006	VGN2	0	0	0	0	0	0	0	0	0	0	0
SV007	VIL	0	0	0	0	0	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364	1364	1364	1364	1364	1364
SV009	IQA	4096	4096	4096	4096	4096	4096	4096	4096	4096	4096	4096
SV010	IDA	4096	4096	4096	4096	4096	4096	4096	4096	4096	4096	4096
SV011	IQG	768	768	768	768	768	768	768	768	768	768	768
SV012	IDG	768	768	768	768	768	768	768	768	768	768	768
SV013	ILMT	500	500	500	500	500	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000	1000	0000	1000	0000	1000	0000
SV018	PIT	---	---	---	---	---	---	---	---	---	---	---
SV019	RNG1	---	---	---	---	---	---	---	---	---	---	---
SV020	RNG2	---	---	---	---	---	---	---	---	---	---	---
SV021	OLT	60	60	60	60	60	60	60	60	60	60	60
SV022	OLL	150	150	150	150	150	150	150	150	150	150	150
SV023	OD1	6	6	6	6	6	6	6	6	6	6	6
SV024	INP	50	50	50	50	50	50	50	50	50	50	50
SV025	MTYP	xxB0	xxB1	xxB2	xxB3	xxB4	xx95	xxB5	xx96	xxB6	xx97	xxB7
SV026	OD2	6	6	6	6	6	6	6	6	6	6	6
SV027	SSF1	4000	4000	4000	4000	4000	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0	0	0	0	0	0
SV029	VCS	0	0	0	0	0	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0	0	0	0	0	0
SV033	SSF2	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV034	SSF3	0003	0003	0003	0003	0003	0003	0003	0003	0003	0003	0003
SV035	SSF4	0000	0000	0040	0040	0040	0040	0040	0040	0040	0000	0000
SV036	PTYP	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV037	JL	0	0	0	0	0	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

Motor		Standard HC motor 2000 r/min rating										
		HC52	HC102	HC152	HC202	HC352	HC452		HC702		HC902	
Drive unit capacity		05	10	20	20	35	45S	45	70S	70	90S	90
SV039	LMCD	0	0	0	0	0	0	0	0	0	0	0
SV040	LMCT	0	0	0	10240	10240	10240	10240	10240	10240	10240	10240
SV041	LMC2	0	0	0	0	0	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0	0	0	0	0	0
SV045	TRUB	0	0	0	0	0	0	0	0	0	0	0
SV046	FHz2	0	0	0	0	0	0	0	0	0	0	0
SV047	EC	100	100	100	100	100	100	100	100	100	100	100
SV048	EMGrt	0	0	0	0	0	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0	0	0	0	0	0	0
SV051	DFBT	0	0	0	0	0	0	0	0	0	0	0
SV052	DFBN	0	0	0	0	0	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0	0	0	0	0	0
SV054	ORE	0	0	0	0	0	0	0	0	0	0	0
SV055	EMGx	0	0	0	0	0	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0	0	0	0	0	0
SV059	TCNV	0	0	0	0	0	0	0	0	0	0	0
SV060	TLMT	0	0	0	0	0	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0	0	0	0	0	0
SV065	TLC	0	0	0	0	0	0	0	0	0	0	0
(System parameter area)												
SV081	SPEC2	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV082	SSF5	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV083	SSF6	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV084	SSF7	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV085	LMCK	0	0	0	0	0	0	0	0	0	0	0
SV086	LMCC	0	0	0	0	0	0	0	0	0	0	0
SV087	FHz4	0	0	0	0	0	0	0	0	0	0	0
SV088	FHz5	0	0	0	0	0	0	0	0	0	0	0
SV089		0	0	0	0	0	0	0	0	0	0	0
SV100		0	0	0	0	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

(b) HC Series (Standard 3000r/min rating)

Motor		Standard HC motor 3000 r/min rating									
		HC53	HC103	HC153	HC203	HC353		HC453		HC703	
Drive unit capacity		05	10	20	35	45S	45	70S	70	90S	90
SV001	PC1	---	---	---	---	---	---	---	---	---	---
SV002	PC2	---	---	---	---	---	---	---	---	---	---
SV003	PGN1	47	47	47	47	47	47	47	47	47	47
SV004	PGN2	0	0	0	0	0	0	0	0	0	0
SV005	VGN1	200	200	200	200	200	200	200	200	200	200
SV006	VGN2	0	0	0	0	0	0	0	0	0	0
SV007	VIL	0	0	0	0	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364	1364	1364	1364	1364
SV009	IQA	4096	4096	4096	4096	4096	4096	4096	4096	4096	4096
SV010	IDA	4096	4096	4096	4096	4096	4096	4096	4096	4096	4096
SV011	IQG	768	768	768	768	768	768	768	768	768	768
SV012	IDG	768	768	768	768	768	768	768	768	768	768
SV013	ILMT	500	500	500	500	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	1000	0000	1000	0000	1000	0000
SV018	PIT	---	---	---	---	---	---	---	---	---	---
SV019	RNG1	---	---	---	---	---	---	---	---	---	---
SV020	RNG2	---	---	---	---	---	---	---	---	---	---
SV021	OLT	60	60	60	60	60	60	60	60	60	60
SV022	OLL	150	150	150	150	150	150	150	150	150	150
SV023	OD1	6	6	6	6	6	6	6	6	6	6
SV024	INP	50	50	50	50	50	50	50	50	50	50
SV025	MTYP	xxC0	xxC1	xxC2	xxC3	xxA4	xxC4	xxA5	xxC5	xxA6	xxC6
SV026	OD2	6	6	6	6	6	6	6	6	6	6
SV027	SSF1	4000	4000	4000	4000	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0	0	0	0	0
SV029	VCS	0	0	0	0	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0	0	0	0	0
SV033	SSF2	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV034	SSF3	0003	0003	0003	0003	0003	0003	0003	0003	0003	0003
SV035	SSF4	0000	0000	0040	0040	0040	0040	0040	0040	0000	0000
SV036	PTYP	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV037	JL	0	0	0	0	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

Motor		Standard HC motor 3000 r/min rating									
		HC53	HC103	HC153	HC203	HC353		HC453		HC703	
Drive unit capacity		05	10	20	35	45S	45	70S	70	90S	90
SV039	LMCD	0	0	0	0	0	0	0	0	0	0
SV040	LMCT	0	0	0	10240	10240	10240	10240	10240	10240	10240
SV041	LMC2	0	0	0	0	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0	0	0	0	0
SV045	TRUB	0	0	0	0	0	0	0	0	0	0
SV046	FHz2	0	0	0	0	0	0	0	0	0	0
SV047	EC	100	100	100	100	100	100	100	100	100	100
SV048	EMGrt	0	0	0	0	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0	0	0	0	0	0
SV051	DFBT	0	0	0	0	0	0	0	0	0	0
SV052	DFBN	0	0	0	0	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0	0	0	0	0
SV054	ORE	0	0	0	0	0	0	0	0	0	0
SV055	EMGx	0	0	0	0	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0	0	0	0	0
SV059	TCNV	0	0	0	0	0	0	0	0	0	0
SV060	TLMT	0	0	0	0	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0	0	0	0	0
SV065	TLC	0	0	0	0	0	0	0	0	0	0
(System parameter area)											
SV081	SPEC2	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV082	SSF5	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV083	SSF6	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV084	SSF7	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV085	LMCk	0	0	0	0	0	0	0	0	0	0
SV086	LMCc	0	0	0	0	0	0	0	0	0	0
SV087	FHz4	0	0	0	0	0	0	0	0	0	0
SV088	FHz5	0	0	0	0	0	0	0	0	0	0
SV089											
:											
SV100		0	0	0	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

(c) HC Series (Low-inertia)

Motor		Low-inertia HC motor				
		HC103R	HC153R	HC203R	HC353R	HC503R
Drive unit capacity		10	10	20	35	45
SV001	PC1	---	---	---	---	---
SV002	PC2	---	---	---	---	---
SV003	PGN1	33	33	33	33	33
SV004	PGN2	0	0	0	0	0
SV005	VGN1	15	15	20	40	40
SV006	VGN2	0	0	0	0	0
SV007	VIL	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364
SV009	IQA	4096	4096	4096	4096	4096
SV010	IDA	4096	4096	4096	4096	4096
SV011	IQG	256	256	256	256	512
SV012	IDG	512	512	512	512	512
SV013	ILMT	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500
SV015	FFC	0	0	0	0	0
SV016	LMC1	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000
SV018	PIT	---	---	---	---	---
SV019	RNG1	---	---	---	---	---
SV020	RNG2	---	---	---	---	---
SV021	OLT	60	60	60	60	60
SV022	OLL	150	150	150	150	150
SV023	OD1	6	6	6	6	6
SV024	INP	50	50	50	50	50
SV025	MTYP	xxE1	xxE2	xxE3	xxE4	xxE5
SV026	OD2	6	6	6	6	6
SV027	SSF1	4000	4000	4000	4000	4000
SV028		0	0	0	0	0
SV029	VCS	0	0	0	0	0
SV030	IVC	0	0	0	0	0
SV031	OVS1	0	0	0	0	0
SV032	TOF	0	0	0	0	0
SV033	SSF2	0200	0200	0200	0200	0200
SV034	SSF3	0000	0000	0000	0000	0000
SV035	SSF4	0000	0000	0000	0000	0000
SV036	PTYP	0000	0000	0000	0000	0000
SV037	JL	0	0	0	0	0
SV038	FHz1	0	0	0	0	0

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

Motor		Low-inertia HC motor				
		HC103R	HC153R	HC203R	HC353R	HC503R
Drive unit capacity		10	10	20	35	45
SV039	LMCD	0	0	0	0	0
SV040	LMCT	0	0	0	0	0
SV041	LMC2	0	0	0	0	0
SV042	OVS2	0	0	0	0	0
SV043	OBS1	0	0	0	0	0
SV044	OBS2	0	0	0	0	0
SV045	TRUB	0	0	0	0	0
SV046	FHz2	0	0	0	0	0
SV047	EC	100	100	100	100	100
SV048	EMGr	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0
SV051	DFBT	0	0	0	0	0
SV052	DFBN	0	0	0	0	0
SV053	OD3	0	0	0	0	0
SV054	ORE	0	0	0	0	0
SV055	EMGx	0	0	0	0	0
SV056	EMGt	0	0	0	0	0
SV057	SHGC	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0
SV059	TCNV	0	0	0	0	0
SV060	TLMT	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0
SV065	TLC	0	0	0	0	0
(System parameter area)						
SV081	SPEC2	0000	0000	0000	0000	0000
SV082	SSF5	0000	0000	0000	0000	0000
SV083	SSF6	0000	0000	0000	0000	0000
SV084	SSF7	0000	0000	0000	0000	0000
SV085	LMCk	0	0	0	0	0
SV086	LMCc	0	0	0	0	0
SV087	FHz4	0	0	0	0	0
SV088	FHz5	0	0	0	0	0
SV089						
:						
SV100		0	0	0	0	0

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

(d) HA series

Motor		Small capacity HA motor				Large capacity HA motor	
		HA053N	HA13N	HA23N	HA33N	HA-LF11K2	HA-LF15K2
Drive unit capacity		01	01	03	03	110	150
SV001	PC1	---	---	---	---	---	---
SV002	PC2	---	---	---	---	---	---
SV003	PGN1	33	33	33	33	33	33
SV004	PGN2	0	0	0	0	0	0
SV005	VGN1	70	70	100	100	150	150
SV006	VGN2	0	0	0	0	0	0
SV007	VIL	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364
SV009	IQA	4096	4096	4096	4096	4096	4096
SV010	IDA	4096	4096	4096	4096	4096	4096
SV011	IQG	768	768	768	768	512	512
SV012	IDG	768	768	768	768	512	512
SV013	ILMT	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000	0000
SV018	PIT	---	---	---	---	---	---
SV019	RNG1	---	---	---	---	---	---
SV020	RNG2	---	---	---	---	---	---
SV021	OLT	60	60	60	60	60	60
SV022	OLL	150	150	150	150	150	150
SV023	OD1	6	6	6	6	6	6
SV024	INP	50	50	50	50	50	50
SV025	MTYP	xx8C	xx8D	xx8E	xx8F	xx2E	xx2F
SV026	OD2	6	6	6	6	6	6
SV027	SSF1	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0
SV029	VCS	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0
SV033	SSF2	0000	0000	0000	0000	0000	0000
SV034	SSF3	0000	0000	0000	0000	0000	0000
SV035	SSF4	0000	0000	0000	0000	0000	0000
SV036	PTYP	0000	0000	0000	0000	0000	0000
SV037	JL	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

Motor		Small capacity HA motor				Large capacity HA motor	
		HA053N	HA13N	HA23N	HA33N	HA-LF11K2	HA-LF15K2
Drive unit capacity		01	01	03	03	110	150
SV039	LMCD	0	0	0	0	0	0
SV040	LMCT	0	0	0	0	0	0
SV041	LMC2	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0
SV045	TRUB	0	0	0	0	0	0
SV046	FHz2	0	0	0	0	0	0
SV047	EC	100	100	100	100	100	100
SV048	EMGrt	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0	0
SV051	DFBT	0	0	0	0	0	0
SV052	DFBN	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0
SV054	ORE	0	0	0	0	0	0
SV055	EMGx	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0
SV059	TCNV	0	0	0	0	0	0
SV060	TLMT	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0
SV065	TLC	0	0	0	0	0	0
(System parameter area)							
SV081	SPEC2	0000	0000	0000	0000	0000	0000
SV082	SSF5	0000	0000	0000	0000	0000	0000
SV083	SSF6	0000	0000	0000	0000	0000	0000
SV084	SSF7	0000	0000	0000	0000	0000	0000
SV085	LMCk	0	0	0	0	0	0
SV086	LMCc	0	0	0	0	0	0
SV087	FHz4	0	0	0	0	0	0
SV088	FHz5	0	0	0	0	0	0
SV089							
:							
SV100		0	0	0	0	0	0

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

(e) HA series (MDS-B-Vx4)

Motor		HA motor 2000 r/min rating						
		HA40N	HA80N	HA100N	HA200N	HA300N	HA700N	HA900N
Drive unit capacity		05	10	20	35	45	70	90
SV001	PC1	---	---	---	---	---	---	---
SV002	PC2	---	---	---	---	---	---	---
SV003	PGN1	33	33	33	33	33	25	25
SV004	PGN2	0	0	0	0	0	0	0
SV005	VGN1	150	150	150	150	150	250	250
SV006	VGN2	0	0	0	0	0	0	0
SV007	VIL	0	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364	1364
SV009	IQA	4096	4096	4096	4096	4096	4096	4096
SV010	IDA	4096	4096	4096	4096	4096	4096	4096
SV011	IQG	768	768	768	768	768	768	768
SV012	IDG	768	768	768	768	768	768	768
SV013	ILMT	500	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000	0000	0000
SV018	PIT	---	---	---	---	---	---	---
SV019	RNG1	---	---	---	---	---	---	---
SV020	RNG2	---	---	---	---	---	---	---
SV021	OLT	60	60	60	60	60	60	60
SV022	OLL	150	150	150	150	150	150	150
SV023	OD1	6	6	6	6	6	6	6
SV024	INP	50	50	50	50	50	50	50
SV025	MTYP	xx00	xx01	xx02	xx03	xx04	xx05	xx85
SV026	OD2	6	6	6	6	6	6	6
SV027	SSF1	4000	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0	0
SV029	VCS	0	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0	0
SV033	SSF2	0000	0000	0000	0000	0000	0000	0000
SV034	SSF3	0000	0000	0000	0000	0000	0000	0000
SV035	SSF4	0000	0000	0000	0000	0000	0000	0000
SV036	PTYP	0000	0000	0000	0000	0000	0000	0000
SV037	JL	0	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

Motor		HA motor 2000 r/min rating						
		HA40N	HA80N	HA100N	HA200N	HA300N	HA700N	HA900N
Drive unit capacity		05	10	20	35	45	70	90
SV039	LMCD	0	0	0	0	0	0	0
SV040	LMCT	0	0	0	0	0	0	0
SV041	LMC2	0	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0	0
SV045	TRUB	0	0	0	0	0	0	0
SV046	FHz2	0	0	0	0	0	0	0
SV047	EC	100	100	100	100	100	100	100
SV048	EMGrt	0	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0	0	0
SV051	DFBT	0	0	0	0	0	0	0
SV052	DFBN	0	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0	0
SV054	ORE	0	0	0	0	0	0	0
SV055	EMGx	0	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0	0
SV059	TCNV	0	0	0	0	0	0	0
SV060	TLMT	0	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0	0
SV065	TLC	0	0	0	0	0	0	0
(System parameter area)								
SV081	SPEC2	0000	0000	0000	0000	0000	0000	0000
SV082	SSF5	0000	0000	0000	0000	0000	0000	0000
SV083	SSF6	0000	0000	0000	0000	0000	0000	0000
SV084	SSF7	0000	0000	0000	0000	0000	0000	0000
SV085	LMCK	0	0	0	0	0	0	0
SV086	LMCC	0	0	0	0	0	0	0
SV087	FHz4	0	0	0	0	0	0	0
SV088	FHz5	0	0	0	0	0	0	0
SV089		0	0	0	0	0	0	0
:								
SV100								

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

(f) HA series (MDS-B-Vx4)

Motor		HA motor 3000 r/min rating						
		HA43N	HA83N	HA93N	HA103N	HA203N	HA303N	HA703N
Drive unit capacity		05	10	20	35	45	70	90
SV001	PC1	---	---	---	---	---	---	---
SV002	PC2	---	---	---	---	---	---	---
SV003	PGN1	33	33	33	33	33	33	25
SV004	PGN2	0	0	0	0	0	0	0
SV005	VGN1	150	150	150	150	150	150	250
SV006	VGN2	0	0	0	0	0	0	0
SV007	VIL	0	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364	1364
SV009	IQA	4096	4096	4096	4096	4096	4096	4096
SV010	IDA	4096	4096	4096	4096	4096	4096	4096
SV011	IQG	768	768	768	768	768	768	768
SV012	IDG	768	768	768	768	768	768	768
SV013	ILMT	500	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000	0000	0000
SV018	PIT	---	---	---	---	---	---	---
SV019	RNG1	---	---	---	---	---	---	---
SV020	RNG2	---	---	---	---	---	---	---
SV021	OLT	60	60	60	60	60	60	60
SV022	OLL	150	150	150	150	150	150	150
SV023	OD1	6	6	6	6	6	6	6
SV024	INP	50	50	50	50	50	50	50
SV025	MTYP	xx80	xx81	xx8A	xx82	xx83	xx84	xx85
SV026	OD2	6	6	6	6	6	6	6
SV027	SSF1	4000	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0	0
SV029	VCS	0	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0	0
SV033	SSF2	0000	0000	0000	0000	0000	0000	0000
SV034	SSF3	0000	0000	0000	0000	0000	0000	0000
SV035	SSF4	0000	0000	0000	0000	0000	0000	0000
SV036	PTYP	0000	0000	0000	0000	0000	0000	0000
SV037	JL	0	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.2 MDS-C1-Vx High-gain (MDS-B-Vx4 Compatible)

Motor		HA motor 3000 r/min rating						
		HA43N	HA83N	HA93N	HA103N	HA203N	HA303N	HA703N
Drive unit capacity		05	10	20	35	45	70	90
SV039	LMCD	0	0	0	0	0	0	0
SV040	LMCT	0	0	0	0	0	0	0
SV041	LMC2	0	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0	0
SV045	TRUB	0	0	0	0	0	0	0
SV046	FHz2	0	0	0	0	0	0	0
SV047	EC	100	100	100	100	100	100	100
SV048	EMGrt	0	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0	0	0
SV051	DFBT	0	0	0	0	0	0	0
SV052	DFBN	0	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0	0
SV054	ORE	0	0	0	0	0	0	0
SV055	EMGx	0	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0	0
SV059	TCNV	0	0	0	0	0	0	0
SV060	TLMT	0	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0	0
SV065	TLC	0	0	0	0	0	0	0
(System parameter area)								
SV081	SPEC2	0000	0000	0000	0000	0000	0000	0000
SV082	SSF5	0000	0000	0000	0000	0000	0000	0000
SV083	SSF6	0000	0000	0000	0000	0000	0000	0000
SV084	SSF7	0000	0000	0000	0000	0000	0000	0000
SV085	LMCK	0	0	0	0	0	0	0
SV086	LMCC	0	0	0	0	0	0	0
SV087	FHz4	0	0	0	0	0	0	0
SV088	FHz5	0	0	0	0	0	0	0
SV089		0	0	0	0	0	0	0
:								
SV100								

7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)


(1) Details for servo parameters

For parameters marked with a (PR) in the table, turn the NC power OFF after setting. After the power is turned ON again, the parameter is validated.

! CAUTION

! In the explanation on bits, set all bits not used, including blank bits, to "0".

No.	Items	Details	Setting range
2201 (PR)	SV001 PC1	Motor side gear ratio	1 to 32767
2202 (PR)	SV002 PC2	Machine side gear ratio	1 to 32767
2203	SV003 PGN1	Position loop gain 1	1 to 200 (rad/s)
2204	SV004 PGN2	Position loop gain 2	0 to 999 (rad/s)
2205	SV005 VGN1	Speed loop gain 1	1 to 999
2206	SV006 VGN2	Speed loop gain 2	-1000 to 1000



7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

No.	Items	Details	Setting range	
2207	SV007 VIL	Speed loop delay compensation	Set this when the limit cycle occurs in the full-closed loop, or overshooting occurs in positioning. Select the control method with SV027 (SSF1)/bit1, 0 (vcnt). Normally, use "Changeover type 2". When you set this parameter, make sure to set the torque offset (SV032 (TOF)). When not using, set to "0".	0 to 32767
		No changeover When SV027 (SSF1)/ bit1, 0 (vcnt)=00 The delay compensation control is always valid.		
		Changeover type 1 When SV027 (SSF1)/ bit1, 0 (vcnt)=01 The delay compensation control works when the command from the NC is "0". Overshooting that occurs during pulse feeding can be suppressed.		
		Changeover type 2 When SV027 (SSF1)/ bit1, 0 (vcnt)=10 The delay compensation control works when the command from the NC is "0" and the position droop is "0". Overshooting or the limit cycle that occurs during pulse feeding or positioning can be suppressed.		
2208	SV008 VIA	Speed loop lead compensation	Set the gain of the speed loop integration control. The standard setting is "1364". During the SHG control, the standard setting is "1900". Adjust the value by increasing/decreasing it by about 100 at a time. Raise this value to improve contour tracking precision in high-speed cutting. Lower this value when the position droop vibrates (10 to 20Hz).	1 to 9999
2209	SV009 IQA	Current loop q axis lead compensation	Set the gain of current loop. As this setting is determined by the motor's electrical characteristics, the setting is fixed for each type of motor.	1 to 20480
2210	SV010 IDA	Current loop d axis lead compensation	Set the standard values for all the parameters depending on each motor type.	1 to 20480
2211	SV011 IQG	Current loop q axis gain		1 to 2560
2212	SV012 IDG	Current loop d axis gain		1 to 2560
2213	SV013 ILMT	Current limit value	Set the normal current (torque) limit value. (Limit values for both + and - direction.) When the value is "500" (a standard setting), the maximum torque is determined by the specification of the motor.	0 to 999 (Stall [rated] current %)
2214	SV014 ILMTsp	Current limit value in special control	Set the current (torque) limit value in a special control (initial absolute position setting, stopper control, etc). (Limit values for both of the + and - directions.) Set to "500" when not using.	0 to 999 (Stall [rated] current %)

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

No.	Items	Details	Setting range
2215	SV015 FFC	Acceleration rate feed forward gain When a relative error in the synchronous control is large, apply this parameter to the axis that is delaying. The standard setting value is "0". For the SHG control, set to "100". To adjust a relative error in acceleration/deceleration, increase the value by 50 to 100 at a time.	0 to 999 (%)
2216	SV016 LMC1	Lost motion compensation 1 Set this when the protrusion (that occurs due to the non-sensitive band by friction, torsion, backlash, etc) at quadrant change is too large. This compensates the torque at quadrant change. This is valid only when the lost motion compensation (SV027 (SSF1/lmc)) is selected. Type 1: When SV027 (SSF1)/ bit9, 8 (lmc)=01 Set the compensation amount based on the motor torque before the quadrant change. The standard setting is "100". Setting to "0" means the compensation amount is zero. Normally, use Type 2. Type 2: When SV027 (SSF1)/ bit9, 8 (lmc)=10 Set the compensation amount based on the stall (rated) current of the motor. The standard setting is double of the friction torque. Setting to "0" means the compensation amount is zero. When you wish different compensation amount depending on the direction When SV041 (LMC2) is "0", compensate with the value of SV016 (LMC1) in both of the + and -directions. If you wish to change the compensation amount depending on the command direction, set this and SV041 (LMC2). (SV016: + direction, SV041: - direction. However, the directions may be opposite depending on other settings.) When "-1" is set, the compensation won't be performed in the direction of the command.	-1 to 200 (%) -1 to 100 (Stall [rated] current %)

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

No.	Items	Details	Setting range																																																																		
2217 (PR)	SV017 SPEC	Servo specification selection	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 12.5%; text-align: center;">F</td> <td style="width: 12.5%; text-align: center;">E</td> <td style="width: 12.5%; text-align: center;">D</td> <td style="width: 12.5%; text-align: center;">C</td> <td style="width: 12.5%; text-align: center;">B</td> <td style="width: 12.5%; text-align: center;">A</td> <td style="width: 12.5%; text-align: center;">9</td> <td style="width: 12.5%; text-align: center;">8</td> </tr> <tr> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black; text-align: center;">mpt3</td> <td style="border: 1px solid black; text-align: center;">mp</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="border: 1px solid black; text-align: center;">abs</td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black; text-align: center;">vdir</td> <td style="border: 1px solid black; text-align: center;">fdir</td> <td style="border: 1px solid black; text-align: center;">spwv</td> <td style="border: 1px solid black; text-align: center;">seqh</td> <td style="border: 1px solid black; text-align: center;">dfbx</td> <td style="border: 1px solid black; text-align: center;">fdir2</td> </tr> </table>	F	E	D	C	B	A	9	8							mpt3	mp	7	6	5	4	3	2	1	0	abs		vdir	fdir	spwv	seqh	dfbx	fdir2																																		
			F	E	D	C	B	A	9	8																																																											
									mpt3	mp																																																											
			7	6	5	4	3	2	1	0																																																											
			abs		vdir	fdir	spwv	seqh	dfbx	fdir2																																																											
			<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">bit</th> <th style="width: 10%;"></th> <th style="width: 40%;">Meaning when "0" is set</th> <th style="width: 40%;">Meaning when "1" is set</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">fdir2</td> <td>Speed feedback forward polarity</td> <td>Speed feedback reverse polarity</td> </tr> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">dfbx</td> <td>Dual feedback control stop</td> <td>Dual feedback control start</td> </tr> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">seqh</td> <td>READY/Servo ON time normal</td> <td>READY/Servo ON time high speed</td> </tr> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">spwv</td> <td>Normal mode</td> <td>High gain servo synchronous mode</td> </tr> <tr> <td style="text-align: center;">4</td> <td style="text-align: center;">fdir</td> <td>Position feedback forward polarity</td> <td>Position feedback reverse polarity</td> </tr> <tr> <td style="text-align: center;">5</td> <td style="text-align: center;">vdir</td> <td rowspan="2">Standard setting</td> <td rowspan="2">HA motor (4 pole motor) Detector installation position 90 degrees (B, D)</td> </tr> <tr> <td style="text-align: center;">6</td> <td style="text-align: center;"></td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">abs</td> <td>Incremental control</td> <td>Absolute position control</td> </tr> <tr> <td style="text-align: center;">8</td> <td style="text-align: center;">mp</td> <td>MP scale 360P (2mm pitch)</td> <td>MP scale 720P (1mm pitch)</td> </tr> <tr> <td style="text-align: center;">9</td> <td style="text-align: center;">mpt3</td> <td>MP scale ABS detection type 1, 2</td> <td>MP scale ABS detection type 3</td> </tr> <tr> <td style="text-align: center;">A</td> <td style="text-align: center;"></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">B</td> <td style="text-align: center;"></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">C</td> <td style="text-align: center;"></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">D</td> <td style="text-align: center;"></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">E</td> <td style="text-align: center;"></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">F</td> <td style="text-align: center;"></td> <td></td> <td></td> </tr> </tbody> </table>	bit		Meaning when "0" is set	Meaning when "1" is set	0	fdir2	Speed feedback forward polarity	Speed feedback reverse polarity	1	dfbx	Dual feedback control stop	Dual feedback control start	2	seqh	READY/Servo ON time normal	READY/Servo ON time high speed	3	spwv	Normal mode	High gain servo synchronous mode	4	fdir	Position feedback forward polarity	Position feedback reverse polarity	5	vdir	Standard setting	HA motor (4 pole motor) Detector installation position 90 degrees (B, D)	6		7	abs	Incremental control	Absolute position control	8	mp	MP scale 360P (2mm pitch)	MP scale 720P (1mm pitch)	9	mpt3	MP scale ABS detection type 1, 2	MP scale ABS detection type 3	A				B				C				D				E				F			
			bit		Meaning when "0" is set	Meaning when "1" is set																																																															
			0	fdir2	Speed feedback forward polarity	Speed feedback reverse polarity																																																															
			1	dfbx	Dual feedback control stop	Dual feedback control start																																																															
			2	seqh	READY/Servo ON time normal	READY/Servo ON time high speed																																																															
			3	spwv	Normal mode	High gain servo synchronous mode																																																															
			4	fdir	Position feedback forward polarity	Position feedback reverse polarity																																																															
			5	vdir	Standard setting	HA motor (4 pole motor) Detector installation position 90 degrees (B, D)																																																															
			6																																																																		
7	abs	Incremental control	Absolute position control																																																																		
8	mp	MP scale 360P (2mm pitch)	MP scale 720P (1mm pitch)																																																																		
9	mpt3	MP scale ABS detection type 1, 2	MP scale ABS detection type 3																																																																		
A																																																																					
B																																																																					
C																																																																					
D																																																																					
E																																																																					
F																																																																					
(Note) Set to "0" for bits with no particular description.																																																																					
2218 (PR)	SV018 PIT	Ball screw pitch	Set the ball screw pitch. Set to "360" for the rotary axis. 1 to 32767 (mm/rev)																																																																		

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

No.	Items	Details	Setting range																													
2219 (PR)	SV019 RNG1	Position detector resolution	In the case of the semi-closed loop control Set the same value as SV020 (RNG2). (Refer to the explanation of SV020.)	1 to 9999 (kp/rev)																												
			In the case of the full-closed loop control Set the number of pulses per ball screw pitch.	1 to 9999 (kp/pit)																												
		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 40%;">Detector model name</th> <th style="width: 30%;">Resolution</th> <th style="width: 30%;">SV019 setting</th> </tr> </thead> <tbody> <tr> <td>OHE25K-ET, OHA25K-ET</td> <td>100,000(p/rev)</td> <td>100</td> </tr> <tr> <td>OSE104-ET, OSA104-ET</td> <td>100,000(p/rev)</td> <td>100</td> </tr> <tr> <td>OSE105-ET, OSA105-ET</td> <td>1,000,000(p/rev)</td> <td>1000</td> </tr> <tr> <td>Relative position detection scale</td> <td>Refer to specification manual for each detector</td> <td>PIT/Resolution (μm)</td> </tr> <tr> <td>AT41 (Mitsutoyo)</td> <td>1 (μm/p)</td> <td>The same as SV018 (PIT)</td> </tr> <tr> <td>FME type, FLE type (Futaba)</td> <td>Refer to specification manual for each detector</td> <td>PIT/Resolution (μm)</td> </tr> <tr> <td>MP type (Mitsubishi Heavy Industries)</td> <td>Refer to specification manual for each detector</td> <td>PIT/Resolution (μm)</td> </tr> <tr> <td>AT342 (Mitsutoyo)</td> <td>0.5 (μm/p)</td> <td>Twice as big as SV018 (PIT)</td> </tr> </tbody> </table>			Detector model name	Resolution	SV019 setting	OHE25K-ET, OHA25K-ET	100,000(p/rev)	100	OSE104-ET, OSA104-ET	100,000(p/rev)	100	OSE105-ET, OSA105-ET	1,000,000(p/rev)	1000	Relative position detection scale	Refer to specification manual for each detector	PIT/Resolution (μm)	AT41 (Mitsutoyo)	1 (μm/p)	The same as SV018 (PIT)	FME type, FLE type (Futaba)	Refer to specification manual for each detector	PIT/Resolution (μm)	MP type (Mitsubishi Heavy Industries)	Refer to specification manual for each detector	PIT/Resolution (μm)	AT342 (Mitsutoyo)	0.5 (μm/p)	Twice as big as SV018 (PIT)	
		Detector model name	Resolution	SV019 setting																												
		OHE25K-ET, OHA25K-ET	100,000(p/rev)	100																												
		OSE104-ET, OSA104-ET	100,000(p/rev)	100																												
		OSE105-ET, OSA105-ET	1,000,000(p/rev)	1000																												
		Relative position detection scale	Refer to specification manual for each detector	PIT/Resolution (μm)																												
		AT41 (Mitsutoyo)	1 (μm/p)	The same as SV018 (PIT)																												
FME type, FLE type (Futaba)	Refer to specification manual for each detector	PIT/Resolution (μm)																														
MP type (Mitsubishi Heavy Industries)	Refer to specification manual for each detector	PIT/Resolution (μm)																														
AT342 (Mitsutoyo)	0.5 (μm/p)	Twice as big as SV018 (PIT)																														
2220 (PR)	SV020 RNG2	Speed detector resolution	Set the number of pulses per one revolution of the motor end detector.	1 to 9999 (kp/rev)																												
					<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 60%;">Detector model name</th> <th style="width: 40%;">SV020 setting</th> </tr> </thead> <tbody> <tr> <td>Equipped to HA053, HA13 (Only for MDS-B-Vx)</td> <td>10</td> </tr> <tr> <td>OHE25K, OHA25K (Only for MDS-B-Vx)</td> <td>100</td> </tr> <tr> <td>OSE104, OSA104</td> <td>100</td> </tr> <tr> <td>OSE105, OSA105</td> <td>1000</td> </tr> </tbody> </table>		Detector model name	SV020 setting	Equipped to HA053, HA13 (Only for MDS-B-Vx)	10	OHE25K, OHA25K (Only for MDS-B-Vx)	100	OSE104, OSA104	100	OSE105, OSA105	1000																
					Detector model name	SV020 setting																										
					Equipped to HA053, HA13 (Only for MDS-B-Vx)	10																										
					OHE25K, OHA25K (Only for MDS-B-Vx)	100																										
OSE104, OSA104	100																															
OSE105, OSA105	1000																															
2221	SV021 OLT	Overload detection time constant	Set the detection time constant of Overload 1 (Alarm 50). Set to "60" as a standard. (For machine tool builder adjustment.)	1 to 999 (s)																												
2222	SV022 OLL	Overload detection level	Set the current detection level of Overload 1 (Alarm 50) in respect to the stall (rated) current. Set to "150" as a standard. (For machine tool builder adjustment.)	110 to 500 (Stall [rated] current %)																												
2223	SV023 OD1	Excessive error detection width during servo ON	Set the excessive error detection width when servo ON. <Standard setting value> $OD1=OD2= \frac{\text{Rapid traverse rate (mm/min)}}{60 \cdot PGN1} / 2 \text{ (mm)}$ When "0" is set, the excessive error detection will not be performed.	0 to 32767 (mm)																												

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

No.	Items	Details	Setting range																																																																																																																																																																																																																																																																																																																																																																																			
2224	SV024 INP	In-position detection width Set the in-position detection width. Set the accuracy required for the machine. The lower the setting is, the higher the positioning accuracy gets, however, the cycle time (setting time) becomes longer. The standard setting is "50".	0 to 32767 (μ m)																																																																																																																																																																																																																																																																																																																																																																																			
2225 (PR)	SV025 MTYP	<table border="1" style="width:100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">F</td><td style="text-align: center;">E</td><td style="text-align: center;">D</td><td style="text-align: center;">C</td><td style="text-align: center;">B</td><td style="text-align: center;">A</td><td style="text-align: center;">9</td><td style="text-align: center;">8</td> </tr> <tr> <td colspan="4" style="text-align: center;">pen</td><td colspan="4" style="text-align: center;">ent</td> </tr> <tr> <td style="text-align: center;">7</td><td style="text-align: center;">6</td><td style="text-align: center;">5</td><td style="text-align: center;">4</td><td style="text-align: center;">3</td><td style="text-align: center;">2</td><td style="text-align: center;">1</td><td style="text-align: center;">0</td> </tr> <tr> <td colspan="8" style="text-align: center;">mtyp</td> </tr> </table> <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 5%;">bit</th> <th colspan="7">Explanation</th> </tr> </thead> <tbody> <tr> <td>0</td> <td colspan="7">Set the motor type.</td> </tr> <tr> <td>1</td> <td style="text-align: center;">Set- ting</td> <td style="text-align: center;">0x</td> <td style="text-align: center;">1x</td> <td style="text-align: center;">2x</td> <td style="text-align: center;">3x</td> <td style="text-align: center;">4x</td> <td style="text-align: center;">5x</td> <td style="text-align: center;">6x</td> <td style="text-align: center;">7x</td> </tr> <tr> <td>2</td> <td>x0</td> <td>HA40N</td> <td></td> <td>HA50L</td> <td>HA53L</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>3</td> <td>x1</td> <td>HA80N</td> <td></td> <td>HA100L</td> <td>HA103L</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>4</td> <td>x2</td> <td>HA100N</td> <td></td> <td>HA200L</td> <td>HA203L</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>5</td> <td>x3</td> <td>HA200N</td> <td></td> <td>HA300L</td> <td>HA303L</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>6</td> <td>x4</td> <td>HA300N</td> <td></td> <td>HA500L</td> <td>HA503L</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>7</td> <td>x5</td> <td>HA700N</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>x6</td> <td>HA900N</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>x7</td> <td></td> <td></td> <td>HA-LH11K2</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>x8</td> <td></td> <td></td> <td>HA-LH15K2</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>x9</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>xA</td> <td></td> <td></td> <td>HA150L</td> <td>HA153L</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>xB</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>xC</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>xD</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>xE</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>xF</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 5%;">Set- ting</th> <th style="width: 10%;">8x</th> <th style="width: 10%;">9x</th> <th style="width: 10%;">Ax</th> <th style="width: 10%;">Bx</th> <th style="width: 10%;">Cx</th> <th style="width: 10%;">Dx</th> <th style="width: 10%;">Ex</th> <th style="width: 10%;">Fx</th> </tr> </thead> <tbody> <tr> <td>x0</td> <td>HA43N</td> <td></td> <td></td> <td>HC52</td> <td>HC53</td> <td></td> <td></td> <td></td> </tr> <tr> <td>x1</td> <td>HA83N</td> <td></td> <td></td> <td>HC102</td> <td>HC103</td> <td></td> <td>HC103R</td> <td></td> </tr> <tr> <td>x2</td> <td>HA103N</td> <td></td> <td></td> <td>HC152</td> <td>HC153</td> <td></td> <td>HC153R</td> <td></td> </tr> <tr> <td>x3</td> <td>HA203N</td> <td></td> <td></td> <td>HC202</td> <td>HC203</td> <td></td> <td>HC203R</td> <td></td> </tr> <tr> <td>x4</td> <td>HA303N</td> <td></td> <td></td> <td>HC352</td> <td>HC353</td> <td></td> <td>HC353R</td> <td></td> </tr> <tr> <td>x5</td> <td>HA703N</td> <td></td> <td></td> <td>HC452</td> <td>HC453</td> <td></td> <td>HC503R</td> <td></td> </tr> <tr> <td>x6</td> <td></td> <td></td> <td></td> <td>HC702</td> <td>HC703</td> <td></td> <td></td> <td></td> </tr> <tr> <td>x7</td> <td></td> <td></td> <td></td> <td>HC902</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>x8</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>x9</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>xA</td> <td>HA93N</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>xB</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>xC</td> <td>HA053(N)</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>xD</td> <td>HA13(N)</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>xE</td> <td>HA23N</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>xF</td> <td>HA33N</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <p align="right">(To be continued to the next page)</p>	F	E	D	C	B	A	9	8	pen				ent				7	6	5	4	3	2	1	0	mtyp								bit	Explanation							0	Set the motor type.							1	Set- ting	0x	1x	2x	3x	4x	5x	6x	7x	2	x0	HA40N		HA50L	HA53L					3	x1	HA80N		HA100L	HA103L					4	x2	HA100N		HA200L	HA203L					5	x3	HA200N		HA300L	HA303L					6	x4	HA300N		HA500L	HA503L					7	x5	HA700N									x6	HA900N									x7			HA-LH11K2							x8			HA-LH15K2							x9										xA			HA150L	HA153L						xB										xC										xD										xE										xF									Set- ting	8x	9x	Ax	Bx	Cx	Dx	Ex	Fx	x0	HA43N			HC52	HC53				x1	HA83N			HC102	HC103		HC103R		x2	HA103N			HC152	HC153		HC153R		x3	HA203N			HC202	HC203		HC203R		x4	HA303N			HC352	HC353		HC353R		x5	HA703N			HC452	HC453		HC503R		x6				HC702	HC703				x7				HC902					x8									x9									xA	HA93N								xB									xC	HA053(N)								xD	HA13(N)								xE	HA23N								xF	HA33N								
F	E	D	C	B	A	9	8																																																																																																																																																																																																																																																																																																																																																																															
pen				ent																																																																																																																																																																																																																																																																																																																																																																																		
7	6	5	4	3	2	1	0																																																																																																																																																																																																																																																																																																																																																																															
mtyp																																																																																																																																																																																																																																																																																																																																																																																						
bit	Explanation																																																																																																																																																																																																																																																																																																																																																																																					
0	Set the motor type.																																																																																																																																																																																																																																																																																																																																																																																					
1	Set- ting	0x	1x	2x	3x	4x	5x	6x	7x																																																																																																																																																																																																																																																																																																																																																																													
2	x0	HA40N		HA50L	HA53L																																																																																																																																																																																																																																																																																																																																																																																	
3	x1	HA80N		HA100L	HA103L																																																																																																																																																																																																																																																																																																																																																																																	
4	x2	HA100N		HA200L	HA203L																																																																																																																																																																																																																																																																																																																																																																																	
5	x3	HA200N		HA300L	HA303L																																																																																																																																																																																																																																																																																																																																																																																	
6	x4	HA300N		HA500L	HA503L																																																																																																																																																																																																																																																																																																																																																																																	
7	x5	HA700N																																																																																																																																																																																																																																																																																																																																																																																				
	x6	HA900N																																																																																																																																																																																																																																																																																																																																																																																				
	x7			HA-LH11K2																																																																																																																																																																																																																																																																																																																																																																																		
	x8			HA-LH15K2																																																																																																																																																																																																																																																																																																																																																																																		
	x9																																																																																																																																																																																																																																																																																																																																																																																					
	xA			HA150L	HA153L																																																																																																																																																																																																																																																																																																																																																																																	
	xB																																																																																																																																																																																																																																																																																																																																																																																					
	xC																																																																																																																																																																																																																																																																																																																																																																																					
	xD																																																																																																																																																																																																																																																																																																																																																																																					
	xE																																																																																																																																																																																																																																																																																																																																																																																					
	xF																																																																																																																																																																																																																																																																																																																																																																																					
Set- ting	8x	9x	Ax	Bx	Cx	Dx	Ex	Fx																																																																																																																																																																																																																																																																																																																																																																														
x0	HA43N			HC52	HC53																																																																																																																																																																																																																																																																																																																																																																																	
x1	HA83N			HC102	HC103		HC103R																																																																																																																																																																																																																																																																																																																																																																															
x2	HA103N			HC152	HC153		HC153R																																																																																																																																																																																																																																																																																																																																																																															
x3	HA203N			HC202	HC203		HC203R																																																																																																																																																																																																																																																																																																																																																																															
x4	HA303N			HC352	HC353		HC353R																																																																																																																																																																																																																																																																																																																																																																															
x5	HA703N			HC452	HC453		HC503R																																																																																																																																																																																																																																																																																																																																																																															
x6				HC702	HC703																																																																																																																																																																																																																																																																																																																																																																																	
x7				HC902																																																																																																																																																																																																																																																																																																																																																																																		
x8																																																																																																																																																																																																																																																																																																																																																																																						
x9																																																																																																																																																																																																																																																																																																																																																																																						
xA	HA93N																																																																																																																																																																																																																																																																																																																																																																																					
xB																																																																																																																																																																																																																																																																																																																																																																																						
xC	HA053(N)																																																																																																																																																																																																																																																																																																																																																																																					
xD	HA13(N)																																																																																																																																																																																																																																																																																																																																																																																					
xE	HA23N																																																																																																																																																																																																																																																																																																																																																																																					
xF	HA33N																																																																																																																																																																																																																																																																																																																																																																																					

7.3 7. SERVO PARAMETERS
MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

No.	Items	Details	Setting range																																																																																	
		<p>(Continued from the previous page)</p> <table border="1" data-bbox="539 293 1414 1805"> <thead> <tr> <th data-bbox="539 293 651 327">bit</th> <th colspan="3" data-bbox="651 293 1414 327">Explanation</th> </tr> </thead> <tbody> <tr> <td data-bbox="539 327 587 360">8</td> <td data-bbox="587 327 651 360" rowspan="5">ent</td> <td colspan="2" data-bbox="651 327 1414 360" rowspan="5">Set the detector type. Set position detector type for "pen", and speed detector type for "ent". In the case of the semi-closed loop control, set the same value for "pen" and "ent".</td> </tr> <tr> <td data-bbox="539 360 587 394">9</td> </tr> <tr> <td data-bbox="539 394 587 427">A</td> </tr> <tr> <td data-bbox="539 427 587 461">B</td> </tr> <tr> <td data-bbox="539 461 587 495">C</td> </tr> <tr> <td data-bbox="539 495 587 528">D</td> <td data-bbox="587 495 651 528" rowspan="8">pen</td> <td data-bbox="651 461 826 495">pen setting</td> <td data-bbox="826 461 995 495">ent setting</td> <td data-bbox="995 461 1414 495">Detector model name</td> </tr> <tr> <td data-bbox="539 528 587 562">E</td> <td data-bbox="651 495 826 528">0</td> <td data-bbox="826 495 995 528">0</td> <td data-bbox="995 495 1414 528">OHE25K (Only for MDS-B-Vx), OSE104</td> </tr> <tr> <td data-bbox="539 562 587 595">F</td> <td data-bbox="651 528 826 562">1</td> <td data-bbox="826 528 995 562">1</td> <td data-bbox="995 528 1414 562">OHA25K (Only for MDS-B-Vx), OSA104</td> </tr> <tr> <td data-bbox="539 595 587 629"></td> <td data-bbox="651 562 826 595">2</td> <td data-bbox="826 562 995 595">2</td> <td data-bbox="995 562 1414 595">OSE105, OSA105</td> </tr> <tr> <td data-bbox="539 629 587 663"></td> <td data-bbox="651 595 826 629">3</td> <td data-bbox="826 595 995 629">3</td> <td data-bbox="995 595 1414 629">Equipped to HA053, HA13 (Only for MDS-B-Vx)</td> </tr> <tr> <td data-bbox="539 663 587 696"></td> <td data-bbox="651 629 826 663">4</td> <td data-bbox="826 629 995 663">Setting impossible</td> <td data-bbox="995 629 1414 663">OHE25K-ET, OSE104-ET</td> </tr> <tr> <td data-bbox="539 696 587 730"></td> <td data-bbox="651 663 826 696">5</td> <td data-bbox="826 663 995 696">Setting impossible</td> <td data-bbox="995 663 1414 696">OHA25K-ET, OSA104-ET</td> </tr> <tr> <td data-bbox="539 730 587 763"></td> <td data-bbox="651 696 826 730">6</td> <td data-bbox="826 696 995 730">Setting impossible</td> <td data-bbox="995 696 1414 730">OSE105-ET, OSA105-ET</td> </tr> <tr> <td data-bbox="539 763 587 797"></td> <td data-bbox="651 730 826 763">7</td> <td data-bbox="826 730 995 763">Setting impossible</td> <td data-bbox="995 730 1414 763"></td> </tr> <tr> <td data-bbox="539 797 587 831"></td> <td data-bbox="651 763 826 797">8</td> <td data-bbox="826 763 995 797">Setting impossible</td> <td data-bbox="995 763 1414 797">Relative position detection scale, MP type (Mitsubishi Heavy Industries)</td> </tr> <tr> <td data-bbox="539 831 587 864"></td> <td data-bbox="651 797 826 831">9</td> <td data-bbox="826 797 995 831">Setting impossible</td> <td data-bbox="995 797 1414 831">AT41 (Mitsutoyo), FME type, FLE type (Futaba)</td> </tr> <tr> <td data-bbox="539 864 587 898"></td> <td data-bbox="651 831 826 864">A</td> <td data-bbox="826 831 995 864">Setting impossible</td> <td data-bbox="995 831 1414 864">AT342 (Mitsutoyo)</td> </tr> <tr> <td data-bbox="539 898 587 931"></td> <td data-bbox="651 864 826 898">B</td> <td data-bbox="826 864 995 898">Setting impossible</td> <td data-bbox="995 864 1414 898"></td> </tr> <tr> <td data-bbox="539 931 587 965"></td> <td data-bbox="651 898 826 931">C</td> <td data-bbox="826 898 995 931">C (Current synchronization)</td> <td data-bbox="995 898 1414 931">The setting of the slave axis in the speed/current synchronization control. When the master axis is the semi-closed control.</td> </tr> <tr> <td data-bbox="539 965 587 999"></td> <td data-bbox="651 931 826 965">D</td> <td data-bbox="826 931 995 965">Setting impossible</td> <td data-bbox="995 931 1414 965"></td> </tr> <tr> <td data-bbox="539 999 587 1032"></td> <td data-bbox="651 965 826 999">E</td> <td data-bbox="826 965 995 999">Setting impossible</td> <td data-bbox="995 965 1414 999"></td> </tr> <tr> <td data-bbox="539 1032 587 1066"></td> <td data-bbox="651 999 826 1032">F</td> <td data-bbox="826 999 995 1032">Setting impossible</td> <td data-bbox="995 999 1414 1032"></td> </tr> </tbody> </table>	bit	Explanation			8	ent	Set the detector type. Set position detector type for "pen", and speed detector type for "ent". In the case of the semi-closed loop control, set the same value for "pen" and "ent".		9	A	B	C	D	pen	pen setting	ent setting	Detector model name	E	0	0	OHE25K (Only for MDS-B-Vx), OSE104	F	1	1	OHA25K (Only for MDS-B-Vx), OSA104		2	2	OSE105, OSA105		3	3	Equipped to HA053, HA13 (Only for MDS-B-Vx)		4	Setting impossible	OHE25K-ET, OSE104-ET		5	Setting impossible	OHA25K-ET, OSA104-ET		6	Setting impossible	OSE105-ET, OSA105-ET		7	Setting impossible			8	Setting impossible	Relative position detection scale, MP type (Mitsubishi Heavy Industries)		9	Setting impossible	AT41 (Mitsutoyo), FME type, FLE type (Futaba)		A	Setting impossible	AT342 (Mitsutoyo)		B	Setting impossible			C	C (Current synchronization)	The setting of the slave axis in the speed/current synchronization control. When the master axis is the semi-closed control.		D	Setting impossible			E	Setting impossible			F	Setting impossible		
bit	Explanation																																																																																			
8	ent	Set the detector type. Set position detector type for "pen", and speed detector type for "ent". In the case of the semi-closed loop control, set the same value for "pen" and "ent".																																																																																		
9																																																																																				
A																																																																																				
B																																																																																				
C																																																																																				
D	pen	pen setting	ent setting	Detector model name																																																																																
E		0	0	OHE25K (Only for MDS-B-Vx), OSE104																																																																																
F		1	1	OHA25K (Only for MDS-B-Vx), OSA104																																																																																
		2	2	OSE105, OSA105																																																																																
		3	3	Equipped to HA053, HA13 (Only for MDS-B-Vx)																																																																																
		4	Setting impossible	OHE25K-ET, OSE104-ET																																																																																
		5	Setting impossible	OHA25K-ET, OSA104-ET																																																																																
		6	Setting impossible	OSE105-ET, OSA105-ET																																																																																
	7	Setting impossible																																																																																		
	8	Setting impossible	Relative position detection scale, MP type (Mitsubishi Heavy Industries)																																																																																	
	9	Setting impossible	AT41 (Mitsutoyo), FME type, FLE type (Futaba)																																																																																	
	A	Setting impossible	AT342 (Mitsutoyo)																																																																																	
	B	Setting impossible																																																																																		
	C	C (Current synchronization)	The setting of the slave axis in the speed/current synchronization control. When the master axis is the semi-closed control.																																																																																	
	D	Setting impossible																																																																																		
	E	Setting impossible																																																																																		
	F	Setting impossible																																																																																		
2226	SV026 OD2	<p>Excessive error detection width during servo OFF</p> <p>Set the excessive error detection width when servo OFF. For the standard setting, refer to the explanation of SV023 (OD1). When "0" is set, the excessive error detection will not be performed.</p>	0 to 32767 (mm)																																																																																	

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

No.	Items	Details	Setting range																																
2227	SV027 SSF1 Servo function selection 1	<table style="margin: auto; border-collapse: collapse;"> <tr> <td style="border: 1px solid black; padding: 2px;">F</td> <td style="border: 1px solid black; padding: 2px;">E</td> <td style="border: 1px solid black; padding: 2px;">D</td> <td style="border: 1px solid black; padding: 2px;">C</td> <td style="border: 1px solid black; padding: 2px;">B</td> <td style="border: 1px solid black; padding: 2px;">A</td> <td style="border: 1px solid black; padding: 2px;">9</td> <td style="border: 1px solid black; padding: 2px;">8</td> </tr> <tr> <td style="border: 1px solid black; padding: 2px;">aflt</td> <td style="border: 1px solid black; padding: 2px;">zrn2</td> <td colspan="2" style="border: 1px solid black; padding: 2px;">afse</td> <td colspan="2" style="border: 1px solid black; padding: 2px;">ovs</td> <td colspan="2" style="border: 1px solid black; padding: 2px;">lmc</td> </tr> <tr> <td style="border: 1px solid black; padding: 2px;">7</td> <td style="border: 1px solid black; padding: 2px;">6</td> <td style="border: 1px solid black; padding: 2px;">5</td> <td style="border: 1px solid black; padding: 2px;">4</td> <td style="border: 1px solid black; padding: 2px;">3</td> <td style="border: 1px solid black; padding: 2px;">2</td> <td style="border: 1px solid black; padding: 2px;">1</td> <td style="border: 1px solid black; padding: 2px;">0</td> </tr> <tr> <td colspan="2" style="border: 1px solid black; padding: 2px;"></td> <td style="border: 1px solid black; padding: 2px;">zrn3</td> <td colspan="2" style="border: 1px solid black; padding: 2px;">vfct</td> <td style="border: 1px solid black; padding: 2px;">upc</td> <td colspan="2" style="border: 1px solid black; padding: 2px;">vcnt</td> </tr> </table>	F	E	D	C	B	A	9	8	aflt	zrn2	afse		ovs		lmc		7	6	5	4	3	2	1	0			zrn3	vfct		upc	vcnt		
		F	E	D	C	B	A	9	8																										
		aflt	zrn2	afse		ovs		lmc																											
		7	6	5	4	3	2	1	0																										
				zrn3	vfct		upc	vcnt																											
		bit	Meaning when "0" is set	Meaning when "1" is set																															
		0	vcnt	Set the execution changeover type of the speed loop delay compensation.																															
		1	00: Delay compensation changeover invalid 01: Delay compensation changeover type 1 10: Delay compensation type 2 11: Setting prohibited																																
		2	upc	Start torque compensation invalid	Start torque compensation valid																														
		3																																	
		4	vfct	Set the number of compensation pulses of the jitter compensation.																															
		5	00: Jitter compensation invalid 01: Jitter compensation 1 pulse 10: Jitter compensation 2 pulses 11: Jitter compensation 3 pulses																																
		6	zrn3	ABS scale: Set to "1" in using AT342, AT343, LC191M/491M.																															
		7																																	
		8	lmc	Set the compensation amount with SV016 (LMC1) and SV041 (LMC2).																															
9	00: Lost motion compensation stop 01: Lost motion compensation type 1 10: Lost motion compensation type 2 11: Setting prohibited																																		
A	ovs	Set the compensation amount with SV031 (OVS1) and SV042 (OVS2).																																	
B	00: Overshooting compensation stop 01: Overshooting compensation type 1 10: Overshooting compensation type 2 11: Overshooting compensation type 3																																		
C	00: Adoptive filter sensitivity standard																																		
D	afse	11: Adoptive filter sensitivity increase (Set 2bits at a time)																																	
E	zrn2	Set to "1".																																	
F	aflt	Adoptive filter stops	Adoptive filter starts																																
(Note) Set to "0" for bits with no particular description.																																			
2228	SV028	Not used. Set to "0".		0																															
2229	SV029 VCS	Speed at the change of speed loop gain	If the noise is bothersome at high speed during rapid traverse, etc, lower the speed loop gain. Set the speed at which the speed loop gain changes, and use this with SV006 (VGN2). (Refer to SV006.) When not using, set to "0".	0 to 9999 (r/min)																															

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

No.	Items	Details	Setting range	
2230		The higher order 8bits and lower order 8bits are used for different functions. "The setting value of SV030" = (lcx*256) + IVC	0 to 32767	
	SV030 IVC (Low order)	Voltage dead time compensation	When 100% is set, the voltage equivalent to the logical non-energized time will be compensated. When "0" is set, a 100% compensation will be performed. Adjust in increments of 10% from the default value 100%. If increased too much, vibration or vibration noise may be generated.	0 to 255 (%)
	SV030 lcx (High order)	Current bias 1	Set to "0" as a standard. Use this in combination with SV040 and the high order 8bits of SV045.	0 to 127
2231	SV031 OVS1	Overshooting compensation 1	Set this if overshooting occurs during positioning. This compensates the motor torque during positioning. This is valid only when the overshooting compensation SV027 (SSF1/ovs) is selected.	-1 to 100 (Stall [rated] current%)
			Type 1: When SV027 (SSF1)/ bitB, A (ovs)=01 Set the compensation amount based on the motor's stall current. This compensates overshooting that occurs during pulse feeding. Normally, use Type 2.	
			Type 2: When SV027 (SSF1)/ bitB, A (ovs)=10 Set the compensation amount based on the motor's stall current. Increase by 1% and determine the amount that overshooting doesn't occur. In Type 2, compensation during the feed forward control during circular cutting won't be performed.	
			Type 3: When SV027 (SSF1)/ bitB, A (ovs)=11 Use this to perform the overshooting compensation during circular cutting or the feed forward control. The setting method is the same in Type 2.	
			When you wish different compensation amount depending on the direction When SV042 (OVS2) is "0", compensate with the value of SV031 (OVS1) in both of the + and -directions. If you wish to change the compensation amount depending on the command direction, set this and SV042 (OVS2). (SV031: + direction, SV042: - direction. However, the directions may be opposite depending on other settings.) When "-1" is set, the compensation won't be performed in the direction of the command.	

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

No.	Items	Details	Setting range																																																																																																																				
2232	SV032 TOF	Torque offset	Set the unbalance torque of vertical axis and inclined axis.	-100 to 100 (Stall [rated] current %)																																																																																																																			
2233	SV033 SSF2	Servo function selection 2	<table style="width: 100%; border-collapse: collapse; margin-bottom: 10px;"> <tr> <td style="width: 12.5%; text-align: center;">F</td> <td style="width: 12.5%; text-align: center;">E</td> <td style="width: 12.5%; text-align: center;">D</td> <td style="width: 12.5%; text-align: center;">C</td> <td style="width: 12.5%; text-align: center;">B</td> <td style="width: 12.5%; text-align: center;">A</td> <td style="width: 12.5%; text-align: center;">9</td> <td style="width: 12.5%; text-align: center;">8</td> </tr> <tr> <td colspan="6" style="text-align: center; border: 1px solid black;">dos</td> <td style="text-align: center; border: 1px solid black;">hvx</td> <td style="text-align: center; border: 1px solid black;">svx</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td colspan="4" style="text-align: center; border: 1px solid black;">fhz2</td> <td colspan="3" style="text-align: center; border: 1px solid black;">nfd</td> <td style="text-align: center; border: 1px solid black;">zck</td> </tr> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">bit</th> <th style="width: 15%;">Meaning when "0" is set</th> <th style="width: 75%;">Meaning when "1" is set</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>zck</td> <td>Z phase check valid (Alarm 42)</td> <td>Z phase check invalid</td> </tr> <tr> <td>1</td> <td rowspan="4">nfd1</td> <td colspan="2">Set the filter depth for Notch filter 1 (SV038).</td> </tr> <tr> <td>2</td> <td>Value</td> <td>000 001 010 011 100 101 110 111</td> </tr> <tr> <td>3</td> <td>Depth (dB)</td> <td>Infntly deep -18.1 -12.0 -8.5 -6.0 -4.1 -2.5 -1.2</td> </tr> <tr> <td></td> <td></td> <td>Deep ←</td> <td>→ Shallow</td> </tr> <tr> <td>4</td> <td rowspan="4">fhz2</td> <td colspan="2">Set the operation frequency of Notch filter 2.</td> </tr> <tr> <td>5</td> <td>0: Invalid</td> <td>3: 750Hz</td> <td>6: 375Hz</td> </tr> <tr> <td>6</td> <td>1: 2250Hz</td> <td>4: 563Hz</td> <td>7: 321Hz</td> </tr> <tr> <td>7</td> <td>2: 1125Hz</td> <td>5: 450Hz</td> <td>8 to F: 281Hz</td> </tr> <tr> <td>8</td> <td>svx</td> <td colspan="2" rowspan="2">Set the performance mode of the servo control. (Only for MDS-C1-Vx)</td> </tr> <tr> <td>9</td> <td>hvx</td> </tr> <tr> <td></td> <td></td> <td colspan="2">00: By current loop gain</td> </tr> <tr> <td></td> <td></td> <td colspan="2">01: MDS-B-Vx compatible mode selected</td> </tr> <tr> <td></td> <td></td> <td colspan="2">10: High gain mode selected</td> </tr> <tr> <td></td> <td></td> <td colspan="2">11: High gain mode selected</td> </tr> <tr> <td>A</td> <td></td> <td colspan="2"></td> </tr> <tr> <td>B</td> <td></td> <td colspan="2"></td> </tr> <tr> <td>C</td> <td></td> <td colspan="2">Digital signal output selection</td> </tr> <tr> <td>D</td> <td rowspan="4">dos</td> <td colspan="2">0 : MP scale absolute position detection, offset demand signal output</td> </tr> <tr> <td>E</td> <td colspan="2">1 : Specified speed signal output</td> </tr> <tr> <td>F</td> <td colspan="2">2 to F : Setting prohibited</td> </tr> <tr> <td></td> <td colspan="2"></td> </tr> </tbody> </table> <p>(Note) Set to "0" for bits with no particular description.</p>	F	E	D	C	B	A	9	8	dos						hvx	svx	7	6	5	4	3	2	1	0	fhz2				nfd			zck	bit	Meaning when "0" is set	Meaning when "1" is set	0	zck	Z phase check valid (Alarm 42)	Z phase check invalid	1	nfd1	Set the filter depth for Notch filter 1 (SV038).		2	Value	000 001 010 011 100 101 110 111	3	Depth (dB)	Infntly deep -18.1 -12.0 -8.5 -6.0 -4.1 -2.5 -1.2			Deep ←	→ Shallow	4	fhz2	Set the operation frequency of Notch filter 2.		5	0: Invalid	3: 750Hz	6: 375Hz	6	1: 2250Hz	4: 563Hz	7: 321Hz	7	2: 1125Hz	5: 450Hz	8 to F: 281Hz	8	svx	Set the performance mode of the servo control. (Only for MDS-C1-Vx)		9	hvx			00: By current loop gain				01: MDS-B-Vx compatible mode selected				10: High gain mode selected				11: High gain mode selected		A				B				C		Digital signal output selection		D	dos	0 : MP scale absolute position detection, offset demand signal output		E	1 : Specified speed signal output		F	2 to F : Setting prohibited				
F	E	D	C	B	A	9	8																																																																																																																
dos						hvx	svx																																																																																																																
7	6	5	4	3	2	1	0																																																																																																																
fhz2				nfd			zck																																																																																																																
bit	Meaning when "0" is set	Meaning when "1" is set																																																																																																																					
0	zck	Z phase check valid (Alarm 42)	Z phase check invalid																																																																																																																				
1	nfd1	Set the filter depth for Notch filter 1 (SV038).																																																																																																																					
2		Value	000 001 010 011 100 101 110 111																																																																																																																				
3		Depth (dB)	Infntly deep -18.1 -12.0 -8.5 -6.0 -4.1 -2.5 -1.2																																																																																																																				
			Deep ←	→ Shallow																																																																																																																			
4	fhz2	Set the operation frequency of Notch filter 2.																																																																																																																					
5		0: Invalid	3: 750Hz	6: 375Hz																																																																																																																			
6		1: 2250Hz	4: 563Hz	7: 321Hz																																																																																																																			
7		2: 1125Hz	5: 450Hz	8 to F: 281Hz																																																																																																																			
8	svx	Set the performance mode of the servo control. (Only for MDS-C1-Vx)																																																																																																																					
9	hvx																																																																																																																						
		00: By current loop gain																																																																																																																					
		01: MDS-B-Vx compatible mode selected																																																																																																																					
		10: High gain mode selected																																																																																																																					
		11: High gain mode selected																																																																																																																					
A																																																																																																																							
B																																																																																																																							
C		Digital signal output selection																																																																																																																					
D	dos	0 : MP scale absolute position detection, offset demand signal output																																																																																																																					
E		1 : Specified speed signal output																																																																																																																					
F		2 to F : Setting prohibited																																																																																																																					

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

No.	Items	Details	Setting range																																
2234	SV034 SSF3 Servo function selection 3	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">F</td> <td style="text-align: center;">E</td> <td style="text-align: center;">D</td> <td style="text-align: center;">C</td> <td style="text-align: center;">B</td> <td style="text-align: center;">A</td> <td style="text-align: center;">9</td> <td style="text-align: center;">8</td> </tr> <tr> <td colspan="8" style="text-align: center; border: 1px solid black;">ovsn</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black; text-align: center;">os2</td> <td style="border: 1px solid black; text-align: center;">zeg</td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black; text-align: center;">has2</td> <td style="border: 1px solid black; text-align: center;">has1</td> </tr> </table>	F	E	D	C	B	A	9	8	ovsn								7	6	5	4	3	2	1	0		os2	zeg				has2	has1	
		F	E	D	C	B	A	9	8																										
		ovsn																																	
		7	6	5	4	3	2	1	0																										
			os2	zeg				has2	has1																										
		bit	Meaning when "0" is set	Meaning when "1" is set																															
		0 has1	Setting for normal use (Except for HC)	HAS control 1 valid (HC: High acceleration rate support)																															
		1 has2	Setting for normal use (Except for HC)	HAS control 2 valid (HC: Overshooting support)																															
		2																																	
		3																																	
4																																			
5 zeg	Z phase normal edge detection (Setting for normal use)	Z phase reverse edge detection (Valid only when SV027/bit6=1)																																	
6 os2	Setting for normal use	Overspeed detection level changeover																																	
7																																			
8																																			
9																																			
A																																			
B																																			
C	Set the non-sensitive band of the overshooting compensation type 3 in increments of 2μm at a time.																																		
D	In the feed forward control, the non-sensitive band of the model position droop is set, and overshooting of the model is ignored.																																		
E ovsn	Set the same value as the standard SV040.																																		
F	Set the same value as the standard SV040.																																		
(Note) Set to "0" for bits with no particular description.																																			

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

No.	Items	Details	Setting range																																
2235	SV035 SSF4 Servo function selection4	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 12.5%; text-align: center;">F</td> <td style="width: 12.5%; text-align: center;">E</td> <td style="width: 12.5%; text-align: center;">D</td> <td style="width: 12.5%; text-align: center;">C</td> <td style="width: 12.5%; text-align: center;">B</td> <td style="width: 12.5%; text-align: center;">A</td> <td style="width: 12.5%; text-align: center;">9</td> <td style="width: 12.5%; text-align: center;">8</td> </tr> <tr> <td style="border: 1px solid black; text-align: center;">clt</td> <td colspan="3" style="border: 1px solid black; text-align: center;">clG1</td> <td style="border: 1px solid black; text-align: center;">cl2n</td> <td style="border: 1px solid black; text-align: center;">clet</td> <td colspan="2" style="border: 1px solid black; text-align: center;">cltq</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td colspan="2" style="border: 1px solid black; text-align: center;">iup</td> <td colspan="6" style="border: 1px solid black; text-align: center;">tdt</td> </tr> </table>	F	E	D	C	B	A	9	8	clt	clG1			cl2n	clet	cltq		7	6	5	4	3	2	1	0	iup		tdt						
		F	E	D	C	B	A	9	8																										
		clt	clG1			cl2n	clet	cltq																											
		7	6	5	4	3	2	1	0																										
		iup		tdt																															
		bit	Meaning when "0" is set	Meaning when "1" is set																															
		0	Td creation time setting																																
		1	Set to "0". (For machine tool builder adjustment)																																
		2	tdt																																
		3																																	
4																																			
5																																			
6	iup	Set to "1" in the case of any motors from HC152 to HC702 and from HC153 to HC453.																																	
7																																			
8	cltq	Set the retracting torque for collision detection in respect to the maximum torque of the motor.																																	
9		00: 100% 01: 90% 10: 80% (Standard) 11: 70%																																	
A	clet	Setting for normal use	The disturbance torque peak of the latest two seconds is displayed in MPOS of the servo monitor screen.																																
B	cl2n	Collision detection method 2 valid	Collision detection method 2 invalid																																
C	clG1	Collision detection method 1																																	
D		Set the collision detection level during cutting feed (G1).																																	
E		The G1 collision detection level=SV060*clG1. When clG1=0, the collision detection method 1 during cutting feed won't function.																																	
F	clt	Setting for normal use	The guide value of the SV059 setting value is displayed in MPOS of the servo monitor screen.																																
(Note) Set to "0" for bits with no particular description.																																			

7.3 7. SERVO PARAMETERS
MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

No.	Items	Details						Setting range													
		F	E	D	C	B	A	9	8												
2236 (PR)	SV036 PTYP	Power supply type	amp			rtyp															
			7	6	5	4	3	2	1	0											
			ptyp																		
			bit	Explanation																	
			0	When the CN4 connector of the drive unit and the power supply are connected, setting below is necessary. To validate the external emergency stop function, add 40h.																	
			1																		
			2																		
			3									Set-ting	0x	1x	2x	3x	4x	5x	6x	7x	8x
			4									x0	Not used			CV-300					
			5									x1		CV-110							CR-10
6	x2											CV-220						CR-15			
7	x3																	CR-22			
	x4	CV-37																CR-37			
	x5		CV-150											CV-450	CV-550						
	x6	CV-55		CV-260						CR-55											
	x7				CV-370																
	x8	CV-75								CR-75											
	x9		CV-185							CR-90											
8	rtyp	Set the regenerative resistor type when MDS-A-CR is used.																			
9		Set-ting	Regenerative resistor model name			Resistance value		Capacity													
A		0	MDS-C1-CV (Setting when using power supply regeneration)																		
B		1	GZG200W260HMJ			26Ω		80W													
		2	GZG300W130HMJ×2			26Ω		150W													
		3	MR-RB30			13Ω		300W													
		4	MR-RB50			13Ω		500W													
		5	GZG200W200HMJ×3			6.7Ω		350W													
		6	GZG300W200HMJ×3			6.7Ω		500W													
		7	R-UNIT-1			30Ω		700W													
	8	R-UNIT-2			15Ω		700W														
	9	R-UNIT-3			15Ω		2100W														
A to F	No setting																				
C	amp	Always set to "0".																			
D																					
E																					
F																					

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

No.	Items	Details	Setting range
2237	SV037 JL	Load inertia scale $SV037 (JL) = \frac{Jl+Jm}{Jm} *100$ Jm: Motor inertia Jl: Motor axis conversion load inertia	0 to 5000 (%)
2238	SV038 FHz1	Notch filter frequency 1 Set the vibration frequency to suppress if machine vibration occurs. (Valid at 72 or more) When not using, set to "0".	0 to 3000 (Hz)
2239	SV039 LMCD	Lost motion compensation timing Set this when the lost motion compensation timing does not match. Adjust by increasing the value by 10 at a time.	0 to 2000 (ms)
2240	The higher order 8bits and lower order 8bits are used for different functions. "Setting value of SV040" = (Icy*256) + LMCT		0 to 32767
	SV040 LMCT (Low order)	Lost motion compensation non-sensitive band Set the non-sensitive band of the lost motion compensation in the feed forward control. When "0" is set, the actual value that is set is 2μm. Adjust by increasing by 1μm at a time.	0 to 100 (μm)
	SV040 Icy (High order)	Current bias 2 Normally, set to "40" if you use HC202 to HC902, HC203 to HC703. Use this in combination with SV030 and the high order 8bits of SV045.	0 to 127
2241	SV041 LMC2	Lost motion compensation 2 Set this with SV016 (LMC1) only when you wish to set the lost motion compensation amount to be different depending on the command directions. Set to "0" as a standard.	-1 to 200 (Stall [rated] current %)
2242	SV042 OVS2	Overshooting compensation 2 Set this with SV031 (OVS1) only when you wish to set the overshooting compensation amount to be different depending on the command directions. Set to "0" as a standard.	-1 to 100 (Stall [rated] current %)
2243	SV043 OBS1	Disturbance observer filter frequency Set the disturbance observer filter band. Set to "100" as a standard. To use the disturbance observer, also set SV037 (JL) and SV044 (OBS2). When not using, set to "0".	0 to 1000 (rad/s)
2244	SV044 OBS2	Disturbance observer gain Set the disturbance observer gain. The standard setting is "100" to "300". To use the disturbance observer, also set SV037 (JL) and SV043 (OBS1). When not using, set to "0".	0 to 500 (%)
2245	The higher order 8bits and lower order 8bits are used for different functions. "Setting value of SV045" = (Ib1*256) + TRUB		0 to 32767
	SV045 TRUB (Low order)	Frictional torque When you use the collision detection function, set the frictional torque.	0 to 100 (Stall [rated] current %)
	SV045 Ib1 (High order)	Current bias 3 Set to "0" as a standard. Use this in combination with SV030 and the high order 8bits of SV040.	0 to 127

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

No.	Items	Details	Setting range
2246	SV046		Not used. Set to "0". 0
2247	SV047 EC	Inductive voltage compensation gain	Set the inductive voltage compensation gain. Set to "100" as a standard. If the current FB peak exceeds the current command peak, lower the gain. 0 to 200 (%)
2248	SV048 EMGr	Vertical axis drop prevention time	Input a length of time to prevent the vertical axis from dropping by delaying Ready OFF until the brake works when the emergency stop occurs. Increase the setting by 100ms at a time and set the value where the axis does not drop. 0 to 20000 (ms)
2249	SV049 PGN1sp	Position loop gain 1 in spindle synchronous control	Set the position loop gain during the spindle synchronous control (synchronous tapping, synchronous control with spindle/C axis). Set the same value as the value of the spindle parameter, position loop gain in synchronous control. When performing the SHG control, set this with SV050 (PGN2sp) and SV058 (SHGCsp). 1 to 200 (rad/s)
2250	PGN2sp	Position loop gain 2 in spindle synchronous control	Set this with SV049 (PGN1sp) and SV058 (SHGCsp) if you wish to perform the SHG control in the spindle synchronous control (synchronous tapping, synchronous control with spindle/C axis). When not performing the SHG control, set to "0". 0 to 999 (rad/s)
2251	SV051 DFBT	Dual feed back control time constant	Set the control time constant in dual feed back. When "0" is set, the actual value that is set is 1ms. The higher the time constant is, the closer it gets to the semi-closed control, so the limit of the position loop gain is raised. 0 to 9999 (ms)
2252	SV052 DFBN	Dual feedback control non-sensitive band	Set the non-sensitive band in the dual feedback control. Set to "0" as a standard. 0 to 9999 (μm)
2253	SV053 OD3	Excessive error detection width in special control	Set the excessive error detection width when servo ON in a special control (initial absolute position setting, stopper control, etc.). If "0" is set, excessive error detection won't be performed when servo ON during a special control. 0 to 32767 (mm)
2254	SV054 ORE	Overrun detection width in closed loop control	Set the overrun detection width in the full-closed loop control. If the gap between the motor end detector and the linear scale (machine end detector) exceeds the value set by this parameter, it is judged to be overrun and Alarm 43 will be detected. When "-1" is set, the alarm detection won't be performed. When "0" is set, overrun is detected with a 2mm width. -1 to 32767 (mm)
2255	SV055 EMGx	Max. gate off delay time after emergency stop	Set a length of time from the point when the emergency stop is input to the point when READY OFF is compulsorily executed. Normally, set the same value as the absolute value of SV056. In preventing the vertical axis from dropping, the gate off is delayed for the length of time set by SV048 if SV055's value is smaller than that of SV048. 0 to 20000 (ms)

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

No.	Items	Details	Setting range	
2256	SV056 EMGt	Deceleration time constant at emergency stop	In the vertical axis drop prevention control, set the time constant used for the deceleration control at emergency stop. Set a length of time that takes from rapid traverse rate (rapid) to stopping. Normally, set the same value as the rapid traverse acceleration/deceleration time constant. When executing the synchronous operation, put the minus sign to the settings of both of the master axis and slave axis.	-20000 to 20000 (ms)
2257	SV057 SHGC	SHG control gain	When performing the SHG control, set this with S003 (PGN1) and SV004 (PGN2). When not performing the SHG control, set to "0".	0 to 999 (rad/s)
2258	SV058 SHGCsp	SHG control gain in spindle synchronous control	Set this with SV049 (PGN1sp) and SV050 (PGN2sp) if you wish to perform the SHG control in the spindle synchronous control (synchronous tapping, synchronous control with spindle/C axis). When not performing the SHG control, set to "0".	0 to 999 (rad/s)
2259	SV059 TCNV	Collision detection torque estimating gain	Set the torque estimating gain when using the collision detection function. After setting as SV035/bitF(ctl)=1 and performing acceleration/deceleration, set the value displayed in MPOS of the NC servo monitor screen. Set to "0" when not using the collision detection function.	-32768 to 32767
2260	SV060 TLMT	Collision detection level	When using the collision detection function, set the collision detection level during the G0 feeding. If "0" is set, none of the collision detection function will work.	0 to 999 (Stall [rated] current %)
2261	SV061 DA1NO	D/A output channel 1 data No.	Input the data number you wish to output to D/A output channel. In the case of MDS-C1-V2, set the axis on the side to which the data will not be output to "-1".	-1 to 127
2262	SV062 DA2NO	D/A output channel 2 data No.		
2263	SV063 DA1MPY	D/A output channel 1 output scale	Set the scale with a 1/256 unit. When "0" is set, output is done with the standard output unit.	-32768 to 32767 (Unit: 1/256)
2264	SV064 DA2MPY	D/A output channel 2 output scale		
2265	SV065		Not used. Set to "0".	0

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

(2) Initial setting value

(a) HC series (Standard 2000 r/min rating)

Motor		Standard HC motor 2000 r/min rating							
		HC52	HC102	HC152	HC202	HC352	HC452	HC702	HC902
Drive unit capacity		05	10	20	20	35	45	70	90
SV001	PC1	---	---	---	---	---	---	---	---
SV002	PC2	---	---	---	---	---	---	---	---
SV003	PGN1	33	33	33	33	33	33	33	33
SV004	PGN2	0	0	0	0	0	0	0	0
SV005	VGN1	100	100	100	100	100	100	150	150
SV006	VGN2	0	0	0	0	0	0	0	0
SV007	VIL	0	0	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364	1364	1364
SV009	IQA	2048	2048	2048	2048	2048	2048	2048	2048
SV010	IDA	2048	2048	2048	2048	2048	2048	2048	2048
SV011	IQG	512	512	512	256	256	256	200	200
SV012	IDG	512	512	512	512	512	512	256	256
SV013	ILMT	500	500	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000	0000	0000	0000
SV018	PIT	---	---	---	---	---	---	---	---
SV019	RNG1	---	---	---	---	---	---	---	---
SV020	RNG2	---	---	---	---	---	---	---	---
SV021	OLT	60	60	60	60	60	60	60	60
SV022	OLL	150	150	150	150	150	150	150	150
SV023	OD1	6	6	6	6	6	6	6	6
SV024	INP	50	50	50	50	50	50	50	50
SV025	MTYP	xxB0	xxB1	xxB2	xxB3	xxB4	xxB5	xxB6	xxB7
SV026	OD2	6	6	6	6	6	6	6	6
SV027	SSF1	4000	4000	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0	0	0
SV029	VCS	0	0	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0	0	0
SV033	SSF2	0000	0000	0000	0000	0000	0000	0000	0000
SV034	SSF3	0003	0003	0003	0003	0003	0003	0003	0003
SV035	SSF4	0000	0000	0040	0040	0040	0040	0040	0000
SV036	PTYP	0000	0000	0000	0000	0000	0000	0000	0000
SV037	JL	0	0	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

Motor		Standard HC motor 2000 r/min rating							
		HC52	HC102	HC152	HC202	HC352	HC452	HC702	HC902
Drive unit capacity		05	10	20	20	35	45	70	90
SV039	LMCD	0	0	0	0	0	0	0	0
SV040	LMCT	0	0	0	10240	10240	10240	10240	10240
SV041	LMC2	0	0	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0	0	0
SV045	TRUB	0	0	0	0	0	0	0	0
SV046	FHz2	0	0	0	0	0	0	0	0
SV047	EC	100	100	100	100	100	100	100	100
SV048	EMGrt	0	0	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0	0	0	0
SV051	DFBT	0	0	0	0	0	0	0	0
SV052	DFBN	0	0	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0	0	0
SV054	ORE	0	0	0	0	0	0	0	0
SV055	EMGx	0	0	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0	0	0
SV059	TCNV	0	0	0	0	0	0	0	0
SV060	TLMT	0	0	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0	0	0
SV065	TLC	0	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

(b) HC series (Standard 3000 r/min rating)

Motor		Standard HC motor 3000 r/min rating						
		HC53	HC103	HC153	HC203	HC353	HC453	HC703
Drive unit capacity		05	10	20	35	45	70	90
SV001	PC1	---	---	---	---	---	---	---
SV002	PC2	---	---	---	---	---	---	---
SV003	PGN1	33	33	33	33	33	33	33
SV004	PGN2	0	0	0	0	0	0	0
SV005	VGN1	100	100	100	100	100	100	100
SV006	VGN2	0	0	0	0	0	0	0
SV007	VIL	0	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364	1364
SV009	IQA	2048	2048	2048	2048	2048	2048	2048
SV010	IDA	2048	2048	2048	2048	2048	2048	2048
SV011	IQG	256	256	256	256	256	256	256
SV012	IDG	512	512	512	512	512	512	512
SV013	ILMT	500	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000	0000	0000
SV018	PIT	---	---	---	---	---	---	---
SV019	RNG1	---	---	---	---	---	---	---
SV020	RNG2	---	---	---	---	---	---	---
SV021	OLT	60	60	60	60	60	60	60
SV022	OLL	150	150	150	150	150	150	150
SV023	OD1	6	6	6	6	6	6	6
SV024	INP	50	50	50	50	50	50	50
SV025	MTYP	xxC0	xxC1	xxC2	xxC3	xxC4	xxC5	xxC6
SV026	OD2	6	6	6	6	6	6	6
SV027	SSF1	4000	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0	0
SV029	VCS	0	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0	0
SV033	SSF2	0000	0000	0000	0000	0000	0000	0000
SV034	SSF3	0003	0003	0003	0003	0003	0003	0003
SV035	SSF4	0000	0000	0040	0040	0040	0040	0000
SV036	PTYP	0000	0000	0000	0000	0000	0000	0000
SV037	JL	0	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

Motor		Standard HC motor 3000 r/min rating						
		HC53	HC103	HC153	HC203	HC353	HC453	HC703
Drive unit capacity		05	10	20	35	45	70	90
SV039	LMCD	0	0	0	0	0	0	0
SV040	LMCT	0	0	0	10240	10240	10240	10240
SV041	LMC2	0	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0	0
SV045	TRUB	0	0	0	0	0	0	0
SV046	FHz2	0	0	0	0	0	0	0
SV047	EC	100	100	100	100	100	100	100
SV048	EMGr	0	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0	0	0
SV051	DFBT	0	0	0	0	0	0	0
SV052	DFBN	0	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0	0
SV054	ORE	0	0	0	0	0	0	0
SV055	EMGx	0	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0	0
SV059	TCNV	0	0	0	0	0	0	0
SV060	TLMT	0	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0	0
SV065	TLC	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

(c) HC series (Low-inertia)

Motor		Low-inertia HC motor				
		HC103R	HC153R	HC203R	HC353R	HC503R
Drive unit capacity		10	10	20	35	45
SV001	PC1	---	---	---	---	---
SV002	PC2	---	---	---	---	---
SV003	PGN1	33	33	33	33	33
SV004	PGN2	0	0	0	0	0
SV005	VGN1	15	15	20	40	40
SV006	VGN2	0	0	0	0	0
SV007	VIL	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364
SV009	IQA	4096	4096	4096	4096	4096
SV010	IDA	4096	4096	4096	4096	4096
SV011	IQG	256	256	256	256	256
SV012	IDG	512	512	512	512	512
SV013	ILMT	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500
SV015	FFC	0	0	0	0	0
SV016	LMC1	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000
SV018	PIT	---	---	---	---	---
SV019	RNG1	---	---	---	---	---
SV020	RNG2	---	---	---	---	---
SV021	OLT	60	60	60	60	60
SV022	OLL	150	150	150	150	150
SV023	OD1	6	6	6	6	6
SV024	INP	50	50	50	50	50
SV025	MTYP	xxE1	xxE2	xxE3	xxE4	xxE5
SV026	OD2	6	6	6	6	6
SV027	SSF1	4000	4000	4000	4000	4000
SV028		0	0	0	0	0
SV029	VCS	0	0	0	0	0
SV030	IVC	0	0	0	0	0
SV031	OVS1	0	0	0	0	0
SV032	TOF	0	0	0	0	0
SV033	SSF2	0000	0000	0000	0000	0000
SV034	SSF3	0000	0000	0000	0000	0000
SV035	SSF4	0000	0000	0000	0000	0000
SV036	PTYP	0000	0000	0000	0000	0000
SV037	JL	0	0	0	0	0
SV038	FHz1	0	0	0	0	0

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

Motor		Low-inertia HC motor				
		HC103R	HC153R	HC203R	HC353R	HC503R
Drive unit capacity		10	10	20	35	45
SV039	LMCD	0	0	0	0	0
SV040	LMCT	0	0	0	0	0
SV041	LMC2	0	0	0	0	0
SV042	OVS2	0	0	0	0	0
SV043	OBS1	0	0	0	0	0
SV044	OBS2	0	0	0	0	0
SV045	TRUB	0	0	0	0	0
SV046	FHz2	0	0	0	0	0
SV047	EC	100	100	100	100	100
SV048	EMGrt	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0
SV051	DFBT	0	0	0	0	0
SV052	DFBN	0	0	0	0	0
SV053	OD3	0	0	0	0	0
SV054	ORE	0	0	0	0	0
SV055	EMGx	0	0	0	0	0
SV056	EMGt	0	0	0	0	0
SV057	SHGC	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0
SV059	TCNV	0	0	0	0	0
SV060	TLMT	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0
SV065	TLC	0	0	0	0	0

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

(d) HA series (Standard 2000 r/min rating)

Motor		Standard HA motor 2000 r/min rating						
		HA40N	HA80N	HA100N	HA200N	HA300N	HA700N	HA900N
Drive unit capacity		05	10	20	35	45	70	90
SV001	PC1	---	---	---	---	---	---	---
SV002	PC2	---	---	---	---	---	---	---
SV003	PGN1	33	33	33	33	33	25	25
SV004	PGN2	0	0	0	0	0	0	0
SV005	VGN1	150	150	150	150	150	250	250
SV006	VGN2	0	0	0	0	0	0	0
SV007	VIL	0	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364	1364
SV009	IQA	2048	2048	2048	2048	2048	2048	2048
SV010	IDA	2048	2048	2048	2048	2048	2048	2048
SV011	IQG	512	512	256	256	256	200	200
SV012	IDG	512	512	512	512	512	256	256
SV013	ILMT	500	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000	0000	0000
SV018	PIT	---	---	---	---	---	---	---
SV019	RNG1	---	---	---	---	---	---	---
SV020	RNG2	---	---	---	---	---	---	---
SV021	OLT	60	60	60	60	60	60	60
SV022	OLL	150	150	150	150	150	150	150
SV023	OD1	6	6	6	6	6	6	6
SV024	INP	50	50	50	50	50	50	50
SV025	MTYP	xx00	xx01	xx02	xx03	xx04	xx05	xx06
SV026	OD2	6	6	6	6	6	6	6
SV027	SSF1	4000	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0	0
SV029	VCS	0	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0	0
SV033	SSF2	0000	0000	0000	0000	0000	0000	0000
SV034	SSF3	0000	0000	0000	0000	0000	0000	0000
SV035	SSF4	0000	0000	0000	0000	0000	0000	0000
SV036	PTYP	0000	0000	0000	0000	0000	0000	0000
SV037	JL	0	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

Motor		Standard HA motor 2000 r/min rating						
		HA40N	HA80N	HA100N	HA200N	HA300N	HA700N	HA900N
Drive unit capacity		05	10	20	35	45	70	90
SV039	LMCD	0	0	0	0	0	0	0
SV040	LMCT	0	0	0	0	0	0	0
SV041	LMC2	0	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0	0
SV045	TRUB	0	0	0	0	0	0	0
SV046	FHz2	0	0	0	0	0	0	0
SV047	EC	100	100	100	100	100	100	100
SV048	EMGr	0	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0	0	0
SV051	DFBT	0	0	0	0	0	0	0
SV052	DFBN	0	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0	0
SV054	ORE	0	0	0	0	0	0	0
SV055	EMGx	0	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0	0
SV059	TCNV	0	0	0	0	0	0	0
SV060	TLMT	0	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0	0
SV065	TLC	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

(e) HA series (Standard 3000 r/min rating)

Motor		Standard HA motor 3000 r/min rating						
		HA43N	HA83N	HA93N	HA103N	HA203N	HA303N	HA703N
Drive unit capacity		05	10	20	35	45	70	90
SV001	PC1	---	---	---	---	---	---	---
SV002	PC2	---	---	---	---	---	---	---
SV003	PGN1	33	33	33	33	33	33	25
SV004	PGN2	0	0	0	0	0	0	0
SV005	VGN1	150	150	150	150	150	150	250
SV006	VGN2	0	0	0	0	0	0	0
SV007	VIL	0	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364	1364
SV009	IQA	2048	2048	2048	2048	2048	2048	2048
SV010	IDA	2048	2048	2048	2048	2048	2048	2048
SV011	IQG	256	256	256	256	256	256	200
SV012	IDG	512	512	512	512	512	512	256
SV013	ILMT	500	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000	0000	0000
SV018	PIT	---	---	---	---	---	---	---
SV019	RNG1	---	---	---	---	---	---	---
SV020	RNG2	---	---	---	---	---	---	---
SV021	OLT	60	60	60	60	60	60	60
SV022	OLL	150	150	150	150	150	150	150
SV023	OD1	6	6	6	6	6	6	6
SV024	INP	50	50	50	50	50	50	50
SV025	MTYP	xx80	xx81	xx8A	xx82	xx83	xx84	xx85
SV026	OD2	6	6	6	6	6	6	6
SV027	SSF1	4000	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0	0
SV029	VCS	0	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0	0
SV033	SSF2	0000	0000	0000	0000	0000	0000	0000
SV034	SSF3	0000	0000	0000	0000	0000	0000	0000
SV035	SSF4	0000	0000	0000	0000	0000	0000	0000
SV036	PTYP	0000	0000	0000	0000	0000	0000	0000
SV037	JL	0	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

Motor		Standard HA motor 3000 r/min rating						
		HA43N	HA83N	HA93N	HA103N	HA203N	HA303N	HA703N
Drive unit capacity		05	10	20	35	45	70	90
SV039	LMCD	0	0	0	0	0	0	0
SV040	LMCT	0	0	0	0	0	0	0
SV041	LMC2	0	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0	0
SV045	TRUB	0	0	0	0	0	0	0
SV046	FHz2	0	0	0	0	0	0	0
SV047	EC	100	100	100	100	100	100	100
SV048	EMGr	0	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0	0	0
SV051	DFBT	0	0	0	0	0	0	0
SV052	DFBN	0	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0	0
SV054	ORE	0	0	0	0	0	0	0
SV055	EMGx	0	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0	0
SV059	TCNV	0	0	0	0	0	0	0
SV060	TLMT	0	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0	0
SV065	TLC	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

(f) HA series (Low-inertia 2000 r/min rating)

Motor		Low-inertia HA motor 2000 r/min rating							
		HA50L	HA100L	HA150L	HA200L	HA300L	HA500L	HA-LH11K2	HA-LH15K2
Drive unit capacity		05	10	10	20	35	45	110	150
SV001	PC1	---	---	---	---	---	---	---	---
SV002	PC2	---	---	---	---	---	---	---	---
SV003	PGN1	33	33	33	33	33	33	33	33
SV004	PGN2	0	0	0	0	0	0	0	0
SV005	VGN1	30	30	30	30	30	50	150	150
SV006	VGN2	0	0	0	0	0	0	0	0
SV007	VIL	0	0	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364	1364	1364
SV009	IQA	2048	2048	2048	2048	2048	2048	2048	2048
SV010	IDA	2048	2048	2048	2048	2048	2048	2048	2048
SV011	IQG	512	512	512	512	256	256	512	512
SV012	IDG	512	512	512	512	512	512	512	512
SV013	ILMT	500	500	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000	0000	0000	0000
SV018	PIT	---	---	---	---	---	---	---	---
SV019	RNG1	---	---	---	---	---	---	---	---
SV020	RNG2	---	---	---	---	---	---	---	---
SV021	OLT	60	60	60	60	60	60	60	3
SV022	OLL	150	150	150	150	150	150	150	150
SV023	OD1	6	6	6	6	6	6	6	6
SV024	INP	50	50	50	50	50	50	50	50
SV025	MTYP	xx20	xx21	xx2A	xx22	xx23	xx24	xx27	xx28
SV026	OD2	6	6	6	6	6	6	6	6
SV027	SSF1	4000	4000	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0	0	0
SV029	VCS	0	0	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0	0	0
SV033	SSF2	0000	0000	0000	0000	0000	0000	0000	0000
SV034	SSF3	0000	0000	0000	0000	0000	0000	0000	0000
SV035	SSF4	0000	0000	0000	0000	0000	0000	0000	0000
SV036	PTYP	0000	0000	0000	0000	0000	0000	0000	0000
SV037	JL	0	0	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

Motor		Low-inertia HA motor 2000 r/min rating							
		HA50L	HA100L	HA150L	HA200L	HA300L	HA500L	HA-LH11K2	HA-LH15K2
Drive unit capacity		05	10	10	20	35	45	110	150
SV039	LMCD	0	0	0	0	0	0	0	0
SV040	LMCT	0	0	0	0	0	0	0	0
SV041	LMC2	0	0	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0	0	0
SV045	TRUB	0	0	0	0	0	0	0	0
SV046	FHz2	0	0	0	0	0	0	0	0
SV047	EC	100	100	100	100	100	100	100	100
SV048	EMGrt	0	0	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0	0	0	0
SV051	DFBT	0	0	0	0	0	0	0	0
SV052	DFBN	0	0	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0	0	0
SV054	ORE	0	0	0	0	0	0	0	0
SV055	EMGx	0	0	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0	0	0
SV059	TCNV	0	0	0	0	0	0	0	0
SV060	TLMT	0	0	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0	0	0
SV065	TLC	0	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

(g) HA series (Small capacity, Low-inertia 3000 r/min rating)

Motor		Small capacity HA motor				Low-inertia HA motor 3000 r/min rating					
		HA053A	HA13N	HA23N	HA33N	HA53L	HA103L	HA153L	HA203L	HA303L	HA503L
Drive unit capacity		01	01	03	03	10	20	20	35	45	70
SV001	PC1	---	---	---	---	---	---	---	---	---	---
SV002	PC2	---	---	---	---	---	---	---	---	---	---
SV003	PGN1	33	33	33	33	33	33	33	33	33	33
SV004	PGN2	0	0	0	0	0	0	0	0	0	0
SV005	VGN1	70	70	100	100	30	30	30	30	30	50
SV006	VGN2	0	0	0	0	0	0	0	0	0	0
SV007	VIL	0	0	0	0	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364	1364	1364	1364	1364
SV009	IQA	2048	2048	2048	2048	2048	2048	2048	2048	2048	2048
SV010	IDA	2048	2048	2048	2048	2048	2048	2048	2048	2048	2048
SV011	IQG	256	256	224	224	512	512	512	512	256	256
SV012	IDG	256	256	224	224	512	512	512	512	512	512
SV013	ILMT	500	500	500	500	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0	0	0	0	0
SV017	SPEC	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV018	PIT	---	---	---	---	---	---	---	---	---	---
SV019	RNG1	---	---	---	---	---	---	---	---	---	---
SV020	RNG2	---	---	---	---	---	---	---	---	---	---
SV021	OLT	60	60	60	60	60	60	60	60	60	60
SV022	OLL	150	150	150	150	150	150	150	150	150	150
SV023	OD1	6	6	6	6	6	6	6	6	6	6
SV024	INP	50	50	50	50	50	50	50	50	50	50
SV025	MTYP	xx8C	xx8D	xx8E	xx8F	xx30	xx31	xx3A	xx32	xx33	xx34
SV026	OD2	6	6	6	6	6	6	6	6	6	6
SV027	SSF1	4000	4000	4000	4000	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0	0	0	0	0
SV029	VCS	0	0	0	0	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0	0	0	0	0
SV033	SSF2	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV034	SSF3	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV035	SSF4	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV036	PTYP	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
SV037	JL	0	0	0	0	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.3 MDS-C1-Vx Standard Specification (MDS-B-Vx Compatible)

Motor		Small capacity HA motor				Low-inertia HA motor 3000 r/min rating					
		HA053A	HA13N	HA23N	HA33N	HA53L	HA103L	HA153L	HA203L	HA303L	HA503L
Drive unit capacity		01	01	03	03	10	20	20	35	45	70
SV039	LMCD	0	0	0	0	0	0	0	0	0	0
SV040	LMCT	0	0	0	0	0	0	0	0	0	0
SV041	LMC2	0	0	0	0	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0	0	0	0	0
SV045	TRUB	0	0	0	0	0	0	0	0	0	0
SV046	FHz2	0	0	0	0	0	0	0	0	0	0
SV047	EC	100	100	100	100	100	100	100	100	100	100
SV048	EMGr	0	0	0	0	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15	15	15	15	15
SV050	PGN2sp	0	0	0	0	0	0	0	0	0	0
SV051	DFBT	0	0	0	0	0	0	0	0	0	0
SV052	DFBN	0	0	0	0	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0	0	0	0	0
SV054	ORE	0	0	0	0	0	0	0	0	0	0
SV055	EMGx	0	0	0	0	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0	0	0	0	0
SV059	TCNV	0	0	0	0	0	0	0	0	0	0
SV060	TLMT	0	0	0	0	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0	0	0	0	0
SV065	TLC	0	0	0	0	0	0	0	0	0	0

7. SERVO PARAMETERS
7.4 MDS-R-Vx

7.4 MDS-R-Vx

(1) Details for servo parameters

For parameters marked with a (PR) in the table, turn the NC power OFF after setting. After the power is turned ON again, the parameter is validated.

⚠ CAUTION

⚠ In the explanation on bits, set all bits not used, including blank bits, to "0".

No.	Items	Details	Setting range
2201 (PR)	SV001 PC1	Motor side gear ratio	1 to 32767
2202 (PR)	SV002 PC2	Machine side gear ratio	1 to 32767
2203	SV003 PGN1	Position loop gain 1	1 to 200 (rad/s)
2204	SV004 PGN2	Position loop gain 2	0 to 999 (rad/s)
2205	SV005 VGN1	Speed loop gain 1	1 to 999
2206	SV006 VGN2	Speed loop gain 2	-1000 to 1000
2207	SV007 VIL	Speed loop delay compensation	0 to 32767


Set the motor side and machine side gear ratio. For the rotary axis, set the total deceleration (acceleration) ratio. Even if the gear ratio is within the setting range, the electronic gears may overflow and cause initial parameter error (servo alarm No. 37).

Set the position loop gain. The standard setting is "33". The higher the setting value is, the more precisely the command can be followed and the shorter the positioning time gets, however, note that a bigger shock is applied to the machine during acceleration/deceleration. When using the SHG control, also set SV004 (PGN2) and SV057 (SHGC).

When using the SHG control, also set SV003 (PGN1) and SV057 (SHGC). When not using the SHG control, set to "0".

Set the speed loop gain. Set this according to the load inertia size. The higher the setting value is, the more accurate the control will be, however, vibration tends to occur. If vibration occurs, adjust by lowering by 20 to 30%. The value should be determined to be 70 to 80% of the value at the time when the vibration stops.

If the noise is bothersome at high speed during rapid traverse, etc, lower the speed loop gain. As shown below, set the speed loop gain of the speed 1.2 times as fast as the motor's maximum speed, and use this with SV029 (VCS). When not using, set to "0".



Set this when the limit cycle occurs in the full-closed loop, or overshooting occurs in positioning. When you set this parameter, make sure to set the torque offset (SV032 (TOF)). When not using, set to "0".

7. SERVO PARAMETERS
7.4 MDS-R-Vx

No.	Items	Details	Setting range	
2208	SV008 VIA	Speed loop lead compensation	Set the gain of the speed loop integration control. The standard setting is "1364". During the SHG control, the standard setting is "1900". Adjust the value by increasing/decreasing it by about 100 at a time. Raise this value to improve contour tracking precision in high-speed cutting. Lower this value when the position droop vibrates (10 to 20Hz).	1 to 9999
2209	SV009 IQA	Current loop q axis lead compensation	Set the gain of current loop. As this setting is determined by the motor's electrical characteristics, the setting is fixed for each type of motor. Set the standard values for all the parameters depending on each motor type.	1 to 20480
2210	SV010 IDA	Current loop d axis lead compensation		
2211	SV011 IQG	Current loop q axis gain		
2212	SV012 IDG	Current loop d axis gain		
2213	SV013 ILMT	Current limit value	Set the normal current (torque) limit value. (Limit values for both + and - direction.) When the value is "500" (a standard setting), the maximum torque is determined by the specification of the motor.	0 to 999 (Stall current %)
2214	SV014 ILMTsp	Current limit value in special control	Set the current (torque) limit value in a special control (initial absolute position setting, stopper control, etc). (Limit values for both of the + and - directions.) Set to "500" when not using.	0 to 999 (Stall current %)
2215	SV015 FFC	Acceleration rate feed forward gain	When a relative error in the synchronous control is large, apply this parameter to the axis that is delaying. The standard setting value is "0". For the SHG control, set to "100". To adjust a relative error in acceleration/deceleration, increase the value by 50 to 100 at a time.	0 to 999 (%)

7. SERVO PARAMETERS
7.4 MDS-R-Vx

No.	Items	Details	Setting range
2216	SV016 LMC1 Lost motion compensation 1	<p>Set this when the protrusion (that occurs due to the non-sensitive band by friction, torsion, backlash, etc) at quadrant change is too large. This compensates the torque at quadrant change. This is valid only when the lost motion compensation (SV027 (SSF1/lmc)) is selected. Only type 2 is compatible with the MDS-R-Vx Series.</p> <hr/> <p>Type 2: When SV027 (SSF1)/bit9, 8 (lmc)=10 Set the compensation amount based on the stall (rated) current of the motor. The standard setting is double of the friction torque. Setting to "0" means the compensation amount is zero.</p> <hr/> <p>When you wish different compensation amount depending on the direction When SV041 (LMC2) is "0", compensate with the value of SV016 (LMC1) in both of the + and -directions. If you wish to change the compensation amount depending on the command direction, set this and SV041 (LMC2). (SV016: + direction, SV041: - direction. However, the directions may be opposite depending on other settings.) When "-1" is set, the compensation won't be performed in the direction of the command.</p>	-1 to 200 (Stall current %)

7. SERVO PARAMETERS
7.4 MDS-R-Vx

No.	Items	Details	Setting range																																																			
2217 (PR)	SV017 SPEC	Servo specification selection	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 12.5%; text-align: center;">F</td> <td style="width: 12.5%; text-align: center;">E</td> <td style="width: 12.5%; text-align: center;">D</td> <td style="width: 12.5%; text-align: center;">C</td> <td style="width: 12.5%; text-align: center;">B</td> <td style="width: 12.5%; text-align: center;">A</td> <td style="width: 12.5%; text-align: center;">9</td> <td style="width: 12.5%; text-align: center;">8</td> </tr> <tr> <td colspan="8" style="text-align: center; border: 1px solid black;">spm</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="text-align: center;">abs</td> <td></td> <td></td> <td style="text-align: center;">fdir</td> <td style="text-align: center;">vfb</td> <td></td> <td style="text-align: center;">dfbx</td> <td></td> </tr> </table>	F	E	D	C	B	A	9	8	spm								7	6	5	4	3	2	1	0	abs			fdir	vfb		dfbx																				
			F	E	D	C	B	A	9	8																																												
			spm																																																			
			7	6	5	4	3	2	1	0																																												
			abs			fdir	vfb		dfbx																																													
			<table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 5%;">bit</th> <th style="width: 35%;">Meaning when "0" is set</th> <th style="width: 60%;">Meaning when "1" is set</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">1</td> <td>dfbx</td> <td>Dual feedback control stop</td> </tr> <tr> <td style="text-align: center;">2</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">3</td> <td>vfb</td> <td>Speed feedback filter stop</td> </tr> <tr> <td style="text-align: center;">4</td> <td>fdir</td> <td>Position feedback forward polarity</td> </tr> <tr> <td style="text-align: center;">5</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">6</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">7</td> <td>abs</td> <td>Incremental control</td> </tr> <tr> <td style="text-align: center;">8</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">9</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">A</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">B</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">C</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">D</td> <td>spm</td> <td>0 : Setting prohibited</td> </tr> <tr> <td style="text-align: center;">E</td> <td></td> <td>1 : HF motor selection (standard)</td> </tr> <tr> <td style="text-align: center;">F</td> <td></td> <td>2 to F : Setting prohibited</td> </tr> </tbody> </table>	bit	Meaning when "0" is set	Meaning when "1" is set	0			1	dfbx	Dual feedback control stop	2			3	vfb	Speed feedback filter stop	4	fdir	Position feedback forward polarity	5			6			7	abs	Incremental control	8			9			A			B			C			D	spm	0 : Setting prohibited	E		1 : HF motor selection (standard)	F		2 to F : Setting prohibited
			bit	Meaning when "0" is set	Meaning when "1" is set																																																	
			0																																																			
			1	dfbx	Dual feedback control stop																																																	
			2																																																			
3	vfb	Speed feedback filter stop																																																				
4	fdir	Position feedback forward polarity																																																				
5																																																						
6																																																						
7	abs	Incremental control																																																				
8																																																						
9																																																						
A																																																						
B																																																						
C																																																						
D	spm	0 : Setting prohibited																																																				
E		1 : HF motor selection (standard)																																																				
F		2 to F : Setting prohibited																																																				
(Note 1) Set to "0" for bits with no particular description.																																																						
2218 (PR)	SV018 PIT	Ball screw pitch	Set the ball screw pitch. Set to "360" for the rotary axis. 1 to 32767 (mm/rev)																																																			
2219 (PR)	SV019 RNG1	Position detector resolution	In the case of the semi-closed loop control Set the same value as SV020 (RNG2). (Refer to the explanation of SV020.) 1 to 9999 (kp/rev)																																																			
			In the case of the full-closed loop control This is available for the relative position oblong wave output specification linear scale. Set the number of pulses per ball screw pitch. 1 to 9999 (kp/PIT)																																																			
			<table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 33%;">Detector model name</th> <th style="width: 33%;">Resolution</th> <th style="width: 34%;">SV019 setting</th> </tr> </thead> <tbody> <tr> <td>Relative position oblong wave output scale</td> <td>Refer to detector specification manual.</td> <td>SV018 (PIT)(mm)/Resolution (μm)</td> </tr> </tbody> </table>	Detector model name	Resolution	SV019 setting	Relative position oblong wave output scale	Refer to detector specification manual.	SV018 (PIT)(mm)/Resolution (μm)																																													
Detector model name	Resolution	SV019 setting																																																				
Relative position oblong wave output scale	Refer to detector specification manual.	SV018 (PIT)(mm)/Resolution (μm)																																																				
2220 (PR)	SV020 RNG2	Speed detector resolution	Set the number of pulses per one revolution of the motor side detector. 1 to 9999 (kp/rev)																																																			
			<table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 33%;">Detector model name</th> <th style="width: 33%;">Motor type</th> <th style="width: 34%;">SV020 setting</th> </tr> </thead> <tbody> <tr> <td>OSA104S2</td> <td>HF□□-A42</td> <td>100</td> </tr> <tr> <td>OSA17</td> <td>HF□□-A47</td> <td>100</td> </tr> </tbody> </table>	Detector model name	Motor type	SV020 setting	OSA104S2	HF□□-A42	100	OSA17	HF□□-A47	100																																										
			Detector model name	Motor type	SV020 setting																																																	
OSA104S2	HF□□-A42	100																																																				
OSA17	HF□□-A47	100																																																				

7. SERVO PARAMETERS
7.4 MDS-R-Vx

No.	Items	Details	Setting range
2221	SV021 OLT	Overload detection time constant Set the detection time constant of Overload 1 (Alarm 50). Set to "60" as a standard. (For machine tool builder adjustment.)	1 to 999 (s)
2222	SV022 OLL	Overload detection level Set the current detection level of Overload 1 (Alarm 50) in respect to the stall (rated) current. Set to "150" as a standard. (For machine tool builder adjustment.)	110 to 500 (Stall current %)
2223	SV023 OD1	Excessive error detection width during servo ON Set the excessive error detection width when servo ON. <Standard setting value> $OD1=OD2= \frac{\text{Rapid traverse rate (mm/min)}}{60 \cdot PGN1} / 2 \text{ (mm)}$ When "0" is set, the excessive error detection will not be performed.	0 to 32767 (mm)
2224	SV024 INP	In-position detection width Set the in-position detection width. Set the accuracy required for the machine. The lower the setting is, the higher the positioning accuracy gets, however, the cycle time (setting time) becomes longer. The standard setting is "50".	0 to 32767 (μm)



7. SERVO PARAMETERS
7.4 MDS-R-Vx

No.	Items	Details	Setting range																																																																																																																																																																																																																																																																																																																																																																						
2225 (PR)	SV025 MTYP	Motor/ Detector type	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">F</td> <td style="text-align: center;">E</td> <td style="text-align: center;">D</td> <td style="text-align: center;">C</td> <td style="text-align: center;">B</td> <td style="text-align: center;">A</td> <td style="text-align: center;">9</td> <td style="text-align: center;">8</td> </tr> <tr> <td colspan="4" style="text-align: center; border: 1px solid black;">pen</td> <td colspan="4" style="text-align: center; border: 1px solid black;">ent</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td colspan="8" style="text-align: center; border: 1px solid black;">mtyp</td> </tr> </table>	F	E	D	C	B	A	9	8	pen				ent				7	6	5	4	3	2	1	0	mtyp																																																																																																																																																																																																																																																																																																																																													
			F	E	D	C	B	A	9	8																																																																																																																																																																																																																																																																																																																																																															
			pen				ent																																																																																																																																																																																																																																																																																																																																																																		
7	6	5	4	3	2	1	0																																																																																																																																																																																																																																																																																																																																																																		
mtyp																																																																																																																																																																																																																																																																																																																																																																									
			<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 5%;">bit</th> <th colspan="8">Explanation</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td colspan="8">Set the motor type.</td> </tr> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">Set- ting</td> <td style="text-align: center;">0x</td> <td style="text-align: center;">1x</td> <td style="text-align: center;">2x</td> <td style="text-align: center;">3x</td> <td style="text-align: center;">4x</td> <td style="text-align: center;">5x</td> <td style="text-align: center;">6x</td> <td style="text-align: center;">7x</td> </tr> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">x0</td> <td>HF53</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">x1</td> <td>HF103</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">4</td> <td style="text-align: center;">x2</td> <td>HF153</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">5</td> <td style="text-align: center;">x3</td> <td>HF203</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">6</td> <td style="text-align: center;">x4</td> <td>HF353</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">x5</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">x6</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">x7</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">x8</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">x9</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">xA</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">xB</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">xC</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">xD</td> <td>HF44</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">xE</td> <td>HF74</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">xF</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">Set- ting</td> <td style="text-align: center;">8x</td> <td style="text-align: center;">9x</td> <td style="text-align: center;">Ax</td> <td style="text-align: center;">Bx</td> <td style="text-align: center;">Cx</td> <td style="text-align: center;">Dx</td> <td style="text-align: center;">Ex</td> <td style="text-align: center;">Fx</td> </tr> <tr> <td></td> <td style="text-align: center;">x0</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">x1</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">x2</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">x3</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">x4</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">x5</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">x6</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">x7</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">x8</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">x9</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">xA</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">xB</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">xC</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">xD</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">xE</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">xF</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	bit	Explanation								0	Set the motor type.								1	Set- ting	0x	1x	2x	3x	4x	5x	6x	7x	2	x0	HF53								3	x1	HF103								4	x2	HF153								5	x3	HF203								6	x4	HF353								7	x5										x6										x7										x8										x9										xA										xB										xC										xD	HF44									xE	HF74									xF										Set- ting	8x	9x	Ax	Bx	Cx	Dx	Ex	Fx		x0										x1										x2										x3										x4										x5										x6										x7										x8										x9										xA										xB										xC										xD										xE										xF								
bit	Explanation																																																																																																																																																																																																																																																																																																																																																																								
0	Set the motor type.																																																																																																																																																																																																																																																																																																																																																																								
1	Set- ting	0x	1x	2x	3x	4x	5x	6x	7x																																																																																																																																																																																																																																																																																																																																																																
2	x0	HF53																																																																																																																																																																																																																																																																																																																																																																							
3	x1	HF103																																																																																																																																																																																																																																																																																																																																																																							
4	x2	HF153																																																																																																																																																																																																																																																																																																																																																																							
5	x3	HF203																																																																																																																																																																																																																																																																																																																																																																							
6	x4	HF353																																																																																																																																																																																																																																																																																																																																																																							
7	x5																																																																																																																																																																																																																																																																																																																																																																								
	x6																																																																																																																																																																																																																																																																																																																																																																								
	x7																																																																																																																																																																																																																																																																																																																																																																								
	x8																																																																																																																																																																																																																																																																																																																																																																								
	x9																																																																																																																																																																																																																																																																																																																																																																								
	xA																																																																																																																																																																																																																																																																																																																																																																								
	xB																																																																																																																																																																																																																																																																																																																																																																								
	xC																																																																																																																																																																																																																																																																																																																																																																								
	xD	HF44																																																																																																																																																																																																																																																																																																																																																																							
	xE	HF74																																																																																																																																																																																																																																																																																																																																																																							
	xF																																																																																																																																																																																																																																																																																																																																																																								
	Set- ting	8x	9x	Ax	Bx	Cx	Dx	Ex	Fx																																																																																																																																																																																																																																																																																																																																																																
	x0																																																																																																																																																																																																																																																																																																																																																																								
	x1																																																																																																																																																																																																																																																																																																																																																																								
	x2																																																																																																																																																																																																																																																																																																																																																																								
	x3																																																																																																																																																																																																																																																																																																																																																																								
	x4																																																																																																																																																																																																																																																																																																																																																																								
	x5																																																																																																																																																																																																																																																																																																																																																																								
	x6																																																																																																																																																																																																																																																																																																																																																																								
	x7																																																																																																																																																																																																																																																																																																																																																																								
	x8																																																																																																																																																																																																																																																																																																																																																																								
	x9																																																																																																																																																																																																																																																																																																																																																																								
	xA																																																																																																																																																																																																																																																																																																																																																																								
	xB																																																																																																																																																																																																																																																																																																																																																																								
	xC																																																																																																																																																																																																																																																																																																																																																																								
	xD																																																																																																																																																																																																																																																																																																																																																																								
	xE																																																																																																																																																																																																																																																																																																																																																																								
	xF																																																																																																																																																																																																																																																																																																																																																																								
			(To be continued to the next page)																																																																																																																																																																																																																																																																																																																																																																						

7. SERVO PARAMETERS
7.4 MDS-R-Vx

No.	Items	Details	Setting range																	
		(Continued from the previous page)																		
		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">bit</th> <th style="text-align: center;">Explanation</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">8</td> <td rowspan="4">Set the speed detector type. Set to "2".</td> </tr> <tr> <td style="text-align: center;">9</td> </tr> <tr> <td style="text-align: center;">A</td> </tr> <tr> <td style="text-align: center;">B</td> </tr> <tr> <td style="text-align: center;">C</td> <td rowspan="5">Set the position detector type.</td> </tr> <tr> <td style="text-align: center;">D</td> <td style="text-align: center;">When applying semi-closed loop control</td> <td style="text-align: center;">Set "2"</td> </tr> <tr> <td style="text-align: center;">E</td> <td style="text-align: center;">Oblong wave (ABZ) output type</td> <td rowspan="2" style="text-align: center;">Set "8"</td> </tr> <tr> <td style="text-align: center;">F</td> <td style="text-align: center;">When using relative position detector scale</td> </tr> </tbody> </table>	bit	Explanation	8	Set the speed detector type. Set to "2".	9	A	B	C	Set the position detector type.	D	When applying semi-closed loop control	Set "2"	E	Oblong wave (ABZ) output type	Set "8"	F	When using relative position detector scale	
bit	Explanation																			
8	Set the speed detector type. Set to "2".																			
9																				
A																				
B																				
C	Set the position detector type.																			
D		When applying semi-closed loop control	Set "2"																	
E		Oblong wave (ABZ) output type	Set "8"																	
F		When using relative position detector scale																		
2226		SV026 OD2	Excessive error detection width during servo OFF	Set the excessive error detection width when servo ON. For the standard setting, refer to the explanation of SV023 (OD1). When "0" is set, the excessive error detection will not be performed.	0 to 32767 (mm)															

7. SERVO PARAMETERS
7.4 MDS-R-Vx

No.	Items	Details	Setting range																																
2227	SV027 SSF1 Servo function selection 1	<table style="margin: auto; border-collapse: collapse;"> <tr> <td style="border: 1px solid black; padding: 2px;">F</td> <td style="border: 1px solid black; padding: 2px;">E</td> <td style="border: 1px solid black; padding: 2px;">D</td> <td style="border: 1px solid black; padding: 2px;">C</td> <td style="border: 1px solid black; padding: 2px;">B</td> <td style="border: 1px solid black; padding: 2px;">A</td> <td style="border: 1px solid black; padding: 2px;">9</td> <td style="border: 1px solid black; padding: 2px;">8</td> </tr> <tr> <td style="border: 1px solid black; width: 20px;"></td> <td style="border: 1px solid black; text-align: center;">zrn2</td> <td style="border: 1px solid black; width: 20px;"></td> <td style="border: 1px solid black; width: 20px;"></td> <td style="border: 1px solid black; text-align: center;">ovs</td> <td style="border: 1px solid black; width: 20px;"></td> <td style="border: 1px solid black; text-align: center;">lmc</td> <td style="border: 1px solid black; width: 20px;"></td> </tr> <tr> <td style="border: 1px solid black; padding: 2px;">7</td> <td style="border: 1px solid black; padding: 2px;">6</td> <td style="border: 1px solid black; padding: 2px;">5</td> <td style="border: 1px solid black; padding: 2px;">4</td> <td style="border: 1px solid black; padding: 2px;">3</td> <td style="border: 1px solid black; padding: 2px;">2</td> <td style="border: 1px solid black; padding: 2px;">1</td> <td style="border: 1px solid black; padding: 2px;">0</td> </tr> <tr> <td style="border: 1px solid black; width: 20px;"></td> <td style="border: 1px solid black; text-align: center;">zrn3</td> <td style="border: 1px solid black; text-align: center;">vfct</td> <td style="border: 1px solid black; width: 20px;"></td> <td style="border: 1px solid black; width: 20px;"></td> <td style="border: 1px solid black; width: 20px;"></td> <td style="border: 1px solid black; width: 20px;"></td> <td style="border: 1px solid black; width: 20px;"></td> </tr> </table>	F	E	D	C	B	A	9	8		zrn2			ovs		lmc		7	6	5	4	3	2	1	0		zrn3	vfct						
		F	E	D	C	B	A	9	8																										
			zrn2			ovs		lmc																											
		7	6	5	4	3	2	1	0																										
			zrn3	vfct																															
		bit	Meaning when "0" is set	Meaning when "1" is set																															
		0																																	
		1																																	
		2																																	
		3																																	
		4	vfct	Set the number of compensation pulses of the jitter compensation.																															
		5		00: Jitter compensation invalid 01: Jitter compensation 1 pulse 10: Jitter compensation 2 pulses 11: Jitter compensation 3 pulses																															
		6	zrn3	Set depending on the Z-phase output type of scale. Rising edge position of the Z-phase does not depend on the movement direction and is constant.	For Z phase, "H" section does not depend on the movement direction and is constant.																														
																																			
		7																																	
8	lmc	Set the compensation amount with SV016 (LMC1) and SV041 (LMC2).																																	
9		00: Lost motion compensation stop 01: Setting prohibited 10: Lost motion compensation type 2 11: Setting prohibited																																	
A	ovs	Set the compensation amount with SV031 (OVS1) and SV042 (OVS2).																																	
B		00: Overshooting compensation stop 01: Setting prohibited 10: Setting prohibited 11: Overshooting compensation type 2																																	
C																																			
D																																			
E	zrn2	Set to "1".																																	
F																																			
(Note) Set to "0" for bits with no particular description.																																			
2228	SV028	Not used. Set to "0".	0																																
2229	SV029 VCS	Speed at the change of speed loop gain If the noise is bothersome at high speed during rapid traverse, etc, lower the speed loop gain. Set the speed at which the speed loop gain changes, and use this with SV006 (VGN2). When not using, set to "0".	0 to 9999 (r/min)																																

7. SERVO PARAMETERS
7.4 MDS-R-Vx

No.	Items	Details	Setting range
2230	SV030 IVC	Voltage non-sensitive compensation When 100% is set, the voltage equivalent to the logical non-energized time will be compensated. When "0" is set, a 100% compensation will be performed. Adjust in increments of 10% from the default value 100%. If increased too much, vibration or vibration noise may be generated.	0 to 200 (%)
2231	SV031 OVS1	<p>Over-shooting compensation 1</p> <p>Set this if overshooting occurs during positioning. This compensates the motor torque during positioning. This is valid only when the overshooting compensation SV027 (SSF1.ovs) is selected.</p> <p>Type 3: When SV027 (SSF1)/bitB, A (ovs)=11 Set the compensation amount based on the motor's stall current. Increase by 1% and determine the amount that overshooting doesn't occur.</p> <p>When you wish different compensation amount depending on the direction When SV042 (OVS2) is "0", compensate with the value of SV031 (OVS1) in both of the + and -directions. If you wish to change the compensation amount depending on the command direction, set this and SV042 (OVS2). (SV031: + direction, SV042: - direction. However, the directions may be opposite depending on other settings.) When "-1" is set, the compensation won't be performed in the direction of the command.</p>	-1 to 100 (Stall current %)
2232	SV032 TOF	Torque offset 1 Set the unbalance torque of vertical axis and slant axis.	-100 to 100 (Stall current %)

7. SERVO PARAMETERS
7.4 MDS-R-Vx

No.	Items	Details	Setting range																																
2233	SV033 SSF2	Servo function selection 2	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 12.5%; text-align: center;">F</td> <td style="width: 12.5%; text-align: center;">E</td> <td style="width: 12.5%; text-align: center;">D</td> <td style="width: 12.5%; text-align: center;">C</td> <td style="width: 12.5%; text-align: center;">B</td> <td style="width: 12.5%; text-align: center;">A</td> <td style="width: 12.5%; text-align: center;">9</td> <td style="width: 12.5%; text-align: center;">8</td> </tr> <tr> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black; text-align: center;">zup</td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black; text-align: center;">dis</td> <td style="border: 1px solid black;"></td> <td style="border: 1px solid black;"></td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td colspan="3" style="border: 1px solid black; text-align: center;">nfd2</td> <td style="border: 1px solid black; text-align: center;">nf3</td> <td colspan="3" style="border: 1px solid black; text-align: center;">nfd1</td> <td style="border: 1px solid black;"></td> </tr> </table>	F	E	D	C	B	A	9	8		zup				dis			7	6	5	4	3	2	1	0	nfd2			nf3	nfd1			
			F	E	D	C	B	A	9	8																									
				zup				dis																											
			7	6	5	4	3	2	1	0																									
			nfd2			nf3	nfd1																												
			bit	Meaning when "0" is set	Meaning when "1" is set																														
			0																																
			1	Set the filter depth for Notch filter 1 (SV038).																															
			2	nfd1	Value	000 001 010 011 100 101 110 111																													
			3	Depth (dB)	Infntly deep	-18.1 -12.0 -8.5 -6.0 -4.1 -2.5 -1.2																													
				Deep←		→ Shallow																													
			4	nf3	Notch filter 3 stop	Notch filter 3 start (1125Hz)																													
			5	Set the operation frequency of Notch filter 2 (SV046).																															
			6	nfd2	Value	000 001 010 011 100 101 110 111																													
			7	Depth (dB)	Infntly deep	-18.1 -12.0 -8.5 -6.0 -4.1 -2.5 -1.2																													
	Deep←		→ Shallow																																
8																																			
9																																			
A	dis	Select the digital signal input.																																	
B		00: DI not used																																	
		01: Contactor B contact input																																	
		10: Reserved																																	
		11: Reserved																																	
C																																			
D																																			
E	zup	Vertical axis pull up control stop	Vertical axis pull up control start																																
F																																			
(Note) Set to "0" for bits with no particular description.																																			

7. SERVO PARAMETERS
7.4 MDS-R-Vx

No.	Items	Details	Setting range																																													
2234	SV034 SSF3	Servo function selection 3																																														
		<table style="width: 100%; border-collapse: collapse; margin-bottom: 5px;"> <tr> <td style="width: 12.5%; text-align: center;">F</td> <td style="width: 12.5%; text-align: center;">E</td> <td style="width: 12.5%; text-align: center;">D</td> <td style="width: 12.5%; text-align: center;">C</td> <td style="width: 12.5%; text-align: center;">B</td> <td style="width: 12.5%; text-align: center;">A</td> <td style="width: 12.5%; text-align: center;">9</td> <td style="width: 12.5%; text-align: center;">8</td> </tr> <tr> <td colspan="8" style="text-align: center; border: 1px solid black;">ovsn</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td colspan="8" style="text-align: center; border: 1px solid black;">zeg</td> </tr> </table>	F	E	D	C	B	A	9	8	ovsn								7	6	5	4	3	2	1	0	zeg																					
F	E	D	C	B	A	9	8																																									
ovsn																																																
7	6	5	4	3	2	1	0																																									
zeg																																																
		<table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 8%;">bit</th> <th style="width: 42%;">Meaning when "0" is set</th> <th style="width: 50%;">Meaning when "1" is set</th> </tr> </thead> <tbody> <tr><td style="text-align: center;">0</td><td></td><td></td></tr> <tr><td style="text-align: center;">1</td><td></td><td></td></tr> <tr><td style="text-align: center;">2</td><td></td><td></td></tr> <tr><td style="text-align: center;">3</td><td></td><td></td></tr> <tr><td style="text-align: center;">4</td><td></td><td></td></tr> <tr><td style="text-align: center;">5</td><td style="vertical-align: top;">zeg Z phase normal edge detection (normal)</td><td style="vertical-align: top;">Z phase reverse edge detection (Valid only when SV027/bit6=1)</td></tr> <tr><td style="text-align: center;">6</td><td></td><td></td></tr> <tr><td style="text-align: center;">7</td><td></td><td></td></tr> <tr><td style="text-align: center;">8</td><td></td><td></td></tr> <tr><td style="text-align: center;">9</td><td></td><td></td></tr> <tr><td style="text-align: center;">A</td><td></td><td></td></tr> <tr><td style="text-align: center;">B</td><td></td><td></td></tr> <tr><td style="text-align: center;">C</td><td colspan="2" rowspan="4" style="vertical-align: top;">Set the non-sensitive band of the overshooting compensation type 3 in increments of 2μm at a time. In the feed forward control, the non-sensitive band of the model position drop is set, and overshooting of the model is ignored. Set the same value as the standard SV040.</td></tr> <tr><td style="text-align: center;">D</td></tr> <tr><td style="text-align: center;">E</td></tr> <tr><td style="text-align: center;">F</td></tr> </tbody> </table>	bit	Meaning when "0" is set	Meaning when "1" is set	0			1			2			3			4			5	zeg Z phase normal edge detection (normal)	Z phase reverse edge detection (Valid only when SV027/bit6=1)	6			7			8			9			A			B			C	Set the non-sensitive band of the overshooting compensation type 3 in increments of 2μm at a time. In the feed forward control, the non-sensitive band of the model position drop is set, and overshooting of the model is ignored. Set the same value as the standard SV040.		D	E	F	
bit	Meaning when "0" is set	Meaning when "1" is set																																														
0																																																
1																																																
2																																																
3																																																
4																																																
5	zeg Z phase normal edge detection (normal)	Z phase reverse edge detection (Valid only when SV027/bit6=1)																																														
6																																																
7																																																
8																																																
9																																																
A																																																
B																																																
C	Set the non-sensitive band of the overshooting compensation type 3 in increments of 2μm at a time. In the feed forward control, the non-sensitive band of the model position drop is set, and overshooting of the model is ignored. Set the same value as the standard SV040.																																															
D																																																
E																																																
F																																																
		(Note) Set to "0" for bits with no particular description.																																														

7. SERVO PARAMETERS
7.4 MDS-R-Vx

No.	Items	Details	Setting range																																																																																			
2235	SV035 SSF4	Servo function selection 4																																																																																				
		<table style="width: 100%; border-collapse: collapse; margin-bottom: 5px;"> <tr> <td style="width: 12.5%; text-align: center;">F</td> <td style="width: 12.5%; text-align: center;">E</td> <td style="width: 12.5%; text-align: center;">D</td> <td style="width: 12.5%; text-align: center;">C</td> <td style="width: 12.5%; text-align: center;">B</td> <td style="width: 12.5%; text-align: center;">A</td> <td style="width: 12.5%; text-align: center;">9</td> <td style="width: 12.5%; text-align: center;">8</td> </tr> <tr> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> <td style="border: 1px solid black; height: 15px;"></td> </tr> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">bit</th> <th style="width: 45%;">Meaning when "0" is set</th> <th style="width: 45%;">Meaning when "1" is set</th> </tr> </thead> <tbody> <tr><td>0</td><td></td><td></td></tr> <tr><td>1</td><td></td><td></td></tr> <tr><td>2</td><td></td><td></td></tr> <tr><td>3</td><td></td><td></td></tr> <tr><td>4</td><td></td><td></td></tr> <tr><td>5</td><td></td><td></td></tr> <tr><td>6</td><td></td><td></td></tr> <tr><td>7</td><td></td><td></td></tr> <tr><td>8</td><td></td><td></td></tr> <tr><td>9</td><td></td><td></td></tr> <tr><td>A</td><td></td><td></td></tr> <tr><td>B</td><td></td><td></td></tr> <tr><td>C</td><td></td><td></td></tr> <tr><td>D</td><td></td><td></td></tr> <tr><td>E</td><td></td><td></td></tr> <tr><td>F</td><td></td><td></td></tr> </tbody> </table>	F	E	D	C	B	A	9	8									7	6	5	4	3	2	1	0									bit	Meaning when "0" is set	Meaning when "1" is set	0			1			2			3			4			5			6			7			8			9			A			B			C			D			E			F			
F	E	D	C	B	A	9	8																																																																															
7	6	5	4	3	2	1	0																																																																															
bit	Meaning when "0" is set	Meaning when "1" is set																																																																																				
0																																																																																						
1																																																																																						
2																																																																																						
3																																																																																						
4																																																																																						
5																																																																																						
6																																																																																						
7																																																																																						
8																																																																																						
9																																																																																						
A																																																																																						
B																																																																																						
C																																																																																						
D																																																																																						
E																																																																																						
F																																																																																						
		(Note) Set to "0" for bits with no particular description.																																																																																				

7. SERVO PARAMETERS
7.4 MDS-R-Vx

No.	Items	Details	Setting range																																
2236 (PR)	SV036 PTYP Regenerative resistor type	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">F</td> <td style="text-align: center;">E</td> <td style="text-align: center;">D</td> <td style="text-align: center;">C</td> <td style="text-align: center;">B</td> <td style="text-align: center;">A</td> <td style="text-align: center;">9</td> <td style="text-align: center;">8</td> </tr> <tr> <td colspan="4" style="text-align: center; border: 1px solid black;">1</td> <td colspan="4" style="text-align: center; border: 1px solid black;">rtyp</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td colspan="4" style="text-align: center; border: 1px solid black;">emgx</td> <td colspan="4" style="text-align: center; border: 1px solid black;">0</td> </tr> </table>	F	E	D	C	B	A	9	8	1				rtyp				7	6	5	4	3	2	1	0	emgx				0				
		F	E	D	C	B	A	9	8																										
		1				rtyp																													
		7	6	5	4	3	2	1	0																										
		emgx				0																													
		bit	Meaning when "0" is set	Meaning when "1" is set																															
		0																																	
		1																																	
		2																																	
		3																																	
4	Set the external emergency stop function. (Setting is prohibited for values with no description.)																																		
5	emgx	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">Set-ting</th> <th style="width: 90%;">Explanation</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>External emergency stop invalid</td> </tr> <tr> <td style="text-align: center;">4</td> <td>External emergency stop valid</td> </tr> </tbody> </table>	Set-ting	Explanation	0	External emergency stop invalid	4	External emergency stop valid																											
Set-ting	Explanation																																		
0	External emergency stop invalid																																		
4	External emergency stop valid																																		
6																																			
7																																			
8	Set the regenerative resistor type.																																		
9	rtyp	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">Set-ting</th> <th style="width: 90%;">Explanation</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0 to 1</td> <td>Setting prohibited</td> </tr> <tr> <td style="text-align: center;">2</td> <td>GZG200W26OHMJ</td> </tr> <tr> <td style="text-align: center;">3</td> <td>GZG300W20OHMJ</td> </tr> <tr> <td style="text-align: center;">4</td> <td>MR-RB32 or GZG200W120OHMJ 3 units connected in parallel</td> </tr> <tr> <td style="text-align: center;">5</td> <td>MR-RB30 or GZG200W39OHMJ 3 units connected in parallel</td> </tr> <tr> <td style="text-align: center;">6</td> <td>MR-RB50 or GZG300W39OHMJ 3 units connected in parallel</td> </tr> <tr> <td style="text-align: center;">7</td> <td>MR-RB31 or GZG200W20OHMJ 3 units connected in parallel</td> </tr> <tr> <td style="text-align: center;">8</td> <td>MR-RB51 or GZG300W20OHMJ 3 units connected in parallel</td> </tr> <tr> <td style="text-align: center;">9</td> <td>MR-RB65 or GRZG400-2OHMJ 4 units connected in serial</td> </tr> <tr> <td style="text-align: center;">A</td> <td>GZG80W26OHMJ</td> </tr> <tr> <td style="text-align: center;">B</td> <td>GZG400W13OHMJ</td> </tr> <tr> <td style="text-align: center;">C</td> <td>GZG400W8OHMJ</td> </tr> <tr> <td style="text-align: center;">D to F</td> <td>Setting prohibited</td> </tr> </tbody> </table>	Set-ting	Explanation	0 to 1	Setting prohibited	2	GZG200W26OHMJ	3	GZG300W20OHMJ	4	MR-RB32 or GZG200W120OHMJ 3 units connected in parallel	5	MR-RB30 or GZG200W39OHMJ 3 units connected in parallel	6	MR-RB50 or GZG300W39OHMJ 3 units connected in parallel	7	MR-RB31 or GZG200W20OHMJ 3 units connected in parallel	8	MR-RB51 or GZG300W20OHMJ 3 units connected in parallel	9	MR-RB65 or GRZG400-2OHMJ 4 units connected in serial	A	GZG80W26OHMJ	B	GZG400W13OHMJ	C	GZG400W8OHMJ	D to F	Setting prohibited					
Set-ting	Explanation																																		
0 to 1	Setting prohibited																																		
2	GZG200W26OHMJ																																		
3	GZG300W20OHMJ																																		
4	MR-RB32 or GZG200W120OHMJ 3 units connected in parallel																																		
5	MR-RB30 or GZG200W39OHMJ 3 units connected in parallel																																		
6	MR-RB50 or GZG300W39OHMJ 3 units connected in parallel																																		
7	MR-RB31 or GZG200W20OHMJ 3 units connected in parallel																																		
8	MR-RB51 or GZG300W20OHMJ 3 units connected in parallel																																		
9	MR-RB65 or GRZG400-2OHMJ 4 units connected in serial																																		
A	GZG80W26OHMJ																																		
B	GZG400W13OHMJ																																		
C	GZG400W8OHMJ																																		
D to F	Setting prohibited																																		
A																																			
B																																			
C																																			
D	amp	Always set to "1 (0001)".																																	
E																																			
F																																			

(Note) Set to "0" for bits with no particular description.

7. SERVO PARAMETERS
7.4 MDS-R-Vx

No.	Items	Details	Setting range
2237	SV037 JL	Load inertia scale Set "the motor inertia + motor axis conversion load inertia" in respect to the motor inertia. $SV037 (JL) = \frac{Jl+Jm}{Jm} *100$ Jm: Motor inertia Jl: Motor axis conversion load inertia	0 to 5000 (%)
2238	SV038 FHz1	Notch filter frequency 1 Set the vibration frequency to suppress if machine vibration occurs. (Valid at 36 or more) When not using, set to "0".	0 to 4500 (Hz)
2239	SV039 LMCD	Lost motion compensation timing Set this when the lost motion compensation timing does not match. Adjust by increasing the value by 10 at a time.	0 to 2000 (ms)
2240	SV040 LMCT	Lost motion compensation non-sensitive band Set the non-sensitive band of the lost motion compensation in the feed forward control. When "0" is set, the actual value that is set is 2μm. Adjust by increasing by 1μm at a time.	0 to 100 (μm)
2241	SV041 LMC2	Lost motion compensation 2 Set this with SV016 (LMC1) only when you wish to set the lost motion compensation amount to be different depending on the command directions. Set to "0" as a standard.	-1 to 200 (Stall current %)
2242	SV042 OVS2	Overshooting compensation 2 Set this with SV031 (OVS1) only when you wish to set the overshooting compensation amount to be different depending on the command directions. Set to "0" as a standard.	-1 to 100 (Stall current %)
2243	SV043 OBS1	Disturbance observer filter frequency Set the disturbance observer filter band. Set to "100" as a standard. To use the disturbance observer, also set SV037 (JL) and SV044 (OBS2). When not using, set to "0".	0 to 1000 (rad/s)
2244	SV044 OBS2	Disturbance observer gain Set the disturbance observer gain. The standard setting is "100" to "300". To use the disturbance observer, also set SV037 (JL) and SV043 (OBS1). When not using, set to "0".	0 to 500 (%)
2245	SV045	Not used. Set to "0".	0
2246	SV046 FHz2	Notch filter frequency 2 Set the vibration frequency to suppress if machine vibration occurs. (Valid at 36 or more) When not using, set to "0".	0 to 4500 (Hz)
2247	SV047 EC	Inductive voltage compensation gain Set the inductive voltage compensation gain. Set to "100" as a standard. If the current FB peak exceeds the current command peak, lower the gain.	0 to 200 (%)
2248	SV048 EMGr	Vertical axis drop prevention time Input a length of time to prevent the vertical axis from dropping by delaying Ready OFF until the brake works when the emergency stop occurs. Increase the setting by 100msec at a time and set the value where the axis does not drop.	0 to 20000 (ms)

7. SERVO PARAMETERS
7.4 MDS-R-Vx

No.	Items	Details	Setting range	
2249	SV049 PGN1sp	Position loop gain 1 in spindle synchronous control	Set the position loop gain during the spindle synchronous control (synchronous tapping, synchronous control with spindle/C axis). Set the same value as the value of the spindle parameter, position loop gain in synchronous control. When performing the SHG control, set this with SV050 (PGN2sp) and SV058 (SHGCsp).	1 to 200 (rad/s)
2250	SV050 PGN2sp	Position loop gain 2 in spindle synchronous control	Set this with SV049 (PGN1sp) and SV058 (SHGCsp) if you wish to perform the SHG control in the spindle synchronous control (synchronous tapping, synchronous control with spindle/C axis). When not performing the SHG control, set to "0".	0 to 999 (rad/s)
2251	SV051 DFBT	Dual feed back control time constant	Set the control time constant in dual feed back. When "0" is set, the actual value that is set is 1ms. The higher the time constant is, the closer it gets to the semi-closed control, so the limit of the position loop gain is raised.	0 to 9999 (ms)
2252	SV052 DFBN	Dual feedback control dead zone	Set the dead zone in the dual feedback control. Set to "0" as a standard.	0 to 9999 (μ m)
2253	SV053 OD3	Excessive error detection width in special control	Set the excessive error detection width when servo ON in a special control (initial absolute position setting, stopper control, etc.). If "0" is set, excessive error detection won't be performed.	0 to 32767 (mm)
2254	SV054 ORE	Overrun detection width in closed loop control	Set the overrun detection width in the full-closed loop control. If the gap between the motor side detector and the linear scale (machine side detector) exceeds the value set by this parameter, it is judged to be overrun and Alarm 43 will be detected. When "-1" is set, the alarm detection won't be performed. When "0" is set, overrun is detected with a 2mm width.	-1 to 32767 (mm)
2255	SV055 EMGx	Max. gate off delay time after emergency stop	Set the time from when emergency stop is input to when READY is forcibly turned OFF. Normally, set the same value as SV056. When using vertical axis drop prevention control, the gate off will be delayed by the time set in SV048 even if SV055 is smaller than SV048.	0 to 20000 (ms)
2256	SV056 EMGt	Deceleration time constant at emergency stop	In the vertical axis drop prevention time control, set the time constant used for the deceleration control at emergency stop. Set a length of time that takes from rapid traverse rate (rapid) to stopping. Normally, set the same value as the rapid traverse acceleration/deceleration time constant.	0 to 20000 (ms)
2257	SV057 SHGC	SHG control gain	When performing the SHG control, set this with S003 (PGN1) and SV004 (PGN2). When not performing the SHG control, set to "0".	0 to 1200 (rad/s)

7. SERVO PARAMETERS
7.4 MDS-R-Vx

No.	Items	Details	Setting range	
2258	SV058 SHGCsp	SHG control gain in spindle synchronous control	Set this with SV049 (PGN1sp) and SV050 (PGN2sp) if you wish to perform the SHG control in the spindle synchronous control (synchronous tapping, synchronous control with spindle/C axis). When not performing the SHG control, set to "0".	0 to 1200 (rad/s)
2259	SV059		Not used. Set to "0".	0
2260	SV060		Not used. Set to "0".	0
2261	SV061 DA1NO	D/A output channel 1 data No.	Input the No. of the data to be output to the D/A output channel.	0 to 102
2262	SV062 DA2NO	D/A output channel 2 data No.		
2263	SV063 DA1MPY	D/A output channel 1 output scale	When "0" is set, the data is output with the standard output unit. Set a value other than 0 to change the output unit. The scale is set with a 1/256 unit. When 256 is set, the unit is the same as the standard output unit.	-32768 to 32767 (Unit: 1/256)
2264	SV064 DA2MPY	D/A output channel 2 output scale		
2265	SV065		Not used. Set to "0".	0
2266 to 2280	SV066 to SV080	System setting parameter	These parameters are set automatically by the NC system.	
2281 to 2288	SV081 to SV088		Not used. Set to "0".	0
2289	SV089 TQMAX Kq	Torque maximizing control Kq gain	Normally set this to "0". (For machine tool builder adjustment)	0 to 32767
2290	SV090 TQMAX Kd	Torque maximizing control Kd gain	Normally set this to "0". (For machine tool builder adjustment)	0 to 32767
2291 to 2300	SV091 to SV100		Not used. Set to "0".	

7. SERVO PARAMETERS
7.4 MDS-R-Vx

(2) Initial setting value

(a) HF series

Motor		HF 44	HF 74	HF 53	HF 103	HF 153	HF 203	HF 353
Drive unit capacity		20/40	20/40	20/40	20/40	40/60/80	40/60/80	60/80
SV001	PC1	---	---	---	---	---	---	---
SV002	PC2	---	---	---	---	---	---	---
SV003	PGN1	33	33	33	33	33	33	33
SV004	PGN2	0	0	0	0	0	0	0
SV005	VGN1	20	40	50	50	50	100	120
SV006	VGN2	0	0	0	0	0	0	0
SV007	VIL	0	0	0	0	0	0	0
SV008	VIA	1364	1364	1364	1364	1364	1364	1364
SV009	IQA	6144	6144	6144	6144	6144	6144	6144
SV010	IDA	6144	6144	6144	6144	6144	6144	6144
SV011	IQG	768	512	1280	1024	1024	1024	1024
SV012	IDG	768	512	1280	1024	1024	1024	1024
SV013	ILMT	500	500	500	500	500	500	500
SV014	ILMTsp	500	500	500	500	500	500	500
SV015	FFC	0	0	0	0	0	0	0
SV016	LMC1	0	0	0	0	0	0	0
SV017	SPEC1	1000	1000	1000	1000	1000	1000	1000
SV018	PIT	---	---	---	---	---	---	---
SV019	RNG1	---	---	---	---	---	---	---
SV020	RNG2	---	---	---	---	---	---	---
SV021	OLT	60	60	60	60	60	60	60
SV022	OLL	150	150	150	150	150	150	150
SV023	OD1	6	6	6	6	6	6	6
SV024	INP	50	50	50	50	50	50	50
SV025	MTYP	220D	220E	2200	2201	2202	2203	2204
SV026	OD2	6	6	6	6	6	6	6
SV027	SSF1	4000	4000	4000	4000	4000	4000	4000
SV028		0	0	0	0	0	0	0
SV029	VCS	0	0	0	0	0	0	0
SV030	IVC	0	0	0	0	0	0	0
SV031	OVS1	0	0	0	0	0	0	0
SV032	TOF	0	0	0	0	0	0	0
SV033	SSF2	0000	0000	0000	0000	0000	0000	0000
SV034	SSF3	0000	0000	0000	0000	0000	0000	0000
SV035	SSF4	0000	0000	0000	0000	0000	0000	0000
SV036	PTYP	1x00	1x00	1x00	1x00	1x00	1x00	1x00
SV037	JL	0	0	0	0	0	0	0
SV038	FHz1	0	0	0	0	0	0	0
SV039	LMCD	0	0	0	0	0	0	0
SV040	LMCT	0	0	0	0	0	0	0
SV041	LMC2	0	0	0	0	0	0	0
SV042	OVS2	0	0	0	0	0	0	0
SV043	OBS1	0	0	0	0	0	0	0
SV044	OBS2	0	0	0	0	0	0	0
SV045		0	0	0	0	0	0	0
SV046	FHz2	0	0	0	0	0	0	0
SV047	EC1	100	100	100	100	100	100	100
SV048	EMGr	0	0	0	0	0	0	0
SV049	PGN1sp	15	15	15	15	15	15	15

7. SERVO PARAMETERS
7.4 MDS-R-Vx

Motor		HF 44	HF 74	HF 53	HF 103	HF 153	HF 203	HF 353
Drive unit capacity		20/40	20/40	20/40	20/40	40/60/80	40/60/80	60/80
SV050	PGN2sp	0	0	0	0	0	0	0
SV051	DFBT	0	0	0	0	0	0	0
SV052	DFBN	0	0	0	0	0	0	0
SV053	OD3	0	0	0	0	0	0	0
SV054	ORE	0	0	0	0	0	0	0
SV055	EMGx	0	0	0	0	0	0	0
SV056	EMGt	0	0	0	0	0	0	0
SV057	SHGC	0	0	0	0	0	0	0
SV058	SHGCsp	0	0	0	0	0	0	0
SV059		0	0	0	0	0	0	0
SV060		0	0	0	0	0	0	0
SV061	DA1NO	0	0	0	0	0	0	0
SV062	DA2NO	0	0	0	0	0	0	0
SV063	DA1MPY	0	0	0	0	0	0	0
SV064	DA2MPY	0	0	0	0	0	0	0
SV065		0	0	0	0	0	0	0
(System parameter area)								
SV081 to SV088		0	0	0	0	0	0	0
SV089	TQMAX Kq	0	0	0	0	0	0	0
SV090	TQMAX Kd	0	0	0	0	0	0	0
SV091 to SV100		0	0	0	0	0	0	0


7.5 Supplement

7.5.1 D/A output specifications

(1) MDS-B-SVJ2

(a) D/A output specifications

Item	Explanation
No. of channels	2ch
Output cycle	888 μ s (min. value)
Output precision	8bit
Output voltage range	-10V to 0 to +10V
Output scale setting	$\pm 1/256$ to ± 128 times
Output pins	CN3 connector MO1 = pin 4 MO2 = pin 14 GND = pin 1, 11
Function	Offset amount adjustment function Output clamp function Low path filter function
Option	Relay terminal: MR-J2CN3TM Connect from the CN3 connector using the SH21 cable as a lead-in wire.



7. SERVO PARAMETERS
7.5 Supplement

(b) Setting the output data

Set the No. of the data to be outputted to each D/A output channel.

#	No.	Abbrev	Parameter name
2261	SV061	DA1NO	D/A output channel 1 data No.
2262	SV062	DA2NO	D/A output channel 2 data No.

No.	Output data	Standard output unit	Output cycle
0	0V test output	For offset amount adjustment	
1	Speed feedback	1000 (r/min) / 2V	888μs
2	Current feedback	Stall (rated) 100% / 2V	888μs
3	Speed command	1000 (r/min) / 2V	888μs
4	Current command	Stall (rated) 100% / 2V	888μs
5	V-phase current value	10A / V	888μs
6	W-phase current-value	10A / V	888μs
7	Estimated disturbance torque	Stall (rated) 100% / 2V	888μs
8	Collision detection disturbance torque	Stall (rated) 100% / 2V	888μs
9	Position feedback (stroke)	100mm / V	3.55ms
10	Position feedback (pulse)	10μm / V	3.55ms
11	Position droop	mm / V	3.55ms
12	Position droop (x10)	100μm / V	3.55ms
13	Position droop (x100)	10μm / V	3.55ms
14	Feedrate (FΔT)	10000(mm/min) / V	888μs
15	Feedrate (FΔT x 10)	1000(mm/min) / V	888μs
16	Model position droop	mm / V	3.55ms
17	Model position droop (x10)	100μm / V	3.55ms
18	Model position droop (x100)	10μm / V	3.55ms
19	q-axis current cumulative value	-	888μs
20	d-axis current cumulative value	-	888μs
21	Motor load level	100% / 5V	113.7ms
22	Amplifier load level	100% / 5V	113.7ms
23	Regenerative load level	100% / 5V	910.2ms
24	PN bus wire voltage	50V / V (1/50)	888μs
25	Speed cumulative item	-	888μs
26	Cycle counter	0-5V (Regardless of resolution)	888μs
27	Excessive error detection amount	mm / V	3.55ms
28	Collision detection estimated torque	Stall (rated) 100% / 2V	888μs
29	Position command (stroke)	100mm / V	3.55ms
30	Position command (pulse)	10μm / V	3.55ms
31 to 99	-		
100	5V test output	-	-
101	Saw-tooth wave test output	-5 to 5V Cycle: 113.7ms	888μs
102	Recutangular wave test output	0 to 5V Cycle: 227.5ms	888μs
103 to	Setting prohibited		

7. SERVO PARAMETERS
7.5 Supplement

(c) Setting the output scale

When "0" is set, the output will be made with the standard output unit. To change the output unit, set a value other than "0".

The scale is set with a 1/256 unit. When 256 is set, the unit will be the same as the standard output.

#	No.	Abbrev	Parameter name
2263	SV063	DA1MPY	D/A output channel 1 output scale
2264	SV064	DA2MPY	D/A output channel 2 output scale

(Example 1) When SV061 = 5, SV063 = 2560

The V-phase current value will be output with 1 A/V unit to D/A output ch.1.

(Example 2) When SV063 = 11, SV064 = 128

The position droop will be output with a 2mm/Vunit to D/A output ch.2.

(2) MDS-C1-Vx, MDS-B-Vx, MDS-B-Vx4


(a) D/A Output specifications

Item	Explanation
No. of channels	2ch
Output cycle	888 μ s (min. value)
Output precision	8bit
Output voltage	0V to 2.5V(zero) to +5V
Output scale setting	$\pm 1/256$ to ± 128 times
Output pins	CN9 connector MO1 = pin 9 MO2 = pin 19 GND = pin 1,11
Function	Phase current feed back output function L-axis U-phase current FB : pin 7 L-axis V-phase current FB : pin 17 M-axis U-phase current FB : pin 6 M-axis V-phase current FB : pin 16
Option	An drive unit with 2 axes also has 2 channels for D/A output. Therefore, set the output data of the axis (SV061,62), which is not observed, to "-1".


7. SERVO PARAMETERS

7.5 Supplement

With the MDS-C1-V1/V2 Series, there is a 2.5V offset voltage (2.5V when data is 0), so the zero level position must be adjusted on the hi-corder side.



Example of D/A output waveform



7. SERVO PARAMETERS
7.5 Supplement

(b) Setting the output data

Set the No. of the data to be outputted to each data D/A output channel.

#	No.	Abbrev	Parameter name
2261	SV061	DA1NO	D/A output channel 1 data No.
2262	SV062	DA2NO	D/A output channel 2 data No.

No.	Output data	Standard output unit	Standard setting value of output scale (Setting values in SV063, SV064)	Standard output unit	Output cycle
-1	D/A output non-selected	For a drive unit. with 2 axes (MDS-C1-V2). Set for the parameter of the axis which is not used.			
0	ch1: Speed feedback	r/min	13 (in case of 2000r/min)	1000(r/min) / V	3.5ms
			9 (in case of 3000r/min)	1500(r/min) / V	3.5ms
	ch2: Current command	Stall current %	131	Stall current 100% / V	3.5ms
1	Current command	Stall current %	131	Stall current 100% / V	3.5ms
2	–				
3	Current feedback	Stall current %	131	Stall current 100% / V	3.5ms
4	–				
5	–				
6	Position droop	NC display unit / 2	328 (When the display unit=1μm)	10μm / 0.5V	3.5ms
7	–				
8	Feedrate (FΔT)	(NC display unit / 2) / communication cycle	55 (When 1μm, 3.5ms)	1000 (mm/min) / 0.5V	3.5ms
9	–				
10	Position command	NC display unit / 2	328 (When the display unit=1μm)	10μm / 0.5V	3.5ms
11	–				
12	Position feedback	NC display unit / 2	328 (When the display unit=1μm)	10μm / 0.5V	3.5ms
13	–				
14	Collision detection estimated torque	Stall current %	131	Stall current 100% / V	3.5ms
15	Collision detection disturbance torque	Stall current %	131	Stall current 100% / V	3.5ms

(To be continued to the next page)

7. SERVO PARAMETERS
7.5 Supplement

(Continued from the previous page)

No.	Output data	Standard output unit	Standard setting value of output scale (Setting values in SV063, SV064)	Standard output unit	Output cycle
64	Current command (High-speed)	Internal unit	8 (adjustment required)	–	0.8μs
65	Current feedback (High-speed)	Internal unit	8 (adjustment required)	–	0.8μs
77	Estimated disturbance torque	Internal unit	8 (adjustment required)	–	0.8μs
125	Saw-tooth wave test output	0V to 5V	0 (256)	Cycle: 227.5ms	0.8μs
126	Rectangular wave test output	0V to 5V	0 (256)	Cycle: 1.7ms	0.8μs
127	2.5V (data 0) test output	2.5V	0 (256)	–	0.8μs

(c) Setting the output scale

#	No.	Abbrev	Parameter name
2263	SV063	DA1MPY	D/A output channel 1 output scale
2264	SV064	DA2MPY	D/A output channel 2 output scale

Usually, the standard setting value is set for the output scale (SV063, SV 064). Set the output magnification with a 1/256 unit. When "0" is set, the output will be made as well as when "256" is set.

$$\text{DATA} \times \frac{\text{SV063}}{256} \times \frac{5 [\text{V}]}{256 (8\text{bit})} + 2.5 [\text{V}] (\text{offset}) = \text{Output voltage} [\text{V}]$$


(Example) When outputting the current FB with 100%/V–stall (SV061=3, SV063=131)

$$100 \times \frac{131}{256} \times \frac{5}{256} + 2.5 = 3.499 [\text{V}]$$

(3) MDS-R-V1/V2

(a) D/A output specifications

Item	Explanation
No. of channels	2ch
Output cycle	0.8ms (min. value)
Output precision	12bit
Output voltage range	0V to 2.5V to 5V
Output scale setting	$\pm 1/256$ to ± 128 times
Output pins	CN9 connector MO1 = pin 4 MO2 = pin 14 GND(LG) = pin 1
Function	Phase current feedback output function L-axis U-phase current FB: pin 6 L-axis V-phase current FB: pin 16 M-axis U-phase current FB: pin 7 M-axis V-phase current FB: pin 17
Option	Relay terminal: MR-J2CN3TM Connect from the CN9 connector using the SH21 cable as a lead-in wire.



7. SERVO PARAMETERS
7.5 Supplement

(b) Setting the output data

Set the No. of the data to be outputted to each D/A output channel.

#	No.	Abbrev	Parameter name	Explanation
2261	SV061	DA1NO	D/A output channel 1 data No.	(Note) With 2-axes drive unit (MDS-R-V2), set "0" for the data No. of the other axis of the same drive unit which does not execute a D/A output.
2262	SV062	DA2NO	D/A output channel 2 data No.	

No.	Output data	Standard output unit	Output cycle
0	D/A output not selected		
1	Speed feedback	1000 (r/min) / 0.5V	0.8ms
2	Current feedback	Stall current / 0.5V	0.8ms
3	Speed command	1000 (r/min) / 0.5V	0.8ms
4	Current command	Stall current / 0.5V	0.8ms
5			
6			
7	Estimated disturbance torque	Stall current / 0.5V	0.8ms
8			
9			
10			
11	Position droop	mm / 0.5V	3.5ms
12	Position droop (x10)	100 μ m / 0.5V	3.5ms
13	Position droop (x100)	10 μ m / 0.5V	3.5ms
14	Feedrate (F Δ T)	10000(mm/min) / 0.5V	0.8ms
15	Feedrate (F Δ T x 10)	1000(mm/min) / 0.5V	0.8ms
16	Model position droop	mm / 0.5V	3.5ms
17	Model position droop (x10)	100 μ m / 0.5V	3.5ms
18	Model position droop (x100)	10 μ m / 0.5V	3.5ms
19			
20			
21	Load level	100% / 0.5V	0.1s
22			
23	Regenerative load level	100% / 0.5V	0.9s
24			
25			
26			
27			
28			
29			
30			
31 to 99	No setting		
100	2.5V test output	-	-
101	Saw-tooth wave test output	0 to 5V Cycle: 113.7ms	0.8ms
102	Rectangular wave test output	0 to 5V Cycle: 227.5ms	0.8ms
103 to	Setting prohibited		

7. SERVO PARAMETERS
7.5 Supplement

(c) Setting the output scale

When "0" is set, the output will be made with the standard output unit. To change the output unit, set a value other than "0".

The scale is set with a 1/256 unit. When 256 is set, the unit will be the same as the standard output.

#	No.	Abbrev	Parameter name
2263	SV063	DA1MPY	D/A output channel 1 output scale
2264	SV064	DA2MPY	D/A output channel 2 output scale

(Example 1) When SV061 = 11, SV063 = 2560

Position droop is output by 0.1mm/V increment to D/A output ch.1.

(Example 2) When SV063 = 11, SV064 = 128

The position droop will be output with a 2mm/Vunit to D/A output ch.2.

7.5.2 Electronic gears

The servo drive unit has internal electronic gears. The command value from the NC is converted into a detector resolution unit to carry out position control. The electronic gears are single gear ratios calculated from multiple parameters as shown below. However, each value (ELG1, ELG2) must be less than 32767. If the value overflows, the initial parameter error (alarm 37) or error parameter No.2301 will be output. If an alarm occurs, the mechanical specifications and electrical specifications must be revised so that the electronic gears are within the specifications range.

<For semi-closed loop control>

$$\text{Reduced fraction of } \frac{\text{ELG1}}{\text{ELG2}} = \frac{\text{PC2} \times \text{RNG1}}{\text{PC1} \times \text{PIT} \times \text{IUNIT}} \quad (\text{reduced fraction})$$

IUNIT = 2/NC command unit (μm)

1μm : IUNIT = 2, 0.1μm : IUNIT = 20

When the above is calculated, the following conditions must be satisfied.

ELG1 ≤ 32767

ELG2 ≤ 32767

<For full-closed loop control>

$$\text{Reduced fraction of } \frac{\text{PGNX}}{\text{PGNY}} = \frac{\text{PC2} \times \text{RNG2} \times \text{PGN1}}{\text{PC1} \times \text{RNG1} \times 30} \quad (\text{reduced fraction})$$

When the above is calculated, the following conditions must be satisfied.

PGNX ≤ 32767

PGNY ≤ 32767

And,

$$\text{Reduced fraction of } \frac{\text{PGNXsp}}{\text{PGNYsp}} = \frac{\text{PC2} \times \text{RNG2} \times \text{PGN1sp}}{\text{PC1} \times \text{RNG1} \times 30} \quad (\text{reduced fraction})$$

When the above is calculated, the following conditions must be satisfied.

PGNXsp ≤ 32767

PGNYsp ≤ 32767

7. SERVO PARAMETERS
7.5 Supplement

7.5.3 Lost motion compensation


When the motor is to rotate in the clockwise direction (looking from the load side) at the command for the + direction, the command direction is CW. Conversely, when the motor is to rotate in the counterclockwise direction, the command direction is CCW.

This rotation direction can be set with the CNC machine parameters. Note that the meaning of the ± will differ for some servo parameters according to this motor rotation direction. The servo parameters affected by CW/CCW are shown below.

SV016 (LMC1), SV041 (LMC2) (When different values are set for SV016 and SV041)
SV031 (OVS1), SV042 (OVS2) (When different values are set for SV031 and SV042)

<Example> If the lost motion compensation amount is to be changed according to the direction, the compensation amount at the quadrant changeover point of each arc where the lost motion compensation is applied will be as shown below according to the command polarity.

	CW	CCW
A	X: SV041	X: SV016
B	Y: SV016	Y: SV041
C	X: SV016	X: SV041
D	Y: SV041	Y: SV016



(Note) The setting value for the parameter is "0" or "-1", the compensation amount is determined as shown below.

Setting value for SV016 (Setting value for SV031)	Setting value for SV041 (Setting value for SV041)	Compensation amount in + direction	Compensation amount in - direction
0	0	No compensation	No compensation
n	0	n	n
0	m	m	m
n	m	n	m
n	-1	n	No compensation
-1	m	No compensation	m

8. SPINDLE PARAMETERS

The spindle parameter setting and display method will differ according to the CNC being used, so refer to Instruction Manual for each CNC and the following spindles.

MELDAS AC Servo and Spindle MDS-A Series MDS-B Series Specifications Manual BNP-B3759

8.1 Spindle Base Specifications Parameters


For parameters indicated with a (PR) in the table, turn the NC power OFF after setting. The setting is validated after the power is turned ON again.

No.	Items	Details	Setting range (Unit)	
3001 3002 3003 3004	slimit 1 2 3 4	Limit rotation speed	Set spindle rotation speed for maximum motor rotation speed with gears 00, 01, 10, 11. (Set the spindle speed for the S analog output 10V.)	
3005 3006 3007 3008	smax 1 2 3 4	Maximum rotation speed		
3009 3010 3011 3012	ssift 1 2 3 4	Shift rotation speed		Set spindle speed for gear shifting with gears 00, 01, 10, 11. (Note) Setting too large value may cause a gear nicks when changing gears.
3013 3014 3015 3016	stap 1 2 3 4	Tap rotation speed		
3017 3018 3019 3020	stapt 1 2 3 4	Tap time constant	Set time constants for constant inclination synchronous tap cycles for gears 00, 01, 10, 11 (linear acceleration/ deceleration pattern).	


8. SPINDLE PARAMETERS

8.1 Spindle Base Specifications Parameters

Relationship between spindle limit rotation speed and maximum spindle rotation speed



Relation between the spindle limit rotation speed and the spindle tap time constant (for the constant inclination synchronous tap cycle)



8. SPINDLE PARAMETERS
8.1 Spindle Base Specifications Parameters

#	Items	Details	Setting range (Unit)	
3021	sori	Orientation rotation speed	Set the spindle orientation rotation speed. Set the rotation speed for when the spindle rotates at the constant rotation speed.	0 to 32767 (r/min)
3022	sgear	Encoder gear ratio	Set the gear ratio of the spindle to the encoder.	0: 1/1 1: 1/2 2: 1/4 3: 1/8
3023	smini	Minimum rotation speed	Set the minimum rotation speed of the spindle. If an S command instructs the rotation speed below this setting, the spindle rotates at the minimum rotation speed set by this parameter.	0 to 32767 (r/min)
3024 (PR)	sout	Spindle connection	Set the type of the spindle to be connected. 0: No connection with the spindle 1: Serial connection (bus) 2 to 5: Analog output	0 to 5
3025	enc-on	Spindle encoder	Set connection information of the spindle encoder. 0: No connection 1: Spindle connection (Spindle encoder connection check function valid.) 2: Serial connection of encoder	0 to 2
3026	cs_ori	Selection of winding in orientation mode	0: Perform orientation using the winding selected when the orientation command is issued. 1: Use winding L whenever the orientation command is issued.	0/1
3027	cs_syn	Selection of winding in spindle synchronous mode	0: The winding H/L is selected by the actual spindle motor rotation speed (calculated from commanded rotation speed) when spindle synchronous control starts. (The winding is not switched during synchronous control. The control is carried out with the winding selected at start.) If the actual spindle motor rotation speed is less than SP020, the winding L is selected, and if more than the value, the winding H is selected. 1: Use winding H whenever the spindle synchronous command is issued.	0/1
3028	sprcmm	L system tap cycle spindle forward run/reverse run M command	Set the M code of the spindle forward run/reverse run command. High-order three digits: The spindle forward run command's M code is set. Low-order three digits: The spindle reverse run command's M code is set.	0 to 999999

8. SPINDLE PARAMETERS
8.1 Spindle Base Specifications Parameters

#	Items	Details	Setting range (Unit)	
3029	tapsel	Asynchronous tap gear selection	Specify whether to use the tap rotation speed or maximum rotation speed for the gear that is selected when an asynchronous tap command is issued. 0: Tap rotation speed 1: Maximum rotation speed This parameter is valid only when the M-function synchronous tap cycle enable parameter (#1272 ext08 bit1) is ON.	0/1
3030 (PR)		(Not used.)		
3031 (PR)	smcp_no	Drive unit I/F channel No. (spindle)	Using a 4-digit number, set the interface channel No. and which axis in that channel is to be used when connecting a spindle drive unit. High-order two digits : Interface channel No. Low-order two digits : Axis No. When using the conventional fixed layout, set all axes to "0000". Set "0000" when using an analog spindle.	0000 0101 to 0107 0201 to 0207
3032 (PR)		(Not used.)		
3036	tap_errm	Synchronous tap tolerable error width	Set the tolerable value for synchronous tap error width. When "0" is set, synchronous tap error monitoring will not be executed.	0 to 1000 (μs)
3037	taps21	Synchronous tap switching spindle speed 2	Set the spindle rotation speed at which the step-2 acceleration/deceleration time constant is to be switched at gear 00, 01, 10, or 11.	0 to 99999 (r/min)
3038	22			
3039	23			
3040	24			
3041	tapt 21	Synchronous tap switching time constant 2	Set the time constant to reach synchronous tap switching spindle rotation speed 2 (#3037 to #3040) at gear 00, 01, 10, or 11.	1 to 5000 (ms)
3042	22			
3043	23			
3044	24			
3045	tapt 31	Synchronous tap switching time constant 3	Set the time constant to reach the maximum rotation speed (#3005 to #3008) at gear 00, 01, 10, or 11.	1 to 5000 (ms)
3046	32			
3047	33			
3048	34			

8. SPINDLE PARAMETERS
8.1 Spindle Base Specifications Parameters

#	Items	Details	Setting range (Unit)	
3049	spt	Spindle synchronization acceleration/ deceleration time constant	Set the acceleration/deceleration time constant for when the spindle synchronization command's rotation speed changes during spindle synchronous control.	0 to 9999 (ms)
3050	sprlv	Spindle synchronization rotation speed attainment level	The spindle rotation speed synchronization complete signal will turn ON when the difference of the reference spindle and synchronous spindle actual rotation speeds is less than the level set for the synchronous spindle rotation speed command value during spindle synchronous control.	0 to 4095 (pulse) (1 pulse = 0.088°)
3051	spplv	Spindle phase synchronization attainment level	The spindle phase synchronization complete signal will turn ON when the phase difference of the reference spindle and synchronous spindle is less than the set level during spindle phase synchronization control.	0 to 4095 (pulse) (1 pulse = 0.088°)
3052	spplr	Spindle motor spindle relative polarity	Set the spindle motor and spindle's relative polarity. Spindle CW rotation at motor CW rotation: Positive polarity Spindle CCW rotation at motor CW rotation: Negative polarity	0: Positive polarity 1: Negative polarity
3053	sppst	Spindle encoder Z -phase position	Set the deviation amount from the spindle's reference position to the spindle encoder's Z phase. The deviation amount is obtained using the clockwise direction looking from the front of the spindle as the positive direction.	0 to 359999 (1/1000°)
3054	sptc1	Spindle synchronization multi-step acceleration/ deceleration changeover speed 1	Set the spindle speed for changing the 1st step's acceleration/deceleration time constant.	0 to 99999 (r/min)

8. SPINDLE PARAMETERS
8.1 Spindle Base Specifications Parameters

#	Items	Details	Setting range (Unit)
3055	sptc2 Spindle synchronization multi-step acceleration/deceleration changeover speed 2	Set the spindle speed for changing the 2nd step's acceleration/deceleration time constant.	0 to 99999 (r/min)
3056	sptc3 Spindle synchronization multi-step acceleration/deceleration changeover speed 3	Set the spindle speed for changing the 3rd step's acceleration/deceleration time constant.	0 to 99999 (r/min)
3057	sptc4 Spindle synchronization multi-step acceleration/deceleration changeover speed 4	Set the spindle speed for changing the 4th step's acceleration/deceleration time constant.	0 to 99999 (r/min)
3058	sptc5 Spindle synchronization multi-step acceleration/deceleration changeover speed 5	Set the spindle speed for changing the 5th step's acceleration/deceleration time constant.	0 to 99999 (r/min)
3059	sptc6 Spindle synchronization multi-step acceleration/deceleration changeover speed 6	Set the spindle speed for changing the 6th step's acceleration/deceleration time constant.	0 to 99999 (r/min)

8. SPINDLE PARAMETERS
8.1 Spindle Base Specifications Parameters

#	Items	Details	Setting range (Unit)
3060	sptc7 Spindle synchronization multi-step acceleration/deceleration changeover speed 7	Set the spindle speed for changing the 7th step's acceleration/deceleration time constant.	0 to 99999 (r/min)
3061	spdiv1 Magnification for time constant changeover speed 1	Set the acceleration/deceleration time constant between the spindle synchronization multi-step acceleration/deceleration changeover speed 1 (sptc1) to the spindle synchronization multi-step acceleration/deceleration changeover speed 2 (sptc2) as a magnification in respect to the spindle synchronization acceleration/deceleration time constant (spt).	0 to 127
3062	spdiv2 Magnification for time constant changeover speed 2	Set the acceleration/deceleration time constant between the spindle synchronization multi-step acceleration/deceleration changeover speed 2 (sptc2) to the spindle synchronization multi-step acceleration/deceleration changeover speed 3 (sptc3) as a magnification in respect to the spindle synchronization acceleration/deceleration time constant (spt).	0 to 127
3063	spdiv3 Magnification for time constant changeover speed 3	Set the acceleration/deceleration time constant between the spindle synchronization multi-step acceleration/deceleration changeover speed 3 (sptc3) to the spindle synchronization multi-step acceleration/deceleration changeover speed 4 (sptc4) as a magnification in respect to the spindle synchronization acceleration/deceleration time constant (spt).	0 to 127
3064	spdiv4 Magnification for time constant changeover speed 4	Set the acceleration/deceleration time constant between the spindle synchronization multi-step acceleration/deceleration changeover speed 4 (sptc4) to the spindle synchronization multi-step acceleration/deceleration changeover speed 5 (sptc5) as a magnification in respect to the spindle synchronization acceleration/deceleration time constant (spt).	0 to 127
3065	spdiv5 Magnification for time constant changeover speed 5	Set the acceleration/deceleration time constant between the spindle synchronization multi-step acceleration/deceleration changeover speed 5 (sptc5) to the spindle synchronization multi-step acceleration/deceleration changeover speed 6 (sptc6) as a magnification in respect to the spindle synchronization acceleration/deceleration time constant (spt).	0 to 127

8. SPINDLE PARAMETERS
8.1 Spindle Base Specifications Parameters

#	Items	Details	Setting range (Unit)
3066	spdiv6 Magnification for time constant changeover speed 6	Set the acceleration/deceleration time constant between the spindle synchronization multi-step acceleration/deceleration changeover speed 6 (sptc6) to the spindle synchronization multi-step acceleration/deceleration changeover speed 7 (sptc7) as a magnification in respect to the spindle synchronization acceleration/deceleration time constant (spt).	0 to 127
3067	spdiv7 Magnification for time constant changeover speed 7	Set the acceleration/deceleration time constant for the spindle synchronization multi-step acceleration/deceleration changeover speed 7 (sptc7) and higher as a magnification in respect to the spindle synchronization acceleration/deceleration time constant (spt).	0 to 127
3068	symtm1 Phase synchronization start confirmation time	Set the time to confirm that synchronization is attained before phase synchronization control is started. When "0" is set, the time will be 2 seconds. When "100" or less is set, the time will be 100ms.	0 to 9999 (ms)
3069	symtm2 Phase synchronization end confirmation time	Set the time to wait for phase synchronization control to end as the time for the rotation speed to reach the attainment range. When "0" is set, the time will be 2 seconds. When "100" or less is set, the time will be 100ms.	0 to 9999 (ms)
3070	syprt Phase synchronization speed	Set the fluctuation amount to change the synchronous spindle rotation speed during phase synchronization control as the command speed and rate. When "0" is set, the amount will be 100%.	0 to 100 (%)
3071	(Not used.)		
3072	(Not used.)		

8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

8.2 MDS-B-SPJ2

For parameters marked with a (PR) in the tables, turn the NC power OFF after setting. The parameters will be valid after the power is turned ON again.

The valid spindle parameters will differ according to the motor and amplifier type. Follow the correspondence table given below, and set the correct parameters.

The spindle parameter setting and display method will differ according to the NC being used, so refer to Instruction Manual for each NC and the following spindles.

MELDAS AC Servo and Spindle MDS-A Series MDS-B Series Specifications Manual... BNP-B3759

The "fixed control constants" and "fixed control bits" in this section are set by Mitsubishi.

⚠ CAUTION

⚠ Do not make remarkable adjustments or changes of the parameters as the operation may become unstable.

⚠ In the explanation on bits, set all bits not used, including blank bits, to "0".

No.	Items		Details	Setting range	Standard setting	
3201	SP001	PGM	Magnetic detector and motor built-in encoder orientation-mode position loop gain	As the set value is larger, the orientation time becomes shorter and servo rigidity is increased. On the contrary, however, vibration is increased and the machine becomes likely to overshoot.	0 to 1000 (0.1 1/s)	100
3202	SP002	PGE	Encoder orientation-mode position loop gain	As the set value is larger, the orientation time becomes shorter and servo rigidity is increased. On the contrary, however, vibration is increased and the machine becomes likely to overshoot.	0 to 1000 (0.1 1/s)	100
3203	SP003			Not used. Set to "0".	0	0
3204	SP004	OINP	Orientation in-position width	Set the position error range in which an orientation completion signal is output.	1 to 2880 (1/16°)	16
3205 (PR)	SP005	OSP	Orientation mode changing speed limit value	Set the motor speed limit value to be used when the speed loop is changed to the position loop in orientation mode. When this parameter is set to "0", SP017 (TSP) becomes the limit value.	0 to 32767 (r/min)	0
3206	SP006	CSP	Orientation mode deceleration rate	As the set value is larger, the orientation time becomes shorter. On the contrary, however, the machine becomes likely to overshoot.	1 to 1000	20
3207	SP007	OPST	In-position shift amount for orientation	Set the stop position for orientation. Set the value by dividing 360° by 4096.	0 to 4095	0
3208	SP008			Not used. Set to "0".	0	0
3209	SP009	PGT	Synchronous tapping position loop gain	Set the spindle position loop gain in synchronous tapping mode.	1 to 100 (1/s)	15

8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting	
3210	SP010	PGS	Spindle synchronous position loop gain	Set the spindle position loop gain in spindle synchronization mode.	1 to 100 (1/s)	15
3211 to 3216	SP011 to SP016			Use not possible.	0	0
3217 (PR)	SP017	TSP	Maximum motor speed	Set the maximum motor speed of the spindle.	1 to 32767 (r/min)	6000
3218 (PR)	SP018	ZSP	Motor zero speed	Set the motor speed for which zero-speed output is performed.	1 to 1000 (r/min)	50
3219 (PR)	SP019	CSN1	Speed cushion 1	Set the time constant for a speed command from "0" to the maximum speed. (This parameter is invalid in position loop mode.)	0 to 32767 (10ms)	30
3220 (PR)	SP020	SDTS	Speed detection set value	Set the motor speed so for which speed detection output is performed. Usually, the setting value is 10% of SP017 (TSP).	0 to 32767 (r/min)	600
3221	SP021	TLM1	Torque limit 1	Set the torque limit rate for torque limit signal 001.	0 to 120 (%)	10
3222 (PR)	SP022	VGNP1	Speed loop gain proportional term under speed control	Set the speed loop proportional gain in speed control mode. When the gain is increased, response is improved but vibration and sound become larger.	0 to 1000 (1/s)	63
3223 (PR)	SP023	VGNI1	Speed loop gain integral term under speed control	Set the speed loop integral gain in speed control mode. Usually, set a value in proportion to SP022 (VGNP1).	0 to 1000 (0.1 1/s)	60
3224	SP024			Not used. Set to "0".	0	0
3225 (PR)	SP025	GRA1	Spindle gear teeth count 1	Set the number of gear teeth of the spindle corresponding to gear 000.	1 to 32767	1
3226 (PR)	SP026	GRA2	Spindle gear teeth count 2	Set the number of gear teeth of the spindle corresponding to gear 001.	1 to 32767	1
3227 (PR)	SP027	GRA3	Spindle gear teeth count 3	Set the number of gear teeth of the spindle corresponding to gear 010.	1 to 32767	1
3228 (PR)	SP028	GRA4	Spindle gear teeth count 4	Set the number of gear teeth of the spindle corresponding to gear 011.	1 to 32767	1
3229 (PR)	SP029	GRB1	Motor shaft gear teeth count 1	Set the number of gear teeth of the motor shaft corresponding to gear 000.	1 to 32767	1
3230 (PR)	SP030	GRB2	Motor shaft gear teeth count 2	Set the number of gear teeth of the motor shaft corresponding to gear 001.	1 to 32767	1
3231 (PR)	SP031	GRB3	Motor shaft gear teeth count 3	Set the number of gear teeth of the motor shaft corresponding to gear 010.	1 to 32767	1
3232 (PR)	SP032	GRB4	Motor shaft gear teeth count 4	Set the number of gear teeth of the motor shaft corresponding to gear 011.	1 to 32767	1

8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting																																																																																																													
3233 (PR)	SP033	SFNC1	Spindle function 1	Set the spindle function 1 in bit units. <table border="1" style="width:100%; text-align:center;"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td>poff</td><td>hzs</td><td></td><td>ront</td><td></td><td></td><td></td><td></td> </tr> <tr> <td colspan="8"> </td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td></td><td></td><td></td><td></td><td></td><td>sftk</td><td>dftt</td><td>1a2m</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th>bit</th> <th>Name</th> <th>Meaning when set to 0</th> <th>Meaning when set to 1</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1a2m</td> <td>1 amplifier 2 motor function: Invalid</td> <td>1 amplifier 2 motor function: Valid</td> </tr> <tr> <td>1</td> <td>dftt</td> <td>Default motor: Main</td> <td>Default motor: Sub</td> </tr> <tr> <td>2</td> <td>sftk</td> <td>SF-TK card invalid</td> <td>SF-TK card valid</td> </tr> <tr><td>3</td><td></td><td></td><td></td></tr> <tr><td>4</td><td></td><td></td><td></td></tr> <tr><td>5</td><td></td><td></td><td></td></tr> <tr><td>6</td><td></td><td></td><td></td></tr> <tr><td>7</td><td></td><td></td><td></td></tr> <tr><td>8</td><td></td><td></td><td></td></tr> <tr><td>9</td><td></td><td></td><td></td></tr> <tr><td>A</td><td></td><td></td><td></td></tr> <tr> <td>B</td> <td></td> <td colspan="2">This is a fixed control bit.</td> </tr> <tr><td>C</td><td>ront</td><td></td><td></td></tr> <tr><td>D</td><td></td><td></td><td></td></tr> <tr><td>E</td><td>hzs</td><td></td><td></td></tr> <tr><td>F</td><td>poff</td><td></td><td></td></tr> </tbody> </table>	F	E	D	C	B	A	9	8	poff	hzs		ront													7	6	5	4	3	2	1	0						sftk	dftt	1a2m	bit	Name	Meaning when set to 0	Meaning when set to 1	0	1a2m	1 amplifier 2 motor function: Invalid	1 amplifier 2 motor function: Valid	1	dftt	Default motor: Main	Default motor: Sub	2	sftk	SF-TK card invalid	SF-TK card valid	3				4				5				6				7				8				9				A				B		This is a fixed control bit.		C	ront			D				E	hzs			F	poff			0000 to FFFF HEX setting	0000
F	E	D	C	B	A	9	8																																																																																																											
poff	hzs		ront																																																																																																															
7	6	5	4	3	2	1	0																																																																																																											
					sftk	dftt	1a2m																																																																																																											
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																															
0	1a2m	1 amplifier 2 motor function: Invalid	1 amplifier 2 motor function: Valid																																																																																																															
1	dftt	Default motor: Main	Default motor: Sub																																																																																																															
2	sftk	SF-TK card invalid	SF-TK card valid																																																																																																															
3																																																																																																																		
4																																																																																																																		
5																																																																																																																		
6																																																																																																																		
7																																																																																																																		
8																																																																																																																		
9																																																																																																																		
A																																																																																																																		
B		This is a fixed control bit.																																																																																																																
C	ront																																																																																																																	
D																																																																																																																		
E	hzs																																																																																																																	
F	poff																																																																																																																	
3234 (PR)	SP034	SFNC2	Spindle function 2	Set the spindle function 2 in bit units. <table border="1" style="width:100%; text-align:center;"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td colspan="8"> </td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>mts1</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th>bit</th> <th>Name</th> <th>Meaning when set to 0</th> <th>Meaning when set to 1</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>mts1</td> <td>Special motor constant invalid</td> <td>Special motor constant setting valid</td> </tr> <tr><td>1</td><td></td><td></td><td></td></tr> <tr><td>2</td><td></td><td></td><td></td></tr> <tr><td>3</td><td></td><td></td><td></td></tr> <tr><td>4</td><td></td><td></td><td></td></tr> <tr><td>5</td><td></td><td></td><td></td></tr> <tr><td>6</td><td></td><td></td><td></td></tr> <tr><td>7</td><td></td><td></td><td></td></tr> <tr><td>8</td><td></td><td></td><td></td></tr> <tr><td>9</td><td></td><td></td><td></td></tr> <tr><td>A</td><td></td><td></td><td></td></tr> <tr><td>B</td><td></td><td></td><td></td></tr> <tr><td>C</td><td></td><td></td><td></td></tr> <tr><td>D</td><td></td><td></td><td></td></tr> <tr><td>E</td><td></td><td></td><td></td></tr> <tr><td>F</td><td></td><td></td><td></td></tr> </tbody> </table>	F	E	D	C	B	A	9	8																	7	6	5	4	3	2	1	0								mts1	bit	Name	Meaning when set to 0	Meaning when set to 1	0	mts1	Special motor constant invalid	Special motor constant setting valid	1				2				3				4				5				6				7				8				9				A				B				C				D				E				F				0000 to FFFF HEX setting	0000
F	E	D	C	B	A	9	8																																																																																																											
7	6	5	4	3	2	1	0																																																																																																											
							mts1																																																																																																											
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																															
0	mts1	Special motor constant invalid	Special motor constant setting valid																																																																																																															
1																																																																																																																		
2																																																																																																																		
3																																																																																																																		
4																																																																																																																		
5																																																																																																																		
6																																																																																																																		
7																																																																																																																		
8																																																																																																																		
9																																																																																																																		
A																																																																																																																		
B																																																																																																																		
C																																																																																																																		
D																																																																																																																		
E																																																																																																																		
F																																																																																																																		

8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting																																																																																																				
3235 (PR)	SP035	SFNC3 Spindle function3	Set the spindle function 3 in bit units. <table border="1" style="width:100%; text-align:center;"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td>hbsd</td><td><input type="checkbox"/></td><td>hwid</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th>bit</th> <th>Name</th> <th>Meaning when set to 0</th> <th>Meaning when set to 1</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>hwid</td> <td>H-coil wide-range constant output invalid</td> <td>H-coil wide-range constant output valid</td> </tr> <tr> <td>1</td> <td></td> <td></td> <td></td> </tr> <tr> <td>2</td> <td>hbsd</td> <td>H-coil base slide invalid</td> <td>H-coil base slide valid</td> </tr> <tr> <td>3</td> <td></td> <td></td> <td></td> </tr> <tr> <td>4</td> <td></td> <td></td> <td></td> </tr> <tr> <td>5</td> <td></td> <td></td> <td></td> </tr> <tr> <td>6</td> <td></td> <td></td> <td></td> </tr> <tr> <td>7</td> <td></td> <td></td> <td></td> </tr> <tr> <td>8</td> <td></td> <td></td> <td></td> </tr> <tr> <td>9</td> <td></td> <td></td> <td></td> </tr> <tr> <td>A</td> <td></td> <td></td> <td></td> </tr> <tr> <td>B</td> <td></td> <td></td> <td></td> </tr> <tr> <td>C</td> <td></td> <td></td> <td></td> </tr> <tr> <td>D</td> <td></td> <td></td> <td></td> </tr> <tr> <td>E</td> <td></td> <td></td> <td></td> </tr> <tr> <td>F</td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	F	E	D	C	B	A	9	8	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	7	6	5	4	3	2	1	0	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	hbsd	<input type="checkbox"/>	hwid	bit	Name	Meaning when set to 0	Meaning when set to 1	0	hwid	H-coil wide-range constant output invalid	H-coil wide-range constant output valid	1				2	hbsd	H-coil base slide invalid	H-coil base slide valid	3				4				5				6				7				8				9				A				B				C				D				E				F				0000 to FFFF HEX setting	0000
F	E	D	C	B	A	9	8																																																																																																		
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																																																																																		
7	6	5	4	3	2	1	0																																																																																																		
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	hbsd	<input type="checkbox"/>	hwid																																																																																																		
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																						
0	hwid	H-coil wide-range constant output invalid	H-coil wide-range constant output valid																																																																																																						
1																																																																																																									
2	hbsd	H-coil base slide invalid	H-coil base slide valid																																																																																																						
3																																																																																																									
4																																																																																																									
5																																																																																																									
6																																																																																																									
7																																																																																																									
8																																																																																																									
9																																																																																																									
A																																																																																																									
B																																																																																																									
C																																																																																																									
D																																																																																																									
E																																																																																																									
F																																																																																																									
3236 (PR)	SP036	SFNC4 Spindle function 4	Set the spindle function 4 in bit units. <table border="1" style="width:100%; text-align:center;"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td>dslm</td><td>dssm</td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td><input type="checkbox"/></td><td><input type="checkbox"/></td><td>enc2</td><td>enc1</td><td>mag2</td><td>mag1</td><td>plg2</td><td>plg1</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th>bit</th> <th>Name</th> <th>Meaning when set to 0</th> <th>Meaning when set to 1</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>plg1</td> <td>PLG of motor 1 valid</td> <td>PLG of motor 1 invalid</td> </tr> <tr> <td>1</td> <td>plg2</td> <td>PLG of motor 2 valid</td> <td>PLG of motor 2 invalid</td> </tr> <tr> <td>2</td> <td>mag1</td> <td>MAG of motor 1 valid</td> <td>MAG of motor 1 invalid</td> </tr> <tr> <td>3</td> <td>mag2</td> <td>MAG of motor 2 valid</td> <td>MAG of motor 2 invalid</td> </tr> <tr> <td>4</td> <td>enc1</td> <td>ENC of motor 1 valid</td> <td>ENC of motor 1 invalid</td> </tr> <tr> <td>5</td> <td>enc2</td> <td>ENC of motor 2 valid</td> <td>ENC of motor 2 invalid</td> </tr> <tr> <td>6</td> <td></td> <td></td> <td></td> </tr> <tr> <td>7</td> <td></td> <td></td> <td></td> </tr> <tr> <td>8</td> <td>dssm</td> <td>Speedometer valid</td> <td>Speedometer invalid</td> </tr> <tr> <td>9</td> <td>dslm</td> <td>Load meter valid</td> <td>Load meter invalid</td> </tr> <tr> <td>A</td> <td></td> <td></td> <td></td> </tr> <tr> <td>B</td> <td></td> <td></td> <td></td> </tr> <tr> <td>C</td> <td></td> <td></td> <td></td> </tr> <tr> <td>D</td> <td></td> <td></td> <td></td> </tr> <tr> <td>E</td> <td></td> <td></td> <td></td> </tr> <tr> <td>F</td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	F	E	D	C	B	A	9	8	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	dslm	dssm	7	6	5	4	3	2	1	0	<input type="checkbox"/>	<input type="checkbox"/>	enc2	enc1	mag2	mag1	plg2	plg1	bit	Name	Meaning when set to 0	Meaning when set to 1	0	plg1	PLG of motor 1 valid	PLG of motor 1 invalid	1	plg2	PLG of motor 2 valid	PLG of motor 2 invalid	2	mag1	MAG of motor 1 valid	MAG of motor 1 invalid	3	mag2	MAG of motor 2 valid	MAG of motor 2 invalid	4	enc1	ENC of motor 1 valid	ENC of motor 1 invalid	5	enc2	ENC of motor 2 valid	ENC of motor 2 invalid	6				7				8	dssm	Speedometer valid	Speedometer invalid	9	dslm	Load meter valid	Load meter invalid	A				B				C				D				E				F					
F	E	D	C	B	A	9	8																																																																																																		
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	dslm	dssm																																																																																																		
7	6	5	4	3	2	1	0																																																																																																		
<input type="checkbox"/>	<input type="checkbox"/>	enc2	enc1	mag2	mag1	plg2	plg1																																																																																																		
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																						
0	plg1	PLG of motor 1 valid	PLG of motor 1 invalid																																																																																																						
1	plg2	PLG of motor 2 valid	PLG of motor 2 invalid																																																																																																						
2	mag1	MAG of motor 1 valid	MAG of motor 1 invalid																																																																																																						
3	mag2	MAG of motor 2 valid	MAG of motor 2 invalid																																																																																																						
4	enc1	ENC of motor 1 valid	ENC of motor 1 invalid																																																																																																						
5	enc2	ENC of motor 2 valid	ENC of motor 2 invalid																																																																																																						
6																																																																																																									
7																																																																																																									
8	dssm	Speedometer valid	Speedometer invalid																																																																																																						
9	dslm	Load meter valid	Load meter invalid																																																																																																						
A																																																																																																									
B																																																																																																									
C																																																																																																									
D																																																																																																									
E																																																																																																									
F																																																																																																									

8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting																																																																																																				
3237 (PR)	SP037	SFNC5 Spindle function 5	Set the spindle function 5 in bit units. <table border="1" style="width:100%; text-align:center;"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td>nstv</td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td>plgo</td><td><input type="checkbox"/></td><td>enco</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th>bit</th> <th>Name</th> <th>Meaning when set to 0</th> <th>Meaning when set to 1</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>enco</td> <td>Encoder orientation invalid</td> <td>Encoder orientation valid</td> </tr> <tr> <td>1</td> <td></td> <td></td> <td></td> </tr> <tr> <td>2</td> <td>plgo</td> <td>PLG orientation invalid</td> <td>PLG orientation valid</td> </tr> <tr> <td>3</td> <td></td> <td></td> <td></td> </tr> <tr> <td>4</td> <td></td> <td></td> <td></td> </tr> <tr> <td>5</td> <td></td> <td></td> <td></td> </tr> <tr> <td>6</td> <td></td> <td></td> <td></td> </tr> <tr> <td>7</td> <td></td> <td></td> <td></td> </tr> <tr> <td>8</td> <td>nstv</td> <td>No-signal detection type (Always monitoring)</td> <td>Monitoring only in position loop or orientation-mode</td> </tr> <tr> <td>9</td> <td></td> <td></td> <td></td> </tr> <tr> <td>A</td> <td></td> <td></td> <td></td> </tr> <tr> <td>B</td> <td></td> <td></td> <td></td> </tr> <tr> <td>C</td> <td></td> <td></td> <td></td> </tr> <tr> <td>D</td> <td></td> <td></td> <td></td> </tr> <tr> <td>E</td> <td></td> <td></td> <td></td> </tr> <tr> <td>F</td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	F	E	D	C	B	A	9	8	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	nstv	7	6	5	4	3	2	1	0	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	plgo	<input type="checkbox"/>	enco	bit	Name	Meaning when set to 0	Meaning when set to 1	0	enco	Encoder orientation invalid	Encoder orientation valid	1				2	plgo	PLG orientation invalid	PLG orientation valid	3				4				5				6				7				8	nstv	No-signal detection type (Always monitoring)	Monitoring only in position loop or orientation-mode	9				A				B				C				D				E				F				0000 to FFFF HEX setting	0000
F	E	D	C	B	A	9	8																																																																																																		
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	nstv																																																																																																		
7	6	5	4	3	2	1	0																																																																																																		
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	plgo	<input type="checkbox"/>	enco																																																																																																		
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																						
0	enco	Encoder orientation invalid	Encoder orientation valid																																																																																																						
1																																																																																																									
2	plgo	PLG orientation invalid	PLG orientation valid																																																																																																						
3																																																																																																									
4																																																																																																									
5																																																																																																									
6																																																																																																									
7																																																																																																									
8	nstv	No-signal detection type (Always monitoring)	Monitoring only in position loop or orientation-mode																																																																																																						
9																																																																																																									
A																																																																																																									
B																																																																																																									
C																																																																																																									
D																																																																																																									
E																																																																																																									
F																																																																																																									
3238 (PR)	SP038	SFNC6 Spindle function 6	Set the spindle function 6 in bit units. <table border="1" style="width:100%; text-align:center;"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td>opl</td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td>pftm</td><td><input type="checkbox"/></td><td>alty</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th>bit</th> <th>Name</th> <th>Meaning when set to 0</th> <th>Meaning when set to 1</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>alty</td> <td>Deceleration stop during special alarm invalid</td> <td>Deceleration stop during special alarm valid</td> </tr> <tr> <td>1</td> <td></td> <td></td> <td></td> </tr> <tr> <td>2</td> <td>pftm</td> <td>Thread cutting position data invalid</td> <td>Thread cutting position data valid</td> </tr> <tr> <td>3</td> <td></td> <td></td> <td></td> </tr> <tr> <td>4</td> <td></td> <td></td> <td></td> </tr> <tr> <td>5</td> <td></td> <td></td> <td></td> </tr> <tr> <td>6</td> <td></td> <td></td> <td></td> </tr> <tr> <td>7</td> <td></td> <td></td> <td></td> </tr> <tr> <td>8</td> <td></td> <td></td> <td></td> </tr> <tr> <td>9</td> <td></td> <td></td> <td></td> </tr> <tr> <td>A</td> <td></td> <td></td> <td></td> </tr> <tr> <td>B</td> <td></td> <td></td> <td></td> </tr> <tr> <td>C</td> <td></td> <td></td> <td></td> </tr> <tr> <td>D</td> <td></td> <td></td> <td></td> </tr> <tr> <td>E</td> <td></td> <td></td> <td></td> </tr> <tr> <td>F</td> <td>opl</td> <td>Open loop operation invalid</td> <td>Open loop operation valid</td> </tr> </tbody> </table>	F	E	D	C	B	A	9	8	opl	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	7	6	5	4	3	2	1	0	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	pftm	<input type="checkbox"/>	alty	bit	Name	Meaning when set to 0	Meaning when set to 1	0	alty	Deceleration stop during special alarm invalid	Deceleration stop during special alarm valid	1				2	pftm	Thread cutting position data invalid	Thread cutting position data valid	3				4				5				6				7				8				9				A				B				C				D				E				F	opl	Open loop operation invalid	Open loop operation valid	0000 to FFFF HEX setting	0000
F	E	D	C	B	A	9	8																																																																																																		
opl	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																																																																																		
7	6	5	4	3	2	1	0																																																																																																		
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	pftm	<input type="checkbox"/>	alty																																																																																																		
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																						
0	alty	Deceleration stop during special alarm invalid	Deceleration stop during special alarm valid																																																																																																						
1																																																																																																									
2	pftm	Thread cutting position data invalid	Thread cutting position data valid																																																																																																						
3																																																																																																									
4																																																																																																									
5																																																																																																									
6																																																																																																									
7																																																																																																									
8																																																																																																									
9																																																																																																									
A																																																																																																									
B																																																																																																									
C																																																																																																									
D																																																																																																									
E																																																																																																									
F	opl	Open loop operation invalid	Open loop operation valid																																																																																																						


8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting																																												
3239 (PR)	SP039	ATYP	Amplifier type Set the amplifier type. Set each amplifier type or "0". This parameter corresponds to MDS-B-SPJ2. <table border="1" style="margin: 10px auto; width: 80%;"> <thead> <tr> <th style="text-align: center;">Parameter setting</th> <th style="text-align: center;">Amplifier type</th> </tr> </thead> <tbody> <tr><td style="text-align: center;">0000</td><td style="text-align: center;">--</td></tr> <tr><td style="text-align: center;">0001</td><td style="text-align: center;">SPJ2-02</td></tr> <tr><td style="text-align: center;">0002</td><td style="text-align: center;">SPJ2-04</td></tr> <tr><td style="text-align: center;">0003</td><td style="text-align: center;">SPJ2-075</td></tr> <tr><td style="text-align: center;">0004</td><td style="text-align: center;">SPJ2-15</td></tr> <tr><td style="text-align: center;">0005</td><td style="text-align: center;">SPJ2-22</td></tr> <tr><td style="text-align: center;">0006</td><td style="text-align: center;">SPJ2-37</td></tr> <tr><td style="text-align: center;">0007</td><td style="text-align: center;">SPJ2-55</td></tr> <tr><td style="text-align: center;">0008</td><td style="text-align: center;">SPJ2-75</td></tr> <tr><td style="text-align: center;">0009</td><td style="text-align: center;">SPJ2-110/110C</td></tr> </tbody> </table>	Parameter setting	Amplifier type	0000	--	0001	SPJ2-02	0002	SPJ2-04	0003	SPJ2-075	0004	SPJ2-15	0005	SPJ2-22	0006	SPJ2-37	0007	SPJ2-55	0008	SPJ2-75	0009	SPJ2-110/110C	0000 to FFFF HEX setting	0000																						
Parameter setting	Amplifier type																																																
0000	--																																																
0001	SPJ2-02																																																
0002	SPJ2-04																																																
0003	SPJ2-075																																																
0004	SPJ2-15																																																
0005	SPJ2-22																																																
0006	SPJ2-37																																																
0007	SPJ2-55																																																
0008	SPJ2-75																																																
0009	SPJ2-110/110C																																																
3240 (PR)	SP040	MTYP	Motor type This is valid when SP034 (SFNC2) bit 0 is set to 0. Refer to the following standard motors, and set the applicable motor number. <table border="1" style="margin: 10px auto; width: 80%;"> <thead> <tr> <th style="text-align: center;">Parameter setting</th> <th style="text-align: center;">Motor type</th> <th style="text-align: center;">Maximum speed</th> <th style="text-align: center;">Corresponding amplifier</th> </tr> </thead> <tbody> <tr><td style="text-align: center;">1000</td><td></td><td></td><td></td></tr> <tr><td style="text-align: center;">1001</td><td style="text-align: center;">SJ-P0.2A</td><td style="text-align: center;">10000 r/min</td><td style="text-align: center;">SPJ2-02</td></tr> <tr><td style="text-align: center;">1002</td><td style="text-align: center;">SJ-P0.4A</td><td style="text-align: center;">10000 r/min</td><td style="text-align: center;">SPJ2-04</td></tr> <tr><td style="text-align: center;">1003</td><td style="text-align: center;">SJ-P0.75A</td><td style="text-align: center;">10000 r/min</td><td style="text-align: center;">SPJ2-075</td></tr> <tr><td style="text-align: center;">1004</td><td style="text-align: center;">SJ-P1.5A</td><td style="text-align: center;">10000 r/min</td><td style="text-align: center;">SPJ2-15</td></tr> <tr><td style="text-align: center;">1005</td><td style="text-align: center;">SJ-P2.2A</td><td style="text-align: center;">8000 r/min</td><td style="text-align: center;">SPJ2-22</td></tr> <tr><td style="text-align: center;">1006</td><td style="text-align: center;">SJ-P3.7A</td><td style="text-align: center;">8000 r/min</td><td style="text-align: center;">SPJ2-37</td></tr> <tr><td style="text-align: center;">1007</td><td style="text-align: center;">SJ-PF5.5-01</td><td style="text-align: center;">8000 r/min</td><td style="text-align: center;">SPJ2-55</td></tr> <tr><td style="text-align: center;">1008</td><td style="text-align: center;">SJ-PF7.5-01</td><td style="text-align: center;">8000 r/min</td><td style="text-align: center;">SPJ2-75</td></tr> <tr><td style="text-align: center;">1009</td><td style="text-align: center;">SJ-PF11-01</td><td style="text-align: center;">6000 r/min</td><td style="text-align: center;">SPJ2-110/110C</td></tr> </tbody> </table>	Parameter setting	Motor type	Maximum speed	Corresponding amplifier	1000				1001	SJ-P0.2A	10000 r/min	SPJ2-02	1002	SJ-P0.4A	10000 r/min	SPJ2-04	1003	SJ-P0.75A	10000 r/min	SPJ2-075	1004	SJ-P1.5A	10000 r/min	SPJ2-15	1005	SJ-P2.2A	8000 r/min	SPJ2-22	1006	SJ-P3.7A	8000 r/min	SPJ2-37	1007	SJ-PF5.5-01	8000 r/min	SPJ2-55	1008	SJ-PF7.5-01	8000 r/min	SPJ2-75	1009	SJ-PF11-01	6000 r/min	SPJ2-110/110C	0000 to FFFF HEX setting	0000
Parameter setting	Motor type	Maximum speed	Corresponding amplifier																																														
1000																																																	
1001	SJ-P0.2A	10000 r/min	SPJ2-02																																														
1002	SJ-P0.4A	10000 r/min	SPJ2-04																																														
1003	SJ-P0.75A	10000 r/min	SPJ2-075																																														
1004	SJ-P1.5A	10000 r/min	SPJ2-15																																														
1005	SJ-P2.2A	8000 r/min	SPJ2-22																																														
1006	SJ-P3.7A	8000 r/min	SPJ2-37																																														
1007	SJ-PF5.5-01	8000 r/min	SPJ2-55																																														
1008	SJ-PF7.5-01	8000 r/min	SPJ2-75																																														
1009	SJ-PF11-01	6000 r/min	SPJ2-110/110C																																														


8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting																																																												
3241 (PR)	SP041	PTYP	Power supply type When this unit is a signal connection axis with power supply unit, set this parameter. Set "0" for this parameter for the unit which is not a signal connection axis. Select a value from the following table according to the regenerative resistance being used. <table border="1" style="margin: 10px auto; width: 80%;"> <thead> <tr> <th style="text-align: center;">Setting value</th> <th style="text-align: center;">Regenerative resistance type</th> <th style="text-align: center;">Resistance value (Ω)</th> <th style="text-align: center;">Capacity (W)</th> </tr> </thead> <tbody> <tr><td style="text-align: center;">0000</td><td style="text-align: center;">-</td><td style="text-align: center;">-</td><td style="text-align: center;">-</td></tr> <tr><td style="text-align: center;">2000</td><td style="text-align: center;">Not connected</td><td style="text-align: center;">-</td><td style="text-align: center;">-</td></tr> <tr><td style="text-align: center;">2100</td><td style="text-align: center;">FCUA-RB04</td><td style="text-align: center;">200</td><td style="text-align: center;">60</td></tr> <tr><td style="text-align: center;">2200</td><td style="text-align: center;">FCUA-RB075</td><td style="text-align: center;">100</td><td style="text-align: center;">80</td></tr> <tr><td style="text-align: center;">2300</td><td style="text-align: center;">FCUA-RB15</td><td style="text-align: center;">60</td><td style="text-align: center;">120</td></tr> <tr><td style="text-align: center;">2400</td><td style="text-align: center;">FCUA-RB22</td><td style="text-align: center;">40</td><td style="text-align: center;">155</td></tr> <tr><td style="text-align: center;">2500</td><td style="text-align: center;">FCUA-RB37</td><td style="text-align: center;">25</td><td style="text-align: center;">185</td></tr> <tr><td style="text-align: center;">2600</td><td style="text-align: center;">FCUA-RB55</td><td style="text-align: center;">20</td><td style="text-align: center;">340</td></tr> <tr><td style="text-align: center;">2700</td><td style="text-align: center;">FCUA-RB75/2</td><td style="text-align: center;">30/15</td><td style="text-align: center;">340/680</td></tr> <tr><td style="text-align: center;">2800</td><td style="text-align: center;">R-UNIT-1</td><td style="text-align: center;">30</td><td style="text-align: center;">700</td></tr> <tr><td style="text-align: center;">2900</td><td style="text-align: center;">R-UNIT-2</td><td style="text-align: center;">15</td><td style="text-align: center;">700</td></tr> <tr><td style="text-align: center;">2A00</td><td style="text-align: center;">R-UNIT-3</td><td style="text-align: center;">15</td><td style="text-align: center;">2100</td></tr> <tr><td style="text-align: center;">2B00</td><td style="text-align: center;">R-UNIT-4</td><td style="text-align: center;">10</td><td style="text-align: center;">2100</td></tr> <tr><td style="text-align: center;">2C00</td><td style="text-align: center;">R-UNIT-5</td><td style="text-align: center;">10</td><td style="text-align: center;">3100</td></tr> </tbody> </table> <p style="margin-top: 10px;">(Note 1) This setting is used when using one FCUA-RB75/2 and when using two in parallel.</p>	Setting value	Regenerative resistance type	Resistance value (Ω)	Capacity (W)	0000	-	-	-	2000	Not connected	-	-	2100	FCUA-RB04	200	60	2200	FCUA-RB075	100	80	2300	FCUA-RB15	60	120	2400	FCUA-RB22	40	155	2500	FCUA-RB37	25	185	2600	FCUA-RB55	20	340	2700	FCUA-RB75/2	30/15	340/680	2800	R-UNIT-1	30	700	2900	R-UNIT-2	15	700	2A00	R-UNIT-3	15	2100	2B00	R-UNIT-4	10	2100	2C00	R-UNIT-5	10	3100	0000 to FFFF HEX setting	0000
Setting value	Regenerative resistance type	Resistance value (Ω)	Capacity (W)																																																														
0000	-	-	-																																																														
2000	Not connected	-	-																																																														
2100	FCUA-RB04	200	60																																																														
2200	FCUA-RB075	100	80																																																														
2300	FCUA-RB15	60	120																																																														
2400	FCUA-RB22	40	155																																																														
2500	FCUA-RB37	25	185																																																														
2600	FCUA-RB55	20	340																																																														
2700	FCUA-RB75/2	30/15	340/680																																																														
2800	R-UNIT-1	30	700																																																														
2900	R-UNIT-2	15	700																																																														
2A00	R-UNIT-3	15	2100																																																														
2B00	R-UNIT-4	10	2100																																																														
2C00	R-UNIT-5	10	3100																																																														
3242 (PR)	SP042		Not used. Set to "0".	0	0																																																												
3243 (PR)	SP043		Not used. Set to "0".	0	0																																																												
3244 (PR)	SP044	TRANS	NC communication frequency Set a frequency of data communication with NC.	0 to 32767	Standard: 0 Special: 1028																																																												
3245	SP045		Not used. Set to "0".	0	0																																																												
3246 (PR)	SP046	CSN2	Speed command dual cushion For an acceleration/deceleration time constant defined in SP019 (CSN1), this parameter is used to provide smooth movement only at the start of acceleration/deceleration. As the value of this parameter is smaller, it moves smoother but the acceleration/deceleration time becomes longer. To make this parameter invalid, set "0".	0 to 1000	0																																																												
3247 (PR)	SP047	SDTR	Speed detection reset value Set the reset hysteresis width for a speed detection set value defined in SP020 (SDTS).	0 to 1000 (r/min)	30																																																												


8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting
3248 (PR)	SP048	SUT	Speed reach range	Set the speed deviation rate with respect to the commanded speed for output of the speed reach signal.	0 to 100 (%) 15
3249	SP049	TLM2	Torque limit 2	Set the torque limit rate for the torque limit signal 010.	1 to 120 (%) 20
3250	SP050	TLM3	Torque limit 3	Set the torque limit rate for the torque limit signal 011.	1 to 120 (%) 30
3251	SP051	TLM4	Torque limit 4	Set the torque limit rate for the torque limit signal 100.	1 to 120 (%) 40
3252	SP052	TLM5	Torque limit 5	Set the torque limit rate for the torque limit signal 101.	1 to 120 (%) 50
3253	SP053	TLM6	Torque limit 6	Set the torque limit rate for the torque limit signal 110.	1 to 120 (%) 60
3254	SP054	TLM7	Torque limit 7	Set the torque limit rate for the torque limit signal 111.	1 to 120 (%) 70
3255 (PR)	SP055	SETM	Excessive speed deviation timer	Set the timer value until the excessive speed deviation alarm is output. The value of this parameter should be longer than the acceleration/deceleration time.	0 to 60 (s) 12
3256	SP056	PYVR	Variable excitation (min value)	Set the minimum value of the variable excitation rate. Select a smaller value when gear noise is too high. However, a larger value is effective for impact response.	0 to 100 (%) 50
3257 (PR)	SP057	STOD	Fixed control constant	Used by Mitsubishi. Set "0" unless designated in particular.	0 0
3258 to 3262	SP058 to SP062			Not used. Set to "0".	0 0
3263 (PR)	SP063	OLT	Overload alarm detection time	Set the time constant for detection of the motor overload alarm.	0 to 1000 (s) 60
3264 (PR)	SP064	OLL	Overload alarm detection level	Set the detection level of the motor overload alarm.	0 to 120 (%) 110
3265 (PR)	SP065	VCGN1	Target value of variable speed loop proportional gain	Set the magnification of speed loop proportional gain with respect to SP022 (VGNP1) at the maximum motor speed defined in SP017 (TSP).	0 to 100 (%) 100
3266 (PR)	SP066	VCSN1	Change starting speed of variable speed loop proportional gain	Set the speed for starting change of speed loop proportional gain. 	0 to 32767 (r/min) 0

8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting																	
3267 (PR)	SP067	VIGWA	Change starting speed of variable current loop gain	Set the speed for starting change of current loop gain.	0 to 32767 (r/min)	0																
3268 (PR)	SP068	VIGWB	Change ending speed of variable current loop gain	Set the speed for ending change of current loop gain.	0 to 32767 (r/min)	0																
3269 (PR)	SP069	VIGN	Target value of variable current loop gain	<p>Set the magnification of current loop gain (torque component and excitation component) for a change ending speed defined in SP068 (VIGWB). When this parameter is set to "0", the magnification is 1.</p>  <p style="text-align: center;">SP069×(1/16)-fold 1-fold Speed SP067 SP068 SP017</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>SP017 (TSP) Maximum motor speed</th> <th>SP067 (VIGWA)</th> <th>SP068 (VIGWB)</th> <th>SP069 (VIGN)</th> </tr> </thead> <tbody> <tr> <td>0 to 6000</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>6001 to 8000</td> <td>5000</td> <td>8000</td> <td>45</td> </tr> <tr> <td>8001 or more</td> <td>5000</td> <td>10000</td> <td>64</td> </tr> </tbody> </table>	SP017 (TSP) Maximum motor speed	SP067 (VIGWA)	SP068 (VIGWB)	SP069 (VIGN)	0 to 6000	0	0	0	6001 to 8000	5000	8000	45	8001 or more	5000	10000	64	0 to 32767 (1/16-fold)	0
SP017 (TSP) Maximum motor speed	SP067 (VIGWA)	SP068 (VIGWB)	SP069 (VIGN)																			
0 to 6000	0	0	0																			
6001 to 8000	5000	8000	45																			
8001 or more	5000	10000	64																			
3270	SP070			Not used. Set to "0".	0	0																
3271 (PR)	SP071	VR2WA	Fixed control constant	Used by Mitsubishi. Set "0" unless designated in particular.	0	0																
3272 (PR)	SP072	VR2WB																				
3273 (PR)	SP073	VR2GN																				
3274 (PR)	SP074	IGDEC																				
3275	SP075	R2KWS																				

8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting	
3276	SP076			Not used. Set to "0".	0	0
3277	SP077	TDSL	Fixed control constant	Used by Mitsubishi. Set "0" unless designated in particular.	0	0
3278 (PR)	SP078	FPWM				
3279 (PR)	SP079	ILMT				
3280	SP080					
3281	SP081	LMCA				
3282	SP082	LMCB				
3283 to 3286	SP083 to SP086					
3287 (PR)	SP087	DIQM	Target value of variable torque limit magnification at deceleration	Set the minimum value of variable torque limit at deceleration.	0 to 150 (%)	75
3288 (PR)	SP088	DIQN	Speed for starting change of variable torque limit magnification at deceleration	Set the speed for starting change of torque limit value at deceleration. 	0 to 32767 (r/min)	3000
3289 to 3292	SP089 to SP092			Not used. Set to "0".	0	0
3293 (PR)	SP093	ORE	Fixed control constant	Used by Mitsubishi. Set "0" unless designated in particular.	0	0
3294 (PR)	SP094			Not used. Set to "0".	0	0
3295 (PR)	SP095	VFAV	Fixed control constant	Used by Mitsubishi. Set "0" unless designated in particular.	0	0

8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting																																																																																																																								
3296 (PR)	SP096	EGAR	Encoder gear ratio	Set the gear ratio between the spindle end and the encoder end (except for the motor-built-in encoder) as indicated below. <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>Setting value</th> <th>Gear ratio (deceleration)</th> <th>Setting value</th> <th>Gear ratio (Acceleration)</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1 : 1</td> <td>-1</td> <td>1 : 2</td> </tr> <tr> <td>1</td> <td>1 : 1/2</td> <td>-2</td> <td>1 : 4</td> </tr> <tr> <td>2</td> <td>1 : 1/4</td> <td>-3</td> <td>1 : 3</td> </tr> <tr> <td>3</td> <td>1 : 1/8</td> <td></td> <td></td> </tr> <tr> <td>4</td> <td>1 : 1/16</td> <td></td> <td></td> </tr> </tbody> </table>	Setting value	Gear ratio (deceleration)	Setting value	Gear ratio (Acceleration)	0	1 : 1	-1	1 : 2	1	1 : 1/2	-2	1 : 4	2	1 : 1/4	-3	1 : 3	3	1 : 1/8			4	1 : 1/16			-3 to 4	0																																																																																															
Setting value	Gear ratio (deceleration)	Setting value	Gear ratio (Acceleration)																																																																																																																										
0	1 : 1	-1	1 : 2																																																																																																																										
1	1 : 1/2	-2	1 : 4																																																																																																																										
2	1 : 1/4	-3	1 : 3																																																																																																																										
3	1 : 1/8																																																																																																																												
4	1 : 1/16																																																																																																																												
3297 (PR)	SP097	SPECO	Orientation specification	Set the orientation specifications in bit units. <table border="1" style="margin-left: 20px;"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>tlet</td> </tr> <tr> <td colspan="8"> </td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td></td><td></td><td>fdir</td><td></td><td>pyfx</td><td>dmin</td><td>odi2</td><td>odi1</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>bit</th> <th>Name</th> <th>Meaning when set to 0</th> <th>Meaning when set to 1</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>odi1</td> <td colspan="2">Orientation rotation direction</td> </tr> <tr> <td rowspan="2">1</td> <td>odi2</td> <td colspan="2">00: Previous (the direction in which the motor has so far rotated under speed control)</td> </tr> <tr> <td></td> <td colspan="2">01: Forward rotation</td> </tr> <tr> <td></td> <td></td> <td colspan="2">10: Backward rotation</td> </tr> <tr> <td></td> <td></td> <td colspan="2">11: Prohibited (Same as setting value = 10)</td> </tr> <tr> <td>2</td> <td>dmin</td> <td>Dummy in-position invalid</td> <td>Dummy in-position valid</td> </tr> <tr> <td>3</td> <td>pyfx</td> <td>Excitation min. (50%) during orientation servo lock invalid</td> <td>Excitation min. (50%) during orientation servo lock valid</td> </tr> <tr> <td>4</td> <td></td> <td></td> <td></td> </tr> <tr> <td>5</td> <td>fdir</td> <td>Encoder detector polarity: +</td> <td>Encoder detector polarity: -</td> </tr> <tr> <td>6</td> <td></td> <td></td> <td></td> </tr> <tr> <td>7</td> <td></td> <td></td> <td></td> </tr> <tr> <td>8</td> <td>tlet</td> <td>Turret indexing invalid</td> <td>Turret indexing valid</td> </tr> <tr> <td>9</td> <td></td> <td></td> <td></td> </tr> <tr> <td>A</td> <td></td> <td></td> <td></td> </tr> <tr> <td>B</td> <td></td> <td></td> <td></td> </tr> <tr> <td>C</td> <td></td> <td></td> <td></td> </tr> <tr> <td>D</td> <td></td> <td></td> <td></td> </tr> <tr> <td>E</td> <td></td> <td></td> <td></td> </tr> <tr> <td>F</td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	F	E	D	C	B	A	9	8								tlet									7	6	5	4	3	2	1	0			fdir		pyfx	dmin	odi2	odi1	bit	Name	Meaning when set to 0	Meaning when set to 1	0	odi1	Orientation rotation direction		1	odi2	00: Previous (the direction in which the motor has so far rotated under speed control)			01: Forward rotation				10: Backward rotation				11: Prohibited (Same as setting value = 10)		2	dmin	Dummy in-position invalid	Dummy in-position valid	3	pyfx	Excitation min. (50%) during orientation servo lock invalid	Excitation min. (50%) during orientation servo lock valid	4				5	fdir	Encoder detector polarity: +	Encoder detector polarity: -	6				7				8	tlet	Turret indexing invalid	Turret indexing valid	9				A				B				C				D				E				F				0000 to FFFF HEX setting	0000
F	E	D	C	B	A	9	8																																																																																																																						
							tlet																																																																																																																						
7	6	5	4	3	2	1	0																																																																																																																						
		fdir		pyfx	dmin	odi2	odi1																																																																																																																						
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																																										
0	odi1	Orientation rotation direction																																																																																																																											
1	odi2	00: Previous (the direction in which the motor has so far rotated under speed control)																																																																																																																											
		01: Forward rotation																																																																																																																											
		10: Backward rotation																																																																																																																											
		11: Prohibited (Same as setting value = 10)																																																																																																																											
2	dmin	Dummy in-position invalid	Dummy in-position valid																																																																																																																										
3	pyfx	Excitation min. (50%) during orientation servo lock invalid	Excitation min. (50%) during orientation servo lock valid																																																																																																																										
4																																																																																																																													
5	fdir	Encoder detector polarity: +	Encoder detector polarity: -																																																																																																																										
6																																																																																																																													
7																																																																																																																													
8	tlet	Turret indexing invalid	Turret indexing valid																																																																																																																										
9																																																																																																																													
A																																																																																																																													
B																																																																																																																													
C																																																																																																																													
D																																																																																																																													
E																																																																																																																													
F																																																																																																																													
3298 (PR)	SP098	VGOP	Speed loop gain proportional term in orientation mode	Set the speed loop proportional gain in orientation mode. When the gain is increased, rigidity is improved in the orientation stop but vibration and sound become larger.	0 to 1000 (1/s)	63																																																																																																																							
3299 (PR)	SP099	VGOI	Orientation mode speed loop gain integral term	Set the speed loop integral gain in orientation mode.	0 to 1000 (0.1 1/s)	60																																																																																																																							
3300 (PR)	SP100	VGOD	Orientation mode speed loop gain delay advance term	Set the a loop gain delay advance gain in orientation mode. When this parameter is set to "0", PI control is exercised.	0 to 1000 (0.1 1/s)	15																																																																																																																							

8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting	
3301 (PR)	SP101	DINP	Orientation advance in-position width	When using the orientation in-position advance function, set the in-position width that is larger than the normal in-position width defined in SP004 (OINP).	1 to 2880 (1/16°)	16
3302 (PR)	SP102	OODR	Excessive error value in orientation mode	Set the excessive error width in orientation mode.	1 to 32767 (1/4 pulse) (1 pulse= 0.088°)	32767
3303 (PR)	SP103	FTM	Index positioning completion OFF time timer	Set the time for forcedly turn OFF the index positioning completion signal (different from the orientation completion signal) after the leading edge of the indexing start signal.	1 to 10000 (ms)	200
3304 (PR)	SP104	TLOR	Torque limit value for orientation servo locking	Set the torque limit value for orientation in-position output. If the external torque limit signal is input the torque limit value set by this parameter is made invalid.	1 to 120 (%)	100
3305 (PR)	SP105	IQG0	Current loop gain magnification 1 in orientation mode	Set the magnification for current loop gain (torque component) at orientation completion.	1 to 1000 (%)	100
3306	SP106	IDG0	Current loop gain magnification 2 in orientation mode	Set the magnification for current loop gain (excitation component) at orientation completion.	1 to 1000 (%)	100
3307	SP107	CSP2	Deceleration rate 2 in orientation mode	Set the deceleration rate in orientation mode corresponding to the gear 001. When this parameter is set to "0", same as SP006 (CSP).	0 to 1000	0
3308	SP108	CSP3	Deceleration rate 3 in orientation mode	Set the deceleration rate in orientation mode corresponding to the gear 010. When this parameter is set to "0", same as SP006 (CSP).	0 to 1000	0
3309 (PR)	SP109	CSP4	Deceleration rate 4 in orientation mode	Set the deceleration rate in orientation mode corresponding to the gear 011. When this parameter is set to "0", same as SP006 (CSP).	0 to 1000	0
3310 (PR)	SP110	WCML	Turret index command magnification	The integer magnification (gear ratio 1 : N) for the index position command (0 to 359) is set.	0 to 32767 (fold)	0
3311	SP111	WDEL	Turret index deceleration magnification	The magnification for the orientation deceleration rate is set using 256 as 1.	0 to 32767 (1/256 -fold)	0
3312	SP112	WCLP	Turret index clamp speed	The max. speed during indexing is set. This becomes the max. speed of the motor when set to "0".	0 to 32767 (r/min)	0


8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting	
3313 (PR)	SP113	WINP	Turret index in-position width	The position error range is set in which an orientation (indexing) completed signal is output during turret indexing. This becomes the same as SP004 (OINP) when set to "0".	0 to 32767 (1/16°)	0
3314	SP114	OPER	Orientation pulse miss check value	An alarm "5C" will occur if the pulse miss value in the orientation stop exceed this setting value. (Note that this is invalid when set to "0".) In this parameter, set the value to fulfill the following conditions. SP114 setting value > 1.5 × SP004 (orientation in-position width)	0 to 32767 (360°/4096)	0
3315	SP115	OSP2	Orientation changeover speed limit value 2	When the door interlock spindle speed clamp signal is ON, this setting is used instead of OSP(SP005), CZRN(SP149) and TZRN(SP214). (Note that SP149 and SP214 are used only for the M65V.)	0 to 32767 (r/min)	0
3316	SP116	OPYVR	Fixed control constants	Used by Mitsubishi. Set "0" unless designated in particular.	0	0
3317	SP117	ORUT				
3318	SP118	ORCT	Number of orientation retry times	Set the number of times to retry when an orientation or feedback error occurs. The warning (A9) is issued while retrying orientation, and an alarm (5C) is issued when the set number of times is exceeded.	0 to 100 (time)	0
3319 to 3376	SP119 to SP176			Not used. Set to "0".	0	0

8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting																																																																																																
3377 (PR)	SP177	SPECS	Spindle synchronous specifications Set the spindle synchronous specifications in bit units. <table style="width: 100%; border-collapse: collapse; margin-bottom: 5px;"> <tr> <td style="text-align: center;">F</td> <td style="text-align: center;">E</td> <td style="text-align: center;">D</td> <td style="text-align: center;">C</td> <td style="text-align: center;">B</td> <td style="text-align: center;">A</td> <td style="text-align: center;">9</td> <td style="text-align: center;">8</td> </tr> <tr> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px; text-align: center;">odx8</td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px; text-align: center;">fdir</td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px; text-align: center;">pyfx</td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px;"></td> <td style="border: 1px solid black; width: 20px; height: 15px; text-align: center;">fclx</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th style="text-align: center;">bit</th> <th style="text-align: center;">Name</th> <th style="text-align: center;">Meaning when set to 0</th> <th style="text-align: center;">Meaning when set to 1</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">fclx</td> <td style="text-align: center;">Closed loop</td> <td style="text-align: center;">Semi-closed loop</td> </tr> <tr> <td style="text-align: center;">1</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">2</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">pyfx</td> <td style="text-align: center;">Normal excitation</td> <td style="text-align: center;">Position loop excitation fixed (strong)</td> </tr> <tr> <td style="text-align: center;">4</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">5</td> <td style="text-align: center;">fdir</td> <td style="text-align: center;">Position detector polarity (+)</td> <td style="text-align: center;">Position detector polarity (-)</td> </tr> <tr> <td style="text-align: center;">6</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">7</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">8</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">A</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">B</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">C</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">D</td> <td style="text-align: center;">odx8</td> <td style="text-align: center;">Magnification of excessive error width x 8 times invalid</td> <td style="text-align: center;">Magnification of excessive error width x 8 times valid</td> </tr> <tr> <td style="text-align: center;">E</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">F</td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	F	E	D	C	B	A	9	8			odx8						7	6	5	4	3	2	1	0			fdir		pyfx			fclx	bit	Name	Meaning when set to 0	Meaning when set to 1	0	fclx	Closed loop	Semi-closed loop	1				2				3	pyfx	Normal excitation	Position loop excitation fixed (strong)	4				5	fdir	Position detector polarity (+)	Position detector polarity (-)	6				7				8				A				B				C				D	odx8	Magnification of excessive error width x 8 times invalid	Magnification of excessive error width x 8 times valid	E				F				0000 to FFFF HEX setting	0000
F	E	D	C	B	A	9	8																																																																																														
		odx8																																																																																																			
7	6	5	4	3	2	1	0																																																																																														
		fdir		pyfx			fclx																																																																																														
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																		
0	fclx	Closed loop	Semi-closed loop																																																																																																		
1																																																																																																					
2																																																																																																					
3	pyfx	Normal excitation	Position loop excitation fixed (strong)																																																																																																		
4																																																																																																					
5	fdir	Position detector polarity (+)	Position detector polarity (-)																																																																																																		
6																																																																																																					
7																																																																																																					
8																																																																																																					
A																																																																																																					
B																																																																																																					
C																																																																																																					
D	odx8	Magnification of excessive error width x 8 times invalid	Magnification of excessive error width x 8 times valid																																																																																																		
E																																																																																																					
F																																																																																																					
3378 (PR)	SP178	VGSP	Spindle synchronous speed loop gain proportional term	Set the speed loop proportional gain in spindle synchronization mode.	0 to 1000 (1/s)	63																																																																																															
3379 (PR)	SP179	VGSI	Spindle synchronous speed loop gain integral term	Set the speed loop integral gain in spindle synchronization mode.	0 to 1000 (0.1 1/s)	60																																																																																															
3380 (PR)	SP180	VGSD	Spindle synchronous speed loop gain delay advance term	Set the speed loop delay advance gain in spindle synchronization mode. When this parameter is set to "0", PI control is exercised.	0 to 1000 (0.1 1/s)	15																																																																																															
3381 (PR)	SP181	VCGS	Target value of variable speed loop proportional gain at spindle synchronization	Set the magnification of speed loop proportional gain with respect to SP178 (VGSP) at the maximum speed defined in SP017 (TSP) at spindle synchronization.	0 to 100 (%)	100																																																																																															

8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting	
3382 (PR)	SP182	VCSS	Change starting speed of variable speed loop proportional gain at spindle synchronization	Set the speed for starting change of speed loop proportional gain at spindle synchronization. 	0 to 32767 (r/min)	0
3383	SP183	SYNV	Sync matching speed at spindle synchronization	For changeover from the speed loop to the position loop at spindle synchronization, set a speed command error range for output of the sync speed matching signal.	0 to 1000 (r/min)	20
3384 (PR)	SP184	FFCS	Acceleration rate feed forward gain at spindle synchronization	Set the acceleration rate feed forward gain at spindle synchronization. This parameter is used only with the SPJ2.	0 to 1000 (%)	0
3385	SP185	SINP	Spindle sync in-position width	Set the position error range for output of the in-position signal at spindle synchronization.	1 to 2880 (1/16°)	16
3386 (PR)	SP186	SODR	Excessive error width at spindle synchronization	Set the excessive error width at spindle synchronization.	1 to 32767 (1/4 pulse) (1 pulse = 0.088°)	32767
3387 (PR)	SP187	IQGS	Current loop gain magnification1 at spindle synchronization	Set the magnification of current loop gain (torque component) at spindle synchronization.	1 to 1000 (%)	100
3388 (PR)	SP188	IDGS	Current loop gain magnification 2 at spindle synchronization	Set the magnification of current loop gain (excitation component) at spindle synchronization.	1 to 1000 (%)	100
3389 to 3392	SP189 to SP192			Not used. Set to "0".	0	0

8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting																																																																																																				
3393 (PR)	SP193	SPECT	Synchronous tapping specifications Set the synchronous tapping specifications in bit units. <table border="1" style="width:100%; text-align:center;"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td>zrtn</td><td>ptyp</td><td>od8x</td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td></td><td></td><td>fdir</td><td>cdir</td><td>pyfx</td><td></td><td></td><td>fclx</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th>bit</th> <th>Name</th> <th>Meaning when set to 0</th> <th>Meaning when set to 1</th> </tr> </thead> <tbody> <tr><td>0</td><td>fclx</td><td>Closed loop</td><td>Semi-closed loop</td></tr> <tr><td>1</td><td></td><td></td><td></td></tr> <tr><td>2</td><td></td><td></td><td></td></tr> <tr><td>3</td><td>pyfx</td><td>Normal excitation</td><td>Position loop excitation fixed (strong)</td></tr> <tr><td>4</td><td>cdir</td><td>Command polarity (+)</td><td>Command polarity (-)</td></tr> <tr><td>5</td><td>fdir</td><td>Position detector polarity (+)</td><td>Position detector polarity (-)</td></tr> <tr><td>6</td><td></td><td></td><td></td></tr> <tr><td>7</td><td></td><td></td><td></td></tr> <tr><td>8</td><td></td><td></td><td></td></tr> <tr><td>9</td><td></td><td></td><td></td></tr> <tr><td>A</td><td></td><td></td><td></td></tr> <tr><td>B</td><td></td><td></td><td></td></tr> <tr><td>C</td><td></td><td></td><td></td></tr> <tr><td>D</td><td>od8x</td><td>Magnification of excessive error width x 8 times invalid</td><td>Magnification of excessive error width x 8 times valid</td></tr> <tr><td>E</td><td>ptyp</td><td>Position control switch type: After zero point return</td><td>Position control switch type: After deceleration stop</td></tr> <tr><td>F</td><td>zrtn</td><td>Zero point return direction: CCW</td><td>Zero point return direction: CW</td></tr> </tbody> </table>	F	E	D	C	B	A	9	8	zrtn	ptyp	od8x						7	6	5	4	3	2	1	0			fdir	cdir	pyfx			fclx	bit	Name	Meaning when set to 0	Meaning when set to 1	0	fclx	Closed loop	Semi-closed loop	1				2				3	pyfx	Normal excitation	Position loop excitation fixed (strong)	4	cdir	Command polarity (+)	Command polarity (-)	5	fdir	Position detector polarity (+)	Position detector polarity (-)	6				7				8				9				A				B				C				D	od8x	Magnification of excessive error width x 8 times invalid	Magnification of excessive error width x 8 times valid	E	ptyp	Position control switch type: After zero point return	Position control switch type: After deceleration stop	F	zrtn	Zero point return direction: CCW	Zero point return direction: CW	0000 to FFFF HEX setting	0000
F	E	D	C	B	A	9	8																																																																																																		
zrtn	ptyp	od8x																																																																																																							
7	6	5	4	3	2	1	0																																																																																																		
		fdir	cdir	pyfx			fclx																																																																																																		
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																						
0	fclx	Closed loop	Semi-closed loop																																																																																																						
1																																																																																																									
2																																																																																																									
3	pyfx	Normal excitation	Position loop excitation fixed (strong)																																																																																																						
4	cdir	Command polarity (+)	Command polarity (-)																																																																																																						
5	fdir	Position detector polarity (+)	Position detector polarity (-)																																																																																																						
6																																																																																																									
7																																																																																																									
8																																																																																																									
9																																																																																																									
A																																																																																																									
B																																																																																																									
C																																																																																																									
D	od8x	Magnification of excessive error width x 8 times invalid	Magnification of excessive error width x 8 times valid																																																																																																						
E	ptyp	Position control switch type: After zero point return	Position control switch type: After deceleration stop																																																																																																						
F	zrtn	Zero point return direction: CCW	Zero point return direction: CW																																																																																																						
3394 (PR)	SP194	VGTP	Synchronous tapping speed loop gain proportional term	Set the speed loop proportional gain in synchronous tapping mode.	0 to 1000 (1/s)	63																																																																																																			
3395 (PR)	SP195	VGTI	Synchronous tapping speed loop gain integral term	Set the speed loop integral gain in synchronous tapping mode.	0 to 1000 (0.1 1/s)	60																																																																																																			
3396 (PR)	SP196	VGTD	Synchronous tapping speed loop gain delay advance term	Set the speed loop delay advance gain in synchronous tapping mode. When this parameter is set to "0", PI control is exercised.	0 to 1000 (0.1 1/s)	15																																																																																																			
3397	SP197			Not used. Set to "0".	0	0																																																																																																			
3398 (PR)	SP198	VCGT	Target value of variable speed loop proportional gain at synchronous tapping	Set the magnification of speed loop proportional gain with respect to SP194 (VGTP) at the maximum motor speed defined in SP017 (TSP) at synchronous tapping.	0 to 100 (%)	100																																																																																																			

8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting	
3399 (PR)	SP199	VCST	Change starting speed of variable speed loop proportional gain at synchronous tapping	Set the speed for starting change of speed loop proportional gain at synchronous tapping. <div style="text-align: center;"> <p>The graph plots 'Proportional gain' on the vertical axis against 'Speed' on the horizontal axis. A horizontal line at the top is labeled 'SP194'. A vertical dashed line drops from the end of this horizontal line to the x-axis at 'SP199'. From 'SP199', a line slopes downwards to the right, ending at 'SP017' on the x-axis. A point on this downward-sloping line is labeled 'SP194x (SP198/100)'.</p> </div>	0 to 32767 (r/min)	0
3400 (PR)	SP200	FFC1	Synchronous tapping acceleration feed forward gain (gear 1)	Set the acceleration feed-forward gain for selection of gear 000 at synchronous tapping. This parameter should be used when an error of relative position to Z-axis servo is large.	0 to 1000 (%) 0	
3401 (PR)	SP201	FFC2	Synchronous tapping acceleration feed forward gain (gear 2)	Set the acceleration feed-forward gain for selection of gear 001 at synchronous tapping.	0 to 1000 (%) 0	
3402 (PR)	SP202	FFC3	Synchronous tapping acceleration feed forward gain (gear 3)	Set the acceleration feed-forward gain for selection of gear 010 at synchronous tapping.	0 to 1000 (%) 0	
3403 (PR)	SP203	FFC4	Synchronous tapping acceleration feed forward gain (gear 4)	Set the acceleration feed-forward gain for selection of gear 011 at synchronous tapping.	0 to 1000 (%) 0	
3404 to 3413	SP204 to SP213			Not used. Set to "0".	0 0	
3414	SP214	TZRN	Synchronous tapping zero point return speed	This parameter is valid when SP193 (SPECT) bitE is set to "0". Set the zero point return speed used when the speed loop changes to the position loop.	0 to 500 (r/min) 50	
3415	SP215	TPDT	Synchronous tapping zero point return deceleration rate	This parameter is valid when SP193 (SPECT) bitE is set to "0". Set the deceleration rate where the machine starts to decelerate when it returns to the target stop point during synchronous tapping zero point return. When the machine tends to overshoot at the stop point set a smaller value.	1 to 10000 (pulse)	
3416	SP216	TPST	Synchronous tapping zero point return shift amount	This parameter is valid when SP193 (SPECT) bitE is set to "0". Set the synchronous tapping zero point position.	0 to 4095 0	

8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items		Details	Setting range	Standard setting	
3417	SP217	TINP	Synchronous tapping in-position width	Set the position error range in which in-position signal is output during synchronize tapping.	1 to 2880 (1/16°)	16
3418 (PR)	SP218	TODR	Excessive error width at synchronous tapping	Set the excessive error width at synchronous tapping.	1 to 32767 (pulse) (1 pulse = 0.088°)	32767
3419 (PR)	SP219	IQGT	Current loop gain magnification 1 at synchronous tapping	Set the magnification of current loop gain (torque component) during synchronous tapping.	1 to 1000 (%)	100
3420 (PR)	SP220	IDGT	Current loop gain magnification 2 at synchronous tapping	Set the magnification of current loop gain (excitation component) during synchronous tapping.	1 to 1000 (%)	100
3421 to 3424	SP221 to SP224			Not used. Set to "0".	0	0
3425	SP225	OXKPH	Fixed control constant	Used by Mitsubishi. Set "0" unless designated in particular.	0	0
3426	SP226	OXKPL				
3427	SP227	OXVKP				
3428	SP228	OXVKI				
3429	SP229	OXSFT				
3430	SP230					
3431	SP231					
3432	SP232					
3433 (PR)	SP233	JL	Disturbance observer general inertia scale	Set the ratio of the motor inertia + load inertia and motor inertia. $\text{Setting value} = \frac{\text{Motor inertia} + \text{load inertia}}{\text{Motor inertia}} \times 100$ (Normally, set "100" or more. When less than "50" is set, the setting will be invalid.)	0 to 5000 (%)	0

8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items			Details	Setting range	Standard setting
3434 (PR)	SP234	OBS1	Disturbance observer low path filter frequency	Set the frequency of the low path filter for when the disturbance observer is valid. Setting (1/s) = $2\pi f$ f: Approx. 1.5 times the disturbance frequency	0 to 1000 (1/s)	0
3435 (PR)	SP235	OBS2	Disturbance observer gain	Set the gain for the disturbance observer.	0 to 500 (%)	0
3436 to 3452	SP236 to SP252			Not used. Set to "0".	0	0
3453	SP253	DA1NO	D/A output channel 1 data number	Set the output data number for channel 1 of the D/A output function. When the setting value is "0", the output is speedometer. Refer to "8.4.1 D/A OUTPUT SPESIFICATIONS".	-32768 to 32767	0
3454	SP254	DA2NO	D/A output channel 2 data number	Set the output data number for channel 2 of the D/A output function. When the setting value is "0", the output is load meter. Refer to "8.4.1 D/A OUTPUT SPESIFICATIONS".	-32768 to 32767	0
3455	SP255	DA1MPY	DA output channel 1 magnification	Set the data magnification for channel 1 of the D/A output function. The output magnification is (setting value)/256. When set to "0", the output magnification becomes 1-fold, in the same manner as when "256" is set. Refer to "8.4.1 D/A OUTPUT SPESIFICATIONS".	-32768 to 32767 (1/256-fold)	0
3456	SP256	DA2MPY	DA output channel 2 magnification	Set the data magnification for channel 2 of the D/A output function. The output magnification is (setting value)/256. When set to "0", the output magnification becomes 1-fold, in the same manner as when "256" is set. Refer to "8.4.1 D/A OUTPUT SPESIFICATIONS".	-32768 to 32767 (1/256-fold)	0

8. SPINDLE PARAMETERS
8.2 MDS-B-SPJ2

No.	Items			Details	Setting range	Standard setting
3457 (PR) to 3520 (PR)	SP257 to SP320	RPM BSD	Motor constant (H coil)	<p>This parameter is valid only in the following two conditional cases:</p> <p>(a) In case that SP034 (SFNC2) bit0=1 and SP034 (SFNC2) bit2=0 Set the motor constants when using a special motor, not described in the SP040 (MTYP) explanation and when not using the coil changeover motor.</p> <p>(b) In case that SP034 (SFNC2) bit0=1 and SP034 (SFNC2) bit2=1 Set the motor constant of the H coil of the coil changeover motor.</p> <p>(Note) It is not allowed for the user to change the setting.</p>	0000 to FFFF HEX setting	0000
3521 (PR) to 3584 (PR)	SP321 to SP384	RPML BSDL	Motor constant (L coil)	<p>This parameter is valid only in the following conditional case:</p> <p>(a) In case that SP034 (SFNC2) bit0=1 and SP034 (SFNC2) bit2=1 Set the motor constant of the L coil of the coil changeover motor.</p> <p>(Note) It is not allowed for the user to change the setting.</p>	0000 to FFFF HEX setting	0000

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

The spindle parameter setting and display method will differ according to the NC being used, so refer to Instruction Manual for each NC and the following spindles.

MELDAS AC Servo and Spindle MDS-A Series MDS-B Series Specifications Manual . BNP-B3759
MELDAS AC Servo and Spindle MDS-C1 Series Specifications Manual BNP-C3000

For parameters marked with a (PR) in the tables, turn the NC power OFF after setting. The parameters will be valid after the power is turned ON again.

The "fixed control constants" and "fixed control bits" in this section are set by Mitsubishi.

⚠ CAUTION

⚠ Do not make remarkable adjustments or changes of the parameters as the operation may become unstable.

⚠ In the explanation on bits, set all bits not used, including blank bits, to "0".

No.	Items	Details	Setting range	Standard setting	
3201	SP001 PGM	Magnetic sensor and motor built-in encoder orientation position loop gain	As the set value is larger, the orientation time becomes shorter and servo rigidity is increased. However, vibration is increased and the machine becomes likely to overshoot.	0 to 1000 (0.1 1/s)	100
3202	SP002 PGE	Encoder orientation position loop gain	As the set value is larger, the orientation time becomes shorter and servo rigidity is increased. However, vibration is increased and the machine becomes likely to overshoot.	0 to 1000 (0.1 1/s)	100
3203	SP003 PGC0	C-axis non-cutting position loop gain	Set the position loop gain in C-axis non-cutting mode. During non-cutting (rapid traverse, etc.) with the C axis control, this position loop gain setting is valid.	1 to 100 (1/s)	15
3204	SP004 OINP	Orientation in-position width	Set the position error range in which an orientation completion signal is output.	1 to 2880 (1/16 °)	16
3205 (PR)	SP005 OSP	Orientation mode changing speed limit value	Set the motor speed limit value to be used when the speed loop is changed to the position loop in orientation mode. When this parameter is set to "0", SP017 (TSP) becomes the limit value.	0 to 32767 (r/min)	0
3206	SP006 CSP	Orientation mode deceleration rate	As the set value is larger, the orientation time becomes shorter. However, the machine becomes likely to overshoot.	1 to 1000	20

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting	
3207	SP007	OPST	In-position shift amount for orientation	Set the stop position for orientation. (i) Motor built-in encoder, encoder: Set the value by dividing 360° by 4096. (ii) Magnetic sensor: Divide -5° to +5° by 1024 and put 0° for 0.	(i) 0 to 4095 (ii) -512 to 512	0
3208	SP008			Not used. Set to "0".	0	0
3209	SP009	PGT	Synchronized tapping Position loop gain	Set the spindle position loop gain in synchronized tapping mode.	1 to 100 (1/s)	15
3210	SP010	PGS	Spindle synchronous position loop gain	Set the spindle position loop gain in spindle synchronization mode.	1 to 100 (1/s)	15
3211 to 3216	SP011 to SP016			Use not possible.	0	0
3217 (PR)	SP017	TSP	Maximum motor speed	Set the maximum motor speed of the spindle.	1 to 32767 (r/min)	6000
3218 (PR)	SP018	ZSP	Motor zero speed	Set the motor speed for which zero-speed output is performed.	1 to 1000 (r/min)	50
3219 (PR)	SP019	CSN1	Speed cushion 1	Set the time constant for a speed command from "0" to the maximum speed. (This parameter is invalid in position loop mode.)	1 to 32767 (10ms)	30
3220 (PR)	SP020	SDTS	Speed detection set value	Set the motor speed so for which speed detection output is performed. Usually, the setting value is 10% of SP017 (TSP).	0 to 32767 (r/min)	600
3221	SP021	TLM1	Torque limit 1	Set the torque limit rate for torque limit signal 001.	0 to 120 (%)	10
3222 (PR)	SP022	VGNP1	Speed loop gain proportional term under speed control	Set the speed loop proportional gain in speed control mode. When the gain is increased, response is improved but vibration and sound become larger.	0 to 1000 (1/s)	63
3223 (PR)	SP023	VGNI1	Speed loop gain integral term under speed control	Set the speed loop integral gain in speed control mode. Usually, set a value in proportion to SP022 (VGNP1).	0 to 1000 (0.1 1/s)	60

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items			Details	Setting range	Standard setting
3224	SP024			Use not possible.	0	0
3225 (PR)	SP025	GRA1	Spindle gear teeth count 1	Set the number of gear teeth of the spindle corresponding to gear 000.	1 to 32767	1
3226 (PR)	SP026	GRA2	Spindle gear teeth count 2	Set the number of gear teeth of the spindle corresponding to gear 001.	1 to 32767	1
3227 (PR)	SP027	GRA3	Spindle gear teeth count 3	Set the number of gear teeth of the spindle corresponding to gear 010.	1 to 32767	1
3228 (PR)	SP028	GRA4	Spindle gear teeth count 4	Set the number of gear teeth of the spindle corresponding to gear 011.	1 to 32767	1
3229 (PR)	SP029	GRB1	Motor shaft gear teeth count 1	Set the number of gear teeth of the motor shaft corresponding to gear 000.	1 to 32767	1
3230 (PR)	SP030	GRB2	Motor shaft gear teeth count 2	Set the number of gear teeth of the motor shaft corresponding to gear 001.	1 to 32767	1
3231 (PR)	SP031	GRB3	Motor shaft gear teeth count 3	Set the number of gear teeth of the motor shaft corresponding to gear 010.	1 to 32767	1
3232 (PR)	SP032	GRB4	Motor shaft gear teeth count 4	Set the number of gear teeth of the motor shaft corresponding to gear 011.	1 to 32767	1

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting																																																																																																												
3233 (PR)	SP033	SFNC1 Spindle function 1	<p>Set the spindle function 1 in bit units.</p> <table border="1" style="width:100%; text-align:center;"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td>poff</td><td>hzs</td><td></td><td>ront</td><td></td><td></td><td>pycal</td><td>pychg</td> </tr> <tr> <td colspan="8"> </td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td>pyst</td><td>pyoff</td><td></td><td></td><td></td><td>sftk</td><td>dflt</td><td>1a2m</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th>bit</th> <th>Name</th> <th>Meaning when set to 0</th> <th>Meaning when set to 1</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1a2m</td> <td>1 amplifier 2 motor function: Invalid</td> <td>1 amplifier 2 motor function: Valid</td> </tr> <tr> <td>1</td> <td>dflt</td> <td>Default motor: Main</td> <td>Default motor: Sub</td> </tr> <tr> <td>2</td> <td>sftk</td> <td>SF-TK card invalid</td> <td>SF-TK card valid</td> </tr> <tr> <td>3</td> <td></td> <td></td> <td></td> </tr> <tr> <td>4</td> <td></td> <td></td> <td></td> </tr> <tr> <td>5</td> <td></td> <td></td> <td></td> </tr> <tr> <td>6</td> <td>pyoff</td> <td colspan="2">This is used by Mitsubishi.</td> </tr> <tr> <td>7</td> <td>pyst</td> <td colspan="2">Set to "0" unless particularly designated.</td> </tr> <tr> <td>8</td> <td>pychg</td> <td></td> <td></td> </tr> <tr> <td>9</td> <td>pycal</td> <td>(Conventional specifications)</td> <td>High-speed rate deceleration method valid for minimum excitation rate</td> </tr> <tr> <td>A</td> <td></td> <td></td> <td></td> </tr> <tr> <td>B</td> <td></td> <td colspan="2">This is used by Mitsubishi. Set to "0" unless particularly designated.</td> </tr> <tr> <td>C</td> <td>ront</td> <td>Normal ready ON</td> <td>High-speed ready ON</td> </tr> <tr> <td>D</td> <td></td> <td colspan="2">This is used by Mitsubishi. Set to "0" unless particularly designated.</td> </tr> <tr> <td>E</td> <td>hzs</td> <td>Gate OFF by high-cycle zero speed invalid</td> <td>Gate OFF by high-cycle zero speed valid</td> </tr> <tr> <td>F</td> <td>poff</td> <td>Contactorm hold at NC power OFF invalid</td> <td>Contactorm hold at NC power OFF valid</td> </tr> </tbody> </table> <p>(Note) When SPH is used, bit 0 and bit 1 will be invalid.</p>	F	E	D	C	B	A	9	8	poff	hzs		ront			pycal	pychg									7	6	5	4	3	2	1	0	pyst	pyoff				sftk	dflt	1a2m	bit	Name	Meaning when set to 0	Meaning when set to 1	0	1a2m	1 amplifier 2 motor function: Invalid	1 amplifier 2 motor function: Valid	1	dflt	Default motor: Main	Default motor: Sub	2	sftk	SF-TK card invalid	SF-TK card valid	3				4				5				6	pyoff	This is used by Mitsubishi.		7	pyst	Set to "0" unless particularly designated.		8	pychg			9	pycal	(Conventional specifications)	High-speed rate deceleration method valid for minimum excitation rate	A				B		This is used by Mitsubishi. Set to "0" unless particularly designated.		C	ront	Normal ready ON	High-speed ready ON	D		This is used by Mitsubishi. Set to "0" unless particularly designated.		E	hzs	Gate OFF by high-cycle zero speed invalid	Gate OFF by high-cycle zero speed valid	F	poff	Contactorm hold at NC power OFF invalid	Contactorm hold at NC power OFF valid	0000 to FFFF HEX setting	0000
F	E	D	C	B	A	9	8																																																																																																										
poff	hzs		ront			pycal	pychg																																																																																																										
7	6	5	4	3	2	1	0																																																																																																										
pyst	pyoff				sftk	dflt	1a2m																																																																																																										
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																														
0	1a2m	1 amplifier 2 motor function: Invalid	1 amplifier 2 motor function: Valid																																																																																																														
1	dflt	Default motor: Main	Default motor: Sub																																																																																																														
2	sftk	SF-TK card invalid	SF-TK card valid																																																																																																														
3																																																																																																																	
4																																																																																																																	
5																																																																																																																	
6	pyoff	This is used by Mitsubishi.																																																																																																															
7	pyst	Set to "0" unless particularly designated.																																																																																																															
8	pychg																																																																																																																
9	pycal	(Conventional specifications)	High-speed rate deceleration method valid for minimum excitation rate																																																																																																														
A																																																																																																																	
B		This is used by Mitsubishi. Set to "0" unless particularly designated.																																																																																																															
C	ront	Normal ready ON	High-speed ready ON																																																																																																														
D		This is used by Mitsubishi. Set to "0" unless particularly designated.																																																																																																															
E	hzs	Gate OFF by high-cycle zero speed invalid	Gate OFF by high-cycle zero speed valid																																																																																																														
F	poff	Contactorm hold at NC power OFF invalid	Contactorm hold at NC power OFF valid																																																																																																														

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting																																																																																																					
3234 (PR)	SP034	SFNC2	Spindle function 2	Set the spindle function 2 in bit units. <table border="1" style="width:100%; text-align:center;"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;">mkc2</td><td style="width:20px; height:15px;">mkch</td><td style="width:20px; height:15px;">invm</td><td style="width:20px; height:15px;">mts1</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th>bit</th> <th>Name</th> <th>Meaning when set to 0</th> <th>Meaning when set to 1</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>mts1</td> <td>Special motor constant invalid</td> <td>Special motor constant setting valid</td> </tr> <tr> <td>1</td> <td>invm</td> <td>A general-purpose motor FV control invalid</td> <td>A general-purpose motor FV control valid</td> </tr> <tr> <td>2</td> <td>mkch</td> <td>Coil switch function invalid</td> <td>Coil switch function valid</td> </tr> <tr> <td>3</td> <td>mkc2</td> <td>Coil switch specification 2 invalid</td> <td>Coil switch specification 2 valid (Note1) (Note2)</td> </tr> <tr><td>4</td><td></td><td></td><td></td></tr> <tr><td>5</td><td></td><td></td><td></td></tr> <tr><td>6</td><td></td><td></td><td></td></tr> <tr><td>7</td><td></td><td></td><td></td></tr> <tr><td>8</td><td></td><td></td><td></td></tr> <tr><td>9</td><td></td><td></td><td></td></tr> <tr><td>A</td><td></td><td></td><td></td></tr> <tr><td>B</td><td></td><td></td><td></td></tr> <tr><td>C</td><td></td><td></td><td></td></tr> <tr><td>D</td><td></td><td></td><td></td></tr> <tr><td>E</td><td></td><td></td><td></td></tr> <tr><td>F</td><td></td><td></td><td></td></tr> </tbody> </table> <p>(Note1) To validate bit3(mkc2), NC side needs to prepare.</p>	F	E	D	C	B	A	9	8									7	6	5	4	3	2	1	0					mkc2	mkch	invm	mts1	bit	Name	Meaning when set to 0	Meaning when set to 1	0	mts1	Special motor constant invalid	Special motor constant setting valid	1	invm	A general-purpose motor FV control invalid	A general-purpose motor FV control valid	2	mkch	Coil switch function invalid	Coil switch function valid	3	mkc2	Coil switch specification 2 invalid	Coil switch specification 2 valid (Note1) (Note2)	4				5				6				7				8				9				A				B				C				D				E				F				0000 to FFFF HEX setting	0000
F	E	D	C	B	A	9	8																																																																																																			
7	6	5	4	3	2	1	0																																																																																																			
				mkc2	mkch	invm	mts1																																																																																																			
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																							
0	mts1	Special motor constant invalid	Special motor constant setting valid																																																																																																							
1	invm	A general-purpose motor FV control invalid	A general-purpose motor FV control valid																																																																																																							
2	mkch	Coil switch function invalid	Coil switch function valid																																																																																																							
3	mkc2	Coil switch specification 2 invalid	Coil switch specification 2 valid (Note1) (Note2)																																																																																																							
4																																																																																																										
5																																																																																																										
6																																																																																																										
7																																																																																																										
8																																																																																																										
9																																																																																																										
A																																																																																																										
B																																																																																																										
C																																																																																																										
D																																																																																																										
E																																																																																																										
F																																																																																																										
3235 (PR)	SP035	SFNC3	Spindle function 3	Set the spindle function 3 in bit units. <table border="1" style="width:100%; text-align:center;"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;"></td><td style="width:20px; height:15px;">lbsd</td><td style="width:20px; height:15px;">hbsd</td><td style="width:20px; height:15px;">lwid</td><td style="width:20px; height:15px;">hwid</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th>bit</th> <th>Name</th> <th>Meaning when set to 0</th> <th>Meaning when set to 1</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>hwid</td> <td>H-coil wide-range constant output invalid</td> <td>H-coil wide-range constant output valid</td> </tr> <tr> <td>1</td> <td>lwid</td> <td>L-coil wide-range constant output invalid</td> <td>L-coil wide-range constant output valid</td> </tr> <tr> <td>2</td> <td>hbsd</td> <td>H-coil base slide invalid</td> <td>H-coil base slide valid</td> </tr> <tr> <td>3</td> <td>lbsd</td> <td>L-coil base slide invalid</td> <td>L-coil base slide valid</td> </tr> <tr><td>4</td><td></td><td></td><td></td></tr> <tr><td>5</td><td></td><td></td><td></td></tr> <tr><td>6</td><td></td><td></td><td></td></tr> <tr><td>7</td><td></td><td></td><td></td></tr> <tr><td>8</td><td></td><td>(Used with SPJ.)</td><td></td></tr> <tr><td>9</td><td></td><td></td><td></td></tr> <tr><td>A</td><td></td><td></td><td></td></tr> <tr><td>B</td><td></td><td></td><td></td></tr> <tr><td>C</td><td></td><td></td><td></td></tr> <tr><td>D</td><td></td><td></td><td></td></tr> <tr><td>E</td><td></td><td></td><td></td></tr> <tr><td>F</td><td></td><td></td><td></td></tr> </tbody> </table>	F	E	D	C	B	A	9	8									7	6	5	4	3	2	1	0					lbsd	hbsd	lwid	hwid	bit	Name	Meaning when set to 0	Meaning when set to 1	0	hwid	H-coil wide-range constant output invalid	H-coil wide-range constant output valid	1	lwid	L-coil wide-range constant output invalid	L-coil wide-range constant output valid	2	hbsd	H-coil base slide invalid	H-coil base slide valid	3	lbsd	L-coil base slide invalid	L-coil base slide valid	4				5				6				7				8		(Used with SPJ.)		9				A				B				C				D				E				F				0000 to FFFF HEX setting	0000
F	E	D	C	B	A	9	8																																																																																																			
7	6	5	4	3	2	1	0																																																																																																			
				lbsd	hbsd	lwid	hwid																																																																																																			
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																							
0	hwid	H-coil wide-range constant output invalid	H-coil wide-range constant output valid																																																																																																							
1	lwid	L-coil wide-range constant output invalid	L-coil wide-range constant output valid																																																																																																							
2	hbsd	H-coil base slide invalid	H-coil base slide valid																																																																																																							
3	lbsd	L-coil base slide invalid	L-coil base slide valid																																																																																																							
4																																																																																																										
5																																																																																																										
6																																																																																																										
7																																																																																																										
8		(Used with SPJ.)																																																																																																								
9																																																																																																										
A																																																																																																										
B																																																																																																										
C																																																																																																										
D																																																																																																										
E																																																																																																										
F																																																																																																										

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting																																																																																																												
3236 (PR)	SP036	SFNC4 Spindle function 4	<p>Set the spindle function 4 in bit units.</p> <table border="1" style="width:100%; text-align:center;"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td>dslm</td><td>dssm</td> </tr> <tr> <td colspan="8"> </td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td><input type="checkbox"/></td><td><input type="checkbox"/></td><td>enc2</td><td>enc1</td><td>mag2</td><td>mag1</td><td>plg2</td><td>plg1</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th>bit</th> <th>Name</th> <th>Meaning when set to 0</th> <th>Meaning when set to 1</th> </tr> </thead> <tbody> <tr><td>0</td><td>plg1</td><td>PLG of motor 1 valid</td><td>PLG of motor 1 invalid</td></tr> <tr><td>1</td><td>plg2</td><td>PLG of motor 2 valid</td><td>PLG of motor 2 invalid</td></tr> <tr><td>2</td><td>mag1</td><td>MAG of motor 1 valid</td><td>MAG of motor 1 invalid</td></tr> <tr><td>3</td><td>mag2</td><td>MAG of motor 2 valid</td><td>MAG of motor 2 invalid</td></tr> <tr><td>4</td><td>enc1</td><td>ENC of motor 1 valid</td><td>ENC of motor 1 invalid</td></tr> <tr><td>5</td><td>enc2</td><td>ENC of motor 2 valid</td><td>ENC of motor 2 invalid</td></tr> <tr><td>6</td><td></td><td></td><td></td></tr> <tr><td>7</td><td></td><td></td><td></td></tr> <tr><td>8</td><td>dssm</td><td>Speedometer output valid</td><td>Speedometer output invalid</td></tr> <tr><td>9</td><td>dslm</td><td>Load meter output valid</td><td>Load meter output invalid</td></tr> <tr><td>A</td><td></td><td></td><td></td></tr> <tr><td>B</td><td></td><td></td><td></td></tr> <tr><td>C</td><td></td><td></td><td></td></tr> <tr><td>D</td><td></td><td></td><td></td></tr> <tr><td>E</td><td></td><td></td><td></td></tr> <tr><td>F</td><td></td><td></td><td></td></tr> </tbody> </table>	F	E	D	C	B	A	9	8	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	dslm	dssm									7	6	5	4	3	2	1	0	<input type="checkbox"/>	<input type="checkbox"/>	enc2	enc1	mag2	mag1	plg2	plg1	bit	Name	Meaning when set to 0	Meaning when set to 1	0	plg1	PLG of motor 1 valid	PLG of motor 1 invalid	1	plg2	PLG of motor 2 valid	PLG of motor 2 invalid	2	mag1	MAG of motor 1 valid	MAG of motor 1 invalid	3	mag2	MAG of motor 2 valid	MAG of motor 2 invalid	4	enc1	ENC of motor 1 valid	ENC of motor 1 invalid	5	enc2	ENC of motor 2 valid	ENC of motor 2 invalid	6				7				8	dssm	Speedometer output valid	Speedometer output invalid	9	dslm	Load meter output valid	Load meter output invalid	A				B				C				D				E				F				0000 to FFFF HEX setting	0000
F	E	D	C	B	A	9	8																																																																																																										
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	dslm	dssm																																																																																																										
7	6	5	4	3	2	1	0																																																																																																										
<input type="checkbox"/>	<input type="checkbox"/>	enc2	enc1	mag2	mag1	plg2	plg1																																																																																																										
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																														
0	plg1	PLG of motor 1 valid	PLG of motor 1 invalid																																																																																																														
1	plg2	PLG of motor 2 valid	PLG of motor 2 invalid																																																																																																														
2	mag1	MAG of motor 1 valid	MAG of motor 1 invalid																																																																																																														
3	mag2	MAG of motor 2 valid	MAG of motor 2 invalid																																																																																																														
4	enc1	ENC of motor 1 valid	ENC of motor 1 invalid																																																																																																														
5	enc2	ENC of motor 2 valid	ENC of motor 2 invalid																																																																																																														
6																																																																																																																	
7																																																																																																																	
8	dssm	Speedometer output valid	Speedometer output invalid																																																																																																														
9	dslm	Load meter output valid	Load meter output invalid																																																																																																														
A																																																																																																																	
B																																																																																																																	
C																																																																																																																	
D																																																																																																																	
E																																																																																																																	
F																																																																																																																	
3237 (PR)	SP037	SFNC5 Spindle function 5	<p>Set the spindle function 5 in bit units.</p> <table border="1" style="width:100%; text-align:center;"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td>splg</td><td>dplg</td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td>nopl</td><td>nsno</td><td>nosg</td> </tr> <tr> <td colspan="8"> </td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td>plgo</td><td>mago</td><td>enco</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th>bit</th> <th>Name</th> <th>Meaning when set to 0</th> <th>Meaning when set to 1</th> </tr> </thead> <tbody> <tr><td>0</td><td>enco</td><td>Encoder orientation invalid</td><td>Encoder orientation valid</td></tr> <tr><td>1</td><td>mago</td><td>Magnetic sensor orientation invalid</td><td>Magnetic sensor orientation valid</td></tr> <tr><td>2</td><td>plgo</td><td>PLG orientation invalid</td><td>PLG orientation valid</td></tr> <tr><td>3</td><td></td><td></td><td></td></tr> <tr><td>4</td><td></td><td></td><td></td></tr> <tr><td>5</td><td></td><td></td><td></td></tr> <tr><td>6</td><td></td><td></td><td></td></tr> <tr><td>7</td><td></td><td></td><td></td></tr> <tr><td>8</td><td>nosg</td><td>No-signal detection type (Always monitoring)</td><td>Monitoring only in position loop or orientation-mode</td></tr> <tr><td>9</td><td>nsno</td><td>No-signal detection valid</td><td>No-signal detection invalid</td></tr> <tr><td>A</td><td>nopl</td><td>Constant monitor of PLG-Z phase no-signal invalid</td><td>Constant monitor of PLG-Z phase no-signal valid</td></tr> <tr><td>B</td><td></td><td></td><td></td></tr> <tr><td>C</td><td></td><td></td><td></td></tr> <tr><td>D</td><td></td><td></td><td></td></tr> <tr><td>E</td><td>dplg</td><td colspan="2">This is used by Mitsubishi.</td></tr> <tr><td>F</td><td>splg</td><td colspan="2">Set to "0" unless particularly designated.</td></tr> </tbody> </table> <p>(Note) For bit0 to 2, do not set two bits or more to "1" at the same time.</p>	F	E	D	C	B	A	9	8	splg	dplg	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	nopl	nsno	nosg									7	6	5	4	3	2	1	0	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	plgo	mago	enco	bit	Name	Meaning when set to 0	Meaning when set to 1	0	enco	Encoder orientation invalid	Encoder orientation valid	1	mago	Magnetic sensor orientation invalid	Magnetic sensor orientation valid	2	plgo	PLG orientation invalid	PLG orientation valid	3				4				5				6				7				8	nosg	No-signal detection type (Always monitoring)	Monitoring only in position loop or orientation-mode	9	nsno	No-signal detection valid	No-signal detection invalid	A	nopl	Constant monitor of PLG-Z phase no-signal invalid	Constant monitor of PLG-Z phase no-signal valid	B				C				D				E	dplg	This is used by Mitsubishi.		F	splg	Set to "0" unless particularly designated.		0000 to FFFF HEX setting	0000
F	E	D	C	B	A	9	8																																																																																																										
splg	dplg	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	nopl	nsno	nosg																																																																																																										
7	6	5	4	3	2	1	0																																																																																																										
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	plgo	mago	enco																																																																																																										
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																														
0	enco	Encoder orientation invalid	Encoder orientation valid																																																																																																														
1	mago	Magnetic sensor orientation invalid	Magnetic sensor orientation valid																																																																																																														
2	plgo	PLG orientation invalid	PLG orientation valid																																																																																																														
3																																																																																																																	
4																																																																																																																	
5																																																																																																																	
6																																																																																																																	
7																																																																																																																	
8	nosg	No-signal detection type (Always monitoring)	Monitoring only in position loop or orientation-mode																																																																																																														
9	nsno	No-signal detection valid	No-signal detection invalid																																																																																																														
A	nopl	Constant monitor of PLG-Z phase no-signal invalid	Constant monitor of PLG-Z phase no-signal valid																																																																																																														
B																																																																																																																	
C																																																																																																																	
D																																																																																																																	
E	dplg	This is used by Mitsubishi.																																																																																																															
F	splg	Set to "0" unless particularly designated.																																																																																																															

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting																																																																																																																																																																								
3238 (PR)	SP038	SFNC6 Spindle function 6	<p>Set the spindle function 6 in bit units.</p> <table border="1" data-bbox="603 331 1139 495"> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td> </tr> <tr> <td>oplp</td><td>lmx</td><td>iqsv</td><td>XFzs</td><td>dcsn</td><td>lmp</td><td>pl80</td><td>sdt2</td> </tr> <tr> <td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td>vfbs</td><td>orm</td><td>adin</td><td>tdn</td><td>plg2</td><td>pftm</td><td></td><td>alty</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <p>For MDS-C1-SP/SPH</p> <table border="1" data-bbox="603 636 1139 1317"> <thead> <tr> <th>bit</th> <th>Name</th> <th>Meaning when set to 0</th> <th>Meaning when set to 1</th> </tr> </thead> <tbody> <tr><td>0</td><td>alty</td><td>Deceleration stop during special alarm invalid</td><td>Deceleration stop during special alarm valid</td></tr> <tr><td>1</td><td></td><td></td><td></td></tr> <tr><td>2</td><td>pftm</td><td>Encoder feedback serial communication invalid</td><td>Encoder feedback serial communication valid</td></tr> <tr><td>3</td><td>plg2</td><td>Semi-closed pulse output signal x2 invalid</td><td>Semi-closed pulse output signal x2 valid</td></tr> <tr><td>4</td><td></td><td></td><td></td></tr> <tr><td>5</td><td>adin</td><td>Interpolation during thread cutting invalid</td><td>Interpolation during thread cutting valid</td></tr> <tr><td>6</td><td>orm</td><td>Orientation start memo invalid</td><td>Orientation start memo valid</td></tr> <tr><td>7</td><td>vfbs</td><td colspan="2">This is used by Mitsubishi. Set to "0" unless particularly designated.</td></tr> <tr><td>8</td><td>sdt2</td><td>(Follows SFNC6-bitC setting)</td><td>Set output 2 to 2nd speed detection output</td></tr> <tr><td>9</td><td>pl80</td><td>MHE90K detector's 180 wave PLG</td><td>180 wave PLG other than MHE90K</td></tr> <tr><td>A</td><td>lmp</td><td colspan="2">This is used by Mitsubishi. Set to "0" unless particularly designated.</td></tr> <tr><td>B</td><td>dcsn</td><td>Dual cushion during acceleration/ deceleration valid</td><td>Dual cushion during acceleration/ deceleration invalid</td></tr> <tr><td>C</td><td>XFzs</td><td>Set output 2 to MP scale low (L) speed mode</td><td>Set output 2 to zero speed output</td></tr> <tr><td>D</td><td>iqsv</td><td colspan="2">This is used by Mitsubishi. Set to "0" unless particularly designated</td></tr> <tr><td>E</td><td>lmx</td><td colspan="2"></td></tr> <tr><td>F</td><td>oplp</td><td>Open loop operation invalid</td><td>Open loop operation valid</td></tr> </tbody> </table> <p>For MDS-B-SP/SPH</p> <table border="1" data-bbox="603 1406 1139 1944"> <thead> <tr> <th>bit</th> <th>Name</th> <th>Meaning when set to 0</th> <th>Meaning when set to 1</th> </tr> </thead> <tbody> <tr><td>0</td><td>alty</td><td>Deceleration stop during special alarm invalid</td><td>Deceleration stop during special alarm valid</td></tr> <tr><td>1</td><td></td><td></td><td></td></tr> <tr><td>2</td><td>pftm</td><td>Encoder feedback serial communication invalid</td><td>Encoder feedback serial communication valid</td></tr> <tr><td>3</td><td>plg2</td><td>Semi-closed pulse output signal x2 invalid</td><td>Semi-closed pulse output signal x2 valid</td></tr> <tr><td>4</td><td>tdn</td><td colspan="2">Fixed control bit</td></tr> <tr><td>5</td><td>adin</td><td colspan="2"></td></tr> <tr><td>6</td><td>orm</td><td>Orientation start memo invalid</td><td>Orientation start memo valid</td></tr> <tr><td>7</td><td>vfbs</td><td colspan="2"></td></tr> <tr><td>8</td><td>sdt2</td><td colspan="2"></td></tr> <tr><td>9</td><td>pl80</td><td colspan="2"></td></tr> <tr><td>A</td><td>lmp</td><td colspan="2">Fixed control bit</td></tr> <tr><td>B</td><td>dcsn</td><td colspan="2"></td></tr> <tr><td>C</td><td>XFzs</td><td colspan="2"></td></tr> <tr><td>D</td><td>iqsv</td><td colspan="2"></td></tr> <tr><td>E</td><td>lmx</td><td colspan="2"></td></tr> <tr><td>F</td><td>oplp</td><td>Open loop operation invalid</td><td>Open loop operation valid</td></tr> </tbody> </table>	F	E	D	C	B	A	9	8	oplp	lmx	iqsv	XFzs	dcsn	lmp	pl80	sdt2	7	6	5	4	3	2	1	0	vfbs	orm	adin	tdn	plg2	pftm		alty	bit	Name	Meaning when set to 0	Meaning when set to 1	0	alty	Deceleration stop during special alarm invalid	Deceleration stop during special alarm valid	1				2	pftm	Encoder feedback serial communication invalid	Encoder feedback serial communication valid	3	plg2	Semi-closed pulse output signal x2 invalid	Semi-closed pulse output signal x2 valid	4				5	adin	Interpolation during thread cutting invalid	Interpolation during thread cutting valid	6	orm	Orientation start memo invalid	Orientation start memo valid	7	vfbs	This is used by Mitsubishi. Set to "0" unless particularly designated.		8	sdt2	(Follows SFNC6-bitC setting)	Set output 2 to 2nd speed detection output	9	pl80	MHE90K detector's 180 wave PLG	180 wave PLG other than MHE90K	A	lmp	This is used by Mitsubishi. Set to "0" unless particularly designated.		B	dcsn	Dual cushion during acceleration/ deceleration valid	Dual cushion during acceleration/ deceleration invalid	C	XFzs	Set output 2 to MP scale low (L) speed mode	Set output 2 to zero speed output	D	iqsv	This is used by Mitsubishi. Set to "0" unless particularly designated		E	lmx			F	oplp	Open loop operation invalid	Open loop operation valid	bit	Name	Meaning when set to 0	Meaning when set to 1	0	alty	Deceleration stop during special alarm invalid	Deceleration stop during special alarm valid	1				2	pftm	Encoder feedback serial communication invalid	Encoder feedback serial communication valid	3	plg2	Semi-closed pulse output signal x2 invalid	Semi-closed pulse output signal x2 valid	4	tdn	Fixed control bit		5	adin			6	orm	Orientation start memo invalid	Orientation start memo valid	7	vfbs			8	sdt2			9	pl80			A	lmp	Fixed control bit		B	dcsn			C	XFzs			D	iqsv			E	lmx			F	oplp	Open loop operation invalid	Open loop operation valid	0000 to FFFF HEX setting	0000
F	E	D	C	B	A	9	8																																																																																																																																																																						
oplp	lmx	iqsv	XFzs	dcsn	lmp	pl80	sdt2																																																																																																																																																																						
7	6	5	4	3	2	1	0																																																																																																																																																																						
vfbs	orm	adin	tdn	plg2	pftm		alty																																																																																																																																																																						
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																																																																																										
0	alty	Deceleration stop during special alarm invalid	Deceleration stop during special alarm valid																																																																																																																																																																										
1																																																																																																																																																																													
2	pftm	Encoder feedback serial communication invalid	Encoder feedback serial communication valid																																																																																																																																																																										
3	plg2	Semi-closed pulse output signal x2 invalid	Semi-closed pulse output signal x2 valid																																																																																																																																																																										
4																																																																																																																																																																													
5	adin	Interpolation during thread cutting invalid	Interpolation during thread cutting valid																																																																																																																																																																										
6	orm	Orientation start memo invalid	Orientation start memo valid																																																																																																																																																																										
7	vfbs	This is used by Mitsubishi. Set to "0" unless particularly designated.																																																																																																																																																																											
8	sdt2	(Follows SFNC6-bitC setting)	Set output 2 to 2nd speed detection output																																																																																																																																																																										
9	pl80	MHE90K detector's 180 wave PLG	180 wave PLG other than MHE90K																																																																																																																																																																										
A	lmp	This is used by Mitsubishi. Set to "0" unless particularly designated.																																																																																																																																																																											
B	dcsn	Dual cushion during acceleration/ deceleration valid	Dual cushion during acceleration/ deceleration invalid																																																																																																																																																																										
C	XFzs	Set output 2 to MP scale low (L) speed mode	Set output 2 to zero speed output																																																																																																																																																																										
D	iqsv	This is used by Mitsubishi. Set to "0" unless particularly designated																																																																																																																																																																											
E	lmx																																																																																																																																																																												
F	oplp	Open loop operation invalid	Open loop operation valid																																																																																																																																																																										
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																																																																																										
0	alty	Deceleration stop during special alarm invalid	Deceleration stop during special alarm valid																																																																																																																																																																										
1																																																																																																																																																																													
2	pftm	Encoder feedback serial communication invalid	Encoder feedback serial communication valid																																																																																																																																																																										
3	plg2	Semi-closed pulse output signal x2 invalid	Semi-closed pulse output signal x2 valid																																																																																																																																																																										
4	tdn	Fixed control bit																																																																																																																																																																											
5	adin																																																																																																																																																																												
6	orm	Orientation start memo invalid	Orientation start memo valid																																																																																																																																																																										
7	vfbs																																																																																																																																																																												
8	sdt2																																																																																																																																																																												
9	pl80																																																																																																																																																																												
A	lmp	Fixed control bit																																																																																																																																																																											
B	dcsn																																																																																																																																																																												
C	XFzs																																																																																																																																																																												
D	iqsv																																																																																																																																																																												
E	lmx																																																																																																																																																																												
F	oplp	Open loop operation invalid	Open loop operation valid																																																																																																																																																																										

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting																																				
3239 (PR)	SP039	ATYP Amplifier type	Set the amplifier type. Set each amplifier type or "0" <table border="1" data-bbox="588 356 1046 965"> <thead> <tr> <th>Parameter setting</th> <th>Amplifier type</th> </tr> </thead> <tbody> <tr><td>0000</td><td>—</td></tr> <tr><td>0001</td><td>SP-075</td></tr> <tr><td>0002</td><td>SP-15</td></tr> <tr><td>0003</td><td>SP-22</td></tr> <tr><td>0004</td><td>SP-37</td></tr> <tr><td>0005</td><td>SP-55</td></tr> <tr><td>0006</td><td>SP-75</td></tr> <tr><td>0007</td><td>SP-110</td></tr> <tr><td>0008</td><td>SP-150</td></tr> <tr><td>0009</td><td>SP-185</td></tr> <tr><td>000A</td><td>SP-220</td></tr> <tr><td>000B</td><td>SP-260</td></tr> <tr><td>000C</td><td>SP-300</td></tr> <tr><td>000D</td><td>SP (H)-370</td></tr> <tr><td>000E</td><td>SP (H)-450</td></tr> <tr><td>000F</td><td>SP-04</td></tr> <tr><td>0010</td><td>SP-550</td></tr> </tbody> </table>	Parameter setting	Amplifier type	0000	—	0001	SP-075	0002	SP-15	0003	SP-22	0004	SP-37	0005	SP-55	0006	SP-75	0007	SP-110	0008	SP-150	0009	SP-185	000A	SP-220	000B	SP-260	000C	SP-300	000D	SP (H)-370	000E	SP (H)-450	000F	SP-04	0010	SP-550	0000 to FFFF HEX setting	0000
Parameter setting	Amplifier type																																								
0000	—																																								
0001	SP-075																																								
0002	SP-15																																								
0003	SP-22																																								
0004	SP-37																																								
0005	SP-55																																								
0006	SP-75																																								
0007	SP-110																																								
0008	SP-150																																								
0009	SP-185																																								
000A	SP-220																																								
000B	SP-260																																								
000C	SP-300																																								
000D	SP (H)-370																																								
000E	SP (H)-450																																								
000F	SP-04																																								
0010	SP-550																																								

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting																																																																																																																																				
3240 (PR)	SP040	MTYP Motor type	<p>This parameter is valid when SP034 (SFNC2) bit0 is set to "0". Set the appropriate motor number from the standard motors listed below.</p> <table border="1" data-bbox="592 443 1106 1458"> <thead> <tr> <th>Parameter setting</th> <th>Motor type</th> <th>Maximum speed</th> <th>Corre-spo nding amplifier</th> </tr> </thead> <tbody> <tr><td>0000</td><td></td><td></td><td></td></tr> <tr><td>0001</td><td>SJ-2.2A</td><td>10000 r/min</td><td>SP-22</td></tr> <tr><td>0002</td><td>SJ-3.7A</td><td>10000 r/min</td><td>SP-37</td></tr> <tr><td>0003</td><td>SJ-5.5A</td><td>8000 r/min</td><td>SP-55</td></tr> <tr><td>0004</td><td>SJ-7.5A</td><td>8000 r/min</td><td>SP-75</td></tr> <tr><td>0005</td><td>SJ-11A</td><td>6000 r/min</td><td>SP-110</td></tr> <tr><td>0006</td><td>SJ-15A</td><td>6000 r/min</td><td>SP-150</td></tr> <tr><td>0007</td><td>SJ-18.5A</td><td>6000 r/min</td><td>SP-185</td></tr> <tr><td>0008</td><td>SJ-22A</td><td>4500 r/min</td><td>SP-220</td></tr> <tr><td>0009</td><td>SJ-26A</td><td>4500 r/min</td><td>SP-260</td></tr> <tr><td>000A</td><td>SJ-30A</td><td>4500 r/min</td><td>SP-300</td></tr> <tr><td>000B</td><td></td><td></td><td></td></tr> <tr><td>000C</td><td></td><td></td><td></td></tr> <tr><td>000D</td><td></td><td></td><td></td></tr> <tr><td>000E</td><td></td><td></td><td></td></tr> <tr><td>000F</td><td></td><td></td><td></td></tr> <tr><td>0010</td><td></td><td></td><td></td></tr> <tr><td>0011</td><td>SJ-N0.75A</td><td>10000 r/min</td><td>SP-075</td></tr> <tr><td>0012</td><td>SJ-N1.5A</td><td>10000 r/min</td><td>SP-15</td></tr> <tr><td>0013</td><td>SJ-N2.2A</td><td>10000 r/min</td><td>SP-22</td></tr> <tr><td>0014</td><td>SJ-N3.7A</td><td>10000 r/min</td><td>SP-37</td></tr> <tr><td>0015</td><td>SJ-N5.5A</td><td>8000 r/min</td><td>SP-55</td></tr> <tr><td>0016</td><td>SJ-N7.5A</td><td>8000 r/min</td><td>SP-75</td></tr> <tr><td>0017</td><td></td><td></td><td></td></tr> <tr><td>0018</td><td></td><td></td><td></td></tr> <tr><td>0019</td><td></td><td></td><td></td></tr> <tr><td>001A</td><td></td><td></td><td></td></tr> <tr><td>001B</td><td>SJ-J2.2A</td><td>10000 r/min</td><td>SP-22</td></tr> <tr><td>001C</td><td>SJ-J3.7A</td><td>10000 r/min</td><td>SP-37</td></tr> <tr><td>001D</td><td>SJ-J5.5A</td><td>8000 r/min</td><td>SP-55</td></tr> <tr><td>001E</td><td>SJ-J7.5A</td><td>8000 r/min</td><td>SP-75</td></tr> <tr><td>001F</td><td></td><td></td><td></td></tr> </tbody> </table>	Parameter setting	Motor type	Maximum speed	Corre-spo nding amplifier	0000				0001	SJ-2.2A	10000 r/min	SP-22	0002	SJ-3.7A	10000 r/min	SP-37	0003	SJ-5.5A	8000 r/min	SP-55	0004	SJ-7.5A	8000 r/min	SP-75	0005	SJ-11A	6000 r/min	SP-110	0006	SJ-15A	6000 r/min	SP-150	0007	SJ-18.5A	6000 r/min	SP-185	0008	SJ-22A	4500 r/min	SP-220	0009	SJ-26A	4500 r/min	SP-260	000A	SJ-30A	4500 r/min	SP-300	000B				000C				000D				000E				000F				0010				0011	SJ-N0.75A	10000 r/min	SP-075	0012	SJ-N1.5A	10000 r/min	SP-15	0013	SJ-N2.2A	10000 r/min	SP-22	0014	SJ-N3.7A	10000 r/min	SP-37	0015	SJ-N5.5A	8000 r/min	SP-55	0016	SJ-N7.5A	8000 r/min	SP-75	0017				0018				0019				001A				001B	SJ-J2.2A	10000 r/min	SP-22	001C	SJ-J3.7A	10000 r/min	SP-37	001D	SJ-J5.5A	8000 r/min	SP-55	001E	SJ-J7.5A	8000 r/min	SP-75	001F				0000 to FFFF HEX setting	0000
Parameter setting	Motor type	Maximum speed	Corre-spo nding amplifier																																																																																																																																						
0000																																																																																																																																									
0001	SJ-2.2A	10000 r/min	SP-22																																																																																																																																						
0002	SJ-3.7A	10000 r/min	SP-37																																																																																																																																						
0003	SJ-5.5A	8000 r/min	SP-55																																																																																																																																						
0004	SJ-7.5A	8000 r/min	SP-75																																																																																																																																						
0005	SJ-11A	6000 r/min	SP-110																																																																																																																																						
0006	SJ-15A	6000 r/min	SP-150																																																																																																																																						
0007	SJ-18.5A	6000 r/min	SP-185																																																																																																																																						
0008	SJ-22A	4500 r/min	SP-220																																																																																																																																						
0009	SJ-26A	4500 r/min	SP-260																																																																																																																																						
000A	SJ-30A	4500 r/min	SP-300																																																																																																																																						
000B																																																																																																																																									
000C																																																																																																																																									
000D																																																																																																																																									
000E																																																																																																																																									
000F																																																																																																																																									
0010																																																																																																																																									
0011	SJ-N0.75A	10000 r/min	SP-075																																																																																																																																						
0012	SJ-N1.5A	10000 r/min	SP-15																																																																																																																																						
0013	SJ-N2.2A	10000 r/min	SP-22																																																																																																																																						
0014	SJ-N3.7A	10000 r/min	SP-37																																																																																																																																						
0015	SJ-N5.5A	8000 r/min	SP-55																																																																																																																																						
0016	SJ-N7.5A	8000 r/min	SP-75																																																																																																																																						
0017																																																																																																																																									
0018																																																																																																																																									
0019																																																																																																																																									
001A																																																																																																																																									
001B	SJ-J2.2A	10000 r/min	SP-22																																																																																																																																						
001C	SJ-J3.7A	10000 r/min	SP-37																																																																																																																																						
001D	SJ-J5.5A	8000 r/min	SP-55																																																																																																																																						
001E	SJ-J7.5A	8000 r/min	SP-75																																																																																																																																						
001F																																																																																																																																									

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting																																																																																																																																																																							
3241 (PR)	SP041	PTYP Power supply type	Power supply type F E D C B A 9 8 <table border="1" style="width:100%; text-align:center;"> <tr> <td colspan="4">amp</td> <td colspan="4">rtyp</td> </tr> </table> 7 6 5 4 3 2 1 0 <table border="1" style="width:100%; text-align:center;"> <tr> <td colspan="8">ptyp</td> </tr> </table> <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th style="width:5%;">bit</th> <th colspan="10">Explanation</th> </tr> </thead> <tbody> <tr> <td>0</td> <td colspan="10" rowspan="3">When the CN4 connector of the drive unit and the power supply are connected, setting below is necessary. To validate the external emergency stop function, add 40h.</td> </tr> <tr> <td>1</td> </tr> <tr> <td>2</td> </tr> <tr> <td>3</td> <td colspan="10"> <table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th style="width:5%;">Set-ting</th> <th>0x</th> <th>1x</th> <th>2x</th> <th>3x</th> <th>4x</th> <th>5x</th> <th>6x</th> <th>7x</th> <th>8x</th> </tr> </thead> <tbody> <tr> <td>4</td> <td>Not used</td> <td></td> <td></td> <td>CV-300</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>5</td> <td>x1</td> <td>CV-110</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-10</td> </tr> <tr> <td>6</td> <td>x2</td> <td></td> <td>CV-220</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-15</td> </tr> <tr> <td>7</td> <td>x3</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-22</td> </tr> <tr> <td></td> <td>x4</td> <td>CV-37</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-37</td> </tr> <tr> <td></td> <td>x5</td> <td></td> <td>CV-150</td> <td></td> <td></td> <td>CV-450</td> <td>CV-550</td> <td></td> <td></td> </tr> <tr> <td></td> <td>x6</td> <td>CV-55</td> <td></td> <td>CV-260</td> <td></td> <td></td> <td></td> <td></td> <td>CR-55</td> </tr> <tr> <td></td> <td>x7</td> <td></td> <td></td> <td></td> <td>CV-370</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>x8</td> <td>CV-75</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-75</td> </tr> <tr> <td></td> <td>x9</td> <td></td> <td>CV-185</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-90</td> </tr> </tbody> </table> </td> <td data-bbox="1158 282 1310 1615">0000 to FFFF HEX setting</td> <td data-bbox="1310 282 1460 1615">0000</td> </tr> <tr> <td data-bbox="137 1615 220 1749">3242 (PR)</td> <td data-bbox="220 1615 312 1749">SP042</td> <td data-bbox="312 1615 580 1749">CRNG C-axis detector range</td> <td data-bbox="580 1615 1158 1749"> This parameter is used to set the C-axis detector range. Set "0" for this parameter. "2" is used by Mitsubishi for testing. </td> <td data-bbox="1158 1615 1310 1749">0 to 7</td> <td data-bbox="1310 1615 1460 1749">0</td> </tr> </tbody> </table>	amp				rtyp				ptyp								bit	Explanation										0	When the CN4 connector of the drive unit and the power supply are connected, setting below is necessary. To validate the external emergency stop function, add 40h.										1	2	3	<table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th style="width:5%;">Set-ting</th> <th>0x</th> <th>1x</th> <th>2x</th> <th>3x</th> <th>4x</th> <th>5x</th> <th>6x</th> <th>7x</th> <th>8x</th> </tr> </thead> <tbody> <tr> <td>4</td> <td>Not used</td> <td></td> <td></td> <td>CV-300</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>5</td> <td>x1</td> <td>CV-110</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-10</td> </tr> <tr> <td>6</td> <td>x2</td> <td></td> <td>CV-220</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-15</td> </tr> <tr> <td>7</td> <td>x3</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-22</td> </tr> <tr> <td></td> <td>x4</td> <td>CV-37</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-37</td> </tr> <tr> <td></td> <td>x5</td> <td></td> <td>CV-150</td> <td></td> <td></td> <td>CV-450</td> <td>CV-550</td> <td></td> <td></td> </tr> <tr> <td></td> <td>x6</td> <td>CV-55</td> <td></td> <td>CV-260</td> <td></td> <td></td> <td></td> <td></td> <td>CR-55</td> </tr> <tr> <td></td> <td>x7</td> <td></td> <td></td> <td></td> <td>CV-370</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>x8</td> <td>CV-75</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-75</td> </tr> <tr> <td></td> <td>x9</td> <td></td> <td>CV-185</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-90</td> </tr> </tbody> </table>										Set-ting	0x	1x	2x	3x	4x	5x	6x	7x	8x	4	Not used			CV-300						5	x1	CV-110							CR-10	6	x2		CV-220						CR-15	7	x3								CR-22		x4	CV-37							CR-37		x5		CV-150			CV-450	CV-550				x6	CV-55		CV-260					CR-55		x7				CV-370						x8	CV-75							CR-75		x9		CV-185						CR-90	0000 to FFFF HEX setting	0000	3242 (PR)	SP042	CRNG C-axis detector range	This parameter is used to set the C-axis detector range. Set "0" for this parameter. "2" is used by Mitsubishi for testing.	0 to 7	0
amp				rtyp																																																																																																																																																																								
ptyp																																																																																																																																																																												
bit	Explanation																																																																																																																																																																											
0	When the CN4 connector of the drive unit and the power supply are connected, setting below is necessary. To validate the external emergency stop function, add 40h.																																																																																																																																																																											
1																																																																																																																																																																												
2																																																																																																																																																																												
3	<table border="1" style="width:100%; text-align:center;"> <thead> <tr> <th style="width:5%;">Set-ting</th> <th>0x</th> <th>1x</th> <th>2x</th> <th>3x</th> <th>4x</th> <th>5x</th> <th>6x</th> <th>7x</th> <th>8x</th> </tr> </thead> <tbody> <tr> <td>4</td> <td>Not used</td> <td></td> <td></td> <td>CV-300</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>5</td> <td>x1</td> <td>CV-110</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-10</td> </tr> <tr> <td>6</td> <td>x2</td> <td></td> <td>CV-220</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-15</td> </tr> <tr> <td>7</td> <td>x3</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-22</td> </tr> <tr> <td></td> <td>x4</td> <td>CV-37</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-37</td> </tr> <tr> <td></td> <td>x5</td> <td></td> <td>CV-150</td> <td></td> <td></td> <td>CV-450</td> <td>CV-550</td> <td></td> <td></td> </tr> <tr> <td></td> <td>x6</td> <td>CV-55</td> <td></td> <td>CV-260</td> <td></td> <td></td> <td></td> <td></td> <td>CR-55</td> </tr> <tr> <td></td> <td>x7</td> <td></td> <td></td> <td></td> <td>CV-370</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>x8</td> <td>CV-75</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-75</td> </tr> <tr> <td></td> <td>x9</td> <td></td> <td>CV-185</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>CR-90</td> </tr> </tbody> </table>										Set-ting	0x	1x	2x	3x	4x	5x	6x	7x	8x	4	Not used			CV-300						5	x1	CV-110							CR-10	6	x2		CV-220						CR-15	7	x3								CR-22		x4	CV-37							CR-37		x5		CV-150			CV-450	CV-550				x6	CV-55		CV-260					CR-55		x7				CV-370						x8	CV-75							CR-75		x9		CV-185						CR-90	0000 to FFFF HEX setting	0000																																																		
Set-ting	0x	1x	2x	3x	4x	5x	6x	7x	8x																																																																																																																																																																			
4	Not used			CV-300																																																																																																																																																																								
5	x1	CV-110							CR-10																																																																																																																																																																			
6	x2		CV-220						CR-15																																																																																																																																																																			
7	x3								CR-22																																																																																																																																																																			
	x4	CV-37							CR-37																																																																																																																																																																			
	x5		CV-150			CV-450	CV-550																																																																																																																																																																					
	x6	CV-55		CV-260					CR-55																																																																																																																																																																			
	x7				CV-370																																																																																																																																																																							
	x8	CV-75							CR-75																																																																																																																																																																			
	x9		CV-185						CR-90																																																																																																																																																																			
3242 (PR)	SP042	CRNG C-axis detector range	This parameter is used to set the C-axis detector range. Set "0" for this parameter. "2" is used by Mitsubishi for testing.	0 to 7	0																																																																																																																																																																							



8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting
3243 (PR)	SP043	TRNG	Synchronous tapping, spindle synchronous detector range	This parameter is used to set the synchronous tapping or spindle synchronous detector range. Set "0" for this parameter.	0 to 7 0
3244 (PR)	SP044	TRANS	NC communication frequency	Set a frequency of data communication with NC.	0 to 32767 Standard: 0 Special: 1028
3245	SP045	CSNT	Dual cushion timer	Set the cycle to add the increment values in the dual cushion process. When this setting value is increased, the dual cushion will increase, and the changes in the speed during acceleration/deceleration will become gradual.	0 to 1000 (ms) 0
3246 (PR)	SP046	CSN2	Speed command dual cushion	For an acceleration/deceleration time constant defined in SP019 (CSN1), this parameter is used to provide smooth movement only at the start of acceleration/deceleration. As the value of this parameter is smaller, it moves smoother but the acceleration/deceleration time becomes longer. To make this parameter invalid, set "0".	0 to 1000 0
3247 (PR)	SP047	SDTR	Speed detection reset value	Set the reset hysteresis width for a speed detection set value defined in SP020 (SDTS).	0 to 1000 (r/min) 30
3247 (PR)	SP047	SDTR	Speed detection reset value	Set the reset hysteresis width for a speed detection set value defined in SP020 (SDTS).	0 to 1000 (r/min) 30
3248 (PR)	SP048	SUT	Speed reach range	Set the speed deviation rate with respect to the commanded speed for output of the speed reach signal.	0 to 100 (%) 15
3249	SP049	TLM2	Torque limit 2	Set the torque limit rate for the torque limit signal 010.	1 to 120 (%) 20
3250	SP050	TLM3	Torque limit 3	Set the torque limit rate for the torque limit signal 011.	1 to 120 (%) 30
3251	SP051	TLM4	Torque limit 4	Set the torque limit rate for the torque limit signal 100.	1 to 120 (%) 40
3252	SP052	TLM5	Torque limit 5	Set the torque limit rate for the torque limit signal 101.	1 to 120 (%) 50
3253	SP053	TLM6	Torque limit 6	Set the torque limit rate for the torque limit signal 110.	1 to 120 (%) 60
3254	SP054	TLM7	Torque limit 7	Set the torque limit rate for the torque limit signal 111.	1 to 120 (%) 70

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting
3255 (PR)	SP055	SETM	Excessive speed deviation timer	Set the timer value until the excessive speed deviation alarm is output. The value of this parameter should be longer than the acceleration/deceleration time.	0 to 60 (s) 12
3256	SP056	PYVR	Variable excitation (min value)	Set the minimum value of the variable excitation rate. Select a smaller value when gear noise is too high. However, a larger value is effective for impact response.	0 to 100 (%) 50
3257 (PR)	SP057	STOD	Constant → excessive judgment value	Set the value for judging when changing from a constant to excessive speed command.	0 to 50 (r/min) 0
3258 (PR)	SP058	SDT2	Fixed control constant	Used by Mitsubishi. Set "0" unless designated in particular.	0 0
3259 (PR)	SP059	MKT	Winding changeover base shut-off timer	Set the base shut-off time for contactor switching at winding changeover. Note that the contactor may be damaged with burning if the value of this parameter is too small.	50 to 10000 (ms) 150
3260 (PR)	SP060	MKT2	Current limit timer after winding changeover	Set the current limit time to be taken after completion of contactor switching at winding changeover.	0 to 10000 (ms) 500
3261 (PR)	SP061	MKIL	Current limit value after winding changeover	Set the current limit value during a period defined in SP060 (MKT2) after completion of contactor switching at winding changeover.	0 to 120 (%) 75
3262	SP062			Not used. Set to "0".	0 0

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting																
3263 (PR)	SP063	OLT	Overload alarm detection time	Set the time constant for detection of the motor overload alarm.	0 to 1000 (s)	60															
3264 (PR)	SP064	OLL	Overload alarm detection level	Set the detection level of the motor overload alarm.	0 to 120 (%)	110															
3265 (PR)	SP065	VCGN1	Target value of variable speed loop proportional gain	Set the magnification of speed loop proportional gain with respect to SP022 (VGNP1) at the maximum motor speed defined in SP017 (TSP).	0 to 100 (%)	100															
3266 (PR)	SP066	VCSN1	Change starting speed of variable speed loop proportional gain	Set the speed when the speed loop proportional gain change starts. 	0 to 32767 (r/min)	0															
3267 (PR)	SP067	VIGWA	Change starting speed of variable current loop gain	Set the speed where the current loop gain change starts.	0 to 32767 (r/min)	0															
3268 (PR)	SP068	VIGWB	Change ending speed of variable current loop gain	Set the speed where the current loop gain change ends.	0 to 32767 (r/min)	0															
3269 (PR)	SP069	VIGN	Target value of variable current loop gain	Set the magnification of current loop gain (torque component and excitation component) for a change ending speed defined in SP068 (VIGWB). When this parameter is set to "0", the magnification is 1. 	0 to 32767 (1/16-fold)	0															
			<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>SP017 (TSP) Maximum motor speed</th> <th>SP067 (VIGWA)</th> <th>SP068 (VIGWB)</th> <th>SP069 (VIGN)</th> </tr> </thead> <tbody> <tr> <td>0 to 6000</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0</td> </tr> <tr> <td>6001 to 8000</td> <td style="text-align: center;">5000</td> <td style="text-align: center;">8000</td> <td style="text-align: center;">45</td> </tr> <tr> <td>8001 or more</td> <td style="text-align: center;">5000</td> <td style="text-align: center;">10000</td> <td style="text-align: center;">64</td> </tr> </tbody> </table>			SP017 (TSP) Maximum motor speed	SP067 (VIGWA)	SP068 (VIGWB)	SP069 (VIGN)	0 to 6000	0	0	0	6001 to 8000	5000	8000	45	8001 or more	5000	10000	64
SP017 (TSP) Maximum motor speed	SP067 (VIGWA)	SP068 (VIGWB)	SP069 (VIGN)																		
0 to 6000	0	0	0																		
6001 to 8000	5000	8000	45																		
8001 or more	5000	10000	64																		

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting																																																																																																				
3270	SP070	FHz	Machine resonance suppression filter frequency	When machine vibration occurs in speed and position control, set the frequency of the required vibration suppression. Note that a value of 100Hz or more is set. Set to "0" when not used.	0 to 3000 (Hz)	0																																																																																																			
3271 (PR)	SP071	VR2WA	Fixed control constant	Used by Mitsubishi. Set "0" unless designated in particular.	0	0																																																																																																			
3272 (PR)	SP072	VR2WB																																																																																																							
3273 (PR)	SP073	VR2GN																																																																																																							
3274 (PR)	SP074	IGDEC																																																																																																							
3275	SP075	R2KWS	<table border="1" style="width:100%; border-collapse: collapse;"> <tr> <td align="center">F</td><td align="center">E</td><td align="center">D</td><td align="center">C</td><td align="center">B</td><td align="center">A</td><td align="center">9</td><td align="center">8</td> </tr> <tr> <td align="center"> </td><td align="center"> </td><td align="center"> </td><td align="center"> </td><td align="center"> </td><td align="center"> </td><td align="center"> </td><td align="center">r2ini</td> </tr> <tr> <td align="center">7</td><td align="center">6</td><td align="center">5</td><td align="center">4</td><td align="center">3</td><td align="center">2</td><td align="center">1</td><td align="center">0</td> </tr> <tr> <td align="center"> </td><td align="center"> </td><td align="center"> </td><td align="center">r2am</td><td align="center">r2lm</td><td align="center">r2dn</td><td align="center">no51</td><td align="center">r2ch</td> </tr> </table> <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>bit</th><th>Name</th><th>Meaning when set to 0</th><th>Meaning when set to 1</th></tr> </thead> <tbody> <tr> <td align="center">0</td><td>r2ch</td><td colspan="2">This is used by Mitsubishi.</td></tr> <tr> <td align="center">1</td><td>no51</td><td colspan="2">Set to "0" unless particularly designated.</td></tr> <tr> <td align="center">2</td><td>r2dm</td><td colspan="2"> </td></tr> <tr> <td align="center">3</td><td>r2lm</td><td colspan="2"> </td></tr> <tr> <td align="center">4</td><td>r2am</td><td colspan="2"> </td></tr> <tr> <td align="center">5</td><td> </td><td colspan="2"> </td></tr> <tr> <td align="center">6</td><td> </td><td colspan="2"> </td></tr> <tr> <td align="center">7</td><td> </td><td colspan="2"> </td></tr> <tr> <td align="center">8</td><td>r2ini</td><td colspan="2">This is used by Mitsubishi. Set to "0" unless particularly designated</td></tr> <tr> <td align="center">9</td><td> </td><td colspan="2"> </td></tr> <tr> <td align="center">A</td><td> </td><td colspan="2"> </td></tr> <tr> <td align="center">B</td><td> </td><td colspan="2"> </td></tr> <tr> <td align="center">C</td><td> </td><td colspan="2"> </td></tr> <tr> <td align="center">D</td><td> </td><td colspan="2"> </td></tr> <tr> <td align="center">E</td><td> </td><td colspan="2"> </td></tr> <tr> <td align="center">F</td><td> </td><td colspan="2"> </td></tr> </tbody> </table>	F	E	D	C	B	A	9	8								r2ini	7	6	5	4	3	2	1	0				r2am	r2lm	r2dn	no51	r2ch	bit	Name	Meaning when set to 0	Meaning when set to 1	0	r2ch	This is used by Mitsubishi.		1	no51	Set to "0" unless particularly designated.		2	r2dm			3	r2lm			4	r2am			5				6				7				8	r2ini	This is used by Mitsubishi. Set to "0" unless particularly designated		9				A				B				C				D				E				F					
F	E	D	C	B	A	9	8																																																																																																		
							r2ini																																																																																																		
7	6	5	4	3	2	1	0																																																																																																		
			r2am	r2lm	r2dn	no51	r2ch																																																																																																		
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																						
0	r2ch	This is used by Mitsubishi.																																																																																																							
1	no51	Set to "0" unless particularly designated.																																																																																																							
2	r2dm																																																																																																								
3	r2lm																																																																																																								
4	r2am																																																																																																								
5																																																																																																									
6																																																																																																									
7																																																																																																									
8	r2ini	This is used by Mitsubishi. Set to "0" unless particularly designated																																																																																																							
9																																																																																																									
A																																																																																																									
B																																																																																																									
C																																																																																																									
D																																																																																																									
E																																																																																																									
F																																																																																																									
3276	SP076	FONS	Machine resonance suppression filter operation speed	When the vibration increases in motor stop (ex. in orientation stop) when the machine vibration suppression filter is operated by SP070, operate the machine vibration suppression filter at a speed of this parameter or more. When set to "0", this is validated for all speeds.	0 to 32767 (r/min)	0																																																																																																			
3277 (PR)	SP077	TDSL	Fixed control constant	Used by Mitsubishi. Set "14" unless designated in particular.		14																																																																																																			
3278 (PR)	SP078	FPWM	Fixed control constant	Used by Mitsubishi. Set "0" unless designated in particular.	0	0																																																																																																			
3279 (PR)	SP079	ILMT																																																																																																							

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting	
3280	SP080			Use not possible.	0	0
3281	SP081	LMCA	Fixed control constant	This is used by Mitsubishi. Set to "0" unless particularly designated.	0	0
3282	SP082	LMCB				
3283	SP083					
3284 to 3286	SP084 to SP086			Use not possible.	0	0
3287 (PR)	SP087	DIQM	Target value of variable torque limit magnification at deceleration	Set the minimum value of variable torque limit at deceleration.	0 to 150 (%)	75
3288 (PR)	SP088	DIQN	Speed for starting change of variable torque limit magnification at deceleration	Set the speed where the torque limit value at deceleration starts to change.	0 to 32767 (r/min)	3000
				<p style="text-align: center;">Torque limit 100% SP087 Inversely proportional to speed SP088 SP017</p>		
3289	SP089			Use not possible.	0	0
3290	SP090			Use not possible.	0	0
3291	SP091	OFSN	Motor PLG forward rotation offset compensation	Set the PLG offset value for the forward rotation. Normally set to "0".	-2048 to 2047 (-1mv)	0
3292	SP092	OFSI	Motor PLG reverse rotation offset compensation	Set the PLG offset value for the reverse rotation. Normally set to "0".	-2048 to 2047 (-1mv)	0
3293 (PR)	SP093	ORE	Tolerable pulse check error	Set this when detecting the pulse detector's pulse mistakes. (Valid only for full close control.)	0 to 32767	0
3294 (PR)	SP094	LMAV	Load meter output filter	Set the filter time constant of load meter output. When "0" is set, a filter time constant is set to 100ms.	0 to 32767 (2ms)	0
3295 (PR)	SP095	VFAV	Fixed control constant	Used by Mitsubishi. Set "0" unless designated in particular.	0	0

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting																																																																																																											
3296 (PR)	SP096	EGAR	Encoder gear ratio <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">Setting value</th> <th style="width: 15%;">Gear ratio (deceleration)</th> <th style="width: 10%;">Setting value</th> <th style="width: 15%;">Gear ratio (acceleration)</th> </tr> </thead> <tbody> <tr><td style="text-align: center;">0</td><td style="text-align: center;">1 : 1</td><td style="text-align: center;">-1</td><td style="text-align: center;">1 : 2</td></tr> <tr><td style="text-align: center;">1</td><td style="text-align: center;">1 : 1/2</td><td style="text-align: center;">-2</td><td style="text-align: center;">1 : 4</td></tr> <tr><td style="text-align: center;">2</td><td style="text-align: center;">1 : 1/4</td><td style="text-align: center;">-3</td><td style="text-align: center;">1 : 3</td></tr> <tr><td style="text-align: center;">3</td><td style="text-align: center;">1 : 1/8</td><td></td><td></td></tr> <tr><td style="text-align: center;">4</td><td style="text-align: center;">1 : 1/16</td><td></td><td></td></tr> </tbody> </table>	Setting value	Gear ratio (deceleration)	Setting value	Gear ratio (acceleration)	0	1 : 1	-1	1 : 2	1	1 : 1/2	-2	1 : 4	2	1 : 1/4	-3	1 : 3	3	1 : 1/8			4	1 : 1/16			-3 to 4	0																																																																																			
Setting value	Gear ratio (deceleration)	Setting value	Gear ratio (acceleration)																																																																																																													
0	1 : 1	-1	1 : 2																																																																																																													
1	1 : 1/2	-2	1 : 4																																																																																																													
2	1 : 1/4	-3	1 : 3																																																																																																													
3	1 : 1/8																																																																																																															
4	1 : 1/16																																																																																																															
3297 (PR)	SP097	SPECO	Orientation specification <p style="text-align: center;">F E D C B A 9 8</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <tr> <td style="width: 10%;">ostp</td> <td style="width: 10%;">orze</td> <td style="width: 10%;">ksft</td> <td style="width: 10%;">gchg</td> <td style="width: 10%;"></td> <td style="width: 10%;">ips2</td> <td style="width: 10%;">zdir</td> <td style="width: 10%;"></td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">6</td> <td style="text-align: center;">5</td> <td style="text-align: center;">4</td> <td style="text-align: center;">3</td> <td style="text-align: center;">2</td> <td style="text-align: center;">1</td> <td style="text-align: center;">0</td> </tr> <tr> <td style="width: 10%;">vg8x</td> <td style="width: 10%;">mdir</td> <td style="width: 10%;">fdir</td> <td style="width: 10%;">osc1</td> <td style="width: 10%;">pyfx</td> <td style="width: 10%;">dmin</td> <td style="width: 10%;">odi2</td> <td style="width: 10%;">odi1</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 5%;">bit</th> <th style="width: 15%;">Name</th> <th style="width: 35%;">Meaning when set to 0</th> <th style="width: 45%;">Meaning when set to 1</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">odi1</td> <td colspan="2">Orientation rotation direction</td> </tr> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">odi2</td> <td colspan="2">00: Previous (the direction in which the motor has so far rotated under speed control) 01: Forward rotation 10: Backward rotation 11: Prohibited (Same as setting value = 10)</td> </tr> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">dmin</td> <td>Orientation in-position advance invalid</td> <td>Orientation in-position advance valid</td> </tr> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">pyfx</td> <td>Excitation min. (50%) during orientation servo lock invalid</td> <td>Excitation min. (50%) during orientation servo lock valid</td> </tr> <tr> <td style="text-align: center;">4</td> <td style="text-align: center;">osc1</td> <td>Indexing speed clamp invalid</td> <td>Indexing speed clamp valid</td> </tr> <tr> <td style="text-align: center;">5</td> <td style="text-align: center;">fdir</td> <td>Encoder detector polarity: +</td> <td>Encoder detector polarity: -</td> </tr> <tr> <td style="text-align: center;">6</td> <td style="text-align: center;">mdir</td> <td>Magnetic sensor polarity: +</td> <td>Magnetic sensor polarity: -</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">vg8x</td> <td>Speed gain *1/8 during torque limit valid</td> <td>Speed gain *1/8 during torque limit invalid</td> </tr> <tr> <td style="text-align: center;">8</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">9</td> <td style="text-align: center;">zdir</td> <td colspan="2">This is used by Mitsubishi. Set to "0" unless particularly designated.</td> </tr> <tr> <td style="text-align: center;">A</td> <td style="text-align: center;">ips2</td> <td>2nd in-position invalid</td> <td>2nd in-position valid</td> </tr> <tr> <td style="text-align: center;">B</td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">C</td> <td style="text-align: center;">gchg</td> <td>Gain changeover during orientation invalid</td> <td>Gain changeover during orientation valid</td> </tr> <tr> <td style="text-align: center;">D</td> <td style="text-align: center;">ksft</td> <td>Orientation virtual target shift invalid</td> <td>Orientation virtual target shift valid</td> </tr> <tr> <td style="text-align: center;">E</td> <td style="text-align: center;">orze</td> <td colspan="2">This is used by Mitsubishi.</td> </tr> <tr> <td style="text-align: center;">F</td> <td style="text-align: center;">ostp</td> <td colspan="2">Set to "0" unless particularly designated.</td> </tr> </tbody> </table> <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="4" style="text-align: center;">In-position advance (bit 2)</th> </tr> <tr> <th colspan="2"></th> <th style="text-align: center;">0 (invalid)</th> <th style="text-align: center;">1 (valid)</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="writing-mode: vertical-rl; transform: rotate(180deg);">Second in-position</td> <td style="text-align: center;">0 (Invalid)</td> <td>In-position signal in OINP width=1 Control output 4/ bit 4=1 Second in-position signal=0 Control output 4/ bit F=1</td> <td>In-position signal in OINP width=1 Control output 4/ bit 4=1 Second in-position signal=0 Control output 4/ bit F=0</td> </tr> <tr> <td style="text-align: center;">1 (Valid)</td> <td></td> <td>In-position signal in DINP width=1 Control output 4/ bit 4=1 Second in-position signal in OINP width = 0 Control output 4/ bit F=1</td> </tr> </tbody> </table>	ostp	orze	ksft	gchg		ips2	zdir		7	6	5	4	3	2	1	0	vg8x	mdir	fdir	osc1	pyfx	dmin	odi2	odi1	bit	Name	Meaning when set to 0	Meaning when set to 1	0	odi1	Orientation rotation direction		1	odi2	00: Previous (the direction in which the motor has so far rotated under speed control) 01: Forward rotation 10: Backward rotation 11: Prohibited (Same as setting value = 10)		2	dmin	Orientation in-position advance invalid	Orientation in-position advance valid	3	pyfx	Excitation min. (50%) during orientation servo lock invalid	Excitation min. (50%) during orientation servo lock valid	4	osc1	Indexing speed clamp invalid	Indexing speed clamp valid	5	fdir	Encoder detector polarity: +	Encoder detector polarity: -	6	mdir	Magnetic sensor polarity: +	Magnetic sensor polarity: -	7	vg8x	Speed gain *1/8 during torque limit valid	Speed gain *1/8 during torque limit invalid	8				9	zdir	This is used by Mitsubishi. Set to "0" unless particularly designated.		A	ips2	2nd in-position invalid	2nd in-position valid	B				C	gchg	Gain changeover during orientation invalid	Gain changeover during orientation valid	D	ksft	Orientation virtual target shift invalid	Orientation virtual target shift valid	E	orze	This is used by Mitsubishi.		F	ostp	Set to "0" unless particularly designated.		In-position advance (bit 2)						0 (invalid)	1 (valid)	Second in-position	0 (Invalid)	In-position signal in OINP width=1 Control output 4/ bit 4=1 Second in-position signal=0 Control output 4/ bit F=1	In-position signal in OINP width=1 Control output 4/ bit 4=1 Second in-position signal=0 Control output 4/ bit F=0	1 (Valid)		In-position signal in DINP width=1 Control output 4/ bit 4=1 Second in-position signal in OINP width = 0 Control output 4/ bit F=1	0000 to FFFF HEX setting	0000
ostp	orze	ksft	gchg		ips2	zdir																																																																																																										
7	6	5	4	3	2	1	0																																																																																																									
vg8x	mdir	fdir	osc1	pyfx	dmin	odi2	odi1																																																																																																									
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																													
0	odi1	Orientation rotation direction																																																																																																														
1	odi2	00: Previous (the direction in which the motor has so far rotated under speed control) 01: Forward rotation 10: Backward rotation 11: Prohibited (Same as setting value = 10)																																																																																																														
2	dmin	Orientation in-position advance invalid	Orientation in-position advance valid																																																																																																													
3	pyfx	Excitation min. (50%) during orientation servo lock invalid	Excitation min. (50%) during orientation servo lock valid																																																																																																													
4	osc1	Indexing speed clamp invalid	Indexing speed clamp valid																																																																																																													
5	fdir	Encoder detector polarity: +	Encoder detector polarity: -																																																																																																													
6	mdir	Magnetic sensor polarity: +	Magnetic sensor polarity: -																																																																																																													
7	vg8x	Speed gain *1/8 during torque limit valid	Speed gain *1/8 during torque limit invalid																																																																																																													
8																																																																																																																
9	zdir	This is used by Mitsubishi. Set to "0" unless particularly designated.																																																																																																														
A	ips2	2nd in-position invalid	2nd in-position valid																																																																																																													
B																																																																																																																
C	gchg	Gain changeover during orientation invalid	Gain changeover during orientation valid																																																																																																													
D	ksft	Orientation virtual target shift invalid	Orientation virtual target shift valid																																																																																																													
E	orze	This is used by Mitsubishi.																																																																																																														
F	ostp	Set to "0" unless particularly designated.																																																																																																														
In-position advance (bit 2)																																																																																																																
		0 (invalid)	1 (valid)																																																																																																													
Second in-position	0 (Invalid)	In-position signal in OINP width=1 Control output 4/ bit 4=1 Second in-position signal=0 Control output 4/ bit F=1	In-position signal in OINP width=1 Control output 4/ bit 4=1 Second in-position signal=0 Control output 4/ bit F=0																																																																																																													
	1 (Valid)		In-position signal in DINP width=1 Control output 4/ bit 4=1 Second in-position signal in OINP width = 0 Control output 4/ bit F=1																																																																																																													

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting	
3298 (PR)	SP098	VGOP	Speed loop gain proportional term in orientation mode	Set the speed loop proportional gain in orientation mode. When the gain is increased, rigidity is improved in the orientation stop but vibration and sound become larger.	0 to 1000 (1/s)	63
3299 (PR)	SP099	VGOI	Orientation mode speed loop gain integral term	Set the speed loop integral gain in orientation mode.	0 to 1000 (0.1 1/s)	60
3300 (PR)	SP100	VGOD	Orientation mode speed loop gain delay advance term	Set a loop gain delay advance gain in orientation mode. When this parameter is set to "0", PI control is applied.	0 to 1000 (0.1 1/s)	15
3301 (PR)	SP101	DINP	Orientation advance in-position width	When using the orientation in-position advance function, set the in-position width that is larger than the normal in-position width defined in SP004 (OINP).	1 to 2880 (1/16°)	16
3302 (PR)	SP102	OODR	Excessive error value in orientation mode	Set the excessive error width in orientation mode.	0 to 32767 (1/4 pulse) (1 pulse= 0.088°)	32767
3303 (PR)	SP103	FTM	Index positioning completion OFF time timer	Set the time for forcedly turn OFF the index positioning completion signal (different from the orientation completion signal) after the leading edge of the indexing start signal.	0 to 10000 (ms)	200
3304 (PR)	SP104	TLOR	Torque limit value for orientation servo locking	Set the torque limit value for orientation in-position output. If the external torque limit signal is input, the torque limit value set by this parameter is made invalid.	0 to 120 (%)	100
3305 (PR)	SP105	IQG0	Current loop gain magnification 1 in orientation mode	Set the magnification for current loop gain (torque component) at orientation completion.	1 to 1000 (%)	100
3306 (PR)	SP106	IDG0	Current loop gain magnification 2 in orientation mode	Set the magnification for current loop gain (excitation component) at orientation completion.	1 to 1000 (%)	100
3307	SP107	CSP2	Deceleration rate 2 in orientation mode	Set the deceleration rate in orientation mode corresponding to the gear 001. When this parameter is set to "0", same as SP006 (CSP).	0 to 1000	0

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting
3308	SP108	CSP3	Deceleration rate 3 in orientation mode	Set the deceleration rate in orientation mode corresponding to the gear 010. When this parameter is set to "0", same as SP006 (CSP).	0 to 1000 0
3309	SP109	CSP4	Deceleration rate 4 in orientation mode	Set the deceleration rate in orientation mode corresponding to the gear 011. When this parameter is set to "0", same as SP006 (CSP).	0 to 1000 0
3310 to 3313	SP110 to SP113			Use not possible.	0
3314	SP114	OPER	Orientation pulse miss check value	An alarm "5C" will occur if the pulse miss value at the orientation stop exceeds this setting value. (Note that this is invalid when set to "0".) In this parameter, set the value to fulfill the following conditions. SP114 setting value > 1.5 × SP004 (orientation in-position width)	0 to 32767 (360°/4096) 0
3315	SP115	OSP2	Orientation motor speed clamp value 2	When the orientation clamp speed is changed by the control input, this parameter setting will be used instead of SP005: OSP. Indexing speed clamp valid This parameter is used when (SP097: SPEC0-bit4 = 1).	0 to 32767 (r/min) 0
3316	SP116	OPYVR	Minimum excitation value after changeover (2nd minimum excitation rate)	Minimum excitation rate when position control input or external input is selected.	0 to 100 (%) 0
3317	SP117	ORUT		This is used by Mitsubishi. Set to "0" unless particularly designated.	0 0
3318	SP118	ORCT	Number of orientation retry times	Set the number of times to retry when an orientation or feedback error occurs. The warning (A9) is issued while retrying orientation, and an alarm (5C) is issued when the set number of times is exceeded.	0 to 100 (time) 0
3319	SP119	MPGH	Orientation position gain H winding compensation magnification	Set the compensation magnification of the orientation position loop gain for the H winding. H winding orientation position loop gain = SP001 (or SP002) × SP119/256 When set to "0", will become the same as SP001 or SP002.	0 to 2560 (1/256-fold) 0

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting
3320	SP120	MPGL	Orientation position gain L winding compensation magnification When set to "0", will become the same as SP001 or SP002.	0 to 2560 (1/256-fold)	0
3321	SP121	MPCSH	Orientation deceleration rate H winding compensation magnification When set to "0", will become the same as SP006.	0 to 2560 (1/256-fold)	0
3322	SP122	MPCSL	Orientation deceleration rate L winding compensation magnification When set to "0", will become the same as SP006.	0 to 2560 (1/256-fold)	0
3323	SP123	MGD0	Magnetic sensor output peak value If a gap between the sensor and the magnetizing element is small, increase the value of this parameter. If it is large, decrease the value of this parameter.	1 to 10000	Standard magnetizing element: 542 Small magnetizing element: 500
3324	SP124	MGD1	Magnetic sensor linear zone width If the radius of the mounted magnetizing element is large, decrease the value of this parameter. If it is small, increase the value of this parameter.	1 to 10000	Standard magnetizing element: 768 Small magnetizing element: 440

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting																																																																																																					
3325	SP125	MGD2	Magnetic sensor switching point	This parameter is used for adjustment of orientation operation of the magnetic sensor. Set the distance dimension from the target stop point at switching from position feedback to magnetic sensor output. Normally, set a value that is approx. 1/2 of the value defined in SP124.	1 to 10000	Standard magnetizing element: 384 Small magnetizing element: 220																																																																																																				
3326 to 3328	SP126 to SP128			Use not possible.	0	0																																																																																																				
3329 (PR)	SP129	SPECC	C-axis specifications	<p>Set the C-axis specifications in bit units.</p> <table border="1" style="width:100%; border-collapse: collapse;"> <tr> <td align="center">F</td><td align="center">E</td><td align="center">D</td><td align="center">C</td><td align="center">B</td><td align="center">A</td><td align="center">9</td><td align="center">8</td> </tr> <tr> <td align="center">zrtn</td><td align="center">ptyp</td><td align="center">fb9x</td><td align="center">zrtd</td><td align="center">zm2</td><td></td><td align="center">zdir</td><td align="center">ztyp</td> </tr> <tr> <td align="center">7</td><td align="center">6</td><td align="center">5</td><td align="center">4</td><td align="center">3</td><td align="center">2</td><td align="center">1</td><td align="center">0</td> </tr> <tr> <td align="center">vg8x</td><td></td><td align="center">fdir</td><td></td><td align="center">phos</td><td align="center">rtrn</td><td align="center">adin</td><td align="center">fclx</td> </tr> </table> <p>(Note) Always set "0" for the empty bits.</p> <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>bit</th><th>Name</th><th>Meaning when set to 0</th><th>Meaning when set to 1</th></tr> </thead> <tbody> <tr> <td align="center">0</td><td>fclx</td><td>Closed loop</td><td>Semi-closed loop (Gear 1 : 1 only)</td></tr> <tr> <td align="center">1</td><td>adin</td><td>Interpolation A/D compensation invalid</td><td>Interpolation A/D compensation valid</td></tr> <tr> <td align="center">2</td><td>rtrn</td><td>Position monitor during ready OFF invalid</td><td>Position monitor during ready OFF valid</td></tr> <tr> <td align="center">3</td><td>phos</td><td>Normal (no compensation)</td><td>Vx4 synchronization compensation valid</td></tr> <tr> <td align="center">4</td><td></td><td></td><td></td></tr> <tr> <td align="center">5</td><td>fdir</td><td>Position detector polarity (+)</td><td>Position detector polarity (-)</td></tr> <tr> <td align="center">6</td><td></td><td></td><td></td></tr> <tr> <td align="center">7</td><td>vg8x</td><td>Speed gain × 1/8 during torque limit valid</td><td>Speed gain × 1/8 during torque limit invalid</td></tr> <tr> <td align="center">8</td><td>ztyp</td><td>Z-phase type: Normal start up</td><td>Z-phase type: Start up only</td></tr> <tr> <td align="center">9</td><td>zdir</td><td>Z-phase rising polarity (+)</td><td>Z-phase rising polarity (-)</td></tr> <tr> <td align="center">A</td><td></td><td></td><td></td></tr> <tr> <td align="center">B</td><td>zm2</td><td colspan="2">This is used by Mitsubishi.</td></tr> <tr> <td align="center">C</td><td>zrtd</td><td colspan="2">Set to "0" unless particularly designated.</td></tr> <tr> <td align="center">D</td><td>fb9x</td><td>Speed feedback Standard (PLG)</td><td>Speed feedback 90,000 pulse detector</td></tr> <tr> <td align="center">E</td><td>ptyp</td><td>Position control switch type: After zero point return</td><td>Position control switch type: After deceleration stop</td></tr> <tr> <td align="center">F</td><td>zrtn</td><td>Zero point return direction: CCW</td><td>Zero point return direction: CW</td></tr> </tbody> </table>	F	E	D	C	B	A	9	8	zrtn	ptyp	fb9x	zrtd	zm2		zdir	ztyp	7	6	5	4	3	2	1	0	vg8x		fdir		phos	rtrn	adin	fclx	bit	Name	Meaning when set to 0	Meaning when set to 1	0	fclx	Closed loop	Semi-closed loop (Gear 1 : 1 only)	1	adin	Interpolation A/D compensation invalid	Interpolation A/D compensation valid	2	rtrn	Position monitor during ready OFF invalid	Position monitor during ready OFF valid	3	phos	Normal (no compensation)	Vx4 synchronization compensation valid	4				5	fdir	Position detector polarity (+)	Position detector polarity (-)	6				7	vg8x	Speed gain × 1/8 during torque limit valid	Speed gain × 1/8 during torque limit invalid	8	ztyp	Z-phase type: Normal start up	Z-phase type: Start up only	9	zdir	Z-phase rising polarity (+)	Z-phase rising polarity (-)	A				B	zm2	This is used by Mitsubishi.		C	zrtd	Set to "0" unless particularly designated.		D	fb9x	Speed feedback Standard (PLG)	Speed feedback 90,000 pulse detector	E	ptyp	Position control switch type: After zero point return	Position control switch type: After deceleration stop	F	zrtn	Zero point return direction: CCW	Zero point return direction: CW		0000
F	E	D	C	B	A	9	8																																																																																																			
zrtn	ptyp	fb9x	zrtd	zm2		zdir	ztyp																																																																																																			
7	6	5	4	3	2	1	0																																																																																																			
vg8x		fdir		phos	rtrn	adin	fclx																																																																																																			
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																							
0	fclx	Closed loop	Semi-closed loop (Gear 1 : 1 only)																																																																																																							
1	adin	Interpolation A/D compensation invalid	Interpolation A/D compensation valid																																																																																																							
2	rtrn	Position monitor during ready OFF invalid	Position monitor during ready OFF valid																																																																																																							
3	phos	Normal (no compensation)	Vx4 synchronization compensation valid																																																																																																							
4																																																																																																										
5	fdir	Position detector polarity (+)	Position detector polarity (-)																																																																																																							
6																																																																																																										
7	vg8x	Speed gain × 1/8 during torque limit valid	Speed gain × 1/8 during torque limit invalid																																																																																																							
8	ztyp	Z-phase type: Normal start up	Z-phase type: Start up only																																																																																																							
9	zdir	Z-phase rising polarity (+)	Z-phase rising polarity (-)																																																																																																							
A																																																																																																										
B	zm2	This is used by Mitsubishi.																																																																																																								
C	zrtd	Set to "0" unless particularly designated.																																																																																																								
D	fb9x	Speed feedback Standard (PLG)	Speed feedback 90,000 pulse detector																																																																																																							
E	ptyp	Position control switch type: After zero point return	Position control switch type: After deceleration stop																																																																																																							
F	zrtn	Zero point return direction: CCW	Zero point return direction: CW																																																																																																							
3330	SP130	PGC1	First position loop gain for cutting on C-axis	Set the position loop gain when the first gain is selected for C axis cutting.	1 to 100 (1/s)	15																																																																																																				
3331	SP131	PGC2	Second position loop gain for cutting on C-axis	Set the position loop gain when the second gain is selected for C axis cutting.	1 to 100 (1/s)	15																																																																																																				

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting	
3332	SP132	PGC3	Third position loop gain for cutting on C-axis	Set the position loop gain when the third gain is selected for C-axis cutting.	1 to 100 (1/s)	15
3333	SP133	PGC4	Stop position loop gain for cutting on C-axis	Set the position loop gain for stopping when carrying out C-axis cutting.	1 to 100 (1/s)	15
3334 (PR)	SP134	VGCP0	C-axis non-cutting speed loop gain proportional item	Set the speed loop proportional gain in C-axis non-cutting mode.	0 to 5000 (1/s)	63
3335 (PR)	SP135	VGCI0	C-axis non-cutting speed loop gain integral item	Set the speed loop integral gain in C-axis non-cutting mode.	0 to 5000 (0.1 1/s)	60
3336 (PR)	SP136	VGCD0	C-axis non-cutting speed loop gain delay advance item	Set the speed loop delay advance gain in C-axis non-cutting mode. When this parameter is set to "0", PI control is exercised.	0 to 5000 (0.1 1/s)	15
3337 (PR)	SP137	VGCP1	First speed loop gain proportional item for C-axis cutting	Set the speed loop proportional gain when the first gain is selected for C-axis cutting.	0 to 5000 (1/s)	63
3338 (PR)	SP138	VGCI1	First speed loop gain integral item for cutting on C-axis	Set the speed loop integral gain when the first gain is selected for C-axis cutting.	0 to 5000 (0.1 1/s)	60
3339 (PR)	SP139	VGCD1	First speed loop gain delay advance item for cutting on C-axis	Set the speed loop delay advance gain when the first gain is selected for curing on the C-axis. When this parameter is set to "0", PI control is applied.	0 to 5000 (0.1 1/s)	15
3340 (PR)	SP140	VGCP2	Second speed loop gain proportional item for cutting on C-axis	Set the speed loop proportional gain when the second gain is selected for C-axis cutting.	0 to 5000 (1/s)	63

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting	
3341 (PR)	SP141	VGCI2	Second speed loop gain integral item for cutting on C-axis	Set the speed loop integral gain when the second gain is selected for C-axis cutting.	0 to 5000 (0.1 1/s)	60
3342 (PR)	SP142	VGCD2	Second speed loop gain delay advance item for cutting on C-axis	Set the speed loop delay advance gain when the second gain is selected for C-axis cutting. When this parameter is set to "0", PI control is applied.	0 to 5000 (0.1 1/s)	15
3343 (PR)	SP143	VGCP3	Third speed loop gain proportional item for cutting on C-axis	Set the speed loop proportional gain when the third gain is selected for C-axis cutting.	0 to 5000 (1/s)	63
3344 (PR)	SP144	VGCI3	Third speed loop gain integral item for cutting on C-axis	Set the speed loop integral gain when the third gain is selected for C-axis cutting.	0 to 5000 (0.1 1/s)	60
3345 (PR)	SP145	VGCD3	Third speed loop gain delay advance item for cutting on C-axis	Set the speed loop delay advance gain when the third gain is selected for C-axis cutting. When this parameter is set to "0", PI control is applied.	0 to 5000 (0.1 1/s)	15
3346 (PR)	SP146	VGCP4	Speed loop gain proportional item for stop of cutting on C-axis	Set the speed loop proportional gain when C-axis cutting is stopped.	0 to 5000 (1/s)	63
3347 (PR)	SP147	VGCI4	Speed loop gain integral item for stop of cutting on C-axis	Set the speed loop integral gain when C-axis cutting is stopped.	0 to 5000 (0.1 1/s)	60
3348 (PR)	SP148	VGCD4	Speed loop gain delay advance item for stop of cutting on C-axis	Set the speed loop delay advance gain when C-axis cutting is stopped. When this parameter is set to "0", PI control is applied.	0 to 5000 (0.1 1/s)	15

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting	
3349	SP149	CZRN	C-axis zero point return speed	This parameter is valid when SP129 (SPECC) bitE is set to "0". Set the zero point return speed used when the speed loop changes to the position loop.	1 to 500 (r/min)	50
3350	SP150	CPDT	C-axis zero point return deceleration point	This parameter is valid when SP129 (SPECC) bitE is set to "0". Set the deceleration rate where the machine starts to decelerate when it returns to the target stop point during C-axis zero point return. When the machine tends to overshoot at the stop point, set the smaller value.	1 to 10000	1
3351	SP151	CPSTL	C-axis zero point return shift amount (low byte)	This parameter is valid when SPECC (SP129) bitE is set to "0". Set the C-axis zero point position.	HEX setting 00000000 to FFFFFFFF (1/1000°)	H: 0000 L: 0000
3352	SP152	CPSTH	C-axis zero point return shift amount (high byte)			
3353	SP153	CINP	C-axis control in-position width	Set the position error range for outputting the in-position signal during C-axis control.	HEX setting 0000 to FFFF (1/1000°)	03E8
3354 (PR)	SP154	CODRL	Excessive error width on C-axis (low byte)	Set the excessive error width on the C-axis.	HEX setting 00000000 to FFFFFFFF (1/1000°)	H: 0001 L: D4C0
3355 (PR)	SP155	CODRH	Excessive error width on C-axis (high byte)			
3356	SP156	OVSH	C-axis overshoot compensation	Set this to prevent overshooting when shifting from movement to stopping with C-axis control. (Set this referring to the load meter display when overshooting occurred.)	0 to 1000 (0.1%)	0
3357 to 3358	SP157 to SP158			Not used. Set to "0".	0	0
3359	SP159	CPY0	C-axis non-cutting variable excitation ratio	Set the minimum value of variable excitation ratio for non-cutting on the C-axis .	0 to 100 (%)	50
3360	SP160	CPY1	C-axis cutting variable excitation ratio	Set the minimum variable excitation ratio for cutting on the C-axis.	0 to 100 (%)	100


8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting
3361 (PR)	SP161	IQGC0	Current loop gain magnification 1 for non-cutting on C-axis	Set the magnification of current loop gain (torque component) for C-axis non-cutting.	1 to 1000 (%) 100
3362 (PR)	SP162	IDGC0	Current loop gain magnification 2 for non-cutting on C-axis	Set the magnification of current loop gain (excitation component) for C-axis non-cutting.	1 to 1000 (%) 100
3363 (PR)	SP163	IQGC1	Current loop gain magnification 1 for cutting on C-axis	Set the magnification of current loop gain (torque component) for C-axis cutting.	1 to 1000 (%) 100
3364 (PR)	SP164	IDGC1	Current loop gain magnification 2 for cutting on C-axis	Set the magnification of current loop gain (excitation component) for C-axis cutting.	1 to 1000 (%) 100
3365	SP165	PG2C	C-axis position loop gain 2	Set the second position loop gain when high-gain control is carried out for control of the C-axis. This parameter is applied to all the operation modes of C-axis control. When this function is not used, assign "0".	0 to 999 (1/s) 0
3366	SP166	PG3C	C-axis position loop gain 3	Set the third position loop gain when high-gain control is carried out for control of the C-axis. This parameter is applied to all the operation modes of C-axis control. When this function is not used, assign "0".	0 to 999 (1/s) 0
3367 (PR)	SP167	PGU	Position loop gain for increased spindle holding force	Set the position loop gain for when the disturbance observer is valid.	0 to 100 (1/s) 15
3368 (PR)	SP168	VGUP	Speed loop gain proportional item for increased spindle holding force	Set the speed loop gain proportional item for when the disturbance observer is valid.	0 to 5000 (1/s) 63
3369 (PR)	SP169	VGUI	Speed loop gain integral item for increased spindle holding force	Set the speed loop gain integral item for when the disturbance observer is valid.	0 to 5000 (0.1 1/s) 60

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting																																																																																																					
3370 (PR)	SP170	VGUD	Speed loop gain delay advance item for increased spindle holding force	Set the speed loop gain delay advance item for when the disturbance observer is valid.	0 to 5000 (0.1 1/s)	15																																																																																																				
3371 to 3376	SP171 to SP176			Not used. Set to "0".	0	0																																																																																																				
3377 (PR)	SP177	SPECS	Spindle synchronous specifications	Set the spindle synchronous specifications in bit units. <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td align="center">F</td><td align="center">E</td><td align="center">D</td><td align="center">C</td><td align="center">B</td><td align="center">A</td><td align="center">9</td><td align="center">8</td> </tr> <tr> <td></td><td></td><td align="center">Odx8</td><td></td><td></td><td></td><td></td><td align="center">phos</td> </tr> <tr> <td align="center">7</td><td align="center">6</td><td align="center">5</td><td align="center">4</td><td align="center">3</td><td align="center">2</td><td align="center">1</td><td align="center">0</td> </tr> <tr> <td></td><td></td><td align="center">fdir</td><td></td><td align="center">pyfx</td><td align="center">rtrn</td><td align="center">adin</td><td align="center">fclx</td> </tr> </table> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 5px;"> <thead> <tr> <th>bit</th><th>Name</th><th>Meaning when set to 0</th><th>Meaning when set to 1</th></tr> </thead> <tbody> <tr> <td align="center">0</td><td>fclx</td><td>Closed loop</td><td>Semi-closed loop</td></tr> <tr> <td align="center">1</td><td>adin</td><td>Interpolation A/D compensation invalid</td><td>Interpolation A/D compensation valid</td></tr> <tr> <td align="center">2</td><td>rtrn</td><td>Position monitor during ready OFF invalid</td><td>Position monitor during ready OFF valid</td></tr> <tr> <td align="center">3</td><td>pyfx</td><td>Normal excitation</td><td>Position loop excitation fixed (strong)</td></tr> <tr> <td align="center">4</td><td></td><td></td><td></td></tr> <tr> <td align="center">5</td><td>fdir</td><td>Position detector direction (positive direction)</td><td>Position detector direction (negative direction)</td></tr> <tr> <td align="center">6</td><td></td><td></td><td></td></tr> <tr> <td align="center">7</td><td></td><td></td><td></td></tr> <tr> <td align="center">8</td><td></td><td></td><td></td></tr> <tr> <td align="center">9</td><td></td><td></td><td></td></tr> <tr> <td align="center">A</td><td></td><td></td><td></td></tr> <tr> <td align="center">B</td><td></td><td></td><td></td></tr> <tr> <td align="center">C</td><td></td><td></td><td></td></tr> <tr> <td align="center">D</td><td>odx8</td><td>Magnification of excessive error width x 8 times invalid</td><td>Magnification of excessive error width x 8 times valid</td></tr> <tr> <td align="center">E</td><td></td><td></td><td></td></tr> <tr> <td align="center">F</td><td></td><td colspan="2">(Used with SPJ)</td></tr> </tbody> </table>	F	E	D	C	B	A	9	8			Odx8					phos	7	6	5	4	3	2	1	0			fdir		pyfx	rtrn	adin	fclx	bit	Name	Meaning when set to 0	Meaning when set to 1	0	fclx	Closed loop	Semi-closed loop	1	adin	Interpolation A/D compensation invalid	Interpolation A/D compensation valid	2	rtrn	Position monitor during ready OFF invalid	Position monitor during ready OFF valid	3	pyfx	Normal excitation	Position loop excitation fixed (strong)	4				5	fdir	Position detector direction (positive direction)	Position detector direction (negative direction)	6				7				8				9				A				B				C				D	odx8	Magnification of excessive error width x 8 times invalid	Magnification of excessive error width x 8 times valid	E				F		(Used with SPJ)		0000 to FFFF HEX setting	0000
F	E	D	C	B	A	9	8																																																																																																			
		Odx8					phos																																																																																																			
7	6	5	4	3	2	1	0																																																																																																			
		fdir		pyfx	rtrn	adin	fclx																																																																																																			
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																							
0	fclx	Closed loop	Semi-closed loop																																																																																																							
1	adin	Interpolation A/D compensation invalid	Interpolation A/D compensation valid																																																																																																							
2	rtrn	Position monitor during ready OFF invalid	Position monitor during ready OFF valid																																																																																																							
3	pyfx	Normal excitation	Position loop excitation fixed (strong)																																																																																																							
4																																																																																																										
5	fdir	Position detector direction (positive direction)	Position detector direction (negative direction)																																																																																																							
6																																																																																																										
7																																																																																																										
8																																																																																																										
9																																																																																																										
A																																																																																																										
B																																																																																																										
C																																																																																																										
D	odx8	Magnification of excessive error width x 8 times invalid	Magnification of excessive error width x 8 times valid																																																																																																							
E																																																																																																										
F		(Used with SPJ)																																																																																																								
3378 (PR)	SP178	VGSP	Spindle synchronous speed loop gain proportional term	Set the speed loop proportional gain in spindle synchronous mode.	0 to 1000 (1/s)	63																																																																																																				
3379 (PR)	SP179	VGSI	Spindle synchronous speed loop gain integral term	Set the speed loop integral gain in spindle synchronous mode.	0 to 1000 (0.1 1/s)	60																																																																																																				


8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting	
3380 (PR)	SP180	VGSD	Spindle synchronous speed loop gain delay advance term	Set the speed loop delay advance gain in spindle synchronous mode. When this parameter is set to "0", PI control is applied.	0 to 1000 (0.1 1/s)	15
3381 (PR)	SP181	VCGS	Spindle synchronous Target value of variable speed loop proportional gain	Set the magnification of speed loop proportional gain with respect to SP178 (VGSP) at the maximum speed defined in SP017 (TSP) in spindle synchronous mode.	0 to 100 (%)	100
3382 (PR)	SP182	VCSS	Spindle synchronous Change starting speed of variable speed loop proportional gain	Set the speed when the speed loop proportional gain change starts in the spindle synchronous mode. 	0 to 32767 (r/min)	0
3383	SP183	SYNV	Spindle synchronous Sync matching speed	For changeover from the speed loop to the position loop in the spindle synchronous mode, set a speed command error range for output of the synchronous speed matching signal.	0 to 1000 (r/min)	20
3384 (PR)	SP184			Not used. This parameter is used only with the SPJ2.	0	0
3385	SP185	SINP	Spindle synchronous In-position width	Set the position error range for output of the in-position signal in the spindle synchronous mode.	1 to 2880 (1/16°)	16
3386 (PR)	SP186	SODR	Spindle synchronous Excessive error width	Set the excessive error width in the spindle synchronous mode.	1 to 32767 (pulse) (1 pulse =0.088°)	32767
3387 (PR)	SP187	IQGS	Spindle synchronous Current loop gain magnification1	Set the magnification of current loop gain (torque component) in the spindle synchronous mode.	1 to 1000 (%)	100

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting																																																																																																					
3388 (PR)	SP188	IDGS	Spindle synchronous Current loop gain magnification 2	Set the magnification of current loop gain (excitation component) in the spindle synchronous mode.	1 to 1000 (%)	100																																																																																																				
3389	SP189	PG2S	Spindle synchronous Position loop gain 2	Set the second position loop gain when high-gain control is carried out in the spindle synchronous mode. When this parameter function is not used, set to "0".	0 to 999 (1/s)	0																																																																																																				
3390	SP190	PG3S	Spindle synchronous Position loop gain 3	Set the third position loop gain when high-gain control is carried out in the spindle synchronous mode. When this parameter function is not used, set to "0".	0 to 999 (1/s)	0																																																																																																				
3391	SP191			Use not possible.	0	0																																																																																																				
3392	SP192			Not used. Set to "0".																																																																																																						
3393 (PR)	SP193	SPECT	Synchronized tapping specifications	Set the synchronized tapping specifications in bit units. <table border="1" style="margin: 5px 0;"> <tr> <td style="text-align: center;">F</td><td style="text-align: center;">E</td><td style="text-align: center;">D</td><td style="text-align: center;">C</td><td style="text-align: center;">B</td><td style="text-align: center;">A</td><td style="text-align: center;">9</td><td style="text-align: center;">8</td> </tr> <tr> <td style="text-align: center;">zrtn</td><td style="text-align: center;">ptyp</td><td style="text-align: center;">od8x</td><td></td><td></td><td></td><td></td><td style="text-align: center;">phos</td> </tr> </table> <table border="1" style="margin: 5px 0;"> <tr> <td style="text-align: center;">7</td><td style="text-align: center;">6</td><td style="text-align: center;">5</td><td style="text-align: center;">4</td><td style="text-align: center;">3</td><td style="text-align: center;">2</td><td style="text-align: center;">1</td><td style="text-align: center;">0</td> </tr> <tr> <td></td><td></td><td style="text-align: center;">fdir</td><td style="text-align: center;">cdir</td><td style="text-align: center;">pyfx</td><td></td><td style="text-align: center;">adin</td><td style="text-align: center;">fclx</td> </tr> </table> <table border="1" style="margin: 5px 0;"> <thead> <tr> <th>bit</th><th>Name</th><th>Meaning when set to 0</th><th>Meaning when set to 1</th></tr> </thead> <tbody> <tr> <td>0</td><td>fclx</td><td>Closed loop</td><td>Semi-closed loop (Gear 1 : 1 only)</td></tr> <tr> <td>1</td><td>adin</td><td>Interpolation A/D compensation invalid</td><td>Interpolation A/D compensation valid</td></tr> <tr> <td>2</td><td>rtrn</td><td>Position monitor during ready OFF invalid</td><td>Position monitor during ready OFF valid</td></tr> <tr> <td>3</td><td>pyfx</td><td>Normal excitation</td><td>Position loop excitation fixed (strong)</td></tr> <tr> <td>4</td><td>cdir</td><td>Command polarity (+)</td><td>Command polarity (-)</td></tr> <tr> <td>5</td><td>fdir</td><td>Position detector polarity (+)</td><td>Position detector polarity (-)</td></tr> <tr> <td>6</td><td></td><td></td><td></td></tr> <tr> <td>7</td><td></td><td></td><td></td></tr> <tr> <td>8</td><td>phos</td><td>Normal (no compensation)</td><td>Synchronized tapping position compensation valid</td></tr> <tr> <td>9</td><td></td><td></td><td></td></tr> <tr> <td>A</td><td></td><td></td><td></td></tr> <tr> <td>B</td><td></td><td></td><td></td></tr> <tr> <td>C</td><td></td><td></td><td></td></tr> <tr> <td>D</td><td>od8x</td><td>Magnification of excessive error width x 8 times invalid</td><td>Magnification of excessive error width x 8 times valid</td></tr> <tr> <td>E</td><td>ptyp</td><td>Position control switch type: After zero point return</td><td>Position control switch type: After deceleration stop</td></tr> <tr> <td>F</td><td>zrtn</td><td>Zero point return direction: CCW</td><td>Zero point return direction: CW</td></tr> </tbody> </table>	F	E	D	C	B	A	9	8	zrtn	ptyp	od8x					phos	7	6	5	4	3	2	1	0			fdir	cdir	pyfx		adin	fclx	bit	Name	Meaning when set to 0	Meaning when set to 1	0	fclx	Closed loop	Semi-closed loop (Gear 1 : 1 only)	1	adin	Interpolation A/D compensation invalid	Interpolation A/D compensation valid	2	rtrn	Position monitor during ready OFF invalid	Position monitor during ready OFF valid	3	pyfx	Normal excitation	Position loop excitation fixed (strong)	4	cdir	Command polarity (+)	Command polarity (-)	5	fdir	Position detector polarity (+)	Position detector polarity (-)	6				7				8	phos	Normal (no compensation)	Synchronized tapping position compensation valid	9				A				B				C				D	od8x	Magnification of excessive error width x 8 times invalid	Magnification of excessive error width x 8 times valid	E	ptyp	Position control switch type: After zero point return	Position control switch type: After deceleration stop	F	zrtn	Zero point return direction: CCW	Zero point return direction: CW	0000 to FFFF HEX setting	0000
F	E	D	C	B	A	9	8																																																																																																			
zrtn	ptyp	od8x					phos																																																																																																			
7	6	5	4	3	2	1	0																																																																																																			
		fdir	cdir	pyfx		adin	fclx																																																																																																			
bit	Name	Meaning when set to 0	Meaning when set to 1																																																																																																							
0	fclx	Closed loop	Semi-closed loop (Gear 1 : 1 only)																																																																																																							
1	adin	Interpolation A/D compensation invalid	Interpolation A/D compensation valid																																																																																																							
2	rtrn	Position monitor during ready OFF invalid	Position monitor during ready OFF valid																																																																																																							
3	pyfx	Normal excitation	Position loop excitation fixed (strong)																																																																																																							
4	cdir	Command polarity (+)	Command polarity (-)																																																																																																							
5	fdir	Position detector polarity (+)	Position detector polarity (-)																																																																																																							
6																																																																																																										
7																																																																																																										
8	phos	Normal (no compensation)	Synchronized tapping position compensation valid																																																																																																							
9																																																																																																										
A																																																																																																										
B																																																																																																										
C																																																																																																										
D	od8x	Magnification of excessive error width x 8 times invalid	Magnification of excessive error width x 8 times valid																																																																																																							
E	ptyp	Position control switch type: After zero point return	Position control switch type: After deceleration stop																																																																																																							
F	zrtn	Zero point return direction: CCW	Zero point return direction: CW																																																																																																							

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting	
3394 (PR)	SP194	VGTP	Synchronized tapping speed loop gain proportional term	Set the speed loop proportional gain in synchronized tapping mode.	0 to 1000 (1/s)	63
3395 (PR)	SP195	VGTI	Synchronized tapping speed loop gain integral term	Set the speed loop integral gain in synchronized tapping mode.	0 to 1000 (0.1 1/s)	60
3396 (PR)	SP196	VGTD	Synchronized tapping speed loop gain delay advance term	Set the speed loop delay advance gain in synchronized tapping mode. When this parameter is set to "0", PI control is applied.	0 to 1000 (0.1 1/s)	15
3397	SP197			This is used by Mitsubishi. Set to "0" unless particularly designated.	0	0
3398 (PR)	SP198	VCGT	Synchronized tapping target value of variable speed loop proportional gain	Set the magnification of speed loop proportional gain with respect to SP194 (VGTP) at the maximum motor speed defined in SP017 (TSP) in synchronized tapping mode.	0 to 100 (%)	100
3399 (PR)	SP199	VCST	Synchronized tapping change starting speed of variable speed loop proportional gain	Set the speed where the speed loop proportional gain change starts during synchronized tapping. 	0 to 32767 (r/min)	0
3400 (PR)	SP200	FFC1	Synchronized tapping acceleration feed forward gain (gear 1)	Set the acceleration feed forward gain for selection of gear 000 during synchronized tapping. This parameter should be used when an error of relative position to Z-axis servo is large.	0 to 1000 (%)	0
3401 (PR)	SP201	FFC2	Synchronized tapping acceleration feed forward gain (gear 2)	Set the acceleration feed forward gain for selection of gear 001 during synchronized tapping.	0 to 1000 (%)	0
3402 (PR)	SP202	FFC3	Synchronized tapping acceleration feed forward gain (gear 3)	Set the acceleration feed forward gain for selection of gear 010 during synchronized tapping.	0 to 1000 (%)	0

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting
3403 (PR)	SP203	FFC4	Synchronized tapping acceleration feed forward gain (gear 4)	Set the acceleration feed forward gain for selection of gear 011 during synchronized tapping.	0 to 1000 (%) 0
3404 to 3413	SP204 to SP213			Not used. Set to "0".	0 0
3414	SP214	TZRN	Synchronized tapping zero point return speed	This parameter is valid when SP193 (SPECT) bitE is set to "0". Set the zero point return speed used when the speed loop changes to the position loop.	0 to 500 (r/min) 50
3415	SP215	TPDT	Synchronized tapping zero point return deceleration rate	This parameter is valid when SP193 (SPECT) bitE is set to "0". Set the deceleration rate where the machine starts to decelerate when it returns to the target stop point during synchronized tapping zero point return. When the machine tends to overshoot at the stop point set a smaller value.	0 to 10000 (pulse) 1
3416	SP216	TPST	Synchronized tapping zero point return shift amount	This parameter is valid when SP193 (SPECT) bitE is set to "0". Set the synchronized tapping zero point position.	0 to 4095 0
3417	SP217	TINP	Synchronized tapping in-position width	Set the position error range for output of the in-position during synchronized tapping.	1 to 2880 (1/16°) 16
3418 (PR)	SP218	TODR	Synchronized tapping excessive error width	Set the excessive error width during synchronized tapping.	1 to 32767 (pulse) (1 pulse =0.088°) 32767
3419 (PR)	SP219	IQGT	Synchronized tapping current loop gain magnification 1	Set the magnification of current loop gain (torque component) during synchronized tapping.	1 to 1000 (%) 100
3420 (PR)	SP220	IDGT	Synchronized tapping current loop gain magnification 2	Set the magnification of current loop gain (excitation component) during synchronized tapping.	1 to 1000 (%) 100

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting	
3421	SP221	PG2T	Synchronized tapping position loop gain 2	Set the second position loop gain when high-gain control is applied during synchronized tapping. When this parameter is not used, set to "0".	0 to 999 (1/s)	0
3422	SP222	PG3T	Synchronized tapping position loop gain 3	Set the third position loop gain when high-gain control is applied during synchronized tapping. When this parameter is not used, set to "0".	0 to 999 (1/s)	0
3423	SP223	SPDV	Speed monitor speed	Set the spindle limit speed in the door open state. (Invalid when 0 is set.) If the spindle end speed exceeds this setting value when the door is open, the speed monitor error (5E) will occur.	0 to 800 (r/min)	0
3424	SP224	SPDF	Speed monitor time	Set the time (continuous) to detect alarms. (Detected instantly when 0 is set.)	0 to 2813 (3.5ms)	0
3425	SP225	OXKPH	Position loop gain magnification after orientation gain changeover (H coil)	If gain changeover is valid (SP097: SPEC0-bitC=1) during orientation, set the magnification of each gain changed to after in-position.	0 to 2560 (1/256-fold)	0
3426	SP226	OXKPL	Position loop gain magnification after orientation gain changeover (L coil)		0 to 2560 (1/256-fold)	0
3427	SP227	OXVKP	Speed loop proportional gain magnification after orientation gain changeover		0 to 2560 (1/256-fold)	0
3428	SP228	OXVKI	Speed loop cumulative gain magnification after orientation gain changeover	If gain changeover is valid (SP097: SPEC0-bitC=1) during orientation, set the magnification of each gain changed to after in-position.	0 to 2560 (1/256-fold)	0
3429	SP229	OXSFT	Orientation virtual target shift amount	Set the amount to shift the target position when orientation virtual target position is valid (SP097: SPEC0-bitD=1).	0 to 2048 (360°/4096)	0
3430 to 3432	SP230 to SP232			Use not possible.		

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items		Details	Setting range	Standard setting	
3433 (PR)	SP233	JL	Disturbance observer general inertia scale	Set the ratio of the motor inertia + load inertia and motor inertia. Setting value = $\frac{\text{Motor inertia} + \text{load inertia}}{\text{Motor inertia}} \times 100$ (Normally, set "100" or more. When less than "50" is set, the setting will be invalid.)	0 to 5000 (%)	0
3434 (PR)	SP234	OBS1	Disturbance observer low path filter frequency	Set the frequency of the low path filter for when the disturbance observer is valid. Setting (1/s) = $2\pi f$ f: Approx. 1.5 times the disturbance frequency	0 to 1000 (1/s)	0
3435 (PR)	SP235	OBS2	Disturbance observer gain	Set the gain for the disturbance observer.	0 to 500 (%)	0
3436	SP236	OBS3		This is used by Mitsubishi. Set to "0" unless particularly designated.	0	0
3437	SP237			Not used. Set to "0".	0	0
3438 to 3441	SP238 to SP241			Use not possible.	0	0
3442	SP242	Vavx		This is used by Mitsubishi. Set to "0" unless particularly designated.	0	0
3443	SP243	UTTM			0	0
3444	SP244	OPLP			0	0
3445	SP245	PGHS			0	0
3446	SP246	TEST			0	0
3447 to 3448	SP247 to SP248			Use not possible.	0	0
3449	SP249	SMO	Speed meter speed	Set the motor rotation speed when the speed meter 10V is output. When set to "0", this parameter becomes the same as SP017 (TSP).	0 to 32767 (r/min)	0
3450	SP250	LMO	Load meter voltage	Set the voltage when the load meter 120% is output. When set to "0", this becomes 10V.	0 to 10 (V)	0
3451 to 3452	SP251 to SP252			Use not possible.	0	0

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items			Details	Setting range	Standard setting
3453	SP253	DA1NO	D/A output channel 1 data number	Set the output data number for channel 1 of the D/A output function. When set to "0", the output is speedometer. Refer to "8.4 (1) For D/A output functions".	-32768 to 32767	0
3454	SP254	DA2NO	D/A output channel 2 data number	Set the output data number for channel 2 of the D/A output function. When set to "0", the output is load meter. Refer to "8.4 (1) For D/A output functions".	-32768 to 32767	0
3455	SP255	DA1MPY	DA output channel 1 magnification	Set the data magnification for channel 1 of the D/A output function. The output magnification is the setting value divided by 256. When set to "0", the output magnification becomes 1-fold, in the same manner as when "256" is set. Refer to "8.4 (1) For D/A output functions".	-32768 to 32767 (1/256-fold)	0
3456	SP256	DA2MPY	DA output channel 2 magnification	Set the data magnification for channel 2 of the D/A output function. The output magnification is the setting value divided by 256. When set to "0", the output magnification becomes 1-fold, in the same manner as when "256" is set. Refer to "8.4 (1) For D/A output functions".	-32768 to 32767 (1/256-fold)	0

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items			Details	Setting range	Standard setting
3457 (PR) to 3520 (PR)	SP257 to SP320	RPM to BSD	Motor constant (H coil)	<p>This parameter is valid only in the following two conditional cases:</p> <p>(a) In case that SP034 (SFNC2) bit0=1 and SP034 (SFNC2) bit2=0 Set the motor constants when using a special motor, not described in the SP040 (MTYP) explanation and when not using the coil changeover motor.</p> <p>(b) In case that SP034 (SFNC2) bit0=1 and SP034 (SFNC2) bit2=1 Set the motor constant of the H coil of the coil changeover motor.</p> <p>(Note) It is not allowed for the user to change the setting.</p>	0000 to FFFF HEX setting	0000

<Details for Motor constant>

No.	Items			Details	Setting range	Standard setting
3494	SP294	Kt	Torque constant for disturbance observer	<p>Set the torque constant for disturbance observer.</p> $\text{Setting (0.01kg}\cdot\text{m)} = \frac{\text{30-minute rated output} \times 1000}{\text{Base speed} \times 1.026} \times 100$	0000 to FFFF HEX setting	-
3495	SP295	GDM	Motor inertia for disturbance observer	<p>Set the motor inertia for disturbance observer.</p> $\text{Setting (0.001kg}\cdot\text{m}^2) = \text{GD}_M^2 \times 1000$	0000 to FFFF HEX setting	-

8. SPINDLE PARAMETERS
8.3 MDS-B-SP/SPH, MDS-C1-SP/SPH

No.	Items			Details	Setting range	Standard setting
3521 (PR) to 3584 (PR)	SP321 to SP384	RPML BSDL	Motor constant (L coil)	<p>This parameter is valid only in the following conditional case:</p> <p>(a) In case that SP034 (SFNC2) bit0=1 and SP034 (SFNC2) bit2=1 Set the motor constant of the L coil of the coil changeover motor.</p> <p>(Note) It is not allowed for the user to change the setting.</p>	0000 to FFFF HEX setting	0000

<Details for Motor constant>


No.	Items			Details	Setting range	Standard setting
3558	SP358	KtL	Torque constant 2 for disturbance observer	<p>Set the torque constant for disturbance observer.</p> $\text{Setting (0.01kg}\cdot\text{m)} = \frac{\text{30-minute rated output} \times 1000}{\text{Base speed} \times 1.026} \times 100$	0000 to FFFF HEX setting	-
3559	SP359	GDML	Motor inertia 2 for disturbance observer	<p>Set the motor inertia for disturbance observer.</p> $\text{Setting (0.001kg}\cdot\text{m}^2) = \text{GD}_M^2 \times 1000$	0000 to FFFF HEX setting	-

8.4 Supplement

8.4.1 D/A Output Specifications

(1) D/A output specifications

Item	Explanation
No. of channels	2ch
Output cycle	444μs (min. value)
Output precision	8bit
Output voltage range	0V to +5V (zero) to +10V, 0V to +10V during meter output
Output scale setting	±1/256 to ±128 tiems
Output pins	CN9 connector MO1 = 9 pin MO2 = 19 pin GND = 1 pin
Function	Phase current feedback output function U-phase current FB : 7 pin V-phase current FB : 17 pin



8. SPINDLE PARAMETERS
8.4 Supplement

(2) Setting the output data

Input the No. of the data to be output to each D/A output channel.

#	No.	Abbrev	Parameter name
3453	SP253	DA1NO	D/A output channel 1 data No.
3454	SP254	DA2NO	D/A output channel 2 data No.

No.	Output data	Original data unit	Standard setting value for output scale (Setting values in SP255, SP256)	Standard output unit	Output cycle
0	ch1: Speed meter output	10V=max. speed (0=0V)	0	Depends on the max. speed	3.5ms
	ch2: Load meter output	10V=120% load (0=0V)	0	30-minute rating 12%/V	3.5ms
1	–				
2	Current command	Rated 100% = 4096	8	30-minute rating 20%/V	3.5ms
3	Current feedback	Rated 100% = 4096	8	30-minute rating 20%/V	3.5ms
4	Speed feedback	r/min	13	500(r/min)/V	3.5ms
5	–				
6	Position droop (lower order 16bit)	0.001deg=64	10 (10.24)	0.01deg/V	0.8μs
7	Position droop (higher order 16bit)	1deg=(64000÷65536)	671	10deg/V	0.8μs
8	Feedrate (FΔT) (lower order 16bit)	0.001deg=64	173 (at 3.5ms communication)	10deg/min/V	0.8μs
9	Feedrate (FΔT) (higher order 16bit)	1deg=(64000÷65536)	629 (at 3.5ms communication)	500rpm/V	0.8μs
10	Position command (lower order 16bit)	0.001deg=64	10 (10.24)	0.01deg/V	0.8μs
11	Position command (higher order 16bit)	1deg=(64000÷65536)	19 (18.64)	360deg/V	0.8μs
12	Position feedback (lower order 16bit)	0.001deg=64	10 (0.24)	0.01deg/V	0.8μs
13	Position feedback (higher order 16bit)	1deg=(64000÷65536)	19 (18.64)	360deg/V	0.8μs
80	Control input 1	HEX	Bit correspondence		3.5ms
81	Control input 2				
82	Control input 3				
83	Control input 4				
84	Control output 1				
85	Control output 2				
86	Control output 3				
87	Control output 4				

8. SPINDLE PARAMETERS
8.4 Supplement

(3) Setting the output scale

#	No.	Abbrev	Parameter name
3455	SP255	DA1MPY	D/A output channel 1 magnification
3456	SP256	DA2MPY	D/A output channel 2 magnification

Usually, the standard setting value is set for the output scale (SV063, SV 064). Set the output magnification with a 1/256 unit. When "0" is set, the output will be made as well as when "256" is set.

$$\text{DATA} \times \frac{\text{SP255}}{256} \times \frac{10 [\text{V}]}{256 \text{ (8bit)}} + 5 [\text{V}] \text{ (offset)} = \text{Output voltage} [\text{V}]$$

(Example) To output current FB at a 30-minute stall rating 20%/V unit (SP253=3, SP255=8)

$$819.2 \times \frac{8}{256} \times \frac{10}{256} + 5 = 6 [\text{V}]$$

9. MACHINE ERROR COMPENSATION

9.1 Function Outline

Machine error compensation includes two independent functions: memorized pitch error compensation and memorized relative position compensation.

(1) Memorized pitch error compensation

According to the specified parameters, this method compensates an axis feed error caused by a ball screw pitch error, etc.

With the reference point defined as the base, set the compensation amount in the division points obtained by equally dividing the machine coordinates. (See Fig. 1. 1)

The compensation amount can be set by either the absolute or incremental system.

Select the desired method with the #4000:Pinc. Machine position is compensated between division points n and $n+1$ as much as compensation amount between them by linear approximation.




Fig. 1. 1 Relationship between the compensation amount and machine position

9. MACHINE ERROR COMPENSATION
9.1 Function Outline

(2) Memorized relative position compensation

This method, according to the parameters specified in advance, compensates the relative position error between two orthogonal axes caused by deflection of the moving stand.

For this, as shown in Fig. 1. 2, specify the compensation amount in the compensation axis direction in the division points obtained by equally dividing the machine coordinates of the base axis.

The base axis is one of the two orthogonal axes to which relative position compensation applies. This axis is used as the criterion for relative-error measurement. The compensation axis is the coordinate axis that is orthogonal to the base axis. The compensation is actually made for this coordinate axis. The section between division points n and $n+1$ is compensated smoothly by linear approximation.




Fig. 1. 2 Relationship between base and compensation axes

9. MACHINE ERROR COMPENSATION
9.1 Function Outline

(SETUP PARAM 5. 1/15)

#	Item	Details	Setting range
4000 (PR)	Pinc	Machine error offset increment method	Specify whether to use the incremental amount method or absolute amount method when setting the machine error compensation data. 0: Absolute volume method 1: Incremental volume method

<1st axis>

#	Item	Details	Setting range	
4001	cmpax	Basic axis	Specify the basic axis address for machine error compensation. 1) For pitch error compensation, set the name of the axis to be compensated. 2) For relative position compensation, set the name of the axis to be the base axis.	X, Y, Z, U, V, W, A, B, or C axis address
4002	drcax	Compensation axis	Set the compensation axis address for machine error compensation. 1) For pitch error compensation, set the same axis name as #4001 cmpax. 2) For relative position compensation, set the name of the axis to be actually compensated.	X, Y, Z, U, V, W, A, B, or C axis address
4003	rdvno	Division point number at reference point position	Set the compensation data No. corresponding to the reference point position. The reference point is actually the base, so there is no compensation No. Set the number that is decremented by 1.	4101 to 5124
4004	mdvno	Division point number at the most negative side	Set the compensation data No. that is on the farthest negative side.	4101 to 5124
4005	pdvno	Division point number at the most positive side	Set the compensation data No. that is on the farthest positive side.	4101 to 5124
4006	sc	Compensation scale factor	Set the compensation amount's scale.	0 to 99
4007	spcdv	Division interval	Set the interval to divide the basic axis. Each compensation data will be the compensation amount for each of these intervals.	1 to 9999999

9. MACHINE ERROR COMPENSATION
9.1 Function Outline

<2nd axis>	<3rd axis>	<4th axis>	<5th axis>	<6th axis>	<7th axis>	<8th axis>	<9th axis>	<10th axis>	
4011	4021	4031	4041	4051	4061	4071	4081	4091	Set the parameters corresponding to the 1st axis' parameters 4001 to 4007 for each axis. A maximum of 6 axes can be controlled, but as the relative position is compensated, settings for 10 axes can be made.
4012	4022	4032	4042	4052	4062	4072	4082	4092	
4013	4023	4033	4043	4053	4063	4073	4083	4093	
4014	4024	4034	4044	4054	4064	4074	4084	4094	
4015	4025	4035	4045	4055	4065	4075	4085	4095	
4016	4026	4036	4046	4056	4066	4076	4086	4096	
4017	4027	4037	4047	4057	4067	4077	4087	4097	

(SETUP PARAM 5. 3/15) to (SETUP PARAM 5. 15/15)

#	Item	Details	Setting range
4101 • • • 5124		Set the compensation amount for each axis.	-128 to 127 The actual compensation amount will be the value obtained by multiplying the setting value with the compensation scale.

9.2 Setting Compensation Data

Compensation data can be set according to either absolute or incremental system.

"#4000:Pinc" 0: Absolute system
 1: Incremental system

(1) Absolute system

Feed from the reference point to each division point is executed as shown in Fig. 2. 1. The following is obtained at this time. Set it as the compensation amount.

$$(\text{Specified position} - \text{Real machine position}) \times 2 \text{ (Unit of output)}$$

For example, assume that the feed from the reference point to the +100mm position is executed. Also, assume that the real machine position is 99.990mm. In this case, the following value is defined as the compensation amount used at the +100mm position:

$$(100000 - 99990) \times 2 = 20 \text{ pulses}$$

The resultant value is defined as the compensation amount. Assume that the real machine position resulting when feed to the -100mm position is executed, is -99.990mm. In this case, the following value is defined as the compensation amount used at the -100mm position:

$$(-100000 - (-99990)) \times 2 = -20 \text{ pulses}$$




Fig. 2. 1

(2) Incremental system

Fig. 2. 2 contains a machine position that is placed in the positive direction with respect to the reference point. Assume that feed from division n-1 to n (division interval) is executed. In this case, the following value is defined as the compensation amount:

$$(\text{Division interval} - \text{Actual movement distance}) \times 2 \text{ (Unit of output)}$$

9. MACHINE ERROR COMPENSATION
9.2 Setting Compensation Data

- (3) Fig. 2. 3 contains a machine position that is placed in the negative direction with respect to the reference point. Assume that feed from division point n+1 to n by the division interval is executed. In this case, the following value is defined as the compensation amount:

$$(\text{Division interval} + \text{Actual movement distance}) \times 2 \text{ (Unit of output)}$$




Fig. 2. 2




Fig. 2. 3

n: Division point compensation number
 1: Division interval


Unit : Unit of output

Range : -128 to 127

(Note) The unit of output is used as the unit of setting. The actual unit of compensation pulses depends on the compensation scale factor.

9.3 Example in Using a Linear Axis as the Base Axis

(1) When "mdvno" or "pdvno" exists at both ends of "rdvno":




Division point number	#4101	#4102	#4103	#4104	#4105	#4106
Specified machine position	-300.000	-200.000	-100.000	100.000	200.000	300.000
Real machine position	-299.999	-200.000	-100.003	100.002	200.002	299.999
Compensation amount	Incremental	2	6	-6	-4	0
	Absolute	-2	0	6	-4	-4

rdvno	4103
mdvno	4101
pdvno	4106

If the setting range (mdvno to "pdvno") is exceeded, the compensation will be based on compensation amount at mdvno or "pdvno".

9. MACHINE ERROR COMPENSATION
9.3 Example in Using a Linear Axis as the Base Axis

(2) When the range compensated is only the positive range:




Division point number		#4113	#4114	#4115	#4116	#4117
Compensation amount	Incremental	-4	2	0	6	2
	Absolute	-4	-2	-2	4	6

rdvno	4112
mdvno	4113
pdvno	4117

If the machine position exceeds "pdvno", the compensation will be based on the compensation amount at "pdvno". If the machine position is negative in this case, no compensation will be executed.

9. MACHINE ERROR COMPENSATION
9.3 Example in Using a Linear Axis as the Base Axis

(3) When the range compensated is only the negative range:




Division point number		#4125	#4126	#4127	#4128	#4129	#4130
Compensation amount	Incremental	-2	2	6	2	0	-6
	Absolute	-2	-4	-2	4	6	6

rdvno	4130
mdvno	4125
pdvno	4130

If the machine position exceeds "mdvno", the compensation will be based on compensation amount at "mdvno".

9. MACHINE ERROR COMPENSATION
9.3 Example in Using a Linear Axis as the Base Axis

(4) When compensation is executed in a range that contains no reference point:




Division point number		#4135	#4136	#4137	#4138	#4139	#4140
Compensation amount	Incremental			-2	-2	6	2
	Absolute			-2	-4	2	4

rdvno	4134
mdvno	4136
pdvno	4140

In this case, the compensation is executed in the range from "mdvno" to "pdvno". This setting rule applies also when the compensation is executed in a range which contains negative machine positions and no reference point.

9.4 Example in Using a Rotation Axis as the Base Axis



Division point number		#4123	#4124	#4125	#4126	#4127	#4128
Compensation amount	Incremental	-4	2	0	6	2	-6
	Absolute	-4	-2	-2	4	6	0

rdvno	4122
mdvno	4123
pdvno	4128

In this case, the sum of the compensation amounts set according to the incremental system is always "0". For the absolute system, the compensation amount at the terminal point (360 degrees) is always "0".

10. PLC CONSTANTS

10.1 PLC Timer

10. PLC CONSTANTS

10.1 PLC Timer

(SETUP PARAM 6. 1/14) to (SETUP PARAM 6. 2/14)

#	PLC device	Item	Details	Setting range
6000 ⋮ 6015	T000 ⋮ T015	10ms adding timer <10ms>	Set the time for the timer used in the PLC program (ladder). (Note) This setting value is valid when parameter "#6449 bit0" in the following "[BIT SELECT]" is set to "0".	0 to 32767 (×10ms)
6016 ⋮ 6095	T016 ⋮ T095	100ms adding timer <10ms>	Set the time for the timer used in the PLC program (ladder). (Note) This setting value is valid when parameter "#6449 bit0" in the following "[BIT SELECT]" is set to "0".	0 to 32767 (×100ms)
6096 ⋮ 6103	T096 ⋮ T103	100ms cumulative timer <100ms INC>	Set the time for the timer used in the PLC program (ladder). (Note) This setting value is valid when parameter "#6449 bit0" in the following "[BIT SELECT]" is set to "0".	0 to 32767 (×100ms)

(SETUP PARAM 6. 10/14) to (SETUP PARAM 6. 14/14)

#	PLC device	Item	Details	Setting range
6600 ⋮ 6999	R1200/bit0 ⋮ R1224/bitF R1250/bit0 ⋮ R1274/bitF	PLC timer expansion 10ms adding timer <10ms>	Set the time for the expanded PLC timer This is set for the timer coils: R1200 to R1224, and timer contacts: R1250 to R1274. A timer command can be issued to a contact other than the existing timer contacts (T0 to T103, Q0 to Q151).	0 to 32767 (×10ms)

10.2 PLC Counter

(SETUP PARAM 6. 3/14)

#	PLC device	Item	Details	Setting range
6200 ⋮ 6223	C000 ⋮ C023	Counter	Set the time for the counter used in the PLC program (ladder). (Note) This setting value is valid when parameter "#6449 bit1" in the following "[BIT SELECT]" is set to "0".	0 to 32767

10. PLC CONSTANTS

10.3 PLC Constants

10.3 PLC Constants

(SETUP PARAM 6. 4/14)

#	PLC device	Item	Details	Setting range
6301	R2800,2801	PLC constant	Set the value to be set in the data type R register used in the PLC program (ladder). Even if the data is set in the R register that corresponds to the PLC side when this parameter is displayed, the screen will not change. Enter a different screen once, and then select this screen again.	-99999999 to 99999999
6348	R2894,2895			

(SETUP PARAM 6. 5/14)

#	PLC device	Item	Details	Setting range
6349	R4900,4901	PLC constant	Set the value to be set in the data type R register used in the PLC program (ladder). Even if the data is set in the R register that corresponds to the PLC side when this parameter is displayed, the screen will not change. Enter a different screen once, and then select this screen again.	-99999999 to 99999999
6396	R4994,4995			

10.4 Selecting the PLC Bit

(SETUP PARAM 6. 6/14) to (SETUP PARAM 6. 7/14)

#	PLC device	Item	Details	Setting range
6401	R2900-Low	Bit selection	This is the bit type parameter used in the PLC program (ladder). Even if the data is set in the R register that corresponds to the PLC side when this parameter is displayed, the screen will not change. Enter a different screen once, and then select this screen again. Some of the parameters following #6449 may be fixed according to the usage purpose. Refer to the PLC Program Development On-board Instruction Manual.	0: OFF 1: ON
6402	R2900-High			
6495	R2947-Low			
6496	R2947-High			

(SETUP PARAM 6. 7/14) to (SETUP PARAM 6. 9/14)

#	PLC device	Item	Details	Setting range
6497	R4400-Low	Bit selection expansion	This is the bit type parameter (expansion) used in the PLC program (ladder). Even if the data is set in the R register that corresponds to the PLC side when this parameter is displayed, the screen will not change. Enter a different screen once, and then select this screen again.	0: OFF 1: ON
6498	R4400-High			
6595	R4449-Low			
6596	R4449-High			

10. PLC CONSTANTS
10.4 Selecting the PLC Bit

Table: "Contents of bit selection parameters #6449 to #6496"

	Symbol name	7	6	5	4	3	2	1		0
0	#6449 R2924 L	NC card Controller thermal alarm on	Setting display unit thermal alarm on	-		Counter C retention	Integrating timer T retention	PLC counter program on		PLC timer program on
1	#6450 R2924 H		External alarm message display	Alarm/operator change	Full screen display of message	-	Operator message on	1 R system	0 F system	Alarm message on
2	#6451 R2925 L	-	-	GX-Developer communication on	PLC development environment selection		Onboard editing not possible	-		Onboard on
3	#6452 R2925 H	-		GOT communication connection		Counter (fixed) retention	Integrating timer (fixed) retention			-
4	#6453 R2926 L	-	-	-	-	-		Message language change code		
5	#6454 R2926 H							Equivalent of remote I/O 2ch		
6	#6455 R2927 L	-	-	-	-	-	-	-		-
7	#6456 R2927 H	-	-	-	-	-	-	-		-
8	#6457 R2928 L	High-speed input specification 1								
9	#6458 R2928 H	High-speed input specification 2								
A	#6459 R2929 L	High-speed input specification 3 (Spare)								
B	#6460 R2929 H	High-speed input specification 4 (Spare)								
C	#6461 R2930 L	High-speed output specification 1								
D	#6462 R2930 H	High-speed output specification 2								
E	#6463 R2931 L	High-speed output specification 3 (Spare)								
F	#6464 R2931 H	High-speed output specification 4 (Spare)								

10. PLC CONSTANTS
10.4 Selecting the PLC Bit

	Symbol name	7	6	5	4	3	2	1	0
0	#6465 R2932 L	-	-	-	-	-	-	-	-
1	#6466 R2932 H	-	-	-	-	-	-	-	-
2	#6467 R2933 L	-	-	-	-	-	-	-	-
3	#6468 R2933 H								
4	#6469 R2934 L			Standard PLC parameter				-	MC alarm 4 output off
5	#6470 R2934 H								
6	#6471 R2935 L	-	-	-	-	-	-	-	-
7	#6472 R2935 H	-	-	-	-	-	-	-	-
8	#6473 R2936 L	-							-
9	#6474 R2936 H								
A	#6475 R2937 L								
B	#6476 R2937 H								
C	#6477 R2938 L								
D	#6478 R2938 H								
E	#6479 R2939 L								
F	#6480 R2939 H								

(Note 1) Be sure to set the bits indicated - and blanks to 0.

(Note 2) Parameters #6481 to #6496 are reserved for debugging by Mitsubishi.

11. MACRO LIST

11. MACRO LIST

(SETUP PARAM 7. 1/3)

#	Item	Details	Setting range (unit)										
7001 to 7091	M [01] to M [10]	<Code> Set the M code used for calling out the macro with the M command. This is valid when #1195 Mmac is set to 1.	1 to 9999										
7002 to 7092		<Type> Set the macro call out type. <table border="1"> <tr> <td>0</td> <td>M98 PΔΔΔΔ; and equivalent value call</td> </tr> <tr> <td>1</td> <td>G65 PΔΔΔΔ; and equivalent value call</td> </tr> <tr> <td>2</td> <td>G66 PΔΔΔΔ; and equivalent value call</td> </tr> <tr> <td>3</td> <td>G66.1 PΔΔΔΔ; and equivalent value call</td> </tr> <tr> <td>others</td> <td>M98 PΔΔΔΔ; and equivalent value call</td> </tr> </table>	0	M98 PΔΔΔΔ; and equivalent value call	1	G65 PΔΔΔΔ; and equivalent value call	2	G66 PΔΔΔΔ; and equivalent value call	3	G66.1 PΔΔΔΔ; and equivalent value call	others	M98 PΔΔΔΔ; and equivalent value call	0 to 3
0	M98 PΔΔΔΔ; and equivalent value call												
1	G65 PΔΔΔΔ; and equivalent value call												
2	G66 PΔΔΔΔ; and equivalent value call												
3	G66.1 PΔΔΔΔ; and equivalent value call												
others	M98 PΔΔΔΔ; and equivalent value call												
7003 to 7093		<Program No.> Set the No. of the program to be called out.	1 to 99999999										
	M2mac	Set the type and program No. for when calling out the macro with the 2nd miscellaneous command. The macro will be called out with the #1170 M2name address command when #1198 M2mac is set to 1.											
7102		<Type> Same as the M call macro.	0 to 3										
7103		<Program No.> Same as the M call macro.	0 to 99999999										

(SETUP PARAM 7. 2/3)

#	Item	Details	Setting range (unit)
7201 to 7291	G [01] to G [10]	<Code> Set the G code to be used when calling the macro with a G command. Do not set a G code used in the system.	1 to 255
7202 to 7292		<Type> Same as the M call Marco.	0 to 3
7203 to 7293		<Program No.> Same as the M call Marco.	1 to 99999999
	Smac	Set the type and program No. for when calling the macro with an S command. This is valid when #1196 Smac is set to 1.	
7302		<Type> Same as the M call Marco.	0 to 3
7303		<Program No.> Same as the M call Marco.	1 to 99999999
	Tmac	Set the type and program No. for when calling the macro with a T command. This is valid when #1197 Tmac is set to 1.	
7312		<Type> Same as the M call macro.	0 to 3
7313		<Program No.> Same as the M call macro.	0 to 99999999

11. MACRO LIST

(SETUP PARAM 7. 3/3)

#	Item		Details	Setting range
7401	ASCII [01]	Valid	The ASCII code macro parameters (#7402 to 7405) are validated. 0: Invalid 1: Valid	0/1
7402		Code	Set the ASCII code used to call macros with the ASCII code.	L system: A, B, D, F, H, I, J, K, M, Q, R, S, T M system: A, B, F, H, I, K, M, Q, R, S, T
7403		Type	Set the macro call type. 0: M98, 1: G65, 2: G66, 3: G66.1	0 to 3
7404		Program No.	Set the number of the program called with macro call.	0 to 99999999
7405		Variable	When the call type is "0", set the variable number set after the ASCII code.	100 to 149
7411	ASCII [02]	Valid	The ASCII code macro parameters (#7412 to 7415) are validated. 0: Invalid 1: Valid	0/1
7412		Code	Set the ASCII code used to call macros with the ASCII code.	L system: A, B, D, F, H, I, J, K, M, Q, R, S, T M system: A, B, F, H, I, K, M, Q, R, S, T
7413		Type	Set the macro call type. 0: M98, 1: G65, 2: G66, 3: G66.1	0 to 3
7414		Program No.	Set the number of the program called with macro call.	0 to 99999999
7415		Variable	When the call type is "0", set the variable number set after the ASCII code.	100 to 149

12. POSITION SWITCH

12.1 OUTLINE OF FUNCTION

The position switch (PSW) is used as an alternate switch for the dog switch provided on an axis of the machine. The position switch uses parameters by which the names of axes and their corresponding coordinates indicating imaginary dog positions are defined in advance. When the machine reaches the imaginary dog position, a signal is output to the PLC interface. The position switch thus works as an imaginary dog switch.

(SETUP PARAM 8. 1/1)

#	Item	Details	Setting range (unit)
7500	Pcheck	High-speed switching of position switch Specify whether to perform position switch area checking at high speeds. 0: Do not perform position switch area checking at high speed (do it the same as before). 1: Perform position switch area checking at high speed.	0/1
75□1	<axis>	Axis name	Specify the name of the axis for which a position switch is provided.
75□2	<dog1>	Imaginary dog position 1	When the machine enters the range between imaginary dog positions 1 and 2, a signal is output to the PLC. -99999.999 to 99999.999 (0.001mm)
75□3	<dog2>	Imaginary dog position 2	
75□4	<check>	Selection of area check method When position switch area checking at high speed is selected, specify the mode of area checking, i.e., whether to use the command type machine position or detector feedback position, for each position switch point. 0: Use the command type machine position as the machine position for position switch area checking. 1: Use the detector feedback position as the machine position for position switch area checking. Note: This parameter is valid only when 1 set in "#7500 Pcheck."	0/1




12. POSITION SWITCH
12.1 Outline of Function


Position switch numbers of PSW1 to PSW24 and signal devices

	<axis>	<dog1>	<dog2>	<check>	device
PSW1	#7501	#7502	#7503	#7504	X270
PSW2	#7511	#7512	#7513	#7514	X271
PSW3	#7521	#7522	#7523	#7524	X272
:	:	:	:	:	:
PSW8	#7571	#7572	#7573	#7574	X277
PSW9	#7581	#7582	#7583	#7584	X328
PSW10	#7591	#7592	#7593	#7594	X329
:	:	:	:	:	:
PSW24	#7731	#7732	#7733	#7734	X337

Instead of the dog switch provided on the machine axis, the coordinate values indicating imaginary dog positions (dog1 and dog2) on the coordinate axis of the axis name preset with axis are set with the position switches (PSW1 – PSW24). When the machine reaches the position, the signal is output to the device corresponding to the PLC interface.

Example of settings of dog1 and dog2 and operation





Setting of dog1 and dog2	dog1, dog2 position	Operation
dog1 < dog2		A signal is output between dog1 and dog2.
dog1 > dog2		A signal is output between dog1 and dog2.
dog1 = dog2		If dog1 equals dog2, the dog1 position triggers a signal.



12. POSITION SWITCH

12.2 Canceling the Position Switch

Rotation axis

Setting of dog1 and dog2	dog1, dog2 position	Description
dog1 < dog2	 <p style="text-align: right;">(Example) dog1 = 30.000 dog2 = 330.000</p>	A signal is output between dog1 and dog2.
	 <p style="text-align: right;">(Example) dog1 = -30.000 dog2 = 30.000</p>	A signal is also output when dog1 is negative.
dog1 > dog2	 <p style="text-align: right;">(Example) dog1 = 330.000 dog2 = 30.000</p>	A signal is output between dog2 and dog1.
$ dog1 - dog2 \geq 360$	 <p style="text-align: right;">(Example) dog1 = 30.000 dog2 = 390.000</p>	A signal is kept output when the difference between dog1 and dog2 exceeds 360 degrees.

12.2 Canceling the Position Switch

To cancel the position switch, enter the number (#75□1) of the position switch to be canceled in # () of the setting field, enter a slash "/" in DATA (), then press the INPUT key. This deletes the axis name for the specified position switch, thus invalidating the position switch.

The data specified for <dog1> and <dog2> are still stored in memory. To validate the position switch again, therefore, it is enough to specify the axis name only.

13. AUXILIARY AXIS PARAMETER

13. AUXILIARY AXIS PARAMETER

Turn the NC power OFF after setting parameters indicated with a (PR) in the table. The setting will be validated after the power is turned ON again.

No.	Name		Details	Setting range	Default value																						
1 (PR)	MSR	Motor series	Set the motor series. This is automatically judged by the system when the default value (0000) is set.	0000 to FFFF (hexadecimal)	0000																						
2 (PR)	RTY	Regeneration option type	Set the regenerative resistor type. Do not set values without a description. <div style="text-align: center;"> <table border="1" style="display: inline-table; margin: 10px;"> <tr> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;">0</td> <td style="padding: 2px 5px;">0</td> </tr> </table> (Default value) </div> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: center;">Setting value</th> <th style="text-align: center;">Details</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Drive unit standard built-in resistor (10CT has no built-in resistor)</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Setting prohibited</td> </tr> <tr> <td style="text-align: center;">2</td> <td>MR-RB032 (30W)</td> </tr> <tr> <td style="text-align: center;">3</td> <td>MR-RB12 (100W)</td> </tr> <tr> <td style="text-align: center;">4</td> <td>MR-RB32 (300W)</td> </tr> <tr> <td style="text-align: center;">5</td> <td>MR-RB30 (300W)</td> </tr> <tr> <td style="text-align: center;">6</td> <td>MR-RB50 (500W)</td> </tr> <tr> <td style="text-align: center;">7~F</td> <td></td> </tr> </tbody> </table>	0	0	0	0	Setting value	Details	0	Drive unit standard built-in resistor (10CT has no built-in resistor)	1	Setting prohibited	2	MR-RB032 (30W)	3	MR-RB12 (100W)	4	MR-RB32 (300W)	5	MR-RB30 (300W)	6	MR-RB50 (500W)	7~F			
0	0	0	0																								
Setting value	Details																										
0	Drive unit standard built-in resistor (10CT has no built-in resistor)																										
1	Setting prohibited																										
2	MR-RB032 (30W)																										
3	MR-RB12 (100W)																										
4	MR-RB32 (300W)																										
5	MR-RB30 (300W)																										
6	MR-RB50 (500W)																										
7~F																											
3 (PR)	PC1	Motor side gear ratio (machine rotation ratio)	Set the No. of gear teeth on the motor side and the No. of gear teeth on the machine side as an integer reduced to its lowest terms.	1 to 32767	1																						
4 (PR)	PC2	Machine side gear ratio (motor rotation ratio)	Set the total gear ratio if there are multiple gear levels. For rotation axes, set the No. of motor rotation speed per machine rotation.	1 to 32767	1																						
5 (PR)	PIT	Feed pitch	Set 360 (default value) for rotation axes. Set the feed lead for linear axes.	1 to 32767 (° or mm)	360																						
6	INP	In-position detection width	In-position is detected when the position droop becomes this setting value or less.	1 to 32767 (1/1000° or μm)	50																						

13. AUXILIARY AXIS PARAMETER

No.	Name	Details	Setting range	Default value																		
7	ATU	Auto-tuning	Set the adjustment of the auto-tuning. Do not set values without a description.																			
<table border="1" style="margin: auto;"> <tr> <td style="padding: 2px;">0</td> <td style="padding: 2px;">1</td> <td style="padding: 2px;">0</td> <td style="padding: 2px;">2</td> </tr> </table> (Default setting value)					0	1	0	2														
0	1	0	2																			
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">Setting value</th> <th style="width: 85%;">Details</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td>Low response (low-rigidity loads, loads which easily vibrate)</td> </tr> <tr> <td style="text-align: center;">2</td> <td>Standard setting value</td> </tr> <tr> <td style="text-align: center;">3</td> <td>Standard setting value</td> </tr> <tr> <td style="text-align: center;">4</td> <td>Standard setting value</td> </tr> <tr> <td style="text-align: center;">5</td> <td>High response (high-rigidity loads, loads which do not easily vibrate)</td> </tr> </tbody> </table>					Setting value	Details	1	Low response (low-rigidity loads, loads which easily vibrate)	2	Standard setting value	3	Standard setting value	4	Standard setting value	5	High response (high-rigidity loads, loads which do not easily vibrate)						
Setting value	Details																					
1	Low response (low-rigidity loads, loads which easily vibrate)																					
2	Standard setting value																					
3	Standard setting value																					
4	Standard setting value																					
5	High response (high-rigidity loads, loads which do not easily vibrate)																					
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">Setting value</th> <th style="width: 85%;">Details</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Standard</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Large friction amount (set the position loop gain slightly lower)</td> </tr> </tbody> </table>					Setting value	Details	0	Standard	1	Large friction amount (set the position loop gain slightly lower)												
Setting value	Details																					
0	Standard																					
1	Large friction amount (set the position loop gain slightly lower)																					
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">Setting value</th> <th style="width: 85%;">Details</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Only auto-tuning PG2, VG2, VIC, and GD2.</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Only auto-tuning PG1, PG2, VG1, VG2, VIC, and GD2 (total gain). (Standard setting)</td> </tr> <tr> <td style="text-align: center;">2</td> <td>No auto-tuning.</td> </tr> </tbody> </table>					Setting value	Details	0	Only auto-tuning PG2, VG2, VIC, and GD2.	1	Only auto-tuning PG1, PG2, VG1, VG2, VIC, and GD2 (total gain). (Standard setting)	2	No auto-tuning.										
Setting value	Details																					
0	Only auto-tuning PG2, VG2, VIC, and GD2.																					
1	Only auto-tuning PG1, PG2, VG1, VG2, VIC, and GD2 (total gain). (Standard setting)																					
2	No auto-tuning.																					
8	PG1	Position loop gain 1	Set the position loop gain for the model loop. Determine the tracking ability regarding the position commands.	4 to 1000 (1/s) 70																		
9			(Not used.)	0																		
10	EMGt	Deceleration control time constant	Set the deceleration time from the clamp speed (Aspeed1). For normal rapid traverse, set the same value as the acceleration/deceleration time constant.	0 to 32768 (ms) 500																		
11			(Not used.)	0																		
12			(Not used.)	0																		
13	MBR	Vertical axis drop prevention time	Input the time the servo OFF is delayed during servo OFF command. Increase the setting by 100ms at a time and set the minimum value where the axis does not drop.	0 to 1000 (ms) 100																		
14	NCH	Notch filter No.	Set the frequency of the machine resonance suppression filter. Do not set values without a description.																			
<table border="1" style="margin: auto;"> <tr> <th style="width: 10%;">Setting value</th> <th style="width: 10%;">0</th> <th style="width: 10%;">1</th> <th style="width: 10%;">2</th> <th style="width: 10%;">3</th> <th style="width: 10%;">4</th> <th style="width: 10%;">5</th> <th style="width: 10%;">6</th> <th style="width: 10%;">7</th> </tr> <tr> <td>Frequency (Hz)</td> <td>No start</td> <td>1125</td> <td>563</td> <td>375</td> <td>282</td> <td>225</td> <td>188</td> <td>161</td> </tr> </table>					Setting value	0	1	2	3	4	5	6	7	Frequency (Hz)	No start	1125	563	375	282	225	188	161
Setting value	0	1	2	3	4	5	6	7														
Frequency (Hz)	No start	1125	563	375	282	225	188	161														

13. AUXILIARY AXIS PARAMETER

No.	Name		Details	Setting range	Default value										
15			(Not used.)		0										
16	JIT	Jitter compensation	<p>Set the No. of ignored jitter compensation pulses. Do not set values without a description.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>Setting value</td> <td>0</td> <td>1</td> <td>2</td> <td>3</td> </tr> <tr> <td>Number of ignore pulses</td> <td>No start</td> <td>1</td> <td>2</td> <td>3</td> </tr> </table>	Setting value	0	1	2	3	Number of ignore pulses	No start	1	2	3		
Setting value	0	1	2	3											
Number of ignore pulses	No start	1	2	3											
17			(Not used.)		0										
18			(Not used.)		0										
19	PG2	Position loop gain 2	Set the position loop gain of the actual loop. Determine the position responsiveness for external disturbance.	1 to 500 (1/s)	25										
20	VG1	Speed loop gain 1	Set the speed loop gain of the model loop. Determine the tracking ability regarding the speed commands.	20 to 5000 (1/s)	1200										
21	VG2	Speed loop gain 2	Set the speed loop gain of the actual loop. Determine the speed responsiveness for external disturbance.	20 to 8000 (1/s)	600										
22	VIC	Speed integral compensation	Determine the characteristics of the speed low-frequency region.	1 to 1000 (ms)	20										
23	VDC	Speed differential compensation	PI control normally results from a default value of 1000. Adjust the overshoot amount by lowering in increments of 20.	0 to 1000	1000										
24	DG2	Load inertia ratio	Set the load inertia ratio for the motor inertia.	0.0 to 50.0 (fold)	2.0										
25			(Not used.)		0										
30 (PR)	MTY	Motor type	Set the motor type. This is automatically judged by the system when the default value (0000) is set.	0000 to FFFF (hexadecimal)	0000										

13. AUXILIARY AXIS PARAMETER

No.	Name	Details	Setting range	Default value	
50	MD1	D/A output channel 1 data No.	Set the Nos. of the data to be output on D/A output channel 1.		
			<div style="border: 1px solid black; display: inline-block; padding: 2px;">0 0 0 0</div> (Default setting value)		
			Setting value	Details	Magnification
			0	Speed feedback (with sign)	Maximum rotation speed = 8V
			1	Current feedback (with sign)	Maximum current (torque) = 8V
			2	Speed feedback (without sign)	Maximum rotation speed = 8V
			3	Current feedback (without sign)	Maximum current (torque) = 8V
			4	Current command	Maximum current (torque) = 8V
			5	Command FΔT	100000 [degrees/min] = 10V
			6	Position droop 1 (1/1)	2048 [pulse] = 10V
			7	Position droop 2 (1/4)	8192 [pulse] = 10V
			8	Position droop 3 (1/16)	32768 [pulse] = 10V
9	Position droop 4 (1/32)	65536 [pulse] = 10V			
A	Position droop 5 (1/64)	131072 [pulse] = 10V			
51	MO1	D/A output channel 1 output offset	Set this value when the zero level of D/A output channel 1 is not suitable.	-999 to 999 (mV)	0
52			(Not used.)		0
53	MD2	D/A output channel 2 data No.	Set the Nos. of the data to be output on D/A output channel 2. The descriptions are the same as "50 MD1".	0000 to FFFF (hexadecimal)	0000
54	MO2	D/A output channel 2 output offset	Set this value when the zero level of D/A output channel 2 is not suitable.	-999 to 999 (mV)	0
55			(Not used.)		0
100 (PR)	station	No. of indexing stations	Set the No. of stations. For linear axes, this value is expressed by: No. of divisions = No. of stations -1.	2 to 360	2

13. AUXILIARY AXIS PARAMETER

No.	Name	Details	Setting range	Default value
101 (PR)	Cont1	Control parameter 1	This is a HEX setting parameter. Set bits without a description to their default values.	
			bit	F E D C B A 9 8 7 6 5 4 3 2 1 0
			Default value	0 0 0 0 0 0 1 0 0 0 0 0 0 0 0 0
			bit	Meaning when "0" is set
		0		
		1	High-speed zero point return after establishment of zero point.	Dog-type return for each zero point return operation.
		2		
		3		
		4		
		5		
		6		
		7		
		8	Reference point return direction (+)	Reference point return direction (-)
		9	Rotation direction determined by operation control signal (DIR)	Rotation direction in the shortcut direction
		A	Machine basic position becomes the origin point	Electrical zero point becomes the origin point
		B		
		C		
		D	Coordinate zero point creation valid	Zero point established at power supply ON position
		E	Rotation direction in operation control signal (DIR) or in the shortcut direction	Rotation direction in the random position command sign direction
		F	Stopper direction is positioning direction	Stopper direction is in the sign direction of the stopper amount

13. AUXILIARY AXIS PARAMETER

No.	Name	Details	Setting range	Default value																																																																																						
102 (PR)	Cont2 Control parameter 2	<p>This is a HEX setting parameter. Set bits without a description to their default values.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-bottom: 10px;"> <thead> <tr> <th style="width: 5%;">bit</th> <th style="width: 3%;">F</th> <th style="width: 3%;">E</th> <th style="width: 3%;">D</th> <th style="width: 3%;">C</th> <th style="width: 3%;">B</th> <th style="width: 3%;">A</th> <th style="width: 3%;">9</th> <th style="width: 3%;">8</th> <th style="width: 3%;">7</th> <th style="width: 3%;">6</th> <th style="width: 3%;">5</th> <th style="width: 3%;">4</th> <th style="width: 3%;">3</th> <th style="width: 3%;">2</th> <th style="width: 3%;">1</th> <th style="width: 3%;">0</th> </tr> </thead> <tbody> <tr> <td>Default value</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>1</td> <td>0</td> </tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 5%;">bit</th> <th style="width: 45%;">Meaning when "0" is set</th> <th style="width: 50%;">Meaning when "1" is set</th> </tr> </thead> <tbody> <tr><td>0</td><td></td><td></td></tr> <tr><td>1</td><td>Error not corrected at servo OFF</td><td>Error corrected at servo OFF</td></tr> <tr><td>2</td><td>Linear axis</td><td>Rotation axis</td></tr> <tr><td>3</td><td>Station assignment direction CW</td><td>Station assignment direction CCW</td></tr> <tr><td>4</td><td>Uniform index</td><td>Non-uniform index</td></tr> <tr><td>5</td><td>DO channel standard assignment</td><td>DO channel reverse assignment</td></tr> <tr><td>6</td><td>2-wire detector communication</td><td>4-wire detector communication</td></tr> <tr><td>7</td><td>Incremental detection</td><td>Absolute position detection</td></tr> <tr><td>8</td><td></td><td></td></tr> <tr><td>9</td><td></td><td></td></tr> <tr><td>A</td><td></td><td></td></tr> <tr><td>B</td><td></td><td></td></tr> <tr><td>C</td><td></td><td></td></tr> <tr><td>D</td><td></td><td></td></tr> <tr><td>E</td><td></td><td></td></tr> <tr><td>F</td><td></td><td></td></tr> </tbody> </table>	bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0	Default value	0	0	0	0	0	0	0	0	1	0	0	0	0	0	1	1	0	bit	Meaning when "0" is set	Meaning when "1" is set	0			1	Error not corrected at servo OFF	Error corrected at servo OFF	2	Linear axis	Rotation axis	3	Station assignment direction CW	Station assignment direction CCW	4	Uniform index	Non-uniform index	5	DO channel standard assignment	DO channel reverse assignment	6	2-wire detector communication	4-wire detector communication	7	Incremental detection	Absolute position detection	8			9			A			B			C			D			E			F				
bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0																																																																										
Default value	0	0	0	0	0	0	0	0	1	0	0	0	0	0	1	1	0																																																																									
bit	Meaning when "0" is set	Meaning when "1" is set																																																																																								
0																																																																																										
1	Error not corrected at servo OFF	Error corrected at servo OFF																																																																																								
2	Linear axis	Rotation axis																																																																																								
3	Station assignment direction CW	Station assignment direction CCW																																																																																								
4	Uniform index	Non-uniform index																																																																																								
5	DO channel standard assignment	DO channel reverse assignment																																																																																								
6	2-wire detector communication	4-wire detector communication																																																																																								
7	Incremental detection	Absolute position detection																																																																																								
8																																																																																										
9																																																																																										
A																																																																																										
B																																																																																										
C																																																																																										
D																																																																																										
E																																																																																										
F																																																																																										
103 (PR)	EmgCont Emergency stop control	<p>This is a HEX setting parameter. Set bits without a description to their default values.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-bottom: 10px;"> <thead> <tr> <th style="width: 5%;">bit</th> <th style="width: 3%;">F</th> <th style="width: 3%;">E</th> <th style="width: 3%;">D</th> <th style="width: 3%;">C</th> <th style="width: 3%;">B</th> <th style="width: 3%;">A</th> <th style="width: 3%;">9</th> <th style="width: 3%;">8</th> <th style="width: 3%;">7</th> <th style="width: 3%;">6</th> <th style="width: 3%;">5</th> <th style="width: 3%;">4</th> <th style="width: 3%;">3</th> <th style="width: 3%;">2</th> <th style="width: 3%;">1</th> <th style="width: 3%;">0</th> </tr> </thead> <tbody> <tr> <td>Default value</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>1</td> </tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 5%;">bit</th> <th style="width: 45%;">Meaning when "0" is set</th> <th style="width: 50%;">Meaning when "1" is set</th> </tr> </thead> <tbody> <tr><td>0</td><td>External emergency stop valid</td><td>External emergency stop invalid (default value)</td></tr> <tr><td>1</td><td>Dynamic brake stop at emergency stop</td><td>Deceleration control stop at emergency stop</td></tr> <tr><td>2</td><td>NC bus emergency stop input valid</td><td>NC bus emergency stop input invalid</td></tr> <tr><td>3</td><td>NC bus emergency stop output valid</td><td>NC bus emergency stop output invalid</td></tr> <tr><td>4</td><td></td><td></td></tr> <tr><td>5</td><td></td><td></td></tr> <tr><td>6</td><td></td><td></td></tr> <tr><td>7</td><td></td><td></td></tr> <tr><td>8</td><td></td><td></td></tr> <tr><td>9</td><td></td><td></td></tr> <tr><td>A</td><td></td><td></td></tr> <tr><td>B</td><td></td><td></td></tr> <tr><td>C</td><td></td><td></td></tr> <tr><td>D</td><td></td><td></td></tr> <tr><td>E</td><td></td><td></td></tr> <tr><td>F</td><td></td><td></td></tr> </tbody> </table>	bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0	Default value	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	bit	Meaning when "0" is set	Meaning when "1" is set	0	External emergency stop valid	External emergency stop invalid (default value)	1	Dynamic brake stop at emergency stop	Deceleration control stop at emergency stop	2	NC bus emergency stop input valid	NC bus emergency stop input invalid	3	NC bus emergency stop output valid	NC bus emergency stop output invalid	4			5			6			7			8			9			A			B			C			D			E			F					
bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0																																																																										
Default value	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1																																																																										
bit	Meaning when "0" is set	Meaning when "1" is set																																																																																								
0	External emergency stop valid	External emergency stop invalid (default value)																																																																																								
1	Dynamic brake stop at emergency stop	Deceleration control stop at emergency stop																																																																																								
2	NC bus emergency stop input valid	NC bus emergency stop input invalid																																																																																								
3	NC bus emergency stop output valid	NC bus emergency stop output invalid																																																																																								
4																																																																																										
5																																																																																										
6																																																																																										
7																																																																																										
8																																																																																										
9																																																																																										
A																																																																																										
B																																																																																										
C																																																																																										
D																																																																																										
E																																																																																										
F																																																																																										

13. AUXILIARY AXIS PARAMETER

No.	Name		Details	Setting range	Default value
104 (PR)	tleng	Linear axis stroke length	Set the movement stroke length for linear axes. This is meaningless when setting non-uniform assignments or commanding random positions.	0.001 to 99999.999 (mm)	100.000
110	ZRNspeed	Reference point return speed	Set the clamp value of the feedrate when a reference point return is carried out. The feedrate becomes the manual operation speed of the parameter group selected at that time, but it is clamped by this parameter setting value.	1 to 100000 (°/min or mm/min)	1000
111	ZRNcreep	Reference point return creep speed	Set the approach speed to the reference point after dog detection during a reference point return.	1 to 65535 (°/min or mm/min)	200
112	grid mask	Grid mask	Set the amount that the dog is artificially extended. Set 1/2 the grid spacing as a standard.	0 to 65536 (1/1000° or μm)	0
113 (PR)	grspc	Grid spacing	Divide the grid spacing that is the conventional motor rotation movement amount into 2, 4, 8, or 16 divisions.	0 to 4 (1/2 ⁿ division)	0
114	ZRNshift	Reference point shift amount	Set the shift amount in a dog-type reference point return from the electric zero point determined on the grid to the reference point.	0 to 65536 (1/1000° or μm)	0
115	ST. ofset	Station offset	Set the distance (offset) from the reference point to station 1.	-99999.999 to 99999.999 (° or mm)	0.000
116 (PR)	ABS base	Absolute position zero point	When movement of the machine coordinate zero point from the origin point is required during absolute position initializing, set that movement amount.	-99999.999 to 99999.999 (° or mm)	0.000
117	Limit (+)	Soft limit (+)	Commands in the plus direction that exceed this setting value are not possible. If the machine is in a position exceeding the setting value, commands in the minus direction are possible. The soft limit function will not operate if Limit (+) and Limit (-) are set to the same value.	-99999.999 to 99999.999 (mm)	1.000
118	Limit (-)	Soft limit (-)	Commands in the minus direction that exceed this value are not possible. If the machine is in a position exceeding the setting value, commands in the plus direction are possible.	-99999.999 to 99999.999 (mm)	1.000

13. AUXILIARY AXIS PARAMETER

No.	Name	Details	Setting range	Default value																																																																																						
120	ABS Type	Absolute position detection parameter	<p>This parameter is set as a hexadecimal. Set the default value for bits that have no description.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-bottom: 10px;"> <thead> <tr> <th style="width: 5%;">bit</th> <th style="width: 3%;">F</th> <th style="width: 3%;">E</th> <th style="width: 3%;">D</th> <th style="width: 3%;">C</th> <th style="width: 3%;">B</th> <th style="width: 3%;">A</th> <th style="width: 3%;">9</th> <th style="width: 3%;">8</th> <th style="width: 3%;">7</th> <th style="width: 3%;">6</th> <th style="width: 3%;">5</th> <th style="width: 3%;">4</th> <th style="width: 3%;">3</th> <th style="width: 3%;">2</th> <th style="width: 3%;">1</th> <th style="width: 3%;">0</th> </tr> </thead> <tbody> <tr> <td>Default value</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>1</td> <td>0</td> <td>0</td> </tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 5%;">bit</th> <th style="width: 45%;">Meaning when "0" is set</th> <th style="width: 50%;">Meaning when "1" is set</th> </tr> </thead> <tbody> <tr><td>0</td><td></td><td></td></tr> <tr><td>1</td><td>Dogless-type method initializing</td><td>Dog-type method initializing</td></tr> <tr><td>2</td><td>Mechanical stopper method initializing</td><td>Origin point alignment method initializing</td></tr> <tr><td>3</td><td>Electrical zero point direction (+)</td><td>Electrical zero point direction (-)</td></tr> <tr><td>4</td><td></td><td></td></tr> <tr><td>5</td><td></td><td></td></tr> <tr><td>6</td><td></td><td></td></tr> <tr><td>7</td><td></td><td></td></tr> <tr><td>8</td><td></td><td></td></tr> <tr><td>9</td><td></td><td></td></tr> <tr><td>A</td><td></td><td></td></tr> <tr><td>B</td><td></td><td></td></tr> <tr><td>C</td><td></td><td></td></tr> <tr><td>D</td><td></td><td></td></tr> <tr><td>E</td><td></td><td></td></tr> <tr><td>F</td><td></td><td></td></tr> </tbody> </table>		bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0	Default value	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	bit	Meaning when "0" is set	Meaning when "1" is set	0			1	Dogless-type method initializing	Dog-type method initializing	2	Mechanical stopper method initializing	Origin point alignment method initializing	3	Electrical zero point direction (+)	Electrical zero point direction (-)	4			5			6			7			8			9			A			B			C			D			E			F			
bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0																																																																										
Default value	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0																																																																										
bit	Meaning when "0" is set	Meaning when "1" is set																																																																																								
0																																																																																										
1	Dogless-type method initializing	Dog-type method initializing																																																																																								
2	Mechanical stopper method initializing	Origin point alignment method initializing																																																																																								
3	Electrical zero point direction (+)	Electrical zero point direction (-)																																																																																								
4																																																																																										
5																																																																																										
6																																																																																										
7																																																																																										
8																																																																																										
9																																																																																										
A																																																																																										
B																																																																																										
C																																																																																										
D																																																																																										
E																																																																																										
F																																																																																										
123	ABS check	Absolute position power OFF tolerable movement value	Set the value for the tolerable amount of movement for a machine that moved during power OFF in an absolute position detection system. The "Absolute position power OFF movement exceeded (ABS)" signal will turn ON if the machine moves more than this setting value during power OFF. The movement amount is not checked when this parameter is set to 0.000.	0.000 to 99999.999 (° or mm) 0.000																																																																																						
130	backlash	Backlash compensation amount	Set the backlash compensation amount.	0 to 9999 (1/1000° or μm) 0																																																																																						
132			(Not used.)	0																																																																																						
133			(Not used.)	0																																																																																						
134			(Not used.)	0																																																																																						
135			(Not used.)	0																																																																																						

13. AUXILIARY AXIS PARAMETER

< Operation parameter group 1 >

No.	Name	Details	Setting range	Default value
150	Aspeed1 Operation parameter group 1 Automatic operation speed	Set the feedrate during automatic operation when operation parameter group 1 is selected. This parameter is regarded as the clamp value for the automatic operation speeds and manual operation speeds of all operation groups. A speed exceeding Aspeed1 cannot be commanded, even if set in the parameters.	1 to 100000 (°/min or mm/min)	5000
151	Mspeed1 Operation parameter group 1 Manual operation speed	Set the feedrate during manual operation or JOG operation when operation parameter group 1 is selected.	1 to 100000 (°/min or mm/min)	2000
152	time1.1 Operation parameter group 1 Acceleration/deceleration time constant 1	Set the linear acceleration/deceleration time for Aspeed 1 (the operation parameter group 1 automatic operation speed (clamp speed)) when operation parameter group 1 is selected. When operating at speeds less than the clamp speed, the axis will linearly accelerate/decelerate at the inclination determined above. When this is set together with acceleration/deceleration time constant 2, S-shape acceleration/deceleration is carried out. In this case, set the acceleration/deceleration time of the linear part in this parameter.	1 to 9999 (ms)	100
153	time1.2 Operation parameter group 1 Acceleration/deceleration time constant 2	Set this parameter when carrying out S-shape acceleration/deceleration. When S-shape acceleration/deceleration is carried out, set the total time of the non-linear parts. When "1" is set in this parameter, linear acceleration/deceleration is carried out. In the handle feed operation mode, this set value is regarded as the time constant for the linear acceleration/deceleration.	1 to 999 (ms)	1

13. AUXILIARY AXIS PARAMETER

No.	Name	Details	Setting range	Default value
154	TL1 Operation parameter group 1 Torque limit value	Set the motor output torque limit value when operation parameter group 1 is selected. At the default value, the torque is limited at the maximum torque of the motor specification. Set the default value when torque limit is not especially required. In the stopper positioning operation mode, this becomes the torque limit value when positioning to the stopper starting coordinates.	1 to 500 (%)	500
155	OD1 Operation parameter group 1 Excessive error detection width	Set the excessive error detection width when operation parameter group 1 is selected. An alarm of excessive error (S03 0052) is detected when the position droop becomes larger than this setting value. In the stopper positioning operation mode, this becomes the excessive error detection width when positioning to the stopper starting coordinates.	0 to 32767 (° or mm)	100
156	just1 Operation parameter group 1 Set position output width	The signal indicating that the machine position is at any one of the stations is the set position reached (JST) signal. During automatic operation, the automatic set position reached (JSTA) signal is also output under the same conditions. Set the tolerable values at which these signals are output when operation parameter group 1 is selected. These signals turn OFF when the machine position is separated from the station by more than this value.	0.000 to 99999.999 (° or mm)	0.500
157	near1 Operation parameter group 1 Near set position output width	The signal indicating that the machine position is near any one of the station positions is the near set position (NEAR) signal. Set the tolerable value at which this signal is output when operation parameter group 1 is selected. This value is generally set wider than the set position output width. During operations, this is related to special commands when the station selection is "0".	0.000 to 99999.999 (° or mm)	1.000

13. AUXILIARY AXIS PARAMETER

< Operation parameter group 2 >

No.	Name	Details	Setting range	Default value
158	Aspeed2 Operation parameter group 2 Automatic operation speed	Set the feedrate during automatic operation when operation parameter group 2 is selected.	1 to 100000 (°/min or mm/min)	5000
159	Mspeed2 Operation parameter group 2 Manual operation speed	Set the feedrate during manual operation or JOG operation when operation parameter group 2 is selected.	1 to 100000 (°/min or mm/min)	2000
160	time2.1 Operation parameter group 2 Acceleration/deceleration time constant 1	Set the linear acceleration/deceleration time for the operation parameter group 1 automatic operation speed (clamp speed) when operation parameter group 2 is selected. When operating at speeds less than the clamp speed, the axis will linearly accelerate/decelerate at the inclination determined above. When this is set together with acceleration/deceleration time constant 2, S-shape acceleration/deceleration is carried out. In this case, set the acceleration/deceleration time of the linear part in this parameter.	1 to 9999 (ms)	100
161	time2.2 Operation parameter group 2 Acceleration/deceleration time constant 2	Set this parameter when carrying out S-shape acceleration/deceleration. When S-shape acceleration/deceleration is carried out, set the total time of the non-linear parts. When 1 is set in this parameter, linear acceleration/deceleration is carried out. In the handle feed operation mode, this set value is regarded as the time constant for the linear acceleration/deceleration.	1 to 999 (ms)	1

13. AUXILIARY AXIS PARAMETER

No.	Name	Details	Setting range	Default value
162	TL2 Operation parameter group 2 Torque limit value	Set the motor output torque limit value when operation parameter group 2 is selected. At the default value, the torque is limited at the maximum torque of the motor specifications. Set the default value when torque limit is not especially required. In the stopper positioning operation mode, this becomes the torque limit value during stopper operation.	1 to 500 (%)	500
163	OD2 Operation parameter group 2 Excessive error detection width	Set the excessive error detection width when operation parameter group 2 is selected. An excessive error alarm (S03 0052) is detected when the position droop becomes larger than this setting value. In the stopper positioning operation mode, this becomes the excessive error detection width during stopper operation.	0 to 32767 (° or mm)	100
164	just2 Operation parameter group 2 Set position output width	The signal indicating that the machine position is at any one of the stations is the set position reached (JST) signal. During automatic operation, the automatic set position reached (JSTA) signal is also output under the same conditions. Set the tolerable values at which these signals are output when operation parameter group 2 is selected. These signals turn OFF when the machine position is separated from the station by more than this value.	0.000 to 99999.999 (° or mm)	0.500
165	near2 Operation parameter group 2 Near set position output width	The signal indicating that the machine position is near any one of the station positions is the near set position (NEAR) signal. Set the tolerable values at which these signals are output when operation parameter group 2 is selected. These values are generally set wider than the set position output width. During operations, this is related to special commands when the station selection is "0".	0.000 to 99999.999 (° or mm)	1.000

13. AUXILIARY AXIS PARAMETER

< Operation parameter group 3 >

No.	Name	Details	Setting range	Default value
166	Aspeed3 Operation parameter group 3 Automatic operation speed	Set the feedrate during automatic operation when operation parameter group 3 is selected.	1 to 100000 (°/min or mm/min)	5000
167	Mspeed3 Operation parameter group 3 Manual operation speed	Set the feedrate during manual operation or JOG operation when operation parameter group 3 is selected.	1 to 100000 (°/min or mm/min)	2000
168	time3.1 Operation parameter group 3 Acceleration/deceleration time constant 1	Set the linear acceleration/deceleration time for the operation parameter group 1 automatic operation speed (clamp speed) when operation parameter group 3 is selected. When operating at speeds less than the clamp speed, the axis will linearly accelerate/decelerate at the inclination determined above. When this is set together with acceleration/deceleration time constant 2, S-shape acceleration/deceleration is carried out. In this case, set the acceleration/deceleration time of the linear part in this parameter.	1 to 9999 (ms)	100
169	time3.2 Operation parameter group 3 Acceleration/deceleration time constant 2	Set this parameter when carrying out S-shape acceleration/deceleration. When S- shape acceleration/deceleration is carried out, set the total time of the non-linear parts. When 1 is set in this parameter, linear acceleration/deceleration is carried out. In the handle feed operation mode, this set value is regarded as the time constant for the linear acceleration/deceleration.	1 to 999 (ms)	1

13. AUXILIARY AXIS PARAMETER

No.	Name	Details	Setting range	Default value
170	TL3 Operation parameter group 3 Torque limit value	Set the motor output torque limit value when operation parameter group 3 is selected. At the default value, the torque is limited at the maximum torque of the motor specifications. Set the default value when torque limit is not especially required. In the stopper positioning operation mode, this becomes the pressing torque limit value after completion of the positioning.	1 to 500 (%)	500
171	OD3 Operation parameter group 3 Excessive error detection width	Set the excessive error detection width when operation parameter group 3 is selected. An excessive error alarm (S03 0052) is detected when the position droop becomes larger than this setting value. In the stopper positioning operation mode, this becomes the excessive error detection width during pressing after completion of the positioning.	0 to 32767 (° or mm)	100
172	just3 Operation parameter group 3 Set position output width	The signal indicating that the machine position is at any one of the stations is the set position reached (JST) signal. During automatic operation, the automatic set position reached (JSTA) signal is also output under the same conditions. Set the tolerable values at which these signals are output when operation parameter group 3 is selected. These signals turn OFF when the machine position is separated from the station by more than this value.	0.000 to 99999.999 (° or mm)	0.500
173	near3 Operation parameter group 3 Near set position output width	The signal indicating that the machine position is near any one of the station positions is the near set position (NEAR) signal. Set the tolerable values at which these signals are output when operation parameter group 3 is selected. These values are generally set wider than the set position output width. During operations, this is related to special commands when the station selection is "0".	0.000 to 99999.999 (° or mm)	1.000

13. AUXILIARY AXIS PARAMETER

< Operation parameter group 4 >

No.	Name	Details	Setting range	Default value
174	Aspeed4 Operation parameter group 4 Automatic operation speed	Set the feedrate during automatic operation when operation parameter group 4 is selected.	1 to 100000 (°/min or mm/min)	5000
175	Mspeed4 Operation parameter group 4 Manual operation speed	Set the feedrate during manual operation or JOG operation when operation parameter group 4 is selected.	1 to 100000 (°/min or mm/min)	2000
176	time4.1 Operation parameter group 4 Acceleration/deceleration time constant 1	Set the linear acceleration/deceleration time for the operation parameter group 1 automatic operation speed (clamp speed) when operation parameter group 4 is selected. When operating at speeds less than the clamp speed, the axis will linearly accelerate/decelerate at the inclination determined above. When this is set together with acceleration/deceleration time constant 2, S-shape acceleration/deceleration is carried out. In this case, set the acceleration/deceleration time of the linear part in this parameter.	1 to 9999 (ms)	100
177	time4.2 Operation parameter group 4 Acceleration/deceleration time constant 2	Set this parameter when carrying out S-shape acceleration/deceleration. When S-shape acceleration/deceleration is carried out, set the total time of the non-linear parts. When 1 is set in this parameter, linear acceleration/deceleration is carried out. In the handle feed operation mode, this set value is regarded as the time constant for the linear acceleration/deceleration.	1 to 999 (ms)	1

13. AUXILIARY AXIS PARAMETER

No.	Name	Details	Setting range	Default value
178	TL4 Operation parameter group 4 Torque limit value	Set the motor output torque limit value when operation parameter group 4 is selected. At the default value, the torque is limited at the maximum torque of the motor specifications. Set the default value when torque limit is not especially required. In the stopper method initializing mode in absolute position detection systems, this becomes the torque limit value during stopper operation.	1 to 500 (%)	500
179	OD4 Operation parameter group 4 Excessive error detection width	Set the excessive error detection width when operation parameter group 4 is selected. An excessive error alarm (S03 0052) is detected when the position droop becomes larger than this setting value. In the stopper method initializing mode in absolute position detection systems, this becomes the excessive error detection width during stopper operation.	0 to 32767 (° or mm)	100
180	just4 Operation parameter group 4 Set position output width	The signal indicating that the machine position is at any one of the stations is the set position reached (JST) signal. During automatic operation, the automatic set position reached (JSTA) signal is also output under the same conditions. Set the tolerable values at which these signals are output when operation parameter group 4 is selected. These signals turn OFF when the machine position is separated from the station by more than this value.	0.000 to 99999.999 (° or mm)	0.500
181	near4 Operation parameter group 4 Near set position output width	The signal indicating that the machine position is near any one of the station positions is the near set position (NEAR) signal. Set the tolerable values at which these signals are output when operation parameter group 4 is selected. These values are generally set wider than the set position output width. During operations, this is related to special commands when the station selection is "0".	0.000 to 99999.999 (° or mm)	1.000

13. AUXILIARY AXIS PARAMETER

No.	Name	Details	Setting range	Default value																																																																																						
190	stpos2	Station 2 coordinate value	-99999.999 to 99999.999 (° or mm)	0.000																																																																																						
191	stpos3	Station 3 coordinate value																																																																																								
192	stpos4	Station 4 coordinate value																																																																																								
193	stpos5	Station 5 coordinate value																																																																																								
194	stpos6	Station 6 coordinate value																																																																																								
195	stpos7	Station 7 coordinate value																																																																																								
196	stpos8	Station 8 coordinate value																																																																																								
197	stpos9	Station 9 coordinate value																																																																																								
200	PSWcheck	<p>PSW detection method</p> <p>This is a HEX setting parameter. Set bits without a description to their default values.</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-bottom: 10px;"> <thead> <tr> <th style="width: 5%;">bit</th> <th style="width: 5%;">F</th> <th style="width: 5%;">E</th> <th style="width: 5%;">D</th> <th style="width: 5%;">C</th> <th style="width: 5%;">B</th> <th style="width: 5%;">A</th> <th style="width: 5%;">9</th> <th style="width: 5%;">8</th> <th style="width: 5%;">7</th> <th style="width: 5%;">6</th> <th style="width: 5%;">5</th> <th style="width: 5%;">4</th> <th style="width: 5%;">3</th> <th style="width: 5%;">2</th> <th style="width: 5%;">1</th> <th style="width: 5%;">0</th> </tr> </thead> <tbody> <tr> <td>Default value</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 5%;">bit</th> <th style="width: 20%;">Position switch</th> <th style="width: 35%;">Meaning when "0" is set</th> <th style="width: 40%;">Meaning when "1" is set</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>PSW1</td> <td rowspan="8" style="vertical-align: top;">The position switch output is judged by the machine position of the command system.</td> <td rowspan="8" style="vertical-align: top;">The position switch output is judged by the machine FB position (actual position).</td> </tr> <tr> <td>1</td> <td>PSW2</td> </tr> <tr> <td>2</td> <td>PSW3</td> </tr> <tr> <td>3</td> <td>PSW4</td> </tr> <tr> <td>4</td> <td>PSW5</td> </tr> <tr> <td>5</td> <td>PSW6</td> </tr> <tr> <td>6</td> <td>PSW7</td> </tr> <tr> <td>7</td> <td>PSW8</td> </tr> <tr> <td>8</td> <td></td> <td></td> <td></td> </tr> <tr> <td>9</td> <td></td> <td></td> <td></td> </tr> <tr> <td>A</td> <td></td> <td></td> <td></td> </tr> <tr> <td>B</td> <td></td> <td></td> <td></td> </tr> <tr> <td>C</td> <td></td> <td></td> <td></td> </tr> <tr> <td>D</td> <td></td> <td></td> <td></td> </tr> <tr> <td>E</td> <td></td> <td></td> <td></td> </tr> <tr> <td>F</td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0	Default value	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	bit	Position switch	Meaning when "0" is set	Meaning when "1" is set	0	PSW1	The position switch output is judged by the machine position of the command system.	The position switch output is judged by the machine FB position (actual position).	1	PSW2	2	PSW3	3	PSW4	4	PSW5	5	PSW6	6	PSW7	7	PSW8	8				9				A				B				C				D				E				F			
bit	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0																																																																										
Default value	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0																																																																										
bit	Position switch	Meaning when "0" is set	Meaning when "1" is set																																																																																							
0	PSW1	The position switch output is judged by the machine position of the command system.	The position switch output is judged by the machine FB position (actual position).																																																																																							
1	PSW2																																																																																									
2	PSW3																																																																																									
3	PSW4																																																																																									
4	PSW5																																																																																									
5	PSW6																																																																																									
6	PSW7																																																																																									
7	PSW8																																																																																									
8																																																																																										
9																																																																																										
A																																																																																										
B																																																																																										
C																																																																																										
D																																																																																										
E																																																																																										
F																																																																																										


13. AUXILIARY AXIS PARAMETER

No.	Name		Details	Setting range	Default value
201 202	PSW1dog1 PSW1dog2	PSW1 area setting 1 PSW1 area setting 2	When the machine position is in the region between region settings 1 and 2, the position switch of each No. will turn ON. Whether the value of setting 1 is larger than setting 2 (vice versa) does not affect the position switch operation. For rotation axes, the output turns ON at the region without including 0.000 degree.	-99999.999 to 99999.999 (° or mm)	0.000
203 204	PSW2dog1 PSW2dog2	PSW2 area setting 1 PSW2 area setting 2			
205 206	PSW3dog1 PSW3dog2	PSW3 area setting 1 PSW3 area setting 2			
207 208	PSW4dog1 PSW4dog2	PSW4 area setting 1 PSW4 area setting 2			
209 210	PSW5dog1 PSW5dog2	PSW5 area setting 1 PSW5 area setting 2			
211 212	PSW6dog1 PSW6dog2	PSW6 area setting 1 PSW6 area setting 2			
213 214	PSW7dog1 PSW7dog2	PSW7 area setting 1 PSW7 area setting 2			
215 216	PSW8dog1 PSW8dog2	PSW8 area setting 1 PSW8 area setting 2			
220	push	Stopper amount			
221	pusht1	Stopper standby time	Set the standby time from the stopper starting coordinate positioning to the stopper operation start during stopper positioning operations.	0 to 9999 (ms)	0
222	pusht2	Stopper torque release time	Set the time from the completion of the stopper operation to the changeover of the stopper torque during stopper positioning operations.	0 to 9999 (ms)	0
223	pusht3	Set position signal output delay time	Set the time from the completion of the stopper operation to the output of the automatic set position reached (JSTA), set position reached (JST), and near set position (NEAR) signals during stopper positioning operations.	0 to 9999 (ms)	0

Revision History

Date of revision	Manual No.	Revision details
Mar. 2006	IB(NA)1500175-A	First edition created.

Global service network



North America FA Center (MITSUBISHI ELECTRIC AUTOMATION INC.)

Illinois CNC Service Center
500 CORPORATE WOODS PARKWAY, VERNON HILLS, IL. 60061, U.S.A.
TEL: +1-847-478-2500 (Se) FAX: +1-847-478-2650 (Se)

California CNC Service Center
5665 PLAZA DRIVE, CYPRESS, CA. 90630, U.S.A.
TEL: +1-714-220-4796 FAX: +1-714-229-3818

Georgia CNC Service Center
2810 PREMIERE PARKWAY SUITE 400, DULUTH, GA., 30097, U.S.A.
TEL: +1-678-258-4500 FAX: +1-678-258-4519

New Jersey CNC Service Center
200 COTTONTAIL LANE SOMERSET, NJ. 08873, U.S.A.
TEL: +1-732-560-4500 FAX: +1-732-560-4531

Michigan CNC Service Satellite
2545 38TH STREET, ALLEGAN, MI., 49010, U.S.A.
TEL: +1-847-478-2500 FAX: +1-269-673-4092

Ohio CNC Service Satellite
62 W. 500 S., ANDERSON, IN., 46013, U.S.A.
TEL: +1-847-478-2608 FAX: +1-847-478-2690

Texas CNC Service Satellite
1000, NOLEN DRIVE SUITE 200, GRAPEVINE, TX. 76051, U.S.A.
TEL: +1-817-251-7468 FAX: +1-817-416-1439

Canada CNC Service Center
4299 14TH AVENUE MARKHAM, ON. L3R 0J2, CANADA
TEL: +1-905-475-7728 FAX: +1-905-475-7935

Mexico CNC Service Center
MARIANO ESCOBEDO 69 TLALNEPANTLA, 54030 EDO. DE MEXICO
TEL: +52-55-9171-7662 FAX: +52-55-9171-7698

Monterrey CNC Service Satellite
ARGENTINA 3900, FRACC. LAS TORRES, MONTERREY, N.L., 64720, MEXICO
TEL: +52-81-8365-4171 FAX: +52-81-8365-4171

Brazil MITSUBISHI CNC Agent Service Center (AUTOMOTION IND. COM. IMP. E EXP. LTDA.)
ACESSO JOSE SARTORELLI, KM 2.1 18550-000 BOITUVA – SP, BRAZIL
TEL: +55-15-3363-9900 FAX: +55-15-3363-9911

European FA Center (MITSUBISHI ELECTRIC EUROPE B.V.)

Germany CNC Service Center
GOTHAER STRASSE 8, 40880 RATINGEN, GERMANY
TEL: +49-2102-486-0 FAX: +49-2102486-591

South Germany CNC Service Center
KURZE STRASSE. 40, 70794 FILDERSSTADT-BONLANDEN, GERMANY
TEL: +49-711-3270-010 FAX: +49-711-3270-0141

France CNC Service Center
25, BOULEVARD DES BOUVETS, 92741 NANTERRE CEDEX FRANCE
TEL: +33-1-41-02-83-13 FAX: +33-1-49-01-07-25

Lyon CNC Service Satellite

U.K CNC Service Center
TRAVELLERS LANE, HATFIELD, HERTFORDSHIRE, AL10 8XB, U.K.
TEL: +44-1707-282-846 FAX: +44-1707-278-992

Italy CNC Service Center
ZONA INDUSTRIALE VIA ARCHIMEDE 35 20041 AGRATE BRIANZA, MILANO ITALY
TEL: +39-039-60531-342 FAX: +39-039-6053-206

Spain CNC Service Satellite
CTRA. DE RUBI, 76-80 -APDO. 420 08190 SAINT CUGAT DEL VALLES, BARCELONA SPAIN
TEL: +34-935-65-2236 FAX:

Turkey MITSUBISHI CNC Agent Service Center (GENEL TEKNİK SİSTEMLER LTD. STI.)
DARULACEZE CAD. FAMAS IS MERKEZI A BLOK NO.43 KAT2 80270 OKMEYDANI ISTANBUL, TURKEY
TEL: +90-212-320-1640 FAX: +90-212-320-1649

Poland MITSUBISHI CNC Agent Service Center (MPL Technology Sp. z. o. o.)
UL SŁICZNA 34, 31-444 KRAKOW, POLAND
TEL: +48-12-632-28-85 FAX:

Wrocław MITSUBISHI CNC Agent Service Satellite (MPL Technology Sp. z. o. o.)
UL KOBIERZYCKA 23, 52-315 WROCLAW, POLAND
TEL: +48-71-333-77-53 FAX: +48-71-333-77-53

Czech MITSUBISHI CNC Agent Service Center (AUTOCONT CONTROL SYSTEM S.R.O.)
NEMOCNICNI 12, 702 00 OSTRAVA 2 CZECH REPUBLIC
TEL: +420-596-152-426 FAX: +420-596-152-112

ASEAN FA Center (MITSUBISHI ELECTRIC ASIA PTE. LTD.)

Singapore CNC Service Center
307 ALEXANDRA ROAD #05-01/02 MITSUBISHI ELECTRIC BUILDING SINGAPORE 159943
TEL: +65-6473-2308 FAX: +65-6476-7439

Thailand MITSUBISHI CNC Agent Service Center (F. A. TECH CO., LTD)
898/19,20,21,22 S.V. CITY BUILDING OFFICE TOWER 1 FLOOR 12,14 RAMA III RD BANGPONGPANG, YANNAWA, BANGKOK 10120. THAILAND
TEL: +66-2-682-6522 FAX: +66-2-682-6020

Malaysia MITSUBISHI CNC Agent Service Center (FLEXIBLE AUTOMATION SYSTEM SDN. BHD.)
60, JALAN USJ 10/1B UEP SUBANG JAYA SELANGOR DARUL EHSAN MALAYSIA
TEL: +60-3-5631-7605 FAX: +60-3-5631-7636

JOHOR MITSUBISHI CNC Agent Service Satellite (FLEXIBLE AUTOMATION SYSTEM SDN. BHD.)
NO. 16, JALAN SHAHBANDAR 1, TAMAN UNGKU TUN AMINAH, 81300 SKUDAI, JOHOR MALAYSIA
TEL: +60-7-557-8218 FAX: +60-7-557-3404

Indonesia MITSUBISHI CNC Agent Service Center (PT. AUTOTEKNINDO SUMBER MAKMUR)
WISMA NUSANTARA 14TH FLOOR JL. M.H. THAMRIN 59, JAKARTA 10350 INDONESIA
TEL: +62-21-3917-144 FAX: +62-21-3917-164

India MITSUBISHI CNC Agent Service Center (MESSUNG SALES & SERVICES PVT. LTD.)
B-36FF, PAVANA INDUSTRIAL PREMISES M.I.D.C., BHOASRI PUNE 411026, INDIA
TEL: +91-20-2711-9484 FAX: +91-20-2712-8115

BANGALORE MITSUBISHI CNC Agent Service Satellite (MESSUNG SALES & SERVICES PVT. LTD.)
S 615, 6TH FLOOR, MANIPAL CENTER, BANGALORE 560001, INDIA
TEL: +91-80-509-2119 FAX: +91-80-532-0480

Delhi MITSUBISHI CNC Agent Parts Center (MESSUNG SALES & SERVICES PVT. LTD.)
1197, SECTOR 15 PART-2, OFF DELHI-JAIPUR HIGHWAY BEHIND 32ND MILESTONE GURGAON 122001, INDIA
TEL: +91-98-1024-8895 FAX:

Philippines MITSUBISHI CNC Agent Service Center (FLEXIBLE AUTOMATION SYSTEM CORPORATION)
UNIT No.411, ALABAMG CORPORATE CENTER KM 25, WEST SERVICE ROAD SOUTH SUPERHIGHWAY, ALABAMG MUNTINLUPA METRO MANILA, PHILIPPINES 1771
TEL: +63-2-807-2416 FAX: +63-2-807-2417

Vietnam MITSUBISHI CNC Agent Service Center (SA GIANG TECHNO CO., LTD)
47-49 HOANG SA ST. DAKAO WARD, DIST.1 HO CHI MINH CITY, VIETNAM
TEL: +84-8-910-4763 FAX: +84-8-910-2593

China FA Center (MITSUBISHI ELECTRIC AUTOMATION (SHANGHAI) LTD.)

China CNC Service Center
2/F, BLOCK 5 BLDG.AUTOMATION INSTRUMENTATION PLAZA, 103 CAOBAO RD. SHANGHAI 200233, CHINA
TEL: +86-21-6120-0808 FAX: +86-21-6494-0178

Shenyang CNC Service Center
TEL: +86-24-2397-0184 FAX: +86-24-2397-0185

Beijing CNC Service Satellite
9/F, OFFICE TOWER1, HENDERSON CENTER, 18 JIANGUOMENNEI DAJIE, DONGCHENG DISTRICT, BEIJING 100005, CHINA
TEL: +86-10-6518-8830 FAX: +86-10-6518-8030

China MITSUBISHI CNC Agent Service Center (BEIJING JIAYOU HIGHTECH TECHNOLOGY DEVELOPMENT CO.)
RM 709, HIGH TECHNOLOGY BUILDING NO.229 NORTH SI HUAN ZHONG ROAD, HAIDIAN DISTRICT, BEIJING 100083, CHINA
TEL: +86-10-8268-3030 FAX: +86-10-6518-8030

Tianjin CNC Service Satellite
RM909, TAIHONG TOWER, NO220 SHIZILIN STREET, HEBEI DISTRICT, TIANJIN, CHINA 300143
TEL: +86-22-2653-9090 FAX: +86-22-2635-9050

Shenzhen CNC Service Satellite
RM02, UNIT A, 13/F, TIANAN NATIONAL TOWER, RENMING SOUTH ROAD, SHENZHEN, CHINA 518005
TEL: +86-755-2515-6691 FAX: +86-755-8218-4776

Changchun Service Satellite
TEL: +86-431-50214546 FAX: +86-431-5021690

Hong Kong CNC Service Center
UNIT A, 25/F RYODEN INDUSTRIAL CENTRE, 26-38 TA CHUEN PING STREET, KWAI CHUNG, NEW TERRITORIES, HONG KONG
TEL: +852-2619-8588 FAX: +852-2784-1323

Taiwan FA Center (MITSUBISHI ELECTRIC TAIWAN CO., LTD.)

Taichung CNC Service Center
NO.8-1, GONG YEH 16TH RD., TAICHUNG INDUSTRIAL PARK TAICHUNG CITY, TAIWAN R.O.C.
TEL: +886-4-2359-0688 FAX: +886-4-2359-0689

Taipei CNC Service Satellite
TEL: +886-4-2359-0688 FAX: +886-4-2359-0689

Tainan CNC Service Satellite
TEL: +886-4-2359-0688 FAX: +886-4-2359-0689

Korean FA Center (MITSUBISHI ELECTRIC AUTOMATION KOREA CO., LTD.)

Korea CNC Service Center
DONGSEO GAME CHANNEL BLDG. 2F. 660-11, DEUNGCHON-DONG KANGSEO-KU SEOUL, 157-030 KOREA
TEL: +82-2-3660-9607 FAX: +82-2-3663-0475

Notice

Every effort has been made to keep up with software and hardware revisions in the contents described in this manual. However, please understand that in some unavoidable cases simultaneous revision is not possible.

Please contact your Mitsubishi Electric dealer with any questions or comments regarding the use of this product.

Duplication Prohibited

This manual may not be reproduced in any form, in part or in whole, without written permission from Mitsubishi Electric Corporation.

© 2006 MITSUBISHI ELECTRIC CORPORATION
ALL RIGHTS RESERVED.



MODEL	EZMotion-NC E60/E68 Series
MODEL CODE	008-401
Manual No.	IB-1500175(ENG)-A

Specifications subject to change without notice.
Printed in Japan on recycled paper.