

Thank you for choosing Mitsubishi Electric inverter. This Inverter Safety Guideline provides handling information and precautions for use of this product. Do not use this product until you have full knowledge of the product mechanism, safety information and instructions. Please forward this Safety Guideline to the end user.

INVERTER

E800-SCE

INVERTER SAFETY GUIDELINE

FR-E820-0008(0.1K) to 0900(22K)SCE
 FR-E840-0016(0.4K) to 0440(22K)SCE
 FR-E820S-0008(0.1K) to 0110(2.2K)SCE
 FR-E810W-0008(0.1K) to 0050(0.75K)SCE

For more information on the product



IB-0600921ENG-G(2312)MEE
 Specifications subject to change without notice.

MITSUBISHI ELECTRIC CORPORATION
 HEAD OFFICE: TOKYO BUILDING 2-3-3, MARUNOUCHI, CHYUO-KU, TOKYO 100-8510, JAPAN

◆ **Related manuals**

Manual name	Manual number	Details
FR-E800 Instruction Manual (Connection)	IB-0600865ENG	Manuals describing installation, wiring, specifications, outline dimensions, standards, and how to connect options.
FR-E800 Instruction Manual (Function)	IB-0600868ENG	Manual describing details of the functions.
FR-E800 Instruction Manual (Communication)	IB-0600871ENG	Manual describing details of the communications.
FR-E800 Instruction Manual (Maintenance)	IB-0600874ENG	Manual describing how to identify causes of faults and warnings.
FR-E800-SCE Instruction Manual (Functional Safety)	BCN-A23489-004	Manual describing details of the safety communication parameters.
FR Configurator2 Instruction Manual	IB-0600516ENG	Manual describing details of the software used to set inverter parameters using a personal computer.
PLC Function Programming Manual	IB-0600492ENG	Manual describing details of the PLC function.

Do not attempt to install, operate, maintain or inspect this product until you have read through this Safety Guideline and supplementary documents carefully to use the equipment correctly. Do not use the product until you have full knowledge of the product mechanism, safety information and instructions.

Installation, operation, maintenance and inspection must be performed by qualified personnel. Here, qualified personnel means a person who meets all the following conditions:

- A person who possesses a certification in regard with electric appliances handling, or person took a proper engineering training. Such training may be available at your local Mitsubishi Electric office. Contact your local sales office for schedules and locations.
- A person who can access operating manuals for the protective devices (for example, light curtain) connected to the safety control system, or a person who has read these manuals thoroughly and familiarized themselves with the protective devices.

In this Safety Guideline, the safety instruction levels are classified into "WARNING" and "CAUTION".

WARNING Incorrect handling may cause hazardous conditions, resulting in death or severe injury.

CAUTION Incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause only material damage.

Note that even the **CAUTION** level may lead to a serious consequence depending on conditions. Be sure to follow the instructions of both levels as they are critical to personnel safety.

Read this Guideline before use. In addition, scan the 2D code below to download the FR-E800 Instruction Manual (Connection) and read "Safety Instructions". The PDF manual can also be downloaded from the Mitsubishi Electric FA Global Website.



For more information on the product



1 INVERTER INSTALLATION AND PRECAUTIONS

When installing the inverter on the enclosure surface, remove the front cover and wiring cover to fit the inverter.

- Install the inverter on a strong surface securely with screws.
- Leave enough clearances and take cooling measures.
- Avoid places where the inverter is subjected to direct sunlight, high temperature and high humidity.
- Install the inverter on a nonflammable wall surface.
- When tightening screws into the upper mounting holes, tilt the screwdriver seven to ten degrees (FR-E820-0050(0.75K) or lower, FR-E820S-0030(0.4K) or lower, FR-E810W-0030(0.4K) or lower).



2 INSTALLATION AND WIRING

2.1 Removal and reinstallation of covers

◆ **Removal of the front cover**

(a) Loosen the mounting screws of the cover. (These screws cannot be removed.)

(b) Pull out the cover using its lower side as a support.

With the cover removed, the control circuit terminals can be wired and the plug-in option can be installed.

◆ **Reinstallation of the front cover**

(a) Check the position of the hooks on the rear of the cover.

(b) Insert the hooks of the cover into the sockets of the wiring cover, and reinstall the cover to the inverter.

(c) Tighten the mounting screw of the front cover. (Tightening torque: 0.6 to 0.8 N·m)

◆ **Removal of the lower front cover (FR-E820-0240(5.5K) or higher, FR-E840-0230(11K) or higher)**

(a) Loosen the screws on the lower front cover. (These screws cannot be removed.)

(b) While holding the areas around the installation hooks on the sides of the lower front cover, pull out the cover using its upper side as a support.

(c) With the lower front cover removed, wiring of the main circuit terminals and control circuit terminals can be performed.

◆ **Reinstallation of the lower front cover (FR-E820-0240(5.5K) or higher, FR-E840-0230(11K) or higher)**

(a) Install the lower front cover by inserting the upper hooks into the sockets on the inverter.

(b) Tighten the screws on the lower part of the lower front cover.

◆ **Removal of the wiring cover (FR-E820-0050(0.75K) or lower, FR-E820S-0030(0.4K) or lower, FR-E810W-0030(0.4K) or lower)**

Pull out the cover along the guides in the direction shown by the arrow in the figure above.

◆ **Reinstallation of the wiring cover (FR-E820-0050(0.75K) or lower, FR-E820S-0030(0.4K) or lower, FR-E810W-0030(0.4K) or lower)**

Fit the cover to the inverter along the guides.

◆ **Removal of the wiring cover (FR-E820-0080(1.5K) to FR-E820-0175(3.7K), FR-E840-0016(0.4K) to FR-E840-0095(3.7K), FR-E820S-0050(0.75K) or higher, FR-E810W-0.75K(0050))**

(a) Insert a tool such as a flathead screwdriver into the half-hole above the "PUSH" mark on the wiring cover to push the stopper behind the wiring cover approx. 3 mm.

(b) Pull out the cover along the guides in the direction shown by the arrow in the figure above.

◆ **Reinstallation of the wiring cover (FR-E820-0080(1.5K) to FR-E820-0175(3.7K), FR-E840-0016(0.4K) to FR-E840-0095(3.7K), FR-E820S-0050(0.75K) or higher, FR-E810W-0.75K(0050))**

Fit the cover to the inverter along the guides, and push the hook into the socket.

◆ **Removal of the wiring cover (FR-E820-0240(5.5K) to 0600(15K), FR-E840-0230(11K), 0300(15K))**

(a) Insert a tool such as a flathead screwdriver into the half-hole above the "PUSH" mark on the wiring cover to push the stopper behind the wiring cover approx. 3 mm.

(b) Pull out the cover along the guides in the direction shown by the arrow in the figure above.

◆ **Reinstallation of the wiring cover (FR-E820-0240(5.5K) to 0600(15K), FR-E840-0230(11K), 0300(15K))**

Fit the cover to the inverter along the guides.

◆ **Removal of the wiring cover (FR-E840-0120(5.5K), 0170(7.5K))**

(a) Insert a tool such as a flathead screwdriver into the half-hole above the "PUSH" mark on the wiring cover to push the stopper behind the wiring cover approx. 3 mm.

(b) Pull out the cover along the guides in the direction shown by the arrow in the figure above.

◆ **Reinstallation of the wiring cover (FR-E840-0120(5.5K), 0170(7.5K))**

Fit the cover to the inverter along the guides.

◆ **Removal of the wiring cover (FR-E820-0760(18.5K), 0900(22K), FR-E840-0380(18.5K), 0440(22K))**

(a) Remove the mounting screws of the wiring cover.

(b) Pull out the cover along the guides in the direction shown by the arrow in the figure above.

◆ **Reinstallation of the wiring cover (FR-E820-0760(18.5K), 0900(22K), FR-E840-0380(18.5K), 0440(22K))**

(a) Fit the cover to the inverter along the guides.

(b) Tighten the mounting screws of the wiring cover (tightening torque: 0.6 to 0.8 N·m).

2.2 Main circuit terminal layout and wiring to power supply and motor

◆ **Three-phase 200/400 V class**

◆ **Single-phase 200 V class / Single-phase 100 V class**

◆ **Single-phase 200 V class / Single-phase 100 V class**

◆ **Removal of the wiring cover (FR-E820S-0008(0.1K) to 0030(0.4K))**

◆ **Reinstallation of the wiring cover (FR-E820S-0008(0.1K) to 0030(0.4K))**

◆ **Removal of the wiring cover (FR-E810W-0008(0.1K) to 0030(0.4K))**

◆ **Reinstallation of the wiring cover (FR-E810W-0008(0.1K) to 0030(0.4K))**

◆ **Removal of the wiring cover (FR-E820-0240(5.5K) to 0600(15K), FR-E840-0230(11K), 0300(15K))**

◆ **Reinstallation of the wiring cover (FR-E820-0240(5.5K) to 0600(15K), FR-E840-0230(11K), 0300(15K))**

◆ **Removal of the wiring cover (FR-E820-0240(5.5K) to 0600(15K), FR-E840-0230(11K), 0300(15K))**

◆ **Reinstallation of the wiring cover (FR-E820-0240(5.5K) to 0600(15K), FR-E840-0230(11K), 0300(15K))**

2.3 **Recommended cables and wiring length**

Select cables of recommended gauge size to ensure that the voltage drop will be 2% or less. If the wiring distance is long between the inverter and motor, the voltage drop in the main circuit will cause the motor torque to decrease especially at a low speed. The following table shows the recommended cable size for cables that are 20 m in length at the ND rating. When using the inverter with the LD rating, refer to the FR-E800 Instruction Manual (Connection).

Applicable Inverter model	Terminal screw size +4	Tightening torque N·m	Crimp terminal			Cable gauge					
			R/L1, S/L2, T/L3 +5	U, V, W	Earthing (grounding) cable	HIV cables, etc. (mm ²) ±1	AWG ±2	PVC cables, etc. (mm ²) ±3			
FR-E820-0008(0.1K) to 0050(0.75K)	M3.5	1.2	2-3.5	2-3.5	2	2	14	14	2.5	2.5	2.5
FR-E820-0080(1.5K), 0110(2.2K)	M4	1.5	2-4	2-4	2	2	14	14	2.5	2.5	2.5
FR-E820-0175(3.7K)	M4	1.5	5-5.4	5-5.4	3.5	3.5	12	12	4	4	4
FR-E820-0240(5.5K)	M5	2.5	5-5.5	5-5.5	5.5	5.5	10	10	6	6	6
FR-E820-0300(7.5K)	M5	2.5	14-5	14-5	14	14	8	8	16	10	6
FR-E820-0470(11K)	M5	2.5	14-5	14-5	14	14	8	8	16	16	16
FR-E820-0600(15K)	M6(M5)	4.4	22-6	22-6	22	22	14	4	25	25	16
FR-E820-0760(18.5K)	M8(M6)	7.8	38-8	38-8	38	38	22	2	35	25	25
FR-E820-0900(22K)	M8(M6)	7.8	38-8	38-8	38	38	22	2	35	35	25
FR-E840-0016(0.4K) to 0095(3.7K)	M4	1.5	2-4	2-4	2	2	14	14	2.5	2.5	2.5
FR-E840-0120(5.5K)	M4	1.5	5-5.4	5-5.4	3.5	3.5	12	12	4	4	4
FR-E840-0170(7.5K)	M4	1.5	5-5.4	5-5.4	3.5	3.5	12	12	4	4	4
FR-E840-0230(11K)	M4	1.5	5-5.4	5-5.4	3.5	3.5	10	10	6	6	10
FR-E840-0300(15K)	M5	2.5	8-5	8-5	8	8	5.5	8	8	10	10
FR-E840-0380(18.5K)	M6	4.4	14-6	14-6	14	14	8	8	16	10	16
FR-E840-0440(22K)	M6	4.4	14-6	14-6	14	14	8	8	16	16	16
FR-E820S-0008(0.1K) to 0030(0.4K)	M3.5	1.2	2-3.5	2-3.5	2	2	14	14	2.5	2.5	2.5
FR-E820S-0050(0.75K)	M4	1.5	2-4	2-4	2	2	14	14	2.5	2.5	2.5
FR-E820S-0102(2K)	M4	1.5	5-4	5-4	3.5	3.5	12	12	4	4	4
FR-E810W-0008(0.1K) to 0030(0.4K)	M3.5	1.2	2-3.5	2-3.5	2	2	14	14	2.5	2.5	2.5
FR-E810W-0050(0.75K)	M4	1.5	5-5.4	5-5.4	3.5	3.5	12	14	2.5	2.5	2.5

- HIV cable (600 V grade heat-resistant PVC insulated wire) with a continuous maximum permissible temperature of 75°C. It is assumed that the cables will be used in a surrounding temperature of 50°C and the wiring distance is 20 m or shorter.
- THWV cable with a continuous maximum permissible temperature of 75°C. It is assumed that the cables will be used in a surrounding air temperature of 40°C or less and the wiring distance of 20 m or shorter. (For use in the United States or Canada, refer to the section "2" instructions for UL and IEC.)
- PVC cable with a continuous maximum permissible temperature of 70°C. It is assumed that the cables will be used in a surrounding air temperature of 40°C or less and the wiring distance of 20 m or shorter (selection example mainly for use in Europe).
- The screw size for terminals R/L1, S/L2, T/L3, U, V, W, PR, N, and P1, and the earthing (grounding) terminal is shown. For the single-phase 200 V power input models, the screw size for terminals R/L1, S/L2, U, V, W, PR, N, and P1, and the earthing (grounding) terminal is shown. For the single-phase 100 V power input models, the screw size for terminals R/L1, S/L2, U, V, W, PR, N, and P1, and the earthing (grounding) terminal is shown. The screw size for the earthing (grounding) terminal on FR-E820-0600(15K) to FR-E820-0900(22K) is indicated in parentheses. When using a single-phase power input model, terminals are R/L1 and S/L2.

The line voltage drop can be calculated by the following formula:
 Line voltage drop [V] = $\sqrt{3} \times \text{wire resistance} [\text{m}\Omega/\text{m}] \times \text{wiring distance} [\text{m}] \times \text{current} [\text{A}] / 1000$
 Use a larger diameter cable when the wiring distance is long or when the voltage drop (torque reduction) in the low speed range needs to be reduced.

◆ **Total wiring length**
 Connect one or more motors within the total wiring length (sum of the wiring lengths of the motor and the inverter) shown in the following table.

Cable type	Carrier frequency	Voltage class	0.1K	0.2K	0.4K	0.75K	1.5K	2.2K	3.7K or higher
Shielded-1	1 (1 kHz) or lower	100 V, 200 V	50 m (200 m)	50 m (200 m)	75 m (300 m)	100 m (500 m)	100 m (500 m)	100 m (500 m)	100 m (500 m)
	2 (2 kHz) or higher	100 V, 200 V	10 m (30 m)	25 m (100 m)	50 m (200 m)	75 m (300 m)	100 m (500 m)	100 m (500 m)	100 m (500 m)
		400 V	—	—	10 m (30 m)	25 m (100 m)	50 m (200 m)	75 m (300 m)	100 m (500 m)

¹ The value in the parentheses is the total wiring length when unshielded cables are used.

When driving a 400 V class motor by the inverter, surge voltages attributable to the wiring constants may occur at the motor terminals, deteriorating the insulation of the motor. In this case, use a 400 V class inverter-driven insulation-enhanced motor* and set Pr.72 PWM frequency selection according to the wiring length. *1.5 kHz or less" when the wiring length is 50 m or shorter, "8 kHz or less" when the wiring length is from 50 m to 100 m, or "2 kHz or less" when the wiring length is longer than 100 m.

2.4 Terminal connection diagram

◆ **Main circuit**

◆ **Control circuit**

◆ **Frequency setting signals (Analog)**

◆ **Safety communication function selection**

◆ **Option connector**

2.5 Details on the main circuit terminals and the control circuit terminals

Type	Terminal symbol	Common	Terminal name	Terminal function description
Main circuit	R/L1, S/L2, T/L3 ¹	—	AC power input	Connected to the commercial power supply.
	U, V, W	—	Inverter output	Connected to a three-phase squirrel cage motor or a FM motor.
	P/+	PR	Brake resistor connection	Connect an optional brake transistor (MRS, MYS, FR-ABR) between terminal P/+ and PR. (Not available for FR-E820-0008(0.1K), FR-E820-0015(0.2K), FR-E820S-0008(0.1K), and FR-E820S-0015(0.2K).)
	P/+	N/-	Brake unit connection	Connect the brake unit (FR-BU, or BU) or the multifunction regenerative converter (FR-RC in power regeneration mode) to these terminals.
	P/+	P1/2	—	DC reactor connection
Input signal	—	—	Earth (ground)	For earthing (grounding) the inverter chassis. Be sure to earth (ground) the inverter.
	10	5	Frequency setting (voltage)	Used as the power supply for an external frequency setting (speed setting) potentiometer.
	2	5	Frequency setting (voltage)	Inputting 0 to 5 VDC (or 0 to 10 VDC) provides the maximum output frequency at 5 V (or 10 V) and makes input and output proportional. This input signal is valid only when the AU signal is ON (terminal 2 is invalid). For current input, input resistance: 245 ± 5 Ω. Permissible maximum current: 30 mA.
	4	5	Frequency setting (current)	Inputting 4 to 20 mA DC (or 0 to 5 VDC, 0 to 10 VDC) provides the maximum output frequency at 20 mA and makes input and output proportional. This input signal is valid only when the AU signal is ON (terminal 2 is invalid). To use terminal 4 (current input at initial setting), assign "4" to Pr.178 to Pr.188 (input terminal function selection) before turning ON the AU signal. The initial setting varies depending on the specification.
	—	—	—	Use Pr.267 to switch among input 4 to 20 mA (initial setting), 0 to 5 VDC, and 0 to 10 VDC. Set the voltage/current input switch in the "V" position to select voltage input (0 to 5 V / 0 to 10 V).
Output signal	A, B, C	—	Relay output (fault output)	1 changeover contact output indicates that the inverter protective function has activated and the outputs are stopped. Fault: discontinuity across B and C (continuity across A and C). Normal: continuity across B and C (discontinuity across A and C).
	SX1	PC	Safety input (channel 1)	Input resistance: 4.7 kΩ, voltage when contacts are open: 21 to 26 VDC, current when contacts are short-circuited: 4 to 8 mA DC.
Safety input/output signal	SX2	PC	Safety input (channel 2)	Terminal functions can be selected using Pr.5851 SX1/SX2 terminal function selection. For details, refer to the FR-E800-SCE Instruction Manual (Functional Safety).
	SY1	SC1	Safety output (channel 1)	Permissible load: 24 VDC (27 VDC at maximum), 0.1 A (The voltage drop is 3.4 V at maximum while the signal is ON).
Common terminal	SD	—	24 VDC power supply common	Common output terminal for 24 VDC 0.1A power supply (terminal PC). Isolated from terminal 5.
	PC	SD	24 VDC power supply common	Common terminal for terminals SX1 and SX2.
	5	—	Frequency setting common	Can be used as a 24 VDC 0.1 A power supply.
	SC1	—	Safety output common (channel 1)	Common terminal for the frequency setting signal (terminal 2 or 4). Do not earth (ground).
Communication	—	—	Ethernet connector (2 ports) ³	Communication can be made via Ethernet. Category: 100BASE-TX/10BASE-T. Transmission method: Baseband. Data transmission speed: 100 Mbps (100BASE-TX) / 10 Mbps (10BASE-T). Maximum segment length: 100 m between the hub and the inverter interface. RJ45. Number of cascade connection stages: Up to 2 (100BASE-TX) / up to 4 (10BASE-T). Number of interfaces available: 2. IP version: IPv4.
	—	—	USB connector ⁴	By connecting an inverter to the personal computer through USB, FR Configurator2 can be used for setting the inverter and monitoring the operation. Interface: conforms to USB 1.1. Transmission speed: 12 Mbps. Connector: USB mini B connector (receptacle mini B type).

- Terminal T/L3 is not available for the single-phase power input models.
- Terminal P1 is not available for the single-phase 100 V power input models. Do not connect the parameter set. The inverter may be damaged.
- Terminal functions vary by Pr. 192 A, B, C terminal function selection.
- USB bus power connection is available. The maximum SCCR is 500 mA.

