

Introduction

Thank you for purchasing the Mitsubishi general-purpose MELSEC series sequencer.
Read this manual and make sure you understand the functions and performance of MELSEC series sequencer thoroughly in advance to ensure correct use.
Please make this manual available to the end user.

CONTENTS

Chapter 1 General Description		1- 1 to 1-14
1.1 Functions List	<List of menu which can be selected in GPPW categorized by circuit edit functions, comments and edit >	1- 3
1.2 Abbreviations and Terms in This Manual	1-11
1.3 FX Series Programming	1-12
1.4 Basic Key Specifications	<Instructions of the key used with the GPPW function>	1-14
Chapter 2 Menu Index		2- 1 to 2- 4
2.1 Menu Index	<Find GPPW menus in alphabetical order>.....	2- 1
Chapter 3 Common Operations		3- 1 to 3-18
3.1 List of Shortcut Keys and Access Keys	<Operating GPPW function by shortcut key>.....	3- 1
3.2 Project Designation	3- 5
3.2.1 Saving a project	<Save created programs in peripheral devices>.....	3- 6
3.2.2 Opening a project	<Read existing projects from peripheral device>.....	3- 9
3.3 Cut, Copy, and Paste	3-10
3.3.1 Cut and paste	3-10
3.3.2 Copy and paste	3-12
3.3.3 Notes on cutting, copying and pasting network parameters	3-14
3.4 Toolbar	<Descriptions of customized toolbar>.....	3-16
3.5 Status Bar	<Descriptions of items displayed on the status bar>	3-17
3.6 Zooming in on or out of the Edit Screen	3-18
3.7 Project Data List	3-18
Chapter 4 Initialization		4- 1 to 4- 2
4.1 Creating a Project	<Creating a new program>	4- 1
Chapter 5 Handling Project Files		5- 1 to 5-35
5.1 Opening the Existing Project File	<Read the created project>	5- 1
5.2 Closing a Project File	< Closing the active project>	5- 2
5.3 Saving a Project	< Saving the active project with the designated name>	5- 2
5.4 Saving a Project with a New Name	<Saving the active project with a new name >.....	5- 3
5.5 Deleting a Project	<Deleting the unnecessary project>	5- 3

5.6 Comparing Data in Projects	<Comparing the active data with the selected data> . 5- 4
5.7 Copying a Project	<Copying the selected data in the destination to the active data>..... 5- 6
5.8 Adding Data to a Project	<Adding comments to the active program> 5- 8
5.9 Copying Data within a Project	<Copying an opened project data> 5- 9
5.10 Deleting Data in a Project	<Deleting an opened project>..... 5-10
5.11 Renaming Data in a Project 5-11
5.12 Changing the PLC Type of a Project	<Changing a PLC type, such as ACPU to QnACPU>5-12
5.13 Reading GPPQ, GPPA, FXGP(DOS) or FXGP(WIN) Files	<Reading PPA/GPPQ/FXGP(DOS)/FXGP(WIN) data which is saved in a peripheral device>..... 5-18
5.14 Exporting GPPQ, GPPA, FXGP(DOS) or FXGP(WIN) Files	<Saving PLC program as GPPA/GPPQ/FXGP(DOS)/FXGP(WIN) format> 5-25
5.15 Displaying Macro References 5-32
5.16 Starting Multiple Projects	<Displaying Multiple GPPW>..... 5-35
5.17 Existing GPPW 5-35

Chapter 6 Creating Circuits

6- 1 to 6-73

6.1 Circuit Creation Method	<Describing the circuit creating methods from List Representation, Tool Button, Function Key and Menu Bar> 6- 1
6.2 Restrictions on Circuit Creation 6- 8
6.2.1 Restrictions in circuit display window 6- 8
6.2.2 Restrictions in circuit edit window 6- 9
6.3 Creating and Editing Circuits 6-13
6.3.1 Inputting contacts and application instructions 6-13
6.3.2 Inputting vertical and horizontal lines 6-22
6.3.3 Deleting incorrect inputs	<Deleting a contact and coil>..... 6-27
6.3.4 Deleting connecting lines	<Deleting vertical and horizontal lines> 6-29
6.3.5 Inserting and deleting in circuit blocks	<Inserting and deleting lines> 6-30
6.3.6 Modifying the existing circuit	<Modifying and overwriting a contact and coil> 6-32
6.3.7 Inserting into the existing circuit	<Adding a contact and coil to the existing circuit> 6-33
6.3.8 Undo the last operation	<Undo the cut, copy or paste operation> 6-34
6.3.9 Cutting, copying and pasting circuits	<Describing operations in units of coils and circuit blocks> 6-35
6.3.10 Inserting a line in the cursor-positioned location 6-43
6.3.11 Deleting a line at the cursor-position location 6-43
6.3.12 Inserting NOPs at a time 6-44
6.3.13 Deleting NOPs at a time 6-44
6.4 Find and Replace 6-45
6.4.1 Finding a device	<Finding a circuit by designating the device> 6-45
6.4.2 Finding an instruction	<Finding a circuit by designating an instructing and device> 6-47
6.4.3 Finding a step No.	<Finding a circuit by designating a circuit step No > 6-49
6.4.4 Finding a character string	<Finding a statement or note by designating character>..... 6-50
6.4.5 Replacing a device	<Replacing a designated device> 6-52

6.4.6	Replacing an instruction	<Replacing an instruction>	6-54
6.4.7	Changing A and B contacts	<Changing A contact to B contact and B contact to A contact>	6-56
6.4.8	Replacing a character string	<Replacing a character string by designating statement or note>	6-58
6.4.9	Changing the statement or note type	<Changing the integrated note to peripheral note>	6-60
6.4.10	Searching for a contact coil	<Indicating the steps and instructions in which the designated instruction has been used>	6-62
6.4.11	Searching for a device-use instruction	<Indicating the frequency of device usage>	6-64
6.5	Display	6-66
6.5.1	Displaying comments	<Displaying the circuit and device comments>	6-66
6.5.2	Displaying statements	<Displaying the circuit and statements>	6-67
6.5.3	Displaying notes	<Displaying the circuit and notes>	6-68
6.5.4	Displaying device names	<Displaying the circuit and device names >	6-69
6.5.5	Switching circuit and list modes	6-70
6.6	Switching Read and Write Modes	6-71
6.6.1	Switching to read mode	6-71
6.6.2	Switching to write mode	6-71
6.7	Changing T/C Setting Values	<Changing the values of timers and counters at a time>	6-72

Chapter 7 Creating Instruction List
--

7- 1 to 7-12

7.1	Common Notes on Instruction List Creation	7- 1
7.2	Creating a Program Instruction list	7- 3
7.2.1	Inputting a contact or application instruction.....	7- 3
7.2.2	Changing the existing program in overwrite mode	7- 4
7.2.3	Inserting or adding the existing program	7- 5
7.2.4	Deleting the existing program list	7- 6
7.2.5	Changing the existing program	7- 7
7.2.6	Inserting NOPs	7- 8
7.2.7	Deleting NOPs	7- 8
7.3	Find and Replace	7- 9
7.3.1	Finding a device	7- 9
7.3.2	Finding an instruction	7- 9
7.3.3	Finding a step No.	7- 9
7.3.4	Finding a character string	7- 9
7.3.5	Replacing a device	7- 9
7.3.6	Replacing an instruction	7- 9
7.3.7	Changing an A or B contact	7-10
7.3.8	Replacing a character string	7-10
7.3.9	Changing the statement or note type	7-10
7.3.10	Searching for a contact coil	7-10
7.3.11	Searching for an instruction using a device	7-10
7.4	Display	7-11
7.4.1	Displaying a device name	7-11
7.5	Switching Read and Write Modes	7-12
7.5.1	Switching to read mode	7-12
7.5.2	Switching to write mode	7-12
7.5.3	Switching to circuit mode	7-12
7.6	Changing T/C Setting Values	7-12

Chapter 8 Conversion	8- 1 to 8- 1
-----------------------------	---------------------

8.1 Converting an Edit Program	8- 1
8.2 Converting Multiple Edit Programs	8- 1

Chapter 9 Setting Device Comments	9- 1 to 9-37
--	---------------------

9.1 Points to be Noted before Comment Creation with GPPW	9- 1
9.1.1 Editing comments only on peripheral devices.....	9- 2
9.1.2 Writing to PLC	9- 4
9.1.2 (1) Writing to ACPU	9- 4
9.1.2 (2) Writing to QnACPU	9- 5
9.1.2 (3) Writing to FXCPU	9- 6
9.1.3 Writing GPPA and GPPQ files to peripheral devices.....	9- 7
9.1.3 (1) Writing a GPPA file	9- 7
9.1.3 (2) Writing a GPPQ file	9- 8
9.1.3 (3) Writing an FXGP(DOS) or FXGP(WIN) file.....	9- 9
9.2 Reading from PLC	9-10
9.2.1 Reading from ACPU	9-10
9.2.2 Reading from QnACPU	9-12
9.2.3 Reading from FXCPU	9-13
9.3 Reading GPPA and GPPQ Files from FD or HD.....	9-14
9.3.1 Reading a GPPA file	9-14
9.3.2 Reading a GPPQ file	9-16
9.3.3 Reading an FXGP(DOS) or FXGP(WIN) file	9-17
9.4 List of Device Comments	9-18
9.5 Common Comments and Comments by Program	9-21
9.6 Creating Device Comments	9-24
9.6.1 Creating device comments on the device comment edit window	9-24
9.6.2 Creating device comments for the created circuit	9-26
9.6.3 Creating device comments after creating a circuit.....	9-27
9.7 Deleting Device Comments	9-28
9.7.1 Deleting all device comments and device names	
<Clear all the comment edit window data>	9-28
9.7.2 Deleting display device comments and device names	
<Clear only the active device>	9-28
9.8 Setting Comment Types	
<Changing the common comments type and comments	
by program >.....	9-29
9.9 Setting Comment Ranges	
<Setting comment ranges when writing to PLC>.....	9-31
9.10 Finding and Replacing a Character String	9-36
9.10.1 Finding a character string	
<Finding the device comments by designating a character	
to be searched>	9-36
9.10.2 Replacing a character string	
<Replacing the device comment by designating character	
to be replaced>	9-37

Chapter 10 Setting Statements and Notes	10- 1 to 10-11
--	-----------------------

10.1 Statement	<Descriptions of integrated statement or peripheral statement>	10- 1
----------------------	--	-------

10.2 Note	<Descriptions of integrated statement or peripheral statement >	10- 3
10.3 Creating and Deleting Statements	10- 5
10.3.1(1) Creating statements in the circuit edit window	10- 5
10.3.1(2) Deleting statements in the circuit edit window	10- 6
10.3.2(1) Editing statements on the list edit window	10- 7
10.3.2(2) Deleting statements on the list edit window	10- 7
10.4 Creating and Deleting Notes	10- 8
10.4.1 (1) Creating notes on the circuit edit window	10- 8
10.4.1 (2) Deleting notes in the circuit edit window	10- 9
10.4.2 Creating notes in the list edit window	10-10
10.4.2 (1) Creating notes in the list edit window	10-10
10.4.2 (2) Deleting notes in the list edit window	10-11

Chapter 11 Setting Device Memory (DWR setting)	11- 1 to 11- 6
---	-----------------------

11.1 Device Memory	11- 1
11.2 Device Value Input	11- 2
11.3 All Clear	11- 4
11.3.1 Clearing all devices	11- 4
11.3.2 Clearing all display devices	11- 4
11.4 Making Fill Settings	<Changing the specified range part at a time to designated device value>	11- 5
11.5 Search and Replace	11- 6
11.5.1 Search	<Searching the device value by designating value>	11- 6
11.5.2 Replace	<Replacing the exsisting data to the designated value>	11- 6

Chapter 12 Setting Device Initialization Values	12- 1 to 12- 2
--	-----------------------

Chapter 13 Setting PLC Parameters	13- 1 to 13-39
--	-----------------------

13.1 Displaying the Parameter Setup Dialog Box	13- 1
13.2 Common Notes on Parameters	13- 3
13.3 Comparison Table of Setting Items	13- 5
• PLC Parameters (A Series)		
13.4 Setting the Memory Capacity	<Program capacity, Capacity for debugging, Comment, Expanded comment capacity, File register capacity and memory capacity information>	13- 6
13.5 Setting PLC RAS	<WDT setting, Operation mode when there is an error and Annunciator display mode>	13- 9
13.6 Setting the PLC System	<RUN-PAUSE contacts, System interrupt setting, Output mode during STOP to RUN>	13-10
13.7 Setting I/O Assignments	13-12
13.8 Setting Devices	<Setting latch ranges and timers/counters>	13-14
• PLC Parameters (QnA Series)		
13.9 Assigning PLC Names	<Assigns labels and comments to the PLC>	13-16

13.10	Setting the PLC System	<Timer limit setting, RUN-PAUSE contacts, Remote reset, Outputmode when changing from STOP to RUN, Common pointer NO., Ordinary data processing, Number of empty slots and system interrupt>	13-17
13.11	Setting PLC Files	13-19
13.12	Setting PLC RAS	<WDT setting, Error check, Operating mode when there is an error, Constant scanning, Annunciator display mode, Break down history and Low-speed program execution time>	13-22
13.13	Setting Devices	<Setting the number of points for each device, latch ranges and local devices>	13-24
13.14	Setting Programs	<Setting when two or more programs exist in the PLC>	13-26
13.15	Setting a Boot File	<Transferring a program from the IC memory card to the internal RAM in the PLC >	13-28
13.16	Setting SFC	<Setting the conditions for starting the SFC program>	13-30
13.17	Making I/O Assignments	13-31
	• PLC Parameters (FX Series)		
13.18	Setting the Memory Capacity	13-32
13.19	Setting Devices	13-34
13.20	Assigning PLC Names	13-35
13.21	Making I/O Assignments	13-36
13.22	Setting the PLC System (1)	13-37
13.23	Setting the PLC System (2)	13-38

Chapter 14 Setting Network Parameters

14- 1 to 14-73

	• Network Parameters (A Series)		
14.1	Setting the Network Screen	14- 5
14.2	Setting MELSECNET (II) Link Parameters	14- 7
14.2.1	Setting the refresh parameter	<Set when AnUCPU is selected>	14- 7
14.2.2	Setting the MELSECNET (II) network range	14- 9
14.3	Setting MELSECNET/10 Network Parameters.....		14-11
14.3.1	Setting the refresh parameter	14-11
14.3.2	Setting the MELSECNET/10 network range (common parameter).....		14-14
14.3.2 (1)	Setting the network range in the PLC to PLC network (administration station).....		14-14
14.3.2 (2)	Setting the network range (remote I/O setting)		14-19
14.3.3	Setting station-specific parameters	14-22
14.4	Common Operations in Setting Network Parameters	14-24
14.5	Making Settings for Data Links	14-26
14.6	Setting Routing Parameters	14-28
14.7	Setting MELSECNET/MINI Parameters	14-30	
	• Network Parameters (QnA Series)		
14.8	Setting the Network Setting Dialog Box	14-33
14.9	Setting the Refresh Parameter	14-35
14.10	Setting the MELSECNET (II) Network Range	14-37
14.11	Setting the MELSECNET/10 Network Range.....		14-40
14.11.1	Setting a network range in the PLC-to-PLC network		14-40

14.11.2	Setting a network range between the remote I/Os	14-45
14.11.2 (1)	Setting a network range in the remote master station.....	14-45
14.11.2 (2)	Setting a network range in the multiplex/parallel remote master station.....	14-50
14.11.2 (3)	Setting a multi-remote substation unit.....	14-53
14.11.2 (4)	Setting a parallel remote substation unit	14-54
14.11.2 (5)	Setting a standby station unit	14-55
14.11.3	Setting station-specific parameters	14-56
14.11.4	Setting routing parameters	14-58
14.12	Setting MELSECNET/mini Parameters	14-60
14.13	Setting CC-Link Parameters	14-63
14.14	Setting Ethernet Parameters	14-67
14.14.1	Setting the IP address	14-67
14.14.2	Setting the NET/10 routing information	
	<Communicating to other PLCs through MELSECNET/10>.....	14-68
14.14.3	Setting the FTP parameter	14-70
14.14.4	Setting the routing information	14-72

Chapter 15 Print

15- 1 to 15-30

15.1	Setting Up a Printer	15- 2
15.2	Setting a Page Layout	15- 4
15.3	Previewing a Print Image	15- 7
15.4	Printing	15- 9
15.5	Setting the Details for Printing	15-12
15.5.1	Creating a title	15-12
15.5.2	Setting a ladder print range	15-13
15.5.3	Setting a Instruction list print range	15-15
15.5.4	Setting a TC setting value print range	15-17
15.5.5	Setting a device comment print range	15-18
15.5.6	Setting a device use list print range	15-20
15.5.7	Setting a device memory print range	15-21
15.5.8	Setting a device initial value print range	15-22
15.5.9	Setting a PLC parameter print item	15-23
15.5.10	Setting a network parameter print item.....	15-24
15.5.11	Setting a list of contact coil used	15-25
15.5.12	Displaying a project contents list	15-26
15.6	Print Examples	15-27

Chapter 16 Other Functions

16- 1 to 16-29

16.1	Checking Programs	16- 1
16.2	Merging Programs	
	<Connecting several PLC programs to make a single program>.....	16- 3
16.3	Checking Parameters	16- 5
16.4	All-clearing the Parameters	16- 7
16.5	Transferring ROM Data	16- 8
	• "A" series program memory configuration	
	• Program memory configuration of the FX series	
16.5.1	ROM reading, writing, and verification	16-15

16.5.2 Writing to files in ROM format	<Saving in a peripheral device>.....	16-17
16.6 Customizing Keys	<Allocating function keys to GPPA/GPPQ format>	16-19
16.7 Setting Options	<Shift the program forward setting, write during run, buffer/link memory monitor, setting comment show number>	16-20
16.8 Displaying Multiple Windows	16-27
16.9 Opening a Specific Project Using a Shortcut	<Creating a shortcut key for a specific project>.....	16-28
16.10 Starting the Ladder Logic Test Tool	16-29
16.11 Outline of Help Function	16-29

Chapter 17 Connecting a PLC

17- 1 to 17-46

17.1 System Configuration when a PLC is Connected.....		17- 1
17.1.1(1) Connection from the serial port	<Connecting a peripheral devices to A series and QnA series CPU (about converter)>	17- 1
17.1.1(2) Connection from the serial port	<Connecting a peripheral devices to A series and QnA series CPU (about converter)>	17- 4
17.1.2 Connecting from an Interface Board for a Personal Computer	<An example of the system configuration of a MELSECNET/10 board>.....	17- 6
17.2 Specifying the Connection Destination•	<Setting connecting destination>•	17- 8
17.2.1 Setting method for communication via a MELSECNET/10 port		17-13
17.2.2 Setting method for communication via an Ethernet board.....		17-15
17.2.3 Setting method for communication via CC-Link (AJ65BT-G4)		17-18
17.2.3 (1) When using A series		17-18
17.2.3 (2) When using QnA series		17-20
17.2.4 Setting method for communication via a computer link module		17-22
17.2.5 Setting method for communication via a serial communication module.....		17-24
17.3 Using PLC Read/Write		17-26
17.3.1 Executing PLC read/PLC write	<Writing and reading of PLC programs>	17-26
17.3.2 Setting the read/write range for device data		17-30
17.3.3 Setting the program reading/writing range.....		17-32
17.3.4 Setting the comment read/write range		17-33
17.4 Verifying Data at the Peripheral Device and PLC.....		17-36
17.5 Deleting Data in the PLC		17-38
17.6 Changing PLC Data Attributes	<Protecting data in PLC>	17-40
17.7 Executing Online Change		17-43
17.7.1 Operating conditions when FXCPU is selected		17-45

Chapter 18 Monitoring

18- 1 to 18-29

18.1 Monitoring, and Stopping/Resuming Monitoring.....		18- 2
18.2 Monitoring/Stopping Monitoring in All Windows.....		18- 4
18.3 Editing Programs During Ladder Monitoring		18- 5
18.4 Switching Present Values Between Decimal and Hexadecimal		18- 7
18.5 Batch Monitoring Devices/Buffer Memories		18- 8
18.6 Monitoring after Registering Devices		18-12
18.7 Setting Monitor Conditions/Stop Conditions	<Start and stop monitor with set conditions>	18-15
18.8 Program List Monitor		18-17
18.9 Monitoring the Interrupt Program List		18-20

18.10 Measuring Scan Time	18-21
18.11 Executing Sampling Trace	18-22
18.11.1 Setting execution & status display	18-23
18.11.2 Setting trace data	18-26
18.11.3 Setting trace conditions	18-28

Chapter 19 Debugging Programs	19- 1 to 19-15
--------------------------------------	-----------------------

19.1 Carrying Out a Device Test	<Change the present value of the turns bit force ON/OFF and word device>	19- 2
19.2 Carrying Out Partial Operation	<Operate steps specified range and stop with set condition>	19- 4
19.3 Executing Step Run	<Executes the designated range by one instruction at a time>	19- 8
19.4 Setting the Scan Range	<Setting the partial operation or step operation of requirement>	19-11
19.5 Operating the PLC Remotely	<Changing PLC status from GPPW to STEP-RUN>	19-13

Chapter 20 Registering Entry Codes	20- 1 to 20- 5
---	-----------------------

20.1 Registering New Entry Codes/Changing Entry Codes	<Registering and changing an entry code for PLC>	20- 1
20.2 Canceling an Entry Code	<Canceling an entry code registered in PLC>	20- 4
20.3 Releasing an Entry Code	<Releasing an entry code registered in PLC>	20- 5

Chapter 21 PLC Memory	21- 1 to 21-11
------------------------------	-----------------------

21.1 Clearing the PLC Memory	21- 1	
21.1.1 All-clearing on ACPU memory	21- 1	
21.1.2 All-Clearing the QnACPU Device Memory	21- 3	
21.1.3 All-Clearing an FXCPU Memory	21- 5	
21.2 Formatting a QnACPU Memory	21- 7	
21.3 Sorting the QnACPU Memory	<Creating a free PLC memory area>	21- 9
21.4 Setting for the PLC's Clock	21-10	

Chapter 22 Diagnosis	22- 1 to 22-14
-----------------------------	-----------------------

22.1 Diagnosing the PLC	22- 1	
22.1.1 Diagnosing an ACPU	<Displaying the key status and fault history of PLC>	22- 1
22.1.2 Diagnosing a QnACPU	<Displaying the key status and fault history of PLC>	22- 3
22.1.3 Diagnosing an FXCPU	22- 5	
22.2 Diagnosing a Network	<MELSECNET(II,/10) network diagnosis>	22- 6
22.2.1 Monitoring other station information	22- 8	
22.2.2 Testing a network	22-10	
22.2.3 Performing a Setting Confirmation Test	22-11	
22.2.4 Performing a station order confirmation test	22-13	

Appendices	Appendix- 1 to Appendix-92
-------------------	-----------------------------------

Appendix 1 GGP Function Access Ranges in MELSECNET(II/10) Systems	Appendix- 1
1.1 Access Range with MELSECNET (II)	Appendix- 1

1.2 Access Range for an A Series Start	Appendix- 2
1.3 Access Range for a QnA Series Start	Appendix- 4
Appendix 2 MELSECNET (II/10) Board Access Range	Appendix- 7
2.1 MELSECNET/10 Board	Appendix- 7
2.1.1 "A" series start	Appendix- 8
2.1.2 QnA series start	Appendix-10
2.2 Access Range via an Ethernet Board	Appendix-12
2.3 Access Range via CC-Link (AJ65BT-G4)	Appendix-15
2.4 Access Range via C24, UC24	Appendix-17
2.5 Access Range via QC24	Appendix-19
Appendix 3 Using Data of Other Applications	Appendix-20
3.1 Using Excel Files as Device Comments	Appendix-20
3.2 Using a Word File as a Device Comment	Appendix-22
Appendix 4 Restrictions Depending on PLC Type Change	Appendix-24
4.1 A series - Changing to the A series	Appendix-24
4.2 Changing Between A Series and QnA Series.....	Appendix-26
4.3 FX Series Changing to the FX Series	Appendix-28
4.4 A Series Changing to FX Series	Appendix-30
Appendix 5 RS-232C cable setting method to C24, UC24, and QC24	Appendix-31
5.1 RS-232C cable setting method to C24 and UC24	Appendix-31
5.2 RS-232C cable setting method to QC24	Appendix-33
Appendix 6 ROM Writer Wiring Examples	Appendix-35
Appendix 7 QnA Series Version Compatibility Table.....	Appendix-36
Appendix 8 Restrictions and Cautions	Appendix-37
Appendix 9 Compatibility of Japanese version,English version.....	Appendix-45
Appendix 10 GPPW and LLT Operations	Appendix-46
Appendix 11 Notes on FX Series Programming	Appendix-47
11.1 Ladder Monitor Display	Appendix-47
11.2 Handling of Comments	Appendix-50
Appendix 12 Instruction Conversion Lists	Appendix-51
12.1 Instruction Conversion List for A <-> QnA Conversions	Appendix-51
12.2 A Instruction Conversion List for FX Series Conversions	Appendix-80

10. SETTING STATEMENTS AND NOTES

Comments are added to make the sequence program easier to understand.
Note that the A series and the FX series do not have any integrated statement or integrated note function.

10.1 Statement

A	QnA	FX
•	•	•

This section describes the statements created by the A, QnA, and FX series. FXGP (DOS) and FXGP (WIN) call such statements "circuit statements".


	Number of Characters
Line statement	64 x n ² lines
Peripheral statement	64 x 1 line
Integrated statement	64 x 1 line

*1 : Each statement can be created within the range specified in the sequence program created.
 *2 : Each note can be created within the range specified in the sequence program created.

- **Integrated statement**
 Since character strings are controlled as part of the sequence program, writing and reading statements to/from the PLC is automatically set. However, the number of steps consumed will increase in proportion to the number of characters created. Any space inserted in character strings will be counted as one character.
 <Number of steps consumed>

$$\begin{matrix} \uparrow \\ \text{Fixed} \end{matrix} \frac{2+}{2} \frac{\text{Number of characters}}{2} \text{ steps (Round off decimals.)}$$

Example of display with integrated statements



- Peripheral statement
A peripheral statement is a character string controlled only by a peripheral device (it is writable and readable to/from the hard disk/floppy disk). When the sequence program is written to the PLC, "*" will be added to the steps with a statement.


[A series, FX series]

The steps of statements will not be consumed.
However, statements will not be written to the PLC.
Also, FX series P,I statement will not be written to FXGP(DOS) and FXGP(WIN).

[QnA series]

The number of steps consumed is 1, regardless of the number of characters.
However, statements will not be written to the PLC.



Example of displayed with peripheral statements



[Caution when reading statements from the PLC]

When overwriting a program without statements read from the PLC to the hard disk, the program stored in the hard disk will be overwritten by the program without statements. Before reading such a program, store the program (originally retained in the hard disk) in a floppy disk.

If any program is edited on a peripheral device and written during running, program mismatching may occur.



10.2 Note

A	QnA	FX
•	•	•

This section describes the notes created by the A, QnA, and FX series. Notes can be created for each coil and application instruction. However, if notes are written to a peripheral device in the form of an ACPU or GPPA file, only the first note of a single circuit block will be written. FXGP (DOS) and FXGP (WIN) call such notes as "coil comments."

	Number of Characters
Note	32 characters x 1 line *1

*1 : Each statement can be created within the range specified in the sequence program created.
 *2 : Each note can be created within the range specified in the sequence program created.


- Integrated note
 Since character strings are controlled as part of the sequence program, writing and reading notes to/from the PLC is automatically set. However, the number of steps consumed will increase in proportion to the number of characters created. Any space inserted in character strings will be counted as one character.

<Number of steps consumed>

$$\frac{\frac{2+}{\uparrow} \text{Number of characters}}{2} \text{ steps (Round off decimals.)}$$

Fixed

Example of display with integrated notes



- Peripheral note
A peripheral note is a character string controlled only by a peripheral device (it is writable and readable to/from the hard disk/floppy disk). When the sequence program is written to the PLC, "*" will be added to the steps with a statement.


[A series, FX series]

The steps of notes will not be consumed.
However, notes will not be written to the PLC.

[QnA series]

The number of steps consumed is 1, regardless of the number of characters.
However, notes will not be written to the PLC.



Example of display with peripheral notes



[Caution when reading notes from the PLC]

When overwriting a program without notes read from the PLC to the hard disk, the program stored in the hard disk will be overwritten by the program without notes. Before reading such a program, store the program, (originally retained on the hard disk) in a floppy disk.

If any program is edited on a peripheral device and written during running, program mismatching may occur.




10.3 Creating and Deleting Statements

10.3.1(1) Creating statements in the circuit edit window

A	QnA	FX
•	•	•

[Operating Procedure]

1. Enter **[Insert]** key to set the insert mode.
2. Move the cursor to the position shown in the following figure.



3. By entering a semicolon ";", the circuit input dialog box is displayed to enable the user to enter a statement.



To enter a P or I statement, enter a semicolon (;) after entering a P or I pointer.
(Example)

PI: P, I statement → **[ENTER]** key or **[OK]** key

↑
Enter a desired statement.

4. After entering the statement, press **[Enter]** key or click the **[OK]** button.


POINTS
<ul style="list-style-type: none"> • For switching integrated statements/peripheral statements on the QnA series, see Section 6.4.9. • For displaying statements created, see Section 6.5.2.

10.3.1(2) Deleting statements in the circuit edit window

A	QnA	FX
•	•	•

[Operating procedure]

1. Move the cursor to the statement to be deleted, and press **Delete** key.



2. After the statement has been deleted, convert the program.

10.3.2(1) Editing statements on the list edit window

A	QnA	FX
•	•	•

1. Move the cursor to the head of the position to which a statement will be added.
(Move the cursor to the head of the circuit block of a circuit.)
2. By entering a semicolon ";", the list input dialog box is displayed.



Pl: P, I statement → **ENTER** key or **OK** key

↑
Enter a desired statement.

3. Create a statement within up to 64 characters.
Up to 255 characters can be entered in the text box.

POINTS
<ul style="list-style-type: none"> • Statements will be displayed in the list mode at all times (it is impossible to not display statements). • For integrated statements and peripheral statements, see Section 10.1.

10.3.2(2) Deleting statements on the list edit window

A	QnA	FX
•	•	•

1. Move the cursor to the statement to be deleted.

```

.* Operation ready ladder
0 LD X1
1 MOV K0 K1M1
6 MOV K0 K4Y60
11 RST C1
14 LD X0
15 AND X4
16 AND X5
17 OR Y70
18 ANI X1
19 RC NO Y70
24 LD X2
25 MPS
26 ANI M1
27 ANI Y72
28 SET Y71
29 RPP
30 SET M1
31 LD Y71
32 ANI X2
33 OUT Y73
34 END
35
    
```

2. Press **Delete** key or **Shift** + **Delete** key.

```

.* Operation ready ladder
0 LD X1
1 MOV K0 K1M1
6 MOV K0 K4Y60
11 RST C1
14 LD X0
15 AND X4
16 AND X5
17 OR Y70
18 ANI X1
19 RC NO Y70
24 LD X2
25 MPS
26 ANI M1
27 ANI Y72
28 SET Y71
29 RPP
30 SET M1
31 LD Y71
32 ANI X2
33 OUT Y73
34 END
35
    
```

10.4 Creating and Deleting Notes


10.4.1 (1) Creating notes on the circuit edit window

A	QnA	FX
•	•	•

[Operating procedure]

1. Press **[Insert]** key to set the overwrite mode.
 Note that a circuit will be added by creating a note in the insert mode.

2. Move the cursor to the position shown in the following figure.



3. By pressing **[Enter]** key, the following dialog box is displayed.



4. Add a semicolon ";" after Y1, and enter a note.



5. After the note has been entered, press **[Enter]** key or click the **[OK]** button.


POINTS
<ul style="list-style-type: none"> • For switching integrated notes and peripheral notes on the QnA series, see Section 6.4.9. • For displaying notes created, see Section 6.5.3.

10.4.1 (2) Deleting notes in the circuit edit window

A	QnA	FX
•	•	•

[Operating procedure]

1. Press **[Insert]** key to set the overwrite mode.
2. Move the cursor to the note to be deleted, and press **[Enter]** key or double-click the **[mouse]** button.



3. Delete the statement Green lamp lights when operation preparations are completed. after the semicolon ";".



Delete this section.

4. After the statement has been deleted, press the **[Enter]** key or click the **[OK]** button.

10.4.2 Creating notes in the list edit window

10.4.2 (1) Creating notes in the list edit window

A	QnA	FX
•	•	•

[Operating procedure]

1. Move the cursor to the head of the position to which a note will be added.
(Move the cursor to the head of the circuit block of a circuit.)
2. By entering a semicolon ";", the list input dialog box appears.



3. Create a note within up to 64 characters.
Up to 255 characters can be entered in the text box.

POINTS

- Notes will be displayed in the list mode at all times (it is impossible to not display statements).
- For integrated notes and peripheral notes, see Section 10.2.

10.4.2 (2) Deleting notes in the list edit window

A	QnA	FX
•	•	•

[Operating Procedure]

1. Move the cursor to the note to be deleted.

```

* Operation ready ladder
0 LD X1
1 MOV ED K1M1
5 MOV ED K4Y60
11 RST C1
14 LD X0
15 AND X4
16 AND X5
17 OR Y70
18 ANI X1
19 MC NO Y70
24 LD X2
25 MPS
26 ANI M1
27 ANI Y72
28 SET Y71
29 MPP
30 SET M1
31 LD Y71
32 ANI X2
33 OUT Y73
34 END
35
    
```

2. Press **Delete** key or **Shift** + **Delete** key.

```

0 LD X1
1 MOV RO K1M1
0 MOV KO K4Y60
11 RST C1
14 LD X0
15 AND X4
16 AND X5
17 OR Y70
18 ANI X1
19 MC NO Y70
24 LD X2
25 MPS
26 ANI M1
27 ANI Y72
28 SET Y71
29 MPP
30 SET M1
31 LD Y71
32 ANI X2
    
```


11.2 Device Value Input

A	QnA	FX
•	•	•


[Purpose]

Changes word device data in batch.

[Operating Procedure]

Select [Project] → [Edit data] → [New], and set the data type (device memory), the name of the data to be added, and the comment.

[Dialog Box]



[Description]

1) Device name

The types of devices that can be edited are listed below:

A series

Device Name	Symbol
Timer	T
Counter	C
Retentive timer	ST
Data register	D
Special register	SD
Link register	W
File register	R

QnA series

Device Name	Symbol
Timer	T
Counter	C
Retentive timer	ST
Data register	D
Special register	SD
Link register	W
Link special register	SW
File register	R
Through file register	ZR
I/O No. setting	U**/G***
Link No. setting	J**/W***
	J**/SW***

FX series

Device Name	Symbol	FX ₀ FX _{0S}	FX _{0N}	FX ₁	FX, FX ₂ FX _{2C}	FX _{2N} FX _{2NC}
Data register	D	•	•	•	•	•
Special data register	D	•	•	•	•	•
File register	D	—	•	—	•	•
RAM file register	D	•	—	—	•	—

- Can be edited. — : No corresponding device.

- 2) **Display** button
Click this button after a device has been set.
- 3) Display switching
Switches the display form on the edit screen between decimal and hexadecimal.
- 4) Edit screen
Device values can be entered within the following ranges:

Display Form	Numeric Input Range
Decimal	-32768 to 32767
Hexadecimal	0000 to FFFF

POINTS

- When setting device memory in a peripheral device
Data can be edited or stored, irrespective of the parameter setting range.
- When writing data to the PLC
Data will be written within the parameter setting range.

11.3 All Clear

11.3.1 Clearing all devices

A	QnA	FX
•	•	•

[Purpose]

Clears all device values for which device memory is set.

[Operating Procedure]

Display the device memory edit window, and select [Edit] → [Clear all (all clear)].

11.3.2 Clearing all display devices

A	QnA	FX
•	•	•

[Purpose]

Clears device values displayed in the window, for which device memory is set.

[Operating Procedure]

Display the device memory edit window, and select [Edit] → [Clear all (displayed devices)].


11.4 Making Fill Settings

A	QnA	FX
•	•	•


[Purpose]

Writes the same data to consecutive devices in batch.

[Operating Procedure]

Display the device memory edit window, and select [Edit] → [FILL] or press .

[Dialog Box]



[Description]

- 1) FILL Range
Designates the devices to which the same data will be batch-written.
<Example of device designation>
D10-D20, T0-T30
- 2) FILL data
Designates the data to be batch-written.
Designate the data in the numeric form on the device memory edit window.
- 3) **OK** button
Click this button after the setting has been completed.

11.5 Search and Replace

11.5.1 Search

A	QnA	FX
•	•	•

[Purpose]

Searches the devices set.

[Operating Procedure]

Display the device memory edit window, and select [Find/Replace] → [Find data].

[Description]

For the description, see Section 6.4.

11.5.2 Replace

A	QnA	FX
•	•	•

[Purpose]

Replaces the set device data.

[Operating Procedure]

Display the device memory edit window, and select [Find/Replace] → [Replace data].

[Description]

For the description, see Section 6.4.

12 SETTING DEVICE INITIALIZATION VALUES

A	QnA	FX
x	•	x


[Purpose]

Sets a device range to treat the device values set on the device value input dialog box as the initial values when starting the PLC.

[Operating Procedure]

Set the type and name of the data to be added in the dialog box displayed by selecting [Project] → [Edit data] → [New].

[Dialog Box]



[Description]

- 1) Range to be set
Up to 8,000 points (8K words) can be set within a range.
Each comment can be set within 32 characters.

The devices, which can be treated as initial values, are listed below:

Device Name	Device
Timer	The present value of T.
Retentive Timer	The present value of ST.
Counter	The present value of C.
Data register	D
Special register	SD
Link register	W
Link special register	SW
File register	R, ZR
Special direct device	U*/G*
Link direct device	J*/W*, J*/SW*

- 2) Setting method
Set the range of the devices to be set for device initial values by specifying [Start/End] or [No. of point/start] Device
- 3) Device memory registration diversion
 Device memory diversion button
 All devices
 All of the devices or the device range edited in the device memory will be entered as device initial values.

 Range to be set
 Set a range to enter the data created in the device memory as device initial values.
 <Example>
 D0-D10, W0-W30

 Register to device memory button
 The data of the device initial values read from the PLC or peripheral device will be stored in the device memory.
- 4) OK button
Click this button after the setting has been completed.

POINT
<ul style="list-style-type: none"> • To treat each device value, to which the range is set, as an initial value when starting the PLC, use the PLC file setting function for PLC parameters.

13. Setting PLC Parameters

For each type of parameter, see the appropriate section listed below:

Parameter	Section
A series PLC parameter	Sections 13.4 to 13.8
QnA series PLC parameter	Sections 13.9 to 13.17
FX series PLC parameter	Sections 13.18 to 13.23
A series network parameter	Sections 14.1 to 14.7
QnA series network parameter	Sections 14.8 to 14.14.4

13.1 Displaying the Parameter Setup Dialog Box

A	QnA	FX
•	•	•

Parameters include PLC parameters and network parameters (the A series and the QnA series only).


Set the appropriate function and the device range to be set for the system used.

[How to display the Parameter Setup dialog box]


The Parameter Setup dialog box can be displayed in either of the following two ways:

(1) Displaying the dialog box from the project data list


1. Double-click [Parameter] on the project data list.



2. PLC Parameter and Network Parameter icons are displayed.




3. Double-click either icon, and the corresponding setup dialog box will open.
 - PLC Parameter Setup dialog box



- (2) Displaying the dialog box from the toolbar
 1. Click in the toolbar, then [Parameter].



Click here.




Click here.

2. Click the right, then [PLC parameter].



Click here.



Click here.


13.2 Common Notes on Parameters

A	QnA	FX
•	•	•

[Parameter display]

This part describes the setting item tabs and network parameter setting items.

<Example>



The meanings of the symbols are the same also when displayed with network parameters.

Red :The PLC does not operate until data is set. (Data is not set.)


Blue :Data is set.

Magenta :The PLC operates without setting data or with the default. (Data is set.)

Dark blue :Data is set. (Data is set.)

[Common notes on parameters]

This part describes the settings common to PLC and network parameters.




- 1) **Default** button
Returns all of the set items or values to the previous settings.
This button is available only for the currently open tab.
- 2) **Check** button
Used to check the set items or values to see if they are correct.
This button is available only for the currently open tab.
- 3) **End setup**
Defines the set items or values and terminates the setting.
- 4) **Cancel** button
Cancels the set items and terminates editing.

5) Acknowledge X/Y Assignment button

This button is available for the models A2ACPU(S1), A3ACPU, A2AS(S1), A2AS-S30, A2AS-S60, A2UCPU(S1), A2USCPU(S1), A2USHCPU(S1), A3UCPU, A4UCPU, and QnAXPU.

It is used to confirm the X/Y assignment numbers of the data set in the I/O assignment setting.



Display by type

Display	Description
I/O assignment	Displays I/O assignment information.
MINI	Displays I/O assignment information and MINI automatic refresh setting information.
CC-Link	Displays I/O assignment information and CC-Link automatic refresh setting information.
NET (II)	Master station : Displays I/O assignment information and refresh parameter information.
	Local station : Displays I/O assignment information and refresh parameter information.
NET/10	PLC-to-PLC network, remote I/O network : Displays network parameter information.

The priority of display is shown below:

1. I/O assignment (AnACPU, AnUCPU, QnA series)
2. Fourth MELSECNET network refresh parameter (AnUCPU, QnA series)
3. Third MELSECNET network refresh parameter (AnUCPU, QnA series)
4. Second MELSECNET network refresh parameter (AnUCPU, QnA series)
5. First MELSECNET network refresh parameter (AnUCPU, QnA series)
6. MELSECNET/MINI refresh (AnACPU, AnUCPU, QnA series)
7. CC-Link remote I/O (QnA series)

The Duplicate Error area displays the first duplicate item detected in checking the items according to the priority.

Duplicate Error	Description
First NET	First MELSECNET network parameter
Second NET	Second MELSECNET network parameter
Third NET	Third MELSECNET network parameter
Fourth NET	Fourth MELSECNET network parameter
MINI	MELSECNET/MINI refresh
CC-Link	CC-Link remote I/O

13.3 Comparison Table of Setting Items

A	QnA	FX
•	×	•

GPPA parameters and GPPW parameters use different setting locations and names. For the items required to be set, see the corresponding table shown below.

[PLC parameters]

GPPA		GPPW
Latch range setting		Device setting
I/O assignment		I/O assignment setting
Auxiliary setting	Step relay setting	Device setting
	Timer setting	Device setting
	Counter setting	Device setting
	RUN-PAUSE contact	PLC system setting
	STOP• RUN output mode	PLC system setting
	Interrupt counter	PLC system setting
	WDT setting	PLC RAS setting
	Operation mode when an error occurs	PLC RAS setting
	Annunciator display mode	PLC RAS setting
	Remote I/O remote terminal setting	PLC system setting
	General data processing	PLC system setting (data communication request batch processing)
MINI automatic refresh setting	Network parameter → MELSECNET/MINI setting	
Network/Link setting		Network parameter

FXGP (DOS) parameters, FXGP (WIN) parameters, and GPPW parameters use different setting locations and names. For the items required to be set, see the corresponding table shown below.

[PLC parameters]

FXGP (DOS)	FXGP (WIN)	GPPW
Latch range	Latch range	Device setting
Program title setting	Print title setting	PLC name setting
PLC mode setting	PLC mode setting	PLC system setting (1)
Serial communication setting	Serial communication setting	PLC system setting (2)
—	Device assignment	I/O assignment setting

PLC Parameters (A Series)

13.4 Setting the Memory Capacity

A	QnA	FX
•	×	×


[Purpose]

Sets the memory capacity to store programs, comments, extended comments, and file registers.

[Operating procedure]

Select [PLC parameter], and click the <<Memory capacity>> tab.

[Dialog Box]



[Description]

1) Program capacity

In the case of the model AnU, the network parameter setting capacity occupies the main program area. The available main program size is as shown below:

PLC Type	Available Main Program Size (Ksteps)
A2U	Max. 14
A3U, A4U, A2SH-S1	Max. 30 - (network parameter size* (Kbytes)+2)

The network parameter size is between 0 Kbytes and 16 Kbytes depending on the data to be set.

2) Capacity for debugging

(Applicable CPU : A0J2H, A1FX, A1S(S1), A1SJ, A1SH, A1SJH, A2C, A2CJ, A2N(S1), A2S(S1), A2SH(S1), A3N)

Set the sampling trace capacity.

The status latch will be displayed only when the debug size is set in the data read in a file in another format.

3) Comment

Set a comment in units of 1 Kbyte (0, 2 to 64 Kbytes).

The required number of bytes for the comment size can be calculated using the following expression:

$$\text{Required number of bytes} = \frac{\text{Number of comments}}{64} + 1 \text{ (Kbytes)}$$

4) Expanded comment

Set an extended comment in units of 2 Kbytes (0, 2 - 63 Kbytes).

The required number of bytes for the extended comment size can be calculated using the expression for setting the comment size.

5) File register

Set the file register size in units of 1 Kbyte.

One Kpoint is a file register of 1,024 points.

6) Memory capacity information

Main capacity The total of the main sequence program, main microcomputer program, and network parameter (AnUCPU only) sizes is displayed.

Sub capacity The total of the sub sequence program and sub microcomputer program sizes is displayed.

POINTS

- Precautions after setting the comment size
 - (1) The following table shows the number of comments writable to the CPU.

PLC	Number of Comments Writable to CPU
A1N	128 comments (F0 to F127)
Others	Within the internal memory capacity or memory cassette capacity

- (2) Only the AnA and the AnUCPU can write extended comment 1 created to the PLC.
- Setting the microcomputer program size requires at least 1 Kstep of sequence program size.
The microcomputer program cannot be edited.
- Set the PLC program size in units of "1 Kstep" and the microcomputer program size in units of "2 Kbytes."
One Kstep is equal to 2 Kbytes.
- It is not necessary to set the comment size for extended comments 2 to 4.
- Precautions for setting the extended comment size in the AnA or AnUCPU
In the AnA or AnUCPU CPU, the set extended comment size is not included in the total parameter memory capacity. Only the data in the internal memory of the peripheral devices is counted.
- AnUCPU requires 4 Kbytes of network parameter size.
The maximum settable capacity of the main sequence program and main microcomputer program sizes is shown below:
Max. main sequence program size - Number of MELSECNET link units x 4 Kbytes
Although the parameter size is 2 Kbytes when the MELSECNET (II) is selected, 4 Kbytes of parameter size are actually required.

13.5 Setting PLC RAS

A	QnA	FX
•	×	×


[Purpose]

Makes settings in order to control the PLC operation status (WDT setting, PLC processing conditions).

[Operating procedure]

Select [PLC parameter], and click the << PLC RAS>> tab.

[Dialog Box]



[Description]

- 1) WDT (watch dog timer) setting
Set this item to detect any operation time error in the PLC.
Set the time in units of 10 ms.
- 2) Operating mode when there is an error
Sets whether to continue or discontinue the ongoing operation when an error occurs in each item.
- 3) Annunciator display mode
Sets whether to alternately display the F number of the annunciator and its comment on the front indicator of the A3A, A3U or A4UCPU or display only the F number.

13.6 Setting the PLC System

A	QnA	FX
•	×	×


[Purpose]

Sets RUN-PAUSE contacts, system interrupt, and other items.

[Operating procedure]

Select [PLC parameter], and click the << PLC system>> tab.

[Dialog Box]



[Description]

1) RUN-PAUSE SE Contacts


- When RUN is set
Sets an input signal to switch the RUN status to the remote STOP status using input contacts.
- When PAUSE is set
Sets an input signal to switch the RUN status to the remote PAUSE status using input contacts.

To switch the status with PAUSE set, turn ON the special relay M9040 in the sequence program or another program.

2) System interrupt setup

Sets the range of the counters to be used within the interrupt program.

In the AnA or AnUCPU, the range can be set by means of the interrupt counter setting function shown below:



3) Output mode at RUN to STOP

- The output (Y) status before the STOP status will be output.

When the PLC status changes from STOP to RUN, the output status before the STOP status will be output.

- Output (Y) will be cleared. (Output will take place after a scan operation.)

Output will not take place immediately after the PLC status changes to RUN, but the result of a scan operation will be output.

4) Data communications request batch processing

Sets whether to process in the AnA or AnUCPU any data communication request from the computer link unit, etc. in END processing.

(By checking off the check box, the same function will become available as when the M9029 is turned ON.)

5) Remote I/O settings for A2C

Sets the number of occupied slots of each station and remote I/O assignment when the A2C or A2CJCPU is selected.

POINT

- The following units perform data communication request batch processing: AJ71UC24, AJ71C24-S6/S8, AJ71C24(S3), AD51-S3, AD51H-S3, AD51FD, AJ71E71, AJ71P41, AJ71C23-S3, A64GOT-L, A64GOT-LT21B (when a bus is connected), A77GOT-S5, etc.

13.7 Setting I/O Assignments

A	QnA	FX
•	×	×


[Purpose]

Sets the I/O assignments of a unit in the PLC system.

[Operating procedure]

Select [PLC parameter], and click the << I/O assignment >> tab.

[Dialog box]



[Description]

1) Slot

The slot numbers shown in the table are described.

<Example> Main base

The number 0 (0-3) in the table represents the shaded slot shown below:

Power Supply	CPU	0-0	0-1	0-2	0-3	0-4	0-5	0-6	0-7
--------------	-----	-----	-----	-----	-----	-----	-----	-----	-----

<Example> First extension base

The number 1 (1-0) in the table represents the shaded slot shown below:

Power Supply	1-0	1-1	1-2	1-3	1-4	1-5	1-6	1-7
--------------	-----	-----	-----	-----	-----	-----	-----	-----

- 2) Type
Selects the type of the module to be loaded on the base unit.
- 3) Style name
Designates the model of the module to be loaded.
Set the style name within nine characters.
- 4) Point
Selects the number of points of the module to be loaded.

POINTS

- | |
|--|
| <ul style="list-style-type: none">• To set a special function module, set I/O assignment for all occupied points of the module.• I/O assignment is not possible when the A1FXCPU is selected. |
|--|

13.8 Setting Devices

A	QnA	FX
•	×	×


[Purpose]

Sets the M, L, and S relays, latch ranges, and timers/counters to be used in the sequence program.

[Operating procedure]

Select [PLC parameter], and click the <<Devices>> tab.

[Dialog box]



[Description]

- 1) Low-speed timer, High-speed timer, Retentive timer
Set the timer range from T0 and the timers in order of low-speed timer, high-speed timer, and retentive timer.
- 2) Extension low-speed timer, extension high-speed timer, extension retentive timer
These timers can be set only with the AnA and the AnUCPU.
Set timers T0 to T255 in units of eight points and timers T256 to T2047 in units of 16 points.
- 3) Start
Sets the head device of the device range to be used.
- 4) Latch Start/End
Sets the head and final latches in units of one point.

5) Step relay

Sets the range of step relays.

When there is a step relay set, specify it with a head number of S.

Condition	Specified Head Number Range of S
With L (latch relay)	0 to 2047
Without L (latch relay)	Head number of L + 1 to 2047

POINTS					
<ul style="list-style-type: none"> Relationship between latch relay (L) and step relay (S) If the latch relay range and the step relay range are set at the same time, the range last set will supersede the range first set. Internal relays (S) cannot be set when the A1FXCPU is selected. Relationship between timer setting and latch range <ol style="list-style-type: none"> Set the latch range of the timer at 10 ms or 100 ms using the auxiliary parameter function after retentive timer range setting. If the set latch range is changed in the timer setting mode, the original latch range will be replaced forcibly with the range set in the timer setting mode. However, the set latch range will be canceled if it is out of the range available in the timer setting mode. Timer range setting order Set timers T0 to T255 from T0 and the following timers from T256 in order of low-speed timer, high-speed timer, and retentive timer. 					
Low-speed timer	High-speed timer	Retentive timer	Low-speed timer	High-speed timer	Retentive timer
T0 → T255			T256 → T2047		
(In units of eight points)			(In units of 16 points)		

PLC Parameters (QnA Series)

13.9 Assigning PLC Names

A	QnA	FX
×	•	×


[Purpose]

Assigns labels and comments to the PLC.
When accessing the PLC from a peripheral device, such a label and comment make it easier to identify the CPU.

[Operating procedure]

Select [PLC parameter], and click the <<PLC name>> tab.

[Dialog box]



[Description]

- 1) Device Label
The label length must be as shown below:

	Number of characters
Label	10

The set label will be displayed on the Parameter Dialog Box.

- 2) Comment
The comment length must be as shown below:

	Number of characters
Comment	64

13.10 Setting the PLC System

A	QnA	FX
×	•	×


[Purpose]

Sets RUN-PAUSE contacts, system interrupt, and other items.

[Operating procedure]

Select [PLC parameter], and click the << PLC system>> tab.

[Dialog box]



[Description]

- 1) **Timer limit setup**
Set the time limit of the low-speed timer and of the high-speed timer.
 - Low-speed timer :10 to 1000 ms (Set the time in units of 10 ms.)
 - High-speed timer :1 to 100 ms (Set the time in units of 1 ms.)
- 2) **RUN-PAUSE contacts**
Set each input number to perform remote RUN/STOP or remote PAUSE using input contacts.
Devices can be set between X0 and X1FFF.
To perform remote RUN/STOP or remote PAUSE with PAUSE set, turn ON the special relay SM206 in the sequence program or another program.
- 3) **Remote reset**
Set whether to enable or disable remote resetting.
- 4) **Output mode at RUN to STOP**
 - Previous state
When the PLC status changes from STOP to RUN, the output status before the STOP status will be output.
 - Recalculate(output is 1 scan later)
Output will not take place immediately after the PLC status changes to RUN, but the result of a scan operation will be output.

- 5) Common pointer No.
Set the head number of the pointers to be shared among all program files.
- 6) General data processing
Set the number of units which will simultaneously communicate during an END processing operation. (By checking off the check box, the same function will become available as when the SM1029 is turned ON.)
- 7) Number of empty slots
Specify the number of I/O points occupied by the vacant slots.
- 8) System interrupt settings
Set the head counter to be used in the interrupt program and the regular intervals of interrupt pointers I28 to I31.

POINTS

- The following units perform general data processing:
AJ71UC24, AJ71C24-S6/S8, AJ71C24(S3), AD51H-S3, AD51FDAJ71E71, AJ71P41, AJ71C23-S3, A64GOT-L, A64GOT-LT21B (when a bus is connected), A77GOT-S5, AJ71QC24(-R2/R4), A1SJ71QC24(-R2), etc.
- If a pointer of the same number exists in two or more program files, an error will occur when the PLC status is switched from STOP to RUN, disabling the program from starting.

13.11 Setting PLC Files

A	QnA	FX
×	•	×


[Purpose]

Sets the file register, comment, device initial value, and local device files, which are stored in the memory area in the internal RAM or on an IC memory card, as files to be used by the PLC.

[Operating Procedure]

Select [PLC parameter], and click the << PLC file>> tab.

[Dialog Box]



[Description]

1) File register

Set which of the files stored on the IC memory card will be used as the file register file, or set this item to newly reserve a file register area.


⊙ Not used

No file register will be set with parameters. Select this option to specify the file register to be used in the sequence program.

Use an ODRSET instruction to specify the file register.

- ⊙ Use the same file name as the program

The file whose name is the same as that of the sequence program will be used as a file register file.



This function is helpful in using the file register of the same number in each program.

- ⊙ Use the following file

A new file register area will be created.

Set the drive (1 to 4), file name, and size of the file register.

If a file name with the same name already exists, change only the file register size.

The above information must be reset whenever the IC memory card is formatted.

- 2) Comment file used in a command

Set the file to be used as the device comment file.

- ⊙ Not used


No comment file will be set with parameters.

Select this option to specify the comment file to be used in the sequence program. Use an QCDSET instruction to specify the file register.

- ⊙ Use the same file name as the program

Specify the drive (1 to 4) set on memory card.

The valid comment file will be switched each time the execution program is switched.



- ⊙ Use the following file

Only the comment file whose drive and file name are specified will become valid.

- 3) Device initial value
Set the file to be used as the device initial value file.
- Ⓐ Not used
No device initial value file will be set.
 - Ⓑ Use the same file name as the program
The device initial value file whose name is the same as that of the program will become valid.
The valid device initial value file will be switched each time the execution program is switched.
Specify a drive (0 to 4).
 - Ⓒ Use the following file
Only the device initial value file whose drive and file name are specified will become valid.
- 4) File for local device
Set a file to reserve a local device save area when a local device is used.
- Ⓐ Not used
No local device file will be set.
 - Ⓑ Use the following file
The PLC will automatically create a local device file with the specified drive (1 to 4) and file name.
Set the device range of local devices using the [Device setting] tab.
See Section 16.7 for details on local device monitoring procedure.

POINT

- When the device initial value file is set, the device initial values will precede even devices for which a latch range is set.

13.12 Setting PLC RAS

A	QnA	FX
×	•	×


[Purpose]

Increases the reliability, operability, and service of the system.

[Operating procedure]

Select [PLC parameter], and click the << PLC RAS>> tab.

[Dialog Box]



[Description]

- 1) WDT (watch dog timer) setup
Set a watch dog timer, a watch dog timer valid only during a scan (initial execution monitoring time), and a watch dog timer valid throughout the execution of a low-speed program (low-speed execution monitoring time).
- 2) Error check
This item is used to set whether to check each error item in END processing. The END processing time can be reduced when the check box is not checked.
- 3) Operating mode when there is an error
Set whether to continue or discontinue the PLC operation when an error occurs.
- 4) Constant scanning
Set the constant scan time.
- 5) Annunciator display mode
Set whether to display the annunciator number, the comment, and the occurrence time on the front indicator of the Q3A, Q4A or Q4ARCPU when the annunciator is turned ON.

- 6) Break down history
Specify the location to store the result of a self-diagnosis performed by the PLC as a fault log.
When "Record in internal RAM" is selected, the latest 16 errors will be stored in the internal RAM in the PLC.
- 7) Lowspeed program execution time
Set the low-speed program execution time.
The time can be set in units of 1 ms.

13.13 Setting Devices

A	QnA	FX
×	•	×


[Purpose]

Sets the number of points for each device, latch ranges, and local devices to be used in the sequence program.

[Operating procedure]

Select [PLC parameter], and click the <<Devices>> tab.


[Dialog Box]



[Description]

- 1) Device point
Up to 32 Kbytes can be set for a device as device points.
The total number of bit device points must not exceed 64 Kpoints.
Set all device points so that the total will not exceed 29 Kwords.
- 2) Latch (1) Start/End
Set the latch range that can be cleared with the latch clear key of the PLC.
- 3) Latch (2) Start/End
Set the latch range that can be executed by remote operation of the PLC menu or the sequence program.
The latch range can be set in units of one point.
However, it cannot be set again in latch clear key enabled/disabled setting.

- 4) Local device Start/End
 Set the local device range to be used in each program.
 Setting the local device range enables the use of the same device number in each program file.
 Before using a local device, make file settings under [PLC file].
 See Section 16.7 for details on local device monitoring procedure.



- 5) Memory status
 The memory status is calculated based on the following bit and word definitions:

- 1 word = 16 bits
- 1 Kword = 1024 words = 16384 bits

<Example> Calculation at default

$$44 \text{ Kbits} = 44 \text{ Kbits} \div 16 \text{ bits} = 2.75 \text{ Kwords}$$

$$\text{Word device (26.0 Kwords)} + \text{Bit device (2.75 Kwords)} = 28.8 \text{ Kwords}$$

POINT

- The following data, which is already written to the PLC, must also be written again whenever any of the device settings are changed and written to the PLC:
 - Sequence program
 - SFC program
 - Monitor entry
 - Sampling trace data

13.14 Setting Programs

A	QnA	FX
×	•	×


[Purpose]

Makes settings in the program to manage two or more programs as files.

[Operating procedure]

Select [PLC parameter], and click the <<Program>> tab.

[Dialog Box]



[Description]

- 1) Data display list
Select from this list a program to set.
- 2) **Insert** button
This button sets the data selected from the data display list in the Program Setting area.
- 3) **Delete** button
This button deletes specified data from the Data area.
- 4) Program name
This area shows all data names specified in the data setting list.
The programs will be executed in the order in which they were entered.
- 5) Execution
The executing conditions are described below:
Standby : A file composed only of subroutines and interrupt routines.
Scan : A file that is executed in each scan.
Initial : A file that is executed only once when the power is turned ON or when the PLC status changes from STOP to RUN.
After this file is executed, the system will automatically stand by.
Low-speed : A file composed only of subroutines and interrupt routines, which stands by for a start by an instruction.

[Setting procedure]

1. Select from the data display list the sequence program to set.
2. Click the button.
3. Set the program type (scan, initial, standby, low-speed) according to 5).

13.15 Setting a Boot File

A	QnA	FX
×	•	×


[Purpose]

Sets a file to automatically transfer a program from the IC memory card to the internal RAM in the PLC.

[Operating procedure]

Select [PLC parameter], and click the <<Boot file>> tab.

[Dialog Box]



[Description]

- 1) Clear internal RAM
Sets whether to clear the internal RAM in the PLC before the boot operation. By increasing the system area, operations, such as monitoring from another station, can be performed at higher speed.
- 2) Boot file setup
This area displays the data for boot operation.
- 3) **Insert** button
Sets the data selected from the data display list in the Data Name area.
- 4) **Delete** button
Deletes specified data from the Data area.
- 5) Type
Sets the type of the specified data as shown below.
The data type will be set automatically when the data is selected from the data setting list.
 - Sequence
 - Parameter
 - Device initi
 - Comment

- 6) Data name
This area shows all data names specified in the data setting list.
- 7) Source
Sets the area where the data to be booted exists.
- 8) Target
All data will be transferred to the internal RAM.

13.16 Setting SFC

A	QnA	FX
x	•	x


[Purpose]

Sets the conditions for starting the SFC program.

[Operating procedure]

Select [Setting PLC parameters], and click the <<Setting SFC>> tab.

[Dialog Box]



[Description]

- 1) SFC program start mode
Selects Initial Start or Continue to start for starting the SFC program.
- 2) Start conditions
Sets whether to automatically start block 0 at the initial start of the SFC program.
- 3) Output mode when the block is stopped.
Sets whether to stop coil output, which is turned ON by an OUT instruction, by turning it OFF or while it remains ON, when a stop request is issued to each block.

POINT
• SFC circuit creation is not possible.

13.17 Making I/O Assignments

A	QnA	FX
×	•	×


[Purpose]

Sets the I/O assignments on the base unit of the PLC system.

[Operating procedure]

Select [PLC parameter], and click the <<I/O assignment>> tab.

[Dialog Box]



[Description]

- 1) I/O Assignment
Sets the unit type and model, number of points, and head X/Y for each slot.
- 2) Standard settings
Sets the model name of each of bases, power supply units, and extension cables within 16 characters.
- 3) Read PLC data key
 - When there are parameters in the PLC
The parameters preserved in the PLC will be read.
 - When there are no parameters in the PLC (reading by loading)
Before reading data, delete the parameter file from the PLC, and switch the PLC status from RESET to RUN.

PLC Parameters (FX Series)

13.18 Setting the Memory Capacity

A	QnA	FX
×	×	•


[Purpose]

Sets the capacity to store programs, comments, and file registers.

[Operating procedure]

Select [PLC parameter], and click the <<Memory capacity>> tab.

[Dialog Box]



[Description]

1) Memory capacity

Sets the memory capacity of the PLC.

The following table shows the memory capacity setting range of each PLC:

Memory Capacity	FX ₀ ^{*1} FX _{0S} ^{*1}	FX _{0N}	FX ₁	FX ₂ FX _{2C} FX _{2NC}	FX _{2N} FX _{2NC}
2,000 steps	●	●	●	◎	*
4,000 steps	—	—	—	*	
8,000 steps	—	—	—	*	◎
16,000 steps	—	—	—	—	*

● Fixed value ◎ Default value * Settable — Not settable

*1 : Although the actual memory capacity of the FX₀ and FX_{0S} PLCs is 800 steps, 2,000 steps will be programmed as the memory capacity parameter.

2) Comment capacity

Sets the size of each comment to be written to the PLC.

Up to 32 blocks can be specified, each of which preserves 50 comments.

The default value for all PLCs is 0 blocks.

The program capacity will decrease by 500 steps per block.

The following table shows the comment size setting range of each PLC:

Memory Capacity	FX ₀ FX _{0S}	FX _{0N}	FX ₁	FX FX ₂ FX _{2C}	FX _{2N} FX _{2NC}
2,000 steps	0 (fixed)	0 to 3	0 to 4	0 to 4	0 to 4
4,000 steps	—	—	4 to 8	0 to 8	0 to 8
8,000 steps	—	—	—	0 to 8	0 to 16
16,000 steps	—	—	—	—	0 to 32

(Unit : Blocks)

3) File register capacity

Up to 14 blocks can be specified, each of which preserves 500 file registers.

The default value for all PLCs is 0 blocks.

The program capacity will decrease by 500 steps per block.

The following table shows the file register size setting range of each PLC:

Memory Capacity	FX ₀ FX _{0S}	FX _{0N}	FX ₁	FX FX ₂ FX _{2C}	FX _{2N} FX _{2NC}
2,000 steps	0 (fixed)	0 to 3	0 (fixed)	0 to 4	0 to 4
4,000 steps	—	—	0 (fixed)	0 to 4	0 to 8
8,000 steps	—	—	—	0 to 4	0 to 14
16,000 steps	—	—	—	0 to 4	0 to 14

(Unit : Blocks)

4) Program capacity

The capacity of the sequence program area is displayed.

The number of steps displayed is calculated as expressed below:

[Memory capacity] - [Comment size (number of blocks x 500 steps)] - [File register size (number of blocks x 500 steps)] = Program capacity

13.19 Setting Devices

A	QnA	FX
x	x	•


[Purpose]

Sets devices to change their power failure compensation ranges.

[Operating procedure]

Select [PLC parameter], and click the << Device>> tab.

[Dialog Box]



[Description]

- 1) Latch start
Specify the head device of the latch range.
- 2) End
Specify the final device of the latch range.

The following table shows the ranges that can be changed, and the default values.

Device	FX ₁		FX, FX ₂ , FX _{2C} , FX _{2N} , FX _{2NC}	
	Range	Default	Range	Default
Auxiliary relay (M)	0 to 1023	500 to 1023	0 to 1023	500 to 1023
State (S)	0 to 999	500 to 999	0 to 999	500 to 999
16-bit counter (C)	0 to 135	100 to 135	0 to 199	100 to 199
32-bit counter (C)	235 to 254	235 to 254	200 to 255	220 to 255
Data register (D)	0 to 127	100 to 127	0 to 511	200 to 511

Do not change the latch range of the FX₀, FX_{0S}, and FX_{0N} series.
The same default value is set for the FX₂, FX_{2C}, FX_{2N}, and FX_{2NC} PLCs.

13.20 Assigning PLC Names

A	QnA	FX
x	x	•


[Purpose]

Assigns comments to PLC programs.

Such comments are called "program titles" in the FXGP (DOS) and the FXGP (WIN).

[Operating procedure]

Select [PLC parameter], and click the << PLC name>> tab.

[Dialog Box]**[Description]**

1) Title

A program title can be entered within 32 characters.

Titles cannot be entered when the FX₀ or FX_{0S} PLC is selected.

13.21 Making I/O Assignments

A	QnA	FX
×	×	•

[Purpose]


Sets element restrictions on program entry in addition to the I/O range conforming to the PLC specifications.

The settings will not be stored in the parameters in the PLC but will be preserved as a project for a peripheral device.

[Operating procedure]

Select [PLC parameter], and click the << I/O assignment>> tab.

[Dialog Box]



[Description]

1) Start

Specify the head element number of the I/O assignment in octal.

2) End

Specify the final element number of the I/O assignment in octal.

The following table shows the ranges that can be changed (X, Y: octal):

I/O	FX ₀ FX _{0S}	FX _{0N}	FX ₁	FX FX ₂ FX _{2C}	FX _{2N} FX _{2NC}
Input (X)	000 to 017	000 to 177	000 to 177	000 to 377	000 to 377
Output (Y)	000 to 015	000 to 177	000 to 177	000 to 377	000 to 377

The default is the maximum range that can be set.

13.22 Setting the PLC System (1)

A	QnA	FX
×	×	•


[Purpose]

Makes the batteryless mode, modem, and RUN terminal settings among the parameters for the FX_{2N} and FX_{2NC} PLCs.

[Operating procedure]

Select [PLC parameter], and click the << PLC System (1) >> tab.

[Dialog Box]



[Description]

- 1) Battery less mode
Check off the check box when the FX_{2N} or FX_{2NC} PLC is to be operated with the memory backup battery removed.
- 2) MODEM initialized
Sets the modem initialization command for remote access to the FX_{2N} or FX_{2NC} PLC using the FXGP (WIN) software.

- "None" (default)
- "User register mode"
- "AIWA (PV-AF288)"
- "OMRON (ME3314B)"

By specifying the "user entry mode," the data stored at data registers D1000 to D1059 will be sent as initialization commands. Write an AT command, which controls the modem according to the sequence program, to these data registers beforehand.

For details of remote access to the PLC, see the manual name - FX-PLCS/WIN-E type programming software operation manual.

- 3) RUN terminal input
To use the inputs (X) of the FX_{2N} or FX_{2NC} PLC as external RUN/STOP terminals, set the input numbers.
"None" (default)
"X000" to "X017," ("X000" to "X007" for a 16-point basic unit)

13.23 Setting the PLC System (2)

A	QnA	FX
×	×	•


[Purpose]

Enters the specified data as FX_{2N} and FX_{2NX} PLC parameters and overwrites the data at special registers D8120 (communication format), D8121 (station number setting), and D8129 (timeout judgment time) when the power to the PLC is turned ON.

[Operating procedure]

Select [PLC parameter], and click the <<PLC system (2)>> tab.

[Dialog Box]



[Description]

- 1) Operate communication setting.
Checking the checkmark of the check box makes the settings valid. By clearing the checkmark, the settings will become invalid, and the data at D8120, D8121, and D8129 will remain unchanged.
- 2) Protocol
"Non-procedural"
"Dedicated protocol"
- 3) Data length
"7 bits" (default)
"8 bits"
- 4) Parity
"Odd" (default)
"None"
"Even"

- 5) Stop bit
 - "1 bit" (default)
 - "2 bit"

- 6) Baud rate
 - "19200"
 - "9600" (default)
 - "4800"
 - "2400"
 - "1200"
 - "600"
 - "300"

- 7) Header
 - The header will become valid by checking the check box.

- 8) Terminator
 - The footer will become valid by checking the check box.

- 9) Control line
 - The control line will become valid by checking the check box.

- 10) H/W type
 - "Regular/RS-232C" (default)
 - "RS-485"

- 11) Control mode
 - The description of the control mode will be displayed.

- 12) Sum check
 - A sum check will be added by checking the check box.

- 13) Transfer control procedure
 - "Form 1" (default)
 - "Form 4"


- 14) Station number setting
 - Sets station numbers between 00_H and 0F_H (default : 00_H).

- 15) Time out judge time
 - Sets the timeout time between 1 and 255 (default : 1).


14. SETTING NETWORK PARAMETERS

This page and the next three pages show the flow of creating the network parameters for the A series and the QnA series.


MELSECNET master station
MELSECNET II compound master station
MELSECNET II master station




MELSECNET local station
MELSECNET II compound local station
MELSECNET II local station




MELSECNET/10 default station




Administration station




Normal station




Remote I/O master station




Multi-remote master station/Parallel remote master station




Multi-remote substation



Parallel remote substation



Standby station (QnA series)



POINT
<ul style="list-style-type: none"> The parameters for the multi-remote master station, the parallel remote master station, the multi-remote substation, the parallel remote substation, and the standby station can be set only with the QnA series.

Network Parameters (A Series)

14.1 Setting the Network Screen

A	QnA	FX
•	×	×

The configuration of MELSECNET systems is different depending on the PC type used.

The following table shows the master stations for the MELSECNET system, the MELSECNET II system, and the MELSECNET II compound system, and the administration stations for the MELSECNET/10 system.

System	CPU Type
MELSECNET	A0J2H, A1S(S1), A1SJ, A1SH, A1SJH, A1N, A2C, A2CJ, A2N(S1), A2S(S1), A2SH, A3N, A2AS(S1), A2AS-S30, A2AS-S60, A3A, A4U
MELSECNET II	A2A(S1), A3A, A2U(S1), A2USH(S1), A2USH-S1, A2AS(S1), A2AS-S30, A2AS-S60, A3U, A4U
MELSECNET II compound	A2A(S1), A3A, A2U(S1), A2USH(S1), A2USH-S1, A2AS(S1), A2AS-S30, A2AS-S60, A3U, A4U
MELSECNET/10	A2U(S1), A2USH(S1), A2USH-S1, A3U, A4U
MELSECNET/MINI	A2A(S1), A3A, A2U(S1), A2USH(S1), A2USH-S1, A3U, A4U

- Set network parameters if necessary.

[Purpose]

Sets communication data for constructing a MELSECNET, MELSECNET II or MELSECNET/10 system.

[Operating procedure]

Select [Network parameter] to display the network parameter selection dialog box, and click the MELSECNET button.

[Dialog box]

1) Valid units during other station access: 1

2) Network Type: None

3) Start I/O No.: None

4) Network No.: None

5) Network parameter capacity: Kb

	Unit No. 1	Unit No. 2	Unit No. 3	Unit No. 4
Network Type	None	None	None	None
Start I/O No.				
Network No.				
Total No.				
Group No.				
Station No.				

Necessary setting: / Already set: / Set & readout:

Start I/O No.: / Input the start I/O No. installed in the unit in 16-point units

Z/Y Assignment Check: Check: Setting ended: Cancel:

[Description]

- 1) Valid units during other station access
Sets which network connected to which unit will be made valid when accessing another station from a peripheral unit that does not match the MELSEC-NET/10.
- 2) Network type
Sets the network type.
- 3) Start I/O No.
Sets the network number to which the unit will be connected when the network unit concerned is a unit matching the MELSECNET/10.
- 4) Network No.
Sets the last two digits of the head I/O number of the network unit concerned in units of 16 points.
- 5) Network parameter capacity
If the network parameters are not set in the PLC, the loading status will be read. When the network parameters are set in the PLC, they will be read.

14.2 Setting MELSECNET (II) Link Parameters

Set the data to be communicated between the master station (M), the local station (L), and the remote I/O station when constructing a system.

14.2.1 Setting the refresh parameter

A	QnA	FX
•	×	×


[Purpose]

Sets the communication status (SB, SW) data on the link device (LB, LW, LX, LY) or data link stored in the network unit in order to transfer it to the device available to the sequence program.


[Operating procedure]

Display the Network setting dialog box (set the network type, the start I/O number, and the total number of (slave) stations on this dialog box), and click the Refresh parameters button.

[Network setting dialog box]



[MELSECNET master station setting dialog box]



[Description]

- 1) Assignment method
Sets the device range to be transmitted by specifying Number of Points/Head or Head/Final.
- 2) Link side, PC side
Set Number of Points, the head device, and the final device in units of 16 points.

14.2.2 Setting the MELSECNET (II) network range

A	QnA	FX
•	×	×


[Purpose]

Sets the range for cyclic transfer in the data link system by link relays (LB), link registers (LW), link inputs (LX), and link outputs (LY).
The dialog box, on which MELSECNET II compound (master) is specified, is cited for description.


[Operating procedure]

Display the network setting dialog box (set the network type, the start I/O number, and the total number of (slave) stations on this dialog box), and click the **Network range assignment** button.

[Dialog box] MELSECNET II Compound (Master) Dialog box



[MELSECNET II compound (master) dialog box]



[Description]

- 1) Assignment method
Sets the device range to be transmitted by specifying Number of Points/Head or Head/Final.
- 2) Supplementary settings
The monitoring time of the link scan time will be displayed.
The monitoring time can be set between 1 ms and 200 ms.
- 3) Switch screens
The window will be switched between BW Setting and XY Setting.
Set window switching according to the following table in the case of the MELSECNET II compound system:

	First Half Data	Second Half Data
NET II → MNET	$M \leftarrow L$ } Set BW and X/Y data $M \rightarrow L$ } will be utilized. If B/W400 and the following exist in the first half data, the final area will be 3FF.	The data will be displayed again when MNET → MENT.
MNET II ← MNET	$M \leftarrow L$ Set BW data will be utilized.	The data will be unset. It will be displayed when $M \rightarrow L$.

- 4) Send range for each station, M station → R station, M station ← R station
Set the number of points, the head device, and the final device in units of 16 points.
 - Each station's transmission range ... B, W
Sets the range within which the local station will write data and will be linked to the master station and other local stations.
 - M station → R station
Sets the range of data transfer to the special function unit within the remote I/O station according to an "RTOP" instruction.
 - M station ← R station
Sets the range of data transfer from the special function unit within the remote I/O station to the link register (W) of the master station according to an "RFRP" instruction.
- 5) Description of each button
See Section 14.4.