


MELSOFT

Engineering Software

# GX Works2 Version 1 Operating Manual (Common)

---

-SW1DND-GXW2-E  
-SW1DNC-GXW2-E





# ● SAFETY PRECAUTIONS ●


(Always read these instructions before using this product.)

Before using this product, thoroughly read this manual and the relevant manuals introduced in this manual and pay careful attention to safety and handle the products properly. If products are used in a different way from that specified by manufacturers, the protection function of the products may not work properly. The precautions given in this manual are concerned with this product. For the safety precautions of the programmable controller system, refer to the User's Manual for the CPU module.

In this manual, the safety precautions are ranked as "⚠️ WARNING" and "⚠️ CAUTION".



Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage.

Note that the ⚠️ CAUTION level may lead to serious consequences according to the circumstances. Always follow the precautions of both levels because they are important for personal safety.

Please save this manual to make it accessible when required and always forward it to the end user.

## [Design Instructions]

### ⚠️ WARNING

- When data change, program change, or status control is performed from a personal computer to a running programmable controller, create an interlock circuit outside the programmable controller to ensure that the whole system always operates safely. Furthermore, for the online operations performed from a personal computer to a programmable controller CPU, the corrective actions against a communication error due to such as a cable connection fault should be predetermined as a system.

## [Security Precautions]

### ⚠️ WARNING

- To maintain the security (confidentiality, integrity, and availability) of the programmable controller and the system against unauthorized access, denial-of-service (DoS) attacks, computer viruses, and other cyberattacks from external devices via the network, take appropriate measures such as firewalls, virtual private networks (VPNs), and antivirus solutions.

## [Startup/Maintenance Instructions]

### ⚠️ CAUTION

- The online operations performed from a personal computer to a running programmable controller CPU (Program change when a programmable controller CPU is RUN, operating status changes such as forced input/output operation and RUN-STOP switching, and remote control operation) must be executed after the manual has been carefully read and the safety has been ensured. When changing a program while a programmable controller CPU is RUN, it may cause a program corruption in some operating conditions. Fully understand the precautions described in Section 15.9 before use.
- The positioning test functions of OPR, JOG, inching or positioning data for QD75/LD75 positioning module must be executed with the programmable controller set to STOP after the manual has been carefully read and the safety has been ensured. Specially when executing the function on the network system, ensure the safety thoroughly since the machinery whose operation cannot be checked by an operator may be activated. The operation failure may cause the injury or machine damage.

# ● CONDITIONS OF USE FOR THE PRODUCT ●

- (1) MELSEC programmable controller ("the PRODUCT") shall be used in conditions;
- i) where any problem, fault or failure occurring in the PRODUCT, if any, shall not lead to any major or serious accident; and
  - ii) where the backup and fail-safe function are systematically or automatically provided outside of the PRODUCT for the case of any problem, fault or failure occurring in the PRODUCT.
- (2) The PRODUCT has been designed and manufactured for the purpose of being used in general industries. MITSUBISHI ELECTRIC SHALL HAVE NO RESPONSIBILITY OR LIABILITY (INCLUDING, BUT NOT LIMITED TO ANY AND ALL RESPONSIBILITY OR LIABILITY BASED ON CONTRACT, WARRANTY, TORT, PRODUCT LIABILITY) FOR ANY INJURY OR DEATH TO PERSONS OR LOSS OR DAMAGE TO PROPERTY CAUSED BY the PRODUCT THAT ARE OPERATED OR USED IN APPLICATION NOT INTENDED OR EXCLUDED BY INSTRUCTIONS, PRECAUTIONS, OR WARNING CONTAINED IN MITSUBISHI ELECTRIC USER'S, INSTRUCTION AND/OR SAFETY MANUALS, TECHNICAL BULLETINS AND GUIDELINES FOR the PRODUCT.
- ("Prohibited Application")
- Prohibited Applications include, but not limited to, the use of the PRODUCT in;
- Nuclear Power Plants and any other power plants operated by Power companies, and/or any other cases in which the public could be affected if any problem or fault occurs in the PRODUCT.
  - Railway companies or Public service purposes, and/or any other cases in which establishment of a special quality assurance system is required by the Purchaser or End User.
  - Aircraft or Aerospace, Medical applications, Train equipment, transport equipment such as Elevator and Escalator, Incineration and Fuel devices, Vehicles, Manned transportation, Equipment for Recreation and Amusement, and Safety devices, handling of Nuclear or Hazardous Materials or Chemicals, Mining and Drilling, and/or other applications where there is a significant risk of injury to the public or property.
- Notwithstanding the above restrictions, Mitsubishi Electric may in its sole discretion, authorize use of the PRODUCT in one or more of the Prohibited Applications, provided that the usage of the PRODUCT is limited only for the specific applications agreed to by Mitsubishi Electric and provided further that no special quality assurance or fail-safe, redundant or other safety features which exceed the general specifications of the PRODUCTS are required. For details, please contact the Mitsubishi Electric representative in your region.
- (3) Mitsubishi Electric shall have no responsibility or liability for any problems involving programmable controller trouble and system trouble caused by DoS attacks, unauthorized access, computer viruses, and other cyberattacks.



**REVISIONS**

Print date	Manual number*1	Revision
Jul. 2008	SH(NA)-080779ENG-A	First edition
Jan. 2009	SH(NA)-080779ENG-B	<p><b>Model Addition</b> Q00UJ, Q00U, Q01U, Q10UDH, Q10UDEH, Q20UDH, Q20UDEH, FX series</p> <p><b>Addition</b> MANUALS, Section 2.1, Section 2.1.2, Section 2.1.3, Section 2.1.5, Section 2.1.6, Section 2.1.7, Section 2.1.8, Section 2.3, Section 3.2.8, Section 5.2, Section 12.8, Section 13.2, Section 14.5, Section 14.6, Section 14.7, Section 15.2.2, Section 15.3, Section 15.4, Section 17.1.2, Section 17.4.3, Section 17.4.4, Appendix 6</p> <p><b>Correction</b> GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.3, Section 2.1.4, Section 2.3, Section 2.5, Section 3.2.1, Section 3.2.2, Section 3.2.3, Section 3.2.4, Section 3.2.6, Section 3.3.1, Section 3.3.4, Section 4.1.6, Section 4.1.7, Section 4.2.1, Section 4.3, Section 4.3.1, Section 4.3.5, Section 4.4, Section 4.4.1, Section 4.5.2, Section 4.5.3, Section 4.6, Section 4.6.1, Section 4.7, Section 6.1, Section 6.1.1, Section 6.2, Section 6.2.1, Section 7.1.2, Section 7.2.2, Section 7.2.4, Section 8.1.2, Section 9.1.1, Section 9.1.2, Section 10.1.2, Section 10.2, Section 10.3, Section 11.1.1, Section 11.2.3, Section 11.3, Section 11.8.1, Section 12.2, Section 12.5, Section 12.9.1, Section 12.9.5, Section 13.1.1, Section 14.1, Section 14.3, Section 15.5.4, Section 16.1, Section 16.3, Section 16.5, Section 17.4.1, Section 17.4.2, Section 18.3.2, Chapter 19, Appendix 1, Appendix 2, Appendix 3, Appendix 4, Appendix 5, Appendix 7, Appendix 8, Appendix 9.3</p>
Jul. 2009	SH(NA)-080779ENG-C	<p><b>Model Addition</b> Q00J, Q00, Q01</p> <p><b>Addition</b> Section 4.1.4, Section 7.2.4, Section 10.3.2, Section 10.3.3, Section 10.3.4, Section 10.3.5, Section 11.1.2, Section 12.9.3, Section 12.10, Section 15.2.1, Section 15.2.2, Section 15.2.3, Section 16.5, Section 18.6.1, Chapter 19</p> <p><b>Correction</b> MANUALS, GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.3, Section 2.3, Section 2.5, Section 3.2.1, Section 3.2.8, Section 4.1.1, Section 4.1.8, Section 4.2.1, Section 4.3.1, Section 4.3.5, Section 4.4, Section 4.6, Section 4.8, Section 5.2, Section 6.1.1, Section 7.1.2, Section 7.2.2, Section 7.2.3, Section 7.3, Section 7.4.2, Section 8.2, Section 9.1.1, Section 9.2.1, Section 9.2.2, Section 10.3.1, Section 10.3.6, Section 11.1, Section 11.2.3, Section 11.4, Section 11.9, Section 12.1, Section 12.1.5, Section 12.5, Section 12.9.1, Section 12.9.4, Section 12.9.6, Section 12.11, Section 14.2.2, Section 14.7, Section 15.1, Section 15.2, Section 16.2, Section 16.4, Section 17.2, Section 18.3, Section 18.4, Section 18.6, Section 20.2, Section 20.3, Section 21.2, Section 22.2.2, Appendix 1, Appendix 2, Appendix 4, Appendix 5, Appendix 6, Appendix 7, Appendix 8, Appendix 9, Appendix 10</p> <p><b>Modification</b> Section 4.1.4 to 4.1.7 → Section 4.1.5 to 4.1.8, Section 4.6.4 → Section 4.7, Section 4.7 to 4.8 → Section 4.8 to 4.9, Section 7.2.4 to 7.2.5 → Section 7.2.5 to 7.2.6, Section 10.2 to 10.3 → Section 10.1 to 10.2, Section 11.1.2 → Section 11.2.3, Section 11.9.3 to 11.9.5 → Section 11.9.4 to 11.9.6, Section 12.10 → Section 12.11, Section 14.2.3 to 14.2.4 → Section 14.2.2 to 14.2.3, Section 15.1.1 → Section 15.2, Section 15.1.2 → Section 15.4, Section 15.2 to 15.5 → Section 16.1 to 16.4, Chapter 16 to 17 → Chapter 17 to 18, Chapter 18 to 19 → Chapter 20 to 21, Appendix 7 → Appendix 6, Appendix 10 → Appendix 8</p> <p><b>Deletion</b> Section 3.3.5, Section 4.4.1</p>
Oct. 2009	SH(NA)-080779ENG-D	<p><b>Addition</b> Appendix 13</p> <p><b>Correction</b> GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.3.1, Section 1.3.6, Section 2.1, Section 4.1.7, Section 6.1, Section 10.1.1, Section 10.3, Section 11.8.1, Section 11.8.2, Section 12.2, Section 20.3.2, Section 21.1, Section 21.2, Appendix 1.2, Appendix 1.6, Appendix 4.2, Appendix 4.3, Appendix 4.4, Appendix 4.5, Appendix 4.9, Appendix 4.10, Appendix 4.14, Appendix 7, Appendix 8, Appendix 10.1, Appendix 12</p>

Print date	Manual number*1	Revision
Jan. 2010	SH(NA)-080779ENG-E	<p><b><u>Model Addition</u></b> L02, L26-BT</p> <p><b><u>Addition</u></b> CONDITIONS OF USE FOR THE PRODUCT, Section 3.3.4, Section 13.2, Section 16.6, Section 18.4.5, Section 18.6.1, Section 18.7, Appendix 10.7, Appendix 14</p> <p><b><u>Correction</u></b> MANUALS, GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.3, Section 2.1, Section 2.2, Section 2.3, Section 2.4, Section 3.2.7, Section 4.1.1, Section 4.1.3, Section 4.1.7, Section 4.1.8, Section 4.3, Section 4.5.1, Section 4.5.5, Section 4.6, Section 6.1, Section 6.2, Section 6.3, Section 6.4, Section 7.1.2, Section 7.2.6, Section 7.3, Section 9.1.2, Section 9.4.2, Section 10.1, Section 10.2, Section 10.3, Section 11.2.1, Section 11.2.3, Section 11.3, Section 11.5, Section 11.7, Section 11.8.1, Section 11.8.2, Section 12.1, Section 12.1.2, Section 12.1.4, Section 12.2, Section 12.3, Section 12.5, Section 12.6, Section 12.8, Section 12.8.2, Section 12.9.1, Section 12.9.2, Section 12.9.4, Section 12.9.5, Section 12.9.6, Section 12.10.2, Section 12.10.3, Section 12.10.4, Section 12.11, Section 12.11.1, Section 12.11.2, Section 13.3.1, Section 13.3.2, Section 13.3.3, Section 14.1.2, Section 14.5, Section 14.7, Section 15.1, Section 15.2, Section 15.2.1, Section 15.2.3, Section 16.1, Section 16.4.1, Section 16.4.2, Section 16.4.3, Section 16.4.4, Section 17.1, Section 17.2, Section 17.3, Section 17.4, Section 17.5, Section 18.1.1, Section 18.1.2, Section 18.1.3, Section 18.1.4, Section 18.4.1, Section 18.4.3, Section 18.5, Section 18.5.2, Section 18.5.3, Section 18.6, Section 19.3, Section 19.4.1, Section 19.4.2, Section 19.5.3, Section 19.6, Section 19.8, Section 21.1, Section 21.2, Appendix 1, Appendix 1.1, Appendix 1.3, Appendix 1.4, Appendix 1.5, Appendix 1.6, Appendix 1.7.1, Appendix 1.8, Appendix 2.1, Appendix 2.2, Appendix 2.3, Appendix 2.4, Appendix 4.2, Appendix 4.9, Appendix 4.13, Appendix 5, Appendix 6, Appendix 7, Appendix 8.1, Appendix 9, Appendix 10, Appendix 10.1, Appendix 10.2, Appendix 10.3, Appendix 10.4, Appendix 10.5, Appendix 10.6, Appendix 10.7, Appendix 12</p>
Apr. 2010	SH(NA)-080779ENG-F	<p><b><u>Model Addition</u></b> Q50UDEH, Q100UDEH, LJ72GF15-T2</p> <p><b><u>Addition</u></b> Section 4.1.8, Section 6.1.1, Section 6.1.2, Section 6.2.1, Section 12.12, Section 18.1.4, Section 18.4, Appendix 4.13, Appendix 10.8</p> <p><b><u>Correction</u></b> MANUALS, GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.1, Section 1.2, Section 1.3.1, Section 2.1.1, Section 2.1.2, Section 2.1.3, Section 2.1.8, Section 2.3, Section 2.5, Section 3.2, Section 3.4, Section 3.5, Section 4.1.2, Section 4.6, Section 4.6.3, Section 4.8, Section 4.8.5, Section 6.1, Section 6.1.1, Section 6.4, Section 10.1.1, Section 11.1.1, Section 11.2.3, Section 11.3, Section 11.4, Section 11.5, Section 11.6, Section 11.7, Section 12.4.1, Section 12.6, Section 12.8, Section 12.9.1, Section 12.9.2, Section 12.9.6, Section 11.2.3, Section 14.1.2, Section 14.2.2, Section 16.1, Section 16.4.2, Section 16.4.3, Section 17.1, Section 17.2, Section 17.3, Section 17.6, Section 18.1, Section 18.3, Section 18.4, Section 18.5.3, Section 18.7, Section 18.7.2, Section 20.1, Section 20.3.2, Section 21.1, Section 21.2, Chapter 22, Appendix 1.1, Appendix 1.6, Appendix 2, Appendix 4.1, Appendix 4.2, Appendix 4.5, Appendix 4.9, Appendix 4.13, Appendix 5, Appendix 6, Appendix 7, Appendix 10, Appendix 12, Appendix 13</p> <p><b><u>Modification</u></b> Section 18.4 to 18.6 → Section 18.5 to 18.7, Appendix 4.13 to 4.14 → Appendix 4.14 to 4.15</p>

Print date	Manual number*1	Revision
Sept. 2010	SH(NA)-080779ENG-G	<p><b>Model Addition</b> QJ72LP25, QJ72BR15</p> <p><b>Addition</b> Section 16.2.2, Section 17.7, Section 18.8, Appendix 2.3, Appendix 15</p> <p><b>Correction</b> GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.2, Section 1.3.1, Section 1.3.2, Section 1.3.4, Section 1.3.5, Section 1.3.8, Section 2.1, Section 2.1.2, Section 2.1.4, Section 2.1.6, Section 2.1.7, Section 2.2, Section 2.2.1, Section 2.3, Section 3.2.1, Section 3.2.2, Section 3.2.3, Section 3.2.4, Section 3.2.6, Section 3.3, Section 3.3.4, Section 3.3.5, Section 4.1.1, Section 4.1.2, Section 4.1.3, Section 4.1.7, Section 4.1.8, Section 4.2.1, Section 4.2.5, Section 4.5.3, Section 4.5.5, Section 4.6, Section 4.6.1, Section 4.7, Section 4.8, Section 4.8.5, Section 4.9, Section 6.1.1, Section 6.2, Section 6.2.1, Section 9.1.2, Section 9.2.1, Section 9.2.2, Section 10.1, Section 10.1.1, Section 10.2, Section 10.3, Section 10.3.1, Section 10.3.2, Section 10.3.3, Section 10.3.4, Section 10.3.5, Section 11.1, Section 11.1.1, Section 11.2, Section 11.2.1, Section 11.2.2, Section 11.2.3, Section 11.3, Section 11.4, Section 11.5, Section 11.6, Section 11.7.1, Section 11.7.2, Section 11.8.1, Section 11.8.2, Section 11.9, Section 12.1, Section 12.1.3, Section 12.1.4, Section 12.1.5, Section 12.2, Section 12.3, Section 12.4, Section 12.8, Section 12.9.1, Section 12.9.5, Section 12.12, Section 13.1, Section 13.1.1, Section 13.2, Section 13.2.1, Section 14.1.1, Section 14.1.2, Section 14.2.1, Section 14.2.2, Section 14.3, Section 15.1.2, Section 15.2, Section 17.1, Section 17.2, Section 17.3, Section 17.4, Section 17.7, Section 18.1.1, Section 18.1.4, Section 18.2.5, Section 18.2.7, Section 18.2.8, Section 18.3, Section 18.4, Section 18.4.4, Section 18.4.5, Section 18.4.6, Section 18.5.1, Section 18.5.3, Section 18.6.2, Section 18.6.3, Section 18.6.4, Section 18.7, Section 21.2, Appendix 1.1, Appendix 1.2, Appendix 1.6, Appendix 2.1, Appendix 2.2, Appendix 2.4, Appendix 2.5, Appendix 4.2, Appendix 4.5, Appendix 4.12, Appendix 4.14, Appendix 4.15, Appendix 6.1, Appendix 6.2, Appendix 7, Appendix 8, Appendix 9, Appendix 10.1, Appendix 10.2, Appendix 10.3, Appendix 10.4, Appendix 10.5, Appendix 10.6, Appendix 10.7, Appendix 10.9, Appendix 12, Appendix 15</p> <p><b>Modification</b> Appendix 4.6.3 → Appendix 4.6.2, Appendix 2.3 → Appendix 2.4</p>
Jan. 2011	SH(NA)-080779ENG-H	<p><b>Addition</b> TERMS, Section 3.3, Section 4.1, Section 12.5, Section 14.1, Section 14.3.4, Section 20.4, Appendix 16</p> <p><b>Correction</b> MANUALS, GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.3, Section 2.1.1, Section 2.1.3, Section 2.2, Section 2.3, Section 3.2.5, Section 3.2.6, Section 4.1.2, Section 4.2.1, Section 4.2.2, Section 4.2.3, Section 4.2.4, Section 4.2.5, Section 4.2.7, Section 4.2.8, Section 4.3.1, Section 4.3.5, Section 4.7.1, Section 4.8, Section 6.1.2, Section 8.2, Section 9.4.1, Section 9.4.2, Section 10.1.1, Section 10.2, Section 11.8, Section 12.1.5, Section 12.1.6, Section 12.2, Chapter 14, Section 16.3, Section 18.1.1, Section 18.7, Section 19.1.1, Section 19.1.3, Section 20.2, Section 20.3.1, Section 20.3.2, Section 21.2, Appendix 1.1, Appendix 1.4, Appendix 1.8, Appendix 4, Appendix 7, Appendix 12, Appendix 15, Appendix 16</p> <p><b>Modification</b> Section 4.1 to 4.9 → Section 4.2 to 4.10, Section 12.5 → Section 12.6, Section 14.1 to 14.7 → Section 14.2 to 14.8</p>
Mar. 2011	SH(NA)-080779ENG-I	<p><b>Addition</b> Section 4.9, Section 16.6, Section 20.1, Section 20.3, Section 20.4, Section 20.5, Section 20.6, Section 20.11,</p> <p><b>Correction</b> MANUALS, GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.1, Section 1.3.1, Section 1.3.3, Section 2.2, Section 2.3, Section 3.3, Section 4.2.1, Section 4.2.2, Section 4.2.3, Section 4.2.4, Section 4.3.2, Section 4.6.1, Section 4.7.1, Section 6.1.1, Section 6.2, Section 6.4, Section 10.1, Section 10.2, Section 10.3, Section 11.1.1, Section 12.1.5, Section 12.7.1, Section 12.9.1, Section 14.1.2, Section 14.6.2, Section 15.1.2, Section 15.3, Section 16.6.3, Section 18.4, Section 18.6.3, Section 20.5.7, Section 20.8.1, Section 21.2, Appendix 1.1, Appendix 1.6, Appendix 4, Appendix 7, Appendix 10, Appendix 12, Appendix 13, Appendix 16, Appendix 17</p> <p><b>Modification</b> Section 20.1 → Section 20.2, Section 20.2 → Section 20.9, Section 20.3.1 → Section 20.7, Section 20.3.2 → Section 20.10, Section 20.4 → Section 20.8, Appendix 15 and 16 → Appendix 16 and 17</p>

Print date	Manual number*1	Revision
Jul. 2011	SH(NA)-080779ENG-J	<p><b>Model Addition</b> L02-P, L26-PBT</p> <p><b>Addition</b> Section 2.1.9, Section 3.4.1, Section 4.1.2, Section 5.2, Section 5.3, Section 10.1.2, Section 12.10.4, Section 20.5.1, Section 20.5.2, Section 20.5.3, Section 20.5.8, Section 20.5.12, Section 20.5.13, Section 20.5.14, Section 20.5.15, Section 20.5.16, Section 20.5.18, Appendix 1.2</p> <p><b>Correction</b> MANUALS, GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, TERMS, Section 1.3.1, Section 1.3.2, Section 1.3.3, Section 1.3.6, Section 2.1, Section 2.2, Section 2.3, Section 2.5, Section 3.1, Section 3.3, Section 3.4, Section 4.1, Section 4.1.1, Section 4.2.1, Section 4.2.2, Section 4.2.3, Section 4.2.7, Section 4.2.8, Section 4.3.1, Section 4.11, Section 4.11.2, Section 6.1.1, Section 9.1.1, Section 9.2.2, Section 9.4.2, Section 10.1, Section 10.1.1, Section 10.1.3, Section 10.2, Section 10.3.1, Section 10.3.2, Section 10.3.3, Section 10.3.4, Section 11.6, Section 12.1, Section 12.1.5, Section 12.1.6, Section 12.9.1, Section 12.9.6, Section 12.10.1, Section 12.10.2, Section 12.10.3, Section 13.3, Section 16.6, Section 16.6.1, Section 16.6.2, Section 16.6.3, Section 16.6.4, Section 16.6.5, Section 16.6.8, Section 17.1, Section 17.5, Section 18.1.1, Section 18.4, Section 18.5.1, Section 18.6.2, Section 20.1, Section 20.3, Section 20.4, Section 20.5.2, Section 20.5.3, Section 20.5.13, Section 20.5.18, Section 20.5.4, Section 20.5.5, Section 20.5.6, Section 20.5.9, Section 20.5.11, Section 20.10, Section 20.11, Section 21.1, Section 21.2, Appendix 1.1, Appendix 1.7, Appendix 4.2, Appendix 4.5, Appendix 4.10, Appendix 4.13, Appendix 4.16, Appendix 4.18, Appendix 6.1, Appendix 6.2, Appendix 7, Appendix 10.9, Appendix 12</p> <p><b>Modification</b> Section 2.1.9 → Section 2.1.10, Section 3.4.6 and Section 3.4.7 → Section 3.4.3 and Section 3.4.4, Section 4.1.2 → Section 4.1.3, Section 5.2 → Section 5.4, Section 10.1.2 → Section 10.1.3, Section 12.10.4 → Section 12.10.5, Section 20.5.1 to Section 20.5.4 → Section 20.5.4 to Section 20.5.7, Section 20.5.5 to Section 20.5.7 → Section 20.5.9 to Section 20.5.11, Section 20.5.8 → Section 20.5.17, Appendix 1.2 to Appendix 1.8 → Appendix 1.3 to Appendix 1.9</p> <p><b>Deletion</b> Section 3.4.2, Section 3.4.3, Section 3.4.5, Section 3.4.6</p>
Sept. 2011	SH(NA)-080779ENG-K	<p><b>Addition</b> Section 2.1.10, Section 9.5, Section 11.9, Section 20.3.1</p> <p><b>Correction</b> TERMS, Section 1.3.1, Section 2.1, Section 3.2.6, Section 3.4, Section 4.2.7, Section 4.2.8, Section 4.6.5, Section 6.2, Section 9.1.2, Section 9.2.1, Section 9.4.2, Section 11.1.1, Section 12.1.3, Section 12.2, Section 18.1.1, Section 20.2, Section 20.3, Section 20.4, Section 20.5.4, Section 20.5.5, Section 20.5.6, Section 20.5.9, Section 20.5.11, Section 20.5.12, Section 20.5.14, Section 20.11, Appendix 4.3, Appendix 4.6, Appendix 4.16, Appendix 5.1, Appendix 6.1, Appendix 7, Appendix 8, Appendix 10, Appendix 12, Appendix 13.1, Appendix 13.2</p> <p><b>Modification</b> Section 2.1.10 → Section 2.1.11, Section 11.9 → Section 11.10</p> <p><b>Deletion</b> Section 6.2.2</p>

Print date	Manual number*1	Revision
Nov. 2011	SH(NA)-080779ENG-L	<p><b>Addition</b>  Section 1.3.7, Section 4.3.5, Section 6.2.2, Section 6.2.3, Section 6.2.4, Section 6.5, Section 6.6, Chapter 22, Appendix 4.16, Appendix 18</p> <p><b>Correction</b>  MANUALS, GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, TERMS, Section 1.1, Section 1.3.1, Section 1.3.2, Section 1.3.3, Section 1.3.6, Section 2.1, Section 2.1.7, Section 2.1.10, Section 3.2.1, Section 4.2.7, Section 4.2.8, Section 4.7.1, Section 6.1.2, Section 6.2, Section 6.4, Section 9.3.1, Section 9.3.2, Section 9.4.2, Section 10.1, Section 10.2, Section 11.1, Section 11.2.1, Section 11.3, Section 11.8.1, Section 11.9, Section 12.1.3, Section 12.1.6, Section 12.2, Section 12.11.1, Section 13.1, Section 13.2, Section 14.1.1, Section 15.1.2, Section 16.4.3, Section 18.5.1, Section 18.5.2, Section 18.5.3, Section 18.5.4, Section 18.5.5, Section 18.7, Section 20.1, Section 21.2, Appendix 1.1, Appendix 1.3, Appendix 1.6, Appendix 1.7, Appendix 2.2, Appendix 2.3, Appendix 2.4, Appendix 4.1, Appendix 4.3, Appendix 4.5, Appendix 4.6, Appendix 4.11, Appendix 4.17, Appendix 4.19, Appendix 7, Appendix 8.1, Appendix 9, Appendix 12, Appendix 15, Appendix 17</p> <p><b>Modification</b>  Section 1.3.7 to Section 1.3.9 → Section 1.3.8 to Section 1.3.10,  Section 4.3.5 → Section 4.3.6,  Appendix 2.1 to Appendix 2.2 → Appendix 2.2 to Appendix 2.3,  Appendix 2.3 → Appendix 2.1,  Appendix 4.16 to Appendix 4.18 → Appendix 4.17 to Appendix 4.19</p>
Jan. 2012	SH(NA)-080779ENG-M	<p><b>Model Addition</b>  FX3GC</p> <p><b>Addition</b>  Section 18.4.2</p> <p><b>Correction</b>  Section 1.3.1, Section 2.1.3, Section 2.1.7, Section 2.1.10, Section 2.3, Section 3.4.1, Section 4.2.8, Section 6.1.1, Section 6.2.1, Section 6.2.2, Section 11.1.1, Section 11.9, Section 12.1, Section 12.1.6, Section 12.9.6, Section 18.4, Section 18.4.4, Section 18.4.6, Section 18.4.7, Section 20.5.2, Section 21.2, Appendix 4.17, Appendix 7, Appendix 10.1, Appendix 10.7, Appendix 12</p> <p><b>Modification</b>  Section 18.4.2 to Section 18.4.6 → Section 18.4.3 to Section 18.4.7</p> <p><b>Deletion</b>  Section 4.7.3</p>

Print date	Manual number*1	Revision
May 2012	SH(NA)-080779ENG-N	<p><b>Model Addition</b> Q02PH, Q06PH, Q12PH, Q12PRH, Q25PH, Q25PRH</p> <p><b>Addition</b> Section 6.2, Section 9.4, Section 11.5, Section 12.11.2, Section 17.2, Section 20.5.1, Section 20.5.4, Section 20.5.6, Appendix 4.20, Appendix 10.5, Appendix 10.6, Appendix 11.2</p> <p><b>Correction</b> GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, TERMS, Section 1.3.1, Section 1.3.2, Section 1.3.3, Section 2.1.7, Section 2.1.10, Section 2.2, Section 2.2.1, Section 2.3, Section 2.4, Section 3.2.1, Section 3.2.2, Section 3.2.5, Section 3.2.6, Section 3.2.7, Section 3.3, Section 3.4.1, Section 4.2.1, Section 4.2.2, Section 4.2.7, Section 4.2.8, Section 4.3.2, Section 4.3.6, Section 4.5, Section 4.6.5, Section 4.7.1, Section 4.10.4, Section 4.11.1, Section 5.2, Section 5.3, Section 6.1, Section 6.1.1, Section 6.2.2, Section 6.2.4, Section 6.3, Section 6.3.1, Section 6.5, Section 6.7, Section 7.2.2, Section 9.1.1, Section 9.1.2, Section 9.2.2, Section 9.5.2, Section 10.1, Section 10.1.1, Section 10.1.2, Section 10.2, Section 11.1.1, Section 11.3, Section 11.4, Section 12.1.6, Section 12.2, Section 12.9.1, Section 12.9.6, Section 12.10.3, Section 14.1.2, Section 14.3, Section 14.4, Section 14.6.2, Section 17.1, Section 17.3, Section 18.1.1, Section 18.1.4, Section 18.6.3, Section 18.6.4, Section 18.7, Section 18.8, Section 20.1, Section 20.5.7, Section 20.5.8, Section 20.5.9, Section 20.5.12, Section 20.10, Section 20.11, Section 21.1, Section 21.2, Appendix 1.1, Appendix 1.3, Appendix 1.7, Appendix 2.3, Appendix 2.4, Appendix 2.5, Appendix 4.1, Appendix 4.2, Appendix 4.4, Appendix 4.5, Appendix 4.10, Appendix 4.17, Appendix 5, Appendix 6.1, Appendix 6.2, Appendix 7, Appendix 8, Appendix 10, Appendix 10.2, Appendix 10.3, Appendix 10.4, Appendix 10.7, Appendix 10.8, Appendix 10.9, Appendix 11, Appendix 12, Appendix 13, Appendix 14, Appendix 17</p> <p><b>Modification</b> Section 6.2 to Section 6.6 → Section 6.3 to Section 6.7, Section 9.4 to Section 9.5 → Section 9.5 to Section 9.6, Section 11.5 to Section 11.10 → Section 11.6 to Section 11.11, Section 17.2 to Section 17.7 → Section 17.3 to Section 17.8, Section 20.5.1 to Section 20.5.2 → Section 20.5.2 to Section 20.5.3, Section 20.5.3 → Section 20.5.5, Section 20.5.4 to Section 20.5.18 → Section 20.5.7 to Section 20.5.21, Appendix 10.5 to Appendix 10.9 → Appendix 10.7 to Appendix 10.11</p>
Sept. 2012	SH(NA)-080779ENG-O	<p><b>Addition</b> Section 1.3.7, Section 6.3.2, Section 12.1.6</p> <p><b>Correction</b> MANUALS, GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, TERMS, Section 1.3.1, Section 3.2.2, Section 3.3, Section 4.2.1, Section 4.2.7, Section 4.2.8, Section 4.5, Section 4.6.5, Section 4.7.1, Section 5.2, Section 5.3, Section 6.1.1, Section 6.3.1, Section 6.3.3, Section 6.3.4, Section 6.5, Section 9.1.1, Section 10.1.1, Section 10.1.2, Section 10.2, Section 10.3.1, Section 10.3.2, Section 10.3.3, Section 10.3.4, Section 10.3.5, Section 11.2.2, Section 12.1, Section 12.1.4, Section 12.1.7, Section 12.9.1, Section 12.9.6, Section 12.10.5, Section 15.2, Section 16.4.3, Section 16.4.4, Section 16.4.5, Section 18.4, Section 18.6, Section 18.6.2, Section 18.6.3, Section 18.7, Section 21.1, Section 21.2, Appendix 1.6, Appendix 7, Appendix 10.11, Appendix 11, Appendix 12</p> <p><b>Modification</b> Section 1.3.7 to Section 1.3.10 → Section 1.3.8 to Section 1.3.11, Section 6.3.2 to Section 6.3.4 → Section 6.3.3 to Section 6.3.5</p>

Print date	Manual number*1	Revision
Feb. 2013	SH(NA)-080779ENG-P	<p><b>Model Addition</b> Q03UDV, Q04UDV, Q06UDV, Q13UDV, Q26UDV, L02S, L06, L26, LJ72MS15</p> <p><b>Addition</b> Section 1.3.9, Section 1.3.10, Section 4.11, Section 13.1, Section 13.5, Section 18.3.2, Section 18.7, Appendix 13</p> <p><b>Correction</b> GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.3.1, Section 1.3.2, Section 1.3.7, Section 1.3.8, Section 2.1, Section 2.2, Section 2.3, Section 2.4, Section 3.1, Section 3.2.1, Section 3.2.2, Section 3.2.3, Section 3.2.5, Section 3.2.8, Section 4.2.2, Section 4.2.8, Section 4.5, Section 4.8, Section 4.12.1, Section 6.1, Section 6.1.1, Section 6.3, Section 6.3.1, Section 6.3.2, Section 6.3.3, Section 6.3.5, Section 6.4, Section 9.1.1, Section 9.3.1, Section 9.3.2, Section 9.4, Section 10.1.1, Section 10.1.2, Section 11.2.2, Section 11.5.3, Section 11.7, Section 11.8, Section 11.9.1, Section 11.10, Section 12.1, Section 12.1.7, Section 12.5, Section 12.8, Section 12.10.2, Section 12.10.5, Section 12.11.1, Section 12.11.2, Section 13.1, Section 13.2, Section 13.3, Section 14.2, Section 14.3, Section 14.6, Section 14.6.1, Section 14.6.2, Section 14.6.3, Section 15.1, Section 15.2, Section 15.3, Section 16.2.1, Section 16.3.1, Section 16.3.2, Section 16.3.3, Section 16.4.2, Section 16.4.5, Section 16.6.2, Section 16.6.3, Section 16.6.4, Section 16.7, Section 17.4, Section 17.7, Section 18.1.1, Section 18.1.4, Section 18.3, Section 18.4, Section 18.4.2, Section 18.5.1, Section 18.5.2, Section 18.5.3, Section 18.5.4, Section 18.5.5, Section 18.6.1, Section 18.6.2, Section 18.6.3, Section 19.4.1, Section 20.5.8, Section 20.10, Section 21.2, Section 22.1.1, Appendix 1.1, Appendix 1.7, Appendix 2.2, Appendix 2.3, Appendix 2.4, Appendix 2.5, Appendix 4.2, Appendix 4.3, Appendix 4.5, Appendix 4.13, Appendix 4.15, Appendix 6.2, Appendix 7, Appendix 10, Appendix 10.2, Appendix 10.3, Appendix 10.4, Appendix 10.5, Appendix 10.6, Appendix 10.7, Appendix 10.8, Appendix 10.9, Appendix 10.10, Appendix 10.11, Appendix 10.12, Appendix 12</p> <p><b>Modification</b> Section 1.3.9 to Section 1.3.11 → Section 1.3.11 to Section 1.3.13, Section 4.11 → Section 4.12, Section 13.1 to Section 13.3 → Section 13.2 to Section 13.4, Section 18.3.2 to Section 18.3.3 → Section 18.3.3 to Section 18.3.4, Section 18.7 to Section 18.9 → Section 18.8 to Section 18.10, Appendix 13 to Appendix 18 → Appendix 14 to Appendix 19</p>
May 2013	SH(NA)-080779ENG-Q	<p><b>Model Addition</b> L02S-P, L06-P, L26-P, FX3S</p> <p><b>Addition</b> Section 1.3.10, Section 6.1.3</p> <p><b>Correction</b> MANUALS, GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, TERMS, Section 1.3.1, Section 1.3.8, Section 1.3.9, Section 1.3.11, Section 2.1, Section 2.1.3, Section 2.1.5, Section 2.1.6, Section 2.1.7, Section 2.1.10, Section 2.3, Section 2.4, Section 3.2.1, Section 4.2.1, Section 4.2.8, Section 4.7.2, Section 4.8, Section 4.11.3, Section 6.1.1, Section 6.3.1, Section 6.3.2, Section 6.3.3, Section 6.3.4, Section 7.1.2, Section 9.2.1, Section 9.5, Section 11.2.1, Section 11.2.2, Section 11.9.1, Section 11.10, Section 12.1, Section 12.8, Section 12.9.1, Section 12.9.6, Section 12.11.1, Section 12.11.2, Section 13.4.1, Section 13.4.3, Section 15.1, Section 15.2, Section 15.3, Section 16.7, Section 17.1, Section 17.4, Section 17.7, Section 18.7, Section 21.2, Appendix 1.1, Appendix 2.1, Appendix 2.2, Appendix 2.3, Appendix 2.4, Appendix 2.5, Appendix 4.2, Appendix 6.1, Appendix 7, Appendix 10, Appendix 12, Appendix 13, Appendix 15, Appendix 16, Appendix 18</p> <p><b>Modification</b> Section 1.3.10 to Section 1.3.13 → Section 1.3.11 to Section 1.3.14, Section 6.3.4 → Section 4.13, Section 6.3.5 → Section 6.3.4</p>
Sept. 2013	SH(NA)-080779ENG-R	<p><b>Correction</b> MANUALS, Section 1.3.1, Section 1.3.6, Section 1.3.10, Section 1.3.11, Section 3.2.8, Section 4.2.8, Section 6.1.3, Section 6.3.1, Section 9.1.1, Section 10.1.1, Section 10.1.2, Section 12.2, Section 14.6, Section 14.8, Section 15.1.4, Section 15.9.1, Section 15.9.2, Section 15.10.3, Section 17.6.3, Section 19.1.2, Appendix 7, Appendix 12, Appendix 18</p>

Print date	Manual number*1	Revision
Dec. 2013	SH(NA)-080779ENG-S	<p><b>Correction</b></p> <p>GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.3.1, Section 1.3.7, Section 2.3, Section 3.2.2, Section 3.4.1, Section 4.1.3, Section 4.2.1, Section 4.2.2, Section 4.2.3, Section 4.2.5, Section 4.2.8, Section 4.4, Section 4.7.1, Section 4.10, Section 4.13, Section 6.1, Section 6.1.1, Section 6.3.2, Section 6.3.3, Section 6.3.4, Section 9.5.2, Section 10.3.1, Section 10.3.5, Section 12.1, Section 12.2, Section 14.1.1, Section 14.2.1, Section 14.9, Section 14.9.1, Section 14.9.2, Section 15.1.7, Section 15.9.5, Section 17.1.2, Section 17.2, Section 17.7, Section 19.6, Section 21.7, Section 21.8, Appendix 2.2, Appendix 2.3, Appendix 2.4, Appendix 7, Appendix 8, Appendix 10, Appendix 10.2, Appendix 10.3, Appendix 10.4, Appendix 10.8, Appendix 10.9, Appendix 10.10, Appendix 10.12, Appendix 12, Appendix 13</p>
Mar. 2014	SH(NA)-080779ENG-T	<p><b>Correction</b></p> <p>GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.3.1, Section 3.2.1, Section 3.4, Section 4.2.1, Section 10.1.1, Section 14.2.1, Section 14.2.2, Section 14.3, Section 14.7, Section 14.8.1, Section 14.8.2, Section 14.10.2, Section 17.6.1, Section 17.6.2, Appendix 2.4, Appendix 4.5, Appendix 7, Appendix 12, Appendix 13, Appendix 15, Appendix 16, Appendix 18</p>
Jun. 2014	SH(NA)-080779ENG-U	<p><b>Correction</b></p> <p>GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.3.1, Section 1.3.8, Section 1.3.11, Section 2.1.1, Section 2.2, Section 2.2.1, Section 2.3, Section 3.2.4, Section 4.2.8, Section 6.1.1, Section 7.2, Section 9.1.1, Section 11.1, Section 11.5.6, Section 12.1, Section 12.2, Section 15.10.3, Section 17.6.3, Section 21.4, Section 21.4.5, Appendix 7, Appendix 10.1, Appendix 12, Appendix 13</p>
Sept. 2014	SH(NA)-080779ENG-V	<p><b>Addition</b></p> <p>Section 9.3.3</p> <p><b>Correction</b></p> <p>GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.3.1, Section 9.2.2, Section 9.4, Section 10.2, Section 12.2, Section 14.2.2, Section 14.3, Section 14.11, Section 15.1, Section 15.1.2, Section 15.1.3, Section 15.1.7, Section 15.10.5, Section 17.1.1, Section 17.6.1, Section 19.7, Section 20.1, Section 21.4, Appendix 1.7, Appendix 2.2, Appendix 2.5, Appendix 4.5, Appendix 4.6, Appendix 4.17, Appendix 7, Appendix 8, Appendix 12, Appendix 14</p>
Dec. 2014	SH(NA)-080779ENG-W	<p><b>Addition</b></p> <p>Section 14.9.3, Section 17.9</p> <p><b>Correction</b></p> <p>GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.3.1, Section 1.3.14, Section 4.13, Section 6.1.1, Section 6.1.2, Section 12.2, Section 14.3, Section 14.9.1, Section 14.9.2, Section 15.1.3, Section 15.1.4, Section 15.10.4, Section 19.1.1, Section 19.1.2, Section 21.8, Appendix 7, Appendix 12</p>
Mar. 2015	SH(NA)-080779ENG-X	<p><b>Correction</b></p> <p>GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.3.7, Section 1.3.11, Section 3.2.5, Section 6.3.2, Section 6.3.3, Section 12.2, Section 15.1.2, Section 15.11.2, Section 21.4, Appendix 2.3, Appendix 7, Appendix 12</p>
Jun. 2015	SH(NA)-080779ENG-Y	<p><b>Correction</b></p> <p>Section 1.3.1, Section 1.3.10, Section 3.3, Section 6.1.1, Section 6.3.4, Section 7.4.2, Section 17.3, Section 21.2.7, Appendix 7, Appendix 12, Appendix 13</p>
Dec. 2015	SH(NA)-080779ENG-Z	<p><b>Addition</b></p> <p>Section 4.13.2, Section 9.6.2</p> <p><b>Correction</b></p> <p>GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.3.1, Section 1.3.3, Section 3.1, Section 4.13, Section 6.3.2, Section 6.3.3, Section 9.2.1, Section 9.2.2, Section 9.6, Section 10.1.2, Section 12.2, Section 21.4, Appendix 7, Appendix 12, Appendix 13</p>



Print date	Manual number*1	Revision
Feb. 2016	SH(NA)-080779ENG-AA	<b>Correction</b> Section 12.2, Section 15.1.5, Appendix 12
Jun. 2016	SH(NA)-080779ENG-AB	<b>Addition</b> Section 14.9.4 <b>Correction</b> GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 3.1, Section 3.2.1, Section 4.2.1, Section 11.4, Section 11.11, Section 14.2.2, Section 14.9, Section 14.9.1, Section 14.9.2, Section 14.9.3, Section 14.9.4, Section 14.10.2, Section 19.5, Appendix 7, Appendix 12, Appendix 13, Appendix 15, Appendix 16, Appendix 18
Sept. 2016	SH(NA)-080779ENG-AC	<b>Correction</b> GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 4.2.3, Section 4.2.5, Section 4.2.7, Section 4.3.6, Section 4.6.1, Section 6.1.1, Section 6.1.3, Section 15.1.4, Section 15.2, Section 21.5.1, Appendix 7, Appendix 10.4, Appendix 10.5, Appendix 12
Dec. 2016	SH(NA)-080779ENG-AD	<b>Addition</b> Section 1.3.11, Section 4.12.4, Section 6.1.4, Section 21.5 <b>Correction</b> Section 1.3.1, Section 4.2.7, Section 4.3.2, Section 4.7.1, Section 4.12.2, Section 6.1.1, Section 11.5.7, Section 11.5.8, Section 15.1.7, Section 15.9.6, Section 16.1, Section 17.4, Appendix 7, Appendix 10, Appendix 10.2, Appendix 10.3, Appendix 10.4, Appendix 10.5, Appendix 10.6, Appendix 10.7, Appendix 10.8, Appendix 10.9, Appendix 10.10, Appendix 10.12, Appendix 12 <b>Modification</b> Section 1.3.11 to Section 1.3.14 → Section 1.3.12 to Section 1.3.15, Section 21.5 to Section 21.10 → Section 21.6 to Section 21.11
Mar. 2017	SH(NA)-080779ENG-AE	<b>Correction</b> Section 4.12, Section 4.12.2, Section 4.12.4, Section 16.1, Section 17.4, Appendix 7, Appendix 10.1, Appendix 10.2, Appendix 10.3, Appendix 10.4, Appendix 10.5, Appendix 10.6, Appendix 10.8, Appendix 10.9, Appendix 12, Appendix 13
Jul. 2017	SH(NA)-080779ENG-AF	<b>Addition</b> Section 3.4.3 <b>Correction</b> Section 1.3.1, Section 1.3.6, Section 1.3.11, Section 2.4, Section 6.1.1, Section 6.1.4, Section 14.10.2, Section 14.11, Section 21.1.1, Section 21.5, Appendix 2.5, Appendix 7, Appendix 12, Appendix 16, Appendix 18 <b>Modification</b> Section 3.4.3 → Section 3.4.4
Jan. 2018	SH(NA)-080779ENG-AG	<b>Correction</b> GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 1.3.4, Section 21.1.1, Appendix 2.3, Appendix 2.5, Appendix 12
Jun. 2018	SH(NA)-080779ENG-AH	<b>Correction</b> SAFETY PRECAUTIONS, Section 1.3.5, Section 1.3.7, Section 6.1, Appendix 1.7, Appendix 7, Appendix 12, Appendix 13
Dec. 2018	SH(NA)-080779ENG-AI	<b>Addition</b> Section 9.1.3, Section 15.1.6 <b>Correction</b> Section 1.3.1, Section 1.3.2, Section 1.3.3, Section 4.2.7, Section 4.3.2, Section 4.3.6, Section 14.2.1, Appendix 1.7, Appendix 7, Appendix 12 <b>Modification</b> Section 15.1.6 to Section 15.1.7 → Section 15.1.7 to Section 15.1.8
Jun. 2019	SH(NA)-080779ENG-AJ	<b>Correction</b> Section 1.3.7, Section 6.3.2, Section 11.5.18, Section 14.2.2, Section 14.6, Section 15.1, Appendix 7, Appendix 10.1, Appendix 12

Print date	Manual number*1	Revision
Dec. 2019	SH(NA)-080779ENG-AK	<b>Addition</b> Appendix 21 <b>Correction</b> Section 14.8.2, Appendix 2.5
Jun. 2020	SH(NA)-080779ENG-AL	<b>Correction</b> GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 2.1.1, Section 2.1.2, Section 2.1.8, Section 3.2.1, Section 4.2.1, Section 11.11, Section 14.2.2, Section 14.10.2, Section 14.13.1, Appendix 15, Appendix 16, Appendix 18, Appendix 21
Dec. 2020	SH(NA)-080779ENG-AM	<b>Correction</b> SAFETY PRECAUTIONS, CONDITIONS OF USE FOR THE PRODUCT, Section 15.1.4
Jun. 2021	SH(NA)-080779ENG-AN	<b>Correction</b> Section 4.11.1, Section 4.11.3, Section 6.1.3, Section 6.1.4, Section 6.3.2, Section 6.3.3, Section 10.2
Dec. 2021	SH(NA)-080779ENG-AO	<b>Correction</b> Section 4.2.4, Section 12.2, Appendix 7, Appendix 9, Appendix 12, Appendix 15
Sept. 2022	SH(NA)-080779ENG-AP	<b>Model Addition</b> Q04UDPV, Q06UDPV, Q13UDPV, Q26UDPV <b>Addition</b> COPYRIGHTS <b>Correction</b> GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL, Section 2.3, Section 2.4, Section 4.2.3, Section 4.8, Section 4.11, Section 4.12, Section 6.1.1, Section 6.1.3, Section 6.1.4, Section 6.3.2, Section 12.2, Section 15.1, Section 15.10.3, Section 15.11.1, Section 16.1, Section 16.2, Section 16.3, Section 16.5, Section 17.4, Section 19.7, Section 21.1.1, Section 21.5, Appendix 2.2, Appendix 2.3, Appendix 2.5, Appendix 4.2, Appendix 7, Appendix 10, Appendix 12, Appendix 13, Appendix 16, Appendix 18, Appendix 20, Appendix 21
May 2023	SH(NA)-080779ENG-AQ	<b>Correction</b> SAFETY PRECAUTIONS, Section 1.3.1, Section 1.3.7, Section 3.2.1, Section 6.3.2, Section 6.3.4, Section 15.1.2, Appendix 12, Appendix 18

\*1 : The manual number is written at the bottom left of the back cover.

Japanese Manual Version SH-080730-BD

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2008 MITSUBISHI ELECTRIC CORPORATION

# INTRODUCTION

---

Thank you for purchasing the engineering software, MELSOFT series.

Before using the product, thoroughly read this manual to develop full familiarity with the functions and performance to ensure correct use.

Note that the menu names and operating procedures may differ depending on an operating system in use and its version. When reading this manual, replace the names and procedures with the applicable ones as necessary.

## CONTENTS

---

SAFETY PRECAUTIONS .....	A - 1
CONDITIONS OF USE FOR THE PRODUCT.....	A - 2
REVISIONS .....	A - 3
INTRODUCTION .....	A - 13
CONTENTS .....	A - 13
MANUALS .....	A - 27
GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL.....	A - 35
TERMS.....	A - 38

## 1 OVERVIEW

---

1.1	Product Overview	1 - 2
1.2	Features	1 - 4
1.3	List of Functions	1 - 9
1.3.1	List of functions common to Simple project and Structured project .....	1 - 9
1.3.2	List of functions for editing in Ladder Diagram .....	1 - 23
1.3.3	List of functions for editing SFC diagrams .....	1 - 26
1.3.4	List of functions for editing SFC block list. ....	1 - 27
1.3.5	List of functions for editing in Structured Text .....	1 - 28
1.3.6	List of functions for editing in Structured Ladder/FBD .....	1 - 29
1.3.7	List of functions for CC IE Field Configuration window. ....	1 - 32
1.3.8	List of functions for CC-Link Configuration window .....	1 - 34
1.3.9	List of functions for AnyWireASLINK Configuration window. ....	1 - 35
1.3.10	List of Ethernet Configuration window .....	1 - 36
1.3.11	List of CC-Link IEF Basic Configuration window .....	1 - 37
1.3.12	List of functions for the Sensor/Device Monitor screen .....	1 - 37
1.3.13	List of functions for GX Simulator2 screen .....	1 - 38
1.3.14	List of functions for I/O system setting screen .....	1 - 39
1.3.15	List of functions for predefined protocol support function.....	1 - 40

## 2 SYSTEM CONFIGURATION

---

2.1	Connection from USB/Serial Port	2 - 2
2.1.1	USB cables (compatible with QCPU (Q mode), LCPU, and communication head module) . . . .	2 - 4
2.1.2	USB cables and function expansion boards (compatible with FX3U/FX3UC) .....	2 - 5
2.1.3	USB cables (compatible with FX3S, FX3G and FX3GC) .....	2 - 5

2.1.4	RS-232 cables (compatible with QCPU (Q mode), LCPU, and remote I/O module) . . . . .	2 - 6
2.1.5	Converters/cables for RS-232 connection (compatible with FXCPU) . . . . .	2 - 6
2.1.6	Connection using function expansion boards (compatible with FXCPU) . . . . .	2 - 7
2.1.7	Connection using RS-232 cables and function expansion boards (special adapters) (compatible with FXCPU) . . . . .	2 - 9
2.1.8	Converters/cables for USB connection (compatible with FXCPU) . . . . .	2 - 12
2.1.9	Connection via AJ65BT-R2N . . . . .	2 - 12
2.1.10	Function expansion board (special adapter) . . . . .	2 - 13
2.1.11	Connection via GOT . . . . .	2 - 13
2.2	Connection from I/F Boards . . . . .	2 - 14
2.2.1	I/F boards . . . . .	2 - 15
2.3	Interfaces and Connectable Modules . . . . .	2 - 16
2.4	System Configuration with Memory Card on Personal Computer . . . . .	2 - 20
2.5	Supported Programming Languages . . . . .	2 - 21

### **3 SCREEN CONFIGURATION AND BASIC OPERATIONS**

---

3.1	Starting and Exiting GX Works2 . . . . .	3 - 2
3.2	Screen Configuration and Basic Operations . . . . .	3 - 3
3.2.1	Main frame configuration . . . . .	3 - 3
3.2.2	Toolbars . . . . .	3 - 5
3.2.3	Work windows . . . . .	3 - 11
3.2.4	Docking windows . . . . .	3 - 17
3.2.5	Navigation window . . . . .	3 - 20
3.2.6	Status bar . . . . .	3 - 23
3.2.7	Changing colors and fonts . . . . .	3 - 24
3.2.8	Customizing shortcut keys . . . . .	3 - 27
3.3	Selecting Language . . . . .	3 - 30
3.4	Help Function . . . . .	3 - 32
3.4.1	Displaying GX Works2 help . . . . .	3 - 32
3.4.2	Displaying operating manuals . . . . .	3 - 35
3.4.3	Connecting to MITSUBISHI ELECTRIC FA Global Website . . . . .	3 - 36
3.4.4	Checking version of GX Works2 . . . . .	3 - 36

### **4 PROJECT MANAGEMENT**

---

4.1	GX Works2 Project Management . . . . .	4 - 2
4.1.1	Workspace format . . . . .	4 - 2
4.1.2	Single file format . . . . .	4 - 4
4.1.3	Project . . . . .	4 - 5
4.2	Project Operations . . . . .	4 - 9
4.2.1	Creating projects . . . . .	4 - 9
4.2.2	Opening existing projects . . . . .	4 - 12
4.2.3	Saving projects . . . . .	4 - 14
4.2.4	Saving projects with compression and decompressing projects . . . . .	4 - 16
4.2.5	Deleting projects . . . . .	4 - 19

4.2.6	Closing projects .....	4 - 20
4.2.7	Verifying project data .....	4 - 20
4.2.8	Changing programmable controller type of projects .....	4 - 28
4.3	Operations of Programmable Controller CPU Data .....	4 - 34
4.3.1	Adding new data to project .....	4 - 34
4.3.2	Copying/pasting data in projects .....	4 - 36
4.3.3	Changing project data names .....	4 - 38
4.3.4	Deleting project data .....	4 - 38
4.3.5	Merging data .....	4 - 39
4.3.6	Displaying/editing properties .....	4 - 42
4.4	Operations of Intelligent Function Module Data .....	4 - 45
4.5	Changing Project Types .....	4 - 46
4.6	Managing Project Revisions .....	4 - 47
4.6.1	Registering revision information (creating backup) .....	4 - 47
4.6.2	Displaying revision list .....	4 - 48
4.6.3	Restoring backup projects .....	4 - 49
4.6.4	Deleting revision information .....	4 - 51
4.6.5	Verifying revisions .....	4 - 51
4.7	Utilizing Projects and Data in Other Formats .....	4 - 53
4.7.1	Opening projects in other formats .....	4 - 56
4.7.2	Reading ASC format data .....	4 - 59
4.8	Saving Projects in Other Formats .....	4 - 60
4.9	Starting GX Developer from GX Works2 .....	4 - 61
4.10	Setting Security for Projects .....	4 - 62
4.10.1	Setting/resetting security of projects .....	4 - 65
4.10.2	Managing (adding/deleting/changing) users .....	4 - 66
4.10.3	Logging in projects .....	4 - 69
4.10.4	Changing access authority of access level .....	4 - 70
4.10.5	Considerations for using the security function .....	4 - 71
4.11	Setting Security Key .....	4 - 72
4.11.1	Managing security key .....	4 - 73
4.11.2	Locking project with security key .....	4 - 79
4.11.3	Considerations of security keys .....	4 - 80
4.12	Protecting POUs in Projects .....	4 - 81
4.12.1	Managing (setting/unlocking/deleting) block passwords .....	4 - 82
4.12.2	Setting/changing block passwords .....	4 - 83
4.12.3	Unlocking block passwords .....	4 - 84
4.12.4	Considerations for a block password .....	4 - 85
4.13	Managing Profiles .....	4 - 89
4.13.1	Registering profiles .....	4 - 89
4.13.2	Deleting profiles .....	4 - 91

## 5 EDITING PROGRAMS

---

5.1	Programming .....	5 - 2
-----	-------------------	-------

---

5.2	Label Programming	5 - 2
5.3	Considerations for Using Label Projects	5 - 4
5.3.1	Editing programs	5 - 4
5.3.2	Writing programs to programmable controller CPU (Write to PLC/Online program change)	5 - 6
5.3.3	Reading programs from programmable controller CPU (Read from PLC)	5 - 7
5.3.4	Verifying programs	5 - 8
5.3.5	Monitoring programs	5 - 8
5.4	Converting/Compiling Projects	5 - 9

## 6 SETTING PARAMETERS

6.1	Setting PLC Parameters	6 - 2
6.1.1	PLC parameter item list	6 - 4
6.1.2	Checking duplications of X/Y assignment among parameters	6 - 18
6.1.3	Setting open setting on Ethernet Configuration window	6 - 20
6.1.4	Setting the station information in the CC-Link IEF Basic configuration window	6 - 28
6.2	Setting Redundant Parameters	6 - 36
6.3	Setting Network Parameters	6 - 37
6.3.1	Network parameter item list	6 - 40
6.3.2	Setting station information on CC IE Field Configuration window	6 - 46
6.3.3	Setting station information on CC-Link Configuration window	6 - 60
6.3.4	Checking devices assigned to CC-Link IE Field Network and CC-Link modules	6 - 70
6.4	Setting Remote Password	6 - 74
6.5	Checking Parameters	6 - 76
6.6	Outputting Parameters to CSV Files	6 - 77
6.7	Setting default parameters	6 - 79

## 7 SETTING DEVICE MEMORY

7.1	Device Memory	7 - 2
7.1.1	Features of device memory	7 - 2
7.1.2	List of devices selectable on the Input Devices screen	7 - 3
7.2	Setting Device Memory	7 - 5
7.2.1	Setting device values in units of points	7 - 7
7.2.2	Setting device values by specifying device range	7 - 8
7.2.3	Setting character strings	7 - 11
7.2.4	Setting same value simultaneously	7 - 12
7.2.5	Changing display format	7 - 13
7.2.6	Changing the number of rows/columns on device memory editor	7 - 14
7.3	Searching Devices	7 - 15
7.4	Writing/Reading Device Memory Data	7 - 16
7.4.1	Writing/reading data to/from programmable controller CPUs	7 - 16
7.4.2	Writing/reading data to/from Excel files	7 - 17

## 8 SETTING DEVICE INITIAL VALUES

---

8.1	Device Initial Values	8 - 2
8.1.1	Feature of device initial values	8 - 2
8.1.2	List of applicable devices for device initial values	8 - 3
8.1.3	Procedure for setting device initial values	8 - 4
8.2	Setting Device Initial Values	8 - 5

---

## 9 SETTING DEVICE COMMENTS

---

9.1	Device Comments	9 - 2
9.1.1	Global device comments/local device comments	9 - 2
9.1.2	List of device comment applicable devices	9 - 8
9.1.3	Changing text size on the device comment editor	9 - 10
9.2	Creating Device Comments	9 - 11
9.2.1	Creating comments on the device comment editor	9 - 11
9.2.2	Creating comments on the ladder editor	9 - 13
9.3	Deleting Device Comments	9 - 15
9.3.1	Deleting comments of all devices	9 - 15
9.3.2	Deleting comments of devices being displayed	9 - 15
9.3.3	Deleting unused device comments	9 - 15
9.4	Extending Number of Points of Device Comment	9 - 16
9.5	Utilizing Sample Comments	9 - 17
9.5.1	Utilizing sample comments of special relays/special registers	9 - 17
9.5.2	Utilizing sample comments of intelligent function modules	9 - 18
9.6	Writing/Reading Device Comments to CSV Files	9 - 19
9.6.1	Writing/reading device comments	9 - 19
9.6.2	Writing/Reading local device comments in a batch	9 - 22
9.6.3	CSV file format	9 - 24

---

## 10 SEARCH/REPLACE

---

10.1	Cross Reference	10 - 2
10.1.1	Creating/displaying cross reference information	10 - 2
10.1.2	Setting conditions	10 - 9
10.1.3	Filtering display	10 - 11
10.2	Device List	10 - 13
10.2.1	Displaying device list	10 - 13
10.3	Search/Replacement	10 - 17
10.3.1	Searching/replacing devices/labels	10 - 18
10.3.2	Searching/replacing instructions	10 - 23
10.3.3	Searching/replacing character strings	10 - 25
10.3.4	Changing contacts between open contact and closed contact	10 - 27
10.3.5	Batch replacing devices	10 - 29
10.3.6	Displaying results and error logs	10 - 31

---

## 11 PRINTING

---

11.1	Print Function	11 - 2
11.2	Setting Printer	11 - 4
11.3	Batch Printing Project Data	11 - 5
11.3.1	Setting printer for batch print	11 - 7
11.4	Page Set Up for Batch Print	11 - 8
11.5	Setting Details of Batch Print	11 - 10
11.5.1	Setting common items (batch-print setting for user library data)	11 - 10
11.5.2	Setting batch print for cover	11 - 12
11.5.3	Setting batch print for PLC parameter	11 - 13
11.5.4	Setting batch print for redundant parameters	11 - 14
11.5.5	Setting batch print for network parameter	11 - 15
11.5.6	Setting batch print for program settings	11 - 16
11.5.7	Setting batch print for ladder programs	11 - 17
11.5.8	Setting batch print for MELSAP3 programs	11 - 20
11.5.9	Setting batch print for MELSAP-L programs	11 - 22
11.5.10	Setting batch print for ST programs	11 - 24
11.5.11	Setting batch print for Structured Ladder/FBD programs	11 - 25
11.5.12	Setting batch print for FB/FUN programs	11 - 26
11.5.13	Setting batch print for labels	11 - 28
11.5.14	Setting batch print for device comments	11 - 29
11.5.15	Setting batch print for device memory data	11 - 30
11.5.16	Setting batch print for device initial values	11 - 31
11.5.17	Setting batch print for TC setting values	11 - 32
11.5.18	Setting batch print for device list	11 - 33
11.5.19	Setting batch print for cross reference information	11 - 35
11.5.20	Setting batch print for statements/notes	11 - 36
11.5.21	Setting batch print for product information list	11 - 37
11.6	Displaying Batch Print Preview	11 - 38
11.7	Printing Data Displayed on Screen	11 - 39
11.8	Setting Print Details for Data Displayed on Screen	11 - 40
11.8.1	Setting print details for ladder programs	11 - 40
11.8.2	Setting print details for device initial values	11 - 42
11.9	Previewing Print Images	11 - 43
11.10	Printing Examples	11 - 44
11.11	Considerations for Printing	11 - 52

## 12 SETTING OPTIONS

---

12.1	Basic Operations	12 - 2
12.2	Option Setting List	12 - 4



## 13 USING LIBRARIES

---

13.1	Libraries	13 - 2
13.1.1	FB libraries	13 - 3
13.1.2	User libraries	13 - 4

## 14 SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

---

14.1	Setting Connection Destinations	14 - 2
14.1.1	Transfer setup screen	14 - 3
14.1.2	Creating connections	14 - 6
14.1.3	Specifying connection destination for regular use	14 - 7
14.2	Accessing Programmable Controller CPU Directly	14 - 8
14.2.1	Connecting with serial/USB cable	14 - 8
14.2.2	Accessing by Ethernet	14 - 12
14.3	Accessing Programmable Controller CPU Via Networks	14 - 15
14.4	Accessing Programmable Controller CPU in Multiple CPU System	14 - 22
14.5	Accessing Redundant CPUs	14 - 25
14.5.1	Considerations for routing intelligent function module on extension base unit	14 - 27
14.5.2	Operation when system switching occurs on Redundant CPU	14 - 28
14.5.3	Operation when communication error occurs during monitoring	14 - 29
14.6	Accessing Programmable Controller CPU via Ethernet Board	14 - 33
14.7	Accessing Programmable Controller CPU via G4 Module	14 - 35
14.8	Setting for Access via Serial Communication Module	14 - 36
14.8.1	Connection on a 1:1 basis	14 - 36
14.8.2	Connection on a 1:n basis	14 - 37
14.9	Setting for Access via GOT (GOT Transparent Function)	14 - 40
14.9.1	Accessing programmable controller CPU via GOT	14 - 41
14.9.2	Accessing programmable controller CPU via serial communication module	14 - 44
14.9.3	Accessing programmable controller CPU via CC-Link IE Controller Network	14 - 46
14.9.4	Accessing programmable controller CPU via CC-Link IE Field Network	14 - 48
14.10	Accessing Programmable Controller CPU via Phone Line	14 - 50
14.10.1	Setting TEL data	14 - 58
14.10.2	Connecting/disconnecting line	14 - 64
14.10.3	Setting options	14 - 71
14.11	Considerations of Communication with Programmable Controller CPU	14 - 72

## 15 WRITING/READING DATA

---

15.1	Writing or Reading Data to/from Programmable Controller CPU	15 - 2
15.1.1	Setting write/read range of program (program file)	15 - 7
15.1.2	Setting write/read range of device data	15 - 8
15.1.3	Setting range of device comment to be written/read	15 - 11
15.1.4	Writing/reading intelligent function module data	15 - 14

15.1.5	Symbolic information . . . . .	15 - 19
15.1.6	Reading the remaining steps for Online program change . . . . .	15 - 22
15.1.7	Specifying target to write device comments to programmable controller CPU . . . . .	15 - 23
15.1.8	Considerations for writing/reading data to/from programmable controller CPU . . . . .	15 - 24
15.2	Verifying Data on Programmable Controller CPU against Data on Personal Computer . . . . .	15 - 29
<hr/>		
15.3	Deleting Programmable Controller CPU Data . . . . .	15 - 34
<hr/>		
15.4	Copying Program Memory Data to ROM . . . . .	15 - 35
<hr/>		
15.5	Writing/Reading/Deleting PLC User Data . . . . .	15 - 36
<hr/>		
15.6	Transferring Data to Program Memory in Batch . . . . .	15 - 38
<hr/>		
15.7	Latch Data Backup . . . . .	15 - 40
15.7.1	Backing up latch data . . . . .	15 - 40
15.7.2	Deleting backup data . . . . .	15 - 41
<hr/>		
15.8	Backing up/Restoring Data . . . . .	15 - 42
15.8.1	Backing up data to memory card . . . . .	15 - 42
15.8.2	Restoring backup data . . . . .	15 - 44
<hr/>		
15.9	Online Program Change . . . . .	15 - 45
15.9.1	Performing Online program change during conversion/compile . . . . .	15 - 46
15.9.2	Performing Online program change in units of files . . . . .	15 - 53
15.9.3	Online program change starting from pointer . . . . .	15 - 55
15.9.4	Considerations for Online program change of rise, fall, or SCJ instruction . . . . .	15 - 56
15.9.5	Considerations of Online program change of SFC programs . . . . .	15 - 59
15.9.6	Considerations of each programmable controller series . . . . .	15 - 60
<hr/>		
15.10	Calculating Memory Size . . . . .	15 - 66
15.10.1	Offline calculation and Online calculation . . . . .	15 - 66
15.10.2	Setting target data for memory size calculation (QCPU (Q mode)/LCPU) . . . . .	15 - 66
15.10.3	Confirming result of memory size calculation (QCPU (Q mode)/LCPU) . . . . .	15 - 67
15.10.4	Confirming result of memory size calculation (FXCPU) . . . . .	15 - 70
15.10.5	Considerations of calculating memory size . . . . .	15 - 72
<hr/>		
15.11	Writing/Reading Data to/from Memory Cards . . . . .	15 - 73
15.11.1	Writing/reading data to/from ATA/SRAM/SD memory cards . . . . .	15 - 74
15.11.2	Writing/reading data to/from SD memory cards (batch save/batch load function) . . . . .	15 - 77
<hr/>		
15.12	Reading Data of Local Devices . . . . .	15 - 79

## 16 PROTECTING DATA

---

16.1	Functions to Protect Data . . . . .	16 - 2
<hr/>		
16.2	Registering/Changing Password (QCPU (Q mode)) . . . . .	16 - 3
16.2.1	Registering/changing password . . . . .	16 - 4
16.2.2	Canceling password . . . . .	16 - 6
16.2.3	Unlocking password temporarily . . . . .	16 - 7
<hr/>		
16.3	Registering/Changing Password (File Password 32) . . . . .	16 - 8
16.3.1	Registering/changing password . . . . .	16 - 9
16.3.2	Canceling password . . . . .	16 - 11
16.3.3	Unlocking password temporarily . . . . .	16 - 12

16.4	Registering/Changing Keyword (FXCPU)	16 - 14
16.4.1	Registering/changing keyword	16 - 14
16.4.2	Canceling keyword	16 - 16
16.4.3	Unlocking keyword temporarily	16 - 17
16.5	Locking with Security Key	16 - 18

## 17 MONITORING

---

17.1	Monitoring Function	17 - 2
17.1.1	Starting/stopping monitoring	17 - 2
17.1.2	Monitoring status	17 - 4
17.2	Monitoring Programs	17 - 7
17.3	Batch Monitoring Devices/Buffer Memory	17 - 8
17.4	Monitoring Program List	17 - 12
17.5	Monitoring Interrupt Program List	17 - 15
17.6	Registering and Monitoring Devices	17 - 16
17.6.1	Registering and monitoring devices	17 - 16
17.6.2	Registering devices	17 - 19
17.6.3	Changing display format (decimal/hexadecimal) of current values	17 - 23
17.6.4	Writing/reading data to/from CSV file	17 - 25
17.7	Monitoring Intelligent Function Modules	17 - 26
17.8	Starting/Stopping Monitoring All Windows	17 - 26
17.9	Using Realtime Monitor Function	17 - 27

## 18 SIMULATING PROGRAMS

---

18.1	Simulation Function	18 - 2
18.1.1	Safety and handling considerations of the simulation function	18 - 2
18.1.2	Functions available for simulation function	18 - 2
18.2	Starting/Stopping Simulation	18 - 4
18.2.1	Saving device memory/buffer memory	18 - 6
18.2.2	Reading device memory/buffer memory	18 - 6
18.2.3	List of device memory/buffer memory that can be saved/read	18 - 7
18.3	Checking unsupported instructions/devices	18 - 9

## 19 DEBUGGING PROGRAMS

---

19.1	Changing Current Values	19 - 2
19.1.1	Changing current value of devices/labels	19 - 2
19.1.2	Changing current value of buffer memory	19 - 5
19.2	Registering/Canceling Forced Input/Output	19 - 7
19.2.1	Registering/canceling forced input to/output from QCPU (Q mode)/LCPU	19 - 7
19.2.2	Registering/canceling forced input to/output from remote I/O module	19 - 9

19.3	Device Test with Execution Condition	19 - 10
19.3.1	Registering device test with execution condition	19 - 10
19.3.2	Checking/disabling registration of device test with execution condition	19 - 12
19.3.3	Batch disabling device test with execution condition	19 - 13
19.4	Sampling Trace	19 - 14
19.4.1	Opening sampling trace screen	19 - 14
19.4.2	Setting executing condition of sampling trace	19 - 15
19.4.3	Registering devices/labels	19 - 19
19.4.4	Executing sampling trace	19 - 22
19.4.5	Saving trace data	19 - 26
19.4.6	Applicable devices/labels for sampling trace	19 - 30
19.4.7	Considerations when performing sampling trace	19 - 32
19.4.8	Compatibility with sampling trace data in GX Developer	19 - 32
19.5	Measuring Scan Time	19 - 33
19.6	Debugging Programs with Simulation Function	19 - 35
19.6.1	Debugging procedure	19 - 38
19.6.2	Setting break points	19 - 39
19.6.3	Setting break devices	19 - 43
19.6.4	Setting skip ranges	19 - 45
19.6.5	Executing program one step at a time	19 - 47
19.6.6	Executing program until condition is satisfied	19 - 47
19.6.7	Canceling step execution	19 - 48
19.6.8	Setting options for step execution	19 - 49
19.6.9	Stopping step execution	19 - 50
19.7	Using CPU Module Logging Configuration Tool	19 - 51

## **20 OPERATING PROGRAMMABLE CONTROLLER CPU**

---

20.1	Remote Operation of Programmable Controller CPU	20 - 2
20.2	Operating Redundant CPUs	20 - 6
20.3	Formatting Programmable Controller CPU Memory	20 - 8
20.4	Clearing Programmable Controller Memory	20 - 10
20.5	Arranging Programmable Controller Memory	20 - 13
20.6	Setting Clock on Programmable Controller CPU	20 - 14
20.7	Registering/Canceling Display Module Menu	20 - 16
20.8	Start Ethernet Adapter Module Configuration Tool	20 - 18

## **21 DIAGNOSING PROGRAMMABLE CONTROLLER STATUS**

---

21.1	Diagnosing Programmable Controller CPU	21 - 2
21.1.1	Diagnosing QCPU (Q mode), LCPU, communication head module, and remote I/O module	21 - 2
21.1.2	Diagnosing FXCPU	21 - 9
21.1.3	Error icons	21 - 10

21.1.4	Online operations . . . . .	21 - 11
21.2	Diagnosing MELSECNET . . . . .	21 - 14
21.2.1	Network test . . . . .	21 - 16
21.2.2	Loop test. . . . .	21 - 18
21.2.3	Setting verification test . . . . .	21 - 19
21.2.4	Station order check test . . . . .	21 - 21
21.2.5	Communication test . . . . .	21 - 22
21.2.6	Error history monitoring . . . . .	21 - 24
21.2.7	Network monitor details . . . . .	21 - 25
21.2.8	Monitoring other station information . . . . .	21 - 26
21.3	Diagnosing CC-Link IE Controller Network . . . . .	21 - 28
21.3.1	Communication test . . . . .	21 - 32
21.3.2	IP communication test . . . . .	21 - 33
21.3.3	Link start/stop . . . . .	21 - 34
21.3.4	Logging. . . . .	21 - 36
21.4	Diagnosing CC-Link IE Field Network . . . . .	21 - 38
21.4.1	Communication test . . . . .	21 - 43
21.4.2	IP communication test . . . . .	21 - 44
21.4.3	Cable test . . . . .	21 - 45
21.4.4	Link start/stop . . . . .	21 - 46
21.4.5	Network event history . . . . .	21 - 47
21.4.6	Reserved station function enable . . . . .	21 - 49
21.4.7	Temporary error invalid station setting/restore . . . . .	21 - 50
21.5	Diagnosing CC-Link IE Field Network Basic . . . . .	21 - 51
21.6	Diagnosing CC-Link and CC-Link/LT . . . . .	21 - 53
21.6.1	Monitoring line (host station/other stations) . . . . .	21 - 53
21.6.2	Loop test/transmission speed test . . . . .	21 - 59
21.6.3	Displaying logs of station information (status logging) . . . . .	21 - 61
21.6.4	Creating check sheets . . . . .	21 - 63
21.6.5	Starting/stopping data link . . . . .	21 - 65
21.7	Diagnosing Ethernet . . . . .	21 - 66
21.7.1	Q series-compatible E71/L series-compatible E71 module . . . . .	21 - 66
21.7.2	Ethernet Built-in CPU, FXCPU with Ethernet adapter connection . . . . .	21 - 72
21.7.3	PING test . . . . .	21 - 79
21.7.4	Loopback test . . . . .	21 - 84
21.8	Executing Sensor/Device Monitoring . . . . .	21 - 88
21.9	System Monitor . . . . .	21 - 89
21.9.1	Checking module's detailed information . . . . .	21 - 99
21.9.2	Checking details of error history . . . . .	21 - 102
21.10	Changing Modules Online . . . . .	21 - 104
21.11	Built-in I/O Module Tools . . . . .	21 - 106
21.11.1	Positioning monitor . . . . .	21 - 106
21.11.2	High-speed counter monitor . . . . .	21 - 107
21.11.3	I/O monitor . . . . .	21 - 108

## 22 SIMULATING OPERATIONS OF EXTERNAL DEVICES

---

22.1	I/O System Setting Function	22 - 2
22.1.1	Differences between conventional debugging and debugging with I/O system setting function. . . . .	22 - 2
22.1.2	Conditions and sequence actions for simulation . . . . .	22 - 4
22.1.3	Timing chart input and device value input . . . . .	22 - 6
22.2	Operating Procedure of I/O System Setting Function	22 - 7
22.3	Screen Configuration of I/O System Setting Function	22 - 8
22.4	Setting by Inputting Device Values	22 - 10
22.4.1	Setting conditions. . . . .	22 - 11
22.4.2	Setting sequence actions. . . . .	22 - 13
22.5	Setting Using Timing Charts	22 - 15
22.5.1	Setting in timing chart format . . . . .	22 - 16
22.5.2	Screen configuration of Edit Timing Chart Format screen . . . . .	22 - 17
22.5.3	Registering devices . . . . .	22 - 18
22.5.4	Setting timing . . . . .	22 - 19
22.5.5	Setting number of scans of timing chart. . . . .	22 - 22
22.5.6	Utilizing timing chart data of existing applications . . . . .	22 - 23
22.5.7	Displaying list of registered devices. . . . .	22 - 24
22.5.8	Exchanging display positions of devices . . . . .	22 - 25
22.5.9	Changing display format of devices . . . . .	22 - 26
22.6	Performing I/O System Setting Function	22 - 27
22.6.1	Executing simulation . . . . .	22 - 27
22.6.2	Disabling simulation. . . . .	22 - 27
22.7	Monitoring I/O System Setting	22 - 28
22.7.1	Starting/stopping monitoring . . . . .	22 - 28
22.7.2	Changing current value of devices. . . . .	22 - 29
22.8	Operating I/O System Setting Files	22 - 30
22.8.1	Creating I/O system setting files . . . . .	22 - 30
22.8.2	Opening existing I/O system setting files . . . . .	22 - 30
22.8.3	Saving I/O system setting files . . . . .	22 - 30

## APPENDIX

---

Appendix 1	List of Toolbars and Shortcut Keys	App - 2
Appendix 1.1	Common toolbars and shortcut keys . . . . .	App - 2
Appendix 1.2	"Navigation Window" toolbar icons. . . . .	App - 6
Appendix 1.3	Toolbar icons and shortcut keys for setting labels . . . . .	App - 7
Appendix 1.4	Toolbar icons and shortcut keys for setting device memory . . . . .	App - 8
Appendix 1.5	Toolbar icons and shortcut keys for verification result . . . . .	App - 9
Appendix 1.6	Toolbar icons and shortcut keys for executing sampling trace. . . . .	App - 9
Appendix 1.7	Toolbar icons and shortcut keys for program editors . . . . .	App - 10
Appendix 1.8	Toolbar icons and shortcut keys for I/O system setting function . . . . .	App - 20
Appendix 1.9	Shortcut keys for operating intelligent function module . . . . .	App - 21
Appendix 2	Simulation Function	App - 22

---

Appendix 2.1	Supported CPU functions . . . . .	App - 22
Appendix 2.2	Supported devices . . . . .	App - 25
Appendix 2.3	Supported instructions . . . . .	App - 41
Appendix 2.4	Enable/disable setting of parameter items . . . . .	App - 49
Appendix 2.5	Restrictions and considerations . . . . .	App - 53
Appendix 3	ASCII Code Table	App - 61
Appendix 4	Considerations of GX Works2 and Differences with GX Developer	App - 62
Appendix 4.1	Before using GX Works2 . . . . .	App - 62
Appendix 4.2	Supported CPU modules . . . . .	App - 63
Appendix 4.3	Unsupported features . . . . .	App - 64
Appendix 4.4	Supported project types . . . . .	App - 65
Appendix 4.5	Programming languages supported by each project type . . . . .	App - 66
Appendix 4.6	Using device comments . . . . .	App - 70
Appendix 4.7	Using device memory . . . . .	App - 70
Appendix 4.8	Using device initial values . . . . .	App - 70
Appendix 4.9	Using search/replace function . . . . .	App - 71
Appendix 4.10	Using online function . . . . .	App - 72
Appendix 4.11	Using monitoring/debugging function . . . . .	App - 73
Appendix 4.12	Using printing function . . . . .	App - 73
Appendix 4.13	Copying saved project data . . . . .	App - 74
Appendix 4.14	Using PLC type change function . . . . .	App - 74
Appendix 4.15	Using program check function . . . . .	App - 74
Appendix 4.16	Using IC memory card function . . . . .	App - 74
Appendix 4.17	Compatibility with GX Developer . . . . .	App - 75
Appendix 4.18	Compatibility with GX IEC Developer . . . . .	App - 76
Appendix 4.19	Key operation . . . . .	App - 76
Appendix 4.20	Program titles . . . . .	App - 77
Appendix 5	Compatibility with Projects Created with Existing Applications	App - 78
Appendix 5.1	Application compatibility . . . . .	App - 78
Appendix 6	Compatibility of Data Read from Programmable Controller CPU	App - 81
Appendix 6.1	Application compatibility . . . . .	App - 81
Appendix 6.2	Data compatibility . . . . .	App - 85
Appendix 7	Compatibility with Existing Applications	App - 90
Appendix 8	Considerations When Saving Projects in GX Developer Format	App - 107
Appendix 8.1	ST instruction table for GX Works2 and GX Developer . . . . .	App - 108
Appendix 9	Character Strings that cannot be Used for Label Names and Data Names	App - 110
Appendix 10	Restrictions When Changing Programmable Controller Type	App - 113
Appendix 10.1	Common restrictions when changing programmable controller series/types . . . . .	App - 114
Appendix 10.2	Restrictions when changing to QnUD(H)CPU . . . . .	App - 116
Appendix 10.3	Restrictions when changing to Q00U, Q00UJ, Q01U, or Q02U . . . . .	App - 121
Appendix 10.4	Restrictions when changing to QnUDE(H)CPU . . . . .	App - 129
Appendix 10.5	Restrictions when changing to High-speed Universal model QCPU or Universal model process CPU . . . . .	App - 133
Appendix 10.6	Restrictions when changing to Redundant CPU . . . . .	App - 137
Appendix 10.7	Restrictions when changing to Process CPU . . . . .	App - 139
Appendix 10.8	Restrictions when changing to High Performance model QCPU . . . . .	App - 141
Appendix 10.9	Restrictions when changing to Basic model QCPU . . . . .	App - 145

Appendix 10.10	Restrictions when changing to LCPU . . . . .	App - 151
Appendix 10.11	Restrictions when changing between QCPU (Q mode)/LCPU and CC IE Field head module . . . . .	App - 160
Appendix 10.12	Restrictions when changing to FXCPU (FXCPU ⇔ FXCPU). . . . .	App - 161
Appendix 11	Instruction Conversion Lists . . . . .	App - 162
Appendix 11.1	Instruction conversion for Universal model QCPU ⇔ CPU other than Universal model QCPU conversion . . . . .	App - 162
Appendix 11.2	Instruction conversion for Redundant CPU ⇔ CPU other than Redundant CPU conversion . . . . .	App - 164
Appendix 12	Functions Added Since Previous Versions . . . . .	App - 166
Appendix 13	Supported Versions of Modules . . . . .	App - 193
Appendix 14	Procedure to Use GX Works2 Unsupported Programmable Controller Type . . . . .	App - 196
Appendix 14.1	Installing GX Developer . . . . .	App - 196
Appendix 14.2	Utilizing programs of GX Works2 unsupported programmable controller type in GX Works2. . . . .	App - 199
Appendix 15	Considerations of installation and uninstallation . . . . .	App - 200
Appendix 15.1	Considerations of installation . . . . .	App - 200
Appendix 15.2	Considerations of uninstallation . . . . .	App - 202
Appendix 16	USB Driver Installation . . . . .	App - 203
Appendix 17	Considerations When Using English Version of GX Works2 . . . . .	App - 204
Appendix 17.1	Data to which double byte character and half-width Japanese kana character are applicable. . . . .	App - 205
Appendix 17.2	Considerations . . . . .	App - 208
Appendix 18	Considerations for Selecting Project Language . . . . .	App - 210
Appendix 19	Modifying Instructions of Projects in Other Formats . . . . .	App - 213
Appendix 19.1	Replacing instruction names . . . . .	App - 214
Appendix 19.2	Adding devices/labels. . . . .	App - 215
Appendix 19.3	Changing positions of devices/labels . . . . .	App - 217
Appendix 19.4	Changing arguments to constants . . . . .	App - 218
Appendix 19.5	Changing label data types to double-precision real number . . . . .	App - 219
Appendix 19.6	Changing label data types . . . . .	App - 221
Appendix 19.7	Changing number of array elements of array data type labels. . . . .	App - 222
Appendix 19.8	Changing label data type to array data type. . . . .	App - 223
Appendix 20	Considerations When Using Projects Created in PX Developer . . . . .	App - 225
Appendix 21	Troubleshooting . . . . .	App - 227

## INDEX

---

TRADEMARKS  
COPYRIGHTS



## ■ MANUALS

Related manuals are separately issued according to the purpose of their functions in GX Works2.

### ● Related manuals

The manuals related to this product are shown below.

Refer to the following tables when ordering required manuals.

#### 1) Operation of GX Works2

Manual name	Manual number (Model code)
GX Works2 Version 1 Operating Manual (Common) Explains the system configuration of GX Works2 and the functions common to Simple project and Structured project such as parameter setting, operation method for the online function. (Sold separately)	SH-080779ENG (13JU63) (this manual)
GX Works2 Version 1 Operating Manual (Simple Project) Explains methods for such as creating and monitoring programs in Simple project of GX Works2. (Sold separately)	SH-080780ENG (13JU64)
GX Works2 Version 1 Operating Manual (Simple Project, Function Block) Explains methods for such as creating function blocks, pasting function blocks to sequence programs, and operating FB library in Simple project of GX Works2. (Sold separately)	SH-080984ENG (13JU72)
GX Works2 Version 1 Operating Manual (Structured Project) Explains methods for such as creating and monitoring programs in Structured project of GX Works2. (Sold separately)	SH-080781ENG (13JU65)
GX Works2 Version 1 Operating Manual (Intelligent Function Module) Explains methods of intelligent function module for such as parameter setting, monitoring programs, and predefined protocol support function in GX Works2. (Sold separately)	SH-080921ENG (13JU69)
GX Works2 Beginner's Manual (Simple Project) Explains fundamental methods for such as creating, editing, and monitoring programs in Simple project for users inexperienced with GX Works2. (Sold separately)	SH-080787ENG (13JZ22)
GX Works2 Beginner's Manual (Structured Project) Explains fundamental methods for such as creating, editing, and monitoring programs in Structured project for users inexperienced with GX Works2. (Sold separately)	SH-080788ENG (13JZ23)

#### 2) Structured programming

Manual name	Manual number (Model code)
MELSEC-Q/L/F Structured Programming Manual (Fundamentals) Explains the programming methods, types of programming languages, and other information required to create structured programs. (Sold separately)	SH-080782ENG (13JW06)
MELSEC-Q/L Structured Programming Manual (Common Instructions) Explains the specifications and functions of common instructions such as sequence instructions, basic instructions, and application instructions, that can be used in structured programs. (Sold separately)	SH-080783ENG (13JW07)
MELSEC-Q/L Structured Programming Manual (Application Functions) Explains the specifications and functions of application functions that can be used in structured programs. (Sold separately)	SH-080784ENG (13JW08)
MELSEC-Q/L Structured Programming Manual (Special Instructions) Explains the specifications and functions of special instructions such as module dedicated instruction, PID control instruction, and built-in I/O function dedicated instruction, that can be used in structured programs. (Sold separately)	SH-080785ENG (13JW09)
FXCPU Structured Programming Manual [Device & Common] Explains the devices and parameters provided in GX Works2 for structured programming. (Sold separately)	JY997D26001 (09R925)
FXCPU Structured Programming Manual [Basic & Applied Instruction] Explains the sequence instructions provided in GX Works2 for structured programming. (Sold separately)	JY997D34701 (09R926)
FXCPU Structured Programming Manual [Application Functions] Explains the application functions provided in GX Works2 for structured programming. (Sold separately)	JY997D34801 (09R927)

### 3) Operation of iQ Works

Manual name	Manual number (Model code)
Let's start iQ Works Version 2 Explains fundamental methods for such as managing the system using MELSOFT Navigator and using system labels for users inexperienced with GX Works2. (Sold separately)	SH-081261ENG (13JZ79)

### 4) iQ Sensor Solution

Manual name	Manual number (Model code)
iQ Sensor Solution Reference Manual Explains the operation methods for online functions in iQ Sensor Solution. (Sold separately)	SH-081133ENG (13JV28)

### 5) CC-Link IE Field Network Basic

Manual name	Manual number (Model code)
CC-Link IE Field Network Basic Reference Manual Explains the operation methods for online functions in CC-Link IE Field Network Basic. (Sold separately)	SH-081684ENG (13JX62)

#### **Point**



The Operating Manuals are included on the DVD and CD of the software package in a PDF file format. Manuals in printed form are sold separately for single purchase. Order a manual by quoting the manual number (model code) listed in the table above.

● **Purpose of this manual**











This manual explains the functions that are common to Simple project and Structured project, including system configuration, parameter settings, and operation methods for online functions of GX Works2. Manuals for reference are listed in the following table according to their purpose.

For information such as the content and number of each manual, refer to the list of 'Related manuals'.

**1) Installation of GX Works2 and USB driver**















Purpose	GX Works2 Installation Instructions	GX Works2 Version 1 Operating Manual
		Common
Learning the operating environment and installation method		
Learning a USB driver installation method		

**2) Operation of GX Works2**

Purpose	GX Works2 Beginner's Manual		GX Works2 Version 1 Operating Manual				
	Simple Project	Structured Project	Common	Simple Project		Structured Project	Intelligent Function Module
					Function Block		
Learning all functions of GX Works2							
Learning the project types and available languages in GX Works2							
Learning the basic operations and operating procedures when creating a simple project for the first time							
Learning the basic operations and operating procedures when creating a structured project for the first time							
Learning the operations of available functions regardless of project type.							
Learning the functions and operation methods for programming							
Learning the operations and operating procedures when creating function blocks (FB) in Simple project.							
Learning data setting methods for intelligent function module							
















### 3) Operations in each programming language

For details of instructions used in each programming language, refer to the section 4 and the section 5 on the following pages.











Purpose		GX Works2 Beginner's Manual		GX Works2 Version 1 Operating Manual	
		Simple Project	Structured Project	Simple Project	Structured Project
Simple Project	Ladder Diagram				
	Sequential Function Chart				
	Structured Text				
Structured Project	Ladder Diagram				
	Sequential Function Chart				
	Structured Ladder/ FBD				
	Structured Text				

\*1 : MELSP3 and FX series SFC only

#### 4) Details of instructions in each programming language (for QCPU (Q mode)/LCPU)

Purpose		MELSEC-Q/L/F Structured Programming Manual	MELSEC-Q/L Structured Programming Manual			MELSEC-Q/L Programming Manual	MELSEC-Q/L/QnA Programming Manual		Manual for module to be used
		Fundamentals	Common Instructions	Special Instructions	Application Functions	Common Instruction	PID Control Instructions	SFC	-
All languages	Learning details of programmable controller CPU error codes, special relays, and special registers								
	Learning the types and details of common instructions								
Using Ladder Diagram	Learning the types and details of instructions for intelligent function modules								
	Learning the types and details of instructions for network modules								
	Learning the types and details of instructions for the PID control function								
	Learning details of specifications, functions, and instructions of SFC (MELSAP3)								
Using Structured Ladder/ FBD or Structured Text	Learning the fundamentals for creating a structured program								
	Learning the types and details of common instructions								
	Learning the types and details of instructions for intelligent function modules								
	Learning the types and details of instructions for network modules								
	Learning the types and details of instructions for the PID control function								
	Learning the types and details of application functions								

5) Details of instructions in each programming language (for FXCPU)

Purpose		MELSEC-Q/L/F Structured Programming Manual	FXCPU Structured Programming Manual			FXCPU Programming Manual		
		Fundamentals	Device & Common	Basic & Applied Instruction	Application Functions	FX0, FX0S, FX0N, FX1, FXU, FX2C	FX1S, FX1N, FX2N, FX1NC, FX2NC	FX3S, FX3G, FX3U, FX3GC, FX3UC
Using Ladder Diagram	Learning the types and details of basic/application instructions, descriptions of devices and parameters							
Using Sequential Function Chart	Learning details of specifications, functions, and instructions of SFC							
Using Structured Ladder/FBD or Structured Text	Learning the fundamentals for creating a structured program							
	Learning the descriptions of devices, parameters, and error codes							
	Learning the types and details of sequence instructions							
	Learning the types and details of application instructions							

● How to read this manual

**Supported CPU**  
Supported programmable controller CPUs are shown in icons under the section title.

**Screen display**  
Describes the screen display procedure. Follow the ⇒ and select [(menu)] to open the screen. \*Screen display may differ depending on the CPU type. In that case, typical example is described.

**Display contents**  
Describes the display contents on the screen.

**Reference location**  
⇒ leads to the reference location and reference manual.

**Section title**  
Clarifies the section of currently open page.

**Chapter heading**  
Index on the right of the page number clarifies the chapter of currently open page.

**Screen button**  
Describes the buttons in the screen.

**Operating procedure**  
Describes the operating procedure of the function.


6 SETTING PARAMETERS

6.1 Setting PLC Parameters

Q CPU L CPU Remote Head FX

This section explains how to set PLC parameters.

**Screen display**  
Select Project view ⇒ "Parameter" ⇒ "PLC Parameter".



**Display contents**

Item	Description										
Tab	The setting items are categorized under tabs according to their purpose. • The parameter setting status is displayed by different font colors of the tab names.										
	<table border="1"> <thead> <tr> <th>Font color</th> <th>Setting status</th> </tr> </thead> <tbody> <tr> <td>Red</td> <td>Status that data is not set under the tab (Data must be set under the tab for operation.)</td> </tr> <tr> <td>Blue</td> <td>Status that data is set under the tab (A red tab name changes to blue after data is set.)</td> </tr> <tr> <td>Magenta</td> <td>Default values (The user settings are not set under the tab.)</td> </tr> <tr> <td>Dark blue</td> <td>Values other than default values (A magenta tab name changes to dark blue after data is set.)</td> </tr> </tbody> </table>	Font color	Setting status	Red	Status that data is not set under the tab (Data must be set under the tab for operation.)	Blue	Status that data is set under the tab (A red tab name changes to blue after data is set.)	Magenta	Default values (The user settings are not set under the tab.)	Dark blue	Values other than default values (A magenta tab name changes to dark blue after data is set.)
Font color	Setting status										
Red	Status that data is not set under the tab (Data must be set under the tab for operation.)										
Blue	Status that data is set under the tab (A red tab name changes to blue after data is set.)										
Magenta	Default values (The user settings are not set under the tab.)										
Dark blue	Values other than default values (A magenta tab name changes to dark blue after data is set.)										
	• Details of the setting items ⇒ Section 6.1.1										

6-2 6.1 Setting PLC Parameter

4.9 Setting Security for Projects


**Screen button**

- Add...  
Adds a user. (⇒ Adding users)
- Delete...  
Deletes a user selected in the list. The current login user cannot be deleted. If registered users are only 'Administrators' and there are no other users to be deleted, deletion of the current login user is possible. If 'Administrators' level users are deleted, security is reset.
- Change...  
Changes the information of the user selected in the list. (⇒ Changing user information)
- Password Setup...  
Changes the password of the user selected in the list. (⇒ Changing passwords)  
The password of the current login user cannot be changed using this function. To change it, select [Project] ⇒ [Security] ⇒ [Change Password].

■ Adding users  
Add a user to a project with security.  
A user whose access level is higher than that of the login user cannot be added.

**Operating procedure**

1. Click the Add... button on the User Management screen.  
The User Addition screen is displayed.



1 OVERVIEW  
2 SYSTEM CONFIGURATION  
3 BASIC OPERATIONS  
4 PROJECT MANAGEMENT  
5 EDITING PROGRAMS

The following table explains the CPU module icons that indicate the function availability.

Icon					Description
QCPU (Q mode)	LCPU	Remote I/O	Communication head module	FXCPU	
					Normal icons indicate that the corresponding function is available.
		-			Icons with * (asterisk) symbol indicate that the corresponding function is available with restrictions such as CPU types.
					Icons with × symbol indicate that the corresponding function is not available.

This manual also uses the following columns:

**Point!**


This indicates notes requiring attention or useful functions relating to the information given on the same page.

**Restrictions!**

This indicates restrictions relating to the information given on the same page.

### ● Symbols used in this manual

The following shows the symbols used in this manual with descriptions and examples.



No.	Symbol	Description	Example
①	[ ]	Menu name on a menu bar	[Project]
②		Toolbar icon	
③	( <u>Underline</u> )	Screen name	Q Parameter Setting screen
④	« »	Tab name in a screen	<<PLC System>>
⑤	" "	Item name in a screen	"Timer Limit Setting"
⑥		Button on a screen	High Speed Interrupt Setting button
-		Keyboard key	Ctrl



## ■ GENERIC TERMS AND ABBREVIATIONS IN THIS MANUAL

The following are the generic terms/abbreviations of such as software packages and programmable controller CPUs used in this manual.

Generic term and abbreviation	Description
GX Works2	Generic product name for SWnDND-GXW2-E and SWnDNC-GXW2-E (n: version)
Existing application	–
GX Developer	Generic product name for SWnD5C-GPPW-E, SWnD5C-GPPW-EA, SWnD5C-GPPW-EV, and SWnD5C-GPPW-EVA (n: version)
GX IEC Developer	Product name for SWnD5C-MEDOC3 (n: version)
GX Simulator	Generic product name for SWnD5C-LLT-E, SWnD5C-LLT-EA, SWnD5C-LLT-EV, and SWnD5C-LLT-EVA (n: version)
GX Configurator	Generic product name for GX Configurator-AD/DA/SC/CT/TC/TI/FL/PT/AS/QP
MELSOFT Navigator	Product name for the integrated development environment included in SWnDNC-IQWK and SWnDND-IQWK (MELSOFT iQ Works) (n: version)
iQ Works	Abbreviation for MELSOFT iQ Works
iQ AppPortal	Generic product name for SWnDND-IQAPL-M (n: version)
GX Simulator2	Abbreviation for GX Works2 simulation function
Personal computer	Generic term for personal computer on which Windows® operates
Q series	Abbreviation for Mitsubishi Electric programmable controller MELSEC-Q series
L series	Abbreviation for Mitsubishi Electric programmable controller MELSEC-L series
FX series	Abbreviation for Mitsubishi Electric programmable controller MELSEC-F series
Basic model QCPU	Generic term for Q00J, Q00, and Q01
High Performance model QCPU	Generic term for Q02, Q02H, Q06H, Q12H, and Q25H
Process CPU	Generic term for Q02PH, Q06PH, Q12PH, and Q25PH
Redundant CPU	Generic term for Q12PRH and Q25PRH
Universal model QCPU	Generic term for Q00UJ, Q00U, Q01U, Q02U, Q03UD, Q03UDE, Q03UDV, Q04UDH, Q04UDEH, Q04UDV, Q04UDPV, Q06UDH, Q06UDEH, Q06UDV, Q06UDPV, Q10UDH, Q10UDEH, Q13UDH, Q13UDEH, Q13UDV, Q13UDPV, Q20UDH, Q20UDEH, Q26UDH, Q26UDEH, Q26UDV, Q26UDPV, Q50UDEH, and Q100UDEH
QnUD(H)CPU	Generic term for Q03UD, Q04UDH, Q06UDH, Q10UDH, Q13UDH, Q20UDH, and Q26UDH
QnUDE(H)CPU	Generic term for Q03UDE, Q04UDEH, Q06UDEH, Q10UDEH, Q13UDEH, Q20UDEH, Q26UDEH, Q50UDEH, and Q100UDEH
High-speed Universal model QCPU	Generic term for Q03UDV, Q04UDV, Q06UDV, Q13UDV, and Q26UDV
Universal model process CPU	Generic term for Q04UDPV, Q06UDPV, Q13UDPV, and Q26UDPV
Built-in Ethernet port QCPU	Generic term for QnUDE(H)CPU, High-speed Universal model QCPU, and Universal model process CPU
Built-in Ethernet port LCPU	Generic term for L02, L02-P, L06, L06-P, L26, L26-P, L26-BT, L26-PBT
QCPU (Q mode)	Generic term for Basic model QCPU, High Performance model QCPU, Process CPU, Redundant CPU, and Universal model QCPU
LCPU	Generic term for L02S, L02S-P, L02, L02-P, L06, L06-P, L26, L26-P, L26-BT, and L26-PBT
FXCPU	Generic term for FX0s, FX0, FX0N, FX1, FX1s, FX1N, FX1NC, FXU, FX2C, FX2N, FX2NC, FX3s, FX3G, FX3GC, FX3U, and FX3UC
RCPU	Generic term for R04, R08, R16, R32, and R120
CPU module	Generic term for QCPU (Q mode), LCPU, and FXCPU
Ethernet Built-in CPU	Generic term for Built-in Ethernet port QCPU and Built-in Ethernet port LCPU

Generic term and abbreviation	Description
Display module	A module with LCD to be mounted to LCPU
Base unit/Block	Generic term for the following: <ul style="list-style-type: none"> <li>• base unit</li> <li>• a composition of modules from the power supply module to the END cover in MELSEC-L series</li> </ul>
FXGP(WIN)	Abbreviation for SW0PC-FXGP/WIN-E
C24	Generic term for QJ71C24, QJ71C24-R2, QJ71C24N, QJ71C24N-R2, QJ71C24N-R4, LJ71C24, and LJ71C24-R2
ACPU	Generic term for A2A, A2A-S1, A3A, A2AP21/R21, A2AP21/R21-S1, A3AP21/R21, A2U, A2U-S1, A3U, A4U, A2US, A2US-S1, A2USH-S1, Q02(H)-A, and Q06H-A
QnACPU	Generic term for Q2AS, Q2AS-S1, Q2ASH, Q2ASH-S1, Q2A, Q3A, and Q4A
Q series C24	Generic term for QJ71C24, QJ71C24-R2, QJ71C24N, QJ71C24N-R2, and QJ71C24N-R4
CC-Link IE Controller Network module	Generic term for QJ71GP21-SX and QJ71GP21S-SX
CC-Link IE Field Network master/local module	Generic term for QJ71GF11-T2, LJ71GF11-T2
CC IE Field head module	Generic term for LJ72GF15-T2
SSCNET III/H head module	Generic term for LJ72MS15
Communication head module	Generic term for CC IE Field head module and SSCNET III/H head module
CC-Link IE	Generic term for CC-Link IE Controller Network and CC-Link IE Field Network
MELSECNET/H network module	Generic term for QJ71LP21, QJ71LP21-25, QJ71LP21S-25, QJ71LP21G, QJ71BR11, QJ72LP25-25, QJ72LP25G, QJ72BR15, and QJ71NT11B
QJ72LP25	Generic term for QJ72LP25-25 and QJ72LP25G
Remote I/O module	Generic term for QJ72LP25 and QJ72BR15
Ethernet adapter module	Generic term for NZ2GF-ETB
Ethernet adapter	Generic term for FX3u-ENET-ADP
Q series-compatible E71	Generic term for QJ71E71-100, QJ71E71-B5, QJ71E71-B2, and QJ71E71
QE71	Generic term for AJ71QE71, AJ71QE71-B5, A1SJ71QE71-B2, A1SJ71QE71-B5, AJ71QE71N-T, A1SJ71QE71N-T, AJ71QE71N-B5, A1SJ71QE71N-B5, AJ71QE71N-B2, A1SJ71QE71N-B2, AJ71QE71N-B5T, A1SJ71QE71N-B5T, AJ71QE71N3-T, and A1SJ71QE71N3-T
A series-compatible E71	Generic term for AJ71E71-S3, A1SJ71E71-B2-S3, A1SJ71E71-B5-S3, AJ71E71N-B2, AJ71E71N-B5T, A1SJ71E71N-B2, A1SJ71E71N-B5T, AJ71E71N-T, A1SJ71E71N-T, AJ71E71N-B5, A1SJ71E71N-B5, AJ71E71N3-T, and A1SJ71E71N3-T
L series-compatible E71	Generic term for LJ71E71-100
Ethernet module	Generic term for Q series-compatible E71, QE71, A series-compatible E71, and L series-compatible E71
CC-Link master/local module	Generic term for QJ61BT11, QJ61BT11N, and LJ61BT11
Q series CC-Link	Generic term for QJ61BT11 and QJ61BT11N
CC-Link bridge module	Abbreviation for AJ65SBT-CLB CC-Link - CC-Link/LT bridge module
CC-Link-AnyWireASLINK bridge module	Generic term for NZ2AW1C2AL
CC-Link IE Field Network-CC-Link bridge module	Generic term for NZ2GF-CCB
CC-Link IE Field Network high-speed counter module	Generic term for NZ2GF-FCF-D62PD2
CC-Link IE Field Network-AnyWireASLINK bridge module	Generic term for NZ2AW1GFAL

Generic term and abbreviation	Description
Simple motion module	Generic term for QD77MS2, QD77MS4, QD77MS16, QD77GF4, QD77GF8, QD77GF16, LD77MH4, and LD77MH16
G4 module	Generic term for AJ65BT-G4(-S3) peripheral connection module and AJ65BT-R2N CC-Link system RS-232 interface module
QA extension base unit	Generic term for QA1S65B, QA1S68B, QA65, and QA68B
LA1S extension base unit	Generic term for LA1S51B, LA1S65B, and LA1S68B
CC-Link IE Field Network communication unit	Generic term for GT15-J71GF13-T2
MELSECNET/H board	Generic term for Q81BD-J71LP21-25, Q80BD-J71LP21S-25, Q80BD-J71LP21G, Q80BD-J71LP21-25, Q80BD-J71BR11
CC-Link IE Controller Network board	Generic term for Q81BD-J71GP21S-SX, Q81BD-J71GP21-SX, Q80BD-J71GP21S-SX, Q80BD-J71GP21-SX Abbreviation for CC-Link IE Controller Network interface board
CC-Link IE Field Network board	Generic term for Q81BD-J71GF11-T2, Q80BD-J71GF11-T2 Abbreviation for CC-Link IE Field Network interface board
Ethernet board	Generic term for Ethernet cards for personal computer and Ethernet interface boards
CC-Link board	Generic term for CC-Link Ver.1 board and CC-Link Ver.2 board
CC-Link Ver.1 board	Generic term for A80BD-J61BT11 and A80BD-J61BT13
CC-Link Ver.2 board	Generic term for Q81BD-J61BT11, Q80BD-J61BT11N
GOT	Generic term for Mitsubishi Electric Graphic Operation Terminal GOT1000 series, GOT-A900 series, and GOT-F900 series
MELSAP3	Abbreviation for the SFC function in MELSAP3 display format
MELSAP-L	Generic term for the SFC function in MELSAP-L (instruction format) and MELSAP-L (start conditions format)
SFC	Generic term for MELSAP3, MELSAP-L, and FX series SFC
MELSOFT Library	Generic term for components (FB library, sample programs, drawing data) which provide easy operation of programmable controller related modules and GOTs, and various devices that are connected to them Contact your local Mitsubishi Electric sales office or representative to obtain components of MELSOFT Library.
Windows® 10 or later	Generic term for Windows® 10 and Windows® 11

## ■ TERMS

The following are the terms used in this manual.

Term	Description
Execution program	A compiled program created in a project with labels A program that can be executed on a programmable controller CPU
Actual device	An actual device assigned to label after compiling a project with labels, or a device that is not described using a label
Common instruction	Generic term for sequence instructions, basic instructions, application instructions, data link instructions, multiple CPU dedicated instructions, and multiple CPU high-speed transmission dedicated instructions
Special instruction	Generic term for module dedicated instructions, PID control instructions, socket communication function instructions, built-in I/O function instructions, and data logging function instructions
Simple project	Generic term for projects created using Ladder Diagram/Sequential Function Chart/Structured Text
Without labels	Generic term for projects created without selecting "Use Label" when creating new projects
With labels	Generic term for projects created with selecting "Use Label" when creating new projects
Structured project	Generic term for projects created using Ladder Diagram/Sequential Function Chart/Structured Text/Structured Ladder/FBD
Project without labels	Generic term for Simple projects that do not use labels
Project with labels	Generic term for Simple projects that use labels and Structured projects
Project with security	Generic term for projects whose securities are set
New project creation with data read from programmable controller CPU	A function to create a new project with data read from a programmable controller CPU without opening a project
Direct connection	A connection method using a USB/serial/Ethernet port of a programmable controller CPU
Device station	Stations other than the master station (local stations, remote I/O stations, remote device stations, intelligent device stations, etc.)
Redundant system	A system configured using Redundant CPUs
Connective system	A Redundant CPU selected on the <u>Transfer Setup</u> screen
Target system	The other Redundant CPU connected to the connective system with a tracking cable
System A	A system to which system A connector for tracking cable is connected in the redundant system
System B	A system to which system B connector for tracking cable is connected in the redundant system
Control system	A system that performs program operation, system control, and network communication in the redundant system
Standby system	A backup system to continue system control in case of a module failure or an error in the control system in the redundant system
Backup mode	A mode for normal operation of the redundant system
Separate mode	A mode for maintaining a system (partial modification of a program, replacement of modules mounted on the main base unit) without stopping the control during an operation of the redundant system
Debug mode	A mode for performing a debug using a single system prior to a redundant system operation
iQSS-compatible device	A device that supports iQ Sensor Solution
Profile	A data in which iQSS-compatible device information (such as module models) is stored

---

# 1 OVERVIEW

This chapter explains an overview of GX Works2.

1.1	Product Overview	1 - 2
1.2	Features	1 - 4
1.3	List of Functions	1 - 9

# 1.1 Product Overview

GX Works2 is a programming tool for designing, debugging, and maintaining programs on Windows®. GX Works2 has improved functionality and operability, with easier-to-use features compared to existing GX Developer.


## ■ Main functions of GX Works2

GX Works2 can manage programs and parameters in units of projects for each programmable controller CPU.

The following explains the main functions.


### ● Programming

Programs can be created in a Simple project in a similar way with existing GX Developer. Structured programming in a Structured project is also available with GX Works2.




### ● Setting parameters

Programmable controller parameter and network parameter can be set with GX Works2. Intelligent function module parameter can be set as well.




### ● Writing/reading data to/from a programmable controller CPU

Created sequence programs can be written to/read from a programmable controller CPU using the Read from PLC/Write to PLC function. Also, using the Online program change function, the sequence programs can be changed even when the programmable controller CPU is in RUN.




● **Monitoring/debugging**

Created sequence programs can be written to the programmable controller CPU and device value at operation can be monitored online/offline.



Programs can be monitored and debugged.



● **Diagnostics**


The current error status and error history of the programmable controller CPU can be diagnosed. Using the diagnostics function, the recovery work is completed in a short time.

Using the System monitor function (for QCPU (Q mode)/LCPU), detailed information on such as intelligent function modules can be obtained. This helps to shorten the recovery work time at error occurrence.



Diagnosing the programmable controller CPU status

Diagnosing the programmable controller CPU status (PLC diagnostics screen)



1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES

## 1.2 Features


This section explains the features of GX Works2.

### ■ Project types in GX Works2

In GX Works2, the project type can be selected from either of Simple project or Structured project.


#### ● Simple project

The Simple project creates sequence programs using instructions for programmable controller CPU. Programs in a Simple project can be created in a similar way to existing GX Developer. Programming without labels and label programming are supported as in GX Developer.



#### ● Structured project

In a Structured project, programs can be created by structured programming. By segmenting a whole control process program into common program parts, highly manageable and usable programming (structured programming) is possible. Only label programming is supported.






## ■ Programming using labels

Using the label programming, programs can be created without regard for the device numbers. By compiling a program created with the label programming, devices are automatically assigned and the program becomes available as an actual program.

Created global labels can be utilized for other programs.

Created labels can be utilized for other programs.




In addition, global labels can be registered as system labels and be shared within iQ Works compliant products (GX Works2, MT Developer2, and GT Designer3).

For details of system labels, refer to the following manual.

(👉 iQ Works Beginner's Manual)


**Enhanced use of program assets**

Projects created with existing GX Developer can be utilized in a Simple project. Utilizing the past assets improves the efficiency of program design.







**Sharing Program Organization Unit (POU) registered as libraries**

In a Structured project, programs, global labels, and structures frequently used can be registered as user libraries. Utilizing these user libraries reduces time required for creating programs.



## Wide variety of programming languages

The wide variety of programming languages available with GX Works2 enables to select the optimum programming language according to control.




ST programs can be used on the ladder editor of GX Works2 using the Inline structured text function.

1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES

■ Other features

● Offline debugging

Offline debugging using the simulation function is possible with GX Works2. This enables debugging to ensure the normal operation of created sequence programs without connecting GX Works2 to the programmable controller CPU.




Connecting to the programmable controller is unnecessary.

Without connecting to the programmable controller CPU, programs can be monitored and debugged in the same way with debugging by the programmable controller CPU.

● The screen layout can be customized to the user's preference

Use dockable windows to change the screen layout of GX Works2.



## 1.3 List of Functions

This section shows the list of functions of GX Works2.

The functions are divided into common functions available (Project, Online, Debug, Diagnostics, Tool, Window, and Help) and functions used for each editing or setting target (Edit, Find/Replace, Compile, and View).

For (Simple), (FB), (Structured), (Intelligent), and (iQSS) indicated in the Reference column, refer to the following manuals respectively:

(Simple) ... GX Works2 Version 1 Operating Manual (Simple Project)  
 (FB) ... GX Works2 Version 1 Operating Manual (Simple Project, Function Block)  
 (Structured) ... GX Works2 Version 1 Operating Manual (Structured Project)  
 (Intelligent) ... GX Works2 Version 1 Operating Manual (Intelligent Function Module)  
 (iQSS) ... iQ Sensor Solution Reference Manual

### 1.3.1 List of functions common to Simple project and Structured project

This section explains the functions common to Simple project and Structured project.

#### ■ List of common functions

The following tables show functions that are available regardless of the type of editing or setting target.

Project (common function)		Reference
New	Create a new project.	Section 4.2.1
Open	Open an existing project.	Section 4.2.2
Close	Close the open project.	Section 4.2.6
Save	Save the project.	Section 4.2.3
Save As	Name and save the project.	
Compress/Unpack		–
Compress	Compress and save a project.	Section 4.2.4
Unpack	Decompress a compressed project.	
Delete	Delete an existing project.	Section 4.2.5
Verify	Verify between two project data.	Section 4.2.7
Project Revision		–
Revision Entry	Register the project change history.	Section 4.6.1
Revision List	Display the list of project change history.	Section 4.6.2
Change PLC Type	Change the programmable controller CPU type.	Section 4.2.8
Change Project Type	Change the project type from Simple project (without labels) to Simple project (with labels), or from Simple project (with labels) to Structured project.	Section 4.5

Project (common function)		Reference
Object		–
New	Add data to the project.	Section 4.3.1
Rename	Rename the selected data.	Section 4.3.3
Delete	Delete the selected data.	Section 4.3.4
Copy	Copy the selected data.	Section 4.3.2
Paste	Paste the copied data.	
Set as Default Connection	Specify data in selected connection destination as a connection destination for regular use.	Section 14.1.3
Property	Display the selected data properties.	Section 4.3.6
Intelligent Function Module		–
New Module	Add new intelligent function module data.	(Intelligent)
Delete Module	Delete intelligent function module data.	
Property	Display properties of the intelligent function module data.	
Save the Positioning Module Data	Save data of the positioning module selected on the Project view to a file.	
Read from the Positioning Module Data	Read data from the positioning module and apply it to the positioning module selected on the Project view.	
Save GX Configurator-QP Data	Save the positioning module data in GX Configurator-QP format.	
Import GX Configurator-QP Data	Read a project created with GX Configurator-QP.	
Intelligent Function Module Parameter List	Display a list of set/unset parameters of the intelligent function module.	
Save/Read FX Special Module Data		–
Read new FX Special Module Data	Read a data created with the setting tool for special module (intelligent function module), and add new data.	(Intelligent)
Save FX Special Module Data	Save a data of the special module (intelligent function module) selected on the Project view in the format of the setting tool.	
Read from FX Special Module Data	Read a data created with the setting tool for a special module (intelligent function module), and reflect it to the positioning module selected on the Project view.	
Open Other Data		–
Open Other Project	Open a project created with GX Developer.	Section 4.7.1
Read ASC Format File	Read an ASC format file.	Section 4.7.2
Export to GX Developer Format File	Save the open project in GX Developer format.	Section 4.8
Library		–
Create	Create a new library.	(Structured)
Install	For Simple projects (with labels), import an FB library to the project. For Structured projects, import a created library to the project.	(FB) (Structured)
Export FB to Library (Project)	Export FBs to other project	(FB)
Deinstall	Delete the library from the project.	(Structured)
Reload	Update the library imported to the project.	
Rename	Rename the library.	
Open	Enable editing of the library.	
Close	Disable editing of the library.	
Change Password	Set a password for the library.	
Save As	Name and save the project.	
Save	Save the library file.	
Help	Display help information of the library.	

Project (common function)		Reference
Security		-
Change Password	Change the password of the current login user.	Section 4.10.2
User Management	Manage user information of the project. Add/delete a user, or change the user information.	Section 4.10.1 Section 4.10.2
Data Security Setting	Set the access authorization of each user related to reading/ writing data.	Section 4.10.4
Soft Security Key Management	Manage the security key which is used to lock or unlock a programmable controller CPU.	Section 4.11
Print	Batch print multiple data in the project.	Section 11.3
Print Preview	Display the print preview of data to be batch printed.	Section 11.6
Print Window	Print the open screen.	Section 11.7
Print Window Preview	Display the print preview of the open screen.	Section 11.9
Printer Setup	Change the printer settings.	Section 11.2
(Recently used files 1 to 4)	Display the recently used GX Works2 project paths, and open the selected project.	-
Start GX Developer	Start GX Developer from GX Works2.	Section 4.9
Exit	Exit GX Works2.	Section 3.1
Edit (common function)		Reference
Undo	Restore the previous processing status.	-
Redo	Restore the processing deleted with [Undo].	
Cut	Cut the selected data.	
Copy	Copy the selected data.	
Paste	Paste the cut or copied data at the cursor position.	
Find/Replace (common function)		Reference
Cross Reference	Display the usage of selected device or label.	Section 10.1
Device List	Display the usage of devices.	Section 10.2
Find Device	Search a device/label in the program.	Section 10.3.1
Find Instruction	Search an instruction.	Section 10.3.2
Find Contact or Coil	Search a contact or coil corresponding to the specified device.	
Find String	Search a string.	Section 10.3.3
Replace Device	Replace a device/label in the program.	Section 10.3.1
Replace Instruction	Replace an instruction.	Section 10.3.2
Replace String	Replace a string.	Section 10.3.3
Change Open/Close Contact	Change an open contact to a closed contact, or change a closed contact to an open contact.	Section 10.3.4
Device Batch Replace	Batch-replace devices with the specified device.	Section 10.3.5
Register to Device Batch Replace	Register selected devices on the <u>Device Batch Replace</u> screen.	
Compile (common function)		Reference
Build	Convert/compile a program being edited.	Section 5.4
Online Program Change	Write sequence programs to a programmable controller CPU after the conversion/compilation.	
Rebuild All	Convert/compile all programs in the project.	

1  
OVERVIEW2  
SYSTEM  
CONFIGURATION3  
SCREEN  
CONFIGURATION AND  
BASIC OPERATIONS4  
PROJECT  
MANAGEMENT5  
EDITING  
PROGRAMS6  
SETTING  
PARAMETERS7  
SETTING DEVICE  
MEMORY8  
SETTING DEVICE  
INITIAL VALUES

View (common function)		Reference
Toolbar		–
Toolbar name	Display/hide each toolbar.	Section 3.2.2
Display All	Display/hide all toolbars.	
Statusbar	Display/hide the status bar.	Section 3.2.6
Color and Font	Set the display color for characters such as labels and device comments on the work window.	Section 3.2.7
Docking Window		–
Navigation	Display/hide the Navigation window.	Section 3.2.5
Element Selection	Display/hide the Element Selection window. Select a part such as function block and function on the window for utilizing it to a program.	(FB) (Structured)
Output	Display/hide the Output window. The conversion (compilation) result is displayed.	(Simple) (Structured)
Cross Reference	Display/hide the Cross Reference window. The devices/labels used in the project are displayed.	Section 10.1
Device List	Display/hide the Device List window. The usage of selected device is displayed.	Section 10.2
Device Reference	Display/hide the Device Reference window. Assignments of refresh devices and link devices of CC-Link IE Field Network and CC-Link are displayed.	Section 6.3.4
	Display/hide the Device Reference window. Assignments of AnyWireASLINK refresh devices and I/O devices are displayed.	(Intelligent)
Watch 1 to 4	Display/hide the Watch window. The monitoring result is displayed.	Section 17.6
Intelligent Function Module Monitor		–
Module 1 to 10	Display/hide the Intelligent Function Module Monitor window.	(Intelligent)
Intelligent Function Module Guidance	Display/hide the Intelligent Function Module Guidance window.	
Find/Replace	Display/hide the Find/Replace window. The search/replace result is displayed.	Section 10.3
Debug		–
Break Point	Display/hide the Break Point window.	Section 19.6.2
Break Device	Display/hide the Break Device window.	Section 19.6.3
Skip Range	Display/hide the Skip Range window.	Section 19.6.4
Reset the Window Position to its Default	Return the display positions of the dockable windows to their default.	Section 3.2.4



Online (common function)		Reference
Read from PLC	Read data from the programmable controller CPU.	Section 15.1
Write to PLC	Write data to the programmable controller CPU.	
Verify with PLC	Verify a project being edited against the data on the programmable controller CPU.	Section 15.2
Remote Operation	Remotely control RUN/PAUSE/STOP of the programmable controller CPU from GX Works2.	Section 20.1
Redundant Operation	Remotely control the system switch, operation mode change, or memory copy on the Redundant CPU from GX Works2.	Section 20.2
Password/Keyword		–
New	Set a password/keyword to the programmable controller CPU.	Section 16.2.1 Section 16.3.1 Section 16.4.1
Delete	Cancel the password/keyword set to the programmable controller CPU.	Section 16.2.2 Section 16.3.2 Section 16.4.2
Disable	Temporarily unlock the password/keyword set to the programmable controller CPU.	Section 16.2.3 Section 16.3.3 Section 16.4.3
Soft Security Key Management	Manage the security key which is used to lock or unlock the programmable controller CPU.	Section 16.5
PLC Memory Operation		–
Format PLC Memory	Format the programmable controller CPU memory.	Section 20.3
Clear PLC Memory	Clear the programmable controller CPU memory.	Section 20.4
Arrange PLC Memory	Arrange the programmable controller CPU memory.	Section 20.5
Delete PLC Data	Delete data on the programmable controller CPU.	Section 15.3
PLC User Data		–
Read	Read the programmable controller CPU user data.	Section 15.5
Write	Write the programmable controller CPU user data.	
Delete	Delete the programmable controller CPU user data.	
Export to ROM Format	Copy the program memory data on the programmable controller CPU to ROM.	Section 15.4
Program Memory Batch Download	Transfer the content of program cache memory to program memory in batch.	Section 15.6
Latch Data Backup		–
Backup	Back up device memory/file register/error history data to the standard ROM.	Section 15.7.1
Delete Backup Data	Delete the backup data on the programmable controller CPU.	Section 15.7.2
PLC Module Change		–
Create Backup Data	Back up data on the programmable controller CPU to the memory card.	Section 15.8.1
Restore	Restore the backup data to another programmable controller CPU.	Section 15.8.2
Set Clock	Set the clock on the programmable controller CPU.	Section 20.6
Register/Cancel Display Module Menu	Register/cancel menus to operate intelligent function module using the LCPU display module menu.	Section 20.7

Online (common function)		Reference
Monitor		-
Monitor Mode	Switch the mode of the open window to "Monitor Mode" during monitoring.	(Simple)
Monitor (Write Mode)	Switch the mode of the open window to "Monitor (Write Mode)" during monitoring.	
Start Monitoring (All Windows)	Start monitoring the programs of all open windows.	Section 17.8
Stop Monitoring (All Windows)	Stop monitoring the programs of all open windows.	
Start Monitoring	Start monitoring the program of the open window.	Section 17.2
Stop Monitoring	Stop monitoring the program of the open window.	Section 17.1
Change Value Format (Decimal)	Display the current device value in decimal in program monitoring.	(Simple) (Structured)
Change Value Format (Hexadecimal)	Display the current device value in hexadecimal in program monitoring.	
Device/Buffer Memory Batch	Monitor device/buffer memory in batch.	Section 17.3
Program List	Monitor the processing time of programs being executed.	Section 17.4
Interrupt Program List	Monitor the number of executions of interrupt programs.	Section 17.5
Change Instance (Function Block)	Select an instance of the function block to be monitored.	(FB) (Structured)
SFC All Block Batch Monitoring	Batch monitor all blocks in the SFC program.	(Simple)
SFC Auto Scroll	Scroll the screen to display active steps automatically when they are out of the screen during monitoring.	
Watch		-
Start Watching	Start monitoring the current values of registered devices/labels and intelligent function module.	Section 17.6
Stop Watching	Stop monitoring the current values of registered devices/labels and intelligent function module.	
Insert Next Object	Insert the next device/label right after the selected row of device/label.	
Display Format of Bit Device		
Number Display	Switch the display format of the current value of bit device to the number display (1/0).	
ON/OFF Display	Switch the display format of the current value of bit device to the 'ON/OFF' display.	
Symbol Display	Switch the display format of the current value of bit device to the symbol display (●/○).	
Register to Watch	Register the selected devices/labels to the Watch window.	
Local Device Batch Read + Save CSV	Read local device data from the programmable controller CPU and saves them on a personal computer in CSV format.	Section 15.12

Debug (common function)		Reference
Start/Stop Simulation	Start/stop simulation.	Section 18.2
Instructions Unsupported by Simulation	Display a list of the instructions and devices used in the program that is not supported by the simulation function.	Section 18.3
Modify Value	For ladder and SFC (Zoom) programs, change the ON/OFF status and values of devices and labels used in the program.	Section 19.1
Forced Input Output Registration/ Cancellation	Register/cancel the forced input/output of the device 'X'/'Y'.	Section 19.2
Device Test with Execution Condition		–
Register	Register the device test with execution condition.	Section 19.3.1
Registration Check/Disable	Check/disable the registration of device test with execution condition.	Section 19.3.2
Batch Disable	Batch disable the device test with execution condition in batch.	Section 19.3.3
Sampling Trace		–
Open Sampling Trace	Display the <u>Sampling Trace</u> screen.	Section 19.4.1
Scan Time Measurement	Measure the scan time of a desired section.	Section 19.5
Step Execution		–
Stop	Stop the step execution.	Section 19.6.9
Cancel	Cancel the step execution.	Section 19.6.7
Break Execution	Execute the break execution.	Section 19.6.6
Step Execution	Execute the step execution.	Section 19.6.5
Execution Option	Display the "Execution Option" screen of the step execution.	Section 19.6.8
Break Setting		–
Set/Cancel Break Point	Set a break point at the cursor position, or cancel the set break point.	Section 19.6.2
Enable/Disable Break Point	Enable/disable the break point at the cursor position.	
Cancel All Break Points	Cancel all break points.	
Break Point Window	Display the Break Point window.	Section 19.6.3
Cancel All Break Devices	Cancel all break devices.	
Break Device Window	Display the Break Device window.	
Skip Setting		–
Set/Cancel Skip Range	Set a skip range, or cancel the set skip range.	Section 19.6.4
Enable/Disable Skip Range	Enable/disable the skip range at the cursor position.	
Cancel All Skip Ranges	Cancel all skip ranges.	
Skip Range Window	Display the Skip Range window.	
Diagnostics (common function)		Reference
PLC Diagnostics	Diagnose the operating status of the programmable controller CPU.	Section 21.1
Ethernet Diagnostics	Diagnose Ethernet.	Section 21.7
CC IE Control Diagnostics	Diagnose CC-Link IE Controller Network.	Section 21.3
CC IE Field Diagnostics	Diagnose CC-Link IE Field Network.	Section 21.4
CC-Link IEF Basic Diagnostics	Diagnose CC-Link IE Field Network Basic.	Section 21.5
MELSECNET Diagnostics	Diagnose MELSECNET/10(H).	Section 21.2
CC-Link Diagnostics	Diagnose CC-Link and CC-Link/LT.	Section 21.6
Sensor/Device Monitor	Monitor the status of iQSS-compatible devices	Section 21.8 (iQSS)
System Monitor	Monitor the system status of the programmable controller CPU.	Section 21.9
Online Module Change	Change modules online.	Section 21.10

1  
OVERVIEW2  
SYSTEM  
CONFIGURATION3  
SCREEN  
CONFIGURATION AND  
BASIC OPERATIONS4  
PROJECT  
MANAGEMENT5  
EDITING  
PROGRAMS6  
SETTING  
PARAMETERS7  
SETTING DEVICE  
MEMORY8  
SETTING DEVICE  
INITIAL VALUES

Tool (common function)		Reference
IC Memory Card		–
Read IC Memory Card	Read data from the IC memory card.	Section 15.11.1
Write IC Memory Card	Write data to the IC memory card.	
Read from IC Memory Card (Edit and Data Copy)	Read data saved by the batch save function of programmable controller CPU from the IC memory card.	Section 15.11.2
Write to IC Memory Card (Edit and Data Copy)	Write data to the IC memory card in the format which can be used for the batch load function of programmable controller CPU.	
Check Program	Check programs of the project without labels and display errors.	(Simple)
Check Parameter	Check parameters and display errors.	Section 6.5
Clear All Parameters	Delete all selected parameters.	Section 6.7
Check Device Duplication of Global Label	Check duplications of devices assigned to global labels, and display the result.	(Simple) (Structured)
Device/Label Automatic-Assign Setting	Set device range to be automatically assigned to a label.	(Simple) (Structured)
Block Password	Set a block password to data.	Section 4.12
Confirm Memory Size	Calculate the size of files to be written to the programmable controller CPU.	Section 15.10
Delete Unused Device Comment	Delete unused device comments in the project.	Section 9.3.3
Merge Data	Merge ladder programs or device comment data.	Section 4.3.5
Set TEL Data/Connect via Modem		–
Line Connection	Connect the line.	Section 14.10.2
Line Disconnection	Disconnect the line.	
AT Command Registration	Register a modem between a personal computer and a serial communication module, or a personal computer and an FXCPU.	Section 14.10.1
Phone Book	Set phone numbers of targets such as remote access targets.	
Options	Set options for TEL data.	Section 14.10.3
Logging Configuration Tool	Start CPU Module Logging Configuration Tool.	Section 19.7
Realtime Monitor Function	Start the Realtime Monitor function of GX LogViewer.	Section 17.9
Ethernet Adapter Module Configuration Tool	Start the Ethernet adapter module configuration tool.	Section 20.8
Built-in I/O Module Tool		–
Positioning Monitor	Display the <u>Positioning Monitor</u> screen.	Section 21.11
High-Speed Counter Monitor	Display the <u>High-Speed Counter Monitor</u> screen.	
I/O Monitor	Display the <u>I/O Monitor</u> screen.	
Check Intelligent Function Module Parameter		–
Check Auto Refresh Duplication	Check duplications of devices set in the Auto refresh function and display the result.	(Intelligent)

Tool (common function)		Reference
Intelligent Function Module Tool		–
Analog Module	–	(Intelligent)
Offset/Gain Setting	Configure the offset/gain setting of the analog module.	
Q61LD Two-Point Calibration Setting	Configure the Q61LD two-point calibration setting.	
Q61LD Default Setting	Configure the Q61LD default setting.	
Create Wave Output Data	Create waveform output data.	
Create Conversion Characteristics Table	Create a conversion characteristics table.	
Free Operation Function Setting	Set the operation expression data.	
Temperature Input Module	–	
Offset/Gain Setting	Configure the offset/gain setting of the temperature input module.	
Register 2-point Sensor Compensation Value	Register the 2-point sensor compensation value of the temperature input module.	
Temperature Control Module	–	
Auto Tuning	Execute the auto tuning function of the temperature control module.	
Sensor Correction Function	Execute the sensor correction function of the temperature control module.	
Counter Module	–	
Preset	Execute the preset function of the counter module.	
QD75/LD75 Positioning Module	–	
Positioning Monitor	Execute the positioning monitor.	
Positioning Test	Execute the positioning test.	
Wave Trace	Execute the wave trace.	
Location Trace	Execute the location trace.	
Serial Communication Module	–	–
Circuit Trace	Execute the circuit trace.	(Intelligent)
Predefined Protocol Support Function		–
Serial Communication Module	Start the predefined protocol support function of serial communication module.	(Intelligent)
Ethernet Module	Start the predefined protocol support function of Ethernet module.	
Built-in/Adapter Serial	Start the predefined protocol support function of built-in/adapter serial.	
Built-in Ethernet	Start the predefined protocol support function of built-in Ethernet.	
Language Selection	Select a language used in the project.	Section 3.3
Profile Management		–
Register	Register the connected device profile to GX Works2.	Section 4.13.1
Delete	Delete the connected device profile from GX Works2.	Section 4.13.2
Key Customize	Change the settings of the shortcut keys.	Section 3.2.8
Options	Set various options.	Chapter 12

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

Window (common function)		Reference
Cascade	Cascade windows.	Section 3.2.3
Tile Vertically	Tile windows vertically.	
Tile Horizontally	Tile windows horizontally.	
Arrange Icons	Arrange the icons at the bottom of the window.	
Close All	Close all open windows.	
(Switch to other window)	Display the open window.	
Other Window	Display the list of open windows. Also, open or arrange specified windows.	
Help (common function)		Reference
GX Works2 Help	Display the <u>GX Works2 Help</u> screen.	Section 3.4.1
Operating Manual		–
GX Works2 Beginner's Manual (Simple Project)	Display the operating manuals.	Section 3.4.2
GX Works2 Beginner's Manual (Structured Project)		
Operating Manual Common		
Operating Manual (Simple Project)		
Operating Manual (Structured Project)		
Operating Manual (Intelligent Function Module)		
Operating Manual (Simple Project, Function Block)		
Connection to MITSUBISHI ELECTRIC FA Global Website	Open the MITSUBISHI ELECTRIC FA Global Website.	Section 3.4.3
About	Display product information such as the version.	Section 3.4.4

## ■ List of functions for setting labels

The following table shows the functions for setting and editing labels.

Edit (function for label setting)		Reference
Delete	Delete the selected data.	-
Select All	Select all items.	(Simple) (Structured)
New Declaration (Before)	Add a row above the cursor position.	
New Declaration (After)	Add a row below the cursor position.	
Delete Row	Delete the row at the cursor position.	
Read from CSV File	Read label settings from the CSV file.	
Write to CSV File	Write label settings to the CSV file.	
System Label		
Reservation to Register System Label	Reserve the selected global label for registration as a system label.	(Simple) (Structured)
Reservation to Release System Label	Reserve the selected global label for deregistration of system label.	
Import System Label	Import the system label information and apply it to global labels.	
Reflect to System Label Database	Apply the registration-reserved/deregistration-reserved global labels to the system label data base.	
Check the changes of the System Label Database	Apply system label information changed in another project to global labels.	
Execute Verification Synchronous with System Label	Resolve a mismatch when system label information contains it.	-
Sort		-
Class	Sort the labels in ascending/descending order with the selected item.	(Simple) (Structured)
Label Name		
Data Type		
Constant		
Device		
Address		
Comment		
Remark		
Unused label list	Extract and display unused labels. Extracted unused labels can be deleted in batch.	(Simple) (Structured)

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

## ■ List of functions for editing device comments

The following table shows functions for editing device comments.

Edit (function for editing device comments)		Reference
Delete	Delete the selected data.	–
Select All	Select all data being displayed.	–
Import from Sample Comment		–
Special Relay/Special Register	Utilize sample comments of SM/SD.	Section 9.5.1
Intelligent Function Module	Utilize sample comments of intelligent function module device.	Section 9.5.2
Clear All (All Devices)	Delete all device comment data.	Section 9.3.1
Clear All (All Displayed Devices)	Delete all device comment data being displayed.	Section 9.3.2
Read from CSV File	Read device comments from the CSV file.	Section 9.6
Write to CSV File	Write device comments to the CSV file.	
Hide Bit Specification Information	Hide the bit-specified word device comment of the selected row.	Section 9.2.1
Show Bit Specification Information	Display the bit-specified word device comment of the selected row.	
Cut The Range including Hidden Bit Specification Information	Cut data including hidden bit-specified comment.	
Copy The Range including Hidden Bit Specification Information	Copy data including hidden bit-specified comment.	
Paste The Range including Hidden Bit Specification Information	Paste data including hidden bit-specified comment.	
View (function for editing device comments)		Reference
Text Size		–
Bigger	Enlarge the text display size on the device comment editor.	Section 9.1.3
Smaller	Reduce the text display size on the device comment editor.	



## ■ List of functions for setting device memory

The following tables show the functions for setting device memory.

Edit (function for setting device memory)		Reference
Delete	Delete the selected data.	–
Insert Row	Insert a row at the cursor position.	Section 7.2
Input Device	Enter a device.	Section 7.2.2
Paste Text	Enter a character string.	Section 7.2.3
FILL	Set the same value to consecutive devices simultaneously.	Section 7.2.4

Find/Replace (function for setting device memory)		Reference
Find Device Cell	Search for a device.	Section 7.3

View (function for setting device memory)		Reference
Display Mode		–
Binary	Display data in binary.	Section 7.2.5
Octal	Display data in octal.	
Decimal	Display data in decimal.	
Hexadecimal	Display data in hexadecimal.	
Float	Display data in real number.	
String	Display data in character string.	
String (ASCII only)	Display data in ASCII string.	
Register		–
16-bit	Display data in units of words.	Section 7.2.5
32-bit	Display data in units of double words.	
64-bit	Display data in units of 64 bits.	
Setup	Change the number of rows or columns in the editor.	Section 7.2.6

Tool (function for setting device memory)		Reference
Read Device Memory from PLC	Read device memory data from the programmable controller CPU.	Section 7.4.1
Write Device Memory to PLC	Write device memory data to the programmable controller CPU.	
Read from Excel File	Read data from an Excel file.	Section 7.4.2
Write to Excel File	Write data to an Excel file.	

## ■ List of functions for verification result

The following tables show the functions for verification result.

Edit (function for verification result)		Reference
Write to CSV File	Write verification result to a CSV file.	Section 4.2.7

Find/Replace (function for verification result)		Reference
Next Unmatch	Move to the next mismatched data.	Section 4.2.7
Previous Unmatch	Move to the previous mismatched data.	

View (function for verification result)		Reference
Return to Result List	Return to the <<Verify Result List>> tab from the <<Detail Verify Result>> tab.	Section 4.2.7
Close Detail Result	Close the <<Detail Verify Result>> tab being displayed.	
Close All Detail Result	Close all <<Detail Verify Result>> tabs being displayed.	

## ■ List of functions for executing sampling trace






















The following tables show the functions for executing sampling trace.

View (function for executing sampling trace)		Reference
Result Position		–
Move to Trigger Point	Display the trigger position.	–
Switching Display Items		–
Device	Display/hide the display item titles.	Section 19.4.3
Address		
Comment		
Data Types		
Radix		
Timing Chart Scale		–
Narrow Scale	Enlarge/reduce the timing chart scale.	Section 19.4.4
Wide Scale		
Trend Graph Scale		–
Narrow Scale	Enlarge/reduce the trend graph scale.	Section 19.4.4
Wide Scale		
Initial Display		
Additional Information		–
Time	Display/hide the additional information.	Section 19.4.2
Program Name		Section 19.4.4

Debug (function for executing sampling trace)		Reference
Sampling Trace		–
Open Sampling Trace	Display the <u>Sampling Trace</u> screen.	Section 19.4.1
Trace Setting	Display the screen on which the sampling trace conditions are set.	Section 19.4.2
Start Trace	Start sampling trace.	Section 19.4.4
Stop Trace	Suspend sampling trace.	–
Execute Manual Trigger	Generate a trigger at any given timing.	–
Register Trace	Write trace settings to a programmable controller CPU. (Select this to start tracing by using a sequence program. A trace starts when the trace start command (SM801) is executed after selecting "Register Trace".)	Section 19.4.4
Forced Execution Registration Effective	Enable to execute the sampling trace from the peripherals.	
Display Trace Buffer Condition	Display trace data storage status.	
Export CSV Data	Save the trace data (trace settings + results) on the personal computer in CSV file format.	Section 19.4.5
Read from PLC	Read the sampling trace data (trace settings + results) from the programmable controller CPU.	
Write to PLC	Write the trace data (trace settings + results) to the programmable controller CPU.	
Delete All Data	Delete all information including the device data registered and the sampling trace result displayed on the <u>Sampling Trace</u> screen.	–

### 1.3.2 List of functions for editing in Ladder Diagram

The following tables show the functions for the ladder editor.

Edit (function for editing in Ladder Diagram)		Reference
Continuous Paste	Increment the device number of device in the cut/copied ladder block and paste it consecutively.	(Simple)
Delete	Delete the selected data.	
Restore After Ladder Conversion	Return the ladder program being edited to the last converted status.	
Insert Row	Insert a row at the cursor position.	
Delete Row	Delete the row at the cursor position.	
Insert Column	Insert a column at the cursor position.	
Delete Column	Delete the column at the cursor position.	
NOP Batch Insert	Insert an NOP in front of the ladder block at the cursor position.	
NOP Batch Delete	Batch-delete NOPs in the program being edited.	
Edit Line	Enter a line at the cursor position.	
Delete Line	Delete the line at the cursor position.	
Change TC Setting	Batch-change timer/counter setting values used in the program.	
Ladder Edit Mode		
Read Mode	Switch the mode of the open window to "Read Mode".	(Simple)
Write Mode	Switch the mode of the open window to "Write Mode".	
Read Mode (All Windows)	Switch the mode of all open windows to "Read Mode".	
Write Mode (All Windows)	Switch the mode of all open windows to "Write Mode".	
Ladder Symbol		-
Open Contact	Insert  at the cursor position.	(Simple)
Close Contact	Insert  at the cursor position.	
Open Branch	Insert  at the cursor position.	
Close Branch	Insert  at the cursor position.	
Coil	Insert  at the cursor position.	
Application Instruction	Insert  at the cursor position.	
Vertical Line	Insert  at the cursor position.	
Horizontal Line	Insert  at the cursor position.	
Delete Vertical Line	Insert  at the cursor position.	
Delete Horizontal Line	Insert  at the cursor position.	
Pulse Contact Symbol		-
Rising Pulse	Insert  at the cursor position.	(Simple)
Falling Pulse	Insert  at the cursor position.	
Rising Pulse Branch	Insert  at the cursor position.	
Falling Pulse Branch	Insert  at the cursor position.	
Rising Pulse Close	Insert  at the cursor position.	
Falling Pulse Close	Insert  at the cursor position.	
Rising Pulse Close Branch	Insert  at the cursor position.	
Falling Pulse Close Branch	Insert  at the cursor position.	
Invert Operation Results	Insert  at the cursor position.	
Operation Result Rising Pulse	Insert  at the cursor position.	
Operation Result Falling Pulse	Insert  at the cursor position.	

1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES


















Edit (function for editing in Ladder Diagram)		Reference
Inline Structured Text		–
Insert Inline Structured Text Box	Insert an inline structured text box.	(Simple)
Display Template	Insert a template corresponds to the instruction, function, or control syntax.	(Structured)
Mark Template (Left)	Set an argument of the template in the selected status from the left by selecting the menu each time.	
Mark Template (Right)	Set an argument of the template in the selected status from the right by selecting the menu each time.	
Edit FB Instance	Rename an FB instance name.	(FB)
Documentation		–
Device Comment	Edit device comments.	Chapter 9
Statement	Edit statements.	(Simple)
Note	Edit notes.	
Statement/Note Batch Edit	Batch-edit the statements/notes in the program.	
Easy Edit		–
Connect Line to Right-Side Symbol	Connect a horizontal line to the instruction or the line at the right of the cursor position.	(Simple)
Connect Line to Left-Side Symbol	Connect a horizontal line to the instruction or the line at the left of the cursor position.	
Enter/Delete HLine Rightward	Enter/delete a line at the right of the cursor position.	
Enter/Delete HLine Leftward	Enter/delete a line at the left of the cursor position.	
Enter/Delete VLine Downward	Enter/delete a line at the downward of the cursor position.	
Enter/Delete VLine Upward	Enter/delete a line at the upward of the cursor position.	
Switch Open/Close Contact	Switch between an open contact and a closed contact.	Section 10.3.4
Switch Statement/Note Type	Change the type of the statement/note.	(Simple)
Instruction Partial Edit	Display the <u>Enter Symbol</u> screen in which the first argument is in the selected status.	
Edit List for Ladder Block	Display/edit the ladder block in list format.	
Read from CSV File	Read a list format program from a CSV file and display it as a ladder program.	
Write to CSV File	Write a ladder program to a CSV file in list format.	
Find/Replace (function for editing in Ladder Diagram)		Reference
Change Module I/O No.	Replace the start module I/O number of the buffer memory address instruction.	(Simple)
Switch Statement/Note Type	Change the type (PLC/Peripheral) of a statement/note.	
Line Statement List	Display a list of line statements used in the program.	
Jump	Move the cursor to the specified step position.	
Jump to Next Ladder Block Start	Move the cursor from the current position to the start of the next ladder block.	
Jump to Previous Ladder Block Start	Move the cursor from the current position to the start of the previous ladder block.	
Next Device	Move the cursor to the same device as the one at the cursor position.	
Next Contact	Move the cursor to the contact where the same device as the one at the cursor position is used.	
Next Coil	Move the cursor to the coil where the same device as the one at the cursor position is used.	
Back	Return the cursor to the previous position before the [Next Device]/[Next Contact]/[Next Coil] function execution.	

View (function for editing in Ladder Diagram)		Reference	
Comment	Display device comments or label comments.	Chapter 9	
Statement	Display statements.	(Simple)	
Note	Display notes.		
Display Lines of Monitored Current Value	Open the <u>Options</u> screen and display/hide the lines of monitored current value.		
Display Format for Device Comment	Open the <u>Options</u> screen and set the display format for device comment.		
Display Ladder Block			
Hide Ladder Block	Hide the ladder block at the cursor position.		
Display Ladder Block	Display the hidden ladder block at the cursor position.		
Hide All Ladder Block	Hide all ladder blocks.		
Display All Ladder Block	Display all hidden ladder blocks.		
Device Display			
Device Display	Display the device assigned by compilation.		
Batch Device Display	Batch-change the label display on the program editors to the device display.		
Cancel All Device Display	Cancel the device display on the program editors, and display data in the format at the time of data entry.		
Display Compile Result	Display the compilation result of the program on the inline structured text box in a list format.		
Zoom	Change the display magnification of the ladder program.		
Text Size			-
Bigger	Enlarge the text display size on the editing screen.		(Simple)
Smaller	Reduce the text display size on the editing screen.		
Open Other Window			-
Open Reference Window	Open the reference window of the ladder editor.		(Simple)
Update Reference Window	Apply the most recent ladder program to the reference window.		
Open Reference Source Window	Display the source of the referenced ladder editor.	(FB)	
Tile FB Horizontally	Tile the ladder editor and the function block program editor horizontally.		
Open Label Setting	Open the <u>Local Label Setting</u> screen for the program being edited.	(Simple)	
Open Zoom SFC Block	Display the SFC diagram of the Zoom editor window.		
Move SFC Cursor		-	
Up	Move the cursor on the SFC diagram upward.	(Simple)	
Down	Move the cursor on the SFC diagram downward.		
Left	Move the cursor on the SFC diagram to the left.		
Right	Move the cursor on the SFC diagram to the right.		
Open Instruction Help	Display the <u>Instruction Help</u> screen.		
ST Monochrome Display	Switch the text color (color or monochrome) in inline structured text boxes.		
Online (function for editing in Ladder Diagram)		Reference	
Monitor		-	
Monitor Condition Setting	Set a condition to start monitoring.	(Simple)	
Monitor Stop Condition Setting	Set a condition to stop monitoring.		
Entry Ladder Monitor	Register and monitor ladder blocks.		
Delete All Entry Ladder	Delete all registered ladder blocks.		

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

### 1.3.3 List of functions for editing SFC diagrams

The following tables show the functions for editing SFC diagrams.

Edit (function for editing SFC diagrams)		Reference
Delete	Delete the selected data.	(Simple)
Arrange SFC	Redisplay the SFC diagram.	
Insert Row	Insert a row at the cursor position.	
Delete Row	Delete the row at the cursor position.	
Insert Column	Insert a column at the cursor position.	
Delete Column	Delete the column at the cursor position.	
Edit Line		-
Vertical Line Segment	Insert  at the cursor position.	(Simple)
Selection Divergence	Insert  at the cursor position.	
Simultaneous Divergence	Insert  at the cursor position.	
Selection Convergence	Insert  at the cursor position.	
Simultaneous Convergence	Insert  at the cursor position.	
Delete Line	Delete the line at the cursor position.	
Change TC Setting	Batch-change timer/counter setting values used in the program.	
Ladder Edit Mode		-
Read Mode	Switch the mode of the open window to "Read Mode".	(Simple)
Write Mode	Switch the mode of the open window to "Write Mode".	
Read Mode (All Windows)	Switch the mode of all open windows to "Read Mode".	
Write Mode (All Windows)	Switch the mode of all open windows to "Write Mode".	
SFC Step Attribute		-
No Attribute	Set the step attribute to No Attribute.	(Simple)
Stored Coil	Set the step attribute to Stored Coil.	
Stored Operation (without Transition Check)	Set the step attribute to Stored Operation (SE).	
Stored Operation (with Transition Check)	Set the step attribute to Stored Operation (ST).	
Reset	Reset the step attribute.	
SFC Symbol		-
[STEP] Step	Insert  at the cursor position.	(Simple)
[B] Block Start Step (with END Check)	Insert  at the cursor position.	
[BS] Block Start Step (without END Check)	Insert  at the cursor position.	
[JUMP] Jump	Insert  at the cursor position.	
[END] END Step	Insert  at the cursor position.	
[DUMMY] Dummy Step	Insert  at the cursor position.	
[TR] Transition	Insert  at the cursor position.	
[--D] Selection Divergence	Insert  at the cursor position.	
[==D] Simultaneous Divergence	Insert  at the cursor position.	
[--C] Selection Convergence	Insert  at the cursor position.	
[==C] Simultaneous Convergence	Insert  at the cursor position.	
[ ] Vertical Line	Insert  at the cursor position.	-
Sort SFC Step No.	Sort the SFC step/transition numbers in ascending/descending order.	(Simple)

Edit (function for editing SFC diagrams)		Reference
Documentation		-
SFC Step/Transition Comment	Change to the SFC step/transition comment editing mode.	(Simple)
Find/Replace (function for editing SFC diagrams)		Reference
Jump	Move the cursor to the specified position.	(Simple)
Find Jump Step	Move to the jump source step.	
Change SFC Step No.	Replace the SFC step number.	
Compile (function for editing SFC diagrams)		Reference
Convert Block	Convert a single block.	(Simple)
View (function for editing SFC diagrams)		Reference
Program Display	Display MELSAP-L programs.	(Simple)
SFC Step/Transition Comment	Display the SFC step/transition comments.	
Zoom	Change the display magnification ratio of the SFC diagram.	
Text Size		
Bigger	Enlarge the text display size on the editing screen.	
Smaller	Reduce the text display size on the editing screen.	
SFC Row Setting	Set the number of rows of SFC diagram.	
Open SFC Blocklist	Display the SFC block list screen.	
MELSAP3 Display	Display SFC in MELSAP3 format.	
MELSAP-L (Instruction Format) Display	Display SFC in MELSAP-L (instruction format).	
MELSAP-L (Start Conditions Format) Display	Display SFC in MELSAP-L (start conditions format).	-
Open Zoom/Start Destination Block	Display the Zoom editor window or the start destination block.	
Back to Start SFC Block	Display the SFC block of the start source.	
Open Header	Open the <u>Local Label Setting</u> screen for the program being edited.	(Simple)
Reset the Window Position to its Default	Return the display position of the SFC diagram editor window and the Zoom editor window to the initial status.	
Online (function for editing in SFC diagrams)		Reference
Monitor		-
Monitor Condition Setting	Set a condition to start monitoring.	(Simple)
Monitor Stop Condition Setting	Set a condition to stop monitoring.	

### 1.3.4 List of functions for editing SFC block list

The following tables show the functions for editing SFC block list.

Find/Replace (function for editing SFC block list)		Reference
Jump	Move the cursor to the specified block number.	(Simple)
Find Block No.	Search for a block number.	
Block Information Find Device	Search for a device.	
View (function for editing SFC block list)		Reference
SFC Block List Comment	Display comments of the SFC block list.	(Simple)
Device Display	Display devices.	
Open SFC Body	Open the SFC diagram.	
Open Header	Display the label setting editor.	

### 1.3.5 List of functions for editing in Structured Text

The following tables show the functions for the ST editor.

Edit (function for editing in Structured Text)		Reference
Delete	Delete the selected data.	–
List Operands	Display the screen for inserting a label by selecting an existing label.	(Structured)
Display Template	Insert a template corresponds to the instruction, function, or control syntax.	
Mark Template (Left)	Set an argument of the template in the selected status from the left by selecting the menu each time.	
Mark Template (Right)	Set an argument of the template in the selected status from the right by selecting the menu each time.	

Find/Replace (function for editing in Structured Text)		Reference
Jump	Jump to the specified line.	(Structured)
Bookmark		–
Toggle Bookmark	Set a bookmark at the cursor line. The bookmark is deleted when one is already set at the cursor line.	(Structured)
Bookmark List	Jump to the specified bookmark from the bookmark list.	
Next Bookmark	Display the next bookmark position.	
Previous Bookmark	Display the previous bookmark position.	
Delete All Bookmarks	Cancel all bookmarks.	
















View (function for editing in Structured Text)		Reference
Display Compile Result	Display the compilation result in a list format.	(Structured)
Zoom		–
Set Zoom Factor	Change the display size of the program.	(Structured)
Increase Zoom		
Decrease Zoom		
Zoom Header/Body		–
Header	Open the label setting editor in the selected POU.	(Structured)
Body	Open the program editor in the selected POU.	
Open Header	Open the <u>Local Label Setting</u> screen for the program being edited.	
ST Monochrome Display	Switch the text color (color or monochrome) in an ST editor.	

Online (function for editing in Structured Text)		Reference
Monitor		–
Start Monitoring	Start monitoring with the split window format that displays monitor data of numeric value and character strings.	(Structured)
Start Monitor (bit type only)	Start monitoring only bit type devices/labels.	



### 1.3.6 List of functions for editing in Structured Ladder/FBD

The following tables show the functions for the Structured Ladder/FBD editor.

Edit (function for editing in Structured Ladder/FBD)		Reference
Delete	Delete the selected data.	–
Select Mode	Use this to place a contact and coil.	(Structured)
Interconnect Mode	Use this to draw a line.	
Guided Mode		–
Guided Editing	Use this to edit using a keyboard.	(Structured)
Overwrite Mode	In the guided mode, overwrite an element entered at the cursor position.	
Insert Mode	In the guided mode, insert an element entered at the cursor position.	
Line Mode	In the guided mode, use this to draw a line.	
Auto Comment	In the guided mode, add a comment entry field at the top of the added ladder block.	
Auto Connect	Specify and connect the start and end points to draw a line.	
Recalculate Line	Arrange a line automatically to redraw it.	
Insert Row	Insert a row into the ladder program being edited.	
Insert Column	Insert a column into the ladder program being edited.	
New Ladder Block List		–
Top	Insert a new ladder block at the start of all ladder blocks.	(Structured)
Before	Insert a new ladder block in front of the ladder block being edited.	
After	Insert a new ladder block after the ladder block being edited.	
Bottom	Insert a new ladder block at the end of all ladder blocks.	
Input Instruction	Open the <u>Input Instruction</u> screen.	
Ladder Symbol		–
Open Contact	Insert  at the cursor position.	(Structured)
Close Contact	Insert  at the cursor position.	
Coil	Insert  at the cursor position.	
Jump	Insert  at the cursor position.	
Return	Insert  at the cursor position.	
Open Branch	Insert  at the cursor position.	
Close Branch	Insert  at the cursor position.	
Input Label	Insert  at the cursor position.	
Output Label	Insert  at the cursor position.	
Horizontal Line Segment	Insert  at the cursor position.	
Vertical Line Segment	Insert  at the cursor position.	
Rising Pulse	Insert  at the cursor position.	
Falling Pulse	Insert  at the cursor position.	
Rising Pulse Close	Insert  at the cursor position.	
Falling Pulse Close	Insert  at the cursor position.	
Comment	Insert a comment entry field at the cursor position.	

Edit (function for editing in Structured Ladder/FBD)		Reference
Ladder Symbol		–
Ladder Block Label	Display the <u>Ladder Block</u> screen.	(Structured)
Left Power Rail	Display/hide the left power rail.	
List Operands	Display the screen for inserting a label by selecting an existing label.	(Structured)
Number of Pins		–
Increment	Increase the number of arguments of functions and function blocks.	(Structured)
Delete	Decrease the number of arguments of functions and function blocks.	
Ladder Block List	Display a list of ladder blocks in a program.	
Signal Configuration		–
Configure	Set the type of a contact and a coil.	(Structured)
Toggle	Change the contact and coil type per execution in the following order. <ul style="list-style-type: none"> <li>• Contact: Open Contact → Close Contact</li> <li>• Coil: Normal → Negation → Set → Reset</li> </ul>	
Find/Replace (function for editing in Structured Ladder/FBD)		Reference
Jump	Jump to the specified ladder block number.	(Structured)
View (function for editing in Structured Ladder/FBD)		Reference
View Mode		–
Label	Display variables by its entered format.	(Structured)
Device	Display devices/addresses in device format. Devices assigned to labels are displayed in device format.	
Address	Display devices/addresses in address format. Devices assigned to labels are displayed in address format.	
Comment	Display devices/addresses in device comment. Labels are displayed in label comment.	
Change Label-Device-Address Mode	Switch the display item in the order of labels, devices, and addresses.	
Change Label-Comment Mode	Switch the display item in the order of labels and comments.	
Change I/O Label-Comment Mode	Switch the display item in the order of input/output labels and comments.	
Add Label Display Items		
Device	Display devices assigned to labels.	
Address	Display addresses assigned to labels.	
Label Comment	Display label comments assigned to labels.	
Device Comment	Display device comments correspond to devices or addresses.	
All Device Display	Batch-change all labels on the program editors to the device display.	
Cancel All Device Display	Cancel the device display on the program editors, and display data in the format at the time of data entry.	
Grid	Show a grid on the screen being edited to display the start/end positions of a line.	
Print Wrap Position	Display the wrapping position for printing.	
Display Compile Result	Display the compilation result in a list format.	
Zoom		–
Set Zoom Factor	Change the display size of the program.	(Structured)
Increase Zoom		
Decrease Zoom		

View (function for editing in Structured Ladder/FBD)		Reference
Zoom Header/Body		-
Header	Open the label setting editor in the selected POU.	(Structured)
Body	Open the program editor in the selected POU.	
Open Header	Open the <u>Local Label Setting</u> screen for the program being edited.	

<b>1</b>	OVERVIEW
<b>2</b>	SYSTEM CONFIGURATION
<b>3</b>	SCREEN CONFIGURATION AND BASIC OPERATIONS
<b>4</b>	PROJECT MANAGEMENT
<b>5</b>	EDITING PROGRAMS
<b>6</b>	SETTING PARAMETERS
<b>7</b>	SETTING DEVICE MEMORY
<b>8</b>	SETTING DEVICE INITIAL VALUES

### 1.3.7 List of functions for CC IE Field Configuration window

The following tables show the functions for the CC IE Field Configuration window.

CC IE Field Configuration (function on the CC IE Field Configuration window)		Reference
Change Module		–
Replace General CC IE Field Module	Replace the general-purpose CC IE Field module to a specific module.	Section 6.3.2
Change to General CC IE Field Module	Change the specific module to a general-purpose CC IE Field module.	
Change Transmission Path Method		–
Line/Star	Change the transmission path method to line or star.	Section 6.3.2
Ring	Change the transmission path method to ring.	
Supplementary Setting	Set the link scan mode setting, loopback function setting, block data assurance per station, and operation setting for returning.	Section 6.3.2
Equal Assignment	Assign the number of link device points of all stations equally.	
Identical Point Assignment	Assign the equal number of link device points based on the total number of set stations.	
Device No. Reassignment	Assign the device numbers continuously in the link device of the specified target station.	
Open System Configuration		–
Open AnyWireASLINK Configuration	Set the AnyWireASLINK Configuration of AnyWireASLINK sensor devices connected to a CC-Link IE Field Network-AnyWireASLINK bridge module.	(iQSS)
Check		–
System Configuration	Check whether the set equipment configuration of CC-Link IE Field Network is correct.	Section 6.3.2
Online		–
Detect Now	Apply the actual system configuration to the CC IE Field Configuration window. (Automatic detection of connected devices)	Section 6.3.2
Verification of the Configuration with the Connected Module	Verify a CC IE Field configuration currently displayed in GX Works2 with the actual system configuration.	
Parameter Processing of Device Station	Perform the parameter processing on a device station.	
Command Execution of Device Station	Perform commands on a device station.	
Backup Device Station	Backup parameters of a selected device station to a memory card.	(iQSS)
Restore Device Station	Restore backed up parameters of a device station.	
Close with Discarding the Setting	Discard the settings and close the CC IE Field Configuration window.	–
Close with Reflecting the Setting	Apply the settings and close the CC IE Field Configuration window.	Section 6.3.2
Edit (function on the CC IE Field Configuration window)		Reference
Copy	Copy the information of the device station of the selected row.	Section 6.3.2
Paste	Paste the copied device station to the last row of the list of stations.	
Select All	Select all cells on the list of stations.	
Delete	Delete the device station of the selected row.	

View (function on the CC IE Field Configuration window)		Reference
Docking Window		-
Module List	Display/hide the Module List window of CC-Link IE Field Network.	Section 6.3.2
Output	Display/hide the Output window.	
Supplementary Information	Display/hide the Supplementary Information window.	
Object Name Display	Display/hide the object name in the list of stations.	

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

### 1.3.8 List of functions for CC-Link Configuration window

The following tables show the functions for the CC-Link Configuration window.

CC-Link Configuration (function on the CC-Link Configuration window)		Reference
Change Module		–
Replace General CC-Link Module	Replace the general-purpose CC-Link module to a specific module.	Section 6.3.3
Change to General CC-Link Module	Change the specific module to a general-purpose CC-Link module.	
Open System Configuration		–
Open AnyWireASLINK Configuration	Display the AnyWireASLINK Configuration of AnyWireASLINK sensor devices connected to a CC-Link-AnyWireASLINK bridge module.	(iQSS)
Check		–
System Configuration	Check whether the set equipment configuration of CC-Link is correct.	Section 6.3.3
Online		–
Detect Now	Apply the actual system configuration to the CC-Link Configuration window. (Automatic detection of connected devices)	Section 6.3.3
Verification of the Configuration with the Connected Module	Verify the CC-Link Configuration window being displayed against an actual system configuration. (Automatic detection of system configuration)	
Parameter Processing of Device Station	Perform the parameter processing on a device station.	
Command Execution of Device Station	Perform commands on a device station.	
Backup Device Station	Backup the parameter of the selected device station to the memory card.	(iQSS)
Restore Device Station	Restore the backup parameter of the device station.	
Close with Discarding the Setting	Discard the settings and close the CC-Link Configuration window.	–
Close with Reflecting the Setting	Apply the settings and close the CC-Link Configuration window.	Section 6.3.3

Edit (function on the CC-Link Configuration window)		Reference
Copy	Copy the information of the device station of the selected row.	Section 6.3.3
Paste	Paste the copied device station to the last row of the list of stations.	
Select All	Select all cells on the list of stations.	–
Delete	Delete the device station of the selected row.	Section 6.3.3

View (function on the CC-Link Configuration window)		Reference
Docking Window		–
Module List	Display/hide the Module List window of CC-Link.	Section 6.3.3
Output	Display/hide the Output window.	
Verify Result	Display/hide the Verify Result window displayed when the Verification of the Configuration with the Connected Module function is executed.	

### 1.3.9 List of functions for AnyWireASLINK Configuration window

The following tables show the functions for the AnyWireASLINK Configuration window.

AnyWireASLINK Configuration (function on the AnyWireASLINK Configuration window)		Reference
Change Module		–
Replace General AnyWireASLINK Module	Replace the general-purpose AnyWireASLINK module to a specific module.	(Intelligent)
Change to General AnyWireASLINK Module	Change the specific module to a general-purpose AnyWireASLINK module.	
Address Auto-Input	Enter the address of the remote module automatically.	–
Check		–
System Configuration	Check whether the set equipment configuration of AnyWireASLINK is correct.	(Intelligent)
Online		–
Detect Now	Apply the actual system configuration to the AnyWireASLINK Configuration window. (Automatic detection of connected devices)	(Intelligent)
Verification of the Configuration with the Connected Module	Verify the AnyWireASLINK Configuration window being displayed against an actual system configuration. (Automatic detection of system configuration)	
Parameter Processing of Remote Module	Perform the parameter processing on a remote module.	(iQSS)
Backup Remote Module	Backup the parameter of the selected remote module to the memory card.	
Restore Remote Module	Restore the backup parameter of the remote module.	
Close with Discarding the Setting	Discard the settings and close the AnyWireASLINK Configuration window.	–
Close with Saving the Setting	Apply the settings and close the AnyWireASLINK Configuration window.	(Intelligent)
Edit (function on the AnyWireASLINK Configuration window)		Reference
Copy	Copy the information of the remote module of the selected row.	–
Paste	Paste the copied remote module to the last row of list of modules.	
Select All	Select all cells on the list of modules.	
Delete	Delete the remote module of the selected row.	
View (function on the AnyWireASLINK Configuration window)		Reference
Docking Window		–
Module List	Display/hide the Module List window of AnyWireASLINK.	
Output	Display/hide the Output window.	
Verify Result	Display/hide the Verify Result window displayed when the Verification of the Configuration with the Connected Module function is executed.	–

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

### 1.3.10 List of Ethernet Configuration window

The following tables show the functions for the Ethernet Configuration window.

Ethernet Configuration (function on the Ethernet Configuration window)		Reference
Change Module		–
Replace General SLMP Module	Replace a general SLMP module to a specific Ethernet device.	Section 6.1.3
Change to General SLMP Module	Change a specific Ethernet device to a general SLMP module.	
Check		–
System Configuration	Check whether the set equipment configuration of Ethernet is correct.	Section 6.1.3
Online		–
Detect Now	Apply the actual system configuration to the Ethernet Configuration window. (Automatic detection of connected devices)	Section 6.1.3
Communication Setting Reflection of Ethernet Device	Apply the communication setting set on the Ethernet Configuration window to the Ethernet device.	(iQSS)
Parameter Processing of Ethernet Device	Perform the parameter processing on an Ethernet device.	
Backup Ethernet Device	Backup parameters of the selected Ethernet devices to the memory card.	
Restore Ethernet Device	Restore the backup parameters of Ethernet devices.	
Close with Discarding the Setting	Discard the settings and close the Ethernet Configuration window.	–
Close with Reflecting the Setting	Apply the settings and close the Ethernet Configuration window.	Section 6.1.3

Edit (function on the Ethernet Configuration window)		Reference
Copy	Copy the information of the Ethernet device of the selected row.	Section 6.1.3
Paste	Paste the copied Ethernet device to the last row of list of device.	
Select All	Select all cells on the list of modules.	
Delete	Delete the Ethernet device of the selected row.	

View (function on the Ethernet Configuration window)		Reference
Docking Window		Section 6.1.3
Module List	Display/hide the Module List window of Ethernet.	
Output	Display/hide the Output window.	



### 1.3.11 List of CC-Link IEF Basic Configuration window

The following tables show the functions for the CC-Link IEF Basic Configuration window.

CC-Link IEF Basic Configuration (function on the CC-Link IEF Basic Configuration window)		Reference
Change Module		–
Replace CC-Link IEF Basic Connected Module	Replace a CC-Link IEF Basic module with a specific module.	Section 6.1.4
Change to CC-Link IEF Basic Connected Module	Change a specific module to a CC-Link IEF Basic module.	
Link Scan Setting	Set the time out time and the number of times to detect the disconnection of a remote station.	Section 6.1.4
Check		–
System Configuration	Check whether the equipment configuration in a set CC-Link IE Field Network Basic is correct.	Section 6.1.4
Online		–
Detect Now	Apply the actual system configuration to the CC-Link IEF Basic Configuration window. (Automatic detection of connected devices)	Section 6.1.4
Communication Setting Reflection of Remote Station	Apply the communication setting set in the CC-Link IEF Basic Configuration window to remote stations.	(Basic)
Parameter Processing of Remote Station	Perform the parameter processing on a remote station.	(Basic)
Close with Discarding the Setting	Discard the settings and close the CC-Link IEF Basic Configuration window.	–
Close with Reflecting the Setting	Apply the settings and close the CC-Link IEF Basic Configuration window.	Section 6.1.4
Edit (function on the CC-Link IEF Basic Configuration window)		Reference
Copy	Copy the information of the CC-Link IEF Basic device of the selected row.	Section 6.1.4
Paste	Paste the copied CC-Link IEF Basic module to the last row in the station list.	
Select All	Select all cells on the list of stations.	
Delete	Delete the CC-Link IEF Basic device of the selected row.	
View (function on the CC-Link IEF Basic Configuration window)		Reference
Docking Window		Section 6.1.4
Module List	Display/hide the Module List window of CC-Link IEF Basic.	
Output	Display/hide the Output window.	

### 1.3.12 List of functions for the Sensor/Device Monitor screen

The following tables show the functions for the Sensor/Device Monitor screen.

Sensor/Device Monitor (function on the Sensor/Device Monitor screen)		Reference
Open System Configuration		–
Open AnyWireASLINK Configuration	Set the AnyWireASLINK Configuration of AnyWireASLINK sensor devices connected to a CC-Link IE Field Network-AnyWireASLINK bridge module or a CC-Link-AnyWireASLINK bridge module.	(iQSS)
Close	Close the Sensor/Device Monitor screen.	–

View (function on the Sensor/Device Monitor screen)		Reference
Docking Window		-
Monitoring Information	Display/hide the Monitor Information window.	
Online (function on the Sensor/Device Monitor screen of CC-Link IE Field Network)		Reference
Parameter Processing of Device Station	Perform the parameter processing on a device station.	(iQSS)
Command Execution of Device Station	Perform commands on a device station.	
Start Monitoring	Start monitoring sensors and equipment.	
Stop Monitoring	Stop monitoring sensors and equipment.	
Online (function on the Sensor/Device Monitor screen of CC-Link)		Reference
Parameter Processing of Device Station	Perform the parameter processing on a device station.	(iQSS)
Command Execution of Device Station	Perform commands on a device station.	
Backup Device Station	Backup the parameter of the selected device station to a memory card.	
Restore Device Station	Restore the backup parameter of the device station.	
Start Monitoring	Start monitoring sensors and equipment.	
Stop Monitoring	Stop monitoring sensors and equipment.	
Online (function on the Sensor/Device Monitor screen of AnyWireASLINK)		Reference
Parameter Processing of Remote Module	Perform the parameter processing on a remote module.	(iQSS)
Backup Remote Module	Backup the parameter of the selected remote module to a memory card.	
Restore Remote Module	Restore the backup parameter of the remote module.	
Start Monitoring	Start monitoring sensors and equipment.	
Stop Monitoring	Stop monitoring sensors and equipment.	
Online (function on the Sensor/Device Monitor screen of Ethernet)		Reference
Parameter Processing of Ethernet Device	Perform the parameter processing on an Ethernet device.	(iQSS)
Backup Ethernet Device	Backup parameters of the selected Ethernet devices to the memory card.	
Restore Ethernet Device	Restore the backup parameters of Ethernet devices.	
Start Monitoring	Start monitoring sensors and equipment.	
Stop Monitoring	Stop monitoring sensors and equipment	

### 1.3.13 List of functions for GX Simulator2 screen

The following tables show the functions for the GX Simulator2 screen.

Tool (function on the <u>GX Simulator2</u> screen)		Reference
Backup Device Memory in Simulation		-
Save	Save device memory/buffer memory in simulation temporarily.	Section 18.2.1
Read	Read device memory/buffer memory saved temporarily.	Section 18.2.2
I/O System Setting	Execute simulation with the I/O system setting.	Section 22.1
Options (function on the <u>GX Simulator2</u> screen)		Reference
Start in minimized status	Start the <u>GX Simulator2</u> screen in the minimized status at starting simulation.	Section 18.2
Save device memory at stop	Save device memory/buffer memory in simulation automatically at stopping simulation.	Section 18.2.1

## 1.3.14 List of functions for I/O system setting screen

The following tables show the functions for the I/O System Setting screen.

File (function for the I/O system setting)		Reference
New	Create a new I/O system setting.	Section 22.8.1
Open	Open an existing I/O system setting.	Section 22.8.2
Save	Save an I/O system setting.	–
Save As	Name and save an I/O system setting.	Section 22.8.3
(Recently used I/O system setting files 1 to 4)	Display the recently used I/O system setting file names and open the selected I/O system setting file.	–
Execute I/O System Setting	Execute the I/O system setting and start simulation.	Section 22.6.1
Disable I/O System Setting	Disable execution of the I/O system setting.	Section 22.6.2
Exit I/O System Settings	Exit the I/O system setting.	–

Edit (function for the I/O system setting)		Reference
Cut	Cut the selected data.	Section 22.4.2
Copy	Copy the selected data.	
Paste	Paste the cut or copied data at the cursor position.	
Delete	Delete the selected data.	–
Enable/Disable Setting		–
Enable All	Enable all I/O system settings.	Section 22.4
Disable All	Disable all I/O system settings.	

View (function for the I/O system setting)		Reference
Toolbar	Display/hide the toolbar.	–
Statusbar	Display/hide the status bar.	

Online (function for the I/O system setting)		Reference
Target Simulator Setting	Set the target simulation with which the I/O system setting is executed.	Section 22.3
Start Monitoring	Start monitoring the <u>I/O System Setting</u> screen.	Section 22.7.1
Stop Monitoring	Stop monitoring the <u>I/O System Setting</u> screen.	

Window (function for the I/O system setting)		Reference
Cascade	Cascade windows.	–
Tile Vertically	Tile windows on the <u>I/O System Setting</u> screen vertically.	
Tile Horizontally	Tile windows on the <u>I/O System Setting</u> screen horizontally.	
Arrange Icons	Arrange the icons at the bottom of the <u>I/O System Setting</u> screen.	

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

### 1.3.15 List of functions for predefined protocol support function

The following tables show the functions for the predefined protocol support function.

File (function of the predefined protocol support function)		Reference
New	Create a new protocol setting file.	(Intelligent)
Open	Open an existing protocol setting file.	
Close	Close the open protocol setting file.	
Save	Save the protocol setting file.	
Save As	Name and save a protocol setting file.	
Open Other Data		
Serial Communication Module Format	Open a protocol setting file of serial communication module format.	
Ethernet Module Format	Open a protocol setting file of Ethernet module format.	
Built-in/Adapter Serial Format	Open a protocol setting file of built-in/adapter serial format.	
Built-in Ethernet Format	Open a protocol setting file of built-in Ethernet format.	
Print	Print such as protocol setting.	
Exit	Exit the predefined protocol support function.	

Edit (function of the predefined protocol support function)		Reference
Add Protocol	Add a protocol.	(Intelligent)
Change to Editable Protocol	Change the protocol selected from the predefined protocol library to an editable one.	
Protocol Detailed Setting	Set the protocol detailed setting such as the number of retries of protocol transmission and whether to clear operating system area (receive data area).	
Add Receive Packet	Add a receive packet.	
Delete	Delete the protocol.	
Copy	Copy the protocol.	
Paste	Paste the protocol.	
Delete Multiple Protocols	Batch-delete multiple protocols.	
Copy Multiple Protocols	Batch-copy multiple protocols.	
Paste Multiple Protocols	Batch-paste multiple protocols.	
Device Batch Setting	Batch-set devices used in the protocol.	
Save User Protocol Library	Save the set protocol as a user protocol library.	

Module Read/Write (function of the predefined protocol support function)		Reference
Read from Module	Read protocol settings from the module.	(Intelligent)
Write to Module	Write registered protocol settings to the module.	
Module Verification	Compare protocol settings being opened with those written in the module.	

Tool (function of the predefined protocol support function)		Reference
Setting Device List	Display the list of devices used in protocols.	(Intelligent)
Register Predefined Protocol Library	Import predefined protocol library provided by Mitsubishi Electric Corporation.	

Debugging Support Function (function of the predefined protocol support function)		Reference
Module Selection	Select a module to be debugged.	(Intelligent)
Protocol Execution Log	Display the protocol execution logs and the protocol execution results.	
State Monitor	Monitor signals, communication error information, operation setting switches, and protocol execution status of the Q series C24N/L series C24 module.	
Window (function of the predefined protocol support function)		Reference
Cascade	Cascade windows.	(Intelligent)
Tile Horizontally	Tile windows horizontally.	
(Switch to other window)	Display the open window.	

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES



---

# 2 SYSTEM CONFIGURATION


This chapter explains the system configuration, configuration devices, and supported languages of GX Works2.

2.1	Connection from USB/Serial Port	2 - 2
2.2	Connection from I/F Boards	2 - 14
2.3	Interfaces and Connectable Modules	2 - 16
2.4	System Configuration with Memory Card on Personal Computer	2 - 20
2.5	Supported Programming Languages	2 - 21

## 2.1 Connection from USB/Serial Port


Q CPU L CPU Remote Head FX

The following shows the possible system configuration for connecting to the programmable controller CPU using the USB/serial port of a personal computer. For ACPU, use GX Developer. For details of the use of ACPU, refer to Appendix 14.



- \*1: Section 2.1.1
- \*2: Section 2.1.2
- \*3: Section 2.1.3
- \*4: Section 2.1.4
- \*5: Section 2.1.5
- \*6: Section 2.1.6
- \*7: Section 2.1.7
- \*8: Section 2.1.8





\*1 : Section 2.1.9  
 \*2 : Section 2.1.10  
 \*3 : Section 2.1.11

1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES

## 2.1.1 USB cables (compatible with QCPU (Q mode), LCPU, and communication head module)

The following table shows USB cables available for QCPU (Q mode), LCPU, and communication head module.

Product name	Type
USB cable	USB cable (A - B type plug)*1
	USB cable (A - miniB type plug)*2

\*1 : For QCPU (Q mode) only, except for Universal model QCPU.

\*2 : For Universal model QCPU/LCPU/communication head module only

### Point

- **Using a USB cable for the first time**  
Install the USB driver. (Appendix 16)

- **Considerations and restrictions**

For the considerations and restrictions when accessing a programmable controller CPU, refer to Section 14.11.


- **Using a USB/RS-232 conversion cable**

For checking the COM port number as connecting a personal computer to a programmable controller CPU using such as USB/RS-232 conversion cable, refer to the user's manual of each cable.

## ■ Configurations for USB connection


Only one programmable controller CPU can be connected to a personal computer using a USB cable. Connection to a programmable controller CPU is not applicable to the configuration examples below.

<Inapplicable configurations>



## 2.1.2 USB cables and function expansion boards (compatible with FX3U/FX3UC)

FX3U-USB-BD



USB cable (included)




### Point

#### ● Using a USB cable for the first time

- Install the USB driver.
  - ☞ FX-USB-AW/FX3U-USB-BD USER'S MANUAL - USB Driver Installation Edition
- GX Works2 selects data from the Connection Destination view on the Navigation window and assigns a serial COM port number.

#### ● Considerations and restrictions

- For the considerations and restrictions relating to FX3U-USB-BD, refer to the user's manual included.
- When "Operate Communication Setting" is selected on the <<PLC System (2)>> tab of PLC parameter, the corresponding port cannot communicate with the programmable controller CPU. Write the setting in which "Operate Communication Setting" is cleared from the built-in programming port of the programmable controller CPU. When the programmable controller type of the project is FX3U/FX3UC, the channel setting (CH1/CH2) combo box is displayed. Select 'CH1' to confirm the setting.



## 2.1.3 USB cables (compatible with FX3s, FX3G and FX3GC)

For details of cables, refer to the following manuals.

- ☞ FX3s Series User's Manual- Hardware Edition
- ☞ FX3G Series User's Manual- Hardware Edition
- ☞ FX3GC Series User's Manual- Hardware Edition

Only one programmable controller CPU can be connected to a personal computer using a USB cable. (☞ Section 2.1.1 "■ Configurations for USB connection")

### Point


#### ● Using a USB cable for the first time

- Install the USB driver. (☞ Appendix 16)
- GX Works2 selects data from the Connection Destination view on the Navigation window and configures a USB.

### 2.1.4 RS-232 cables (compatible with QCPU (Q mode), LCPU, and remote I/O module)

The following table shows RS-232 cables whose operations have been confirmed at Mitsubishi Electric Corporation.

LCPU can be connected with an RS-232 adapters (L6ADP-R2).

Model	Product name
QC30R2 (Personal computer connector: 9-pin D-sub connector) 	Mitsubishi Electric Corporation RS-232 cable










**Point**

● **High-speed communication**

For high-speed communication (transmission speed: 115.2/57.6kbps), use a personal computer compatible with high-speed communication.

When a communication error occurs, retry the communication after reducing the transmission speed setting.

### 2.1.5 Converters/cables for RS-232 connection (compatible with FXCPU)

Personal computer side (RS-232 cable)	RS-232/RS-422 converter	Programmable controller CPU side (RS-422 cable)
 F2-232CAB (25-pin D-sub↔25-pin D-sub)	 FX-232AW	For FX1/FXu/FX2c  FX-422CAB (0.3 m) FX-422CAB-150 (1.5 m)
 F2-232CAB-1 (9-pin D-sub↔25-pin D-sub)	 FX-232AWC	For FX0s/FX0/FX0N/FX1s/FX1N/FX1NC/FX2N/FX2NC/ FX3s/FX3G/FX3GC/FX3U/FX3UC  FX-422CAB0 (1.5 m)
 F2-232CAB-2 (Half pitch↔25-pin D-sub)	 FX-232AWC-H	-
 AC30N2A(25-pin↔25-pin)		

**Point**

● **Transmission speed**

When connecting to FX3s/FX3G/FX3GC/FX3U/FX3UC using FX-232AWC-H, select any of 9.6kbps, 19.2kbps, 38.4kbps, 57.6kbps, or 115.2kbps for the transmission speed.

When connecting using FX-232AWC or FX-232AW, select either 9.6kbps or 19.2kbps for the transmission speed.

● **Connecting to FXCPU**

Be sure to use equipment shown in the table when connecting to FXCPU.

## ■ Considerations for using RS-422 interface cables/converters

For the specifications of an RS-422 interface conversion cable/converter and the considerations for using them, please read the following instructions as well as the manuals of each product for correct handling.

### ● Connecting/disconnecting the conversion cable/converter

When connecting/disconnecting a peripheral device, conversion cable or converter to/from the RS-422 interface, be sure to touch a grounding strap or grounded metal to discharge static electricity stored in the cable or in your body before the operation, regardless of whether electricity is being supplied or not. After doing this, follow the procedure below.

Turn the programmable controller CPU OFF before connecting/disconnecting a conversion cable/converter that receives 5VDC power supply from the RS-422 interface.

#### Operation

1. Turn OFF the personal computer.
2. Turn OFF the conversion cable/converter. Ground the FG terminal if provided.
3. Connect/disconnect the conversion cable/converter to/from the personal computer and the programmable controller CPU.
4. Turn ON the conversion cable/converter.
5. Turn ON the personal computer.
6. Start up the software package.

## 2.1.6 Connection using function expansion boards (compatible with FXCPU)

The following table shows the compatibility of FXCPU with function expansion boards.

Series	Function expansion board
FX3U, FX3UC (FX3UC-32MT-LT, FX3UC-32MT-LT-2 only)	FX3U-422-BD
FX3S, FX3G	FX3G-422-BD
FX2N	FX2N-422-BD
FX1S, FX1N	FX1N-422-BD

**Point**
**● PLC parameter**

When "Operate Communication Setting" is selected on the <<PLC System (2)>> tab of PLC parameter, the corresponding port cannot communicate with the programmable controller CPU. Write the setting in which "Operate Communication Setting" is cleared from the built-in programming port of the programmable controller CPU. When the programmable controller type of the project is FX3G/FX3GC or FX3U/FX3UC, the channel setting (CH1/CH2) combo box is displayed.

Select 'CH1' to confirm the setting.

The screenshot shows the 'FX Parameter' dialog box with the 'Operate Communication Setting' tab selected. The 'CH1' dropdown menu is open, showing 'CH1' as the selected option. The 'Operate Communication Setting' checkbox is unchecked. The dialog contains various communication parameters:

- Protocol:** Non-Procedural
- Data Length:** 7Bit
- Parity:** Odd
- Stop Bit:** 1Bit
- Transmission Speed:** 9600 (bps)
- Header:**
- Terminator:**
- Control Line:**
- H/W Type:** Regular/RS-232C
- Control Mode:** Invalid
- Sum Check:**
- Transmission Control Procedure:** Form1(Without CR,LF)
- Station Number Setting:** 00 H (00H-0FH)
- Time Out Judge Time:** 1 X 10ms (1-255)

Buttons at the bottom include: Print Window..., Print Window Preview, Default, Check, End, and Cancel.

## 2.1.7 Connection using RS-232 cables and function expansion boards (special adapters) (compatible with FXCPU)

The following table shows the compatibility of RS-232 cables with function expansion boards and special adapters according to the shape and pin configuration of the serial port of the personal computer.

Serial port shape of personal computer	Series	Function expansion board and special adapter	RS-232 cable
9-pin D-sub	FX3U, FX3UC	FX3U-232-BD*1	FX-232CAB-1
		Function expansion board (FX3U-***-BD)*2 + FX3U-232ADP	
	FX3G, FX3GC	FX3G-232-BD*3	FX-232CAB-1
		FX3G-CNV-ADP*4 + FX3U-232ADP	
	FX3S	FX3G-232-BD	FX-232CAB-1
		FX3S-CNV-ADP + FX3U-232ADP	
	FX2N	FX0N-232ADP + FX2N-CNV-BD	F2-232CAB-1
		FX2N-232-BD	FX-232CAB-1
		FX2NC-232ADP + FX2N-CNV-BD	
	FX1NC, FX2NC	FX0N-232ADP	F2-232CAB-1
		FX2NC-232ADP	FX-232CAB-1
	FX1S, FX1N	FX0N-232ADP + FX1N-CNV-BD	F2-232CAB-1
FX1N-232-BD		FX-232CAB-1	
FX2NC-232ADP + FX1N-CNV-BD			
Half pitch 14-pin	FX3U, FX3UC	FX3U-232-BD*1	FX-232CAB-2
		Function expansion board (FX3U-***-BD)*2 + FX3U-232ADP	
	FX3G, FX3GC	FX3G-232-BD*3	FX-232CAB-2
		FX3G-CNV-ADP*4 + FX3U-232ADP	
	FX3S	FX3G-232-BD	FX-232CAB-2
		FX3S-CNV-ADP + FX3U-232ADP	
	FX2N	FX0N-232ADP + FX2N-CNV-BD	F2-232CAB-2
		FX2N-232-BD	FX-232CAB-2
		FX2NC-232ADP + FX2N-CNV-BD	
	FX1NC, FX2NC	FX0N-232ADP	F2-232CAB-2
		FX2NC-232ADP	FX-232CAB-2
	FX1S, FX1N	FX0N-232ADP + FX1N-CNV-BD	F2-232CAB-2
FX1N-232-BD		FX-232CAB-2	
FX2NC-232ADP + FX1N-CNV-BD			

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES

Serial port shape of personal computer	Series	Function expansion board and special adapter	RS-232 cable
25-pin D-sub	FX3U, FX3UC	FX3U-232-BD*1	F2-232CAB-1
		Function expansion board (FX3U-***-BD)*2 + FX3U-232ADP	
	FX3G, FX3GC	FX3G-232-BD*3	F2-232CAB-1
		FX3G-CNV-ADP*4 + FX3U-232ADP	
	FX3S	FX3G-232-BD	F2-232CAB-1
		FX3S-CNV-ADP + FX3U-232ADP	
	FX2N	FX0N-232ADP + FX2N-CNV-BD	F2-232CAB
		FX2N-232-BD	F2-232CAB-1
		FX2NC-232ADP + FX2N-CNV-BD	
	FX1NC, FX2NC	FX0N-232ADP	F2-232CAB
		FX2NC-232ADP	F2-232CAB-1
	FX1S, FX1N	FX0N-232ADP + FX1N-CNV-BD	F2-232CAB
FX1N-232-BD		F2-232CAB-1	
FX2NC-232ADP + FX1N-CNV-BD			

\*1 : For FX3UC series, only FX3UC-32MT-LT and FX3UC-32MT-LT-2 are connectable.

\*2 : '\*\*\*' of function expansion boards (FX3U-\*\*\*-BD) indicates 232, 485, 422, USB, CNV, or 8AV.  
Function expansion board (FX3U-\*\*\*-BD) is not required for FX3UC (D, DS, DSS) series.

\*3 : FX3GC series are not connectable.

\*4 : ADP (FX3G-CNV-ADP) for FX3U adapter connection is not required for FX3GC series.






### ● PLC parameter


When "Operate Communication Setting" is selected on the <<PLC System (2)>> tab of PLC parameter, the corresponding port cannot communicate with the programmable controller CPU. Write the setting in which "Operate Communication Setting" is cleared from the built-in programming port of the programmable controller CPU. When the programmable controller type of the project is FX3G/FX3GC or FX3U/FX3UC, the channel setting (CH1/CH2) combo box is displayed.

- FX3U/FX3UC (FX3UC-32MT-LT, FX3UC-32MT-LT-2) series  
When using the first adapter of FX3U-232ADP which is connected to FX3U-232-BD or FX3U-CNV-BD, specify 'CH1' and check the setting.  
When using FX3U-232ADP which is connected to a board other than FX3U-CNV-BD, or when using the second adapter of FX3U-232ADP which is connected to FX3U-CNV-BD, specify 'CH2' and check the setting.
- FX3UC (D, DS, DSS)/FX3GC series  
When using the first adapter of FX3U-232ADP which is connected to FX3UC (D, DS, DSS) or FX3GC series, specify 'CH1' and check the setting.  
When using the second adapter of FX3U-232ADP, specify 'CH2' and check the setting.
- FX3G series (14-/24-point type)  
When using FX3G-232-BD, or when using the first adapter of FX3U-232ADP which is connected to FX3G-CNV-ADP, specify 'CH1' and check the setting.
- FX3G series (40-/60-point type)  
When using FX3G-232-BD, or when using the first adapter of FX3U-232ADP which is connected to FX3G-CNV-ADP, specify 'CH1' and check the setting. In this case, when using the second adapter of FX3U-232ADP which is connected to FX3G-CNV-ADP, specify 'CH2' and check the setting.  
When using FX3G-232-BD and FX3U-232ADP which is connected to FX3G-CNV-ADP, specify 'CH1' and check the setting of FX3U-232ADP, and specify 'CH2' and check the setting of FX3G-232-BD.



## 2.1.8 Converters/cables for USB connection (compatible with FXCPU)

---



### Point

#### ● Using a USB cable for the first time

- Install the USB driver.
  - ☞ FX-USB-AW/FX3U-USB-BD USER'S MANUAL - USB Driver Installation Edition
- GX Works2 selects data from the Connection Destination view on the Navigation window and assigns a serial COM port number.

#### ● Considerations and restrictions

- For the considerations and restrictions relating to FX-USB-AW, refer to the user's manual included.
- 

## 2.1.9 Connection via AJ65BT-R2N

---

Use an RS-232 cable complies with the RS-232 standard within 15m.

For details, refer to the following manual.

- ☞ CC-Link System RS-232 Interface Module User's Manual (MELSOFT Connection Mode)

## 2.1.10 Function expansion board (special adapter)

Programmable controller side connector shape of cable included in modem package	Series	Function expansion board and special adapter
9-pin D-sub	FX3U, FX3UC	FX3U-232-BD*1
		Function expansion board (FX3U-***-BD)*2 + FX3U-232ADP
	FX3G, FX3GC	FX3G-232-BD*3
		FX3G-CNV-ADP*4 + FX3U-232ADP
	FX3S	FX3G-232-BD
		FX3S-CNV-ADP + FX3U-232ADP
	FX2N	FX2N-232-BD
FX2NC-232ADP + FX2N-CNV-BD		
FX1NC, FX2NC	FX2NC-232ADP	
25-pin D-sub	FX1S, FX1N	FX1N-232-BD
		FX2NC-232ADP + FX1N-CNV-BD
	FX2N	FX0N-232ADP + FX2N-CNV-BD
25-pin D-sub	FX1NC, FX2NC	FX0N-232ADP
	FX1S, FX1N	FX0N-232ADP + FX1N-CNV-BD


\*1 : For FX3UC series, only FX3UC-32MT-LT and FX3UC-32MT-LT-2 are connectable.

\*2 : \*\*\*\* of function expansion boards (FX3U-\*\*\*-BD) indicates 232, 485, 422, USB, CNV, or 8AV. Function expansion board (FX3U-\*\*\*-BD) is not required for FX3UC (D, DS, DSS) series.

\*3 : FX3GC series are not connectable.

\*4 : ADP (FX3G-CNV-ADP) for FX3U adapter connection is not required for FX3GC series.

Set "MODEM Initialized" on the <<PLC System (1)>> tab of PLC parameter according to the modem. For details, refer to Section 14.10.



## 2.1.11 Connection via GOT

The use of the transparent function of GOT enables the access to a programmable controller CPU via GOT. (☞ Section 14.9)


## 2.2 Connection from I/F Boards

Q CPU L CPU Remote Head FX <sup>\*1</sup>

\*1 : CC IE Field head module only

The following shows the system configuration for connecting to a programmable controller CPU using an I/F board installed on the personal computer.

For the methods how to install an I/F board, how to install the driver, and the supported programmable controller CPUs, refer to the manuals of each I/F board.



\*1 : Section 2.2.1

## 2.2.1 I/F boards

This section explains applications of I/F boards.  
For details, refer to the manual of each I/F board.

### ■ MELSECNET/H board

- For accessing Process CPU, use SW0DNC-MNETH-B version E or later.
- For accessing Redundant CPU, use SW0DNC-MNETH-B version K or later.

### ■ CC-Link Ver.1 board

- For accessing Process CPU, use SW4DNF-CCLINK-B version C or later.
- For accessing Redundant CPU, use SW4DNF-CCLINK-B version G or later.

1  
OVERVIEW2  
SYSTEM  
CONFIGURATION3  
SCREEN  
CONFIGURATION AND  
BASIC OPERATIONS4  
PROJECT  
MANAGEMENT5  
EDITING  
PROGRAMS6  
SETTING  
PARAMETERS7  
SETTING DEVICE  
MEMORY8  
SETTING DEVICE  
INITIAL VALUES

## 2.3 Interfaces and Connectable Modules

Q CPU L CPU Remote Head FX

This section explains details of the modules that can be connected from the USB port, serial port, and each I/F board.

### ■ Modules connectable from USB port

The following table shows the modules that can be connected from the USB port.

#### ● Q series, L series

Programmable controller series	Module model
Q series	Q00UJ, Q00U, Q01U, Q02H, Q02PH, Q02U, Q03UD, Q03UDE, Q03UDV, Q04UDH, Q04UDEH, Q04UDV, Q04UDPV, Q06H, Q06PH, Q06UDH, Q06UDEH, Q06UDV, Q06UDPV, Q10UDH, Q10UDEH, Q12H, Q12PH, Q12PRH, Q13UDH, Q13UDEH, Q13UDV, Q13UDPV, Q20UDH, Q20UDEH, Q25H, Q25PH, Q25PRH, Q26UDH, Q26UDEH, Q26UDV, Q26UDPV, Q50UDEH, Q100UDEH
L series	L02S, L02S-P, L02, L02-P, L06, L06-P, L26, L26-P, L26-BT, L26-PBT, LJ72GF15-T2, LJ72MS15

#### ● FX series

Module name	Connection route	Module model
Programmable controller main unit	FX-USB-AW*1	FX0S, FX0, FX0N, FX1S, FX1N, FX1NC, FX2N, FX2NC, FX3U, FX3UC
	USB direct connection	FX3S, FX3G, FX3GC
USB expansion board	USB direct connection*1	FX3U-USB-BD

\*1 : As FXCPU uses the serial ↔ USB conversion driver software, specify the COM port number of the RS-232 in the connection destination setting.

## ■ Modules connectable from serial port

The following table shows the modules that can be connected from the serial port.

Programmable controller series	Module name	Module model
Q series	Programmable controller CPU module	Q00J, Q00UJ, Q00, Q00U, Q01, Q01U, Q02(H), Q02PH, Q02U, Q03UD, Q04UDH, Q06H, Q06PH, Q06UDH, Q10UDH, Q12H, Q12PH, Q12PRH, Q13UDH, Q20UDH, Q25H, Q25PH, Q25PRH, Q26UDH
	Serial communication module*1	QJ71C24, QJ71C24-R2, QJ71C24N, QJ71C24N-R2, QJ71C24N-R4
	MELSECNET/H network remote I/O module	QJ72LP25, QJ72BR15
	G4 module	AJ65BT-G4-S3, AJ65BT-R2N
L series	Programmable controller CPU module	L02S, L02S-P, L02*2, L02-P*2, L06*2, L06-P*2, L26*2, L26-P*2, L26-BT*2, L26-PBT*2
	Serial communication module*1	LJ71C24, LJ71C24-R2
	G4 module	AJ65BT-G4-S3, AJ65BT-R2N
FX series*3	Programmable controller main unit	FX0S, FX0, FX0N, FX1, FX1S, FX1N, FX1NC, FXU, FX2C, FX2N, FX2NC, FX3S, FX3G, FX3GC, FX3U, FX3UC

\*1 : When accessing the programmable controller CPU from a personal computer via serial communication modules, note that modules that can be connected to the personal computer are limited. Even if a module cannot be directly connected to the personal computer, it may be usable as the nth module in multi-drop connection.

- For details of the multi-drop connection, refer to the following manuals.  
 ☞ Q Corresponding Serial Communication Module User's Manual (Basic)  
 ☞ MELSEC-L Serial Communication Module User's Manual (Basic)

<Q series>

○: Applicable ×: Not applicable

Model	Interface		1:1 system configuration	Multi-drop connection	
				1st module	nth module
QJ71C24N QJ71C24	CH1	RS-232	○	○	×
	CH2	RS-422/485	×	×	○
QJ71C24N-R2 QJ71C24-R2	CH1	RS-232	○	×	×
	CH2	RS-232	○ (Function version B or later)	×	×
QJ71C24N-R4	CH1	RS-422/485	×	×	×
	CH2	RS-422/485	×	×	×

<L series>

○: Applicable ×: Not applicable

Model	Interface		1:1 system configuration	Multi-drop connection	
				1st module	nth module
LJ71C24	CH1	RS-232	○	○	×
	CH2	RS-422/485	×	×	○
LJ71C24-R2	CH1	RS-232	○	×	×
	CH2	RS-232	○	×	×

\*2 : Connectable only with an RS-232 adapter (L6ADP-R2).

\*3 : Connectable only with an RS-232 ↔ RS-422 conversion board/adapter.

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES

■ **Modules connectable from MELSECNET/H board**

The following table shows the modules that can be connected from the MELSECNET/H board.

I/F board model	Programmable controller series	Module model
Q81BD-J71LP21-25 Q80BD-J71LP21S-25 Q80BD-J71LP21-25 Q80BD-J71LP21G Q80BD-J71BR11	Q series	QJ71LP21, QJ71LP21G, QJ71BR11, QJ71LP21-25, QJ71LP21S-25

■ **Modules connectable from CC-Link IE Controller Network board**

The following table shows the modules that can be connected from the CC-Link IE Controller Network board.

I/F board model	Programmable controller series	Module model
Q81BD-J71GP21S-SX Q81BD-J71GP21-SX Q80BD-J71GP21S-SX Q80BD-J71GP21-SX	Q series	QJ71GP21-SX, QJ71GP21S-SX

■ **Modules connectable from CC-Link IE Field Network board**

The following table shows the modules that can be connected from the CC-Link IE Field Network board.

I/F board model	Programmable controller series	Module model
Q81BD-J71GF11-T2 Q80BD-J71GF11-T2	Q series	QJ71GF11-T2
	L series	LJ72GF15-T2, LJ71GF11-T2

■ **Modules connectable from CC-Link Ver.1 board**

The following table shows the modules that can be connected from the CC-Link Ver.1 board.

I/F board model	Programmable controller series	Module model
A80BD-J61BT11 A80BD-J61BT13	Q series	QJ61BT11, QJ61BT11N

■ **Modules connectable from the CC-Link Ver.2 board**

The following table shows the modules that can be connected from the CC-Link Ver.2 board.

I/F board model	Programmable controller series	Module model
Q81BD-J61BT11 Q80BD-J61BT11N	Q series	QJ61BT11, QJ61BT11N
	L series	L26-BT, L26-PBT, LJ61BT11



## ■ Modules connectable from Ethernet board

The following table shows the modules that can be connected from the Ethernet board.

I/F board model	Programmable controller series	Module model
Ethernet board built-in a personal computer or commercially available	Q series	QJ71E71, QJ71E71-B2, QJ71E71-100, QJ71E71-B5, Q03UDE, Q03UDV, Q04UDEH, Q04UDV, Q04UDPV, Q06UDEH, Q06UDV, Q06UDPV, Q10UDEH, Q13UDEH, Q13UDV, Q13UDPV, Q20UDEH, Q26UDEH, Q26UDV, Q26UDPV, Q50UDEH, Q100UDEH
	L series	LJ71E71, L02, L02-P, L06, L06-P, L26, L26-P, L26-BT, L26-PBT
	FX series	FX-ENET series

1

OVERVIEW

2

SYSTEM CONFIGURATION

3

SCREEN CONFIGURATION AND BASIC OPERATIONS

4

PROJECT MANAGEMENT

5

EDITING PROGRAMS

6

SETTING PARAMETERS

7

SETTING DEVICE MEMORY

8

SETTING DEVICE INITIAL VALUES

## 2.4 System Configuration with Memory Card on Personal Computer



This section explains the system configuration when accessing from the personal computer with the memory card on the personal computer.

### ● Installing memory card into PC card slot

When installing a Q series memory card into the PC card slot, the following adapter is required.

Product name	Model	manufacturer
PC card adapter	Q2MEM-ADP	Mitsubishi Electric Corporation

### ● Writing/reading data to/from memory card

Using the following functions, even if a memory card cannot be installed into the programmable controller CPU, data can be written or read by installing the memory card to personal computer.

○: Applicable ×: Not applicable

Function	PLC series	Memory card	Windows®XP	Windows Vista®	Reference
IC memory card data write/read	Q series*1	SRAM card*2	×	×	Section 15.11.1
		ATA card	○	○	
		Flash card	×	×	
IC memory card data write/read (edit and data copy)	Q series*3 L series*4	SD memory card	○	○	Section 15.11.2
	L series*4	SD memory card	○	○	

\*1 : Not supported by Basic model QCPU, Q00UJ, Q00U, Q01U, High-speed Universal model QCPU, and Universal model process CPU.

\*2 : When using a SRAM card, set the driver to CONFIG.NT.  
(For details, refer to HELP of Windows®)

When using an ATA card, Windows® recognizes it automatically.

If the ATA card cannot be recognized, set the personal computer in "System" in Windows® Control Panel.

If the driver for SRAM card is set to CONFIG.NT, cancel the setting.

\*3 : For High-speed Universal model QCPU and Universal model process CPU only

\*4 : Not supported by L02S and L02S-P.

## 2.5 Supported Programming Languages



This section explains details of the programming languages supported by GX Works2.

○: Supported ×: Not supported

Programming language	Description	Simple project		Structured project
		without labels	with labels	
Ladder Diagram (LD)	A graphic language using ladder programs composed of contacts and coils. Ladder diagrams are created in a similar way to existing GX Developer. In projects with labels, the Inline structured text function can be used to edit ST programs on the ladder editor.	○	○	○*1
Structured Text (ST)	A text language with grammatical structure similar to C language.	×	○*1	○
Sequential Function Chart (SFC)*2	A graphic language which defines the executing order or condition of a program.	○	○*1	○*1
Structured Ladder	A graphic language using ladder programs composed of contacts and coils.	×	×	○
Function Block Diagram (FBD)	A graphic language using ladder programs by connecting functions and/or function blocks with lines.	×	×	○

\*1 : Not supported by FXCPU.

\*2 : For QCPU (Q mode)/LCPU, the display format of SFC can be selected from "MELSAP3", "MELSAP-L (Instruction Format)", and "MELSAP-L (Start Conditions Format)".

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES



---

# 3 SCREEN CONFIGURATION AND BASIC OPERATIONS

This chapter explains the screen configuration and basic operations of GX Works2.

3.1	Starting and Exiting GX Works2	3 - 2
3.2	Screen Configuration and Basic Operations	3 - 3
3.3	Selecting Language	3 - 30
3.4	Help Function	3 - 32

## 3.1 Starting and Exiting GX Works2

Q CPU L CPU Remote Head FX

This section explains the operation methods for starting and exiting GX Works2.

### ■ Starting GX Works2

---

Start GX Works2.

#### Operating procedure

- Start GX Works2 from "MELSOFT" in Windows Start.

### ■ Exiting GX Works2

---

Exit GX Works2.

#### Operating procedure

- Select [Project] ⇒ [Exit].

# 3.2 Screen Configuration and Basic Operations

Q CPU L CPU Remote Head FX

This section explains the main frame (basic screen) of GX Works2 that is displayed when it is started up.

## 3.2.1 Main frame configuration

The following screen shows a main frame configuration on which a work window and docked windows are displayed.

### Screen display

The screenshot shows the GX Works2 main frame configuration. The interface includes a title bar, menu bar, toolbar, navigation window, work window, element selection window, docked windows (Cross Reference and Watch 1), and a status bar. The work window displays a ladder logic diagram for a counter circuit. The docked windows show a cross-reference table and a watch table.

**Labels and Components:**

- Title bar: MELSOFT Series GX Works2 ...op\OpemaniCommon-EV3.2 Screen Configuration.gxw - [[PRG]Write MAIN 319 Step]
- Menu bar: Project, Edit, Find/Replace, Compile, View, Online, Debug, Diagnostics, Tool, Window, Help
- Toolbar: Standard Windows toolbar with icons for file operations and execution.
- Navigation window: Project tree showing folders like Global Label, Program Setting, POU, Program, MAIN, SUB1, FB\_Pool, Structured Data Type, Local Device Comment, Device Memory, MAIN, Device Initial Value, Project, User Library, and Connection Destination.
- Work window: Ladder logic diagram showing a counter circuit with components like X0, Y4, M10, DTOP, and counter instructions.
- Element Selection window: Selection pane showing Function Block, CARRY1, CARRY2, and INITIAL.
- Docked window: Cross Reference table and Watch 1 table.
- Status bar: Language (English), Mode (Simple), and Host Station (Q25H).

1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES

## Display contents

Name	Description	Reference
Title bar	Display a project name.	–
Menu bar	Display menu options for executing each function.	–
Toolbar	Display tool buttons for executing each function.	Section 3.2.2
Work window	A main screen used for operations such as programming, parameter setting, and monitoring	Section 3.2.3
Docking window	A sub screen to support operations performed on a work window	Section 3.2.4
Navigation	Display contents of a project in tree format.	Section 3.2.5
Element Selection	Display a list of functions (such as function blocks) used for programming.	GX Works2 Version 1 Operating Manual (Simple Project, Function Block) (Structured Project)
Output	Display compilation and check results (errors and warnings).	GX Works2 Version 1 Operating Manual (Simple Project) (Structured Project)
Cross Reference	Display cross reference results.	Section 10.1
Device List	Display the device list.	Section 10.2
Device Reference	Display assignments of refresh devices and link devices specified for the parameters of CC-Link IE Field Network and CC-Link.	Section 6.3.4
	Display assignments of refresh devices and I/O devices specified for the AnyWireASLINK parameter.	GX Works2 Version 1 Operating Manual (Intelligent Function Module)
Watch 1 to 4	A screen used for monitoring and changing current device values.	Section 17.6
Intelligent Function Module Monitor 1 to 10	Screens used for monitoring intelligent function modules.	GX Works2 Version 1 Operating Manual (Intelligent Function Module)
Find/Replace	A screen used for searching and replacing character strings in the project.	Section 10.3
Debug	A screen used for setting the debug which uses the simulation function.	Section 19.6.2 Section 19.6.3 Section 19.6.4
Status bar	Display information about a project being edited.	Section 3.2.6

### Point

● **When the focus point is not indicated on the screen**

To display the focus point, set the Windows Control Panel settings.  
(Example)

- 1) Open "Ease of Access Center" from Windows® Control Panel.
- 2) Select "Make the keyboard easier to use".
- 3) Select "Underline keyboard shortcuts and access keys".



## 3.2.2 Toolbars

A toolbar is a block of on-screen buttons for executing frequently-used functions included in a menu. (☞ Appendix 1)  
The toolbars to be displayed and their display positions on the screen can be set by the user.



### ■ Displaying/hiding toolbars

Select a toolbar to be displayed.

#### Operating procedure

- Select [View] ⇒ [Toolbar] ⇒ [(toolbar name)].

The selected toolbar is displayed on the screen.



#### ■ Docking/floating toolbars



Switch the display format (docked/floating) of a toolbar.

#### ● Floating a toolbar

Display a toolbar floating from the main frame.

#### Operation



- Drag a docked toolbar to the desired position for floating display.



- **Docking a toolbar**  
Display a toolbar docked to the main frame.

**Operation**

- **Drag the title bar of a floating toolbar and drop it in the main frame.**



**Point**

- **Method for docking a toolbar at the original position**  
To dock a floating toolbar back at the original position, double-click on the title bar of the toolbar.

1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES

#### ■ Displaying/hiding all toolbars

Display/hide all toolbars that are set to be displayed.

The display setting of toolbar can be saved by performing the following operation.

#### Operating procedure


- **Select [View] ⇒ [Toolbar] ⇒ [Display All].**

The standard toolbars and all other toolbars are displayed.\*1

The changes of toolbar positions and the display setting of displaying/hiding toolbars are maintained.

\*1: Inactive toolbars are included. Toolbars of inapplicable functions are grayed out.

<When the [Display All] function is enabled>



When the [Display All] function is disabled while all toolbars are displayed, only the active toolbars are displayed.

<When the [Display All] function is disabled>




## ■ Customizing toolbars

Set the types of tool buttons to be displayed on each toolbar.

### Operating procedure


#### 1. Select the Toolbar options button ( ) ⇒ [Add or Remove Buttons].

A list of tool buttons is displayed.



#### 2. Select the check box in front of the tool button to be displayed on the screen.

The selected tool buttons are displayed on the screen.



The toolbar configuration returns to the default when [Reset Toolbar] is selected.

### Restrictions

#### ● Restrictions when customizing toolbars

The type of tool buttons for the following toolbars cannot be set.

- Monitor status
- Debug function
- Sampling trace


## ■ Displaying editing screens with the toolbar

---

For Simple projects only, editing screens can be displayed with the toolbar.

### Screen display

Select [View] ⇒ [Toolbar] ⇒ [Docking Window/Switch Project Data].



### Operating procedure


1. Select a data type to be displayed.

2. Select a data name to be displayed.

The editing screen of the selected data name is displayed.

### Point

#### ● Display icon ( )


The editing screen of the selected data type and data name can be displayed by clicking .

---



### 3.2.3 Work windows

A work window is a main screen used for operations such as programming, parameter setting, and monitoring in GX Works2.

#### Screen display



#### Display contents

Item	Description
Tab	<p>Become active when selected.                      The tab order can be changed by dragging and dropping tabs.                      The window(s) can be closed from the menu displayed by right-clicking the tab. In the other way, the active window can be closed by clicking  on the tab.</p> 
Tooltip	Display a brief explanation when the cursor is placed on the selected tab.
Scroll button	Scroll the tab display to the left and right. Display hidden tabs.
Switching button	Display the list of windows being displayed. Select a data name displayed on the list to display its corresponding window on the top.
Display windows	Display screens such as the program editor, label setting editor, and monitoring screen.

1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES



#### ■ Maximizing/minimizing screens

Maximize/minimize the screen size on the work window.

##### ● Maximizing the screen

###### Operation

- Click the Maximize button (  ).








● Minimizing the screen


**Operation**

- Click the Minimize button ( - ).



**Point**

● Restoring the screen size

Click  to return the maximized/minimized screen to its previous size.



1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES


#### ■ Arranging screens

Arrange screens to display on the work window.

##### ● Cascading screens

###### Operation


- Select [Window] ⇒ [Cascade].



##### ● Tiling screens vertically

###### Operation


- Select [Window] ⇒ [Tile Vertically].



● Tiling screens horizontally

**Operation**


- Select [Window] ⇒ [Tile Horizontally].



● Arranging icons (minimized windows) at the bottom of the work window

**Operation**

- Select [Window] ⇒ [Arrange Icons].



1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES


## ■ Arranging/displaying windows

---

Display a list of open windows, and also open and arrange specified windows.  
This function is useful to display the desired window efficiently when multiple windows are open.

### Screen display

Select [Window] ⇒ [Other Window].



## 3.2.4 Docking windows

This section explains the operations common to dock windows.

### ■ Displaying/Hiding dockable windows

Display/show a dockable window.

#### Operating procedure

- Select [View] ⇒ [Docking Window] ⇒ [(target item)].

### ■ Docking/floating dockable windows

Switch the display format of a dockable window.

#### ● Docked display


Display a dockable window docked to the main frame.

#### ● Floating display


Display a dockable window floating from the main frame.

#### Operation

- Drag the title bar of a floating dockable window and drop it to the guidance in the main frame.



Drag a dockable window to the guidance.




A new tab appears after the window is docked.

The docked window is floated by dragging the title bar to the desired position.

#### Point


#### ● Operation of dockable windows

Docked windows can be switched from docked to floating or vice versa by double-clicking the title bar.



#### ● Changing the tab order

The tab order can be changed by dragging and dropping the desired tab to the left or right when multiple dockable windows are docked.




## Window minimized mode

Minimize a docked window as a tab.

The window minimized mode can be set and disabled by the following procedure.

### Operating procedure

- Click the window minimized mode switching icon (  /  ).



## Resetting positions of dockable windows


Return the display positions of the dockable windows to their default.

The status of display/hide and window minimize mode, and the display size can also be returned.

### Operating procedure

- Select [View] ⇒ [Docking Window] ⇒ [Reset the Window Position to its Default].

The following message is displayed. Click the  button to perform the function.




### 3.2.5 Navigation window

This section explains the Navigation window that displays the contents of a project in tree format. Operations such as creating new data and displaying editing screens can be performed on the Navigation window.

(☞ Chapter 4)

#### Screen display

Select [View] ⇒ [Docking Window] ⇒ [Navigation].




#### Display contents

Name	Description	Reference
Title bar	Display a title of a view being displayed.	-
Toolbar	Display tool buttons of functions to be executed on each view.	Appendix 1
View selection area	Area for selecting a view to display.	-
Project	Display the Project view.	Section 4.2.1
User Library	Display the User Library view.	GX Works2 Version 1 Operating Manual (Structured Project)
Connection Destination	Display the Connection Destination view.	Section 14.1.1

#### Point

● **Color of characters on title bar when uncompiled data exist**

The compilation is not completed if the color of the characters on the title bar are red.





## ■ Sorting data

Sort data displayed in tree format.

### Operating procedure

1. Open a folder on the Navigation window and select the data for sorting.
2. Right-click and select [Sort] ⇒ [(sort type)] from the shortcut menu.

The data displayed in tree format are sorted in the ascending order.

When the same operation is performed after sort execution, the sort order is switched between ascending and descending.

The following table shows the sort types.

Type	Description
Execution Order*1	Sort data in the selected folder according to the execution order. When a program file is selected, tasks in the program file are sorted according to the execution order. When a task is selected, programs in the task are sorted according to the execution order.
Name	Sort the data in the selected folder according to the name.
Date	Sort the data in the selected folder according to the date modified.
Language*2	Sort the data in the selected folder according to the programming language type.
POU Type*3	Sort the data in the selected folder according to the POU type.

\*1 : SFC programs of Simple project, and program files and tasks of Structured project only

\*2 : Tasks, programs, and FB/FUN of Structured project only


\*3 : FB/FUN of Structured project only

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES


## ■ Expanding all uncompiled data

Expand all uncompiled data exist on the Project view and User Library view.

### Operating procedure

1. Click  on the toolbar.
2. Select [Expand All Uncompiled Data].


All uncompiled data are expanded and become selectable status.




## ■ Collapsing tree

Collapse tree on the Project view and User Library view.

### Operating procedure

1. Click  on the toolbar.
2. Select [Collapse All].

The tree is collapsed.



### 3.2.6 Status bar

The status bar displays information about the current project at the bottom of the screen.

Connection Time:00:01:38		English		Simple		MITSUBISHI TARO		Q06UDH		Host Station		(1/20Step)		Ovrwrite		CAP		NUM	
Connection time	Project language	Project type	Security information	Programmable controller type	Connection destination	Cursor position	Insert/Overwrite	Caps Lock	Num Lock										

The following shows the information to be displayed.

Item	Description
Connection time	Display the connection duration of the phone line.
Project language	Display the language set for the language selection.
Project type	Display the project type. <ul style="list-style-type: none"> <li>• Unlabeled : Simple project (without labels)</li> <li>• Simple : Simple project (with labels)</li> <li>• Structured : Structured project</li> </ul>
Security information	Display the login user name when security is set for the project.
Programmable controller type	Display the programmable controller type of the project.
Connection destination	Display the set content of the <u>Transfer Setup</u> screen. For Redundant CPU, the set content is displayed as shown below. <div style="border: 1px solid gray; padding: 5px; margin: 5px 0;"> <span style="border: 1px solid gray; padding: 2px;">Q25PRH</span>     <span style="border: 1px solid gray; padding: 2px;">Host Station Not Specified</span> </div>
Cursor position	Display the cursor position in the editing screen.
Insert/Overwrite	Display the current mode (insert or overwrite).
Caps Lock	Display the effective status of the Caps Lock.
Num Lock	Display the effective status of the Num Lock.


#### ■ Displaying/hiding status bar

Display/hide the status bar.

#### Operating procedure

- Select [View] ⇒ [Statusbar].

A check mark is appended in front of the menu option and the status bar is displayed on the screen.




1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES

### 3.2.7 Changing colors and fonts

Change the color and font settings on program editors and label editors.


#### Screen display

Select [View] ⇒ [Color and Font].



#### Operating procedure

1. Set the items on the screen.

Item	Description
Target	Select the change target work window.
Font Setting	Change font settings.
Auto (Based on system settings)	Select this to use the font settings in Windows®.
User settings	Select this to customize the font settings. Click the  button to select the desired font.
Color Setting	–
Color Setting Items	Select the change target item and color.

2. Click the  button.


## Screen button

● **Change...**

Displays the Font screen.

The font type, style, and size can be customized.



Some font styles and sizes, however, cannot be set depending on target work windows.



● **Custom...**

Displays the Color screen.


The color can be customized. The created color is added as "Custom" in the color selection field of the Color and Font screen. Only one color can be added as "Custom".



● **Import...**

Displays the Import Color and Font setting file screen.

Select "Color and Font setting file (\*.gcs)" and click the **Open** button to read the file.



1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY


8 SETTING DEVICE INITIAL VALUES

● **Export...**

Displays the Export Color and Font setting file screen.

Set a save destination and a file name for the color and font setting file (\*.gcs).

The content displayed on the Color and Font screen is saved on the file by clicking the **Save** button.



● **Back to Default**

Resets the color and font settings to default.

● **Apply**

Applies the changed color and font settings.

**Point**

● **Font setting**

Some fonts may be displayed as garbled characters.  
Change the setting to another font if this happens.


## 3.2.8 Customizing shortcut keys

Customize a shortcut key of each function.

Customized shortcut keys can be registered as a template and utilized.

### Screen display

Select [Tool] ⇒ [Key Customize].



### Setting shortcut keys

This function creates/changes/deletes a shortcut key.

### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Shortcut Key	–
Category	Select a category from the group list categorized by window.
Command	Select a function name whose shortcut key to be changed.
Current Key	Display the shortcut key assigned to the selected command.
Press the keys to assign	Specify a new shortcut key to be assigned. Input it by pressing a key(s) on the keyboard. Example)  +
Current Assignment	Display the menu name to which the entered shortcut key is assigned. When the key is already assigned to another function, the function name is displayed.

2. Click the  button.

The shortcut key is assigned.

The assigned shortcut key is displayed in "Current Key".


3. Click the  button.

The shortcut key is created/changed.

### Screen button

● 

Deletes the shortcut key selected in "Current Key".

● 

Displays the Enter Template Name screen.

Register the assigned shortcut keys as a template with a desired name.

The registered template is displayed in "Template".





### Point



● **Assigning shortcut keys**

Up to three shortcut keys can be assigned to one function. The shortcut key displayed on the top in "Current Key" is displayed on the menu.

● **Templates**

The maximum file name length for a template is 24 characters.

● **Shortcut key ( + ) for changing current value**

To prevent from pressing the  +  keys by mistake, changing the current value using the shortcut key can be invalid on the Option screen.

Select "Disable Current Value Changing by Pressing Shift+Enter" in [Tool] ⇒ [Option] ⇒ "Monitor" ⇒ "Common".




## ■ Registering templates

This function registers/deletes a template of shortcut keys.

### Operating procedure




#### 1. Set the item on the screen.

Item	Description
Template	Select a template of shortcut keys from  . <ul style="list-style-type: none"> <li>• Default Setting Change to the default setting.</li> <li>• GPPA Format Setting Batch change the shortcut key setting of ladder programming to the same setting of GPPA.</li> <li>• GPPW Format Setting Batch change the shortcut key setting of ladder programming and SFC programming to the same setting of GX Developer.</li> <li>• Setting of MEDOC Format Batch change the shortcut key setting of ladder programming to the same setting of MELSEC MEDOC.</li> </ul>

#### 2. Click the button.

The selected template of shortcut keys is applied.

### Screen button

-  Deletes a template selected in "Template".
-  Imports a pre-saved template file (\*.gks) and adds it to "Template".
-  Saves a template selected in "Template" as a template file (\*.gks).

### Restrictions

#### ● Templates with "MEDOC Format Setting"

Any of the following symptoms occurs when the template with "MEDOC Format Setting" is imported to GX Works2 Version 1.95Z or earlier.

- Shortcut keys of the tool buttons on the "Ladder" toolbar are hidden.
- When the numeric key is pressed on the Find screen displayed by the simple search function, the display on the element selection field is changed.
- An operation according to the set shortcut keys is performed when a number is entered on the ladder editor, the Enter VLine screen, the Enter HLine screen, the Delete VLine screen, or the Delete HLine screen.

## 3.3 Selecting Language

Q CPU L CPU Remote Head FX

This section explains how to select a language used for project data (such as device comments, statements, and notes).

By selecting a language of the project, data can be created in a language other than English.


Data created in another language can be displayed without character corruption.

For restrictions when selecting a project language, refer to Appendix 18.


### Screen display

Select [Tool] ⇒ [Language Selection].

< Before creating a new project >



< When editing a project >



### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Project Language	Select the language of the project.
Save the project (Overwrite save)	Select this to save the project before changing the project language.

#### 2. Click the button.

The project data are displayed in the selected project language.

**Point** 

- **Considerations when project language change is canceled**

If characters other than alphanumeric characters are used for data names and label names, the project language change may be canceled. In such case, change data names or label names according to the error message displayed on the Output window. In some cases, even after the project language is changed, characters other than the characters of the selected language may be used. Change the characters other than those of the selected language.

For data names which causes the cancellation of project language change when characters other than alphanumeric characters are used, refer to Appendix 17.1.

- **Considerations when changing project language**

The project language change function does not change the characters on setting menus and screens.

To display characters on setting menus and screens in another language, use the specific version of GX Works2 that supports the language.

1

OVERVIEW

2

SYSTEM  
CONFIGURATION

3

SCREEN  
CONFIGURATION AND  
BASIC OPERATIONS

4

PROJECT  
MANAGEMENT

5

EDITING  
PROGRAMS

6

SETTING  
PARAMETERS

7

SETTING DEVICE  
MEMORY

8

SETTING DEVICE  
INITIAL VALUES

## 3.4 Help Function

Q CPU L CPU Remote Head FX

This section explains the help function of GX Works2.

### 3.4.1 Displaying GX Works2 help

Use the GX Works2 help function to learn GX Works2 operations, understand functions, and check error codes of programmable controller CPU.

The following items can be checked with the GX Works2 help function.


- Help for operations
- Help for instructions
- Help for special relays/special registers
- Help for CPU errors
- Error codes for CPU module communication
- Changes from GX Developer
- List of shortcut keys
- Registered Trademarks and Trademarks
- FX manuals\*1

\*1 : For FXCPU, GX Works2 Help (for FXCPU) and Adobe® Reader® version 8 or later are required to view the help. For installing GX Works2 Help (for FXCPU), refer to the following section.

📄 ■ Installing GX Works2 help for FXCPU

#### Screen display

Select [Help] ⇒ [GX Works2 Help] (🔍).



### Point

#### ● Displaying GX Works2 help

Enter a keyword in the keyword entry field on the standard toolbar of GX Works2, and press the **[Enter]** key to display the help items searched by the keyword.




Keyword entry field

The help items can also be displayed by the screen title by pressing the **[F1]** key with the selected screen such as Navigation window, program editor, and Element Selection window of GX Works2. (Some screens do not support the **[F1]** key function.)


For FXCPU, when a special relay (M) or a special register (D) is searched, the head of the section which describes the special relay (M) or the special register (D) in the programming manual (PDF file) is displayed.

#### ● Instruction help

- Instructions which are supported by the instruction help function are: common instructions and application functions for QCPU (Q mode)/LCPUCPU, and sequence instructions and application functions for FXCPU.
- The SFC editor is not supported by the instruction help function.
- Operators and ST control syntax are not supported by the instruction help function.
- When the selected instruction is corresponded by multiple items, the Result screen (for QCPU (Q mode)/LCPUCPU) or the Help Reference screen (for FXCPU) is displayed. Double-click the item to display the help.




- When the selected instruction contains a special relay or special register, the Help References screen is displayed. Select a keyword displayed and click the **Open** button.



#### ● Error codes when communicating with CPU module

When an error whose error code is in the range between 4000H and 4C09H occurs while communicating with the CPU module, the following pop-up screen is displayed on the right-bottom corner of the screen.

The pop-up help function is not supported by FXCPU.



### Point

#### ● Operation of the help function for FXCPU

- The "Add to Favorites" function on the Navigation window of GX Works2 help, and the "Keyword", "Search", "Favorites", and "History" functions under [View] ⇒ [Navigation] are not supported by the help function for FXCPU. For the search function, display the programming manual (PDF) and use the search function of Adobe® Reader®.
- If another PDF reader other than Adobe® Reader® is installed, the content of the help function may not be displayed. In this case, reinstall Adobe® Reader®.
- Use the Adobe® Reader® version supported by operating system and Internet Explorer®.
- When an Adobe® Reader® error occurs while using the help function, the error may be solved by restarting a personal computer.

#### ■ Installing GX Works2 help for FXCPU

To install GX Works2 Help (for FXCPU), double-click "setup.exe" in the "Disk2\DocFX" folder on the DVD. \*1


\*1 : For GX Works2 Version 1.86Q or later and Version 1.568S or earlier, double-click "setup.exe" in the "DocFX" folder on the CD (Disc 2).

## ■ Setting options for GX Works2 help function

Set options for "Startup", "Window", and "Tab" items of the GX Works2 help function.

### Screen display

Select the GX Works2 help menu [Operation] ⇒ [Options].



### Operating procedure

- Set the items on the screen.

Item	Description
Startup	–
Restore the previous status at the start of Help	Select this to activate the GX Works2 help function with the state of previous operation.
Window	–
Add help icon to the System Tray when window is minimized	Select this to set the GX Works2 help function in the task tray when the GX Works2 help window is minimized. When this item is selected and the GX Works2 help window is minimized, the GX Works2 help function can be activated from the task tray.
Set maximum number of window	Select this to set a maximum number of windows to be displayed with the GX Works2 help function. Enter a maximum number of windows.
Tab	–
Switch tab by rolling mouse wheel on tab	Select this to switch tabs with the mouse wheel when the cursor is on the tab.*1
Specify tab size	Select this to specify the tab size. Enter a width and a height of the tab.

\*1 : When the tab of FX manual is displayed in front, the tabs cannot be switched with the mouse wheel. Select a tab other than that of FX manual to switch tabs.

## 3.4.2 Displaying operating manuals

Display the operating manuals of GX Works2 Version 1.

### Screen display

Select [Help] ⇒ [Operating Manual] ⇒ [(manual name)].

### 3.4.3 Connecting to MITSUBISHI ELECTRIC FA Global Website

---

Open the MITSUBISHI ELECTRIC FA Global Website in a web browser.  
Make sure your personal computer connect to the Internet in advance.

#### Operating procedure

- Select [Help] ⇒ [Connection to MITSUBISHI ELECTRIC FA Global Website].


### 3.4.4 Checking version of GX Works2

---

Display information such as the software version of GX Works2.

#### Operating procedure

- Select [Help] ⇒ [About].





---

# 4 PROJECT MANAGEMENT

This chapter explains basic operations and management of projects.

4.1	GX Works2 Project Management	4 - 2
4.2	Project Operations	4 - 9
4.3	Operations of Programmable Controller CPU Data	4 - 34
4.4	Operations of Intelligent Function Module Data	4 - 45
4.5	Changing Project Types	4 - 46
4.6	Managing Project Revisions	4 - 47
4.7	Utilizing Projects and Data in Other Formats	4 - 53
4.8	Saving Projects in Other Formats	4 - 60
4.9	Starting GX Developer from GX Works2	4 - 61
4.10	Setting Security for Projects	4 - 62
4.11	Setting Security Key	4 - 72
4.12	Protecting POUs in Projects	4 - 81
4.13	Managing Profiles	4 - 89

1

OVERVIEW

2

SYSTEM  
CONFIGURATION

3

SCREEN  
CONFIGURATION AND  
BASIC OPERATIONS

4

PROJECT  
MANAGEMENT

5

EDITING  
PROGRAMS

6

SETTING  
PARAMETERS

7

SETTING DEVICE  
MEMORY

8

SETTING DEVICE  
INITIAL VALUES

## 4.1 GX Works2 Project Management

Q CPU L CPU Remote Head FX

This section explains the management of GX Works2 projects.

In GX Works2, created projects are saved in the workspace format or the single file format.


### 4.1.1 Workspace format

A workspace manages multiple projects at once.

When configuring a system containing multiple programmable controller CPUs, a project needs to be created for each programmable controller CPU. However, projects in the same system can be managed by saving projects created in a single workspace in the workspace format.


When using MELSOFT Navigator, save projects in the workspace format.

< System configuration example >




Batch-manage projects in the workspace format

< GX Works2 project management >



## ■ Configuration of workspace and project

The following explains the configuration of GX Works2 workspace and project.



Do not change or delete workspace configuration or project using an application such as Windows® Explorer.

If a data name is changed or deleted using an application such as Windows® Explorer and projects without containing actual data may remain in a project list of the function such as opening a project. Those faulty projects can be deleted from the project list by selecting [Project] ⇒ [Delete].

For copying GX Works2 project on Windows® Explorer, select either following operation to copy the project without breaking the configuration of workspace and project.

- Copy the entire save destination folder (① above).
- Copy the workspace name folder and "workspacelist.xml".

When "workspacelist.xml" (④ above) or "projectlist.xml" (⑤ above) does not exist in the folder by performing the copy operation other than above, the copied workspaces/projects are not displayed in "Workspace/Project List" on the Open screen.

However, note that the project can be opened forcibly by selecting "All Folders" for "Display" on the Open screen and displaying all folders.

When a file other than "workspacelist.xml" or "projectlist.xml" is missing, the project may not be opened.

### Restrictions

#### ● Opening a project forcibly by selecting "All Folders"

The following operations cannot be performed.


- Register, Restore, and Verify functions of project revision history
- Security user management
- Automatic project save

However, the above restrictions are invalidated by selecting [Project] ⇒ [Save As], and saving the project.

## 4.1.2 Single file format

---

The single file format is a format to handle project files as a single file (\*.gxw). Projects are managed without being aware of the folder configuration and the file configuration by saving projects in the single file format. Operations such as changing project names, copying and pasting projects, and sending and receiving data, can easily be performed on Explorer.



### *Point*

- **When using MELSOFT Navigator**

Projects saved in the single file format cannot be used in MELSOFT Navigator.  
Save projects in the workspace format.


---

### 4.1.3 Project

Project contents displayed on the Project view in tree format are as shown below. Contents displayed on the view differs according to the types of programmable controller and project. For (Simple), (Structured), and (Intelligent) indicated in the reference destinations, refer to the following manuals respectively:

- (Simple) ... GX Works2 Version 1 Operating Manual (Simple Project)
- (Structured) ... GX Works2 Version 1 Operating Manual (Structured Project)
- (Intelligent) ... GX Works2 Version 1 Operating Manual (Intelligent Function Module)

The following are examples for QCPU (Q mode).



- \*1 : For FXCPU, "Special Module (Intelligent Function Module)" is displayed.
- \*2 : For FXCPU, execution types are not categorized. The only one category 'Execution Program' is displayed.
- \*3 : For FXCPU, this item is not displayed.
- \*4 : Chapter 6
- \*5 : Chapter 9
- \*6 : Section 6.1.1
- \*7 : For FXCPU, either of one ladder or one SFC can be created because FXCPU has only one execution program.
- \*8 : Chapter 7
- \*9 : Chapter 8

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS


4 PROJECT MANAGEMENT

5 EDITING PROGRAMS


6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES



- \*1 : For FXCPU, "Special Module (Intelligent Function Module)" is displayed.
- \*2 : For FXCPU, execution types are not categorized. The only one category 'Execution Program' is displayed.
- \*3 : For FXCPU, Simple project (with labels), the 'Execution Program' can be divided into multiple programs.
- \*4 : For FXCPU, this item is not displayed.
- \*5 : Chapter 6
- \*6 : Chapter 9
- \*7 : Section 6.1.1
- \*8 : For FXCPU, program can be created only by Ladder Diagram.
- \*9 : Chapter 7
- \*10 : Chapter 8



- \*1 : For FXCPU, "Special Module (Intelligent Function Module)" is displayed.
- \*2 : For FXCPU, execution types are not categorized. The only one category 'Execution Program' is displayed.
- \*3 : For FXCPU, this item is not displayed.
- \*4 : Chapter 6
- \*5 : Chapter 9
- \*6 : Section 6.1.1
- \*7 : Chapter 7
- \*8 : Chapter 8

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES


**Point**

● **Program Setting**

On the Project view, an execution type of a program can be set by right-clicking the name of the program whose execution type is to be changed and selecting [Register Program] ⇒ [Initial]/[Scan]/[Standby]/[Fixed Scan]/[Low Speed] from the shortcut menu, or dragging and dropping it. The execution type set on the Project view is applied to the program setting of the PLC parameter.

(Program setting in PLC parameter → Section 6.1.1)

Example) Set the execution type of MAIN to 'Scan Program' with the drag-and-drop operation.





## 4.2 Project Operations

This section explains basic operations of GX Works2 such as creating, opening, and saving projects.

### 4.2.1 Creating projects

Q CPU L CPU Remote Head FX

Configure the settings to create a new project.

#### Screen display

Select [Project] ⇒ [New] (📄).

#### Operating procedure

- Set the items on the screen.

Item	Description
Series	Select the programmable controller series for the project.
Type	Select the programmable controller type (programmable controller CPU model) used for the project. When a programmable controller type which is not supported by GX Works2 but is supported by GX Developer is selected, start GX Developer and create a new project. For a procedure to use unsupported programmable controller type, refer to Appendix 14.
Project Type	Select the type of the project to be created. Select "Simple Project" or "Structured Project".
Use Label	Select this to create a project using labels when "Simple Project" is selected.
Language	Select the language for the program data to be created when creating a new project.

**Point**
**● Settings for when a new project cannot be created**

Set the access authority for a login user to the following folders to which the access authority has not been set.

- The folder to which GX Works2 is installed.  
Example) C:\Program Files\MELSOFT
- C:\Users\(\login user name)\AppData\Local\MITSUBISHI\SWnDN-GPPW2
- The TEMP folder set by environment variable.  
Example) C:\Users\(\login user name)\AppData\Local\Temp  
C:\Documents and Settings\(\login user name)\Local Settings\Temp

If the access authority cannot be changed, right-click the GX Works2 program and select [Run as administrator]. To activate the program from the shortcut menu, open the property of the shortcut menu and select "Run this program as an administrator" under "Privilege Level" on the <<Compatibility>> tab.

**● Changing data such as workspace name after creating a new project**

Do not change the storage location and names of folders/files of a created workspace/project using an application such as Windows® Explorer.

For details of workspace/project configuration, refer to Section 4.1.1.

**● Common pointer number setting for projects with labels**

When a project with labels is created, the last half of the device range of pointer (P) is set for "Common Pointer No." on the <<PLC System>> tab of PLC parameter. This range is set as a pointer range for the "Device/Label Automatic-Assign Setting" function.

For details of the "Device/Label Automatic-Assign Setting" function, refer to the following manuals.

☞ GX Works2 Version 1 Operating Manual (Simple Project)

☞ GX Works2 Version 1 Operating Manual (Structured Project)

**● Connection destination**


When creating a new project, the connection destination is set to the route set for "Current Connection" in the previously-edited project. Review the connection destination setting to change the previously-edited project and the connection destination.

When creating a new project after installing GX Works2 for the first time, the setting is set to access the programmable controller CPU directly.

**● Creating a new SFC project with FXCPU**

When 'SFC' is selected in "Language" with FXCPU, the Block Information Setting screen is displayed.

When an SFC project is created with FXCPU, a ladder program needs to be created using ladder blocks to start up an initial step of the SFC program. Select "Ladder Block" in "Block Type", and create a startup ladder program using ladder blocks.




## ■ Creating new projects with data read from programmable controller CPU or intelligent function module (New project creation with data read from programmable controller CPU)

A new project can be created with data read from a programmable controller CPU or an intelligent function module when the Read from PLC function is executed without creating a new project. When a programmable controller type which is not supported by GX Works2 but is supported by GX Developer is selected, start GX Developer and create a new project. For a procedure to use unsupported programmable controller types, refer to Appendix 14.

### Operating procedure

#### 1. Start GX Works2 and select [Online] ⇒ [Read from PLC].

The PLC Series Selection screen is displayed.



#### 2. Set the item on the screen.

Item	Description
PLC Series	Select the programmable controller series from which data are read.

#### 3. Click the button.

The Transfer Setup screen is displayed.

#### 4. Set a communication route to access to the programmable controller CPU.

For the method for setting a connection destination, refer to Chapter 14.

The Online Data Operation screen is displayed when the setting of connection destination is completed.

#### 5. Execute the Read from PLC function on the Online Data Operation screen.

For the method for executing the Read from PLC function on the Online Data Operation screen, refer to Section 15.1.

### Point

#### ● Considerations when creating a new project with data read from programmable controller CPU

When parameters are not read from the programmable controller CPU with data to create a new project, default parameters are set.

Check the parameter setting.

#### ● Creating a new project with data read from intelligent function module

For the function to create a new project with data read from programmable controller CPU, when an intelligent function module is mounted on the same base unit as the connected programmable controller CPU, the project data are created according to the mounted module configuration. Thus, the data of intelligent function modules whose parameters are not written to the programmable controller CPU are also created.

This function is not supported by FXCPU.

#### ● Creating a new project with data read from Redundant CPU

Data cannot be read from a Redundant CPU by specifying a system, such as "Control System", "Standby System", "System A", or "System B" for "Target System" of redundant operation.

When reading data from the Redundant CPU by specifying the system, read data after creating a project.

## 4.2.2 Opening existing projects


Q CPU L CPU Remote Head FX

Read a project saved on a hard disk of personal computer.


### Screen display

Select [Project] ⇒ [Open] ( ).

< Opening a project in the workspace format >



< Opening a project in the single file format >



### Operating procedure

#### 1. Set the items on the screen.




Item	Description
Workspace Location	Enter the folder (drive/path) where the workspace is saved. The folder can be selected on the <u>Browse For Folder</u> screen by clicking the <b>Browse...</b> button.
Workspace/Project List	Select the workspace or project. The display is switched to the project list by double-clicking "Workspace".
Display	Select this to display folders for GX Works2 projects only, folders for GX Developer projects only, or all folders. By selecting "All Folders" also displays workspace folders and project folders copied/moved by the application such as Windows® Explorer.
Workspace Name	Display the selected workspace name.
Project Name	Display the selected project name.
Title	Display the title of the selected project.

#### 2. Click the **Open** button.

The specified project is displayed.

When the GX Developer project is specified, GX Developer starts automatically and the project is displayed.

## Screen button

-  **Browse...**  
Displays the Browse For Folder screen.
-  **Open a Single File Format Project...**  
Switches to the Open screen in the single file format.
-  **Open a Workspace Format Project...**  
Switches to the Open screen in the workspace format.

## Point

### ● Changing data such as workspace name


Do not change the storage location and names of folders/files of a created workspace/project using an application such as Windows® Explorer.

For details of workspace/project configuration, refer to Section 4.1.1.

### ● Opening Structured projects

When a Structured project is opened in later version of GX Works2 than the one used for saving the project, the Library Update Confirmation screen may be displayed.

To modify the project and update the new instructions and/or application functions, select the corresponding check box(es).



All programs need to be compiled when instructions or application functions are updated.

Compiling all programs changes the device assignment to labels.

Therefore, device values set before the program change remain on the device-assigned labels.

Perform the following operations for a precautionary measure.

- For QCPU (Q mode)/LCPU  
After writing data to the programmable controller CPU, reset the programmable controller CPU, clear all device memories including latches, clear all file registers, and switch the programmable controller CPU to RUN.
- For FXCPU  
After writing data to the programmable controller CPU, clear device memory using the PLC memory clear function, and switch the programmable controller CPU to RUN.  
(☞ Section 20.4)

For the considerations for compiling all programs, refer to the following manuals.

☞ GX Works2 Version 1 Operating Manual (Simple Project)/(Structured Project)

### ● Opening projects being edited by other users


The project being edited can be opened by other users as a read-only project. Note that the following functions cannot be used.

- Saving projects
- Project revision history
- Succeeding project revision when saving projects with a specific name
- Change PLC type function
- Security function

### ● Opening projects created in other languages

Characters in a project created in other languages may get garbled when it is opened.

### ● Open screen

- The Open screen with the initial setting opens a project in the single file format.  
Switch the screen by clicking the  button to open the existing project in the workspace format.
- A programmable controller type and a title are not displayed on the Open screen in the single file format.
- If the file save destination path is long, the "Look in" field may be left blank when opening a project in the single file format. Even with the blank field, the selected folder/file can be opened normally.

### ● Projects saved on the network drive or the removal storage device

Do not open the project directly. Open it after saving it to the hard disk of the personal computer.

1

OVERVIEW

2

SYSTEM CONFIGURATION

3

SCREEN CONFIGURATION AND BASIC OPERATIONS

4

PROJECT MANAGEMENT

5

EDITING PROGRAMS

6

SETTING PARAMETERS

7

SETTING DEVICE MEMORY

8

SETTING DEVICE INITIAL VALUES

### 4.2.3 Saving projects

Q CPU L CPU Remote Head FX

Save a project on a personal computer or another data storage device.  
 When saving a project, an iQ AppPortal information file can be output by setting the Project Property.  
 (☞ Section 4.3.6)


#### ■ Saving projects under the specified name

Save the open project under the specified name.


#### Screen display

Select [Project] ⇒ [Save As].

< Saving a project in the workspace format >




< Saving a project in the single file format >



#### Operating procedure

##### 1. Set the items on the screen.

Item	Description
Save Location	Enter the folder (drive/path) where the workspace is saved. The folder can be selected in the <u>Browse For Folder</u> screen by clicking the  button.
Workspace/Project List	Select the workspace or project. The display is switched to the project list by double-clicking "Workspace".
Workspace Name	Enter the workspace name.
Project Name	Enter the project name.
Title	Enter the title of the project.
Include revisions*1	Select this to succeed and save the project revision information. (☞ Section 4.6)
Include security*1	Select this to succeed and save the security information of the project. (☞ Section 4.10)

\*1 : This setting can be set only when saving the already existing project with another name.

##### 2. Click the button.

The project is saved in the specified folder under the specified workspace name, project name, and title.

## Screen button

- **Browse...**  
Displays the Browse For Folder screen.
- **Save as a Single File Format Project...**  
Switches to the Save As screen in the single file format.
- **Save as a Workspace Format Project...**  
Switches to the Save As screen in the workspace format.

## Point

- **When saved workspace exists**  
When the saved workspace or project exists, a folder to which the workspace is saved can be specified from "Workspace/Project List".
- **Number of characters used for workspace name, project name, and title**  
The total number of characters used for the path name of the folder to which the project is saved, workspace name, and project name should not exceed 200 characters.  
A title can be entered within 128 characters.
- **Saving a project contains Structured Ladder programs**  
If multiple Structured Ladder editors are opened, the project may not be able to be saved.  
In this case, start another GX Works2 and save the project by copying all data to the newly-created project.  
(☞ Section 4.3.2 "Copying/pasting data in projects")
- **Save As screen**
  - The Save As screen with the initial setting saves a project in the single file format.  
Switch the screen by clicking the **Save as a Workspace Format Project...** button to save the project in the workspace format.
  - If the file save destination path is long, the "Save in" field may be left blank when saving a project in the single file format. Even with the blank field, the selected folder/file can be saved normally.
- **Security check for a project (enhancement of countermeasures for vulnerabilities)**  
By saving a project with the following option setting enabled, it is possible to prevent the project from being opened when the data consistency is lost due to the corruption or falsification of the project.
  - Select [Tool] ⇒ [Options] ⇒ "Project" ⇒ "Common Setting", and select "Enable the security check for the project".  
A project in which the above option setting is enabled cannot be opened in GX Works2 Version 1.606G or earlier and PX Developer Version 1.55H or earlier.

## ■ Saving projects

Overwrite and save the project being edited.

## Operating procedure

- **Select [Project] ⇒ [Save] (💾)**  
The data to be saved is overwritten on the existing project data.

## Point

- **Registering project revision when overwriting**  
By setting the option, the Revision Entry screen for registering the project revision is displayed when overwriting the project.  
To display the Revision Entry screen when overwriting the project, select [Tool] ⇒ [Options] ⇒ "Project" and then select "Revision is Registered when Save Project" in "Change History". In addition, the revision title can be automatically set when overwriting by selecting "Automatically set revision titles".  
(For details of project revision history ☞ Section 4.6)
- **Compilation status is not saved by overwriting data**  
Performing compilation only and overwriting the project, and then opening the project again may cause the project to be in an uncompiled status.  
In this case, overwrite the uncompiled project without performing compilation to save the compilation status normally.

## 4.2.4 Saving projects with compression and decompressing projects

Q CPU L CPU Remote Head FX


Save projects with compression, and decompress projects saved with compression. Files can be saved with their sizes reduced by compressing the project. Files can also be saved by separating them in specific sizes. These functions produce easier project data passing. These functions are not compatible with commercially available file compression and decompression tools.

### ■ Saving projects with compression

Save a desired project with compression.




#### Screen display

Select [Project] ⇒ [Compress/Unpack] ⇒ [Compress].



#### Operating procedure

##### 1. Set the items on the screen.

Item	Description
<b>Choose a Workspace to Compress</b>	
Workspace Location	Enter the folder (drive/path) where the workspace is saved. The folder can be selected in the <u>Browse For Folder</u> screen by clicking the  button.
Workspace/Project List	Select the workspace and project.
Workspace Name	Display the selected workspace name.
Project Name	Display the selected project name.
<b>Choose a Destination Folder</b>	
Compressed File Name	Enter the folder where the compressed file is saved, and the compressed file name. The compressed file name can be specified in the <u>Compressed File Name</u> screen by clicking the  button.
Include revisions	Select this to succeed and save the project revision information. (  Section 4.6)
Split into volumes of the following size	Select this to save data in multiple compressed files. Specify the split size in the range from 1 to 999MB.



## 2. Click the **Compress** button.


The compressed project file (\*.gwz) is saved in the specified folder.

### ■ Decompressing projects saved with compression

Decompress a project saved with compression.

#### Screen display

Select [Project] ⇒ [Compress/Unpack] ⇒ [Unpack].



#### Operating procedure

### 1. Set the items on the screen.

Item	Description
Choose a File to Unpack	
Compressed File Name	Enter the folder (drive/path) in which the compressed file to be decompressed is saved, and the compressed file name. The compressed file name can be specified in the <u>Compressed File Name</u> screen by clicking the <b>Browse...</b> button.
Choose a Destination Folder	
Workspace Location	Enter the folder (drive/path) to which the project to be decompressed is saved. The folder can be selected in the <u>Browse For Folder</u> screen by clicking the <b>Browse...</b> button.
Workspace/Project List	Select the workspace and project.
Workspace Name	Enter the name of the workspace to which the decompressed project is saved.
Project Name	Enter the name of the project to which the decompressed project is saved.

## 2. Click the **Unpack** button.

The compressed project file is decompressed and saved in the specified folder.

#### Screen button

##### ● **Unpack and Open**

Decompresses a compressed project file and opens the project.

**Point**

● **Decompressing compressed files**

A compressed file can also be decompressed on the Unpack screen which is displayed by double-clicking the compressed file (\*.g wz) on Windows® Explorer.

● **Names of divided compressed files**

When a project is saved in divided compressed files, a number is automatically added after the extension in each name of the second or later compressed files as shown below.

ProjectAA.g wz	.....	Name of the first file
ProjectAA.g wz.002	.....	Name of the second file
ProjectAA.g wz.003	.....	Name of the third file
ProjectAA.g wz.004	.....	Name of the fourth file

● **Decompressing divided compressed files**

Select the first file (\*.g wz) when decompressing a series of divided compressed files. To be decompressed, all of a series of divided files must be in the same folder.

● **Projects saved with the security check enabled**

A project, in which the option of "Enable the security check for the project" under [Tool] ⇒ [Options] ⇒ "Project" ⇒ "Common Setting" is enabled, cannot be compressed.

## 4.2.5 Deleting projects

Q CPU L CPU Remote Head FX

Delete a project saved on a personal computer or another data storage device.

### Operating procedure


1. Select [Project] ⇒ [Delete].

The Delete Project screen is displayed.

2. Select the project to be deleted.

3. Click the **Delete** button.

The selected project is deleted.



### Point

● **Deleting projects**

- Once a project is deleted, it cannot be restored again.
- The open project cannot be deleted. Delete the project after closing it.
- Projects that can be deleted using this function are the projects saved in the workspace format only. Delete projects saved in the single file format using Windows® Explorer.

● **iQ AppPortal information file**

The iQ AppPortal information file (\*.iqap) is not deleted even when deleting a project. Delete it by using Windows® Explorer.

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES

## 4.2.6 Closing projects

Q CPU L CPU Remote Head FX

Close an open project.

### Operating procedure

- Select [Project] ⇒ [Close].

## 4.2.7 Verifying project data

Q CPU L CPU Remote Head FX

Verify data of an open project against data of another project.

Verification can be performed only when the programmable controller types and project types are the same. \*1

This function is used to compare the contents of two projects or to locate program changes made in projects.

To verify data against data on the programmable controller CPU, use the Verify with PLC function. (☞ Section 15.2)

The following data can be selected as verification targets for the project verification.


- Programs
- Parameters
- Intelligent function module parameters (initial setting/auto refresh)\*2
- Device comments
- Device memory data
- QD75/LD75 positioning module\*2

\*1 : For Q series, data can be verified when the type of two projects are the same.  
For L series, data can be verified when the type of two projects are the same.

\*2 : Not supported by FXCPU.

### Screen display

Select [Project] ⇒ [Verify].





## Operating procedure

1. Click the  button to set the verify destination project.

	Item	Description
Verify Destination Project	Workspace Location	Display the path to the workspace of the verify destination.
	Workspace Name	Display the workspace name of the verify destination. This field will be blank when a project in the single file format is specified for the verify destination project.
	Project Name	Display the project name of the verify destination.
	Title	Display the project title of the verify destination.

2. Set the items on the screen.

	Item	Description
<<File Selection>>	Verify Source	Display project data of verify source (data being edited). Selects the data in the project data list.
	Verify Destination	Display project data of verify destination (saved project data). Selects the data in the project data list.
<<SFC Block Selection>>*1,*2		Select SFC blocks in the SFC Block list. 
		Select the parameter verification level. 




\*1 : Simple projects only  
\*2 : Not supported by FXCPU.

3. Click the  button.

The verification result is displayed on the Verify Result screen.

 ■ Checking verification result details

## Screen button

-  Selects all the data displayed in the project data list.
-  Cancels the selection status of all the data selected in the project data list.
-  Updates the data displayed in the project data list.

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES

### Point

#### ● **Verifying programs**

The verification function verifies the data created by the compilation. If the program is edited after the compilation, compile the program again before performing the verification.

#### ● **Data names of verification target data**

When multiple data are selected for verification, verification is performed between the source and destination data with the same name. However, device comments are verified only when their data names are same.

When only one source program is verified against one destination program, verification can be performed even with different names.

#### ● **Security status of project**

Projects to which the security is set can be verified when both verify source data and verify destination data are not read-protected.

#### ● **Verifying projects between different programmable controller types**

When the number of steps are different between the projects that have the same instructions, the verification results do not match.

For counting the number of steps required for instructions, refer to the programming manual of each programmable controller CPU.

#### ● **Verifying intelligent function module parameters (initial setting/auto refresh)**

Among modules without initial setting such as QD75/LD75 positioning modules, serial communication/modem interface modules, and AS-i master modules, only modules in which the auto refresh is set are the verification targets.

#### ● **Verifying QD75/LD75 positioning modules**


One module each for verify source and verify destination can be selected.

The following data can be selected as verification targets.

- Parameter
- Servo parameter (For QD75M/MH only)
- Positioning data (Except for positioning comments and M code comments)
- Block start data

## ■ Verifying parameters

The verification level can be selected when verifying parameters.



The following table shows the verification details for each setting item.

Item	Description
User Setting Area Only	Verify only the parameter area set by the user.
All Area	Verify all the area including the parameter area set by the system.

### ● Mismatch in the system setting area

When a mismatch is detected in the parameter area set by the system in the verification set to "All Area", either of the following messages is displayed.

Take corrective action according to the message.

Message	Corrective action
The header information of the parameter blocks is inconsistent.	<p>A mismatch is detected in other than user setting area. Write the parameters, having been written to the programmable controller CPU, to the programmable controller again. When a mismatch is detected on the block number AFFF, perform the following operation to reset the area which is set by the system.</p> <ul style="list-style-type: none"> <li>Select Project view ⇒ Parameter ⇒ Network Parameter ⇒ Ethernet/CC IE/ MELSECNET. Click the <b>End</b> button on the displayed MELSECNET/CC IE/ <u>Ethernet Module Configuration</u> screen and write the parameters to the programmable controller CPU.</li> </ul>
This parameter block can't analyze.	<p>Versions of GX Works2, GX Developer, or GX IEC Developer used to create the projects differ between the verify source and the verify destination. The programmable controller CPU operation is not affected.</p>

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

## ■ Checking verification result details


Details of mismatched data can be checked on the <<Verify Result List>> tab on the Verify Result screen.

Details of program verification result can be checked for ladder programs only.

### Operating procedure

1. Double-click the row of the data to display the details of the Verify Result screen.

The following are screens of project with labels.





2. Set the item on the screen.

Item	Description
Do not move cursor at [Next Unmatch]/[Previous Unmatch] after changing background color when devices are within the automatic-assign range for the row shows devices unmatched*1, *2	Select this to exclude a verification result which is unnecessary to find and in which devices are only reassigned to other devices when a program is compiled. When only devices automatically assigned to labels mismatch, the background color of the verification result is changed to a different color from other rows. The cursor is not placed when searching for the result using the [Next Unmatch] (📄)/[Previous Unmatch] (📄) function.

\*1 : For projects with labels only  
\*2 : For program files

3. Select [Find/Replace] ⇒ [Next Unmatch] (📄)/[Previous Unmatch] (📄).

The cursor can only be placed on the rows with mismatches.

**Point**

● **Detail Verify Result tabs**

- The tab order can be changed by dragging and dropping <<Detail Verify Result>> tabs.
- The screen returns from the <<Detail Verify Result>> tab to the <<Verify Result List>> tab by selecting [View] ⇒ [Return to Result List] (📄).
- The selected <<Detail Verify Result>> tab can be closed by selecting [View] ⇒ [Close Detail Result] (🗑️)/[Close All Detail Result] (🗑️).


● **Verifying device memory data**

Device memory data are verified with the actual values.  
Even when the display formats of data are different on the device memory editor, the verification result on the same value will be a match.  
For FXCPU, the verification result is as follows:

- a result of internal relay (M) verification includes special device M.
- a result of data register (D) verification includes file register and special device D.

● **Devices to which a value is not set on the device memory editor**

Devices to which a value is not set on the device memory editor are verified as a value 0.  
Therefore, if 'device memory data to which devices are not set' and 'device memory data to which devices are entered without setting device values' are verified, the verification result will be a match.



● **Direct input (DX) and direct output (DY)**

When verifying device comments or device memory data, check the verification result with input (X)/output (Y) for direct input (DX)/direct output (DY).

● **Number of verification results displayed**

If the number of mismatches exceeds 1,000, up to 1,000 mismatch results are displayed and verification is suspended after that.  
For a ladder program of program (program file) and POU, since the function determines the difference of the number of lines between the verify source and the verify target in the list format as a mismatch, the verification is canceled in the middle of the process even before reaching 1,000 mismatches and the rest of the program is determined as a mismatch. The remaining part needs to be verified again after modifying the mismatched data.

● **Copying verification results**

Verification results can be copied and pasted to a text file. Select rows of verification result to be copied, and select [Edit] ⇒ [Copy].  
The copied data are pasted on a text file as data separated by tabs.


1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES

### Point

#### ● Jumping from verification result

When "Enable calling function block and using inline ST" is selected under [Tool] ⇒ [Options] ⇒ "Compile" ⇒ "Basic Setting", function block program items with no difference may be indicated as a mismatch on the Verify Result screen. In this case, check the mismatch part by any of the following methods.

- Checking labels/devices set to input/output variables of function block  
Open the source program from which function blocks are called, and check labels/devices.
- Checking mismatch parts with the program verification result  
Select items as shown below to verify programs.



#### ● Jumping from verification result of intelligent function module parameter (initial setting/auto refresh)

When different modes are set to the verify destination and the verify source for auto refresh of temperature control module, jumping to verification result is not performed.

For setting the auto refresh of temperature control module, refer to the following manual.

☞ GX Works2 Version 1 Operating Manual (Intelligent Function Module)

#### ● Block password to which the execution program protection setting is enabled

In a verification result, whether program files are matched or mismatched cannot be checked on the <<Detail Verify Result>> tab but on the <<Verify Result List>> tab.

To check the verification result of program files on the <<Detail Verify Result>> tab, refer to the following section.

(☞ Section 4.12.4)

## ■ Checking method when verify source data are modified

Updated verify source data are displayed in the verification result.

Therefore, the verification result of updated verify source data can be checked without executing the verification function again when mismatched data is modified.

Even when a data name of verify source is changed, the changed data name is displayed in the verification result.

### Operating procedure

1. Modify the verify source data.
2. Open the <<Verify Result List>> tab or the <<Detail Verify Result>> tab on the Verify Result screen.
3. Double-click the modified data on the <<Verify Result List>> tab or the <<Detail Verify Result>> tab.

The updated data is displayed in the verification result.


## ■ Writing verification results to CSV files

Output data displayed on the Verify Result screen to a CSV file.

### Operating procedure

1. Select [Edit] ⇒ [Write to CSV File] (📄).

The Write to CSV File screen is displayed.



2. Enter a file name.

3. Click the **Save** button.

The verification results are saved on a personal computer.

### ● Formatting CSV file

The saved CSV file is displayed as shown below when it is opened in spreadsheet software.

<Display of the Verify Result screen>

No.	Object Type	Data(Verify Source)	Data(Verify Destination)	Verify Result
1	Program File	MAIN	MAIN	Mismatch
2	Program File	SUB1	SUB1	Mismatch
3	Program File	SUB2	SUB2	Match
4	Program	MAIN	MAIN	Mismatch
5	Program	SUB2	SUB2	Match
6	FB_Pool	CARRY1	CARRY1	Mismatch
7	FB_Pool	SHOKIKA	SHOKIKA	Match
8	FB_Pool	CARRY2	CARRY2	Match
9	Parameter	PLC/Network	PLC/Network	Mismatch
10	Parameter	Intelligent Function Module(Initial Setting/Dest. Only		

<CSV file>

No.	Object Type	Data(Verify Source)	Data(Verify Destination)	Verify Result
1	Program File	MAIN	MAIN	Mismatch
2	Program File	SUB1	SUB1	Mismatch
3	Program File	SUB2	SUB2	Match
4	Program	MAIN	MAIN	Mismatch
5	Program	SUB2	SUB2	Match
6	FB_Pool	CARRY1	CARRY1	Mismatch
7	FB_Pool	SHOKIKA	SHOKIKA	Match
8	FB_Pool	CARRY2	CARRY2	Match
9	Parameter	PLC/Network	PLC/Network	Mismatch
10	Parameter	Intelligent Function Module(Initial Setting/Auto Refresh)		Source Only

1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES

## 4.2.8 Changing programmable controller type of projects




\*1 : CC IE Field head module only

Change the programmable controller type of a project being edited.

### Screen display

Select [Project] ⇒ [Change PLC Type].





### Operating procedure

#### 1. Set the items on the screen.

Item	Description
PLC Series	Select the programmable controller series after change.
PLC Type	Select the programmable controller type after change.

#### 2. Click the button.

The confirmation message is displayed. Click the  button to execute the function.






### ● Changing programmable controller type of projects which contain intelligent function modules (For QCPU (Q mode)/LCPU/CC IE Field head module)

Basically intelligent function modules are deleted after the programmable controller series is changed, but certain intelligent modules can be changed to those which are applicable to the programmable controller series after change. For details of the shift of models of intelligent function modules associated with change of programmable controller series, refer to the following section.

☞ ■ Changing intelligent function modules between programmable controller series

To change the model of an intelligent function module, select a module name in "Module Name After Change" on the following screen displayed at changing the programmable controller type.

To delete all intelligent function modules, select "Delete all after changing intelligent function module".




### ● Changing programmable controller type of projects which contain intelligent function modules (For FXCPU)

After changing the programmable controller series, intelligent function module data is deleted.

### ● List of modifications (For QCPU (Q mode)/LCPU/CC IE Field head module)

After the Change PLC Type function is completed, the following List of Modifications screen is displayed, and the changes of the program and parameters can be checked.

The items in the following screen can be copied and pasted to the text file using the **Ctrl + C** and **Ctrl + V** keys.



### Point

- **Restrictions on the Change PLC Type function execution**

For the restrictions on the Change PLC Type function execution for each programmable controller series, refer to Appendix 10.

- **Programs which use devices/labels for indexes in structure array labels**

After changing the programmable controller type from/to Universal model QCPU/LCPU, the program operation may be changed.

Review the program where over 65,536 array elements are accessed.

- **Interruption of processing**

If the project of change source includes the data which is neither supported nor able to be modified by any editing operations with the project of the programmable controller type after change, the processing is interrupted. If this happens, modify the data first to correspond with the programmable controller type after change, and then execute the Change PLC Type function.

- **Execution failure of the Change PLC Type function**

The Change PLC Type function cannot be executed in the following cases:

- During the execution of the monitoring function such as program monitoring and device/buffer memory batch monitoring.
- Security is set for the open project and the user does not belong to the 'Administrators' group.
- During the execution of the simulation function.

- **Data before changing the programmable controller type**

Restoring the data, after executing the Change PLC Type function, to the data before change is not possible. Execute the function after saving the project data. In addition, note that the project is in the unsaved status after the function execution.

- **Unsupported instructions, devices outside the range, and unsupported index settings created with project with labels**

The unsupported instructions, devices outside the range, and unsupported index settings created with the project with labels are not converted when performing PLC type change function regardless of its program language. After performing PLC type change, perform compilation and review the corresponding error location in the program.

## ■ Changing intelligent function modules between programmable controller series

Basically intelligent function modules are deleted after changing the programmable controller series, but a part of intelligent modules can be changed to those which are applicable to the programmable controller series after change.

The following table shows modules which can be changed.


Module type	Module name	
	QCPU (Q mode)	LCPU/CC IE Field head module
Analog	Q64AD Q68ADV Q68ADI Q64ADH	L60AD4
	Q68ADV	L60ADVL8
	Q68ADI	L60ADIL8
	Q64ADH	L60AD4-2GH
	Q62DAN Q64DAN Q68DAVN Q68DAIN Q64DAH	L60DA4
Temperature control	Q64TCTTN	L60TCTT4
	Q64TCTTBWN	L60TCTT4BW
	Q64TCRTN	L60TCRT4
	Q64TCRTBWN	L60TCRT4BW
Counter	QD62 QD62D	LD62 LD62D
	QD75P1 QD75P2 QD75P4 QD75P1N QD75P2N QD75P4N QD75D1 QD75D2 QD75D4 QD75D1N QD75D2N QD75D4N	LD75P1 LD75P2 LD75P4 LD75D1 LD75D2 LD75D4
Serial communication/ Modem interface	QJ71C24N QJ71C24N-R2	LJ71C24 LJ71C24-R2
	QD77MS2	LD77MS2
Simple motion	QD77MS4	LD77MS4
	QD77MS16	LD77MS16
AnyWireASLINK interface	QJ51AW12AL	LJ51AW12AL


1  
OVERVIEW2  
SYSTEM  
CONFIGURATION3  
SCREEN  
CONFIGURATION AND  
BASIC OPERATIONS4  
PROJECT  
MANAGEMENT5  
EDITING  
PROGRAMS6  
SETTING  
PARAMETERS7  
SETTING DEVICE  
MEMORY8  
SETTING DEVICE  
INITIAL VALUES


## ■ Detailed replacement method screen for changing CPU to Universal model QCPU


In GX Works2 with the installed QnH -> QnU Conversion Support Tool, the methods for replacing instructions and parameters can be displayed from the List of Modifications screen when the programmable controller type is changed from Basic model QCPU or High Performance model QCPU to Universal model QCPU.

### Operating procedure

1. Click the  button.




2. Specify the project before changing the programmable controller type, and click the  button.




The overview of the replacement method regarding instructions and parameters which are changed by the PLC type change function can be checked on the displayed Detailed replacement method screen. The Web browser is activated by clicking the link to check details of settings. Adobe® Reader® is required to view the detailed information.

3. Click the  button to search the instruction/device to be replaced.





4. Replace the instruction/device by following the instruction on the <<Replacing Procedure>> tab.



1

OVERVIEW

2

SYSTEM  
CONFIGURATION

3

SCREEN  
CONFIGURATION AND  
BASIC OPERATIONS

4

PROJECT  
MANAGEMENT

5

EDITING  
PROGRAMS

6

SETTING  
PARAMETERS

7

SETTING DEVICE  
MEMORY

8

SETTING DEVICE  
INITIAL VALUES

## 4.3 Operations of Programmable Controller CPU Data

This section explains how to operate each data in a project.

### 4.3.1 Adding new data to project




Add new data to a project.

The data that can be added differs according to the type of programmable controller or project.

#### Screen display

Select [Project] ⇒ [Object] ⇒ [New].



#### Operating procedure

##### 1. Set the items on the screen.

Item	Description
Data Type	Select the type of the data to be added.
Data Name	Enter the name of the data to be created.
Program Language	Select the programming language for creating programs. Selection is allowed only when the data type is any of the following: <ul style="list-style-type: none"> <li>• Program (program block), Function*1 or Function block*2.</li> </ul>
Result Type*1	Set the data type of return value of the function.
Inherent Property*1	This item can be set when a function or function block is selected. For details of check box items, refer to the following manual. GX Works2 Version 1 Operating Manual (Structured Project)

\*1 : For Structured projects only

\*2 : For Simple projects (with labels) and Structured projects only

## 2. Click the button.

The editing screen for the created data is displayed.

### Point

#### ● Number of characters for a data name

The numbers of characters shown in the following table can be used for data names according to the selectable data type.

However, some operators such as "-" and "\*", and some instruction names such as "MOV", cannot be used. For details of the characters which cannot be use for data names, refer to Appendix 9.

Data type name	Number of characters
Program (program file), local device comment, device memory, and device initial value	8 characters
Other data types	32 characters

#### ● Maximum numbers of data types that can be created

The table below indicates the maximum numbers of data types that can be created.

Data type name	Maximum number
Connection destination	128
SFC block in Simple project*1	320 (128 for Q00UJ/Q00U/Q01U/Q02U, 25 for FXCPU)
Program in FXCPU Simple project (with labels)	64
Other data (structures, global labels, etc.)	800

\*1 : SFC of Simple projects (with labels) is not supported by FXCPU.

#### ● FXCPU

For FXCPU, the data of device initial values cannot be created.

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

## 4.3.2 Copying/pasting data in projects

Q CPU L CPU Remote Head FX


Utilize data of a project being edited or other projects.

### Operating procedure

1. Select a data name to be copied on the Project view.

2. Select [Project] ⇒ [Object] ⇒ [Copy].

The selected data name is copied.




3. Select a folder to paste the data name on the Project view.

4. Select [Project] ⇒ [Object] ⇒ [Paste].



If the same data name exists in the folder where the data is to be pasted or when the data name cannot be used for the project of the folder where the data is to be pasted because of the different project languages, the Data Paste screen is displayed.

Select a folder →



5. Enter a new name in the "Data Name After Paste" field, and click the **OK** button.

The data name is pasted.



## Point

### ● Copying/pasting data

- Data between different projects can be copied and pasted only when their programmable controller types and project types are the same.\*1

\*1 : For Q series, data can be copied/pasted when the type of two projects are the same.  
For L series, data can be copied/pasted when the type of two projects are the same.

- Multiple data can be copied by holding down the **[Shift]** or **[Ctrl]** key and selecting the data.
- Data can be copied/pasted by right-clicking data to be copied/folder to be pasted and selecting [Copy]/[Paste] from the shortcut menu, or by dragging and dropping the data from the data to be copied to the folder to be pasted.
- The program is in an uncompiled status after data are pasted. Compile the program again.
- For projects with security, only users whose access level is 'Administrators' can copy/paste data.
- Copying and pasting PLC parameter or network parameter only are not possible. If they are copied individually, the whole parameter files are copied and the files in the folder where the data is to be pasted are overwritten.
- Pasting of global label data is canceled when the maximum number of labels described below is exceeded. Adjust the number of global labels in the copy destination and the copy source, and retry pasting data.
  - Global label (within a project): 20480
  - Global label (within a user library): 20480
- Data locked with a block password cannot be copied. To copy the data, unlock the block password first.

### ● Copying/pasting tasks in Structured project

When tasks are pasted, the number of programs that can be set on the [Task Setting](#) screen may be exceeded. Compile the program and delete the unnecessary programs.


1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

### 4.3.3 Changing project data names



Change the data name of an open project.

#### Operating procedure

1. Select the data name to be changed on the Project view.
2. Select [Project] ⇒ [Object] ⇒ [Rename].
3. Change the data name.
4. Press the  key.

The selected data name is changed.

### 4.3.4 Deleting project data



Delete data in an open project.

#### Operating procedure

1. Select the data name to be deleted on the Project view.
2. Select [Project] ⇒ [Object] ⇒ [Delete].

The selected data is deleted.

#### Point


##### ● Deleting data

- Multiple data can be selected and deleted.
- When data under the POU are deleted, data under the Program Setting are deleted simultaneously.

### 4.3.5 Merging data




Merge ladder programs or device comment data of multiple projects, and add them to a project. When the programmable controller series of the projects are the same, data can be merged even if data's programmable controller types or project types are different.



#### Screen display

Select [Tool] ⇒ [Merge Data].



#### Operating procedure

1. Select the data type to be merged.

Item	Description
Data Type	Specify the data type to be merged.
Ladder Program	Select this to merge ladder programs.
Device Comment	Select this to merge device comments.

1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES

## 2. Set the items on the screen.


Item	Description
Source Data	–
Source Project	Click the <b>Browse...</b> button, and specify the source project.
Workspace Location	Display the path to the workspace of the source project.
Workspace Name	Display the workspace name of the source project. This field will be blank when a project in the single file format is specified for the source project.
Project Name	Display the project name of the source project.
Title	Display the project title of the source project.
Source Data List	Display programs or device comments of the source project. Select data to be merged. Programs which contain function blocks or inline structured text programs are not displayed.
Target Data List	Display data to be merged. Up to 128 data can be displayed. Data are merged in the displayed order.
Data Name after Merging	–
Data Name	Specify a data name after merging.

## 3. Click the **Execute** button.

Data of "Target Data List" are merged and added to the project.

### Screen button

- **Add->**  
Adds data selected in "Source Data List" to "Target Data List".
- **Add All->**  
Adds all data displayed in "Source Data List" to "Target Data List".
- **<-Delete**  
Deletes data selected in "Target Data List".
- **<-Delete All**  
Deletes all data displayed in "Target Data List".
- **Set Range...**  
Displays the Set Range screen.  
Set the range of programs selected in "Target Data List".  
The range cannot be set when the source project or the target project is a project with labels.






Options...


Displays the Options screen.

Select the processing for label/device comment duplication when merging programs or device comments of projects with labels.

< Program of project with labels >



< Device comment >



**Point**

● **Data to be merged**

- Data saved on a personal computer are merged. Save the project data being edited in order to merge them.
- If the merged data exceeds the program capacity, the data are merged within the program capacity.

Example) When merging three programs: MAIN1, MAIN2, and SUB3

In the setting of the following screen, the programs are merged from MAIN1. After merging MAIN1 and MAIN2, if the result of merging SUB3 exceeds the program capacity, only MAIN1 and MAIN2 are merged.

Target Data List					
Project Name	Project Type	Data Name	Range	PLC Type	Title
Project2	Simple	MAIN1	Whole Range	Q06UDH	
Project2	Simple	MAIN2	Whole Range	Q06UDH	
Project2	Simple	SUB3	Whole Range	Q06UDH	

● **Merging program data when the target project is a project without labels**

When the target project is a project without labels, data of program with labels are merged as a program of actual devices. Furthermore, uncompiled programs in a project with labels of source project are not displayed in "Source Data List".

● **Merging data during monitoring**

Data cannot be merged during monitoring. Stop monitoring to merge data.

● **Merging programs**

When the programmable controller types of the source project and the target project are different, instructions and devices which cannot be used for the programmable controller type of the target project are merged as the way they are.

Check the merged program for errors with the program check function or the compilation.

For projects with labels, the local label settings are also merged when programs with labels are merged. However, since the global label settings are not merged, set labels after programs are merged, or copy the global label data from the source project.

1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES


### 4.3.6 Displaying/editing properties

Q CPU L CPU Remote Head FX

Display data properties of folders, parameters, and programs. A title and/or comment can be set to each data.

#### Screen display


- For property of project

Click  on the Project view.


- For property of each data

Select [Project] ⇒ [Object] ⇒ [Property] (.

<<Detail>>



<<Comment>>



#### Operating procedure

- Set the items on the screen.

Item	Description
Data Name	Display the data name.
Title*1, *2	Set a title for the data. (The number of applicable characters is 128 for a project and 32 for other data.)
Last Change*1	Display the date when the data was updated.
Comment*1	Set a comment for the data. Press the <b>Ctrl</b> and <b>Enter</b> keys for a line feed. (The number of applicable characters is 5,120.)
MELSOFT iQ AppPortal information file output when saving project*3	Set the output type of an iQ AppPortal information file.

\*1 : For FXCPU Simple project (with labels), "Title", "Last Change", and <<Comment>> tab are not supported by the property of "MAIN" under Project view ⇒ "Program Setting" ⇒ 'execution program'.

\*2 : For titles of programs that are read from/written to a programmable controller CPU along with the program data, refer to Point in this section.

\*3 : This item appears for the Project Property screen and the Property screen of User Library.


**Point**

● **Titles**


Set titles are displayed on each view with a corresponding data name.

For SFC project without labels, a device comment of BL device corresponds to the SFC block becomes a title. When the device comment of the reference target is read-protected by the security setting, the title is not displayed on the view.

Titles of programs that are read from/written to a programmable controller CPU along with the program data are titles of data created for each execution type in the program setting. Those titles are displayed on the Online Data Operation screen when reading/writing data from/to a programmable controller CPU.



For ladder programs and ST programs created in a Simple project, program titles of the program setting and POU are linked. When the program title is set either in the program setting or POU, the title is reflected to the other title.




1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES

### ● Properties of Structured projects

Properties of the following data can be set for Structured projects in addition to those indicated above.


Data	Setting
Task	Priority and executing condition of a task
Function/Function block	Whether to use EN/ENO, or MC/MCR for EN control
Library	Path to a help file

For details, refer to the explanations of each function.

( GX Works2 Version 1 Operating Manual (Structured Project))

### ● Destinations for saving properties

The 'titles' and 'comments' set to the data properties can be saved as symbolic information.

( Section 15.1.5)

When reading data from the programmable controller CPU, the symbolic information must be written to/read from the programmable controller CPU in order to restore the settings of the properties.

When data are read without the symbolic information from the programmable controller CPU, the settings of the properties are not restored.

## 4.4 Operations of Intelligent Function Module Data

Q CPU L CPU Remote Head FX

For the method for setting the intelligent function module data, refer to the following manual.


☞ GX Works2 Version 1 Operating Manual (Intelligent Function Module)

1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES

## 4.5 Changing Project Types



This section explains how to change the type of an open project. Using the method explained below, the type of a Simple project is changed from 'without labels' to 'with labels'. In addition, a Simple project 'with labels' can be changed to a Structured project. Changing from a Simple project 'with labels' to a Simple project 'without labels' or changing a Structured project to a Simple project is not supported.



\*1: Not supported by FXCPU.

### Operating procedure


- Select [Project] ⇒ [Change Project Type].

### Point

#### ● Changing project types

When a Simple project (with labels) is changed to a Structured project, project data are stored in the following folder.

- SFC: Created under the Program folder.
- Function block: Created under the FB/FUN folder.



#### ● Operation after changing project type

When the project type is changed, programs are in the uncompiled status. Compile all programs again after changing the project type. (☞ Section 5.4)

## 4.6 Managing Project Revisions

Q CPU L CPU Remote Head FX

This section explains how to register a backup of the project with added revision information, and restoring the registered backup data (content of the past project).

### 4.6.1 Registering revision information (creating backup)

Create a backup of the project at the point of registration, and register it with the revision information.

#### Screen display

Select [Project] ⇒ [Project Revision] ⇒ [Revision Entry].

#### Operating procedure

- Set the items on the screen.

Item	Description
Revision No.	Display the revision number to be registered.
Date	Display "--/--/---- --:--:--" (month/date/year hour:minute:second).
User	Display the user name when using the project with security.
Title	Enter a title of the revision.
Comment	Enter comments for the revision.

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES

**Point**


- **Revision number and the allowable number of revisions that can be registered**  
 A revision number for the registered revision is automatically assigned from 1 to 9999.  
 The maximum number of revisions that can be registered is 100. If the number of the registered revisions is to be exceeded 100, delete unnecessary revisions. The deleted revision numbers are unused.  
 If the revision number is to be exceeded 9999, delete all the revision data, or save the project with a different name without succeeding the revision information. (☞ Section 4.2.3)
- **The allowable number of characters that can be entered for a title**  
 The maximum number of characters that can be entered for a title is 32.
- **The allowable number of characters that can be entered for a comment**  
 The maximum number of characters that can be entered for a comment is 256.  
 A line feed is handled as 2 characters.
- **Registration of project revisions when overwriting and saving projects**  
 By setting the option, the Revision Entry screen for the project revision is displayed when overwriting and saving the project.  
 Select [Tool] ⇒ [Options] ⇒ "Project", and then select "Revision is Registered when Save Project" in "Change History".  
 In addition, the revision title can be automatically set when overwriting by selecting "Automatically set revision titles".
- **Registration of project revisions for projects with security**  
 For the projects with security, the revisions can be registered only when the user's access level is 'Administrators'.
- **Information for iQ AppPortal**  
 Information for iQ AppPortal is not registered for revision information.

## 4.6.2 Displaying revision list

Display registered revision information in the order of the revision number.  
 The revision list is used for registering, restoring, deleting, and verifying backups.

### Screen display

Select [Project] ⇒ [Project Revision] ⇒ [Revision List].



### Display contents


Item	Description
No.	Display the revision numbers.
Date	Display the dates of revision registration.
User	For the projects with security, display the user names who have registered the revisions.
Title	Display the titles of the revisions.



## Screen button

- **Detailed Information...**

Displays the detailed information of the revision which is selected in the list. "Title" and "Comment" can be edited.



- **Register...**

Registers the project being edited as a revision. (☞ Section 4.6.1)

- **Restore...**

Restores the backup data. (☞ Section 4.6.3)

- **Delete**

Deletes the revision information. (☞ Section 4.6.4)

- **Verify...**

Verifies the revision with other revisions or the projects being edited. (☞ Section 4.6.5)

### Point

- **Revision List screen**

Each column can be sorted in ascending/descending order by clicking on the column header.


## 4.6.3 Restoring backup projects

Restore the backup revision information.

After restoring the backup, the project is in the status at the time of registering the revision information.


### Operating procedure

1. Select the revision to be restored on the **Revision List** screen (☞ Section 4.6.2).



2. Click the **Restore...** button.

The revision information to be restored is displayed.




3. Confirm the revision information to be restored. Click the **OK** button.

The backup of the selected revision information is restored.


The revision number and title of the restored project are displayed on the title bar.


Revision number and title  
of the restored project.



**Point**

● The **Revision List** screen after restoring a project

After project restoration,  is displayed on the row of the restored project on the **Revision List** screen.



● **Access level to be able to use the restoring function when using the projects with security**

For the projects with security, the revisions can be restored only when the user's access level is 'Administrators'.

● **Revisions for the project with security**

If the project being edited is the project with security, the registered security in the revision is deactivated when the security is deactivated. When the revision is restored in such situation, since the project is restored without security, all users can access the project including the revision data.

To protect the revision data after deactivating the security, delete the revision data in advance.

● **Considerations for restoring projects**

Register the revision of the project being edited before restoring a project.


When the other revision is restored and overwritten without registering the revision of the project being edited, the project before restoration is overwritten.

## 4.6.4 Deleting revision information


Delete the registered revision information.

### Operating procedure

1. Select the revision information to be deleted on the **Revision List** screen (☞ Section 4.6.2).



2. Click the **Delete** button.  
The message on the right is displayed.



3. Click the **Yes** button.  
The selected revision information is deleted.

### Point

- **Revision number**  
The deleted revision numbers are unused.
- **Revisions being restored**  
The revision of the project which has been restored from the revision cannot be deleted. To delete the revision, overwrite and save the project after restoring it.

## 4.6.5 Verifying revisions

Verify the revision information with other revision information or the project being edited.  
The following data can be selected as verification targets for the revision verification.

- Programs
- Parameters
- Intelligent function module parameters (initial setting/auto refresh)\*1
- Device comments
- Device memory data
- QD75/LD75 positioning module\*1


\*1 : Not supported by FXCPU.

**Operating procedure**

**1. Select the revision to be verified on the Revision List screen (☞ Section 4.6.2).**


When the verification function is performed selecting only one revision, the selected revision information is verified with the project being edited.

To verify two revisions, select two revisions by holding down the **[Shift]** key or **[Ctrl]** key.



**2. Click the **Verify...** button.**

The message as shown on the right is displayed. This message is displayed when verifying the selected revision information with the project being edited.




**3. Click the **Yes** button.**

The Revision Verification screen is displayed.

**4. Select the data to be verified.**

For details of setting items, refer to the project verification. (☞ Section 4.2.7)




**5. Click the **Execute** button.**

The verification result is displayed on the Verify Result screen. For details of the Verify Result screen, refer to the project verification.

(☞ Section 4.2.7)

The following is a screen of project with labels.




## 4.7 Utilizing Projects and Data in Other Formats

This section explains how to utilize projects created with GX Developer or GX IEC Developer, and files (ASCII files) created using the Export function of GX IEC Developer in GX Works2. Projects edited with GX Works2 can also be utilized in GX Developer.

### ■ Utilizing projects and data created with GX Developer or GX IEC Developer in GX Works2

Projects created with GX Developer or GX IEC Developer can be utilized in GX Works2 by using the 'Open Other Project' function. (☞ Section 4.7.1)



1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS


6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES


### ■ Utilizing files created using the Export function of GX IEC Developer

ASCII files created using the Export function of GX IEC Developer can be added as projects in GX Works2 by using the 'Read ASC Format File' function. (☞ Section 4.7.2)



### ■ Utilizing projects and data created with GX Works2 in GX Developer

Files created/edited in Simple project with GX Works2 can be utilized in GX Developer by using the 'Export to GX Developer Format File' function. (☞ Section 4.8)



## ■ Storage of utilized data in GX Works2

Each project and data created with GX Developer or GX IEC Developer are stored in the areas shown in the table below with GX Works2.

GX Developer projects are opened as Simple projects and GX IEC Developer projects, as Structured projects.

### ● Comparison of projects and data storage locations between GX Developer and GX Works2

GX Developer	GX Works2 (Simple project)	GX Works2 (Structured project)
Parameter	Parameter	Parameter
Device Comment	Global Device Comment	Global Device Comment
Global variables	Global Label	Global Label
Program	Program	POU
FB	FB_Pool	FB/FUN
Structure	Structured Data Types	Structured Data Types
Device memory	Device Memory	Device Memory
Device initial value	Device Initial Value	Device Initial Value


### ● Comparison of projects and data storage locations between GX IEC Developer and GX Works2

GX IEC Developer	GX Works2 (Structured project)
User Library	User Library
Parameter (Programmable controller parameter)	Parameter
DUT_Pool (Structure)	Structured Data Types
Global_Vars (Global variable)	Global Label
Task_Pool	POU
POU_Pool	POU

## ■ Security level of GX IEC Developer

The security level in the GX IEC Developer project is cleared after reading the project.

When the GX IEC Developer project is read using GX Works2, the following Enter Password screen is displayed.



## ■ Compatible applications

For 'Open Other Project' and 'Export to GX Developer Format File', the supported versions differ according to the CPU type.

For the application compatibility, refer to Appendix 5.


## 4.7.1 Opening projects in other formats




Open a project created with GX Developer or GX IEC Developer in GX Works2.

### Screen display

Select [Project] ⇒ [Open Other Data] ⇒ [Open Other Project].



### Operating procedure

- **Specify the project, and click the  button.**  
Select '\*.gpj' for a GX Developer project and '\*.pro' for a GX IEC Developer project.  
The selected project is opened.

### ■ Considerations for opening projects in other formats

#### ● Status after opening a different format project with labels

When a different format project with labels is opened, the project is in the uncompiled status. Compile all programs in the project before executing online operations such as writing data and monitoring. When a compilation error occurs, correct the corresponding program according to the programming manual.

#### ● When a programmable controller type of project which is created in GX Developer is not supported by GX Works2

Open the project by starting GX Developer.

#### ● Projects which contain FBD, SFC, IL, or MELSEC-IL programs created with GX IEC Developer

FBD programs created with GX IEC Developer can be read with GX Works2 Version 1.56J or later as Structured Ladder/FBD programs.

Projects which contain SFC, IL, or MELSEC-IL programs created with GX IEC Developer cannot be read with GX Works2.



### ● Opening different format projects that contain SFC programs

- Block information data such as: block information devices, block titles and block statements, are set in the block data property.
- When a GX Developer format project, including a ladder block with an unconverted SFC program, is opened by selecting [Open Other Project] in a version between 1.87R and 1.551Z of GX Works2, the number added to the end of the block name may not be in sequence.
- When a GX Developer format project, including a ladder block with an unconverted SFC program, is opened by selecting [Open Other Project] in a version 1.555D or later of GX Works2, the program name is added in the block name.

### ● Opening different format projects that contain ST programs

Since the argument type or the number of arguments in some ST instruction is different between GX Developer and GX Works2, an error may occur at compilation. When a compilation error occurs, correct the instruction according to the structured programming manuals.

Note that, however, programs can be compiled in GX Works2 by setting the following option.

- Select "Use Dedicated Instruction for GX Developer, GX IEC Developer" under [Tool] ⇒ [Options] ⇒ "Project" ⇒ "Common Setting".

### ● Setting common pointer number

When the common pointer number is not set in the PLC parameter setting of GX Developer, a compilation error may occur at the compilation after opening the project in other format. In such case, change "Common Pointer No." on the <<PLC System>> tab of PLC parameter or change the pointer device range in the "Device/Label Automatic-Assign Setting" function.

### ● Utilizing detailed settings for Write to PLC function

Values set in GX Developer are utilized to the secured steps for Online program change (☞ Section 15.1.1) and the writing range of device comment (☞ Section 15.1.3) which are set when writing data to programmable controller CPU.

Note that "PLC comment write format (CPU Format)" which is set along with the writing range of device comment in GX Developer is not utilized.

For a project in which the comment capacity is restricted by setting "PLC comment write format (CPU Format)" in GX Developer, the comment capacity may be exceeded when data are written to a programmable controller CPU using GX Works2.

In such a case, set "Comment Format (PLC Format)" (☞ Section 15.1.3) or reduce the writing range of device comment.


### ● Utilizing option settings

GX Developer option setting "Copy source/display source of reference during comment edit" is utilized to GX Works2 option setting "Program Editor" ⇒ "All Editors" ⇒ "Device Comment" ⇒ "Reference of Device Comment".

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

### ● Opening a GX IEC Developer project

When a GX IEC Developer project that contains a user library is opened, the following message may be displayed and the user library may not be read. If the following message is displayed, select [Project] ⇒ [Library] ⇒ [Install] in GX Works2 to obtain the user library.



When a GX IEC Developer project is read by selecting [Project] ⇒ [Open Other Data] ⇒ [Open Other Project], intelligent function module parameters are not reflected.

### ● When a GX Developer data name contains a character that cannot be used in GX Works2

A GX Developer project with a GX Works2 invalid character can be opened.

Note that, however, the invalid character in the data is replaced by an underscore (\_).<sup>\*1</sup> Change the data name after opening the project.

\*1 : For FXCPU, data which contains invalid characters in its data name is not read.


### ● Changing the number of columns of device memory editor

The number of columns of device memory editor can be changed when opening GX Developer format project by selecting the following option.

- [Tool] ⇒ [Options] ⇒ "Device Memory Editor" ⇒ "Initial Value of Column Number"

When selecting "Always Confirm", the number of columns of device memory editor can be changed at opening the Device Memory screen at the first time on the following screen.

When setting "Auto" as a default, or always specify the same number of columns by selecting "Specify the number of column", set with option or select "Set the selected content in option" in advance.




## 4.7.2 Reading ASC format data




Add ASC format data created in GX IEC Developer to a GX Works2 project being edited. Data can be added only when a new project is created or a project is opened in Structured project.

### Screen display

Select [Project] ⇒ [Open Other Data] ⇒ [Read ASC Format File].



### Operating procedure

- Specify the file, and click the  button.  
Select '\*.asc' for the file.  
The specified data is added to the project.

### Point

- Importing project data of different programmable controller type**  
Project data having a different programmable controller type can be imported to a project being edited. The programmable controller type of the project being edited is not changed even when data with the different programmable controller type are imported.  
In this case, since instructions and devices not supported by the open project are also imported, compile the programs to check and correct errors after importing data.
- Importing data whose name already exists in the project**  
A number is appended in serial order (starting from one) to the end of the data name to be imported, and then the data is added to the project.
- Importing global labels**  
When the global labels are imported, the "Device" column of the global label may be blank. If the "Device" column is blank, check the items on the <<Device>> tab of PLC parameter.
- Importing FBD programs of GX IEC Developer**  
Imported FBD programs are converted to Structured Ladder programs.

## 4.8 Saving Projects in Other Formats



\*1 : Not supported by High-speed Universal model QCPU and Universal model process CPU.


\*2 : Not supported by L02S, L02S-P, L06, L06-P, L26 and L26-P.

\*3 : Not supported by FX3s.


This section explains how to save a Simple project of GX Works2 in the GX Developer format.

### Screen display

Select [Project] ⇒ [Export to GX Developer Format File].



### Operating procedure

1. Select the save destination of the GX Developer format project.
2. Enter the project name, and click the  button.

### Point

#### ● Considerations for saving projects

For the restrictions other than the ones described below, refer to Appendix 8.

- Programs are saved in the uncompiled status.
- Data cannot be saved when the security access level is set to other than 'Administrators'. Change the access level before saving the data. (☞ Section 4.10.4)
- The data with a block password cannot be saved. Unlock the block password before saving the data. (☞ Section 4.12.3)
- Projects in which labels are used for FXCPU cannot be saved in the GX Developer format.
- When a GX Developer format project is saved to the folder in which a GX Developer format project with the same name exists, the previously saved project is overwritten.  
If the saving of the project failed, all data except for the data created by user will be deleted.

#### ● Considerations for handling projects in GX Developer

- Since the program is saved uncompiled, the program needs to be compiled when it is opened in GX Developer. For projects with labels, the compilation results and device assignment may be different from those of GX Works2.
- For a maintenance work on the same programmable controller CPU using both GX Developer and GX Works2, programming with actual devices is recommended.

## 4.9 Starting GX Developer from GX Works2



Start a new GX Developer project from GX Works2.

GX Developer needs to be installed in advance to perform this function.


For details of GX Developer installation, refer to Appendix 14.

For details of GX Developer operation, refer to the following manual.

👉 GX Developer Version 8 Operating Manual

### Operating procedure

- Select [Project] ⇒ [Start GX Developer].



1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES

## 4.10 Setting Security for Projects

Q CPU L CPU Remote Head FX

This section explains how to set security for projects to protect the projects themselves and the data in projects.

Setting security not only restricts an access to projects but also prevents the data, such as POU's, device comments, and parameters, that are created by the user from erroneous modification and/or disclosure to unauthorized users.

This function cannot restrict writing/reading of data to/from a programmable controller CPU. Use the online password function to protect the data on a programmable controller CPU. (Chapter 16)

### ■ Access levels and access authority

An access to data can be restricted by setting an access level to the individual user.

An access level is an operating authority given to a login user of the project.

There are five access levels as shown below. The data that can be edited by a user having lower access level can also be edited by a user who has higher access level.

	Access level	Operating authority
Higher ↑ ↓ Lower	Administrators	<Administrator level> All operations are possible.
	Developers (Level 3)	<Developer level> Security setting, data access, and a part of operations are restricted.
	Developers (Level 2)	
	Developers (Level 1)	
	Users	<Operator level> Only access to project data is possible. Data cannot be read from the programmable controller CPU.

Example) The data with access authority of Developers (Level 2) can be edited by a login user whose access level is Developers (Level 2) or higher (Administrators, Developers (Level 3) or Developers (Level 2)).

## ■ Access authority applicable data

The following tables show the data to which access authority can be applied.

### ● Simple project

○: Applicable ×: Not applicable

Items on Project view	Read	Write
Parameter	○	○
Intelligent Function Module	×	×
Intelligent function module data	○	○
Global Device Comment	○	○
Global Label	×	×
Global label data	×	○
Program Setting	×	×
Program file data	×	×
POU	×	×
Ladder program data	×	×
Program	○	○
Local Label	×	○
ST program data* <sup>1</sup>	×	×
Program	○	○
Local Label	×	○
SFC program data	×	×
SFC block	×	×
Program	○	○
Local label* <sup>1</sup>	×	○
FB_Pool	×	×
Program	○	○
Local label	×	○
Structured Data Types	×	×
Structure data	×	○
Local Device Comment	×	×
Comment data	○	○
Device Memory	×	×
Device memory data	○	○
Device Initial Value* <sup>1</sup>	×	×
Device initial value data	×	×

\*1 : Not supported by FXCPU.

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

● Structured project

○: Applicable ×: Not applicable

Items on Project view	Read	Write
Parameter	○	○
Intelligent Function Module	×	×
Intelligent function module data	○	○
Global Device Comment	○	○
Global Label	×	×
Global label data	×	○
Program Setting	×	×
Program file data	○	○
POU	×	×
Program	×	×
Ladder program data*1	×	×
Program	○	○
Local Label	×	○
ST program data	×	×
Program	○	○
Local Label	×	○
SFC program data*1	×	×
Program	○	○
Local Label	×	○
Structured Ladder/FBD program data	×	×
Program	○	○
Local Label	×	○
FB/FUN	×	×
Program	○	○
Local label	×	○
Structured Data Types	×	×
Structure data	×	○
Local Device Comment	×	×
Comment data	○	○
Device Memory	×	×
Device memory data	○	○
Device Initial Value*1	×	×
Device initial value data	×	×

\*1 : Not supported by FXCPU.



## 4.10.1 Setting/resetting security of projects

Set security for an open project and reset the security.

### ■ Setting security for projects

Set security for a project.

Once security is set for a project, user authentication is required when the project is opened once again. (☞ Section 4.10.3)

### Screen display

Select [Project] ⇒ [Security] ⇒ [User Management].

### Operating procedure

#### 1. Set the items on the screen.

Item	Description
User Name	Enter a user name in 1 to 20 characters, using alphabets, numerals, and/or symbols corresponding to the ASCII codes (Appendix 3) of 20H to 26H and 28H to 7EH. (Alphabets are case-sensitive.)
Access Level	Display 'Administrators'. (Fixed)
Password	Enter a password in 6 to 32 characters, using alphabets, numerals, and/or symbols corresponding to the ASCII codes (Appendix 3) of 20H to 7EH. (Alphabets are case-sensitive.)
Re-enter Password	Set the same password again for confirmation.

#### 2. Click the button.

Security is set for the project.

### Point

#### ● Setting security

When security is set for a project, the project is in the status logged in by the set user (Administrators). The current login user can be checked in the status bar. (☞ Section 3.2.6)

#### ● Loss of login password

If a user forgets the login password, logging in to the project is disabled. Remember the password securely. If the user whose access level is Developers (Level 3) or lower forgets the password, log in the project using the access level 'Administrators' and set the password again.

## ■ Resetting security of projects

Reset the set security of a project by deleting all users, and returns the project to the status without security. (☞ Section 4.10.2)


### 4.10.2 Managing (adding/deleting/changing) users

Manage the registered status of users for a project with security. This function also adds/deletes/changes users.

This function is available only when a project is logged in by the user whose access level is 'Administrators' or 'Developers'.

#### Screen display

Select [Project] ⇒ [Security] ⇒ [User Management].



#### Display contents

Item	Description
Number of User Registrations	Display the number of registered users and the maximum number of registrations.
User Name	Display the registered user names.
Access Level	Display the access level of each registered user.

### Screen button

- **Add...**  
Adds a user. (☞ '■ Adding users')
- **Delete...**  
Deletes a user selected in the list.  
The current login user cannot be deleted. If registered users are only 'Administrators' and there are no other users to be deleted, deletion of the current login user is possible.  
If 'Administrators' level users are deleted, security is reset.
- **Change...**  
Changes the information of the user selected in the list. (☞ '■ Changing user information')
- **Password Setup...**  
Changes the password of the user selected in the list. (☞ '■ Changing passwords')  
The password of the current login user cannot be changed using this function. To change it, select [Project] ⇒ [Security] ⇒ [Change Password].

### ■ Adding users


Add a user to a project with security.

A user whose access level is higher than that of the login user cannot be added.

### Operating procedure

1. Click the **Add...** button on the **User Management** screen.

The **User Addition** screen is displayed.



2. Set the items on the screen.

Item	Description
User Name	Enter a user name in 1 to 20 characters, using alphabets, numerals, and/or symbols corresponding to the ASCII codes (Appendix 3) of 20H to 26H and 28H to 7EH. (Alphabets are case-sensitive.)
Access Level	Select the access level.
Password	Enter a password in 6 to 32 characters, using alphabets, numerals, and/or symbols corresponding to the ASCII codes (Appendix 3) of 20H to 7EH. (Alphabets are case-sensitive.)
Re-enter Password	Set the same password again for confirmation.

3. Click the **OK** button.

The user is added.

The added user is displayed in the **User Management** screen.

1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES

## ■ Changing user information

Change the user information (user name and access level) of registered users.

The information of the login user and the user whose access level is higher than that of login user cannot be changed.

### Operating procedure

1. Click the **Change...** button on the **User Management** screen.


The Change User Data screen is displayed.

2. **Set the items on the screen.**

Setting items  Section 4.10.1

3. Click the **OK** button.

The user information is changed.



## ■ Changing passwords

Change the password of the user selected in the list on the User Management screen.

The password of the login user and the user whose access level is higher than that of the login user cannot be changed. To change the password of the login user, use the Change password function by selecting [Project] ⇒ [Security] ⇒ [Change Password].

### Operating procedure


1. Click the **Password Setup...** button on the **User Management** screen.

The Change Password screen is displayed.

2. **Set "New Password" and "Re-enter Password".**

3. Click the **OK** button.

The password is changed.



### 4.10.3 Logging in projects

A user authentication procedure is required when opening a project with security.

#### Screen display

Screen display when a project with security is opened.

#### Operating procedure

##### 1. Set the items on the screen.

Item	Description
User Name	Enter the user name registered to the project to be logged in.
Password	Enter the password.

##### 2. Click the button.

Login authentication is performed with the entered user name and password. The project is opened when the entry is confirmed to be correct.

#### Point

##### ● Checking login status

The current login user can be checked in the status bar. (☞ Section 3.2.6)

## 4.10.4 Changing access authority of access level


Set an authorization of displaying/saving data for each access level.

The access authority of access levels higher than that of the login user cannot be changed.

If the access level of the current login user is 'Users', changing the access authority is not allowed.

### Screen display

Select [Project] ⇒ [Security] ⇒ [Data Security Setting].



### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Access Object	Select one or more data for which access authority is changed.
Access Authority	Set 'enable/disable' of reading/writing data for each access level by moving the slider.*1

\*1 : When multiple data are selected, the default access authority setting is displayed. Click the slider to set the displayed access authority as it is. The access authority will not be set by only selecting multiple data.

#### 2. Click the button.

### Point

#### ● Setting access authority

The access authority can also be set by right-clicking on a single data of which access authority is to be changed on the Project view and selecting [Data Security Setting] from the shortcut menu. When multiple data are selected, the shortcut menu is invalid.


## 4.10.5 Considerations for using the security function

### 1) Read protected data

A name of read protected data is displayed in gray and cannot be opened.

On the screens of project verification and programmable controller verification, a lock mark icon is appended.

The following figures are an example for the case that "Parameter", programs and local labels of "MAIN1", and programs of "MAIN2" are read protected.



### 2) Write protected data

The write protected data can be opened as the read only data.

### 3) Properties of data

The properties of the read/write protected data can be displayed, but cannot be edited.

### 4) Device comment display on ladder editor and the Sampling Trace screen

If the data of the device comment is set as read protected, the device comment is not displayed on ladder editor or the Sampling Trace screen.

### 5) Reading symbolic information from programmable controller CPU using project with security

When symbolic information\*1 is read from a programmable controller CPU, the security settings (settings on the Data Security Setting screen) of the data, which are not included in the symbolic information, are set to their default.

If the settings on the Data Security Setting screen are changed, make settings again after reading data from the programmable controller CPU.

Note that the block password\*2 is not set to default even when the symbolic information is read.

Therefore, setting a block password to each POU is recommended.

\*1 : Symbolic information (☞ Section 15.1.5)

\*2 : Block password (☞ Section 4.12)

## 4.11 Setting Security Key



\*1 : High-speed Universal model QCPU and Universal model process CPU only

This section explains how to control the access with a security key.

### ■ Security key

The security key locks/unlocks projects and a programmable controller CPU.

The lock can only be unlocked with a security key, and therefore project data and data in a programmable controller CPU can be protected.


#### ● For projects

Locked project can be accessed or edited only by the users who registered the security key on the personal computer.


#### ● For programmable controller CPU

The following files can be written to/read from the locked programmable controller only by the users who registered the security key on the personal computer.

- Symbolic information
- Program
- Parameter
- Intelligent function module parameter
- Device comment



Another user can unlock the locked project data or programmable controller CPU by importing/exporting the security key.






## 4.11.1 Managing security key

Create a security key, and import/export/delete the security key.

### Screen display

Select [Project] ⇒ [Security] ⇒ [Soft Security Key Management].



### Display contents

Item	Description
Key Information Registered in the Personal Computer	–
Name	Display the name of the security key.
Creation Date	Display the date of creation of the security key.
Lock Project	Display the lock applicability for the project.
Lock CPU	Display the lock applicability of the programmable controller CPU.
Expiration Date	Display the expiration date when an expiration date is set on the security key.

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT









5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES

### Screen button

-  Imports the security key. (  "■ Importing security key")
-  Exports the security key. (  "■ Exporting security key")
-  Creates a security key. (  "■ Creating a security key")
-  Deletes the security key. (  "■ Deleting security key")


### ■ Creating a security key


---

Create a security key.

#### Operating procedure

1. Click the  button.  
The New screen is displayed.



2. Enter a name and click the  button.  
The security key is created.

#### Point

##### ● Considerations of created security key

Created security keys can be registered only for the user who logged in the personal computer.

The maximum number of security key registrations is 128 including created security keys and imported security keys for each login user of personal computer.

---


## ■ Importing security key

Import the security key which is exported previously to the personal computer.

### Operating procedure


1. Click the **Import...** button.

The Import screen is displayed.



2. Select the security file to be imported, and click the **Open** button.

The Password screen is displayed.



3. Enter the password set for the file when it was exported, and click the **OK** button.

The security key is imported to the personal computer.


## ■ Exporting security key

Export the security key.

### Operating procedure

1. Select the security key to be exported, and click the  button.

The Export screen is displayed.




2. Set the items on the screen.

Item	Description
Security Key Information	–
Name	Display the name of the security key.
Password	–
Password	Enter a password for the security file to be exported. Set a password in 6 to 32 characters, using alphabets, numerals, and/or symbols corresponding to the ASCII codes (Appendix 3) of 20H to 7EH.
Password for Confirmation	Set the same password again for confirmation.
Detailed Setting	–
Expiration Date	Set the expiration date of the security key.
Operation Restriction	–
Lock Project	Select whether to apply the security key setting to the project.
Lock CPU	Select whether to apply the security key setting to the programmable controller CPU.

3. Click the **Execute** button.

The Save as screen is displayed.



4. Enter a name of the file to be saved.

5. Click the **Save** button.

The security key file is saved.

**Point**

● **Considerations of exported security files**

The exported security files should be tightly controlled.

■ **Deleting security key**


Delete the security key registered on the personal computer.

**Operating procedure**

- **Select the security key to be deleted, and click the **Delete** button.**


The following confirmation message is displayed.

Click the **Yes** button to delete the security key.



### Point


- **Considerations when deleting security key**

Unlocking the security key is recommended before deleting it. (  Section 4.11.2)

Take extra caution when deleting security keys.

The project cannot be opened if the security key which is used to lock the project is deleted.

PLC read/write cannot be executed if the security key which is used to lock the programmable controller CPU. In this

case, click the  button on the Soft Security Key Management screen to unlock the security key forcibly.

However, the programmable controller CPU is formatted at the same time as the security key is unlocked.

Even when the security key with the same name is recreated after deleting the security key, it will not be the same security key.


---

## 4.11.2 Locking project with security key

Lock the project with a security key.

### Screen display


Select [Project] ⇒ [Security] ⇒ [Soft Security Key Management].



### Display contents

Item	Description
Key Information Registered in the Personal Computer	Display the information of selected security key. (☞ Section 4.11.1)
<<Project>>	Display the screen to lock/unlock the project.
Project Information	–
Project Name	Display the name of the project.
Title Name	Display the project title.
Security Key Information	–
Name	Display the name of the security key which is used to lock the project.
Creation Date	Display the date of creation of the security key which is used to lock the project.
Explanation	Display the information when the cursor is placed on the button on the screen.

### Operating procedure

1. Select the security key to lock the project from "Key Information Registered in the Personal Computer".
2. Click the  button.  
The project is locked with the selected security key.

### Screen button

-  **Unlock**  
Unlocks the locked project.

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES

### 4.11.3 Considerations of security keys

---

**1) When GX Works2 is uninstalled**

Security keys are not deleted even when GX Works2 is uninstalled.

**2) Security status**

When the security key is "Execution Possible" at the point of opening the project, the security key is handled under the authority of "Execution Possible" while the project is being opened.

For example, even when the security key of the opened project is deleted and the "Execution Impossible" security key is imported, the security key is handled under the authority of "Execution Possible" while the project is being opened.

**3) Locking a project with security key**

The security key set to the project becomes effective after saving the project.

**4) Project locked with security key**

The following operations cannot be performed.

- Write to PLC/Read from PLC/Verify with PLC function with symbolic information, programs, parameters, intelligent function module parameters, or device comments when "Memory Card (SD)" is specified for the target memory
- Online program change function when "Memory Card (SD)" is specified for the write target.
- Write to PLC function with parameters when "Memory Card (SD)" is specified for the target memory of "Comment File Used in a Command" on the <<PLC File>> tab of PLC parameter.
- Write IC Memory Card function

**5) CPU module locked with security key**

The following operations cannot be performed.

- Backup data creation function of PLC Module Change
- Data restoration function of PLC Module Change
- Write PLC User Data/Read PLC User Data function with latch data backup file created with the Latch Data Backup function

**6) Write to PLC/Read from PLC function**

Writing/reading data to/from a programmable controller CPU may take time depending on a connection route when the security key is set.

**7) Expiration date**

- If the expiration date of the security key registered in a personal computer is expired, a project locked with the corresponding security key cannot be opened.
- To use the same security key after the expiration date, export the security key from the exported personal computer again, and import it to the personal computer.



## 4.12 Protecting POU's in Projects



This section explains how to set a block password to a POU in a project with labels. Setting a block password to a POU disables the access to program content. To access program content, the block password must be unlocked.

The following table shows the POU's to which a block password can be set.

Project type	POU to which a block password can be set
Simple project (without labels)	None
Simple project (with labels)	Function block
Structured project	Program block Function block Function

### Point

- **Effective range of block passwords**

A block password is the function that protects POU's, not execution programs.

To protect execution programs, use the security function or online password function.

For High-speed Universal model QCPU, Universal model process CPU, LCPU and FXCPU, however, whether to protect execution programs with a block password can be selected. (Block password setting Section 4.12.2)

- **Considerations of project with security**

To set/unlock/delete a block password in a project with security, a user who has a security access authority to read/write the program needs to log in. (Security Section 4.10)

- **Reading symbolic information from programmable controller CPU**

Even when the symbolic information is read from a programmable controller CPU, the set status of block password does not change.

- **Considerations when using FXCPU**

A memory cassette to which the execution program with a block password is written can be used on FX3U/FX3UC version 3.00 or later only.


1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

## 4.12.1 Managing (setting/unlocking/deleting) block passwords

Manage the block password setting status of a POU.  
In addition, this function sets/unlocks/deletes a block password.

### Screen display

Select [Tool] ⇒ [Block Password].



### Display contents

Item	Description
POU Name	Display POU's.
Registration Status	Display the status of block password for each POU.

### Screen button

- **Password Setting...**  
Sets a block password to a POU. (☞ Section 4.12.2)
- **Disable Lock...**  
Unlocks the block password set to the POU. (☞ Section 4.12.3)
- **Delete Password**  
Deletes the registered block password. The block password of the POU must be unlocked before deleting it.

### Point

- **Selecting multiple POU's**  
Multiple POU's of "Function Block List" can be selected and the password can be set/disabled in batch. The following is the consideration when the block password settings of selected POU's are different.
  - POU's whose block password is different from the entered password are not unlocked.

## 4.12.2 Setting/changing block passwords

Set a block password to a POU.

### Operating procedure

1. Select a POU to set a block password on the **Block Password** screen and click the **Password Setting...** button.

The **Change Block Password** screen is displayed.



2. Set the items on the screen.

Item	Description
Password	Enter a password in 6 to 32 characters, using alphabets, numerals, and/or symbols corresponding to the ASCII codes ( Appendix 3) of 20H to 7EH. (Alphabets are case-sensitive.)
Re-enter Password	Set the same password again for confirmation.
Execution Program Protection Setting*1	Select this to disable reading execution programs. Programs need to be compiled when selecting or unselecting it in FXCPU.

\*1 : High-speed Universal model QCPU (first 5 digits of the serial number are "19012" or higher), Universal model process CPU (first 5 digits of the serial number are "19012" or higher), LCPU (first 5 digits of the serial number are "18112" or higher) and FXCPU (version 3.00 or later of FX3U and FX3UC) support it.

3. Click the **OK** button.

The block password is set to the selected POU.


Lock of the POU by the block password becomes effective when the project is opened once again.

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

**Point**

● **Display on the Project view**

A POU with a block password is displayed on the Project view as shown below.




● **Changing block passwords**

To change a block password, simply set a new password for the POU to which a block password has already been set. However, the block password must be unlocked before changing it.


### 4.12.3 Unlocking block passwords

Unlock the block password set to a POU.  
The access to the of POU's is enabled by unlocking block passwords.

**Operating procedure**

1. **Select a POU to unlock the block password on the Block Password screen and click the  button.**

The Unlock Block Password screen is displayed.



2. **Set the item on the screen.**

Item	Description
Password	Enter the block password to be unlocked.

3. **Click the  button.**

The block password of the selected POU is unlocked.  
The unlock of the POU by the block password is valid while the project is being opened. To lock the POU again, reopen the project.

## 4.12.4 Considerations for a block password

### ■ Functions restricted in the execution program protection status

A project will be in the execution program protection status by enabling the execution program protection setting when setting a block password.

By writing a project in the execution program protection status, a programmable controller CPU will also be in the same status.

The following shows the functions restricted by High-speed Universal model QCPU, Universal model process CPU, LCPU, and FXCPU in the execution program protection status.

However, the functions can be used by the methods mentioned in "Avoidance of restrictions".

For (Simple) and (Structured) indicated in the Reference column, refer to the following manuals respectively:

(Simple) ... GX Works2 Version 1 Operating Manual (Simple Project)

(Structured) ... GX Works2 Version 1 Operating Manual (Structured Project)

### ● GX Works2 functions

Function name	Limitations	Reference	Avoidance of restrictions
Verify	Unable to display the detailed result of program files.	Section 4.2.7	Verify Source: Unlock* <sup>1</sup> (☞ Section 4.12.3) Verify Destination : ☞ ■ Canceling the execution program protection status of a project
Change PLC Type	Unable to change to the programmable controller type for which the execution program protection setting of a block password is not supported.	Section 4.2.8	☞ ■ Canceling the execution program protection status of a project
Print/Print preview	Unable to print and display the print preview in the device display.	Section 11.5.7 Section 11.5.8	Unlock* <sup>1</sup> (☞ Section 4.12.3)
Write to PLC	Unable to write programs to an SD memory card by using the using the Write to PLC function.	Section 15.1	☞ ■ Canceling the execution program protection status of a project
Verify with PLC	Unable to display the detailed result of program files.	Section 15.2	Verify Source : Unlock* <sup>1</sup> (☞ Section 4.12.3) Verify Destination: ☞ ■ Canceling the execution program protection status of a programmable controller CPU
Online program change	Unable to perform Online program change (during conversion/compilationwith Build) when the protection status (enable or disable) for the execution program protection setting of a block password is set as follows; • Programmable controller CPU: disabled, GX Works2: enabled	Section 15.9.2	
Write IC Memory Card* <sup>2</sup>	Unable to write data to an IC memory card.	Section 15.11.1	☞ ■ Canceling the execution program protection status of a project
Write to IC Memory Card (Edit and Data Copy)* <sup>2</sup>	Unable to write (edit and copy) data to an IC memory card.	Section 15.11.2	
Change TC Setting* <sup>2</sup>	Unable to change TC setting values when the protection status (enable or disable) for the execution program protection setting of a block password is set as follows; • Programmable controller CPU: disabled, GX Works2: enabled	(Simple)	
Device Display/Batch Device Display	Unable to display in the device display and the batch device display.		Unlock* <sup>1</sup> (☞ Section 4.12.3)
Display Compile Result	Unable to display the compilation result.	(Structured)	

\*1 : Unlock all block passwords to which the execution program protection setting was enabled.

\*2 : These functions are not supported by FXCPUs.

● Programmable controller CPU functions


Function name	Limitations	Reference	Avoidance of restrictions
CPU Module Change Function with SD Memory Card	Unable to back up data to an SD memory card. For details on this function, refer to the following manual. ☞ QnUCPU User's Manual (Function Explanation, Program Fundamentals) ☞ MELSEC-L CPU Module User's Manual (Function Explanation, Program Fundamentals)	-	
CPU module data backup/restoration function	Unable to use the data backup function of a CPU module. For details on this function, refer to the following manual. ☞ QnUCPU User's Manual (Function Explanation, Program Fundamentals)	-	
Project data batch save/load function	Unable to save projects in a batch. For details on this function, refer to the following manual. ☞ MELSEC-L CPU Module User's Manual (Function Explanation, Program Fundamentals)	-	
File transfer function (FTP Server)	Unable to execute the following commands to a program file. • get • mget • rename For details on this function, refer to the following manual. ☞ QnUCPU User's Manual (Communication via Built-in Ethernet Port) ☞ MELSEC-L CPU Module User's Manual (Built-In Ethernet Function)	-	☞ ■ Canceling the execution program protection status of a programmable controller CPU
File transfer function (FTP Client)	Unable to execute The SP.FTPPUT instruction to a program file. For details on this function, refer to the following manual. ☞ MELSEC-L CPU Module User's Manual (Built-In Ethernet Function)	-	
File read (Access from a module by using MC protocol)	Unable to execute the following commands from a target device to a program file. • 1824(File Copy) • 1827(File Open) • 1828(File Read) For details on this function, refer to the following manual. ☞ MELSEC Communication Protocol Reference Manual	-	
File access from a GOT	Unable to perform the following functions from a GOT to a program file. • Backup • Circuit monitor • SFC Monitor • Ladder editing For details on this function, refer to the following manual. ☞ Manual for the GOT used	-	

## ■ Canceling the execution program protection status of a project

To cancel the execution program protection status of a project, all of the execution program protection settings need to be disabled.

### Operating procedure

1. Unlock the block password. (👉 Section 4.12.3)
2. Select a POU to disable the execution program protection setting on the **Block Password** screen, and click the **Password Setting...** button.  
The Change **Block Password** screen is displayed.
3. Unselect the checkbox of "Execution Program Protection Setting".
4. Click the **OK** button.




## ■ Canceling the execution program protection status of a programmable controller CPU

To cancel the execution program protection status of a programmable controller CPU, all of the execution program protection settings in it need to be disabled.

### Operating procedure

1. Read all programs from a programmable controller. (👉 Section 15.1)
2. Unlock the block password. (👉 Section 4.12.3)
3. Select a POU to disable the execution program protection setting on the **Block Password** screen, and click the **Password Setting...** button.  
The Change **Block Password** screen is displayed.
4. Unselect the checkbox for "Execution Program Protection Setting".
5. Click the **OK** button.
6. Write all programs to a programmable controller. (👉 Section 15.1)
7. Turn the programmable controller CPU OFF to ON, or reset it.



### ■ Considerations for writing a program to a programmable controller

---

A project including a block password to which the execution program protection setting is enabled needs to be written to a programmable controller after completing the following functions.

If the project is written before completing the following functions, an error occurs in GX Works2 or the programmable controller CPU.

#### ● GX Works2 functions

- Program memory batch transfer
- Online program change
- TC Settings change

#### ● Programmable controller CPU functions

- File access control by security key
- Backing up latch data to standard ROM
- Writing/Reading device data to standard ROM
- PLC module change by the SD memory card (restore)
- CPU module data restoration function
- Project data batch load
- IP address change function
- E-mail address registration/deletion of the E-mail send/receive function (SP.MLOPEADR instruction) (Only when back-up specification is enabled)



## 4.13 Managing Profiles



Manage the registration status of GX Works2 profile (such as CSP+\*1).

Profiles are data in which the connected equipment information (such as module models) is stored. The connected modules are added to the module list on each configuration window by registering profiles. The previously registered connected equipment information is also updated. To register profiles, log on the personal computer as the user having the administrator authority, and close the project in advance.

\*1: For CSP+, refer to the homepage of CC-Link Partner Association ([www.cc-link.org](http://www.cc-link.org)).

### 4.13.1 Registering profiles

#### Operating procedure

1. Select [Tool] ⇒ [Profile Management] ⇒ [Register].

The Register Profile screen is displayed.

2. Select the profile, and click the  button.

The profile is registered.

The added module can be found in the module list on the configuration window when the project is opened next time.

The following is the display of the CC-Link Configuration window.

A CC-Link module  
is added. →



1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES

### Point

#### ● **Managing profiles**

A profile is managed by each personal computer, and shared within GX Works2 and other MELSOFT products. Therefore, a profile registered in GX Works2 is applied to other MELSOFT products.

#### ● **Considerations for registering profiles**

The profiles are the compressed files (such as \*.zip, \*.ipar, and \*.cspp)  
Register profiles without decompressing files.

#### ● **Considerations when using Windows® 7, Windows® 8, or Windows® 8.1**

A profile may not be able to be registered to GX Works2 when using Windows® 7, Windows® 8, or Windows® 8.1. Set the access authority for a login user to the following folders to which the access authority has not been set.

- The folder to which GX Works2 is installed.

Example) C:\Program Files\MELSOFT


If the access authority cannot be changed, right-click the GX Works2 program and select [Run as administrator]. To activate the program from the shortcut menu, open the property of the shortcut menu and select "Run this program as an administrator" under "Privilege Level" on the <<Compatibility>> tab.

## 4.13.2 Deleting profiles

### Operating procedure

1. Select [Tool] ⇒ [Profile Management] ⇒ [Delete].

The Profile Delete screen is displayed.



2. Select the profile to be deleted, and click the **Delete** button.

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES



---

# 5 EDITING PROGRAMS

This chapter explains the functions of the program editors used to edit sequence programs.

5.1	Programming	5 - 2
5.2	Label Programming	5 - 2
5.3	Considerations for Using Label Projects	5 - 4
5.4	Converting/Compiling Projects	5 - 9

## 5.1 Programming



For programming in each project, refer to the following manuals:

- ☞ GX Works2 Version 1 Operating Manual (Simple Project)
- ☞ GX Works2 Version 1 Operating Manual (Structured Project)

## 5.2 Label Programming



Programs can be standardized by using the label programming.

This function is available when a new program is created with the selection of "Use Label".

For projects without labels, the programming can be changed to the label programming by changing the project type. (☞ Section 4.5)

### ■ Features of label programming


- Since device assignment can be changed according to the equipment configuration by creating general-purpose programs with the label programming, the programs with labels can simply be utilized for other programs.
- Programs can be created using labels without knowing the equipment configuration.
- Labels and actual devices are associated as the equipment configuration is determined. This function allows easier creation of execution programs.
- By simply specifying a label assignment method, devices are assigned automatically with the program compilation function without being aware of device names/device numbers.
- Debugging can be performed effectively by monitoring/debugging programs without changing label names.

## ■ Terms used in label programming

The following are the terms used in the label programming.

Project view	Term	Description
	Label project	New projects created with the selection of "Use Label" on the <u>New Project</u> screen. (☞ Section 4.2.1)
	Symbolic information	Data of information such as programs, global labels, and local labels, required for label programming. (☞ Section 15.1.5) These data are restored by writing/reading symbolic information to/from a programmable controller CPU.
	Program	Program data written with applicable programming languages. For label projects, these are data included in symbolic information even when a program is created using devices only.
	Execution program	Programs executed on programmable controller CPUs. Devices are assigned to labels with compilation, and execution programs are created.
	Actual device	Devices assigned to labels after compilation, or devices not written with labels.
	Global label	Labels available for all program data when multiple program data are created in a project.
	Local label	Labels available for each program data only. Labels and each program data are set one to one.
	Device/label automatic-assign setting	A setting of types and ranges of devices assigned to labels. ☞ GX Works2 Version 1 Operating Manual (Simple Project) ☞ GX Works2 Version 1 Operating Manual (Structured Project)
	Compilation	An operation in which programs are converted to execution programs.

The following is an image of writing/reading label project data to/from a programmable controller CPU in GX Works2.



## 5.3 Considerations for Using Label Projects



This section explains the considerations for using label projects.


### 5.3.1 Editing programs

- 1) **Label comments set on the label setting editor are displayed as comments to labels. Comments created on the device comment editor are not displayed.**  
Up to 1024 characters can be set for label comments, however, the number of characters that can be displayed is 32.
- 2) **When the same label is set for global label/local label, the label comment set for local label setting is displayed.**
- 3) **The index setting cannot be set when labels are used. Use actual devices to set the index setting.**

#### ■ Considerations when editing programs

- 1) **When an instruction in which data are stored to multiple word devices is used as shown below, specify an array for the label in the storage destination of operation result.**
  - Division (Storing values such as quotient and remainder of division)
  - Instructions such as the block data transfer instruction (BMOV)

[ Storage example when division is specified with array ]






## 2) When setting arrays, be aware of device types and the number of elements in the data storage destination.

If the setting is incorrect, the content of devices assigned to other labels may be overwritten.

[ Example of incorrect device type setting ]



For the above example, assign 4 words to the label (Value\_A) in the storage destination of operation result.

To assign 4 words, set the following setting on the label setting editor.


Device type: Array (double word) Number of elements: 2

After compilation, the consecutive device ranges for 4 words are secured.

## 3) Do not overlap the device ranges which are stored as execution result of instruction when assigning devices with global labels.

If the setting is incorrect, the content of devices assigned to other labels may be overwritten.

[ Example of incorrect device setting ]



For the above example, assign the device of label (Value\_B) to D104.

## 5.3.2 Writing programs to programmable controller CPU (Write to PLC/Online program change)

### ■ Writing symbolic information

- 1) In order to restore programs by reading symbolic information from the programmable controller CPU, write symbolic information.


Symbolic information can be written by selecting the following item on the execution screen of Write to PLC/Online program change.

- Write to PLC: Symbolic Information
- Online program change: Write Symbolic Information to PLC



Note that symbolic information and execution programs can be written to separate memories. Specify the write destination memory for "Target Memory". The default setting of write destination memory for symbolic information can be changed in the option setting. Set "Setting for Save Destination of Symbolic Information to PLC" under [Tool] ⇒ [Options] ⇒ "Symbolic Information".

< Write to PLC >

Symbolic information and all execution programs are selected when "Symbolic Information" is selected. The program which is consistent with the symbolic information can be written to the programmable controller CPU.



< Online program change >



When the Write to PLC/Online program change operation is performed on execution programs only, program inconsistency occurs. This operation must be performed on both symbolic information and execution programs.

- 2) When writing data to a programmable controller CPU, the confirmation message asking "Do you want to overwrite?" may be displayed as corresponding to the execution programs. The symbolic information will not be written normally if "No" was selected. Perform the data write operation again, and complete the operation normally.

### ■ Writing execution programs only

- 1) When an area to store symbolic information cannot be secured on the programmable controller CPU, write execution programs only.

Projects contain symbolic information must be kept securely on a personal computer.

- 2) Write execution programs without selecting the following item.


- Write to PLC: Symbolic Information
- Online program change: Write Symbolic Information to PLC

### 5.3.3 Reading programs from programmable controller CPU (Read from PLC)

#### ■ Reading symbolic information


- 1) Execute the Read from PLC operation with a label project.
- 2) When reading data from a programmable controller CPU, specify the memory to which the symbolic information is stored for "Target Memory" of symbolic information.
- 3) Do not perform the Read from PLC operation on the symbolic information when the symbolic information and the execution programs on the programmable controller CPU are not consistent.

When the symbolic information is read with program inconsistency, the execution programs which are running on the programmable controller CPU cannot be restored. Check the date of the Write to PLC operation which was performed on the symbolic information and the execution programs, and prevent from performing the Read from PLC operation with program inconsistency. Date of the data write operation can be checked with the column of "Last Change" on the Online Data Operation screen for "Delete PLC Data".



The following are the considerations when symbolic information needs to be read with program inconsistency.

- Create backup data of symbolic information on a personal computer before performing the Read from PLC operation.  
Symbolic information on a personal computer will be overwritten with symbolic information on a programmable controller CPU. To prevent from erasing the latest symbolic information, save the project and create backup data of symbolic information.
- The following message is displayed when the Read from PLC operation is performed with program inconsistency.  
Follow the instruction described in the message.




## ■ Reading execution programs only

---

### 1) Do not read execution programs only.

When only the execution programs needs to be read, read them with a project without labels. The following warning message is displayed when the execution programs created from the symbolic information are read with a project without labels.



## 5.3.4 Verifying programs

---

Symbolic information cannot be verified. The program verification operation can be performed on execution programs only.

## 5.3.5 Monitoring programs

---

Programs created with labels can be monitored.  
Programs with labels registered to the Watch window can be monitored.

## 5.4 Converting/Compiling Projects



This section explains how to convert/compile an edited project to convert it into the code executable on the programmable controller CPU.

The type of conversion/compilation differs according to the project type as shown in the table below.

Project type	Conversion/compilation type	Description
Simple project (without labels)	Build	Fix changes.
	Online Program Change	Fix changes, and simultaneously, write the difference between the fixed programs and the programs stored on the programmable controller CPU to the programmable controller CPU.
	Rebuild All	Convert all programs.
Simple project (with labels)/ Structured project	Build	Convert and compile uncompiled data (programs, structures, labels and functions/function blocks).
	Online Program Change	Convert and compile data, and simultaneously, write the difference between the fixed programs and the programs stored on the programmable controller CPU to the programmable controller CPU.
	Rebuild All	Convert and compile all data (programs, structures, labels and functions/function blocks).

For details, refer to the following manuals:

- ☞ Section 15.9 "Online Program Change"
- ☞ GX Works2 Version 1 Operating Manual (Simple Project)
- ☞ GX Works2 Version 1 Operating Manual (Structured Project)

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES



---

# 6 SETTING PARAMETERS

This chapter explains the setting items, operations on the setting screens, and common notes on parameter settings.  
For necessary information and details of settings, refer to the manuals of each module to be used.


6.1	Setting PLC Parameters	6 - 2
6.2	Setting Redundant Parameters	6 - 36
6.3	Setting Network Parameters	6 - 37
6.4	Setting Remote Password	6 - 74
6.5	Checking Parameters	6 - 76
6.6	Outputting Parameters to CSV Files	6 - 77
6.7	Setting default parameters	6 - 79

## 6.1 Setting PLC Parameters

This section explains how to set PLC parameters.

### Screen display

Select Project view ⇒ "Parameter" ⇒ "PLC Parameter".



### Display contents

Item	Description										
	The setting items are categorized under tabs according to their purpose. <ul style="list-style-type: none"> <li>The parameter setting status is displayed by different font colors of the tab names.</li> </ul>										
Tab	<table border="1"> <thead> <tr> <th>Font color</th> <th>Setting status</th> </tr> </thead> <tbody> <tr> <td>Red</td> <td>Status that data is not set under the tab (Data must be set under the tab for operation.)</td> </tr> <tr> <td>Blue</td> <td>Status that data is set under the tab (A red tab name changes to blue after data is set.)</td> </tr> <tr> <td>Magenta</td> <td>Default values (The user settings are not set under the tab.)</td> </tr> <tr> <td>Dark blue</td> <td>Values other than default values (A magenta tab name changes to dark blue after data is set.)</td> </tr> </tbody> </table>	Font color	Setting status	Red	Status that data is not set under the tab (Data must be set under the tab for operation.)	Blue	Status that data is set under the tab (A red tab name changes to blue after data is set.)	Magenta	Default values (The user settings are not set under the tab.)	Dark blue	Values other than default values (A magenta tab name changes to dark blue after data is set.)
	Font color	Setting status									
	Red	Status that data is not set under the tab (Data must be set under the tab for operation.)									
	Blue	Status that data is set under the tab (A red tab name changes to blue after data is set.)									
	Magenta	Default values (The user settings are not set under the tab.)									
Dark blue	Values other than default values (A magenta tab name changes to dark blue after data is set.)										
	<ul style="list-style-type: none"> <li>Details of the setting items  Section 6.1.1</li> </ul>										



## Screen button

- **Print Window...**  
Executes printing. (☞ Section 11.7)
- **Print Window Preview**  
Executes print preview. (☞ Section 11.9)
- **Acknowledge XY Assignment** **(Not supported by FXCPU)**  
Checks the X/Y setting made on the <<I/O Assignment>> tab of PLC parameter or in the network parameter.
- **Default**  
Resets all setting items on the screen being open to their defaults.
- **Check**  
Checks whether the user-set parameters on the screen being open are correct.

## Point

### ● Considerations when changing PLC parameters

For QCPU (Q mode)/LCPU, all programs need to be compiled when the following PLC parameters are changed.

- "Common Pointer No." and "Timer Limit Setting" on the <<PLC System>> tab
- "File Register" and "File for Local Device" on the <<PLC File>> tab
- Settings on the <<Device>> tab

Compiling all programs changes the device assignment to labels. Therefore, device values set before the program change remain on the device-assigned labels.

Perform the following operations for a precautionary measure.

- For QCPU (Q mode)/LCPU  
After writing data to the programmable controller CPU, reset the programmable controller CPU, clear all device memories including latches, clear all file registers, and switch the programmable controller CPU to RUN.
- For FXCPU  
After writing data to the programmable controller CPU, clear device memory using the PLC memory clear function, and switch the programmable controller CPU to RUN.

(☞ Section 20.4)

For the considerations for compiling all programs, refer to the following manuals.

☞ GX Works2 Version 1 Operating Manual (Simple Project)/(Structured Project)


### ● Function to apply the parameters of MELSOFT Navigator

- When GX Works2 is started up from MELSOFT Navigator, parameters that can be set by MELSOFT Navigator are displayed with green background.
- A parameter set by the function to apply the parameters of MELSOFT Navigator cannot be edited.  
To edit it, select [Tool] ⇒ [Options] ⇒ "IQ Works Interaction" and select "Enable an editing of parameters set in MELSOFT Navigator".

## 6.1.1 PLC parameter item list


**Q CPU** **L CPU** **Remote** **Head** **FX**

The following table shows the applicable PLC parameter items for each programmable controller type. For details of each item, refer to the following manuals.

( User's manuals and programming manuals of each CPU)

○: Applicable –: Not applicable

Setting tab name	Q series				L series		FX series
	Basic model QCPU	High Performance model QCPU/ Process CPU/ Universal model QCPU	Redundant CPU	Remote I/O module	LCPU	Communication head module	FXCPU*1
Communication Head Setting	–	–	–	–	–	○	–
PLC Name	○	○	○	–	○	○	○
PLC System*2	○	○	○	○	○	○	○
PLC File	○	○	○	–	○	–	–
PLC RAS	○	○	○	○	○	○	–
Boot File	○	○*3	○	–	○*4	–	–
Program	–	○	○	–	○	–	–
SFC	○	○	○	–	○	–	–
Device	○	○	○	–	○	–	○
I/O Assignment	○	○	○	○	○	○	–
Multiple CPU Setting	○*5	○*5	–	–	–	–	–
Built-in Ethernet Port Setting	–	○*6	–	–	○*4	–	–
Ethernet Port Setting	–	–	–	–	–	–	○
Built-in I/O Function Setting	–	–	–	–	○	–	–
Serial Communication	○*7	○*8	–	–	–	–	–
Built-in Serial Setting	–	–	–	–	○*9	–	–
Adapter Serial Setting	–	–	–	–	○*4	–	–
Memory Capacity	–	–	–	–	–	–	○
Special Function Block	–	–	–	–	–	–	○
Positioning	–	–	–	–	–	–	○
Operation Setting	–	–	–	○	–	○	–

\*1 : For FXCPU, PLC parameter setting items differ according to the programmable controller type. ( ■ PLC parameter setting items for FXCPU)

\*2 : For FXCPU, PLC System is separated into PLC System (1) and PLC System (2).

\*3 : Not supported by Q00UJ/Q00U/Q01U.

\*4 : Not supported by L02S/L02S-P.

\*5 : Not supported by Q00J/Q00UJ.

\*6 : For Built-in Ethernet port QCPU only

\*7 : For Q00/Q01 only

\*8 : For Q00UJ/Q00U/Q01U/Q02U/QnUD(H)CPU only

\*9 : For L02S/L02S-P only

## ■ PLC parameter setting items for QCPU (Q mode)/LCPU

### 1) PLC Name

Item	Description	Remarks
Label	Set a label (name and application) of the programmable controller CPU.	-
Comment	Set a comment for the label of the programmable controller CPU.	-

### 2) PLC System

Item	Description	Remarks
Timer Limit Setting	Set the time limit of the low-speed/high-speed timer.	-
RUN-PAUSE Contacts	Set the contacts for controlling RUN/PAUSE of the programmable controller CPU. PAUSE contact only setting is not available. (RUN contact only or RUN contact + PAUSE contact setting is available.)	-
Latch Data Backup Operation Valid Contact	Set the contact device for executing a latch data backup operation.	Universal model QCPU/LCPU only
	Set whether to back up all files on the standard RAM when executing a latch data backup operation.	High-speed Universal model QCPU/Universal model process CPU only
Remote Reset	Set whether to allow a remote reset operation from GX Works2.	-
Output Mode at STOP to RUN	Set the status of output (Y) when the programmable controller is switched from STOP to RUN.	-
Floating Point Arithmetic Processing	Set whether to perform floating-point processing in double precision.	High Performance model QCPU only
Intelligent Function Module Setting	Set the interrupt pointer assignment of the module. Set the start I/O number and start SI number of the module.	-
Module Synchronization	Set whether to synchronize the start-up of the programmable controller CPU with that of the intelligent function module.	-
Built-in CC-Link Setting	Set whether to set the built-in CC-Link.	L26-BT/L26-PBT only
Common Pointer No.	Set the start number of the common pointers used in the program.	Not applicable to Basic model QCPU
Points Occupied by Empty Slot	Set the number of points occupied by empty slots for the main base unit/extension base unit/block.	-
System Interrupt Settings	Set the start number of the interrupt counters. Set the execution interval for the interrupt pointers.	-
	Set the fixed scan interval for high-speed interrupt pointers, high-speed I/O refresh, and high-speed buffer transfer.	High Performance model QCPU/High-speed Universal model QCPU/Universal model process CPU only
Interrupt Program/Fixed Scan Program Setting	Set whether to perform high-speed execution of an interrupt program.	-
A-PLC Compatibility Setting	Set whether to use the MELSEC-A series special relays/special registers (SM1000/SD1000 to SM1299/SD1299).	Not applicable to Basic model QCPU/Redundant CPU
Service Processing Setting	Set the processing time and the number of times of service processing.	Universal model QCPU/LCPU only
PLC Module Change Setting	Set this to replace the CPU module using a memory card.	Universal model QCPU/LCPU (except for L02S/L02S-P) only

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

## 3) PLC File

Item	Description	Remarks
File Register	Set the file register file to be used in the program.	–
	Set whether to transfer data to the standard ROM when executing a latch data backup operation.	Universal model QCPU (except for High-speed Universal model QCPU and Universal model process CPU)/LCPU only
Comment File Used in a Command	Set the device comment file to be used in the program.	Not applicable to Basic model QCPU
Initial Device Value	Set the device initial value file to be used on the programmable controller CPU.	–
File for Local Device	Set the local device file to be used in the program.	Not applicable to Basic model QCPU
File used for SP.DEVST/S.DEVLD Instruction	Set the device data ROM write/read instruction file to be used in the program.	Universal model QCPU/LCPU only

## 4) PLC RAS

Item	Description	Remarks
WDT (Watchdog Timer) Setting	Set the WDT of the programmable controller CPU.	–
	Set the WDT for an initial execution type program.	–
	Set the WDT for a low-speed execution type program.	High Performance model QCPU only
Error Check	Set whether to detect specified errors.	–
Operating Mode When There is an Error	Set the programmable controller CPU operation mode when an error is detected.	–
Operation History	Set whether to save the operation history of a CPU module.	High-speed Universal model QCPU/Universal model process CPU only* <sup>1</sup>
Constant Scanning	Set the constant scan time.	–
Error History	Set the storage destination for error histories of the programmable controller CPU.	High Performance model QCPU only
Low Speed Program Execution Time	Set the execution time of a low-speed program in every scan.	High Performance model QCPU only
Module Error History Collection (Intelligent Function Module)	Set whether to collect the error history of the intelligent function module.	Universal model QCPU/LCPU only
Memory Check	Set whether to check the memory of the program.	Process CPU/Redundant CPU only

\*1 : A CPU module whose function version is B and first five digits of the serial number are "19062" or higher.

## 5) Boot File

Item	Description	Remarks
Boot Option	Set whether to clear the program memory when booting up.	Not applicable to Basic model QCPU
	Set whether to write data in the memory card automatically to the standard ROM when booting up.	Not applicable to Basic model QCPU
Boot File Setting	Set the type, data name, transfer source drive, and transfer destination drive of the boot file.	Not applicable to Basic model QCPU
	Set whether to boot up with the standard ROM.	Basic model QCPU only

## 6) Program

Item	Description	Remarks
Program	Set the file name and execution type (executing condition) for programs when several programs are written to the programmable controller CPU. Set the fixed scan interval (the execution interval of a fixed scan execution type program).	Not applicable to Basic model QCPU
File Usability Setting button	Display the <u>File Usability Setting</u> screen.	Not applicable to Basic model QCPU
I/O Refresh Setting button	Display the <u>I/O Refresh Setting</u> screen.	High Performance model QCPU only

## 7) SFC

Item	Description	Remarks
SFC Program Start Mode	Set the start-up mode of an SFC program.	-
Start Conditions	Set the start-up condition of an SFC program.	-
Output Mode When the Block is Stopped	Set the SFC program output mode at block stop.	-

1

OVERVIEW

2

SYSTEM CONFIGURATION

3

SCREEN CONFIGURATION AND BASIC OPERATIONS

4

PROJECT MANAGEMENT

5

EDITING PROGRAMS

6

SETTING PARAMETERS

7

SETTING DEVICE MEMORY

8

SETTING DEVICE INITIAL VALUES

## 8) Device

Item	Description	Remarks
Disable device write from external	Set whether to prohibit device writing from an external device.	High-speed Universal model QCPU/Universal model process CPU only*1
Device Points	Set the number of points used for each device of the programmable controller CPU.	–
Latch (1) Start/End	Set the latch range (start device number/end device number) clearable with the RESET/L.CLR switch or a remote latch clear operation.	–
Latch (2) Start/End	Set the latch range (start device number/end device number) not clearable with the RESET/L.CLR switch or a remote latch clear operation.	–
Local Device Start/End	Set the range (start device number/end device number) of devices used as a local device.	–
Write Protection Start/End	Set a device range to prohibit device writing from an external device (start device No./end device No.).	High-speed Universal model QCPU/Universal model process CPU only*1
File Register Extended Setting	Set the extended data register and extended link register.	Universal model QCPU/LCPU only
Indexing Setting for Device*2	Set the start number of Z to be 32-bit indexed, or use the index register ZZ for 32-bit index setting.	Universal model QCPU/LCPU only
Latch Interval Setting	Set the device latch interval to be performed by the set interval or by each scan.	High-speed Universal model QCPU/Universal model process CPU only
Pointer Extended Setting for Automatic-Assign Device	Set whether to use the pointer extended setting. When using the pointer extended setting, set the extended points.	LCPU (L06/L06-P/L26/L26-P/L26-BT/L26-PBT) only

\*1 : A CPU module whose function version is B and first five digits of the serial number are "19062" or higher.

\*2 : "Indexing Setting for ZR Device" is displayed for programmable controller CPUs other than high-speed universal model QCPUs and universal model process CPUs.

## 9) I/O Assignment

Item	Description	Remarks
I/O Assignment	Set the type, model, number of occupied I/O points, and start I/O number of each module mounted on the base unit/block.	–
	Set the switch settings of the programmable controller CPU.	Universal model QCPU/LCPU only
	Set the switch settings of the intelligent function module.	–
Base Setting	Set the model and the number of slots of the base unit, the model of the power supply module, and the model of the extension cable.	Not applicable to LCPU

## 10) Multiple CPU Setting

Item	Description	Remarks
No. of PLC	Set the number of programmable controller CPUs used in the multiple CPU system.	-
Operation Mode	Set the operation mode of the multiple CPU system when a stop error occurs in any of the programmable controller CPU No. 2 to No. 4. The multiple CPU system stops when a stop error occurs in the CPU No. 1.	
Host Station	Set the CPU number for the host CPU.	Universal model QCPU (excluding Q00UJ/Q00U/Q01U/Q02U) only
Multiple CPU Synchronous Startup Setting	Select the CPU modules to be started up synchronously.	
Online Module Change	Set whether to allow Online module change in the multiple CPU system.	Not applicable to Q00U/Q01U/Q02U
I/O Sharing When Using Multiple CPUs	Set whether to retrieve the I/O status of the I/O module or intelligent function module controlled by other programmable controller CPUs.	-
Communication Area Setting (Refresh Setting)	Set the CPU shared memory to enable data sharing among multiple CPUs. (Usable devices: B, M, Y, D, W, R, and ZR)	-
Multiple CPU High Speed Transmission Area Setting	Set the user setting area, auto refresh, assignment confirmation, and system area.	Universal model QCPU (excluding Q00U/Q01U/Q02U) only

1

OVERVIEW

2

SYSTEM CONFIGURATION

3

SCREEN CONFIGURATION AND BASIC OPERATIONS

4

PROJECT MANAGEMENT

5

EDITING PROGRAMS

6

SETTING PARAMETERS

7

SETTING DEVICE MEMORY

8

SETTING DEVICE INITIAL VALUES

## 11) Built-in Ethernet Port Setting

Item	Description	Remarks
IP Address Setting	Set the IP address and the input format of the IP address.	Ethernet Built-in CPU only
Communication Data Code	Select the Binary code or ASCII code for communication.	
Open Setting button/ Ethernet Conf. button	Set the protocol, open system, and host station port number. • For High-speed Universal model QCPU/Universal model process CPU/LCPU (except for L02S/L02S-P) When selecting "Set Open Setting in Ethernet Configuration window", the Open Setting button is switched to the Ethernet Conf. button. Set the communication settings to the Ethernet device on the Ethernet Configuration window. The equipment configuration is displayed graphically.	
FTP Setting button	Select whether to use the FTP function.	
FTP Client Setting button	Set a login name, password, and FTP server connection target settings (FTP server name, FTP server address).	LCPU (except for L02S/L02S-P) only
E-mail Setting button	Set a password, e-mail address, and mail server name.	
DNS Setting button	Set the address of DNS server.	
Time Setting button	Set whether to use the SNTP function, and set the timing of setting the time.	Ethernet Built-in CPU only
MELSOFT Connection Extended Setting button	Set whether to use the MELSOFT Connection Extended function, and set a network number and a station number when using it.	High-speed Universal model QCPU/Universal model process CPU only
CC-Link IEF Basic Setting button	Set whether to use CC-Link IE Field Network Basic, and set the network configuration setting and the refresh setting.	High-speed Universal model QCPU/Universal model process CPU/ Ethernet Built-in LCPU only
Disable Using Port Setting	Set whether to disable using each port.	High-speed Universal model QCPU*2/ Universal model process CPU*2 only
Simple PLC Communication Setting	Set the communication pattern and the communication settings.	High-speed Universal model QCPU*1/ Universal model process CPU*1/ Ethernet Built-in LCPU*3 only
IP Packet Transfer Setting	Set whether to use the IP Packet Transfer function.	Universal model QCPU (except for Q00UJ/Q00U/Q01U/Q02U)/ LCPU (except for L02S/L02S-P) only

\*1 : Modules with function version B and the first five digits of the serial number are '20042' or higher are supported.

\*2 : Modules with function version B and the first five digits of the serial number are '24082' or higher are supported.

\*3 : Modules with a serial number whose first five digits are '13042' or higher are supported.



**12) Built-in I/O Function Setting**

Item	Description	Remarks
Positioning	Set the parameters of the positioning axis 1 setting and positioning axis 2 setting.	LCPU only
High-speed Counter	Set the operation mode of high-speed counter CH1 setting and high-speed counter CH2 setting.	
Input Signal	Set the input signal function, input response time, and interrupt processing condition.	
Output Signal	Select the output signal function and error time output mode.	

**13) Serial Communication**

Item	Description	Remarks
Transmission Speed	Set the transmission speed.	-
Sum Check	Set the sum check.	
Transmission Wait Time	Set the transmission wait time.	
Online Change	Set whether to allow Online program change.	

**14) Built-in Serial Setting**

Item	Description	Remarks
Select Function	Select the function to be used.	-
Transmission Setting	Set the transmission setting of the communication protocol.	
Communication Speed Setting	Set the communication speed.	
Serial Communication Function	Set the transmission wait time and online change.	
Predefined Protocol Support Function	Set the start device which stores the operation status of the communication protocol.	

**15) Adapter Serial Setting**

Item	Description	Remarks
Adapter Type	Select the adapter type to be used.	-
Select Function	Select the function to be used.	
Transmission Setting	Set the transmission setting of the communication protocol.	
Communication Speed Setting	Set the communication speed.	
Station No. Setting (0 -- 31)	Set the station number for multi-drop connection.	
Serial Communication Function	Set the transmission wait time and online change.	
Predefined Protocol Support Function	Set the start device which stores the operation status of the communication protocol.	

1

OVERVIEW

2

SYSTEM CONFIGURATION

3

SCREEN CONFIGURATION AND BASIC OPERATIONS

4

PROJECT MANAGEMENT

5

EDITING PROGRAMS

6

SETTING PARAMETERS

7

SETTING DEVICE MEMORY

8

SETTING DEVICE INITIAL VALUES

## ■ PLC parameter setting items for communication head module

### 1) Communication Head Setting

Item	Description	Remarks
CC-Link IE Field Network Setting	Set the operation mode of the network.	CC IE Field head module only
	Set the network number of the module.	
	Set the station number of the module.	
	Set whether to hold (store) the error history and system error history on a flash ROM at power OFF or reset.	
SSCNET III/H Network Setting	Set the operation mode of the network.	SSCNET III/H head module only
	Set whether to hold (store) the error history and system error history on a flash ROM at power OFF or reset.	

### 2) PLC Name

Item	Description	Remarks
Label	Set a label (name and application) of the programmable controller CPU.	-
Comment	Set a comment for the label of the programmable controller CPU.	

### 3) PLC System

Item	Description	Remarks
Remote Reset	Set whether to allow a remote reset operation from GX Works2.	-

### 4) PLC RAS

Item	Description	Remarks
Module Error History Collection (Intelligent Function Module)	Set whether to collect the error history of the intelligent function module.	-

### 5) Operation Setting

Item	Description	Remarks
Assignment Method	Select the assignment method of devices to be transferred.	-
Forwarding Parameter between Devices	Set transmission source devices and transmission destination devices.	

### 6) I/O Assignment

Item	Description	Remarks
I/O Assignment	Set the type, model, number of occupied I/O points, and start I/O number of each module mounted on the base unit.	-
	Set the switch settings of the programmable controller CPU.	
	Set the switch settings of the intelligent function module.	

## ■ PLC parameter setting items for remote I/O module

### 1) PLC system

Item	Description	Remarks
Module Synchronization	Set whether to synchronize the start-up of the programmable controller CPU with that of the intelligent function module.	-
Points Occupied by Empty Slot	Set the number of points occupied by empty slots for the main base unit/extension base unit.	-

### 2) PLC RAS

Item	Description	Remarks
Error Check	Set whether to detect specified errors.	-
Operating Mode When There is an Error	Set the programmable controller CPU operation mode when an error is detected.	-

### 3) Operation Setting

Item	Description	Remarks
Assignment Method	Select the assignment method of devices to be transferred.	-
Forwarding Parameter between Devices	Set transmission source devices and transmission destination devices.	

### 4) I/O Assignment

Item	Description	Remarks
I/O Assignment	Set the type, model, number of occupied I/O points, and start I/O number of each module mounted on the base unit.	-
	Set the switch settings of the programmable controller CPU.	
	Set the switch settings of the intelligent function module.	
Base Setting	Set the model and the number of slots of the base unit, the model of the power supply module, and the model of the extension cable.	-


1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

**Point**

● **Utilizing existing data to set parameters of multiple CPU**


Parameters for multiple CPU can be set by utilizing existing data by clicking the **Import Multiple CPU Parameter** button on the <<I/O Assignment>>/<<Multiple CPU Setting>> tab.

Specify the project to be utilized, read the message, and then execute the function.




● **Reading mounting status of programmable controller CPU**

The mounting status of the programmable controller CPU can be read and overwritten to the current parameters by clicking the **Read PLC Data** button on the <<I/O Assignment>> tab. Read the message and execute the function.



● **"Indexing Setting for ZR Device" on the <<Device>> tab.**

When "Use ZZ" is set for the 32-bit index setting, the ZZ device cannot be used or monitored independently in the program.




To confirm the current value of the ZZ device, specify Z and set the display format to 32-bit integer, on the Device/Buffer Memory Batch Monitor screen.

● **Program settings**


Executing conditions set in the program setting of the PLC parameter are applied to "Program Setting" on the Project view. Program settings can also be set on the Project view.

For details of program setting on the Project view, refer to Section 4.2.1

<Setting screen for PLC parameter>



<Project view>



Execution types set in the Program can be confirmed.

## ■ PLC parameter setting items for FXCPU

For FXCPU, PLC parameter setting items differ according to the programmable controller type.

### 1) PLC Name

Item	Description	Remarks
Title	Set a program title to be stored on the programmable controller CPU.	FX1, FX0N, FX1S, FX1N, FXU, FX2N, FX3S, FX3G, FX3U, FX1NC, FX2C, FX2NC, FX3GC, and FX3UC only

### 2) PLC System (1)

Item	Description	Remarks
Battery Less Mode	Set this to operate the programmable controller CPU without the memory backup battery.	FX2N, FX3U, FX2NC, and FX3UC only
Battery Mode	Set this to operate the programmable controller CPU with the memory backup battery.	FX3G and FX3GC only
MODEM Initialized	Select the modem initialization command for the remote access to the programmable controller CPU.	FX1S, FX1N, FX2N, FX3S, FX3G, FX3U, FX1NC, FX2NC, FX3GC, and FX3UC only
RUN Terminal Input	Select the input number to use the input (X) of the programmable controller CPU as the external RUN/STOP terminal.	FX1S, FX1N, FX2N, FX3S, FX3G, FX3U, FX1NC, FX2NC, FX3GC, and FX3UC only

### 3) PLC System (2)

Item	Description	Remarks
Channel selection	Select a channel to be the connection target. Applicable to FX3G, FX3GC, FX3U, and FX3UC only.	FX1S, FX1N, FX2N, FX3S, FX3G, FX3GC, FX3U, FX1NC, FX2NC, and FX3UC only
Operate Communication Setting	Set whether to enable the communication setting.	
Protocol*1	Select the communication protocol.	
Data Length*1	Select the data length.	
Parity*1	Select the parity.	
Stop Bit*1	Select the stop bit.	
Transmission Speed*1	Select the transmission speed.	
Header*1	Set the header.	
Terminator*1	Set this to enable the terminator.	
Control Line*1	Set this to enable the control line.	
H/W Type*1	Select the cable type used in the communication.	
Control Mode	Display the control mode.	
Sum Check*1	Set this to add the sum check.	
Transmission Control Procedure*1	Select the transmission control procedure.	
Station Number Setting*1	Set the station number.	
Time Out Judge Time*1	Set the timeout period.	

\*1 : Not applicable when "Operate Communication Setting" is OFF.

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

4) Device

Item	Description	Remarks
Device	Set the latch range.	FX1, FXU, FX2N, FX3U, FX2C, FX2NC, and FX3UC only

5) Memory Capacity

Item	Description	Remarks
Memory Capacity*1	Select the memory capacity of the programmable controller CPU. Not applicable to FX0, FX0s, FX0N, and FX1s.	FX0S, FX0, FX1, FX0N, FX1S, FX1N, FXU, FX2N, FX3S, FX3G, FX3U, FX1NC, FX2C, FX2NC, FX3GC, and FX3UC only
Symbolic Information Capacity*2	<ul style="list-style-type: none"> <li>Display the symbolic information capacity of a built-in memory based on the setting value of the memory capacity.</li> <li>Display the symbolic information capacity of a memory cassette by clicking the <b>Check Other Items</b> button.</li> </ul>	FX3U and FX3UC only
Comments Capacity	Set the comment capacity. Not applicable to FX0 and FX0s.	
File Register Capacity	Set the file register capacity. Not applicable to FX0, FX0s, and FX1.	FX0S, FX0, FX1, FX0N, FX1S, FX1N, FXU, FX2N, FX3S, FX3G, FX3U, FX1NC, FX2C, FX2NC, FX3GC, and FX3UC only
Program Capacity	Display the capacity for sequence programs.	
Special Function Memory Capacity	Set whether to use the Special Function Block Settings, Positioning Instruction Settings, and Built-in CC-Link/LT. Applicable to FX3G, FX3GC, FX3U, and FX3UC only.	

\*1 : When the symbolic information is saved in a built-in memory or a memory cassette, the symbolic information is deleted by changing the memory capacity and writing the parameters. In this case, write the symbolic information again.

\*2 : This item is not printed with the batch print function or the print window function.

6) Special Function Memory Capacity

Item	Description	Remarks
Special Function Block	Set the initial value of special extension modules/blocks. Set the Built-in CC-Link/LT Setting.	FX3U and FX3UC only
	Special Function Block Settings   Set the initial value of BFM.	
Positioning	<ul style="list-style-type: none"> <li>Set the bias speed, max. speed, creep speed, zero return speed, acceleration time, deceleration time, and interruption input of DVIT instruction for each axis.</li> <li>Set the details of the positioning table for each axis.</li> </ul>	FX3G, FX3U, FX3GC, and FX3UC only

## 7) Ethernet Port Setting

Item	Description	Remarks
Channel	Select whether to connect the Ethernet port, and if the port is connected, select a channel. Only FX3G, FX3GC, FX3U, and FX3UC can be set.	FX3S, FX3G, FX3U, FX3GC, and FX3UC only
IP Address Setting*1	Set the IP address and the input format of the IP address.	
Communication Data Code	Select the Binary code or ASCII code for communication.	
Disable direct connection to MELSOFT	Set whether to disable the direct connection with MELSOFT.	
Do not respond to search for CPU on network	Disable to respond to the Find CPU function of MELSOFT Connection.	
Open Setting button	Set the protocol, open system, and host station port number.	
Time Setting button	Set whether to use the SNTP function, and set the timing of setting the time.	
Log Record Setting button	Set the storage location for error logs on the <a href="#">Log Record Setting</a> screen.	

\*1 : The IP address can be set not only on PLC parameter settings but also with the IP address change function. In this case, the settings of IP address change function will be given priority.

 FX3U-ENET-ADP User's Manual

1

OVERVIEW

2

SYSTEM CONFIGURATION

3

SCREEN CONFIGURATION AND BASIC OPERATIONS

4

PROJECT MANAGEMENT

5

EDITING PROGRAMS

6

SETTING PARAMETERS

7

SETTING DEVICE MEMORY

8

SETTING DEVICE INITIAL VALUES


## 6.1.2 Checking duplications of X/Y assignment among parameters

Q CPU L CPU Remote Head FX

Check duplications of X/Y assignment among parameters.

### Screen display

Select Project view ⇒ "Parameter" ⇒ "PLC Parameter" ⇒ Acknowledge XY Assignment .




### Display contents

Item	Description										
XY No.	Display the I/O number.										
Type	Display the content set in the network parameter. n: Slot number of the module (excluding Ethernet)										
	<table border="1"> <thead> <tr> <th>Display on Network column</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>PLC network/CC IE (Slot n)</td> <td>MELSECNET, CC-Link IE</td> </tr> <tr> <td>Remote I/O Net (Slot n)</td> <td>MELSECNET/H (Remote Master)</td> </tr> <tr> <td>CC-Link (Slot n)</td> <td>CC-Link</td> </tr> <tr> <td>Blank</td> <td>Not set.</td> </tr> </tbody> </table>	Display on Network column	Description	PLC network/CC IE (Slot n)	MELSECNET, CC-Link IE	Remote I/O Net (Slot n)	MELSECNET/H (Remote Master)	CC-Link (Slot n)	CC-Link	Blank	Not set.
	Display on Network column	Description									
	PLC network/CC IE (Slot n)	MELSECNET, CC-Link IE									
	Remote I/O Net (Slot n)	MELSECNET/H (Remote Master)									
CC-Link (Slot n)	CC-Link										
Blank	Not set.										
I/O Assignment	Display whether the I/O assignment setting is set in the PLC parameter.										
	<table border="1"> <thead> <tr> <th>Display on I/O Assignment column</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>I/O Assignment</td> <td>I/O assignment is set.</td> </tr> <tr> <td>Blank</td> <td>I/O assignment is not set.</td> </tr> </tbody> </table>	Display on I/O Assignment column	Description	I/O Assignment	I/O assignment is set.	Blank	I/O assignment is not set.				
Display on I/O Assignment column	Description										
I/O Assignment	I/O assignment is set.										
Blank	I/O assignment is not set.										
Slot	Display the slot, module type, number of occupied I/O points, and model name when the I/O assignment setting is set in the PLC parameter.										
Module Type	Display the I/O assignment status as shown in the table below when the I/O assignment setting in the PLC parameter is not set and X/Y devices are assigned in the network parameter.										
Points											
Model Name	<table border="1"> <thead> <tr> <th>Item</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>"Slot" to "Points"</td> <td>Assignment of X devices</td> </tr> <tr> <td>"Model Name"</td> <td>Assignment of Y devices</td> </tr> </tbody> </table>	Item	Description	"Slot" to "Points"	Assignment of X devices	"Model Name"	Assignment of Y devices				
	Item	Description									
"Slot" to "Points"	Assignment of X devices										
"Model Name"	Assignment of Y devices										
Duplication	Display the module in which the first duplication is detected by parameter check.										
	<table border="1"> <thead> <tr> <th>Display on Duplication column</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>MNET/CC IE (Slot 1) to MNET/CC IE (Slot 16)</td> <td>Network parameter of MELSECNET or CC-Link IE (slot 1 to slot 16)</td> </tr> <tr> <td>CC-Link</td> <td>CC-Link remote I/O</td> </tr> </tbody> </table>	Display on Duplication column	Description	MNET/CC IE (Slot 1) to MNET/CC IE (Slot 16)	Network parameter of MELSECNET or CC-Link IE (slot 1 to slot 16)	CC-Link	CC-Link remote I/O				
Display on Duplication column	Description										
MNET/CC IE (Slot 1) to MNET/CC IE (Slot 16)	Network parameter of MELSECNET or CC-Link IE (slot 1 to slot 16)										
CC-Link	CC-Link remote I/O										



## Screen button

-  Export to CSV File

Writes data on the Acknowledge XY Assignment screen to a CSV file. (  Section 6.6)

## Point

- **When a setting screen other than PLC parameter setting screen is being opened**

When the MELSECNET/CC IE/Ethernet Module Configuration screen or the CC-Link Module Configuration screen is displayed, since the setting is not completed, set data of the previous setting are checked for duplications.

- **Priority in the parameter check**

The following table shows the priority in when GX Works2 checks the parameter settings.

Priority	Display
1	I/O assignment
2	MELSECNET or CC-Link IE Controller Network (slot 16) network refresh parameter
3	MELSECNET or CC-Link IE Controller Network (slot 15) network refresh parameter
.	.
.	.
17	MELSECNET or CC-Link IE Controller Network (slot 1) network refresh parameter
18	CC-Link remote I/O

- **Refresh devices which are not displayed**

Due to network specifications, the number of refresh devices which are set to the following stations in the CC-Link parameter cannot be recognized in GX Works2. Therefore, they are not displayed on the Acknowledge XY Assignment screen.

- Local station
- Sub-master station

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

### 6.1.3 Setting open setting on Ethernet Configuration window



\*1 : High-speed Universal model QCPU and Universal model process CPU only

\*2 : Not supported by L02S and L02S-P.


Set the equipment configuration of Ethernet by dragging and dropping from the module list. Select "Set Open Setting in Ethernet Configuration window" on the <<Built-in Ethernet Port Setting>> tab of PLC parameter in advance.

For the online operations on the Ethernet Configuration window, refer to the following manual.

iQ Sensor Solution Reference Manual

#### Screen display

Project view ⇒ "Parameter" ⇒ "PLC parameter" ⇒ <<Built-in Ethernet Port Setting>> ⇒ Click the **Ethernet Conf.** button.




## Operating procedure

1. Select an Ethernet device from the module list, and drag and drop it to the 'list of devices' or 'device map area'.

An Ethernet device is added to the 'list of devices'.

The added Ethernet device is displayed on the 'device map area'.



2. Set the items on the screen.

Item	Description
No.	Display the connection number.
Model Name	Display the model name of Ethernet device.
Communication Method	This setting is not required for QCPUs (Q mode), LCPUs, head modules, remote I/O modules, and FXCPUs.
Protocol	Set the protocol for the open setting.
Fixed Buffer Send/Receive Setting	This setting is not required for QCPUs (Q mode), LCPUs, head modules, remote I/O modules, and FXCPUs.
PLC	–
IP Address	The IP address of the host station specified on the <<Built-in Ethernet Port Setting>> tab of PLC parameter is displayed.
Port No.	Set the port number of the host station set to open setting.
Sensor/Device	–
MAC Address	A blank is displayed. The MAC address is displayed when the configuration is detected by executing the automatic detection of connected devices.
Host Name	Set the host name of Ethernet device.
IP Address	Set the IP address of Ethernet device.
Port No.	Set the port number of Ethernet device.
Sub-net Mask	Set the subnet mask of Ethernet device.
Default Gateway	Set the default gateway of Ethernet device.
Existence Confirmation	This setting is not required for QCPUs (Q mode), LCPUs, head modules, remote I/O modules, and FXCPUs.

3. Select [Close with Reflecting the Setting].

Exit the settings of the Ethernet Configuration window.

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT


5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY


8 SETTING DEVICE INITIAL VALUES

### Screen button



Detect the actual system configuration automatically and apply it to the Ethernet Configuration window. (Automatic detection of connected devices)

For operations and considerations for setting "device map area" by executing the automatic detection of connected devices, refer to the following manual.

 [iQ Sensor Solution Reference Manual](#)



Moves the position of the Ethernet device selected in the 'list of devices' up/down.

### Point

#### ● Corrective actions when profiles do not match

When displaying a configuration window, an error message may appear if the following two profiles do not match:

- Profile of a device used in a project
- Profile of a device registered in GX Works2

In this case, contact the manufacturer of the device for the profile that corresponds to "File Version" and "Device Version" displayed on the Output window.

An error can be cleared by restarting GX Works2 after registering an obtained profile to GX Works2.

## ■ Considerations when the selected status of "Set Open Setting in Ethernet Configuration window" is changed

The following are the considerations when editing open setting by changing selected/cleared status.

### ● Selecting the item

The open setting set on the Built-in Ethernet Port Open Setting screen is applied on the Ethernet Configuration window automatically.

- The connections to which the open system is set are displayed as general-purpose Ethernet modules on the Ethernet Configuration window.
- The open system unset connection numbers are not applied to the Ethernet Configuration window, and the remaining connection numbers are moved forward to the location of the unset number. Therefore, when the connection number is specified in the program, add the number of general-purpose Ethernet modules which are moved forward so as to not shift the already set existing connection number.
- When the parameter is set on the Ethernet Configuration window, the file size of parameter to be written to the programmable controller CPU increases.

### ● Clearing the item

The open setting set on the Ethernet Configuration window is applied on the Built-in Ethernet Port Open Setting screen automatically.

- For iQSS-compatible devices, the open system is changed to MC protocol, and only the protocol and port number of the programmable controller are set to Built-in Ethernet Port Open Setting screen.

## ■ Considerations for setting of the "IP Address" column of "PLC" on 'list of devices'

The following are the considerations when setting the "IP Address" column of "PLC" of 'list of devices' on the Ethernet Configuration window.

### ● When the IP address on the <<Built-in Ethernet Port Setting>> tab is changed

When the IP address of the host station is changed on the <<Built-in Ethernet Port Setting>> tab of PLC parameter after setting the parameter on the Ethernet Configuration window, the IP address does not match between the host station and the programmable controller CPU.

In this case, open the Ethernet Configuration window.

The "IP Address" column of "PLC" is changed to the IP address that has been set on the <<Built-in Ethernet Port Setting>> tab.

### ● When the automatic detection of connected devices is executed

When setting the configuration of the iQSS-compatible device by executing the automatic detection of connected devices, the detected IP address is set to the "IP Address" column of "PLC". If the iQSS-compatible device has been communicated with other programmable controller CPU, the different IP address as the host station is set.

In this case, set the same IP address on the "IP Address" column of "PLC" as the one set on the <<Built-in Ethernet Port Setting>> tab.

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES


## ■ Replacing general SLMP module

Replace a general SLMP module with a specific Ethernet device.

### Operating procedure

1. Select the general SLMP module to be replaced in the 'list of devices' on the Ethernet Configuration window.
2. Select [Ethernet Configuration] ⇒ [Change Module] ⇒ [Replace General SLMP Module].

The Replace General SLMP Module screen is displayed.




3. Set the items on the screen.

Item	Description
Replacement Target	–
List of modules to be replaced	The general SLMP modules placed on the 'list of devices' are displayed. Select the check box(es) on the "No." column of the general SLMP module to be replaced. Two or more devices can be selected.
Replacement Candidate	Select the Ethernet device to be replaced with.

#### 4. Click the **Replace** button.

The general SLMP module in the 'list of devices' is replaced with the Ethernet device selected for "Replacement Candidate". Also, the general SLMP module displayed on the 'device map area' is replaced with the Ethernet device selected for "Replacement Candidate".



The general SLMP module is replaced to the selected Ethernet device.

#### Screen button

- **Select All**  
Selects all devices displayed on "Replacement Target".
- **Cancel All Selections**  
Cancels the selected status of all devices selected for "Replacement Target".

#### ■ Changing to general SLMP module

Change an Ethernet device to a general SLMP module.

#### Operating procedure

1. Select an Ethernet device to be changed in the 'list of devices' on the Ethernet Configuration window.
2. Select [Ethernet Configuration] ⇒ [Change Module] ⇒ [Change to General SLMP Module].  
The Ethernet device is changed to the general SLMP module.

#### ■ Checking system configuration of Ethernet

Check whether the equipment configuration of Ethernet is correct after setting the open setting on the Ethernet Configuration window.

#### Operating procedure

- Select [Ethernet Configuration] ⇒ [Check] ⇒ [System Configuration].  
The system configuration of Ethernet is checked.  
Check the result of the system configuration check on the Output window.

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

## ■ Copying/pasting Ethernet devices

Copy/paste a selected Ethernet device.

### Operating procedure

1. Select "No." or "Model Name" of the Ethernet device to be copied from the 'list of devices'.

The corresponding row is selected.

Select "No." or "Model Name"

	No.	Model Name	Communication Method	Protocol	Fixed Buffer Send/Receive Setting	PLC	
						IP Address	Port No.
		Host Station				192.168.3.39	
	1	MELSOFT Connection Module		TCP		192.168.3.39	
	2	SLMP Connection Module		TCP		192.168.3.39	1025
	3	UDP Connection Module		UDP		192.168.3.39	1031
	4	SLMP Connection Module		TCP		192.168.3.39	1026
	5	SLMP Connection Module		TCP		192.168.3.39	1030

2. Select [Edit] ⇒ [Copy].

The selected Ethernet device is copied.

3. Select [Edit] ⇒ [Paste].

The copied Ethernet device is added to the last row of the 'list of devices'.

## ■ Deleting Ethernet devices

Delete a selected Ethernet device.

### Operating procedure

1. Select "No." or "Model Name" of the Ethernet device to be deleted from the 'list of devices'.

The corresponding row is selected.

Select "No." or "Model Name"

	No.	Model Name	Communication Method	Protocol	Fixed Buffer Send/Receive Setting	PLC	
						IP Address	Port No.
		Host Station				192.168.3.39	
	1	MELSOFT Connection Module		TCP		192.168.3.39	
	2	SLMP Connection Module		TCP		192.168.3.39	1025
	3	UDP Connection Module		UDP		192.168.3.39	1031
	4	SLMP Connection Module		TCP		192.168.3.39	1026
	5	SLMP Connection Module		TCP		192.168.3.39	1030

2. Select [Edit] ⇒ [Delete].

The selected Ethernet device is deleted.



## ■ Displaying/hiding Module List/Output window


Display/hide the Module List/Output window.

### Operating procedure

- Select [View] ⇒ [Docking Window] ⇒ [Module List]/[Output].

#### Point

#### ● Displaying Module List/Output window

The Module List/Output window can be displayed as a docked display/floating display.  
( Section 3.2.4 "Docking windows")

1  
OVERVIEW2  
SYSTEM  
CONFIGURATION3  
SCREEN  
CONFIGURATION AND  
BASIC OPERATIONS4  
PROJECT  
MANAGEMENT5  
EDITING  
PROGRAMS6  
SETTING  
PARAMETERS7  
SETTING DEVICE  
MEMORY8  
SETTING DEVICE  
INITIAL VALUES

## 6.1.4 Setting the station information in the CC-Link IEF Basic configuration window



\*1 : High-speed Universal model QCPU and Universal model process CPU only


\*2 : Built-in Ethernet port LCPU only

Set the station information and the equipment configuration of CC-Link IE Field Network Basic.

### Operating procedure

1. Select Project view ⇒ "Parameter" ⇒ "PLC parameter" ⇒ <<Built-in Ethernet Port Setting>>
2. Set the IP address, the subnet mask pattern, and the default router IP address in "IP Address Setting".
3. Click the **CC-Link IEF Basic Setting** button and select "Use the CC-Link IEF Basic" on the **CC-Link IEF Basic Setting** screen.
4. Click the **Network Configuration Setting** button.


The CC-Link IEF Basic Configuration window is displayed.



## 5. Select the module from the module list, and drag and drop it to the 'list of stations' or 'device map area'.

The remote station (CC-Link IEF Basic module) is added to the 'list of stations'.

The added module is displayed on the 'device map area'.



## 6. Set the items on the screen.

Item	Description
Connected Count	Display the number of remote stations controlled by the master station (programmable controller CPU).
List of stations	Display a station on CC-Link IE Field Network Basic in a list format.
No.	"0" is displayed for master station, and 'remote station number' is displayed for remote station.
Model Name	Display the model name of the master station/remote station. When the module information does not exist, "Module With No Profile Found" is displayed.
STA#	"0" is displayed for master station, and a number between 1 to 16 is displayed for a remote station.
Station Type	Display the station type of the master station/remote station.
RX/Ry Setting	Display the points of RX/Ry, the start device number, and the end device number. Click the cell and select the number of occupied stations*1 displayed by clicking ▾.
RWw/RWr Setting	Display the points of RWw/RWr, the start device number, and the end device number.
Group No.	Set the group number.
RSVD STA	Display the setting status of a reserved station for a remote station. Click the cell and change the setting displayed by clicking ▾.
IP Address	Set the IP address of a remote station.
Subnet Mask	Set the subnet mask of a remote station.
MAC Address	The MAC address is displayed when the configuration is detected by executing the automatic detection of connected devices.
Comment	Display the information set to comment 1 on the Property screen.
Device map area	Display the equipment configuration of CC-Link IEF Basic graphically.

\*1 : The number of points used differs depending on the number of occupied stations.

- 1 station: RX/Ry 64 points, RWw/RWr 32 points
- 2 stations: RX/Ry 128 points, RWw/RWr 64 points
- 3 stations: RX/Ry 192 points, RWw/RWr 96 points
- 4 stations: RX/Ry 256 points, RWw/RWr 128 points

## 7. Click [Close with Reflecting the Setting].

Exit the settings on the CC-Link IEF Basic Configuration window.


### Screen button




Detect the actual system configuration automatically and apply it to the CC-Link IEF Basic Configuration window. (Automatic detection of connected devices)

For operations and considerations for setting "device map area" by executing the automatic detection of connected devices, refer to the following manual.

 CC-Link IE Field Network Basic Reference Manual



Sets some items on the Link Scan Setting screen. ( ■ Setting the link scan setting)





Moves the position of the module selected in the 'list of stations' up/down.

### Point

- **Setting for a CC-Link IEF Basic connected module**

When a non-Mitsubishi device or a device which is not displayed on the module list is used, drag and drop a CC-Link IEF Basic connected module.

A CC-Link IEF Basic connected module can be replaced with a specific module by registering a profile.

( Section 4.13.1) ( ■ Replacing a CC-Link IEF Basic connected module)

- **Display of a module name on the 'device map area'**

"Object Name" on the Properties screen is displayed for each module name on the 'device map area'.

- **Corrective actions when profiles do not match**

For details, refer to Point in Section 6.1.3.


## ■ Replacing a CC-Link IEF Basic connected module

Replace a CC-Link IEF Basic module with another one.

### Operating procedure

1. Select a CC-Link IEF Basic connected module to be replaced in the 'list of stations' on the CC-Link IEF Basic configuration window.
2. Select [CC-Link IEF Basic Configuration] ⇒ [Change Module] ⇒ [Replace CC-Link IEF Basic Connected Module].

The Replace CC-Link IEF Basic Connected Module screen is displayed.



3. Set the items on the screen.

Item	Description
Replacement Target	Display the station type and the points for the RX/RV setting of the module selected on the CC-Link IEF Basic configuration window.
List of modules to be replaced	Display modules with the same condition as the one selected for "Replacement Target". Select the checkbox(es) on the "Station No." column of the module to be replaced. Two or more modules can be selected.
Replacement Candidate	Select a module to be replaced with.

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS


6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES

#### 4. Click the **Replace** button.

The CC-Link IEF Basic connected module in the list of stations is replaced with the module selected for "Replacement Candidate". The CC-Link IEF Basic connected module displayed on the 'device map area' is replaced with the module selected for "Replacement Candidate".



The CC-Link IEF Basic connected module is replaced to the selected device.

### Screen button

● **Select All**

Selects all devices displayed on "Replacement Target".

● **Cancel All Selections**

Cancels the selected status of all devices selected for "Replacement Target".

### ■ Changing to a CC-Link IEF Basic connected module

Change a module of a remote station to a CC-Link IEF Basic connected module.

### Operating procedure


1. Select a module to be changed in the 'list of stations' on the CC-Link IEF Basic configuration window.
2. Select [CC-Link IEF Basic Configuration] ⇒ [Change Module] ⇒ [Change to CC-Link IEF Basic Connected Module].


The module is changed to the CC-Link IEF Basic connected module.

## ■ Setting the link scan setting

Set the time out time and the number of retries to detect the disconnection of a remote station.


### Screen display

Click the  button on the CC-Link IEF Basic Configuration window.



### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Remote Station Disconnect Detected Setting	—
Time-out Period (10 to 65535)	Set the timeout time for remote station disconnection detection.
Counts	Set the number of retries for remote station disconnection detection. Click the cell and change the setting by clicking  .
Remote Station Disconnect Detected Image Diagram Display	The operation image regarding the remote station disconnection detection period is displayed. Refer to this at the setting of "Time-out Period".

#### 2. Click the button.

The settings are applied to the CC-Link IEF Basic Configuration window.

## ■ Checking system configuration of CC-Link IEF Basic

Check whether the equipment configuration of CC-Link IEF Basic is correct after setting the station information on the CC-Link IEF Basic Configuration window.

### Operating procedure

- **Select [CC-Link IEF Basic Configuration] ⇒ [Check] ⇒ [System Configuration].**

The system configuration of CC-Link IEF Basic is checked.

Check the result of the system configuration check on the Output window.

## ■ Copying/pasting modules

Copy/paste a selected module.

### Operating procedure

#### 1. Select "No." or "Model Name" of the module to be copied on the 'list of stations'.

The corresponding row is selected.

Select "No." or "Model Name" →

	No.	Model Name	STA#	Station Type	RX/Ry Setting			RWw/RWr Setting		
					Points	Start	End	Points	Start	End
	0	Host Station	0	Master Station						
	1	CC-Link IEF Basic Module	1	Remote Station	64 (1 Occupied Station)	0000	003F	32	0000	001F
	2	CC-Link IEF Basic Module	2	Remote Station	64 (1 Occupied Station)	0040	007F	32	0020	003F
	3	CC-Link IEF Basic Module	3	Remote Station	64 (1 Occupied Station)	0080	00BF	32	0040	005F
	4	CC-Link IEF Basic Module	4	Remote Station	64 (1 Occupied Station)	00C0	00FF	32	0060	007F
	5	CC-Link IEF Basic Module	5	Remote Station	64 (1 Occupied Station)	0100	013F	32	0080	009F

#### 2. Select [Edit] ⇒ [Copy].

The selected module is copied.

#### 3. Select [Edit] ⇒ [Paste].

The copied module is added to the last row of the 'list of stations'.

## ■ Deleting module

Delete a selected module.

### Operating procedure

#### 1. Select "No." or "Model Name" of the module to be deleted on the 'list of stations'.

The corresponding row is selected.

Select "No." or "Model Name" →

	No.	Model Name	STA#	Station Type	RX/Ry Setting			RWw/RWr Setting		
					Points	Start	End	Points	Start	End
	0	Host Station	0	Master Station						
	1	CC-Link IEF Basic Module	1	Remote Station	64 (1 Occupied Station)	0000	003F	32	0000	001F
	2	CC-Link IEF Basic Module	2	Remote Station	64 (1 Occupied Station)	0040	007F	32	0020	003F
	3	CC-Link IEF Basic Module	3	Remote Station	64 (1 Occupied Station)	0080	00BF	32	0040	005F
	4	CC-Link IEF Basic Module	4	Remote Station	64 (1 Occupied Station)	00C0	00FF	32	0060	007F
	5	CC-Link IEF Basic Module	5	Remote Station	64 (1 Occupied Station)	0100	013F	32	0080	009F

#### 2. Select [Edit] ⇒ [Delete].

The selected module is deleted.



## ■ Displaying/hiding Module List/Output window

Display/hide the Module List/Output window.

### Operating procedure

- Select [View] ⇒ [Docking Window] ⇒ [Module List]/[Output].

#### Point

#### ● Displaying Module List/Output window

The Module List/Output window can be displayed as a docked display/floating display.  
(☞ Section 3.2.4 "Docking windows")

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

## 6.2 Setting Redundant Parameters




\*1 : Redundant CPU only

This section explains how to set redundant parameters.

### Screen display

Select Project view ⇒ "Parameter" ⇒ "Redundant Parameters".



### Screen button

For the screen buttons, refer to Section 6.1.

## ■ Redundant parameter setting items

### 1) Operation mode setting

Item	Description
Start Mode Setting	Set the device status when the system is powered ON or reset.
Standby System Watch Setting	Set whether to check errors on the standby system. If an error occurs, the error can be checked with the PLC diagnostics function.
Debug Mode Setting	Set whether to start an operation in the debug mode.
Backup Mode Setting	Set whether to check the operating status consistency.

### 2) Tracking setting

Item	Description
Tracking Device Setting	Select a setting method for the tracking device.
Tracking Characteristics Setting	Set the tracking transfer mode.

## 6.3 Setting Network Parameters

This section explains how to set the network parameters.

Only the parameter settings of the following network are supported for LCPU and FXCPU.

LCPU : CC-Link IE Field Network, Ethernet, and CC-Link


FXCPU: CC-Link

### ■ Ethernet/CC-Link IE/MELSECNET parameter setting

#### Screen display

Select Project view ⇒ "Parameter" ⇒ "Network Parameter" ⇒ "Ethernet/CC IE/MELSECNET"/"CC IE Field" .

The screen below is a screen for MELSECNET/CC-Link IE/Ethernet module configuration.



#### Screen button

- **Interlink Transmission Parameters** (Not supported by LCPU)

Displays the Interlink Transmission Parameters screen.

- **Acknowledge XY Assignment**


Checks the I/O assignment setting set in the PLC parameter and the status of X/Y devices assigned in the network parameter. (☞ Section 6.1.2)

- **Routing Parameters**

Displays the Routing Information screen.

- **Assignment Image**

Displays the Assignment Image screen of the refresh parameters.




- **Group setting...** (Redundant CPU only)  
Displays the Group Setting screen.
- **Clear**  
Deletes the set parameters.
- **Check**  
Checks whether the set parameters are correct.
- **Print Window...**  
Executes printing. (☞ Section 11.7)
- **Print Window Preview**  
Executes print preview. (☞ Section 11.9)

## ■ CC-Link parameter setting

### Screen display

Select Project view ⇒ "Parameter" ⇒ "Network Parameter" ⇒ "CC-Link".

The following is an example of setting screen when QCPU (Q mode) is selected.



### Screen button

- **Print Window...**  
Executes printing. (☞ Section 11.7)
- **Print Window Preview**  
Executes print preview. (☞ Section 11.9)
- **Acknowledge XY Assignment** (Not supported by FXCPU)  
Displays the details of the I/O assignment settings. (☞ Section 6.1)
- **Clear**  
Deletes the set parameters.
- **Check**  
Checks whether the set parameters are correct.

### Point

- **Function to apply the parameters of MELSOFT Navigator**
  - Parameter items which can be set from MELSOFT Navigator are displayed in green when GX Works2 is started from MELSOFT Navigator.
  - Parameters which are set by the function to apply the parameters of MELSOFT Navigator cannot be edited. To edit, select "Enable an editing of parameters set in MELSOFT Navigator" under [Tool] ⇒ [Options] ⇒ "iQ Works Interaction".
- **Number of columns displayed on the CC-Link Module Configuration screen (QCPU (Q mode)/LCPU only)**  
A number of columns can be changed by selecting 4 or 2 columns for "Display number of columns for CC-Link list setting" under [Tool] ⇒ [Options] ⇒ "Parameter".

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES


### 6.3.1 Network parameter item list

Q CPU L CPU Remote Head<sup>\*1</sup> FX

\*1 : CC IE Field head module only

The following table shows the applicable network parameter types for each programmable controller type.

For details of each item, refer to the following manuals.

( User's manuals and reference manuals of each module)

○: Applicable –: Not applicable

Network type	Q series				L series		FX series
	Basic model QCPU	High Performance model QCPU/ Process CPU/ Redundant CPU	Universal model QCPU	Remote I/O module	LCPU	CC IE Field head module	FXCPU
CC-Link IE Controller Network <sup>*1</sup>	○	○	○	–	–	–	–
CC-Link IE Field Network	–	–	○	–	○	–	–
MELSECNET/10	○	○	○	–	–	–	–
MELSECNET/H	○	○	○	–	–	–	–
MELSECNET/H Remote I/O	–	○	○	–	–	–	–
Ethernet	○	○	○	○	○	–	–
CC-Link	○	○	○	○	○	○	○ <sup>*2</sup>

\*1 : CC-Link IE Controller Network modules with the function version D and a serial number whose first 5 digits are '10041' or higher are supported.  
For Process CPU and Redundant CPU, CC-Link IE Controller Network modules with a serial number whose first five digits are '10042' or higher is required.

\*2 : Supported by FX3G, FX3GC, FX3U, and FX3UC only.

## ■ CC-Link IE setting

Item		Description
Network Type		Specify the network type (CC-Link IE) whose parameters are to be set.
Start I/O No.		Set the start I/O number.
Network No.		Set the network number.
Total (Linked) Stations		Set the total number of (linked) stations.
Group No.*1		Set the group number.
Station No.		Set the station number of a module.
Mode		Set the mode.
Network Range Assignment/ Network Configuration Settings (Common parameters)	Specify I/O Master Station*1	Set the I/O master station.
	Specify Reserved Station*1	Specify the reserved station.
	Equal Assignment	Assign the number of link device points of all stations equally.
	Identical Point Assignment	Assign the equal number of link device points based on the total number of set stations.
	Help-Network Setting*1	Display the condition to assure 32-bit data.
	Shared Group Setting*2	Set the shared group of the group cyclic function.
	Supplementary Setting	Set the link scan mode setting, loopback function setting, block data assurance per station, and operation setting for returning.
Network Operation Settings*3		Set the parameter name, data link faulty station setting, output setting during CPU STOP, IP address setting, and other settings.
Refresh Parameters		Set refresh parameters.
Interrupt Settings		Set the device code, detection method, interrupt condition, interrupt (SI) number, and other settings.
Specification method for station number		Set whether to set a station number by program or by parameter. The station number can be specified by program only when the normal station or the local station is selected in a project for Universal model QCPU/LCPU.
Operate with parameter of host/master station*4		Set whether to operate link device points and assignments of the device station with the parameter set on the host station or the parameter set on the master station. This item can be set for sub-master station only.
Redundant Setting		Set the system B mode.

\*1 : For CC-Link IE Controller Network only

\*2 : For CC-Link IE Controller Network of Universal model QCPU only

\*3 : For CC-Link IE Controller Network of Universal model QCPU (except for Q00UJ/Q00U/Q01U/Q02U), IP address setting only

\*4 : For CC-Link IE Field Network only

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

## ■ MELSECNET/10 and MELSECNET/H setting

Item		Description
Network Type		Specify the network type (MELSECNET/10 mode or MELSECNET/H mode) whose parameters are to be set.
Start I/O No.		Set the start I/O number.
Network No.		Set the network number.
Total (Linked) Stations		Set the total number of (linked) stations.
Group No.		Set the group number.
Mode		Set the mode.
Network Range Assignment (Common parameters)	Specify I/O Master Station	Set the I/O master station.
	Specify Reserved Station	Specify the reserved station.
	Equal Assignment	Assign the number of link device points of all stations equally.
	Identical Point Assignment	Assign the equal number of link device points based on the total number of set stations.
	Help-Network Setting* <sup>1</sup>	Display the condition to assure 32-bit data.
	Supplementary Setting	Set the transient setting, low-speed cyclic setting, and other settings.
	Station Inherent Parameters	Set station inherent parameters.
Refresh Parameters		Set refresh parameters.
Interrupt Settings		Set the device code, detection method, interrupt condition, interrupt (SI) number, and other settings.
Operation at reconnection* <sup>1</sup>		Set whether to operate the station as a control station or a normal station when the line is reconnected.
Baud Rate Setting* <sup>1</sup>		Set the baud rate on modules that support the twist bus.
Redundant Setting		Set the system B mode.

\*1 : For MELSECNET/H (control station) and MELSECNET/H extended mode (control station) only



## ■ MELSECNET/H Remote I/O setting

Item		Description
Network Type		Set "MELSECNET/H (remote master)".
Start I/O No.		Set the start I/O number.
Network No.		Set the network number.
Total (Linked) Stations		Set the total number of (linked) stations.
Mode		Set the mode.
Network Range Assignment (Common parameters)	Specify Reserved Station	Specify the reserved station.
	Equal Assignment	Assign the number of link device points of all stations equally.
	Supplementary Setting	Set the constant scan time and the maximum number of return stations in one link scan.
Refresh Parameters		Set refresh parameters.
Interrupt Settings		Set the device code, detection method, interrupt condition, interrupt (SI) number, and other settings.
Redundant Setting		Set the system B mode.

## ■ Ethernet setting

Item		Description
Network Type		Specify "Ethernet".
Start I/O No.		Set the start I/O number.
Network No.		Set the network number.
Group No.		Set the group number.
Station No.		Set the station number.
Mode		Set the mode.
Operation Setting		Set the common items for the module.
Initial Setting		<ul style="list-style-type: none"> <li>Set data communication timer values.</li> <li>Set IP addresses for DNS servers.</li> </ul>
Open Setting		Set parameters required for the open processing.
Router Relay Parameter		Set parameters for the router relay function of Ethernet.
Station No. ↔ IP Information		Set information to link network number and station number with IP address for communication target station or relay station when communicating with another station programmable controller CPU via Ethernet.
FTP Parameters*1		Set FTP parameters such as the login name, password, command input monitoring timer, and PLC monitoring timer.
E-mail Setting*1	General Setting	Set the password, e-mail address, and inquiry interval for receiving mails.
	Mail Server Name	Set the SMTP server, POP server, and IP addresses for both servers.
	Send Mail Address Setting	Set addresses of send mail.
	News Setting	Set the notifying condition.
Interrupt Settings*1		Set the device code, detection method, interrupt condition, interrupt (SI) number, and other settings.
Redundant Setting*2		Set the system B, system switching settings when communication error occurs, and other settings.

\*1 : Not supported by remote I/O module.

\*2 : The redundant setting cannot be set when "Ethernet (Extension Base)" is selected. (Different IP addresses cannot be assigned to each system.)

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

## ■ QCPU (Q mode)/LCPU CC-Link setting

Item	Description
Number of Modules	Set the number of CC-Link master/local modules.
Set the station information in the CC-Link configuration window	Select this to set station information on the CC-Link Configuration window.
Start I/O No.	Set the start I/O number.
Operation Setting	Set the Parameter Name, Data Link Faulty Station Setting, Case of CPU Stop Setting, Number of Occupied Stations, Expanded Cyclic Setting, Block Data Assurance per Station, and Auto Detect Setting of the Connected Device.
Type	Set the station type such as a master/local/standby master station.
Station No.*1	Set the station number.
Master Station Data Link Type	The setting is fixed to "PLC Parameter Auto Start" for the master station.
Mode	Set the mode.
Transmission Speed*1	Set the transmission speed.
Total Module Connected	Set the total number of remote stations, local stations, intelligent device stations, and/or standby master stations connected to the master station.
Remote Input (RX)	Set the devices to refresh the data of RX, RY, RWr, and RWw.
Remote Output (RY)	
Remote Register (RWr)	
Remote Register (RWw)	
Ver.2 Remote Input (RX)	Set the devices to refresh the data of RX, RY, RWr, and RWw for the remote network additional mode.
Ver.2 Remote Output (RY)	
Ver.2 Remote Register (RWr)	
Ver.2 Remote Register (RWw)	
Special Relay (SB)	Set the devices to refresh the data of SB and SW.
Special Register (SW)	
Retry Count	Set the number of retries in case a communication error occurs.
Automatic Reconnection Station Count	Set the number of remote stations, local stations, intelligent device stations, and/or standby master stations that can be returned to the system in one link scan.
Standby Master Station No.	Specify the station number of the standby master station.
PLC Down Select	Specify the data link status when an error occurs on the programmable controller CPU on the master station.
Scan Mode Setting	Specify whether to synchronize the link scan with the sequence scan.
Delay Time Setting	Set the link scan interval delay time.
Station Information Setting/ CC-Link Configuration Setting*2	<p>The setting screen and the setting items differ according to the selected/cleared status of "Set the station information in the CC-Link configuration window".</p> <ul style="list-style-type: none"> <li>• Cleared Set station information on the <u>CC-Link Station Information</u> screen. Set the settings such as the station type and the number of occupied stations. A number of rows can be changed by selecting 16 or 8 rows for "Display number of rows for CC-Link station information" under [Tool] ⇒ [Options] ⇒ "Parameter".</li> <li>• Selected Set station information on the CC-Link Configuration window. In addition to the setting items on the <u>CC-Link Station Information</u> screen, settings such as the module type are set. The equipment configuration is displayed graphically.</li> </ul>
Remote Device Station Initial Setting	Set the target station number and procedure registration (such as operating condition and executing condition).
Interrupt Settings*3	Set the device code, detection method, interrupt condition, interrupt (SI) number, and other settings.

\*1 : For LCPU and CC IE Field head module only.

\*2 : With the station information set on the CC-Link Configuration window, only the corresponding setting items on the CC-Link Station Information screen are printed when executing the batch print or print window function. The equipment configuration on the CC-Link Configuration window is not printed.

\*3 : Not supported by CC IE Field head module and remote I/O module.

## ■ FXCPU CC-Link setting

This parameter setting is supported by FX3G, FX3GC, FX3U, and FX3UC only.

Item	Description
Connection Block	Select "Set" to set a CC-Link master block.
Special Function Block No.	Specify the special function block number (0 to 7).
Operation Setting	Set the Parameter Name, Data Link Disorder Station, and Case of CPU Stop Setting.
Type	This setting is fixed to "Master Station" when "Set" is selected for "Connection Block".
Master Station Data Link Type	This setting is fixed to "PLC Parameter Auto Start" when "Set" is selected for "Connection Block".
Mode	Set the mode.
Total Module Connected	Set the total number of remote I/O stations, remote device stations, and/or intelligent device stations (including reserve stations) connected to the master station.
Retry Count	Set the number of retries in case a communication error occurs.
Automatic Reconnection Station Count	Set the number of remote I/O stations, remote device stations, and/or intelligent device stations that can be returned to the system in one link scan.
PLC Down Select	Specify the data link status when an error occurs on the programmable controller CPU on the master station.
Station Information Setting	Set the station type, exclusive counts, and other settings. A number of rows can be changed by selecting 16 or 8 rows for "Display number of rows for CC-Link station information" under [Tool] ⇒ [Options] ⇒ "Parameter".
Remote Device Station Initial Setting	Set the target station number and procedure registration (such as operating condition and executing condition).

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

### 6.3.2 Setting station information on CC IE Field Configuration window




Network configuration and equipment configuration of CC-Link IE Field Network can be set when "CC IE Field (Master Station)", "CC IE Field (Sub-Master Station)", or "CC IE Field (Motion Master Station)" is set in the CC-Link IE Field Network parameter.

Select "Set the network configuration setting in the CC IE Field Configuration window" on the MELSECNET/CC-Link IE/Ethernet Module Configuration screen in advance.

#### Screen display

Click the **CC IE Field Configuration Setting** button on the MELSECNET/CC-Link IE/Ethernet Module Configuration screen.




#### Operating procedure





1. Select the module from the module list, and drag and drop it to the 'list of stations' or 'device map area'.

The device station is added to the 'list of stations'.

The added module is displayed on the 'device map area'.



## 2. Set the items on the screen.

Item	Description
Mode Setting	Select the mode by clicking  .
Assignment Method	Specify the assignment method by clicking  .
Link Scan Time (Approx.)	Display the approximate value of link scan time.
List of stations	Display the list of stations which configure CC-Link IE Field Network.
No.	"0" is displayed for master station, and 'device station number' is displayed for device station.
Model Name	Display the module type of master station/device station. When the module information does not exist, "Module without profile" is displayed. Set this item after registering the profile.
STA#	"0" is displayed for master station, and a number between 1 to 120 is displayed for a device station.
Station Type	Display the station type of master station/device station. Click the cell and select the station type displayed by clicking  .
RX/Ry Setting	Set the RX/Ry assignment for each device station. Set RX/Ry in 16-point unit.
RWw/RWr Setting	Set the RWw/RWr assignment for each device station. Set RWw/RWr in 4-point unit.
Refresh Device	Display devices of the CPU module to which link devices of master/local module are link-refreshed. This item is displayed only when the refresh parameter is set.
Reserved/Error Invalid Station	Display the setting status of reserved station/error invalid station for device station. Click the cell and change the setting by clicking  .
Alias	Display the device name.
Comment	Display the information set to comment 1 on the <a href="#">Property</a> screen.
Station-specific mode setting	Display the station-specific mode of the module.
Device map area	Display the equipment configuration of CC-Link IE Field Network graphically.


## 3. Select [CC IE Field Configuration] ⇒ [Close with Reflecting the Setting].

Exit the settings of the CC IE Field Configuration window.

### Screen button



Moves the position of the module selected in the 'list of stations' up/down. The station number does not change even when the position of the module is moved.



Detect the actual system configuration automatically and apply it to the CC IE Field Configuration window. (Automatic detection of connected devices)

For operations and considerations of setting station information and equipment configuration with the automatic detection of connected devices, refer to the following manual.

 [iQ Sensor Solution Reference Manual](#)

\*1 : Supported by the following CPU modules.

- High-speed Universal model QCPUs (function version is B and the first five digits of the serial number are '17052' or higher)
- Universal model process CPUs (function version is B and the first five digits of the serial number are '17052' or higher)
- LCPUs

1

OVERVIEW

2

SYSTEM CONFIGURATION

3

SCREEN CONFIGURATION AND BASIC OPERATIONS

4

PROJECT MANAGEMENT

5

EDITING PROGRAMS

6

SETTING PARAMETERS

7

SETTING DEVICE MEMORY

8

SETTING DEVICE INITIAL VALUES

● **Verify** \*1

Read the station information and equipment configuration from the actual system configuration, and verify with the CC IE Field configuration currently displayed in GX Works2.

For the procedure for verifying system configuration with a connected device and its considerations, refer to the following manual.

 iQ Sensor Solution Reference Manual

\*1: Supported by the following CPU modules.

- High-speed Universal model QCPUs (function version is B and the first five digits of the serial number are '17052' or higher)
- Universal model process CPUs (function version is B and the first five digits of the serial number are '17052' or higher)

**Point** 

● **Considerations when the selected status of "Set the network configuration setting in the CC IE Field configuration window" is changed**

The following are the considerations when editing the network configuration by changing selected/cleared status.

- Selecting the item

The network configuration of "CC IE Field (Master Station)" or "CC IE Field (Sub-Master Station)" set on the MELSECNET/CC-Link IE/Ethernet Module Configuration screen is set on the CC IE Field Configuration window automatically.

Note that, all modules of the network configuration are changed to general-purpose CC IE Field modules. The file size of parameter to be written to the programmable controller CPU increases.



- Clearing the item

The network configuration set on the CC IE Field Configuration window is set on the MELSECNET/CC-Link IE/Ethernet Module Configuration screen automatically.

● **Setting general-purpose CC IE Field modules**

When a non-Mitsubishi module or a module which is not displayed on the module list is used, drag and drop a general-purpose CC IE Field module.

A general-purpose CC IE Field module can be replaced with a specific module by registering a profile.

( Section 4.13.1), ( ■ Replacing general-purpose CC IE Field module)

● **Display of module name on the 'device map area'**

"Object Name" on the Properties screen is displayed for each module name on the 'device map area'.

● **Corrective actions when profiles do not match**

For details, refer to Point in Section 6.1.3.


## ■ Replacing general-purpose CC IE Field module

Replace a general-purpose CC IE Field module of device station with a specific module.

### Operating procedure

1. Select the general-purpose CC IE Field module to be replaced in the 'list of stations' on the CC IE Field Configuration window.
2. Select [CC IE Field Configuration] ⇒ [Change Module] ⇒ [Replace General CC IE Field Module].

The Replace General CC IE Field Module screen is displayed.




3. Set the items on the screen.

Item	Description
Replacement Target	–
Station Type	Display the station type selected on the CC IE Field Configuration window.
List of modules to be replaced	Display modules with the same condition as the one selected for "Replacement Target". Select the check box(es) on the "STA#" column of the module to be replaced. Two or more modules can be selected.
Replacement Candidate	Select the module to be replaced with.
Replace the object name of replacement target module to the model name selected in replacement candidate	Click the checkbox when replacing the object name of a replacement target module to the model name selected from "Replacement Candidate".

4. Click the **Replace** button.

The general-purpose CC IE Field module in the list of stations is replaced with the module selected for "Replacement Candidate".

The general-purpose CC IE Field module displayed on the 'device map area' is replaced with the module selected for "Replacement Candidate".



The general-purpose module is replaced with the selected module.

**Screen button**

**Select All**

Selects all modules displayed on "Replacement Target".

**Cancel All Selections**

Cancels the selected status of all modules selected for "Replacement Target".

**Replacing to general-purpose CC IE Field module**

Replace a module of device station to a general-purpose CC IE Field module.

**Operating procedure**

1. Select a module to be replaced in the 'list of stations' on the CC IE Field Configuration window.
2. Select [CC IE Field Configuration] ⇒ [Change Module] ⇒ [Change to General CC IE Field Module].  
The module is changed to the corresponding general-purpose CC IE Field module.

**Changing transmission path method**

Change the transmission path method to line/star or ring.

**Operating procedure**

- Select [CC IE Field Configuration] ⇒ [Change Transmission Path Method] ⇒ [Line/Star]/[Ring].  
The transmission path method is changed to the selected transmission path method.

**Point**

- **Transmission path method and loopback function setting**  
The change of transmission path method and the loopback function setting on the CC IE Field Supplementary Setting screen are linked.  
When line/star is selected, the loopback function setting is disabled.  
When ring is selected, the loopback function setting is enabled.



## ■ Setting supplementary functions

Set the link scan mode setting, loopback function setting, block data assurance per station, and operation setting for returning.

### Operating procedure

#### 1. Select [CC-IE Field Configuration] ⇒ [Supplementary Setting].

The CC IE Field Supplementary Setting screen is displayed.

#### 2. Set the items on the screen.

Item	Description
Link Scan Mode Setting	Set the link scan mode.
Loopback Function Setting	Set whether to use the loopback function. Select this item when the transmission path method is ring.
Block Data Assurance per Station	Set whether to assure block data per station for link refreshes between the CPU module and the master/local module. Select this when including a remote device station in the network configuration.
Operation Setting for Returning	Set whether to operate the station as a master station or a sub-master station when the station is reconnected.

#### 3. Click the button.

The settings are applied to the CC IE Field Configuration window.

### Point

#### ● Transmission path method and loopback function setting

The change of transmission path method and the loopback function setting on the CC IE Field Supplementary Setting screen are linked.

When "Use" is cleared for the loopback function setting, line/start is selected for the setting under [CC IE Field Configuration] ⇒ [Change Transmission Path Method].

When "Use" is selected for the loopback function setting, ring is selected for the setting under [CC IE Field Configuration] ⇒ [Change Transmission Path Method].

## ■ Assigning link devices equally

Assign link device points of all stations equally.

### Operating procedure

#### 1. Select [CC IE Field Configuration] ⇒ [Equal Assignment].

The Equal Assignment screen is displayed.

#### 2. Set the items on the screen.

Item	Description
RX/Ry Equal Assignment	–
Start Station	Set the start station number to be assigned equally.
End Station	Set the last station number to be assigned equally.
Start No.	Set the start number of the link device to be assigned equally.
Total Points Assigned	Set the total number of link device points to be assigned equally.
RWw/RWr Equal Assignment	–
Start Station	Set the start station number to be assigned equally.
End Station	Set the last station number to be assigned equally.
Start No.	Set the start number of the link device to be assigned equally.
Total Points Assigned	Set the total number of link device points to be assigned equally.

#### 3. Click the button.

Link devices are assigned equally to the device stations within the set range.

## ■ Assigning the equal number of link device points


Assign the equal number of link device points based on the total number of set stations.

### Operating procedure

1. Select [CC IE Field Configuration] ⇒ [Identical Point Assignment].

The Identical Point Assignment screen is displayed.

2. Enter the number of points to be assigned.

3. Click the  button.

The equal number of points is assigned per stations.

## ■ Reassigning link devices

Assign the device numbers continuously in the link device of the specified target station. The current assigned points are used for the link device points.

### Operating procedure

1. Select [CC IE Field Configuration] ⇒ [Device No. Reassignment].

The Device No. Reassignment screen is displayed.

## 2. Set the items on the screen.

Item	Description
Target Station	–
Start Station	Set the start station number to start the assignment.
End Station	Set the last station number to end the assignment.
RX/Ry Setting	–
Start No.	Set the start device number of RX/Ry to start the assignment.
RWw/RWr Setting	–
Start No.	Set the start device number of RWw/RWr to start the assignment.

## 3. Click the button.

Device numbers are assigned continuously for the stations in the set range.

### Point

- **When selecting the checkbox of "Assign Default Points of Module in Link Device Points"**  
The default points of each module are reassigned.  
Note that if a default point is '0,' the corresponding link device is not assigned.

## ■ Checking system configuration of CC-Link IE Field Network

Check whether the equipment configuration of CC IE Field is correct after setting the network configuration on the CC IE Field Configuration window.

### Operating procedure

- **Select [CC IE Field Configuration] ⇒ [Check] ⇒ [System Configuration].**  
The system configuration of CC-Link IE Field Network is checked.  
Check the result of the system configuration check on the Output window.

## ■ Performing parameter processing of device station

Perform the processing relates to parameters of device stations.

The applicable parameter processing differs according to the target device station.

The setting status and setting values of the Parameter Processing of Device Station screen can be saved in the CSV file format.

### Point

#### ● Considerations when performing parameter processing

Check the following before performing the parameter processing.

- The network parameter of master station matches with the start I/O number of PLC parameter.
- The network parameter of programmable controller CPU matches with the actual CC IE Field configuration.

### Operating procedure

1. Select a module to which parameters are applied from the 'list of stations' on the CC IE Field Configuration window.
2. Select [CC IE Field Configuration] ⇒ [Online] ⇒ [Parameter Processing of Device Station].

The Parameter Processing of Device Station screen is displayed.

The following is a screen of NZ2GF2B1-16D.

Parameter Processing of Device Station

Target Module Information: NZ2GF2B1-16D  
Start I/O No.:0000 - Station No.:2

Method selection: Parameter read

The parameters are read from the target module.

Parameter Information

Select All Cancel All Selections Clear All "Read Value" Clear All "Write Value" Copy "Initial Value" to "Write Value" Copy "Read Value" to "Write Value"

Name	Initial Value	Unit	Read Value	Unit	Write Value	Unit	Setting Range	Description
<b>Station parameter</b>								
<input checked="" type="checkbox"/> Input response time setting	5: 10ms							The input module takes in noise as an input de
<input checked="" type="checkbox"/> Output HOLD/CLEAR setting	0: CLEAR							Set whether to hold or clear each output stat
<input checked="" type="checkbox"/> Cyclic data update watch time...	0	x100ms		x100ms		x100ms	0 to 20	Set the cyclic data update watch time so that
<input checked="" type="checkbox"/> Mode switch	9: Automati...							Set the operation mode.
<input checked="" type="checkbox"/> Initial operation setting	0: with initia...							Set whether the initial processing using the pr
<b>Basic module parameter</b>								
<input checked="" type="checkbox"/> Synchronous Input Timing Acq...								Set the synchronous input timing acquisition f
<input type="checkbox"/> Synchronous Input Timing	0: Disable							Enable/Disable of synchronous input timing ac

Process Option


There is no option in the selected process.

-The refreshed device values of remote I/O or remote registers may be overwritten.  
-Accesses the PLC CPU by using the current connection destination. Please check if there is any problem with the connection destination.  
-Process is executed according to the parameters written in the PLC CPU.  
-For information on items not displayed on the screen, please refer to the Operating Manual.

Execute Parameter Processing

Import... Export... OK Cancel







### 3. Set the items on the screen.

Item	Description
Target Module Information	Display the device stations on which the parameter processing is performed.
Method selection	Select a processing to be performed from the list displayed by clicking  .
Parameter Information	Display the parameters of the device station. The selected parameters are the targets of the selected process to be executed.
Process Option	Set this for the processing selected for "Method selection".

### 4. Click the button.

The parameter processing is performed.

#### Screen button

-  Selects all parameters of "Parameter Information".
-  Cancels the selected status of all the parameters selected for "Parameter Information".
-  Deletes all values displayed in the "Read Value" column of "Parameter Information".
-  Deletes all values displayed in the "Write Value" column of "Parameter Information".
-  Imports the selected status and writing values of "Parameter Information" saved in the CSV file format in advance.
-  Saves the selected status and writing values of "Parameter Information" in the CSV file format.

## ■ Performing commands for device stations

Perform commands for device stations.


Applicable commands differ according to the target device station.

### Operating procedure


1. Select a module on which a command is performed from the 'list of stations' on the CC IE Field Configuration window.
2. Select [CC IE Field Configuration] ⇒ [Online] ⇒ [Command Execution of Device Station].


The Command Execution of Device Station screen is displayed.

The following is a screen of NZ2GF2B1-16D.



3. Set the items on the screen.

Item	Description
Target Module Information	Display the information of target module on which the command is performed.
Method selection	Select a processing to be performed from the list displayed by clicking  .
Command Setting	Set the writing values set for the processing selected for "Method selection". For details, refer to the manual of the device station being used.

4. Select the  button.

The command processing is performed.

The result of the processing is displayed on "Execution Result".

1  
OVERVIEW2  
SYSTEM  
CONFIGURATION3  
SCREEN  
CONFIGURATION AND  
BASIC OPERATIONS4  
PROJECT  
MANAGEMENT5  
EDITING  
PROGRAMS6  
SETTING  
PARAMETERS7  
SETTING DEVICE  
MEMORY8  
SETTING DEVICE  
INITIAL VALUES

## ■ Copying/pasting modules

Copy/paste a selected module.

### Operating procedure

1. Select "No." or "Model Name" of the CC-Link module to be copied from the 'list of stations'.

The corresponding row is selected.

Select "No." or "Model Name".

	No.	Model Name	STA#	Station Type	RX/RX Setting		
					Points	Start	End
	0	Host Station	0	Master Station			
	1	GT16**-X	1	Intelligent Device Station	16	0000	000F
	2	NZ2GF2B1-16D	2	Remote Device Station	16	0010	001F
	-	NZ2EX-16(DI)	-	-	16	0020	002F
	3	NZ2GF2B1-16D	3	Remote Device Station	16	0030	003F
	4	QJ71GF11-T2	4	Local Station	16	0040	004F

2. Select [Edit] ⇒ [Copy].

The selected module is copied.

3. Select [Edit] ⇒ [Paste].

The copied module is added to the last row of the 'list of stations'.

### Point

#### ● Selected status of modules

All cells on the 'list of stations' can be selected by selecting [Edit] ⇒ [Select All].

## ■ Deleting modules

Delete a selected module.

### Operating procedure

1. Select "No." or "Model Name" of the module to be deleted from the 'list of stations'.

The corresponding row is selected.

Select "No." or "Model Name".

	No.	Model Name	STA#	Station Type	RX/RX Setting		
					Points	Start	End
	0	Host Station	0	Master Station			
	1	GT16**-X	1	Intelligent Device Station	16	0000	000F
	2	NZ2GF2B1-16D	2	Remote Device Station	16	0010	001F
	-	NZ2EX-16(DI)	-	-	16	0020	002F
	3	NZ2GF2B1-16D	3	Remote Device Station	16	0030	003F
	4	QJ71GF11-T2	4	Local Station	16	0040	004F

2. Select [Edit] ⇒ [Delete].

The selected module is deleted.



## ■ Displaying/hiding Module List/Output/Supplementary Information window

Display/hide the Module List/Output/Supplementary Information window.

### Operating procedure

- Select [View] ⇒ [Docking Window] ⇒ [Module List]/[Output]/[Supplementary Information].

#### Point

#### ● Displaying Module List/Output/Supplementary Information window

The Module List/Output/Supplementary Information window can be displayed as a docked display/floating display. (☞ Section 3.2.4 "Docking windows")

## ■ Displaying/hiding the object name in the list of stations

Display/hide the object name in the list of stations.

### Operating procedure

- Select [View] ⇒ [Object Name Display].

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

### 6.3.3 Setting station information on CC-Link Configuration window




\*1 : CC IE Field head module only

Station information and equipment configuration of CC-Link can be set when master station or master station (duplex function) is set in the CC-Link network parameter. Select "Set the station information in the CC-Link configuration window" on the CC-Link network parameter screen in advance.

#### Screen display

Click the **CC-Link Configuration Setting** button on the network parameter screen of CC-Link.




#### Operating procedure

1. Select a module from the module list, and drag and drop it to the 'list of stations' or 'device map area'.

A device station is added to the 'list of stations'.

The added module is displayed on the 'device map area'.




## 2. Set the items on the screen.

Item	Description
Mode Setting	Select the mode by clicking ▾.
TX Speed	Select the transmission speed by clicking ▾.
Link Scan Time (Approx.)	Display the approximate value of link scan time.
List of stations	Display the list of stations which configure CC-Link network.
Station No.	Display the number of device stations and station numbers set to the master station. "0/0" is displayed for master station, and 'device station number/station number' is displayed for device station. Example: For a module set as the 3rd module of the device station and its station number is 6: 3/6
Model Name	Display the module type of master station/device station. When the module information does not exist, "Module without profile" is displayed.
Station Type	Display the station type of master station/device station. Click the cell and select the station type displayed by clicking ▾.
Version	Display the module version of device station. Click the cell and select the version displayed by clicking ▾.
STA Occupied	Display the number of occupied stations of device station. Click the cell and select the number of occupied stations displayed by clicking ▾.
Expanded Cyclic Setting	Display the expanded cyclic setting of device station.
Remote Station Points	Display the number of remote station points of device station.
Reserved/Err Invalid STA	Display the setting status of reserved station/error invalid station for device station. Click the cell and change the setting displayed by clicking ▾.
Intelligent Buffer Selection (decimal-word unit)	Display buffer memory for Send/Receive/Auto when the device station is an intelligent device station. Click the cell and enter the value.
Station-specific mode setting	Display the setting when the station-specific mode setting is supported by the device station. Click the cell and select the station-specific mode displayed by clicking ▾.
Device map area	Display the equipment configuration of CC-Link network graphically.

## 3. Select [Close with Reflecting the Setting].

Exit the settings of the CC-Link Configuration window.

### Screen button



Detect the actual system configuration automatically and apply it to the CC-Link Configuration window. (Automatic detection of connected devices)


For operations and considerations of setting station information and equipment configuration with the automatic detection of connected devices, refer to the following manual.

 iQ Sensor Solution Reference Manual



Reads the station information and the equipment configuration from the actual system configuration, and verify them against the CC-Link Configuration window being displayed.

For the operating procedure and the considerations when verifying the connected equipment and the actual system configuration, refer to the following manual.

 iQ Sensor Solution Reference Manual



Moves the position of the module selected in the 'list of stations' up/down.

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

### Point

#### ● Considerations when the selected status of "Set the station information in the CC-Link configuration window" is changed

The following are the considerations when editing the station information by changing selected/cleared status.

- Selecting the item

The station information set on the [CC-Link Station Information](#) screen is set on the CC-Link Configuration window automatically.

Note that, all modules of the station information are changed to general-purpose CC-Link modules. The file size of parameter to be written to the programmable controller CPU increases.


- Clearing the item


The station information set on the CC-Link Configuration window is set on the [CC-Link Station Information](#) screen automatically.

#### ● Setting general-purpose CC-Link modules

When a non-Mitsubishi module or a module which is not displayed on the module list is used, drag and drop a general-purpose CC-Link module.

A general-purpose CC IE Field module can be replaced with a specific module by registering a profile.

( Section 4.13.1)

( ■ Replacing general-purpose CC-Link module)

#### ● Display of module name on the 'device map area'

"Object Name" on the [Properties](#) screen is displayed for each module name on the 'device map area'.

#### ● Transmission speed of Q series CC-Link master/local module

Change the transmission speed with the transmission speed/mode setting switch on the module.

The transmission speed selected on the CC-Link Configuration window is not applied to the module if the Write to PLC operation is performed.

#### ● Corrective actions when profiles do not match

For details, refer to Point in Section 6.1.3.


## ■ Replacing general-purpose CC-Link module

Replace a general-purpose CC-Link module of device station with a specific module. A description of link device is displayed on the CC-Link Device Reference window by replacing a general-purpose CC-Link module with a specific module.

### Operating procedure

1. Select a general-purpose CC-Link module to be replaced in the 'list of stations' on the CC-Link Configuration window.
2. Select [CC-Link Configuration] ⇒ [Change Module] ⇒ [Replace General CC-Link Module].

The Replace General CC-Link Module screen is displayed.




3. Set the items on the screen.

Item	Description
Replacement Target	Display the version, the number of occupied stations, station type, and expanded cyclic setting of the module selected on the CC-Link Configuration window.
List of modules to be replaced	Display modules with the same condition as the module selected for "Replacement Target". Select the check box(es) on the "Station Number" column of the module to be replaced. Two or more modules can be selected.
Replacement Candidate	Select a module to be replaced with.

1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES

#### 4. Click the **Replace** button.

The general-purpose CC-Link module in the list of stations is replaced with the module selected for "Replacement Candidate". The general-purpose CC-Link module displayed on the 'device map area' is replaced with the selected module.



### Screen button

- **Select All**  
Selects all modules displayed on "Replacement Target".
- **Cancel All Selections**  
Cancels the selected status of all modules selected for "Replacement Target".

## ■ Changing to general-purpose CC-Link module

Change a module of device station to a general-purpose CC-Link module.

### Operating procedure

1. Select a module to be changed in the 'list of stations' on the CC-Link Configuration window.
2. Select [CC-Link Configuration] ⇒ [Change Module] ⇒ [Change to General CC-Link Module].  
The module is changed to the corresponding general-purpose CC-Link module.

## ■ Checking system configuration of CC-Link

Check whether the equipment configuration of CC-Link is correct after setting the station information on the CC-Link Configuration window.

### Operating procedure

- Select [CC-Link Configuration] ⇒ [Check] ⇒ [System Configuration].  
The system configuration of CC-Link is checked.  
Check the result of the system configuration check on the Output window.

## ■ Performing parameter processing of device station

Perform the processing relates to parameters of device stations.

The applicable parameter processing differs according to the target device station.

The setting status and setting values of the Parameter Processing of Device Station screen can be saved in the CSV file format.

### Point

#### ● Considerations when performing parameter processing

Check the following before performing the parameter processing.

- The network parameter of master station matches with the start I/O number of PLC parameter.
- The network parameter of programmable controller CPU matches with the actual CC-Link configuration.
- A refresh device is set on the CC-Link parameter of programmable controller CPU.

### Operating procedure

1. Select a module to which parameters are applied from the 'list of stations' on the **CC-Link Configuration** window.
2. Select **[CC-Link Configuration] ⇒ [Online] ⇒ [Parameter Processing of Device Station]**.

The Parameter Processing of Device Station screen is displayed.

The following is a screen of FR-A720-0.4K.

Parameter Processing of Device Station

Target Module Information: FR-A720-0.4K  
Start I/O No.:0000 - Station No.:1

Method selection: Parameter read  
Reads parameters from the inverter.  
Parameter setting value "8888" is shown as 65520, and setting value "9999" is shown as 65535.

Parameter Information  
Checked parameters are the targets of selected processes.

Name	Initial Value	Unit	Read Value	Unit	Write Value	Unit	Setting Range	Description
<input type="checkbox"/> [Pr.0] Torque boost	60						0 to 300	Set the output voltage at 0Hz as %.
<input type="checkbox"/> [Pr.1] Maximum frequency	12000						0 to 65535	Set the upper limit of the output frequency.
<input type="checkbox"/> [Pr.2] Minimum frequency	0						0 to 65535	Set the lower limit of the output frequency.
<input type="checkbox"/> [Pr.3] Base frequency	6000						0 to 65535	Set the frequency at rated motor torque (50Hz/60Hz)
<input type="checkbox"/> [Pr.4] Multi-speed setting (hig...	6000						0 to 65535	Set the frequency which is applied when RH turns ON
<input type="checkbox"/> [Pr.5] Multi-speed setting (mid...	3000						0 to 65535	Set the frequency which is applied when RM turns ON
<input type="checkbox"/> [Pr.6] Multi-speed setting (low...	1000						0 to 65535	Set the frequency which is applied when RL turns ON.
<input type="checkbox"/> [Pr.7] Acceleration time	50						0 to 36000	Set the motor acceleration time.
<input type="checkbox"/> [Pr.8] Deceleration time	50						0 to 36000	Set the motor deceleration time.


Clear All "Read Value"      Clear All "Write Value"

Process Option  
There is no option in the selected process.

-The refreshed device values of remote I/O or remote registers may be overwritten.  
-Accesses the PLC CPU by using the current connection destination. Please check if there is any problem with the connection destination.  
-Process is executed according to the parameters written in the PLC CPU.  
-For information on items not displayed on the screen, please refer to the Operating Manual.

Execute  
Import...      Export...      Close







### 3. Set the items on the screen.

Item	Description
Target Module Information	Display the information of target equipment on which the parameter processing is performed.
Method selection	Select a processing to be performed from the list displayed by clicking  .
Parameter Information	Select the parameter(s) to perform the processing and enter settings such as a writing value.
Process Option	Set this for the processing selected for "Method selection".

### 4. Click the button.

The parameter processing is performed.

#### Screen button

-  Selects all parameters of "Parameter Information".
-  Cancels the selected status of all the parameters selected for "Parameter Information".
-  Deletes all values displayed in the "Read Value" column of "Parameter Information".
-  Deletes all values displayed in the "Write Value" column of "Parameter Information".
-  Imports the selected status and writing values of "Parameter Information" saved in the CSV file format in advance.
-  Saves the selected status and writing values of "Parameter Information" in the CSV file format.



## ■ Performing commands for device stations

Perform commands for device stations.

Applicable commands differ according to the target device station.

### Point

#### ● Considerations when performing commands

Check the following before performing commands.


- The programmable controller CPU set as a connection target is in STOP status.
- The network parameter of master station matches with the start I/O number of PLC parameter.
- The network parameter of programmable controller CPU matches with the actual CC-Link configuration.
- A refresh device is set on the CC-Link parameter of programmable controller CPU.

### Operating procedure

1. Select a module on which a command is performed from the 'list of stations' on the CC-Link Configuration window.
2. Select [CC-Link Configuration] ⇒ [Online] ⇒ [Command Execution of Device Station].

The Command Execution of Device Station screen is displayed.

The following is a screen of FR-A720-0.4K.



3. Set the items on the screen.

Item	Description
Target Module Information	Display the information of target module on which the command is performed.
Method selection	Select a processing to be performed from the list displayed by clicking .
Command Setting	Set the writing values for the processing selected for "Method selection".

4. Click the button.

The command processing is performed.

The result of the processing is displayed on "Execution Result".

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

## ■ Copying/pasting modules

Copy/paste a selected module.

### Operating procedure

1. Select "Station No." or "Model Name" of the module to be copied from the 'list of stations'.

The corresponding row is selected.

Select "Station No." or "Model Name".

	Station No.	Model Name	Station Type	Version	# of STA Occupied	Expanded cyclic Settings
	0/0	Host Station	Master Station			
	1/1	CP-1BT11M	Local Station	Ver.1	1 Station Occupied	Single
	2/2	AJ65SBT2B-64DA	Remote Device Station	Ver.1	1 Station Occupied	Single
	3/3	General Remote I/O Station	Remote I/O Station	Ver.1	1 Station Occupied	Single
	4/4	FR-A720-0.4K	Remote Device Station	Ver.1	1 Station Occupied	Single

2. Select [Edit] ⇒ [Copy].

The selected module is copied.

3. Select [Edit] ⇒ [Paste].

The copied module is added to the last row of the 'list of stations'.

## ■ Deleting modules

Delete a selected module.

### Operating procedure

1. Select "Station No." or "Model Name" of the module to be deleted from the 'list of stations'.

The corresponding row is selected.

Select "Station No." or "Model Name".

	Station No.	Model Name	Station Type	Version	# of STA Occupied	Expanded cyclic Settings
	0/0	Host Station	Master Station			
	1/1	CP-1BT11M	Local Station	Ver.1	1 Station Occupied	Single
	2/2	AJ65SBT2B-64DA	Remote Device Station	Ver.1	1 Station Occupied	Single
	3/3	General Remote I/O Station	Remote I/O Station	Ver.1	1 Station Occupied	Single
	4/4	FR-A720-0.4K	Remote Device Station	Ver.1	1 Station Occupied	Single

2. Select [Edit] ⇒ [Delete].

The selected module is deleted.

## ■ Displaying/hiding Module List/Output window

Display/hide the Module List/Output window.

### Operating procedure

- Select [View] ⇒ [Docking Window] ⇒ [Module List]/[Output].

#### Point

#### ● Displaying Module List/Output window

The Module List/Output window can be displayed as a docked display/floating display.  
(☞ Section 3.2.4 "Docking windows")

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

### 6.3.4 Checking devices assigned to CC-Link IE Field Network and CC-Link modules



\*1 : For CC-Link IE Field Network, universal model QCPU only

\*2 : For CC-Link, CC IE Field head module only

Display the refresh devices assigned to each module of CC-Link IE Field Network and CC-Link. Set the parameters of CC-Link IE Field Network and CC-Link in advance.

#### Screen display

Select [View] ⇒ [Docking Window] ⇒ [Device Reference] (DEV).

#### ● List of device stations

The following is an example of the setting screen for CC-Link IE Field Network.

< When "Display Detailed Information" is cleared >

Module No.	Model/Obj. Name	STA#	Station Type	RX Refresh Device	RY Refresh Device	RW Refresh Device	RWw Refresh Device
1	GT16**X	1	Intelligent Device Station	X0 to X1F	Y0 to Y1F	W0 to W7	D0 to D7
2	NZ2CF2B1-16D	2	Remote Device Station	X20 to X3F	Y20 to Y3F	W8 to W1B	D8 to D27
-	NZ2EX-16(D)	-	-	X40 to X4F	Y40 to Y4F	-	-
3	General Remote Device Station	3	Remote Device Station	X50 to X5F	Y50 to Y5F	W1C to W23	D28 to D35
4	RJ71GF11-T2	4	Local Station	X60 to X7F	Y60 to Y7F	W24 to W33	D36 to D51
5	General Local Station	5	Local Station	X80 to X8F	Y80 to Y8F	W34 to W3B	D52 to D59
6	General Remote Device Station	6	Remote Device Station	X90 to X9F	Y90 to Y9F	W3C to W43	D60 to D67

List of device stations

< When "Display Detailed Information" is selected >

Module No.	Model/Obj. Name	STA#	Station Type	Remote Input(RX)		Remote Output(RY)		Remote Register(RW)		Remote Register(RWw)	
				Refresh Device	Buffer Mem. (10)	Refresh Device	Buffer Mem. (10)	Refresh Device	Buffer Mem. (10)	Refresh Device	Buffer Mem. (10)
1	GT16**X	1	Intelligent Device Station	X0 to X1F	0 to 1	Y0 to Y1F	1024 to 1025	W0 to W7	10240 to 10247	D0 to D7	2048 to 2055
2	NZ2CF2B1-16D	2	Remote Device Station	X20 to X3F	2 to 3	Y20 to Y3F	1026 to 1027	W8 to W1B	10248 to 10267	D8 to D27	2056 to 2075
-	NZ2EX-16(D)	-	-	X40 to X4F	4 to 4	Y40 to Y4F	1028 to 1028	-	-	-	-
3	General Remote Dev	3	Remote Device Station	X50 to X5F	5 to 5	Y50 to Y5F	1029 to 1029	W1C to W23	10268 to 10275	D28 to D35	2076 to 2083
4	RJ71GF11-T2	4	Local Station	X60 to X7F	6 to 7	Y60 to Y7F	1030 to 1031	W24 to W33	10276 to 10291	D36 to D51	2084 to 2099
5	General Local Station	5	Local Station	X80 to X8F	8 to 8	Y80 to Y8F	1032 to 1032	W34 to W3B	10292 to 10299	D52 to D59	2100 to 2107
6	General Remote Dev	6	Remote Device Station	X90 to X9F	9 to 9	Y90 to Y9F	1033 to 1033	W3C to W43	10300 to 10307	D60 to D67	2108 to 2115

#### ● List of link devices

< When "Display Detailed Information" is cleared >

Remote Input(RX)				Remote Output(RY)			
Host STA Refresh Device	Target STA Link Device	Explanation	Host STA Refresh Device	Target STA Link Device	Explanation	Host STA Refresh Device	Target STA Link Device
X0	RX0		Y0	RY0		W0	RW0
X1	RX1		Y1	RY1		W1	RW1
X2	RX2	1 <==	Y2	RY2	1 ==>	W2	RW2
X3	RX3		Y3	RY3		W3	RW3
X4	RX4		Y4	RY4		W4	RW4

List of link devices

< When "Display Detailed Information" is selected >

Remote Input(RX)			Remote Output(RY)		
Host STA Refresh Device	Link Device	Buffer Mem. (10)	Host STA Refresh Device	Link Device	Buffer Mem. (10)
X0	RX0	0.b0	Y0	RY0	1024.b0
X1	RX1	0.b1	Y1	RY1	1024.b1
X2	RX2	0.b2	Y2	RY2	1024.b2
X3	RX3	0.b3	Y3	RY3	1024.b3

## Operating procedure

- Set the items on the screen.

Item	Setting status
Start I/O No.	Select the start I/O number of master station or local station from the list displayed by clicking <input type="button" value="v"/> to display the list of device stations or link devices.
Device Station List	Select this to switch the display between the list of device stations and the list of link device stations.
Link Device List	
Display Detailed Information	Select this to display the detailed information of the list of device stations or list of link devices.

## Display contents


Item	Description
Device Station List	Displayed when "Device Station List" is selected.
List of device stations	Display the information of the device stations and the range of the refresh devices assigned to the host station. When "Display Detailed Information" is selected, the range of the buffer memory is also displayed. When refresh devices are not assigned, the cells of the refresh device range will be blank.
Link Device List	Displayed when "Link Device List" is selected.
List of link devices	Display the assignment status of refresh devices on the host station and link devices on the target station. When "Display Detailed Information" is selected, link devices and buffer memory are also displayed on the host station side.

## Screen button

- 

Opens the screen to set the display options.


Select the item for "Displayed Contents for Model Name" and "Buffer Memory Display Format" by clicking , and click the  button.

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

● **Export to CSV File**

Opens the screen to set the purpose and the output format of CSV file output.

Set "Application", "Output Data Range", and "Label Output Format", and click the **Execute** button.



When "Output CSV File for Global Label" is selected for "Application", the output CSV file can be imported on the [Global Label Setting](#) screen.

( GX Works2 Version 1 Operating Manual (Simple Project))

( GX Works2 Version 1 Operating Manual (Structured Project))



● **Display content of Device Reference window**

- All items are displayed only when the network configuration and station information are set by using the parameter reflection function of MELSOFT Navigator.
- When the network configuration of CC-Link IE Field Network is set in the module configuration screen, the model name of the target module is not displayed.
- When the station information of CC-Link is set in the CC-Link Station Information screen, the model name or object name of the target module is not displayed.
- When the network type of CC-Link IE Field Network is a local station or sub-master station, and when that of CC-Link is a local station, master station (duplex function), or standby master station, the assignment status of the refresh devices is not displayed.

● **Checking refresh devices supported by master station and local station**

With a CC-Link configuration containing a local station, when checking refresh devices supported by refresh devices which are set on the master station, open the project of the local station and check them on the Device Reference window.

Example: When checking refresh devices of local station which supports refresh device D2008 of the CC-Link master station

< Project of master station >  
The value of RWw3 is refreshed by the value of D2008.

Host STA(Master)				
Refresh Device	Link Device	Buffer Mem.(DEC.)		STA#
D2005	RWw0	480		
D2006	RWw1	481		
D2007	RWw2	482	==>	1
D2008	RWw3	483		


< Project of local station >  
The value of D3008 is refreshed by the value of RWr3.

Host STA(Master)				
Refresh Device	Link Device	Buffer Mem.(DEC.)		STA#
D3005	RWw0	736		
D3006	RWw1	737		
D3007	RWw2	738	<==	1
D3008	RWw3	739		

When a value is stored to D2008 on the master station, a value is stored to D3008 on the local station.

● **Displaying list of link devices**


- The selected device station can be displayed on top of the cell by right-clicking 'list of link devices' and selecting [Select Device Station] from the shortcut menu.



Select the station number 7 of the device station.

The station number 7 is displayed at the top.

- The Device/Buffer Memory Batch Monitor screen is displayed by right-clicking a refresh device or buffer memory selected from the 'list of link devices' and selecting [Device/Buffer Memory Batch] from the shortcut menu. For details of the device/buffer memory batch monitoring, refer to Section 17.3.



1	OVERVIEW
2	SYSTEM CONFIGURATION
3	SCREEN CONFIGURATION AND BASIC OPERATIONS
4	PROJECT MANAGEMENT
5	EDITING PROGRAMS
6	SETTING PARAMETERS
7	SETTING DEVICE MEMORY
8	SETTING DEVICE INITIAL VALUES

## 6.4 Setting Remote Password




\*1 : CC IE Field head module only

This section explains how to set a password to prevent illegal access from remote users to the QCPU (Q mode)/LCPU via a Q series-compatible E71 module, C24 module, or Ethernet Built-in CPU.

### Screen display

Select Project view ⇒ "Parameter" ⇒ "Remote Password".

The following is an example of setting screen when QCPU (Q mode) is selected.



### Operating procedure


#### 1. Set the items on the screen.

Item		Description
Password		Set the password.
Password Active Module Setting	Model Name	Set the model of the routing programmable controller CPU or module. For the programmable controller CPU, select "Ethernet Built-in CPU".
	Start XY	Set the start I/O number.
	Condition	Set the details when selecting "Ethernet Built-in CPU" or "QJ71E71". <ul style="list-style-type: none"> <li>● <b>User connection No. valid setting</b> Set whether to enable the remote password for the user connection No. 1 to No. 16.</li> <li>● <b>System connection valid setting</b> Set whether to enable the remote password for the system connections.</li> </ul>

#### 2. Click the button.

The Password Confirmation screen is displayed.

#### 3. Enter the set password again.






#### 4. Click the button.

The remote password setting ends.

To set the password on the programmable controller CPU, write the parameter to the programmable controller CPU using the Write to PLC function.


( Section 15.1)

#### *Point!*

- **Modules that support remote password setting**

For the modules that support the remote password setting and the details of the remote password setting, refer to the user's manual of the programmable controller CPU, Q series-compatible E71 module or C24 module to be used.

- **Characters for password**

Enter the password in 4 characters, using alphabets, numerals, and symbols corresponding to ASCII codes 20H to 7EH ( Appendix 3).

## 6.5 Checking Parameters


Q CPU L CPU Remote Head FX

This section explains how to check errors in the PLC parameter and the network parameter which are set in the project.  
The result of the parameter check is displayed on the Output window.


### Screen display

Select [Tool] ⇒ [Check Parameter].

<QCPU (Q mode)/LCPU>



<FXCPU>




### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Check Target	Select the items for the check parameter.

#### 2. Click the **Execute** button.

The check parameter is performed, and the result is displayed on the Output window.



## 6.6 Outputting Parameters to CSV Files

Q CPU L CPU Remote Head FX

The following parameters can be written to CSV files.

- **I/O assignment setting**

Project view ⇒ "Parameter" ⇒ "PLC Parameter" ⇒ <<I/O Assignment>>

- **Acknowledge XY assignment**

Project view ⇒ "Parameter" ⇒ "PLC Parameter" ⇒ Acknowledge XY Assignment


Project view ⇒ "Parameter" ⇒ "Network Parameter" ⇒ "(network parameter)" ⇒ Acknowledge XY Assignment

### Operating procedure

1. Click the **Export to CSV File** button.


The confirmation message for writing data is displayed.

< I/O assignment setting >



2. Click the **Yes** button.

The Write to CSV file screen is displayed.



3. Enter a file name of the data to be saved.

4. Click the **Save** button.

Parameters are saved to a CSV file.

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY


8 SETTING DEVICE INITIAL VALUES

■ CSV file format

The following is an image of the saved CSV file opened in spreadsheet software.

- Example of CSV file for I/O assignment setting

< I/O Assignment setting >




< CSV file >

I/O Assignment Setting														
PLC	PLC	Points	Start XY	Model Name	Output Mode at Error Occurrence	PLC Operation Mode at HW Error Occurrence	I/O Response Time	Switch1	Switch2	Switch3	Switch4	Switch5	Control PLC	Base Model Name
0	Q25H-CPU		0	Q25H-CPU	Clear	Stop	10ms							Q312B
1	I/O Mix	16	0	QI42P	Clear	Stop								Q312B
2	Intelligent	32	32	QJ61BT11N	Clear	Stop								Q61P
3	Intelligent	32	64	QJ71C24N-R4	Clear	Stop								Q61P
4	Intelligent	32	96	QD75MH4	Clear	Stop								Q61P
5	Intelligent	32	128	QD75MH4	Clear	Stop								Q61P

- Example of CSV file for acknowledge XY assignment

< Acknowledge XY Assignment screen >



< CSV file >

Acknowledge XY Assignment								
'XYNo.'	'Type'	'Slot'	'Module Type'	'Points'	'Model Name'	'Network Assignment X'	'Network Assignment Y'	'Overlap Error'
0	I/O Assignment	0(*- 0)	Input	16 Points				MNET/CC IE (Slot 1)
16	I/O Assignment	1(*- 1)	Intelligent	32 Points				MNET/CC IE (Slot 2)
32	I/O Assignment	1(*- 1)	Intelligent	32 Points				MNET/CC IE (Slot 2)
48	I/O Assignment	2(*- 2)	Intelligent	32 Points				CC-Link
64	I/O Assignment	2(*- 2)	Intelligent	32 Points				CC-Link
80	CC-Link(Slot 1)					Station 3 -> X0050	Station 3 -> Y0050	
96	CC-Link(Slot 1)					Station 4 -> X0060	Station 4 -> Y0060	

● Details of CSV file

The following explains the details of CSV file format.

- The file format is Unicode (including UTF-16, Little Endian, and BOM).
- The delimiter of items is a tab (t).
- Each item is enclosed in double quotation marks ("").
- If the item contains double quotation marks (""), the double quotation marks in the item are expressed as two double quotation marks ("").
- A line feed is set at the end of the line. The line feed code is LF.

## 6.7 Setting default parameters


Q CPU L CPU Remote Head FX

This section explains how to set default parameters to the PLC parameter or the network parameter in batch.

### Screen display

Select [Tool] ⇒ [Clear All Parameters].

The following is an example of setting screen when QCPU (Q mode) is selected.



### Operating procedure

#### 1. Set the item on the screen.

Item	Description
Select Data	Select the parameter to which default parameters are set.

#### 2. Click the button.

Default parameters are set to the selected parameter.

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES



---

# 7 SETTING DEVICE MEMORY

This chapter explains the settings of the device memory.

7.1	Device Memory	7 - 2
7.2	Setting Device Memory	7 - 5
7.3	Searching Devices	7 - 15
7.4	Writing/Reading Device Memory Data	7 - 16

## 7.1 Device Memory



This section explains the features of the device memory.

### 7.1.1 Features of device memory

---

Device memory is the function that reads/writes data from/to the device memory on a programmable controller CPU.

- **Read**

The function batch-reads device memory data from a programmable controller CPU to GX Works2. The read data can be used to check the status of the device memory on a programmable controller CPU as well as for offline debugging.

- **Write**

The function batch-writes device memory data from GX Works2 to a programmable controller CPU. The current values of the device memory on a programmable controller CPU can be batch changed.



## 7.1.2 List of devices selectable on the Input Devices screen

### ■ QCPU (Q mode)/LCPU

○: Can be edited △: Display only -: Not supported

Category	Device type	Symbol	Display/edit	
Internal user device	Input	X	△	
	Output	Y	△	
	Internal relay	M	○	
	Latch relay	L	○	
	Annunciator	F	○	
	Edge relay	V	○	
	Step relay	S	△	
	Link relay	B	○	
	Link special relay	SB	○	
	Timer	Current value	T	○
		Contact	TS	-
		Coil	TC	-
	Counter	Current value	C	○
		Contact	CS	-
		Coil	CC	-
	Retentive timer	Current value	ST	○
		Contact	STS	-
		Coil	STC	-
	Data register	D	○	
	Link register	W	○	
Link special register	SW	○		
Direct input	DX	-		
Direct output	DY	-		
Internal system device	Special relay	SM	△	
	Special register	SD	○	
Link direct device	Link input	J□X□	△	
	Link output	J□Y□	△	
	Link register	J□W□	○	
	Link special register	J□SW□	○	
	Link relay	J□B□	△	
	Link special relay	J□SB□	△	
File register	File register	R*1	-	
		ZR*1,*2	○	
Index register	Index register	Z	△	
Intelligent function module device	Intelligent function module device	U□G□	○	

\*1 : Not supported by Q00J/Q00UJ.

\*2 : For Universal model QCPU/LCPU, the device cannot be used when '0k' is set for "Device points" of file register (ZR(R)) under "File Register Extended Setting" on the &lt;&lt;Device&gt;&gt; tab of PLC parameter.

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES

■ FXCPU

○: Can be edited △: Display only –: Not supported

Category	Device type	Symbol	Display/edit									
			FX0 FX0S	FX0N	FX1	FX1S	FX1N FX1NC	FXU FX2C	FX2N FX2NC	FX3S	FX3G FX3GC	FX3U FX3UC
Internal user device	Input	X	△	△	△	△	△	△	△	△	△	△
	Output	Y	△	△	△	△	△	△	△	△	△	△
	Internal relay	M	○	○	○	○	○	○	○	○	○	○
	State	S	△	△	△	△	△	△	△	△	△	△
	Timer	T	○	○	○	○	○	○	○	○	○	○
	Counter*1	C	○	○	○	○	○	○	○	○	○	○
	Data register	D	○	○	○	○	○	○	○	○	○	○
	File register	D	–	○	–	○	○	○	○	○	○	○
Internal system device	Special relay	M	○	○	○	○	○	○	○	○	○	○
	Special data register	D	○	○	○	○	○	○	○	○	○	○
Extended register		R	–	–	–	–	–	–	–	–	○	○
Extended file register		ER	–	–	–	–	–	–	–	–	○	○


\*1 : 32-bit counter (C200 and later) is not supported.



**Point**

● **Inserting rows**

Select [Edit] ⇒ [Insert Row] to insert a blank row at the cursor position.



● **Cutting/copying/pasting character strings in units of rows**

To paste a character string in units of rows, select the desired cell(s) and paste the character string. If a row is selected, pasting is not possible.

● **Cutting/copying/pasting character strings in units of cells**

To paste a character string in units of cells, if the selected cell(s) is in the row where a device is not entered, pasting is not possible.

● **Copying device memory**

Device memory data of the selected range can be copied and pasted to Excel. Data can also be copied and pasted to device memory from Excel.

When a value other than 0 is pasted as a bit device, it is replaced to 1.

When copying data and moving cursor on Excel before pasting the copied data on GX Works2, the value different from the copied data may be pasted.


In this case, copy and paste the data without moving the cursor on Excel.

● **Deleting devices**


If a deletion is executed after selecting a cell, the device value clears to '0'.

If a deletion is executed after selecting a row, the selected row (device) is deleted.

<Deletion in units of cells>



<Deletion in units of rows>



## 7.2.1 Setting device values in units of points

Set a device and device value in units of points.

Create a new device memory in advance. (☞ Section 4.3.1)

Example) Set the following values.

'Device: D0, Device value: 12'

### Operating procedure

1. Select the cell to which a device value is set.

	+0	+1	+2

2. Enter 'D0' for a device.

	+0	+1	+2
	D0		

3. Press the  key.

The entered device is set in the device number display area.

In this example, 'D0' is set in the device number display area and the value is displayed in the device value display area.

	+0	+1	+2
D0	0		

4. Enter '12' for a device value.

'12' is set as the device value of device 'D0'.

	+0	+1	+2
D0	12		

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

## 7.2.2 Setting device values by specifying device range

### ■ Setting device values by specifying a device range on the Input Device screen

Set device values by specifying a device range on the Input Device screen.


Example) Set the following values.

'Device: D, range: 0 to 50, display format: decimal number'


#### Operating procedure

1. Select the cell to which a device value is set.

	+0	+1	+2

2. Select [Edit] ⇒ [Input Device] .

The Input Device screen is displayed.



3. Set the items on the screen.

Item	Description
Device	Select the device name. For devices that can be edited, refer to Section 7.1.2.
Module Start*1	Display when U□\V□ or J□\□ is selected in the "Device" field.
Network No.*1	Enter the start XY address or network number.
Range	Select the range of devices to be set.
All	Select this to target all of the selected devices.
Address	Select this to target the devices in the specified range.
Display Mode	Select the display format of device values.
BIN	Select this to display device values in binary numbers.
OCT	Select this to display device values in octal numbers.
DEC	Select this to display device values in decimal numbers.
HEX	Select this to display device values in hexadecimal numbers.
FLOAT	Select this to display device values in real numbers.
String	Select this to display device values in character strings.
String (ASCII only)	Select this to display device values in ASCII strings.



## ■ Setting device values by specifying a device range on the cell

Set device values by specifying a device range on the cell.

Example) Set the following values.

'Device: D, range: 20 to 40, display format: decimal number'

### Operating procedure

#### 1. Select a cell to which the device value is set.

	+0	+1	+2	

#### 2. Enter the device range.

	+0	+1	+2	
	D20-D140			

#### 3. Click the button.

Devices from D20 to D140 are registered to the cells and the values are displayed.

	+0	+1	+2	+3	+4	+5	+6	+7	+8	+9	+10(A)
D20	0	0	0	0	0	0	0	0	0	0	0
D30	0	0	0	0	0	0	0	0	0	0	0
D40	0	0	0	0	0	0	0	0	0	0	0
D50	0	0	0	0	0	0	0	0	0	0	0
D60	0	0	0	0	0	0	0	0	0	0	0
D70	0	0	0	0	0	0	0	0	0	0	0
D80	0	0	0	0	0	0	0	0	0	0	0
D90	0	0	0	0	0	0	0	0	0	0	0
D100	0	0	0	0	0	0	0	0	0	0	0
D110	0	0	0	0	0	0	0	0	0	0	0
D120	0	0	0	0	0	0	0	0	0	0	0
D130	0	0	0	0	0	0	0	0	0	0	0
D140	0	0	0	0	0	0	0	0	0	0	0

### Point

#### ● Display format of bit device and word device

The following table shows the display format of bit device and word device when the device range is specified on the cell.

Device	Value	Display format	Display size
Bit device	0	Binary	—
Word device	0	Decimal	16 bits

#### ● Device registration when only the start address or the end address is specified

A device range can be specified by specifying the start address or the end address only.

- **When only the start address is specified (Example: Specify 'D0-' for the device range)**  
Devices from 'D0' to the last valid address are registered to the cells.
- **When only the end address is specified (Example: Specify '-D100' for the device range)**  
Devices from 'D0 to D100' are registered to the cells.

#### ● Abbreviating device name

When specifying a device range on the cell, only the end address can be abbreviated.

For example, when a device range is specified with 'D0-100', the devices in the range of 'D0-D100' are registered.

#### ● Specifying R devices (This function is not supported by FXCPU.)

When R device is specified, it is changed to ZR device and registered.




## 7.2.3 Setting character strings

Set a character string to a device.

Set "Display Mode" to 'String' in advance. (☞ Section 7.2.5)


### Operating procedure

1. Select a range of cells to which a character string is set.




2. Select [Edit] ⇒ [Paste Text].

The Paste Text screen is displayed.



3. Enter a character string, and click the **OK** button.

The entered character string is set to the selected cells or row.



### Point

#### ● Entering character strings


When "Register" is '16-bit', '32-bit', or '64-bit', the maximum number of characters that can be entered to one cell is 2, 4, or 8 respectively.

## 7.2.4 Setting same value simultaneously

Set the same value to consecutive devices.


### Operating procedure

#### 1. Select devices to which a value is to be set.



#### 2. Select [Edit] ⇒ [Fill] ( ).

The FILL screen is displayed.




#### 3. Set the items on the screen.

Item	Description
Data Format	Select the data format of device values.
BIN	Select this to set device values in binary numbers.
OCT	Select this to set device values in octal numbers.
DEC	Select this to set device values in decimal numbers.
HEX	Select this to set device values in hexadecimal numbers.
Device Value	Enter a value set to devices simultaneously.

#### 4. Click the **OK** button.

The specified device value is set to devices simultaneously.



### Point

#### ● Setting the same value simultaneously

Device values can also be set simultaneously by selecting a range, right-clicking it on the device memory editor, and selecting [FILL] from the shortcut menu.

## 7.2.5 Changing display format


### Switching display format

Switch the device value display format for each cell on the device memory editor.

#### Operating procedure

- Select [View] ⇒ [Display Mode] ⇒ [Binary/Octal/Decimal/Hexadecimal/Float/String/String (ASCII)].

Device values are displayed in the selected display format.




### Switching display size in 16-bit/32-bit/64-bit

Switch the device value display size in 16-bit/32-bit/64-bit for each cell on the device memory editor.

#### Operating procedure

- Select [View] ⇒ [Register] ⇒ [16-bit/32-bit/64-bit].

Device values are displayed in the selected display size (16 bits, 32 bits, or 64 bits).




## 7.2.6 Changing the number of rows/columns on device memory editor

Change the number of rows/columns on the device memory editor.

### Screen display

Select [View] ⇒ [Setup].



### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Number of Columns	Set the number of columns on the editor.
Auto	Select this to set the number of columns to 16.
Specify the number of columns (1 - 255)	Select this to set the desired number of columns on the editor. Setting range: 1 to 255
Row	Set the number of rows on the editor.
4096 Rows	Select this to set the number of rows to 4096.
Specify the number of rows (16 - 655360)	Select this to set the desired number of rows on the editor. Setting range: 16 to 655360
Additional Safety Inquiry	Select this to display the confirmation message when device deletion is executed.

#### 2. Click the button.

The set number of rows/columns are displayed.

### Point

#### ● Number of columns

When "Number of Columns" is set to "Auto", the device values are displayed in 10 columns or 16 columns according to the specified devices.

For FXCPU, the device values of X and Y are displayed in 8 columns.

#### ● Considerations for changing rows and columns

When a value smaller than the current value is set for "Number of Columns" or "Row", a confirmation message is displayed and the data on the device memory editor is discarded.

When a value larger than the current value is set for "Number of Columns", the sequence of devices registered to the device memory editor do not change by the setting of "Number of Columns".


## 7.3 Searching Devices



This section explains how to search for a device set in the device memory.

### Screen display

Select [Find/Replace] ⇒ [Find Device Cell].



### Operating procedure

#### 1. Set the items on the screen.

Item	Description	
Find what	Enter the device to be searched for.	
Direction	Up	Select this to perform searching in the upward direction from the cursor position.
	Down	Select this to perform searching in the downward direction from the cursor position.

#### 2. Click the button.

The cursor moves to the found device.

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT

5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES

## 7.4 Writing/Reading Device Memory Data



This section explains how to write/read device memory data being edited to/from a programmable controller CPU or Excel file.


### 7.4.1 Writing/reading data to/from programmable controller CPUs

Write/read device memory data to/from a programmable controller CPU.

To write/read device memory data in units of files, refer to the online Write to PLC/Read from PLC function. (☞ Section 15.1)

#### Screen display

Select [Tool] ⇒ [Write Device Memory to PLC]/[Read Device Memory from PLC].



#### Operating procedure

- Set the item on the screen.


Item	Description
Range	Select the write/read range.
Selected Devices	Select this to write/read data in the specified range to/from a programmable controller CPU.
All Devices	Select this to write/read all data in the device memory being edited to/from a programmable controller CPU.

## 7.4.2 Writing/reading data to/from Excel files

Write/read device memory data to/from an Excel file.

### Screen display

Select [Tool] ⇒ [Write to Excel File]/[Read from Excel File].



### Operating procedure

#### 1. Enter a file name or select the file to be opened.

The Save screen or Open screen is displayed.

#### 2. Click the **Save** or **Open** button.

Data are saved to the specified destination, or the file is opened from the specified location.

### Point

#### ● Compatible Excel version

Microsoft Office Excel 97 or later version is compatible with the data write/read operations.

#### ● Reading data

When data are read from an Excel file, they are read with the saved setting of "Number of Columns".

The following are regarded as errors and processed as explained.

- Unsupported devices ⇒ Deleted
- Invalid value ⇒ Set to '0'.
- Invalid display format ⇒ Displayed in decimal numbers.

#### ● Reading/writing data of which display size is 32-bit/64-bit

Cells set the display size to 32-bit/64-bit are merged and written to an Excel file.

If the number of merged cells exceeds '32767', cells from '32768' onwards are not merged. Instead, they are written to the file and the character strings "<<32-bit>>"/" <<64-bit>>" are added to them.

When reading the Excel file back to the device memory again, do not unmerge the cells or edit the character strings "<<32-bit>>"/" <<64-bit>>".





---

# 8 SETTING DEVICE INITIAL VALUES

This chapter explains how to set, edit, and delete device initial values.

8.1	Device Initial Values	8 - 2
8.2	Setting Device Initial Values	8 - 5

## 8.1 Device Initial Values



This section explains the device initial values.

### 8.1.1 Feature of device initial values

The device initial values are device values used for the sequence program operation when the programmable controller turns RUN.

When the device initial values are set, the initial setting program is unnecessary.

● **When device initial values are not set**

The initial setting program is necessary.




● **When device initial values are set**

Example)

	Points	Start	End	Comment
1	3	D0	D2	
2	2	D11	D12	
3				
4				
5				
6				

The initial setting program is unnecessary.



## 8.1.2 List of applicable devices for device initial values

The following table shows the list of devices which can be used as device initial values.

Category	Device name	Device
Internal user device	Timer	T
	Retentive timer	ST
	Counter	C
	Data register	D
	Link register	W
	Link special register	SW
Internal system device	Special register	SD
File register	File register	R <sup>*1,*2</sup> , ZR <sup>*2</sup>
Intelligent function module device	Intelligent function module device	U□\G□
Link direct device	Link register	J□\W□
	Link special register	J□\SW□


\*1 : When the R device is specified to utilize the device memory data, the ZR device value is utilized for the R device.

\*2 : Not applicable to Q00UJ.

1  
OVERVIEW2  
SYSTEM CONFIGURATION3  
SCREEN CONFIGURATION AND BASIC OPERATIONS4  
PROJECT MANAGEMENT5  
EDITING PROGRAMS6  
SETTING PARAMETERS7  
SETTING DEVICE MEMORY8  
SETTING DEVICE INITIAL VALUES

### 8.1.3 Procedure for setting device initial values

The following flow chart shows the procedure for setting the device initial values.



## 8.2 Setting Device Initial Values



This section explains how to set device values set in the device memory as device initial values. Create a new device initial value data in advance. (➔ Section 4.3.1)

### Screen display

Select Project view ⇒ "Device Initial Value" ⇒ "(data name)".

Range setting

	Points	Start	End	Comment
1	11	D0	D10	Device Initial Value Comment1
2	11	SW0	SW0A	Device Initial Value Comment2
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				

The device range and the device data that is set above will be write to PLC.  
You must execute 'Device Memory Diversion' operation when the device initial range setting is changed.

Setting Method:  Start/End  Points/Start

Device Memory Diversion:  Device Memory for Diversion

Print... Print Preview... Print Setting... OK Cancel

### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Range setting	Set the range for device initial values.
Points	Set the number of points of each device. Up to 8,000 points of devices can be set within a range.
Start	Specify the start device of the range to be set.
End	Specify the end device of the range to be set.
Comment	Enter a comment in the set device range. (Up to 32 characters)
Setting Method	
Start/End	Select this to set the range for device initial values by start or end device.
Points/Start	Select this to set the range for device initial values by device points or start device.

#### 2. Select the data name to be utilized from in "Device Memory Diversion", and click the button.

The device value in the set range is set as a device initial value.

#### 3. Click the button.

1 OVERVIEW

2 SYSTEM CONFIGURATION

3 SCREEN CONFIGURATION AND BASIC OPERATIONS

4 PROJECT MANAGEMENT




5 EDITING PROGRAMS

6 SETTING PARAMETERS

7 SETTING DEVICE MEMORY

8 SETTING DEVICE INITIAL VALUES

### Screen button

-  Executes printing. (☞ Section 11.7)
-  Executes print preview. (☞ Section 11.9)
-  Displays the Print Setting (Device Initial Value) screen. (☞ Section 11.8.2)

### Point

- **Using device initial values**  
If the device values with set ranges are used as the initial values when activating the programmable controller CPU, specify the file name to be used for the initial values on the <<PLC File>> tab of PLC parameter.
- **Device range**  
The device range that can be set for device initial values is the range set on the <<Device>> tab of PLC parameter.

---

# 9 SETTING DEVICE COMMENTS

This chapter explains the operation methods for setting, editing, and deleting device comments.

9.1	Device Comments	9 - 2
9.2	Creating Device Comments	9 - 11
9.3	Deleting Device Comments	9 - 15
9.4	Extending Number of Points of Device Comment	9 - 16
9.5	Utilizing Sample Comments	9 - 17
9.6	Writing/Reading Device Comments to CSV Files	9 - 19

# 9.1 Device Comments




This section explains the general concept of device comments and the setting availability.

## 9.1.1 Global device comments/local device comments

Device comment is categorized into global device comment and local device comment.


### Global device comments

A global device comment is a device comment created automatically when a new project is created. Global device comments are set to use common device comment data among multiple programs. Global device comments can be set even when there is only one program.



A global device comment name is fixed to COMMENT. Global device comments can be changed to local device comments.

<Image that is created with only global device comments>





## Local device comments

A local device comment is a device comment created by the user.


No local device comment exists when a new project is created.

Create a local device comment if necessary. (☞ Section 4.3.1)

Local device comments are used in association with each program.


Device comments are set under the same name as sequence programs.

For Structured projects, device comments are set under the same data name as the program file name.



Display example when local device comments are set.

<Image of a project created with only local device comments>



9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

**Point**

● **Writing device comments to a programmable controller CPU**

Up to the following number of device comments can be written to the programmable controller CPU.

Per device: 32k points

Total number of device comments: 64k points

When the number of set device comments exceeds the number of points that can be written to the programmable controller CPU, set the range when writing device comments to the programmable controller CPU. (☞ Section 15.1.3)

● **Data name of global device comments**


A global device comment is displayed as "COMMENT" in the screen for Write to PLC/Read from PLC.

● **Setting local device comments with data names different from the sequence program name**

Multiple local device comments can be created with data names different from the sequence program name. In this case, however, the comments are not related to the sequence program.

To make the comments relate to the sequence program, the comments should have the same data names as the program name.

This is useful for cases, such as when switching comments between Japanese and English in the same program.



● **Global device comments/local device comments**

Global device comments/local device comments correspond respectively to common comments/comments by program in GX Developer.


● **Device comments for Basic model QCPU**

Global device comments are not supported by Basic model QCPU.

A local device comment for Basic model QCPU is fixed to "MAIN".

When an SFC program is created, the SFC program "MAIN-SFC" also refers to a local device comment "MAIN".

<Image of an SFC program for Basic model QCPU>



● **Character limit when writing global device comments to FXCPU**

For FXCPU, up to 32 characters of global device comments can be written as a project data, however, only up to 16 characters can be written to the programmable controller CPU.

● **Local device comments for FXCPU**

For FXCPU, local device comments cannot be written to a programmable controller CPU. If local device comments needs to be written, create comments as global device comments, or change local device comments to global device comments. When changing a local device comment to a global device comment, change its data name to "COMMENT". (☞ Section 4.3.3)

● **Difference between device comment and label comment**

A device comment is a comment appended to a device, and it is 'data' to be read from/write to a programmable controller CPU.

A label comment is a comment appended to a defined label. A label comment is not applied to a device comment even when a program is compiled.

## ■ Displaying device comments on program editors

Device comments can be displayed on program editors.  
The following are the settings to display device comments.

### ● Displaying device comments on the ladder editor or Zoom editor

Select [View] ⇒ [Comment].

Device comments are displayed on the device on the ladder editor or the Zoom editor.

For labels, label comments are displayed. The device comments that are assigned to the labels are not displayed.

For details of ladder editor and Zoom editor, refer to the following manual.

☞ GX Works2 Version 1 Operating Manual (Simple Project)

### ● Displaying device comments on Structured Ladder/FBD editor

When [Label] is selected in [View Mode], select [View] ⇒ [Add Label Display Items] ⇒ [Device Comment].

The device comment is displayed on the device or address on the Structured Ladder/FBD editor.

The device comments of the devices which are assigned to the labels are not be displayed.

For details of Structured Ladder/FBD editor, refer to the following manual.

☞ GX Works2 Version 1 Operating Manual (Structured Project)

### ● Displaying device comments on tooltips

Select "Device Comment" under [Tool] ⇒ [Options] ⇒ "Program Editor" ⇒ "Ladder/SFC"/"Structured Ladder/FBD/ST"\*1 ⇒ "Tool hint display items".

Device comments are displayed on tooltips.

\*1 : For Simple project (with labels), select "ST" instead of "Ladder/SFC"/"Structured Ladder/FBD/ST".

■ Specifying device comments to be displayed in program

When both global and local device comments are set, specify the comment to be displayed by the following method.

**Operation**

- Set the device comment to be referenced by selecting [Tool] ⇒ [Options] ⇒ "Program Editor" ⇒ "All Editors" ⇒ "Device Comment".

Example) When different device comments are set for the same device (M)

Global device comment (COMMENT)

Device Name	Comment
M0	
M1	Initial Start 1
M2	Initial Start 2

Local device comment (MAIN)

Device Name	Comment
M0	
M1	Stop Device 1
M2	Stop Device 2

The display differs as shown below according to the option setting.

● When the reference of the device M in the sequence program MAIN is set to the global device comment

<Option>

<Sequence program MAIN>

The global device comment, 'Initial Start 1', is displayed as a device comment for M1.

● When the reference of the device M in the sequence program MAIN is set to the local device comment

<Option>

<Sequence program MAIN>

The local device comment, 'Stop Device 1', is displayed as a device comment for M1.

● When the reference of the device M in the sequence program MAIN is set to the PLC parameter setting

<Option>

<Device>

	Sym.	Dig.	Device Points	Latch (1) Start	Latch (1) End	Latch (2) Start	Latch (2) End	Local Device Start	Local Device End
Input Relay	X	16	8K						
Output Relay	Y	16	8K						
Internal Relay	M	10	8K					0	1
Latch Relay	L	10	8K						

<Sequence program MAIN>

The local device comment, 'Stop Device 1', is displayed for local device M1, and the global device comment, 'Initial Start 2', is displayed for global device M2.

**Point** 

● **Specifying device comments for "Specify the Reference/Reflection" in batch**

The following operations can be performed to set "Specify the Reference/Reflection".

By clicking the  /  /  button, the "Reference/Reflection Target for Device Comment" settings of all device comments of program selected for "Program/Program File Name" are set to "Global"/"Local"/"PLC Parameter Setting".\*1

By clicking the  button, the setting of "Specify the Reference/Reflection" of the selected program is applied to all programs.

\*1 : Only devices with which the range of local devices can be specified on the <<Device>> tab of PLC parameter can be set.

● **Device comment to be referenced is not set**

If a comment does not exist in the device comment set for "Specify the Reference/Reflection", the other device comment can be displayed by setting the option.\*1

Select [Tool] ⇒ [Options] ⇒ "Program Editor" ⇒ "All Editors" ⇒ "Device Comment", and select "Reference/Reflect the other, when device comment is not set."

\*1 : Except for when 'PLC Parameter Setting' is set for "Specify the Reference/Reflection".

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

### 9.1.2 List of device comment applicable devices

The following table shows device types and comment setting availability.

○: Applicable / ×: Not applicable

Category	Device name	Symbol	Bit specification*1	QCPU (Q mode)/ LCPU	FXCPU
Internal user device	Input	X	×	○	○
	Output	Y	×	○	○
	Internal relay	M	×	○	○
	Latch relay	L	×	○	-
	Annunciator	F	×	○	-
	Edge relay	V	×	○	-
	Step relay	S	×	×	-
	Link relay	B	×	○	-
	Link special relay	SB	×	○	-
	State	S	×	-	○
	Timer	T	×	○	○
	Retentive timer	ST	×	○	-
	Counter	C	×	○	○
	Data register	D	○	○	○
	Link register	W	○	○	-
	Link special register	SW	○	○	-
	Direct input	DX	×	○	-
	Direct output	DY	×	○	-
Internal system device	Special relay	SM	×	○	-
		M	×	-	○
	Special register	SD	○	○	-
		D	×	-	○
Link direct device	Link input	J□\X□	×	○	-
	Link output	J□\Y□	×	○	-
	Link register	J□\W□	○	○	-
	Link special register	J□\SW□	○	○	-
	Link relay	J□\B□	×	○	-
	Link special relay	J□\SB□	×	○	-
File register	File register	R	○	○*2	○*3
		ZR	○	○*2	-
	(RAM) File register	D	×	-	○
Index register	Index register	Z, ZZ	×	×	-
Intelligent function module device	Intelligent function module device	U□\G	○	○	○*4
Nesting	Nesting	N	×	×	×
Pointer	Pointer	P	×	○	○
	Interrupt pointer	I	×	○	○

Category	Device name	Symbol	Bit specification*1	QCPU (Q mode)/ LCPU	FXCPU
Other	Network number specified device	J	x	○	—
	SFC block device	BL*5	x	○	—
	Step relay (Step relay with a block specification)	BL\S	x	○	—
	SFC transition device	BL\TR	x	○	—
	I/O number specified device	U	x	○	○*4

\*1 : Bit-specified word device comment is applicable to Universal model QCPU/LCPU only.

\*2 : Not applicable to Q00J/Q00UJ.

\*3 : R (extended register) is applicable to FX3G/FX3GC or FX3U/FX3UC only

\*4 : Applicable to FX3U/FX3UC only

\*5 : For projects with labels, comments of the BL device are not applied to the block titles.

### Point

#### ● Device comment creation supported range in the multiple CPU system configuration for QCPU (Q mode)

Device comments can be created in the following ranges, corresponding to the buffer memory of the programmable controller CPU (3E00H to 3E30H) in a multiple CPU system.

Supported range	Unsupported range
U0(\G0) to U1FF(\G65535)	U200(\G0) to U3DF(\G65535)
U3E0(\G0) to U3FF(\G65535)	

#### ● Screen to display bit-specified comments

Bit-specified word device comments can be displayed only on device comment editors, ladder editors, the Cross Reference window, the Watch window, and the Sampling Trace screen.

### 9.1.3 Changing text size on the device comment editor

---

Text display size can be changed on the device comment editor.

#### Operating procedure

- **Select [View] ⇒ [Text Size] ⇒ [Bigger]/[Smaller].**

The changed text size is applied to all open device comment editors.

The text display size can be changed by selecting the [Bigger]/[Smaller] button each time.

#### Point

- **Considerations when enlarging the text size**

Comment text may be truncated when the text size is enlarged.

In this case, adjust the column width or text size to display correctly.

---



## 9.2 Creating Device Comments



This section explains how to create device comments, which make it easy to understand content of program processing.

### 9.2.1 Creating comments on the device comment editor

Create device comments for each device on the same screen.

When creating local device comments, create a new device comment in advance. (☞ Section 4.3.1)


#### Screen display

- **Creating global device comments**

Select Project view ⇒ "Global Device Comment".

- **Creating local device comments**

Select Project view ⇒ "Local Device Comment" ⇒ "(data name)".



#### Operating procedure

- **Set the items on the screen.**

Item	Description
Device Name	Specify the device to be edited.
Comment*1,*2	Enter a device comment for each device.
Include the bit specification information in editing	Display the setting status of the option "Execute the operation including the hidden bit specification information"*3.

\*1 : For Universal model QCPU/LCPU, the entry field for bit-specified word device comment can be expanded/collapsed by clicking a column of "Device Name".


\*2 : The line wrapping of the device comment for display on the ladder editor and Zoom editor can be checked on "Preview".

\*3 : The option "Execute the operation including the hidden bit specification information" is set as follows:  
Select [Tool] ⇒ [Options] ⇒ "Device Comment Editor", and select "Execute the operation including the hidden bit specification information".

### Screen button

- **Show All Bit Specification Information (Universal model QCPU/LCPU only)**  
Displays all entry fields for bit-specified word device comment.
- **Hide All Bit Specification Information (Universal model QCPU/LCPU only)**  
Hides all entry fields for bit-specified word device comment.

### Point

- **Limit for the number of characters to be entered**  
Enter each device comment within 32 characters.  
The limit for the number of characters to be entered can be switched between 16 characters and 32 characters.  
( Section 12.2)
- **Cutting/copying/pasting device comments for word devices which support bit-specified word device comments**  
For Universal model QCPU/LCPU, device comments including bit-specified word device comments can be cut/copied/pasted by the following option.
  - Select [Tool] ⇒ [Options] ⇒ "Device Comment Editor", and select "Execute the operation including the hidden bit specification information".Also, device comments including bit-specified word device comments can be cut/copied/pasted by the following menus.
  - [Edit] ⇒ [Cut The Range including Hidden Bit Specification Information]
  - [Edit] ⇒ [Copy The Range including Hidden Bit Specification Information]
  - [Edit] ⇒ [Paste The Range including Hidden Bit Specification Information]

### Restrictions

- **Range selection of entry fields for bit-specified word device comment**  
When a range is selected with entry fields for bit-specified word device comment are collapsed, the last entry field for bit-specified word device comment becomes out of the range selection.  
To select the last entry field for bit-specified word device comment, expand the entry fields and select the range.

## 9.2.2 Creating comments on the ladder editor

Modify and add device comments.

### ■ Creating device comments in device comment editing mode

Example: Set 'Result of module A' to D1 and 'Initial setting is completed' to D2.

#### Operating procedure

1. Select [Edit] ⇒ [Documentation] ⇒ [Device Comment] (📄).


The mode changes to the device comment editing mode.

2. Move the cursor to the device comment entry position.




3. Press the  key.

The Input Device Comment screen is displayed.



4. Enter a device comment.

The line wrapping of the device comment for display can be checked when the comment is entered.



5. Click the  button.

The entered device comment is displayed as shown at the right.



#### Point

- **Limit for the number of characters to be entered**

Enter each device comment within 32 characters.

The limit for the number of characters to be entered can be switched between 16 characters and 32 characters.

(☰ Section 12.2)

- **Disabling the device comment editing mode**

Select the same menu option again and clear the check box from the item displayed on the screen.

- **Target of applying device comment change**

Device comments changed or added on the ladder editor are applied to global device comments.

To apply changes to local device comments, specify the reflection target for "Reference/Reflection Target for Device Comment" under [Tool] ⇒ [Options] ⇒ "Program Editor" ⇒ "All Editors" ⇒ "Device Comment".

- **Editing status of Input Device Comment screen**

The cursor is in the "Device/Label Comment" field (editing status) when the Input Device Comment screen is displayed.

The comment can be edited directly.

For copying comments repeatedly, it is useful to set the "Device/Label Comment" field to be displayed in selecting status using the following option.

Select [Tool] ⇒ [Options] ⇒ "Program Editor" ⇒ "Ladder/SFC" ⇒ "Enter ladder", and select "Do not leave the Device/Label Comment field editing status".



## ■ Creating device comments in the ladder editing mode

Device comments can be added/modified on the created ladder program on the ladder editing screen.  
Example: Set the comment 'Indication of initial start.' for X1.

### Operating procedure


- Enter ';;X1=Indication of initial start' on the ladder editor.


The entered comment is added as a device comment.



### Point

- Entering comments following element entry

Using the method explained below, a comment can be entered following an element entry in ladder editing mode. Click  in the Enter Symbol screen, or select [Tool] ⇒ [Options] ⇒ "Program Editor" ⇒ "Ladder/SFC" ⇒ "Enter ladder" and select "Enter label comment and device comment".



- Target of applying device comment change

Device comments changed or added on the ladder editor are applied to global device comments. To apply changes to local device comments, specify the reflection target for "Reference/Reflection Target for Device Comment" under [Tool] ⇒ [Options] ⇒ "Program Editor" ⇒ "All Editors" ⇒ "Device Comment".

- Considerations when entering device comments in the ladder editing mode

When entering device comments in the ladder editing mode, do not enter device comments to devices which are out of the range of device points set on the <<Device>> tab of PLC parameter because they cannot be deleted.

## 9.3 Deleting Device Comments



This section explains how to delete device comments.

### 9.3.1 Deleting comments of all devices

Delete comments of all devices on the device comment editor being displayed.

#### Operating procedure

- **Select the device comment editor** ⇒ [Edit] ⇒ [Clear All (All Devices)].  
All device comments set on the device comment editor are deleted.

### 9.3.2 Deleting comments of devices being displayed

Delete comments of devices being displayed on the device comment editor.

#### Operating procedure

- **Select the device comment editor** ⇒ [Edit] ⇒ [Clear All (All Displayed Devices)].  
All comments of devices being displayed on the device comment editor are deleted.

### 9.3.3 Deleting unused device comments

Delete device comments which are not used in the project.

#### Operating procedure

- **Select [Tool]** ⇒ [Delete Unused Device Comment].  
The device comments are deleted and the result is displayed.

#### Point

- **Device comments that cannot be deleted using the Delete Unused Device Comment function**  
The device comments which are set to the following devices cannot be deleted.
  - SM
  - SD
  - Jn\SB
  - Jn\SW
  - BL
  - BLn\S
  - BLn\TR

## 9.4 Extending Number of Points of Device Comment



The number of points of device comment can be extended by changing the mode from the standard mode to the extended mode.

Device comment can be set within the extended number of points in the project.

The following table shows the number of points of device comment that can be set in the standard mode and the extended mode.

Item	Standard mode	Extended mode
Number of points of device comment per device	32k points	192k points
Number of points of device comment per file	1024k points	2048k points

### Operating procedure

- Select "Extended mode" under [Tool] ⇒ [Options] ⇒ "Device Comment Editor".

### Point

#### ● Writing/reading device comments to/from a programmable controller CPU

- Regardless of the standard mode or the extended mode, up to the following number of device comments can be written to the programmable controller CPU.

Per device: 32k points

Total number of device comments: 64k points

When the number of set device comments exceeds the number of points that can be written to the programmable controller CPU, set the range when writing device comments to the programmable controller CPU.

(☰ Section 15.1.3)

- When merging device comments which are read from the programmable controller CPU and device comments in the project, 32k or more points of device comments which are set in the extended mode are not deleted. However, when do not merge them, 32k or more points of device comments which are set in the extended mode are deleted because the device comments are replaced with that in the programmable controller CPU. When merging device comments, select "Merge device comment with the project data at time of PLC read" under [Tool] ⇒ [Option] ⇒ "PLC Read/Write".

#### ● When changing the mode from the extended mode to the standard mode

Select "Standard mode" under [Tool] ⇒ [Options] ⇒ "Device Comment Editor" to change the mode from the extended mode to the standard mode.

Note that, however, when the number of points which exceeds the number of points that can be set in the standard mode is set, the mode cannot be changed. Delete the exceeded device comments and change the mode.

#### ● Considerations for saving GX Developer format project

[Export to GX Developer Format File] under [Project] cannot be performed when the extended mode is set.

Save the GX Developer format project after changing the mode to the standard mode.

## 9.5 Utilizing Sample Comments

This section explains how to set a sample comment of special relays/special registers and intelligent function modules automatically.

Open the device comment editor in advance.

### 9.5.1 Utilizing sample comments of special relays/special registers




Utilize sample comments of special relays/special registers.

#### Operating procedure

- Select [Edit] ⇒ [Import from Sample Comment] ⇒ [Special Relay/Special Register].

The sample comments of special relays/special registers are set on the device comment editor being edited.



#### Point

- **Project language and sample comments to be utilized**

When the project language is changed, sample comments with the language selected for the project language are utilized.


## 9.5.2 Utilizing sample comments of intelligent function modules




Utilize sample comments of intelligent function module devices and input/output signals.

### Operating procedure


1. Select [Edit] ⇒ [Import from Sample Comment] ⇒ [Intelligent Function Module].



2. Select modules whose sample comments are utilized.
3. Click the  button.

The sample comments of intelligent function module devices are set on the device comment editor being edited.

For Universal model QCPU/LCPU, bit-specified word device comments can also be utilized.



### Point

#### ● Utilizing sample comments

- Sample comments can also be utilized by right-clicking any position on the device comment editor, and selecting [Import from Sample Comment] from the shortcut menu.
- For data protected by security, device comments cannot be utilized.
- When the project language is changed, sample comments of the selected project language are utilized.

#### ● Number of characters displayed on device comment editor

The sample comments are displayed with the number of characters set in "Device Comment Editor" under [Tool] ⇒ [Options].

#### ● Considerations when utilizing sample comments

When utilizing sample comments of intelligent function module, the data size may exceed the memory capacity of the programmable controller CPU and data may not be written to a programmable controller CPU. In this case, delete unnecessary sample comments.



## 9.6 Writing/Reading Device Comments to CSV Files



This section explains how to write/read device comment data to a CSV file.

### 9.6.1 Writing/reading device comments

This section explains the writing/reading device comments to/from the CSV file. The local device comments can be written/read in a batch. (☞ Section 9.6.2)


#### ■ Writing device comment data

Write device comment data to a CSV file.

#### Operating procedure


##### 1. Select [Edit] ⇒ [Write to CSV File].

The confirmation message for writing data is displayed.



##### 2. Click the button.

The Write to CSV File screen is displayed.



##### 3. Enter a file name of the data to be saved.

##### 4. Click the button.

Device comment data is saved in the CSV file.


## ■ Reading device comment data

Read device comment data from a CSV file.

### Operating procedure

#### 1. Select [Edit] ⇒ [Read from CSV File].


The Read from CSV File screen is displayed.



#### 2. Select a file to be read.

#### 3. Click the button.

The confirmation message for reading data is displayed.



#### 4. Click the button.

Device comment data is read from the CSV file.

### Point

#### ● Device comment data for which an error message is displayed when reading data

An error message is displayed on the Output window if the following data is included when reading device comment data.

- Device comment data of devices which are not supported by the programmable controller type of the project.
- Bit-specified device comments (For programmable controller type whose project does not support bit-specified comments.)

Reading of device comment data is suspended when the number of error messages exceeds 100.

#### ● Reading device comment data whose number of characters exceeds the applicable amount

When a device comment whose number of characters exceeds applicable amount is set on the device comment editor, a warning message is displayed on the Output window and characters exceeded the applicable amount are deleted.


## ■ Setting extended settings

Set settings such as selecting target devices for writing/reading device comment data.

### Screen display

Select the **Extension Setting...** button on the confirmation message for writing/reading data.

< When reading device comment data >



### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Target Device Selection	Display all devices to which device comments can be set in a program.
Non-target	Display devices which are not to be written/read.
Target	Display devices which are to be written/read.
Read after deleting comment data of target device type*1	Select this to read devices after deleting set device comments.

\*1 : This item can be selected only when reading data.

#### 2. Click the **OK** button.

Return to the confirmation message for writing/reading data.

### Screen button

- **Add->**  
Moves devices selected for "Non-target" to "Target".
- **Add All->**  
Moves all devices displayed on "Non-target" to "Target".
- **<-Delete**  
Moves devices selected for "Target" to "Non-target".
- **<-Delete All(O)**  
Moves all devices displayed on "Target" to "Non-target".
- **Default**  
Sets the setting items to the default.

## 9.6.2 Writing/Reading local device comments in a batch


This section explains the writing/reading the local device comments in a batch by specifying the folder. This function is useful for cases, such as when switching comments between Japanese and English in the same program.

### ■ Writing data of the local device comments in a batch

Save the data of the local device comments in a batch to the specified folder. Even if there are the data of multiple local device comments, all the local device comments can be written in a batch to the CSV file just by specifying the folder. However, extended settings cannot be set.

#### Operating procedure

1. Select Project view ⇒ "Local Device Comment".
2. Right-click and select [Batch Write to Folder] from the shortcut menu.  
The Browse For Folder screen is displayed.



3. Select a folder in which the local device comments are to be stored.
4. Click the  button.

The CSV file for each local device comment is created in the folder.

## ■ Reading data of the local device comments in a batch

Read the data of the local device comments in a batch from the specified folder.


Even if there are the data of multiple local device comments, all the CSV files can be read in a batch just by specifying the folder.

However, extended settings cannot be set.

Save only the CSV file of local device comment data to the folder specified for reading. The CSV files not containing the local device comments data will be read as an empty local device comment.

### Operating procedure

1. Select Project view ⇒ "Local Device Comment".
2. Right-click and select [Batch Read from Folder] from the shortcut menu.  
The Browse For Folder screen is displayed.



3. Select a file to be read.
4. Click the  button.  
Multiple local device comments are read from the folder.

### Point

#### ● Device comment data for which an error message is displayed when reading data

An error message is displayed on the Output window if the following data is included when reading device comment data.

- Device comment data of devices which are not supported by the programmable controller type of the project.
- Bit-specified device comments (For programmable controller type whose project does not support bit-specified comments.)

Reading of device comment data is suspended when the number of error messages exceeds 100.

#### ● Reading device comment data whose number of characters exceeds the applicable amount

When a device comment whose number of characters exceeds applicable amount is set on the device comment editor, a warning message is displayed on the Output window and characters exceeded the applicable amount are deleted.

### 9.6.3 CSV file format

A title name of device comment editor and a title name of CSV file are linked.

- Data of the column whose title matches with the title of the device comment editor are read to the device comment editor.
- Data of the column whose title does not match with the title of the device comment editor are not read.
- Data can be read even when the sorted order of CSV file does not match with the sorted order of the device comment editor.

The following is an image of the saved CSV file opened in spreadsheet software.

< Device comment editor >

Device Name	Comment
X0	Module READY
X1	
X2	Cntr val lrg(pt No. 1)
X3	Cntr val coince(pt No. 1)
X4	Cntr val sml(pt No. 1)
X5	
X6	Extrnl prst rqst dtc

< CSV file >

Device Name	Comment
X0	"Module READY"
X2	Cntr val lrg(pt No. 1)
X3	Cntr val coince(pt No. 1)
X4	Cntr val sml(pt No. 1)
X6	Extrnl prst rqst dtc

#### ● Details of CSV file

The following indicates the details of CSV file format.

- The file format is Unicode (including UTF-16, Little Endian, and BOM).
- The delimiter of items is a tab (t).
- Each item is enclosed in double quotation marks (").
- If the item contains double quotation marks ("), the double quotation marks in the item are expressed as two double quotation marks (").
- A line feed is set at the end of the line.  
The line feed code is CR+LF.
- A blank space is handled as a regular character.

< Image of device comments in CSV file >

```
"SYOKIKA"
"Device Name"  "Comment"
"X0"          ""Module READY""
"X2"          "Cntr val lrg(pt No. 1)"
"X3"          "Cntr val coince(pt No. 1)"
"X4"          "Cntr val sml(pt No. 1)"
"X6"          "Extrnl prst rqst dtc"
```

---

# 10 SEARCH/REPLACE

This chapter explains the operation methods for searching for/replacing the character strings used in programs.

10.1	Cross Reference	10 - 2
10.2	Device List	10 - 13
10.3	Search/Replacement	10 - 17

## 10.1 Cross Reference

Q CPU L CPU Remote Head FX

This section explains how to create and display the cross reference information, which shows a list of locations where devices/labels selected on the program editor/label setting editor are used. The Cross Reference window is displayed horizontally when it is docked on top or bottom of the main frame, and displayed vertically when it is docked on left or right of the main frame.

### ■ Target data for creating cross reference information

Cross reference information is created based on devices used in the following editors/parameters.

- Ladder
- SFC
- ST
- Structured Ladder/FBD
- Global label
- Local label
- Structure
- Multiple CPU refresh setting of PLC parameter
- Simple PLC communication setting of PLC parameter
- Refresh parameters of network parameter
- Auto refresh setting of intelligent function module parameter
- Block information of SFC program


### 10.1.1 Creating/displaying cross reference information

Create and display cross reference information of the label/device selected on the program editor/label setting editor.

#### Screen display

Select [View] ⇒ [Docking Window] ⇒ [Cross Reference] ()

<<Cross Reference Information>>





**Operating procedure**

**1. Specify the conditions to create cross reference information as necessary.**


By setting the conditions, the operation such as: searching for a label definition on the label setting editor, displaying hierarchy of structure/array/FB, and displaying a start device and end device of the instruction such as the DMOV instruction which uses two or more points of device, can be performed. (Section 10.1.2)

**2. Select a device/label on the program editor/label setting editor.**


**3. To specify the range to be searched, select a search location by clicking the**

**Browse...** button of "Find in".

Two or more search locations can be selected.

Click  to select a location from the list of previously searched locations. The location cannot be entered directly.


This function is not supported by FXCPU.




**4. Click the  button.**

The cross reference information is created and the result is displayed.

When the range to be searched is specified and "Find Label Definition" on the <<Condition Setting>> tab is selected, the cross reference information of global labels, FBs, and structures is also created other than the information of specified search location.

By pressing the  key after selecting a row in the result list, or by double-clicking or right-clicking the selected row and selecting [Jump] from the shortcut menu, the editor in which the device/label is used opens and the corresponding device/label becomes in the selected status. The following screen is a result of a Structured project in which "Display all items" and "Display hierarchically" are selected on the <<Condition Setting>> tab.



9 SETTING DEVICE COMMENTS

10 SEARCH/REPLACE

11 PRINTING

12 SETTING OPTIONS



13 USING LIBRARIES

14 SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15 WRITING/READING DATA

16 PROTECTING DATA

## Display contents

Item	Description
Attributes	Display icons which indicate attributes of devices/labels. (  'Icons to indicate attribute' in this section)
Device/Label	Display the device/label name.
Class* <sup>1,2</sup>	Display the class of the device/label.
Label Data Type* <sup>1,2</sup>	Display the data type of the device/label.
Constant* <sup>1,2</sup>	Display the constant value set for VAR_GLOBAL_CONSTANT or VAR_CONSTANT.
Device* <sup>1</sup>	Display the device assigned to the label (automatically assigned device).
Address* <sup>2,3</sup>	Display the address of the device/label.
Read/Write	Display whether Read or Write the device/label is.
Instruction* <sup>2,4</sup>	Display the name of the instruction in which the device/label is used.
Ladder Symbol	For ladder programs, display elements of instruction in which devices are used.
Position	Display the position which identifies the location of the device/label. (  'Position information' on the next page)
Project* <sup>3</sup>	Display the project name or the library name in which the device/label is used.
Program File Name* <sup>3</sup>	Display the program file name in which the device/label is used.
Task* <sup>3</sup>	Display the task name of the program registration destination in which the device/label is used.
Data Type	Display the type of data in which the device/label is used.
Data Name	Display the program or the data name registered in the program in which the device/label is used. Display the block name for SFC program.
Comment* <sup>2</sup>	Display the comments of the device/label.
System Label Name* <sup>1,2</sup>	Display the system label name which corresponds to the global label. For devices/labels set for SFC block information, this column will be blank.

\*1 : These items are not displayed in Simple project (without labels).

\*2 : Only when "Display all items" is selected on the <<Condition Setting>> tab.

\*3 : For Structured projects only

\*4 : For ladder programs and SFC (Zoom) programs only


## Screen button

### Print Window...

Prints the selected row. ( Section 11.7)

Prints all lists when a row is not selected.

### Print Window Preview


Displays a print preview of the selected row. ( Section 11.9)

Displays a print preview of all lists when a row is not selected.

## Point

### ● Creating cross reference information

- Cross reference information can also be created by right-clicking a device/label on the program editor, and selecting [Cross Reference] from the shortcut menu.

Cross reference information can also be created based on all devices/labels by clicking the  button without specifying devices/labels after the Cross Reference window is displayed.

- The maximum number of creation results of the cross reference information is 80,000. However, since the internal data that are not displayed are included to the results, the number of results to be displayed in the cross reference information may not reach 80,000.  
When "Auto-tracking" is selected on the <<Condition Setting>> tab, the maximum number of creation results of the cross reference information is 500.











### ● When a search location is selected from the list

When a program file name or an execution type is changed, the target program file may not be listed in "Find in". In this case, cross reference information of the program files whose name matches is created.


### ● Jump function

The jump function cannot be used for the cross reference information of parameters, block information, and block start steps.

### ● Moving the focus

-  (  +  ) moves the focus between the editor and the Cross Reference window.
-  (  +  ) /  +  (  +  ) moves the cursor to the previous/next row.

### ● Displaying comments

In a ladder/SFC project, comments specified in [Tool] ⇒ [Options] ⇒ "Program Editor" ⇒ "All Editors" ⇒ "Device Comment" ⇒ "Reference/Reflection Target for Device Comment" are displayed as device comments.  
( Section 9.1.1)

### ● Searching cross reference information with label definitions

The time to display the creation results of the cross reference information becomes longer when the number of results exceeds 80,000 substantially.

When labels contain array elements exist, this symptom can be avoided by clearing the check box of "Display hierarchically" on the <<Condition Setting>> tab.

### ● Searching label names which are combined with symbols of the timer device or counter device and device number

When a label name, which is combined with the following characters (device symbol + number), is entered to "Device/Label" on the Cross Reference window, it will be searched as a device.

To display the cross reference information of the label, select "All Device/Label" in "Device/Label", enter the label name to "Device/Label", and filter the cross reference information.

Device	Symbol	Example of label name
Timer device	TS, TC, TN	TS10
Counter device	CS, CC, CN	CC50
Retentive timer device	STS, STC, STN, SS, SC, SN	sn100

## Restrictions

### ● When "Create cross reference information after completion compile" is selected in the option setting

- When timer device (T) is specified as a search condition, devices of contact (TS), coil (TC), and current value (TN) also become search targets. When any of the timer devices: contact (TS), coil (TC), or current value (TN), is specified, timer device (T) is also searched along with the specified device.  
The same operation as above applies when specifying retentive timer device or counter device.
- When device/label which is not indexed is specified as a search condition, only devices/labels which are not indexed are searched.

## ■ Icons to indicate attribute

The following table shows icons displayed according to the attribute of device/label.


When the attribute is label, an icon is displayed with a combination of class and data type as shown in the display example.

Attribute	Icon	Description	Display example
Device		Displayed when the attribute is device.	
Label	-	-	-
Class		Displayed when the label class is VAR_GLOBAL.	
		Displayed when the label class is VAR_INPUT.	
		Displayed when the label class is VAR_OUTPUT.	
		Displayed when the label class is VAR_IN_OUT.	
Data type		Displayed when the label data type is simple data type.	
		Displayed when the label data type is function block.	
		Displayed when the label data type is structure.	
Label usage		Displayed when labels are used in a program.	

## ■ Position information

The following position information is displayed according to the editor.

Type	Description	Example
Ladder editor	Step number	Step No. 5
ST editor	Number of lines	Row No. 2
SFC editor*1	SFC symbol and step number	SFC Step No. 3, Step No. 4
Structured Ladder/FBD editor	Ladder block number and grid position	2. (10. 2)
Label Setting screen, Structure Setting screen	Row number	1
Parameter	Name of parameter item to which devices are set	Auto Refresh
Block information of SFC program	Name of block information to which devices/ labels are set	Block START/END Bit
Inline structured text	STB step (number of lines)	STB 3 (Row No.2)

\*1 : For the SFC block number, check the property of block (program) displayed in "Data Name". (For details of properties  Section 4.3.6)

## ■ Displaying cross reference information

### ● Displaying cross reference information in uncompiled state





For a project with labels, cross reference information can be created based on the compilation result, and it can be displayed even in an uncompiled state.

To display cross reference information in an uncompiled state, perform one of the following operations.

- Select "Fast Find" on the <<Condition Setting>> tab.  
This item can be set for Simple projects (with labels) only.  
For details of "Fast Find", refer to Section 10.1.2.
- Select [Tool] ⇒ [Options] ⇒ "Compile" ⇒ "Basic Setting", select "Create cross reference information after completion compile", and execute the compilation.  
By setting this item, the cross reference information can be displayed quicker while the compilation time gets longer.

### ● Display after creation of cross reference information is completed

The icon on the bottom left of the screen changes according to the status of the displayed cross reference information.

Icon	Status of cross reference information
	Indicate the cross reference information is updated.
	Indicate the project has been changed after the cross reference information is created.
	Indicate the cross reference information cannot be used. For instance, cross reference information has not been created.
	Indicate the cross reference information created in past is displayed. (Only when "Fast Find" is selected.)

- The data protected by security cannot be displayed.
- If the program or the option setting is changed, the cross reference information does not correspond with the program. In order to update the cross reference information, create it again.
- Each column can be sorted in ascending/descending order by clicking on the column header. However, the sort cannot be performed if the structure/array/FB is displayed in the tree. To cancel the display in the tree, clear "Display hierarchically" and "Display the last device of multiple points device" on the <<Condition Setting>> tab.

### ● Deleting data after compiling a program

When data is deleted after the program is compiled, the deleted data may be displayed as a search result.

To display the most recent cross reference information, compile the program and create cross reference information again.

### ● Searching for multiple word (such as DMOV instruction) in a ladder program

When a negative constant (example: K-1) is specified for device/label, an incorrect search result may be displayed.

In this case, perform the search function by specifying all devices/labels, and check the search result.

### ● Searching for refresh device of CC-Link parameter

For refresh devices (RX/RV) set in a local station or standby station of the CC-Link parameter, the target of search is only the first 16 points of devices.

### ● When the same name is used for label and device

The Auto-tracking function of cross reference gives devices a priority to be searched.

To display cross reference information of label whose name is the same as that of device, search for "All Device/Label" in "Device/Label". Then, enter a label name in the "Device/Label" column of filtering condition, and execute the filtering display.



● Searching for BL devices

When BLn is specified for the device to be searched, the block start steps for n block start are also searched.

"BLOCK" (with END check) or "BLOCK-S" (without END check) is displayed in the "Instruction" column on the Cross Reference window.


■ Displaying/hiding columns

Columns in the screen can be displayed or hidden by right-clicking a column header of the cross reference information and selecting the items to be displayed or hidden from the shortcut menu.



■ Displaying devices/labels that use FB instance

To create the cross reference information from the devices/labels used in the function block, select the FB instance to create the cross reference information.




## 10.1.2 Setting conditions

Conditions are set on the <<Condition Setting>> tab on the Cross Reference window. Whenever the condition is changed, the cross reference information needs to be recreated.

### Screen display

Select the <<Condition Setting>> tab on the Cross Reference window.



### Operating procedure

- Set the items on the screen.

Item	Description
Find Condition	—
Find label definition	Select this to search each label setting editor.
Find Constant (K,H)	Select this to search the constant (K and H).
Find Device other than the Head	Select this to search devices following the start device of digit-specified device/multiple word device.
Specify find order*1	Specify the search order.
Display Condition	—
Display all items	Select this to display all items that can be created in the cross reference information.
Display hierarchically	Select this to display a structure/array/FB hierarchically.
Display the last device of multiple points device*2	Select this to display the start and last devices when a device which uses two or more points in a instruction is specified.
Find Mode	—
Auto-tracking*3, *4	Select this to create cross reference information of devices/labels selected on the editor automatically.
Auto-Tracking Only in Click/Key Operation	Select this to update cross reference information only when the cursor is moved by clicking the mouse or pressing the key. When this item is selected, the Auto-tracking function does not apply to the operations with the mouse wheel and the scroll bar.
Fast Find*5	Select this to display cross reference information more quickly. Only "Device/Label", "Device", "Instruction", "Ladder Symbol", "Position", and "Data Name" are displayed. ST programs, inline structured text programs, and the second hierarchy of function block in ladder programs are not searched. By selecting this item, the setting of "Create cross reference information after completion compile" under [Tool] => [Options] => [Compile] => "Basic Setting" is disabled.
Explanation	Display the explanation of the condition item.

\*1 : For QCPU (Q mode) excluding Basic model QCPU and LCPU only

\*2 : For ladder programs and SFC (Zoom) programs only

\*3 : The Auto-tracking does not function in the following cases.  
When the ladder editor is in device display.  
When the ladder editor is in edit line mode/delete line mode.

\*4 : For projects with labels, this item can be selected when "Create cross reference information after completion compile" is selected under [Tool] => [Options] => [Compile] => [Basic Setting], or when "Find Mode" is selected on the <<Condition Setting>> tab.

\*5 : For Simple projects (with labels) only


**Point**

● **"Specify find order" on the <<Condition Setting>> tab**

The search order of the "Specify find order" function and the display order of search result are as follows.

- When "Do not specify" is selected, data are searched in the order of data name.  
The search result is displayed in the order of parameters, programs, and labels.
- When "Program Setting" is selected, data are searched in the order of program files set on the <<Program>> tab of PLC parameter.  
The search result is displayed in the order of local label and program, global labels, and parameters.

Note that when "Fast Find" on the <<Condition Setting>> tab is selected or "Create cross reference information after completion compile" in the option setting is selected, "Do not specify" is set for "Specify find order".



Search order when "Program Setting" is selected.

● **"Display the last device of multiple points device" on the <<Condition Setting>> tab**

The last device of the device which uses multiple device points in an instruction or refresh parameter can be displayed. Select "Display the last device of multiple points device" on the <<Condition Setting>> tab to display the last device. The start and last devices are displayed in a tree format as shown below.

Device/Label	Device	Instruction	Position	Data Name
Filtering Condition	Filtering ...	Filtering Condit...	Filtering Condition	Filtering Condition
X0	X0	LD	Step No.0	MAIN
D0	D0	DMOV	Step No.1	MAIN
D10	D10	DMOV	Step No.1	MAIN
[Start]	D10			
[End]	D11			

● **"Auto-tracking" on the <<Condition Setting>> tab**

For ladder program, devices/labels of second and the following arguments of the instruction are also automatically tracked.

To display cross reference information of second and the following arguments of the instruction during the Auto-tracking mode, perform the following operations.

- For a project without labels, select from the "Device/Label" input column.
- To search devices in a project with labels, select from the "Device" column of filtering condition.
- To search labels, select from the "Device/Label" column of filtering condition.

● **"Find Mode" on the <<Condition Setting>> tab**

If "Find Mode" is selected, cross reference information is automatically created when the following operation is performed.

- Changing a ladder or SFC (Zoom) program
- Compiling a program
- Adding/deleting program data
- Reading data from a programmable controller CPU
- Changing a programmable controller type



## 10.1.3 Filtering display


Filter the created cross reference information.

Elements cannot be filtered.

The following is an example of display by filtering devices/labels with the condition 'D\*'.  



### Operating procedure

1. Enter 'D\*' in the filtering condition column under "Device/Label".




2. Press the **Enter** key.

The data matching with the set filtering condition are displayed on the Cross Reference window.



**Point**

- **Filtering condition**

Clicking  enables to select a keyword from the list of previously entered keywords.

For "Data Name" and "Program File Name", search results can also be selected from the list as well as previously entered keywords.

- **Tree display of filtering condition**

Only data whose components match with the filtering conditions are displayed in the tree format when filtering display is executed for the structure data names or the instance names of the function block.

- **Deleting filtering condition**

Filtering display of the column can be canceled by deleting keywords entered in each filtering condition column.

- **Keywords for filtering condition**

The wild card characters can be used in a filtering condition shown as below.

Example) When the filtering condition is set for the device/label column.

Wild card	Search target	Example	Search Result
*	Specifies any character string.	*30*	ready301, K4X30, K1Y30, K4Y30
?	Specifies any one character.	K4?30	K4X30, K4Y30
[ ]	Specifies any one of those characters.	[XY]8	X8, Y8
[! ]	Specifies any one of characters except for the characters in the bracket.	K4X[!3]0	K4X40, K4Y50
[ - ]	Specifies character strings within the range in the bracket.	D[0-2]	D0, D1, D2
#	Specifies any one-digit number.	Local200#	Local2001, Local2003

## 10.2 Device List

Q CPU L CPU Remote Head FX

This section explains how to display the usage of the specified devices.

### ■ Target data


Devices used in the following data are displayed in the device list.

- Ladder
- SFC
- ST
- Structured Ladder/FBD
- Multiple CPU refresh setting of PLC parameter
- Simple PLC communication setting of PLC parameter
- Refresh parameters of network parameter
- Auto refresh setting of intelligent function module parameter

### 10.2.1 Displaying device list





#### Screen display

Select [Find/Replace] ⇒ [Device List].



### Operating procedure




#### 1. Set the items on the screen.

Item		Description
Device		Enter a device to be searched for. Click  to select a device from the list of previously searched devices.
Find In		Select a location to search for. Click  to select a location to search for. Two or more search locations can be selected. After selecting the search location, click the  button to save the search location. Click  to select a location from the list of previously searched locations. The location cannot be entered directly.
Display Option	All devices	Display all devices.
	Used devices	Display devices used in the program. Selected items are searched.
	Unused devices	Display devices not used in the program.
Number of Find Points	65536 Points	Select this to set device points to be searched to 65536 points.
	512 Points	Select this to set device points to be searched to 512 points.

#### 2. Click the button.


Search result is displayed.



### Display contents



Item	Description
Find Range	Display the range of the devices searched. The display can be switched by clicking the  /  button.
Device	Display the device name.
Contact	Display '*' when the device is used as a contact.
Coil (counts)	Display '*' and the number of uses when the device is used as a coil.
Parameter*1	Display '*' when the device is used as a parameter or an intelligent function module parameter.
Comment	Display the device comment set for reference/reflection target in the option setting. (  Section 9.1.1 "■ Specifying device comments to be displayed in program") Specify a program for "Find In" to enter device comments.

\*1 : Not supported by FXCPU.

### Screen button

- 



Prints the selected row. ( Section 11.7)  
Prints all lists when a row is not selected.
- 

Displays a print preview of the selected row. ( Section 11.9)  
Displays a print preview of all lists when a row is not selected.
- 

Deletes device comments which are not used in a program in device units.

## ■ Displaying/hiding columns

Columns can be displayed or hidden by right-clicking a column header of the search result and selecting the items to be displayed or hidden from the shortcut menu.



## ■ Considerations of search in device list

---

The following shows the considerations of search in the device list.

### ● Handling of coil instructions

As output instructions, the following application instructions can also be the target of search. SET, RST, PLS, PLF, FF, SFT, SFTP, and MC

### ● Searching for R devices and ZR devices

R devices and ZR devices are distinguished in the device list. Specify them separately when searching for R devices or ZR devices.

### Point

---

### ● Saved search locations

When the name of the program specified in the search location is changed, the program is not searched. In order to search the program with the changed name, specify the program in the search location.

Note that, however, when the program name is changed to the original name, the program is searched.

### ● Confirming locations of devices

The Cross Reference window can be opened from a used device displayed in the device list, and the location of the device can be confirmed.

To open the Cross Reference window, select a desired row in the device list and follow any of the following operations.

- Press the **Ctrl** + **E** keys or press the **Enter** key.
- Double-click the row.
- Right-click the row and select [Cross Reference] from the shortcut menu.

For the cross reference function, refer to Section 10.1.

### ● Displaying comments

- When searching for data with a selection of one program, device comments specified for "Reference/Reflection Target for Device Comment" under [Tool] ⇒ [Options] ⇒ "Program Editor" ⇒ "All Editors" ⇒ "Device Comment" are displayed. (☞ Section 9.1.1)
  - When searching for data with a selection of two or more programs, global device comments are displayed.
-

## 10.3 Search/Replacement



This section explains how to search for and replacing character strings, devices, labels, instructions, etc. in project data.

If the All Find/All Replace function is executed, the details of the execution result are displayed.

### Point

#### ● Purposes of each search/replacement

The following table shows the purposes of each search/replacement.

Function	Purpose
Find Device/Replace Device	Used for searching for/replacing a device or label in a program.
Find Instruction/Replace Instruction	Used for searching for/replacing an instruction in a program.
Find String/Replace String	Used for searching for/replacing a character string used in a program, label, and device comment.
Change Open/Close Contact	Used for switching the contact type of a specified device in a program from normal to negation, or from negation to normal.
Device Batch Replace	Used for searching for/replacing devices or labels in a program in batch.

#### ● Displaying the Find/Replace screen

The Find/Replace screen can also be displayed by selecting [View] ⇒ [Docking Window] ⇒ [Find/Replace].

#### ● Replace function

- The programs are in the uncompiled status after the Replace function is executed. Compile all the programs again.
- The Replace function cannot be executed during monitoring. Execute the function after monitoring is finished.
- The Replace function cannot be executed when a program is opened with the read-only mode. Execute the function after setting the data in editable mode by the setting such as resetting the security.

#### ● Searching/replacing labels

One point of device can be replaced when searching/replacing labels.

#### ● Searching/replacing data in inline structured text box

The search starts from the top of the program in the inline structured text box regardless of the cursor position.

#### ● Replacement of items corresponding to system labels

The following items that correspond to system labels cannot be replaced.


- Relation with system label
- System label name
- Attribute

### 10.3.1 Searching/replacing devices/labels

Search/replace devices/labels in the program.

#### Screen display

Select [Find/Replace] ⇒ [Find Device]/[Replace Device] (F5).



#### Operating procedure

##### 1. Set the items on the screen.

Item		Description
Find In		Click the <b>Browse...</b> button to select a location to search for. Two or more search locations can be selected.
		Click <b>▼</b> to select a location from the list of previously searched locations. The location cannot be entered directly.
Find Device		Enter a device/label to be searched for or a replacing device/label.
Replace Device		Click <b>▼</b> to select from the list of devices or labels entered previously.
Device Point		Enter the number of points to be searched/replaced, counted from the device entered in the "Find Device" field. When a label is entered for "Find Device" or "Replace Device", enter 1.
		Click <b>▼</b> to select either hexadecimal or decimal for the value to be used. Example) When X50 for "Find Device", X100 for "Replace Device", 3 for "Device Point", and "DEC" for entered value are set, the devices are replaced as shown below. X50→X100, X51→X101, X52→X102
Find Direction	From Top	Select this to execute a search in the downward direction from the start of the program.
	Down	Select this to execute a search in the downward direction from the cursor position.
	Up	Select this to execute a search in the upward direction from the cursor position.
Option	Digit*1	Select this to execute a search for the entered device and digit-specified bit devices that include the entered device.
	Multiple word*1	Select this to execute a search for the entered device and the double-word format (double word/real number/indirect specification) word devices that include the entered device.
	Consecutive search with enter key	Select this not to move the focus to the editor after the search/replace function. The searched/replaced position may not be highlighted.
Device Comment*2	Move	Select this to move a device comment of "Find Device" to "Replace Device".
	Copy	Select this to copy a device comment of "Find Device" to "Replace Device".
	Not to Change	Select this not to move or copy a device comment of "Find Device".

\*1 : For ladder programs, SFC (Zoom) programs, Structured Ladder/FBD programs, and ST programs only

\*2 : For ladder programs and SFC (Zoom) programs only



## 2. Click the **Find Next** button.

The cursor moves to the searched device.

### Screen button

- **Find Next**  
Searches for the character string entered in "Find String".
- **All Find**  
Batch searches for the character string entered in "Find String".  
The search result is also displayed. (☞ Section 10.3.6)
- **Replace**  
Replaces the character string entered in "Find String" with the character string entered in "Replace String".
- **All Replace**  
Batch replaces the character string entered in "Find String" with the character string entered in "Replace String".  
The replace result is also displayed. (☞ Section 10.3.6)

## ■ Examples of device search

The following tables show examples of specification for device search operations.

### ● Example of device search (Option: None)

Device specification	Search result ( For ladder program )
M0	<u>M0</u> , <u>K4M0</u> , <u>M0Z0</u> , <u>K4M0Z0</u>
K4M0	<u>K4M0</u> , <u>K4M0Z0</u>
D0	<u>D0</u> , <u>D0Z0</u> , <u>D0.1</u>
D0.1	<u>D0.1</u>
J1\B0*1	<u>J1\B0</u> , <u>J1\B0Z0</u> , <u>J1Z0\B0</u> , <u>J1Z0\B0Z0</u> , <u>J1\K4B0</u> , <u>J1\K4B0Z0</u> , <u>J1Z0\K4B0</u> , <u>J1Z0\K4B0Z0</u>

\*1 : Not supported by FXCPU.

### ● Example of device search (Option: Digit)

Device specification	Search result ( For ladder program )
X0 to X3	<u>K1X0</u>
X0 to X0F	<u>K4X0</u>
X0 to X1F	<u>K8X0</u>
X0Z0	<u>X0Z0</u> , <u>K1X0Z0</u> , <u>K4X0Z0</u> , <u>K8X0Z0</u>

### ● Example of device search (Option: Multiple word)

Device specification	Search result ( For ladder program )
D0 to D1	<u>DMOV K1 D0</u> , <u>EMOV E1 D0</u> , <u>DMOV K1 @D0</u>
D0 to D9	<u>BMOV D0 D100 K10</u>
D0Z0 to D1Z0	<u>DMOV K1 D0Z0</u>
ZR0ZZ0 to ZR1ZZ0*1	<u>DMOV K1 ZR0ZZ0</u>
J1\W0 to J1\W1*1	<u>DMOV K1 J1\W0</u>
@D0 to @D1*1	<u>DMOV K1 @D0</u>
T0 to T1	<u>DMOV K1 T0</u>
T0Z0 to T1Z0	<u>DMOV K1 T0Z0</u>

\*1 : Not supported by FXCPU.

## ■ Devices/labels that can be replaced or batch replaced

The following table shows the devices/labels that can be replaced or batch replaced.

○: Replaceable x: Not replaceable

	New device/label								
	Device (X0, D0)	Bit-specified word device (D0.1*1)	Word device indirect specification*2 (@D0)	Digit-specified bit device (K1X1)	Index setting (X0Z0)	Digit-specified bit device + Index setting (K4X0Z0)	Index setting + Bit-specified word device (J1Z0\W0.1*2)	Label/ String (g_bool1)	
Old device/ label	Device (X0, D0)	○	○	○	○	○	x	x	○
	Bit-specified word device (D0.1*1)	○	○	x	x	x	x	x	○
	Word device indirect specification*2 (@D0)	x	x	x	x	x	x	x	○
	Digit-specified bit device (K1X1)	x	x	x	x	x	x	x	○
	Index setting (X0Z0)	x	x	x	x	x	x	x	○
	Digit-specified bit device + Index setting (K4X0Z0)	x	x	x	x	x	x	x	○
	Index setting + Bit-specified word device (J1Z0\W0.1*2)	x	x	x	x	x	x	x	○
	Label/String (g_bool1)	○	○	○	○	○	○	○	○

\*1 : Supported by FX3U and FX3UC only.

\*2 : Not supported by FXCPU.

9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA

## ■ Searching/replacing devices/labels in inline structured text program

The following explains the considerations when searching/replacing devices/labels in the inline structured text program.

### ● Searching/replacing devices

Devices in the range specified for the parameter are searched. Devices out of the specified range are not searched.

### ● Searching/replacing labels

Both registered and unregistered labels are searched. All unregistered labels which are used at the label positions in the inline structured text program are searched.

The following table shows the examples of label positions.

Label position	Example	Description
Applicable label position	label1	Labels exist independently.
	MOV (label1, D0, D1);	Labels used at label positions in functions.
Inapplicable label position	label1 (m1, m2)	Labels used at instruction positions.

### ● Comments in inline structured text program

Strings which are recognized as comments are not searched.

The following table shows the examples of comments.

String	Example	Description
String recognized as comment	(* D1 *)	Strings between the comment start symbol and the end symbol.
	(* D1...	Strings following the comment start symbol when the comment does not end with the end symbol.
String not recognized as comment	D1 *)	Strings in front of the comment end symbol when the comment start symbol is not used.

### ● Device/label names


Device/label names are not case-sensitive.

## 10.3.2 Searching/replacing instructions

Search/replace instructions.

### Screen display

Select [Find/Replace] ⇒ [Find Instruction] (  )/[Replace Instruction]/[Find Contact or Coil] (  ).










Element selection area

Device instruction input area

### Operating procedure

1. Set the items on the screen.

Item		Description
Find In		Click the  button to select a location to search for. Two or more search locations can be selected. Click  to select a location from the list of previously searched locations. The location cannot be entered directly.
Find Instruction	Element selection area	Click  to select an element to be searched for from the list.
	Device instruction input area	Enter an instruction, device, or label to be searched for. Click  to select from the list of instructions, devices, or labels entered previously.
Replace With	Element selection area	Click  to select a replacing element from the list.
	Device instruction input area	Enter a replacing instruction, device, or label. Click  to select from the list of instructions, devices, or labels entered previously.
Find Direction	From Top	Select this to execute a search in the downward direction from the start of the program.
	Down	Select this to execute a search in the downward direction from the cursor position.
	Up	Select this to execute a search in the upward direction from the cursor position.
Option	Consecutive search with enter key	Select this not to move the focus to the editor after the search/replace function. The searched/replaced position may not be highlighted.

2. Click the  button.

The cursor moves to the searched instruction.

### Screen button

For the screen buttons, refer to Section 10.3.1.

### Examples of instruction search

The following table shows the examples of instruction search.

Instruction specification	Search result
MOV	MOV, MOVP
MOVP	MOVP
MOV D0 K4Y0	MOV D0 K4Y0, MOVP D0Z1 K4Y0, MOV D0 K4Y0Z1, MOVP D0Z1 K4Y0Z1
MOVP D0 J1W0*1	MOVP D0 J1W0, MOVP D0Z1 J1W0, MOVP D0 J1Z1W0Z1, MOVP D0Z1 J1Z1W0Z1

\*1 : Not supported by FXCPU.

### Considerations for searching for/replacing instructions

The following explains the considerations for searching for/replacing instructions.


#### ● Instruction search specifying a coil instruction

As output instructions, the following application instructions can also be the target of search.  
SET, RST, PLS, PLF, FF, SFT, SFTP, and MC

#### ● Instruction replacement between a 16-bit (word) instruction and a 32-bit (double word) instruction

When a 16-bit (word) instruction is replaced with a 32-bit (double word) instruction, and if a constant is set for the device, the constant value is not sign-extended to a value in 32 bits.

Example



When a 32-bit instruction is replaced with a 16-bit instruction, and if a constant is set for the device, upper 16 bits are discarded.

Example



#### Point

#### ● Searching for NOP instructions and TRAN instructions


The NOP instructions used in the ladder programs and the TRAN instructions used in the transition condition of SFC programs cannot be searched.

### 10.3.3 Searching/replacing character strings

Search/replace character strings.

#### Screen display

Select [Find/Replace] ⇒ [Find String]/[Replace String].



#### Operating procedure

##### 1. Set the items on the screen.

Item		Description
Find In		Click the <b>Browse...</b> button to select a location to search for. Two or more search locations can be selected. Click <b>▼</b> to select a location from the list of previously searched locations. The location cannot be entered directly.
Find String		Enter a character string to be searched for or a replacing character string.
Replace String		Click <b>▼</b> to select a character string from the list of character strings entered previously.
Find Direction	From Top	Select this to execute a search in the downward direction from the start of the program.
	Down	Select this to execute a search in the downward direction from the cursor position.
	Up	Select this to execute a search in the upward direction from the cursor position.
Option	Match case	Select this to execute a case-sensitive search.
	Match whole word only	Select this to execute a search by matching whole word only. For details of the whole word, refer to Point in this section.
	Do not search comments in program	Select this to exclude line statements, PI statements, notes, and comments in programs from the search target.
	Consecutive search with enter key	Select this not to move the focus to the editor after the search/replace function. The searched/replaced position may not be highlighted.

##### 2. Click the **Find Next** button.

The cursor moves to the searched character string.

#### Screen button

For the screen buttons, refer to Section 10.3.1.

**Point**

- **Searching for NOP instructions and TRAN instructions**

The NOP instructions used in the ladder programs and the TRAN instructions used in the transition condition of SFC programs cannot be searched.

- **Searching/replacing data by matching whole word only**

The whole word means a string separated by the break characters. The search/replace by matching whole word searches for only the character strings which are completely match with the character string entered in "Find String". Break characters are shown as below.

- Space, tab, line feed

Example) Searching for a device comment 'abc ; def' by the following character strings.

String to be searched for	Search result	
	Not selected	Selected
a	<u>a</u> bc ; def	Nothing is found.
abc	<u>abc</u> ; def	<u>abc</u> ; def
bc	<u>bc</u> ; def	Nothing is found.
abc ; def	<u>abc ; def</u>	<u>abc ; def</u>




### 10.3.4 Changing contacts between open contact and closed contact

Change contact types from open contact to closed contact, and conversely, from closed contact to open contact.

#### Screen display

Select [Find/Replace] ⇒ [Change Open/Close Contact].



#### Operating procedure

1. Set the items on the screen.

Item		Description
Find In		Click the <b>Browse...</b> button to select a location to search for. Two or more search locations can be selected. Click <b>▼</b> to select a location from the list of previously searched locations. The location cannot be entered directly.
Replace Device		Enter a device/label of which the contact type is to be changed between open contact and closed contact. Click <b>▼</b> to select from the list of devices/labels entered previously.
Device Point		Enter the number of points to be searched/replaced, counted from the device entered in the "Replace Device" field. When a label is entered for "Replace Device", enter 1. Click <b>▼</b> Click to select either decimal or hexadecimal for the value to be entered.  Example) When X100 for "Replace Device", 3 for "Device Point" and "DEC" for entered value are set, the contact type is replaced between open contact and closed contact at X100, X101 and X102.
Find Direction	From Top	Select this to execute a search in the downward direction from the start of the program.
	Down	Select this to execute a search in the downward direction from the cursor position.
	Up	Select this to execute a search in the upward direction from the cursor position.
Option	Consecutive search with enter key	Select this not to move the focus to the editor after the search/replace function. The searched/replaced position may not be highlighted.

9 SETTING DEVICE COMMENTS  
 10 SEARCH/REPLACE  
 11 PRINTING  
 12 SETTING OPTIONS  
 13 USING LIBRARIES  
 14 SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION  
 15 WRITING/READING DATA  
 16 PROTECTING DATA

2. Click the **Find Next** button.

The cursor moves to the searched device.

3. Click the **Replace** or **All Replace** button to change the contact type.

The contact types are changed from open to closed contact and from close to open contact, and the search for the next target devices continues.

If the **All Replace** button is clicked, all contact types of searched devices are batch changed from open to closed contact and from close to open contact.

**Point**

● **Change open/closed contact function**

For the ladder editor, the contact type at the cursor position can also be changed by selecting [Edit] ⇒ [Easy Edit] ⇒ [Switch Open/Close Contact] or pressing the **Ctrl**+**Z** keys. Convert the program when this function is performed as the program becomes unconverted status.

● **Operation applicability of the change open/closed contact function**

The following table shows the contacts whose contact types can be changed.


Replace Example					
XO	↔	XO	XO	↔	XO
VO	↔	VO		↔	VO

## 10.3.5 Batch replacing devices

Batch replace devices with the specified device/label.

### Screen display

Select [Find/Replace] ⇒ [Device Batch Replace].



### Operating procedure

#### 1. Set the items on the screen.

Item	Description	
Find In	Click the <b>Browse...</b> button to select a location to search for. Two or more search locations can be selected. Click <b>▼</b> to select a location from the list of previously searched locations. The location cannot be entered directly.	
Find Device	Enter a device/label to be replaced.	
Replace Device	Enter a replacing device/label.	
Points	Points: Enter the number of points to be replaced, counted from the device specified for "Find Device". When a label is entered for "Find Device" or "Replace Device", enter 1.	
Point Format	Point format: Click <b>▼</b> to select either decimal or hexadecimal for the value entered for "Points".  Example) When X0 for "Find Device", X10 for "Replace Device", 5 for "Points", and "DEC" for "Point Format" are set, the devices are replaced as shown below: X0→X10, X1→X11, X2→X12, X3→X13, X4→X14	
Device Comment*1	Move	Select this to move a device comment of "Find Device" to "Replace Device".
	Copy	Select this to copy a device comment of "Find Device" to "Replace Device".
	Not to Change	Select this not to move or copy a device comment of "Find Device".

\*1 : For ladder programs and SFC (Zoom) programs only

#### 2. Click the **Execute** button.

The devices/labels entered in "Find Device" are batch replaced with the devices/labels entered in "Replace Device".

### Screen button



Resets all setting items to default.

### Point

- **Registering devices/labels in batch**

Multiple devices can also be registered at once by selecting a range and dragging and dropping it from the ladder editor.

- **Replacing devices in batch**

Batch replacement between 16-bit counter devices and 32-bit counter devices is not supported by FXCPU.

- **Devices that can be batch replaced**

For devices that can be replaced in batch, refer to Section 10.3.1.

---


## 10.3.6 Displaying results and error logs

After the All Find/All Replace function is executed, results and error logs are displayed.

### ■ Displaying results

#### Screen display

Click the **All Find** / **All Replace** button in the respective Find/Replace windows ⇒ <<Result>>.



#### Display contents

Item	Description
Search/replace results	Display the character strings, locations, and positions which have been searched for or replaced.
Target List	Display the character strings which match with the one in "Find/Replace String".
Place	Display the locations where the search/replace function is executed.
Position	Display the position information to specify the location where the search/replace function is executed. (☞ '● Position information' on the next page)
Status	Display the details of the search/replace results.
Find/Replace Result	Display the number of character strings which have been searched for or replaced.
Error Logs	Display the number of error logs.
Find String	Display the character strings specified in "Find String".
Replace String	Display the character strings specified in "Replace String".
Find In	Display the location specified on the relevant Find/Replace window.
Sub status bar	Display the search/replace results.

● **Position information**

The following position information is displayed according to the editor.


Type	Description	Example
Ladder editor	Step number	2 Step* <sup>1</sup>
ST editor	Number of lines	(6)
SFC editor	SFC symbol and step number	Transition No. 0
Structured Ladder/FBD editor	Ladder block number and grid position	2. (10. 2)
Device comment editor	Device name, start position	X1, 0 Column
Label Setting screen, Structure Setting screen, Device memory editor	Row, column	8 Row 1 Column

\*1 : For project with labels and SFC (Zoom), parentheses are appended to the step number.  
(Example: (2) Step)

## ■ Displaying error logs

### Screen display

Click the **All Find** / **All Replace** button in the respective Find/Replace windows ⇒ <<Error Log>>.



### Display contents

Item	Description
Status	Display the number of error logs, and the search location.
Error logs	Display the errors in search/replace results.

### Point

#### ● Jump function

The jump function is used to jump from any row of search/replace results or logs to the corresponding character strings. To execute a jump, right-click on the selected row and select [Jump] from the shortcut menu, or double-click the selected line.





---

# 11 PRINTING

This chapter explains how to print data such as sequence programs and devices created with GX Works2.

11.1	Print Function	11 - 2
11.2	Setting Printer	11 - 4
11.3	Batch Printing Project Data	11 - 5
11.4	Page Set Up for Batch Print	11 - 8
11.5	Setting Details of Batch Print	11 - 10
11.6	Displaying Batch Print Preview	11 - 38
11.7	Printing Data Displayed on Screen	11 - 39
11.8	Setting Print Details for Data Displayed on Screen	11 - 40
11.9	Previewing Print Images	11 - 43
11.10	Printing Examples	11 - 44
11.11	Considerations for Printing	11 - 52

## 11.1 Print Function

Q CPU L CPU Remote Head FX

This section explains the overview of print function and printable data.

### ■ Batch print and print window functions

The print functions are batch print function and print window function.

#### ● Batch print function

A function to batch print multiple data in a project.

#### ● Print window function

A function to print data displayed on the active window.

### ■ Printable and non-printable data

The following table shows the printable and non-printable data.

○: Printable ×: Non-printable

Data	Batch print	Print window
Cover	○	×
PLC parameter	○	○
Redundant parameter	○	○
Network parameter	○	○
Intelligent function module*1	×	○
Program setting	○	○
Ladder	○	○
SFC (MELSAP3)	○	○
SFC (MELSAP-L)*1	○	○
ST*2	○	○
Structured Ladder/FBD*2	○	○
Function/Function block program*2	○	○
Label*2	○	○
Device comment	○	○
Device memory	○	○
Device initial value*1	○	○
Change TC Setting	○	×
Device list	○	○
Cross reference	○	○
Statement/Note	○	×
Project content list	○	×
User library content list	○	×
Product information list	○	×
System monitor*1	×	○
Verification result	×	○

\*1 : Not supported by FXCPU.

\*2 : User library data can be printed.

## Point

### ● Print items on the batch print screen

Data supported by the batch print function are displayed on the batch print screen in the order shown in the table on the previous page, and changed data are saved in the project. Therefore, when a project created in the old version of GX Works2 is opened in the new version, the listed order of the print items may be changed. Change the order of the print items with "Set Print Order".

9

SETTING DEVICE  
COMMENTS

10

SEARCH/REPLACE

11

PRINTING

12

SETTING OPTIONS

13

USING LIBRARIES

14

SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15

WRITING/READING  
DATA

16

PROTECTING  
DATA

## 11.2 Setting Printer


Q CPU L CPU Remote Head FX

This section explains how to set a printer.

Print job output can be selected on the Printer Setup screen for batch print. For details, refer to Section 11.3.1.

### Screen display

Select [Project] ⇒ [Printer Setup].



### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Name	Select the printer to be used.
Paper	Set the paper size and paper feed method of the printer.
Size	Select the size of paper.
Source	Select the paper feed method.
Orientation	Set the page orientation.
Portrait	Select this to print the page in portrait mode.
Landscape	Select this to print the page in landscape mode.

#### 2. Click the button.

#### Point

##### ● Printer settings

Printer settings changed in GX Works2 are not saved.

#### Restrictions

##### ● Printing data using equipment such as other companies' PDF printers

Some lines of a table may not be printed correctly.


# 11.3 Batch Printing Project Data

Q CPU L CPU Remote Head FX

This section explains how to batch print project data. A print preview can be displayed before printing data. For displaying a print preview, refer to Section 11.6.

## Screen display

Select [Project] ⇒ [Print].



## Operating procedure

1. Set the items on the screen.

Item	Description
Print Item	Select the data to be printed. <input checked="" type="checkbox"/> is displayed for items without data to be printed or items whose data is read-protected by the security setting. <input type="checkbox"/> is displayed for print items to which read-protected is set in the security setting.
Setting by Item	Set details of print settings for each data. (Section 11.5)

2. Click the  button.

Data of items selected under "Print Item" are printed in the order from the top.


9 SETTING DEVICE COMMENTS  
 10 SEARCH/REPLACE  
 11 PRINTING  
 12 SETTING OPTIONS  
 13 USING LIBRARIES  
 14 SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION  
 15 WRITING/READING DATA  
 16 PROTECTING DATA

**Screen button**

- **Move Up / Move Down**  
Moves the selected item up/down under "Print Item".
- **Print Setup...**  
Displays the Print Setup screen. (☞ Section 11.3.1)
- **Page Setup...**  
Displays the Page Setup screen. (☞ Section 11.4)  
Set a header/footer of the paper on which data is printed.
- **Print Preview**  
Displays a print preview of the item selected under "Print Item". (☞ Section 11.6)

**Point!**

- **Using a function to print multiple pages on a single page**  
When using the function to print multiple pages on a single page, data are printed in a group of print item.  
When data ends in the middle of the page, the next data will not be printed on the same page but will be printed on the new page.  
The following figure shows the example of printing two pages on a single page.




## 11.3.1 Setting printer for batch print

For batch print, the printer can also be set on the Print screen. Print job output can be selected in the printer setting for batch print. For notes and restrictions on printer setting, refer to Section 11.2.

### Screen display

Select the  button on the Print screen.



### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Name	Select the printer to be used.
Paper	Set the paper size and paper feed method of the printer.
Size	Select the size of paper.
Source	Select the paper feed method.
Orientation	Set the page orientation.
Portrait	Select this to print the page in portrait mode.
Landscape	Select this to print the page in landscape mode.
Print Job	Select a method for print job output.
Output Method	Select whether to print all print items as one print job or to print each print item separately.

#### 2. Click the button.

#### Point

##### ● Printing with a PDF output printer

For a PDF output printer which outputs print results to files, files are created for each print job. The size of the files to be created is depending on the printer driver.


## 11.4 Page Set Up for Batch Print

Q CPU L CPU Remote Head FX

This section explains how to set the page setup for batch print.


### Screen display

Select the **Print Screen** ⇒ **Page Setup...**



### Operating procedure

**1. Set the items on the screen.**

Item	Description
Paper	–
Size	Select the paper size.
Source	Select the paper feed method.
Orientation	Set the page orientation.
Margins (Unit: mm)	Set spaces for top/bottom/right/left of the paper.
Headers/Footers	–
Page Number Format	Select "Continue from previous page" or "Include chapter number" for the page numbers printed in header/footer.
Start at:	Set a page number for the first page to be printed when "Continue from Previous Page" is selected.
Header	Enter character strings to be printed in header or footer. Up to 512 characters including string patterns and line feeds can be entered in the header/footer. Note that a line feed is handled as two characters.
Footer	Click  to display a list of string pattern. Selected string pattern is entered at the cursor position.

**2. Click the  button.**



### Screen button

- Restore Default


Restores the default setting of header/footer.

### Point

#### ● Printing chapter numbers

By selecting "Include chapter number", page numbers are displayed with: the numbered item in "Print Item", the numbered item in "Print", and the page number of each data. Even when there is no actual data to be printed in "Print Item" or "Print", the numbers with the chapter number format will be assigned in order.

The following figure shows an example of page number assignment with the chapter number format.



#### ● When characters which exceed the maximum number of characters are entered to header/footer

When the project is opened in GX Works2 with a language different from the opened project data, characters which exceed 512 characters may be displayed.


When characters which exceed 512 characters are entered to the header/footer, characters cannot be entered or pasted; however, they can be deleted or cut.

#### ● Header and footer

String patterns of header/footer may not function when a project created in GX Works2 in other language is opened, or a project created in GX Works2 Version 1.64S or later is opened in GX Works2 Version 1.62Q or earlier.

When the string pattern of header and footer do not function, set the setting again.

<When a project created in GX Works2 Version 1.64S or later is opened in GX Works2 Version 1.62Q or earlier>



9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

## 11.5 Setting Details of Batch Print

Q CPU L CPU Remote Head FX

This section explains how to set items for the batch print function.

### 11.5.1 Setting common items (batch-print setting for user library data)


Set items to print user library data.

Selected user library data names can be printed under the following print items.

- ST
- Structured Ladder/FBD
- FB/FUN program
- Label

#### Screen display

Select "Print all (Common setting)" in "Print Item" on the Print screen.




#### Operating procedure


- Set the items on the screen.


Item	Description
User library	—
Print user library*1	Select this to print user library data.
Do not print	Display data names which will not be printed
Print	Display data names to be printed. Data are printed in the order from the top.
Select data name display format	—
Display format	Select a display format of data name when ST, Structured Ladder/FBD, FB/FUN program, or label is selected.


\*1 : This item cannot be selected for Simple project.


## Screen button

- 

Moves data selected in "Do not print" to "Print".
- 

Moves all data in "Do not print" to "Print".
- 

Moves data selected in "Print" to "Do not print".
- 

Moves all data in "Print" to "Do not print".
- 


Moves data selected in "Print" up/down.

## Point

### ● Printing read protected data

When printing read protected data displayed on the field of "Do not print", enable the editing status of the user library for editing.

For details of editing user library, refer to the following manual.

 GX Works2 Version 1 Operating Manual (Structured Project)


9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA

## 11.5.2 Setting batch print for cover

Set items to print a cover.

### Screen display

Select "Cover" in "Print Item" on the Print screen.



### Operating procedure

- Set the items on the screen.

Item	Description
Print Selection	Select the item(s) to be printed.
Layout	Display print area of the item(s) selected for "Print Selection".
Text	Enter text for each item to be printed. Text can be entered when "Title", "Comment", "Prepared By", and/or "Date" are selected for "Print Selection". A maximum of 200 characters can be set for each item. Note that a line feed is handled as two characters. The numbers of characters and lines that can be printed differ according to the size or font setting of print paper. Check the print image with the print preview function.
Font	Set fonts for each item to be printed. Fonts can be set when "Title", "Comment", "Prepared By", and/or "Date" are selected for "Print Selection".
Font	Select a font.
Size	Select a font size.
Font Style	Select a font style.

### Screen button

- **Print by Item...**  
Prints items selected in "Print Item".
- **Preview by Item**  
Displays a print preview of items selected in "Print Item".


### 11.5.3 Setting batch print for PLC parameter

Set items to print PLC parameter.

#### Screen display

Select "PLC Parameter" in "Print Item" on the **Print** screen.

The following is an example of setting screen when QCPU (Q mode) is selected.



#### Operating procedure

- Set the item on the screen.

Item	Description
Print What	Select the item(s) of PLC parameter to be printed.

#### Screen button

For the screen buttons, refer to Section 11.5.2.

- **Select All**  
Selects all items.
- **Reset All**  
Clears the selection of all items.

9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15  
WRITING/READING  
DATA


16  
PROTECTING  
DATA

## 11.5.4 Setting batch print for redundant parameters

Set items to print redundant parameters.

### Screen display

Select "Redundant Parameter" in "Print Item" on the Print screen.



### Operating procedure

- Set the item on the screen.

Item	Description
Print what	Select the item(s) of redundant parameters to be printed.

### Screen button

For the screen buttons, refer to Section 11.5.2.


## 11.5.5 Setting batch print for network parameter

Set items to print the network parameter.

### Screen display

Select "Network Parameter" in "Print Item" on the Print screen.

The following is an example of setting screen when QCPU (Q mode) is selected.



### Operating procedure

- Set the item on the screen.

Item	Description
Print What	Select the item(s) of network parameter to be printed.

### Screen button

For the screen buttons, refer to Section 11.5.2.

9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15  
WRITING/READING  
DATA


16  
PROTECTING  
DATA

## 11.5.6 Setting batch print for program settings

Set items to print program settings on the Navigation window.

### Screen display

Select "Program setting" in "Print Item" on the Print screen.



### Operating procedure

- Set the items on the screen.

Item	Description
Print selection	—
Program setting	Select this to print the list of program setting content.
Additional information	Select this to print the titles of the list of program setting content.
Task setting <sup>*1</sup>	Select this to print tasks registered in the program setting.
Execution type	Select the execution types to be printed. Data are printed in the order from the top.
Program list	Select the programs to be printed. Data are printed in the order from the top.
Select data name	Items selected for "Execution type" and "Program list" are displayed.
Do not print	Display data names which will not be printed
Print	Display data names to be printed. Data are printed in the order from the top.
Additional information	Append selected items to the task setting.
Print conditions	Set the conditions for printing.
Print title only for the task with no program registered	Select this to print only titles even when programs are not registered to the task. When this item is selected, only header, footer, and/or title are printed for each data on one page.

\*1 : This item cannot be selected for Simple project.

### Screen button

For the screen buttons, refer to Section 11.5.1 and Section 11.5.2.




## 11.5.7 Setting batch print for ladder programs

Set items to print ladder programs.

### Screen display

Select "Ladder" in "Print Item" on the Print screen.





### Operating procedure

- Set the items on the screen.

Item	Description
Select Program	Display all data names of ladder program.
Do Not Print	Display data names which will not be printed.
Print	Display data names to be printed. Data are printed in the order from the top.
Display Mode of Program*1	Select whether to print data in label display or device display.
Additional Information	Append selected items to the ladder program.
Device Comment	Select this to append device comments. For labels, label comments are appended. Set the number of comment rows and columns to be printed.
Statement/Note	Select this to append statements and notes.
Contact	Select this to append contact usage destination. Set the print position and print range. To specify the print range, click the <b>Set Range...</b> button, and set the device range on the <u>Device Range Setting (Contact)</u> screen.
Coil	Select this to append coil usage destination. Set a print range. To specify the print range, click the <b>Set Range...</b> button, and set the device range on the <u>Device Range Setting (Coil)</u> screen.

Item	Description
Print Conditions	Set the conditions for printing ladder programs.
Ladder Contact	Set the number of contacts to be printed.
Print NOPLF*2	Select this to print the NOPLF instructions. (Data will be printed on the new page at the NOPLF instruction in the program with or without this item is selected.)
Delete blank rows of contacts and specify the number of column	Select this to print programs with blank rows of contact usage destination closed up. When this item is selected, the number of columns of contact usage destination can be selected.
Delete blank rows above and under coil	Select this to print programs with blank rows of coil usage destination closed up.
Page break by ladder block	Select this to print data on the new page in ladder block unit. When this item is cleared, data is printed on the new page in ladder row unit.
Print ladder blocks include hidden ones*3	Select this to print hidden ladder blocks.
Print blank rows with no device comment	Select this to print blank rows which do not contain device comments.
Print lines in bold	Select this to print programs with bold lines.
Specify Print Range	–
Print Range	Set the ladder program print range. To specify the print range, select "Specify Range" and set a start step and an end step.


- \*1 : When a block password to which the execution program protection setting is enabled is set, the buttons, , cannot be used in the device display. Unlock all block passwords to use these  in the device display.
- \*2 : Not supported by FXCPU.
- \*3 : For projects with labels, this item can be selected only when "Print in Label Display" is selected for "Display Mode of Program".

## Screen button

For the screen For the screen buttons, refer to Section 11.5.1 and Section 11.5.2.


- 

Displays the Device Range Setting screen.




### Contact/coil usage destination

Contact usage destination and coil usage destination are output as shown below.



The following shows an example of contact usage destination.

Example) Contact usage destination of Y0



### Printing examples with a setting of "Delete blank rows of contacts and specify the number of column"

The following examples show the difference of printing contact usage destination according to the setting of "Delete blank rows of contacts and specify the number of column".

< Without the item selected (5 columns) >

M1					
A/S	4	5	6	7	8
B/D	10	11	12	13	14
M1					
A/S	16	17	18	19	20
B/D	22	23	24	25	26

< With the item selected (5 columns) >

M1					
A/S	4	5	6	7	8
B/D	16	17	18	19	20
M1					
A/S	10	11	12	13	14
B/D	22	23	24	25	26

9 SETTING DEVICE COMMENTS

10 SEARCH/REPLACE

11 PRINTING

12 SETTING OPTIONS

13 USING LIBRARIES

14 SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15 WRITING/READING DATA


16 PROTECTING DATA

## 11.5.8 Setting batch print for MELSAP3 programs

Set items to print SFC (MELSAP3) programs.

### Screen display

Select "MELSAP3" in "Print Item" on the Print screen.



### Operating procedure





- Set the items on the screen.

Item	Description
Select Program	Display data names of SFC (MELSAP3) program.
Select Print Units*1	Select either "Program block" or "Program file".
Do Not Print	Display data names which will not be printed.
Print	Display data names to be printed. Data are printed in the order from the top.
Display Mode of Block List/Action/Transition*2	Select whether to print data in label display or device display. This item can be selected only when "Block List" or "Action/Transition" is selected in "SFC Diagram Print Item".
SFC Diagram Print Item	Select the item(s) to be printed in SFC diagram.
SFC Diagram	Select the item(s) to be printed.
Block List*3	
Comment List	
Action/Transition	
Property (SFC Program)*3,*4	
Note List	

Item	Description
Additional Information	Append selected item(s) to "SFC Diagram Print Item".
SFC Diagram	–
SFC Step/Transition Comment	Select this to append SFC steps/transition comments to the SFC diagram.
Action Input	Select this to append operation outputs to the SFC diagram.
Transition Conditions	Select this to append transition conditions to the SFC diagram.
Block List*4	–
SFC Block List Comment	Select this to append SFC block list comments to the block list.
Start Destination Block	Select this to append start destination block to the block list.
Action/Transition	–
Device Comment	Select this to append device comments to Action/Transition. For labels, label comments are appended. Set the numbers of rows and columns for comments to be printed.
Print Conditions	Set conditions for printing programs.
Number of Print Column of SFC Diagram	Specify the number of columns of SFC diagram to be printed on a single page. The program is printed with reducing the size to fit the specified number of columns on a single page.
Number of Action/Transition Contacts	Set the number of contacts to be printed.
Specify Print Range	–
Print Range*3	Set the SFC (MELSAP3) program print range. To specify the print range, select "Specify Range" and set a start block and an end block.

\*1 : This item cannot be selected for Simple project.

\*2 : When a block password to which the execution program protection setting is enabled is set, the buttons, , , , , cannot be used in the device display.

Unlock all block passwords to use these , , ,  in the device display.

\*3 : For Structured projects, this item cannot be selected when "Program block" is selected for "Select print units".

\*4 : Not supported by FXCPU.

## Screen button

For the screen buttons, refer to Section 11.5.1 and Section 11.5.2.


9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

## 11.5.9 Setting batch print for MELSAP-L programs

Set items to print SFC (MELSAP-L) programs.  
This setting is not supported by FXCPU.

### Screen display

Select "MELSAP-L" in "Print Item" on the Print screen.



## Operating procedure

- Set the items on the screen.

Item	Description
Select Program	Display all data names of SFC (MELSAP-L) program.
Select print units*1	Select either "Program block" or "Program file".
Do Not Print	Display data names which will not be printed.
Print	Display data names to be printed. Data are printed in the order from the top.
SFC Diagram Print Item	Select the item(s) to be printed in SFC diagram.
SFC Diagram	Select the item(s) to be printed.
Block List	
Comment List	
Property (SFC Program)	
Additional Information	Append selected item(s) to "SFC Diagram Print Item".
SFC Diagram	–
SFC Step/Transition Comment	Select this to append SFC steps/transition comments to the SFC diagram.
Program	Select this to append programs to the SFC diagram.
Block List	–
SFC Block List Comment	Select this to append SFC block list comments to the block list.
Start Destination Block	Select this to append start destination block to the block list.
Print Conditions	Set conditions for printing programs.
Number of Print Column of SFC Diagram	Specify the number of columns of SFC diagram to be printed on a single page. The program is printed with reducing the size to fit the specified number of columns on a single page.
Specify Print Range	–
Print Range	Set the SFC (MELSAP-L) program print range. To specify the print range, select "Specify Range" and set a start step and an end step.

\*1 : This item cannot be selected for Simple project.

## Screen button

For the screen buttons, refer to Section 11.5.1 and Section 11.5.2.

9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15  
WRITING/READING  
DATA


16  
PROTECTING  
DATA

## 11.5.10 Setting batch print for ST programs

Set items to print ST programs.

### Screen display

Select "ST" in "Print Item" on the Print screen.



### Operating procedure

- Set the items on the screen.

Item	Description
Select Program	Display all data names of ST program.
Do Not Print	Display data names which will not be printed.
Print	Display data names to be printed. Data are printed in the order from the top.
Specify Print Range	–
Print Range	Set the ST program print range. To specify the print range, select "Specify Range" and set a start line and an end line.

### Screen button

For the screen buttons, refer to Section 11.5.1 and Section 11.5.2.




## 11.5.11 Setting batch print for Structured Ladder/FBD programs

Set items to print Structured Ladder/FBD programs.

### Screen display

Select "Structured Ladder/FBD" in "Print Item" on the Print screen.



### Operating procedure

- Set the items on the screen.

Item	Description
Select Program	Display all data names of Structured Ladder/FBD program.
Do Not Print	Display data names which will not be printed.
Print	Display data names to be printed. Data are printed in the order from the top.

### Screen button

For the screen buttons, refer to Section 11.5.1 and Section 11.5.2.

9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15  
WRITING/READING  
DATA


16  
PROTECTING  
DATA

## 11.5.12 Setting batch print for FB/FUN programs

Set items to print function and function block programs.

### Screen display

Select "FB/FUN Program" in "Print Item" on the Print screen.



### Operating procedure

- Set the items on the screen.

Item	Description
Print Selection	–
Function/FB Label	Select this to print function/function block labels.
Select Program	Display all data names of function/function block program.
Do Not Print	Display data names which will not be printed.
Print	Display data names to be printed. Data are printed in the order from the top.
Additional Information	Append selected items to the ladder program.
Device comment	Select this to append device comments. For labels, label comments are appended. Set the number of comment rows and columns to be printed.
Statement/Note	Select this to append statements and notes.
Contact	Select this to append contact usage destination. Set the print position and print range. To specify the print range, click the <b>Set Range...</b> button, and set the device range on the <u>Device Range Setting (Contact)</u> screen.
Coil	Select this to append coil usage destination. Set a print range. To specify the print range, click the <b>Set Range...</b> button, and set the device range on the <u>Device Range Setting (Coil)</u> screen.

Item	Description
Print Conditions	Set the conditions for printing ladder programs.
Ladder Contact	Set the number of contacts to be printed.
Print NOPLF*1	Select this to print the NOPLF instructions. (Data will be printed on the new page at the NOPLF instruction in the program with or without this item is selected.)
Delete blank rows of contacts and specify the number of column	Select this to print programs with blank rows of contact usage destination closed up. When this item is selected, the number of columns to be printed can be selected.
Delete blank rows above and under coil	Select this to print programs with blank rows of coil usage destination closed up.
Page break by ladder block	Select this to print data on the new page in ladder block unit. When this item is cleared, data is printed on the new page in ladder row unit.
Print ladder blocks include hidden ones*2	Select this to print hidden ladder blocks.
Print blank rows with no device comment	Select this to print blank rows which do not contain device comments.
Print lines in bold	Select this to print programs with bold lines.
Specify Print Range	–
Print Range	Set the ladder program print range. To specify the print range, select "Specify Range" and set a start step and an end step.

\*1 : Not supported by FXCPU.

\*2 : For projects with labels, this item can be selected only when "Print in Label Display" is selected for "Display Mode of Program".

## Screen button

For the screen buttons, refer to Section 11.5.1, Section 11.5.2, and Section 11.5.7.

### Point

#### ● Data to be printed in FB/FUN programs

Data to be printed in FB/FUN programs are function blocks created in ladder programs and functions/function blocks created in ST programs or Structured Ladder/FBD programs.

Display-prohibited programs are not displayed in "Select Program".

9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15  
WRITING/READING  
DATA


16  
PROTECTING  
DATA

## 11.5.13 Setting batch print for labels

Set items to print label data.

### Screen display

Select "Label" in "Print Item" on the Print screen.



### Operating procedure

- Set the items on the screen.

Item	Description
Print Selection	Display all data names of label.
Label List	Select the label type(s) to be printed. Data are printed in the order from the top. The item is displayed in gray when data to be printed do not exist.
Select Data Name	Display items selected in "Label List".
Do Not Print	Display data names which will not be printed.
Print	Display data names to be printed. Data are printed in the order from the top.

### Screen button


For the screen buttons, refer to Section 11.5.1 and Section 11.5.2.

## 11.5.14 Setting batch print for device comments

Set items to print device comment data.

### Screen display

Select "Device Comment" in "Print Item" on the Print screen.



### Operating procedure

- Set the items on the screen.

Item	Description
Print Selection	Display all data names of device comment.
Device Comment List	Select the device comment to be printed. Data are printed in the order from the top. The item is displayed in gray when data to be printed do not exist, or all data are read protected.
Select Data Name	Display items selected in "Device Comment List".
Do Not Print	Display data names which will not be printed.
Print	Display data names to be printed. Data are printed in the order from the top.
Print Conditions	–
Print include the device with no comment. *Available only when selecting print range in Specify Print Range option.	Select this to print data including devices to which device comments are not registered.
Print title only for the device comment with no comment.	Select this to print only titles of data to which device comments are not registered. When this item is selected, only header, footer, and/or title are printed for each data on one page.
Specify Print Range	Set the device comment print range. To specify the print range, select "Specify Range" and set the device range by clicking the <b>Set Range...</b> button. Since direct inputs (DX) and direct outputs (DY) are device comments as same as inputs (X) and outputs (Y), they are not printed when "Whole Range" is selected. When printing direct inputs (DX) or direct outputs (DY), select "Specify Print Range", and set the device range.

### Screen button


For the screen buttons, refer to Section 11.5.1, Section 11.5.2, and Section 11.5.7.

## 11.5.15 Setting batch print for device memory data

Set items to print device memory data.

### Screen display

Select "Device Memory" in "Print Item" on the Print screen.



### Operating procedure

- Set the items on the screen.

Item	Description
Device Memory Selection	Display all data names of device memory.
Do Not Print	Display data names which will not be printed.
Print	Display data names to be printed. Data are printed in the order from the top.
Print Conditions	–
Print rows that all device value are 0.	Select this to print rows in which device values are all 0.
Print blank rows with no device set.	Select this to print rows in which devices are not set.
Print title only for the device memory with no device set.	Select this to print only titles of device memory data in which devices to be printed are not set. When this item is selected, only header/footer/titles are printed on a single page per data.

### Screen button


For the screen buttons, refer to Section 11.5.1 and Section 11.5.2.

## 11.5.16 Setting batch print for device initial values

Set items to print device initial values.  
This setting is not supported by FXCPU.


### Screen display

Select "Device Initial Value" in "Print Item" on the Print screen.



### Operating procedure

- Set the items on the screen.

Item	Description
Device Initial Value Selection	Display all data names of device initial values.
Do Not Print	Display data names which will not be printed.
Print	Display data names to be printed. Data are printed in the order from the top.
Print Selection	–
Device Initial Value Range	Select this to print specified range of device initial values.
Device Initial Value	Select this to print device initial values (device values).
Print Type	Select a bit unit for handling device initial values for printing.
Print Form	Select a data format of device initial value for printing.
Print Conditions	–
Print device that value is 0.	Select this to print devices whose value is 0.
Print title only for the data that is not set device initial value and range.	Select this to print only titles of data to which the device initial value range is not set, or data which do not contain devices to be printed. When this item is selected, only header/footer/titles are printed on a single page per data.
Specify Print Range	Set the device initial value print range. To specify the print range, select "Specify Range" and set the device range by clicking the  button.

### Screen button


For the screen buttons, refer to Section 11.5.1, Section 11.5.2, and Section 11.5.7.

## 11.5.17 Setting batch print for TC setting values

Set items to print TC setting values.

### Screen display

Select "TC Setting" in "Print Item" on the Print screen.



### Operating procedure

- Set the items on the screen.

Item	Description
Select Program	Display all data names of ladder/MELSAP3/MELSAP-L programs.
Do Not Print	Display data names which will not be printed.
Print	Display data names to be printed. Data are printed in the order from the top.
Print Target Device	Select the item to be printed.
Timer setting value	Select this to print timer setting values. Labels to which timer is set as a data type are also printed.
Retentive timer setting value*1	Select this to print retentive timer setting values. Labels to which retentive timer is set as a data type are also printed.
Counter setting value	Select this to print counter setting values. Labels to which counter is set as a data type are also printed.
Additional Information	Append the selected item to the devices to be printed.
Device comment	Select this to append device comments. For labels, label comments are appended.
Print Conditions	–
Print title only for the program with no TC setting.	Select this to print only titles of programs which do not contain TC setting values. When this item is selected, only header/footer/titles are printed on a single page per data.

\*1 : Not supported by FXCPU.

### Screen button

For the screen buttons, refer to Section 11.5.1 and Section 11.5.2.




## 11.5.18 Setting batch print for device list

Set items to print the device list.

### Screen display

Select "Device List" in "Print Item" on the Print screen.



### Operating procedure

- Set the items on the screen.

Item	Description
Find In	Set a search location of data to be printed. Click the <b>Browse...</b> button to select a search location. A search location cannot be entered directly.
Find What	Set a search target for devices to be printed.
All devices	Select this to search all devices.
Used devices	Select this to search devices used for contacts, coils, and parameters. Selected items are searched with the specified condition (AND or OR condition).
Unused devices	Select this to search devices which are not used.
Additional Information	Append the selected item(s) to the device list.
Device Comment	Select this to append device comments.
Print Conditions	–
Print title only when no find result returns.	Select this to print only titles even when the program does not contain any devices. When this item is selected, only header/footer/titles are printed on a single page.
Specify Print Range	Set the device comment print range. To specify the print range, select "Specify Range" and set the device range for "Conditions for Range Specification".
Conditions for Whole Range Specification	–
Include ZR device	Select this to include ZR devices in the print target when "Whole Range" is specified for "Specify Print Range".
Include extension device (e.g. U0\G0, J1\X0)	Select this to include extended devices in the print target when "Whole Range" is specified for "Specify Print Range". (BLm\Sn and BLm\TRn devices are printed with or without this item is selected.)
Conditions for Range Specification	Set a range of devices to be printed.

### Screen button


For the screen buttons, refer to Section 11.5.1, Section 11.5.2, and Section 11.5.7.

## 11.5.19 Setting batch print for cross reference information

Set items to print cross reference information created on the Cross Reference window.

### Screen display

Select "Cross Reference" in "Print Item" on the Print screen.



### Operating procedure

- Set the items on the screen.

Item	Description
Specify Print Range	–
All	Select this to print all rows.
Selected Rows	Select this to print selected row(s). Select the row(s) to be printed on the Cross Reference window in advance.
Print Conditions	–
Print title only when a cross reference information is not created.	Select this to print only titles when the cross reference information is not created. When this item is selected, only header/footer/table titles are printed on a single page.

### Screen button


For the screen buttons, refer to Section 11.5.2.

## 11.5.20 Setting batch print for statements/notes

Set items to print statement/note data.

### Screen display

Select "Statement/Note" in "Print Item" on the Print screen.



### Operating procedure

- Set the items on the screen.

Item	Description
Select Program	Display all program names of ladder program.
Do Not Print	Display data names which will not be printed.
Print	Display data names to be printed. Data are printed in the order from the top.
Statement/Note Print Item	Selected items are printed.
Line Statement List	Select the item(s) to be printed.
Note List	
P Statement List	
I Statement List	
Print Conditions	–
Print title only for the program with no Statement/Note.	Select this to print only titles of data in which statements/notes do not exist. When this item is selected, only header, footer, and/or title are printed for each data on one page.

### Screen button


For the screen buttons, refer to Section 11.5.1 and Section 11.5.2.

## 11.5.21 Setting batch print for product information list

Set items to print the product information list created on the System Monitor screen. This setting is not supported by FXCPU.

### Screen display

Select "Product Information List" in "Print Item" on the Print screen.



### Operating procedure

- Set the item on the screen.

Item	Description
Setting for Product Information List	—
File Name	Set a product information list file to be printed. Click the <b>Browse...</b> button to select a product information list file. A product information list file cannot be entered directly.

### Screen button

For the screen buttons, refer to Section 11.5.2.

#### Point

- Printable product information list files**

Only the product information list files created on the System Monitor screen in GX Works2 can be printed. Product information list files created in GX Developer cannot be printed.

## 11.6 Displaying Batch Print Preview

Q CPU L CPU Remote Head FX

This section explains how to check the print image of each data.


### Operating procedure

**1. Select [Project] ⇒ [Print Preview].**

The Print screen is displayed. (☞ Section 11.3)

**2. Click the  button.**

The Print Preview screen is displayed.






**3. Select items in "Print Item" and "Data Name" to change the data and check the print image.**

**4. Click the  button.**


The print image of the selected data is displayed.

### Screen button

-  Prints data.
-  Displays the previous page/next page.
-  Changes the display size of print image.

### Point

● **Displaying previous/next page in print preview**

The range in which previous/next pages can be displayed by clicking the  button is within one data.

Use the "Jump Preview to" function to switch from the displayed preview data to another data.

● **Page numbers displayed in footer**

When "Continue from previous page" is selected in the page setting, "[Insert page number here]" is displayed at the position where a page number is to be printed in the print preview.

## 11.7 Printing Data Displayed on Screen

Q CPU L CPU Remote Head FX

This section explains how to print data displayed on the screen.

The print image can be checked prior to the printing. For checking print images, refer to Section 11.9.

### Screen display

Select [Project] ⇒ [Print Window].

The Print Window function cannot be executed from the menu for the following data.

Execute the Print Window function as described below for each data.

#### ● Parameters

Click the **Print Window...** button on the PLC parameter setting screen or the network parameter setting screen.


#### ● Device initial value

Click the **Print...** button on the Device Initial Value screen.


#### ● Device list or cross reference

Select rows to be printed, and click the **Print...** button on each screen.

<Data other than intelligent function module>



<Intelligent function module>



### Operating procedure

1. Set the items on the screen.
2. Click the **OK** / **Print...** button.  
Printing starts.

#### Point

#### ● Printer settings

Click the **Properties...** or **Preferences** button to make detailed settings for the printer.

#### ● Printing ladder program screens

When printing a ladder program screen, the Print Window (Ladder) screen is displayed. For SFC (Zoom) programs, the Print Window (Ladder) screen is not displayed.

For details, refer to Section 11.8.1.

## 11.8 Setting Print Details for Data Displayed on Screen



This section explains how to set print details.

Print details can be set using ladder program and device initial setting.

### 11.8.1 Setting print details for ladder programs


Set print details such as print range and additional information of ladder program.

#### Screen display

Select [Project] ⇒ [Print Window]/[Print Window Preview].

The following explains a setting operation for the Print Window function. Apply the same operation for the Print Window Preview function.

<Option setting screen for Print Window>



#### Operating procedure

##### 1. Set the items on the screen.

Item	Description
Additional Information	Append selected items to the ladder program.
Device comment	Select this to append device comments. Set the number of comment columns to be printed. The number of comment rows is fixed.
Statement/Note	Select this to append statements and notes.
Contact	Select this to append contact usage destination. Set the print position and print range. To specify the print range, click the <b>Set Range...</b> button, and set the device range on the <u>Device Range Setting (Contact)</u> screen.
Coil	Select this to append coil usage destination. Set the print range. To specify the print range, click the <b>Set Range...</b> button, and set the device range on the <u>Device Range Setting (Coil)</u> screen.
Specified Print Range	–
Print Range	Set the print range of ladder program. To specify the print range, select "Specified Range" and set a start step and an end step.



**2. Click the OK button.**

For the Print Window function, the Print Window screen is displayed. (☞ Section 11.7)  
 For the Print Window Preview function, the Print Window Preview screen is displayed.  
 (☞ Section 11.9)

**Screen button**

For the screen buttons, refer to Section 11.5.7.

- Print Window Preview

Displays a print preview.

**■ Contact/coil usage destination**

For details of contact/coil usage destination, refer to Section 11.5.7.


SETTING DEVICE COMMENTS	9
SEARCH/REPLACE	10
PRINTING	11
SETTING OPTIONS	12
USING LIBRARIES	13
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION	14
WRITING/READING DATA	15
PROTECTING DATA	16

## 11.8.2 Setting print details for device initial values

Set print details such as print items and print range of device initial values.

### Screen display

Click the **Print Setting...** button on the **Device Initial Value** screen.



### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Print Item	—
Device Initial Value Range	Select this to print specified range of device initial values.
Device Initial Value	Select this to print device initial values (device values).
Device Initial Value Output Setting	Set the items to print device initial values (device values).
Print Range	—
Whole Range	Select this to print all devices registered as device values
Specified Range	Select this to specify a the print range. The method to specify a range is the same as that of device initial value setting. (☞ Section 8.2)
Print Type	Select a bit unit for handling device initial values at printing.
Print Form	Select a data format of device initial value at printing.
Print Condition	—
Print device with value of zero	Select this to print devices whose value is 0.

#### 2. Click **OK** the button.

## 11.9 Previewing Print Images

Q CPU L CPU Remote Head FX

This section explains how to check print images of data displayed on the screen.

### Screen display

Select [Project] ⇒ [Print Window Preview].

The Print Window Preview function cannot be executed from the menu for the following data. Execute the Print Window Preview function as described below for each data.

- Parameters

Click the **Print Preview...** button on the PLC parameter setting screen or the network parameter setting screen.


- Device initial value

Click the **Print Preview...** button on the Device Initial Value screen.

- Device list or cross reference

Select rows to be printed, and click the **Print Preview...** button on each screen.

<For Structured Ladder/FBD>

9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA



## Network parameters

Network Parameter 1/28/2013

Ethernet/CC IE/MELSENET

(Ethernet/CC IE/MELSENET)

	Module 1	Module 2	Module 3	Module 4
Network Type	CC IE Control(Control Station)	CC IE Control(Normal Station)	Ethernet	CC IE Control(Normal Station)
Start I/O No.	0000	0020	0040	0060
Network No.	1	1	2	3
Total Stations	4	-	-	-
Group No.	0	0	0	0
Station No.	1	2	3	4
Mode	Online	Online	Online	Online
Network Range Assignment Exist	-	-	Operation Setting Exist	-
Network Operation Settings	None	-	Initial Setting None	-
Refresh Parameters Exist	-	Refresh Parameters Exist	Open Setting None	Refresh Parameters Exist
Interrupt Settings	None	Interrupt Settings None	Router Relay Parameter None	Interrupt Settings None
Specify Station No. by Parameter	Specify Station No. by Parameter	-	Station No. <-> IP Information None	Specify Station No. by Parameter
-	-	-	FTP Parameters None	-
-	-	-	E-mail Setting None	-
-	-	-	Interrupt Settings: None	-
-	-	-	-	-

## Intelligent function modules

Intelligent Function Module 6/26/2008

Start I/O: 0030 Q64AD Analog Module

Parameter

Item	CH1	CH2	CH3	CH4
<b>Basic setting</b>				
<b>Set the A/D conversion system.</b>				
A/D conversion enable/disable setting	0:Enable	0:Enable	0:Enable	0:Enable
Sampling/Averaging process setting	0:Sampling Processing	0:Sampling Processing	0:Sampling Processing	0:Sampling Processing
Average time/Average number of times specification	0:Count Average	0:Count Average	0:Count Average	0:Count Average
Average time/average number of times	0 Times	0 Times	0 Times	0 Times

## Program setting

### Program setting

Program setting 4/26/2012

Data Name : Program setting

Parameter type	Parameter Name	Unit	Initial value	Unit Name	Unit Abbrev.
Initial Program	PAR1-1	None	PAR1-1		None / P.C. / Program
Basic Program	PAR1-2	None	PAR1-1		Program
Ready Program	PAR1-3	None	PAR1-1		Program
Warm Start Program	PAR1-4	None	PAR1-2		Program
Parameter type	PAR1	None	Unit_P1		Program

### Task setting

Program setting 4/27/2012

Data Name : Task\_01

Task Setting

Execution type: Scan Program

Program file name: MAIN

Attribute: [No setting]

	Program Name	Comment
1	pou_01	
2	pou_02	
3	pou_03	

9  
SETTING DEVICE COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES


14  
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15  
WRITING/READING DATA


16  
PROTECTING DATA

■ Programs

● Ladder



● SFC diagram (MELSP3)



● SFC block list

SFC Block List

12/22/2011

Data Name:MAIN

No.	Data Name	Title	Conversion Status	Block Start	Step Transition	Block PAUSE/RESTART	Pause Mode	Number of Active Steps	Continuous Transition Bit
0	Block	First Process	*	M0	M1	M2	M3	D0	M4
1	Block1	Second Process	*	M10	M11	M12	M13	D10	M14
2	Block2	Third Process	*	M20	M21	M22	M23	D20	M24
3	Block3	In Process; DO NOT USE	*						

● ST

Program  
LibraryName:-  
Data Name:LD\_Prg


12/22/2011

```

IF X10 OR X11 THEN
  MbrtorOn:=TRUE;
END_IF;
FOR counter=0 TO 10 BY 2 DO
  IF Var02 < 120 THEN
    Var01 = D0 + counter;
    ELIF Var01 > 22400 THEN
      Var01 = Var01 + Var02;
    END_IF;
  END_FOR;

```

● Structured Ladder/FBD



■ Labels

● Global labels

Global Label Setting  
Library Name:-  
Data Name:Global1  
10/15/2009

	Class	Label Name	Data Type	Constant	Device	Comment	Remark	Relation with System Label	System Label Name	Attribute
1	VAR_GLOBAL	gpr02_1	Word[Signed]		J3E1G01			Disclose	gpr02_1	Common
2	VAR_GLOBAL	gpr02_2	Word[Signed]		J3E1G02			Disclose	gpr02_2	Common
3	VAR_GLOBAL	gpr02_3	Word[Signed]		J3E1G03			Disclose	gpr02_3	Common
4	VAR_GLOBAL	gpr02_4	Bit		J2V1					
5	VAR_GLOBAL	gpr02_5	Bit		J2V2					
6	VAR_GLOBAL_CONSTANT	gpr02_6	Bit	TRUE						
7	VAR_GLOBAL	patch1	Bit		J1X1			Disclose	patch1	Link
8	VAR_GLOBAL	patch2	Bit		J1X2			Disclose	patch2	Link
9	VAR_GLOBAL	patch3	Bit		D11			Disclose	patch3	I/O

● Local labels

Local Label Setting  
Library Name:-  
Data Name:SUB1  
6/26/2008

	Class	Label Name	Type	Constant	Device	Address	Comment
1	VAR	Label1	Word[Signed]				
2	VAR	FB1	STRUCT		Detail Setting	Detail Setting	
3	VAR	FB2	STRUCT(0..2)				
4	VAR_CONSTANT	FB3	FB				
5	VAR	Label2	Bit				

● Function/function block labels

Function/FB Label Setting  
Library Name:-  
Data Name:FB\_MLD  
6/26/2008

	Class	Label Name	Type	Constant	Comment
1	VAR_INPUT	FB label1	Bit		
2	VAR_INPUT	FB label2	Word[Signed]		
3	VAR_INPUT	FB label3	Word[Signed]		
4	VAR_CONSTANT	FB label4	Word[Signed]	0	
5	VAR_INPUT	FB label5	Bit		

9  
SETTING DEVICE COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15  
WRITING/READING DATA

16  
PROTECTING DATA

● Structures

Structure Setting				12/22/2011
Library Name:-				
Data Name:Structured				
	Label Name	Data Type	Constant	Comment
1	Element1	Bit		
2	Element2	Word[Signed]		
3	Element3	Double Word[Signed]		
4	Element4	Word[Signed](0..9)		
5	Element5	String(32)		

■ Structure devices

● Structure devices

(Devices are printed automatically after printing labels.)

Structured Data Device Setting				6/26/2008	
Library Name:-					
Data Name:Global1					
	Label Name	Structured Data Type Name	Data Name	Type	Device
1	PS1	PS1	Psau1	CR	
			Psau2	CR(0..3)	
			Psau3	CR(0..2)	
			Psau4	CR	
			Psau5	CR	
			Psau6	CR	
			Psau7	CR(0..2)	
			Psau8	CR(0..1)	
			Psau9	CR	
			Psau10	CR	
			Psau11	CR	
			Psau12	CR	

■ Device comments

Device Comment		6/26/2008
Data Name:COMMENT		
Device Name	Comment	
X0	Internal Relay 1	
X1	Internal Relay 2	
X2	Special Relay 1	
X3	Special Relay 2	

■ Device memory data

Device Memory										6/26/2008
Data Name:MAIN										
Device Name	+0	+1	+2	+3	+4	+5	+6	+7	+8	+9
X0	0b	0b	0b	0b	0b					
D0	0d	4d	0d	0d	0d	0d	1d			
SW0	0h	1h	2h	3h	4h	5h	6h	7h	8h	9h
W0	0h	1h	2h	3h	4h	5h				
SD0	"###"	"###"	"###"	"###"	"###"	"###"	"###"	"###"	"###"	"###"



■ Device initial values

● Device initial value ranges

Device Initial Value Range 6/11/2009

Data Name: MAIN

No.	Points	Start Device	End Device	Comment
1	5	D0	D4	Data register
2	7	D10	D16	
3	2	D18	D19	
4	16	W0A	W19	Link register
5	3	W1A	W1C	

● Device initial values

Device Initial Value 12/22/2011

Data Name: MAIN Device Type: 16Bit Form: DEC

Device	+0	+1	+2	+3	+4	+5	+6	+7	+8	+9	+10(A)	+11(B)	+12(C)	+13(D)	+14(E)	+15(F)
D0	1	2	3	4	5											
D10	77	85	73	78	32	32	46									
D18	80	85														
W0A	597	597	597	597	597	597	597	597	597	597	597	597	597	597	597	597
W1A	597	597	597													

■ TC setting values

TC Setting 6/27/2011

Data Name : MAIN

Position	Device/Label	Setting Value
( 1)C10		K10
( 8)T1		K100
( 19)T3		D10

■ Device list

Device List 3/17/2011

Find Range: Y0 to Y1FFF  
 Find In: Project1  
 Display Option: All devices  
 Print Range: All

\*: in use, (counts): the number of coil uses

Device	Contact	Coil (counts)	Parameter	Comment
Y0				
Y1		*( 2)		Preset command
Y2	*	*( 1)		Coincidence signal enable
Y3				Down count command
Y4	*	*( 1)		Count enable command
Y5				External preset detection reset
Y6				Counter function selection start
Y7		*( 4)		Coincidence signal No.2 reset

9  
SETTING DEVICE COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15  
WRITING/READING DATA

16  
PROTECTING DATA

■ Cross reference

Cross Reference 3/4/2011

Device/Label: All Device/Label

Print Range: All

Device/Label	Device	Instruction	Position	Program File Name	Data Name
Filtering Condition	Filtering Condition	Filtering Condition	Filtering Condition	Filtering Condition	Filtering Condition
D150	D150		Auto Refresh		0000:Q64AD
D200	D200		Multiple CPU Setting		PLC Parameter
IN_01	SM401		1, ( 4, 2)	MAIN	MAIN_02
Y0	Y0		1, ( 19, 2)	MAIN	MAIN_02
lg_data2			1		Global1

■ Statements/Notes

Statement/Note 6/28/2011

Data Name : MAIN

[Line Statement List]

Step	Line Statement
(0)	Control 21525651
(13)	Auto Operation
	--Warning alarm for 5 secs. at Auto Operation Star-UP-
(61)	Initial Process A
(88)	Set/reset Y75
(122)	Coat Interruptions

■ Project content list

Project Contents List 6/27/2011

Data Name : Project Contents List

Workspace Name : GXW2\_Common

Project Name : Project\_A

Title : PrintTest

Data name	Last Change	Title
Parameter	6/27/2011 11:33:25 AM	
PLC Parameter	6/27/2011 11:33:25 AM	
Network Parameter	6/27/2011 11:33:25 AM	
Ethernet, CC-Link, MELSECNET	6/27/2011 11:33:25 AM	
CC-Link	6/27/2011 11:33:25 AM	
Remote Parameter	6/27/2011 11:33:25 AM	
Disinfectant Function Module	6/27/2011 11:33:25 AM	
Global Label	6/27/2011 11:33:25 AM	
Global1	6/27/2011 11:33:25 AM	
Resource Catalog		

■ User library content list

User library contents list 4/9/2012

Data Name : User library contents list

Workspace name:

Project name:

Title:

Data name	Last change	Title
LIB_SYOKIXA	4/9/2012 11:36:06 AM	
Program	4/9/2012 11:37:34 AM	
LIB_MAINPRG	4/9/2012 11:37:13 AM	
Program	4/9/2012 11:37:13 AM	
Local Label	4/9/2012 11:37:13 AM	
LIB_ST	4/9/2012 11:37:34 AM	
Program	4/9/2012 11:37:34 AM	
Local Label	4/9/2012 11:37:34 AM	
Global Label	4/9/2012 11:39:01 AM	
LIB_GLOBAL	4/9/2012 11:39:01 AM	
FB/FUN	4/9/2012 11:39:38 AM	
LIB_RUN	4/9/2012 11:39:38 AM	
Program	4/9/2012 11:39:38 AM	
Local Label	4/9/2012 11:39:38 AM	
Structured Data Types	4/9/2012 11:42:49 AM	
LIB_INT	4/9/2012 11:42:49 AM	

## Product information list

Product Information List  
Data Name : Product Information List 6/27/2011

Base	Slot	Type	Series	Model Name	Point	I/OAddress	MasterPLC	Serial No.	Ver	Production Number
0	CPU	CPU	Q	Q100UDEHCF	-	-	-	H1127A000000000	B	-
0	0	Intelli.	Q	QD81DL96	32Point	0000	-	120520000000000	B	-
0	1	-	-	Empty	-	-	-	-	-	-
0	2	Input	Q	QX40(-T5)	16Point	0030	-	-	-	-
0	3	-	-	Empty	-	-	-	-	-	-
0	4	-	-	Empty	-	-	-	-	-	-
0	5	-	-	Empty	-	-	-	-	-	-
0	6	-	-	Empty	-	-	-	-	-	-
0	7	-	-	Empty	-	-	-	-	-	-

## Verification result

### Verify result list

Verify Result[PLC Verify] 6/27/2011

Verify Source:Project\_A  
Verify Destination:in Q100UDEH PLC  
Hierarchy:Verify Result List  
Verify Result:There were 7 parts not matched.

No.	Object Type	Data(Verify Source)	Data(Verify Destination)	Verify Result
1	Program File	MAIN	MAIN	Mismatch
2	Program File	MAIN1	MAIN1	Match
3	Program File	MAIN2	MAIN2	Match
4	Program File	MAIN4		Source Only
5	Program File		MAIN3	Dest. Only
6	Program File		MAIN5	Dest. Only
7	Program File		MAIN6	Dest. Only
8	Program File		MAIN7	Dest. Only
9	Parameter	PLC/Network	PLC/Network	Mismatch

### Detailed verify result

Verify Result[PLC Verify] Program File 6/27/2011

Verify Source:Project\_A  
-> MAIN  
Verify Destination:in Q100UDEH PLC  
-> MAIN  
Hierarchy:Verify Result... List -> [1]Program File  
Verify Result:There were 2 parts not matched.

Line	Step	Verify Source	Step	Verify Destination	Verify Result
1	0	LD X0	0	LD X0	Match
2	1	OUT C10 K10	1	OUT C10 K10	Match
3	5	LD C10	5	LD C10	Match
4	6	OUT Y30	6	OUT Y31	Mismatch
5	7	LD Y30	7	LD Y31	Mismatch
6	8	OUT T1 K100	8	OUT T1 K100	Match
7	12	LD T1	12	LD T1	Match
8	13	OUT Y10	13	OUT Y10	Match

9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15  
WRITING/READING  
DATA

16  
PROTECTING  
DATA

## 11.11 Considerations for Printing

Q CPU L CPU Remote Head FX

The following explains the considerations for printing.

### Common considerations of Batch Print and Print Window functions

#### ● Displaying print previews and printing data



Print preview display and printing cannot be executed in the following situations.

- The print target data do not exist.
- The print target screen is being monitored.  
(Start printing after stopping the monitoring.)

#### ● Considerations of printing large volume data


Large volume data may not be printed at all or printed half way due to the limitations of printer driver or Windows® print spooler.

In this case, print data by following the instructions described below.

- Separate the data by setting a print range with "Specify Print Range".
- Set the property of the printer from Windows® Control Panel.  
Example) Select "Devices and Printers" from Windows® Control Panel, open the property of the printer being used, and select "Print directly to the printer" on the Advanced tab on the property screen.
- Set "Output by Item" for the print job output on the Print Setup screen (☞ Section 11.3.1). (For batch print only)
- Set "Output by Item" for the print job output on the Print screen displayed by clicking the  button or the  button. (For batch print only)

#### ● Printing SFC diagrams

When an SFC diagram is printed, the printout may be divided into multiple pages depending on the number of the branches and couplings, and the number of steps. A number that indicates the position is printed at top right of each page.



● **Printing hierarchically-displayed cross reference information**

Cross reference information is printed as shown below when "Display hierarchically" is selected on the <<Condition Setting>> tab.

- "+" and "-" are not printed.
- Each hierarchy of device/label is displayed with indentation.
- When only the lower hierarchy of device/label is selected, the hierarchy above the selected hierarchy is also printed.
- Data in the collapsed rows are not printed.

<Cross reference information displayed on screen>

Device/Label	Label Data T...	Device	Address	Instruction	Position	Program...	Task	Data Type	Data Name	Comment
D150		D150	%MW0.150	Auto Refresh				Intellige...	0000:Q64AD	
D200		D200	%MW0.200	Multiple CPU Setting				Parameter	PLC Parameter	
[Start]		D200	%MW0.200							
[End]		D229	%MW0.229							
IN 01	Bit	SM401	%MX10.401		1, ( 4, 2)	MAIN	Task...	Program	MAIN_02	
Y0	Bit	Y0	%QX0		1, ( 19, 2)	MAIN	Task...	Program	MAIN_02	
g_data2	Struct1(0..3)				1			Global L...	Global1	Array of Struct1
[0]	Struct1									
AAA	Bit	M8176	%MX0.8176		1			Structure	Struct1	Member1
DDD	Double Word...	D12280	%MD0.12280		2			Structure	Struct1	Member2
CCC	Bit(0..2)				3			Structure	Struct1	Member3
[1]	Struct1									

<Printed cross reference information>

Cross Reference 3/16/2011


Device/Label: All Device/Label

Print Range: All

Device/Lab el	Label Data Type	Device	Address	Instructio n	Position	Program File Name	Task	Data Type	Data Name	Comment
D150		D150	%MW0.150	Auto Refresh				Intelligent Function Module Parameter	0000:Q64AD	
D200		D200	%MW0.200	Multiple CPU Setting				Parameter	PLC Parameter	
[Start]		D200	%MW0.200							
[End]		D229	%MW0.229							
IN_01	BR	SM401	%MX10.401		1, ( 4, 2)	MAIN	Task_01	Program	MAIN_02	
Y0	Bit	Y0	%QX0		1, ( 19, 2)	MAIN	Task_01	Program	MAIN_02	
g_data2	Struct1(0..3)				1			Global Label	Global1	Array of Struct1
[0]	Struct1									
AAA	BR	M8176	%MX0.8176		1			Structure	Struct1	Member1
DDD	Double Word[Unsign ed]/Bit String[32-bit]	D12280	%MD0.12280		2			Structure	Struct1	Member2
CCC	Bit(0..2)				3			Structure	Struct1	Member3
[1]	Struct1									

● **Considerations for using the print function with 64-bit edition Windows® operating system**

- When the print result is output with the Print or Print Window function, the Save As screen may not be displayed in the foreground.  
Use **[Alt] + [Tab]** keys or **[Alt] + [Esc]** keys to bring the screen in the foreground.
- GX Works2 does not respond when the GX Works2 operation is performed while the Save As screen is displayed.  
When the following screen is displayed, select "Wait for the program to respond".  
Do not select "Close the program". Unsaved data will be lost.



9 SETTING DEVICE COMMENTS  
 10 SEARCH/REPLACE  
 11 PRINTING  
 12 SETTING OPTIONS  
 13 USING LIBRARIES  
 14 SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION  
 15 WRITING/READING DATA  
 16 PROTECTING DATA



■ Considerations of Print Window function

● Uncompiled programs


Uncompiled program are not printed or reflected to the print preview.  
Print data or display the print preview after converting the program.

● NOPLF instruction

The NOPLF instruction is not supported.

● Structured Ladder/FBD

If a bend point is created in a Structured Ladder/FBD program, it will be printed as shown below. If the bend point is unnecessary to be printed, delete it on the Structured Ladder/FBD editor.  
For details of bend points GX Works2 Version 1 Operating Manual (Structured Project)



● Page feed in ladder program

If a ladder block or function block does not fit in one page, the page is automatically fed and the ladder block or function block is printed from the top of the next page.

● Printing structure/label setting editor

Since the screen width is adjusted automatically to fit the page size when the structure/label setting editor is printed, the printing may be difficult to read depending on the column width of the screen. In order to improve the printing quality, adjust the column width of the structure/label setting editor. The visibility of the printing is increased by adjusting the column width to narrow. However, if the words input into the Remark/Comment column are too long, or one cell is divided into multiple pages, the content in that cell cannot be printed completely.

● Printing intelligent function module data

When the print function is performed on the Print Window Preview screen while the positioning data of intelligent function module are displayed, the font size and the display position of the header may be different from the normal display. Perform the print function on the Print Window screen.

SETTING DEVICE COMMENTS	9
SEARCH/REPLACE	10
PRINTING	11
SETTING OPTIONS	12
USING LIBRARIES	13
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION	14
WRITING/READING DATA	15
PROTECTING DATA	16





---

# 12 SETTING OPTIONS

Option settings such as screen display format setting and detailed operation settings of each function are available.

12.1	Basic Operations	12 - 2
12.2	Option Setting List	12 - 4


## 12.1 Basic Operations

Q CPU L CPU Remote Head FX

This section explains how to set options.

### Screen display

Select [Tool] ⇒ [Options].



### Operating procedure

- **Set the items on the screen.**

When the cursor is placed on a setting item, an explanation of the item is displayed on the "Explanation" field.

### Screen button

- **Back to System Default**

Restores the initial settings.

- **Back to User Default**

Restores the user default settings.

- **Set as User Default**

Stores the current settings as the user default and applies them to a new project.


**● Considerations when changing option settings**


All programs need to be compiled when the following option settings are changed.

- "Default Length of String Data Type" in "Label Setting Editor"
- Settings in "Compile"


Compiling all programs changes the device assignment to labels. Therefore, device values set before the program change remain on the device-assigned labels.

Perform the following operations for a precautionary measure.

- For QCPU (Q mode)/LCPU  
After writing data to the programmable controller CPU, reset the programmable controller CPU, clear all device memories including latches, clear all file registers, and switch the programmable controller CPU to RUN.
- For FXCPU  
After writing data to the programmable controller CPU, clear device memory using the PLC memory clear function, and switch the programmable controller CPU to RUN.

( Section 20.4)

For the considerations for compiling all programs, refer to the following manuals.

 GX Works2 Version 1 Operating Manual (Simple Project)/(Structured Project)

9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA

## 12.2 Option Setting List





Q CPU L CPU Remote Head FX

The following table shows the option setting items.

For (Simple), (FB), (Structured) and (Intelligent) indicated in the Reference column, refer to the following manuals respectively.

- (Simple) ... GX Works2 Version 1 Operating Manual (Simple Project)
- (FB) ... GX Works2 Version 1 Operating Manual (Simple Project, Function Block)
- (Structured) ... GX Works2 Version 1 Operating Manual (Structured Project)
- (Intelligent) ... GX Works2 Version 1 Operating Manual (Intelligent Function Module)

Tree item	Item	Explanation	Default	Reference	
Project	Common Setting	Automatically change language according to system <sup>*1</sup>	Language setting will be automatically changed according to system when edit Ladder/SFC program (Statement and Note) or device comment.	Selected	–
		Use Dedicated Instruction for GX Developer, GX IEC Developer	Dedicated Instruction for GX Developer, GX IEC Developer (Instructions that their name ends with '_M' and '_MD') can be used in the projects using the following function. Open Other Project, Read from PLC or PLC Type change.	Cleared	Section 4.7.1
		Connect directly to PLC on creating a new project	Select whether to connect to PLC directly on creating a new project. In a Ethernet built-in CPU, the connection target is USB. You are required to restart GX Works2 to enable the setting change.	Cleared	–
		Enable the security check for the project	Select whether to check the security for the project. Security for the project is enhanced by enabling the setting. * Please note the following points after enabling the setting to save the project. <ul style="list-style-type: none"> <li>• Unable to open the project in the version 1.606G or earlier ones of GX Works2.</li> <li>• Unable to open the project in the version 1.55H or earlier ones of PX Developer.</li> </ul>	Cleared	Section 4.2.3
	Automatic Save	Save project after compiling	Select whether to save the project automatically after completing compiling. For simple project, this setting is valid only when 'Use Label' is checked.	Cleared	(Simple) (Structured)
		Save project after writing to PLC	Select whether to save the project automatically after writing to the programmable controller CPU.	Cleared	Section 15.1
		Save project after online change	Select whether to save the project automatically after completing online change to the programmable controller CPU. If the checkbox is checked before 'Save project after compiling', the operation is given to priority.	Cleared	Section 15.9.1
		Save project after changes in TC setting values are written to PLC	Select whether to save the project automatically after changes in TC setting values have been written to the programmable controller CPU.	Cleared	(Simple)

Tree item		Item	Explanation	Default	Reference			
Project	Change History	Revision is not Registered when Save Project	Select whether to register the revision after saving a project.	Selected	Section 4.2.3			
		Revision is registered when Save Project		Cleared				
		Display confirmation message showing whether to register history	Select whether to display a confirmation message of the revision registration after saving a project.	Cleared				
		Automatically set revision titles	Select whether to automatically set revision titles at revision registration after saving a project. Automatically-set titles can be changed on the Revision List window.	Cleared				
Program Editor	All Editors	Program/Program File Name	Set a reference/reflection target of device comment of each program/program file.	MAIN	Section 9.1.1			
				Specify the Reference/Reflection		Set a reference/reflection target according to the local device range of PLC parameter when set to "PLC parameter setting". Within the local device range: local device comment Outside the local device range: global device comment	Global	
		Reference/reflect the other, when device comment is not set.	The behavior of each device will be as follows: 1) Global/Local comment will be referred. 2) If comment does not exist, the behavior will be: • specified to Global: refer Local comment. • specified to Local: refer Global comment.	Cleared				
			Apply the current setting of reference/reflection target for device comment to all programs/program files.	-				
			Set all reference/reflection target to 'global' for device comment of selected program/program file name.	-				
			Set a all reference/reflection target to 'local' for device comment of selected program/program file name.	-				
			Set all reference/reflection targets for device comment of target device of the selected program/program file name to "PLC parameter setting". Target Device: Device can be specified within the local device range in the device setting of PLC parameter	-				
		Structured Ladder/FBD/ST	Tool Hint	Monitored Value		Select display item in tool hint when mouse cursor is placed over label/device name.	Selected	(Structured)
				Class			Cleared	
				Device			Selected	
Address	Cleared							
Device Comment	Selected							
Data Type	Cleared							
Constant Value	Cleared							
Label Comment	Selected							
Remark	Cleared							
Tool Hint Display Format	Select display lines on tool hint.			Multi Line				

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

Tree item		Item	Explanation	Default	Reference	
Program Editor	Structured Ladder/ FBD	Label	Display label name/ comment of contact or coil in multiline	Set display lines and characters per line.	Cleared	(Structured)
			Device	Select whether to display the device which is assigned to the label or corresponding to address at the same time when 'Label' is selected from View mode. * Users can neither edit the displayed device nor set them to the Find/Replace target at the same time.	Cleared	
			Address	Select whether to display the address which is assigned to the label or corresponding to device at the same time when 'Label' is selected from View mode. * Users can neither edit the displayed address nor set them to the Find/Replace target at the same time.	Cleared	
			Label Comment	Select whether to display the label comment which is assigned to the label at the same time when 'Label' is selected from View mode. * Users can neither edit the displayed label comment nor set them to the Find/Replace target at the same time.	Cleared	
			Device Comment	Select whether to display device comment which is assigned to device or address when 'Label' is selected from View mode. Cannot display device comment which is assigned to label while using label. * Users can neither edit the displayed device comment nor set them to the Find/Replace target at the same time.	Cleared	
			Declare new label name	Select whether to display the label registration/selection dialog when entering new labels.	Selected	
	FB/FUN	Wrap instance name for function block	Select whether to wrap function block instance name at the function block width.	Cleared		
		Specify the number of enable characters for label name/comment	Specify the number of display characters of function or function block label.	Cleared		
		Automatic input/output labels	Select whether to add input/output label when function block or function is pasted.	Selected		
		Automatic ENO labels	Select whether to add ENO output label when function block or function is pasted.	Cleared		
		Add Automatic Output Variable to VAR_IN_OUT	Select whether to add output variable in VAR_IN_OUT when function block is pasted.	Cleared		
		Pin overwrites	Select whether to overwrite I/O label with a grid line when ruling a grid line over function or function block.	Selected		
		Double clicking opens header	Select whether a label editor is displayed when function or function block is double clicked.	Selected		
		Double clicking opens body	Select whether a program editor is displayed when function or function block is double clicked.	Cleared		

Tree item		Item	Explanation	Default	Reference	
Program Editor	Structured Ladder/ FBD	Guided	Ladder Wrapping	Select whether to wrap ladder. The edited ladder shall be object after changing the setting.	Selected	(Structured)
			Return Contacts		8	
			Open Structured Ladder/ FBD Editor in guided mode	Set guided mode as default when open Structured Ladder/FBD editor.	Cleared	
			Allow hotkey repeater	Select whether to display grid line ruling dialog at drawing lines.	Cleared	
			Enter label names after contacts and coils	Select whether to input label names or devices after entering contacts and coils.	Selected	
			Auto Comment Block Width	Set the width of comment to be added in ladder block with grid numbers when adding ladder block.	8	
	ST		Auto Indention	Select whether to use the automatic indent when beginning a new line after entering ST control syntax such as IF or FOR, and when displaying template of inline structured text.	Selected	
			Instruction/label name prediction	Select whether to display listed label names starting with the input character when a character is input.	Selected	
			Tabulator Length	Set tabulator length. It is not available with inline structured text.	4	

9  
SETTING DEVICE COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15  
WRITING/READING DATA

16  
PROTECTING DATA

Tree item		Item	Explanation	Default	Reference	
Program Editor	Ladder/ SFC	Enter ladder	Check duplicated coil	Select whether to check duplicated coils when entering instruction. Unconverted ladder is not the object for duplicated coil check.	Cleared	(Simple)
			Enter label comment and device comment	Select whether to enter label comment or device comment continuously after entering instructions.	Cleared	
			Do not leave the Device/Label Comment field editing status	Set whether to leave the Device/Label Comment field editing status after opening the comment input dialog. Able to edit comments if users uncheck this setting. Able to copy entire comments if users check this setting.	Cleared	
			Do not display note in ladder input window when edit coil instructions	Select whether to display note in ladder input window when edit coil instructions.	Cleared	
			Check special relay/special register compatible with A-PLC	When A-PLC Compatible Setting of PLC Parameter setting has not be enabled at the time of instruction inputting, check whether to display a confirming message to input special relay/special register compatible with A-PLC. MELSAP-L is an exception.	Cleared	
			Display available instruction tool hints in entering instruction	Select whether to automatically display tool hint of instruction in entering instruction.	Selected	
			Display available instructions in entering instruction	Select whether to automatically display available instructions in entering instruction.	Selected	
			Display available labels in entering instruction	Select whether to automatically display available defined labels in entering instruction.	Selected	
	Tool Hint	Monitored Value	Select display item in tool hint when mouse cursor is placed over label name. * Options for simple project (with label) or label program of structured project. * As for function block, devices are excluded from display target in tool hint.	Selected		
		Class		Cleared		
		Device		Selected		
		Device Comment		Selected		
		Data Type		Cleared		
		Constant Value		Cleared		
		Label Comment		Cleared		
Remark		Cleared				
Tool Hint Display Format	Select the number of display lines in tool hint. * Will be wrapped in 64 single-byte characters or 32 double-byte characters.	Multiple lines				



Tree item		Item	Explanation	Default	Reference	
Program Editor	Ladder	Comment	Device Comment	Select whether to display the label comment or the device comment at ladder editor.	Cleared	(Simple)
			Statement	Select whether to display the statement comment at ladder editor.	Cleared	
			Note	Select whether to display the note comment at ladder editor.	Cleared	
			Device Comment Display Format	Set the display rows and columns for label comment or device comment.	Row: 4 Column: 8	
			Copy device comment in copying ladder	Select whether to copy device comment in copying ladder. * Pasting will be executed by comment reference/reflection setting. * Pasting will not be executed between different PLC. * Copy or pasting will not be executed for protected comments.	Cleared	
	Ladder Diagram	Display Connection of Ladder Diagram	Set the number of contacts. ([Program Editor] ⇒ [SFC] ⇒ [Zoom])	11 Contacts		
		Use the Switching Ladder Edit Mode (Read, Write, Monitor, Monitor (Write))	Select whether to switch Ladder Edit Mode (Read, Write, Monitor and Monitor (Write)). Will be the same operation as the ladder edit mode of GX Developer. * Unable to set when security setting is enabled.	Selected		
		Display labels and devices	Select whether to display labels, and devices assigned to label. (Exclude function block.) * Devices are excluded from Find/Replace target. * Options for simple project (with label) or label program of structured project.	Cleared		
		Display STL instruction in contact format * Only applies to the FXCPU	Select whether to display STL instruction in contact format. This is valid for simple projects (Not using labels) only. Contact format ladder block display for STL instruction is not wrap displayed.	Cleared		
		Display Instruction Help at symbol error occurrence	Select whether to automatically display Instruction Help when symbol errors occur.	Selected		
		Open Undefined Label Registration dialog at ladder entry	Select whether to open Undefined Label Registration dialog when labels used at ladder entry are undefined.	Selected		
		Set initial value to '1' for Enter HLine/Delete HLine dialog	Select whether to set initial value to '1' when Enter HLine/Delete HLine dialog is opened.	Cleared		
		Stop at the connection points (Instruction/Vertical Line) when enter or delete horizontal line.	Select whether to edit line by connection point (Instruction/Vertical Line) when Enter HLine/Delete HLine is executed.	Cleared		

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

Tree item		Item	Explanation	Default	Reference		
Program Editor	SFC	Comment	Block List	Display device comment on SFC block list.	Cleared	(Simple)	
			Step/Transition	Display step/transition comment on SFC editor.	Cleared		
		SFC 1	SFC Edit Area	Set SFC edit area when create SFC. Please change by "SFC Row Setting" after creating a SFC.	Col Number: 10 Line Number: 306		
			Tile SFC and Zoom vertically		Select whether to tile Zoom windows at the cursor position on SFC when creating SFC diagram. Checking this option changes the [Open Zoom with New Window] option into unchecked.		Selected
				Arrange	Select the type of tile for SFC and ZOOM window.		Tile Vertically
				SFC Display Window Ratio	Select window display ratio for SFC when Tile Vertically is selected.		30%
			MELSAP-L Label/Device Display Format	Set display lines for MELSAP-L program.	4		
			Jump to start destination block	Set whether to jump to start destination block when cursor is moved to block start step.	Cleared		
		SFC 2	Leave comment or step No. selected	Select whether to leave comment or step No. selected in <u>Enter SFC Symbol</u> screen when changing SFC symbol in MELSAP3. Block or symbol must be left selected in <u>Enter SFC Symbol</u> screen when newly entering SFC symbol.	Cleared		
		Zoom	Open Zoom with New Window	Select whether to open a new window for each Zoom or to change the display in the fixed window when opening Zoom. Checking this option changes the "Tile SFC and Zoom vertically" option into unchecked.	Cleared		
			Number of Action/ Transition Contacts	Set the number of contacts.	Same as the "Ladder Diagram" setting		

Tree item	Item	Explanation	Default	Reference
Device Comment Editor	Number of Device Comment Edit/Display Characters	Set the number of input and display characters for device comment.	32	Section 9.2.1
	Extended setting	<ul style="list-style-type: none"> <li>When "Standard mode" is selected. Device comment up to 32K points per device can be registered. In total, up to 1024K points per file can be registered.</li> <li>When "Extended mode" is selected. Device comment up to 192K points per device can be registered. In total, up to 2048K points per file can be registered.</li> </ul>	Standard mode	Section 9.4
	Execute the operation including the hidden bit specification information *Only applies to Universal model QCPU and LCPU	Set whether to execute the Copy/Cut/Paste operation including the hidden bit specification information.	Cleared	Section 9.2.1
Device Memory Editor	Always Confirm	Display the window which sets the editor column when opening the target device memory editor for the first time after reading PLC or opening other project.	Always Confirm	Section 4.7.1 Section 15.1.8
	Auto	Always set the column automatically when opening the target device memory editor for the first time after reading PLC or opening other project. Set 8, 10 and 16 columns automatically according to device type.		
	Specify the Column Number	Always set the specified columns when opening the target device memory editor for the first time after reading PLC or opening other project.		
Label Setting Editor	Automatic copy and increment when inserting a row	Select whether to copy the texts in the upper row after incrementing it when inserting a row.	Selected	(Simple) (Structured)
	Copy data type/comment items	Select if the data type, comment, and remark shall be object for auto copy.	Selected	
	Default Length of String Data Type	Set the default string length for string data type.	32	
	Display last blank row	Select whether to display last blank row. This setting is valid for global label and local label except the local label of function block, function and structured data type.	Cleared	
Parameter	Use user defined parameter * Only applies to the QCPU, LCPU	Display the User Defined Parameter Setting button and able to set it. Once the user set parameter is set, it will remain even after checking off the selection box.	Cleared	-
	Display number of columns for CC-Link list setting * Only applies to the QCPU, LCPU	Select 4 columns or 2 columns to display number of columns in CC-Link list setting of network parameter. Please reopen the CC-Link list setting window to reflect changes.	4 Columns	Section 6.3
	Display number of rows for CC-Link station information	Select 16 rows or 8 rows to display number of rows in CC-Link station information of network parameter. Please reopen the CC-Link list setting window to reflect changes.	16 Rows	Section 6.3.1

9

SETTING DEVICE COMMENTS

10

SEARCH/REPLACE

11

PRINTING

12

SETTING OPTIONS

13

USING LIBRARIES

14

SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15

WRITING/READING DATA

16

PROTECTING DATA

Tree item	Item	Explanation	Default	Reference
Common	Disable Current Value Changing by Pressing Shift+Enter	Select whether to disable the current value changing of bit device (bit label) of cursor position when executing ladder editor monitor/watch/intelligent function module monitor/device/buffer memory batch monitor by pressing [Shift]+[Enter] key. This setting will be saved when stopping GX Works2. Please stop this GX Works2 at last when multiple GX Works2 are running.	Cleared	Section 19.1
	Start monitoring if converted or compiled program is opened during monitoring	Select whether to start monitoring automatically if other program is opened while monitor status bar is displayed. Unconverted or uncompiled program will not be monitored.	Cleared	Section 17.2
Monitor	Display Format of Monitoring Value	Select whether to display monitored value in Decimal or Hexadecimal.	Decimal	(Structured)
	Monitor buffer memory and link direct device * Only applies to the QCPU, LCPU, FX3U(C)	Select whether to monitor buffer memory and link direct device during monitoring. Scan time of PLC will be lengthened depending on the setting.	Cleared	
	Significant Characters	Set the number of displayable characters to monitor character-string data.	16	
	Verify with PLC setting before starting monitoring	<ul style="list-style-type: none"> <li>When "Always Verify with PLC" is selected. Verify with PLC before starting monitoring. However, do not verify if simulator is running, selecting uncompiled program's POU, or unchanged POU (Last verification status is held while editor is open).</li> <li>When "Not Always Verify with PLC" is selected. Start monitoring without verifying with PLC.</li> <li>When "Confirm whether to Verify with PLC" is selected. Show a confirmation box whether to verify with PLC before starting monitoring. However, the confirmation box will not be displayed and do not verify if simulator is running, selecting uncompiled program's POU, or unchanged POU (Last verification status is held while editor is open).</li> </ul>	Confirm whether to Verify with PLC	
Ladder/SFC	Set automatic registration destination	Label and device of ladder block (Ladder) in cursor, action/transition step (SFC) will be registered to watch window while monitoring watch window. (Caution 1: Cursor move will be slow under the setting. 2: Select FB instance for function block.)	Not Specified	Section 17.6.2

Tree item	Item	Explanation	Default	Reference	
Monitor	Ladder	Display Format of Monitoring Value	Select the display format of the monitored value in decimal or hexadecimal.	Decimal	(Simple)
		Monitor buffer memory and link direct device * Only applies to the QCPU, LCPU, FX3U(C)	Select whether to monitor buffer memory and link direct device during Ladder-monitoring. Scan time of PLC will be lengthened depending on the setting.	Cleared	
		FXGP format Ladder monitor * Only applies to the FXCPU	PLS/PLF instruction is displayed in GP(DOS) and FXGP(WIN) formats. If it is not checked, it is displayed in GX Developer form.	Cleared	
		Display monitored value by device/label name of contact/coil instruction	In monitoring ladder, select whether to highlight contact/coil instruction based on the monitored value displayed by device/label name.	Cleared	
		Display Lines for Monitoring Current Value	Select whether to display rows of the current value monitor during Ladder-monitoring.	Show Always	
	SFC*2	Watch Step Not Transferring within Watching Time	Select whether to display a warning dialog when detect a step that does not transfer even if specified time passes while monitoring. It is excluded from the target of [Set as User Default] function.	Cleared	(Simple)
		Program/Program File Name	Select watch target program/program file. It is excluded from the target of [Set as User Default] function.	(SFC program name)	
		Target All Blocks	Specify watch target block. It is excluded from the target of [Set as User Default] function.	Selected	
		Specify the Block Detail Setting	Specify watch target block. It is excluded from the target of [Set as User Default] function.	Cleared	
		Stop Transition Watch Monitor when Detected	Select whether to detect other step that does not transfer while displaying warning dialog.	Selected	
		Monitor block start with new window	Select whether to open a corresponding SFC window to monitor when the active step transfers to a block start step.	Cleared	

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

Tree item	Item	Explanation	Default	Reference
PLC Read/Write	Keep last file selection for PLC read/write dialog	Select whether to store file selection status to PLC read/write dialog.	Selected	Section 15.1
	Turn PLC to STOP at time of PLC write after executing Rebuild All and do not execute remote RUN	Select whether to turn the PLC to STOP at the time of PLC write and not execute remote RUN because executing "Rebuild All" from the menu or icon changes the device assignment. PLC write cannot be executed in RUN with this option checked.	Cleared	
	Clear the device ranges set in the Device/Label Automatic-Assign setting to 0 at time of PLC write after a Rebuild All operation * Recommended setting: checked <sup>3,4</sup> * Unnecessary for simple projects (Do not use label)	After executing a Rebuild All, when labels are reassigned to new devices, values from the previous program will remain in the previously assigned devices. This setting automatically clears the device ranges in the Device/Label Automatic-Assign Setting.	Selected	Section 15.1.8 (Simple) (Structured)
	Check the password in reading/writing/verifying/deleting PLC <sup>2</sup>	Select whether to check password in reading/writing/verifying/deleting PLC. Read user default at reading new PLC time. The label program of GX Developer check the password that does not pertain to this setting.	Selected	-
	Check program cache memory when writing to PLC * Universal Model QCPU (except for High-speed Universal model QCPU and Universal model process CPU) and LCPU only	Select whether to execute automatically check program cache memory when writing to program memory. Automatic recovery is enabled in Write to PLC, Online program change, TC setting change, Write title, and Password/Keyword.	Cleared	Manual of programmable controller CPU
	Merge device comment with the project data at time of PLC read.	Select whether to merge the read device comments with the project data or replace the project data with the read device comments in reading from PLC. Device comments created in the extended mode will also be deleted if this option is disabled.	Selected	Section 15.1.8
	Show a completion message if the PLC read/write window is automatically closed	Select whether to show the confirmation message if the PLC read/write operation is successfully finished and the window is automatically closed.	Selected	-
	Show the confirmation message in executing Write to PLC	Select whether to show the confirmation message for the data to be written at the time of PLC write.	Cleared	-

Tree item	Item	Explanation	Default	Reference
Online Change	Execute fall instruction * Only applies to the QCPU and LCPU	Select whether to execute fall instruction (LDF, LDFI, ANDF, ANDFI, ORF, ORFI, MEF, PLF, FCALLP, EFCALLP) at online change.	Cleared	Section 15.9
	Transfer program cache memory to program memory * Only applies to the QCPU and LCPU	Select whether to transfer the program cache memory to program memory when online change completed. * Message will be shown to confirm whether to transfer to or not if it is unchecked.	Selected	
	Execute online change based on relative step No. * Ladder Only * Only applies to the QCPU and LCPU	Select whether to execute online change based on relative step No. from pointer. Even if real step No. is different, online change is available as long as relative step No. from the pointer is corresponding.	Cleared	
	Execute online change by Compile * Enabled when 'Switch the Ladder Edit Mode' is set	Select whether to execute Online Program Change when ladder program or SFC program is edited and compiled. Will be enabled when 'Switch Ladder Edit Mode' is checked. ([Options] ⇒ [Program Editor] ⇒ [Ladder] ⇒ [Ladder Diagram])	Cleared	
	Under booting, reflect changes to boot source during online program change * Except for Q00UJ/Q00U/Q01UCPU, basic model QCPU and FXCPU	Select whether to reflect the changes to boot source after online program change.	Cleared	
Symbolic Information	Setting for Writing Symbolic Information to PLC	Set the writing format for symbolic information. The capacity will be optimized by high speed mode support version but be read only by 1.45X or later. The capacity will not be optimized by compatible mode but be read by 1.44W or previous. FXCPU support only high-speed mode.	High Speed Mode	Section 15.1.5
	Write symbolic information when Online Program Change is executed	Select whether to write symbolic information when Online Program Change is executed. The system writes the symbolic information when Online Program Change is executed if this option is enabled. * The write target of the symbolic information is grayed out if this option is enabled.	Cleared	-
	In the Write to PLC window, keep the symbolic information selected status as a write target	Select whether to keep the symbolic information selected status when the Write to PLC is selected. * Symbolic information and all programs will be write target at time of PLC write when the option is enabled. Only program cannot be written.	Cleared	Section 15.1.5
	Setting for Save Destination of Symbolic Information to PLC	Set a PLC drive to store symbolic information. This setting can be changed when you connect to PLC. Program Memory/Device Memory will be selected in simulation mode if an unusable storage is specified. Default value will be set after changing PLC type.	Program Memory/Device Memory	Section 5.3.2

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

Tree item	Item	Explanation	Default	Reference	
Save Destination of Device Comment	Set save destination of device comment to the target memory of PLC data	Under device comment selected status, select whether to change the target memory of PLC data to the one specified by Save Destination of Device Comment.	Cleared	Section 15.1.7	
	Save Destination of Device Comment	Set the target memory for device comment save destination. Able to change it later. In simulation mode, program/device memory will be selected if invalid destination is specified. * This setting will not be saved by 'Set as User Default' setting.	Program Memory/ Device Memory		
Compile	Basic Setting	Enable calling function block and using inline ST	Enable calling function block from ladder to ST or vice versa, from ladder to Structured Ladder/FBD or vice versa, using inline ST in ladder, reducing steps when using function block. * Input label for VAR_IN_OUT remains equal to output label.	Selected	(Structured)
		Do not execute duplicated coil check, ladder check and consistency (pair) check after Build or Online Program Change	Check when program check is not needed after Build or Online Program Change. It can reduce the compile time depending on the setting.	Selected	(Simple) (Structured)
		Do not target the SET instruction for duplicated coil check	Select whether to set the SET instruction as the target for duplicated coil check.	Cleared	
		Use the same label name in global label and local label	Select whether to use the same label name in global label and local label. When the same label is selected, local label will be given priority.	Cleared	
		Create cross reference information after completion compile.	Creating cross reference information after compiling enables to reduce find time. The information can be found in uncompiled project. Specified find condition is treated as filter condition. The setting will be canceled if find mode is 'Fast Find'.	Cleared	Section 10.1.1
	Output Result	Stop Build	Set the number of error and warning to stop the compile.	Error: 25 Warning: 100	(Simple) (Structured)
		Disable Warning and Notification Message	Register warning codes to invalidate. The registered warning codes shall not be displayed in output window.	(No setting)	
		Display the Use Status Notification of Automatic-Assign Device in Output Result	The use status of device automatic-assign is displayed in output window.	Selected	-



Tree item		Item	Explanation	Default	Reference	
Compile	Ladder/ SFC	Compile Condition	Make sure that the instruction is not used beyond the device range assigned by the label* <sup>2</sup>	Select whether to display warnings or not when ladder/SFC program instruction is using devices out of device range assigned by the labels in instruction. Able to detect instructions that may use devices out of range and may overwrite other label's value.	Cleared	(Simple)
		Compile Condition 1	Use lower-case device names as labels* <sup>5</sup>	Select whether to use device names typed with lower case characters as labels. Only the device name outside device range is valid for Inline Structured Text.	Cleared	(Structured)
			Function Output Setting	Select whether to connect directly from the objective function output to other input.	Selected	
			Allow VAR_OUTPUT at FB call (ST)	Select whether to allow VAR_OUTPUT at FB call. Check: Able to specify VAR_OUTPUT as FB argument. (e.g. FBInst(FBVarOUT:=Variable);) Uncheck: Compile error C8015 returns if VAR_OUTPUT is specified as FB argument.	Selected	
			Add temporary variables as arguments to use macrocode	For FB call of ST or structured ladder from structured ladder, set whether to add temporary variables to input, I/O, or output argument to use macrocode.* Unable to add them depending on the programming language. Please refer to the appropriate manual. (Unable to add temporary variable in a structure.)	Cleared	
	Structured Ladder/ FBD/ST	Compile Condition 2	(D)INT_TO_BOOL_E, (D)WORD_TO_BOOL_E, TIME_TO_BOOL_E	Check the box to generate code that holds the output (SET). When unchecked, the instruction word output will be treated as a coil (OUT).	Selected	
			NOT_E		Selected	
			LIMITAION_E, MAXIMUM_E, MINIMUM_E		Selected	
			EQ_E, NE_E, GT_E, GE_E, LT_E, LE_E		Selected	
			AND_E, OR_E, XOR_E		Selected	
		User Defined Function with EN/ENO	Select whether to generate a code which keeps bit type output of the target function. (Codes keeping bit type are generated if output is in bit type array or in structure array, regardless of option setting.)	Selected		
		User Defined Function Block with EN/ENO	Select whether to generate a code which keeps bit type output of the target function block. (Codes keeping bit type are generated if output is in bit type array or in structure array, regardless of option setting.)	Cleared		
		Compile Condition 3	Automatically assign each system device to output of functions that use EN/ENO	Select whether to assign each system device to output functions of EN/ENO. Only functions enabled. (Function block is disabled.) Only checked functions at [Generate Code That Holds the Output of the Following] are enabled when the output is bit type.	Selected	(Structured)

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

Tree item	Item	Explanation	Default	Reference
Intelligent Function Module*2	Display Specification of Positioning Data	Set the range of positioning data to be displayed.	Data No.1 to 100	(Intelligent)
	Confirm PLC operation status when writing a Data	Select whether to check an operation status of programmable controller CPU and allow to be written in the status of STOP.	Selected	Section 15.1.4
	Display a confirmation message when writing to flash ROM	Select to display a confirmation message when writing to flash ROM.	Selected	
	Guidance	Display intelligent function module guidance	Select whether to automatically display intelligent function module guidance.	Selected
iQ Works Interaction	Enable an editing of parameters set in MELSOFT Navigator	Select whether enabling or not editing parameters set by MELSOFT Navigator.	Selected	Section 6.1
System Label Setting*6,*7	Use MELSOFT Navigator Option Information	Checking this option enables use of the option setting of MELSOFT Navigator. The option setting specified in MELSOFT Navigator at the time of opening this project is used.	Cleared	(Simple) Structured)
	System Label Name Setting	Set how to name system labels. When system labels are entered, system label names are determined based on this setting at the time of project save.	Use global names directly	
Sampling Trace	Display a message to confirm operation contents at the start of trace	Display a confirming message to start trace.	Selected	-
	Display a message to confirm discard of the trace result at the start of trace	Display a message to confirm discard of the trace result at the start of trace.	Selected	
	Display a caution message in saving data as GX LogViewer format CSV file	Display a caution message about data changes in saving data as GX LogViewer format CSV file.	Selected	

\*1 : Supported by Japanese version of GX Works2 only.

\*2 : Not supported by FXCPU.

\*3 : This setting is not required when the following operations are performed, and the programmable controller CPU is switched to RUN for writing programs to programmable controller CPU after compiling programs.  
 • For QCPU (Q mode)/LPCPU: reset the programmable controller CPU, clear all device memories including latches, clear all file registers.  
 • For FXCPU: perform the PLC memory clear function.

\*4 : 0 clear process may take a couple of minutes when a large amount of devices to be cleared exists.

\*5 : Not supported by Simple project.

\*6 : Not supported by Universal model process CPU.

\*7 : For FXCPU, this item is supported by FX3S, FX3G, FX3GC, FX3U, and FX3UC only.

### Point

#### ● Options supported by communication head module and remote I/O module

The following option items are supported by projects for communication head module and remote I/O module.

- Project
- Parameter
- PLC Read/Write
- Intelligent Function Module
- iQ Works Interaction\*1

\*1 : For CC IE Field head module only

---

# 13 USING LIBRARIES

This chapter explains the overview of library function in GX Works2.

13.1 Libraries

13 - 2

---

9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15  
WRITING/READING  
DATA

16  
PROTECTING  
DATA

## 13.1 Libraries

FB library and user library are the libraries of GX Works2.

Work hours for creating programs can be reduced by using functions of library.

This section explains the overview of libraries.

The following table shows the applicability of libraries according to the project type.

○: Applicable ×: Not applicable

Project type	Library	
	FB library	User library
Simple project (without labels)	×	×
Simple project (with labels)	○ ☞ Section 13.1.1	×
Structured project	○ ☞ Section 13.1.1	○ ☞ Section 13.1.2

### 13.1.1 FB libraries



FB libraries are the collection of function blocks prepared as MELSOFT Library and they can be used in projects with labels.

Contact your local Mitsubishi Electric sales office or representative to obtain MELSOFT Library. To use the FB library in a Structured project, import the library to a Simple project (with labels), and change the project type to a Structured project by selecting [Project] ⇒ [Change Project Type].

Programs can be created efficiently by using the FB libraries.

The following shows an example of using the FB library of QD70 positioning module (QD70P4).



For details of using the FB libraries, refer to the following manual.

📖 GX Works2 Version 1 Operating Manual (Simple Project, Function Block)

SETTING DEVICE COMMENTS	9
SEARCH/REPLACE	10
PRINTING	11
SETTING OPTIONS	12
USING LIBRARIES	13
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION	14
WRITING/READING DATA	15
PROTECTING DATA	16


## 13.1.2 User libraries



User libraries are components which can be shared between multiple projects and they can be used in a Structured project only.

User libraries are created by a user.

Frequently-used components are stored and reused for programming efficiency.



The following data can be registered to user libraries.

- Global labels
- Structures
- POU (program blocks, functions, function blocks)

For details of using user libraries, refer to the following manual.

📖 GX Works2 Version 1 Operating Manual (Structured Project)

---

# 14 SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

This chapter explains how to set a connection destination for accessing a programmable controller CPU from GX Works2.

14.1	Setting Connection Destinations	14 - 2
14.2	Accessing Programmable Controller CPU Directly	14 - 8
14.3	Accessing Programmable Controller CPU Via Networks	14 - 15
14.4	Accessing Programmable Controller CPU in Multiple CPU System	14 - 22
14.5	Accessing Redundant CPUs	14 - 25
14.6	Accessing Programmable Controller CPU via Ethernet Board	14 - 33
14.7	Accessing Programmable Controller CPU via G4 Module	14 - 35
14.8	Setting for Access via Serial Communication Module	14 - 36
14.9	Setting for Access via GOT (GOT Transparent Function)	14 - 40
14.10	Accessing Programmable Controller CPU via Phone Line	14 - 50
14.11	Considerations of Communication with Programmable Controller CPU	14 - 72

## 14.1 Setting Connection Destinations

Q CPU L CPU Remote Head FX


This section explains how to set communication routes, including the interfaces both on the personal computer and programmable controller CPU and the routing networks, for accessing a programmable controller CPU.

Multiple connection destinations can be set in GX Works2. To set multiple connection destinations, create data for each connection destination on the New Data screen. (Section 14.1.2)

The programmable controller type of the project should be the same as that of the programmable controller CPU to be accessed.

### Screen display


Select Navigation window ⇒ Connection Destination view ⇒ "(connection destination data name)".





### 14.1.1 Transfer setup screen

Interfaces are displayed on the Transfer Setup screen as shown below and detailed settings of each interface can be configured.



Detailed settings can be set for underlined items on the screen. Double-click these items to set the details. The items whose icons are displayed in yellow are items that have been already set.

- **PC side I/F**  
Set the interface of the personal computer.
- **PLC side I/F**  
Set the interface of the programmable controller CPU connected to the personal computer.

SETTING DEVICE COMMENTS	9
SEARCH/REPLACE	10
PRINTING	11
SETTING OPTIONS	12
USING LIBRARIES	13
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION	14
WRITING/READING DATA	15
PROTECTING DATA	16

● **Other Station Setting**

Select whether routing network exists or not. In addition, set the "Check at communication time" and "Retry times" as necessary.

Item	Description
No Specification	Specify this to access the programmable controller CPU directly connected to a personal computer.
Other Station (Single Network) <sup>*1</sup>	Specify this to access the programmable controller CPU on another station via only one kind of network (including a multi-tier system) such as CC-Link only, MELSECNET/10(H) only, CC-Link IE only, C24 module only and Ethernet only. Since Ethernet is regarded as equivalent to CC-Link IE and MELSECNET/10(H), specify "Single Network" for a mixed system in which Ethernet, CC-Link IE, and MELSECNET/10(H) are configured.
Other Station (Co-existence Network) <sup>*1,*2</sup>	Specify this to access the programmable controller CPU on another station via two kinds of network. This means the system that is configured with two different networks, such that from MELSECNET/10(H) to CC-Link master/local module or from Q series C24 module to MELSECNET/10(H).

\*1 : When the host station is specified, select "No Specification".

\*2 : Not supported by FXCPU.

● **Network Communication Route**

Select the network type, network number, station number, and start I/O number of the network that is routed for accessing the programmable controller CPU on another station. The setting items differ according to the selected network type.

● **Co-existence Network Route<sup>\*1</sup>**

Select the network type, network number, station number, and start I/O number of the network to access. The setting items differ according to the selected network type.

● **Target system<sup>\*1,\*2</sup>**

Specify the access target in the multiple CPU system or the redundant system.

\*1 : Not supported by FXCPU.

\*2 : Not supported by LCPU.

**Screen button**

● **Connection Channel List...**

Displays the Connection Channel List screen.


The connection destination can be set while checking network routes on the Connection Channel List screen.

Since the route selected in the Connection Channel List screen is set automatically on the Transfer Setup screen, the setting is easy even for a complex system.

The following is an example of setting screen when QCPU (Q mode) is selected.

**Operation**

1. **Select a route on the Connection Channel List screen.**
2. **Click the **Update** / **OK** button.**  
The selected route is displayed on the Transfer Setup screen. Set the network number, station number, and other settings depending on the access target.
  - "List mode"



List mode	Description
Display All Routes	Display all routes supported by GX Works2.
Display Selected Routes	Specify the interfaces for "PC side I/F" and "PLC side I/F" on the <u>Transfer Setup</u> screen and select "Display Selected Routes" to display only accessible routes for "Other Station Setting" and "Network Communication Route" setting.

● **PLC Direct Coupled Setting**

Changes the connection destination setting for the setting that connects a personal computer directly to the programmable controller CPU to be accessed.

This function is useful to change the station specification from another station to host station.

● **Connection Test**

Tests if the target programmable controller CPU set on the Transfer Setup screen can be accessed normally.

If accessed normally, the model of the target programmable controller CPU module is displayed on the "PLC Type" field, one of the detailed setting display fields. In addition, for the multiple CPU system, the CPU number of the connection destination is displayed on the "Detail" field.

● **System image(S)...**

Shows the set connection channel in an illustration.

● **Phone Line Connection (C24)...** / **TEL (FXCPU)...**

Displays the Line Connection screen.

The screen is used to set the communication using a phone line.

For details of the Line Connection screen setting, refer to Section 14.10.2.

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA


## 14.1.2 Creating connections

Create a new connection.

Select Navigation window ⇒ Connection Destination view, and perform the following operation.

### Screen display

Select [Project] ⇒ [Object] ⇒ [New] (📄).



### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Data Name	Enter the name of the connection to be created.
Set as Default Connection	Select this to specify the connection destination to be created for regular use.

#### 2. Click the button.

The created connection destination is added to "All Connections" on the Connection Destination view.


### 14.1.3 Specifying connection destination for regular use

Specify a connection destination for regular use when multiple connection destinations are set.

#### Operating procedure

1. Select the connection destination data to be specified as for regular use from "All Connections" on the Connection Destination view.
2. Select [Project] ⇒ [Object] ⇒ [Set as Default Connection].

The name of the selected connection destination data is set as the connection destination for regular use, and displayed on "Current Connection".



#### Point

##### ● Connection destination setting

The connection destination data can also be specified for regular use by dragging and dropping it from "All Connections" to "Current Connection".

9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA


## 14.2 Accessing Programmable Controller CPU Directly

This section explains the setting method for accessing the programmable controller CPU directly connected to a personal computer.

### 14.2.1 Connecting with serial/USB cable



The following explains the setting for accessing the host programmable controller CPU from GX Works2 with serial/USB cable.




## ■ Connecting to QCPU (Q mode)/LCPU

The following explains the setting for accessing the QCPU (Q mode)/LCPU on the host station.

### Operation


#### 1. Set "PC side I/F".

☞ Section 14.1.1




#### 2. Set "PLC side I/F".

Select the series of the programmable controller CPU to be connected.



#### 3. Set "No Specification" for "Other Station Setting".

Set "Check at communication time" and "Retry times" as necessary.

9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA


## ■ Connecting to FXCPU

The following explains the setting for accessing the FXCPU on the host station.

### Operation


#### 1. Set "PC side I/F".

☞ Section 14.1.1




#### 2. Set "PLC side I/F".

This setting is not required for the series other than FX3G, FX3GC, FX3U, and FX3UC.



#### 3. Set "No Specification" for "Other Station Setting".

Set "Check at communication time" and "Retry times" as necessary.





**Point**

● **Lead time to display communication error**

When powering OFF the programmable controller CPU or resetting hardware during a program monitoring, displaying communication error will take time.

Until the error is displayed, the "Connection Status" is displayed as "in execution" on the monitoring status bar.

The lead time to display communication error can be calculated with the following formula.

(Specified time of communication time check) × 3 × (Specified time of number of retries +1)

Example) When communication time check is specified as 30 seconds, and number of retries is specified to '0' (30 seconds) × 3 × (0 +1) equals 90 seconds, and the maximum of 90 seconds later, an error will be displayed.

When a communication error occurs in the functions listed below, an error message will be displayed at '0' time retry, regardless of the number of retries being set.

- Intelligent function module monitor
- Read from PLC
- Write to PLC
- Verify with PLC
- Online program change
- Delete PLC data
- Read PLC user data
- Write PLC user data
- Delete PLC user data
- Monitor
- Device/buffer memory batch monitoring
- Program list monitoring
- Interrupt program monitoring
- Entry Ladder Monitor
- Watch
- SFC block list monitoring
- SFC all block batch monitoring
- SFC active steps monitoring

● **"PC side I/F" of FXCPU**

For FXCPU, select the RS-232/USB with considering the description indicated in the table below.

Item	Description
RS-232 C (Including FX-USB-AW and FX3U-USB-BD)	Select this item when connecting using the RS-232 of a personal computer or when connecting to the USB of a personal computer with FX-USB-AW/FX3U-USB-BD.
USB	Select this item when connecting the GOT2000 series and GOT1000 series USB to the USB of a personal computer directly using the transparent function or when connecting to the USB of a personal computer directly.

● **Communication speed with FXCPU**

The following table shows communication speed that FXCPU support.

Communication speed	FX0 FX0S	FX0N	FX1	FXU FX2C	FX1S	FX1N FX1NC	FX2N FX2NC	FX3S	FX3G FX3GC	FX3U FX3UC
9.6kbps	○	○	○	○	○	○	○	○	○	○
19.2kbps	—	—	—	—	—	○	○	○	○	○
38.4kbps	—	—	—	—	—	—	—	○	○	○
57.6kbps	—	—	—	—	—	—	—	○	○	○
115.2kbps	—	—	—	—	—	—	—	○	○	○

For connecting to FX3S, FX3G, FX3GC, FX3U, or FX3UC and communicating at 38.4kbps/57.6kbps/115.2kbps, the following adapter is required.

FX3S, FX3G, FX3GC: FX-232AWC-H

FX3U, FX3UC: FX-232AWC-H or FX-USB-AW

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA


## 14.2.2 Accessing by Ethernet



\*1: Built-in Ethernet port QCPU only

\*2: FX3S, FX3G, FX3GC, FX3U, and FX3UC only



Access the Ethernet Built-in CPU or the FXCPU with Ethernet adapter from GX Works2 by Ethernet.



\*1 : For details of the system consists of FXCPU and an Ethernet adapter, refer to the following manual.  
 FX3U-ENET-ADP User's Manual

### Operation

- Set the connection destination setting.




Item	Description
PC side I/F	Select an adapter*1 and a protocol. If there are multiple adapters, make sure that the adapter that is used for communication is selected. When there is only one adapter, it does not need to be specified. Since network number and station number are not used, the settings of network number and station number are not required.
PLC side I/F	Select the access method. (  Detailed settings of PLC side I/F)

\*1 : When an adapter name is not displayed on the pull-down list of "Adapter", check the following:

- Is the Ethernet adapter enabled?
- Is the Ethernet cable connected to an Ethernet adapter properly?

## ■ Detailed settings of PLC side I/F

The following is a setting example when searching for an Ethernet Built-in CPU or an FXCPU with Ethernet adapter on the same network connected via hub and utilizing the IP address. The following is a screen of QCPU (Q mode)/LCPU.





### Operation

1. Select a programmable controller type connected to a personal computer in "PLC Mode". For FXCPU, the programmable controller type is fixed to FXCPU.
2. Select "Connection via HUB".
3. For QCPU (Q mode)/LCPU, click the **Find CPU (Built-in Ethernet port) on Network** button, and for FXCPU, click the **Search for FXCPU on Network** button.  
The IP addresses, CPU types, labels, and comments of the Ethernet Built-in CPU or the FXCPUs with Ethernet adapter on the same network are displayed in the 'connection destination CPU information list'.
4. Select an Ethernet Built-in CPU or an FXCPU with Ethernet adapter to be connected in the 'connection destination CPU information list', and click the **Selection IP Address Input** button.  
The selected IP address is displayed in "IP Address".

9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA


### Point

- **When a warning message is displayed**

When clicking the  button, a warning message may be displayed, which indicates that a function of GX Works2 is blocked by Windows firewall. Click the  button, and continue the operation.

- **When the same IP addresses are displayed**

If the same IP address is displayed in the 'connection destination CPU information list' when the


 button is clicked, multiple IP addresses may be set in the Windows® Network Connections setting.

In such case, select the Ethernet adapter that is used for communication for "PC side I/F". (  Section 14.2.2)

## 14.3 Accessing Programmable Controller CPU Via Networks

Q CPU L CPU Remote Head FX

This section explains how to access the programmable controller CPU on another station from a personal computer via networks.



### Operation

1. Set "PC side I/F".  
 ➔ Section 14.1.1
2. Set "PLC side I/F".  
 ➔ Section 14.1.1
3. Set "Other Station Setting"  
 ➔ Section 14.1.1
4. Set "Network Communication Route" / "Co-existence Network Route".  
 Select the network type, network number, station number, and start I/O number of the network that is routed for accessing the programmable controller CPU on another station. The setting items differ according to the selected network type.


9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA

### Point

#### ● Setting connection target with checking the communication route

Click the **Connection Channel List...** button to display the **Connection Channel List** screen.

On the **Connection Channel List** screen, the images of the communication route selected from the list on the screen can be checked. Since the selected route is reflected on the **Transfer Setup Connection** screen automatically, the communication route can easily be set. (☞ Section 14.1.1)



#### ● Connection via Ethernet

The setting of "Station No.↔IP Information" of the Ethernet parameter may be required. For details, refer to the following manual.


☞ MELSEC-Q/L Ethernet Interface Module User's Manual (Application)

■ Setting example of "Other Station (Single Network)"

The following is the setting example for accessing the programmable controller CPU via single network.

● Screen settings for CC-Link system with QCPU (Q mode)/LCPU (single network)

The following shows the connection destination detail setting screen example for the CC-Link system configuration.



① Start I/O number of route source CC-Link master/local module ( ③ )

④ Station number of route target CC-Link master/local module ( ④ )

**Point**

- Accessible station numbers when accessing the programmable controller CPU on another station via CC-Link  
 When the programmable controller CPU is connected directly or via a serial communication module, accessible station numbers when accessing the programmable controller CPU on another station via CC-Link are 0 (master) to 63.


9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

● Screen settings for CC-Link system with FXCPU (single network)

- When FXCPU is a master station  
The following shows the example of connection destination detail setting screen for the CC-Link system configuration.

For details of CC-Link system with FXCPU, refer to the following manuals.

☞ CC-Link user's manuals for FXCPU



- \*1: FX3G/FX3GC version 2.00 or later  
FX3U/FX3UC version 3.10 or later
- \*2: FX3G/FX3GC/FX3U/FX3UC  
For FX3UC, supported by version 2.20 or later
- \*3: CC-Link master station
- \*4: CC-Link intelligent device station


**Point**

● Considerations when accessing other stations via CC-Link

- When accessing other stations via CC-Link, FXCPUs other than the master station can be accessed only when an FXCPU master station (2 in above figure) is relayed. Accessing other FXCPUs via FXCPU other than master station cannot be performed.
- Specify the special block number (0 to 7) of CC-Link master station which is connected to the master station for "Start I/O No." in the Network Communication Route Detailed Setting of CC-Link screen.
- The following are the accessible station numbers according to the FXCPU model of the master station.  
FX3U, FX3UC: 1 to 16  
FX3G, FX3GC: 1 to 12



- When QCPU (Q mode) is a master station  
The following shows the example of connection destination detail setting screen for accessing FXCPU via QCPU (Q mode).  
For details of CC-Link system with FXCPU, refer to the following manuals.  
☞ CC-Link user's manuals for FXCPU



\*1: Master station  
\*2: FX3G/FX3GC/FX3U/FX3UC  
For FX3UC, supported by version 2.20 or later  
\*3: CC-Link intelligent device station

Start I/O number of route source  
CC-Link master/local module (③)

Station number of request target  
CC-Link intelligent device station (④)



**Point**

- Accessible station numbers when accessing other stations via CC-Link  
Accessible station numbers are 1 to 63.

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

● **Screen settings for the mixed system in which MELSECNET/10(H), CC-Link IE, and Ethernet are configured (single network)**

For the mixed system in which MELSECNET/10(H), CC-Link IE, and Ethernet are configured, specify "Single Network" when accessing the programmable controller CPU on another station. (Since Ethernet is regarded as equivalent to CC-Link IE and MELSECNET/10(H), specify "Single Network".) The following shows the connection destination detail setting screen example for the mixed system configuration (Q series only).



**Point**

● **Accessing programmable controller CPUs on another station**

Routing parameters need to be set when accessing a programmable controller CPU on another station with a different network number, or when accessing a programmable controller CPU on another station via network system mixed with MELSECNET/10(H), CC-Link IE and Ethernet.

Accessing a programmable controller CPU on another station is possible within the network system specifications by setting routing parameters.

For details of routing parameters, refer to the manual of each network module.

● **Mixed system consisting of MELSECNET/10(H), CC-Link IE, and Ethernet**

Ethernet parameter "Station No. ↔ IP Information" must be set. For details, refer to the following manual.

📖 MELSEC-Q/L Ethernet Interface Module User's Manual (Application)


## ■ Setting example of "Other Station (Co-existence Network)"

The following is the setting example for accessing the programmable controller CPU via co-existence network.

This setting is not supported by LCPU and FXCPU.

### ● Screen settings for the mixed system in which MELSECNET/10(H) and Q series C24 modules are configured (co-existence network)

The following shows the connection destination detail setting screen example for the mixed system configuration (Q series only).



① PC side I/F Serial Setting

② PLC side I/F Detailed Setting of C24

③ Network Communication Route Detailed Setting of CC IE Control NET/10(H)

④ Co-existence Network Route Detailed Setting of C24

Start I/O number of route source C24 module (③)

Station number of route target C24 module (④)

9

SETTING DEVICE COMMENTS

10

SEARCH/REPLACE

11

PRINTING

12

SETTING OPTIONS

13

USING LIBRARIES

14

SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15

WRITING/READING DATA

16

PROTECTING DATA

## 14.4 Accessing Programmable Controller CPU in Multiple CPU System



\*1 : Not supported by Q00J/Q00UJ and Redundant CPU.

This section explains the setting method for accessing the programmable controller CPU (host CPU) directly connected to the personal computer or other programmable controller CPUs (other CPUs) in the multiple CPU system. The setting method for accessing the multiple CPU system on another station via a network is also explained.

### ■ Accessing host CPU

The setting for accessing the host CPU is the same as that for accessing the programmable controller CPU on the host station. (☞ Section 14.2)


### ■ Accessing other CPUs

In the multiple CPU system, specify the CPU number of the access target at "Multiple CPU Setting" when accessing a programmable controller CPU that is not directly connected to the personal computer.

For Basic model QCPU and Universal model QCPU (Q00U/Q01U/Q02U), the CPU No. 1 to 3 can be specified.


For High Performance model QCPU, Process CPU, and Universal model QCPU (except for Q00U/Q01U/Q02U), the CPU No. 1 to 4 can be specified.

The following shows a setting example when accessing the CPU No. 4 by connecting the personal computer to the CPU No. 1.



### Operation

1. Set the settings from "PC side I/F" to "Co-existence Network Route" (☞ Section 14.1.1)
2. Set the access target CPU number with "Multiple CPU Setting" for "Target System".



## ■ Accessing the programmable controller CPU via network in multiple CPU system

The following explains the setting method for accessing the programmable controller CPU in a multiple CPU system on another station via a network.



### ● Relay station

Set the parameters so that the network module mounted on the relay station is controlled by the same programmable controller CPU. (In the figure below, CPU No. 2 is the control CPU.)

### ● Access target station

Set the CPU number in "Multiple CPU Setting" on the Transfer Setup screen if the access target station has the multiple CPU system.

The following shows a setting example when accessing the CPU No. 4 in the multiple CPU system on the access target station via a network.



\*1: Section 14.1.1

SETTING DEVICE COMMENTS	9
SEARCH/REPLACE	10
PRINTING	11
SETTING OPTIONS	12
USING LIBRARIES	13
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION	14
WRITING/READING DATA	15
PROTECTING DATA	16

### *Point*

---

- **Access range by network module function versions**

To access programmable controller CPUs which are not controlling the network module of the access target station, use the network module with function version B or later.


---

# 14.5 Accessing Redundant CPUs

Q CPU
<sup>\*1</sup>
~~L CPU~~
~~Remote~~
~~Head~~
~~FX~~

\*1 : Redundant CPU only

This section explains how to access Redundant CPUs.



### Operation

1. Set the settings from "PC side I/F" to "Co-existence Network Route". (👉 Section 14.1.1)
2. Specify the system with "Target System".

Item	Description
Not Specified	<ul style="list-style-type: none"> <li>• When connecting a CPU directly A programmable controller CPU directly connected to a personal computer</li> <li>• When routing a module mounted on a main base unit A programmable controller CPU of the station on which a network module whose station number is specified for the network communication route is mounted</li> <li>• When routing a module mounted on an extension base unit A programmable controller CPU whose system is set as a control system</li> </ul>
Control System	A programmable controller CPU whose system is a control system
Standby System	A programmable controller CPU whose system is a standby system
System A	A programmable controller CPU with an A side connector of tracking cable
System B	A programmable controller CPU with a B side connector of tracking cable

9 SETTING DEVICE COMMENTS  
 10 SEARCH/REPLACE  
 11 PRINTING  
 12 SETTING OPTIONS  
 13 USING LIBRARIES  
 14 SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION  
 15 WRITING/READING DATA  
 16 PROTECTING DATA

*Point* 

● **"Target System" setting when performing the monitoring function**

When performing the monitoring function on a Redundant CPU, set "Not Specified", "System A", or "System B" for "Target System".

---



## 14.5.1 Considerations for routing intelligent function module on extension base unit

The following table shows the applicability of functions according to the "Target System" setting when accessing a Redundant CPU via an intelligent function module on the extension base unit.

○: Applicable △: Applicable with restrictions ×: Not applicable

Function	Target System		Restrictions
	System A/ System B	Not specified/ Control system/ Standby system	
Change TC setting	×	×	
Online program change	×	×	
Read from PLC	○	×	
Write to PLC	×	×	
Verify with PLC	○	×	
Redundant Operation	○	△	System switching and change operation mode functions are not applicable.
Password	New	○	×
	Delete	○	×
	Disable	○	×
Clear PLC memory	○	△	Clear all file registers function is not applicable.
Arrange PLC memory	×	×	
Delete PLC data	○	×	
Read PLC user data	○	×	
Write PLC user data	×	×	
Delete PLC user data	○	×	
Export to ROM format	×	×	
Monitor mode	○	△	Monitoring SFC programs is not applicable.
Monitor (write mode)	○	△	Monitoring and verifying SFC programs are not applicable.
Start monitoring (all windows)	○	△	Monitoring SFC programs is not applicable.
Stop monitoring (all windows)	○	△	Monitoring SFC programs is not applicable.
Start monitoring	○	△	Monitoring SFC programs is not applicable.
Stop monitoring	○	△	Monitoring SFC programs is not applicable.
Local device monitoring	○	×	
Monitoring program list	○	×	
Interrupt program list	○	×	
Monitoring condition setting	×	×	
SFC all block batch monitoring	○	×	
SFC auto scroll	○	×	
Sampling trace	×	×	
Scan time measurement	○	×	
MELSECNET diagnostics	△	×	Network test, loop test, setting verification test, station order check test, and communication test are not applicable.
Online module change	○	×	
Confirm memory size	○	△	Online mode is not applicable.

SETTING DEVICE  
COMMENTS

9

SEARCH/REPLACE

10

PRINTING

11

SETTING OPTIONS

12

USING LIBRARIES

13

SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

14

WRITING/READING  
DATA

15

PROTECTING  
DATA


16

## 14.5.2 Operation when system switching occurs on Redundant CPU

When a system switching occurs while accessing a Redundant CPU, the access is continued as described below.

This function is valid when "Control System" or "Standby System" is set for "Target System" on the Transfer Setup screen.

When "Control System" is set for "Target System".



## 14.5.3 Operation when communication error occurs during monitoring

If a communication error occurs on the route of communication with Redundant CPU, the communication route is automatically switched to continue the monitoring of the system specified on the Transfer Setup screen.

When the following conditions 1 to 3 are satisfied, the access to the Redundant CPU is continued by route switching.

### 1) Monitoring functions of route switch target

- Ladder program monitoring (including Entry Ladder Monitor function, and monitoring programs of Zoom editor and inline structured text)\*<sup>1</sup>
- ST program monitoring
- Structured Ladder/FBD monitoring
- Local device monitoring\*<sup>2</sup>
- Device/buffer memory batch monitoring\*<sup>3</sup>
- Watch
- Monitoring condition setting\*<sup>4</sup>
- Monitoring stop condition setting\*<sup>4</sup>
- Remote operation
- Redundant operation
- PLC diagnostics
- Monitoring of intelligent function module

\*1 : Not supported by SFC diagram.

\*2 : When a communication error occurs and the local device monitoring target program is switched, the monitoring stops.

\*3 : When a communication error occurs at a timing of display format change, or when a communication error occurs during scrolling, the monitoring stops.

\*4 : When a communication error occurs, conditions cannot be registered/canceled.

### 2) Operation modes and connection targets in which a route switch can be performed

–	Operation mode/connection target in which a monitoring can be continued
Operation mode	Backup mode, separate mode
Connection target	Control system, standby system, system A, system B

### 3) Communication routes in which a route switch can be performed

9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA

PC side I/F	PLC side I/F	Other Station Setting	Network Communication Route	Co-existence Network Route
Serial/USB	PLC Module	Other Station (Single Network)	CC IE Cont, NET/10(H)	–
			CC IE Field	–
			Ethernet	–
		Other Station (Co-existence Network)	C24	CC IE Cont, NET/10(H) Ethernet
			CC-Link	CC IE Cont, NET/10(H) Ethernet
	GOT	Other Station (Single Network)	CC IE Cont, NET/10(H)	–
			CC IE Field	–
			Ethernet	–
		Other Station (Co-existence Network)	C24	CC IE Cont, NET/10(H) Ethernet
			CC-Link	CC IE Cont, NET/10(H) Ethernet
Serial/USB	Head Module	Other Station (Single Network)	CC IE Field	–
		Other Station (Co-existence Network)	C24	CC IE Cont, NET/10(H) Ethernet
			CC-Link	CC IE Cont, NET/10(H) Ethernet
	C24	Other Station (Single Network)	CC IE Cont, NET/10(H)	–
			CC IE Field	–
			Ethernet	–
		Other Station (Co-existence Network)	C24	CC IE Cont, NET/10(H) Ethernet
			CC-Link	CC IE Cont, NET/10(H) Ethernet
	NET/10(H) Remote	Other Station (Single Network)	CC IE Cont, NET/10(H)	–
			Ethernet	–
		Other Station (Co-existence Network)	C24	CC IE Cont, NET/10(H) Ethernet
			CC-Link	CC IE Cont, NET/10(H) Ethernet
G4 Module	Other Station (Co-existence Network)	CC-Link	CC IE Cont, NET/10(H) Ethernet	
CC IE Cont NET/10(H) Board	CC IE Cont NET/10(H) Module	Other Station (Single Network)	CC IE Cont, NET/10(H)	–
CC IE Field Board	CC IE Field Master/Local Module	Other Station (Single Network)	CC IE Field	–
	Head Module	Other Station (Single Network)	CC IE Field	–
	CC IE Field Ethernet Adapter	Other Station (Single Network)	CC IE Field	–
CC-Link Board	CC-Link Module	Other Station (Co-existence Network)	CC-Link	CC IE Cont, NET/10(H) Ethernet

PC side I/F	PLC side I/F	Other Station Setting	Network Communication Route	Co-existence Network Route
Ethernet Board	CPU module	Other Station (Single Network)	CC IE Cont, NET/10(H)	-
			CC IE Field	-
			Ethernet	-
		Other Station (Co-existence Network)	C24	CC IE Cont, NET/10(H) Ethernet
			CC-Link	CC IE Cont, NET/10(H) Ethernet
				Ethernet
	GOT	Other Station (Single Network)	CC IE Cont, NET/10(H)	-
			CC IE Field	-
			Ethernet	-
		Other Station (Co-existence Network)	C24	CC IE Cont, NET/10(H) Ethernet
			CC-Link	CC IE Cont, NET/10(H) Ethernet
				Ethernet
	Ethernet Module	Other Station (Single Network)	Ethernet	-
	CC IE Field Ethernet Adapter	Other Station (Single Network)	CC IE Field	-

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

**Point****● Operation of monitoring functions when a route switch occurs**

When the target monitoring functions for route switch and other monitoring functions are mixed in an operation, the target monitoring functions for route switch continues operation and other monitoring functions stop operation.

**● Situations when a route cannot be switched**

A route switch which is triggered by a communication error cannot be performed when any of the following situations occurs at a monitoring start.

- An error occurs on the first communication to the connective system.
- One of the Redundant CPUs is powered OFF or reset.
- A tracking error occurs and a communication cannot be established between the redundant CPUs.

**● Messages indicating a system switch request from network module and a tracking cable communication error detection**

If a message indicating a system switch request from network module or a tracking cable communication error detection is displayed during monitoring, the system may have been switched.

Check the corresponding location by following the instruction described on the message, and remove the error factor of route switch.

In order to display the above message(s) when communicating via Ethernet, select the following item(s) in the redundant setting of the Ethernet parameter.

If the item is not selected, the message will not be displayed even when a route switch is performed.


- Issue system switch in Cable disconnection timeout
- Issue system switch in communication error

# 14.6 Accessing Programmable Controller CPU via Ethernet Board

Q CPU
  L CPU
  Remote
  Head
  FX

\*1 : CC IE Field head module only

This section explains the setting method for accessing the programmable controller CPU via an Ethernet board of a personal computer. The following shows a setting example when accessing the programmable controller CPU from GX Works2 via Q series-compatible E71 modules. For the setting to access FXCPU, refer to the manual of the Ethernet module or the manual of the setting software.



9  
SETTING DEVICE COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES


14  
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15  
WRITING/READING DATA

16  
PROTECTING DATA

**Operation**

- Set the connection destination setting.



Item	Description
PC side I/F	Set the adapter*1, network number, station number*2, and protocol. If there are multiple adapters, make sure that the adapter that is used for communication is selected. When there is only one adapter, it does not need to be specified.
PLC side I/F	Set the model, station number, IP address and other items for the module to be connected to the personal computer. For "Station No. ⇔ IP Information", set the method corresponding to the setting for "Station No. ⇔ IP Information" of Ethernet parameter.
Network Communication Route	Set the network number and station number of the access target station.

\*1 : When an adapter name is not displayed on the pull-down list of "Adapter", check the following:

- Is the Ethernet adapter enabled?
- Is the Ethernet cable connected to an Ethernet adapter properly?

\*2 : Set the station number avoiding the same station number already assigned to the existing system or another Ethernet module.

**Point**

● **Connecting MELSOFT products (such as GX Works2)**

When connecting a MELSOFT product (such as GX Works2) using TCP/IP connection, select "MELSOFT Connection" for "Open System" on the network parameter. In case connecting to multiple MELSOFT products, set the number of connections to be connected.

For UDP/IP connection, the connection for MELSOFT products is not necessary to be added.

For details of settings, refer to the following manuals.

☞ Q Corresponding Ethernet Interface Module User's Manual (Basic)

☞ MELSEC-L Ethernet Interface Module User's Manual (Basic)

'MELSOFT Connection' is supported by Q series-compatible E71 function version B modules with a serial number whose first five digits are '02122' or higher.

● **Multiple network systems**

For a multiple network system, routing parameters must be set.

☞ MELSEC-Q/L Ethernet Interface Module User's Manual (Application)



# 14.7 Accessing Programmable Controller CPU via G4 Module



\*1 : CC IE Field head module only


This section explains the setting method for accessing the programmable controller CPU via a G4 module.

For details of AJ65BT-R2N, refer to the following manual.

☞ **CC-Link System RS-232 Interface Module User's Manual (MELSOFT Connection Mode)**

The following shows a setting example when accessing the programmable controller CPU via AJ65BT-G4-S3 module from GX Works2.

Data link must be correctly established by setting the switch settings and parameters for the AJ65BT-G4-S3 module and the CC-Link master module.



### Operation

- Set the connection destination setting.

Item	Description
PC side I/F	Set the COM port and transmission speed.
PLC side I/F	Set the model of the G4 module to be connected.
Other Station Setting	Set "Other Station (Single Network)".
Network Communication Route	Set the station number of the access target station.

9 SETTING DEVICE COMMENTS  
 10 SEARCH/REPLACE  
 11 PRINTING  
 12 SETTING OPTIONS  
 13 USING LIBRARIES  
 14 SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION  
 15 WRITING/READING DATA  
 16 PROTECTING DATA

# 14.8 Setting for Access via Serial Communication Module


Q CPU
  L CPU
  Remote
  Head <sup>\*1</sup>
 FX

\*1 : CC IE Field head module only

This section explains the setting method for accessing the programmable controller CPU on host station or on another station via a C24 module.

## 14.8.1 Connection on a 1:1 basis

The following shows a setting example when accessing a programmable controller CPU by connecting a personal computer and a Q series C24 module.



For connection on a 1:1 basis, the accessing or monitoring can be performed without setting the switch setting.

For details of the switch settings, refer to the following manuals.

- ☞ Q Corresponding Ethernet Interface Module User's Manual (Basic)
- ☞ MELSEC-L Ethernet Interface Module User's Manual (Basic)

### Operation

- **Set the connection destination setting.**

The following shows a setting example on a screen when accessing a programmable controller CPU from GX Works2 via a C24 module.

The image below is an example for Q series C24 module.

The image displays three screenshots from the GX Works2 software interface:

- Transfer Setup Connection1**: The main configuration window. Under 'PC side I/F', the 'Q Series Bus' icon is selected. Under 'PLC side I/F', the 'C24' icon is selected. The 'Station No.' is set to 0 and 'Computer Type' is 'QJ71C24'. A circled '1' points to the 'Q Series Bus' icon, and a circled '2' points to the 'C24' icon.
- PC side I/F Serial Setting**: A dialog box showing 'COM Port' set to 'COM1' and 'Transmission Speed' set to '19.2kbps'. A circled '1' points to this dialog.
- PLC side I/F Detailed Setting of C24**: A dialog box showing 'PLC Type' set to 'QJ71C24', 'Station No.' set to 0, 'Parity' set to 'Odd', and 'Sum Check' set to 'Exists'. A circled '2' and a '\*1' symbol point to this dialog.
- Host Station Detailed Setting**: A dialog box showing 'Check at Communication Time' set to 30 seconds and 'Retry Times' set to 0. A circled '3' points to this dialog.

Item	Description
PC side I/F	Set the COM port and transmission speed.
PLC side I/F*1	Set the model and station number of the C24 module to be connected.
Other Station Setting	Set "No Specification".


\*1 : If a number other than '0' is set in the station number setting of the C24 module, set the same number for its station number.  
The station number setting can be set in "Switch 5" (station number setting) in the switch setting of the PLC parameter.

## 14.8.2 Connection on a 1:n basis

Access the programmable controller CPU in another station from GX Works2 in a system composed of multiple programmable controller CPU stations.

### ■ Access via a serial communication module

The following shows a setting example when accessing the programmable controller CPU in another station via Q series C24 modules.



The following table shows an example of switch settings of the I/O assignment setting. For details of the switch settings, refer to the following manuals.

☞ Q Corresponding Ethernet Interface Module User's Manual (Basic)

☞ MELSEC-L Ethernet Interface Module User's Manual (Basic)

#### ● Station number 0

Item	Description		Setting
Switch 1	CH1 communication speed	CH1 transmission setting	07E6H
Switch 2	-	CH1 communications protocol	0008H
Switch 3	CH2 communication speed	CH2 transmission setting	07E7H
Switch 4	-	CH2 communications protocol	0000H
Switch 5	Module station number		0000H

#### ● Station number 1


Item	Description		Setting
Switch 1	CH1 communication speed	CH1 transmission setting	Set according to the application on CH1 side.
Switch 2	-	CH1 communications protocol	
Switch 3	CH2 communication speed	CH2 transmission setting	07E6H
Switch 4	-	CH2 communications protocol	0005H
Switch 5	Module station number		0001H

● Detailed description of settings

Item		Description
Operation Setting	Station number 0	Linked operation
	Station number 1	Independent operation
Data bit setting		8
Parity bit yes/no setting		Yes
Odd/even parity bit		Odd
Stop bit setting		1
Sum check yes/no setting		Yes
Online change enable/disable setting		Enable
Setting change enable/disable setting		Disable
Transmission speed setting		19200bps
Communications protocol	Station number 0	GX Developer connection
	Station number 1	CH1: Set to meet the application CH2: MC protocol format 5

**Operation**

- **Set the connection destination setting.**  
The following shows a setting example of a screen for accessing C24 modules from GX Works2. The image below is an example for Q series C24 module.




Item	Description
PC side I/F	Set the COM port and transmission speed.
PLC side I/F	Set the model and station number of the C24 module to be connected.
Other Station Setting	Set "Other Station (Single Network)".
Network Communication Route	Specify the start I/O number of the C24 module connected to GX Works2 and the station number of access target.

## Direct connection of a programmable controller CPU

The following shows a setting example when accessing the programmable controller CPU in another station via Q series C24 modules by directly connecting the personal computer to the programmable controller CPU.

A programmable controller CPU on another station can be accessed only with CH2 of a Q series C24 module.



### Operation

- **Set the connection destination setting.**

The following shows a setting example of a screen for accessing a programmable controller CPU from GX Works2 via C24 modules.

The image below is an example for Q series C24 module.

The screenshot shows the 'Transfer Setup Connection1' dialog box in GX Works2. It has several tabs: 'PC side I/F', 'PLC side I/F', 'Other Station Setting', and 'Network Communication Route'. The 'PC side I/F' tab is selected, showing options for USB, CC-IE Cont NET/10(H) Board, CC-Link Board, Ethernet Board, CC-IE Field Board, and Q Series Bus. The 'PLC side I/F' tab is also visible, showing options for Module, CC-IE Cont NET/10(H) Module, CC-Link Module, Ethernet Module, C24, and GOT. The 'Other Station Setting' tab shows 'Other Station (Single Network)' selected. The 'Network Communication Route' tab shows 'Head I/O' set to 20 and 'Station No.' set to 1. Three callouts point to sub-dialogs: 1 points to 'PC side I/F Serial Setting' (RS-232C selected, COM 1, 19.2Kbps), 2 points to 'PLC side I/F Detailed Setting of PLC Module' (QCPU (Q mode) selected), and 3 points to 'Host Station Detailed Setting' (Check at Communication Time 30 sec, Retry Times 0).

Item	Description
PC side I/F	Set the interface of the personal computer. (Refer Section 14.1.1)
PLC side I/F	Select the series of the programmable controller CPU to be connected.
Other Station Setting	Set "Other Station (Single Network)".
Network Communication Route	Specify the start I/O number of the C24 module connected to GX Works2 and the station number of access target.

## 14.9 Setting for Access via GOT (GOT Transparent Function)

This section explains how to access the programmable controller CPU from GX Works2 via GOT using the GOT transparent function.

### Point

- **Considerations on executing online operations from GX Works2**

Do not execute online operations from GT Designer2 to GOT (such as downloading project data) when online operations are being executed from GX Works2 to the programmable controller CPU using the GOT transparent function.

- **When GOT does not monitor normally**

**The GOT transparent function cannot be used in the following cases.**

- When GOT does not monitor normally due to programmable controller CPU errors or communication errors between the programmable controller CPU and GOT
- During the period of time between turning ON or resetting the programmable controller CPU or GOT and the start of GOT monitoring

Check the following items if GOT does not monitor normally.


Item	Description
Does the programmable controller CPU operate normally?	Refer to the user's manual of the programmable controller CPU used.
Is the programmable controller CPU connected to GOT normally?	Refer to the connection manual of the GOT mentioned in each section.

## 14.9.1 Accessing programmable controller CPU via GOT

Q CPU  
  L CPU  
  Remote  
  Head  
  FX

Access the programmable controller CPU via GOT.

Personal computer (GX Works2)



The following table shows the connection between the personal computer and GOT.

○: Connectable, -: Not connectable

Connection	GOT*1			
	GOT2000 series	GOT1000 series	GOT-A900 series	GOT-F900 series
RS-232 connection	○	○	○	○
USB connection	○	○	-	-
Ethernet connection	○	○	-	-

- \*1 : For cables connecting GOT with the programmable controller CPU, GOT settings, and considerations, refer to the manual of the GOT connected.
- GOT2000 Series Connection Manual (Mitsubishi Products) For GT Works3 Version1
  - GOT1000 Series Connection Manual (Mitsubishi Products) for GT Works3
  - GOT1000 Series Connection Manual
  - GOT-A900 Series User's Manual (GT Works2 Version2/GT Designer2 Version2 compatible Connection System Manual)
  - GT Designer2 Version2 Operating Manual
  - GOT-F900 SERIES GRAPHIC OPERATION TERMINAL HARDWARE Manual [Connection]

9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15  
WRITING/READING  
DATA


16  
PROTECTING  
DATA

**■ Connecting personal computer and GOT with RS-232 or USB**

The following shows the settings for connecting a personal computer and a GOT with RS-232 or USB.

**Operation**

1. Set "PC side I/F". (☞ Section 14.1.1)
2. For QCPU (Q mode), LCPU, FX3s, FX3G, FX3GC, FX3U, or FX3UC, double-click "GOT" on "PLC side I/F".  
The PLC side I/F Detailed Setting of GOT screen is displayed.



For CPUs other than FX3s, FX3G, FX3GC, FX3U, or FX3UC, click "GOT" on "PLC side I/F". The screen will not be displayed in this situation.

3. For QCPU (Q mode), LCPU, FX3s, FX3G, FX3GC, FX3U, or FX3UC, set the following setting on the PLC side I/F Detailed Setting of GOT screen.

Item	Description	
Detail setting for GOT and PLC connection	Select "PLC Module/CC IE Field Ethernet Adapter"	
Setup	Select "QCPU (Q mode)", "LCPU", or "FXCPU" for "PLC Mode".	
	<b>Setting method</b>	<b>Description</b>
	Bus connection	Select "via GOT (Bus) transparent mode". (For QCPU (Q mode) only)
	Direct connection	Select "via GOT (direct connection) transparent mode".
	Ethernet connection	Select "via GOT (Ethernet) transparent mode", and set the GOT (Ethernet) transparent setting from the <b>Setting...</b> button.
GOT-F900	Select "via GOT-F900 transparent mode". Note that if the detailed setting for PC side I/F is USB, this item cannot be selected. (FXCPU only)	

4. Set "Other Station Setting" depending on a route to the connection destination. (☞ Section 14.1.1)

**Point**

● **Connecting modules via Ethernet adapter module (For QCPU (Q mode)/LCPU)**

Modules can be connected via Ethernet adapter module using an Ethernet adapter module with the GOT (Ethernet) transparent function.

- Select "via GOT (Ethernet) transparent mode" in the detailed setting and select "NZ2GF-ETB" in the field next to the **Setting...** button.




## ■ Connecting personal computer and GOT with Ethernet

The following shows the settings for connecting a personal computer and a GOT with Ethernet.

### Operation

1. Set "PC side I/F". (☞ Section 14.1.1)
2. Double-click "GOT" on "PLC side I/F".  
The PLC side I/F Detailed Setting of GOT screen is displayed.
3. Set the following setting on the PLC side I/F Detailed Setting of GOT screen.

<Detailed setting screen when using the Ethernet connection between personal computer and GOT>



Item	Description
Ethernet Detail setting for PC and GOT connection	Set settings such as an IP address and a host name when using the Ethernet connection between a personal computer and a GOT.
Detail setting for GOT and PLC connection	Select "PLC Module/CC IE Field Ethernet Adapter"
Setup	Set the following setting according to the setting method between a GOT and a programmable controller CPU. For details, refer to "☞ ■ Connecting personal computer and GOT with RS-232 or USB".

4. Set "Other Station Setting" depending on a route to the connection destination.  
For FXCPU, only "No Specification" can be set. (☞ Section 14.1.1)

9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION


15  
WRITING/READING  
DATA

16  
PROTECTING  
DATA

## 14.9.2 Accessing programmable controller CPU via serial communication module



The following explains the GX Works2 setting method for accessing the programmable controller CPU via a GOT and a serial communication module.



\*1 : The following table shows the connection between the personal computer and GOT.

○: Applicable, -: Not connectable

Connection	GOT			
	GOT2000 series	GOT1000 series	GOT-A900 series	GOT-F900 series
RS-232 connection	-	○	-	-
USB connection	○	○	-	-
Ethernet connection	○	○	-	-

\*2 : For details of cables connecting GOT with the serial communication module, GOT settings, and considerations, refer to the manual of the GOT to be connected.

- GOT2000 Series Connection Manual (Mitsubishi Products) For GT Works3 Version1
- GOT1000 Series Connection Manual (Mitsubishi Products) for GT Works3
- GOT1000 series Connection Manual

## ■ Connecting to QCPU (Q mode)/LCPU

The following shows the settings for accessing QCPU (Q mode)/LCPU.

### Operation

1. Set "PC side I/F". (☞ Section 14.1.1)
2. Double-click "GOT" on "PLC side I/F".  
The PLC side I/F Detailed Setting of GOT screen is displayed.
3. Set the following setting on the PLC side I/F Detailed Setting of GOT screen.

<Detailed setting screen when using the Ethernet connection between personal computer and GOT>

Item	Description
Ethernet Detail setting for PC and GOT connection	Set settings such as an IP address and a host name when using the Ethernet connection between a personal computer and a GOT.
Detail setting for GOT and PLC connection	Select "C24".
Setup	Select "QJ71C24", "QJ71CMO", or "LJ71C24" for "Module Name".

4. Set "Other Station Setting" depending on a route to the connection destination. (☞ Section 14.1.1)

9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION


15  
WRITING/READING  
DATA

16  
PROTECTING  
DATA

### 14.9.3 Accessing programmable controller CPU via CC-Link IE Controller Network



The following explains the GX Works2 setting method for accessing the programmable controller CPU via a GOT and a CC-Link IE Controller Network module.



\*1 : The following table shows the connection between the personal computer and GOT.

○: Connectable, -: Not connectable

Connection	GOT			
	GOT2000 series	GOT1000 series	GOT-A900 series	GOT-F900 series
RS-232 connection	-	○	-	-
USB connection	○	○	-	-
Ethernet connection	○	○	-	-

\*2 : For cables connecting GOT with the programmable controller CPU, GOT settings, and considerations, refer to the manual of the GOT connected.

- GOT2000 Series Connection Manual (Mitsubishi Products) For GT Works3 Version1
- GOT1000 Series Connection Manual (Mitsubishi Products) for GT Works3
- GOT1000 Series Connection Manual

## ■ Connecting to QCPU (Q mode)

The following shows the settings for accessing QCPU (Q mode).

### Operation

1. Set "PC side I/F". (☞ Section 14.1.1)
2. Double-click "GOT" on "PLC side I/F".  
The PLC side I/F Detailed Setting of GOT screen is displayed.
3. Set the following setting on the PLC side I/F Detailed Setting of GOT screen.

<Detailed setting screen when using  
the Ethernet connection  
between personal computer and GOT>

Item	Description
Detail setting for GOT and PLC connection	Select "CC IE Cont".
CPU Mode	Select the programmable controller CPU to be connected.
Relay Network No.	Set the network number of the CC-Link IE Controller Network module to be relayed.
Relay Station No.	Set the station number of the CC-Link IE Controller Network module to be relayed.

4. Set "Other Station Setting" depending on a route to the connection destination. (☞ Section 14.1.1)

9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15  
WRITING/READING  
DATA


16  
PROTECTING  
DATA

### 14.9.4 Accessing programmable controller CPU via CC-Link IE Field Network



\*1 : CC IE Field head module only

The following explains the GX Works2 setting method for accessing the programmable controller CPU via a GOT and a CC-Link IE Field Network module.



\*1 : The following table shows the connection between the personal computer and GOT.

○: Connectable, -: Not connectable

Connection	GOT			
	GOT2000 series	GOT1000 series	GOT-A900 series	GOT-F900 series
RS-232 connection	-	-	-	-
USB connection	○	-	-	-
Ethernet connection	○	-	-	-

\*2 : For cables connecting GOT with the programmable controller CPU, GOT settings, and considerations, refer to the manual of the GOT connected.

- GOT2000 Series Connection Manual (Mitsubishi Products) For GT Works3 Version1


**■ Connecting to QCPU (Q mode)**

The following shows the settings for accessing QCPU (Q mode).

**Operation**

1. Set "PC side I/F". (☞ Section 14.1.1)
2. Double-click "GOT" on "PLC side I/F".  
The PLC side I/F Detailed Setting of GOT screen is displayed.
3. Set the following setting on the PLC side I/F Detailed Setting of GOT screen.

<Detailed setting screen when using  
the Ethernet connection  
between personal computer and GOT>



Item	Description
Detail setting for GOT and PLC connection	Select "CC IE Field".
CPU Mode	Select the programmable controller CPU to be connected.
Relay Network No.	Set the network number of the CC-Link IE Field Network module to be relayed.
Relay Station No.	Set the station number of the CC-Link IE Field Network module to be relayed.

4. Set "Other Station Setting" depending on a route to the connection destination. (☞ Section 14.1.1)

9 SETTING DEVICE COMMENTS  
 10 SEARCH/REPLACE  
 11 PRINTING  
 12 SETTING OPTIONS  
 13 USING LIBRARIES  
 14 SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION  
 15 WRITING/READING DATA  
 16 PROTECTING DATA

## 14.10 Accessing Programmable Controller CPU via Phone Line


Q CPU L CPU Remote <sup>\*1</sup> Head FX

\*1 : CC IE Field head module only

This section explains how to set functions to access a programmable controller CPU via phone line, and how to connect/disconnect the line.

Modems described in the system configuration below include an external type, built-in PC modem, PC card modem (PIMCIA), and TA (terminal adapter).

### ■ When accessing a serial communication module from a personal computer



\*1 : Only modules with RS-232C interface can be used.

Select [Tool] ⇒ [Set TEL Data/Connect via Modem] ⇒ [Line Connection] to access the serial communication module from the personal computer.

For details of setting items on the Line Connection screen, refer to the following section.

☞ Section 14.10.2 "■ Connecting a line automatically"

The setting of the modem function of serial communication module can be set with the parameter setting of intelligent function module.

For details of the modem function, refer to the following manual.

☞ MELSEC-Q/L Serial Communication Module User's Manual (Application)

#### 1) Switch settings of serial communication module

Item		Description
Transmission setting	Operation setting	Independent
	Data bit	8
	Parity bit	None
	Even/odd parity	Odd
	Stop bit	1
	Sum check code	Exist
	Online change	Enable
	Setting modifications	Disable/Enable
Communication rate (transmission speed) setting		According to modem specification
Communication protocol (mode setting)		5



**2) Initial settings for buffer memories**


The initial settings are required for the following buffer memories.

Buffer memory address	Name	Setting
2EH (46)	Modem connection channel specification	0: None 1: CH1 2: CH2
34H (52)*1	Data number for initialization specification	0H: Specified initialization data send in user registration frame area for transmission From 7D0H: Data number for initialization
36H (54)	MELSOFT connection specification	0: Not connected 1: Connected

\*1 : The following initialization data are registered as a factory setting for serial communication module.  
 Q/L series C24: 7D0H (2000) to 7DDH (2013)  
 If a modem to be used is registered to the initialization data, specify the registration number.  
 When using an unregistered modem, a user can register initialization data to the following registration numbers.  
 · 9C4H (2500) to 9E1H (2529)  
 · 8001H (-32767) to 801FH (-32737)

**■ When accessing an FXCPU from a personal computer**

Access an FX1S, FX1N, FX1NC, FX2N, FX2NC, FX3S, FX3G, FX3GC, FX3U, or FX3UC through a modem with a phone line, and remotely-operate the functions such as monitoring, testing, and writing/reading programs.



\*1 : For the combinations of an FXCPU and a function expansion board (special adapter), refer to the Section 2.1.10.

9 SETTING DEVICE COMMENTS

10 SEARCH/REPLACE

11 PRINTING

12 SETTING OPTIONS


13 USING LIBRARIES

14 SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15 WRITING/READING DATA

16 PROTECTING DATA

1) Operation flow



\*1 : Section 14.10.2  
 \*2 : Section 14.10.1

**Point**


● **Power supply procedure**

Power should be supplied to the modem first, then to the programmable controller CPU. If the programmable controller CPU is turned ON before the modem, the initialization command which is sent to the modem at the power ON of programmable controller CPU is invalidated, and a communication error occurs when operating the system remotely. Furthermore, if only the modem is turned OFF after the power supply, the initialization command is cleared and the same communication error occurs.


2) **Setting PLC parameters**

Set the PLC parameters which are required to access an FXCPU through the phone line.

<<PLC System (1)>> tab >



<<PLC System (2)>> tab >



Channel selection

**Operating procedure**

- Set the items on the screen.

Item	Description
<<PLC System (1)>>	-
MODEM Initialized	Set the initialization command of the modem on the programmable controller side, which is used for the remote access of the programmable controller CPU.
User Register Mode	Select this when using a modem other than "AIWA (PV-AF288)" or "OMRON (ME3314B)". The following are the communication specifications for this mode. <ul style="list-style-type: none"> <li>• Start bit: 1 bit</li> <li>• Data length: 7 bits</li> <li>• Parity: EVEN</li> <li>• Stop bit: 1 bit</li> </ul>
AIWA (PV-AF288)	Select this when using "AIWA (PV-AF288)".
OMRON (ME3314B)*1	Select this when using "OMRON (ME3314B)".
PP Modem Mode (CH1)	Select this when using a modem other than "AIWA (PV-AF288)" or "OMRON (ME3314B)", or when using a modem which cannot set the communication specification for the user registration mode. For details, refer to Point in this section. This item can be set for FX3s, FX3G, FX3GC, FX3U, and FX3UC only. Note that only PP Modem Mode (CH1) is supported by FX3s.
PP Modem Mode (CH2)	The following are the communication specifications for this mode. <ul style="list-style-type: none"> <li>• Start bit: 1 bit</li> <li>• Data length: 8 bits</li> <li>• Parity: None</li> <li>• Stop bit: 1 bit</li> </ul>
<<PLC System (2)>>	-
Channel selection	Specify the channel of programmable controller side to communicate with a personal computer. This item is supported by FX3s, FX3G, FX3GC, FX3U, and FX3UC only. Note that only CH1 is supported by FX3s.
Operate Communication Setting	Clear this item when setting the programmable controller CPU which is operated remotely.

\*1 : When selecting OMRON (ME3314B) for FX2N, use the module with the version 2.01 or later (manufacturing number 78\*\*\*\* or later).

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

**Point****● Setting PP modem mode (CH1) and PP modem mode (CH2)**

- <FX3U/FX3UC (FX3UC-32MT-LT, FX3UC-32MT-LT-2) series>  
When using the first adapter of FX3U-232ADP which is connected to FX3U-232-BD or FX3U-CNV-BD, specify "PP Modem Mode (CH1)".  
When using FX3U-232ADP which is connected to a board other than FX3U-CNV-BD, specify "PP Modem Mode (CH2)".
- <FX3UC (D, DS, DSS)/FX3GC series>  
When using the first adapter of FX3U-232ADP which is connected to FX3UC (D, DS, DSS) or FX3GC series, specify "PP Modem Mode (CH1)".  
When using the second adapter of FX3U-232ADP, specify "PP Modem Mode (CH2)".
- <FX3G series (14-/24-point type)>  
When using FX3G-232-BD, or when using the first adapter of FX3U-232ADP which is connected to FX3G-CNV-ADP, specify "PP Modem Mode (CH1)".
- <FX3G series (40-/60-point type)>  
When using FX3G-232-BD, or when using the first adapter of FX3U-232ADP which is connected to FX3G-CNV-ADP, specify "PP Modem Mode (CH1)".  
When using FX3G-232-BD and FX3U-232ADP which is connected to FX3G-CNV-ADP, specify "PP Modem Mode (CH1)" for FX3U-232ADP, and specify "PP Modem Mode (CH2)" for FX3G-232-BD.

**● Considerations for creating sequence programs**

To perform a remote access, the special data register D8120 (communication format) of the programmable controller CPU needs to be "0".

D8120 can be cleared to 0 by clearing "Operate Communication Setting" on the <<PLC System (2)>> tab.

Note that if a value other than "0" is specified for D8120 in the sequence program, the remote access cannot be performed.

Create a sequence program without specifying a specific value for D8120.

**3) Setting AT commands**

When "User Register Mode", "PP Modem Mode (CH1)", or "PP Modem Mode (CH2)" is selected for "MODEM Initialized" on the <<PLC System (1)>> tab, set AT commands according to the following operations.

- Register AT commands to programmable controller CPU  
Send the following data register data to the modem as a modem initialization command following the "AT&F" (initialization to the factory setting) command when the programmable controller CPU is turned ON.
    - D1000 to D1059 (For FX1N, FX1NC, FX2N, FX2NC, FX3G, FX3GC, FX3U, or FX3UC)
    - D200 to D255 (For FX1S, FX3S)
- Write a user-registered modem initialization command to above data register in advance using the Modify Value function or a sequence program.

Example) When the initialization command is "ATE0S0=2Q1&D0&M4\Q0\J0&W"

Register No.	ASCII	Hexadecimal
D1000	A	41
D1001	T	54
D1002	E	45
D1003	0	30
D1004	S	53
D1005	0	30
D1006	=	3D
D1007	2	32
D1008	Q	51
D1009	1	31
D1010	&	26
D1011	D	44
D1012	0	30

Register No.	ASCII	Hexadecimal
D1013	&	26
D1014	M	4D
D1015	4	34
D1016	\	5C
D1017	Q	51
D1018	0	30
D1019	\	5C
D1020	J	4A
D1021	0	30
D1022	&	26
D1023	W	57
D1024	CR	0D
D1025	LF	0A

A user-registered initialization command ends the transmission at the point when "0" is read. As a precaution, create a sequence program in which the input area of initialization command for modem and the data register area used by the general sequence program do not overlap.

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

- Setting content of registered modem

The following table shows the setting items of AT command for the modem registered to the programmable controller CPU in advance.

The setting items differ according to the modem to be used. For details of the actual setting items, refer to the manual of the modem.

Setting item	AIWA (PV-AF288) ATE0S0=2Q1&D0&M5\Q0\JO&W	OMRON (ME3314B) ATE0S0=2Q1&D0&H0&R1S15=8&W
Command echo setting	E0 (None)	E0 (None)
Number of automatic incoming calls	S0=2 (Twice)	S0=2 (Twice)
Result code display	Q1 (None)	Q1 (None)
DTR control	&D0 (Always ON)	&D0 (Always ON)
Communication mode	&M5 (V.42bis)	S15=8 (V.42bis)
Terminal flow control	\Q0 (None)	&R1 (None)
Transmission data flow control	–	&H0 (None)
Terminal speed fixed mode	\JO (Fixed)	–
Write to non-volatile memory	&W	&W

## ■ Modem specifications

Select a modem which satisfies the following specifications.

Communication data can be transferred from a built-in modem personal computer or a PC card modem (PCMCIA) used by connecting it to a personal computer.

### 1) When using a subscriber/in-plant phone line

- AT commands are supported. (Initialization command)
- DR terminal can be turned ON (High) independently.  
(Example: A modem, whose CD terminal turns ON as the DR terminal turns ON, cannot be used.)
- Communication standard
  - ITU-T V.90/V.34/V.32bis/V.32/V.22bis/V.22/V.21/V.FC
  - Bell 212A/103

### 2) Manual line connection (when connecting a line through an operator)

- Addition to the above specification 1), "ANS mode" and "ORG mode" can be switched.  
(The above mode switches are available on the specific AIWA modem.)

The communication may not be established with the above specification depending on a line condition.

### Point

#### ● Performing communication using a PC internal modem or PC card (PCMCIA)

The COM port setting is required on the Transfer Setup screen to perform communication using a PC internal modem or PC card (PCMCIA). For the COM port number for the PC internal modem or PC card (PCMCIA), refer to the manual of the PC internal modem or PC card (PCMCIA).

#### ● Performing communication via a modem

When performing communication from GX Works2 via a modem, the standard AT commands cannot be used for some specific modems. If a line cannot be connected by selecting standard AT commands, a user needs to specify the AT commands.

For details of specifying AT commands, refer to the following section.

☞ Section 14.10.2 "■ Connecting a line automatically"

## ■ Connection cables

Use an RS-232 cable included in a modem package, or a specified cable to connect a personal computer and a modem.

Since the connectors may differ depending on a personal computer, check the specification of the connector when purchasing a modem.

## ■ Restrictions on phone line

### 1) Do not use a line with the call-waiting feature enabled.

Data may be corrupted or the line is disconnected by the incoming call when the line is enabled with the call-waiting feature.

### 2) Do not use an extension phone.

The phone line may be disconnected when the receiver is picked up during the phone line connection.

### 3) An analog two-wire circuit can be used for the phone line.

For a digital line, the line can be connected by using a TA (terminal adapter).

### Point

#### ● Phone line with a four-wire circuit

A phone line with a four-wire circuit may not be used depending on the modular connector type.

For a phone line with a four-wire circuit, perform a connection test in advance.

### 4) Modems for wireless communication using a cellular phone

Select a model according to the cellular phone to be used.

For details, contact the company of the cellular phone to be used.

### 5) Coexistence with other applications when performing modem communication

When performing modem communication, applications such as GX Works2 and MX Component cannot perform modem communication simultaneously.

When performing modem communication in GX Works2, set the other applications not to perform modem communication.

If modem communication is performed simultaneously with GX Works2 and other applications, a phenomenon such as a communication error and a line disconnection occurs.

9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA

## 14.10.1 Setting TEL data

A personal computer can be connected with a programmable controller CPU using a phone line. Use a serial communication module for QCPU (Q mode)/LCPU, and use a function expansion board (special adapter) for FXCPU, to perform communication using a phone line.

### Point

#### ● Managing telephone directory and AT commands

The registered telephone directory and AT commands are managed under each user of Windows® operating system. The telephone directory and AT commands registered by another user cannot be used even when the same personal computer is used.


To use the telephone directory and AT commands registered by another user, use the import/export function.

### ■ Creating a telephone directory

Register phone numbers.

#### Screen display

Select [Tool] ⇒ [Set TEL Data/Connect via Modem] ⇒ [Phone Book].



#### Display contents

Item	Description
List of registered phone numbers	Display group names and user names of phone numbers.
Details	Display the registered information of the data selected on the list of registered phone numbers.




**Operating procedure**

1. Select a group for which the phone number to be registered on the list of registered phone numbers.

2. Click the **New Phone Number...** button.

The Phone Number Setting screen is displayed.



3. Set the items on the screen.

Item	Description
Group Name	Display the group name to which the information is registered.
Destination Name	Enter the name of the phone number to be set. The maximum number of characters that can be set is 50.
Phone Number	Enter the phone number. The maximum number of characters that can be set is 50.
Outside Line Number	Set the outside line number. The maximum number of characters that can be set is 10.
For only Line Connection	When a password is set for Q/L series-compatible C24, this setting enables to process the password authorization automatically to connect the line.
Comments	Enter notes on the registered information. The maximum number of characters that can be set is 60.

4. Click the **OK** button.

The phone number is registered.

**Screen button**

● **New Group...**

Creates a new group.

The Group Setting screen is displayed by clicking the **New Group...** button. Enter a group name. The maximum number of characters that can be set is 50.

● **Edit...**

Opens the screen to edit the registered data.

Select a registered data to be edited on the list of registered phone numbers.

The Phone Number Setting screen is displayed by clicking the **Edit...** button. Edit the data.

9 SETTING DEVICE COMMENTS

10 SEARCH/REPLACE

11 PRINTING

12 SETTING OPTIONS

13 USING LIBRARIES

14 SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION


15 WRITING/READING DATA

16 PROTECTING DATA


- 

Copies a registered phone number to another group.

Select the registered data to be copied on the list of registered phone numbers.

The Group screen is displayed by clicking the  button.


Select the group to which data is copied, and click the  button.



- 

Moves a registered phone number to another group.

Select the registered data to be moved on the list of registered phone numbers.

The Group screen is displayed by clicking the  button.

Select the group to which data is moved, and click the  button.

- 

Deletes a registered group and phone number.

Data cannot be batch deleted in group unit.

- 

Deletes all registered groups and phone numbers.

- 

Searches for a registered phone number. The search condition is a partial match.

Target data is searched from all registered data.

When entering search conditions to both "Destination Name" and "Phone Number", the data which satisfies the both search conditions is searched.


- 

Performs a selection processing of phone number setting when referring from the Line Connection screen.

- 

Imports phone number data from the specified file and adds it to the directory.

Execute the file import after deleting all groups and phone numbers to replace the data with the imported phone number data.

- 

Writes the data set on the Phone Book screen to the specified file.


## ■ Registering AT commands

Register AT commands.

### Screen display

Select [Tool] ⇒ [Set TEL Data/Connect via Modem] ⇒ [AT Command Registration].

List of registered AT commands →



### Display contents

Item	Description
List of registered AT commands	Display titles of AT commands.
Details	Display the registered information of the data selected on the list of registered AT commands.

9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15  
WRITING/READING  
DATA

16  
PROTECTING  
DATA

### Operating procedure

1. Select "MELSOFT Application Side Connection Modem" or "TEL Side Connection Modem" on the list of registered AT commands.
2. Click the **New AT Command...** button.

The AT Command Registration screen is displayed.


3. Set the items on the screen.



Item	Description
Group Name	Display the group name of data to which AT command is registered.
Title	Enter a title for the AT command to be registered.
AT Command	Set the command for modem initialization. The maximum number of characters that can be entered is 70 in ASCII code.



4. Click the **OK** button.

The AT command is registered.


## Screen button




- 


Opens the screen to edit the registered data.  
Select the registered data to be edited on the list of registered AT commands.  
The AT Command Registration screen is displayed by clicking the  button.  
Edit the data.
  - 


Copies a registered AT command to another group.  
Select the registered data to be copied on the list of registered AT commands.  
The Group screen is displayed by clicking the  button.  
Select the group (to which data is copied), and click the  button.
- Group** ✖


Group Name: MELSOFT Application Side Connection Modem


OK
Cancel
- 

Moves a registered AT command to another group.  
Select the registered data to be moved on the list of registered AT commands.  
The Group screen is displayed by clicking the  button.  
Select the group (to which data is moved), and click the  button.
  - 

Deletes a registered AT command.
  - 

Deletes all registered AT commands.
  - 

Performs a selection processing of AT command when referring from the Line Connection screen.
  - 

Imports AT command from the specified file and adds it to the directory.  
Execute the file import after deleting all AT commands to replace the commands with the imported commands.
  - 

Writes data set on the AT Command Registration screen to the specified file.

9

SETTING DEVICE  
COMMENTS

10

SEARCH/REPLACE

11

PRINTING

12

SETTING OPTIONS

13

USING LIBRARIES

14

SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15

WRITING/READING  
DATA

16

PROTECTING  
DATA

## 14.10.2 Connecting/disconnecting line


Connect/disconnect a line.

### ■ Connecting a line automatically


Connect a personal computer to a programmable controller CPU (with the following method: automatic/callback/manual) for remote access.

#### Screen display

Select [Tool] ⇒ [Set TEL Data/Connect via Modem] ⇒ [Line Connection].



#### Display contents

Item	Description
Connect	<p>Display a line connection status.</p> <p>The device which is being accessed is displayed flashing.</p> <p>Devices will be displayed after the connection is established successfully.</p> <p>When an error occurs during the connection attempt, the failed location is displayed with , and devices are displayed in gray.</p> <p>Check the failed location with a displayed message regarding the cause of the failure.</p>

## Operating procedure

### 1. Set the items on the screen.

Item	Description
Connection Method	Select a method: Automatic, Callback, or Manual (connecting a line through an operator). The phone number is set when specifying a phone number of the callback target. For a connection using the callback function, refer to "■ Connecting a line using the callback function". For a manual connection, refer to "■ Connecting a line through an operator (manual connection)".
Line	–
Line Type	Select a line type: Tone, Pulse, or ISDN.
Outside Line Number	Set the number as necessary when calling through the outside line.
Port	Select the COM port number which is connected to the modem.
Connection Destination	Set the phone number of the target. The previously-registered phone numbers in the telephone directory can be specified by clicking the <b>Browse...</b> button.
AT Command	–
Modem standard	Use the AT command set on the modem.
AT Command Setting	When a difficulty of line connection arises using the standard AT command, create an AT command with reference to the manual of the modem and the content displayed by clicking the <b>Help of AT Command...</b> button.
Record the logging data	Line connected time, line disconnected time, connection duration, destination, target phone number, callback, error status, or normal connection can be checked in log files. The log file at the line connection is saved in the following log file. <Save location> User folder\AppData\Roaming\MITSUBISHI\MELSOFT\TEL\Log <Log file name> year, month, day.dat (Example: 110615.dat)
User mode (8bits NP)	This item is supported by FX3S, FX3G, FX3GC, FX3U, and FX3UC only. Select this when "PP Modem Mode (CH1)" or "PP Modem Mode (CH2)" is selected in the PLC parameter. Do not select this item when the setting other than "PP Modem Mode (CH1)" or "PP Modem Mode (CH2)" is selected.

### 2. Click the **Connect** button.

When the line was not connected, perform the modem initialization.

For the considerations for connecting a line using the callback function, refer to the following manual.

📖 MELSEC-Q/L Serial Communication Module User's Manual (Application)

### Screen button

- **Stop**  
Stops the line connection.
- **Options...**  
Displays the Options screen. (📖 Section 14.10.3)

9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES


14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15  
WRITING/READING  
DATA

16  
PROTECTING  
DATA

● **Init. Modem**

Performs a modem initialization when the modem did not respond at the line connection. The following confirmation message is displayed by clicking the **Init. Modem** button.



A modem initialization starts by clicking the **Yes** button. "AT&F" is set as a default command for the modem initialization.

The command for the modem initialization can be changed by "Modem Initialization AT Command" under [Tool] ⇒ [Set TEL Data/Connect via Modem] ⇒ [Options].

Change the initialization command according to the modem used.

When a failure occurs to the modem initialization, the Options screen is displayed.

Only the settings of items which may become a problem at the line connection can be changed.

For details of the Options screen, refer to Section 14.10.3.


**Point**

● **Phone line connection**

The phone line connection can also be performed on the Transfer Setup screen.

● **When the line is disconnected by disturbance**

If the line is disconnected by disturbance during the line connection, a confirmation message will be displayed to select whether to reconnect or disconnect the line.



● **Connection duration**

The connection duration is displayed on the status bar when the line is connected.



● **When the connection destination is changed during the phone line connection**

Even when the connection destination is changed to another COM port or a communication board (such as MELSECNET/10) on the Transfer Setup screen during the phone line connection, the communication can be performed using the communication routes while the phone line is being connected.

● **When two or more error messages are displayed**

Two or more communication error messages are displayed when the modem is turned OFF during the phone line connection. In this case, set a longer time check period for "Other Station Setting" on the Transfer Setup screen.

● **Using a serial communication module to communicate through a phone line**

The following table shows the items to be set on a programmable controller CPU and GX Works2 when performing communication using a serial communication module (for Q/L series) through a phone line.

Setting target	Setting item	Reference
Programmable controller CPU	<ul style="list-style-type: none"> <li>Switch setting</li> <li>Set the following items in the sequence program.</li> <li>Write the initialization command (ATS0=1).</li> <li>Set the initialization request.</li> </ul>	Section 14.10
GX Works2	<ul style="list-style-type: none"> <li>AT command registration</li> <li>Phone number registration</li> </ul>	Section 14.10.1



## ■ Connecting a line using the callback function


The callback function is a function which enables access from GX Works2 to QCPU (Q mode)/LCPU with the line re-connection (callback) operation performed on the Q/L series C24 module side, after the line connection operation is performed in GX Works2.

The callback function is not supported by FXCPU.

For 1 to 3, and 9, telephone usage is charged on a personal computer side.

For 4 to 8, telephone usage is charged on a Q/L series C24 module side.

For details, refer to the following manual.

 MELSEC-Q/L Serial Communication Module User's Manual (Application)

### 1) Automatic

Select "Automatic" when the callback function is not set on a Q/L series C24 module.

### 2) Automatic (Callback Fixation)

Connect a line without using the callback function when the callback function is set on a Q/L series C24 module.

A connection operation can be performed on a personal computer whose phone number is registered to the buffer memory (2101H).

### 3) Automatic (Callback Number Specification)

Connect a line without using the callback function when the callback function is set on a Q/L series C24 module.

A connection operation can be performed on a specific personal computer.

### 4) Callback Connect (Fixation)

A callback operation is performed on a personal computer whose phone number is registered to the buffer memory (2101H) of a Q/L series C24 module.

### 5) Callback Connect (Number Specification)

A callback operation is performed on a specified personal computer.

### 6) Callback Request (Fixation)

Send a callback request from a specified personal computer, and perform a callback operation on a personal computer whose phone number is registered to the buffer memory (2101H) of a Q/L series C24 module. (A callback operation is not performed on the personal computer which is connected first.)

### 7) Callback Request (Number Specification)

Send a callback request from a specified personal computer, and perform a call back operation on a specified personal computer. (A callback operation is not performed on GX Works2 which is connected first.)

### 8) Callback Reception Waiting

When connecting a line with Callback Request (Fixation or Number Specification), select "Callback Reception Waiting" for the personal computer on which a callback is to be performed.

### 9) Manual

This setting is not for the callback function.

Select this item when connecting a line through an operator.

9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA


A line connection with the GX Works2 connection method described in the following table can be performed when "Callback function specification" is set for the modem function of the intelligent function module parameter of a Q/L series C24 module.

The following table shows the setting items of "Callback function specification" of the modem function and corresponding setting items of GX Works2 connection method.

○: Connectable

Q/L series C24 side callback function specification	Connection method on GX Works2 side								
	1)	2)	3)	4)	5)	6)	7)	8)	9)
Auto	○								○
Setting 1: Auto/Callback Connection (at Fixation)		○		○		○		○	
Setting 2: Auto/Callback Connection (at Number Specified)		○	○	○	○	○	○	○	
Setting 3: Callback Connection (at Number Specified Max 10)			○		○		○	○	
Setting 4: Callback Connection (at Fixation)				○		○		○	
Setting 5: Callback Connection (at Number Specified)				○	○	○	○	○	
Setting 6: Callback Connection (at Number Specified Max 10)					○		○	○	

The following is an example of line connection with "Callback Request (Number Specification)".




## ■ Connecting a line through an operator (manual connection)


Connect to the in-plant phone line through an operator.

A manual line connection cannot be performed on modems without the ANS/ORG/TEL switch.

### ● System configuration



### Operation

1. Select [Tool] ⇒ [Set TEL Data/Connect via Modem] ⇒ [Line Connection].  
(Select "Manual" for the line connection method on the Line Connection screen. For details of operating procedure, refer to "■ Connecting a line automatically".)
2. Set the mode on Modem 1 on Phone 1 side to the ORG mode, and Modem 2 on Phone 3 side to the ANS mode.
3. Call Phone 2 (operator) from Phone 1.
4. Phone 1 and Phone 3 are connected through Phone 2 (operator).
5. While Phone 1 and Phone 3 are connected, connect C24.
6. Turn ON the DATA switch on Modem 2 on Phone 3 side.
7. After the modem tone on Modem 1 on Phone 1 side is confirmed, turn the DATA switch ON.
8. When the modem tone on Modem 1 on Phone 1 side is faded, click the  button in GX Works2.  
When the line is connected normally, the message "Line connected" is displayed.

### ● Considerations

- If the connection cannot be established in step 6 and step 7, repeat the operations and adjust the timing.
- The ANS - ORG switch is required on the modem to connect a line manually.

9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA


## ■ Disconnecting a line

---

Disconnect a phone line being connected.

### Operating procedure

- Select [Tool] ⇒ [Set TEL Data/Connect via Modem] ⇒ [Line Disconnection].




### 14.10.3 Setting options

Set options for a line connection.

#### Screen display

Select [Tool] ⇒ [Set TEL Data/Connect via Modem] ⇒ [Options].



#### Operating procedure

- Set the items on the screen.

Item	Description
Line Connection CD Signal Wait Time	Extend the set period when the CD signal does not turn ON within the set period depending on the area (example: overseas) to be connected.
Line Connection Modem Report Wait Time	Extend the set period when the response speed of the modem is slow.
Line Disconnection CD Signal Wait Time	Extend the set period when the CD signal does not turn OFF within the set period depending on the area (example: overseas) to be connected.
Line Disconnection Delay Time	Extend the set period when the response speed of the modem is slow.
Data Transmission Delay Time	
AT Command Response Wait Time	
Password Cancellation Response Wait Time	Extend the set period when the quality of line connection is poor.
AT Command/Password Cancellation Retry Times	Increase the number of settings.
Line Callback Cancel Wait Time	Extend the set period when the line of the target (Q/L series C24) is not disconnected within the set period depending on the area (example: overseas) to be connected.
Callback Delay Time	Extend the set period when a specific period is required for the device which relays a connection (example: modem) between the line disconnection and the reconnection.
Modem Initialization AT Command	Set a command at the modem initialization. The maximum number of characters that can be entered is 70 in ASCII code.
Communication Initialization Time-out period	Set the timeout period at the communication initialization.

9  
SETTING DEVICE COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15  
WRITING/READING DATA

16  
PROTECTING DATA

## 14.11 Considerations of Communication with Programmable Controller CPU

Q CPU L CPU Remote Head FX

This section explains the considerations of communication with the programmable controller CPU. Refer to POINT and Restrictions described in each section as well as the descriptions in this section.

### ■ Considerations of communication via multiple network systems

When accessing QCPU (Q mode)/LCPU via multiple network systems, connected station\*1 and relay stations\*2 must be QCPU (Q mode)/LCPU or RCPU.

\*1 : Station directly connected from GX Works2

\*2 : Stations to be routed on network system

When accessing a programmable controller CPU to which remote password is set via RCPU, the remote password cannot be cleared from GX Works2. Delete the password using the MELSOFT product supported by RCPU.

### ■ Considerations of communication with the programmable controller CPU using a USB cable

#### 1) Connecting and disconnecting a USB cable, resetting the programmable controller CPU, and turning the power ON/OFF

A communication error may occur and operation may not be recovered if connecting and disconnecting a USB cable, resetting the programmable controller CPU, or turning the power ON/OFF is performed frequently during communication with the programmable controller CPU.

Be sure to set GX Works2 to offline\*1 as much as possible during these operations.

When operation is not recovered from an error, remove the USB cable. Then, connect it again after five or more seconds. (Even after this operation, an error may occur at initial communication.

However, communication will be successful after that.)

\*1 : The offline indicates the status other than indicated below.

- Write to PLC, Read from PLC, Monitor, and PLC diagnostics

#### 2) Combination of personal computers and USB cables

A communication error may occur depending on the combination of personal computers and USB cables.

If an error occurs, take appropriate actions according to the message displayed on the screen.

## Other considerations

### 1) High-speed communication using an RS-232 cable

Communication may fail depending on the performance of the personal computer when high-speed communication is attempted by changing the transmission speed at the serial port of the personal computer (personal computer side interface). Communication speed may also slow down due to communication retries. Decrease the transmission speed if high-speed communication is not performed normally.


### 2) Resume function, suspend setting, power saving function, and standby mode of the personal computer

A communication error may occur during communication with the programmable controller CPU when the resume function, suspend function, power saving function, or standby mode is set to the personal computer. Disable these settings for communication with the programmable controller CPU.

### 3) Switching the connection to GX Works2 during communication through the serial communication function

When using Q00, Q01, Q00UJ, Q00U, Q01U, Q02U, or QnUD(H)CPU, the connection can be switched to GX Works2 during communication to a personal computer, indicator, etc. through the serial communication function.

If unable to connect to GX Works2, adjust the transmission speed to that specified on the <<Serial Communication>> tab of PLC parameter.



### 4) Disconnecting Ethernet cable while communicate with Ethernet board

If disconnecting the Ethernet cable and connecting it to other personal computer, a communication error occurs. This communication error may not be recovered without resetting the programmable controller CPU.

Disconnect/connect an Ethernet cable after stopping the online functions such as monitoring, or end GX Works2 once.





---

# 15 WRITING/READING DATA

This chapter explains operations to write or read data to/from the programmable controller CPU or a memory card.

15.1	Writing or Reading Data to/from Programmable Controller CPU	15 - 2
15.2	Verifying Data on Programmable Controller CPU against Data on Personal Computer	15 - 29
15.3	Deleting Programmable Controller CPU Data	15 - 34
15.4	Copying Program Memory Data to ROM	15 - 35
15.5	Writing/Reading/Deleting PLC User Data	15 - 36
15.6	Transferring Data to Program Memory in Batch	15 - 38
15.7	Latch Data Backup	15 - 40
15.8	Backing up/Restoring Data	15 - 42
15.9	Online Program Change	15 - 45
15.10	Calculating Memory Size	15 - 66
15.11	Writing/Reading Data to/from Memory Cards	15 - 73
15.12	Reading Data of Local Devices	15 - 79

## 15.1 Writing or Reading Data to/from Programmable Controller CPU

This function writes project data to the programmable controller CPU or a memory card, or reads data from the programmable controller CPU or a memory card to the project.

Data for intelligent function module also can be written/read. (☞ Section 15.1.4)

For reading data from a programmable controller CPU without a project being opened, refer to '■ Creating new projects with data read from programmable controller CPU or intelligent function module (New project creation with data read from programmable controller CPU)'.

For FXCPU projects with labels, created project data can be read from FX3U/FX3UC version 3.00 or later only.


To boot QCPU (Q mode) using a standard ROM or Flash card, it is recommended to firstly write necessary data to the program memory using the Write to PLC function and then write the data to the standard ROM or Flash card using the Export to ROM Format function. (☞ Section 15.4)

### Screen display

Select [Online] ⇒ [Write to PLC] (📁)/[Read from PLC] (📁).


The following explains the settings for writing data to a programmable controller CPU. Settings for reading data from a programmable controller CPU can be made in the same manner.

<Write to PLC screen for the projects without labels.>



<Write to PLC screen for the projects with labels>

For QCPU (Q mode)/LCPUCPU/FXCPU (FX3U/FX3UC version 3.00 or later), the symbolic information is displayed in the file list.



**Operating procedure**

**1. Set the items on the screen.**

Item	Description
Connection Channel List	Display the information of the connection destination setting.
Target module tab	Switch the setting target module. Characters on the tab are displayed in blue when data to be written/read exist.
PLC Module	Set the settings to write data to the programmable controller CPU.
Intelligent Function Module*1	Set the settings to write intelligent function module data to the buffer memory or flash ROM of the intelligent function module. ☞ Section 15.1.4
Title*1	Display the title of the target memory by clicking the <b>Refresh</b> button.
Option*2	–
Display Size	Select this to display the "Size" column in the file list and the memory capacity.
File list	–
Target	Select the data to be written/read.
Target Memory*1	Select "Target Memory" on the row of "Symbolic Information" or "PLC Data" displayed in light blue, and select the target memory to be read/written from (▼). For details of the memory card application, refer to the following manuals. ☞ QCPU User's Manual (Hardware Design, Maintenance and Inspection) ☞ MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)
Memory capacity*3	–
Writing Size	Display the total size of written data selected in "Target".
Free Volume	Display the free space volume of the target memory.
Use Volume	Display the used space volume of the target memory.

\*1 : Not supported by FXCPU.

\*2 : Displayed only when a project with labels is written to the programmable controller CPU.

9  
SETTING DEVICE COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS


13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15  
WRITING/READING DATA





16  
PROTECTING DATA

\*3 : For FXCPU, the program size and the symbolic information size are displayed when the project is written to the programmable controller CPU. Symbolic information size is displayed on the screen for projects with labels of FX3U/FX3UC version 3.00 or later only.

When program (program file), device comment file, device memory file, file register file, or symbolic information file is selected, the range can be set by clicking the  button.

When reading data from the programmable controller CPU, and the device memory is selected, the detailed settings are required.

For details, refer to the following sections.


-  Section 15.1.1 "Setting write/read range of program (program file)"
-  Section 15.1.2 "Setting write/read range of device data"
-  Section 15.1.3 "Setting range of device comment to be written/read"
-  Section 15.1.6 "Reading the remaining steps for Online program change"


## 2. Click the button.


When the Write to PLC function is executed, the specified data are written to the target memory.


When the Read from PLC function is executed, the specified data are read from the target memory.


### Screen button

- 








Displays the illustration of the connection channel.
- 


Selects the parameters and all the programs displayed in the list.
- 

Selects all data displayed in the list.
- 

Cancels the selection status of all data selected in the list.
- 


Switches display/hide of the Related functions button.  
For details of the related functions, refer to the following sections.

  - Remote Operation  Section 20.1 "Remote Operation of Programmable Controller CPU"
  - Set Clock  Section 20.6 "Setting Clock on Programmable Controller CPU"
  - PLC User Data  Section 15.5 "Writing/Reading/Deleting PLC User Data"
  - Write Title: Sets a title to the target memory.
  - Format PLC Memory  Section 20.3 "Formatting Programmable Controller CPU Memory"
  - Clear PLC Memory  Section 20.4 "Clearing Programmable Controller Memory"
  - Arrange PLC Memory  Section 20.5 "Arranging Programmable Controller Memory"
-  **(Read from PLC and Delete PLC Data only)**

Displays the project name of the symbolic information in the Title/Project Name column.  
It is not displayed for projects without labels or by FXCPU.
- 

Updates the file list on the Online Data Operation screen.  
For QCPU (Q mode)/LCPU, the writing size, free volume, and used volume are also updated.  
When multiple personal computers are connected to the programmable controller CPU, update the target memory before reading data from the programmable controller CPU.

## ■ Unlocking a remote password

The confirmation message for unlocking the remote password is displayed when the programmable controller CPU for which the remote password is set is accessed via C24 modules or Q series-compatible E71 modules. Unlock the password by following the message.  
 (Setting a remote password  Section 6.4)

When the number of permissible incorrect remote password entries or the cumulative number of permissible incorrect password entries has been set and the number of incorrect entries exceeds the set number, the programmable controller CPU will be in the status as shown in the following table. For corrective action, refer to MELSEC-Q/L Serial Communication Module User's Manual (Application).

Item	Status
When the number of permissible entries is exceeded	The line is disconnected automatically.
When the cumulative number of permissible entries is exceeded	Turn ON the ERR. LED on the module.

When accessing a programmable controller CPU to which remote password is set via RCP, the remote password cannot be cleared from GX Works2. Delete the password using the MELSOFT product supported by RCP.

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

**Point**

● **Target memory**

The following table shows the relations between the target memory on the Online Data Operation screen and the drive of the programmable controller CPU.

PLC type	Drive No.	Target memory on the <u>Online Data Operation</u> screen	PLC parameter
QCPU (Q mode)/LCPU	0	Program memory/Device memory	Program memory (Drive 0)
QCPU (Q mode)*1	1	Memory card (SRAM)	Memory card (RAM) (Drive 1)
	2	Memory card (Flash): Q2MEM-2MBF	Memory card (ROM) (Drive 2)
		Memory card (Flash): Q2MEM-4MBF	
		Memory card (ATA)	
QCPU (Q mode)*2/LCPU		Memory card (SD)	Memory card (SD) (Drive 2)
QCPU (Q mode)/LCPU	3	Standard RAM	Standard RAM (Drive 3)
	4	Standard ROM	Standard ROM (Drive 4)

\*1 : Not supported by Basic model QCPU, Q00UJ, Q00U, Q01U, High-speed Universal model QCPU, and Universal model process CPU.

\*2 : High-speed Universal model QCPU and Universal model process CPU only.

● **Memory capacity**

- When a project is written to the programmable controller CPU, the target memory capacity may be displayed smaller than the actual file size.
- If the target memory settings differ between "Symbolic Information" and "PLC Data", the memory capacity of the target selected in PLC data is displayed.

● **Writing multiple programs to programmable controller CPU**

When more than one program is written to the programmable controller CPU, programs categorized as "No Execution Type" will never be executed on the programmable controller CPU.

For saving the memory capacity of the programmable controller CPU, it is recommended to remove them from the target data of the Write to PLC function.

● **Reading device memory data from programmable controller CPU**

Device memory data are read in the condition in which "Number of Columns" is set to "Auto" on the device memory editor.


● **Saving the selection status of the files for the Write to PLC/Read from PLC function**

The selection status of the files for the Write to PLC/Read from PLC function can be saved.

To save the file selection status, select [Tool] ⇒ [Options] ⇒ "PLC Read/Write" and set "Operational Setting".

However, the file selection status is canceled by any of the following operations.

- Changing the connection destination setting
- Changing the target memory
- Changing the PLC type
- Ending the project



<Option setting>


## 15.1.1 Setting write/read range of program (program file)



Set the range of a program (program file) to be written/read when the program (program file) is selected on the Online Data Operation screen.

### Screen display

Select the program (program file) and click the **Detail** button.



### Operating procedure

- Set the items on the screen.

Item	Description
Selected Program (Program File)	Display the program name selected in the 'File list'.
Range	Display write/read range of each program.
Allocate Memory for 'Online Change' (Write to PLC only)	Enter the number of steps secured for Online program change.
Option	–
Specify Same Step Count for Online Change to All Files (Write to PLC only)	Select this to specify the equal number of secured steps for Online program change to all files.
Reading Left Capacity at the Same Time (Read from PLC only)	Select this to read the remaining secured steps for Online program change of the files written on the programmable controller CPU.
Merge Peripheral Statement/Note (Read from PLC only)	Select this to use an Peripheral statement/note. If a program is read without selecting this item, the Peripheral statement/note is lost.

### Screen button

- Allocate Memory for Online Change** (Read from PLC only)  
Displays the remaining steps for Online program change.

9  
SETTING DEVICE COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15  
WRITING/READING DATA

16  
PROTECTING DATA

### 15.1.2 Setting write/read range of device data



Set the type and range of device memory and the range of file register to be written/read when any or both of them are selected on the Online Data Operation screen.

#### ■ Setting type and range of device memory to be written/read

Set the type and range of device memory to be written to/read from a programmable controller CPU. The following tables show devices that can be written/read.

##### ● QCPU (Q mode)/LCPU

○: Applicable ×: Not applicable

Device	Writing	Reading
M, L, B, F, SB, V, S <sup>*1</sup> , T <sup>*2</sup> , ST <sup>*2</sup> , C <sup>*2</sup> , D, W, SW, FX, FY, FD, Z	○	○
X, Y, SM, SD, intelligent function module device, link direct device	×	○

\*1: Not supported by Basic model QCPU.

\*2: Three types of data (contact, coil, and current value) can be written/read.

##### ● FXCPU

○: Applicable ×: Not applicable


Device	Writing	Reading
M, S, T, C, D, R <sup>*1</sup> , ER <sup>*1</sup>	○	○
X, Y, D (Special register), M (Special relay)	×	○

\*1: Supported by FX3G, FX3GC, FX3U, and FX3UC only.

#### Screen display

Select the device data and click the **Detail / Detail** button.

<QCPU (Q mode)/LCPU>





## Operating procedure

- Set the items on the screen.

Item	Description
Device Data Name (Read from PLC only)	Enter the data name for data created when the device memory data are read.
Device Selection	–
Internal Device Memory	Select this to write/read device data. For FXCPU, this setting is fixed as selected status.
Input Column	Set the method for specifying the device range to be written/read.
Points + Start	Select this to specify the range with the number of device points and the start device number.
Start + End	Select this to specify the range with the start and end device numbers.
Device range list	Set the device to be written/read and the device range. The default device range is a range set on the <<Device>> tab of PLC parameter. Devices to which 0 point is set cannot be set without selecting the check box.
Link Direct Device*1 (Read from PLC only)	Select this to read the link device of the data link module or the network module to the link direct device.*2. *3 Setting range: Slots 1 to 4
Buffer Memory Head I/O No.*1 (last 1 digit is not required) (Read from PLC only)	Select this to read the intelligent function module buffer memory to the intelligent function module device.*3 Setting range: 0 to 1FF

\*1 : Not supported by FXCPU.

\*2 : For the method to number the module to be set, refer to Point in Section 20.1.

\*3 : For specifying devices, refer to MELSEC-Q/L Programming Manual (Common Instructions).

## Screen button

- Default

Changes the device range to the default.

9  
SETTING DEVICE COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15  
WRITING/READING DATA


16  
PROTECTING DATA

## ■ Setting range of file register to be written/read

Set the range of file register to be written to/read from a programmable controller CPU.  
For Q00JCPU/Q00UJCPU/FXCPU, the range of file register to be written/read cannot be set.

### Screen display

Select a file register and click the **Detail / Detail** button.  
<QCPU (Q mode)/LCPU>



### Operating procedure

- Set the item on the screen.

Item	Description
Specified Range	Specify the range of file register to be written/read. If multiple file registers are selected, each file register value is written/read in the same range.

### Screen button

For the buttons on the screen, refer to ■ Setting type and range of device memory to be written/read.

#### Point

#### ● Specifying file registers

- When writing data to a programmable controller CPU, "Whole Range" cannot be selected.
- For Universal model QCPU/LCPU, specify the range of file register assigned on the <<Device>> tab of PLC parameter when using extended data registers or extended link registers.


### 15.1.3 Setting range of device comment to be written/read



Set the device and range of global device comment/local device comment to be written or read when the global device comment/local device comment is selected on the Online Data Operation screen. Set this setting to limit the writing range of device comments in cases such as when the programmable controller CPU has small free capacity. When the range of device comments is not set, all device comments are written/read. For FXCPU, this function only supports global device comments being written to the programmable controller CPU.

#### Screen display

Select a global device comment/local device comment and click the **Detail** button.



#### Operating procedure

1. Set the items on the screen.

Item	Description
Device Comment Name	Display the selected device comment name.
Device Range	–
Device Name	Set the device name whose write/read range is to be specified.
Start	Set the start device number.
End	Set the end device number.
Bit Specification Information	–
Bit specification information included*1	Select this to specify whether bit-specified word device comments are included as write target.
Comment Format (PLC Format)	–
Number of characters per 1 comment*2	Set the number of characters for a comment to be written to a programmable controller CPU.

\*1 : For Universal model QCPU/LCPU only  
 \*2 : Not supported by FXCPU.


SETTING DEVICE COMMENTS	9
SEARCH/REPLACE	10
PRINTING	11
SETTING OPTIONS	12
USING LIBRARIES	13
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION	14
WRITING/READING DATA	15
PROTECTING DATA	16

## 2. Click the button.


The screen returns to the Online Data Operation screen.

### Point


#### ● Message displayed when setting range to be written with FXCPU

By clicking the  button, the number of device comments and the maximum number of comments to be written are displayed.

<When the "Parameter" checkbox is not selected on the Online Data Operation screen.>



<When the "Parameter" checkbox is selected on the Online data Operation screen.>



#### ● When the setting of "Number of characters per 1 comment" is changed

When the number of characters set for "Number of characters per 1 comment" is less than the number of characters of device comment set for the project, the device comment with less number of characters is written to a programmable controller CPU. Therefore, mismatched data may be detected when verifying project data.

### Restrictions

#### ● Specifying bit-specified word device comments as write target

Device comments cannot be read in GX Developer.

When a device comment contains a bit-specified comment of LCPU is read in GX Works2 Version 1.62Q or earlier, the bit-specified comment is deleted.

When a device comment contains a bit-specified comment of Universal model QCPU is read in GX Works2 Version 1.31H or earlier, the bit-specified comment is deleted.

## ■ Device comment unset devices

Data to be written differ depending on the setting range of the device comments to be written as shown below.


Range	Data to be written
When range is not set	Data of device comment unset devices are not written.
When range is set	Blank data is written to device comment unset devices within the range to be written.

<Device comments in the project>

M0 : Emergency stop  
M1 :  
M2 : Operating  
⋮




Write to PLC  
(With no range set)



M0 : Emergency stop  
M2 : Operating  
⋮



Write to PLC  
(With range set)



M0 : Emergency stop  
M1 : (Blank)  
M2 : Operating  
⋮

### Point

● **If the device comments read with the Read from PLC function are empty**

If the read device comments with the following option is set are empty, the device comments of the devices will be unset status.

- [Tool] ⇒ [Option] ⇒ "PLC Read/Write" ⇒ "Merge device comment with the project data at time of PLC read"

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

## 15.1.4 Writing/reading intelligent function module data



Write the intelligent function module data to a programmable controller CPU or intelligent function module buffer memory/flash ROM.

Intelligent function module data includes intelligent function module parameters to be written to a programmable controller CPU as a parameter file, and data whose values are written directly to intelligent function module buffer memory/flash ROM.

For details of data to be written as intelligent function module parameters and data to be written to intelligent function module buffer memory/flash ROM, refer to the following manuals.

☞ GX Works2 Version 1 Operating Manual (Intelligent Function Module)

☞ User's Manual to be used

### ■ Writing/reading intelligent function module parameters to/from programmable controller CPU

Write intelligent function module parameters to a programmable controller CPU, and read the data from the programmable controller CPU to a project.

#### Screen display

Select [Online] ⇒ [Write to PLC] (🖨️)/[Read from PLC] (🖨️) ⇒ <<PLC Module>>.

The settings for writing/reading data to/from a programmable controller CPU are explained together as they are similar operations.

<Write to PLC screen>

File list

Module Name/Data Name	Title	Target	Detail	Last Change	Target Memory Setting	Size
(Untitled Project)					Program Memory/De...	
Symbolic Information		<input type="checkbox"/>				
Symbolic Information		<input type="checkbox"/>				
PLC Data					Program Memory/De...	
Program(Program File)		<input type="checkbox"/>	Detail			
MAIN		<input type="checkbox"/>		2017/02/07 10:46:25		
SUB1		<input type="checkbox"/>		2017/02/07 10:46:43		
SUB2		<input type="checkbox"/>		2017/02/07 10:46:50		
Parameter		<input checked="" type="checkbox"/>				
PLC/Network/Remote Password/Switch Setti...		<input type="checkbox"/>		2017/02/07 10:46:25		
Intelligent Function Module (Initial Setting/Aut...		<input checked="" type="checkbox"/>		2017/02/07 10:52:07		164 Bytes
Global Device Comment		<input type="checkbox"/>				

Memory capacity

Writing Size: 164Bytes

Free Volume: 240,020

Use Volume: 5,740Bytes

Refresh

Related Functions <<

Execute Close

Remote Operation Set Clock PLC User Data Write Title Format PLC Memory Clear PLC Memory Arrange PLC Memory Soft Security Key Management

#### Operating procedure

1. Select "Intelligent Function Module (Initial Setting/Auto Refresh)" from the file list. For the items on the screen, refer to Section 15.1.

2. Click the **Execute** button.

In the Write to PLC operation, the intelligent function module parameters are written to the target memory.

In the Read from PLC operation, the intelligent function module parameters on the programmable controller CPU are read from the target memory.

■ **Writing/reading data to/from intelligent function module buffer memory/flash ROM**


Write the set intelligent function module data to the buffer memory/flash ROM of the intelligent function module via a programmable controller CPU, and read the intelligent function module data to a project. Use the operation for changing the data temporarily during debugging.

If a module does not have initial settings for intelligent function module parameters, this function can directly write data such as initial values to the intelligent function module buffer memory/flash ROM.

**Screen display**

Select [Online] ⇒ [Write to PLC] (📡) / [Read from PLC] (📡) ⇒ <<Intelligent Function Module>>. The following explains the settings for writing data to a programmable controller CPU. Settings for reading data from a programmable controller CPU can be made in the same manner.

<Write to PLC screen>




The items in **Detail** may differ depending on the module.

9  
SETTING DEVICE COMMENTS  
10  
SEARCH/REPLACE  
11  
PRINTING  
12  
SETTING OPTIONS  
13  
USING LIBRARIES  
14  
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION  
15  
WRITING/READING DATA  
16  
PROTECTING DATA

### Operating procedure

**1. Select "Valid" for write/read target module and "Target" for each item.**

Set details such as a write/read range and write target by clicking the  button of each item.

**2. Click the  button.**

In the Write to PLC operation, the set data are written to the intelligent function module buffer memory/flash ROM, and in the Read from PLC operation, the data are read from the intelligent function module buffer memory/flash ROM.

### Screen button

For the buttons on the screen, refer to Section 15.1.



**Point**

● **Writing data to programmable controller CPU**

When writing the intelligent function module parameters, match the configuration of the intelligent function module on the project with the configuration in the intelligent function module parameters stored on the programmable controller CPU.

Data cannot be written to the programmable controller CPU unless the start XY address and the module name for the write target match.

● **Reading data from programmable controller CPU**

When the intelligent function module parameter does not exist on the programmable controller CPU, read the data from the programmable controller CPU after adding the intelligent function module according to the actual module configuration to the Navigation window.


For the method for adding the intelligent function module, refer to the following manual.

☞ GX Works2 Version 1 Operating Manual (Intelligent Function Module)

The configuration of Intelligent function module on the project side is recreated according to the Intelligent function module parameter. After that, the setting of the Intelligent function module parameter setting is reflected to the parameter and automatic refresh settings.

Default values are set to the Intelligent function module parameter in which parameters are not set. In this case, after reading data from a programmable controller CPU, read data from the buffer memory/flash ROM of the mounted module.

The following screen is displayed when the actual mounting status is different from the configuration on the module\*1 or a specific Intelligent function module\*2 is used at reading data from the programmable controller CPU. When the cell under "Model Name" of intelligent function module parameter is indicated with red, select the module model. And as for blue, change the module model as necessary. Select the module model by double-clicking the cell under "Model Name".



\*1 : For modules without the initial setting in intelligent function module parameters, the actual module configuration is judged by setting or unsetting the auto refresh. When an actual module exists and the auto refresh is not set for the current project, the cell is highlighted in yellow.

\*2 : The specific intelligent modules are listed below.

Analog module: Q62DAN, Q64DAN, Q68DAVN, Q68DAIN, Q62DA, Q64DA, Q68DAV, Q68DAI

Temperature control module: Q64TCTT, Q64TCTTBW, Q64TCRT, Q64TCRTBW, Q64TCTTN, Q64TCTTBWN, Q64TCRTN, Q64TCRTBWN

QD75 positioning module: QD75P1/P2/P4, QD75P1N/P2N/P4N, QD75D1/D2/D4, QD75D1N/D2N/D4N

Serial communication/modem interface module: QJ71C24N, QJ71C24N-R2, QJ71C24N-R4, QJ71C24, QJ71C24-R2

For QD75 positioning modules and serial communication/modem interface modules, the screen to select a module is displayed when the auto refresh is set.

● **Writing data when the QD75 ready signal (X0) is ON (positioning data only)**

Data cannot be written when the QD75 ready signal (X0) of the target intelligent function module is ON.

When the QD75 ready signal (X0) is OFF, the availability of operation differs according to the option setting\*1.

○: Applicable x: Not applicable

		"Confirm PC operation status when writing a data"	
		Selected	Cleared
Programmable controller CPU operating status	STOP	○	○
	Other than STOP	x	○

\*1 : Select [Tool] ⇒ [Options] ⇒ "Intelligent Function Module" ⇒ "QD75/LD75 Type Positioning".

9  
SETTING DEVICE COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15  
WRITING/READING DATA

16  
PROTECTING DATA

**Point** 

● **Displaying the confirmation message when writing data to a flash ROM (positioning data only)**

The confirmation message can be displayed when data are written to a flash ROM by the following setting.

Select [Tool] ⇒ [Options] ⇒ "Intelligent Function Module" ⇒ "QD75/LD75 Type Positioning" and select "Display a confirmation message when writing to flash ROM".

**Restrictions** 

● **Writing data to a flash ROM of serial communication/modem interface module when using Redundant CPU**

Before writing data, change the operation mode of the Redundant CPU to the separate mode, and set "Not Specified" for "Target System".

## 15.1.5 Symbolic information



\*1 : FX3U/FX3UC (version 3.00 or later) only

Symbolic information is data that store the program configuration such as structures and labels.

To restore these data included in the symbolic information when reading a program from the programmable controller CPU, write/read the symbolic information to/from the programmable controller CPU.

Data such as structures and labels included in the symbolic information cannot be restored if only sequence programs are read. (In case of a Structured project, the programming language is treated as Ladder Diagram.)

The following table shows the program data included in the symbolic information.

Project type	Data included in symbolic information
Simple project	Structures
	Global labels
	Local labels
	Programs
	Function blocks
Structured project	User libraries
	Structures
	Global labels
	Program Setting
	Tasks
	POU
	Local labels
	Programs
Function blocks	
Functions	

9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15  
WRITING/READING  
DATA

16  
PROTECTING  
DATA

**Point****● Write target of symbolic information**

Symbolic information can also be written to drives other than the program memory (drive 0).

For details of writable drives, refer to the following manual.

☞ User's Manual (Function Explanation, Program Fundamentals) of the CPU module to be used

**● Compile status when the symbolic information is read**

- When the symbolic information and parameters are read simultaneously, and the data in the symbolic information match with parameters and programs (program files) on the programmable controller CPU, the read data are in compiled status.
- When only the symbolic information is read, the read data are in uncompiled status.
- When the symbolic information of GX Developer or GX IEC Developer is read, the read data are in uncompiled status. Compile the program again after executing the Read from PLC function.

**● Considerations for reading symbolic information**

For the considerations for reading label programs (symbolic information) of the existing application using GX Works2, or reading label programs (symbolic information) of GX Works2 using the existing application, refer to the following section. (☞ Appendix 6.2 "Data compatibility")

**● FXCPU**

When a memory cassette to which the symbolic information has been written is used on an FXCPU other than FX3U/FX3UC version 3.00 or later, the memory cassette can be used, however, the symbolic information cannot be read from the memory cassette.

When the symbolic information is written to a memory cassette on an FXCPU other than FX3U/FX3UC version 3.00 or later, the symbolic information may be corrupted.

**● When always writing the symbolic information**

By setting the option, the symbolic information is always set to be written when the Write to PLC window is displayed. Select [Tool] ⇒ [Options] ⇒ "Symbolic Information" and select "In the Write to PLC window, keep the symbolic information selected status as a write target".

**● Automatic project save after writing to programmable controller CPU**

By setting the option, the project can be saved automatically after writing to the programmable controller CPU.

Select [Tool] ⇒ [Options] ⇒ "Project" ⇒ "Automatic Save" and select "Save project after writing to PLC".

## ■ High speed mode and Compatible mode

'High speed mode' and 'Compatible mode' are added as modes to write symbolic information to a programmable controller CPU in GX Works2 Version 1.48A.

Use 'High speed mode' when using GX Works2 for the first time.

For FXCPU, only 'High speed mode' is supported.

'High speed mode' or 'Compatible mode' can be selected by "Setting for Writing Symbolic Information to PLC" under [Tool] ⇒ [Options] ⇒ "Symbolic Information". 'High speed mode' is set as a default setting.

### ● High speed mode

- Higher speed of writing/reading symbolic information compare to 'Compatible mode'.
- Smaller symbolic information data size increases a free space on a programmable controller CPU.
- The number of files for the symbolic information is counted as two files. Check the number of files that can be stored on a programmable controller CPU.

<Considerations>

- Symbolic information written to a programmable controller CPU with 'High speed mode' cannot be read in GX Works2 Version 1.43V or earlier.

### ● Compatible mode

- Symbolic information which does not support 'High speed mode', and it is the same as the one in GX Works2 Version 1.43V or earlier.
- Larger symbolic information data size decreases a free space on a programmable controller CPU.

### Point

#### ● 'High speed mode' and 'Compatible mode'

'High speed mode' and 'Compatible mode' can be changed any time.


Symbolic information on a programmable controller CPU is always the one written most recently. Thus, the management of symbolic information is not complicated.

#### ● Symbolic information on programmable controller CPU

Symbolic information written to a programmable controller CPU with 'High speed mode' cannot be displayed on the screen for Read from PLC in GX Works2 Version 1.43V or earlier.

#### ● Write to PLC function when symbolic information is set on the <<Boot File>> tab of PLC parameter.

When symbolic information is set on the <<Boot File>> tab of PLC parameter, performing the Write to PLC function with changing the mode between 'High speed mode' and 'Compatible mode' may cause an improper boot operation. When the mode is changed, write symbolic information to a programmable controller CPU after performing the following operation.

- Check if symbolic information is set on the <<Boot File>> tab of PLC parameter, click the  button and update the boot file setting.
- Select symbolic information and parameters on the screen for Write to PLC and write symbolic information to a programmable controller CPU. Confirm the target memory of symbolic information is the same as that of the transfer destination set on the <<Boot File>> tab of PLC parameter.

9

SETTING DEVICE  
COMMENTS

10

SEARCH/REPLACE

11

PRINTING

12

SETTING OPTIONS

13

USING LIBRARIES

14

SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15

WRITING/READING  
DATA

16

PROTECTING  
DATA

## 15.1.6 Reading the remaining steps for Online program change




When reading data of a project with labels from programmable controller, this option can be selected whether to read the remaining steps for Online program change from the file written to the programmable controller CPU.

For a project without labels, refer to the following section.

☞ Section 15.1.1 "Setting write/read range of program (program file)"

### Screen display

Select symbolic information and click the **Detail** button.



### Operating procedure

- Select the checkbox of "Read the remaining capacity for Allocate Memory for Online Change".


## 15.1.7 Specifying target to write device comments to programmable controller CPU



Specify a target memory to write device comments to a programmable controller CPU. In order to store device comments to the storage destination which is different from the target memory of the current programmable controller data, select "Set save destination of device comment to the target memory of PLC data" under [Tool] => [Options] => "Save Destination of Device Comment", and set a target for "Save Destination of Device Comment" in advance.


### Screen display

Select device comments (global device comments, local device comments) on the Online Data Operation screen.



### Operating procedure

1. The following message is displayed.



2. Click the **Yes** button.

The target set for "Target Memory" is changed to the target specified for "Save Destination of Device Comment" in the option setting.

## 15.1.8 Considerations for writing/reading data to/from programmable controller CPU

Q CPU L CPU Remote Head FX

The following explains the considerations for writing/reading data to/from the programmable controller CPU.

### 1) Writing or reading programs with a Peripheral statement/note to or from the programmable controller CPU


The information of the lines with Peripheral statement/note is written to the programmable controller CPU, but the content of the statement/note are not written to the programmable controller CPU.

If a program with the same name as that of the program set with a Peripheral statement/note is read from the programmable controller CPU, the former overwrites the latter (the one in GX Works2), so the Peripheral statements/notes of the latter is discarded. To keep the Peripheral statement/note in GX Works2 when reading data from the programmable controller CPU, merge the Peripheral statement/note.

(Merging statements/notes  GX Works2 Version 1 Operating Manual (Simple Project))

### 2) An uncompiled program exists when writing data to the programmable controller CPU

If the following message is displayed when writing data to the programmable controller CPU, click the  button and stop writing data. Then, execute [Compile] ⇒ [Build] again on the uncompiled program.



### 3) Writing programs to programmable controller CPU after compiling all programs


Compiling all programs changes the device assignment to labels. Therefore, device values set before the program change remain on the device-assigned labels.

By setting the following option, device values in the range set with the "Device/Label Automatic-Assign Setting" function can be automatically cleared to 0 after writing programs to the programmable controller CPU.

- [Tool] ⇒ [Options] ⇒ "When writing to PLC after a Rebuild All operation, clear the device ranges set in the Device/Label Auto-Assign setting to 0."

Perform the following operations for a precautionary measure when the above option setting is not set.

- For QCPU (Q mode)/LCPU  
After writing data to the programmable controller CPU, reset the programmable controller CPU, clear all device memories including latches, clear all file registers, and switch the programmable controller CPU to RUN.
- For FXCPU  
After writing data to the programmable controller CPU, clear device memory using the PLC memory clear function, and switch the programmable controller CPU to RUN.

( Section 20.4)



- 4) **Editing programs after writing symbolic information to the programmable controller CPU**  
 Edit programs in the same project type as the symbolic information if editing them after writing symbolic information to the programmable controller CPU.

In addition, be sure to write the latest symbolic information to the programmable controller CPU if writing only execution programs to it using such as Online program change.

If execution programs are read out and edited in GX Works2 projects without labels or GX Developer and rewritten to the programmable controller CPU, the programs being edited may be inconsistent with the execution programs on the programmable controller CPU when symbolic information is read out using GX Works2.

If inconsistency occurs by the operation mentioned above, check the mismatch parts using the Verify with PLC function and correct them.

- 5) **Performing the Write to PLC function when symbolic information is not written to the programmable controller CPU**

Program data are not displayed on the screen for Read from PLC in a project with labels.

When reading programs in a project with labels, select symbolic information.

When symbolic information is not written to the programmable controller CPU, create a new project without labels, and read the programs.

When reading programs in a project without labels, the read programs are displayed as a ladder program. However, as there are cases where programs cannot be displayed correctly as a ladder program, be sure to check the program after the symbolic information has been read from the programmable controller CPU.

The background color of the ladder block in which the program cannot be displayed correctly in a program is displayed in yellow.

The program can be edited by deleting the ladder block or adding new ladder block before or after it, even when the background color is displayed in yellow.

Be sure to write/read the symbolic information to/from the programmable controller CPU in order to restore the program to its original state.

- 6) **Writing data after the device range in PLC parameter is changed**


When the device range of PLC parameter has been changed, write the parameter to the programmable controller CPU.

Programs cannot be written to the programmable controller CPU unless the parameter is written to the programmable controller CPU.

- 7) **When the date on the personal computer is February 29**

When the date on the personal computer is February 29, the following message is displayed if the Write to PLC, Online program change, or Change TC setting function is performed on a Basic model QCPU function version A.

The file will be written with the date 'February 28' by clicking  button.



- 8) **Basic model QCPU function version A**

Basic model QCPU function version A does not support SFC programs, device initial values, and remote passwords.

For the Write to PLC function, these files cannot be written even though their names are displayed. For the Read from PLC function, files of SFC programs and device initial values are not displayed in the file list. Files of remote passwords cannot be read out even though their file names are displayed.

SETTING DEVICE COMMENTS	9
SEARCH/REPLACE	10
PRINTING	11
SETTING OPTIONS	12
USING LIBRARIES	13
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION	14
WRITING/READING DATA	15
PROTECTING DATA	16

**9) Writing data to a Redundant CPU in the backup mode**

When a Redundant CPU is operating in the backup mode, the write to PLC function is performed on both systems (control system and standby system).

However, in any of the following states, the write to PLC function is performed on the connective system only.

- The target system power is OFF.
- The target system is reset.
- The tracking cable failed.

**10) Writing data to a Redundant CPU in the separate mode/debug mode**

When a Redundant CPU is operating in the separate mode or debug mode, the write to PLC function is only performed on the Redundant CPU which is specified for "Target System" on the Transfer Setup screen.


**11) FXCPU**

- For projects with labels, data can be read from a programmable controller CPU, and symbolic information can be read from/write to a programmable controller CPU in a project of FX3U/FX3UC version 3.00 or later only. Since these functions cannot be performed on the other FXCPU projects with labels, store the projects in a safe place.
- When a project including a block password to which the execution program protection setting was enabled is written, the execution program cannot be read. To restore the program, write the symbolic information.
- When a program with an Peripheral statement/note is written to the programmable controller CPU, the Peripheral statement/note cannot be written to it. (The information of the lines with Peripheral statement/note also cannot be written to the programmable controller CPU.)

**12) Writing data to FXCPU in batch**

Set the programmable controller CPU to STOP status.

When it is in RUN status, the message shown below is displayed. Select the  button.

**13) When the program memory of FXCPU is the EPROM cassette**

Write programs with the ROM writer. For the EEPROM or flash memory cassette, turn the PROTECT switch OFF first and write programs.

**14) Writing/reading ER device with FX3U/FX3UC**

Writing/reading data cannot be executed with FX3U/FX3UC unless the memory cassette is installed to the programmable controller main unit.

**15) Writing data to FX1s version earlier than 2.00**

Data of project with labels cannot be written.

Use data of project without labels.

- 16) Reading the symbolic information, which has been written to the programmable controller CPU using the Japanese version of GX Works2, using the English version of GX Works2**  
 The symbolic information, which has been created and written to the programmable controller CPU using the Japanese version of GX Works2, cannot be read from the programmable controller CPU using the English version of GX Works2.

In this case, save again the project created with the Japanese version of GX Works2 using the English version of GX Works2, and write the symbolic information to the programmable controller CPU.


By following the operation described above, the symbolic information can be read from the programmable controller CPU using the English version of GX Works2.

- 17) Reading projects created in English version of GX Works2 from programmable controller CPU**  
 When reading projects created in the English version of GX Works2 Version 1.31H or earlier from the programmable controller CPU, select "Japanese" for the language selection.

- 18) Reading data from SD memory card**  
 The following are the considerations when reading data from the SD memory card.
- Program files/intelligent function module parameters created on the programmable controller CPU whose series is different from the connected programmable controller CPU cannot be read.
  - Parameters/symbolic information on the programmable controller CPU whose type is different from the connected programmable controller CPU cannot be read.

Example) When the program file created on the LCPU is stored on the SD memory card  
 The program file created on the LCPU cannot be read from the SD memory card on the High-speed Universal model QCPU.

- 19) Changing the number of columns of device memory editor**  
 The number of columns of device memory editor can be changed when opening GX Developer format project by selecting the following option.
- [Tool] ⇒ [Options] ⇒ "Device Memory Editor" ⇒ "Initial Value of Column Number"
- When selecting "Always Confirm", the number of device memory editor can be changed at opening the Device Memory screen at the first time on the following screen.  
 When setting "Auto" as a default, or always specify the same number of columns by selecting "Specify the number of column", set with option or select "Set the selected content in option" in advance.
- If reading device memory whose number of device memory editor has been changed without changing the number of columns, do not perform PLC read but select [Tool] ⇒ [Read Device Memory from PLC] (☞ Section 7.4.1)



SETTING DEVICE COMMENTS	9
SEARCH/REPLACE	10
PRINTING	11
SETTING OPTIONS	12
USING LIBRARIES	13
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION	14
WRITING/READING DATA	15
PROTECTING DATA	16

**20) Reading device comments**

By setting the following option, whether to merge the device comments in the project with giving priority to the read device comments can be set.

- [Tool] ⇒ [Option] ⇒ "PLC Read/Write" ⇒ "Merge device comment with the project data at time of PLC read"

If the option is not set, the device comment file in the project is deleted and replaced with the read device comment when reading data.

**21) Reading a program with a block password to which the execution program protection setting was enabled**

For High-speed Universal model QCPU, Universal model process CPU, LCPU or FXCPU, reading an execution program only is not available if the project written to the CPU includes a block password to which the execution program protection setting was enabled. To read an execution program, the symbolic information needs to read simultaneously.

# 15.2 Verifying Data on Programmable Controller CPU against Data on Personal Computer

Q CPU L CPU Remote Head FX

This section explains how to verify the open project against the data on the programmable controller CPU.

The verification function is used to compare the content of two projects or to locate program changes.

To verify data between two projects, use the Verify function. (Section 4.2.7)


The following data can be selected as verification targets for the Verify with PLC function.

- Programs
- Parameters
- Intelligent function module parameters (initial setting/auto refresh)\*1
- Device comments
- Device memory data
- File registers
- QD75/LD75 positioning module\*1

\*1 : Not supported by FXCPU.


## Screen display

Select [Online] ⇒ [Verify with PLC].  
<CPU module>



9 SETTING DEVICE COMMENTS  
10 SEARCH/REPLACE  
11 PRINTING  
12 SETTING OPTIONS  
13 USING LIBRARIES  
14 SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION  
15 WRITING/READING DATA  
16 PROTECTING DATA

<Intelligent function module>



**Operating procedure**

**1. Select data to verify from the file list.**

Item	Description
Connection Channel List	Display the information of the connection destination setting.
Target module tab	Switch the setting target module. Characters on the tab are displayed in blue when data to be verified exist.
PLC Module	Set the settings to verify data with data on the programmable controller CPU.
Intelligent Function Module*1	Set the settings to verify data with data on the intelligent function module. ☞ Section 15.1.4
Title*1	Display the title of the target memory by clicking the  button.
File list	—
Target	Select the data to be verified.
Target Memory*1	Select "Target Memory" on the row of "PLC Data" displayed in light blue, and select a target memory to be verified from (▼). For details of the memory card application, refer to the following manuals. ☞ QCPU User's Manual (Hardware Design, Maintenance and Inspection) ☞ MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)
Comment Verify Type	Set a basis either; data being edited or module data, when verifying device comments. (☞ "■ Comment verify type")
Memory capacity*1	—
Writing Size	Display the total size of written data selected in "Target".
Free Volume	Display the free space volume of the target memory.
Use Volume	Display the used space volume of the target memory.

\*1 : Not supported by FXCPU.

**2. Click the button.**


The verification results are displayed on the Verify Result screen.

☞ Section 4.2.7 "■ Checking verification result details"

## Screen button

For the buttons on the screen, refer to Section 15.1.

- **SFC Block Selection...** (Not supported by FXCPU)  
Opens the screen to select the SFC block to be verified.



### Point

- **Verifying automatically assigned devices**

Devices are verified based on the range of device/label automatic-assign setting of the project. When changing the range of device/label automatic-assign setting after writing to PLC, and then automatically assigned devices of the module are outside the range, the verification result mismatches.

- **Verification result when CC-Link Configuration window is created**

When the same profile is not registered to the verify destination and the verify source, the verification result may be a mismatch.

(☞ Section 4.13)

- **Project security status**

Projects to which the security is set can be verified when both verify source data and verify destination data are not read-protected.

- **Verifying intelligent function module parameters (initial setting/auto refresh)**

Among modules without initial setting such as QD75/LD75 positioning modules, serial communication/modem interface modules, and AS-i master modules, only modules in which the auto refresh is set are the verification targets.

- **Verifying QD75/LD75 positioning modules**

One module each for verify source and verify destination can be selected.

The following data can be selected as verification targets.

- Parameter
- Servo parameter (For QD75M/MH only)
- Positioning data (Except for positioning comments and M code comments)
- Block start data

- **Verifying device memory data for FXCPU**


Special registers (M) and special data registers (D) cannot be selected as verification targets.

## ■ Parameter verification

Verification levels can be selected for verifying parameters.  
This function is not supported by FXCPU.

### Screen display

Select the parameter and click the  button.



The following table shows the setting items for parameter verification.

Item	Description
User Setting Area Only	Verify only the parameter area set by the user.
All Areas	Verify all area including the parameter area set by the system.

### ● Mismatched point in system area

If a mismatched point is detected in the system area by the "All Areas" verification, either of the following messages is displayed.

Take corrective action according to the message.

Message	Corrective action
The header information of the parameter block is inconsistent.	A mismatch exists in area other than the user setting area.*1 Rewrite the parameters having been written to the programmable controller CPU.
This parameter block can't analyze.	Versions of GX Works2, GX Developer, or GX IEC Developer used to create the project differ between the programmable controller CPU and GX Works2. The operation of the programmable controller CPU is not affected. To match the "All Areas" verification, install the latest version of GX Works2, read the parameters from the programmable controller CPU, and write them again to the programmable controller CPU.


\*1 : Data in areas other than the user setting area may be erroneous due to such as noise.



## ■ Comment verify type

A basis of the range, either 'data being edited' or 'module data', can be set in the Verify with PLC function of device comment.

The comment verify type can be set when global device comments or local device comments of both 'data being edited' and 'module data' are selected.



The following table shows the items of the comment verify type and their descriptions.

Item	Description
Comment Verify Type	-
GX Works2 Data	Verify data with the range of device comments in the project as a basis. When this item is selected, detail setting of the selected device comments can be set by clicking the <b>Detail</b> button. (Section 15.1.3)
PLC Data	Verify data with the range of device comments written to the programmable controller CPU as a basis.

### ● Verification result differences of comment verification method

The following shows an example of the Verify with PLC function performed on the following device comments.

Device	Device comments in project	Device comments on programmable controller CPU
M0	Global device comment 1	Global device comment 1
M1	Global device comment 2	Global device comment 2
M2	Device comment of M2	Global device comment 3
M3		Programmable controller CPU only
M4	Project only	
M5		
M6		Programmable controller CPU only

< When "GX Works2 Data" is selected for verification >

No.	Device Name	Verify Source	Verify Destination
1	M2	Device comment of M2	Global device comment 3
2	M3		Programmable controller CPU only
3	M4	Project only	

< When "PLC Data" is selected for verification >

No.	Device Name	Verify Source	Verify Destination
1	M2	Device comment of M2	Global device comment 3
2	M3		Programmable controller CPU only
3	M4	Project only	
4	M6		Programmable controller CPU only


## 15.3 Deleting Programmable Controller CPU Data

Q CPU L CPU Remote Head FX

This section explains how to delete data on the programmable controller CPU such as programs and parameters.

### Screen display

Select [Online] ⇒ [Delete PLC Data].



### Operating procedure

1. Select the data to delete from the file list.  
For the items on the screen, refer to Section 15.1.
2. Click the **Execute** button.  
The specified data are deleted.

### Screen button

For the buttons on the screen, refer to Section 15.1.

#### Point

- **Deleting symbolic information**  
If the symbolic information is deleted, information such as labels cannot be restored.
- **Deleting programs (program files) only**  
The content of the symbolic information are not updated, even if a program (program file) is deleted. When the symbolic information is read, the deleted program is restored.


# 15.4 Copying Program Memory Data to ROM



This section explains how to copy the program memory data on the programmable controller CPU to a standard ROM on the programmable controller CPU or a Flash card in batch. This function is used to boot up using a standard ROM or a Flash card, or save program memory data in a standard ROM or a Flash card without a battery backup. Since the program memory of Universal model QCPU and L CPU is a flash ROM, program memory data can be saved without a battery backup for those CPUs.

## Screen display

Select [Online] ⇒ [Export to ROM Format].




## Operating procedure

1. Set the items on the screen.

Item	Description
Target	Select the memory in which the program memory data are to be written.

2. Click the  button.

The message is displayed.



3. Click the  button.

The program memory data are exported in ROM format and the data are written to the memory set in "Target".

### Point

- **Considerations for writing**  
All the write target data are deleted.
- **Reading data written in ROM format**  
Use the Read from PLC function to read the data written in ROM format.
- **Exporting device memory in ROM format**  
The device memory cannot be written using the Export to ROM format function.

SETTING DEVICE COMMENTS	9
SEARCH/REPLACE	10
PRINTING	11
SETTING OPTIONS	12
USING LIBRARIES	13
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION	14
WRITING/READING DATA	15
PROTECTING DATA	16

## 15.5 Writing/Reading/Deleting PLC User Data



\*1 : Not supported by Basic model QCPU, Q00UJ, Q00U, and Q01U.

This section explains how to write/read/delete PLC user data (CSV format file/binary format file) to/from an ATA card/SD memory card/standard ROM.

PLC user data written to an ATA card/SD memory card/standard ROM can be used in sequence programs.

For the method for handling the PLC user data in sequence programs, refer to the following manual.

👉 MELSEC-Q/L Programming Manual (Common Instructions)

### Point

- **Formatting ATA cards**

Format the ATA card to be used on the programmable controller CPU by selecting [Online] ⇒ [PLC Memory Operation] ⇒ [Format PLC Memory] in GX Works2.

If a card is formatted using the function such as Windows® format functions, it may not be used on the programmable controller CPU.

- **Project file attributes**

The file attributes (read only, hidden file) set by the application such as Windows® Explorer are ignored.

- **Memory capacity**

When PLC user data are written to the programmable controller CPU, the target memory capacity may be displayed smaller than it really is.

- **Folders in memory card**

When reading/deleting PLC user data, data such as logging data contained in folders are not displayed in "PLC Side File".

- **Writing data to an SD memory card**


When PLC user data is written to an SD memory card, the characters of the file names become upper-case characters.

### Screen display

Select [Online] ⇒ [PLC User Data] ⇒ [Write]/[Read]/[Delete].

The following explains the settings for writing PLC user data. The settings for reading/deleting PLC user data can be made in the same manner.

<Writing PLC User Data>



### Operating procedure

1. Use the **Browse...** button to set the storage source for the PLC user data to be written.

When reading PLC user data, set the save destination for the PLC user data to be read.

2. Set the items on the screen.

Item	Description
Connection Channel List	Display the information of the connection destination setting.
Target Memory	Select the memory to which the PLC user data are to be written. For details of the memory card application, refer to the following manuals. ☞ QCPU User's Manual (Hardware Design, Maintenance and Inspection) ☞ MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)
Title	Display the title of the target memory by clicking the <b>Refresh</b> button.
Local File (Write only)	Select the PLC user data to be written. The maximum file size is 32MB per file.
PLC Side File (Read/Delete only)	Select the PLC user data to be read. Select the PLC user data to be deleted.

3. Click the **Execute** button.

When writing PLC User Data, the selected PLC user data are written.

When reading PLC User Data, the selected PLC user data are read.

When deleting PLC User Data, the selected PLC user data are deleted.

### Screen button

For the explanation of the buttons on the screen, refer to Section 15.1.

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

## 15.6 Transferring Data to Program Memory in Batch



\*1 : Universal model QCPU only

This section explains how to transfer the content of program cache memory to program memory in batch.


Use this function to transfer data at desired timing, for example, when option setting is made so that a program is not transferred to the program memory at Online program change.

### Operating procedure


#### 1. Select [Online] ⇒ [Program Memory Batch Download].

Either of the following screens is displayed according to the programmable controller CPU and its version.

<Universal model QCPU with a serial number whose first five digits are '10012' or higher, LCPU>



<Universal model QCPU with a serial number whose first five digits are '10011' or lower>



#### 2. Click the button.

The content in the program cache memory is transferred to program memory in batch.


**Point**

● **Considerations of program memory batch transfer**

The following functions cannot be executed during program memory batch transfer. Execute these functions only after completing program memory batch transfer.

- Online program change (ladder program, Structured Ladder/FBD program, ST program, function block)\*1
- Change TC Setting (when "Write changed program to PLC" is selected)\*1
- Write to PLC function (when program memory is the target memory)\*1
- Program memory batch transfer (this function)
- Set as default connection
- Change PLC Type function
- Check Parameter

\*1 : For Universal model QCPU with a serial number whose first five digits are '12012' or higher, the following message is displayed and the process of the program memory batch transfer can be canceled. To cancel the transfer, click the  button.



● **When the program cache memory and the program memory match**

The batch transfer of the program memory data is not executed.

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

## 15.7 Latch Data Backup



\*1 : Universal model QCPU only

This section explains how to back up data such as device memory, file register, and error history to the standard ROM.

The backup content stored using this function is automatically restored to the program memory or other area when the programmable controller CPU is turned from OFF to ON or when it is reset. This function allows the system to create backups of the data such as device data and error history data for those times when the system needs to be shut down for a prolonged time without use of battery.


For details of backup target data, refer to the User's Manual (Function Explanation, Program Fundamentals) of the CPU module to be used.

### 15.7.1 Backing up latch data

Back up device memory/file register/error history data.

#### Operating procedure

1. Select [Online] ⇒ [Latch Data Backup] ⇒ [Backup].



2. Click the  button.

Device memory/file register/error history data are backed up.

#### Point

##### ● Devices

The latch data backup function is available for the following devices.

M, L, B, F, V, T, ST, C, D, W, Z, ZR, R

To back up ZR and R, select "Transfer to Standard ROM at Latch data backup operation" on the <<PLC File>> tab of PLC parameter.




## 15.7.2 Deleting backup data

Delete the backup data on programmable controller CPU.

### Operating procedure

1. Select [Online] ⇒ [Latch Data Backup] ⇒ [Delete Backup Data].



2. Click the  button.

Backup data are deleted.

### Point

- **Considerations for deleting backup data**

Backup data cannot be deleted when the programmable controller CPU is in RUN status.  
To delete the backup data, set the programmable controller CPU to STOP status.

9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA

## 15.8 Backing up/Restoring Data



\*1: Universal model QCPU (except for Q00UJ, Q00U, Q01U) only

\*2: Not supported by L02S and L02S-P.

This section explains how to back up data on the programmable controller CPU to a memory card, and restoring it to another programmable controller CPU.


### 15.8.1 Backing up data to memory card

Back up data on the programmable controller CPU to a memory card.

#### Screen display

Select [Online] ⇒ [PLC Module Change] ⇒ [Create Backup Data].

The following is an example of setting screen when QCPU (Q mode) is selected.



#### Operating procedure


##### 1. Set the items on the screen.

Item	Description
Connection Channel List	Display information of the connection channel being set.
Status	Display the execution status of backup.
Setting	Select data to be backed up from "Backup Target Data". "Default Backup Data" settings are fixed as selected status. They cannot be changed.

## 2. Click the **Execute** button.

Data backup starts.

When data backup is completed normally, the image as shown below is displayed in "Status".



## 3. Remove the memory card.

Turn the programmable controller CPU from OFF to ON, or reset it.

### Screen button

- **Display Status**


Refreshes and displays the execution status of backup when the power is turned OFF or reset.

- **Confirm Data Size**

Displays a total size of data selected in "Backup Target Data".

- **Options**

Opens the screen to set options for creating backup data.



### Point

- **Deleting backup data**

Backup data can be deleted by selecting [Online] ⇒ [Delete PLC Data]. However, backup data in a Flash card cannot be deleted.


## 15.8.2 Restoring backup data

Restore the registration from backup data for the programmable controller CPU replacement.

### Screen display

Select [Online] ⇒ [PLC Module Change] ⇒ [Restore].

The following is an example of setting screen when QCPU (Q mode) is selected.




### Operating procedure

- Click the **Execute** button.

Data restoration starts.

When data restoration is completed normally, the image as shown below is displayed in "Status".



# 15.9 Online Program Change

This section explains the operations for changing programs or data while the programmable controller CPU is in RUN (Online program change).

The Online program change operations include Online program change performed during conversion/ compilation and performed from the Write to PLC screen in units of files.

Be sure to fully understand the descriptions below and in Section 15.9.4 to Section 15.9.6 for operating with care.

## WARNING

- When data change, program change, or status control is performed from a personal computer to a running programmable controller, create an interlock circuit outside the programmable controller to ensure that the whole system always operates safely. Furthermore, for the online operations performed from a personal computer to a programmable controller CPU, the corrective actions against a communication error due to such as a cable connection fault should be predetermined as a system.

## CAUTION



- The online operations performed from a personal computer to a running programmable controller CPU (Program change when a programmable controller CPU is RUN, operating status change such as RUN-STOP switching, and remote control operation) have to be executed after the manual has been carefully read and the safety has been ensured. When changing a program while a programmable controller CPU is RUN, it may cause a program corruption in some operating conditions. Fully understand the precautions described in this section.

SETTING DEVICE COMMENTS	9
SEARCH/REPLACE	10
PRINTING	11
SETTING OPTIONS	12
USING LIBRARIES	13
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION	14
WRITING/READING DATA	15
PROTECTING DATA	16

## 15.9.1 Performing Online program change during conversion/compile



Perform Online program change during conversion/compilation after program change.  
 Before changing a program, check that the program matches the one on the programmable controller CPU using the Verify with PLC function. Online program change cannot be performed if the programs do not match.



### Projects without labels


#### Operating procedure

1. Verify a program against a program on the programmable controller CPU to ensure that they match.
2. Change or modify the program.
3. Select [Compile] ⇒ [Online Program Change] to perform Online program change.


The message is displayed.

Fully understand the message before performing Online program change.

<When not writing/deleting SFC blocks>



<When writing/deleting SFC blocks>




4. Click the  button.

**Point**

● **When target memory to write data is booting up**

When updating the changes to the boot source while "Under booting, reflect changes to boot source during online program change" is selected under [Tool] ⇒ [Options] ⇒ "Online Change", and the target memory is booting up, click the  button on the message shown below.\*1

\*1 : For Universal model QCPU (except for Q00UJ/Q00U/Q01UCPU) and LCPU only



9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15  
WRITING/READING  
DATA


16  
PROTECTING  
DATA

## ■ Projects with labels

### Operating procedure

1. Verify a program against a program on the programmable controller CPU to ensure that they match.
2. Change or modify the program.
3. Select [Compile] ⇒ [Online Program Change].


The Confirm Build Method for Online Program Change screen is displayed.




4. Select "Execute compile and online change after conversion" and click the  button.

The program is converted and compiled simultaneously, and Online program change is performed. The following message is displayed.

<When not writing/deleting SFC blocks>



<When writing/deleting SFC blocks>






5. Click the **Precautions** button.


The following message is displayed.

Be sure to read and fully understand the message, and click the **OK** button.


<When not writing/deleting SFC blocks>



<When writing SFC blocks>



<When deleting SFC blocks>



6. Set the items on the screen.

Item	Description
Online Change	
Write Symbolic Information to PLC*1	Select this to write the symbolic information to the programmable controller CPU. Select "Target Memory".
Reflect Changes to Boot Source*2,*3	Select this to apply the change to the boot source while the target memory is booting.

\*1 : For FXCPU, this item is supported by FX3U/FX3UC version 3.00 or later only.

\*2 : Not supported by FXCPU.

\*3 : This item can be selected when "Under booting, reflect changes to boot source during online program change" is selected under [Tool] => [Options] => "Online Change", and the target memory is booting up. (For Universal model QCPU (except for Q00UJ/Q00U/Q01UCPU) and LCPU only)

7. Click the **Yes** button.

Online program change is completed.

9 SETTING DEVICE COMMENTS

10 SEARCH/REPLACE

11 PRINTING

12 SETTING OPTIONS

13 USING LIBRARIES

14 SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15 WRITING/READING DATA


16 PROTECTING DATA

### ■ Writing range for Online program change

Perform Online program change with the following writing range which depends on the editing mode. When a new ladder block is inserted, the inserted program is written together with two steps (one before and the other after the program) to the programmable controller CPU. Therefore, the Online program change may not be completed at a time depending on the number of program steps added and the two steps before and after the program. In this case, reduce the number of steps written at a time and perform Online program change in several times. The following table shows the number of steps that can be written at once.

CPU type	Number of steps that can be written at once
QCPU (Q mode), LCPU	512
FX3S, FX3G, FX3GC, FX3U, FX3UC (earlier than V2.00)	256
FX0N, FXU, FX2C, FX1S, FX1N, FX1NC, FX2N, FX2NC, FX3UC (V2.00 or later)	127

**Example)**



### ● Editing separate ladder blocks

For QCPU (Q mode), when the programmable controller CPU has "Online change area of multiple blocks" in its memory, multiple blocks can be written in units of blocks.

For High Performance model QCPU, "Online change area of multiple blocks" can be created using the memory format function. (☞ Section 20.3)


● **Editing Structured Ladder/FBD or ST programs**

Structured Ladder/FBD or ST programs are compiled in program block unit. Even with a partial program change, the whole program block becomes a write target of Online program change. For this reason, the number of steps that can be written is exceeded and an error may occur in Online program change.

When an error occurs, update the program with the Write to PLC function.

For QCPU (Q mode)/LCPU, Online program change can be performed in file unit.


(☞ Section 15.9.2)



Example) Online program change target after compiling a program with a line change

As shown in the following figures, delete the line in the ladder block 1 and change the labels to M\_TEST, and compile the program.

Since the temporary variable (1) used for the line in the ladder block 1 is released and reused as a temporary variable of the line in the ladder block 2, a change is also applied to the ladder block 2 to which any changes has not been applied by a user, and the ladder block 2 becomes the Online program change target.



9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

### Point

- **When performing Online program change to a programmable controller CPU for the first time, or an error occurs during Online program change**

Make sure that the program before writing matches the program on the programmable controller CPU with the Verify with PLC function.

- **When the program part to be written does not match**

If the program part to be written does not match with the program on the programmable controller CPU, Online program change cannot be performed.

Perform Online program change in units of files. (☞ Section 15.9.2)

- **When Online program change of multiple blocks cannot be performed**

The message is displayed in the following cases when Online program change is performed. Select whether to perform Online program change in units of files.

- There are no "Online change area of multiple blocks".
- The number of blocks exceeds the limit of Online program change of multiple blocks.
- The programmable controller CPU does not support the Online program change of multiple blocks.

- **When performing Online program change to a programmable controller CPU in which the symbolic information has been written**

Symbolic information, which contain the program configuration data such as structures and labels, are the data necessary only for restoring the data such as structures and labels after reading a program from the programmable controller CPU. (☞ Section 15.1.1) Therefore, the write of symbolic information does not affect the operation of the programmable controller CPU, however, when performing Online program change to a programmable controller CPU in which the symbolic information has been written, be sure to write the execution program together with the symbolic information.

Note that since programs (program files) are written in batch along with source information, writing only source information is not applicable.

However, it may take a few or more minutes to write symbolic information, therefore, the following action is recommended.

When performing Online program change repeatedly, do not write symbolic information every Online program change but perform Online program change in units of files, and perform the Write to PLC operation to write symbolic information after all processes of Online program change are completed. (☞ Section 15.9.2)

- **Online program change after compiling all programs**

All programs need to be compiled when the following operations are performed. Therefore the [Online Program Change] function cannot be performed.

Write programs to programmable controller CPU after compiling all programs. (☞ Section 15.1, Section 15.9.2)

- Changing the following PLC parameters (QCPU (Q mode)/LCPUCPU only)
  - "Common Pointer No." and "Timer Limit Setting" on the <<PLC System>> tab
  - "File Register" and "File for Local Device" on the <<PLC File>> tab
  - Settings on the <<Device>> tab
- Changing the following option settings
  - "Default Length of String Data Type" in "Label Setting Editor"
  - Settings in "Compile"
- Changing automatically assigned devices
- Updating instructions and application functions when opening Structured project.
- Changing PLC type
- Changing project type
- Executing the Write to PLC function when a new project is not created, or a project is not opened

- **Automatic project save after Online program change**

By setting the option, the project can be saved automatically after Online program change. Select [Tool] ⇒ [Options] ⇒ "Project" ⇒ "Automatic Save" and select "Save project after online change".

- **Editing separate ladder blocks with FXCPU**

For FXCPU, ladder blocks between the edited ladder blocks are also written to the programmable controller CPU.

- **Performing Online program change with FXCPU**



- Symbolic information can be written to a programmable controller CPU with the Online program change function for projects of FX3U/FX3UC version 3.00 or later only.
- The Online program change function does not support SFC programs.
- When selecting [Compile] ⇒ [Online Program Change], Online program change may not be able to be performed if a restriction of the programmable controller CPU is applied to the compilation result. (☞ Section 15.9.6)

## 15.9.2 Performing Online program change in units of files



\*1 : Not supported by Basic model QCPU.

Write programs or data in units of files while the programmable controller CPU is in RUN.




Writes data to programmable controller CPU in units of files.

### Operating procedure

- Select [Online] ⇒ [Write to PLC] for Online program change.

The message is displayed.  
Fully understand the message before performing Online program change.  
(Writing to programmable controller CPU  
↳ Section 15.1)



SETTING DEVICE COMMENTS	9
SEARCH/REPLACE	10
PRINTING	11
SETTING OPTIONS	12
USING LIBRARIES	13
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION	14
WRITING/READING DATA	15
PROTECTING DATA	16

**Point****● Data that can be written in units of files with Online program change**

Data such as sequence programs and device comments can be written with Online program change. The data that can be written with Online program change differs depending on the write target memory. For details, refer to the following manual.

- User's Manual (Function Explanation, Program Fundamentals) of the CPU module to be used


**● Online program change after compiling all programs**

The Online program change cannot be performed after compiling all programs. When the Online program change function is executed after compiling all programs, the programmable controller CPU is remotely stopped and programs are written to the programmable controller CPU.

Compiling all programs changes the device assignment to labels. Therefore, device values set before the program change remain on the device-assigned labels.

By setting the following option, device values in the range set with the "Device/Label Automatic-Assign Setting" function can be automatically cleared to 0 after writing programs to the programmable controller CPU.

- [Tool] ⇒ [Options] ⇒ "When writing to PLC after a Rebuild All operation, clear the device ranges set in the Device/Label Auto-Assign setting to 0."


For not configuring the above setting, as a precautionary measure, after writing programs to the programmable controller CPU, reset the programmable controller CPU, clear all device memories including latches, clear all file registers, then switch the programmable controller CPU to RUN. (  Section 20.4)

For the considerations for compiling all programs, refer to the following manuals.



- GX Works2 Version 1 Operating Manual (Simple Project)/(Structured Project)

**● Memory shortage of the programmable controller CPU**

Increase the free space of the programmable controller CPU with the Memory arrangement function.


(  Section 20.5)

If the capacity is still insufficient after the operation, switch the programmable controller CPU to STOP and delete unnecessary programs in it. Then, write the programs using the Write to PLC function.

(Delete PLC Data  Section 15.3, Write to PLC  Section 15.1)

**● When performing Online program change to a programmable controller CPU in which the symbolic information has been written**

Symbolic information, which contains the program configuration data such as structures and labels, is data necessary for restoring the data such as structures and labels after reading a program from the programmable controller CPU.

(  Section 15.1.1)

Therefore, the symbolic information does not affect the operation of the programmable controller CPU, however, write the symbolic information when performing Online program change to a programmable controller CPU to which the symbolic information has been written.

However, note that since it may take a few minutes to write symbolic information, it is recommended not to write symbolic information every Online program change but to write symbolic information after all Online program changes are completed.

**● When performing Online program change to Universal model QCPU**

The following Online program change cannot be performed.

- Online program change performed on a program which does not exist on a programmable controller CPU.
- Online program change performed on a program which is not registered on the <<Program>> tab of PLC parameter.
- Online program change on an SFC program in unit of file.

### 15.9.3 Online program change starting from pointer




\*1 : Not supported by Basic model QCPU function version A.

Write data to one file with two or more GX Works2s while the programmable controller CPU is in RUN, using relative step numbers starting from a pointer.


A pointer for Online program change needs to be set in advance.

Example)



#### Screen display

Select [Tool] ⇒ [Options] ⇒ "Online Change".



#### Operating procedure

- Select "Execute online change based on relative step No.".

When Online program change is performed, data are written with relative step numbers starting from the pointer.

#### Point

##### ● Ladder blocks including a pointer

When performing Online program change based on relative step numbers starting from the pointer, do not add any line statements to a ladder block including the pointer.

If Online program change of a program with line statements is performed, program mismatching may occur. In this case, perform Read from PLC, and executes normal Online program change.

SETTING DEVICE COMMENTS	9
SEARCH/REPLACE	10
PRINTING	11
SETTING OPTIONS	12
USING LIBRARIES	13
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION	14
WRITING/READING DATA	15
PROTECTING DATA	16

## 15.9.4 Considerations for Online program change of rise, fall, or SCJ instruction



The following explains the considerations for Online program change of programs containing the rise, fall, or SCJ instruction.

### ■ QCPU (Q Mode)/LCPU

#### ● Fall instruction

The fall instruction may be executed even if the executing condition (ON→OFF) in the online-changed ladder programs is not satisfied.

For the types and functions of the fall instructions, refer to the Programming Manual for each CPU.

<Fall instruction examples> PLF, LDF, ANDF, ORF, MEF, FCALLP, EFCALLP, and STMR

ON/OFF status of a contact (conduction state at Online program change)	Fall instruction
OFF→OFF	Executed*1
OFF→ON	Not executed
ON→OFF	Executed*1
ON→ON	Not executed

\*1 : For details of disabling the fall instruction execution, refer to the following section.

( ■ Disabling the fall instruction in Online program change for QCPU (Q mode)/LCPU)

#### ● Rise instruction

The rise instruction is not executed even if the executing condition (OFF→ON) in the online-changed ladder programs is satisfied.

The rise instruction is executed when the executing condition turns OFF→ON again.

For the types and functions of the rise instructions, refer to the programming manual of each CPU.

<Rise instruction examples> PLS, LDP, ANDP, ORP, MEP, and STMR

ON/OFF status of a contact (conduction state at Online program change)	Rise instruction
OFF→OFF	Not executed
OFF→ON	Not executed
ON→OFF	Not executed
ON→ON	Not executed

#### ● SCJ instruction

When the executing condition for the SCJ instruction is ON after writing, the instruction jumps to the specified pointer without waiting for one scan.



## ■ Disabling the fall instruction in Online program change for QCPU (Q mode)/LCPU

The following explains methods for avoiding the fall instruction execution when the executing condition (ON→OFF) of the fall instruction for the online-changed program is not satisfied.


### ● Using the option setting (not supported by Basic model QCPU)

The fall instruction execution can be disabled by selecting [Tool] ⇒ [Options] ⇒ "Online Change" and setting "Execute fall instruction". However, the fall instruction is not executed even if the executing condition (ON→ OFF) is satisfied in the online-changed ladder programs. The fall instruction is executed when the execution condition turns ON→ OFF again.

For information on the QCPU versions that support this function, refer to the User's Manual (Function Explanation, Program Fundamentals) of the CPU module to be used.

Example) The following example shows the difference in the executing status depending on the option setting.

<Program example>



"Execute fall instruction" is selected in the [Options]. "Execute fall instruction" is not selected in the [Options].

### Point

#### ● Universal model QCPU/LCPU

In option setting for Universal model QCPU/LCPU, the item is not selected at default.

#### ● Replacing the instruction with the EGF instruction

The fall instruction execution can be disabled with the EGF instruction, which converts the operation result into a pulse.

For details, refer to the following manual.

📖 MELSEC-Q/L Programming Manual (Common Instructions)

9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15  
WRITING/READING  
DATA

16  
PROTECTING  
DATA

■ FXCPU

● Fall instruction

When Online program change of ladder programs which include fall instructions (LDF/ANDF/ORF) is completed, the fall instructions are not executed regardless of the ON/OFF status of their target devices.

Fall instructions (PLF) are also not executed regardless of the ON/OFF status of their operating condition devices.

To execute a fall instruction, turn the status of its target device/operating condition device ON → OFF again.

Performing Online program change of a ladder block including fall instructions (LDF/ANDF/ORF)	
Target devices are ON	Target devices are OFF
Contacts of the LDF/ANDF/ORF instructions in the ladder block remain OFF.	

Performing Online program change of a ladder block including the PLF instruction	
Operating condition is ON	Operating condition is OFF
Target devices of the PLF instruction in the ladder block do not operate.*1	

\*1 : Operate if the operating condition changes ON → OFF before/after Online program change.

● Rise instruction

When Online program change of ladder programs which include rise instructions is completed, the rise instructions are executed if their target devices/operating condition devices are ON.

- Target rise instructions: LDP, ANDP, ORP, and Pulse operation type application instructions (such as MOVP)

Performing Online program change of a ladder block including rise instructions (LDP/ANDP/ORP)	
Target devices are ON	Target devices are OFF
Contacts of the LDP/ANDP/ORP instructions in the ladder block turn ON for one scan.	Contacts of the LDP/ANDP/ORP instructions in the ladder block remain OFF.

Performing Online program change of a ladder block including pulse operation type application instructions (such as MOVP)	
Operating condition is ON	Operating condition is OFF
The relevant pulse operation type application instruction in the ladder block operates for one scan.	The relevant pulse operation type application instruction in the ladder block does not operate.

Performing Online program change of a ladder block including the PLS instruction	
Operating condition is ON	Operating condition is OFF
Target devices of the PLS instruction in the ladder block do not operate.*1	

\*1 : Operate if the operating condition changes OFF → ON before/after Online program change.

● **Operation result falling pulse instruction**

When Online program change of ladder programs which include operation result falling pulse instructions (MEF) is completed, the operation result falling pulse instructions are not executed regardless of the satisfied/not satisfied status of their executing condition.

To execute an operation result falling pulse instruction, turn the operation result up to it once ON, and then OFF.

Performing Online program change of a ladder block including the MEF instruction	
Executing condition is satisfied	Executing condition is not satisfied
The operation result of the MEF instruction is OFF.	

● **Operation result rising pulse instruction**

When Online program change of ladder programs which include operation result rising pulse instructions (MEP) is completed, the operation result of the operation result rising pulse instruction is ON if the operation result up to it is ON.

Performing Online program change of a ladder block including the MEP instruction	
Operation result up to the MEP instruction is ON	Operation result up to the MEP instruction is OFF
The operation result of the MEP instruction is ON.	The operation result of the MEP instruction is OFF.

## 15.9.5 Considerations of Online program change of SFC programs



The following explains the considerations of Online program change of SFC programs.

● **Online program change for operation outputs/transition conditions**

Online program change cannot be performed after changing programs of multiple operation outputs/transition conditions.

After correcting the program, perform Online program change for each unit of operation output or transition condition.

● **Online program change of SFC diagrams (For CPU modules which do not support Online program change of SFC blocks)**

When a SFC diagram is edited, perform Online program change in unit of file by selecting [Online] ⇒ [Write to PLC] (☞ Section 15.9.2).

● **Online program change of SFC diagrams (For CPU modules which support Online program change of SFC blocks)**

When a SFC diagram is edited, Online program change can be performed in unit of SFC block by selecting [Compile] ⇒ [Online Program Change].

**Restrictions!**

● **Online program change of SFC blocks**

For details of CPU modules which support Online program change of SFC blocks, and restrictions regarding Online program change of SFC blocks, refer to the following manual.

☞ MELSEC-Q/L/QnA Programming Manual (SFC)

SETTING DEVICE COMMENTS	9
SEARCH/REPLACE	10
PRINTING	11
SETTING OPTIONS	12
USING LIBRARIES	13
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION	14
WRITING/READING DATA	15
PROTECTING DATA	16



## 15.9.6 Considerations of each programmable controller series



The following explains the considerations of Online program change for each programmable controller series.

### ■ QCPU (Q mode)/LCPUCPU

Item	Description
Online program change to another station	Online program change to another station can be performed within the accessible range set in the connection destination setting. Take extra caution when performing Online program change to another station.
During boot operation	
Online program change on Redundant CPU	<ul style="list-style-type: none"> <li>When the online program change function is performed during a boot operation in the backup mode, the function is performed on the program memory and transfer source drive of both systems (connective system and target system).</li> <li>When the online program change function is performed during a boot operation in the separate/debug mode, the function is performed on the program memory and transfer source drive of connective system.</li> <li>When a memory card (ROM) or standard ROM is used, all files on the transfer source drive are deleted and changed to files on the program memory. Set the setting on the &lt;&lt;Boot File&gt;&gt; tab of PLC parameter to transfer all files on the transfer source drive to the program memory.</li> </ul>
Deleting a corresponding device from a program	When an instruction is deleted during the OUT instruction execution, or when the device number has been changed and the corresponding device cannot be found in the program, the output status is retained. Perform Online program change after ensuring that sequence programs containing unnecessary coil outputs are OFF.
Online program change while a low-speed execution type program is executed	While a low-speed execution type program is executed, Online program change starts after the program execution. The program execution is suspended during Online program change. However, if "PRG TIME OVER(5010)" keeps occurring while a low-speed execution type program is executed, Online program change cannot be performed. In this case, set the programmable controller CPU to STOP, and increase the constant scan time and low-speed program execution time in PLC parameter, then execute Online program change again.

Item	Description
<p>Allocating memory for Online program change</p>	<ul style="list-style-type: none"> <li>When the number of secured steps exceeds the currently set number during Online program change, the following message is displayed. In this case, set a new number of secured steps.</li> <li>If '0' is set for the number of secured steps on the following message screen, the area for the exceeding amount from the secured steps is reserved and a sequence program is written.</li> <li>The number of secured steps newly set on the following message screen is not displayed on the <u>Program Detail Setting</u> screen of the Write to PLC function.</li> </ul>  <ul style="list-style-type: none"> <li>The message above is not displayed with Basic model QCPU function version A.</li> <li>When re-securing the secured steps for Online program change in the backup mode of Redundant CPU, the steps are secured on the basis of the smaller remaining program memory capacity of either control system or standby system.</li> </ul> <p>Example) When the remaining capacity (step) of the control system is 100 steps and that of the standby system is 50 steps The maximum number of re-secured steps for Online program change is 50.</p>
<p>Error during Online program change</p>	<p>The following message may be displayed during Online program change. Take corrective action by following the message.</p>  <p>If the above error message is displayed, the program in GX Works2 changes back to the uncompiled status. However, the program on the programmable controller CPU may have been changed.</p> <p>In this case, compile the GX Works2 program and verify it against the program on the programmable controller CPU to confirm that these programs match. If the programs do not match, write the program to the programmable controller CPU using the Write to PLC function to match them.</p>
<p>Online program change of a program for which a password is set</p>	<p>When Online program change is performed to a sequence program for which a password is set, the <u>Disable Password</u> screen is displayed. Unlock the password to perform Online program change.</p> <p>Online program change is not possible if a password cannot be unlocked.</p>
<p>When system is configured with Redundant CPU</p>	
<p>Backup mode</p>	<ul style="list-style-type: none"> <li>Online program change is performed on both systems (connective system and target system). However, if the target system fails (communication cannot be established with the target system), Online program change is not performed on both systems.</li> <li>Online program change cannot be performed in units of files to the program file which does not exist on the programmable controller CPU. Perform Online program change in units of files after changing the operation mode of the programmable controller CPU to the separate mode or write data to the programmable controller CPU after switching the programmable controller CPU to STOP.</li> </ul>
<p>Separate mode/debug mode</p>	<p>Online program change is only performed on the programmable controller CPU specified for "Target System" on the <u>Transfer Setup</u> screen.</p>

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

Item	Description															
Online program change to Universal model QCPU	<ul style="list-style-type: none"> <li>• Universal model QCPU has option setting of "Transfer program cache memory to program memory" that allows selection whether to transfer the data of program cache memory to program memory after Online program change. (For option setting, see Section 12.2)</li> <li>• For Universal model QCPU, when a password is registered/changed while the programmable controller CPU is running, the program memory batch transfer is executed. (see Section 15.6)</li> <li>• While program memory is being transferred in Universal model QCPU after Online program change, the following functions cannot be executed.               <ul style="list-style-type: none"> <li>• Online program change (ladder program, SFC program, Structured Ladder/FBD program, ST program, function block)*1</li> <li>• Change TC Setting (when "Write changed program to PLC" is selected)*1</li> <li>• Write to PLC (when the target memory is program memory)*1</li> <li>• Program memory batch transfer</li> <li>• Set as default connection</li> <li>• Change PLC Type</li> <li>• Check Parameter</li> </ul> </li> </ul>															
When using LCPU	<p>Online program change can be performed when the protection status (enable or disable) for "Execution program protection setting" of a block password is set as follows;</p> <p style="text-align: right;">○: Performed, -: Not performed</p> <table border="1" data-bbox="592 864 1409 1021"> <thead> <tr> <th colspan="2" data-bbox="592 864 1007 898"></th> <th colspan="2" data-bbox="1007 864 1409 898">GX Works2</th> </tr> <tr> <th colspan="2" data-bbox="592 898 1007 943"></th> <th data-bbox="1007 898 1209 943">enabled</th> <th data-bbox="1209 898 1409 943">disabled</th> </tr> </thead> <tbody> <tr> <td data-bbox="592 943 810 1021" rowspan="2">Programmable controller CPU</td> <td data-bbox="810 943 1007 976">enabled</td> <td data-bbox="1007 943 1209 976" style="text-align: center;">○</td> <td data-bbox="1209 943 1409 976" style="text-align: center;">○</td> </tr> <tr> <td data-bbox="810 976 1007 1021">disabled</td> <td data-bbox="1007 976 1209 1021" style="text-align: center;">-</td> <td data-bbox="1209 976 1409 1021" style="text-align: center;">○</td> </tr> </tbody> </table>			GX Works2				enabled	disabled	Programmable controller CPU	enabled	○	○	disabled	-	○
		GX Works2														
		enabled	disabled													
Programmable controller CPU	enabled	○	○													
	disabled	-	○													

\*1 : For Universal model QCPU with a serial number whose first five digits are '12012' or higher, the process of the program memory batch transfer can be canceled. (see Section 15.6)

■ FXCPU

Item	Description
Programmable controller CPUs that support Online program change	
Model name	FX2C/FXU series (Version No. V2.1 or later) FX0Nseries (Version No.V1.10 or later) and FX1S/FX1N/FX2N/FX3S/FX3G/FX3GC/FX3U/FX1NC/FX2NC/FX3UC series
Memory type	FX3U/FX3UC series Built-in RAM or optional FLASH cassette (PROTECT switch OFF)
	FX3G series Built-in EEPROM or optional EEPROM memory cassette (PROTECT switch OFF)
	FX3GC series Built-in EEPROM
	FX3S series Built-in EEPROM or optional EEPROM memory cassette (PROTECT switch OFF)
	FX2N series Built-in RAM, optional RAM cassette or optional EEPROM cassette (PROTECT switch OFF)
	FX2NC series Built-in RAM or optional memory board (PROTECT switch OFF)
	FX1NC series Built-in EEPROM
	FX1S/FX1N series Built-in EEPROM or optional memory cassette (PROTECT switch OFF)
	FXU/FX2C series Built-in RAM or optional RAM cassette
	FX0N series Built-in EEPROM
<ul style="list-style-type: none"> <li>When using FX0N, FX1S, FX1N, FXU, FX2N, FX1NC, FX2C or FX2NC</li> </ul>	<ul style="list-style-type: none"> <li>A modified ladder program must not contain added/deleted/changed P and I labels.</li> <li>A target range for Online program change must not contain I labels</li> <li>If a ladder program before or after modification contains the C235 to C255 high-speed counter output instruction (OUT instruction) and the application instructions (MNET, ANRD, ANWR, RMST, RMWR, BLK, and MCDE), the ladder program cannot be changed.</li> <li>A new 1ms retentive timer must not be inserted.</li> <li>If the number of program steps decrease due to deletion of contacts, coils, application instructions, etc., the number of NOPs equivalent to the number of steps removed are added.</li> <li>For the application instruction (EXTR) for FX2N and FX2NC, do not perform Online program change during communication (while the instruction is being activated). Communication may stop if Online program change is performed during communication. If the communication stops, switch the programmable controller CPU from STOP to RUN.</li> </ul>
<ul style="list-style-type: none"> <li>When using FX1S, FX1N, FX1NC, FX2N or FX2NC</li> </ul>	Do not perform Online program change on a function block which contains pulse output instructions (PLSY, PLSR, PWM) or positioning instructions (ZRN, PLSV, DRVI, DRVA) after performing any of the following operations. <ul style="list-style-type: none"> <li>Changing a program of a ladder block which contains instructions described above.</li> <li>Changing a program of a ladder block in front or back of a ladder block which contains instructions described above.</li> <li>Deleting a ladder block in front/back of a ladder block, or adding a ladder block to front/back of a ladder block, which contains instructions described above.</li> </ul>

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

Item	Description
<ul style="list-style-type: none"> <li>When using FX3S, FX3G, FX3U, FX3GC, or FX3UC</li> </ul>	<ul style="list-style-type: none"> <li>A modified ladder program must not contain added/deleted/changed P and I labels.</li> <li>A target range for Online program change must not contain I labels.</li> <li>If a ladder program before or after modification contains the C235 to C255 high-speed counter output instruction (OUT instruction) and the application instructions (SORT2, TBL, RBFM, WBFM), the ladder program cannot be changed.</li> <li>A new 1ms retentive timer must not be inserted.</li> <li>If the number of program steps decrease due to deletion of contacts, coils, application instructions, etc., the number of NOPs equivalent to the number of steps removed are added.</li> <li>Do not perform Online program change for positioning instructions (DSZR, DVIT, ZRN, PLSV, DRVI, DRVA) while the pulse output instruction is being executed. The pulse output stops if the ladder program is online-changed during the pulse output instruction execution. PLSV instruction [without acceleration or deceleration] stops immediately. DSZR, DVIT, ZRN, PLSV [with acceleration and deceleration] DRVI and DRVA instructions stop after decreasing the speed. When these instructions are stopped as a result of Online program change, deactivate the instructions (OFF) and activate them again (ON).</li> <li>For the IVMC, IVCK, IVDR, IVRD, IVWR, and IVBWR inverter communication instructions, do not perform Online program change during communication (while the instruction is being activated). Communication may stop if Online program change is performed during inverter communication. If communication stops, switch the programmable controller CPU from STOP to RUN.</li> <li>Do not perform Online program change on a function block which contains pulse output instructions (PLSY, PWM, and PLSR).</li> <li>The error cannot be detected when performing Online program change even if the ladder program contains the ladder error. After switching the programmable controller CPU from STOP to RUN, the error will be detected.</li> </ul>
<ul style="list-style-type: none"> <li>When using FXU (V3.07 or later) or FX2c<sup>1</sup></li> </ul>	<ul style="list-style-type: none"> <li>A substitute instruction for a new instruction cannot be inserted or replaced in the program.</li> <li>Even a substitute instruction is already written in a program, the function is disabled due to Online program change.</li> <li>The operations of the CMP, ZCP, MOV, ADD, SUB, MUL, DIV, INC, and DEC instructions can be processed at a high speed when word devices specified by digit or index modification are not set to the data. However, the high-speed processing function is disabled when Online program change or insertion is performed.</li> <li>The OFF execution time of the application instructions for FXU (V3.07 or later) and FX2c can be processed at a high speed. However, the high-speed processing function is disabled when Online program change or insertion is performed. The processing time is approximately 60% of that for FXU (V2.30 or earlier).</li> </ul>
<ul style="list-style-type: none"> <li>When using FXU (V2.1 to V2.30)</li> </ul>	<ul style="list-style-type: none"> <li>The application instructions and element numbers added to FXU (V3.07 or later) are written to the programmable controller CPU program memory. The programmable controller CPU assumes that these instructions are non-processing instructions and continues its operation. However, when the programmable controller CPU operating status is changed from STOP to RUN, a program is checked and, as the result, the 'PROG-E LED' indicator flashes. If this happens, correct application instructions and element numbers not supported and batch-transfer the correct program.</li> <li>If an element number specified as an operand of application instructions is not supported by FXU (V2.1 to V2.30), the instruction is written to the programmable controller CPU program memory as it is. In this case, an element number range over operation error occurs. The programmable controller CPU assumes that these instructions are non-processing instructions and continues its operation. However, when the programmable controller CPU operating status is changed from STOP to RUN, a program is checked and, as the result, the "PROG-E LED" indicator flashes. If this happens, batch-transfer the program with the correct operand set to application instructions.</li> </ul>



Item	Description
<ul style="list-style-type: none"> <li>When using FX0N (V1.10 or later)</li> </ul>	<ul style="list-style-type: none"> <li>If a written element number is not supported by FX0N, the message "The changed program contains an instruction or device not supported for Online program change. Online program change operation is disabled for this program" is displayed, and the program change is stopped.</li> <li>The pulse executing type application instruction is not available for FX0N. If this instruction is written, the message "Write failure" is displayed, and the program change is stopped.</li> </ul>
<ul style="list-style-type: none"> <li>When using FX0N, FX1S, FX1N, FXU, FX2N, FX3U, FX1NC, FX2C, or FX2NC</li> <li>When using FX3UC (earlier than V2.00)</li> </ul>	<ul style="list-style-type: none"> <li>Ladder program change is possible for one ladder block at a time and the number of program steps after editing (adding/deleting) must be within 127 (including an NOP immediately after the ladder block and excluding the end circuit). To change programs with more than 127 steps, use the Batch-transfer function.</li> </ul>
<ul style="list-style-type: none"> <li>When using FX3S, FX3G, FX3U, or FX3GC</li> <li>When using FX3UC (V2.00 or later)</li> </ul>	<ul style="list-style-type: none"> <li>Ladder program change of multiple ladder blocks at a time is possible and the changes can be written with Online program change. However, the number of the program steps from the start ladder block to the end circuit after editing must be within 256 steps (including unchanged ladder programs). To change programs with more than 256 steps, use the Batch-transfer function.</li> </ul>
<ul style="list-style-type: none"> <li>When using FX3U/FX3UC (V3.00 or later)</li> </ul>	<ul style="list-style-type: none"> <li>Online program change can be performed when the protection status (enable or disable) for the execution program protection setting of a block password is set same as that for the target programmable controller CPU.</li> </ul>

\*1 : Each deteriorated function can be recovered by switching the programmable controller CPU from STOP to RUN after Online program change.

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

## 15.10 Calculating Memory Size



This section explains how to calculate a memory size required when data in a user-created project is written to the programmable controller CPU.

### 15.10.1 Offline calculation and Online calculation

There are two ways to calculate the memory size: the offline calculation and the online calculation.

(☞ Section 15.10.3)

For FXCPU, only the offline calculation is supported.

(☞ Section 15.10.4)

#### ● Offline calculation

Displays the size of available memory if data are written to the programmable controller CPU after its memory is initialized by such as the PLC memory format function.

In the system file memory size entry field, enter the system file size acquired by the online calculation.

#### ● Online calculation

Displays the size of available memory if selected files are actually written to the programmable controller CPU.

Regarding data written on the programmable controller CPU, the exact size of available memory can be confirmed.


This function is available when GX Works2 is capable of communicating with the programmable controller CPU.

### 15.10.2 Setting target data for memory size calculation (QCPU (Q mode)/LCPU)

Set the target data for memory size calculation.

#### Screen display

Select [Tool] ⇒ [Confirm Memory Size].



**Operating procedure**

1. Set the items on the screen.

Item	Description
Target Memory/Memory Card Type*1	Set the memory of which the size is to be calculated, and memory card type. For details of the memory card application, refer to the following manuals. <ul style="list-style-type: none"> <li>☞ QCPU User's Manual (Hardware Design, Maintenance and Inspection)</li> <li>☞ MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)</li> </ul>
File list	—
Target	Select data of which the size is to be calculated.

\*1 : For High-speed Universal model QCPU and Universal model process CPU, when the standard RAM is selected for "Target Memory", "Extended SRAM Cassette Type" is displayed.

2. Click the **Execute** button.

The result of memory size calculation is displayed. (☞ Section 15.10.3)

**Screen button**

For the buttons on the screen, refer to Section 15.1.

### 15.10.3 Confirming result of memory size calculation (QCPU (Q mode)/LCPU)

Display the result of memory size calculation. Additionally, the offline calculation and online calculation can be switched each other.

**Screen display**

Select [Tool] ⇒ [Confirm Memory Size] ⇒ **Execute** .  
<Offline calculation>

Calculation result section

Target section

Sum total section

Memory status graph section

System file memory size entry field

Target	Target File	File Size	Size
Program	MAIN	5620	5620
Program	MAIN1	15364	15364
Parameter	-	640	644
Symbolic Information	-	10688	10692
System File	-	-	28520
Total Actual Size		-	60188
Available Size		-	6288
Drive Capacity		-	12288

9  
SETTING DEVICE COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS


13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15  
WRITING/READING DATA

16  
PROTECTING DATA

<Online calculation>



Display contents

Item	Description
Target Memory	Display the target memory and IC card type selected on the <u>Confirm Memory Size</u> screen.
Display Option	Select the unit (Byte/Step/%) used for displaying the file size and memory size.
<<Offline>>/<<Online>>	Switch the result display between the offline calculation and online calculation. The result of the offline calculation is displayed just after the execution of the memory size calculation.
Calculation result section	—
Target section	Display the size of the data selected on the <u>Confirm Memory Size</u> screen in units of files.
System file memory size entry field (Offline calculation only)	Enter the memory size of system files. The default value is "0" at the offline calculation. Enter the memory size when using system files. When the exact memory size is required, it can be confirmed by the online calculation. The memory size of system files may differ depending on target memory.
Sum total section	Display the calculation result according to conditions of the target memory, IC card type, and files specified in the <u>Confirm Memory Size</u> screen.
Memory status graph section	Display the calculation result in a circle graph. It is displayed in red when there is no available memory.
Detail	Display the detailed information of the result of the memory size calculation.

Screen button

For the buttons on the screen, refer to Section 15.1.

**Point**

● **File size of symbolic information**

The symbolic information in a project (with labels) is compressed every compilation. Since date information is added every time, the memory size may vary even though the symbolic information itself is not changed.

● **File size units for programmable controller CPUs**

Memory of a programmable controller CPU is occupied by file size units. Therefore, the required memory size may be larger than the actual file size.

For details of file size units, refer to the following manuals.

☞ User's Manual (Function Explanation, Program Fundamentals) of the CPU module to be used

● **Memory size required for parameters and system files**

Parameters/system files consist of multiple files.

The memory size required to store parameters/system files is the total of memory areas occupied by each files.

The following table shows files included in parameters and system files.

However, a sampling trace file and local device are displayed separately.

Target	File	Parameter
Parameters	Parameter file	PLC parameter, network parameter, and redundant parameter
	Boot file	Created when the boot file setting is configured.
	Remote password	Created when the remote password setting is configured.
Sampling trace files	Sampling trace file	For details of each file, refer to the following manuals.
Local devices	Local device	☞ User's Manual (Function Explanation, Program Fundamentals) of the CPU module to be used
	Error history file	
System files	User setting system area	An area specified when the programmable controller CPU memory is formatted. (For formatting programmable controller CPU memory, ☞ Section 20.3)
	PLC user data	User-optional data
	Graphic data for PX Developer	User-created graphic data

● **Used capacity**

The total size of file which is not selected as a target of memory size calculation among the data written in a programmable controller CPU is displayed as "Use Volume".

The used capacity is displayed at the online calculation.

Example) When only Program SUB1 (2500 byte) is selected as the memory size calculation target when Program MAIN (4000 byte) and SUB1 have been written to the programmable controller CPU.

<Result of memory size calculation (Online calculation)>

Target	Target File	File Size	Size
Use Volume			4000
Program	SUB1	2500	2500
System File		0	0

● **Memory capacity**

The memory capacity may be displayed smaller than it really is.

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

## 15.10.4 Confirming result of memory size calculation (FXCPU)

Display sizes and capacities of program and symbolic information calculated offline.  
Displayed values are values when the program and parameters are written to the programmable controller CPU.

### Screen display

Select [Tool] ⇒ [Confirm Memory Size].

**Confirm Memory Size(Offline)**

Status: Compiled

Program Size: 865 Steps

Program Capacity: 15000 Steps \*PLC parameter setting

Error Information: None

Confirm Symbolic Information

Memory Type: Built-in Memory

Symbolic Information Size: 2968 Bytes

Symbolic Information Capacity: 96000 Bytes

Error Information: None

\*To increase the symbolic information capacity, use a large capacity memory type or decrease the setting in PLC parameter for memory capacity.  
\*Program data and symbolic memory information will be written to the same memory device.

Device Comment Points: 51 Points \*PLC writing target

Maximum Comment Points: 100 Points \*PLC parameter setting

(Global Device Comment Registered Points: 56 Points)

Close

### Display contents

Item	Description
Status	Display compilation status. "---" is displayed for Simple projects (without labels).
Program Size	Display the number of current program steps. "---" is displayed when the program is uncompiled.
Program Capacity	Display the value set for "Program Capacity" on the <<Memory Capacity>> tab of PLC parameter of the project.
Error Information	Display error information regarding the program size and capacity.
Confirm Symbolic Information* <sup>1</sup>	Select this to calculate the symbolic information size and capacity.
Memory Type	Select a memory type used on the programmable controller CPU. The symbolic information capacity increases/decreases according to the memory type.
Symbolic Information Size	Display the current symbolic information size in byte unit. "---" is displayed when the program is uncompiled.
Symbolic Information Capacity	Display the symbolic information capacity in byte unit. The symbolic information capacity increases/decreases according to the memory type used on the programmable controller CPU or the memory capacity set in the PLC parameter.
Error Information	Display error information regarding the symbolic information size and capacity.
Device Comment Points* <sup>2</sup>	Display the number of global device comments to be written.
MaximumComment Points* <sup>2</sup>	Display the number of comments set to Comments Capacity in <<Memory Capacity>> of PLC parameter.
(Global Device Comment Registered Points)	Display the total number of global device comments being set.

\*1 : This item is displayed only for FX3U and FX3UC projects with labels.

\*2 : For the FX0S or FX0 project, the items are disabled.

**Point** 

● **File size of symbolic information**

For projects with labels, the symbolic information is compressed each time the memory capacity is calculated or data is written to the programmable controller CPU. Since date information is included when the symbolic information is compressed, its memory capacity may change even though the symbolic information has not been changed.

9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15  
WRITING/READING  
DATA

16  
PROTECTING  
DATA

## 15.10.5 Considerations of calculating memory size

---

The following explains the considerations of calculating memory size.

### 1) Memory size calculation using the offline calculation

A memory size of system files may differ depending on the target memory.

Confirm a memory size of system files using the online calculation and enter the value in the system file memory size entry field.

Without using the value calculated by the online calculation, an accurate result may not be ensured.

### 2) Limit of the number of files

The number of files that can be stored on the programmable controller CPU is limited, however, the memory size calculation ignores the limit.

Set target data so that the number of files including those stored on the programmable controller CPU is less or equal to the limit.

For the number of files which can be stored on a programmable controller CPU, refer to the following manuals.

☞ QCPU User's Manual (Hardware Design, Maintenance and Inspection)

☞ MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)

### 3) Specifying a range of file registers

At the online calculation, when a range smaller than that of file registers written on the programmable controller CPU is specified for the target data of the memory size calculation, the difference from the written file registers is displayed as "Use Volume".

### 4) Calculating a memory size of a Flash card/standard ROM

For High Performance model QCPU, a memory size of a Flash card/standard ROM can be confirmed only using the offline calculation.

For Universal model QCPU, a memory size of a Flash card can be confirmed only using the offline calculation. A memory size of a standard ROM can also be confirmed using the online calculation.

To confirm a memory size required when writing data using the export to ROM function, select 'Program Memory' for "Target Memory".

### 5) When data cannot be written to the programmable controller CPU

When data cannot be written to the programmable controller CPU despite enough available memory, perform Arrange PLC Memory to secure consecutive free memory areas. (Arrange PLC Memory ☞ Section 20.5)

### 6) Calculating a memory size of an ATA card

For Q2MEM-8/16/32MBA, confirm an accurate drive capacity using the online calculation.

Depending on the versions of the Q2MEM-8/16/32MBA and CPU module, the offline calculation may be based on a drive capacity smaller than it really is.

### 7) Calculating a memory size of an SD memory card

The calculation of the memory size of an SD memory card is different between the online calculation and the offline calculation.

For the offline calculation, the memory size is calculated based on the size of the SD memory card selected for "Memory Card Type".

For the online calculation, the memory size is calculated based on the size of the SD memory card inserted on the programmable controller CPU.



## 15.11 Writing/Reading Data to/from Memory Cards

This section explains the functions for writing/reading data to/from a memory card installed on a personal computer.

If a memory card cannot be installed to a programmable controller CPU, the data can be written to/read from the memory card on a personal computer by using this function.

For the system configuration and other information to use a memory card on a personal computer, refer to Section 2.4.

For writing/reading data when the memory card is installed to a programmable controller CPU, refer to  Section 15.1.

### Point

- **Formatting memory cards**

Format the memory card to be used on the programmable controller CPU by selecting [Online] ⇒ [PLC Memory Operation] ⇒ [Format PLC Memory] in GX Works2.

If a memory card is formatted using the function such as Windows® format function it may not be used on the programmable controller CPU.

- **PLC user data**

The PLC user data in the memory card installed on a personal computer cannot write/read to/from GX Works2 directly. Write/read the data using the application such as Windows® Explorer.

For writing/reading the PLC user data in the memory card installed to a programmable controller CPU, refer to Section 15.5.

- **Reading intelligent function module data**

To read intelligent function module data, create the intelligent function module data in the project in advance.

If the intelligent function module data that match the data in the memory card or the image data do not exist, the data are read as data of an unsupported module.


9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA

### 15.11.1 Writing/reading data to/from ATA/SRAM/SD memory cards




\*1: Universal model QCPU (except for Q00UJ, Q00U, Q01U) only  
 \*2: Not supported by L02S and L02S-P.

Write/read data in a memory card (ATA card, SRAM card or SD memory card) installed on a personal computer to/from GX Works2.



#### Screen display

Select [Tool] ⇒ [IC Memory Card] ⇒ [Write IC Memory Card]/[Read IC Memory Card].  
 <Screen for writing IC memory card>



#### Operating procedure

##### 1. Set the items on the screen.

Item	Description
Drive/Path	Click the <b>Browse...</b> button and select a drive on the <b>Browse for Folder</b> screen. If a folder is selected, it cannot be used on a programmable controller CPU.
Title	Enter title of the target memory when writing data to the IC memory card. Display the title of the target memory when reading data from the IC memory card.
Edit Data (Write IC Memory Card only)	Select data to be written from the data list. Display the data list of the open project. (☞ Section 15.1)
IC Memory Data (Read IC Memory Card only)	Select data to be read from the data list. Display the data list of the project in the memory card. (☞ Section 15.1)

2. Click the **Execute** button.


For the Write IC Memory Card function, the specified data are written to the memory card.  
 For the Read IC Memory Card function, the specified data are read from the memory card.

**Screen button**

● **Password Setup...**

Opens the screen to set a password to a specified data when writing data to an IC memory card. The set password is validated after data are written to the IC memory card. For details of setting a password, refer to the following sections.  
 For QCPU (Q mode) (except for High-speed Universal model QCPU and Universal model process CPU) [↗](#) Section 16.2.1  
 For High-speed Universal model QCPU, Universal model process CPU, and LCPU [↗](#) Section 16.3.1


< Create/Change Password (Target Project Data) screen (For QCPU (Q mode)) >



● **Delete Password...**

Opens the screen to cancel a set password when writing data to an IC memory card. The set password is canceled after data are written to the IC memory card. For details of canceling a password, refer to the following sections.  
 For QCPU (Q mode) (except for High-speed Universal model QCPU and Universal model process CPU) [↗](#) Section 16.2.2  
 For High-speed Universal model QCPU, Universal model process CPU, and LCPU [↗](#) Section 16.3.2

< Delete Password (Target Project Data) screen (For QCPU (Q mode)) >



**Point**

● **Canceling a password**

The password cancellation on the Delete Password screen can only be performed while the project is opened after the password is set. To cancel the password after the project is reopened, overwrite the data by writing data to the IC memory card without setting a password.

9	SETTING DEVICE COMMENTS
10	SEARCH/REPLACE
11	PRINTING
12	SETTING OPTIONS
13	USING LIBRARIES
14	SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION
15	WRITING/READING DATA
16	PROTECTING DATA

## ■ Considerations when reading program files with the Read IC Memory Card function

---

Perform the following operations when reading program files with the Read IC Memory Card function.

- **When parameters are written to the IC memory card along with the program files**

Read parameters along with the program files.

- **When parameters are not written to the IC memory card along with the program files**

Before reading the program files, open the project at the time of writing data to the IC memory card. Import the parameters used to write data to the IC memory card from the programmable controller CPU.

## 15.11.2 Writing/reading data to/from SD memory cards (batch save/batch load function)




\*1 : Not supported by L02S and L02S-P.

Read project data saved on an SD memory card with the batch save function of programmable controller CPU, or copy all data to a personal computer.  
 Write project data to an SD memory card in the format which can be used for the batch load function of programmable controller CPU.

For the batch save/batch load function, refer to the following manual.


👉 MELSEC-L CPU Module User's Manual (Function Explanation, Program Fundamentals)



### Screen display

Select [Tool] ⇒ [IC Memory Card] ⇒ [Write to IC Memory Card (Edit and Data Copy)]/[Read from IC Memory Card (Edit and Data Copy)].

<For writing IC memory card (edit and data copy)>



SETTING DEVICE COMMENTS	9
SEARCH/REPLACE	10
PRINTING	11
SETTING OPTIONS	12
USING LIBRARIES	13
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION	14
WRITING/READING DATA	15
PROTECTING DATA	16

**Operating procedure**

**1. Set the items on the screen.**

Item	Description
Drive	Select a drive to write/read data.
Folder name	A folder in the "SaveLoad" folder on the specified drive is displayed. Select a folder to write/read data.
Title	For the write to IC memory card (edit and data copy) function, enter a title of the folder selected for "Folder name". For the read from IC memory card (edit and data copy) function, the title of the folder selected for "Folder name" is displayed.
Edit Data (for Write to IC Memory Card (Edit and Data copy))	Display the data list of the open project. Select data to be written from the data list.
IC Memory Data (for Read from IC Memory Card (Edit and Data Copy))	Display the data list of the project in the memory card. Select data to be read from the data list.
PLC user data save destination	–
Save PLC user data	For the write to IC memory card (edit and data copy) function, select this to write PLC user data. For the read from IC memory card (edit and data copy) function, select this to copy PLC user data to a personal computer.]
Source drive/path to write (for Write to IC Memory Card (Edit and Data Copy))	Click the <b>Browse...</b> button and select a drive/path on which PLC user data to be written on the IC memory card are saved.
Source drive/path to read (for Read from IC Memory Card (Edit and Data Copy))	Click the <b>Browse...</b> button and select a drive/path to save user data.
Target memory (for Write to IC Memory Card (Edit and Data Copy))	Specify a save destination for PLC user data selected for "Source drive/path to write".

**2. Click the **Execute** button.**

For the write to IC memory card (edit and data copy) function, the specified data are written to the memory card.


For the read from IC memory card (edit and data copy) function, the specified data are read from the memory card.

**Screen button**

For the buttons on the screen, refer to Section 15.1 and Section 15.11.1.

● **Copy all data...**

Copies all data saved with the batch save function of programmable controller CPU on the IC memory card to the copy destination specified for "Source drive/path to".



**Point**

● **Considerations for writing data to SD memory card**

Data are written after all files in the target folder are deleted.

## 15.12 Reading Data of Local Devices




\*1 : Universal model QCPU (except for Q00UJ) with a serial number whose first five digits are "12012" or higher only

This section explains how to read local device data from the programmable controller CPU and save the data on a personal computer in CSV format.

### Operating procedure

**1. Select [Online] ⇒ [Local Device Batch Read + Save CSV].**

The Local Device Batch Read + Save CSV screen is displayed.



**2. Enter a name of the file to be saved.**

**3. Click the  button.**

The data of local devices are saved on the personal computer.

9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA

■ Formatting CSV files

Saved CSV files are displayed as shown below when they are opened in spreadsheet software.

Example) The following tables show the settings of this example.

- Setting for programs and file usability

Program name	File usability setting
MAIN	Based on PLC file settings
SUB	Not used
SUB2	Based on PLC file settings

- Setting for local devices

Device name	Device range
M	0 to 49
T	0 to 29
D	100 to 149

<CSV file>

The diagram illustrates the CSV file structure for three programs: MAIN, SUB, and SUB2. It shows the following sections:

- Program MAIN:**
  - Header: [PROGRAM NAME] MAIN, [FILE USABILITY SETTING] Use PLC file setting
  - Device M: [DEVICE NAME] M, followed by columns for device ranges \*0 to \*49. Values are OFF.
  - Device T (Contact): [DEVICE NAME] T(Contact), followed by columns for device ranges \*0 to \*49. Values are OFF.
  - Device T (Coil): [DEVICE NAME] T(Coil), followed by columns for device ranges \*0 to \*49. Values are OFF.
  - Device T (Current): [DEVICE NAME] T(Current), followed by columns for device ranges \*0 to \*49. Values are 0.
- Program SUB:**
  - Header: [PROGRAM NAME] SUB, [FILE USABILITY SETTING] Unused
  - Local devices of program SUB: Indicated by a bracket on the right side of the SUB header section.
- Program SUB2:**
  - Header: [PROGRAM NAME] MAIN, [FILE USABILITY SETTING] Use PLC file setting
  - Device M: [DEVICE NAME] M, followed by columns for device ranges \*0 to \*49. Values are OFF.
  - Device T (Contact): [DEVICE NAME] T(Contact), followed by columns for device ranges \*0 to \*49. Values are OFF.

Annotations and Notes:

- On the left, arrows point to the header rows for each program, identifying 'Program name' and 'File usability setting'.
- On the left, a bracket groups the rows for device M, T(Contact), T(Coil), and T(Current) under the label 'Device names and local device values'.
- On the right, a bracket groups the header rows for programs MAIN, SUB, and SUB2 under the label 'Local devices of program MAIN', 'Local devices of program SUB', and 'Local devices of program SUB2' respectively.
- A dashed box on the right contains the note: 'For T, ST, and C, contacts, coils, and current values are read respectively.'



---

# 16 PROTECTING DATA

This chapter explains the function for protecting the project data and the programmable controller CPU data against such as falsification and leak.

16.1	Functions to Protect Data	16 - 2
16.2	Registering/Changing Password (QCPU (Q mode))	16 - 3
16.3	Registering/Changing Password (File Password 32)	16 - 8
16.4	Registering/Changing Keyword (FXCPU)	16 - 14
16.5	Locking with Security Key	16 - 18

## 16.1 Functions to Protect Data

Q CPU L CPU Remote Head FX

The function to protect data differs according to the target data or target CPU.

The following table shows the list of functions for protecting data.

For "(Structured)" indicated in the Reference column, refer to the following manual.

 GX Works2 Version 1 Operating Manual (Structured Project)

○: Supported ×: Not supported

Target data	Target CPU					Function	Reference
	QCPU (Q mode)	LCPU	Remote I/O module	Communication head module	FXCPU		
Project data	○	○	○	○	○	Security	Section 4.10
	○*1	×	×	×	×	Soft Security Key Management	Section 4.11
POU	○	○	×	×	○	Block Password	Section 4.12
User library	○	○	×	×	○	Change Password	(Structured)
Programmable controller CPU data	○	○	○	○*2	×	Remote Password	Section 6.4
	○*3	×	×	×	×	Password	Section 16.2
	○*1	○	×	×	×		Section 16.3
	×	×	×	×	○	Keyword	Section 16.4
	○*1	×	×	×	×	Soft Security Key Management	Section 16.5
○*4	○*5	×	×	○*6	Execution program protection (Block Password)	Section 4.12	

\*1 : For High-speed Universal model QCPU and Universal model process CPU only

\*2 : Supported by CC IE Field head module only.

\*3 : Not supported by High-speed Universal model QCPU and Universal model process CPU.

\*4 : For a module with the serial number whose first 5 digits are "19012" or higher.

\*5 : For a module with the serial number whose first 5 digits are "18112" or higher.

\*6 : For FX3U/FX3UC version 3.00 or later only

### ■ Differences of functions

The following table shows the differences of functions for protecting data.

○: Applicable ×: Not applicable

Item	Function					
	Security	Soft Security Key Management	Block Password	Change Password	Remote Password	Password/Keyword
Protect project data	○	○	○	×	×	×
Protect programmable controller CPU	×	○	×	×	○	○
Protect library data	×	×	×	○	×	×
Limit users who can disable the protection function	○	○	○	×	○	○
Limit personal computers that can disable the protection function	×	○	×	×	×	×
Transfer the security setting to another personal computer	×	○	×	×	×	×

## 16.2 Registering/Changing Password (QCPU (Q mode))



\*1 : Not supported by High-speed Universal model QCPU and Universal model process CPU.

This section explains how to register a password to protect data in QCPU (Q mode).  
For registering/changing passwords on High-speed Universal model QCPU or Universal model process CPU, refer to Section 16.3.

To register a password, connect GX Works2 to a programmable controller CPU in advance.  
Project data cannot be protected by using this function. Use the project security function to protect the project data. (☞ Section 4.10)

### Point

#### ● Password management

Keep passwords in a secure place.

If a registered password is lost, initialize the programmable controller CPU using the PLC memory format function (☞ Section 20.3) and write the project to the programmable controller CPU.

#### ● Registering a password

- Set a password with 4 characters. For usable characters, refer to "Explanation of Registration Conditions" on the Input Password screen.
- A password can be set for the following items.
  - Program
  - Device comment
  - Device initial value

#### ● Registering/changing/canceling passwords when writing data to an IC memory card

When the Create/Change Password screen or the Delete Password screen is opened from the IC Memory Card Operation screen, passwords of data in the project are registered/changed/canceled. Therefore, "Target Memory" is not displayed.

#### ● Unlocking password

When files with the same name exist on the different drives (such as program memory and standard RAM), the password which is unlocked first is applied to the other file.

- With the same password
  - When one file is unlocked, the other file with the same name is also unlocked.
- With the different password
  - Enter the password to unlock the file with the same name.


9  
SETTING DEVICE COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION15  
WRITING/READING DATA16  
PROTECTING DATA

## 16.2.1 Registering/changing password

Register a password to project data on a programmable controller CPU.

### Screen display


Select [Online] ⇒ [Password/Keyword] ⇒ [New].



**Operating procedure**

1. Select the target memory.
2. Select the target data for registering/changing a password in the data list.
3. Click the **Setting...** button.

The Input Password screen is displayed.




4. Set the items on the screen.

Item	Description
Registration Condition	Select a condition for password check.
Read/Write Protection	Select this to check a password when data are read in addition to "Write Protection".
Write Protection	Select this to check a password when data are written to the programmable controller CPU.
New Password	Enter a new password or a password after change.
Re-enter Password	Enter the new password again for confirmation.

5. Click the **OK** button.

The screen returns to the Create/Change Password screen.

Symbol  is appended to the data for which a password is registered.

Data Type	Data Name	Registration	Registration Conditions
Program	MAIN	 Register	Read/Write Protection
Program	SUB1		
Program	SUB2		

6. Click the **OK** button.

The password is registered or changed for the data on the programmable controller CPU.

**Point**

● **Registering a password**

- A password can be set to multiple data by holding down the **Shift** or **Ctrl** key and selecting the data in the data list.
- A password set to data in the transfer source memory of boot operation remains set in the transfer destination memory.

● **Universal model QCPU**

For Universal model QCPU, when a password is registered/changed while the programmable controller CPU is running, the program memory batch transfer is executed. (☞ Section 15.6)

● **Changing a password**

If a password has been already set for the selected data, the Disable Password screen is displayed. Enter the old password to unlock the password.


9  
SETTING DEVICE COMMENTS  
10  
SEARCH/REPLACE  
11  
PRINTING  
12  
SETTING OPTIONS  
13  
USING LIBRARIES  
14  
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION  
15  
WRITING/READING DATA  
16  
PROTECTING DATA

## 16.2.2 Canceling password

Cancel the password set to the data on the programmable controller CPU.

### Screen display

Select [Online] ⇒ [Password/Keyword] ⇒ [Delete].



### Operating procedure

1. Select data whose password is to be canceled in the data list.

2. Click the **Setting...** button.

The Input Disable Password screen is displayed.  
This screen is not displayed when the password has already been canceled.



3. Enter the password set to the data.

4. Click the **OK** button.

The screen returns to the Delete Password screen.

5. Click the **OK** button.

The password set to the data on the programmable controller CPU is canceled.



## 16.2.3 Unlocking password temporarily


Unlock a password temporarily, set to the data on the programmable controller CPU, by authenticating it.

When the password is unlocked, the corresponding data on the programmable controller CPU can be accessed freely until the project is closed.

This function does not cancel the password set for the data on the programmable controller CPU.

### Screen display

Select [Online] ⇒ [Password/Keyword] ⇒ [Disable].




### Operating procedure

1. Select data whose password is to be temporarily unlocked in the data list.

2. Click the **Setting...** button.

The Input Disable Password screen is displayed.

3. Enter the password set to the data.




4. Click the **OK** button.

The screen returns to the Disable Password screen.

5. Click the **OK** button.

The password set to the data on the programmable controller CPU is temporarily unlocked.



9

SETTING DEVICE COMMENTS

10

SEARCH/REPLACE

11

PRINTING

12

SETTING OPTIONS

13

USING LIBRARIES

14

SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION

15

WRITING/READING DATA

16

PROTECTING DATA

## 16.3 Registering/Changing Password (File Password 32)



\*1 : High-speed Universal model QCPU and Universal model process CPU only.

This section explains how to register a password to protect data in High-speed Universal model QCPU, Universal model process CPU, or LCPU.

To register a password, connect GX Works2 to a programmable controller CPU in advance.

Project data cannot be protected by using this function. Use the project security function to protect the project data. (☞ Section 4.10)

### Point

#### ● Password management

Keep passwords in a secure place.

If a registered password is lost, initialize the programmable controller CPU using the PLC memory format function (☞ Section 20.3) and write the project to the programmable controller CPU.

#### ● Registering a password

- Set a password with the number of characters between 4 and 32. For usable characters, refer to "Explanation of Registration Conditions" on the Input Password screen.
- A password can be set for the following items.
  - Symbolic information
  - Program
  - PLC parameter, network parameter
  - Device comment
  - Device initial value

#### ● Registering/changing/canceling passwords when writing data to an IC memory card

When the Create/Change Password screen or the Delete Password screen is opened from the IC Memory Card Operation screen, passwords of data in the project are registered/changed/canceled. Therefore, "Target Memory" is not displayed.

#### ● Unlocking password

When files with the same name exist on the different drives (such as program memory and standard RAM), the password which is unlocked first is applied to the other file.

- With the same password
  - When one file is unlocked, the other file with the same name is also unlocked.
- With the different password
  - Enter the password to unlock the file with the same name.




## 16.3.1 Registering/changing password

Register a password to project data on a programmable controller CPU.

### Screen display


Select [Online] ⇒ [Password/Keyword] ⇒ [New].



### Operating procedure

1. Select the target memory.
2. Select the target data for registering/changing a password in the data list.
3. Click the **Setting...** button.

The Input Password screen is displayed.

9  
SETTING DEVICE COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE CONTROLLER CPU CONNECTION DESTINATION15  
WRITING/READING DATA16  
PROTECTING DATA






#### 4. Set the items on the screen.

Item	Description
Registration Condition	Select a condition for password check.
Read protection	Select this to check a password when data are read from the programmable controller CPU.
Write protection	Select this to check a password when data are written to the programmable controller CPU.
Read protection/Write protection	Select this to check a password when data are written in addition to "Read protection".
Use the same password for read protection/write protection	Select this to use the same password for the read protection and write protection when 'Read protection/Write protection' is selected in "Registration Condition".
New Password (Read Protection)	Enter a new password or a password after change. The password enables the read protection.
Re-enter Password (Read Protection)	Enter the new password again for confirmation.
New Password (Write Protection)	Enter a new password or a password after change. The password enables the write protection. This item cannot be set when "Use the same password for read protection/write protection" is selected.
Re-enter Password (Write Protection)	Enter the new password again for confirmation. This item cannot be set when "Use the same password for read protection/write protection" is selected.

#### 5. Click the button.

The screen returns to the Create/Change Password screen.

Symbol  is appended to the data for which a password is registered.



Data Type	Data Name	Read Prote...	Write Protection
 Program	MAIN	 Register	 Register
 Device Comment	COMMENT		
 Device Initial Value	MAIN		

#### 6. Click the button.

The password is registered or changed for the data on the programmable controller CPU.

#### Point

##### ● Registering a password

- A password can be set to multiple data by holding down the  or  key and selecting the data in the data list.
- A password set to data in the transfer source memory of boot operation remains set in the transfer destination memory.

##### ● Changing a password


If a password has been already set for the selected data, the Disable Password screen is displayed. Enter the old password to unlock the password.

## 16.3.2 Canceling password

Cancel the password set to the data on the programmable controller CPU.

### Screen display

Select [Online] ⇒ [Password/Keyword] ⇒ [Delete].




### Operating procedure

1. Select data whose password is to be canceled in the data list.
2. Click the **Setting...** button.

The Input Disable Password screen is displayed.

This screen is not displayed when the password has already been canceled.




3. Set the items on the screen.

Item	Description
Delete Condition	Select the condition for password cancellation when the password registration condition of the data selected is "Read Protection/Write Protection".
Disable Password (Read Protection)	Enter the password set to the data.
Disable Password (Write Protection)	

4. Click the **OK** button.  
The screen returns to the Delete Password screen.

5. Click the **OK** button.  
The password set to the data on the programmable controller CPU is canceled.



### 16.3.3 Unlocking password temporarily


Unlock a password temporarily, set to the data on the programmable controller CPU, by authenticating it.

When the password is unlocked, the corresponding data on the programmable controller CPU can be accessed freely until the project is closed.

This function does not cancel the password set for the data on the programmable controller CPU.

#### Screen display


Select [Online] ⇒ [Password/Keyword] ⇒ [Disable].



#### Operating procedure

1. Select data whose password is to be temporarily unlocked in the data list.
2. Click the **Setting...** button.

The Input Disable Password screen is displayed.



3. Set the items on the screen.


Item	Description
Disable Condition	Select the condition for password unlock when the password registration condition of the data selected is "Read Protection/Write Protection".
Disable Password (Read Protection)	Enter the password set to the data.
Disable Password (Write Protection)	

4. Click the **OK** button.

The screen returns to the Disable Password screen.

5. Click the **OK** button.

The password set to the data on the programmable controller CPU is temporarily unlocked.



9  
SETTING DEVICE  
COMMENTS

10  
SEARCH/REPLACE

11  
PRINTING

12  
SETTING OPTIONS

13  
USING LIBRARIES

14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION

15  
WRITING/READING  
DATA

16  
PROTECTING  
DATA

## 16.4 Registering/Changing Keyword (FXCPU)



This section explains how to register a keyword to protect data in FX series programmable controller CPU.

To register a keyword, connect GX Works2 to a programmable controller CPU in advance.

Project data cannot be protected using this function. Use the project security function to protect the project data. (☞ Section 4.10)

For the FX series versions which support this function, refer to the user's manual of the programmable controller CPU to be used.

### Point

#### ● Keyword management

Do not lose the keywords.

If a registered keyword is lost, initialize the programmable controller CPU using the PLC memory clear function (☞ Section 20.4) and write the project to the programmable controller CPU.

### 16.4.1 Registering/changing keyword

#### Screen display

Select [Online] ⇒ [Password/Keyword] ⇒ [New].

## Operating procedure

### 1. Select the function. (FX3s, FX3G, FX3GC, FX3U, and FX3UC only)

Select either the terminable limitation or permanent limitation.

Item	Description
Keyword Protection	Set the keyword for the limitation. Limitation can be canceled.
Permanent PLC Lock	Setting the keyword is unnecessary. Limitation cannot be canceled.

### 2. For "Keyword Protection", set "Keyword Input".

For FX3s, FX3G, FX3GC, FX3U, and FX3UC, select '16 digits' or '8 digits'.

Item	Description
Keyword (8 digits)	Set 8 digits using characters 0-9 and/or A-F. This item can be set when "Keyword Protection" is selected and '8 digits' is selected. The Read/Write Protection is available.
Keyword (16 digits)	Set 16 digits using characters 0-9 and/or A-F. This item can be set when "Keyword Protection" is selected and '16 digits' is selected. This item is supported only by FX3s, FX3G, FX3GC, FX3U, and FX3UC. The protection level can be selected from "Read/Write Protection", "Write Protection", and "All Online Operation Protection".
Customer Keyword*1	Set 16 digits using characters 0-9 and/or A-F. This item can be set when "Keyword (16 digits)" is set and "Customer keyword is used (16 digits)" is selected. This item is supported only by FX3s, FX3G, FX3GC, FX3U, and FX3UC. The protection level is the same as that for "Keyword (16 digits)".

\*1 : Set this item combining with "Keyword (16 digits)" as necessary. The customer keyword can be disabled temporarily but it cannot be changed or canceled.

### 3. Select the protection level.

For the programmable controller CPU other than FX3s, FX3G, FX3GC, FX3U, and FX3UC, "Protection Level" is fixed to 'Read/Write Protection'.

Item	Description
Read/Write Protection	Limit the read, write, and verify operations.
Write Protection	Limit the write operation.
All Online Operation Protection	Limit the read, write, verify, and device monitor operations.

### 4. Click the button.

9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA


## 16.4.2 Canceling keyword

---

Cancel the keyword set to the data on the programmable controller CPU.

### Screen display


Select [Online] ⇒ [Password/Keyword] ⇒ [Delete].



### Operating procedure

**1. Enter the keyword being registered.**

Enter only the first 8 digits when 'Keyword Protection (8 digits)' is registered. The customer keyword cannot be canceled.

**2. Click the  button.**

The keyword registered on the programmable controller CPU is canceled.



### 16.4.3 Unlocking keyword temporarily


Unlock a password temporarily, set to the data on the programmable controller CPU, by authenticating it.

When the keyword is unlocked, the corresponding data on the programmable controller CPU can be accessed freely until the project is closed.

This function does not cancel the keyword set for the data on the programmable controller CPU.

#### Screen display

Select [Online] ⇒ [Password/Keyword] ⇒ [Disable].



#### Operating procedure

##### 1. Set the items on the screen.

Item	Description
Keyword Disable	Select this to unlock the keyword temporarily.
Keyword	Enter the keyword registered to the programmable controller CPU. Enter only the first 8 digits when 'Keyword Protection (8 digits)' is registered. When the customer keyword is registered, the keyword can be disabled by entering the customer keyword.*1
Keyword Protect*1	Select this to get the keyword unlocked status to the locked status.

\*1 : FX3S, FX3G, FX3GC, FX3U, and FX3UC only

##### 2. Click the button.

The selected operation (Keyword Disable/Keyword Protect) is executed.

## 16.5 Locking with Security Key




\*1 : High-speed Universal model QCPU and Universal model process CPU only

This section explains how to lock the programmable controller CPU with a security key and limit the access.

For creating, importing/exporting, or deleting security keys, refer to Section 4.11.

### Screen display


Select [Online] ⇒ [Soft Security Key Management]



### Display contents



Item	Description
Key Information Registered in the Personal Computer	Display the information of selected security key. (☞ Section 4.11.1)
<<CPU>>	Display the screen to lock/unlock the programmable controller CPU.
Connection Destination Channel List	—
Connection Interface	Display the interface on the personal computer and the interface on the programmable controller CPU connected to the personal computer.
Network No.	Display the network number of the connection destination.
Station No.	Display the station number of the connection destination.
PLC Type	Display the programmable controller type of the connection destination.
Security Key Information	—
Name	Display the name of the security key which is used to lock the programmable controller CPU.
Creation Date	Display the date of creation of the security key which is used to lock the programmable controller CPU.
Explanation	Display the information when the cursor is placed on the button on the screen.

## Operating procedure

1. Select the security key to lock the programmable controller CPU from "Key Information Registered in the Personal Computer".
2. Click the  button.

The programmable controller CPU is locked with the selected security key.

## Screen button

-  Acquires the security key information of the programmable controller CPU in the connection destination and displays it.
-  Unlocks the locked programmable controller CPU.

## Point

- **Considerations when locking programmable controller CPU**  
The programmable controller CPU cannot be locked with the security key when it is in RUN status. Set the programmable controller CPU to STOP status to lock it with the security key.

9  
SETTING DEVICE  
COMMENTS10  
SEARCH/REPLACE11  
PRINTING12  
SETTING OPTIONS13  
USING LIBRARIES14  
SETTING PROGRAMMABLE  
CONTROLLER CPU  
CONNECTION DESTINATION15  
WRITING/READING  
DATA16  
PROTECTING  
DATA



# 17 MONITORING

This chapter explains how to monitor the execution status of the programmable controller CPU connected to the personal computer.

17.1	Monitoring Function	17 - 2
17.2	Monitoring Programs	17 - 7
17.3	Batch Monitoring Devices/Buffer Memory	17 - 8
17.4	Monitoring Program List	17 - 12
17.5	Monitoring Interrupt Program List	17 - 15
17.6	Registering and Monitoring Devices	17 - 16
17.7	Monitoring Intelligent Function Modules	17 - 26
17.8	Starting/Stopping Monitoring All Windows	17 - 26
17.9	Using Realtime Monitor Function	17 - 27

## 17.1 Monitoring Function

Q CPU L CPU Remote Head FX

This section explains how to monitor programs.

The monitoring function is a function used to check operating status of a programmable controller CPU by connecting a personal computer and a programmable controller CPU.

### 17.1.1 Starting/stopping monitoring

The monitoring function can be started/stopped by any of the following menus.

- [Online] ⇒ [Monitor] ⇒ [Start Monitoring (All Windows)]/[Stop Monitoring (All Windows)]
- [Online] ⇒ [Monitor] ⇒ [Start Monitoring]/[Stop Monitoring]
- [Online] ⇒ [Watch] ⇒ [Start Watching]/[Stop Watching]

The menu to start/stop monitoring differs according to the monitoring type.

The following table shows the monitoring type to which the execution is applied by each menu.

For (Simple), (Structured), and (Intelligent) indicated in the Reference column, refer to the following manuals respectively:

(Simple) ... GX Works2 Version 1 Operating Manual (Simple Project)

(Structured) ... GX Works2 Version 1 Operating Manual (Structured Project)

(Intelligent) ... GX Works2 Version 1 Operating Manual (Intelligent Function Module)

○: Applicable ×: Not applicable

Monitoring type	Menu			Reference
	Start/Stop monitoring (All windows)	Start/stop monitoring*1	Start/stop watching*1	
Program monitoring	○	○	×	Section 17.2 (Simple) (Structured)
Device/buffer memory batch monitoring	○	○	×	Section 17.3
Program list monitoring	○	×*2	×	Section 17.4
Interrupt program monitoring	○	×*2	×	Section 17.5
SFC all block batch monitoring	○	○	×	(Simple)
Watch	○	×	○	Section 17.6
Intelligent function module monitoring	○	×	○	(Intelligent)

\*1 : Applied to active windows.

\*2 : The monitoring can be started/stopped by the buttons on the screen.

**Point**

● **Monitor values**

The values at execution of END instruction are displayed.  
To display the monitor values of ladder program or SFC program in process, use the Monitor Condition Setting function.

● **When monitoring multiple projects using a single personal computer**

- When monitoring multiple projects using a single personal computer, and if an communication error occurs in one of the projects, the monitoring speed of the other projects may become slow.  
The operation will be back to normal when the error message displayed in the project in which the communication error occurred is closed.
- When monitoring multiple projects using a single personal computer, the following functions may not be performed normally.
  - Program list monitoring
  - Interrupt program list monitoring
  - Monitoring condition setting
  - Monitoring stop condition setting
  - Scan time measurement

● **Monitoring devices that cannot be monitored**

When devices that cannot be monitored are specified in a program monitoring, watch, or device/buffer memory batch monitoring execution, the monitoring result is displayed as "FFFFH(-1)".

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

## 17.1.2 Monitoring status

Monitoring status is displayed on the tool bar during monitoring on the work window. Monitoring status bar is hidden when monitoring all items is stopped.


### Screen display

#### At the start of monitoring


##### ● When connected to a programmable controller CPU

Items displayed on the screen differ according to the programmable controller type. The following are the examples of the Monitor Status screen for High Performance model QCPU and Redundant CPU.

<High Performance model QCPU>




<Redundant CPU>



##### ● During simulation




















Items displayed on the screen differ according to the programmable controller type. The following is the example of the Monitor Status screen for High Performance model QCPU.

<High Performance model QCPU>





## Display contents

Item	Description
Connection status	Display the connection status between a programmable controller CPU and personal computer in which the simulation function is started.
	When connected to a programmable controller CPU During simulation
RUN/STOP status	Display the programmable controller CPU status operated by the key switch on the programmable controller CPU or the remote operation from GX Works2.
	RUN
	STOP
 *1	STEP-RUN
ERR. status	Display the ERR. LED status of the programmable controller CPU. The PLC Diagnostics screen is displayed when the icon is clicked. PLC diagnostics screen (  Section 21.1)
	ERR. is OFF.
	ERR. is ON.
	ERR. is flashing.
USER status*1,*2	Display the USER LED status of the programmable controller CPU. The PLC Diagnostics screen is displayed when the icon is clicked. PLC diagnostics screen (  Section 21.1)
	USER is OFF.
	USER is ON.
	USER is flashing.
Control system/standby system status	Display the control system/standby system status of Redundant CPU.
	Control system
	Standby system
	Unknown
System A/system B status	Display the system A/system B status of Redundant CPU.
	System A
	System B
	Unknown
Status of device test with execution condition*1	Display the status of the device test with execution condition.
	Flash when data on the programmable controller CPU and one being edited are not identical. The registered information on the programmable controller CPU is read out when the monitor is restarted. Return to ON when the both data are identical.
Execution program status*3	RAM, EPROM, EEPROM (FX3UC : FLROM)
Scan time status	Display the maximum scan time of the monitor target programmable controller CPU. For QCPU (Q mode), the display is given in units of 0.1ms.
Local device monitoring target selection field*1,*2	Select the name of the program for which local device monitoring is performed. If "Auto setting" is selected, the local devices in the program on the active screen are automatically monitored. Not displayed by Q00UJ.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22




SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

Item	Description
Unsupported instructions	Display whether an unsupported instruction exists or not when the simulation function is executed. The <u>Instructions Unsupported by Simulation</u> screen is displayed when the icon is clicked. Checking unsupported instruction/device (  Section 18.3)
	Unsupported instruction exists.
	Unsupported instruction does not exist.

\*1 : Not supported by FXCPU.

\*2 : Not supported by communication head module and remote I/O module.

\*3 : Not supported by QCPU (Q mode)/LCPU.

**Point** 

● **Operation of the PLC Memory Clear function during the monitoring of local devices**

When the "Clear Device's whole Memory" operation is executed during the monitoring of local devices, local devices are cleared in the programs selected in the 'local device monitoring target selection field' on the monitoring status bar.

## 17.2 Monitoring Programs




This section explains how to monitor the execution status of the programmable controller CPU. The monitored items differ according to the programming language used.

For details, refer to the following manuals.

- ☞ GX Works2 Version 1 Operating Manual (Simple Project)
- ☞ GX Works2 Version 1 Operating Manual (Structured Project)

### Screen display

Select [Online] ⇒ [Monitor] ⇒ [Start Monitoring] (🖨️).



### Point

#### ● Monitor other programs during monitoring

By selecting the following option, the monitor can be started automatically when opening the other program editors while displaying the monitoring status. However, unconverted or uncompiled programs cannot be started monitoring. [Tool] ⇒ [Option] ⇒ "Monitor" ⇒ "Common" ⇒ "Start monitoring if converted or compiled program is opened during monitoring"

# 17.3 Batch Monitoring Devices/Buffer Memory

Q CPU L CPU Remote Head FX


This section explains how to monitor devices/buffer memory in batch.

For device batch monitoring, specify the target devices.

For buffer memory batch monitoring, specify the address of the intelligent function module.

## Screen display

Select [Online] ⇒ [Monitor] ⇒ [Device/Buffer Memory Batch] (Dev).



## Operating procedure


- Set the items on the screen.

Item	Description
Device	Select this to monitor devices in batch.
Device Name	Select this to enter the name of a device to be monitored in batch.
T/C Set Value Reference Program*1	Specify the program whose setting value is to be displayed when monitoring timer (T) or counter (C) in batch.
Buffer Memory	Select this to monitor buffer memory in batch.
Module Start	Enter the start I/O number of the intelligent function module in hexadecimal number. <ul style="list-style-type: none"> <li>• For FXCPU Enter the block number of the special extension device. (0 to 7) FX0N-3A, FX2N-2AD and FX2N-2DA cannot be the target of the buffer memory monitor.</li> <li>• For Multiple CPU system configuration Specify the programmable controller CPU to be monitored. CPU No. 1: 3E00, CPU No. 2: 3E10, CPU No. 3: 3E20, CPU No. 4: 3E30</li> </ul>
Address	Enter the address of buffer memory to be monitored in decimal or hexadecimal.
Decimal/Hexadecimal selection	Select the address input format (decimal or hexadecimal).
Display format	Switch the display format of the monitoring values. Save and read batch monitor display format files.
Device comment display	Select whether to display device comments. When displaying device comments, device comments referred in the selected program are displayed.

\*1 : Not supported by communication head module and remote I/O module.

**Screen button**

- **Reference...** (Not supported by remote I/O module)  
Displays the T/C Set Value Reference Program screen.



**Operation**

- **Set the items on the screen.**

Item	Description
Program Reference Selection/POU Reference Selection	Set the reference of POU. In Simple project, selection is fixed at "Project".
	Project Select this to reference a program in the project.
	User Library Select this to reference a POU in the user library by clicking [v].
Program/POU_Pool	Select the POU to be referenced. Projects selected by "POU Reference Selection" or POU in "User Library" is displayed. Items to be displayed are as shown below. Simple project : Program file Structured project : POU


- **Modify Value...**  
Displays the Modify Value screen. (☞ Section 19.1)

● Details...

Displays the Display Format screen.

Set the monitor display format.

The screen displays the settings as an example. Setting is possible while confirming the display.



**Operation**

- Set the items on the screen.

Item		Description
Monitor Format		Select the monitor format.
Bit		Select this to monitor bits in unit of one point.
Bit and Word		Select this to monitor both bits and words in unit of one point.
Bit Multi-point		Select this to monitor bits in unit of multiple points.
Word Multi-point		Select this to monitor words in unit of multiple points.
Display		Select the data type of the value stored in word device/buffer memory when "Bit and Word" or "Word Multi-point" is selected for "Monitor Format".
16bit Integer		Select this to monitor in 16-bit integer.
32bit Integer		Select this to monitor in 32-bit double word (signed) integer.
Real Number (32Bit)		Select this to monitor in 32-bit (single-precision real number).
Real Number (64Bit)		Select this to monitor in 64-bit (double-precision real number).
ASCII		Select this to monitor in character string.
Value		Select either decimal or hexadecimal display format for 16-bit or 32-bit integer.
DEC		Select this to monitor in decimal number.
HEX		Select this to monitor in hexadecimal number.
Bit Order		Select the alignment sequence of bits to be monitored when "Bit and Word" or "Bit Multi-point" is selected for "Bit".
0-F		Select this to monitor bit information from the left to the right on the screen. This method is appropriate for monitoring bit devices.
F-0		Select this to monitor bit information from the right to the left on the screen. This method is appropriate for monitoring word devices or buffer memory.
Switch No. of Points*1		Select the number of points to be monitored per row.
16 Points (8 Points)		Select this to monitor 8 points of word device or 16 points of bit device per row.
10 Points (10 Points)		Select this to monitor 10 points per row.

\*1 : For FXCPU, the display can be switched between 8 points and 16 points when an X/Y device is selected.

- **Open...**  
Utilizes the saved display formats.
- **Save...**  
Saves the current display format in the file.

**Point**

- **Opening multiple Device/Buffer Memory Batch Monitor screens**  
The maximum number of Device/Buffer Memory Batch Monitor screens that can be opened is 64. A screen number is appended at the end of the screen title.



- **Monitoring time when multiple Device/Buffer Memory Batch Monitor screens are opened**  
When the multiple Device/Buffer Memory Batch Monitor screens are opened, lead time to start monitoring and monitoring intervals may become longer.
- **Accessing multiple CPU shared memory**  
Multiple CPU shared memory of multiple CPU system can be monitored only by the Device/Buffer Memory Batch Monitor function.

**Restrictions**

- **FXCPU that support the buffer memory batch monitor function**  
FX1N, FX1NC, FX2N, FX2NC, FX3G, FX3GC, FX3U, and FX3UC support the buffer memory batch monitor function.

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX


# 17.4 Monitoring Program List



This section explains how to monitor the processing time of programs being executed.

## Screen display

Select [Online] ⇒ [Monitor] ⇒ [Program List].



## Display contents

Item	Description
Entire Scan Time	Display the time set in the WDT setting of PLC RAS setting of PLC parameter.
Monitoring Time	Display each monitoring time of the scan program, initial program, and low-speed program. When the scan time exceeds these time, a programmable controller CPU error occurs.
Total Scan Time	Display the total time of each item of "Detail of Scan Time for Scan Execution".
Detail of Scan Time for Scan Execution	Display the processing time of each item. "Constant Wait" displays the waiting time of the constant scan when the constant scan is set. When the low-speed program execution time is also set, however, it displays '0.000' ms.
Execution Status of Programs	Display the execution status of programs specified in the program setting of PLC parameter.
Program	Display the program names in the input order in PLC parameter.
Execution	Display the execution type of the programs specified in PLC parameter.
Scan Time	Display the actual scan time (current value). Display '0.000' ms in the program stop (standby) status.
Execution Count	Display the number of executions, counted from 0 at the point of turning the programmable controller CPU to the RUN status. After reaching 65536, it returns to 0. It is stored even after the program stops.

## Screen button

- **Start Program...**  
Displays the Start Program screen. (☞ ■ Starting programs)
- **Stop Program...**  
Displays the Stop Program screen. (☞ ■ Stopping programs)



**Point**


● **Program list monitor**

In a simulation, only "Execution Count" in "Execution Status of Programs" is monitored.

■ **Starting programs**


**Screen display**

Select Program List screen ⇒ 



**Operating procedure**

1. Set the items on the screen.

Item	Description
Program Name	Select the name of a program to be started from  .
Start Mode	Select the execution type.
Scan execution	Set the execution type to the scan execution.
Low speed execution	Set the execution type to the low-speed execution.
Fixed scan execution	Set the execution type to the fixed scan execution. The time input area in "Fixed scan execution" displays the value set in "Fixed Scan Interval" on the <<Program>> tab of PLC parameter. Change it as necessary.

2. Click the  button.

The selected program is started.

**Point**

● **Starting programs**

A program can be started when using one of the following programmable controller CPUs.

- High Performance model QCPU
- Process CPU
- Redundant CPU
- High-speed Universal model QCPU\*1
- Universal model process CPU\*1


\*1: A CPU module whose function version is B and first 5 digits of the serial No. are "18112" or higher.

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

## ■ Stopping programs


### Screen display

Select **Program List** screen ⇒ 



### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Program Name	Select the name of a program to be stopped from  .
Stop Mode	Select the stop mode.
Stop output after stop	<ul style="list-style-type: none"> <li>For the scan execution type program, turn outputs OFF (Non-execution processing) at the next scan. The program is set as the standby status after the subsequent scan. (The same behavior as the POFF instruction)</li> <li>For the low-speed execution type program, stop its execution, and turn outputs OFF at the next scan. The program is set as the standby status after the subsequent scan.</li> </ul>
Hold output after stop	Place the scan execution type program in the standby status, and store the output of the OUT instruction.



#### 2. Click the button.

The selected program turns in the stopped status.

### Point

#### ● Stopping programs

- A program can be started when using one of the following programmable controller CPUs.
  - High Performance model QCPU
  - Process CPU
  - Redundant CPU
  - High-speed Universal model QCPU\*1
  - Universal model process CPU\*1

\*1 : A CPU module whose function version is B and first 5 digits of the serial No. are "18112" or higher.
- When "Stop output after stop" is selected, outputs may not turn OFF depending on instructions. For details, refer to the section explains the POFF instruction in the following manuals.
  -  MELSEC-Q/L Programming Manual (Common Instructions)
  -  MELSEC-Q/L Structured Programming Manual (Common Instructions)


# 17.5 Monitoring Interrupt Program List

Q CPU
L CPU
Remote
Head
FX

This section explains how to display the number of executions of interrupt programs used in a program.

## Screen display

Select [Online] ⇒ [Monitor] ⇒ [Interrupt Program List].



Interrupt pointer monitor list

## Operating procedure

- Input the interrupt pointer number whose execution counts are to be displayed in "Interrupt Pointer".

## Display contents

Item	Description
Interrupt pointer monitor list	-
Interrupt Pointer	Display the interrupt pointer entered in "Interrupt Pointer" on the top.
Execution Count	Start counting when the programmable controller CPU turns to the RUN status and display the execution counts. When reaching 65536, returns to 0.
Comment	Display the device comment.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

## 17.6 Registering and Monitoring Devices

Q CPU L CPU Remote Head FX

This section explains how to monitor devices.

### 17.6.1 Registering and monitoring devices

Register multiple devices/labels in single screen and monitor them simultaneously.

#### Screen display

Select [View] ⇒ [Docking Window] ⇒ [Watch 1] to [Watch 4].

Device/Label	Current Value	Data Type	Class	Device	Address	Comment
X0	--	Bit		X0	%IX0	ModuleReady
POU_01/counter	--	Bit	VAR	M8191	%MX0.8...	
DY0	--	Bit		DY0	%QX1.0	
pop3	--	Bit	VAR_GLOBAL_CONSTANT	SM401	--	

#### Display contents

Item	Description
Device/Label	Display the device/label name.
Current Value	Display the current value of the device/label. The display format (decimal/hexadecimal) of the current value can be switched. (☞ Section 17.6.3) The display format (number display (1/0)/ ON/OFF display/ symbol display (●/○)) of the current value of bit device can be switched.
Binary Value	Display the current value of the device/label in binary.
Octal Value	Display the current value of the device/label in octal.
Decimal Value	Display the current value of the device/label in decimal.
Hexadecimal Value	Display the current value of the device/label in hexadecimal.
Float Value	Display the current value of the device/label in real number.
String Value	Display the current value of the device/label in character string.
Time Value	Display the current value of the device/label in time.
Data Type	Display the data type of the device/label.
Class	Display the class of the label. Nothing is displayed for the devices.
Device	Display the device, or device assigned to the label. For the labels with the class of VAR_CONSTANT or VAR_GLOBAL_CONSTANT, the initial value set on the label editor is displayed.
Address*1	Display the address of the device/label.
Comment	Display the comments of the device/label. For devices, global device comments are displayed.*2
Forced I/O Status	Display the forced ON/OFF status of the X/Y devices registered on the <u>Forced Input Output Registration/Cancellation</u> screen. For the X/Y devices which are not registered to the <u>Forced Input Output Registration</u> screen or other than X/Y devices, "--" is displayed

\*1 : For Structured projects only

\*2 : Not displayed for Basic model QCPU because global device comment is not supported.

## Operating procedure

### 1. Select a row to be edited, and then click its "Device/Label" column.

The cell becomes the editing status.

Device/Label	Current Value	Data Type	Class	Device	Address	Comment
X0	--	Bit		X0	%IX0	ModuleReady
Y4	--	Bit		Y4	%QX4	CountEnable
D0	--	Word[Signed]		D0	%MW0.0	
M0	--	Bit		M0	%MX0.0	QD62Ready

### 2. Enter a device/label to be registered.

For local labels, enter as 'program (program block) name/label name'.

Example) POU\_01/counter

Device/Label	Current Value	Data Type	Class	Device	Address	Comment
X0	--	Bit		X0	%IX0	ModuleReady
Y4	--	Bit		Y4	%QX4	CountEnable
D0	--	Word[Signed]		D0	%MW0.0	
M0	--	Bit		M0	%MX0.0	QD62Ready
POU_01/counter						

### 3. Press the **Enter** key.

The entered device/label is registered.

When the device/label is registered, its relevant information such as data type and class is registered automatically.

Device/Label	Current Value	Data Type	Class	Device	Address	Comment
X0	--	Bit		X0	%IX0	ModuleReady
Y4	--	Bit		Y4	%QX4	CountEnable
D0	--	Word[Signed]		D0	%MW0.0	
M0	--	Bit		M0	%MX0.0	QD62Ready
POU_01/counter	--	Word[Signed]	VAR	D12287	%MW0.12287	

### 4. Select [Online] ⇒ [Monitor] ⇒ [Start Watching].

The current value of the registered device/label is displayed.

#### Point

#### ● Registered devices/labels on Watch windows

Once devices/labels are registered and the project is saved, registered devices/labels are displayed in registered status when the project is opened again.

#### ● Deleting registered devices/labels

A device/label can be deleted by right-clicking the specified cell and selecting [Delete] from the shortcut menu or pressing the **Delete** key.

#### ● Sorting items on Watch window

Items in the columns can be sorted in the ascending/descending order by clicking each column header.

To sort the items by the "Current Value" column, display all registered devices. When the items are sorted without displaying the registered devices, scroll the screen.

### ■ Changing order of columns

Change the order of the columns by dragging and dropping a header except for "Device/Label" column.

Device/Label	Device	Current Value	Data Type	Class	Address	Comment
X0	X0	--	Bit		%I0	ModuleReady
Y4	Y4	--	Bit		%Q4	CountEnable
D0	D0	--	Word(Signed)		%MW...	
M0	M0	--	Bit		%MX0.0	QD62Ready
POU_01/counter	D12287	--	Word(Signed)	VAR	%MW...	



Device/Label	Device	Current Value	Data Type	Class	Address	Comment
X0	X0	--	Bit		%I0	ModuleReady
Y4	Y4	--	Bit		%Q4	CountEnable
D0	D0	--	Word(Signed)		%MW...	
M0	M0	--	Bit		%MX0.0	QD62Ready
POU_01/counter	D12287	--	Word(Signed)	VAR	%MW...	

### ■ Displaying/hiding columns

Display/hide the columns by right-clicking a header on the Watch window and select/clear the items to be displayed/hidden.

The column of the selected item is inserted where the mouse is right-clicked.

When the column header of "Device/Label" is right-clicked, the column of the selected item is inserted on the right side.

Device/Label	Device	Current Value	Data Type	Device/Label	Comment
X0	X0	--	Bit		ModuleReady
Y4	Y4	--	Bit		CountEnable
D0	D0	--	Word(Signed)		
M0	M0	--	Bit		QD62Ready
POU_01/counter	D12287	--	Word(Signed)		



Device/Label	Device	Current Value	Binary Value	Octal Value	Decimal Value	Hexadecimal Value	Float Value	Device/Label	Data Type	Class
X0	X0	--	--	--	--	--	--		Bit	
Y4	Y4	--	--	--	--	--	--		Bit	
D0	D0	--	--	--	--	--	--		Word(Signed)	
M0	M0	--	--	--	--	--	--		Bit	
POU_01/counter	D12287	--	--	--	--	--	--		Word(Signed)	VAR

## 17.6.2 Registering devices


Register devices to the Watch window.

### ■ Registering devices/labels from program editor/label editor using shortcut menu

Register devices/labels from the program editor/label editor using a shortcut menu. Multiple devices/labels can be registered in batch by selecting a range.

#### Operation

1. Select devices/labels to be registered to the Watch window.
2. Right-click and select [Register to Watch] from the shortcut menu.  
The devices/labels are registered to the Watch window.



#### Point


- **Registering devices/labels from the label editor**  
When registering devices/labels to the Watch window from the label editor, right-click a target row and select [Register to Watch] from the shortcut menu.
- **Registering device/labels with shortcut menu**  
With the shortcut menu, devices/labels are registered to the foreground Watch window.  
When two or more Watch windows are displayed in the foreground, devices/labels are registered to the Watch window with the younger Watch window number.  
When the Watch window is not displayed, the Watch window 1 is opened and devices/labels are registered to it.

## ■ Registering devices/labels from program editor/label editor with drag-and-drop operation

Register devices/labels from the program editor/label editor with the drag-and-drop operation. Multiple devices/labels can be registered in batch by selecting a range.

### Operation

- Select devices/labels to be registered to the Watch window, and drag and drop them on to the Watch window.




### Point

#### ● Drag-and-drop operation of devices/labels to Watch window

The drag-and-drop operation of devices/labels to the Watch window can be performed only from the program editor or the label editor.

#### ● Drag-and-drop operation of devices/labels from ladder editor

The drag-and-drop operation of devices/labels can be performed when the cursor is changed to  as it is moved to the border of the selected range.



## ■ Registering devices/labels at cursor position automatically


Register devices/labels in the ladder block at the cursor position to the Watch window automatically by setting the option.

When this option is set, "(Ladder/SFC Automatic Registration)" is displayed on the title bar of Watch window.

The automatic registration to the Watch window can be executed when the program is written in Ladder Diagram or Sequential Function Chart.

### Operation

1. Specify the automatic registration destination for "Setting for Automatic Registration to Watch Window" under [Tool] ⇒ [Options] ⇒ "Monitor" ⇒ "Ladder/SFC".
2. Open the Watch window which is specified as an automatic registration destination.
3. Select [Online] ⇒ [Watch] ⇒ [Start Watching].
4. Move the cursor to the ladder block which is to be registered to the Watch window. Devices/labels in the ladder block at the cursor position are displayed on the Watch window which is specified as an automatic registration destination. The displayed devices/labels are overwritten with the devices/labels in the ladder block to which the cursor is moved.



17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I


INDEX

## ■ Inserting next devices/labels

Insert a row of the next device/label right after the row of the selected device/label.  
When a device is selected, the device whose device number is incremented is inserted.  
When a label is selected, the label registered in the next row on the label editor is inserted.

### Operating procedure

#### 1. Select a device/label on the Watch window.




Device/Label ▲	Current Value	Device	Data Type	Class	Address	Comment
X0	--	X0	Bit		%I0	ModuleReady
Y4	--	Y4	Bit		%Q4	CountEnable
D0	--	D0	Word[Signed]		%MW...	
M0	--	M0	Bit		%M0.0	QD62Ready
POU_01/counter	--	D12283	Word[Signed]	VAR	%MW...	

#### 2. Right-click and select [Insert Next Object] from the shortcut menu.

Or press the **Ctrl** + **F3** keys.

The next device/label is inserted.




Device/Label ▲	Current Value	Device	Data Type	Class	Address	Comment
X0	--	X0	Bit		%I0	ModuleReady
X1	--	X1	Bit		%I1	CounterValueMax[No.1]
Y4	--	Y4	Bit		%Q4	CountEnable
D0	--	D0	Word[Signed]		%MW...	
M0	--	M0	Bit		%M0.0	QD62Ready
POU_01/counter	--	D12283	Word[Signed]	VAR	%MW...	

## 17.6.3 Changing display format (decimal/hexadecimal) of current values

Change the display format (decimal/hexadecimal) of the current values.


### Operating procedure

- Right-click on the Watch window, and select [Change Value Format (Decimal)]/[Change Value Format (Hexadecimal)] from the shortcut menu.




Device/Label	Current Value	Data Type	Class	Device	Address	Comment
X0	0	Bit		X0	%IX0	ModuleReady
POU_01/counter	12	Word[Signed]	VAR	D12287	%Mw0.12287	
D0	0	Word[Signed]		D0	%Mw0.0	
M0	0	Bit		M0	%MX0.0	QD62Ready
Y4	0	Bit		Y4	%QX4	CountEnable
X2	0	Bit		X2	%IX2	CounterValueMatch

Switch to the hexadecimal display



Switch to the decimal display




Device/Label	Current Value	Data Type	Class	Device	Address	Comment
X0	H00	Bit		X0	%IX0	ModuleReady
POU_01/counter	H000C	Word[Signed]	VAR	D12287	%Mw0.12287	
D0	H0000	Word[Signed]		D0	%Mw0.0	
M0	H00	Bit		M0	%MX0.0	QD62Ready
Y4	H00	Bit		Y4	%QX4	CountEnable
X2	H00	Bit		X2	%IX2	CounterValueMatch

### Point

#### ● Changing current values

The current value can be changed by entering a value directly in the "Current Value" column during monitoring. For bit devices, select a row and press the **[Shift]** and **[Enter]** keys or press the **[Shift]** key and double-click the row to change the current value.



Device/Label	Current Value	Data Type	Class	Device	Address	Comment
X0	0	Bit		X0	%IX0	
D0	100	Word[Signed]		D0	%MW0.0	
X3	0	Bit		X3	%IX3	
X4	0	Bit		X4	%IX4	
X5	0	Bit		X5	%IX5	


To prevent from pressing the **[Shift]** + **[Enter]** keys by mistake, changing the current value using the shortcut key can be invalid on the **Option** screen.

Select "Disable Current Value Changing by Pressing Shift+Enter" in [Tool] ⇒ [Option] ⇒ "Monitor" ⇒ "Common".

#### ● Displaying Watch window

If a registered device/label is a structure/function block/array label, the detail of the device/label is displayed in tree format.

When the project is opened next time, the tree will be displayed folded.




Device/Label	Current Value	Data Type	Class	Device	Address	Comment
[-] g_data1		STRUCT01	VAR_GLOB...			
AAA	--	Word[Signed]		D12287	%MW0.12287	Member 1 data
EEE	--	Word[Signed]		D12286	%MW0.12286	Member 2data
CCC	--	Word[Signed]		D12285	%MW0.12285	Member 3data
DDD	--	Word[Signed]		D12284	%MW0.12284	Member 4 data
[-] g_data2		STRUCT2	VAR_GLOB...			
FFF	--	Bit		M8191	%MX0.8191	
[-] GGG		Double Wor...				
[0]	--	Double Wor...		D12276	%MD0.12276	
[1]	--	Double Wor...		D12278	%MD0.12278	
[2]	--	Double Wor...		D12280	%MD0.12280	
[3]	--	Double Wor...		D12282	%MD0.12282	

## 17.6.4 Writing/reading data to/from CSV file

Write/read devices/labels registered to the Watch window to/from the CSV file.

### Screen display

Right-click and select [Write to CSV File]/[Read from CSV File] from the shortcut menu.



### Operating procedure

1. Enter a file name, or select a file to be opened.
2. Click the **Save** button, or the **Open** button.

The devices/labels are saved to the specified save destination, or the devices/labels are read from the specified location to the Watch window.

## 17.7 Monitoring Intelligent Function Modules

Q CPU L CPU Remote Head FX

For the method how to monitor input/output signals and buffer memory of intelligent function modules, refer to the following manual.

☞ GX Works2 Version 1 Operating Manual (Intelligent Function Module)

## 17.8 Starting/Stopping Monitoring All Windows

Q CPU L CPU Remote Head FX

This section explains how to start/stop monitoring all open windows.

### Operating procedure

- Select [Online] ⇒ [Monitor] ⇒ [Start Monitoring (All Windows)]/[Stop Monitoring (All Windows)].

## 17.9 Using Realtime Monitor Function



\*1 : Not supported by L02S and L02S-P.


This section explains how to start the Realtime Monitor function of GX LogViewer from GX Works2. To use this function, install GX LogViewer in advance.

For the operation method, refer to the following manual.

☞ GX LogViewer Version 1 Operating Manual

### Screen display

[Tool] ⇒ [Real-time Monitor Function]



### Point

- **Supported version of GX LogViewer**

To use this function, GX LogViewer Version 1.40S or later is required.





---

# 18 SIMULATING PROGRAMS

This chapter explains how to debug programs offline using the simulation function.

18.1	Simulation Function	18 - 2
18.2	Starting/Stopping Simulation	18 - 4
18.3	Checking unsupported instructions/devices	18 - 9

## 18.1 Simulation Function



This section explains how to debug a sequence program offline using the virtual programmable controller, without connecting to the programmable controller CPU.

This function is useful to test programs before operating them actually on the programmable controller CPU.

For the considerations and restrictions on the simulation function, refer to Appendix 2.

### 18.1.1 Safety and handling considerations of the simulation function

The following explains the considerations of safety and handling of the simulation function.

- 1) The simulation function simulates the actual programmable controller CPU to debug a sequence program. However, this function does not guarantee the operation of the debugged sequence program.
- 2) The simulation function uses the memory for simulation to input and output data to/from the I/O module and intelligent function module. Some instructions/functions and device memory are not supported. Therefore, the operation results obtained with the virtual programmable controller may differ from those obtained using the actual programmable controller CPU.

#### Point

After debugging programs using the simulation function, those programs must be debugged online before operating them actually on the programmable controller CPU.

### 18.1.2 Functions available for simulation function

The following table shows the GX Works2 functions that are available for the simulation function.

Function	Description	Reference
Write to PLC	Write parameter files and program files to the virtual programmable controller.	Section 15.1
Online program change <sup>*1,*2</sup>	Write programs to a virtual programmable controller in RUN status.	Section 15.9
Verify with PLC	Verify data in the virtual programmable controller against project data.	Section 15.2
Delete PLC Data	For QCPU (Q mode)/LCPU, delete data in the virtual programmable controller.	Section 15.3
Monitor	Monitor the status of operation processing.	Section 17.2
Monitor status	Display the monitoring status of the virtual programmable controller.	Section 17.1.2
Device memory/Buffer memory batch monitor	Batch-monitor the device memory/buffer memory of the virtual programmable controller.	Section 17.3
Program list monitor	For QCPU (Q mode)/LCPU, monitor the processing time of programs being executed on the virtual programmable controller.	Section 17.4
Entry Ladder Monitor	Register ladder blocks on the <u>Entry Ladder Monitor</u> screen, and monitor them.	(Simple)
Watch	Register and monitors data such as virtual programmable controller devices.	Section 17.6

Function	Description	Reference
Local Device Batch Read + Save CSV	Read local device data and save them on a personal computer.	Section 15.12
Device memory backup in simulation	Save and read device memory/buffer memory of the virtual programmable controller.	Section 18.2.1 Section 18.2.2
Modify value	Modify the current value of the virtual programmable controller.	Section 19.1
Forced input output registration/cancellation	For QCPU (Q mode)/LCPU, register/cancel the forced input/output of X/Y devices of the virtual programmable controller.	Section 19.2
Device Test with Execution Condition	For QCPU (Q mode)/LCPU, register devices of the virtual programmable controller to the device test with execution condition.	Section 19.3
Sampling trace	For QCPU (Q mode)/LCPU, trace the device value of the virtual programmable controller.	Section 19.4
Step Execution*3	Debug the program by executing it partially.	Section 19.6
Remote Operation	Switch the execution status of the virtual programmable controller, such as STOP and PAUSE.	Section 20.1
PLC Memory Operation	Perform memory format, memory clear, memory arrangement for the virtual programmable controller.	Section 20.3 Section 20.4 Section 20.5
PLC Diagnostics	Check the virtual programmable controller status and errors.	Section 21.1
I/O System Setting	Simulate operations of external devices using the virtual programmable controller.	Chapter 22

\*1 : The simulation function is not supported by FXCPU.

\*2 : Online program change of SFC blocks is not supported.

\*3 : Not supported by FXCPU.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## 18.2 Starting/Stopping Simulation



This section explains how to start/stop simulation.


### Operating procedure

- Select [Debug] ⇒ [Start/Stop Simulation] (🖥️).


The GX Simulator2 screen is displayed, and the simulation starts.

To end the simulation function, select [Debug] ⇒ [Start/Stop Simulation] again.

<Simulating a single project>



<Simulating multiple projects>



### Display contents


Item	Description
Switch	Display the operating status of the virtual programmable controller.
RESET*1	Select this to switch the operating status of the virtual programmable controller.
STOP	
RUN	
LED	Display the operating status of the virtual programmable controller. For details of the LED, refer to the following manuals. ● For QCPU (Q mode)/LCPU ☞ User's Manual (Hardware Design, Maintenance and Inspection) of each CPU module ● For FXCPU ☞ User's Manual - Hardware Edition of each FXCPU ☞ HARDWARE MANUAL of each FXCPU For the operating status error, the icon on the upper left corner of the screen is displayed in red.

\*1 : Not supported by FXCPU.

## Screen button



Switches between display/hide of the project name during the simulation.



### Point

- **Simulations of multiple projects**

The maximum of 4 projects can be simulated simultaneously by starting the simulation of other project during the simulation.

- **Simulation of FXCPU**

For FXCPU, more than one project cannot be simulated simultaneously.

- **Considerations when changing project names**

If a project name is changed during the simulation, the project name on the GX Simulator2 screen is not changed. To display the changed project name on the GX Simulator2 screen, exit the simulation, and then start the simulation again.

- **Minimized display at start up of simulation**

By setting the option, the GX Simulator2 screen can be started up in minimized mode when the simulation is activated. To start up the GX Simulator2 screen in minimized mode, select "Start in minimized status" from [Options] on the GX Simulator2 screen. From the next start up, the GX Simulator2 screen is not displayed but becomes in taskbar icon mode.

- **Stopping the simulation**

The simulation function may not be stopped by the GX Works2 simulation stop operation when another application such as MX Component is being connected to GX Simulator2. (GX Works2 is disconnected from GX Simulator2.) The simulation function stops when another application is disconnected.

17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## 18.2.1 Saving device memory/buffer memory

---

Save device memory/buffer memory of the virtual programmable controller temporarily.

### Operating procedure

1. Switch the operating status of the GX Simulator2 screen to STOP.
2. Select [Tool] ⇒ [Backup Device Memory in Simulation] ⇒ [Save] on the GX Simulator2 screen.

### Point

- **Saving device memory/buffer memory when stopping simulation**

By setting the option, device memory/buffer memory in the virtual programmable controller can be saved when the simulation is stopped.

To save device memory/buffer memory when the virtual programmable controller is stopped, select "Save device memory at stop" from [Options] on the GX Simulator2 screen.

---

## 18.2.2 Reading device memory/buffer memory

---

Read out the temporarily saved device memory/buffer memory to the virtual programmable controller.

### Operating procedure

1. Switch the operating status of the GX Simulator2 screen to STOP.
2. Select [Tool] ⇒ [Backup Device Memory in Simulation] ⇒ [Read] on the GX Simulator2 screen.

## 18.2.3 List of device memory/buffer memory that can be saved/read

This section explains device memory/buffer memory that can be saved and read with the virtual programmable controller.

### ■ Device memory that can be saved/read

The following table shows the list of device memory that can be saved/read.

#### ● QCPU (Q mode)/LCPU

Category	Type	Device
Internal user device	Bit	X (DX)
		Y (DY)
		M
		L
		F
		V
		S
		B
		SB
		T (contact)
	ST (contact)	
	C (contact)	
	Word	T (current value)
		ST (current value)
		C (current value)
D (including Extended D)		
W (including Extended W)		
Internal system device	Bit	FX
		FY
		SM
Word	FD	
	SD	
Index register	Word	Z (including ZZ)
File register	Word	R
		ZR

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

● FXCPU

Category	Type	Device
Device	Bit	X
		Y
		M
		S
		T (contact)
		C (contact)*1
	Word	T (current value)
		C (current value)*1
		D
Special device	Bit	M (special M)
	Word	D (special D)
Index register	Word	V
		Z
Extended register	Word	R*2

\*1 : High-speed counters (C235 and later) are not supported.

\*2 : Supported by FX3G, FX3GC, FX3U, and FX3UC only.

■ Buffer memory that can be saved/read

Buffer memory that can be saved and read is an memory area of modules to which the I/O assignment settings are configured in the PLC parameter.

For QCPU (Q mode), the buffer memory [U3E0 to U3E3\G0 to 4095] and the multiple CPU high-speed transfer area [U3E0 to U3E3\G10000 to 65535] on the programmable controller CPU cannot be saved/read.

For LCPU/FXCPU, all buffer memory can be saved/read.




## 18.3 Checking unsupported instructions/devices



The following explains how to display a list of instructions and devices used in a program and not supported by the simulation function.

### Screen display

Select [Debug] ⇒ [Instructions Unsupported by Simulation].



### Point

#### ● Display of unsupported instructions

Unsupported instructions are not displayed when the programmable controller does not become in RUN status because of the CPU module error at the start of the simulation.

A status without a CPU module error is required for unsupported instructions to be displayed.



---

# 19      DEBUGGING PROGRAMS

This chapter explains how to debug sequence programs.

19.1	Changing Current Values	19 - 2
19.2	Registering/Canceling Forced Input/Output	19 - 7
19.3	Device Test with Execution Condition	19 - 10
19.4	Sampling Trace	19 - 14
19.5	Measuring Scan Time	19 - 33
19.6	Debugging Programs with Simulation Function	19 - 35
19.7	Using CPU Module Logging Configuration Tool	19 - 51

## 19.1 Changing Current Values



This section explains how to change current device values of the programmable controller CPU in ladder and SFC (Zoom) programs.

The following explains how to turn ON/OFF forcibly the bit device on the programmable controller CPU from the monitoring screen and also changing the current value of the word device and buffer memory.

### 19.1.1 Changing current value of devices/labels

#### Screen display

Select [Debug] ⇒ [Modify Value] (Dev).

<For bit device>


Device/Label	Data Type	Setting Value

<For word device>





Device/Label	Data Type	Setting Value

**Operating procedure**

**1. Set the items on the screen.**

Item	Description	
Device/Label	Display the device or label selected on the monitoring screen. Also enter the device or label.	
Data Type	Display the data type of the device or label. Also select the data type from  .	
Value (For word device)	Enter a new value according to the data type as shown below:	
	Data Type	Entry
	Word [Signed], Double Word [Signed], Word [Unsigned]/Bit String [16-bit], Double Word [Unsigned]/ Bit String [32-bit]	Enter a value in decimal or hexadecimal format.
	FLOAT (Single Precision)	Enter a value in decimal or exponential form. Example: • Decimal form: -1.23456 • Exponential form: -1.23456E + 01
	FLOAT (Double Precision)*1	Enter a value in decimal form.
	String	Enter a character string. (Quotation marks (" ") are not necessary.)
Time	Enter a value in the time format. • T#0s (Applicable to Structured projects only)	

\*1 : Not supported by FXCPU.

**2. For bit devices, click the  /  /  button.  
For word devices, click the  button.**

The current value of the programmable controller CPU is changed, and the result is displayed in "Execution Result".

**Restrictions!**

- **Devices whose current values cannot be changed**  
The current values of indirectly specified devices (@D0) cannot be changed.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

## ■ Shortcut key to switch ON/OFF of bit devices

---

### ● To forcibly switch ON/OFF status of bit devices

During monitoring the following items, a bit device can be forcibly switched ON/OFF by pressing the **Shift** key + **Enter** key after selecting the bit device, or double-clicking the bit device while pressing the **Shift** key.

- Ladder editor
- ST editor\*1
- Structured Ladder/FBD editor\*1
- Device/buffer memory batch monitoring
- Watch
- Monitoring of intelligent function module

\*1: Only double-clicking a bit device while pressing the **Shift** key is available.

After the ON/OFF status of bit devices have been switched on the ladder editor, ST editor, or Structured Ladder/FBD editor, the changed result can be checked in "Execution Result" on the Modify Value screen.

### ● To disable the shortcut keys to switch ON/OFF status of bit devices


To prevent from pressing the **Shift** + **Enter** keys by mistake, changing the current value using the shortcut key can be invalid on the Option screen.

Select "Disable Current Value Changing by Pressing Shift+Enter" in [Tool] ⇒ [Option] ⇒ "Monitor" ⇒ "Common".

## 19.1.2 Changing current value of buffer memory


### Screen display

Select [Debug] ⇒ [Modify Value] .



### Operating procedure

#### 1. Set the items on the screen.

Item	Description												
Module Start (HEX)	Enter the start I/O number of the intelligent function module.												
Address	Enter the address of the intelligent function module.												
Data Type	Display the data type of the buffer memory. Also select the data type from  .												
Value	Enter a new value according to the data type as shown below.												
	<table border="1"> <thead> <tr> <th>Data Type</th> <th>Entry</th> </tr> </thead> <tbody> <tr> <td>Word [Signed], Double Word [Signed], Word [Unsigned]/Bit String [16-bit], Double Word [Unsigned]/Bit String [32-bit]</td> <td>Enter a value in decimal or hexadecimal format.</td> </tr> <tr> <td>FLOAT (Single Precision)</td> <td>Enter a value in decimal or exponential form. Example: • Decimal form: -1.23456 • Exponential form: -1.23456E + 01</td> </tr> <tr> <td>FLOAT (Double Precision)*1</td> <td>Enter a value in decimal form.</td> </tr> <tr> <td>String</td> <td>Enter a character string. (Quotation marks ( " ") are not necessary.)</td> </tr> <tr> <td>Time</td> <td>Enter a value in the time format. • T#0s (Applicable to Structured projects only)</td> </tr> </tbody> </table>	Data Type	Entry	Word [Signed], Double Word [Signed], Word [Unsigned]/Bit String [16-bit], Double Word [Unsigned]/Bit String [32-bit]	Enter a value in decimal or hexadecimal format.	FLOAT (Single Precision)	Enter a value in decimal or exponential form. Example: • Decimal form: -1.23456 • Exponential form: -1.23456E + 01	FLOAT (Double Precision)*1	Enter a value in decimal form.	String	Enter a character string. (Quotation marks ( " ") are not necessary.)	Time	Enter a value in the time format. • T#0s (Applicable to Structured projects only)
	Data Type	Entry											
	Word [Signed], Double Word [Signed], Word [Unsigned]/Bit String [16-bit], Double Word [Unsigned]/Bit String [32-bit]	Enter a value in decimal or hexadecimal format.											
	FLOAT (Single Precision)	Enter a value in decimal or exponential form. Example: • Decimal form: -1.23456 • Exponential form: -1.23456E + 01											
	FLOAT (Double Precision)*1	Enter a value in decimal form.											
String	Enter a character string. (Quotation marks ( " ") are not necessary.)												
Time	Enter a value in the time format. • T#0s (Applicable to Structured projects only)												

\*1 : Not supported by FXCPU.

#### 2. Click the button.

The current value of the buffer memory is changed, and the result is displayed in "Execution Result".

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

### Point

#### ● **Modify Value screen**

- When the Modify Value screen is open, a device/label is displayed on the Modify Value screen if it is selected on the editor.
- The Modify Value screen of device/label and buffer memory can be switched by clicking tabs.

#### ● **Execution result of current value change**

Display/hide of the execution result of current value change can be switched by `Execution Result << / Execution Result >>`.

A device/label can be displayed in "Device/Label" area by selecting the device/label and clicking the

`Reflect to Input Column` button or double-clicking it in "Execution Result".

#### ● **Selecting devices/labels used in instructions that handle multiple devices**

When an instruction that uses multiple devices (such as FROM/TO instruction) is selected, all devices/labels used in the instruction are displayed in the "Device/Label" combo box.

Select a device from the combo box and then execute the Modify Value function.

---



## 19.2 Registering/Canceling Forced Input/Output



\*1 : Not supported by Basic model QCPU.


This section explains how to register/cancel the forced input/output of devices.

X/Y device can be forcibly turned ON/OFF without the effect of the input/output to/from external devices while the programmable controller CPU is in RUN status. This enables program debugs without external devices.

### 19.2.1 Registering/canceling forced input to/output from QCPU (Q mode)/LCPU

#### Screen display

Select [Debug] ⇒ [Forced Input Output Registration/Cancellation].



#### Operating procedure

**1. Enter a device to be turned ON/OFF forcibly.**

Clicking enables to select a device from the list of previously entered ones.

**2. Click the button.**

The forced ON/OFF is registered to the programmable controller CPU.

The current registration status of the forced ON/OFF is displayed in the 'registration status display area'.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

**Screen button**

- **Cancel Registration**  
Cancels the forced ON/OFF of a device registered to the programmable controller CPU.
- **Update Status**  
Reads the registration status from the programmable controller CPU.
- **Batch Cancel Registration**  
Cancels all forced input/output registered to the programmable controller CPU.

**Point**

- **Canceling registration**  
The device registration can be canceled by placing the cursor on the device area in the registration status display area and pressing the **Delete** key.
- **Device forced input/output registration**  
The status of the device forced input/output registration may be changed by GX Works2 or external devices that can register/cancel such as forced input/output, for the exclusion control is not executed on the programmable controller CPU side.
- **Forced ON/OFF status**  
The ON/OFF status can be inverted by double-clicking the ON/OFF cell.


No.	Device	ON/OFF
1	X0	ON
2	Y10	OFF
3		
4		

**Double-click**

● **Closing the Forced Input Output Registration/Cancellation screen**

The following message is displayed when the **Close** button is clicked on the **Forced Input Output Registration/Cancellation** screen.


Click the **Yes** button to cancel all forced input/output registrations.



## 19.2.2 Registering/canceling forced input to/output from remote I/O module

### Screen display

Select [Debug] ⇒ [Forced Input Output Registration/Cancellation].



### Operating procedure

- Click the **Test Registration** / **Cancel Test Registration** button.  
A disabled/enabled refresh of X/Y device is registered to the remote I/O module. The current registration status of disabled/enabled refresh is displayed in the 'registration status display area'.

### Screen button

- **Update Status**  
Reads the current registration status of the remote I/O module.
- **Batch Cancel Registration**  
Cancels all disabled refreshes registered to the remote I/O module.

### Point

- **Connection route in which forced input/output registration/cancellation can be performed**  
In order to use this function on remote I/O module, the connection route must be set to "Serial Port NET/10(H) Remote Module Connection".

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## 19.3 Device Test with Execution Condition



\*1 : Universal model QCPU only.

This section explains how to change device value at the execution of programs and steps specified in advance.

This enables debugs of specific ladder blocks without changing programs.

This function can be executed only in a ladder program of Simple project.

### 19.3.1 Registering device test with execution condition

Register the device test with execution condition.

#### Screen display

Select [Debug] ⇒ [Device Test with Execution Condition] ⇒ [Register].

<For bit device>

Register Device Test with Execution Condition

Device/Label: SM1036

Data Type: Bit

FORCE ON    FORCE OFF

Execute Condition

Program Name: MAIN

Cannot set it to SFC program.

Step No.: 0

Execution Timing: Before Executing Instruction

<For word device>

Register Device Test with Execution Condition

Device/Label: D0

Data Type: Word[Signed]

Value: 1230

DEC    HEX

Set

Execute Condition

Program Name: MAIN


Cannot set it to SFC program.

Step No.: 1

Execution Timing: Before Executing Instruction

**Operating procedure**

**1. Set the items on the screen.**

Item		Description												
Device/Label		Display the device or label selected on the monitoring screen. Also enter the device or label.												
Data Type		Display the data type of the device or label. Also select the data type from  .												
Value (For word device)		Enter a new value according to the data type as shown below.												
		<table border="1"> <thead> <tr> <th>Data Type</th> <th>Entry</th> </tr> </thead> <tbody> <tr> <td>Word [Signed], Double Word [Signed], Word [Unsigned]/Bit String [16-bit], Double Word [Unsigned]/Bit String [32-bit]</td> <td>Enter a value in decimal or hexadecimal format.</td> </tr> <tr> <td>FLOAT (Single Precision)</td> <td>Enter a value in decimal or exponential form. Example: • Decimal form: -1.23456 • Exponential form: -1.23456E + 01</td> </tr> <tr> <td>FLOAT (Double Precision)</td> <td>Enter a value in decimal form.</td> </tr> <tr> <td>String</td> <td>Enter a value as a character string. (Quotation marks (" ") are not necessary.)</td> </tr> <tr> <td>Time</td> <td>Enter a value in the time format. • T#0s (Applicable to Structured projects only)</td> </tr> </tbody> </table>	Data Type	Entry	Word [Signed], Double Word [Signed], Word [Unsigned]/Bit String [16-bit], Double Word [Unsigned]/Bit String [32-bit]	Enter a value in decimal or hexadecimal format.	FLOAT (Single Precision)	Enter a value in decimal or exponential form. Example: • Decimal form: -1.23456 • Exponential form: -1.23456E + 01	FLOAT (Double Precision)	Enter a value in decimal form.	String	Enter a value as a character string. (Quotation marks (" ") are not necessary.)	Time	Enter a value in the time format. • T#0s (Applicable to Structured projects only)
		Data Type	Entry											
		Word [Signed], Double Word [Signed], Word [Unsigned]/Bit String [16-bit], Double Word [Unsigned]/Bit String [32-bit]	Enter a value in decimal or hexadecimal format.											
		FLOAT (Single Precision)	Enter a value in decimal or exponential form. Example: • Decimal form: -1.23456 • Exponential form: -1.23456E + 01											
		FLOAT (Double Precision)	Enter a value in decimal form.											
String	Enter a value as a character string. (Quotation marks (" ") are not necessary.)													
Time	Enter a value in the time format. • T#0s (Applicable to Structured projects only)													
Execute Condition	Program Name	Specify the program name for the timing of the forced ON/OFF and current value change.												
	Step No.	Specify the step number in the program for the timing of the forced ON/OFF and current value change.												
	Execution Timing	Select 'before' or 'after' the instruction in the step number in the program for the timing of the forced ON/OFF and current value change.												


**2. For bit devices, click the  button.**


**For word devices, click the  button.**

The device/label is registered to the device test with execution condition.

**Point**

● **Registering devices**

- Up to 32 devices can be registered.
- The registration of the device test with execution condition is canceled by performing the following operations.
  - Online program change of the program in the range which includes the specified step
  - Write to PLC
- A box with the specified color appears at the instruction of the specified step.  
(Changing color  Section 3.2.7)



- The device value is changed at the specified step regardless of whether the instruction of the specified step is executed.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX


I  
INDEX

### 19.3.2 Checking/disabling registration of device test with execution condition

Check the registration of the device test with execution condition, write it to a file, read it out from a file, and disable it.

#### Screen display

Select [Debug] ⇒ [Device Test with Execution Condition] ⇒ [Registration Check/Disable].



#### Display contents

Item	Description
Status of Displayed Data	Display whether the data being displayed is read from the programmable controller CPU or from a file.
Registration information list	Display the registration of the device test with execution condition. Display up to 32 records.

#### Screen button

- **Update Status**  
Reads the registration information from the programmable controller CPU.
- **Disable Registration**  
Disables the registration selected in 'registration information list'.
- **Batch Register**  
Registers the registration information data to the programmable controller CPU in batch.
- **Batch Disable**  
Disables the registration information data on the programmable controller CPU in batch.
- **Read File...**  
Reads the registration information list from a file.
- **Write File...**  
Saves the registration information data being displayed in 'registration information list' to a file.

**Point****● Checking/disabling the device test with execution condition**

- The registration of devices specified in the device test with execution condition can be checked/disabled on the monitor screen of the ladder editor. Right-click on a device and select [Debug] ⇒ [Check Register Device Test with Execution Condition]/[Disable Register Device Test with Execution Condition] from the shortcut menu.
- Other than the above operation, registrations of device test with execution condition are canceled by the following operations.
  - Reset or turn from OFF to ON the programmable controller CPU.
  - Perform the Online program change including the specified step.
  - Write the program file to the program memory of the programmable controller CPU while the programmable controller CPU is in STOP status.
  - Delete the program file in the program memory of the programmable controller CPU while the programmable controller CPU is in STOP status.
  - Format the program memory of the programmable controller CPU while the programmable controller CPU is in STOP status.

**19.3.3 Batch disabling device test with execution condition**

Batch disable the registered device test with execution condition.

**Operating procedure**

- Select [Debug] ⇒ [Device Test with Execution Condition] ⇒ [Batch Disable].

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## 19.4 Sampling Trace



\*1 : Not supported by Basic model QCPU and Q00UJ.

This section explains the operation of the sampling trace function.


The sampling trace function acquires the data at the preset timing to find how device values change during program operation and traces the changes by displaying them in time series.

For details of the sampling trace function, refer to the manual of each CPU module.

### 19.4.1 Opening sampling trace screen

#### Operating procedure

- Select [Debug] ⇒ [Sampling Trace] ⇒ [Open Sampling Trace].



#### Point

##### ● Devices displayed with red background

When devices or data types which cannot be used in a new programmable controller CPU type are contained in the sampling trace data after the Change PLC Type operation, they are displayed with red background.

Modify them to devices appropriate for the new programmable controller CPU type, and execute the sampling trace again.



## 19.4.2 Setting executing condition of sampling trace


The following explains the settings required for executing sampling trace and the execution method.

### ■ Setting sampling trace execution method and data storage destination

Set the sampling trace execution method and the storage destination of the trace data.

#### Screen display

Select [Debug] ⇒ [Sampling Trace] ⇒ [Trace Setting] (  ) ⇒ <<Setting of Executing and Saving>>.



#### Operating procedure

- Set the items on the screen.

Item	Description
Trace Execution Method	Set the trace execution method.
Execute after overwriting current trace settings in the PLC	Select this to execute sampling trace after overwriting the current trace setting to the programmable controller CPU.
Execute using existing trace settings in the PLC	Select this to execute sampling trace using the trace setting stored on the programmable controller CPU.
Trace Data (setting+result) Storage	Set the memory and the file name where the trace data set on the <<Condition Setting>> tab and the trace result after execution are stored.
Trace Auto Startup Setting	Select this to perform the sampling trace automatically when the programmable controller CPU is in RUN. (Universal model QCPU/LCPU only*1)

\*1 : For the versions of Universal model QCPU that support this function, refer to the User's Manual (Function Explanation, Program Fundamentals) of the CPU module to be used.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I


INDEX

## ■ Setting sampling trace conditions

Set the sampling trace conditions such as the number of traces and the trigger condition.




### Screen display

Select [Debug] ⇒ [Sampling Trace] ⇒ [Trace Setting] (🔧) ⇒ <<Condition Setting>>.



## Operating procedure

- Set the items on the screen.

Item	Description
Trace Count Setting	Set the number of data acquisitions (samplings) before and after the trigger. Select a value using the combo box or enter a value directly. Setting range: Count Before Trigger < Total Count ≤ 8192
Additional Information	Set the information to be added to the trace result.
Time	Add the time of the trace start.
Program Name	Add the name of the program in which the sampling trace is executed.
Data Acquisition Timing Setting	Set the trace data acquisition timing.
Each Scan	Select this to acquire the data every scan.
Specified Interval	Select this to acquire the data in the set intervals. The setting unit is 1ms.
Each Multiple CPU High Speed Transfer Cycle*1	Select this to acquire the data in the Each multiple CPU high-speed transfer cycle.
Detail Setting	Select this to set the data acquisition timing depending on the device condition. Use the  button to set the conditional expression.
Trigger Condition Setting	Set the trigger (condition) that is taken as the start point (0 point) of sampling trace execution.
At the Time of Trace Instruction Execution	Select this to generate a trigger when the TRACE instruction in the program is executed. For the TRACE instruction, refer to the following manual. (  MELSEC-Q/L Programming Manual (Common Instructions))
At the Time of Manual Trigger Execution	Select this to generate a trigger manually with GX Works2. Select [Debug] ⇒ [Sampling Trace] ⇒ [Execute Manual Trigger] to generate a trigger.
Detail Setting	Select this to set a trigger timing depending on the device condition. A trigger is generated when the conditional expression is satisfied. Use the  button to set the conditional expression.

\*1 : For Universal model QCPU only

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I


INDEX

**Screen button**

- **Setting Change...**

Displays the Detail Setting screen.

Setting of the conditional expression can be changed in the Data Get Timing screen or the Trigger Condition screen.



**Operation**

- **Set the items on the screen.**

Item	Description													
Device /Label	Enter a device, address or label.  Section 19.4.6													
Device	Display the device corresponds to "Device /Label".													
Address*1	Display the address corresponds to "Device /Label".													
Comment	Display the device comment of "Device /Label".													
Condition	Select the timing condition.													
	<ul style="list-style-type: none"> <li>• For the data get timing setting The data are collected at the end processing of one scan or when the condition of the specified device/label is satisfied.</li> </ul>													
	<table border="1"> <thead> <tr> <th>Device</th> <th>Condition</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Bit device</td> <td>↑</td> <td>Collect data at the rising of the specified device/label.</td> </tr> <tr> <td>↓</td> <td>Collect data at the falling of the specified device/label.</td> </tr> <tr> <td rowspan="2">Word device</td> <td>=</td> <td>Collect data when the current value of the specified device becomes the specified condition value.</td> </tr> <tr> <td>Change*2</td> <td>Collect data when the current value of the specified device changes.</td> </tr> </tbody> </table>	Device	Condition	Description	Bit device	↑	Collect data at the rising of the specified device/label.	↓	Collect data at the falling of the specified device/label.	Word device	=	Collect data when the current value of the specified device becomes the specified condition value.	Change*2	Collect data when the current value of the specified device changes.
	Device	Condition	Description											
	Bit device	↑	Collect data at the rising of the specified device/label.											
		↓	Collect data at the falling of the specified device/label.											
	Word device	=	Collect data when the current value of the specified device becomes the specified condition value.											
		Change*2	Collect data when the current value of the specified device changes.											
	<ul style="list-style-type: none"> <li>• For the trigger condition setting Satisfaction of the condition of the specified device/label becomes a trigger.</li> </ul>													
	<table border="1"> <thead> <tr> <th>Device</th> <th>Condition</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Bit device</td> <td>↑</td> <td>Consider the rising of the specified device/label as a trigger.</td> </tr> <tr> <td>↓</td> <td>Consider the falling of the specified device/label as a trigger.</td> </tr> <tr> <td rowspan="2">Word device</td> <td>=</td> <td>Consider the time when the current value of the specified device becomes the specified condition value as a trigger.</td> </tr> <tr> <td>Write data*2</td> <td>Consider the time when data are written to the specified device/label as a trigger.</td> </tr> </tbody> </table>	Device	Condition	Description	Bit device	↑	Consider the rising of the specified device/label as a trigger.	↓	Consider the falling of the specified device/label as a trigger.	Word device	=	Consider the time when the current value of the specified device becomes the specified condition value as a trigger.	Write data*2	Consider the time when data are written to the specified device/label as a trigger.
Device	Condition	Description												
Bit device	↑	Consider the rising of the specified device/label as a trigger.												
	↓	Consider the falling of the specified device/label as a trigger.												
Word device	=	Consider the time when the current value of the specified device becomes the specified condition value as a trigger.												
	Write data*2	Consider the time when data are written to the specified device/label as a trigger.												
Radix	Select the radix of the condition value. (Word device only)													
Values	Set the condition value. (Word device only)													

\*1 : For Structured projects only

\*2 : For Universal model QCPU/LCPU only


## 19.4.3 Registering devices/labels

Register the devices/labels on the Sampling Trace screen.

### Operating procedure

- **Register the devices/labels to which the sampling trace is performed.**

Devices/labels can be registered by entering them directly or copying them from the program editor or label editor by the drag-and-drop operation.



### Display contents

Item	Description
Display title	-
Device/Label	Set the device, address, label, structure, array, and function block to which the sampling trace is performed. 50 bit devices and 50 word devices can be registered.
Device* <sup>1</sup>	Display the device corresponds to "Device /Label".
Address* <sup>1</sup> , * <sup>2</sup>	Display the address corresponds to "Device /Label".
Comment* <sup>1</sup>	Display the device comment for the address or device/label which are entered in "Device /Label".
Data Type* <sup>1</sup>	Display the data type of "Device/Label". The data type of the word device can be changed after registration.
Radix* <sup>1</sup>	If the device entered in "Device/Label" is the bit device, the radix is fixed as "Binary". If the device entered in "Device/Label" is the word device, the radix can be selected from "Binary", "Decimal", "Hexadecimal" or "ASCII". If the device entered in "Device/Label" is the single-precision/double-precision real number, the radix is fixed as "FLOAT".
Vertical Axis	Display the time axis data of the selected cell as displaying the trace result.

\*1 : Items can be displayed by selecting [View] ⇒ [Switching Display Items].

\*2 : For Structured projects only

### Point

- **Editing with a selection of two or more rows**

Two or more rows can be selected by holding down the **[Shift]** key or the **[Ctrl]** key to copy or delete.

When non-consecutive rows are selected by holding down the **[Ctrl]** key and copied, blank rows are deleted when the selected rows are pasted.

Multiple rows cannot be selected during the sampling trace execution.


## ■ Changing data types of word devices

For word devices, data type can be changed after registration.

When the data type of a device/label that uses the multiple devices is changed, the necessary devices are displayed in the tree format.

Example:

Changing data type of D10 from "Word [Signed]" to "Double Word [Signed]"




### Restrictions!

- When 'Double Word'/'FLOAT (Single Precision)'/ 'FLOAT (Double Precision)' is set to "Data Type"  
The data acquired by the sampling trace function may become inconsistent.

## ■ Registering devices/labels from program editor/label editor with drag-and-drop operation


Register a device/label from the program editor/label editor with the drag-and-drop operation. Multiple devices/labels can be registered in batch by selecting a range.

<Ladder editor>




Select the device, instruction and ladder block.

<Structured Ladder/FBD editor>




Select the device and ladder block.

<ST editor>



Select the device and line.

<Label editor>




Class	Label Name	Data Type	Con
VAR_GLOBAL	Switch_A	Bit	...
VAR_GLOBAL	Switch_B	Bit	...
VAR_GLOBAL	Tank_A_Temperature	Word[signed]	...
VAR_GLOBAL	Tank_B_History	Word[signed](0..9)	...
VAR_GLOBAL	Tank_B_Temperature	Double Word[signed]	...
VAR_GLOBAL	Module_A_Base_Point	Bit	...

Select the device by a unit of row.


Drag & drop



Activate the window by placing the cursor on the Sampling Trace tab while dragging the data, and drop the data on the Sampling Trace screen.



The device is registered at the cursor position.



Device/Label	Device	Comment	Data Type	Radix	Vertical Axis
M0	M0		Bit	BIN	-
M1	M1		Bit	BIN	-
SwitchA	M8189		Bit	BIN	-

### Point

#### ● Drag-and-drop operation of data from ladder editor

The drag-and-drop operation of data can be performed when the cursor is changed to as it is moved to the border of the selected range.

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX


### 19.4.4 Executing sampling trace

#### Operating procedure

- Select [Debug] ⇒ [Sampling Trace] ⇒ [Start Trace] (🔍).


Sampling trace starts.

The Trace Data Storage Status screen is displayed when the sampling trace is started.







Item	Description
Total Data	Display the current status of data acquisition (sampling) after the start of sampling trace in percentage in reference to the number of times set for "Trace Setting". Even after this status reaches 100%, sampling trace is continuously executed and the data are overwritten from the oldest data.
Data After Trigger	Display the current status of data acquisition (sampling) after the generation of trigger in percentage in reference to the number of times set for "Trace Setting". When this status reaches 100%, sampling trace stops.
Trace data file name	Display the trace data file name that is registered for the sampling trace on the programmable controller CPU.

After the stop or completion of sampling trace, the trace result is displayed on the Sampling Trace screen.





## Display contents

Item	Description
Display title	-
Vertical Axis	Display the device value of the selected cell position, on the 'vertical axis information line'.
Currently selected number of data acquisitions	Indicate the number of data acquisitions on the column selected with the vertical axis information line. The line can be moved to the selected number of data acquisitions by entering a value.
Chart	Display the acquired data in chart.
Timing chart scale	One block corresponds to one data acquisition. The number of scale indicates the number of data acquisitions. To change the display width, select [View] ⇒ [Timing Chart Scale] ⇒ [-: Narrow Scale] (  )/[+: Wide Scale] (  ), or move a scroll wheel on a mouse while pressing the <b>[Shift]</b> key.
Trigger position	A red mark is displayed at the position corresponding to the trigger generated timing on the timing chart scale when a trigger is generated.
Vertical axis information line	This line is displayed at the position where a cell is selected on the chart in yellow. The device value on the vertical axis information line is displayed in cells under "Vertical Axis". When the vertical axis information line is double-clicked, the data at the right side of the line are displayed on the sampling trace (detailed data) screen.  ■ Switching screen to the sampling trace (detailed data) screen
Trend graph registration target	Register the selected word device to the trend graph. Deregister them by clearing the check box. When the selected status is changed while two or more rows are selected, the change applies to the selected status of all the selected rows.
Trend graph	Display the changes of the word device values on the trend graph.  ■ Displaying trace results on trend graphs


### Point

#### ● Starting sampling trace from sequence program

Select [Debug] ⇒ [Sampling Trace] ⇒ [Register Trace].

To start sampling trace, execute the Trace start command (SM801) in a program.

#### ● Displaying only the trace result stored on the programmable controller CPU without executing sampling trace

Select [Debug] ⇒ [Sampling Trace] ⇒ [Read from PLC]. (  Section 19.4.5)

#### ● Word devices whose data types can be changed after sampling trace results are displayed

The type of a word device can be changed to the double word type or the real type, only when the consecutive devices with the required points are registered as the trace data.

Example) If the sampling trace is performed to D0, D1, D2, and D3, the data type of D0 can be changed to the double word type.

If the data type of D2 is changed to the data type that uses multiple devices, such as the double word and single-precision real number, the data type of D0 cannot be changed as it has no consecutive 4-words devices.

#### ● Performing sampling trace from other peripherals during performing sampling trace

For Universal model QCPU/LCPU, the sampling trace currently being performed can be stopped by other peripherals and perform another sampling trace. When the sampling trace is performed by other peripherals, select [Debug] ⇒ [Sampling Trace] ⇒ [Forced Execution Registration Effective] to activate the forced registration.

#### ● Trace ready status (SM800) after sampling trace is completed

In GX Developer, the trace ready status (SM800=1) is held until the trace results are read, even if the sampling trace is completed. In GX Works2, the trace results are automatically read and displayed when the sampling trace is completed, and then the trace ready status (SM800=0) is canceled.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

■ Switching screen to the sampling trace (detailed data) screen


Display the device/label value change in numeric values.

Screen display

- Click the tool button  (Switch Chart/Detail).

The sampling trace (detailed data) screen is displayed.

Click the tool button  (Switch Chart/Detail) again to switch to the chart.



Display contents

Item	Description
Additional information	Display the additional information set for "Additional Information" on the <<Condition Setting>> tab on the <u>Trace Setting</u> screen. Select [View] ⇒ [Additional Information] ⇒ [Time]/[Program Name].
Detailed data	Confirm the device values. In the case of a bit device, '*' is displayed for ON, nothing is displayed (blank) for OFF. In the case of a word device, numeric values are displayed. The registered "Device /Label" are linked with the <u>Sampling Trace</u> screen (chart).

## ■ Displaying trace results on trend graphs


Display the changes of the word device values on the trend graph.

### Operating procedure

- Select the check box(es) of the 'trend graph registration target' on the **Sampling Trace** screen.

The selected word device is registered on the trend graph.

Clear the check box to cancel the registration on the trend graph.



### Display contents


Item	Description
Trend graph line color	Change the background color of cell under 'trend graph line color' to the line color of the trend graph. Double-click the cell, and the <b>Color</b> screen is displayed to allow changing of the trend graph line color.

### Point

- **Wide/narrow scales of trend graphs**

Place the cursor at the base point to widen/narrow, and select [View] ⇒ [Trend Graph Scale] ⇒ [-: Narrow Scale] (📏) / [+: Wide Scale] (📏) or move a scroll wheel on a mouse while pressing the [Ctrl] key. The widened/narrowed graph with the specified base point as the center is displayed.

Select [View] ⇒ [Trend Graph Scale] ⇒ [Initial Display] to recover the display to the initial state.



- **Moving trend graphs**

Double-click the trend graph to move the graph up or down with the double-clicked point as the center.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## 19.4.5 Saving trace data

Save the trace data of sampling trace (sampling trace target devices/labels, trace setting, and trace results) on a personal computer or a programmable controller CPU.

### ■ Saving trace data on personal computer


Save the trace data on a personal computer in the CSV file format.

The menu item of the function cannot be selected when a trace result does not exist.

#### Operating procedure

**1. Select [Debug] ⇒ [Sampling Trace] ⇒ [Export CSV Data].**

The Export CSV Data screen is displayed.



**2. Enter the file name to be saved.**

**3. Select the file type.**

For checking the trace setting or the trace result using Excel, select "GX Works2 format CSV file".  
For checking the trace result read by using GX LogViewer, select "GX LogViewer format CSV file".

**4. Click the  button.**

The trace data is saved on the personal computer.

**Point**

● **Checking triggers in CSV file**

For the trace numbers of the sampling trace when the trace data are output to the file selected for "GX Works2 format CSV file", the number at the time of the trigger execution is set to 0, and the numbers are displayed with the negative values for the numbers before the trigger execution and positive values for the numbers after the trigger execution.

Example) If M0, which was obtained at the fifth time after the trigger execution, is ON, M0 with the trace number '4' is displayed as 'ON' in the CSV file.

	Trace No.	Time(sec.)	Program Name	Radix	[M0]	[M1]	[Switch_A]	[Switch_B]	[D1.0]	[Tank_A.Te
	-4							*	200	200
	-3				*			*	200	200
	-2							*	200	200
	-1							*	200	200
	0							*	200	200
	1				*			*	200	200
	2							*	200	200
	3							*	200	200
	4				*			*	200	200
	5							*	200	200
	6							*	200	200

When the trace data are output to the file selected for "GX LogViewer format CSV file", "\*" is displayed on the data rows at the time of the trigger execution.

● **Display of CSV files opened in Excel**

To display the file selected for "GX Works2 format CSV file" in Excel similar to the display of the sampling trace result, copy the devices and the range of the result, select "Transpose" in "Paste Special", and then paste them on to Excel.

● **Display of Counter (C), Timer (T), and Retentive timer (ST)**

When the file selected for "GX LogViewer format CSV file" is read in GX LogViewer, device names are displayed in the format displayed on the Sampling Trace screen. Therefore, as shown in the following table, the display of device names differs between the file selected for "GX LogViewer format CSV file" and the CSV file output using the logging configuration tool.

File selected for "GX LogViewer format CSV file"	CSV file output using the logging configuration tool
T (Current value)	T
T (Contact)	TS
T (Coil)	TC
C (Current value)	C
C (Contact)	CS
C (Coil)	CC
ST (Current value)	ST
ST (Contact)	SS
ST (Coil)	SC

■ Formatting CSV files

Saved CSV files are displayed as shown below when they are opened in spreadsheet software.

● Example of "GX Works2 format CSV file"

SW1DNC-GXW2 Trace Result						
<Output Version>	1.98C					
<<Setting of Executing and Saving>>						
<Trace Execution Method>	[*]	Execute after overwriting current trace settings in the PLC				
	[ ]	Execute using existing trace settings in the PLC				
<Trace Data Storage>						
Target Memory		Memory Card (SRAM)				
File Name		[MAIN]				
<Trace Auto Startup Setting>	[ ]	Auto Startup				
<<Condition Setting>>						
<Trace Count Setting>						
Total Count	100					
Count Before Trigger	3					
Count After Trigger	97					
<Additional Information>						
	[*]	Time				
	[*]	Program Name				
<Data Get Timing>						
	[*]	Each Scan				
	[ ]	Specified Interval				
	[ ]	Each Hi-Speed Transfer Cycle among Multi CPU				
	[ ]	Detail Setting				
<Trigger Condition Setting>						
	[*]	At the Time of Trace Instruction Execution				
	[ ]	At the Time of Manual Trigger Execution				
	[ ]	Detail Setting				
		Device/Label	[M0]	[M1]	[SwitchA]	
		Device	M0	M1	M8190	
		Address	%MX0.0	%MX0.1	%MX0.8190	
		Comment	[Station_No1	[Station_No2	[ControlNo0:	
		Data Type	Bit	Bit	Bit	
Trace No.	Time(sec.)	Program Name	Radix	BIN	BIN	BIN
	-3	0 [MAIN1]				
	-2	0 [MAIN1]				
	-1	0.001 [MAIN1]		*		

● Example of "GX LogViewer format CSV file"

[LOGGING]	SamplingTrace_1	2	3	4
INDEX	BIT[1;0]	BIT[1;0]	BIT[1;0]	SHORT[DEC.0]
INDEX	M0	M1	M8190	D0
				TRIGGER[*]
				Trigger
1	0	0	0	78947352
2	0	0	0	78979536
3	1	0	0	0
4	1	0	0	0
5	1	0	0	0
6	1	0	0	0
7	1	0	0	0

## ■ Writing/reading trace data to/from programmable controller CPU

Write/read the trace data to/from a programmable controller CPU.

### Operating procedure

- **Select [Debug] ⇒ [Sampling Trace] ⇒ [Read from PLC]/[Write to PLC].**  
The Write to PLC function writes the trace data to the target memory set on the <<Setting of Executing and Saving>> tab on the Trace Setting screen.

### Point

- **Reading trace data to programmable controller CPU**  
The word data, which was read by the Read from PLC function, is read as the word (signed) type regardless of the data type settings at the time of writing the data.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

### 19.4.6 Applicable devices/labels for sampling trace

■ List of applicable devices for sampling trace

○: Applicable ×: Not applicable

Category	Device type	Device	Sampling trace screen	Data acquisition timing	Trigger condition	
Internal user device	Input	X	○*1	○*1	○	
	Output	Y	○*1	○*1	○	
	Internal relay	M	○*1	○*1	○	
	Latch relay	L	○*1	○*1	○	
	Annunciator	F	○*1	○*1	○	
	Edge relay	V	○*1	○*1	○	
	Step relay	S	×	×	×	
	Link relay	B	○*1	○*1	○	
	Link special relay	SB	○*1	○*1	○	
	Timer	Current value	T	○	○	○
		Contact	TS	○*2	○*2	○*2
		Coil	TC	○*2	×	×
	Counter	Current value	C	○	○	○
		Contact	CS	○*2	○*2	○*2
		Coil	CC	○*2	×	×
	Retentive timer	Current value	ST	○	○	○
		Contact	STS	○*2	○*2	○*2
		Coil	STC	○*2	×	×
	Data register	D	○*1	○*1	○*1	
	Link register	W	○*1	○*1	○*1	
Link special register	SW	○*1	○*1	○*1		
Internal system device	Function input	FX	○	○	○	
	Function output	FY	○	○	○	
	Special relay	SM	○*1	○*1	○	
	Function register	FD	○*1	○*1	○*1	
	Special register	SD	○*1	○*1	○*1	
Link direct device	Link input	J□\X□	○*1	○*1	×	
	Link output	J□\Y□	○*1	○*1	×	
	Link register	J□\W□	○*1	○*1	×	
	Link special register	J□\SW□	○*1	○*1	×	
	Link relay	J□\B□	○*1	○*1	×	
	Link special relay	J□\SB□	○*1	○*1	×	
File register	File register	R	○*1	○*1	○*1	
		ZR	○*1	○*1	○*1	
Index register	Index register	Z	○	○	×	
		ZZ	×	×	×	
Intelligent function module device	Intelligent function module device	U□\G□	○*1	○*1	×	
	Cyclic transmission area device	U3E□\G□	○*1	○*1	×	
Nesting	Nesting	N	×	×	×	



Category	Device type	Device	Sampling trace screen	Data acquisition timing	Trigger condition	
Pointer	Pointer	P	x	x	x	
	Interrupt pointer	I	x	x	x	
Others	SFC block device	BL	x	x	x	
	SFC transition device	TR	x	x	x	
	Network number specified device	J	x	x	x	
	I/O number specified device	U	x	x	x	
	Macro instruction argument device	VD	x	x	x	
Constant	Decimal constant	K	x	x	x	
	Hexadecimal Constant	H	x	x	x	
	Real constant	Single-precision floating-point data	E	x	x	x
		Double-precision floating-point data	E	x	x	x
	String constant	""	x	x	x	

\*1 : Following modification settings are applicable.

- Digit-specified bit device (K1 to K8 and K1 to K4 can be used for the Sampling Trace screen and data acquisition timing respectively.)
- Bit-specified word device
- Index setting (not available under the trigger condition)

\*2 : For Structured projects only

## ■ Applicable label types for sampling trace

Label type	Description	Example
Global label*1	Register and display as 'label name'.	Label1
Local label*1	Register and display as 'program/label name'.	POU_01/ Label1
Structure*1	Register and display as 'label name.member name'. Register all members when the whole structure labels are registered.	G_data.AAA
Function block*1	Register and display as 'instance name.label name in function block'. Register all labels in the function block when the whole instances (function blocks) are registered.	FB_01.IN01
Array*1	Register and display as 'label name [one-dimensional element number] [two-dimensional element number] [three-dimensional element number]'. Register all elements/all members when the whole array labels are registered.	Array[0,0,0]
Structure array*1	Register and display as 'label [one-dimensional element number] [two-dimensional element number] [three-dimensional element number]. member name'. Register and display arrays when the structure contains member labels of arrays. Register all elements/all members when the whole structure array labels are registered.	Array2[0,0,0]. AAA
Nested function block*1	Register and display as 'instance name.label name in function block.label in nested function block'. Register and display structures when the nest function block contains structure labels. Register all labels in the instance when the whole instances (nested function blocks) are registered.	FB1_01.FB2_ 01.Label1

\*1 : The following data types are applicable.

Bit, Word [Signed], Word [Unsigned], Word [Unsigned]/Bit String [16-bit], Double Word [Signed], Double Word [Unsigned]/Bit String [32-bit], FLOAT (Single Precision), FLOAT (Double Precision), Timer, Counter, Retentive Timer

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

### 19.4.7 Considerations when performing sampling trace

---

The following explains the considerations when performing the sampling trace.

● **When files for both local device and trace data exist in standard RAM**

Perform the following operation to change the local device when the files for both the local device and trace data exist in the standard RAM.

If the following operation is not performed, the files for the trace data may be deleted.

**Operation**

1. **Select [Debug] ⇒ [Sampling Trace] ⇒ [Read from PLC].**  
Read the file for trace data from the standard RAM.
2. **Change the settings for the local device, and write the changes to the programmable controller CPU.**
3. **Select [Debug] ⇒ [Sampling Trace] ⇒ [Write to PLC].**  
Write the file for the trace data, which was read in the procedure 1, to the standard RAM.

### 19.4.8 Compatibility with sampling trace data in GX Developer

---

The sampling trace data which are saved by "Trace settings file operation" using GX Developer cannot be read in GX Works2.

The sampling trace data which are set in GX Works2 cannot be saved as the format that can be read in GX Developer.

Perform the following operation when utilizing the sampling trace data.

● **Utilizing GX Developer sampling trace data in GX Works2**

**Operation**

1. **Write the sampling trace data, which are set in GX Developer, to the programmable controller CPU.**  
Perform the "Write to PLC" function of "Trace settings PLC operation" in GX Developer.
2. **Read the sampling trace data from the programmable controller CPU in GX Works2.**  
Select [Debug] ⇒ [Sampling Trace] ⇒ [Read from PLC] in GX Works2.

● **Utilizing GX Works2 sampling trace data in GX Developer**

**Operation**

1. **Write the sampling trace data, which are set in GX Works2, to the programmable controller CPU.**  
Select [Debug] ⇒ [Sampling Trace] ⇒ [Write to PLC] in GX Works2.
2. **Read the sampling trace data from the programmable controller CPU in GX Developer.**  
Perform the "Read from PLC" function of "Trace settings PLC operation" in GX Developer.

# 19.5 Measuring Scan Time




\*1 : Not supported by Basic model QCPU.

This section explains how to measure the initial, current, maximum, and minimum scan time for a user-defined section of a ladder or SFC program. The processing time can be measured even in subroutines and interrupt programs. This function can be performed in Simple projects only.

## Screen display

Select [Debug] ⇒ [Scan Time Measurement].



## Operating procedure

1. Set the items on the screen.

Item	Description
Measurement Limit	Set the measurement range.
Program Name	Display the name of the program being opened.
Block No.*1	Display the SFC block number.
Block Name*1	Display the SFC block name.
Start Step	Set the start step. For SFC program, set the SFC step number.
End Step	Set the end step. For SFC program, set the SFC step number.

\*1 : SFC programs only

2. Click the **Start** button.

The first value, current value, maximum value, and minimum value are measured. 0.000ms is displayed when the measured time is shorter than 0.100ms. For Universal model QCPU, the scan time 0.001ms or longer can be measured.

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX


### Point

#### ● Scan time measurement range

- By selecting a range on the ladder editor/SFC diagram editor and selecting [Debug] ⇒ [Scan Time Measurement], the selected range can be set to "Start Step" and "End Step".
- For a ladder program, when a step specified as "Start Step" or "End Step" exists in the ladder program, the measurement range is set in units of ladder blocks which include the selected range.

#### ● When scan time cannot be measured

- Scan time cannot be measured depending on a step specified as "Start Step" or "End Step".  
For details of the case that scan time cannot be measured, refer to the following manual.

 User's Manual (Function Explanation, Program Fundamentals) of the CPU module to be used

---

# 19.6 Debugging Programs with Simulation Function




This section explains how to debug programs with the simulation function. This function is supported only by ladder and ST programs of Simple project. The following table shows the main step execution functions.


Item	Description
Break execution	Execute a program until set break conditions are satisfied. Break conditions are set with break points or break devices.
Step execution	Execute a program one step at a time.
Partial execution	Execute a program partially from the specified point. A partial execution is executed by executing a break execution with set break points and break devices.

The following are program editors in a debugging process with the step execution functions.

<Example of step execution in ladder program>



<Example of step execution in ST program>



17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU


21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

**Point** **● Online functions which can be performed during step execution**

The RUN/STOP status on the monitoring status bar becomes STEP-RUN (  ) when the step execution is executed. The following are the Online functions which can be performed when the monitoring status is STEP-RUN.

- Write to PLC function (SFC file batch online program change is not supported.)
- Verify with PLC function
- Remote operation
- Delete PLC Data function

**● Editing programs during step execution**

For ladder programs, programs can be edited even when the step execution is being executed.


Note that, however, when the step execution is executed in the status in which the program in GX Works2 and the program in the virtual programmable controller do not match, then the step execution function is executed on the program in the virtual programmable controller as the basis. Therefore, the cursor position of canceled position may be displayed at a different position.

**● Ladder blocks with yellow background**

In a ladder program, the step execution may not be executed normally in ladder blocks with yellow background which indicates a program cannot be displayed as a ladder program.

**● Programs with "Standby" execution type**

The step execution cannot be executed on programs in which "Standby" is set for execution type in the program setting.

However, the step execution can be executed on a program in which the execution start position is set for "From current cursor position" in the execution option setup (  Section 19.6.8), and the cursor is positioned in a program in which "Standby" is set.

**Restrictions**

● **Restrictions after setting break conditions and skip range**

All settings of break condition and skip range are canceled when a data name or a library name is changed/deleted in a project.

● **Break in ST control syntax**

The following are the considerations when executing the step execution on an ST program contains ST control syntax.

- A break execution may be executed in a line of control syntax which is not calculated.

When the step execution is executed on the following program in which W10=0 is set for the break condition, the break execution is executed in the 6th line. Note that, however, since a calculation is not processed in the line where the break execution is executed, this break does not affect the calculation result.

ST line number	ST program	Operation
1	FOR W10 := 0 TO 3 DO	-
2	CASE W10 OF	-
3	0:	-
4	D0 := D0 + 1;	-
5	1..3:	-
6	D1 :=D1 +1;	When W10=0, this line is not processed but the break execution is executed.
7	END_CASE;	-
8	END_FOR;	-


- In step execution, a break execution is not executed in a RETURN syntax and an EXIT syntax.

When the step execution is executed on the following program, the break execution is not executed in the 3rd and 4th lines even if the break condition is satisfied.

ST line number	ST program	Operation
1	W0 := 0;	-
2	IF X0 THEN	-
3	RETURN;	The break execution is not executed in the RETURN syntax when X0=ON in the step execution. (The break execution is executed in the first line.)
4	END_IF;	-
5		-
6	FOR W0 := 0 TO 4 DO	-
7	IF X1 THEN	-
8	EXIT;	The break execution is not executed in the EXIT syntax when X1=ON in the step execution. (The break execution is executed in the 11th line.)
9	END_IF;	-
10	END_FOR;	-
11	W0 := 0;	-

● **Step execution on successive function blocks**

When function blocks are used successively in the ST program, even if a step execution is canceled in the process of the function blocks, the canceled-position cursor may be placed at one step before the next function block instruction. The following program is an example when a step execution is canceled in the process of the successive function blocks.




● **When using the same function blocks multiple times**

When the step execution is executed, a break position may move to the first instance at the timing of entering the second and the following instances. This phenomenon occurs when the instance created from the same function block in the program file is used multiple times.

## 19.6.1 Debugging procedure

The following flow chart explains the procedure to debug programs.



- \*1 : Section 18.2
- \*2 : Section 19.6.2
- \*3 : Section 19.6.3
- \*4 : Section 19.6.4
- \*5 : Section 19.6.6
- \*6 : Section 19.6.7
- \*7 : Section 19.6.5
- \*8 : Section 19.6.9



## 19.6.2 Setting break points

By setting a break point, a step execution can be canceled at a specific position in a program. Break points are set in: step unit for ladder program, and line unit for ST program. Break points can be set up to 64 points in an entire project.

### ■ Setting/canceling break points

Set/cancel break points.

#### Operating procedure

1. Move the cursor to the position to set a break point or cancel the set break point.
2. Select [Debug] ⇒ [Break Setting] ⇒ [Set/Cancel Break Point] (🔍).

A break point is set at the cursor position. When the break point is already set, it is canceled. Set break points are registered on the Break Point window.

<Example of break points (for ladder)>



<Example of break points (for ST)>

```

● D0.C := X3;
● MOV(MO), D0, D1;


```

#### Point

##### ● When break point overlaps with other indications

When a break point overlaps with a canceled-position cursor on the ladder editor, the canceled-position cursor is displayed as a priority. When a break point overlaps with other indications such as a skip range and mixed color is displayed at the overlapped position.

The following program is an example of overlapped indications.



17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX

INDEX

## ■ Enabling/disabling break points

Enable/disable set break points.

The break point function is executed at the position with enabled break point.

The break point function is not executed when the break point is disabled.

### Operating procedure


1. Move the cursor to the break point to be enabled/disabled.
2. Select [Debug] ⇒ [Break Setting] ⇒ [Enable/Disable Break Point] (🔧).

The break point at the cursor position is enabled/disabled.

<Example of disabled break point (for ladder program)>



<Example of disabled break point (for ST)>



## ■ Canceling all break points

Cancel all break points.

### Operating procedure

- Select [Debug] ⇒ [Break Setting] ⇒ [Cancel All Break Points] (🗑️).
- All break points are canceled.


## ■ Setting break conditions on Break Point window

Display a list of set break points.

Set break conditions and the number of execution counts for break points.

### Screen display

Select [View] ⇒ [Docking Window] ⇒ [Debug] ⇒ [Break Point] (📄).







### Operating procedure

- Set the items on the screen.

Item	Description
Enable/Disable	Display enabled/disabled status of break points. ● : Enabled ○ : Disabled
Data Name	Display program names to which break point is set.
Position	Display positions of set break points in a program. For ladder program: Step numbers displayed on the editor. For ST program: Line numbers
Program Content	Display program content of set break points. For ladder program: Instructions (list format), pointers (P), or interrupt pointers (I) For ST program: Text
Break Condition	Set break conditions. This item can be set for ladder programs only.
Always	Execute the break execution when scans are completed for a set number of times.
ON	Execute the break execution when the specified step/pointer is ON after scans are completed for a set number of times.
OFF	Execute the break executions when the specified step/pointer is OFF after scans are completed for a set number of times.
Rising	Execute the break execution when the specified step/pointer turns ON from OFF after scans are completed for a set number of times.
Falling	Execute the break execution when the specified step/pointer turns OFF from ON after scans are completed for a set number of times.
Execution Count	Set the number of scans until break execution is executed. This item can be set for ladder programs only.

### Screen button

-  Jump  
Jumps to the selected break point.
-  Enable/Disable  
Enables/disables the selected break point.
-  Cancel  
Cancels the selected break point.
-  Cancel All  
Cancels all break points.

### Point

- **Counting and resetting number of execution counts**  
The number of execution counts is counted/reset according to the following rules.
    - When two or more break points are passed in one scan, the passed number of times is counted as the number of execution counts.
    - Break points which are not passed by an instruction such as the jump instruction are not counted as the number of execution counts.
    - The execution count of all break points is reset for each break.
    - When changing the number of execution counts, the corresponding execution count of break point is reset.
-

### 19.6.3 Setting break devices

By setting a break device, a step execution can be canceled when the value of device/label satisfies the specific condition.

Break devices can be set up to 16 points in total of bit devices and word devices.

When a break device is set, a break execution is executed at the instruction which is the one after the execution of the calculation to satisfy the break condition.

In order to execute the break execution after the break condition is satisfied, disable or cancel the break devices.


#### ■ Setting/canceling break devices


Set/cancel break devices, or enable/disable set break devices.

The break device function is executed at the position with enabled break device.

The break device function is not executed when the break device is disabled.

#### Screen display

Select [View] ⇒ [Docking Window] ⇒ [Debug] ⇒ [Break Device] (  ).



Break device information list

17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## Operating procedure



### 1. Click the button.

A blank row is added to the last row of the break device information list.

### 2. Set the items on the screen.

Item	Description
Combination	–
Judge each break device (OR condition)	Select this to execute the break execution when any condition of break devices is satisfied.
Judge all break devices (AND condition)	Select this to execute the break execution when conditions of all break devices are satisfied.
Enable/Disable	Enable/disable the break device. Selected: Enabled Cleared: Disabled
Comparative Source (Device/Label)	Enter the comparative source device/label. For a local label, enter data in a 'program name/label name' format.
Condition	Select the comparative condition. The condition selection changes according to the comparative source device/label.
Rising	Execute the break execution when the comparative device/label rises.
Falling	Execute the break execution when the comparative device/label falls.
=	Execute the break execution when the value of comparative source device/label matches with the value of comparative target device/label.
<	Execute the break execution when the value of comparative source device/label is smaller than the value of comparative target device/label.
>	Execute the break execution when the value of comparative source device/label is larger than the value of comparative target device/label.
<=	Execute the break execution when the value of comparative source device/label is the same as or less than the value of comparative target device/label.
>=	Execute the break execution when the value of comparative source device/label is the same as or more than the value of comparative target device/label.
<>	Execute the break execution when the value of comparative source device/label does not match with the value of comparative target device/label.
Comparative Target (Value/Device/Label)	Enter a comparative target device/label.
Comparative Type	Set the data type to compare comparative source and comparative target.


## Screen button

-  Closes the selected break device.
-  Closes all break points.

## ■ Canceling all break devices

Cancel all break devices.

## Operating procedure

- **Select [Debug] ⇒ [Break Setting] ⇒ [Cancel All Break Devices] .**  
All break devices are canceled.

## 19.6.4 Setting skip ranges

A skip range is a range in which a program will not be executed during the step execution. A range can be set in ladder block unit for ladder programs. Up to 16 ranges can be set in a project.

### ■ Setting/canceling skip ranges

Set a skip range, or cancel the set skip range.

#### Operating procedure

#### 1. Select a ladder block to set a skip range.

Multiple ladder blocks can be selected by selecting a range.

#### 2. Select [Debug] ⇒ [Skip Setting] ⇒ [Set/Cancel Skip Range] ( ).

The skip range is set. When the skip range is already set, it is canceled.

Multiple skip ranges set within the selected ladder blocks are all canceled.

Set skip ranges are registered on the Skip Range window.

<Example of skip range>



#### Point

#### ● Skip range setting in ST programs

Skip ranges cannot be set in ST programs.

#### ● When skip range overlaps with other indications

When a skip range overlaps with other indications such as a break point and mixed color is displayed at the overlapped position.

### ■ Enabling/disabling skip ranges

Enable/disable the skip range at the cursor position.

The program of the ladder block with enabled skip range is not executed.

When the skip range is disabled, the program of the ladder block with set skip range is also executed.

#### Operating procedure

#### 1. Move the cursor to the skip range to be enabled/disabled.

#### 2. Select [Debug] ⇒ [Skip Setting] ⇒ [Enable/Disable Skip Range] ( ).

The skip range at the cursor position is enabled/disabled.

<Example of disabled skip range>



17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX

INDEX

## ■ Canceling all skip ranges

Cancel all skip ranges.

### Operating procedure


- Select [Debug] ⇒ [Skip Setting] ⇒ [Cancel All Skip Ranges] (🗑️).  
All skip ranges are canceled.

## ■ Displaying Skip Range window

Display a list of set skip ranges.

### Screen display

Select [View] ⇒ [Docking Window] ⇒ [Debug] ⇒ [Skip Range] (📄).



### Display contents

Item	Description
Enable/Disable	Enable/disable the skip range. <input checked="" type="checkbox"/> : Enabled <input type="checkbox"/> : Disabled
Data Name	Display the program name to which the skip range is set.
Start	Display the start position of the skip range with a step number.
End	Display the end position of the skip range with a step number.

### Screen button

- Jump  
Jumps to the start position of the selected skip range.
- Enable/Disable  
Enables/disables the selected skip range.
- Cancel  
Cancels the selected skip range.
- Cancel All  
Cancels all skip ranges.



## 19.6.5 Executing program one step at a time

Execute programs one step at a time.

### Operating procedure

- Select [Debug] ⇒ [Step Execution] ⇒ [Step Execution] (  ).

One instruction of a program is executed for ladder program, and one line of a program is executed for ST program.

When the step execution is executed on a function block in the program, the step execution is executed on the program in the function block.

The canceled-position cursor is displayed on the function block while the step execution is being executed on the program in the function block.

## 19.6.6 Executing program until condition is satisfied

Execute a program until the condition is satisfied.

### Operating procedure

- Select [Debug] ⇒ [Step Execution] ⇒ [Break Execution] (  ).

When the break condition is satisfied, the break execution is stopped.

### Point

- **When multiple break conditions are satisfied simultaneously**

When the conditions of break point and break device are satisfied simultaneously, the Break Point window is activated and the cursor moves to the break point where the condition is satisfied.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## 19.6.7 Canceling step execution



Cancel the step execution.

### Operating procedure

- Select [Debug] ⇒ [Step Execution] ⇒ [Cancel] (F10).

The step execution is canceled.

The canceled-position cursor is displayed at the canceled position.



### Point

#### ● Canceled-position cursor

The canceled-position cursor is displayed on the program editor in which the step execution is executed as described below.

- The step execution is canceled.
- The step execution completed without satisfying the break condition.
- The break condition is satisfied and the step execution is canceled.


## 19.6.8 Setting options for step execution

Set options for the step execution function.

Set the start position of the step execution and the setting for the automatic step execution.

### Screen display

Select [Debug] ⇒ [Step Execution] ⇒ [Execution Option] (☰).



### Operating procedure

1. Set the items on the screen.

Item	Description
Execution Start Position	Set the execution position of the step execution. The setting will be changed depending on the last operation that is performed. For details, refer to Point in this section.
From start	Execute the step execution from the start of the program according to the setting set on the <<Program>> tab of PLC parameter.
From canceled position	Execute the step execution from the canceled position.
From current cursor position	Execute the step execution from the current cursor position on the active program editor. When the program editor is not active, the operation is the same as that of "From start".
Automatic Step Execution	–
Execute step execution automatically	Select this to execute the step execution automatically. The automatic step execution is executed by executing the step execution after setting this item.
Repetition Count	Set the number of times the step execution is executed automatically. When this item is blank, the step execution is executed repeatedly until the break condition is satisfied or the step execution is canceled. This item is applicable when "Execute Step execution automatically" is selected.
Execution Interval	Set the cycle of automatic step execution in 100ms unit. This item is applicable when "Execute Step execution automatically" is selected.

2. Click the  button.

**Point****● Setting execution start position**

The setting of the execution start position will be changed depending on the last operation that is performed. The following table shows the execution start position corresponding to the operation that is performed.

Last-performed operation	Execution Start Position
Simulation start, step execution stop	From start
Cancellation, break execution, step execution	From canceled position

## 19.6.9 Stopping step execution

Stop the step execution.

### Operating procedure

- Select [Debug] ⇒ [Step Execution] ⇒ [Stop] (⏏).

The step execution is stopped.

The canceled-position cursor on the program editor is hidden.

# 19.7 Using CPU Module Logging Configuration Tool




\*1 : High-speed Universal model QCPU and Universal model process CPU only  
 \*2 : Not supported by L02S and L02S-P.

This section explains how to start CPU Module Logging Configuration Tool from the menu of GX Works2.  
 To start CPU Module Logging Configuration Tool, install the logging configuration tool in advance.  
 For the operation methods, refer to the following manual.  
 ☞ QnUDVCPULCPU User's Manual (Data Logging Function)

## Screen display

Select [Tool] ⇒ [Logging Configuration Tool].



### Point

- **Supported versions of logging configuration tool**  
 The following table shows the supported versions of logging configuration tool for each programmable controller type.

Programmable controller type	Version of logging configuration tool
LCPUL	1.00A or later
High-speed Universal model QCPU	1.25B or later
Universal model process CPU	1.30G or later

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX



---

# 20 OPERATING PROGRAMMABLE CONTROLLER CPU

This chapter explains how to change the execution status and setting the clock of the programmable controller CPU from GX Works2.

20.1	Remote Operation of Programmable Controller CPU	20 - 2
20.2	Operating Redundant CPUs	20 - 6
20.3	Formatting Programmable Controller CPU Memory	20 - 8
20.4	Clearing Programmable Controller Memory	20 - 10
20.5	Arranging Programmable Controller Memory	20 - 13
20.6	Setting Clock on Programmable Controller CPU	20 - 14
20.7	Registering/Canceling Display Module Menu	20 - 16
20.8	Start Ethernet Adapter Module Configuration Tool	20 - 18

## 20.1 Remote Operation of Programmable Controller CPU




This section explains how to switch the RUN/STOP status of the programmable controller CPU and allowing the memory card removal from GX Works2.


### Screen display

Select [Online] ⇒ [Remote Operation].


<High Performance model QCPU>



<FXCPU>



<Redundant CPU>





## Operating procedure

### 1. Set the items on the screen.

Item	Description
Connection Channel List	Display the information of the connection destination.
Specify Execution Target*1,*2	Set the target station of remote operation.
Currently Specified Station	Select this to perform the remote operation only on the station specified in the connection destination setting.
All Stations	Select this to perform the remote operation on the station specified in the connection destination setting and all the stations on the same network. Set a target network with "Specify Module No."*3 or "Specify Network No.".
Specified Group	Select this to perform the remote operation on the station specified in the connection destination setting and each station of the specific group on the specified network. Set a target network with "Specify Module No." or "Specify Network No.", and set a group number with "Specify Group No.".
Specify both systems	Select this to perform the remote operation on the both systems (control system and standby system) with the route specified on the <u>Transfer Setup</u> screen. This item is applicable to Redundant CPU only.
Operation	Select the operation details.
RUN	Select this to switch the operating status of the programmable controller CPU.
STOP	
PAUSE*2	
Latch Clear*2	
RESET*2	
Remove Memory Card*2,*3	Select this to remove the memory card while the programmable controller CPU is ON. "Specify Execution Target" cannot be set. The station set as a connection target can only be executed.
Operation during RUN*2	Set the status of the device memory and signal flow when the programmable controller CPU is switched to RUN.
Device Memory	Select whether to clear the device memory.
Signal Flow	Select whether to retain the signal flow.
Redundant status*2,*3	Display the operation mode and system status of Redundant CPU. This item is applicable to Redundant CPU only.

\*1 : When the target network is CC-Link IE Field Network, the target station can be specified with "Currently Specified Station" and "All Stations".

\*2 : Not supported by FXCPU.

\*3 : Not supported by LCPU.

### 2. Click the button.

The operating status of the programmable controller CPU is changed.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

**Point**

● **Remote operation and RUN/STOP switch for QCPU (Q mode)/LCPU**

When operation to the programmable controller CPU differs among controls by the remote operation, RUN/STOP switch, and remote RUN/PAUSE contact, the programmable controller CPU operates according to the priority shown below:

Operation to the programmable controller CPU	Priority
STOP	1
PAUSE	2
RUN	3

The following table shows the operating status after RUN/STOP switching on the programmable controller CPU or remote RUN/PAUSE contact operation.

		Programmable controller CPU switch		Remote RUN/STOP contact is ON. (The programmable controller CPU is in STOP.)
		RUN	STOP	
Remote operation	RUN	RUN	STOP	STOP
	STOP	STOP	STOP	STOP
	PAUSE	PAUSE	STOP	STOP
	Latch clear	Inoperable*1	Latch clear	Latch clear
	RESET*2	Inoperable*1	RESET	RESET

\*1 : Operable when the programmable controller CPU is switched to STOP by remote operation.

\*2 : The remote reset operation must be enabled on the <<PLC System>> tab of PLC parameter.

● **Remote reset operation on Redundant CPU**

A remote reset operation on Redundant CPU may not be performed depending on the status of the control system or the standby system.

The following table shows the CPU status at a remote reset operation and the operation results.

○: Applicable  
×: Not applicable

Current redundant CPU status		Remote reset operation result	
Control system status	Standby system status	Control system	Standby system
RUN/PAUSE	RUN/PAUSE	×	×
	STOP*1/Stop error		○
STOP*1/Stop error	RUN*2/PAUSE	○	×
	STOP*1/Stop error		○

\*1 : A remote reset operation cannot be performed when a remote operation is performed on a Redundant CPU from other GX Works2.

\*2 : A system switch occurs and the system is activated.

● **Considerations for removing a memory card**

Turn OFF SM605 to allow the memory card removal.


If the memory card is removed when not allowed, the programmable controller CPU becomes in an error status.

**Point**

● **Counting modules to set "Specify Module No."**

Physically count the module from the programmable controller side, and specify the number. However, note that the target modules to be counted are MELSECNET/H network modules and CC-Link IE Controller Network modules only. Do not include other modules such as Ethernet modules, CC-Link master/local modules, and CC-Link IE Field Network modules.

The following figure shows an example of counting modules.



● **Remote operation of FXCPU**

M8035 (forced RUN mode), M8036 (forced RUN command), and M8037 (forced STOP command) are controlled. The remote operation is possible regardless of the status of the programmable controller CPU side RUN/STOP switch. Programmable controller CPUs that support the remote operation are as follows: FX1S, FX1N, FX1NC, FX2N, FX2NC, FX3S, FX3G, FX3GC, FX3U, and FX3UC

**Restrictions**

● **Performing remote operation on other stations**

When performing the remote operation on other stations with "All Stations" or "Specified Group", the remote operation cannot be performed on the following modules.

- ACPU/QnACPU

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

## 20.2 Operating Redundant CPUs




\*1 : Redundant CPU only

This section explains how to switch the system, change the operation mode, and copy memory data from the control system to the standby system from GX Works2.

This function cannot be performed in the debug mode.

### Screen display


Select [Online] ⇒ [Redundant Operation].



### Operating procedure

1. Set the items on the screen.

Item	Description
Connection channel list	Display the information of the specified connection target.
Redundant operation	Select a redundant operation to be performed.
System switching	Change the system of the current connection target from the control system to the standby system.
Change operation mode	Change the operation mode on the current connection target. The mode can be changed from backup mode to separate mode, and vice versa.
Copy memory	Copy data of standard RAM, standard ROM, and program memory from the control system to the standby system.
Memory copy progress status	Display memory copy progress. "Memory copy failed" is displayed when the memory copy fails.
Redundant status	Display the operation mode and the system status of Redundant CPU.

2. Click the  button.

**Point** 

● **Considerations of memory copy function**

The following functions cannot be performed on the control system while the memory copy function is being performed.

- Writing data to a running CPU.
- Writing data to a programmable controller CPU (flash ROM)
- Switching systems
- Changing operation mode
- Copying memory data in a redundant operation
- Formatting programmable controller CPU memory
- Copying program memory data to ROM

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

## 20.3 Formatting Programmable Controller CPU Memory




This section explains how to format the programmable controller CPU memory or the memory card. The function is used when using the programmable controller CPU and the memory card for the first time or clearing all data stored in them.

However, the Flash card cannot be formatted using this function. (Flash cards do not require formatting.)

### Screen display

Select [Online] ⇒ [PLC Memory Operation] ⇒ [Format PLC Memory].



### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Connection Channel List	Display the information of the connection destination setting.
Target Memory	Set the memory to be formatted.
Format Type	Select the format type.
Do not create a user setting system area (the required system area only)	Select this to create the necessary system area only.
Create a user setting system area	Select this to create the necessary system area, the area for high-speed monitoring from another station, and the area for enabling Online program change of multiple blocks.

#### 2. Click the button.

The target memory is formatted.

## Format types

The system area is an area created on the programmable controller CPU memory. The system area consists of the 'Necessary system area' automatically created upon formatting the programmable controller CPU memory and 'User setting system area' created by the user. In the necessary system area, data such as local devices are stored.

The user setting system areas are set for the following purposes:

### ● Area for enabling high-speed monitoring from another station

The area is set to accelerate monitoring from peripheral such as GX Works2 connected to a serial communication module and other communication module.

Change the capacity according to the number of device points (capacity) to be monitored through a serial communication module or other communication module and the volume of other user data to be stored in the program memory.

The setting range for Basic model QCPU, and Universal model QCPU (Q00UJ/Q00U/Q01U) is 0 to 3k steps.

The setting range for High Performance model QCPU, Process CPU, Redundant CPU, Universal model QCPU (except for Q00UJ/Q00U/Q01U), and LCPU is 0 to 15k steps.

### ● Area for enabling Online program change of multiple blocks

This area is set to enable Online program change of multiple locations (multiple blocks) simultaneously.

The following table shows the restrictions on Online program change of multiple blocks according to the capacity.

Since 4k steps are secured automatically other than for the program memory, this setting is not required for Universal model QCPU and LCPU.

Description	Secured system area capacity for Online program change of multiple blocks						
	Basic model QCPU				High Performance model QCPU/ Process CPU/Redundant CPU		
	Function version A	Function version B or later			0k steps	2k steps	4k steps
	–	0k steps	1.25k steps	2.5k steps			
The number of blocks for simultaneous writing	Online program change of multiple blocks is not possible.	Online program change of multiple blocks is not possible.	Max. 32 blocks	Max. 64 blocks	Online program change of multiple blocks is not possible.	Max. 32 blocks	Max. 64 blocks
The number of steps per block for writing			Max. 512 steps	Max. 1024 steps		Max. 512 steps	Max. 1024 steps
The number of used pointers (P, I) per block for writing			Not limited			Max. 50	Max. 100

### Point

#### ● Device memory

The device memory values cannot be cleared with the Memory format function.

To clear the device memory values, execute [Online] ⇒ [PLC Memory Operation] ⇒ [Format PLC Memory].  
(☞ Section 20.4)

#### ● Formatting a memory card

To format an SRAM card, ATA card or SD memory card to be used on the programmable controller CPU, select [Online] ⇒ [PLC Memory Operation] ⇒ [Format PLC Memory].

If it is formatted using other functions such as the Windows®, the card may not be usable when it is installed to a programmable controller CPU.

#### ● Memory in which user setting system areas can be created

The areas can be created only in the program memory.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## 20.4 Clearing Programmable Controller Memory



This section explains how to initialize device memory data on the programmable controller CPU and file registers stored in the memory card and setting them to '0'.


### ■ QCPU (Q mode)/LCPU

Initialize device memory data on the programmable controller CPU and file registers stored in the memory card and set them to '0'.

However, the memory clear function is not available for standard ROM/Flash cards/SD memory cards.

### Screen display

Select [Online] ⇒ [PLC Memory Operation] ⇒ [Clear PLC Memory].



### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Connection Channel List	Display the information of the connection destination setting.
Clear Device's whole Memory	Select this to clear the device memory data.
Include Latch	Select this to clear device data in the latch range also. The device data for which latch clear is disabled is also cleared.
Clear all File Registers	Select this to clear the file register data.
Target Memory*1	Select the memory in which file registers are stored.
All Files*1	Select this to clear all file registers in the target memory.
Specific File*1	Select this to clear the selected file register memory. Select a file name of the file register.

\*1: For QCPU (Q mode) only

#### 2. Click the button.

The target memory data is cleared.



**Point**

● **Operation of the PLC Memory Clear function during the monitoring of local devices**


When the "Clear Device's whole Memory" operation is executed during the monitoring of local devices, local devices are cleared in the programs selected in the 'local device monitoring target selection field' on the monitoring status bar.

■ **FXCPU**

Initialize device memory data in FXCPU and resetting them to '0'.

**Screen display**


Select [Online] ⇒ [PLC Memory Operation] ⇒ [Clear PLC Memory].



**Operating procedure**

1. **Set the items on the screen.**

Item	Description
Connection Channel List	Display the information of the connection destination setting.
Target Data	Select the device memory to be cleared.
PLC Memory	Select this to clear all data. (Programs, comments, parameters, file registers, device memory, and extended file registers)
Data Device	Select this to clear all registers. (Data registers, file registers, RAM file registers, special registers, extended registers, and extended file registers)
Bit Device	Select this to clear all bit devices. (X, Y, M, S, T, and C) Additionally, the current values of 'T' and 'C' are reset to '0'.

2. **Click the  button.**

The target data is cleared.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

**Point****● Executing condition of the memory clear for FXCPU**

Item	Memory
PLC memory	Available for the built-in memory, and RAM/EEPROM (PROTECT switch OFF)/FLASH memory (PROTECT switch OFF) cassette. Not available for the EEPROM (PROTECT switch ON)/FLASH memory (PROTECT switch ON) and EPROM cassette.
Data device	Equivalent to executing condition to PLC memory
Bit device	Available for all the memory.

**● Considerations when using FXCPU**


- Execute this function when the programmable controller CPU is in STOP status. Memory data cannot be cleared in RUN status.
- When the status of the programmable controller CPU is changed to STOP by the remote operation, bit devices cannot be cleared. Execute the PLC memory clear function after switching the status of the programmable controller CPU to STOP.
- When the PLC memory clear function is executed while an FX3S/FX3G/FX3GC programmable controller CPU and an Ethernet port are connected directly, a communication error caused by Windows Firewall may occur. In this case, open the Control Panel and specify GX Works2 as an 'Allowed apps', 'Allowed program', or 'exception' in the Windows Firewall setting.

## 20.5 Arranging Programmable Controller Memory




This section explains how to secure consecutive free memory areas by arranging the data stored in program memory/standard RAM of the programmable controller CPU or memory card. Use this function to rearrange files whose arrangement became discontinuous by operations such as Delete PLC Data. However, the Memory arrangement function is not available for standard ROM/Flash cards/SD memory cards.

The following figure shows how consecutive free areas are created with the Memory arrangement function after Delete PLC Data.



### Screen display

Select [Online] ⇒ [PLC Memory Operation] ⇒ [Arrange PLC Memory].



### Operating procedure

1. Set the items on the screen.

Item	Description
Connection Channel List	Display the information of the connection destination setting.
Target Memory	Set the memory to be arranged.

2. Click the **Execute** button.

The target memory is arranged.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX


## 20.6 Setting Clock on Programmable Controller CPU



This section explains how to set the clock on a programmable controller CPU.  
The clock setting function is not supported by FX0s, FX0, and FX1.

### Screen display

Select [Online] ⇒ [Set Clock].



### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Date and time	Set the date and time.
Specify Execution Target*1,*2	Set the target station whose clock is to be set.
Currently Specified Station	Select this to set the clock only upon the station specified in the connection destination setting.
All Stations	Select this to perform the remote operation to the station specified in the connection destination setting and all the stations on the specified network. Set a target network with "Specify Module No."*3 or "Specify Network No.".
Specified Group	Select this to perform the remote operation to the station specified in the connection destination setting and each station of the specific group on the specified network. Set a target network with module mounted on the station specified in the connection destination setting for "Specify Module No." or "Specify Network No.", and set a group number with "Specify Group No.".

\*1 : Not supported by FXCPU.

\*2 : The target station can be specified with "Currently Specified Station" or "All Stations" when the target network is CC-Link IE Field Network.

\*3 : Not supported by LCPU.

#### 2. Click the **Execute** button.

The programmable controller CPU clock is set.

### Screen button



Applies the time of personal computer to the 'date and time' boxes.

**Point** 

● **Clock setting for QCPU (Q mode)/LCP**

For QCPU (Q mode)/LCP, the clock setting can be set regardless of the ON/OFF status of the clock setting device 'SM1028'.

Note that the ON/OFF status of 'SM1028' does not change upon clock setting.

● **Considerations of the clock setting**

In the clock setting, a time-lag error may appear due to the span of transfer.

● **Counting modules to set "Specify Module No."**

Refer to Point in Section 20.1.

**Restrictions** 

● **Performing clock setting to other stations**

When performing the clock setting to other stations with "All Stations" or "Specified Group", the clock setting cannot be performed to the following modules.

- ACPU/QnACPU

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

## 20.7 Registering/Canceling Display Module Menu



\*1 : Not supported by L02S and L02S-P.

This section explains how to register/cancel menu items to/from a standard ROM or SD memory card to operate the intelligent function modules using the L CPU display module.

Use this function to confirm or change each setting of intelligent function module by operating the display module.

For details of functions and operations of display module, refer to the following manual.


☞ MELSEC-L CPU Module User's Manual (Function Explanation, Program Fundamentals)

For details of intelligent function modules which support registration/cancellation of display module menu, and functions which can be performed on each intelligent function module, refer to the following manual.

☞ Manual of the intelligent function module to be used

### Screen display

Select [Online] ⇒ [Register/Cancel Display Module Menu].



### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Target Memory	Select the target memory to which the display module menu items are to be registered/canceled.
Register/Cancel Menu	Select registration/cancellation of the menus.
Target Module	Select the target module of the menu items to be registered.
Menu Language	Select the language of the menu items.

#### 2. Click the button.

The display module menu items are registered/canceled.

**Point**
**● Modules and corresponding GX Works2 versions**

The following table shows the modules and corresponding GX Works2 versions for registering/canceling the display module menu.

Module type	Module name	Version
Analog	L60AD4 L60DA4	GX Works2 Version 1.24A
Temperature control	L60TCTT4 L60TCTT4BW L60TCRT4 L60TCRT4BW	GX Works2 Version 1.62Q
Counter	LD62 LD62D	GX Works2 Version 1.31H
Serial communication	LJ71C24 LJ71C24-R2	GX Works2 Version 1.24A
CC-Link	LJ61BT11	

17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## 20.8 Start Ethernet Adapter Module Configuration Tool




This section explains how to start the Ethernet adapter module configuration tool.  
For details of Ethernet adapter module configuration tool, refer to the following manual.

☞ **CC-Link IE Field Network Ethernet Adapter Module User's Manual**

### Operating procedure

1. Select [Tool] ⇒ [Ethernet Adapter Module Configuration Tool].

The Ethernet Adapter Module Configuration Tool screen is displayed.



2. Enter the IP address or domain name of the Ethernet adapter module to "Connection Destination", and click the **OK** button.

A default web browser is activated and a start screen of the Ethernet adapter module configuration tool is displayed.



---

# 21      **DIAGNOSING PROGRAMMABLE CONTROLLER STATUS**

This chapter explains how to display system status and error codes of the programmable controller CPU.

21.1	Diagnosing Programmable Controller CPU	21 - 2
21.2	Diagnosing MELSECNET	21 - 14
21.3	Diagnosing CC-Link IE Controller Network	21 - 28
21.4	Diagnosing CC-Link IE Field Network	21 - 38
21.5	Diagnosing CC-Link IE Field Network Basic	21 - 51
21.6	Diagnosing CC-Link and CC-Link/LT	21 - 53
21.7	Diagnosing Ethernet	21 - 66
21.8	Executing Sensor/Device Monitoring	21 - 88
21.9	System Monitor	21 - 89
21.10	Changing Modules Online	21 - 104
21.11	Built-in I/O Module Tools	21 - 106

## 21.1 Diagnosing Programmable Controller CPU

This section explains how to display system status and error codes of the programmable controller CPU.

### 21.1.1 Diagnosing QCPU (Q mode), LCPU, communication head module, and remote I/O module



Display the programmable controller CPU status.

#### Screen display

Select [Diagnostics] ⇒ [PLC Diagnostics].

<QCPU (Q mode)>

CPU operating status

Image of programmable controller CPU

PLC	Status	No.	Current Error(Abbreviation)	Current Error(Detail)	Year/Month/Day	Time
1	▲	3300	SP. PARA ERROR	SP. PARA ERROR	2000-01-02	21:28:18
2						
3						
4						

Status	No.	Error Message(Abbreviation)	Error Message(Detail)	Year/Month/Day	Time
▲	3300	SP. PARA ERROR	SP. PARA ERROR	2000-01-02	21:28:18
▲	1600	BATTERY ERROR	BATTERY ERROR	2000-01-02	21:28:15
▲	1500	AC/DC DOWN	AC/DC DOWN	2000-01-02	10:07:58
▲	2200	MISSING PARA	PARAMETER ERROR	2000-01-01	22:30:25
▲	1500	AC/DC DOWN	AC/DC DOWN	2000-01-01	22:28:41
▲	1500	AC/DC DOWN	AC/DC DOWN	2000-01-01	03:32:04
▲	1500	AC/DC DOWN	AC/DC DOWN	2000-01-01	02:33:41
▲	2200	MISSING PARA	PARAMETER ERROR	2000-01-01	02:33:20
▲	2200	MISSING PARA	PARAMETER ERROR	2000-01-01	02:33:12
▲	1500	AC/DC DOWN	AC/DC DOWN	2000-01-01	02:31:38
▲	1500	AC/DC DOWN	AC/DC DOWN	2000-01-01	01:30:07
▲	1500	AC/DC DOWN	AC/DC DOWN	2000-01-01	01:23:55
▲	1500	AC/DC DOWN	AC/DC DOWN	2000-01-01	01:27:56

<LCPU>

CPU operating status

Image of programmable controller CPU

PLC	Status	No.	Current Error(Abbreviation)	Current Error(Detail)	Year/Month/Day	Time
1	▲	2501	CANT EXE. PRG.	CANT EXE. PRG.	2012-01-05	16:36:40

Status	No.	Error Message(Abbreviation)	Error Message(Detail)	Year/Month/Day	Time
▲	2501	CANT EXE. PRG.	CANT EXE. PRG.	2012-01-05	16:36:40

<Communication head module>

CPU operating status → The function menu is extended from the PLC image.

Image of programmable controller CPU →

Model Name	Operation Status	Switch
LJ72GF15-T2	RUN	RUN

PLC	Status	No.	Current Error(Abbreviation)	Current Error(Detail)	Year/Month/Day	Time
1	0		No Error			

Status	No.	Error Message(Abbreviation)	Error Message(Detail)	Year/Month/Day	Time
1500	AC/DC DOWN	AC/DC DOWN	AC/DC DOWN	2000-1-1	0:37:1
1500	AC/DC DOWN	AC/DC DOWN	AC/DC DOWN	2000-1-1	0:0:26
1500	AC/DC DOWN	AC/DC DOWN	AC/DC DOWN	2000-1-1	0:22:6
9900	NETWORK ERROR	NETWORK ERROR	NETWORK ERROR	2000-1-1	0:0:0
1500	AC/DC DOWN	AC/DC DOWN	AC/DC DOWN	2000-1-1	0:4:7
3105	LINK PARA. ERROR	LINK PARA. ERROR	LINK PARA. ERROR	2000-1-1	0:3:46
1500	AC/DC DOWN	AC/DC DOWN	AC/DC DOWN	2000-1-1	0:3:45
3105	LINK PARA. ERROR	LINK PARA. ERROR	LINK PARA. ERROR	2000-1-1	0:2:34
1500	AC/DC DOWN	AC/DC DOWN	AC/DC DOWN	2000-1-1	1:24:32
3105	LINK PARA. ERROR	LINK PARA. ERROR	LINK PARA. ERROR	2000-1-1	0:2:34
1500	AC/DC DOWN	AC/DC DOWN	AC/DC DOWN	2000-1-1	0:3:15
3105	LINK PARA. ERROR	LINK PARA. ERROR	LINK PARA. ERROR	2000-1-1	0:3:12
9900	NETWORK ERROR	NETWORK ERROR	NETWORK ERROR	2000-1-1	0:2:34

<Remote I/O module>

CPU operating status → The function menu is extended from the PLC image.





Image of programmable controller CPU →

Model Name	Operation Status	Switch
QJ72LP25-25	----	----

PLC	Status	No.	Current Error(Abbreviation)	Current Error(Detail)	Year/Month/Day	Time
1	▲	3103	LINK PARA. ERROR	LINK PARA. ERROR	2000-0-0	0:0:0
2						
3						
4						

Status	No.	Error Message(Abbreviation)	Error Message(Detail)	Year/Month/Day	Time
▲	3103	LINK PARA. ERROR	LINK PARA. ERROR	2000-0-0	0:0:0


**Display contents**

Item	Description																																	
Monitor Status	Display the current monitor status.																																	
Connection Channel List	Display the connection route which has been set.																																	
CPU operating status	<ul style="list-style-type: none"> <li>● Single CPU system Display the operating status and switch status of the programmable controller CPU. For Redundant CPU, an enable/disable state of manual switching and a tracking communication status are also displayed.</li> <li>● Multiple CPU system (QCPU (Q mode) only) Display the operating status and the switch status of CPU No. 1 to No. 4.</li> <li>• "Uninstallable/Blank" is displayed for a slot with no module mounted.</li> </ul>																																	
Image of programmable controller CPU	Perform online operations of the programmable controller CPU. (For details, see Section 21.1.4 "Online operations")																																	
Error Information	Select this to display the current error information of the programmable controller CPU.																																	
Continuation Error Information*1	<p>Select this to clear user specified errors and minor errors.</p> <p>To clear errors, select the errors and click the <b>Clear Continuation Error</b> button.</p> 																																	
PLC Status Information	<p>Select this to display the status information of the programmable controller CPU. Display contents differ according to the programmable controller CPU. QCPU (Q mode)/LCPU</p> <table border="1" data-bbox="729 1155 1326 1402"> <thead> <tr> <th>Parameter</th> <th>Valid Drive Information</th> <th>Drive0 (Program Memory)</th> </tr> </thead> <tbody> <tr> <td>Program Memory</td> <td>Write Count</td> <td>210 Times</td> </tr> <tr> <td>Standard ROM</td> <td>Write Count</td> <td>1 Times</td> </tr> <tr> <td>Battery Life Extension</td> <td></td> <td>Invalid</td> </tr> <tr> <td>Battery Use Level</td> <td></td> <td></td> </tr> <tr> <td>IC Card Type Drive1</td> <td></td> <td>Not Exist</td> </tr> <tr> <td>IC Card Type Drive2</td> <td></td> <td>Not Exist</td> </tr> <tr> <td>Backup Information</td> <td></td> <td>-</td> </tr> <tr> <td>Restore Information</td> <td></td> <td>-</td> </tr> </tbody> </table> <p>Communication head module/Remote I/O module</p> <table border="1" data-bbox="729 1464 1326 1523"> <thead> <tr> <th>Parameter</th> <th>Valid Drive Information</th> <th>Drive 0 (Parameter Memory)</th> </tr> </thead> <tbody> <tr> <td>Parameter Memory</td> <td>Write Count</td> <td>80 Times</td> </tr> </tbody> </table>	Parameter	Valid Drive Information	Drive0 (Program Memory)	Program Memory	Write Count	210 Times	Standard ROM	Write Count	1 Times	Battery Life Extension		Invalid	Battery Use Level			IC Card Type Drive1		Not Exist	IC Card Type Drive2		Not Exist	Backup Information		-	Restore Information		-	Parameter	Valid Drive Information	Drive 0 (Parameter Memory)	Parameter Memory	Write Count	80 Times
Parameter	Valid Drive Information	Drive0 (Program Memory)																																
Program Memory	Write Count	210 Times																																
Standard ROM	Write Count	1 Times																																
Battery Life Extension		Invalid																																
Battery Use Level																																		
IC Card Type Drive1		Not Exist																																
IC Card Type Drive2		Not Exist																																
Backup Information		-																																
Restore Information		-																																
Parameter	Valid Drive Information	Drive 0 (Parameter Memory)																																
Parameter Memory	Write Count	80 Times																																
Serial Communication Error*2	<p>Monitor the programmable controller CPU when the serial communication function is set.</p> <p>Error information is cleared by clicking the <b>Clear</b> button.</p> <table border="1" data-bbox="735 1637 1321 1774"> <tbody> <tr> <td>Overrun Error</td> <td>Normal</td> </tr> <tr> <td>Parity Error</td> <td>Illegal</td> </tr> <tr> <td>Framing Error</td> <td>Illegal</td> </tr> </tbody> </table>	Overrun Error	Normal	Parity Error	Illegal	Framing Error	Illegal																											
Overrun Error	Normal																																	
Parity Error	Illegal																																	
Framing Error	Illegal																																	
Change the window size and position after error jump	Select this to downsize the PLC Diagnostics screen and move it to the upper left of the entire screen when the error jump is executed.																																	
Error History	Display the latest error history by clicking the <b>Error History</b> button.																																	
Occurrence Order Display	Sort error history in ascending/descending order.																																	
Status Icon Legend	Display the status icons on the screen. (see Section 21.1.3 "Error icons")																																	

\*1 : For High-speed Universal model QCPU, Universal model process CPU, and LCPU only

\*2 : For Q00UJ/Q00U/Q01U/Q02U/QnUD(H)CPU only

## Screen button

- **System Image...**  
Displays the illustration of the connection route which has been set.
- **Error Jump / Error Jump (Not supported by communication head module and remote I/O module)**  
Jumps the screen display to the sequence program step number corresponding to the selected error item/error history item.  
However, jump is not applicable in the following cases.
  - The error is not a program error.
  - The error step information does not exist.
  - The information of the program number and SFC step number of SFC block or the transition number does not exist.
  - SFC program error of FXCPU.
  - The label program is not compiled.
- **Error Clear**  
Clears the current error information.
- **Error Help / Error Help**  
Displays the explanation screen corresponding to the error number of the selected error item/error history item.
- **Error History**  
Displays the latest error history.
- **Create CSV File**  
Saves the error history being displayed in a file in the CSV file format.
- **Operation History(1) (High-speed Universal model QCPU and Universal model process CPU only)**  
Displays the operation history of a CPU module. (  ■ Displaying operation histories)

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX


**Point**

● **Displaying the Error Details screen**

The following Error Details screen is displayed by double-clicking the Present Error column or the error item in the Error History display column.

SD5 to 15 (Common Error Information) and SD16 to 26 (Individual Error Information) of the programmable controller CPU are displayed on the Error Details screen.


For details, refer to the manual of the programmable controller CPU module.



● **"Change the window size and position after error jump" check box**

When "Change the window size and position after error jump" is selected and the error jump is executed, the PLC Diagnostics screen is downsized as shown below. This function applies when executing the error jump on either Present Error column or Error History display column.

The screen returns to the original size by clicking the Restore the Window Size button.



● **When error is not found at error jump destination**

In the following conditions, an error may not be found at the error jump destination.

- When the program of the open project does not match with the program on the programmable controller CPU.
- When diagnosing programmable controller other than the one set as a connection destination in the project.

Example) When a module is selected from the CC IE Control Diagnostics and the System Monitor is activated, and the PLC Diagnostics is activated from the activated System Monitor.

● **Confirming operation mode of Redundant CPU**

The operation mode of Redundant CPU can be confirmed with the 'BACKUP' LED displayed on the 'image of programmable controller CPU'.

'BACKUP' LED status	Operation mode
ON (green)	Backup mode
ON (red)	Backup mode (In a state in which the control (RUN) cannot be continued by the system switching.)
ON (orange)	Separate mode
OFF	Debug mode

For details of CPU module LED, refer to the following manual.

☞ QCPU User's Manual (Hardware Design, Maintenance and Inspection)

## ■ Displaying operation histories

Display operation histories for a CPU module (device writing and file writing).

Note that only High-speed Universal model QCPU\*1 and Universal model process CPU\*1 support this function.

\*1 : The module whose function version is B and first five digits of the serial number are "19062" or higher.

### Point


#### ● Operation history

For the operation history, refer to the following manuals.

- ☞ QnUCPU User's Manual (Function Explanation, Program Fundamentals)
- ☞ QCPU User's Manual(Hardware Design, Maintenance and Inspection)

## Screen display

Click the Operation History[1] button on the PLC Diagnostics screen.



## Display contents

Item	Description
Operation history list	Display operation histories for a CPU module. The most recent 10000 operation histories are displayed.
No.	Display an operation history number.
Date and Time	Display a time that an operation was performed (year, month, date, hour, minute, second).
Operation Type	Display the information to classify operations into each type. <ul style="list-style-type: none"> <li>• System</li> <li>• Operation</li> </ul>
Operation Code	Display a value indicating each operation in four-digit decimal number.
Overview	Display an operation overview.
Operation history detailed information	Display the operation history detailed information.

17 MONITORING  
 18 SIMULATING PROGRAMS  
 19 DEBUGGING PROGRAMS  
 20 OPERATING PROGRAMMABLE CONTROLLER CPU  
 21 DIAGNOSING PROGRAMMABLE CONTROLLER STATUS  
 22 SIMULATING OPERATIONS OF EXTERNAL DEVICES  
 A APPENDIX  
 I INDEX

### Screen button

- Updates the operation history with the latest information.
- Clears the operation history.
- Save the displayed operation history in a CSV file format.

### Point

- **Operation history screen**  
The operation history can be sorted in ascending order or descending order by clicking the header of the operation history list.




## 21.1.2 Diagnosing FXCPU



Display the programmable controller CPU status.

### Screen display

Select [Diagnostics] ⇒ [PLC Diagnostics].



### Display contents

Item	Description
Connection Channel List	Display the connection route which has been set.
Error Information	Display errors being occurring. The corresponding error help is displayed by double-clicking the row of error information. (It is also displayed by clicking the <b>Error Help</b> button.)
PLC Panel	Display the status of the connection destination CPU module.
PLC Information	Display the memory type and version of the connection destination CPU module.
Monitor Status	Display the current monitor status.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS





22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

## Screen button





For the screen buttons, refer to Section 21.1.1.

-  Remote RUN  
Switches the execution status of the programmable controller CPU to RUN.  
Not supported by FX0, FX0s, FX1, FXU, and FX2c.
-  Remote STOP  
Switches the execution status of the programmable controller CPU to STOP.  
Not supported by FX0, FX0s, FX1, FXU, and FX2c.
-  Clear PLC Memory  
Displays the Clear PLC Memory screen.
-  Set Clock  
Displays the Set Clock screen.  
Not supported by FX0s, FX0, and FX1.

### 21.1.3 Error icons

**Q CPU** **L CPU** **Remote** **Head** **FX**

The following table shows the details of the error information icons of the programmable controller CPU.

Icon	Programmable controller CPU status
 Serious error	RESET and others
 Moderate error	STOP due to error in parameter or instruction codes
 User specified error*1	The error that allow "STOP"/"Continue" to be specified as an "Operating Mode When There is an Error" on the <<PLC RAS>> tab of PLC parameter.
 Minor error	Errors that allow RUN status such as battery low and annunciator ON

\*1 : Not supported by FXCPU.

### 21.1.4 Online operations




The PLC Memory Operation function and the Remote Operation function can be executed from the figure of programmable controller CPU.


When the cursor is moved to the figure of programmable controller CPU, the function menu is expanded. Click the figure of programmable controller CPU to display the items to be set.

#### Screen display

<QCPU (Q mode) (For Universal model CPU)>




<QCPU (Q mode) (For Redundant CPU)>



17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX



<Remote I/O module>



### Display contents

Item		Reference
PLC Memory Operation	(Type of memory operation)	Memory format
		Memory clear
		Memory arrangement
Remote Operation/PLC Module Change	Remote operation	
	Backup data creation	
	Data restoration	
Redundant Operation		
Ethernet Diagnostics		
Set Clock/Write Title	Set clock	
	Write title	
CC-Link Diagnostics		
CC-Link IE Field Diagnostics		
MELSECNET Diagnostics		

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX


## 21.2 Diagnosing MELSECNET



This section explains how to check the MELSECNET/10(H) status connected to the selected module.

### Screen display

Select [Diagnostics] ⇒ [MELSECNET Diagnostics].



### Display contents

Item	Description
Link module selection tab	Switch the MELSECNET diagnostics result display screen for each link modules from 1 to 4. The information whether a link module is mounted or not is acquired from the mounted status.
Network Information	Display the network information of the selected module.
Link Information	Display the network status.
Communication Information	Display the communication status of the target network.

### Screen button

- **Network Test...**  
Displays the Network Test screen. (☞ Section 21.2.1)
- **Loop Test...**  
Displays the Loop Test screen. (☞ Section 21.2.2)
- **Setting Verification Test...**  
Displays the Setting Confirmation Test screen. (☞ Section 21.2.3)
- **Station Order Check Test...**  
Displays the Station Order Check Test screen. (☞ Section 21.2.4)
- **Communication Test...**  
Displays the Communication Test screen. (☞ Section 21.2.5)
- **Error History Monitor...**  
Displays the Error History Monitor screen. (☞ Section 21.2.6)
- **Network Monitor Details...**  
Displays the Network Monitor Details screen. (☞ Section 21.2.7)

- **Other\_Station Info...**

Displays the Other Station Information screen. (☞ Section 21.2.8)

### Point

- **Network to be diagnosed**

To change a network to be diagnosed, change the target station in the connection destination setting.

- **When another station is set in the connection destination setting**

Test functions such as network test cannot be executed when the connection destination setting is set to other than "No Specification".

- **MELSECNET/H (bus) connection**

- The loop test and station order test cannot be executed with the MELSECNET/H (bus) connection with the coaxial cable.
- The loop test, setting verification test, and station order test cannot be executed with the MELSECNET/H (bus) connection with the twisted pair cable.

17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX

I

INDEX


## 21.2.1 Network test

Perform link start/stop (cyclic transmission stop/restart) on the host station, specified station, and all stations in MELSECNET/10(H).

Use this function to avoid receiving data from another stations or to avoid sending data from host station when starting up (debugging) the system.

### Screen display

Click the  button on the **MELSECNET Diagnostics** screen.



### Display contents

Item	Description
Network Information	Display the network information on the host station of the selected module.
Monitor Status	Display the current monitor status.
Host Status	Display the operating status of the host station for the selected module.
Operation Status of All Stations	Display the link status of all stations on the tested network.

### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Link Start/Stop	Set the items to execute the test.
Operation	Link Start <ul style="list-style-type: none"> <li>Select this to start the station that was stopped by the host station.</li> <li>The station that was stopped by another station cannot be started.</li> </ul>
	Link Stop <ul style="list-style-type: none"> <li>Select this to stop a station from the host/another station.</li> </ul>
	Forced Link Start <ul style="list-style-type: none"> <li>Select this to forcibly perform the link start on a station stopped by the host station or another station, or to forcibly perform the link start on a station to which the link stop is performed by special relay/special register. However, forced start in units of stations is not possible while all stations are stopped.</li> <li>To check whether the station is stopped by stop specification of all stations, check SW0000.</li> <li>This function can be executed when "PLC side I/F" in the connection destination setting is set to "C24".</li> <li>This function cannot be executed when the MELSECNET/10(H) board is used.</li> <li>This function cannot be executed via the A series-compatible E71/QE71 module. (The route via A series-compatible E71/QE71 is not supported by GX Works2.)</li> </ul>
Designate Object Station	Specify the object station of the network test.
Object Module	Select the object module of the network test.



## 2. Click the **Execute Test** button.

The network test is executed according to the settings.

### Point

- **When another station is set in the connection destination setting**

The network test function cannot be executed when the connection destination setting is set to other than "No Specification".

17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## 21.2.2 Loop test


Check the loop status of MELSECNET/10(H).

Use this function to perform the loop test in the forward loop/reverse loop status with the completion of the optical loop system wiring.

Wiring status of data link cables (IN/OUT) can be checked.

### Screen display

Click the  button on the MELSECNET Diagnostics screen.



### Display contents

Item	Description
Network Information	Display the network information on the host station of the selected module.
Execute Results	Display the number of stations and the result (normal/invalid, reserved station: R) of loop test.

### Operating procedure

#### 1. Set the items on the screen.

Item		Description
Loop Test		Set the items to execute the test.
Test Method	Parameter Designation	Select this to test all the (linked) stations specified by the network parameter (except for reserved stations). All stations are tested, if network parameter does not exist.
	All Stations Designation	Select this to test all stations.
Object Module		Select the module for which loop test is executed.

#### 2. Click the button.

The loop test is executed according to the settings.

#### Point

● **When another station is set in the connection destination setting**


The loop test function cannot be executed when the connection destination setting is set to other than "No Specification".

## 21.2.3 Setting verification test

Check the status of the station number, network number, and group number set for each station. Use this function to check duplicates of control stations or station numbers, or whether the network number set to the station to which GX Works2 is connected matches with the network number set in the network parameter of host station.

### Screen display

Click the  button on the **MELSECNET Diagnostics** screen.



### Display contents

Item	Description
Network Information	Display the network information on the host station of the selected module.
Execute Results	Display the test result.
Station No.	Display the station number of the stations for which the setting verification test was executed. Up to 64 stations are displayed.
Control Station No.	Display "○" symbol at the target station if control station is set at two or more places.
Duplicated Station No.	Display "○" symbol at the target station if the same station number is set at two or more places.
Network No.	Display the network number of the stations for which the setting verification test was executed. If the network number differs from that of the host station, it is identified by red.
Group No.	Display the group number of the stations for which the setting verification test was executed. For the remote I/O network, the station in error is blank.
Reserved Station	Display "○" symbol for the station reserved by parameter setting. (When "Parameter Designation" is set in the test execution method.)
Error Station	Display "○" symbol for the station when it is reserved by parameter setting or if a module is faulty in all station specification.
Network Type Error Station	Display "○" symbol for the station where the parameter setting and the actual connection type disagree.
Duplex R Sub M Station Duplication	Display "○" symbol for the station where multiple sub-master stations exist on the same network.
Parallel R Sub M Station Duplication	Display "○" symbol for the station where multiple sub-master stations exist on the same network.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## Operating procedure

### 1. Set the items on the screen.

Item		Description
Setting Check Test		Set the items to execute the test.
Test Method	Parameter Designation	Select this to test all the (linked) stations specified by the network parameter (except for reserved stations). All stations are tested, if network parameter does not exist.
	All Stations Designation	Select this to test all stations.
Object Module		Select the module for which setting verification test is executed.

### 2. Click the button.

The setting verification test is executed according to the settings.

#### Point

- **Considerations for executing the test**

The test cannot be executed to multiple stations simultaneously.  
If executed, cyclic transmission stops.

- **When another station is set in the connection destination setting**


The setting verification test cannot be executed when the connection destination setting is set to other than "No Specification".

## 21.2.4 Station order check test

Check the station number of the connected stations in the optical loop system of MELSECNET/10(H).

### Screen display

Click the **Station Order Check Test...** button on the **MELSECNET Diagnostics** screen.



### Display contents

Item	Description
Network Information	Display the network information on the host station of the selected module. The loop status indicates the forward/reverse loop, forward loop, reverse loop or loopback status. "No. of Stations" indicates the number of stations that have been checked, including the reserved station.
Execute Results	Display the station number in "Forward Loop Direction from Host Station" and "Reverse Loop Destination from Host Station". In the loopback status, the test is executed only in "Forward Loop Direction from Host Station". The number for the reserved station is not displayed.

### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Station Order Check Test	Set the items to execute the test.
Test Method	Parameter Designation Select this to test all the (linked) stations specified by the network parameter (except for reserved stations). All stations are tested, if network parameter does not exist.
	All Stations Designation Select this to test all stations.
Object Module	Select the module for which station order check test is executed.

#### 2. Click the **Execute** button.

The station order check test is executed according to the settings.

#### Point

- **Considerations for executing the test**

The test cannot be executed to multiple stations simultaneously.  
If executed, cyclic transmission stops.

- **When another station is set in the connection destination setting**

The station order check test cannot be executed when the connection destination setting is set to other than "No Specification".

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## 21.2.5 Communication test


Perform the communication test between networks on MELSECNET/10(H).

Use this function to check whether communication can be performed between the host station and the communication target.

Especially, when the communication target is located on another network, the routing parameter setting can be checked by the relayed network numbers and station numbers displayed on the screen.

### Screen display

Click the  button on the **MELSECNET Diagnostics** screen.



### Display contents

Item	Description
Execute Results	Display the result of communication test executed between networks.

### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Communication Test	Set the items to execute the test.
Destination	Set the network number and station number.
Communication Data	Set the data length (1 to 900 bytes), number of communications (1 to 100 times), and monitoring time (1 to 100 seconds) to execute the test.

#### 2. Click the button.

The communication test is executed according to the settings.


### Point

#### ● When another station is set in the connection destination setting

The communication test cannot be executed when the connection destination setting is set to other than "No Specification".

### Example of communication test

The following shows an example of the communication test between the host station (network number 1, station number 1) and the communication target (network number 3, station number 2) with the network configuration described below.



Return direction from communication target to host station

Direction from host station to communication target

**Communication Test**

Execute Results

Network No.	Station No.	Network No.	Station No.
1	3	4	1
2	2	1	2
3	2	1	3

Own Station

Network No.

Station No.

Communication Information

Communication Count:  Times

Communication Time:  X 100ms

Destination Station

Network No.

Station No.

Relay station number of network No. 1: 4

Relay station number of network No. 2: 3

Communication Test

1: Destination      2: Communication Data

Network No.       Data Length  Bytes

Station No.       Communication Count  Times

   Watchdog Time  Seconds


17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

## 21.2.6 Error history monitoring

Display the error history of MELSECNET/10(H).

### Screen display

Click the  button on the MELSECNET Diagnostics screen.




### Display contents

Item	Description
Network Information	Display the network information of the selected host station.
Loop Switching	Display the number of times that the loop is switched.
Transient Transmission Errors	Display the number of occurrences of transient transmission error.
F.Loop/R.Loop	Display the items during monitoring.

### Screen button

- 


Displays the Error History Detail Monitoring screen that lists the details of loop switching and transient transmission error.





● **Clear Error History**

Displays the Clear of Error History screen. Select the items to be cleared and click the **Execute** button.




## 21.2.7 Network monitor details

Display the network line status of MELSECNET/10(H).

### Screen display

Click the **Network Monitor Details...** button on the MELSECNET Diagnostics screen.



### Display contents

Item	Description
Network Information	Display the network information of the selected host station.
Control Station Information	Display the control station information. For the I/O master station, the information is displayed only for PLC to PLC network.*1 LX/LY assignment is displayed only for the remote I/O network.*1
Data Link Information	Display the data link information.
Status of Self Station	Display the host station status. Parameter setting is displayed only for PLC to PLC network.

\*1 : Not supported by remote I/O module.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I


INDEX

## 21.2.8 Monitoring other station information

Monitor other station connected to MELSECNET/10(H).

### Screen display

Click the **Other Station Info...** button on the **MELSECNET Diagnostics** screen.



### Display contents

Item	Description
Network Information	Display the network information of the selected host station.
Other Station Information	Display detailed information on the error details display field when an item button is clicked. <ul style="list-style-type: none"> <li>• "ERR" is displayed on the error information display field if a faulty station or a stop station is detected.</li> <li>• "RSV" is displayed on the error information display field if a reserved station exists.</li> <li>• "PWR" is displayed on the error information display field if a power is supplied to a module with external power supply.</li> </ul>
Error details display field	Display the status of each station for the items selected in "Other Station Information".

The table below shows the items that can be selected in "Other Station Information" of QCPU (Q mode).

○: Applicable ×: Not applicable (grayed out)

	MELSECNET/10(H)					
	PLC to PLC network				Remote I/O network	
	Control station		Normal station		Master station	
	Loop	Bus	Loop	Bus	Loop	Bus
Communication Status of each Station	○	○	○	○	○	○
Data-Link Status of each Station	○	○	○	○	○	○
Parameter Status of each Station*1	○	○	×	×	○	○
CPU Operation Status of each Station	○	○	○	○	○	○
CPU RUN Status of each Station*1	○	○	○	○	×	×
Loop Status of each Station	○	×	○	×	○	×
Reserved Station Designation of each Station	○	○	○	○	○	○
Power Operation Status of each Station External*1	○	×	○	×	○	×
Search Status of Local Station Error*1	×	×	×	×	×	×
Each Station PLC Operation Mode Status*1,*2	○	○	○	○	×	×
Each Station Pairing Status*1,*2	○	○	○	○	×	×
Each Station PLC System Status*1,*2	○	○	○	○	×	×
Each Station Network Type Status*1,*2	○	○	○	○	×	×

\*1 : Not supported by remote I/O module.

\*2 : For MELSECNET/H network module only

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

## 21.3 Diagnosing CC-Link IE Controller Network



This section explains how to check the CC-Link IE Controller Network status of a selected module.


### Point

- **When another station is set in the connection destination setting**  
When another station is set in the connection destination setting, the function cannot be executed.
- **Details of CC-Link IE Controller Network diagnostics**  
Refer to CC-Link IE Controller Network Reference Manual.

### Selecting the diagnostics target

When two or more CC-Link IE Controller Network modules are connected to the connected station, the Select Diagnostics Destination screen as shown below is displayed before starting diagnostics.

Select a network to be diagnosed and click the **OK** button.



### Diagnostics screen

#### Screen display

Select [Diagnostics] ⇒ [CC IE Control Diagnostics].

Network information

## Display contents

Item	Description																																			
Network information	<p>Display the network information of the selected module. The status is displayed by icons shown below.</p> <table border="1"> <thead> <tr> <th colspan="2">Icon</th> <th rowspan="2">Station status</th> </tr> <tr> <th>Module</th> <th>Board</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td>Normally operating station</td> </tr> <tr> <td></td> <td></td> <td>Focusing (icon enclosed by dotted line)</td> </tr> <tr> <td></td> <td></td> <td>Selected station</td> </tr> <tr> <td></td> <td></td> <td>Error (cyclic transmission stopped)</td> </tr> <tr> <td></td> <td></td> <td>Warning (Although cyclic transmission is executed, an error occurred with a module and/or a cable)</td> </tr> <tr> <td></td> <td></td> <td>Module whose shared group is different</td> </tr> <tr> <td></td> <td>—</td> <td>Reserved station (gray)</td> </tr> <tr> <td></td> <td>—</td> <td>Disconnected station (black)</td> </tr> <tr> <td>Connected Station </td> <td>—</td> <td>Current connected station, specified in the connection destination setting</td> </tr> <tr> <td>Undef. </td> <td>—</td> <td>Number unspecified station (Although "Specify Station No. by Program" is selected in parameter (normal station only), a station number is not set in the program.)</td> </tr> </tbody> </table> <p>Clicking an icon sets the corresponding station as the selected station and displays the details in "Selected Station's Network Equipment Status". The selected station can also be determined by moving the focus with the right and left arrow keys and pressing the <b>[Space]</b> or <b>[Enter]</b> key. Double-clicking an icon displays the <u>System Monitor</u> screen (  Section 21.9) of the corresponding station.</p>	Icon		Station status	Module	Board			Normally operating station			Focusing (icon enclosed by dotted line)			Selected station			Error (cyclic transmission stopped)			Warning (Although cyclic transmission is executed, an error occurred with a module and/or a cable)			Module whose shared group is different		—	Reserved station (gray)		—	Disconnected station (black)	Connected Station 	—	Current connected station, specified in the connection destination setting	Undef. 	—	Number unspecified station (Although "Specify Station No. by Program" is selected in parameter (normal station only), a station number is not set in the program.)
	Icon		Station status																																	
	Module	Board																																		
			Normally operating station																																	
			Focusing (icon enclosed by dotted line)																																	
			Selected station																																	
			Error (cyclic transmission stopped)																																	
			Warning (Although cyclic transmission is executed, an error occurred with a module and/or a cable)																																	
			Module whose shared group is different																																	
		—	Reserved station (gray)																																	
		—	Disconnected station (black)																																	
	Connected Station 	—	Current connected station, specified in the connection destination setting																																	
Undef. 	—	Number unspecified station (Although "Specify Station No. by Program" is selected in parameter (normal station only), a station number is not set in the program.)																																		
Selected Station's Network Equipment Status	Display the status of the CC-Link IE Controller Network module in the station selected in the network information display field and the status of the connecting cable.																																			

## Screen button

- **Change Module...**  
Displays the Select Diagnostics Destination screen. The diagnostic target module can be changed.
- **Change Select Station**  
Changes the selected station to the station to which the station number specified in "Select Station" is assigned. The status of the selected station is displayed in "Selected Station's Network Equipment Status".
- **Previous<< / Next>>**  
Switches the screen display of the network information when the total number of station is 61 or more.
- **Communication Test...**  
Displays the Communication Test screen. The communication route from the connected station to the specified destination station can be confirmed. ( Section 21.3.1)
- **IP Communication Test...** **(Universal model QCPU (except for Q00UJ/Q00U/Q01U/Q02U) only)**  
Displays the IP Communication Test screen. The IP communication route from the connected station to the communication destination station can be confirmed. ( Section 21.3.2)
- **Link Start/Stop...**  
Displays the Link Start/Stop screen. The data link start/stop can be performed to the specified station. ( Section 21.3.3)

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

- **Logging...**  
Displays the Logging screen. The communication route switch information and the transient transmission error of the connected station can be monitored. The monitor information can be saved in a file. (☞ Section 21.3.4)
- **System Monitor...**  
Displays the System Monitor screen. The system status of the selected station can be confirmed. (☞ Section 21.9)
- **Remote Operation...**  
Displays the Remote Operation screen. The remote operation can be performed to the programmable controller CPU of the selected station. (☞ Section 20.1)

### Point!

- **Connection destination for executing CC-Link IE Controller Network diagnostics**  
The communication test and the link start/stop can be executed only when the connected station is selected.
- **When an unsupported CPU module is specified as the selected station, or a CC-Link IE Controller Network interface board is specified as the selected station**  
The system monitor or remote operation cannot be performed when an unsupported CPU module is specified as the selected station. The system monitor cannot be performed when a CC-Link IE Controller Network interface board is specified as the selected station.
- **When the total number of stations is set to 65 or more**  
In a case where the total number of stations is set to 65 or more and High Performance model QCPU is specified as the connected station, an error occurs when a station whose station number is 65 or more is selected. The error, however, does not occur where Universal model QCPU is connected with a cable in a multiple CPU configuration.


### Restrictions!

- **Communication test and link start/stop**  
To execute the communication test or link start/stop, a target station must be connected using a USB/RS-232 cable.

■ Display on the "Selected Station's Network Equipment Status" field when an error occurs

When an error occurs on a CC-Link IE Controller Network module or connection cable, the button is displayed on the "Selected Station's Network Equipment Status" field as shown below. The detailed information, error factor, and troubleshooting can be displayed by clicking the button.

The icon (🔴) is displayed as shown below when a destination station is disconnected.



17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

## 21.3.1 Communication test

Perform the communication test on CC-Link IE Controller Network.

### Screen display

Click the **Communication Test...** button on the **CC IE Control Network Diagnostics** screen.

### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Communication Test Parameters	Set the items to execute the test.
Target Station	Set the network number and station number.
Communication Data Setting	Set the data length (1 to 900 bytes), the number of communications (1 to 100 times), and monitoring time (1 to 100 seconds) to execute the test.

#### 2. Click the **Execute Test** button.

The communication test is executed according to the settings.

### Display contents

Item	Description
Communication Test Result	Display the result of inter-network communication test. Networks and stations routed from the own station (connected station) to the target station are displayed on the <<Outward>> tab and those routed from the target station to the own station (connected station) are displayed on the <<Inward>> tab.




## 21.3.2 IP communication test

Perform the IP communication test on CC-Link IE Controller Network.

### Screen display

Click the **IP Communication Test...** button on the **CC IE Control Network Diagnostics** screen.



### Operating procedure

#### 1. Set the items on the screen.

Item	Description
IP Communication Test Parameters	Set the information for the test.
IP Address Input Format	Select the input format (decimal/hexadecimal) of the IP address.
Connected Station (Own)	Display the IP address of the Ethernet Built-in CPU.
Communication Target	Set the IP address of the target station.

#### 2. Click the **Execute Test** button.

The IP communication test is performed according to the set information.

### Display contents

Item	Description
IP Communication Test Result	Display the result of the IP communication test between the networks. Network numbers and station numbers routed from the own station to the target station are displayed on the <<Outward>> tab. Network numbers and station numbers routed from the target station to the own station are displayed on the <<Inward>> tab.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX


I  
INDEX

### 21.3.3 Link start/stop

Start/stop the data link of individual stations on CC-Link IE Controller Network.

#### Screen display

Click the  button on the CC IE Control Network Diagnostics screen.



#### Operating procedure

##### 1. Set the items on the screen.

Item	Description
Network Information	Display the network information of the connected station.
All Station Status	Display the link status of all stations on the same network which are performing the data link with the connected station. Target stations of the link start/stop operation can be selected in "Selective Status".
Link Start/Stop	–
Link Start	Select this to start the data link.
Link Stop	Select this to stop the data link.
Forced Link Start	Select this to forcibly start the data link of a station which has been stopped by another station or a special relay/special register.



##### 2. Click the button.

The link start/stop is executed for all selected stations at once.

**Point** 

● **Selection of link start/stop**

The target stations of the link start/stop operation can also be selected by the following methods.

Selection	Operating procedure	
Group Selection	Right-click on the "Group" column of a station and select "Group Selection" from the shortcut menu. Stations which have the same group number as the selected line become selected. When the "Group" column whose value is 0 is right-clicked, this shortcut menu cannot be selected.	
Select All	Right-click the "Station No." column of a station and select "Select All" from the shortcut menu.	

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES


A  
APPENDIX


I  
INDEX

### 21.3.4 Logging

Display the communication route switch information and transient transmission error information of the selected station.

#### Screen display

Select the  button on the CC IE Control Network Diagnostics screen.



#### Display contents

Item	Description
Display Station	Display the network information of the currently selected station.

#### ■ Displaying the communication route switch information and transient transmission error information

The <<Monitor Details>> tab displays the communication route switch information and transient transmission error information.

Maximum 100 logs can be displayed. If the number of logs exceeds 100, the logs are deleted from the oldest one.


#### Display contents

Item	Description
Switch Transmission Path	Display the loop status of communication route, the number of station where loopback occurred, and the date when communication route switching occurred.
Transient Transmission Errors	Display the error code, network number and station number of the transient request target, and the date of error occurrence if transient transmission error occurs.

## Screen button

- **Save Error Log...**


Displays the Save Error Log screen and the contents displayed on the <<Monitor Details>> tab can be saved in a CSV file.



## ■ Clearing errors

Clear the errors of the currently selected station using the <<Error Clear>> tab.

## Screen display



## Operating procedure

1. Select the item to be cleared.
2. Click the **Clear Error Information** button.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## 21.4 Diagnosing CC-Link IE Field Network



\*1 : Universal model QCPU only

\*2 : CC IE Field head module only

This section explains how to check the CC-Link IE Field Network status of a selected module.


### Point

- **When another station is set in the connection destination setting**  
When another station is set in the connection destination setting, the function cannot be executed.
- **Details of CC-Link IE Field Network diagnostics**  
Refer to the User's Manual of each module.

### ■ Selecting the diagnostics target

When two or more CC-Link IE Field Network modules are connected to the connected station, the Select Diagnostics Destination screen as shown below is displayed before starting diagnostics.

Select a network to be diagnosed and click the  button.




■ Diagnostics screen

Screen display

Select [Diagnostics] ⇒ [CC IE Field Diagnostics].

The following is an example of setting screen when QCPU (Q mode) is selected.



Display contents

Item	Description
Select Diagnostics Destination	—
Module	Display the module and network number of the diagnostics target.
Select Station	Display the station number of the station selected in the network information. When the connected station is CC IE Field head module, this item is fixed to the own station.
Network Status*1	—
Network information	Display the total number of device stations, the link scan time (in units of ms), and the number of error-detected stations on the network being displayed.
Network configuration	Display the state of the network. The status of each station is displayed with icons. Descriptions of displayed icons can be checked by clicking the Legend... button. Clicking an icon sets the corresponding station as the selected station and displays the details on the "Selected Station Communication Status Monitor" field. The selected station can also be determined by moving the focus with the right and left arrow keys and pressing the [Space] or [Enter] key.
Data link unexecuted stations	Display stations on which the data link is not established among the stations set to the parameter. The disconnected stations which are deleted by the "Hide Disconnected Station" function are also displayed.
Monitor Status	—
St. Info	Select whether to display each station on the 'network configuration' with station type or with device name. A station type is displayed when the device name is not set in the network parameter, or the module used is not supported by the function to display station type, despite "Device Name" is selected.
Selected Station Communication Status Monitor*2	Display the communication status of the own station.

\*1 : Not displayed when the connected station is a CC IE Field head module.

\*2 : When the master station is duplicated, the icon for QJ71GF11-T2 is displayed even if the selected station is QD77GF4, QD77GF8, and QD77GF16.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

## Screen button

- **Change Module...** **(Not supported by CC IE Field head module)**  
Displays the Select Diagnostics Destination screen. The diagnostic target module can be changed. (☞ ■ Selecting the diagnostics target)
- **Update(K)...**  
Updates the network configuration to delete the disconnected station.
- **Legend...**  
Displays the Legend screen. The explanation for icons displayed on the Diagnostics screen is displayed.



- **Communication Test...**  
Displays the Communication Test screen. The communication route from the connected station to the specified destination station can be confirmed. (☞ Section 21.4.1)
- **IP Communication Test...**  
Displays the IP Communication Test screen. The IP communication route from the connected station to the communication target station can be confirmed. (☞ Section 21.4.2)
- **Cable Test...**  
Displays the Cable Test screen. The cable connection status can be tested. (☞ Section 21.4.3)
- **Link Start/Stop...** **(Not supported by CC IE Field head module)**  
Displays the Link Start/Stop screen. The data link start/stop can be performed to the specified station. (☞ Section 21.4.4)
- **Network Event History...** **(Not supported by CC IE Field head module)**  
Displays the Network Event History screen. Displays the history of events that have occurred on the own station and the network, and the various network information. (☞ Section 21.4.5)



- **Reserved Station Function Enable...** (Not supported by CC IE Field head module)  
Displays the Reserved Station Function Enable screen. The reserved stations can temporarily be disabled, and the temporarily disabled reserved stations can be enabled. (☞ Section 21.4.6)
- **Enable / Disable Ignore Station Errors...** (Not supported by CC IE Field head module)  
Displays the Enable/Disable Ignore Station Errors screen. The temporary error invalid stations can be set, and the registered temporary error invalid stations can be canceled. (☞ Section 21.4.7)
- **System Monitor...** (Not supported by Ethernet adapter module/CC-Link IE Field Network board/CC-Link IE Field Network communication unit)  
Displays the System Monitor screen. The system status of the selected station can be confirmed. (☞ Section 21.9)
- **System Error History...** (Supported by Ethernet adapter module/CC-Link IE Field Network-CC-Link bridge module only)  
Displays the Error History screen. The system status of the selected station can be confirmed. (☞ Section 21.9)
- **Remote Operation...** (Not supported by Ethernet adapter module/CC-Link IE Field Network board/CC-Link IE Field Network communication unit)  
Displays the Remote Operation screen. The remote operation can be performed to the programmable controller CPU of the selected station. (☞ Section 20.1)

**Point** 

- **Connection destination for executing CC-Link IE Field Network diagnostics**  
The communication test and the link start/stop can be executed only when the connected station is selected.
- **When an unsupported CPU module is specified as the selected station**  
The IP communication test, system monitor, or remote operation cannot be performed when an unsupported CPU module is specified as the selected station.
- **When the selected station is a remote device station**
  - The system monitor cannot be performed.
  - For the remote operation, only remote reset operations can be performed on the selected station.
  - Extension modules are displayed on the "Selected Station Communication Status Monitor" field only when a CC-Link IE Field Network master/local module is connected.  
For the versions (serial numbers) of master/local modules which can display the extension modules, refer to the following manuals.
    - ☞ MELSEC-Q CC-Link IE Field Network Master/Local Module User's Manual
    - ☞ MELSEC-L CC-Link IE Field Network Master/Local Module User's Manual
- **Considerations of sub-master station display**  
When a sub-master station is specified in the network parameter of the master station, a device station whose station number is the same as that of the sub-master station is indicated as "Sub-Master".  
In this case, review the network parameter and the system configuration.
- **Received frame error displayed on the cable**  
Received frame error is displayed regardless of the port.  
Therefore, when the cables are connected to port 1 and port2, a received frame error is displayed on both side.  
The received frame error of the cable is displayed on the 'network configuration'. It is not displayed on the "Selected Station Communication Status Monitor" field.

**Restrictions** 

- **Communication test and link start/stop**  
To execute the communication test or link start/stop, a target station must be connected using a USB/RS-232 cable.

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX


## ■ Display on the "Selected Station Communication Status Monitor" field

The button as shown below is displayed on the "Selected Station Communication Status Monitor" field for any of the following situations:

- an error occurs on a CC-Link IE Field Network master/local module, CC IE Field head module, or Ethernet adapter module;
- an error occurs on a connection cable; or
- a station number is not specified.

The detailed information, error factor, and troubleshooting can be displayed by clicking the button.

The icon (🔴) is displayed as shown below when a destination station is disconnected.



### Point

#### ● Setting a station number of CC IE Field head module

A station number of CC IE Field head module can be set or changed when connecting a CC IE Field head module whose station number is not set.

Specify "CC IE Field Head Module" for "Select Station" on the [CC IE Field Diagnostics](#) screen for the master station,

and click the [Station No. Setting...](#) button displayed on the "Selected Station Communication Status Monitor" field.

Station numbers of the following modules used in the master station can be reset.

- QJ71GF11-T2 (With a serial number whose first five digits are "12072" or higher)
- LJ71GF11-T2

For details of setting station numbers, refer to the following manual.


📖 MELSEC-L CC-Link IE Field Network Head Module User's Manual

## 21.4.1 Communication test

Perform the communication test on CC-Link IE Field Network.

### Screen display

Click the **Communication Test...** button on the **CC IE Field Diagnostics** screen.



Presence or absence of errors on the communication test

### Operating procedure

1. Set the items on the screen.

Item	Description
Communication Test Parameters	Set the items to execute the test.
Connected Station (Own)	Display the network number and station number of the connected station.
Target Station	Set the network number and station number.
Communication Data Setting	Set the data length (1 to 900 bytes), the number of communications (1 to 100 times), and monitoring time (1 to 100 seconds) to execute the test.

2. Click the **Execute Test** button.

The communication test is performed according to the settings.

### Display contents

Item	Description
Communication Test Result	Display the result of inter-network communication test. Also in 'Presence or absence of errors on the communication test', display whether the communication test has been executed normally. Networks and stations routed from the own station (connected station) to the target station are displayed on the <<Outward>> tab and those routed from the target station to the own station (connected station) are displayed on the <<Inward>> tab.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX


I  
INDEX

## 21.4.2 IP communication test

Perform the IP communication test on CC-Link IE Field Network.

### Screen display

Click the **IP Communication Test...** button on the **CC IE Field Diagnostics** screen.



### Operating procedure

#### 1. Set the items on the screen.

Item	Description
IP Communication Test Parameters	Set the information for the test.
IP Address Input	Select the input format (decimal/hexadecimal) of the IP address.
Connected Station (Own)	Display the IP address of the Ethernet Built-in CPU.
Communication Target	Set the IP address of the target station.

#### 2. Click the **Execute Test** button.

The IP communication test is performed according to the set information.\*1

\*1 : A maximum of two minutes may be required for the cancellation processing when the module is not connected with the serial/USB cable.

### Display contents


Item	Description
IP Communication Test Result	Display the result of the IP communication test between the networks. Network numbers and station numbers routed from the own station to the target station are displayed on the <<Outward>> tab. Network numbers and station numbers routed from the target station to the own station are displayed on the <<Inward>> tab.

## 21.4.3 Cable test

Test the status of the cable connections between the testing station and the devices connected to the ports of the testing station.

### Screen display


Click the  button on the **CC IE Field Diagnostics** screen.



### Operating procedure

1. Set the items on the screen.

Item	Description
Cable Test Contents	—
Testing Station Setting	Set the network number and station number of the station which executes the cable test.

2. Click the  button.

The cable test is executed on the testing station.

### Display contents

Item	Description
Cable Test Result	Display the cable test result, error factor, and troubleshooting of each port.

17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX

I

INDEX


## 21.4.4 Link start/stop

Start/stop the data link of a specified station. This function can be used for debugging purposes to stop the station from receiving data from other stations and sending its own data.

The data link cannot be started/stopped to the stations other than the own station when the connected station is the master station operating as a sub-master station.

### Screen display

Click the  button on the **CC IE Field Diagnostics** screen.



Selected Status	Station No.	Link Status	Station Type
<input type="checkbox"/>	0	Stopped	Master Station
<input type="checkbox"/>	1	Operating	Local Station
<input type="checkbox"/>	2	Stopped	Intelligent Device Station
<input type="checkbox"/>	3	Operating	Intelligent Device Station
<input type="checkbox"/>	5	Operating	Intelligent Device Station
<input type="checkbox"/>	6	Stopped	Intelligent Device Station
<input type="checkbox"/>	7	Operating	Intelligent Device Station
<input type="checkbox"/>	8	Stopped	Intelligent Device Station
<input type="checkbox"/>	9	Operating	Intelligent Device Station
<input type="checkbox"/>	10	Stopped	Intelligent Device Station

### Operating procedure

#### 1. Set the items on the screen.

Item	Description
Network Information	–
Connected Station Information	Display the network information of the connected station.
Link Start/Stop Setting Contents	–
All Stations Information	Display the link status of all stations on the same network which are performing the data link with the connected station. Target stations of the link start/stop operation can be selected in "Selected Status".
Link Start/Stop Executing Contents	Select "Link Start"/"Link Stop". To forcibly start the data link of a station which has been stopped by another station or a special relay/special register, select "Forced Link Start".

#### 2. Click the button.

The link start/stop is executed for all selected stations at once.

When the process is completed, "Selected Status" are cleared and the contents of "Link Status" are updated.

### Screen button


- **Select All**  
Selects all stations displayed in the list.
- **Cancel All Selections**  
Cancels the selection status of all stations selected in the list.

## 21.4.5 Network event history

Display the list of event history occurred on the own station and on the network.

### Screen display

Click the **Network Event History...** button on the **CC IE Field Diagnostics** screen.



### Display contents

Item	Description
Network Event History List	Display the list of network event history. Each column can be sorted in ascending/descending order by clicking on the column header.
Detailed Information	Display the detailed information of an event selected in "Network Event History List".

### Screen button

- **Clear Event History**  
Clears the network event history exists on the programmable controller CPU.
- **History Acquisition Setting...**  
Displays the History Acquisition Setting screen.  
Select events to be acquired.
  - All events displayed in the list are selected by clicking the **Select All** button.
  - The selection status of all events selected in the list are canceled by clicking the **Select None** button.
- **Create CSV File**  
Saves the network event history in CSV file format.
- **Refresh**  
Updates "Network Event History List".




## 21.4.6 Reserved station function enable

Disable the reserved stations temporarily, and enable the temporarily disabled reserved station. This function cannot be performed when the connected station is a local station or the master station operating as a sub-master station.

### Screen display

Click the  button on the **CC-Link IE Field Diagnostics** screen.



### Operating procedure

1. Select reserved stations to be disabled temporarily/enabled from "Reserved Station List".
2. Click the  button.

The selected reserved stations are disabled temporarily/enabled.

When the process is completed, the contents of "Reserved Station List" are updated.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX


## 21.4.7 Temporary error invalid station setting/restore

Set/cancel temporary error invalid stations.

This function cannot be performed when the connected station is a local station or the master station operating as a sub-master station.

### Screen display

Click the  button on the **CC-Link IE Field Diagnostics** screen.



### Operating procedure

1. Select stations to be set/canceled as temporary error invalid stations from "Ignore Station Error List".
2. Click the  button.

The temporary error invalid stations are set/canceled.

When the process is completed, the contents of "Ignore Station Error List" are updated.

# 21.5 Diagnosing CC-Link IE Field Network Basic



\*1 : High-speed Universal model QCPU and Universal model process CPU only  
 \*2 : Built-in Ethernet port LCPU only

This section explains how to check the network status of CC-Link IE Field Network Basic.

**Point**

- **Details of CC-Link IEF Basic Diagnostics**  
 Refer to CC-Link IE Field Network Basic Reference Manual.

### Screen display

[Diagnostics] ⇒ [CC-Link IEF Basic Diagnostics]

Station No.	Occpd Stns	Reserved Station	IP Address	Transmission Status	Disconnected Count	Timeout Count	Latest Error	Error Details...
1	1	No Setting	192.168.3.100	Transmitting	0	0	No Error	Error Details...
2	1	No Setting	192.168.3.99	Disconnecting	1	3	CFE8	Error Details...
3	1	No Setting	192.168.3.1	Unfixed	0	0	No Error	Error Details...
7	1	No Setting	192.168.3.5	Unfixed	0	0	No Error	Error Details...
8	1	Reserved Station	192.168.3.6	Unfixed	0	0	No Error	Error Details...
----	----	----	----	----	----	----	----	----
----	----	----	----	----	----	----	----	----
----	----	----	----	----	----	----	----	----
----	----	----	----	----	----	----	----	----
----	----	----	----	----	----	----	----	----
----	----	----	----	----	----	----	----	----
----	----	----	----	----	----	----	----	----
----	----	----	----	----	----	----	----	----
----	----	----	----	----	----	----	----	----
----	----	----	----	----	----	----	----	----

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

## Display contents

Item	Description
Change IP Address Display	Switch decimal/hexadecimal notation of IP address display.
Master Station Status	Display the total number of remote stations, IP address, and an error code of the master station.
Network Status	–
Rough Diagnostics*1	–
Link Scan Time	Display the link scan time (in units of ms) of group No.1 to 4*2, and the number of stations in an error state or unspecified stations.
Detailed Diagnostics*1	–
Diagnostics Target Group	Select a group*2 to display in the station list.
Station No.	Display the station number of a remote station.
Occpd Stns	Display the number of occupied stations of a remote station.
Reserved Station	Display a reserved station of a remote station.
IP Address	Display the IP address of a remote station.
Transmission Status	Display the transmission status of a remote station.
Disconnected Count	Display the number of disconnection between the master station and remote stations (0 to 65535).
Timeout Count	Display the number of timeouts between the master station and remote stations (0 to 65535).
Latest Error	Display the latest error code for a remote station.
Error Details	Display the error contents and corrective actions for a remote station.


\*1 : The background color is changed as described below depending on the number of unspecified stations (not including reserved stations) or stations in an error state.

Yellow: An unspecified station exists.


Red: A station in an error status exists. Or, an unspecified station and a station in an error state exist at the same time.

\*2 : For LCPUs, select group No.1 (fixed).

## Screen button



Displays the error contents and corrective actions for the master station.



Clears an error code.

## 21.6 Diagnosing CC-Link and CC-Link/LT

This section explains how to monitor the network information of each station, diagnosing the network status, and testing.

### 21.6.1 Monitoring line (host station/other stations)

Q CPU L CPU Remote Head<sup>\*1</sup> FX

\*1 : CC IE Field head module only

Monitor host station line/another station line in CC-Link or CC-Link/LT.

#### Screen display

Select [Diagnostics] ⇒ [CC-Link Diagnostics].

The following is an example of setting screen when QCPU (Q mode) is selected.

Module list/  
diagnostic  
target selection

Station list

Connecting Station	Master station
Data Link Status	Disconnecting(Loop Error)
Operation Status	----
Master Station Switch	Master station
Used Line	----
CH.0 Side Line Status	----
CH.1 Side Line Status	----
Line Type	Twist/Single/Bus
Link Scan Time	Max Oms. /Min Oms. /Current Oms.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU










21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES


A  
APPENDIX


I  
INDEX


## Display contents


Item	Description												
Diagnostics Result	Display the number of all errors/warnings being occurring in the modules.												
Module list/diagnostic target selection	Display CC-Link and CC-Link/LT modules exist in the connected station. The number of errors (errors and warnings) is also displayed. The diagnostic target can be changed by clicking a desired module.												
Station list	<p>Display the icons of stations configuring the CC-Link network. In the detail display, the 33rd station and later are displayed by clicking the  button.</p> <p>The display can be switched by the  /  button. The information of all stations are displayed on the screen at once in the all-station display.</p> <p>Click the  button to check the description of each icon.</p>												
<<Connecting Station Information>>	Display such as the data link status of the connecting station (host station).												
<<Selected Station Information>>	<p>Display such as the data link status of the station (another station) selected in the station list.</p>  <p>The screenshot shows a dialog box with three tabs: 'Connecting Station Information', 'Selected Station Information', and 'Selected Station Error Information'. The 'Selected Station Information' tab is active, displaying a table with the following data:</p> <table border="1"> <tr><td>Station No.</td><td>0</td></tr> <tr><td>Number of Occupied Stations</td><td>1</td></tr> <tr><td>Station Type</td><td>Master Station</td></tr> <tr><td>Company</td><td>MITSUBISHI ELECTRIC CORPORATION</td></tr> <tr><td>Connecting Module</td><td>PLC</td></tr> <tr><td>Comment</td><td></td></tr> </table>	Station No.	0	Number of Occupied Stations	1	Station Type	Master Station	Company	MITSUBISHI ELECTRIC CORPORATION	Connecting Module	PLC	Comment	
Station No.	0												
Number of Occupied Stations	1												
Station Type	Master Station												
Company	MITSUBISHI ELECTRIC CORPORATION												
Connecting Module	PLC												
Comment													
<<Selected Station Error Information>>	<p>Display the error information of the station selected in the station list.</p>  <p>The screenshot shows a dialog box with three tabs: 'Connecting Station Information', 'Selected Station Information', and 'Selected Station Error Information'. The 'Selected Station Error Information' tab is active, displaying a table with the following data:</p> <table border="1"> <tr><td colspan="2">By double-clicking each error shown below, the details and corrective actions can be displayed.</td></tr> <tr><td></td><td>Data link error</td></tr> <tr><td></td><td></td></tr> <tr><td></td><td></td></tr> <tr><td></td><td></td></tr> <tr><td></td><td></td></tr> </table>	By double-clicking each error shown below, the details and corrective actions can be displayed.			Data link error								
By double-clicking each error shown below, the details and corrective actions can be displayed.													
	Data link error												


## Screen button

- 

Updates the module list/diagnostic target selection.
-  (Not supported by FXCPU)
 

Switches modules to be displayed in units of eight modules.
- 

Reset the icon layout in the station list to the station number order. For the layout edit of the station list, refer to Point in this section.
-  (Not supported by FXCPU)
 

Switches the screen of the station list. When an error or warning exists on each screen, the icon indicating the error information is displayed on the button.
-  (Not supported by FXCPU)
 

Switches the all-station display and detail display.

● **Related Functions>> / Related Functions<<**


Displays/hides the related function buttons.  
For details of related functions, refer to the following sections.

- Loop Test\*1 Section 21.6.2 "Loop test/transmission speed test"
- Status Logging\*2 Section 21.6.3 "Displaying logs of station information (status logging)"
- Create Check Sheet Section 21.6.4 "Creating check sheets"
- Start Data Link/Stop Data Link\*1 Section 21.6.5 "Starting/stopping data link"

\*1 : Not supported by remote I/O module.  
\*2 : Not supported by FXCPU.

● **Legend...**

Displays the explanation for icons displayed on the diagnostics screen.  
The following is an example of setting screen when QCPU (Q mode) is selected.



**Point**


● **Update of the number of errors and warnings displayed in "Diagnostics Result"**

During the monitoring, the number of errors/warnings being occurring on the network of a module selected in "Module list/diagnostic target selection" is only updated.

To also update the number of errors/warnings on other modules, update the module list using .

● **Editing layout of station list**

Icons in the station list can be moved and allocated freely with the drag-and-drop operation.



● **Diagnostic target**


- For QCPU (Q mode)/LCPU, only QJ61BT11, QJ61BT11N, and LJ61BT11 are diagnosed in the CC-Link system configuration, and only QJ61CL12 and LJ61CL12 are diagnosed in the CC-Link/LT system configuration.
- For FXCPU, the diagnostic target is CC-Link system only. Remote I/O, remote device stations, and intelligent device stations are diagnosed.

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

**Point!**

● **Diagnosing CC-Link bridge modules (Not supported by FXCPU)**

When a CC-Link bridge module is selected in the station list, the bridge diagnostics can be executed by right-clicking it and selecting [Bridge Diagnostics] from the shortcut menu.



To return to the CC-Link Diagnostics screen, click the **Back to CC-Link Diagnostics** button.

● **Considerations for executing each function**

Do not execute the following functions by a sequence program and peripheral at the same time. If executed, they may not be executed correctly.

- Start data link/stop data link
- Set/cancel temporary error invalid station
- Loop test
- Obtain transmission speed setting (including the acquisition of the transmission speed setting in the Check Sheet Creation Wizard)

● **Considerations for setting network parameters with a program**

Create a program so that a station number is in consecutive ascending order. When a station number is not consecutive or not in ascending order, the diagnostic function may not perform normally.

**Restrictions!**

● **Restrictions on bridge diagnostics, loop test, and check sheet creation**

Bridge diagnostics, loop test, and check sheet creation can be performed only when the connected station is a master station.




## ■ Setting/canceling temporary error invalid station

Replacing a module in online is possible without detecting an error in the corresponding remote station. To set the temporary error invalid station, select the desired station in the station list and right-click it, and select [Enable/Disable Ignore Station Errors] from the shortcut menu.

If multiple stations are set as occupied stations, specify the start station number of each occupied station for the temporary error invalid station. If setting is set for a station that is not the start station in actual assignment, invalid setting is ignored.

In addition, do not set the temporary error invalid station by a sequence program or peripheral at the same time. If set, the temporary error invalid station may not be set correctly.



17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## ■ Company names in other station information


- 1) The field displays the company name or manufacturer code of the device connected in CC-Link.
- 2) The field displays the manufacturer code if company name is not entered in the manufacturer code list.
- 3) The manufacturer code list (**partner\_English.dat**) is saved in the following folder and can be edited using text editor available in market.  
C:\Program Files\MELSOFT\DnaviZero\DnaviSatellite\CCLink
- 4) The company names can be edited on the diagnostics screen, however, changes are not applied to **partner\_English.dat**.

For some manufacturers, manufacturer codes are not listed. Edit the file according to the following file format specifications.


	Manufacturer code	Company name
Max. number of characters	5	255
Usable characters*1	0 to 9	<ul style="list-style-type: none"> <li>• Alphanumeric characters</li> <li>• Symbols</li> </ul>
Remarks	Manufacturer code other than 5 digits is ignored.	Display differs depending on the screen width. With small fonts, up to 75 characters are displayed, characters exceeding the limit are not displayed.

\*1 : If "," is used in a company name, enclose the company name by double quotations (" ").  
Example: "xxxx Co., Ltd"

The following is an example of **partner\_English.dat** displayed using a text editor.



If the manufacturer code list does not exist in the install destination of GX Works2 or if it is corrupted, the following message is displayed.



## 21.6.2 Loop test/transmission speed test

Q CPU L CPU Remote Head<sup>\*1</sup> FX

\*1 : CC IE Field head module only


Check operating status of lines for all stations or specified stations, and checking the transmission speed settings of all stations.

### Screen display

Double-click  on the **CC-Link Diagnostics** screen.

Loop Test

The following is an example of setting screen when QCPU (Q mode) is selected.



↑  
Test result

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## Operating procedure

### 1. Set the items on the screen.

Item	Description
Loop Test	<p>Execute the loop test according to the specification of "All Stations" or "Selected Station No.".</p> <p>Setting is not possible when CC-Link/LT is selected.</p> <p>All Stations: Select this to execute the test for all stations.            QCPU (Q mode)/LCPU: 64 stations            FXCPU : 16 stations</p> <p>Selected Station No.: Select this to execute the test for the specified stations.            To specify a station, specify the start address of an occupied station.</p> <p>Example) When four occupied stations and two occupied stations are connected</p> <div style="text-align: center;"> <p style="text-align: center;">"1" is specified    "5" is specified</p> </div> <p>If 2, 3, 4, or 6 is specified, the station becomes faulty station.</p>
Obtain transmission speed setting	Obtain the transmission speed settings of all stations.

### 2. Click the button.

The loop test/acquisition of the transmission speed setting is executed and the result is displayed in the 'Test result'.

Check 'Legends' for the descriptions of the icons displayed in the 'Test result'.

#### Point

##### ● Considerations for executing the test

Do not execute the loop test/acquisition of the transmission speed setting by a sequence program or peripheral at the same time. If executed, the loop test/acquisition of the transmission speed setting may not be executed correctly. In addition, when executing the acquisition of the transmission speed setting, do not execute the acquisition of the transmission speed setting in the Check Sheet Creation Wizard at the same time.

## 21.6.3 Displaying logs of station information (status logging)

Q CPU L CPU Remote Head<sup>\*1</sup> FX

\*1 : CC IE Field head module only


Collect logs of the station information (the data link status of other stations, date of acquisition).

### Screen display

Double-click  on the CC-Link Diagnostics screen.

Status Logging


<Q series CC-Link module whose serial number is lower than 12032>



The screenshot shows the 'Status Logging' window. On the right, a grid of 65 station status icons is displayed, with station 0 highlighted in red. An arrow points to this grid with the label 'Log data display area'. Below the grid is a legend with four icons: 'Reserved station' (grey), 'Temporary error invalid station' (red), 'Error invalid station' (red with 'X'), and 'Error' (red with 'X'). On the left, the 'Log List' table is visible:

Date of Log Acquisition	Error	Error Details
2001/01/02 05:58:53		Data Link Error(Station No.1,2,...

<Q series CC-Link module whose serial number is 12032 or higher/LCPU>



The screenshot shows the 'Status Logging' window for a module with serial number 12032 or higher. It features a 'Log Storage Area in CC-Link Module' section with radio buttons for 'RAM' (selected) and 'RAM + Flash ROM'. Below this is a 'Log List' table:

Date of Log Acquisition	Error	Error Details
2001/01/28 03:50:18		Data Link Error(Station No.1,2,...

An arrow points to the grid of station status icons (0-64) on the right, labeled 'Log data display area'. The legend at the bottom is identical to the previous screenshot.

17 MONITORING

18 SIMULATING PROGRAMS

19 DEBUGGING PROGRAMS

20 OPERATING PROGRAMMABLE CONTROLLER CPU

21 DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22 SIMULATING OPERATIONS OF EXTERNAL DEVICES

A APPENDIX

INDEX

## Operating procedure

### 1. Set the items on the screen.


Item	Description
Time of Logging Acquisition	Specify the period of time to collect the log on the second time scale. The log is collected during the time of period between when the logging starts and when the specified time elapses.
Log Storage Area in CC-Link Module	Specify the logging storage destination. Since the log which is stored on a RAM is deleted when the programmable controller CPU is turned from OFF to ON or reset, select "RAM + Flash ROM" to keep the log stored. The log on a flash ROM can remain stored on the flash ROM of the CC-Link master/local module even if the programmable controller CPU is turned from OFF to ON or reset.

### 2. Click the button.

The log is collected during the specified log acquisition time and displayed in "Log List".

The log displayed in "Log List" is read out from the RAM.

The log collection stops when the number of log records reaches 5000.

When '0' is specified, the log collection continues until the  button is clicked or the number of log records reaches 5000.

The status as of the date selected in "Log List" is displayed in the 'Log data display area'.

Check "Legends" for the descriptions of the icons displayed in the 'Log data display area'.

## Screen button

### 

Clears the log in the module.

Also clears the log stored on a flash ROM when "RAM + Flash ROM" is selected.

### 

Saves information of the log list in CSV format. Also reads out a log file saved in CSV format and displays in "Log List".

## Point

### ● Log collection when "RAM + Flash ROM" is selected

When "RAM + Flash ROM" is selected, the first 45 records of the log are stored on a flash ROM and the following records are stored on a RAM.

### ● Checking the log stored on a flash ROM

The log stored on a flash ROM is transferred to a RAM when the programmable controller CPU is turned from OFF to ON or reset. The log stored on the flash ROM can be displayed in "Log List" by reopening the [Status Logging](#) screen.

### ● Log collection

In the case where GX Works2 cannot always be connected, select "RAM + Flash ROM".

The log (up to 45 records) stored on a flash ROM can be displayed when GX Works2 is reconnected after the logging.

In the case where GX Works2 can always be connected, up to 5000 records of the log can be collected whichever "RAM" or "RAM + Flash ROM" is selected.

## 21.6.4 Creating check sheets


Q CPU L CPU Remote Head<sup>\*1</sup> FX

\*1 : CC IE Field head module only

Create a check sheet for troubleshooting by the wizard.


### Operating procedure

1. Double-click  on the CC-Link Diagnostics screen.



2. Set the items according to the terms on the screens.

For details of setting items, refer to the following guide.

 Open Field Network CC-Link Troubleshooting Guide

The created check sheet is saved in Excel format.

#### Point

- **Considerations for checking the transmission speed**

Do not execute the check (acquisition) of the transmission speed setting by a sequence program or peripheral at the same time. If executed, the check (acquisition) of the transmission speed setting may not be executed correctly.

- **Check sheets**

"System Configuration" can be output when Excel 2000 or later is installed.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A


APPENDIX

I

INDEX

Example of a check sheet:

The following shows an example of a check sheet in case where Excel 2000 or later is installed.

Confirmation Item	Contents		
1. Master Station	[1]Master Type	Programmable Controller PLC Master Module	
		Q06UDHCPU QJ61BT11	
	[2]Master Version	Programmable Controller PLC Master Module	
		H0819A000000000B 020810000000000B	
	[3]Module Mount Status	I/O Address:	
		0010H	
	[4]Other Network Module	Other Network Module:	
		QJ61BT11	
	[5]Mode	Mode Setting:	<input type="checkbox"/> Remote Net Mode( <input type="checkbox"/> Ver.1 / <input type="checkbox"/> Additional / <input type="checkbox"/> Ver.2) / <input type="checkbox"/> Remote I/O Net Mode
		Scan Mode:	<input type="checkbox"/> Synchronous/ <input type="checkbox"/> Asynchronous Mode
		Module Mode:	<input type="checkbox"/> I/O mode / <input type="checkbox"/> Intelligent mode (SW8:A Series Only)
[6]Parameter	Checking the parameter matching status between the specification and PLC		
	Parameter	Setting	
	Number of PLCs	4Count	
	Standby Master Station Setting	None	
	PLC Down Drive Specification	<input type="checkbox"/> Stop/ <input type="checkbox"/> Continue	
	Reserved Station	Station No.3	
	Error Invalid Station	Station No.4	
	Station Information	Written in the system configuration	
[7]Parameter Setting	<input type="checkbox"/> GX WORKS2/ <input type="checkbox"/> Dedicated Instruction/ <input type="checkbox"/> FROM/TO Instruction		
[8]Link Start Method	<input type="checkbox"/> Startup by Buffer Memory:Y6 / <input type="checkbox"/> Startup by E2PROM:Y8 (Only QnA, A, FX Series)		
[9]Link Data Access	<input type="checkbox"/> Auto Refresh/ <input type="checkbox"/> Dedicated Instruction/ <input type="checkbox"/> FROM/TO Instruction		
[10]Transmission Speed	<input type="checkbox"/> 10M / <input type="checkbox"/> 5M / <input type="checkbox"/> 2.5M / <input type="checkbox"/> 625k / <input type="checkbox"/> 156kbps		
[11]Connected Count	4Count		
2. Linked Station	[11]Connected Count	4Count	
	*The details have been described	[12]Station Type*	Remote I/O Station:2Count, Remote Device Station:0Count, Intelligent Device Station:2Count
		[13]Number of Occupied Stations	<input type="checkbox"/> Number of occupied stations of each station(Please check it when you confirm it.)
		[14]CC-Link Version*	<input type="checkbox"/> Ver.1 / <input type="checkbox"/> Ver.2(Expanded Cyclic Setting:[ 1]Times, [ 2]Times, [ 4]Times, [ 8]Times)
		[15]Transmission Speed	<input type="checkbox"/> 10M / <input type="checkbox"/> 5M / <input type="checkbox"/> 2.5M / <input type="checkbox"/> 625k / <input type="checkbox"/> 156kbps
3. Transmission Cable	[16]Cable Type	Cable Model Name:	
	[17]Transmission Distance	Total Extension Distance:	m
	[18]Inter-Station Distance	Distance between Shortest Stations:	m
4. Terminal Resistor	[19]Resistance Value	<input type="checkbox"/> 110ohm / <input type="checkbox"/> 130ohm / <input type="checkbox"/> Not Exist	
	[20]Connected Terminal	<input type="checkbox"/> Connection between DA-DB of terminal resistor(Please check it when you confirm it.)	
5. Grounding	[21]FG Terminal	<input type="checkbox"/> Grounding of FG terminal of each station(Please check it when you confirm it.)	
		Describe the installation status to "6.System Configuration" when it is not set up in each station.	
6. System Configuration	[22]		
	Station No., Station Type		
	Number of Occupied Stations		
	Length of Cable		



## 21.6.5 Starting/stopping data link

Q CPU L CPU Remote Head<sup>\*1</sup> FX

\*1 : CC IE Field head module only

Start/stop the data link.

The following operating procedure is explained with icons of QCPU (Q mode) as an example.

### Operating procedure

- Double-click  on the **CC-Link Diagnostics** screen.

Stop Data Link

The data link is stopped. The icon is switched to



Start Data Link

To start the data link, click




Start Data Link

### ■ Considerations of data link stop

Performing 'data link stop' disables data transmission from GX Works2 when the personal computer is connected to a master station via CC-Link as shown in the system configuration below.

To re-establish the connection to send data from GX Works2, reset the programmable controller CPU to which the data link stop is performed and restart the data link.



17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## 21.7 Diagnosing Ethernet



This section explains how to check various setting status of Ethernet module, Ethernet Built-in CPU, and FXCPU with Ethernet adapter.

### 21.7.1 Q series-compatible E71/L series-compatible E71 module

Check Q series-compatible E71/L series-compatible E71 module parameter status, error history, status of each connection, status of each protocol, LED status, received e-mail information, and send e-mail information.

For details of each displayed item, refer to the following manuals.


☞ Q Corresponding Ethernet Interface Module User's Manual (Basic)

☞ MELSEC-L Ethernet Interface Module User's Manual (Basic)

The screens of QCPU (Q mode) are used in this section.

#### Screen display

Select [Diagnostics] ⇒ [Ethernet Diagnostics].



## Display contents

Item	Description
Target Module Setting	Select "Module No.", and specify an Ethernet module to be monitored. The following is the setting range. QCPU: 1 to 4 LCPU: 1 to 2
Change IP Address Display	Switch decimal/hexadecimal notation of IP address display.
Monitoring information	The following Ethernet module information can be monitored. <ul style="list-style-type: none"> <li>Parameter status (  ■ Monitoring the parameter status)</li> <li>Error history (  ■ Monitoring the error history)</li> <li>Status of each connection (  ■ Monitoring the status of each connection)</li> <li>Status of each protocol (  ■ Monitoring the status of each protocol)</li> <li>LED status (  ■ Monitoring the LED status)</li> <li>Received e-mail information (  ■ Monitoring the received e-mail information)</li> <li>Send e-mail information (  ■ Monitoring the send e-mail information)</li> </ul>

## Screen button


- **PING Test**  
Displays the PING Test screen. ( Section 21.7.3)
- **Loop Test** (Supported by QCPU (Q mode) only)  
Displays the Loopback Test screen. ( Section 21.7.4)
- **COM.ERR Off** (Supported by QCPU (Q mode) only)  
Turns OFF the [COM ERR] LED.

## ■ Monitoring the parameter status

Monitor the Ethernet module parameter status.

## Screen display

Select the <<Parameter Status>> tab on the Ethernet Diagnostics screen.



17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX


INDEX

## ■ Monitoring the error history

Monitor the error history area.

### Screen display

Select the <<Error History>> tab on the Ethernet Diagnostics screen.



### Screen button

- **Clear History**


Clears the error history.

## ■ Monitoring the status of each connection

Monitor the status of each connection.

### Screen display

Select the <<Status of Each Connection>> tab on the Ethernet Diagnostics screen.




## ■ Monitoring the status of each protocol

Monitor the status of each protocol.

### Screen display

Select the <<Status of Each Protocol>> tab on the Ethernet Diagnostics screen.




## ■ Monitoring the LED status

Monitor the status of LED on the front of the Ethernet module.

### Screen display

Select the <<LED Status>> tab on the Ethernet Diagnostics screen.



### Point

#### ● Considerations for monitoring

If RAM test or ROM test is set with the switch setting of an Ethernet module, programmable controller communication error occurs.

## ■ Monitoring the received e-mail information

Monitor the received e-mail information.

### Screen display

Select the <<Received E-mail Information>> tab on the **Ethernet Diagnostics** screen.

The screenshot shows the 'Ethernet Diagnostics' window with the 'Received E-mail Information' tab selected. The window title is 'Ethernet Diagnostics'. The 'Target Module Setting' section includes:
 

- Module No.: 1st Module
- I/O Address: 0000
- CPU: PLC No.1
- Change IP Address Display: DEC, HEX

 The main content area has several tabs: Parameter Status, Error History, Status of Each Connection, Status of Each Protocol, LED Status, Received E-mail Information (active), and Send E-mail Information.
   
 Under the active tab, there are several data fields:
 

- Number of Mails Remained on Server: [ ]
- Number of Attached File Receives: [ ]
- Number of Dedicated Instructions with Normal End: [ ]
- Frequency of Enquiries to Server: [ ]
- Number of Dedicated Instructions Ending with Errors: [ ]
- Frequency of Server Transfer Errors: [ ]
- Number of Normal Receives: [ ]
- Clear Information: [ ]

 Below these is an 'Error Log' section:
 

- Number of Error Log Writes: [ ]
- Clear History: [ ]

 A table with the following columns is displayed: No., Error Code, Command Code, From, Receive Date, Subject. The table contains 8 rows, with the first row labeled 'Latest'.
   
 At the bottom of the window, there are buttons: BING Test, Loop Test, COM.ERR Off, Start Monitor, Stop Monitor, and Close.

### Screen button


- **Clear Information**  
Clears the number of times set in each item by '0'.
- **Clear History**  
Clears "Number of Error Log Writes" by '0' and the contents of "Error Log".

## ■ Monitoring the send e-mail information

Monitor the send e-mail information.

### Screen display

Select the <<Send E-mail Information>> tab on the **Ethernet Diagnostics** screen.



### Screen button

- **Clear Information**  
Clears the number of times set in each item by '0'.
- **Clear History**  
Clears "Number of Error Log Writes" by '0' and the contents of "Error Log".

## 21.7.2 Ethernet Built-in CPU, FXCPU with Ethernet adapter connection

Check parameter status, error history, status of each connection, connection status, and time status setting of Ethernet Built-in CPU or FXCPU with Ethernet adapter.


For details of displayed items, refer to the following manuals.

- ☞ QCPU User's Manual (Hardware Design, Maintenance and Inspection)
- ☞ QnUCPU User's Manual (Communication via Built-in Ethernet Port)
- ☞ MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)
- ☞ MELSEC-L CPU Module User's Manual (Built-in Ethernet Function)
- ☞ FX3U-ENET-ADP User's Manual

### Screen display

Select [Diagnostics] ⇒ [Ethernet Diagnostics].

The following is a screen of LCPU.



### Display contents

Item	Description
Target Module Setting*1	Select "CPU", and specify the CPU to be monitored. Setting range is CPU number 1 to 4.
Change IP Address Display	Switch decimal/hexadecimal notation of IP address display.
Monitoring information	The following built-in Ethernet port information can be monitored. <ul style="list-style-type: none"> <li>• Parameter status (☞ ■ Monitoring the parameter status)</li> <li>• Error history (☞ ■ Monitoring the error history)</li> <li>• Status of each connection (☞ ■ Monitoring the status of each connection)</li> <li>• Access history*2 (☞ ■ Monitoring the status of each connection)</li> <li>• Connection status (☞ ■ Monitoring the connection status)</li> <li>• Time status setting (☞ ■ Monitoring the time setting status)</li> <li>• Simple PLC communication status*3 (☞ ■ Monitoring the simple PLC communication status)</li> <li>• Protocol status*2 (☞ ■ Monitoring the protocol status)</li> </ul>

\*1 : For QCPU (Q mode) only

\*2 : For FXCPU only

\*3 : For LCPU only

### Screen button

For the buttons on the screen, refer to Section 21.7.




## ■ Monitoring the parameter status

Monitor the parameter status of Ethernet Built-in CPU or FXCPU with Ethernet adapter.

### Screen display

Select the <<Parameter Status>> tab on the Ethernet Diagnostics screen.  
The following is a screen of LCP.




## ■ Monitoring the error history

Monitor the error history area.

### Screen display

Select the <<Error History>> tab on the Ethernet Diagnostics screen.  
The following is a screen of LCP.



### Screen button

- **Clear History**  
Clears the error history.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

## Monitoring the status of each connection

Monitor the status of each connection.

For FXCPU, the status of each connection can be monitored by the access history function.

### Screen display

Select the <<Status of Each Connection>> tab on the **Ethernet Diagnostics** screen.  
<QCPU (Q mode)/LCPU>

Connection No./Function	Host Station Port No.	Destination IP Address	Destination Port No.	Latest Error Code	Protocol	Open System	TCP Status	Remote Password Status	Unlock Error Count	Forced Deactivation Status
1	----	0.0.0.0	----	----	UDP	MELSOFT Connection	----	Invalid or Locked	0	Allowed
2	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Invalid or Locked	0	Allowed
3	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Invalid or Locked	0	Allowed
4	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Invalid or Locked	0	Allowed
5	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Invalid or Locked	0	Allowed
6	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Invalid or Locked	0	Allowed
7	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Invalid or Locked	0	Allowed
8	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Invalid or Locked	0	Allowed
9	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Invalid or Locked	0	Allowed
10	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Invalid or Locked	0	Allowed
11	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Invalid or Locked	0	Allowed
12	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Invalid or Locked	0	Allowed
13	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Invalid or Locked	0	Allowed
14	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Invalid or Locked	0	Allowed
15	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Invalid or Locked	0	Allowed
16	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Invalid or Locked	0	Allowed
FTP Server	----	0.0.0.0	----	----	----	----	Disconnected	Invalid or Locked	0	Allowed
MELSOFT Direct Connection	----	0.0.0.0	----	----	----	----	----	Invalid or Locked	0	Allowed

<FXCPU>

Connection No./Function	Host Station Port No.	Destination IP Address	Destination Port No.	Latest Error Code	Protocol	Open System	TCP Status	Forced Deactivation Status
1	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Allowed
2	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Allowed
3	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Allowed
4	----	0.0.0.0	----	----	TCP	MELSOFT Connection	Disconnected	Allowed
MELSOFT Direct Connection	----	0.0.0.0	----	----	----	----	----	Allowed

Latest	Year/Month/Day	Time	Connection No.	Protocol	Open System	Destination IP Address
2						
3						
4						
5						
6						
7						
8						
9						
10						

### Screen button

- **Clear Latest Error Code**  
Clears the error codes.
- **Clear Unlock Error Count (QCPU (Q mode)/LCPU only)**  
Clears "Unlock Error Count".
- **Disable Deactivation of Selected Row**  
Allows the connection of the selected row.
- **Force Deactivation of Selected Row**  
Cancels the connection of the selected row.
- **Clear History (FXCPU only)**  
Clears the access history.


## ■ Monitoring the connection status

Monitor the connection status.

For FXCPU, the broadcast information is not monitored.

### Screen display

Select the <<Connection Status>> tab on the Ethernet Diagnostics screen.  
The following is a screen of LCPU.



### Screen button

- **Clear Line Status** (QCPU (Q mode)/LCPU only)  
Clears the number of receive buffer overflows and broadcast information.


17  
MONITORING18  
SIMULATING PROGRAMS19  
DEBUGGING PROGRAMS20  
OPERATING PROGRAMMABLE CONTROLLER CPU21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS22  
SIMULATING OPERATIONS OF EXTERNAL DEVICESA  
APPENDIXI  
INDEX

## ■ Monitoring the time setting status

Monitor the time setting status.

### Screen display

Select the <<Time Setting Status>> tab on the **Ethernet Diagnostics** screen.  
The following is a screen of Built-in Ethernet port QCPU.



### Screen button

- **Execute Time Setting**

Sets the time according to the time setting on the <<Built-in Ethernet Port Setting>> tab of PLC parameter written to the programmable controller CPU.

### Point

- **Setting time**

For Ethernet Built-in CPU and FXCPU with Ethernet adapter, the time on a programmable controller CPU can be set automatically by collecting the time information from the time information server (SNTP server) connected to the LAN according to the time setting on the <<Built-in Ethernet Port Setting>> tab of PLC parameter.

For details of the time setting, refer to the following manuals.

- ☞ QnUCPU User's Manual (Communication via Built-in Ethernet Port)
- ☞ MELSEC-L CPU Module User's Manual (Built-in Ethernet Function)
- ☞ FX3U-ENET-ADP User's Manual


## ■ Monitoring the simple PLC communication status

Monitor the simple PLC communication status.

This function can be executed only when using LCPU with a serial number whose first five digits are '13042' or higher.

### Screen display


Select the <<Simple PLC Communication Status>> tab on the Ethernet Diagnostics screen.



### Screen button

#### ● Details

Displays the Details screen which shows detailed information of each setting.



#### ● Displaying simple PLC communication status

Since the simple PLC communication status indicates the current status, the error history may not be confirmed. Confirm errors on the <<Error History>> tab.

( ← ■ Monitoring the error history)

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX


## ■ Monitoring the protocol status

Monitor the total number of communication packets.

This function can be executed only when using FXCPU with Ethernet adapter.

### Screen display

Select the <<Protocol Status>> tab on the Ethernet Diagnostics screen.



### Screen button

- **Clear the Status of Each Protocol**  
Clears the protocol status.

### 21.7.3 PING test

A PING test is a test to check the existence of Ethernet modules to which the initial processing has been completed, or devices with specified IP address on the same Ethernet line.

The following checks are performed when the PING test is executed on Ethernet module, Ethernet Built-in CPU, or FXCPU with Ethernet adapter.

- Whether the line is connected correctly between the host station and the target device.
- Whether the parameters are set correctly for the Ethernet module on host station.
- Whether the initial processing has been completed correctly for the Ethernet module on host station. (For Ethernet module only)

#### Point

##### ● Required setting items

Make sure to check the following before executing the PING test when using an Ethernet module.

- "Station No. ↔ IP Information" of Ethernet parameter is set.
- RUN LED and INT LED on the Ethernet module are ON.

##### ● System configuration where the PING test can be executed

- A PING test is valid for the system configured with Ethernet, MELSECNET/10(H), and CC-Link IE Controller Network. It cannot be executed via CC-Link, CC-Link IE Field Network, and serial communication.
- A PING test can only be executed to the Ethernet module on the same segment as the target station. However, it cannot be executed to a host station.

##### ● Administrator authority required to execute the PING test

To execute the PING test, the user must log on Windows® as the user having the administrator authority.

### ■ PING test overview

The following are the two methods to execute a PING test.

- Sending a ping from an Ethernet module\*<sup>1</sup>

Execute a PING test on a device (PING test target station) exists on the same network as the Ethernet module (PING test execution station) which sends a ping.

When "Ethernet Module" is selected for "PLC side I/F" on the Transfer Setup screen, specify a PING test target station only.

When "PLC Module" is selected for "PLC side I/F" on the Transfer Setup screen, specify a PING test execution station and a PING test target station.

\*<sup>1</sup> : Not supported by FXCPU with Ethernet adapter.
- Sending a ping from an Ethernet board on a personal computer
 

The same operation as a PING test executed by the command prompt of Windows®. A PING test is executed on a device on the network via Ethernet from a personal computer.

17  
MONITORING18  
SIMULATING  
PROGRAMS19  
DEBUGGING  
PROGRAMS20  
OPERATING  
PROGRAMMABLE  
CONTROLLER CPU21  
DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS22  
SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICESA  
APPENDIXI  
INDEX

● **Sending a ping from an Ethernet module (when "Ethernet Module" is selected for "PLC side I/F")**

A PING test is executed on a device on the same network from the access station when accessing the programmable controller CPU via Ethernet module.

This function is not supported by FXCPU with Ethernet adapter.



PING test execution station: Access target station (A station does not need to be specified.)

PING test target station: Specify a device on the same network as the access target station.

Select "Module No." for "Target Module Setting" on the Ethernet Diagnostics screen.

For the settings on the Transfer Setup screen, refer to the following example.

For the system configuration described in the following figure, configure the settings of the connection destination as shown below to execute a PING test for station number 1 from the station number 2.





● **Sending a ping from an Ethernet module (when "PLC Module" is selected for "PLC side I/F")**

A PING test is executed on a device on the same network from an Ethernet module which exists on the same base unit as the connected station when accessing the programmable controller CPU with a serial/USB/Ethernet port direct connection or a connection via Ethernet hub.

This function is not supported by the programmable controller CPU accessed via a built-in Ethernet port of Ethernet Built-in CPU or FXCPU with Ethernet adapter.

PING test execution station: Specify an Ethernet module which exists on the same base unit as the connected station.



PING test target station: Specify a device on the same network as the PING test execution station.

Select "Module No." for "Target Module Setting" on the Ethernet Diagnostics screen.

For the settings on the Transfer Setup screen, refer to the following example.

For the system configuration described in the following figure, configure the settings of the connection destination as shown below to execute a PING test for the station number 2 on the network number 2.

When the Ethernet module (station number 1 on network number 1 in the system shown below) is Q series-compatible E71 module, a PING test can be executed with the function version B or later only.



17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

● Sending a ping from an Ethernet board on a personal computer

Select "CPU" for "Target Module Setting" on the Ethernet Diagnostics screen.  
 Settings on the Transfer Setup screen is not necessary. The already-set connection destination settings do not affect the execution of PING test.  
 For FXCPU with Ethernet adapter, the specification of target module is not necessary.

**Screen display**


Perform any of the following operations.

Click the **PING Test** button on the Ethernet Diagnostics screen.


Click the **Loop Test** button the Ethernet Diagnostics screen and click the **PING Test** button on the Loop Test screen.

● Sending a ping from an Ethernet module (when "Module No." is selected for "Target Module Setting")

<<"Ethernet Module" is selected for "PLC side I/F">>




<<"PLC Module" is selected for "PLC side I/F">>



PING test information

Sub status bar

● Sending a ping from an Ethernet board on a personal computer (when "CPU" is selected for "Target Module Setting")



PING test information

Sub status bar

## Operating procedure

### 1. Set the items on the screen.

Item	Description
Input Item	–
Address Specification	Set the IP address of the target Ethernet module for PING test.
Transfer Setup	Specify the connection destination of the PING test.
Execution Station of PING	Set the network number and station number of the Ethernet module which executes the PING test.
Target of PING	Set the IP address of the Ethernet module which is a target of the PING test.
Setting Options	Set whether to display a host name in the result. Also set data size (For Q series-compatible E71 and FXCPU with Ethernet adapter: 1 to 8,192 bytes, for Ethernet Built-in CPU: 1 to 1,460 bytes), communication time check (1 to 30 seconds), number of transmissions (1 to 50 times, or until interrupted).

### 2. Click the button.

The PING test is executed according to the settings.

## Display contents

Item	Description
PING test information	Display the IP address and data size to which the PING test is executed.
When "Module No." is selected for "Target Module Setting" ("Ethernet Module" is selected for "PLC side I/F")*1 When "CPU" is selected for "Target Module Setting"*1	<ul style="list-style-type: none"> <li>● <b>Transmitting data</b> <ul style="list-style-type: none"> <li>• When successful IP address (example: Reply from 10.97.29.75): Data size (example: bytes=32) Communication speed (example: time&lt;1ms TTL=128)</li> <li>• When unsuccessful Request timed out.</li> </ul> </li> <li>● <b>Completion of data transmission</b> <ul style="list-style-type: none"> <li>Packets transmitted</li> <li>Received</li> <li>Lost</li> <li>Minimum packet round-trip time (ms)</li> <li>Maximum packet round-trip time (ms)</li> <li>Average packet round-trip time (ms)</li> <li>"Packets transmitted" and "Received" are updated each time a packet is sent.</li> </ul> </li> </ul>
When "Module No." is selected for "Target Module Setting" ("PLC Module" is selected for "PLC side I/F")*1	<ul style="list-style-type: none"> <li>● <b>Transmitting data</b> <ul style="list-style-type: none"> <li>• When successful Success</li> <li>• When unsuccessful Time Out</li> </ul> </li> <li>● <b>Completion of data transmission</b> <ul style="list-style-type: none"> <li>Packets transmitted</li> <li>Received</li> <li>Lost</li> <li>"Packets transmitted" and "Received" are updated each time a packet is sent.</li> </ul> </li> </ul>
Sub status bar	Display the number of send successes and total number of packet transmissions.

\*1 : Not supported by FXCPU.

## Screen button

-  Default

Resets the setting items of option setting to their defaults.

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

## 21.7.4 Loopback test

---

A loopback test is a test to check whether the initial processing of each module has been completed by sending a loopback test message to the Q series-compatible E71 modules (function version B or later) of the specified network number or station number.

The following checks are performed when the loopback test is executed.

- Whether the line is connected correctly between the host station and the target device.
- Whether the parameters are set correctly for the Ethernet module on host station.
- Whether the initial processing has been completed correctly for the Ethernet module on host station.

### Point

#### ● Required setting items

Make sure to check the following before executing the loopback test when using an Ethernet module.

- "Station No. ⇔ IP Information" of Ethernet parameter is set.
- RUN LED and INT LED on the Ethernet module are ON.

#### ● System configuration where the loopback test can be executed

- A loopback test is available only with Q series-compatible E71 modules (function version B or later). Ethernet modules (function version A) are treated as "No Response" even if connected.  
A loopback test is valid for the system configured only with Ethernet.
- A loopback test can only be executed to the Ethernet module on the same segment as the target station.

#### ● Considerations for executing the loopback test

In a multiple network system, to execute the loopback test by specifying a station number in another network number, setting the routing parameters is necessary.


---

## Loopback test overview

For a loopback test, a target station differs according to the connection destination setting described below.


- When "Ethernet Module" is selected for "PLC side I/F" on the Transfer Setup screen.
- When "PLC Module" is selected for "PLC side I/F" on the Transfer Setup screen.

### ● When "Ethernet Module" is selected for "PLC side I/F"



A loopback test is executed to the network number specified on the Loopback Test screen when accessing the programmable controller CPU via Ethernet module.

In the system as shown below, when the loopback test is executed for station numbers 2 to 4 in network number 2, the response from the station number 2 (loopback test execution station) is treated as "No Response".



17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES


A

APPENDIX

I



INDEX

● When "PLC Module" is selected for "PLC side I/F"




A loopback test is executed to the network number specified on the Loopback Test screen when accessing the programmable controller CPU with a serial/USB/Ethernet port direct connection or a connection via Ethernet hub.

For the system configuration described in the following figure, configure the settings of the connection destination as shown below to execute a loopback test for the Ethernet module on the network number 2.



## Screen display

Click the **Loop Test** button on the **Ethernet Diagnostics** screen.



## Display contents

Item	Description
Network No.	Set the network number for which the loopback test is executed. Setting range: 1 to 239
Number of Confirmation Nodes	Set the station number to be checked. Setting range: 1 to 64
Check at Communication Time	Setting range: 1 to 99 seconds. <b>Initial Setting</b> of Ethernet parameter includes TCP Resend Timer. The communication time check value of loopback test must be larger than the value set for TCP Resend Timer. If not, the tested Ethernet module may be judged inexistent even if it is connected correctly.
Result	The loopback test is executed in order from the start station number and whether or not the response is returned within the set communication time check value is displayed in the order of station numbers. If an IP address is duplicated, such IP address is displayed in red.
IP Address Input Style	Switch decimal/hexadecimal notation of IP address display.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

## 21.8 Executing Sensor/Device Monitoring



Check the status of iQSS-compatible devices.

For details of the sensor/device monitoring function, refer to the following manual.

 [iQ Sensor Solution Reference Manual](#)



# 21.9 System Monitor




This section explains how to display the system status of the programmable controller CPU.

## Screen display


Select [Diagnostics] => [System Monitor].

Some terms and module images are different but the screen configurations are same between the screens of QCPU (Q mode) and LCPU. The screens of QCPU (Q mode) are used in this section.

<QCPU (Q mode) (without extension base unit)>



<QCPU (Q mode) (with extension base unit)>



17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## <Redundant CPU>

**System Monitor**

Monitor Status: Monitoring | Connection Channel List: Serial Port, PLC Module Connection | System Image...

Mode:  System monitor  Online module change

Main Base:  Main Base | I/O Adr.: 0000 0010 0020 0030

Redundant system (Target system):  Standby system[System B]

Extension Base:  Extension1/7Line

Operation to Selected Module: Main Base: CPU, Slot: Q25PRHCPU

**Base Information List**

Base	Module	Base Model Name	Power Supply	Base Type	Slots	Installed Modules
		Main Base	Exist	Q	5	0
		Extension Base1				
		Extension Base2				
		Extension Base3				
		Extension Base4				
		Extension Base5				
		Extension Base6				
		Extension Base7				
Overall		1Base				0Module

**Module Information List (Main Base)**

Status	Base-Slot	Series	Model Name	Point	Parameter Type	Point	I/O Address	Network No. Station No.
-	-	-	Power	-	Power	-	-	-
	0-0	Q	Q25PRHCPU System A Control system Backup mode	-	CPU	-	-	-
	0-1	-	Empty	-	Empty	16Point	0000	-
	0-2	-	Empty	-	Empty	16Point	0010	-
	0-3	-	Empty	-	Empty	16Point	0020	-
	0-4	-	Empty	-	Empty	16Point	0030	-

Legend: Error (Red X), Major Error (Red Circle), Moderate Error (Red Triangle), Minor Error (Yellow Triangle), Assignment Error (Yellow Circle), Module Changing (Blue Circle), Assignment Incorrect (Blue Circle)

Buttons: Stop Monitor, Print, Product Information List, System Error History, Close

## <Remote I/O module>

**System Monitor**

Monitor Status: Monitoring | Connection Channel List: Serial Port NET10(H) Remote Module Connection(RS-232C) | System Image...

Mode:  System Monitor  Online Module Change

Main Base:  Main Base | I/O Adr.: 0000 0010 0030 0050 0060

Operation to Selected Module: Main Base: CPU, Slot: Q372LP25-25

**Main Base Information List**

Base	Module	Base Model Name	Power Supply	Base Type	Slots	Installed Modules
		Main Base	Exist	Q	5	3
		Extension Base1				
		Extension Base2				
		Extension Base3				
		Extension Base4				
		Extension Base5				
		Extension Base6				
		Extension Base7				
Overall		1Base				3Module


**Module Information List (Main Base)**

Status	Base-Slot	Series	Model Name	Point	Parameter Type	Point	I/O Address	Network No. Station No.	Master PLC
-	-	-	Power	-	Power	-	-	-	-
	0-0	Q	Q372LP25-25	-	CPU	-	-	1-1	-
	0-0	Q	Q650AIN	16Point	Intelli.	16Point	0000	-	-
	0-1	Q	Q07SP4	32Point	Intelli.	32Point	0010	-	-
	0-2	Q	Q371GR21-SX	32Point	Intelli.	32Point	0030	1****	-
	0-3	-	Empty	-	Empty	16Point	0050	-	-
	0-4	-	Empty	-	Empty	16Point	0060	-	-

Legend: Error (Red X), Major Error (Red Circle), Moderate Error (Red Triangle), Minor Error (Yellow Triangle), Assignment Error (Yellow Circle), Module Changing (Blue Circle), Assignment Incorrect (Blue Circle)

Buttons: Stop Monitor, Print, Product Information List, System Error History, Close

## Display contents

Item	Description
Monitor Status	Display the current monitor status.
Connection Channel List	Display the information of the route to the connection destination.
Mode*1	Select this to perform either system monitor or online module change function.
System Monitor	Execute the system monitor.
Online Module Change	Execute the online module change. (For details, refer to  Section 21.10)
Main Base*2	Display the operating status of the module and I/O address.
Redundant system (Target system)*3	Display the information of the target system.
Operation to Selected Module	Display the name, slot number, and model name of the base unit/block to which the selected module is mounted.*4
Extension Base*2	This item is displayed when the extension base unit/block is connected. Switch the display by pressing the arrow button on the right. The base unit/block, operating status of the module, and I/O address are displayed.
Base Information List*2	Display the status of each base unit/block.
Base*2	Display the status of the base unit/block.
Module	Display the error status of each module mounted to the base unit/block.
Base Model Name*2	Display the base name set to the parameter on the programmable controller CPU. If the parameter is not set, "Main Base", "Extension Base 1" to "Extension Base 7" are displayed.
Power Supply	Display whether there is power supply.
Base Type*2	Display the type of the base unit/block. For Q series, "QA" is displayed for QA extension base unit. "Q" is displayed for other base units. For L series, "LA" is displayed for LA1S extension base unit. "L" is displayed for other blocks.
Slots	Display the slot number.
Installed Modules*5	Display the number of modules mounted to the base unit.
Number Of Total Modules Occupations*6	Display the total number of modules counted for all mounted modules.*7
Module Information List	Display the information of modules on the base unit/block where the selected module is mounted.
Status	Display the status of each module.
Base-Slot*2	Display the slot number of each module.
Series*4	Display the series of each module.
Model Name*4	Display the model name of each module.
Point*4	Display the number of occupied I/O points of each module.
Parameter	Type Point*4
I/O Address*4	Display the I/O address of each module set to the parameter on the programmable controller CPU. If the parameter is not set, type/points of the mounted module is displayed.
Network No. Station No.*4	Display the network number and the station number set to each module.
Master PLC*5	Display the programmable controller CPU number that controls each module in a multiple CPU configuration. "-" is displayed for the programmable controller CPU or the blank slot.
Number Of Module Occupied*6,*7	Display the number of modules counted for each module.
Legend	Display the legend of the icon displayed on the screen.

\*1 : For Process CPU, Redundant CPU, and remote I/O module only.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

\*2 : Each item is displayed as shown below according to the programmable controller series.

QCPU (Q mode)	LCPU
Main Base	Main Block
Extension base	Extension block
Base Information List	Block Information List
Base	Block
Base Model Name	Block Name
Base Type	Block Type
Base-Slot	Block-Slot


\*3 : For Redundant CPU only

\*4 : "\*\*\*\*\*", "\_", and "\*\*\*\*" are displayed if the module is not mounted or the parameter is different with the mounting status.

\*5 : For QCPU (Q mode) only

\*6 : For LCPU only

\*7 : A module with width exceeding 28.5mm logically counts as two modules.

Be sure that "Number Of Total Modules Occupations" does not exceed the number of modules that can be mounted.  
 MELSEC-L CPU Module User's Manual (Hardware Design, Maintenance and Inspection)

### Point

#### ● Connection Channel List

In "Connection Channel List", the route information of the connection destination setting is displayed at all times.

#### ● Considerations when using QA extension base unit or LA1S extension base unit

- QA extension base unit is supported by High Performance model QCPUs and Universal model QCPUs with a serial number whose first five digits are '12102' or higher. When using those programmable controller CPUs which do not support it, QA extension base unit is not displayed on the System Monitor screen.
- LA1S extension base unit is supported by LCPUs with a serial number whose first five digits are '16112' or higher. When using LCPUs which do not support LA1S extension base unit, it is not displayed on the System Monitor screen.
- When A series module or QnA series module is mounted on the QA extension base unit, the images displayed on the system monitor of both A series and QnA series modules are common. Additionally, a module type is displayed for Model Name of Module Information List.
- When A series or QnA series module is selected, the functions under "Operation to Selected Module" cannot be performed.


#### ● System monitor when a GOT is connected via bus


When a GOT is connected via bus, a single row of extension base unit (16 points x 10 slots) is displayed on the System Monitor screen, and the GOT is displayed as an intelligent function module with 16 I/O points.

The displayed slot position is the position set on the GOT side.

For details of GOT bus connection, refer to the following manuals.

 GOT2000 Series Connection Manual (Mitsubishi Products) For GT Works3 Version1


 GOT1000 Series Connection Manual (Mitsubishi Products) for GT Works3

 GOT-A900 Series User's Manual (GT Works2 Version2/GT Designer2 Version2 compatible Connection System Manual)

## Screen button

- **System Image...**


Displays the illustration of the connection route.  
(☞ Section 14.1.1)



- **Detailed Information**

Displays the module information of the selected module.  
The following is an example of the Module's Detailed Information screen when QJ71LP21-25 is selected.


(☞ Section 21.9.1)

17  
MONITORING18  
SIMULATING PROGRAMS19  
DEBUGGING PROGRAMS20  
OPERATING PROGRAMMABLE CONTROLLER CPU21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS22  
SIMULATING OPERATIONS OF EXTERNAL DEVICESA  
APPENDIX

INDEX


**H/W Information**

Displays the hardware LED information and the hardware switch information. The display contents of the H/W Information differ according to module version. For details, refer to the User's Manual of each module.




**Diagnostics**

Displays the diagnostic information of the selected module. The following is an example of the PLC Diagnostics screen when the programmable controller CPU module is selected. (See Section 21.1)




● **Error History Detail**

Displays error history logs of the module selected on the System Monitor screen. This button is available when GX Works2 is connected to the programmable controller CPU that supports the module error history collection function. (☞ Section 21.9.2)




● **Print**

Prints the figure of the system configuration.



● **Product information List...**

Displays the product information of each module mounted to the base unit/block.




• Clicking the **Create CSV File** button saves the product information data in CSV file format.

● **System Error History**

Displays all error history logs of the programmable controller and modules.

This button is available when GX Works2 is connected to the programmable controller CPU that supports the module error history collection function.

(☞ Section 21.9.2)






**Point**

● **Operation to selected module**


The functions of "Operation to Selected Module" can also be executed from the shortcut menu by selecting modules from "Main Base" or "Extension Base" ("Main Block" or "Extension Block" for LCPU).



● **Displaying module status**

The following screen is displayed if the mounting status of the module cannot be obtained due to the incorrect parameter settings.

Execute the system monitor function again after adjusting the parameter to the mounting status.



17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

**■ Error icons**

The following table shows the details of the error status icons of the programmable controller CPU and the modules.

Module	Icon	Error	Programmable controller CPU status
Programmable controller CPU	Serious error	MAIN CPU down	RESET and others
	Moderate error	Stop error	STOP due to error in parameter or instruction codes
	Minor error	Error allowing operation	Errors that allow RUN status such as battery low and annunciator ON
	Assignment error	Assignment error	Assignment errors such as multiple CPU setting is not set.
Module	Error	H/W error	H/W errors in the base or the power supply
	Serious error*1	Module system error	H/W errors in modules
	Moderate error	Module error	No appropriate environment for executing the functions of modules
	Minor error*1	Module warning	Impropriety in programs or user's operations
	Assignment error	Assignment error	The assigning status of the module is different with the mounting status of the module. (The status that the module type and points cannot be obtained.)
	Illegal assignment	Illegal assignment	The assigning status of the module is different with the mounting status of the module. (The status that the module type and points can be obtained.)

\*1 : This item is not displayed for remote I/O module.

**■ Display when mounted modules do not match with the I/O assignment setting on PLC parameter**

The following shows "Module Information List" on the System monitor function according to the I/O assignment on PLC parameter. If module mounting status does not match with the I/O assignment, change "I/O Assignment" of the I/O assignment setting to match with the mounting status. "\*\*\*\*\*", "-", and "\*\*\*" are displayed if the module is not mounted, or the parameter is different with the mounting status.

Status	Base-Slot	Series	Model Name	Point	Parameter		I/O Address	Network No. Station No.	Master PLC
					Type	Point			
	-	-	Power	-	Power	-	-	-	-
	CPU	Q	Q03UDCPU	-	CPU	-	-	-	-
	0-0	Q	QJ61BT11	32Point	Intelli.	128Point	0090	-	-
	0-1	-	Intelli.	16Point	-	**Point	0080	-	-
	0-2	-	*****	**Point	-	**Point	-	-	-
	0-3	-	Empty	-	-	**Point	-	-	-


## 21.9.1 Checking module's detailed information

Display the module information of the selected module.

### ■ Modules of QCPU (Q mode)/LCP

#### Screen display

Select a module on the System Monitor screen and click the Detailed Information button. The following is an example of the Module's Detailed Information screen when QJ71LP21-25 is selected.



#### Screen button

- **H/W Information**  
Displays the hardware LED information and the hardware switch information. (☞ Section 21.9)
- **Update Error History**  
Updates the error history of the module.
- **Clear Error History** **(Supported by LCPU only)**  
Deletes the error history of the module.
- **Error Clear**  
Clears the error displayed in "Latest Error Code".

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX


I

INDEX

## ■ Built-in I/O module

### Screen display

Select a built-in I/O module on the **System Monitor** screen and click the **Detailed Information** button.






### Screen button

For the buttons on the screen, refer to ■ Modules of QCPU (Q mode)/LCPU.

- **Built-in Function <<** / **Built-in Function >>**

Displays/hides the built-in function buttons.


For details of the built-in function buttons, refer to the following sections.

- Positioning monitor  Section 21.11.1
- High-speed counter monitor  Section 21.11.2
- I/O monitor  Section 21.11.3

## ■ Built-in CC-Link module

### Screen display

Select a built-in CC-Link module on the **System Monitor** screen and click the **Detailed Information** button.



### Screen button

For the buttons on the screen, refer to ■ Modules of QCPU (Q mode)/LCPU.

17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## 21.9.2 Checking details of error history

Check error history of the programmable controller CPU and modules.  
Error history of a specified module can be displayed by using the refine search function.

### Screen display

Select [Diagnostics] ⇒ [System Monitor] ⇒ Error History Detail / System Error History  
<Error history (when programmable controller CPU is selected)>

**Error History**

Monitor Status: **STOP** Stop Monitor

Connection Channel List: Serial Port: PLC Module Connection(USB) System Image...

**Refine Search**  
Match all of the criteria below  
None  
Clear Refine Criteria... Enter Refine Criteria...

**Error History**  
Error History List  
Displayed Errors/Errors: 117/117 Error Code Notation: DEC HEX

No.	Error Code	Date and Time	Model Name	Start I/O
00117	0960	2010/01/20 13:32:10	Q03UDCPU	----
00116	0960	2010/01/20 13:28:08	Q03UDCPU	----
00115	0960	2010/01/01 10:39:19	Q03UDCPU	----
00114	0960	2010/01/01 10:38:53	Q03UDCPU	----
00113	0960	2010/01/01 10:27:36	Q03UDCPU	----
00112	0579	2009/12/26 17:00:58	Q03UDCPU	----
00111	05DC	2009/12/26 10:29:08	Q03UDCPU	----
00110	05DC	2009/12/26 10:07:05	Q03UDCPU	----
00109	09C5	2009/12/26 09:04:26	Q03UDCPU	----
00108	09C5	2009/12/26 09:00:45	Q03UDCPU	----
00107	09C5	2009/12/25 17:07:59	Q03UDCPU	----
00106	09C5	2009/12/25 16:51:35	Q03UDCPU	----
00105	09C5	2009/12/25 16:49:45	Q03UDCPU	----
00104	09C5	2009/12/25 16:48:23	Q03UDCPU	----
00103	09C5	2009/12/25 16:46:29	Q03UDCPU	----
00102	09C5	2009/12/25 16:30:06	Q03UDCPU	----
00101	09C5	2009/12/25 16:22:30	Q03UDCPU	----
00100	09C5	2009/12/25 16:13:45	Q03UDCPU	----
00099	09C5	2009/12/25 16:12:30	Q03UDCPU	----

Clear History... Refresh Create CSV File... Close

**Error Details**  
Model Name: Q03UDCPU  
Start I/O: ----  
Mount Position: Main Base PLC Slot

**Error and Solution** Intelligent Module Information

**Explanation**  
The start I/O number in the intelligent function module parameter set on GX Configurator differs from the actual I/O number.

**Solution**  
Check the parameter setting.

<System error history>

**Error History**

Monitor Status: **STOP** Stop Monitor

Connection Channel List: Serial Port: PLC Module Connection(USB) System Image...

**Refine Search**  
Match all of the criteria below  
None  
Clear Refine Criteria... Enter Refine Criteria...

**Error History**  
Error History List  
Displayed Errors/Errors: 117/117 Error Code Notation: DEC HEX

No.	Error Code	Date and Time	Model Name	Start I/O
00017	F111	2009/07/16 13:59:18	QJ71LP215-25	0010
00016	F111	2009/07/16 13:40:21	QJ71LP215-25	0010
00015	F111	2009/07/16 13:37:26	QJ71LP215-25	0010
00014	F111	2009/07/16 13:34:10	QJ71LP215-25	0010
00013	F803	0000/00/00 00:00:00	QJ71LP215-25	0030
00012	F803	0000/00/00 00:00:00	QJ71LP215-25	0030
00011	F803	0000/00/00 00:00:00	QJ71LP215-25	0030
00010	F803	0000/00/00 00:00:00	QJ71LP215-25	0030
00009	F803	0000/00/00 00:00:00	QJ71LP215-25	0030
00008	FD0A	0000/00/00 00:00:00	QJ71LP215-25	0030
00007	FD24	0000/00/00 00:00:00	QJ71LP215-25	0030
00006	FD24	0000/00/00 00:00:00	QJ71LP215-25	0030
00005	F803	0000/00/00 00:00:00	QJ71LP215-25	0010
00004	F820	0000/00/00 00:00:00	QJ71LP215-25	0010
00003	FD04	0000/00/00 00:00:00	QJ71LP215-25	0010
00002	FD24	0000/00/00 00:00:00	QJ71LP215-25	0010
00001	FD04	0000/00/00 00:00:00	QJ71LP215-25	0010
00117	0960	2010/01/20 13:32:10	Q03UDCPU	----
00116	0960	2010/01/20 13:28:08	Q03UDCPU	----

Clear History... Refresh Create CSV File... Close

**Error Details**  
Model Name: QJ71LP215-25  
Start I/O: 0010  
Mount Position: Main Base Slot No. 1

**Error and Solution** Intelligent Module Information

**Module Information**

Item	Information
Baton pass status (host)	Executing ba...
Cause of data link stop	Normal
Baton pass status of each station ...	0000000000...
Baton pass status of each station ...	0000000000...
Baton pass status of each station ...	0000000000...
Baton pass status of each station ...	0000000000...
Loopback station (forward loop side)	1
Loopback station (reverse loop side)	0
Cyclic transmission status of each ...	0000000000...
Cyclic transmission status of each ...	0000000000...
Cyclic transmission status of each ...	0000000000...


## Display contents

Item	Description
Monitor Status	Display the current monitor status.
Connection Channel List	Display the information of the connection destination setting.
Refine Search	Display the refinement criteria for the error history list. Not displayed when no refinement criterion is specified.
Error History List	–
Error Code Notation	Select the display format of error codes (DEC/HEX).
No.	Display the error history number. Errors are numbered in order of occurring.
Error Code	Display the error code that indicates details of the error.
Date and Time	Display date and time of the error occurrence.
Model Name	Display the model name of the module on which the error occurs.
Start I/O	Display the start I/O number of the module on which the error occurs.
Error Details	–
Model Name	Display the model name of the module selected in the error history list.
Start I/O	Display the start I/O number of the module selected in the error history list. For the module that uses multiple slots, the starting slot is only displayed.
Mount Position	Display the mount position of the module selected in the error history list.
<<Error and Solution>>	Display the explanation and solution of the error on the module being selected in the error history list.
<<Intelligent Module Information>>	Display the module information at the error occurrence of the intelligent function module being selected in the error history list.

## Screen button

For the buttons on the screen, refer to Section 21.9.

- **Clear Refine Criteria...**  
Clears all refinement criteria.
- **Enter Refine Criteria...**  
Displays the Enter Refine Criteria screen.  
To start refining the search, click the **Start Refine** button.



- **Clear History...**  
Clears the error history saved on the programmable controller CPU.
- **Refresh**  
Updates information displayed in the error history list.
- **Create CSV File...**  
Exports information displayed in the error history list to a file in CSV format.

### Point

- **Programmable controller CPUs and modules that support the function to display detailed error history**  
Detailed error history can be displayed when a programmable controller CPU and intelligent function module that support the module error history collection function are used.  
For versions of modules that support the function, refer to the User's Manual of each module.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## 21.10 Changing Modules Online




\*1 : Process CPU and Redundant CPU only

This section explains how to change modules online.


### Screen display

Select [Diagnostics] ⇒ [Online Module Change].  
<Remote I/O module>



### Operating procedure

1. Double-click the module to be exchanged on the System Monitor screen.  
The Online Module Change screen is displayed.



2. Change the module by following the instruction of "Status/Guidance".



**Point**

- **Remote I/O module versions compatible with Online module change**

Use the function version D or later to perform the Online module change function on a remote I/O module. For the method for checking the function version, refer to the following manual.

☞ Q Corresponding MELSECNET/H Network System Reference Manual (Remote I/O network)

- **Canceling Online module change**

- Online module change can be suspended by clicking the **Cancel** button during the process of Online module change to check the system status with monitoring or current value change.
- Online module change can be continued from the suspended status by selecting [Diagnostics] ⇒ [Online Module Change].
- Online module change can also be continued when GX Works2 is terminated during the process of Online module change by restarting GX Works2 and performing the same operation above.


- **Executing Online module change on a single programmable controller CPU from two personal computers**

The authority to execute Online module change can be transferred to the personal computer which executed the function later.

- **Online module change during monitoring**

Stop monitoring before executing Online module change.

Online module change can be executed without stopping the monitoring, however, the following message will be displayed.

**Restrictions**

- **Restrictions on Online module change**

- Online module change cannot be performed to multiple modules simultaneously.
- Online module change cannot be continued when the programmable controller CPU is reset, or the power is turned OFF during the process of Online module change.
- Online module change cannot be performed when a Process CPU or Redundant CPU is in the following state.
  - The RESET/L.CLR switch of the programmable controller CPU is reset.
  - A stop error occurred and the programmable controller CPU is stopped.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## 21.11 Built-in I/O Module Tools



This section explains how to monitor the operating status of the positioning function, high-speed counter function, and I/O signals using the built-in I/O module tools.

For the monitoring items and setting values, refer to MELSEC-L CPU Module User's Manual (Built-in I/O Function).


### 21.11.1 Positioning monitor

Monitor the operating status of the positioning function.

The methods for executing the error reset and OPR OFF are also explained.

#### Screen display



Select [Tool] ⇒ [Built-In I/O Module Tool] ⇒ [Positioning Monitor].



#### Display contents

Item	Description
Monitor	Display the current status.
Test	–
Error Reset	Click <input type="button" value="▼"/> to select an axis to execute the error reset.
OPR OFF	Click <input type="button" value="▼"/> to select an axis to execute the OPR OFF.

#### Screen button


-  Executes the error reset of the selected axis.
-  Executes the OPR OFF of the selected axis.

## 21.11.2 High-speed counter monitor

Monitor the operating status of the high-speed counter function.  
The methods for executing the current value preset and error reset are also explained.

### Screen display

Select [Tool] ⇒ [Built-In I/O Module Tool] ⇒ [High-Speed Counter Monitor].



### Display contents

Item	Description
Monitor	Display the current status.
Test	—
Current Value Preset	Click <input type="button" value="▼"/> to select a channel. After selecting the channel, enter the preset value.
Error Reset	Click <input type="button" value="▼"/> to select a channel to execute the error reset.

### Screen button

- Applies the preset value of the selected channel to the programmable controller CPU.
- Executes the error reset of the selected channel.

17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX

I


INDEX

### 21.11.3 I/O monitor

Monitor the I/O signals.

#### Screen display

Select [Tool] ⇒ [Built-In I/O Module Tool] ⇒ [I/O Monitor].



#### Display contents

Item	Description
Input Signal	Display the status of each input signal.
Output Signal	Display the status of each output signal.

---

# 22 SIMULATING OPERATIONS OF EXTERNAL DEVICES

This chapter explains debugging operations using the I/O system setting function.

22.1	I/O System Setting Function	22 - 2
22.2	Operating Procedure of I/O System Setting Function	22 - 7
22.3	Screen Configuration of I/O System Setting Function	22 - 8
22.4	Setting by Inputting Device Values	22 - 10
22.5	Setting Using Timing Charts	22 - 15
22.6	Performing I/O System Setting Function	22 - 27
22.7	Monitoring I/O System Setting	22 - 28
22.8	Operating I/O System Setting Files	22 - 30

## 22.1 I/O System Setting Function



The I/O system setting function simulates operations of external devices.

Using the I/O system setting function, operations of external devices can be simulated without a special debugging sequence program. Since input devices (X) can also be turned ON/OFF, devices in programs do not need to be rewritten during the simulation.

### 22.1.1 Differences between conventional debugging and debugging with I/O system setting function

---

This section explains differences between conventional debugging and debugging with the I/O system setting function.

#### ■ Conventional debugging

---

##### 1) Devices need to be rewritten

As input devices (X) can be turned ON/OFF only with an external device connected to the I/O module, the program needs to be modified by changing X0 → M0, X1 → M1, etc. to conduct debugging without an external device.

##### 2) A sequence program for debugging is required

A debugging sequence program needs to be added to simulate operations of external devices.

#### ■ Debugging with the I/O system setting function

---


##### 1) Devices do not need to be rewritten

It is not necessary to rewrite devices (X0 → M0) as input devices (X) can be turned ON/OFF with the I/O system setting function.

##### 2) A sequence program for debugging is not required

For sequence actions for debugging can be set/changed easily from the setting screen, a sequence program for debugging is not required.

Example: Simulating operations of program when Y0 is turned ON, and 5 seconds later X1 is turned ON to stop running



17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

## 22.1.2 Conditions and sequence actions for simulation


The I/O system setting function simulates operations of external devices according to specified conditions and sequence actions for debugging.

In "Condition", set a condition for starting up a sequence action for debugging. For settings of conditions, refer to Table 22.1.2-1.

In "Sequence Action", set devices of which values are to be changed or a timing chart which is to be started up at timing when the condition is true, using either of two kinds of setting methods: device value input and timing chart input. For details, refer to Section 22.1.3.

Sequence actions for debugging can be switched easily by selecting/clearing "Enable" on the I/O system setting screen.

Example) Settings on the I/O system setting screen using the device value input



By selecting/clearing "Enable", sequence actions for debugging can be switched easily.



● Combinations of conditions and examples of settings on the I/O system setting screen

Table 22.1.2-1 Combination of conditions and setting examples

	Combination of conditions	Condition setting on the I/O system setting screen
1		
2		
3		
4		
5		
6		
7		

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

### 22.1.3 Timing chart input and device value input

There are two methods to set sequence actions in the I/O system setting function: one is the device value input to change value of a desired device after a specified amount of time has elapsed when a condition has been satisfied; the other is the time chart input to execute a timing chart when a condition has been satisfied.

● **Device value input**

A value of a specified device can be changed after the specified condition is satisfied and the time specified for the timer is elapsed.

This enables actions such as the following.

Example: "When Y0 is turned ON, 5 seconds later X0 and X3 are turned ON"

↑ Condition                      ↑ Timer                      ↑ Sequence action

<Setting of device value input>

No.	Condition	Timer ms	Sequence Action	Setting
1	Y0=ON	500 x10	X0,X3	ON OFF <input checked="" type="checkbox"/> Enable

**Point**

● **Sequence action after timer activation**

After the timer is activated, the timer will not be suspended even when the condition changes to unsatisfied status, and the sequence action is performed to change the value of the specified device.

● **Timing chart input**

When a specified condition has been satisfied, device variation defined in timing chart format can be performed.

This enables complicated actions such as the following.


Example: "When Y0 is turned ON, D0 is counted up, Y0 is turned OFF when X0 is turned ON"

↑ ① Condition                      ②                      ↑                      ④                      ③

Timing chart format

<Setting of timing chart input>


No.	Condition	Timing Chart Format	Setting
1	Y0=ON	Edit Timing Chart Format	<input type="checkbox"/> Enable



## 22.2 Operating Procedure of I/O System Setting Function



The following shows the operating procedure of the I/O system setting function.



- \*1: Section 18.2
- \*2: Section 22.3
- \*3: Section 22.4
- \*4: Section 22.5
- \*5: Section 22.8.3
- \*6: Section 22.6
- \*7: Section 22.7

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX


## 22.3 Screen Configuration of I/O System Setting Function





This section explains the screen configuration of the I/O system setting function.

### Screen display

Select the GX Simulator2 screen ⇒ [Tool] ⇒ [I/O System Setting].



### Display contents


Item	Description	Reference
Menu bar	Display menu options for executing each function.	Section 1.3.14
Toolbar	Display tool buttons for executing each function.	Appendix 1.8
File under Editing	Display the name of a file being edited.	—
File under Execution	Display the name of a file being executed.	—
I/O system setting tree	Select a setting method for the I/O system setting. <ul style="list-style-type: none"> <li>● <b>Timing Chart Input</b> To set the I/O system setting in timing chart format, double-click the number to be set.</li> <li>● <b>Device Value Input</b> To set the I/O system setting by setting device values, double-click the number to be set.*1</li> </ul>	Section 22.4 Section 22.5
Edit/monitor screen	Edit/monitor the I/O system setting. <ul style="list-style-type: none"> <li>● <b>At timing chart input</b>   </li> <li>● <b>At device value input</b>   </li> </ul>	Section 22.4 Section 22.5
Status bar	Display information about a project being edited.	—

\*1 : For FXCPU, the setting range is No. 1 to No. 100.

**Point** 

● **Target Simulator Setting screen (QCPU (Q mode)/LCPU)**

If simulation has been started from multiple projects at startup of the I/O system setting function, the Target Simulator Setting screen is displayed to specify a simulator (virtual programmable controller) on which the I/O system setting is performed.



**Restrictions** 

● **Startup of the I/O system setting**

The I/O system setting of GX Simulator Version 7 and the I/O system setting of GX Works2 cannot be started up simultaneously.  
Startup the I/O system setting of GX Works2 after disabling the I/O system setting of GX Simulator Version 7.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX


## 22.4 Setting by Inputting Device Values






This section explains how to configure the I/O system setting by inputting device values.

### Operating procedure

1. Double-click a desired setting number from "Device Value Input" in the I/O system setting tree.



2. Set the items on the screen.

Item	Description
No.	Setting number in the <u>I/O System Setting</u> screen.
Condition	<p>Specify the input condition from the virtual programmable controller.</p> <p>The <u>Device Specification</u> screen is displayed by clicking .</p> <p>( Section 22.4.1)</p> <p>Bit devices and word devices can be specified for the input condition. Labels cannot be specified.</p> <p>For a bit device, ON/OFF can be set in a designated condition; for a word device, comparison (=, &lt;, &gt;, &lt;=, &gt;=) with a constant or another word device can be set in a designated condition.</p> <p>In addition, a relational condition can be set by specifying AND/OR operation.</p> <div style="text-align: center;">  </div> <p>With an And operation, the condition is satisfied if both designated conditions on the left and right are achieved. Otherwise, the condition is not satisfied.</p> <p>With an OR operation, the condition is satisfied if either or both of designated conditions in upper and lower columns are achieved.</p>
Timer ms	<p>Set a period of time from when the specified condition is satisfied until the sequence action is issued.</p> <p>The setting range is 1 to 1000 (10 to 10000ms).</p>
Sequence Action	<p>Set a bit device to be turned ON/OFF or a word device of which the value is to be changed after the specified condition is satisfied. Labels cannot be set.</p>
Setting	<p>Set whether each setting is to be enabled/disabled. Select this to enable the setting.</p>

## 22.4.1 Setting conditions

Conditions can be entered directly, or set on the Device Specification screen.

For devices that can be entered for conditions, refer to Appendix 2.2.

Note that there are devices which are not supported by the I/O system setting. For unsupported devices, refer to Restrictions in this section.

### ● Data entry method (direct data entry)

#### Operation


- Enter conditional expressions directly.

Example) For bit devices: X0=ON, M10=OFF


For word devices: D0=20, D5<20, D15<>5, D25>=10, D0=D50

### ● Data entry method (set on the Device Specification screen)

<When a bit device is selected>



<When a word device is selected>



#### Operation

- Set the items on the screen.

Item	Description
Compare Source	—
<<Device>>	—
Device	Set a device.
<<Buffer Memory>> <sup>*1</sup>	—
Module Start (HEX)	Enter a start I/O number of the intelligent function module in hexadecimal.
Address	Enter a buffer memory address in decimal/hexadecimal.
Decimal/Hexadecimal	Select an input form (decimal/hexadecimal) of the buffer memory address.
Condition	Select a comparison condition when the compare source is other than a bit device.
Compare Destination	—
<<Value>>	—
Select ON/OFF	Specify ON/OFF when the compare source is a bit device.
Value	Enter a value when the compare source is a word device.
<<Device>>	—
Device	Set a device.
<<Buffer Memory>> <sup>*1</sup>	—
Module Start (HEX)	Enter a start I/O number of the intelligent function module in hexadecimal.
Address	Enter a buffer memory address in decimal/hexadecimal.
Decimal/Hexadecimal	Select an input form (decimal/hexadecimal) of the buffer memory address.

\*1 : For FXCPU, these items are supported by FX3U and FX3UC only.

### **Restrictions!**

#### ● **Unsupported devices**

The following special relays are not supported by the I/O system setting.  
Use other supported devices to set conditions.

- SM402 (After RUN, ON for only 1 scan)
  - SM403 (After RUN, OFF for only 1 scan)
  - SM404 (Low speed execution type program After RUN, ON for 1 scan only)
  - SM405 (Low speed execution type program After RUN, OFF for 1 scan only)
  - SM1038 (After RUN, ON for only 1 scan)
  - SM1039 (After RUN, OFF for only 1 scan)
-



## 22.4.2 Setting sequence actions

Sequence actions can be entered directly, or set on the Bit Device Setting screen or the Word Device Setting screen.

For devices that can be entered for conditions, refer to the following section.

(☞ Appendix 2.2)

### ● Data entry method (direct data entry)


#### Operation

- Enter devices directly.

Example) For bit devices: X2-4, M5, M7

For word devices: D12=234, D20=10

### ● Data entry method (set on the Bit Device Setting screen)



#### Operation

- Set the items on the screen.

Item	Description
Bit Device List	Display the list of bit devices being set.
Bit Device Setting	—
Device (from)	Set a bit device.
Device No. (to)	Set an end bit device number for the range specification.

17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES


A

APPENDIX

I

INDEX

● **Data entry method (set on the Word Device Setting screen)**



**Operation**

- **Set the items on the screen.**

Item	Description
Word Device List	Display the list of word devices being set.
<<Device>>	—
Device	Set a word device.
Setting Value/Device	Set a device value or device.
<<Buffer memory>>*1	—
Module Start (HEX)	Enter a start number of the module in hexadecimal.
Address	Enter a buffer memory address in decimal/hexadecimal.
Decimal/Hexadecimal	Select an input form (decimal/hexadecimal) of the buffer memory address.

\*1: For FXCPU, these items are supported by FX3U and FX3UC only.

■ **Data entry method for direct data entry**

Enter a device of which a value is to be changed when the specified condition is satisfied.

For setting multiple devices, separate each device with ",".

For setting consecutive devices, connect the start device number and end device number with "-".

Example) X0, X2, M10-20  
D0=100, W0=100

**Point**

● **Number of device points that can be executed simultaneously**

Up to 25000 device points can be executed simultaneously in the device input of the I/O system setting.

● **Setting conditions and sequence operation**

- Index settings (Example: D0Z0), bit-specified word device (Example: D0.0), and digit-specified bit device (Example: K4X0) cannot be set in the conditions and sequence operation.
- The I/O system setting does not support local devices. When local devices are set, the I/O system setting may not perform properly.

● **Cutting/copying/pasting I/O system setting by unit of setting number**

The I/O system setting can be cut/copied/pasted by unit of setting number.

To cut/copy/paste the I/O system setting, click a setting number of the I/O system setting and select [Edit] ⇒ [Cut]/[Copy]/[Paste].


## 22.5 Setting Using Timing Charts




This section explains how to set the I/O system setting using timing charts.

### Operating procedure

1. Double-click a desired setting number from "Timing Chart Input" in the I/O system setting tree.



2. Set the items on the screen.

Item	Description
No.	Setting number in the <u>I/O System Setting</u> screen.
Condition	Specify the input condition from the simulation. (☞ Section 22.4.1)
Timing Chart Format	The <u>Edit Timing Chart Format</u> screen is displayed by clicking the  button.
Keep	Select this to execute the timing specified in the timing chart repeatedly.
Setting	Set whether each setting is to be enabled/disabled. Select this to enable the setting.

### Point


#### ● Cutting/copying/pasting I/O system setting by unit of setting number

The I/O system setting can be cut/copied/pasted by unit of setting number.

To cut/copy/paste the I/O system setting, click a setting number of the I/O system setting and select [Edit] ⇒ [Cut]/[Copy]/[Paste].

## 22.5.1 Setting in timing chart format

The following shows the setting procedure on the Edit Timing Chart Format screen.



\*1 : Section 22.5.6

\*2 : Section 22.5.3

\*3 : Section 22.5.4


\*4 : Section 22.5.5

## 22.5.2 Screen configuration of Edit Timing Chart Format screen




The following explains the screen configuration of the Edit Timing Chart Format screen.

### Screen display

Select the Timing Chart Input screen ⇒ .



### Display contents

Item	Description	Reference
Menu bar	Display menu options for executing each function.	-
Toolbar	Display tool buttons for executing each function.	-
Device name/device value	<p>Display devices specified in the <u>Enter Device</u> screen.</p> <ul style="list-style-type: none"> <li>● <b>Bit device</b> The device name is displayed in yellow when the device is ON at the timing of the cursor position.</li> <li>● <b>Word device</b> The device value at timing of the cursor position is displayed in a text box on the right of the device name. When a word device is specified as 32-bit integer, (D) is added at the end of the device name, and when a word device is specified as single precision real number, (E) is added at the end of the device name. Example) D0(D), W6(D), D10(E), W60(E)</li> </ul>	-
Number of scans	<p>Display the number of scans at the timing.</p> <p>To repeat a scan for the specified number of times, set the number of scans. (☞ Section 22.5.5)</p> <p>When "Keep" below the  button is selected, enabled scans can be repeated while the condition is satisfied. (Example: Keep scanning for 6 scans, which is the specified number of scans)</p> 	-
Status	<p>Display status of the timing chart being set.</p>  <ul style="list-style-type: none"> <li>*1: The target device is turned OFF → ON.</li> <li>*2: The target device is turned ON → OFF.</li> <li>*3: There is no change in the device value.</li> <li>*4: There is a change in the device value.</li> </ul>	-

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX


I  
INDEX

## 22.5.3 Registering devices

Register devices for setting timing.

### Operating procedure

1. Select [Device] ⇒ [Enter Device] from the Edit Timing Chart Format screen.



2. Set the items on the screen.

Item	Description
<<Device>>	Select this tab to register devices.
Device	Set a device to be registered.
Initial Value	Set the initial value of the device. For a bit device, select ON/OFF of the bit. For a word device, set the initial value.
<<Buffer Memory>>*1	Select this tab to register buffer memory.
Module Start (HEX)	Set a start address of a module to be registered.
Address	Set the address of the buffer memory to be registered.
Decimal/Hexadecimal	Select the input form of the buffer memory address.
Initial Value	Set the initial value of the buffer memory to be registered.
Display Format	—
Value	Select the display format of the value.
View	Select the display format of the device.

\*1 : For FXCPU, this item is supported by FX3U and FX3UC only.

### Point


#### ● Deleting registered devices

To delete a registered device, select the device displayed in device name/device value on the Edit Timing Chart Format screen, and select [Device] ⇒ [Delete Device].

## 22.5.4 Setting timing

Set/edit the timing.

Move the cursor to the timing to be set, and perform an operation using any of tool buttons, menus, and shortcut keys.



Operation	Toolbar	Menu	Shortcut key
Device ON		<ul style="list-style-type: none"> <li>Select [Edit] ⇒ [Bit Device] ⇒ [Device ON].</li> <li>Right-click and select [Device ON] from the shortcut menu.</li> <li>Double-click at the cursor position</li> </ul>	
Device OFF		<ul style="list-style-type: none"> <li>Select [Edit] ⇒ [Bit Device] ⇒ [Device OFF].</li> <li>Right-click and select [Device OFF] from the shortcut menu.</li> <li>Double-click at the cursor position.</li> </ul>	
Progressive OFF		<ul style="list-style-type: none"> <li>Select [Edit] ⇒ [Bit Device] ⇒ [Progressive OFF].</li> <li>Right-click and select [Progressive OFF] from the shortcut menu.</li> </ul>	
Progressive ON		<ul style="list-style-type: none"> <li>Select [Edit] ⇒ [Bit Device] ⇒ [Progressive ON].</li> <li>Right-click and select [Progressive ON] from the shortcut menu.</li> </ul>	
All OFF		<ul style="list-style-type: none"> <li>Select [Edit] ⇒ [Bit Device] ⇒ [All OFF].</li> <li>Right-click and select [All OFF] from the shortcut menu.</li> </ul>	
All ON		<ul style="list-style-type: none"> <li>Select [Edit] ⇒ [Bit Device] ⇒ [All ON].</li> <li>Right-click and select [All ON] from the shortcut menu.</li> </ul>	
Change		<ul style="list-style-type: none"> <li>Select [Edit] ⇒ [Word Device] ⇒ [Change].</li> <li>Right-click and select [Change] from the shortcut menu.</li> <li>Double-click the cursor position.</li> </ul>	
No Change		<ul style="list-style-type: none"> <li>Select [Edit] ⇒ [Word Device] ⇒ [No Change].</li> <li>Right-click and select [No Change] from the shortcut menu.</li> </ul>	
Insert		<ul style="list-style-type: none"> <li>Select [Edit] ⇒ [Insert].</li> <li>Right-click and select [Insert] from the shortcut menu.</li> </ul>	
Delete		<ul style="list-style-type: none"> <li>Select [Edit] ⇒ [Delete].</li> <li>Right-click and select [Delete] from the shortcut menu.</li> </ul>	

17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## ■ Setting timing of bit devices

### ● Setting the ON/OFF cycle


Set continuous ON/OFF repeated for the specified period after the specified timing.

Example) Set the following value to scan 1 (cursor position).


Cycle: 2

### Operation

1. Select a cell corresponding to a scan of a bit device to be changed.




2. Select [Edit] ⇒ [Timing Setting].



3. Set an ON/OFF cycle of the bit device.

4. Click the  button.

ON/OFF of the bit device is cyclically set.






■ **Setting timing of word devices**

● **Changing the value at the specified timing**

Change the value of the specified device at the specified timing.


Example) Set the following value to scan 3 (cursor position).

Setting Value: 10, Continue, Number of Scans: 4, Increase and Decrease: Increase, Increase and Decrease Value: 20




**Operation**

1. Select a cell corresponding to a word device to be changed.



2. Select [Edit] ⇒ [Word Device] ⇒ [Change] (F7).




3. Set the items on the screen.

Item	Description
Value Setting	Select this to set a value.
Setting Value	Enter a setting value for the word device.
Continue	Select this to set the setting value continuously.
Number of Scans	Enter the number of scans to be continued.
Increase and Decrease	Set this to increase/decrease the value.
Increase and Decrease Value	Set the increase/decrease value.
Trigonometric Function	Select this to change the value using trigonometric functions.
SIN curve	Select this to change the value with a SIN curve.
COS curve	Select this to change the value with a COS curve.
Maximum Value	Enter the maximum value.
Cycle Scan	Select the number of scans corresponding to one period of SIN/COS curves.

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

4. Click the  button.  
The value of the word device is set.




## 22.5.5 Setting number of scans of timing chart

Set the number of scans of a timing chart input from an external device.

### Screen display

Select the Edit Timing Chart Format screen ⇒ [Scan] ⇒ [Scan Setting].



### Operating procedure


1. Enter the value for "No. of Scans".
2. Click the  button.  
Columns of disabled scans are shaded on the timing chart.

## 22.5.6 Utilizing timing chart data of existing applications

Read and utilize a timing chart data file (\*.DAT) saved with the timing chart of GX Simulator. Since devices and timing are automatically registered after reading, there is no need to register them again.

### Screen display

Select the **Edit Timing Chart Format** screen ⇒ [File] ⇒ [Open File].



### Restrictions

- Number of device points that can be read from a timing chart data file**  
 Timing chart data for 16 device points from the top in the screen can only be saved with the timing chart function. Therefore, move necessary devices to within 16 points from the top in the screen and save the data when creating a timing chart data file.
- Number of scans that can be read from a timing chart data file**  
 Scan 0 to 99 are available in the **Edit Time Chart Format** screen of the I/O system setting function. When a timing chart data file includes scan 100 and later, they are discarded.
- When a double-precision real number is used in a timing chart data file**  
 When a double-precision real number is contained in a timing chart data file created with GX Simulator, the file cannot be read.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I


INDEX

## 22.5.7 Displaying list of registered devices

Display a list of registered devices.

### Screen display


Select the Edit Timing Chart Format screen ⇒ [Device] ⇒ [Device List].





### Display contents


Item	Description
Device List	Display devices registered on the <u>Edit Timing Chart Format</u> screen.

### Screen button

- 

Displays the Enter Device screen, and adds a device to the Edit Timing Chart Format screen.
- 

Deletes the device being selected from the Edit Timing Chart Format screen.
- 

Displays the device being selected on the Edit Timing Chart Format screen.
- 


Moves the display position of a device being selected up/down on the Edit Timing Chart Format screen.

## 22.5.8 Exchanging display positions of devices


Exchange the display positions of devices by dragging and dropping a device name.

### Operating procedure

1. Drag a device name on the Edit Timing Chart Format screen.



2. Place the square frame over a device to be exchanged.


17  
MONITORING18  
SIMULATING  
PROGRAMS19  
DEBUGGING  
PROGRAMS20  
OPERATING  
PROGRAMMABLE  
CONTROLLER CPU21  
DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS22  
SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICESA  
APPENDIXI  
INDEX

## 22.5.9 Changing display format of devices

Change the display format of devices registered in the Edit Timing Chart Format screen. This function is not applicable to bit devices.

### Operating procedure

1. Select the Edit Timing Chart Format screen ⇒ [Device] ⇒ [Property].



2. Set the items on the screen.

Item	Description
Display Format	–
Value	Select the display format of values.
View	Select the display format of devices.

3. Click the  button.

## 22.6 Performing I/O System Setting Function




This section explains the operations of simulation using the I/O system setting function.

### 22.6.1 Executing simulation


Execute simulation with settings configured using the I/O system setting function.

#### Operating procedure

1. Select the I/O System Setting screen ⇒ [File] ⇒ [Open] (📂), and open an I/O system setting file (\*.IOS).



2. Select the I/O System Setting screen ⇒ [File] ⇒ [Execute I/O System Setting] (I/O). The confirmation message is displayed.



3. Click the  button.

#### Point

- **I/O system setting files**  
When the I/O system setting function is executed after an I/O system setting file is changed, the changes are automatically overwritten to the file.
- **Simulation with the I/O system setting**  
Make sure that the simulator (virtual programmable controller) specified as execution target is in the RUN status at "LED" on the GX Simulator2 screen.  
When it is in the STOP status, sequence actions and timing charts are not performed even though conditions of the device value input or timing chart input are satisfied.

### 22.6.2 Disabling simulation

Stop simulation of the I/O system setting being executed by disabling the I/O system setting.

#### Operating procedure

- Select the I/O System Setting screen ⇒ [File] ⇒ [Disable I/O System Setting] (I/O).

## 22.7 Monitoring I/O System Setting



This section explains how to monitor devices on the I/O System Setting screen. Using this function, status of registered conditions can be confirmed, and values of devices registered in conditions can be changed.

### 22.7.1 Starting/stopping monitoring


Start/stop monitoring on the I/O System Setting screen.

#### ■ Start monitoring

Start monitoring on the I/O System Setting screen.

#### Operating procedure

- Select [Online] ⇒ [Start Monitoring] (🔍) on the I/O System Setting screen. Monitoring starts.



#### ■ Stop monitoring

Stop monitoring on the I/O System Setting screen.

#### Operating procedure

- Select [Online] ⇒ [Stop Monitoring] (🔍) on the I/O System Setting screen.



## ■ Screen display during monitoring

When monitoring starts, the I/O System Setting screen is displayed as shown below. Conditions that are satisfied are displayed in yellow.

No.	Condition	Timer ms	Sequence Action	Setting
1	SM400=ON	1 x10	X0 ON	Enable
2	M0=ON	1 x10	X15X17 ON	Enable

### Screen button

- Timing Chart Preview

Displays the Edit Timing Chart Format screen to confirm the monitoring status.

## 22.7.2 Changing current value of devices

Change current device value during monitoring.

No.	Condition	Timing Chart Format	Setting
1	Y0=ON D0<15	Timing Chart Preview	
2	X2=OFF	Timing Chart Preview	

### Operating procedure

- Set the items on the screen.

Item	Description
For a bit device	Click a bit device to invert its status.
For a word device	Click a word device to display the <u>Change Device Value</u> screen below and change its value.

**Change Device Value**

Device: D0

Current Value: 15

New Value: 12

Specify a new device value.

Apply Close

### Screen button

For the button on the screen, refer to Section 22.7.1.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## 22.8 Operating I/O System Setting Files



This section explains how to operate an I/O system setting file (\*.IOS).

### 22.8.1 Creating I/O system setting files

Create a new I/O system setting file.


#### Operating procedure

- Select [File] ⇒ [New] (📄).

### 22.8.2 Opening existing I/O system setting files

Open a saved I/O system setting file.

#### Operating procedure

1. Select [File] ⇒ [Open] (📁).
2. Select a file to be opened and click the  button.

#### Point

##### ● Supported existing applications

I/O system setting files created with GX Simulator Version 6 or later can also be opened.

#### Restrictions

##### ● 'Push Button'/'Always ON' set with existing GX Simulator

When an I/O system setting file in which a 'Push Button'/'Always ON' is set with GX simulator is read with GX Works2, a 'Push Button' is converted to a '(blank)' and a 'Always ON' is converted to a 'SM400=ON' by QCPU (Q mode). A 'Push Button' is converted to a '(blank)' and an 'Always ON' is converted to an 'M8000=ON' by FXCPU.

### 22.8.3 Saving I/O system setting files

Save an I/O system setting file being open under a specified name.

#### Operating procedure

1. Select [File] ⇒ [Save As].
2. Enter a name of the file to be saved and click the  button.

---

# APPENDIX

Appendix 1	List of Toolbars and Shortcut Keys	App - 2
Appendix 2	Simulation Function	App - 22
Appendix 3	ASCII Code Table	App - 61
Appendix 4	Considerations of GX Works2 and Differences with GX Developer	App - 62
Appendix 5	Compatibility with Projects Created with Existing Applications	App - 78
Appendix 6	Compatibility of Data Read from Programmable Controller CPU	App - 81
Appendix 7	Compatibility with Existing Applications	App - 90
Appendix 8	Considerations When Saving Projects in GX Developer Format	App - 107
Appendix 9	Character Strings that cannot be Used for Label Names and Data Names	App - 110
Appendix 10	Restrictions When Changing Programmable Controller Type	App - 113
Appendix 11	Instruction Conversion Lists	App - 162
Appendix 12	Functions Added Since Previous Versions	App - 166
Appendix 13	Supported Versions of Modules	App - 193
Appendix 14	Procedure to Use GX Works2 Unsupported Programmable Controller Type	App - 196
Appendix 15	Considerations of installation and uninstallation	App - 200
Appendix 16	USB Driver Installation	App - 203
Appendix 17	Considerations When Using English Version of GX Works2	App - 204
Appendix 18	Considerations for Selecting Project Language	App - 210
Appendix 19	Modifying Instructions of Projects in Other Formats	App - 213
Appendix 20	Considerations When Using Projects Created in PX Developer	App - 225
Appendix 21	Troubleshooting	App - 227

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## Appendix 1 List of Toolbars and Shortcut Keys

Q CPU L CPU Remote Head FX

This section shows the list of toolbars and shortcut keys that can be used for GX Works2.

For (Simple), (FB), (Structured), and (Intelligent) indicated in the Reference column, refer to the following manuals respectively:











(Simple) ... GX Works2 Version 1 Operating Manual (Simple Project)  
 (FB) ... GX Works2 Version 1 Operating Manual (Simple Project, Function Block)  
 (Structured) ... GX Works2 Version 1 Operating Manual (Structured Project)  
 (Intelligent) ... GX Works2 Version 1 Operating Manual (Intelligent Function Module)

### Appendix 1.1 Common toolbars and shortcut keys

The following explains the toolbars that are available regardless of the editing target and the corresponding shortcut keys.





















#### ■ "Standard" toolbar icons

The following table shows the "Standard" toolbar icons and the corresponding shortcut keys.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
		New	Create a new project.	Section 4.2.1
		Open	Open an existing project.	Section 4.2.2
		Save	Save the project.	Section 4.2.3
		Print	Print data such as sequence programs and devices.	Chapter 11
		GX Works2 Help	Display the <u>GX Works2 Help</u> screen.	Section 3.4.1
-	-	Find Help for GX Works2	Search for help items with an entered keyword on the <u>GX Works2 Help</u> screen.	

## ■ "Program Common" toolbar icons

The following table shows the "Program Common" toolbar icons and the corresponding shortcut keys.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
	Ctrl + X	Cut	Cut the selected data.	–
	Ctrl + C	Copy	Copy the selected data.	–
	Ctrl + V	Paste	Paste the cut/copied data at the cursor position.	–
	Ctrl + Z	Undo	Cancel the previous operation.	–
	Ctrl + Y	Redo	Perform the operation canceled by [Undo].	–
	Ctrl + F	Find Device	Search for a device.	Section 10.3.1
	–	Find Instruction	Search for an instruction.	Section 10.3.2
	Ctrl + Alt + F7	Find Contact or Coil	Search for a contact or coil corresponding to a specified device.	
	–	Write to PLC	Write data to the programmable controller CPU.	Section 15.1
	–	Read from PLC	Read data from the programmable controller CPU.	
	–	Start Monitoring (All Windows)	Start monitoring all windows being opened.	Section 17.2
	–	Stop Monitoring (All Windows)	Stop monitoring all windows being opened.	
	F3	Start Monitoring	Start monitoring the window being operated.	
	Alt + F3	Stop Monitoring	Stop monitoring the window being operated.	
	–	Device/Buffer Memory Batch Monitor	Batch monitor device/buffer memories.	Section 17.3
	Shift + Enter	Modify Value	For ladder and SFC (Zoom) programs, change the ON/OFF and value of a device/label used in a program.	Section 19.1
	F4	Build	Compile/convert a program being edited.	Section 5.4
	Shift + F4	Online Program Change	Compile/convert a program and write it to the programmable controller CPU.	
	Shift + Alt + F4	Rebuild All	Compile/convert all programs in a project.	
	–	Start/Stop Simulation	Start/stop simulation.	Section 18.2

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS












22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX








## ■ "Docking Window/Switch Project Data" toolbar icons

The following table shows the "Docking Window/Switch Project Data" toolbar icons.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
	–	Navigation	Display/hide the Navigation window.	Section 3.2.5
	–	Element Selection	Display/hide the Element Selection window.	(FB) (Structured)
	–	Output	Display/hide the Output window.	(Simple) (Structured)
	–	Cross Reference	Display/hide the Cross Reference window.	Section 10.1
	–	Device List	Display/hide the Device List window.	Section 10.2
	–	Device Reference	Display/hide the Device Reference window.	Section 6.3.4
	–	Watch	Display/hide the Watch window.	Section 17.6
	–	Intelligent Function Module Monitor	Display/hide the Intelligent Function Module Monitor window.	(Intelligent)
	–	Intelligent Function Module Guidance	Display/hide the Intelligent Function Module Guidance window.	
	–	Find/Replace	Display/hide the Find/Replace window.	Section 10.3
–	–	Select data type	Select a data type and data name to be displayed.	Section 3.2.2
–	–	Select data name		
	–	Display	Display the editing screen of the selected data type and data name.	

## ■ "Intelligent Function Module" toolbar icons

The following table shows the "Intelligent Function Module" toolbar icons.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
	–	QD75/LD75 Positioning Module Wave Trace	Execute a wave trace of the QD75/LD75 positioning module.	(Intelligent)
	–	QD75/LD75 Positioning Module Location Trace	Execute a location trace of the QD75/LD75 positioning module.	
	–	Serial Communication Module Circuit Trace	Execute a circuit trace of the serial communication module.	
	–	QD75/LD75 Positioning Module Test Monitor	Execute a positioning monitor of the QD75/LD75 positioning module.	
	–	QD75/LD75 Positioning Module Test	Execute a positioning test of the QD75/LD75 positioning module.	
	–	Offset/Gain Setting of Temperature Input Module	Execute offset/gain setting of the temperature input module.	
	–	Offset/Gain Setting of Analog Module	Execute offset/gain setting of the analog module.	

## ■ "Debug Function" toolbar icons

The following table shows the "Debug Function" toolbar icons.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
	–	Stop	Stop the step execution.	Section 19.6.9
	–	Cancel	Cancel the step execution.	Section 19.6.7
	–	Break Execution	Execute the break execution.	Section 19.6.6
	–	Step Execution	Execute the step execution.	Section 19.6.5
	–	Execution Option	Display the <u>Execution Option</u> screen of the step execution.	Section 19.6.8
	–	Set/Cancel Break Point	Set a break point at the cursor position, or cancel the set break point.	Section 19.6.2
	–	Enable/Disable Break Point	Enable/disable the break point at the cursor position.	
	–	Cancel All Break Points	Cancel all break points.	
	–	Break Point	Display the Break Point window.	
	–	Cancel All Break Devices	Cancel all break devices.	Section 19.6.3
	–	Break Device	Display the Break Device window.	
	–	Set/Cancel Skip Range	Set a skip range, or cancel the set skip range.	Section 19.6.4
	–	Enable/Disable Skip Range	Enable/disable the skip range at the cursor position.	
	–	Cancel All Skip Ranges	Cancel all skip ranges.	
	–	Skip Range	Display the Skip Range window.	

## ■ Other shortcut keys

The following table shows other shortcut keys that are available regardless of the editing target.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
–		Rename Rename (Library)	Change the name of the selected data or library on the Navigation window.	Section 4.3.3 (Structured)
–		Delete	Delete the selected data.	Section 4.3.4
–		Copy	Copy data in the project.	Section 4.3.2
–		Paste	Paste the copied data to a folder.	
–		Add New Module	Add the intelligent function module data to the project being edited.	(Intelligent)
–		Exit	Close the project being edited and exits GX Works2.	Section 3.1
–		Cross Reference	Create the cross reference information.	Section 10.1
–		Device List	Display the device list.	Section 10.2
–		–	After creating cross reference information, move to the next cross reference information.	Section 10.1
–		–	After creating cross reference information, move to the previous cross reference information.	
–		–	After creating cross reference information, move focus between the Cross Reference window and work windows.	
–		Find Device	Search for a device/label in the program.	Section 10.3.1
–		Find String	Search for a string.	Section 10.3.3

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS










20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES







A  
APPENDIX

I  
INDEX

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
–		Replace Device	Replace a device/label in the program.	Section 10.3.1
–		Replace String	Replace a string.	Section 10.3.3
–		–	After performing the search/replace function once, search for an item in the downward direction.	Section 10.3
–		–	After performing the search/replace function once, search for an item in the upward direction.	
–		Start Watching	Start monitoring the current values of registered devices/labels and intelligent function module.	Section 17.6
–		Stop Watching	Stop monitoring the current values of registered devices/labels and intelligent function module.	
–		Register Device Test with Execution Condition	Register the device test with execution condition.	Section 19.3
–		–	Close the window displayed on the uppermost position.	–
–		–	Move to the next uppermost window.	–

## Appendix 1.2 "Navigation Window" toolbar icons

The following table shows the "Navigation Window" toolbar icons.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
	–	Add New Data	Add data to the project.	Section 4.3.1
	–	Copy	Copy selected data.	Section 4.3.2
	–	Paste	Paste copied data.	
	–	Property	Display a property of the selected data.	Section 4.3.6
	–	Refresh	Update the display content of the Navigation window.	–
	–	Project Property	Display a property of the open project.	–
		Expand All Uncompiled Data	Expand all uncompiled data in the tree on the Project view and the User Library view.	Section 3.2.5
		Collapse All	Collapse all data in the tree on the Project view and the User Library view.	
















## Appendix 1.3 Toolbar icons and shortcut keys for setting labels

The following explains the toolbar icons and the corresponding shortcut keys for setting labels.











### ■ "Label" toolbar icons

The following table shows the "Label" toolbar icons and the corresponding shortcut keys.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
	 + 	New Declaration (Before)	Add a row above the cursor position.	(Simple) (Structured)
	–	New Declaration (After)	Add a row below the cursor position.	
	 + 	Delete Row	Delete the row at the cursor position.	
	–	Read from CSV File	Read label settings from the CSV file.	
	–	Write to CSV File	Write label settings to the CSV file.	
	–	Check the changes of the System Label Database	Apply system label information changed in another project to global labels.	
	–	Import System Label	Import system label information and apply it to global labels.	
	–	Reservation to Register System Label	Reserve the selected global label for registration as a system label.	
	–	Reservation to Release System Label	Reserve the selected global label for deregistration of system label.	

### ■ Other shortcut keys

The following table shows other shortcut keys for setting labels.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
–	 + 	Select All	Select all rows.	(Simple) (Structured)
–	 +  /  + Num  *1	–	Display all lines of comment and remark of the selected line.	
–	 +  /  + Num  *1	–	Display only the first line of comment and remark of the selected line.	

\*1 : 'Num' indicates keys in the numeric keypad.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX


















INDEX

## Appendix 1.4 Toolbar icons and shortcut keys for setting device memory

The following explains the toolbar icons and the corresponding shortcut keys for setting device memory.


### ■ "Device Memory" toolbar icons

The following table shows the "Device Memory" toolbar icons and the corresponding shortcut keys.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
	–	Display Mode/Binary	Display data in binary.	Section 7.2.5
	–	Display Mode/Octal	Display data in octal.	
	–	Display Mode/Decimal	Display data in decimal.	
	–	Display Mode/Hexadecimal	Display data in hexadecimal.	
	–	Display Mode/Float	Display data in real number.	
	–	Display Mode/String	Display data in character string.	
	–	Display Mode/String (ASCII only)	Display data in ASCII string.	
	–	Register/16-bit	Display data in units of words.	
	–	Register/32-bit	Display data in units of double words.	
	–	Register/64-bit	Display data in units of 64 bits.	
		Input Device	Enter a device.	Section 7.2.2
	–	FILL	Set the same value to consecutive devices.	Section 7.2.4
	–	Read Device Memory from PLC	Read data in device memory from a programmable controller CPU.	Section 7.4.1
	–	Write Device Memory to PLC	Write data in device memory to a programmable controller CPU.	
	–	Read from Excel File	Read data from an Excel file.	Section 7.4.2
	–	Write to Excel File	Write data to an Excel file.	












### ■ Other shortcut key

The following table shows other shortcut key for setting device memory.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
–		Insert Row	Insert a row at the cursor position.	Section 7.2

## Appendix 1.5 Toolbar icons and shortcut keys for verification result

The following table shows the toolbar icons and the corresponding shortcut keys for the verification result.













Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
		Next Unmatch	Move to the next mismatched data.	Section 4.2.7 Section 15.2
		Previous Unmatch	Move to the previous mismatched data.	
		Return to Result List	Display the <<Verify Result List>>tab.	
		Close Detail Result	Close the <<Detail Verify Result>>tab being displayed.	
		Close All Detail Result	Close all <<Detail Verify Result>>tab.	
	–	Write to CSV File	Write verification result to a CSV file.	

## Appendix 1.6 Toolbar icons and shortcut keys for executing sampling trace

The following explains the toolbar icons and the shortcut keys for executing sampling trace.

### ■ Toolbar icons for executing sampling trace

The following table shows the toolbar icons for executing sampling trace.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
	–	Trace Setting	Display the <u>Trace Setting</u> screen.	Section 19.4.2
	–	Start Trace	Start sampling trace. To start sampling trace, the trace ready signal (SM800) must be ON.	Section 19.4.4
	–	Stop Trace	Stop sampling trace.	
	–	Display Trace Buffer Condition	Display the <u>Trace Data Storage Status</u> screen.	
	–	–	Display the current sampling trace status	–
	–	Buffer Status	Displayed when the trace data have been acquired up to the specified total number of samplings.	
	–	Trigger Occurrence	Displayed when a trigger is generated during sampling trace.	Section 19.4.4
	–	Zoom Out Timing Chart	Zoom the scale of timing chart	
	–	Zoom In Timing Chart		
	–	Zoom Out Trend Graph	Zoom the scale of trend graph	
	–	Zoom In Trend Graph		
	–	Switch Chart/Detail	Switch the trace result display on the <u>Sampling Trace</u> screen between the timing chart (graph) and the detailed data (value).	

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

## Other shortcut keys

The following table shows the other shortcut keys for executing sampling trace.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
–		–	Move the vertical axis information line 10 columns to the left.	Section 19.4.4
–		–	Move the vertical axis information line 10 columns to the right.	
–		–	Move the vertical axis information line 100 columns to the left.	
–		–	Move the vertical axis information line 100 columns to the right.	
–		–	Move the vertical axis information line toward the left from the vertical axis information line to the columns of first data change.	
–		–	Move the vertical axis information line toward the right from the vertical axis information line to the columns of first data change.	























## Appendix 1.7 Toolbar icons and shortcut keys for program editors

The following explains the toolbar icons and the corresponding shortcut keys for program editors.

### "Ladder" toolbar icons and shortcut keys

The following table shows the toolbar icons and the corresponding shortcut keys for the ladder editor.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
		Open Contact	Insert an open contact at the cursor position.	(Simple)
		Open Branch	Insert an open contact branch at the cursor position.	
		Close Contact	Insert a closed contact at the cursor position.	
		Close Branch	Insert a closed contact branch at the cursor position.	
		Coil	Insert a coil at the cursor position.	
		Application Instruction	Insert an application instruction at the cursor position.	
		Horizontal Line	Insert a horizontal line at the cursor position.	
		Vertical Line	Insert a vertical line at the cursor position.	
		Delete Horizontal Line	Delete the horizontal line at the cursor position.	
		Delete Vertical Line	Delete the vertical line at the cursor position.	
		Rising Pulse	Insert a rising pulse at the cursor position.	
		Falling Pulse	Insert a falling pulse at the cursor position.	
		Rising Pulse Branch	Insert a rising pulse branch at the cursor position.	
		Falling Pulse Branch	Insert a falling pulse branch at the cursor position.	
		Rising Pulse Close	Insert a rising pulse close at the cursor position.	
		Falling Pulse Close	Insert a falling pulse close at the cursor position.	

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference	
	Shift + Alt + F7	Rising Pulse Close Branch	Insert a rising pulse close branch at the cursor position.	(Simple)	
	Shift + Alt + F8	Falling Pulse Close Branch	Insert a falling pulse close branch at the cursor position.		
	Alt + F5	Operation Result Rising Pulse	Insert an operation result rising pulse at the cursor position.		
	Ctrl + Alt + F5	Operation Result Falling Pulse	Insert an operation result falling pulse at the cursor position.		
	Ctrl + Alt + F0	Invert Operation Results	Insert an operation result inversion at the cursor position.		
	F10	Edit Line	Input a line at the cursor position.		
	Alt + F9	Delete Line	Delete the line at the cursor position.		
	Ctrl + B	Insert Inline Structured Text Box	Insert an inline structured text box.		
	-	Device Comment	Edit device comments.		Section 9.2.2
	-	Statement	Edit statements.		(Simple)
	-	Note	Edit notes.		
	-	Statement/Note Batch Edit	Batch-edit statements/notes.		
	Ctrl + L	Line Statement List	Display the list of line statements used in the program.		
	Ctrl + Alt + F1	Display Template	Insert a template corresponds to the instruction/function/control syntax.	(Structured)	
	Alt + [	Mark Template (Left)	Set an argument of the template in the selected status from the left by selecting the menu each time.		
	Alt + ]	Mark Template (Right)	Set an argument of the template in the selected status from the right by selecting the menu each time.		
	Shift + F2	Read Mode	Switch the mode of the open window to "Read Mode".	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS	
	F2	Write Mode	Switch the mode of the open window to "Write Mode".		
-	Ctrl + Shift + F2	Read Mode (All Windows)	Switch the mode of all open windows to "Read Mode".		
-	Ctrl + F2	Write Mode (All Windows)	Switch the mode of all open windows to "Write Mode".		
	F3	Monitor Mode	Switch the mode of the open window to "Monitor Mode" during monitoring.		
	Shift + F3	Monitor (Write Mode)	Switch the mode of the open window to "Monitor (Write Mode)" during monitoring.	(Simple)	
	Ctrl + Alt + F6	Device Display	Display devices assigned by compilation.		
	-	Zoom	Change the display magnification ratio of the ladder program.		
-	Ctrl + Alt + V	Continuous Paste	Increment the device number of device in the cut/copied ladder block and paste it consecutively.		
-	Shift + Insert	Insert Row	Insert a row at the cursor position.		
-	Shift + Delete	Delete Row	Delete the row at the cursor position.		
-	Ctrl + Insert	Insert Column	Insert a column at the cursor position.		
-	Ctrl + Delete	Delete Column	Delete the column at the cursor position.		
-	Ctrl + Shift + ]	Connect Line to Right-Side Symbol	Connect a horizontal line to the element at the right of the cursor position.		
-	Ctrl + Shift + [	Connect Line to Left-Side Symbol	Connect a horizontal line to the element at the left of the cursor position.		
-	Ctrl + ]	Enter/Delete HLine Rightward	Enter/delete a line at the right of the cursor position.		

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference	
-		Enter/Delete HLine Leftward	Enter/delete a line at the left of the cursor position.	(Simple)	
-		Enter/Delete VLine Downward	Enter/delete a line at the downward of the cursor position.		
-		Enter/Delete VLine Upward	Enter/delete a line at the upward of the cursor position.		
-		Switch Open/Close Contact	Switch a open contact to closed contact, and vice versa.		
-		Switch Statement/Note Type	Change the type of a statement/note.		
-		Instruction Partial Edit	Open the <u>Enter Symbol</u> screen in which the first argument is in the selected status.		
-		-	Select a device/label on the <u>Enter Symbol</u> screen. Switch the device/label to be selected using the /  button.		
-		-	Increment/decrement a device/label on the <u>Enter Symbol</u> screen.		
-		-	Display options of instruction/label on the <u>Enter Symbol</u> screen.		
-		-	Move the cursor on the editing screen while the <u>Enter Symbol</u> screen is displayed.		
-		Jump	Display the specified row.		
-		Jump to Next Ladder Block Start	Move the cursor from the current position to the start of the next ladder block.		
-		Jump to Previous Ladder Block Start	Move the cursor from the current position to the start of the previous ladder block.		
-		Next Device	Move the cursor to the same device as the one at the cursor position.		
-		Next Contact	Move the cursor to the contact where the same device as the one at the cursor position is used.		
-		Next Coil	Move the cursor to the coil where the same device as the one at the cursor position is used.		
-		Back	Return the cursor to the previous position before the [Next Device]/[Next Contact]/[Next Coil] function execution.		
-		Comment	Display device comments.		
-		Statement	Display statements.		
-		Note	Display notes.		
-		Non-Display Ladder Block	Hide a ladder block.		
-		Display Ladder Block	Display hidden a ladder block.		
-		Bigger	Change the display size of text larger on the editing screen.		
-		Smaller	Change the display size of text smaller on the editing screen.		
-		Tile FB Horizontally	Tile the ladder editor and the function block program editor horizontally.		(FB)

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
–		Back to Zoom SFC Block	Open the SFC diagram corresponds to the program on the Zoom editor window.	(Simple)
–		Moves up/down/left/right	Move the cursor toward up/down/left/right of the SFC diagram.	
–		Open Instruction Help	Display the <u>I</u> nstruction <u>H</u> elp screen.	
–		ST Monochrome Display	Switch the text color (color or monochrome) in inline structured text boxes.	
–		–	Display the <u>F</u> ind screen.	
–		–	Display the instruction help of GX Works2 or reference manual of FB library.	
–		–	Enter an assignment operator (:=) when editing the inline structured text program.	(Structured)

\*1 : 'Num' indicates keys in the numeric keypad.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS






























22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## ■ "ST" toolbar icons and shortcut keys

The following table shows the toolbar icons and the corresponding shortcut keys for the ST editor.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
		List Operands	Display the <u>Label Registration/Selection</u> screen.	(Structured)
		Display Template	Insert a template corresponds to the instruction/function/control syntax.	
		Mark Template (Left)	Set an argument of the template in the selected status from the left by selecting the menu each time.	
		Mark Template (Right)	Set an argument of the template in the selected status from the right by selecting the menu each time.	
		Toggle Bookmark	Set a bookmark at the cursor line. If a bookmark has already been set, delete the set bookmark.	
	–	Bookmark List	Jump to the specified bookmark from the bookmark list.	
		Next Bookmark	Display the next bookmark position.	
		Previous Bookmark	Display the previous bookmark position.	
		Delete All Bookmarks	Delete all bookmarks.	
		Increase Zoom	Zoom in the screen one level.	
		Decrease Zoom	Zoom out the screen one level.	
–		Jump	Jump to the specified line.	
–		Zoom Header/Body Header	Open the label setting editor of the selected POU.	
–		Copy	Copy the selected data.	
–		Cut	Cut the selected data.	
–		Paste	Paste the cut/copied data at the cursor position.	
–		–	Display the instruction help of GX Works2, reference manual of FB library, or help of user library.	
–		–	Enter an assignment operator (:=) when editing the inline structured text program.	(Structured)
–		ST Monochrome Display	Switch the text color (color or monochrome) in an ST editor.	(Structured)

\*1 : 'Num' indicates keys in the numeric keypad.



## ■ "Structured Ladder/FBD" toolbar icons and shortcut keys

The following table shows the toolbar icons and the corresponding shortcut keys for the Structured Ladder/FBD editor.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
	Ctrl + Q	Select Mode	Change the input mode for positioning contacts/coils.	(Structured)
	Ctrl + T	Interconnect Mode	Change the input mode for drawing lines.	
	Ctrl + Shift + Q	Guided Mode/Guided Editing	Change the input mode for entry with keyboard.	
	Ctrl + Shift + A	Guided Mode/Auto Comment	Add a comment entry field at the start of the ladder block added in Guided editing.	
	Ctrl + B	Auto Connect	Connect the start and end points to draw a line automatically.	
	Ctrl + W	Insert Row	Insert a row into the ladder program being edited.	
	Ctrl + U	Insert Column	Insert a column into the ladder program being edited.	
	Ctrl + Alt + B	New Ladder Block Before	Insert a new ladder block in front of the ladder block being edited.	
	Ctrl + Alt + A	New Ladder Block After	Insert a new ladder block after the ladder block being edited.	
	-	Input Instruction	Open the <u>Input Instruction</u> screen.	
	-	Left Power Rail	Display/hide the left power rail.	
	1	Open Contact	Insert an open contact at the cursor position.	
	2	Close Contact	Insert a closed contact at the cursor position.	
	3	Open Branch	Insert an open contact branch at the cursor position.	
	4	Close Branch	Insert a closed contact branch at the cursor position.	
	5	Vertical Line Segment	Insert a vertical line at the cursor position.	
	6	Horizontal Line Segment	Insert a horizontal line at the cursor position.	
	7	Coil	Insert a coil at the cursor position.	
	8	Element Selection	Display the Element Selection window.	
	9	Input Label	Insert an input variable at the cursor position.	
	0	Output Label	Insert an output variable at the cursor position.	
	-	Rising Pulse	Insert a rising pulse at the cursor position.	
	-	Falling Pulse	Insert a falling pulse at the cursor position.	
	-	Rising Pulse Close	Insert a rising pulse close at the cursor position.	
	-	Falling Pulse Close	Insert a falling pulse close at the cursor position.	
	Ctrl + J	Jump	Insert a jump at the cursor position.	

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
	<b>Ctrl</b> + <b>R</b>	Return	Insert a return at the cursor position.	(Structured)
	<b>Ctrl</b> + <b>M</b>	Comment	Insert a comment entry field.	
	<b>Ctrl</b> + <b>Shift</b> + <b>L</b>	Ladder Block Label	Display the <u>Ladder Block</u> screen.	
	<b>F2</b>	List Operands	Display the <u>Label Registration/Selection</u> screen.	
	<b>+</b>	Increment Pins	Increment the number of arguments of functions and function blocks.	
	<b>-</b>	Delete Pins	Delete the number of arguments of functions and function blocks.	
	<b>Ctrl</b> + Num <b>+</b> *1	Increase Zoom	Zoom in the screen one level.	
	<b>Ctrl</b> + Num <b>-</b> *1	Decrease Zoom	Zoom out the screen one level.	
-	<b>Alt</b> + <b>↑</b> / <b>↓</b>	-	Narrow and widen the width of ladder block in the Guided mode.	
-	<b>Ctrl</b> + <b>Alt</b> + <b>S</b>	Signal Configuration/Configure	Set the type of contact and coil.	
-	<b>Ctrl</b> + <b>Alt</b> + <b>C</b>	Signal Configuration/Toggle	Change the type of contact and coil in the order shown below: <ul style="list-style-type: none"> <li>• Contact: Open Contact → Close Contact</li> <li>• Coil: Normal → Negation → Set → Reset</li> </ul>	
-	<b>Ctrl</b> + <b>G</b>	Jump	Jump to the specified ladder block number.	
-	<b>Ctrl</b> + <b>Shift</b> + <b>M</b>	Change Label-Device-Address Mode	Switch the display format in order (label, device, address).	
-	<b>Ctrl</b> + <b>Shift</b> + <b>K</b>	Change Label-Comment Mode	Switch the display between label and comment.	
-	<b>Shift</b> + <b>F2</b>	Zoom Header/Body/Header	Open the label setting editor screen for the selected POU.	
-	<b>Ctrl</b> + <b>Insert</b>	Copy	Copy the selected data.	
-	<b>Shift</b> + <b>Delete</b>	Cut	Cut the selected data.	
-	<b>Shift</b> + <b>Insert</b>	Paste	Paste the cut/copied data at the cursor position.	
-	<b>Insert</b>	Guided Mode/Overwrite, Insert Mode	Switch the input mode between Overwrite/Insert in the Guided mode.	
-	<b>Ctrl</b> + <b>L</b>	Guided Mode/Line Mode	Change the input mode for drawing lines in Guided editing.	
-	<b>Ctrl</b> + <b>PgUp</b>	-	Scroll a ladder block to the right.	
-	<b>Ctrl</b> + <b>PgDown</b>	-	Scroll a ladder block to the left.	
-	<b>F1</b>	-	Display the instruction help of GX Works2 help or the help of the user library.	




\*1 : 'Num' indicates keys in the numeric keypad.

■ "SFC" toolbar icons and shortcut keys

The following table shows the toolbar icons and the corresponding shortcut keys for the SFC editor.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
	<b>[F5]</b>	[STEP] New Step	Insert  at the cursor position.	(Simple)
	<b>[F6]</b>	[B] Block Start Step (with END check)	Insert  at the cursor position.	
	<b>[Shift] + [F6]</b>	[BS] Block Start Step (without END check)	Insert  at the cursor position.	
	<b>[F8]</b>	[JUMP] Jump	Insert  at the cursor position.	
	<b>[F7]</b>	[END] END Step	Insert  at the cursor position.	
	<b>[Shift] + [F5]</b>	[DUMMY] Dummy Step	Insert  at the cursor position.	
	<b>[F5]</b>	[TR] Transition	Insert  at the cursor position.	
	<b>[F6]</b>	[--D] Selection Divergence	Insert a selection divergence.	
	<b>[F7]</b>	[==D] Simultaneous Divergence	Insert a simultaneous divergence.	
	<b>[F8]</b>	[--C] Selection Convergence	Insert a selection convergence.	
	<b>[F9]</b>	[==C] Simultaneous Convergence	Insert a simultaneous convergence.	
	<b>[Shift] + [F9]</b>	[ ] Vertical Line	Insert a vertical line.	
	<b>[Ctrl] + [1]</b>	No Attribute	Set the step attribute to No Attribute.	
	<b>[Ctrl] + [2]</b>	Stored Coil	Set the step attribute to Stored Coil.	
	<b>[Ctrl] + [3]</b>	Stored Operation (without Transition Check)	Set the step attribute to Stored Operation (SE).	
	<b>[Ctrl] + [4]</b>	Stored Operation (with Transition Check)	Set the step attribute to Stored Operation (ST).	
	<b>[Ctrl] + [5]</b>	Reset	Reset the step attribute.	
	<b>[Alt] + [F5]</b>	Vertical Line (Draw Line)	Insert  at the cursor position.	
	<b>[Alt] + [F7]</b>	Selection Divergence (Draw Line)	Insert  at the cursor position.	
	<b>[Alt] + [F8]</b>	Simultaneous Divergence (Draw Line)	Insert  at the cursor position.	
	<b>[Alt] + [F9]</b>	Selection Convergence (Draw Line)	Insert  at the cursor position.	
	<b>[Alt] + [F10]</b>	Simultaneous Convergence (Draw Line)	Insert  at the cursor position.	
	<b>[Ctrl] + [F9]</b>	Delete Line	Delete the line at the cursor position.	
	-	SFC Step/Transition Comment	Edit the SFC step/transition comments.	
	-	Sort SFC Step No.	Sort the SFC block step numbers.	
	-	SFC All Block Batch Monitoring	Batch monitor all blocks in the SFC program.	
	-	SFC Auto Scroll	Scroll the screen to display active steps automatically when they are out of the screen during monitoring.	
	<b>[Shift] + [F2]</b>	Read Mode	Switch the mode of the open window to "Read Mode".	
	<b>[F2]</b>	Write Mode	Switch the mode of the open window to "Write Mode".	
-	<b>[Ctrl] + [Shift] + [F2]</b>	Read Mode (All Windows)	Switch the mode of all open windows to "Read Mode".	
-	<b>[Ctrl] + [F2]</b>	Write Mode (All Windows)	Switch the mode of all open windows to "Write Mode".	

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
	<b>[F3]</b>	Monitor Mode	Switch the mode of the open window to "Monitor Mode" during monitoring.	(Simple)
	<b>[Shift] + [F3]</b>	Monitor (Write Mode)	Switch the mode of the open window to "Monitor (Write Mode)" during monitoring.	
	–	Zoom	Change the display magnification ratio of the SFC diagram.	
–	<b>[Ctrl]</b> + turn mouse scroll wheel upward	Bigger	Enlarge the text display size on the editing screen.	
–	<b>[Ctrl]</b> + turn mouse scroll wheel downward	Smaller	Reduce the text display size on the editing screen.	
–	<b>[Shift] + [Insert]</b>	Insert Row	Insert a row at the cursor position.	
–	<b>[Shift] + [Delete]</b>	Delete Row	Delete the row at the cursor position.	
–	<b>[Ctrl] + [Insert]</b>	Insert Column	Insert a column at the cursor position.	
–	<b>[Ctrl] + [Delete]</b>	Delete Column	Delete the column at the cursor position.	
–	<b>[Ctrl] + [G]</b>	Jump	Move the cursor to the SFC step number/ transition number in the specified block	
–	<b>[Ctrl] + [M]</b>	Find Jump Step	Move the cursor to the step of the jump source.	
–	Numeric key	–	Move the cursor to the SFC step number/ transition number.	
–	<b>[Ctrl] + [Alt] + [F4]</b>	Convert Block	Convert a single block only.	
–	<b>[Ctrl] + [F5]</b>	SFC Step/Transition Comment	Display the SFC step/transition comments.	
–	<b>[Ctrl] + [L]</b> / <b>[Ctrl]</b> + double-click	Open Zoom/Start Destination Block	Display the Zoom editor window or the start destination block.	
–	<b>[Space]</b>	–	Display the start destination block.	
–	<b>[Ctrl] + [R]</b>	Back to Start SFC Block	Display the start source block.	
–	<b>[Ctrl] + [Alt] + [F8]</b>	Program Display	Display programs on the SFC diagram when editing in MELSAP-L.	

## ■ SFC block list shortcut keys

The following table shows the shortcut keys for the SFC block list.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
–	<b>[Ctrl] + [G]</b>	Jump	Jump to the specified block number/data name.	(Simple)
–	Numeric key	–	Jump to the selected block number.	
–	<b>[Ctrl] + [F5]</b>	SFC Block List Comment	Display comments of the SFC block list.	

■ Other shortcut keys

The following table shows other shortcut keys for program editors.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
–		–	Move the cursor in the arrow direction.	(Structured)
–		–	Scroll up the screen.	
–		–	Scroll down the screen.	
–		–	Scroll the screen to the left.	
–		–	Scroll the screen to the right.	
–		–	Move the cursor to its leftmost position in the row.	
–		–	Move the cursor to its rightmost position in the row.	
–		–	Move the cursor to the start of the program.	
–		–	Move the cursor to the end of the program.	
–		–	Set a range.	
–		–	Select the range from the current position up to the start of the program.	
–		–	Select the range from the current position down to the end of the program.	
–		–	Delete the selected target.	

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS


















22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## Appendix 1.8 Toolbar icons and shortcut keys for I/O system setting function

The following table shows the toolbar icons and the corresponding shortcut keys for the I/O system setting function.







Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
		New	Create a new I/O system setting.	Section 22.8.1
		Open	Open an existing I/O system setting.	Section 22.8.2
		Save	Save the I/O system setting.	–
		Cut	Cut the selected data.	Section 22.4.2
		Copy	Copy the selected data.	
		Paste	Paste the cut/copied data at the cursor position.	
	–	Execute I/O System Setting	Execute the I/O system setting function and starts simulation.	Section 22.6.1
	–	Disable I/O System Setting	Disable the execution of the I/O system setting function.	Section 22.6.2
	–	Start Monitoring	Start monitoring the <u>I/O System Setting</u> screen.	Section 22.7.1
	–	Stop Monitoring	Stop monitoring the <u>I/O System Setting</u> screen.	
–		Exit I/O System Settings	Exit the I/O system setting.	–

## Appendix 1.9 Shortcut keys for operating intelligent function module

The following explains the toolbar icons and the corresponding shortcut keys for editing intelligent function module data.









### ■ Toolbar icons for positioning monitoring function

The following table shows the toolbar icons for the positioning monitoring function.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
	–	–	Monitor the operating status of positioning module.	(Intelligent)
	–	–	Monitor the start history.	
	–	–	Monitor the error history.	
	–	–	Monitor the warning history.	
	F3	–	Start the positioning monitor.	
	Alt + F3	–	Stop the positioning monitor.	

### ■ Toolbar icons and shortcut keys for predefined protocol support function

The following table shows the toolbar icons and the corresponding shortcut keys for the predefined protocol support function.

Toolbar icon	Shortcut key	Corresponding menu	Description	Reference
	Ctrl + N	New	Create a new communication protocol.	(Intelligent)
	Ctrl + O	Open	Open an existing communication protocol.	
	Ctrl + S	Save	Save the protocol information.	
	Ctrl + C	Copy	Copy the selected data.	
	Ctrl + V	Paste	Paste the cut/copied data at the cursor position.	
	–	Print	Print the protocol information.	
	–	Write to Module	Write data to the module.	
	–	Read from Module	Read data from the module.	

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

## Appendix 2 Simulation Function



The simulation function debugs sequence programs on the virtual programmable controller on the personal computer.

The created sequence programs can be debugged without connecting the personal computer to the programmable controller CPU.

This section explains the simulation function and the restrictions.

### Appendix 2.1 Supported CPU functions

This section explains the programmable controller CPU functions that are supported by GX Works2 simulation function.

The following tables show the functions that are supported by the simulation function.

○: Supported △: Supported with restrictions ×: Not supported

Function name	Function detail	Supported/Not supported	Remarks
Programming			
Memory	Program memory	○	–
	Program cache memory	×	–
	Memory card (RAM)	○	–
	Memory card (ROM)	×	–
	Standard RAM	○	–
	Standard ROM	○	–
I/O number	I/O number assignment (automatic)	○	–
	I/O number assignment (specified)	○	–
	Number of points occupied by empty slots	○	–
	Number of base slots	△	QCPU (Q mode) only
Interrupt program	–	×	–
Multiple program execution	Program executing order setting	○	–
	Initial execution type	○	–
	Scan execution type	○	–
	Low-speed execution type program	△	For the operation of low-speed execution type programs, refer to Appendix 2.5.
	Standby type	○	–
	Fixed scan execution type	○	–
	Change (Set) by parameter	○	–
Change by instruction	○	–	
Boot operation	–	○	–



Function name	Function detail	Supported/ Not supported	Remarks
Programmable controller CPU function			
Programming language	Ladder Diagram	○	—
	List	×	—
	Sequential Function Chart (MELSAP3, MELSAP-L)	△*1	—
	Structured Text	○	—
Communication with intelligent function module	—	×	—
Constant scan	—	△	No operation is performed in actual time.
Watch dog timer (WDT)	—	△	30,000,000 instructions per scan
Latch function	—	△	Supported by device backup function.
Device initial value	—	○	—
Service processing setting	—	×	—
Output mode setting at STOP to RUN	—	○	—
Input response time selection	—	×	—
Error time output mode setting	—	×	—
CPU operation mode at hardware error	—	×	—
Switch setting of intelligent function module	—	×	—
Monitoring function	—	○	—
Monitor condition setting	—	×	—
Monitoring/testing local devices	—	○	—
Remote password	—	×	—
CPU module system display	—	×	—
LED display	—	○	—
Interrupt from intelligent function module	—	×	—
Serial communication function	—	×	—
Remote RUN/STOP	—	○	—
Remote PAUSE	—	×	—
Remote RESET	—	○	—
Remote latch clear	—	×	—
Scan time measurement	—	×	—
Program list monitoring	—	△	No operation is performed in actual time.
Interrupt program list monitoring	—	×	—
Monitoring/testing devices	—	○	—
Forced ON/OFF of external I/O	—	○	—
Device test with execution condition	—	○	—
Sampling trace	—	○	—
Online program change	—	△	SFC file batch online program change is not supported.
Debugging by multiple programming tools	—	×	—

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
—	INDEX

Function name	Function detail	Supported/ Not supported	Remarks
Programmable controller CPU function			
Self-diagnostic function	—	○	—
Error history	—	○	—
System protection	—	×	—
Password registration	—	×	—
Error reset	—	○	—
LED control function	—	○	—
Module error history collection function	—	×	—
Local device batch read function	—	×	—
Backing up latch data to standard ROM	—	×	—
Writing/Reading device data to standard ROM	—	△	Supported by device backup function.
Reading module name	—	×	—
Clock function	—	△	Clock setting is not supported. Extended clock setting (1/1000 seconds) is not supported.
Battery long-life operation	—	×	—
Memory check function	—	×	—
LCPU data logging function	—	△	Only trigger logging is supported by sampling trace function.
LCPU built-in I/O function	—	×	—
LCPU built-in Ethernet function	—	×	—
LCPU built-in CC-Link function	—	×	—
QCPU multiple CPU system	—	×	—
QCPU network	—	×	—
Device, Constant			
A series CPU compatibility setting (Special relay, special register)	—	×	—
Device indexing	16-bit indexing	○	—
	32-bit indexing	○	—
Pointer	Local/Common pointer	○	—
Local device	—	○	—
Floating point arithmetic processing (Internal precision)	—	△	Rounding error occurs.
Device setting	—	○	—
Indirect specification	—	○	—
File register setting	—	○	—
Extended data register, extended link register (Use file registers)	—	○	—
Extension of bit device points	—	○	—

- \*1 : The following functions are not supported.
- Periodic execution program setting
  - Operation mode at block/step concurrent start
  - Step transition monitoring timer
  - Control SFC type program
  - Step/Transition comment read (instruction)

## Appendix 2.2 Supported devices

This section explains the devices supported by the simulation function.

However, some devices may be restricted or not supported. No processing is performed for unsupported devices (NOP processing).

Unsupported devices used in a program and their used locations can be checked by selecting [Debug] ⇒ [Instructions Unsupported by Simulation]. (☞ Section 18.3)

### ● Device list (QCPU (Q mode)/LCPU)

○: Supported ×: Not supported

Category	Type	Device name	Support	Remarks	
Internal user device* <sup>1</sup>	Bit device	Input (X)	○	Actual inputs are invalid.	
		Output (Y)	○	Actual outputs are invalid.	
		Internal relay (M)* <sup>2</sup>	○	–	
		Latch relay (L)	○	–	
		Annunciator (F)	○	–	
		Edge relay (V)* <sup>2</sup>	○	–	
		Step relay (S)	○	–	
		Link special relay (SB)	○	–	
	Link relay (B)	○	–		
	Word device	Timer (T)* <sup>2</sup> , * <sup>3</sup>	○	No operation is performed in actual time. The high-speed timer can be set in units of 0.1ms (by parameter). (For Universal model QCPU and LCPU, in units of 0.01ms)	
		Retentive timer (ST)* <sup>3</sup>	○	No operation is performed in actual time. The high-speed retentive timer can be set in units of 0.1ms (by parameter). (For Universal model QCPU and LCPU, in units of 0.01ms)	
		Counter (C)* <sup>3</sup>	○	–	
		Data register (D)* <sup>2</sup>	○	–	
		Link register (W)	○	–	
		Link special register (SW)	○	–	
	Internal system device	Bit device	Function input (FX)	○	–
			Function output (FY)	○	–
Special relay (SM)			○	For the supported special relays, refer to the Special relay list.	
Word device		Function register (FD)	○	–	
		Special register (SD)	○	For the supported special registers, refer to the Special register list.	
Link direct device	Bit device	Link input (Jn\X)	×	–	
		Link output (Jn\Y)	×	–	
		Link relay (Jn\B)	×	–	
		Link special relay (Jn\SB)	×	–	
	Word device	Link register (Jn\W)	×	–	
		Link special register (Jn\SW)	×	–	
Intelligent function module device	Word device	Intelligent function module device (Un\G)	○	I/O assignment setting in PLC parameter is required.	
Index register	Word device	Index register (Z)	○	–	
File register* <sup>4</sup>	Word device	File register (R) File register (ZR)	○	File register setting in PLC parameter is required.	
Extended device* <sup>4</sup>	Word device	Extended data register (D)	○		
		Extended link register (W)	○		
Nesting	–	Nesting (N)	○	–	

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

Category	Type	Device name	Support	Remarks
Pointer	-	Pointer (P)	○	-
		Interrupt pointer (I)	×	-
Others	Bit device	SFC block device (BL)	○	-
		SFC transition device (TR)	×	-
	-	Network number specified device (J)	×	-
		I/O number specified device (U)	×	-
		Macro instruction argument device (VD)	○	-
		CPU shared memory (Un\G)	○	Memory for reading/writing data among CPU modules in a multiple CPU system. Enabled only when multiple CPU settings are made. Not supported by LCPU.
Constant	-	Decimal constant	○	K-2147483648 to K2147483647
		Hexadecimal constant	○	H0 to HFFFFFFF
		Real constant	○	E±1.17550-38 to E±3.40282+38
			○	E±2.22507-308 to E±1.79770+308 Supported by Universal model QCPU/LCPU only.
		String constant	○	Up to 32 characters per instruction

\*1 : The device points of the internal user devices can be changed within the following range.  
 High-speed Universal model QCPU/Universal model process CPU: Within 60k word  
 Other CPUs: Within 29k word

\*2 : Devices that can be used for local devices

\*3 : Timer/Retentive timer/Counter: Contact and coil are bit devices and current value is a word device.

\*4 : The total device points of the file registers and the extended registers can be changed within the following range. (1k unit)  
 QnUD(H)CPU, QnUDE(H)CPU, and LCPU: 0 to 4086k points  
 High-speed Universal model QCPU/Universal model process CPU: 0 to 4736k points  
 Other CPUs: 0 to 1018k points

● Device list (FXCPU)

○: Supported ×: Not supported

Category	Type	Device name	Purpose	Support	Remarks
Internal user device	Bit device	Input (X)	–	○	Octal number. Actual inputs are invalid.
		Output (Y)	–	○	Octal number. Actual outputs are invalid.
	Auxiliary relay (M)	General type* <sup>1</sup> (changeable)	○	–	
		Latched type* <sup>2</sup> (changeable)	○	–	
		General type (fixed)	○	–	
		Latched type* <sup>3</sup> (fixed)	○	–	
		Special type	○	–	
	State (S)	Initial state* <sup>1</sup>	○	–	
		Initial state (latched)	○	–	
		General type* <sup>1</sup>	○	–	
		Latched type* <sup>2</sup>	○	–	
		Latched type* <sup>3</sup>	○	–	
	Timer (T)	100ms	○	–	
		10ms	○	–	
		100ms/10ms	○	–	
		Retentive type for 1ms* <sup>3</sup>	○	–	
		Retentive type for 100ms* <sup>3</sup>	○	–	
		1ms* <sup>3</sup>	○	–	
		Counter (C)	16-bit up-counter* <sup>1</sup>	○	–
			16-bit up-counter* <sup>2</sup>	○	–
			32-bit bidirectional counter* <sup>1</sup>	○	–
			32-bit bidirectional counter* <sup>2</sup>	○	–
	High-speed counter		×	–	
	Data register (D) (32 bits when used in pairs)	16-bit general type* <sup>1</sup>	○	–	
		16-bit latched type* <sup>2</sup>	○	–	
		16-bit latched type* <sup>3</sup>	○	–	
		16-bit special type	○	–	
		File type* <sup>1</sup>	○	–	
		RAM file type	○	–	
		16-bit latched type (extension register [R])	○	–	
		16-bit latched type (extension file register [ER])	×	–	
		Buffer memory	○	–	
16-bit index type		○	–		

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

Category	Type	Device name	Purpose	Support	Remarks
Nesting (N)			Master control	○	–
Pointer	Pointer (P)		JUMP or CALL branch	○	–
	Interrupt pointer (I)		Interruption	×	–
Decimal constant			16 bits	○	–
			32 bits	○	–
Hexadecimal constant			16 bits	○	–
			32 bits	○	–
Real number constant				○	–
Character string constant				○	–

\*1 : Non-latched area. It can be changed to the latched area by parameter setting.

\*2 : Latched area. It can be changed to the non-latched area by parameter setting.













\*3 : Fixed latched area. The characteristics of latch cannot be changed.

● Special relay list (QCPU (Q mode)/LCPU)

For details of special relays

☞ User's Manual (Function Explanation, Program Fundamentals) of the CPU module to be used

No.	Name	Description
SM0	Diagnostic error	OFF : No error ON : Error
SM1	Self-diagnostic error	OFF : No self-diagnostic error ON : Self-diagnostic error
SM5	Error common information	OFF : No error common information ON : Error common information
SM16	Error individual information	OFF : No error individual information ON : Error individual information
SM50	Error reset	OFF→ON: Error reset
SM56	Operation error	OFF : Normal ON : Operation error
SM62	Annunciator detection	OFF : Not detected ON : Detected
SM165	Program memory batch transfer execution status	OFF : Completed ON : Not being executed or not completed
SM202	LED OFF command	OFF→ON: LED OFF
SM203	STOP contact	STOP status
SM204	PAUSE contact	PAUSE status
SM206	PAUSE enable coil	OFF : PAUSE disabled ON : PAUSE enabled
SM213	Clock data read request	OFF : Ignored ON : Read request
SM250	Max. loaded I/O read	OFF : Ignored ON : Read
SM320	Presence/absence of SFC program	OFF : SFC program absent ON : SFC program present
SM321	Start/stop SFC program	OFF : SFC program not executed (stop) ON : SFC program executed (start)
SM322	SFC program start status	OFF : Initial start ON : Resume start
SM323	Presence/absence of continuous transition for entire block	OFF : Continuous transition not effective ON : Continuous transition effective
SM324	Continuous transition prevention flag	OFF : When transition is executed ON : When no transition
SM325	Output mode at block stop	OFF : OFF ON : Preserves
SM326	SFC device clear mode	OFF : Clear device ON : Preserves device

No.	Name	Description
SM327	Output during end step execution	OFF : Hold step output turned OFF (cleared) ON : Hold step output held
SM328	Clear processing mode when end step is reached	OFF : Clear processing is performed. ON : Clear processing is not performed.
SM329	Online module change of SFC non-active block in progress flag	OFF : Not executed ON : Being executed
SM400	Always ON	ON _____ OFF
SM401	Always OFF	ON _____ OFF _____
SM402	After RUN, ON for only 1 scan	ON  OFF
SM403	After RUN, OFF for only 1 scan	ON  OFF
SM404	Low speed execution type program ON for 1 scan only after RUN	ON  OFF
SM405	Low speed execution type program After RUN, OFF for 1 scan only	ON  OFF
SM409*1	0.01 second clock	
SM410*1	0.1 second clock	
SM411*1	0.2 second clock	
SM412*1	1 second clock	
SM413*1	2 second clock	
SM414*1	2n second clock	
SM415*1	2n (ms) clock	
SM420	User timing clock No. 0	
SM421	User timing clock No. 1	
SM422	User timing clock No. 2	
SM423	User timing clock No. 3	
SM424	User timing clock No. 4	
SM430	User timing clock No. 5	
SM431	User timing clock No. 6	
SM432	User timing clock No. 7	
SM433	User timing clock No. 8	
SM434	User timing clock No. 9	

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

No.	Name	Description
SM510	Low speed program execution flag	OFF : Completed or not executed ON : Execution under way
SM600	Memory card usable flags	OFF : Unusable ON : Use enabled
SM602	Drive 1 flag	OFF : No drive 1 ON : Drive 1 present
SM603	Drive 2 flag	OFF : No drive 2 ON : Drive 2 present
SM604	Memory card in-use flag	OFF : Not used ON : In use
SM620	Drive 3/4 usable flags	OFF : Unusable ON : Use enabled
SM621	Drive 3/4 protect flag	OFF : Not protected ON : Protected
SM622	Drive 3 flag	OFF : No drive 3 ON : Drive 3 present
SM623	Drive 4 flag	OFF : No drive 4 ON : Drive 4 present
SM624	Drive 3/4 in-use flag	OFF : Not used ON : In use
SM626	Extended SRAM cassette insertion flag	OFF : Not inserted ON : Inserted
SM640	File register use	OFF : File register not used ON : File register in use
SM650	Comment use	OFF : Comment not used ON : Comment in use
SM672	Memory card file register access range flag	OFF : Within access range ON : Outside access range
SM680	Program memory write error	OFF : Write not executed/ normal ON : Write error
SM681	Program memory writing flag	OFF : Write not executed ON : During writing
SM700	Carry flag	OFF : Carry OFF ON : Carry ON
SM702	Search method	OFF : Search next ON : 2-part search
SM703	Sort order	OFF : Ascending order ON : Descending order
SM704	Block comparison	OFF : Non-match found ON : All match
SM709	DT/TM instruction improper data detection flag	OFF : Improper data not detected ON : Improper data detected
SM716	Block comparison (Except an interrupt program)	OFF : Mismatch found ON : No mismatch
SM717	Block comparison (Interrupt program)	OFF : Mismatch found ON : No mismatch

No.	Name	Description
SM722	BIN/DBIN instruction error disabling flag	OFF : Error detection performed ON : Error detection not performed
SM750	Scaling instruction search method setting	OFF : Search next ON : 2-part search
SM774	PID bumpless processing (for complete derivative)	OFF : Matched ON : Not matched
SM776	Enable/disable local device at CALL	OFF : Local device disabled ON : Local device enabled
SM777	Enable/disable setting for local devices in interrupt program	OFF : Local device disabled ON : Local device enabled
SM794	PID bumpless processing(for incomplete derivative)	OFF : Matched ON : Not matched
SM800	Trace preparation	OFF : Not ready ON : Ready
SM801	Trace start	OFF : Suspend ON : Start
SM802	Trace execution in progress	OFF : Suspend ON : Start
SM803	Trace trigger	OFF → ON: Start
SM804	After trace trigger	OFF : Not after trigger ON : After trigger
SM805	Trace completed	OFF : Not completed ON : End
SM826	Trance error	OFF : Normal ON : Error
SM829	Forced registration specification of trace setting	OFF : Forced registration disabled ON : Forced registration enabled
SM1500*2	Process control instruction S.IN hold mode	OFF : No-hold ON : Hold
SM1501*2	Process control instruction S.OUT hold mode	OFF : No-hold ON : Hold
SM1510*3	Operation mode	(Fixed to 'OFF') OFF : Backup mode, debug mode ON : Separate mode
SM1511*3	System A identification flag	(Fixed to 'ON' (System A))*4
SM1512*3	System B identification flag	(Fixed to 'OFF' (System A))*4
SM1513*3	Debug mode status flag	(Fixed to 'ON') OFF : Not in debug mode ON : Debug mode
SM1515*3	Operation system status	(Fixed to 'ON' (Control system))*5
SM1516*3		(Fixed to 'OFF' (Control system))*5



- \*1 : When the setting value of the constant scan is equal to the integral multiple of the clock time, the value of the special relay is OFF every scan. For the setting to turn the clock of the special relay ON/OFF, refer to Point in the next page.
- \*2 : These devices are for the process control instruction, and supported by Process CPU, Redundant CPU, and Universal model process CPU only.  
When the program with the process control instruction is written to the programmable controller CPU other than Process CPU, Redundant CPU, and Universal model process CPU, a stop error occurs on the CPU from INSTRCT.CODE ERR (error code 4002).
- \*3 : Applicable for operations on Redundant CPU only. Fixed to the status in the parentheses.
- \*4 : The following shows the correspondences for the system A and the system B of Redundant system.  
System A: When SM1511 is ON, or SM1512 is OFF.  
System B: When SM1511 is OFF, or SM1512 is ON.  
Unspecified system: When both SM1511 and SM1512 are OFF.
- \*5 : The following shows the correspondences for the operating status of CPU module.  
Control system: When SM1515 is ON, or SM1516 is OFF.  
Standby system: When SM1515 is OFF, or SM1516 is ON.  
Unspecified system: When both SM1515 and SM1516 are OFF.

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
—	INDEX

**Point**


● **Turning clock of special relay ON/OFF**

To turn the clock of the special relay ON/OFF, set the constant scan setting value avoiding the integral multiple of the clock time, as described by the following example "Not equal to integral multiple" shown below.

• **Example: Not equal to integral multiple**

The following figure shows the behavior of the 0.1-second clock when the constant scan is 50ms.


The special relay repeats ON/OFF.



• **Example: Equal to integral multiple**

The following figure shows the behavior of the 0.1-second clock when the constant scan is 100ms (default).

The value of the special relay is OFF every scan.







● **Contact scan setting**

To set the constant scan setting value, select [PLC Parameter] ⇒ <<PLC RAS>> and set it.

### ● Special relay list (FXCPU)

For details of special relays

☞ Programming Manual of the FXCPU module to be used

No.	Name	Description
M8000	RUN monitor NO contact	OFF : STOP ON : RUN
M8001	RUN monitor NC contact	OFF : RUN ON : STOP
M8002	Initial pulse NO contact	ON for only 1 scan after RUN
M8003	Initial pulse NC contact	OFF for only 1 scan after RUN
M8004	Error occurrence	ON while either one among M8060 to M8067 is ON
M8011	10ms clock	
M8012	100ms clock	
M8013	1 sec. clock	
M8014	1 min. clock	
M8018	Installation detection for real-time clock	Always ON
M8020	Zero	ON when the addition or subtraction result is 0
M8021	Borrow	ON when the subtraction result is less than the maximum negative value
M8022	Carry	ON when "carry" occurs in the addition result
M8023	Floating-point calculation command	ON : Carry out floating-point calculation
M8024	BMOV instruction execution direction	ON : Write OFF : Read
M8026	RAMP mode	ON : Hold output value OFF : Reset value at output
M8028	Timer switch command	OFF : 100ms timer ON : 10ms timer
M8029	Instruction execution complete	OFF : During executing ON : Execution completed
M8031	Non-latched memory all clear	OFF : Hold ON : Clear
M8032	Latched memory all clear	OFF : Hold ON : Clear
M8033	Memory holding against STOP mode	OFF : Clear ON : Hold
M8034	All output disable	OFF : Enable output ON : Disable output
M8038	RAM file clear command	OFF : Hold ON : Clear
M8039	Constant scan mode	OFF : Normal scan ON : Constant mode

No.	Name	Description
M8040	Transfer disable	OFF : Enable transfer ON : Disable transfer
M8041	Transfer start (for IST instruction)	OFF : Stop transfer ON : Start transfer
M8042	Start pulse (for IST instruction)	ON : IST instruction start command
M8043	Zero point return complete (for IST instruction)	ON : IST instruction zero point return complete command
M8044	Zero point condition (for IST instruction)	ON : Zero point OFF : Zero point return is undetermined
M8045	All output reset disable (for IST instruction)	ON : Disable reset OFF : Enable reset
M8046	STL state ON	ON : ON while either one among S0 to S899 is ON
M8047	STL monitoring enable	ON : Enable D8040 to D8047
M8048	Annunciator ON	ON while either one among S900 to S999 is ON
M8049	Annunciator enable	ON : Enable D8049 OFF : Disable D8049
M8067	Operation error	ON : Operation error OFF : No operation error
M8068	Operation error latch	Hold occurrence of M8067
M8074	RAM file register setting	ON : Use setting OFF : Not use setting
M8090	BKCMP instruction: Block comparison signal	ON : Comparison result matches OFF : Comparison result does not match
M8091	Output character quantity selector signal	ON : Change nothing OFF : Write 00H (NULL)
M8160	XCH instruction: SWAP function	ON : 8-bit conversion OFF : Normal mode
M8161	8-bit processing mode	Processing mode in the ASC, ASCI, and HEX instructions
M8164	FROM and TO instructions: Transfer points variable mode	Transfer points switch command
M8168	SMOV instruction: Hexadecimal data handling function	Data shift in 4-bit units
M8200	Counter counting direction	ON : C200 is down-counting OFF : C200 is up-counting

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

No.	Name	Description
M8201	Counter counting direction	ON : C201 is down-counting OFF: C201 is up-counting
M8202	Counter counting direction	ON : C202 is down-counting OFF: C202 is up-counting
M8203	Counter counting direction	ON : C203 is down-counting OFF: C203 is up-counting
M8204	Counter counting direction	ON : C204 is down-counting OFF: C204 is up-counting
M8205	Counter counting direction	ON : C205 is down-counting OFF: C205 is up-counting
M8206	Counter counting direction	ON : C206 is down-counting OFF: C206 is up-counting
M8207	Counter counting direction	ON : C207 is down-counting OFF: C207 is up-counting
M8208	Counter counting direction	ON : C208 is down-counting OFF: C208 is up-counting
M8209	Counter counting direction	ON : C209 is down-counting OFF: C209 is up-counting
M8210	Counter counting direction	ON : C210 is down-counting OFF: C210 is up-counting
M8211	Counter counting direction	ON : C211 is down-counting OFF: C211 is up-counting
M8212	Counter counting direction	ON : C212 is down-counting OFF: C212 is up-counting
M8213	Counter counting direction	ON : C213 is down-counting OFF: C213 is up-counting
M8214	Counter counting direction	ON : C214 is down-counting OFF: C214 is up-counting
M8215	Counter counting direction	ON : C215 is down-counting OFF: C215 is up-counting
M8216	Counter counting direction	ON : C216 is down-counting OFF: C216 is up-counting
M8217	Counter counting direction	ON : C217 is down-counting OFF: C217 is up-counting
M8218	Counter counting direction	ON : C218 is down-counting OFF: C218 is up-counting

No.	Name	Description
M8219	Counter counting direction	ON : C219 is down-counting OFF: C219 is up-counting
M8220	Counter counting direction	ON : C220 is down-counting OFF: C220 is up-counting
M8221	Counter counting direction	ON : C221 is down-counting OFF: C221 is up-counting
M8222	Counter counting direction	ON : C222 is down-counting OFF: C222 is up-counting
M8223	Counter counting direction	ON : C223 is down-counting OFF: C223 is up-counting
M8224	Counter counting direction	ON : C224 is down-counting OFF: C224 is up-counting
M8225	Counter counting direction	ON : C225 is down-counting OFF: C225 is up-counting
M8226	Counter counting direction	ON : C226 is down-counting OFF: C226 is up-counting
M8227	Counter counting direction	ON : C227 is down-counting OFF: C227 is up-counting
M8228	Counter counting direction	ON : C228 is down-counting OFF: C228 is up-counting
M8229	Counter counting direction	ON : C229 is down-counting OFF: C229 is up-counting
M8230	Counter counting direction	ON : C230 is down-counting OFF: C230 is up-counting
M8231	Counter counting direction	ON : C231 is down-counting OFF: C231 is up-counting
M8232	Counter counting direction	ON : C232 is down-counting OFF: C232 is up-counting
M8233	Counter counting direction	ON : C233 is down-counting OFF: C233 is up-counting
M8234	Counter counting direction	ON : C234 is down-counting OFF: C234 is up-counting

● Special register list (QCPU (Q mode)/LCPU)

For details of special registers

☞ User's Manual (Function Explanation, Program Fundamentals) of the CPU module to be used

No.	Name	Description
SD0	Diagnostic error	Diagnostic error code
SD1	Clock time for diagnosis error occurrence	Clock time for diagnosis error occurrence
SD2		
SD3		
SD4		
SD4	Error information categories	Error information category code
SD5	Error common information	Error common information
SD6		
SD7		
SD8		
SD9		
SD10		
SD11		
SD12		
SD13		
SD14		
SD15		
SD16	Error individual information	Error individual information
SD17		
SD18		
SD19		
SD20		
SD21		
SD22		
SD23		
SD24		
SD25		
SD26		
SD50	Error reset	Error code to be reset
SD62	Annunciator number	Annunciator number
SD63	Number of annunciators	Number of annunciators
SD64	Table of detected annunciator numbers	Annunciator detection number
SD65		
SD66		
SD67		
SD68		
SD69		
SD70		
SD71		
SD72		
SD73		
SD74		
SD75		

No.	Name	Description
SD76	Table of detected annunciator numbers	Annunciator detection number
SD77		
SD78		
SD79		
SD200	Status of switch	Status of CPU switch
SD201	LED status	Status of CPU-LED
SD202	LED OFF command	Bit pattern of LED that is turned OFF
SD203	Operating status of CPU	Operating status of CPU*1
SD204	LED display color	CPU-LED display color
SD207	LED display priority ranking	Priorities 1 to 4
SD208		Priorities 5 to 8
SD209		Priorities 9 to 11
SD210	Clock data	Clock data (year, month)
SD211	Clock data	Clock data (day, hour)
SD212	Clock data	Clock data (minute, second)
SD213	Clock data	Clock data (higher digits of year, day of week)
SD220	LED display data	LED display data
SD221		
SD222		
SD223		
SD224		
SD225		
SD226		
SD227		
SD240	Base mode	0: Automatic mode 1: Detail mode
SD241	Extension stage number	0: Main base only 1 to 7: Extension stage number
SD242	A/Q base differentiation	0 : QA**B is installed (A mode) 1 : Q**B is installed (Q mode)
SD243	No. of base slots (Operation status)	Number of base slots
SD244		
SD250	Loaded maximum I/O	Loaded maximum I/O number
SD282	Device assignment	Number of points assigned for D (for internal device extension)
SD283		
SD284		Number of points assigned for W (for internal device extension)
SD285		
SD286		Number of points assigned for M (for extension)
SD287		
SD288		Number of points assigned for B (for extension)
SD289		

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

No.	Name	Description
SD290	Device assignment	Number of points assigned for X
SD291		Number of points assigned for Y
SD292		Number of points assigned for M
SD293		Number of points assigned for L
SD294		Number of points assigned for B
SD295		Number of points assigned for F
SD296		Number of points assigned for SB
SD297		Number of points assigned for V
SD298		Number of points assigned for S
SD299		Number of points assigned for T
SD300		Number of points assigned for ST
SD301		Number of points assigned for C
SD302		Number of points assigned for D
SD303		Number of points assigned for W
SD304		Number of points assigned for SW
SD305		Device assignment (Index register)
SD306	Device assignment (Same as parameter contents)	Number of points assigned for ZR (for extension)
SD307		
SD308	Device assignment (Assignment including the number of points set to the extended data register and extended link register setting)	Number of points assigned for D (for inside + for extension)
SD309		Number of points assigned for W (for inside + for extension)
SD310		
SD311		
SD395	Multiple CPU system information	Multiple CPU number
SD396		No. 1 CPU operation status
SD412*2	1 second counter	Number of counts in 1-second units
SD414*2	2n second clock setting	2n second clock units
SD415*2	2n millisecond clock setting	2n millisecond clock units
SD420	Scan counter	Number of counts in each scan
SD430	Low speed scan counter	Number of counts in each scan
SD500	Execution program No.	Program number in execution
SD520*3	Current scan time	Current scan time (ms value)
SD521*3		Current scan time (μs value)
SD522*3	Initial scan time	Initial scan time (ms value)
SD523*3		Initial scan time (μs value)
SD524*3	Minimum scan time	Minimum scan time (ms value)
SD525*3		Minimum scan time (μs value)
SD526	Maximum scan time	Maximum scan time (ms value)
SD527		Maximum scan time (μs value)
SD528	Current scan time for low speed execution type programs	Current scan time (ms value)
SD529		Current scan time (μs value)

No.	Name	Description
SD532	Minimum scan time for low speed execution type programs	Minimum scan time (ms value)
SD533		Minimum scan time (μs value)
SD534	Maximum scan time for low speed execution type programs	Maximum scan time (ms value)
SD535		Maximum scan time (μs value)
SD600	Memory card type	Memory card type
SD602	Drive 1 (Memory card RAM) capacity	Drive 1 capacity
SD603	Drive 2 (Memory card ROM) capacity	Drive 2 capacity
SD604	Memory card use conditions	Memory card use conditions
SD620	Drive 3/4 type	Drive 3/4 type
SD622	Drive 3 (Standard RAM) capacity	Drive 3 capacity
SD623	Drive 4 (Standard ROM) capacity	Drive 4 capacity
SD624	Drive 3/4 use conditions	Drive 3/4 use conditions
SD640	File register drive	Drive number
SD641 to SD646	File register file name	File register file name
SD647	File register capacity	File register capacity
SD648	File register block number	File register block number
SD650	Comment drive	Comment drive number
SD651 to SD656	Comment file name	Comment file name
SD670	Parameter enable drive information	Parameter enable drive number
SD681	Program memory write (transfer) status	(Fixed to 100) Write (transfer) status display (percentage)
SD840	Debugging function usage	Debugging function usage
SD1500*4	Process control instruction	Basic period for process control instruction
SD1501*4		
SD1502*4	Process control instruction Detail error code	Detailed error code for process control instruction
SD1503*4	Process control instruction Generated error location	Generated error location for process control instruction
SD1506*4	Dummy devices	Dummy devices
SD1507*4		

No.	Name	Description
SD1508 *4	Process control instruction Function availability selection	b0 Bumpless function availability setting for the S.PIDP instruction 0: Enabled 1: Disabled (Default: 0)

- \*1 : SD203 supports the operating status of CPU only. STOP/ PAUSE cause is fixed to 0.
- \*2 : Values are derived from the constant scan setting value and the number of scans.
- \*3 : All values are equal to the constant scan setting value.
- \*4 : These devices are for the process control instruction, and supported by Process CPU and Redundant CPU only. When the program with the process control instruction is written to the programmable controller CPU other than Process CPU and Redundant CPU, a stop error occurs on the CPU from INSTRCT.CODE ERR (error code 4002).

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
—	INDEX

● **Special register list (FXCPU)**

For details of special registers

☞ Programming Manual of the FXCPU module to be used

No.	Name	Description
D8000	Watchdog timer	200ms*1
D8001	PLC type and system version	*2
D8002	Memory capacity	Maximum capacity based on the programmable controller type
D8004	Error M number	M8060 to M8068
D8006	Low battery voltage detection level	30 (Unit: 0.1 V)
D8010	Current scan time	*3
D8011	Minimum scan time	*3
D8012	Maximum scan time	*3
D8013	Second data	Operate as 1-second timer
D8014	Minute data	Time data
D8015	Hour data	Time data
D8016	Day data	Time data
D8017	Month data	Time data
D8018	Year data	Time data
D8019	Day-of-the-week data	Time data
D8028	Value of register Z	Value of register Z
D8029	Value of register V	Value of register V
D8030	Variable analog potentiometer VR1	*4
D8031	Variable analog potentiometer VR2	*4
D8039	Constant scan time	Initial value: 100ms (Unit: 1ms)*5
D8040	ON state relay number 1	Value of STL monitor
D8041	ON state relay number 2	Value of STL monitor
D8042	ON state relay number 3	Value of STL monitor
D8043	ON state relay number 4	Value of STL monitor
D8044	ON state relay number 5	Value of STL monitor
D8045	ON state relay number 6	Value of STL monitor
D8046	ON state relay number 7	Value of STL monitor
D8047	ON state relay number 8	Value of STL monitor
D8049	Smallest active state relay number	Value of STL monitor
D8067	Error code for operation error	Error code number
D8068	Latched step number where operation error has occurred	Hold step number where operation error has occurred
D8069	Step number where error has occurred	Step number where error has occurred
D8101	PLC type and system version	*2
D8102	Memory capacity	Maximum capacity based on the programmable controller type

No.	Name	Description
D8164	FROM and TO instructions: Transfer points quantity specification	Write transfer points
D8182	Value of register Z1	Value of register Z1
D8183	Value of register V1	Value of register V1
D8184	Value of register Z2	Value of register Z2
D8185	Value of register V2	Value of register V2
D8186	Value of register Z3	Value of register Z3
D8187	Value of register V3	Value of register V3
D8188	Value of register Z4	Value of register Z4
D8189	Value of register V4	Value of register V4
D8190	Value of register Z5	Value of register Z5
D8191	Value of register V5	Value of register V5
D8192	Value of register Z6	Value of register Z6
D8193	Value of register V6	Value of register V6
D8194	Value of register Z7	Value of register Z7
D8195	Value of register V7	Value of register V7
D8312	Latched step number where operation error has occurred	Lower
D8313		Upper
D8314	Step number where error has occurred 32 bits	Lower
D8315		Upper

\*1 : Initialized to 200ms on every programmable controller type. The watchdog timer time can be changed, but the WDT check is never performed.

\*2 : The value of D8001 and D8101 differs according to the programmable controller type.

Programmable controller CPU	Value ("****" indicates version)	
	D8001	D8101
FX0, FX0S	20***	0
FX0N	20***	
FX1	21***	
FXU, FX2C	20***	
FX1S	22***	
FX1N, FX1NC	26***	
FX2N, FX2NC	24***	
FX3S	28***	28***
FX3G, FX3GC	26***	26***
FX3U, FX3UC	24***	16***

\*3 : The value is always set to 100ms.

\*4 : Operates as a general data register. Write a value between 0 and 255 and test the operation using functions such as the Modify Value function of GX Works2.

\*5 : The value can be changed, but a single scan is always executed in 100ms.



## ■ Devices supported by the I/O system setting function

The following table shows the list of devices which can be used for conditions, the device value input, and timing chart input in the I/O system setting function.

### ● Device list (QCPU (Q mode)/LCPU)

○: Supported ×: Not supported

Category	Device name	Symbol	QCPU (Q mode)/LCPU	
Internal user device	Input	X	○	
	Output	Y	○	
	Internal relay	M	○	
	Latch relay	L	○	
	Annunciator	F	○	
	Edge relay	V	×	
	Step relay	S	×	
	Link relay	B	○	
	Link special relay	SB	○	
	Timer	Current value	TN	○
		Contact	TS	○
		Coil	TC	×
	Counter	Current value	CN	○
		Contact	CS	○
		Coil	CC	×
	Retentive timer	Current value	STN(SN)	○
		Contact	STS(SS)	○
		Coil	STC(SC)	×
	Data register	D	○	
	Link register	W	○	
Link special register	SW	○		
Direct input	DX	×		
Direct output	DY	×		
Internal system device	Function input	FX	○	
	Function output	FY	○	
	Special relay	SM	○	
	Function register	FD	○	
	Special register	SD	○	
Link direct device	Link input	J□\X□	×	
	Link output	J□\Y□	×	
	Link register	J□\W□	×	
	Link special register	J□\SW□	×	
	Link relay	J□\B□	×	
	Link special relay	J□\SB□	×	
Intelligent function module device	Intelligent function module device	U□\G□	○	
Index register	Index register	Z	○	
File register	File register	R	○	
		ZR	○	
Nesting	Nesting	N	×	
Pointer	Pointer	P	×	
	Interrupt pointer	I	×	

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

Category	Device name	Symbol	QCPU (Q mode)/LCPU
Others	SFC block device	BL	×
	SFC transition device	TR	×
Constant	Decimal constant	K	○
	Hexadecimal constant	H	○
	Real constant	E	×

● Device list (FXCPU)

○: Supported ×: Not supported



Category	Device name	Symbol	FXCPU	
Device	Input	X	○	
	Output	Y	○	
	Auxiliary relay	M	○	
	State	S	○	
	Timer	Current value	TN	○
		Contact	TS	○
		Coil	TC	×
	Counter	Current value	CN	○
		Contact	CS	○
		Coil	CC	×
	Data register	D	○	
	Direct specification of buffer memory	U□\G□	○*1	
Index register	Index register	V	○	
		Z	○	
Extension register	Extension register	R	○*2	
Nesting	Nesting	N	×	
Pointer	JUMP or CALL branch	P	×	
	Interrupt pointer	I	×	
Constant	Decimal constant	K	○	
	Hexadecimal constant	H	○	
	Real number constant	E	×	


\*1: Supported by FX3U and FX3UC only.

\*2: Supported by FX3U, FX3UC, FX3G, and FX3GC only.

## Appendix 2.3 Supported instructions

This section explains the instructions supported by the simulation function. Instructions/functions used in Structured projects can also be simulated. However, some instructions may be restricted or not supported. No processing is performed for unsupported instructions (NOP processing).

When an unsupported instruction is used,  is displayed in "Unsupported instructions" on the monitoring status bar. (  Section 17.1.2)

Unsupported devices used in a program and their used locations can be checked by selecting [Debug] => [Instructions Unsupported by Simulation]. (  Section 18.3)

### ■ QCPU (Q mode)/LCPU

#### ● Sequence instructions

Category	Symbol	Restrictions
Contact instruction	LD, LDI, AND, ANI, OR, ORI, LDP, LDF, ANDP, ANDF, ORP, ORF, LDPI, LDFI, ANDPI, ANDFI, ORPI, and ORFI	–
Bond instruction	ANB, ORB, MPS, MRD, MPP, INV, MEP, MEF, EGP, and EGF	–
Output instruction	OUT, OUT T, OUT C, OUT F, OUTH T, SET, RST, SET F, RST F, PLS, PLF, and FF	–
Shift instruction	SFT(P)	–
Master control instruction	MC and MCR	–
End instruction	FEND and END	–
Other instruction	STOP, NOP, NOPLF, and PAGE	–

#### ● Basic instructions

Category	Symbol	Restrictions
Comparison operation instruction	=, <>, >, <=, <, >=, D=, D<>, D>, D<=, D<, D>=, E=, E<>, E>, E<=, E<, E>=, and BKCMP□(P)	–
	\$=, \$<>, \$>, \$<=, \$< and \$>=	Not supported by Basic model QCPU.
	ED=, ED<>, ED>, ED<=, ED<, ED>=, and DBKCMP□(P)	Supported by Universal model QCPU/LCPU only.
Arithmetic operation instruction	CMP(P), DCMP(P), ZCP(P), DZCP(P), ECMP(P), EDCMP(P), EZCP(P), EDZCP(P)	Supported by High-speed Universal model QCPU/LCPU only.
	+(P), -(P), D+(P), D-(P), *(P), /(P), D*(P), D/(P), B+(P), B-(P), DB+(P), DB-(P), B*(P), B/(P), DB*(P), DB/(P), E+(P), E-(P), E*(P), E/(P), BK+(P), BK-(P), INC(P), DEC(P), DINC(P), and DDEC(P)	–
	\$(P)	Not supported by Basic model QCPU.
Data conversion instruction	ED+(P), ED-(P), ED*(P), ED/(P), DBK+(P), and DBK-(P)	Supported by Universal model QCPU/LCPU only.
	BCD(P), DBCD(P), BIN(P), DBIN(P), INT(P), DINT(P), FLT(P), DFLT(P), DBL(P), WORD(P), GRY(P), DGRY(P), GBIN(P), DGBIN(P), NEG(P), DNEG(P), ENEG(P), BKBCD(P), and BKBIN(P)	–
	INTD(P), DINTD(P), FLTD(P), DFLTD(P), EDNEG(P), ECON(P), and EDCON(P)	Supported by Universal model QCPU/LCPU only.
Data transfer instruction	MOV(P), DMOV(P), EMOV(P), \$MOV(P), CML(P), DCML(P), BMOV(P), FMOV(P), XCH(P), DXCH(P), BXCH(P), and SWAP(P)	–
	EDMOV(P) and DFMOV(P)	Supported by Universal model QCPU/LCPU only.
	SMOV(P)	Supported by High-speed Universal model QCPU/LCPU only.
Program branch instruction	CJ, SCJ, JMP, and GOEND	–

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX



Category	Symbol	Restrictions
Program control instruction	PSTOP(P), POFF(P), and PSCAN(P)	Not supported by Basic model QCPU.
Display instruction	LEDR	–
Process control instruction	S.IN, S.OUT1, S.PID, S.PHPL, S.LLAG, S.I, S.D, S.DED, S.FG, S.IFG, S.FLT, S.ENG, S.IENG, S.ABS, S.OUT2, S.MOUT, S.R, S.PIDP, S.SPI, S.IPD, S.BPI, S.HS, S.LS, S.MID, S.AVE, S.LIMIT, S.VLMT1, S.VLMT2, S.ONF2, S.ONF3, S.DBND, S.PGS, S.SEL, S.BUMP, S.AMR, S.SUM, S.TPC, S.ADD, S.SUB, S.MUL, S.DIV, S.SQR, S.>, S.<, S.=, S.>=, S.<=, S.DUTY, S.BC, S.2PID, S.PSUM, S.AT1	Supported by Process CPU, Redundant CPU, and Universal model process CPU only.*1
Other instruction	DUTY, ZRRDB(P), ZRWRB(P), ADRSET(P), ZPUSH(P), ZPOP(P), TIMCHK, WDT(P), TRACE, TRACER, and RBMOV(P)	<ul style="list-style-type: none"> <li>The RBMOV instruction operates as the BMOV instruction.</li> <li>The TRACE, TRACER, and RBMOV(P) are not supported by Basic model QCPU.</li> <li>The RBMOV(P) instruction is not supported by LCPU.</li> </ul>

\*1 : When the program is written to the programmable controller CPU other than Process CPU, Redundant CPU, and Universal model process CPU, a stop error occurs on the CPU from INSTRCT.CODE ERR (error code 4002).

### ● PID control instructions

Category	Symbol	Restrictions
PID Control Data Settings (Incomplete differentiation)	S.PIDINIT, SP.PIDINIT	Not supported by Process CPU.
PID Control (Incomplete differentiation)	S.PIDCONT, SP.PIDCONT	
Operation Stop/Start of Designated Loop No. (Incomplete differentiation)	S.PIDSTOP, SP.PIDSTOP, S.PIDRUN, SP.PIDRUN	
Parameter Change at Designated Loop (Incomplete differentiation)	S.PIDPRMW, SP.PIDPRMW	
PID Control Data Settings	PIDINIT(P)	
PID Control	PIDCONT(P)	
Operation Stop/Start of Designated Loop No.	PIDSTOP(P), PIDRUN(P)	
Parameter Change at Designated Loop	PIDPRMW(P)	
PID Control Loop	PID	Supported by High-speed Universal model QCPU/LCPU only.

### ● SFC control instructions

Category	Symbol	Restrictions
Step operation status check instruction	LD, LDI, AND, ANI, OR, ORI	–
Block operation status check instruction		–
Active step batch readout instruction	MOV(P), DMOV(P), BMOV(P)	–
Block START instruction	SET	–
Block END instruction	RST	–
Block STOP instruction	PAUSE	–
Block restart instruction	START	–
Step START instruction	SET	–
Step END instruction	RST	–

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## ● Multiple CPU dedicated instructions

Category	Symbol	Restrictions
CPU shared memory access instruction	FROM(P), DFRO(P), S(P), TO, TO(P), and DTO(P)	Not supported by LCPU.

## ■ FXCPU

For details of the instructions, refer to the following manual.

☞ FXCPU Structured Programming Manual [Basic & Applied Instruction]

### ● Sequence instructions

Category	Symbol	Restrictions
Contact instruction	LD, LDI, AND, ANI, OR, ORI, LDP, LDF, ANDP, ANDF, ORP, and ORF	-
Bond instruction	ANB, ORB, MPS, MPP, and INV	-
	MEP and MEF	-
Output instruction	OUT, SET, RST, PLS, and PLF	-
Master control instruction	MC and MCR	-
Step ladder instruction	STL and RET	-
Other instruction	END and NOP	-

### ● Application instructions

○: Supported, -: Not supported

Category	Symbol	32-bit instruction	Pulse instruction execution
Program flow	CJ	-	○
	CALL	-	○
	SRET	-	-
	FEND	-	-
	FOR	-	-
	NEXT	-	-
Move and compare	CMP	○	○
	ZCP	○	○
	MOV	○	○
	SMOV	-	○
	CML	○	○
	BMOV	-	○
	FMOV	○	○
	XCH	○	○
	BCD	○	○
BIN	○	○	
Arithmetic and logical operation	ADD	○	○
	SUB	○	○
	MUL	○	○
	DIV	○	○
	INC	○	○
	DEC	○	○
	WAND	○	○
	WOR	○	○
	WXOR	○	○
	NEG	○	○

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

Category	Symbol	32-bit instruction	Pulse instruction execution
Rotation and shift operation	ROR	○	○
	ROL	○	○
	RCR	○	○
	RCL	○	○
	SFTR	-	○
	SFTL	-	○
	WSFR	-	○
	WSFL	-	○
	SFWR	-	○
	SFRD	-	○
Data operation	ZRST	-	○
	DECO	-	○
	ENCO	-	○
	SUM	○	○
	BON	○	○
	MEAN	○	○
	ANS	-	-
	ANR	-	○
	SQR	○	○
	FLT	○	○
Handy instruction	IST	-	-
	SER	○	○
	ABSD	○	-
	INCD	-	-
	TTMR	-	-
	STMR	-	-
	ALT	-	-
	RAMP	-	-
	SORT	-	-
External FX I/O device	ASC	-	-
	FROM	○	○
	TO	○	○
External Device (optional device)	ASCI	-	○
	HEX	-	○
Data transfer 2	ZPUSH	-	○
	ZPOP	-	○



Category	Symbol	32-bit instruction	Pulse instruction execution
Floating point	ECMP	○	○
	EZCP	○	○
	EMOV	○	○
	ESTR	○	○
	EVAL	○	○
	EBCD	○	○
	EBIN	○	○
	EADD	○	○
	ESUB	○	○
	EMUL	○	○
	EDIV	○	○
	EXP	○	○
	LOGE	○	○
	LOG10	○	○
	ESQR	○	○
	ENEG	○	○
	INT	○	○
	SIN	○	○
	COS	○	○
	TAN	○	○
	ASIN	○	○
	ACOS	○	○
	ATAN	○	○
	RAD	○	○
	DEG	○	○
	WSUM	○	○
	WTOB	-	○
	BTOW	-	○
UNI	-	○	
DIS	-	○	
SWAP	○	○	
Real time clock control	TCMP	-	○
	TZCP	-	○
	TADD	-	○
	TSUB	-	○
	HTOS	○	○
	STOH	○	○
	TRD	-	○
	HOUR	○	-
External device	GRY	○	○
	GBIN	○	○
Block data operation	BK+	○	○
	BK-	○	○
	BKCMP=	○	○
	BKCMP>	○	○
	BKCMP<	○	○
	BKCMP<>	○	○
	BKCMP<=	○	○
	BKCMP>=	○	○

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

Category	Symbol	32-bit instruction	Pulse instruction execution
Character string control	STR	○	○
	VAL	○	○
	\$+	-	○
	LEN	-	○
	RIGHT	-	○
	LEFT	-	○
	MIDR	-	○
	MIDW	-	○
	INSTR	-	○
	\$MOV	-	○
Data operation 3	FDEL	-	○
	FINS	-	○
	POP	-	○
	SFR	-	○
	SFL	-	○
Data comparison	LD=	○	-
	LD>	○	-
	LD<	○	-
	LD<>	○	-
	LD<=	○	-
	LD>=	○	-
	AND=	○	-
	AND>	○	-
	AND<	○	-
	AND<>	○	-
	AND<=	○	-
	AND>=	○	-
	OR=	○	-
	OR>	○	-
	OR<	○	-
	OR<>	○	-
	OR<=	○	-
OR>=	○	-	
Data table operation	LIMIT	○	○
	BAND	○	○
	ZONE	○	○
	DABIN	○	○
	BINDA	○	○
Data transfer 3	RBFM	-	-
	WBFM	-	-

## Appendix 2.4 Enable/disable setting of parameter items

Some parameter setting items of GX Works2 are not applicable to the simulation function. The following table shows the parameter setting items applicable to the simulation function. The remote password is not supported.

### ■ QCPU (Q mode)/LCPUCPU

#### ● PLC parameter setting applicability

○: Applicable ×: Not applicable

Parameter	Item	Applicability
PLC Name	Label	×
	Comment	×
PLC System	Timer Limit Setting	○
	RUN-PAUSE Contacts	○
	Latch Data Backup Operation Valid Contact	×
	Remote Reset	Fixed to 'Allow'
	Output Mode at STOP to RUN	○
	Floating Point Arithmetic Processing	Fixed to 'Perform internal arithmetic operations in double precision' <sup>*1</sup>
	Intelligent Function Module Setting (Interrupt Pointer Setting)	×
	Module Synchronization	×
	Built-in CC-Link Setting	×
	Common Pointer No.	○
	Points Occupied by Empty Slot	○
	System Interrupt Settings	×
	High Speed Interrupt Settings	×
	Interrupt Program/Fixed Scan Program Setting	×
	A-PLC Compatibility Setting	×
	Service Processing Setting	Fixed to 'Execute it while waiting for contact scan setting'
PLC Module Change Setting	×	
PLC File	File Register	○
	Transfer to Standard ROM at Latch data backup operation	×
	Comment File Used in a Command	○
	Initial Device Value	○
	File for Local Device	○
	File used for SP.DEVST/S.DEVLD Instruction	×

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

Parameter	Item		Applicability	
PLC RAS	WDT (Watchdog Timer) Setting	WDT Setting	WDT error occurs if 30,000,000 or more instructions are executed during one scan.	
		Initial Execution Monitoring Time	×	
		Low Speed Execution Monitoring Time	×	
	Error Check		○*2	
	Operating Mode When There is an Error		○*3	
	Constant Scanning		○	
	Error History		○	
	Low Speed Program Execution Time		×	
Module Error History Collection		×		
Boot File	Boot Option		×	
	Boot File Setting		×	
Program	Program		○*4	
SFC	SFC Program Start Mode		○	
	Start Conditions		○	
	Output Mode When the Block is Stopped		○	
Device	Device Points		○	
	Latch Start/End (possible to clear with latch clear)		×	
	Latch Start/End (disabled to clear with latch clear)		×	
	Local Device Start/End		○	
	Extended Device Latch Start/End (possible to clear with latch clear)		×	
	Extended Device Latch Start/End (disabled to clear with latch clear)		×	
I/O Assignment Setting	I/O Assignment		○	
	Base Setting		○*5	
	Switch Setting		×	
	Detailed Setting	Error Time Output Mode		×
		PLC Operation Mode at H/W Error		×
		I/O Response Time		×
Control PLC		×		
Multiple CPU Setting	No. of PLC		○	
	Host Station		×	
	Operation Mode		×	
	Multiple CPU Synchronous Startup Setting		×	
	Online Module Change		×	
	I/O Sharing When Using Multiple CPUs		×	
	Communication Area Setting (Refresh Setting)		×	
	Multiple CPU High Speed Transmission Area Setting		○	
	Auto Refresh Setting		×	
Built-in Ethernet Port Setting	IP Address Setting		×	
	Communication Data Code		×	
	Open Setting		×	
	FTP Setting		×	
	Time Setting		×	
Built-in I/O Function Setting	Positioning		×	
	High-speed Counter		×	
	Input Signal		×	
	Output Signal		×	

Parameter	Item	Applicability
Serial Communication	Transmission Speed	x
	Sum Check	x
	Transmission Wait Time	x
	Online Change	x
Acknowledge XY Assignment		x

- \*1 : Internal operations are performed with double precision. However, the processing speed does not change.
- \*2 : When "Check Device Range at Indexing" is selected, an operation error occurs if the file register out of the range is accessed. Other errors are not supported.
- \*3 : Supports "Computation Error" and "Intelligent Module Program Execution Error".
- \*4 : There are restrictions for "Low Speed" and "Fixed Scan" type programs. (☞ Appendix 2.5)
- \*5 : Slots are assigned with a maximum number of slots when "Auto" is selected for "Base Mode".

● Network parameter setting applicability

○: Applicable x: Not applicable

Parameter	Item	Applicability
Network Parameter	Ethernet/CC IE/MELSECNET	x
	CC-Link	x

■ FXCPU

● PLC parameter setting applicability

○: Applicable x: Not applicable

Parameter	Item	Applicability
Memory Capacity	Memory Capacity	○
	Comments Capacity	○
	File Register Capacity	○
	Program Capacity	○
	Special Function Memory Capacity	○
Device	Device	○
PLC Name	Title	x
PLC System (1)	Battery Less Mode	x
	MODEM Initialized	x
	RUN Terminal Input	x
PLC System (2)	Channel Setting	x
	Operate Communication Setting	x
	Protocol	x
	Data Length	x
	Parity	x
	Stop Bit	x
	Transmission Speed	x
	Header	x
	Terminator	x
	Control Line	x
	H/W Type	x
	Control Mode	x
	Sum Check	x
	Transmission Control Procedure	x
	Station Number Setting	x
Time Out Judge Time	x	

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

Parameter	Item	Applicability
Special Function Block (Built-in CC-Link/LT Setting)	Unit Name	x
	Address	x
	Value	x
	Size/Type	x
	Check the identification code before initializing	x
	Identification Code	x
	Transmission Speed	x
	Point Mode	x
	Station Type	x
	I/O Points	x
	Specify Reserved Station	x
Positioning	Bias Speed [Hz]	x
	Max. Speed [Hz]	x
	Creep Speed [Hz]	x
	Zero Return Speed [Hz]	x
	Acceleration Time [ms]	x
	Deceleration Time [ms]	x
	Interruption Input of DVIT Instruction	x
	Rotation Direction Signal	x
	Head Address	x
	Positioning Instruction	x
	Pulse [pls]	x
	Frequency [Hz]	x
	Positioning table settings will not be initialized when the PLC is powered ON	x
Ethernet Port Setting	Channel	x
	IP Address Setting	x
	Communication Data Code	x
	Disable direct connection to MELSOFT	x
	Do not respond to search for CPU on network	x
	Open Setting	x
	Time Setting	x
	Log Record Setting	x

● Network parameter setting applicability

○: Applicable x: Not applicable

Parameter	Item	Applicability
Network Parameter	CC-Link	x

## Appendix 2.5 Restrictions and considerations

This section explains the restrictions and considerations on debugging programs using the simulation function.

### ● QCPU (Q mode)/LCPU

No.	Item	Debugging using the simulation function
1	Time processing	Time processing of the timer instruction/function is performed by assuming that the scan time is 100ms. If the constant scan time is set in parameter, the set constant scan time is used as the scan time.
2	Supported instructions	Some instructions including the data refresh instruction are not supported by the simulation function. Unsupported instructions are processed as NOP. (Supported instructions  Appendix 2.3)
3	Process control instructions	NSTRCT. CODE ERR (error code 4004) occurs when a device which cannot be used for instruction argument is specified. For programmable controller CPU, this error occurs at the timing of CPU power ON/reset, switching from STOP to RUN, or instruction execution. For the simulation function, however, this error occurs only at the timing of instruction execution. Therefore, the error will not occur for the simulation function if the instruction with an inapplicable device is not executed, however, when that program is written to the programmable controller CPU, an error occurs even if the instruction is not executed.
4	Processing time	<p>The time set for constant scan is used for updating the timer current value. If the constant scan is not set, the simulation function performs the same operation as the constant scan time is set to 100ms.</p> <ul style="list-style-type: none"> <li>In the virtual programmable controller, the number of counts per scan of the timer instruction changes depending on the constant scan setting. When the constant scan time is set to 100ms, the count of the 100ms timer is +1 per scan. The count of the same timer is +3 per scan when the constant scan time is set to 300ms.</li> <li>A virtual programmable controller waits for the end of a constant scan after executing one scan. However, if the value of a constant scan is small (10 ms, for example), the virtual programmable controller may not wait and the next scan will be executed. A timer instruction starts counting up after executing one scan; however, if the value of the constant scan is small described as above, the timer instruction will count up faster than the actual time. Additionally, when another software (GT Designer3, for example) keep accessing a virtual programmable controller, a scan time will be longer. Consequently, the scan time and constant scan time value get closer, and the symptom above tends to occur.</li> </ul>
5	Monitoring	<ul style="list-style-type: none"> <li>If [Local device not executed] is selected from "Local device monitoring target selection field" on the monitoring status bar during the monitoring of local devices, the simulation function monitors the devices of the program executed at the end of each scan. However, the function may monitor the devices of the low-speed execution type or fixed scan execution type programs processed at the end of each scan if these types of program are included in the programs for simulation. For details, refer to 6 and 7 in this table.</li> <li>If a program for local device monitoring is specified in the GX Works2 local device monitoring, the simulation function monitors the local devices in the specified program regardless of the existence of a scan execution type program.</li> </ul>

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS



22

SIMULATING OPERATIONS OF EXTERNAL DEVICES


A

APPENDIX

INDEX

No.	Item	Debugging using the simulation function
6	Operation of low-speed execution type programs	<p>In the virtual programmable controller, one low-speed execution type program is always executed after the execution of scan execution type programs. This execution is not affected by the constant scan time and the program execution time set for low-speed execution type programs.</p> <p>The following shows the operating procedure of programs. (The procedure does not change in step operation.)</p>  <p>(Assume that one scan takes 100ms, then five scans takes 500ms. Changing reference time is possible by changing the constant scan setting value. (Refer to No. 3.))</p> <p>All scan execution type programs are executed in each scan, whereas one low-speed execution type program is executed. Therefore, when N number of low-speed execution type programs are set, the execution of all programs completes in N scans.</p>  <ul style="list-style-type: none"> <li>• Since a low-speed execution type program is always executed within one scan in the virtual programmable controller, the monitor value of SM510 remains OFF</li> </ul>



No.	Item	Debugging using the simulation function
7	Operation of fixed scan execution type programs	<ul style="list-style-type: none"> <li>The simulation function measures the time at the end of scan execution type and low-speed execution type programs and judges whether to execute fixed scan execution type programs. The following shows the processing timing of the simulation function when the scan time is set to 100ms and the timing of fixed scan execution type programs is set to 200ms.</li> </ul>  <ul style="list-style-type: none"> <li>When a constant scan is set, a fixed scan execution type program is executed when the total number of times of constant scans is equivalent to the set fixed scan interval. Note that, however, a virtual programmable controller performs wait processing every time the value of a constant scan is accumulated. (Example)                      Constant scan value: 100 ms, fixed scan interval: 1000 ms                      Number of times a virtual programmable controller performed wait processing: <math>1000/100 = 10</math> times                      When a small value (10 ms, for example) is set as a constant scan time, the difference of time between the actual fixed scan interval and that of a virtual programmable controller will be greater because the difference of time among each wait processing is accumulated with the increase of the number of times of wait processing.</li> </ul>
8	Automatic write at the start of simulation	At the start of simulation, PLC parameters and programs registered in the program setting of PLC parameter are written to the virtual programmable controller. The file register specified in "Use the following file" on the <<PLC File>> tab of PLC parameter is automatically created.
9	Interrupt programs	Not supported by the simulation function. Even created, an interrupt program is not processed.
10	Floating point numbers	Since a rounding error always occurs in the operation result of an instruction using floating point numbers, the result does not match with the result of the operation executed on the programmable controller CPU.
11	Using memory card or extended SRAM cassette	The memory card (SRAM) performs in the following capacity according to the programmable controller type. Basic model QCPU, High Performance model QCPU: 4M QnUD(H)CPU, QnUDE(H)CPU : 8M For details of capacity, refer to No. 20 in this table. Memory card (ROM) and memory card (SD) are not supported. For High-speed Universal model QCPU and Universal model process CPU, the simulation function performs the same operation as an extended SRAM cassette (8M) is installed.
12	I/O module	Not supported by the simulation function.
13	Network	Not supported by the simulation function.
14	Intelligent function module (Intelligent parameters)	The virtual programmable controller has a buffer memory area of 64k points for 64 modules to be used for accessing intelligent function modules. This buffer memory can be used for saving and reading data. To use intelligent function modules in the simulation function, the I/O assignment must be set on the <<I/O Assignment>> tab of PLC parameter.
15	Double-precision operation for the floating-point arithmetic processing	The double-precision operation of the simulation function performs the internal operation with double precision and converts the final result to the single precision. The processing speed is not changed even if the double-precision operation is set not to be performed on the <<PLC System>> tab of PLC parameter.
16	Clock data	Clock data can be read out to SD210-SD213 by the clock data read request (SM213). However, the set clock function is not supported.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

No.	Item	Debugging using the simulation function				
17	Intelligent function module	<p>Buffer memory for the intelligent function module is stored with the setting on the &lt;&lt;I/O Assignment&gt;&gt; tab of PLC parameter. Buffer memory (U□\G□) cannot be accessed when the I/O assignment setting is not set.</p> <p>Select 'Intelligent' as the module type and specify the point to create buffer memory in compliance with the specified points.</p> <p>If the module type is not specified, it becomes an empty slot.</p> <p>If the module type is specified but the point is not specified, the point of the specified module becomes equivalent to one specified for "Point Occupied by Empty Slot" on the &lt;&lt;PLC System&gt;&gt; tab of PLC parameter.</p>				
18	Watchdog timer	When the program loops endlessly (when 30,000,000 or more instructions are executed during one scan), a WDT error may occur.				
19	Operating status monitor	SD393, SD395, and SD396 are only supported.				
		○: Supported ×: Not supported				
		Name/Description		Device	Supported/ Not supported	Description
		No. 1 CPU reset flag		SM240	×	Fixed to 'OFF'
		No. 2 CPU reset flag		SM241	×	Fixed to 'OFF'
		No. 3 CPU reset flag		SM242	×	Fixed to 'OFF'
		No. 4 CPU reset flag		SM243	×	Fixed to 'OFF'
		No. 1 CPU error flag		SM244	×	Fixed to 'OFF'
		No. 2 CPU error flag		SM245	×	Fixed to 'OFF'
		No. 3 CPU error flag		SM246	×	Fixed to 'OFF'
		No. 4 CPU error flag		SM247	×	Fixed to 'OFF'
		Multiple CPU system information	Number of multiple CPUs	SD393	○	
			CPU mounting information	SD394	×	Fixed to '0'
			Multiple CPU number	SD395	○	Fixed to '1'
No. 1 CPU operation status	SD396		○			
No. 2 CPU operation status	SD397		×	Fixed to '0'		
No. 3 CPU operation status	SD398		×	Fixed to '0'		
No. 4 CPU operation status	SD399	×	Fixed to '0'			

No.	Item	Debugging using the simulation function																																																																	
20	Available drive volume	<p>Difference of the drive volume may originate, for the file format is different from the actual programmable controller CPU. The following lists the available volume of each drive and the file size in the virtual programmable controller CPU.</p> <ul style="list-style-type: none"> <li>• Available volume for users: Available space for users (free space after formatting)</li> <li>• File size: Minimum size of one file</li> </ul> <p>For details, refer to the User's Manual (Function Explanation, Program Fundamentals) of the CPU module to be used. Memory card (ROM) or memory card (SD) on the drive 2 cannot be used.</p> <table border="1"> <thead> <tr> <th colspan="2" rowspan="2">-</th> <th>Program memory*1</th> <th>Memory card (RAM)</th> <th>Standard RAM</th> <th>Standard ROM*2</th> </tr> <tr> <th>Drive 0</th> <th>Drive 1</th> <th>Drive 3</th> <th>Drive 4</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Basic model QCPU/ High Performance model QCPU</td> <td>Available volume for users</td> <td>1008k bytes</td> <td>4078k bytes</td> <td>256k bytes</td> <td>1008k bytes</td> </tr> <tr> <td>File size</td> <td>2048 bytes</td> <td>1024 bytes</td> <td>1024 bytes</td> <td>2048 bytes</td> </tr> <tr> <td rowspan="2">QnUD(H)CPU, QnUDE(H)CPU (Other than Q50UDEHCPU and Q100UDEHCPU)</td> <td>Available volume for users</td> <td>1040k bytes</td> <td>8172k bytes</td> <td>1280k bytes</td> <td>4096k bytes</td> </tr> <tr> <td>File size</td> <td>512 bytes</td> <td>4096 bytes</td> <td>512 bytes</td> <td>2048 bytes</td> </tr> <tr> <td rowspan="2">QnUD(H)CPU, QnUDE(H)CPU</td> <td>Available volume for users</td> <td>4000k bytes</td> <td>8172k bytes</td> <td>1792k bytes</td> <td>16384k bytes</td> </tr> <tr> <td>File size</td> <td>512 bytes</td> <td>4096 bytes</td> <td>512 bytes</td> <td>2048 bytes</td> </tr> <tr> <td rowspan="2">High-speed Universal model QCPU/Universal model process CPU</td> <td>Available volume for users</td> <td>1040k bytes</td> <td>-</td> <td>9472k bytes</td> <td>4102k bytes</td> </tr> <tr> <td>File size</td> <td>512 bytes</td> <td>-</td> <td>512 bytes</td> <td>2048 bytes</td> </tr> <tr> <td rowspan="2">LCPU</td> <td>Available volume for users</td> <td>1040k bytes</td> <td>-</td> <td>768k bytes</td> <td>2048k bytes</td> </tr> <tr> <td>File size</td> <td>512 bytes</td> <td>-</td> <td>512 bytes</td> <td>2048 bytes</td> </tr> </tbody> </table>	-		Program memory*1	Memory card (RAM)	Standard RAM	Standard ROM*2	Drive 0	Drive 1	Drive 3	Drive 4	Basic model QCPU/ High Performance model QCPU	Available volume for users	1008k bytes	4078k bytes	256k bytes	1008k bytes	File size	2048 bytes	1024 bytes	1024 bytes	2048 bytes	QnUD(H)CPU, QnUDE(H)CPU (Other than Q50UDEHCPU and Q100UDEHCPU)	Available volume for users	1040k bytes	8172k bytes	1280k bytes	4096k bytes	File size	512 bytes	4096 bytes	512 bytes	2048 bytes	QnUD(H)CPU, QnUDE(H)CPU	Available volume for users	4000k bytes	8172k bytes	1792k bytes	16384k bytes	File size	512 bytes	4096 bytes	512 bytes	2048 bytes	High-speed Universal model QCPU/Universal model process CPU	Available volume for users	1040k bytes	-	9472k bytes	4102k bytes	File size	512 bytes	-	512 bytes	2048 bytes	LCPU	Available volume for users	1040k bytes	-	768k bytes	2048k bytes	File size	512 bytes	-	512 bytes	2048 bytes
		-			Program memory*1	Memory card (RAM)	Standard RAM	Standard ROM*2																																																											
				Drive 0	Drive 1	Drive 3	Drive 4																																																												
		Basic model QCPU/ High Performance model QCPU	Available volume for users	1008k bytes	4078k bytes	256k bytes	1008k bytes																																																												
			File size	2048 bytes	1024 bytes	1024 bytes	2048 bytes																																																												
		QnUD(H)CPU, QnUDE(H)CPU (Other than Q50UDEHCPU and Q100UDEHCPU)	Available volume for users	1040k bytes	8172k bytes	1280k bytes	4096k bytes																																																												
			File size	512 bytes	4096 bytes	512 bytes	2048 bytes																																																												
		QnUD(H)CPU, QnUDE(H)CPU	Available volume for users	4000k bytes	8172k bytes	1792k bytes	16384k bytes																																																												
			File size	512 bytes	4096 bytes	512 bytes	2048 bytes																																																												
		High-speed Universal model QCPU/Universal model process CPU	Available volume for users	1040k bytes	-	9472k bytes	4102k bytes																																																												
			File size	512 bytes	-	512 bytes	2048 bytes																																																												
		LCPU	Available volume for users	1040k bytes	-	768k bytes	2048k bytes																																																												
File size	512 bytes		-	512 bytes	2048 bytes																																																														
21	Considerations for Online program change	<p>At Online program change, all instructions are executed regardless of options. Secured steps for Online program change are 500 steps by default at the start up of the simulation function. Secured steps can be changed at "Allocate Memory for 'Online Change' (Write to PLC only)".</p> <p>When changing SFC programs with Online program change, the SFC programs perform an initial start regardless of the setting of the start-up mode of SFC program.</p>																																																																	
22	Program monitoring	In ladder programs, line monitor is available even though the program written to the programmable controller CPU and one being edited are different.																																																																	
23	Initial start for SFC programs	When 'Initial start' is selected for "SFC program start mode" and a set of operations 'STOP→Write to PLC→RUN' is performed, not 'Initial start' but 'Resume start' is adopted if programs written to the programmable controller CPU have no change.																																																																	
24	Considerations for file batch online change	<p>In the following cases, file batch online change cannot be performed.</p> <ul style="list-style-type: none"> <li>• Program memory does not have free space larger than the program to be written.</li> <li>• The maximum number of files has already been stored in program memory.</li> </ul>																																																																	
25	Error codes for online operation errors	For QCPU (Q mode), error codes for online operation errors are equal to those of QnUDE(H)CPU.																																																																	
26	Operation error	For High-speed Universal model QCPU and Universal model process CPU, conditions of operation error occurrence are equal to those of QnUDE(H)CPU.																																																																	
27	When "-0" is specified as the floating-point type real number	No error occurs. (Processed as '0' in operation.)																																																																	

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

No.	Item	Debugging using the simulation function
28	Operation when a negative number is set to 'n' (number of devices/number of transfers) of an instruction	<p>When a negative number is set to 'n' (number of devices/number of transfers) of the following instructions, the instruction is not processed. Since the program may cause an error when it is executed on a programmable controller CPU, review the program if a negative number is set to 'n'.</p> <ul style="list-style-type: none"> <li>• FMOV(P)</li> <li>• WTOB(P)</li> <li>• BTOW(P)</li> <li>• MAX(P)</li> <li>• MIN(P)</li> <li>• SORT</li> <li>• FIFW(P)</li> <li>• FIFR(P)</li> <li>• FPOP(P)</li> <li>• FDEL(P)</li> <li>• FINS(P)</li> </ul>
29	Errors detected in the CALL(P)/RET/FOR/NEXT instruction	For High-speed Universal model QCPU and Universal model process CPU, the content of error detected in the CALL(P)/RET/FOR/NEXT instruction is equal to those of QnUD(H)CPU.
30	Device range check	<p>For the device range check for the instructions to which the variable-length devices are set, R device is checked within the range of ZR device.</p> <p>For Basic model QCPU and High Performance model QCPU, devices are not read/written if devices within and out of the range of R/ZR device are accessed in the device range check for the instructions to which the fixed-length devices are set.</p>
31	Monitoring local devices	<p>If [Local device not executed] is selected from "Local device monitoring target selection field" on the monitoring status bar during the monitoring of local devices, the virtual programmable controller CPU monitors the devices of the program executed at the end of each scan.</p> <p>However, it may monitor the devices of the low-speed execution type or fixed scan execution type programs processed at the end of each scan if these types of program are included in the programs for simulation. If a program for local device monitoring is specified in the local device monitor, the virtual programmable controller CPU monitors the local devices in the specified program regardless of the existence of a scan execution type program.</p>
32	Assigning base units	<p>Slots are assigned with a maximum number of slots when "Auto" is selected for "Base Mode" on the &lt;&lt;I/O Assignment&gt;&gt; tab of PLC parameter.</p> <p>To avoid slots to be assigned with a maximum number of slots, select "Details" and set the number of slots.</p>
33	VAL(P)/DVAL(P)/EVAL(P) instruction	For a high performance model QCPU, when the last character string that is specified for an argument of an instruction is '2EH' ("."), for example '0000.', the operation error (4100) occurs on a programmable controller CPU. But on the simulation function, no error occurs and the instruction is executed.
34	ST, inline ST	<p>"\$" cannot be used as an escape sequence in character string type data.</p> <p>When "\$" is used, the result does not match with the result of the operation executed on the programmable controller CPU.</p>

\*1 : The file size unit of program memory of Universal model QCPU/LCPU is 4 bytes (equal to Q26UDH).

\*2 : The value shown at 'Standard ROM' of Basic model QCPU/High Performance QCPU is one after the writing to the ROM.

● FXCPU

No.	Item	Debugging using the simulation function																							
1	Selection of programmable controller CPU and operation of FX series CPU	In the simulation function of FXCPU, the CPU-specific functions and device range operate according to the specifications of the selected FXCPU. Application instructions can operate in the simulation function even they are not supported by the selected FXCPU. Since a program may contain unsupported instructions after changing its programmable controller type from a top model to a low model, the program may cause a program error when it is written to the FXCPU even it can be performed in the simulation function. For example, even the pulse execution type application instructions are not supported by FX0, FX0s, and FX0n they can be performed in the simulation function. However, a program error may occur due to the unsupported instructions when the program is written to the FXCPU.																							
2	Program check at STOP to RUN	The program check function at STOP to RUN detects a program error only when an MC/MCR exists in the STL instruction or the RET instruction is not input in response to the STL instruction. Note that other problems cannot be detected by the program check function at STOP to RUN, and check them in advance using the program check function of GX Works2.																							
3	Enable/disable setting of parameter items	Some parameter setting items of GX Works2 become disabled in the simulation function even they are set. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Parameter</th> <th>Setting item</th> </tr> </thead> <tbody> <tr> <td rowspan="7">PLC Parameter</td> <td>Memory Capacity</td> <td>All items are enabled</td> </tr> <tr> <td>Device</td> <td>All items are enabled</td> </tr> <tr> <td>PLC Name</td> <td>All items are disabled</td> </tr> <tr> <td>PLC System (1)</td> <td>All items are disabled</td> </tr> <tr> <td>PLC System (2)</td> <td>All items are disabled</td> </tr> <tr> <td>Special Function Block</td> <td>All items are disabled</td> </tr> <tr> <td>Positioning</td> <td>All items are disabled</td> </tr> <tr> <td>Ethernet Port Setting</td> <td>All items are disabled</td> </tr> <tr> <td>Network Parameter</td> <td>CC-Link</td> <td>All items are disabled</td> </tr> </tbody> </table>	Parameter		Setting item	PLC Parameter	Memory Capacity	All items are enabled	Device	All items are enabled	PLC Name	All items are disabled	PLC System (1)	All items are disabled	PLC System (2)	All items are disabled	Special Function Block	All items are disabled	Positioning	All items are disabled	Ethernet Port Setting	All items are disabled	Network Parameter	CC-Link	All items are disabled
Parameter		Setting item																							
PLC Parameter	Memory Capacity	All items are enabled																							
	Device	All items are enabled																							
	PLC Name	All items are disabled																							
	PLC System (1)	All items are disabled																							
	PLC System (2)	All items are disabled																							
	Special Function Block	All items are disabled																							
	Positioning	All items are disabled																							
Ethernet Port Setting	All items are disabled																								
Network Parameter	CC-Link	All items are disabled																							
4	Program memory capacity	The simulation function is performed with the maximum step capacity of each model.																							
5	Watchdog timer	The watchdog timer (D8000) operates in 200ms with all CPUs. The setting value can be changed but the change is not applied to its operation.																							
6	Buffer memory monitor	In the simulation function, the buffer memory of a special extension device operates as a general register which can be read/written by the FROM/TO instruction. It does not have functions specific to the special extension device.																							
7	Variable analog potentiometer	The data register (D8030/D8031), which stores the value of the variable analog potentiometer built in FX0, FX0s, FX0n, FX1s, FX1n, FX3s, and FX3g, operates as a general analog register. Write a value between 0 and 255 and test the operation using GX Works2.																							
8	High-speed counter	The high-speed counter is not supported by the simulation function.																							
9	SORT/SORT2 instruction	The SORT/SORT2 instruction is executed over multiple scans on FXCPU. In the simulation function, however, its execution is always completed in one scan and M8029 (Instruction execution complete) turns ON immediately.																							
10	Latched type device	A latched type device keeps holding its value when the simulation function is in STOP status. It clears its value when the simulation function is ended.																							
11	Non-latch type device	A non-latched type device clears its value when the simulation function is in STOP status or ended.																							
12	Clear PLC Memory	Execute the Clear PLC Memory function to clear and initialize user data written with the simulation function. Execute it too when the operation of the simulation function is not stable.																							
13	Character string constant	Up to 16 characters can be processed as a character string constant in a program. The 17th and later characters are ignored when the length of characters is 17 or more. Example: \$+ "12345678901234567" "abcdefghijklmnpq" D0 When the operation shown above is processed, the following data are stored in the devices starting from D0. D0 to D15 = "1234567890123456abcdefghijklmnp" (The 17th and later characters of each character string constant ("7" and "q") are ignored.)																							

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

No.	Item	Debugging using the simulation function
14	Write to PLC of device memory	The Write to PLC function does not support the device memory listed below. <ul style="list-style-type: none"><li>• Input (X)</li><li>• Output (Y)</li><li>• Special relay (M8000 and later)</li><li>• Special register (D8000 and later)</li></ul>
15	Special Block	Only the buffer memory of the special block is supported by the simulation function.
16	ST, inline ST	"\$" cannot be used as an escape sequence in character string type data. When "\$" is used, an error may occur in the simulation function.

# Appendix 3 ASCII Code Table

Q CPU L CPU Remote Head FX

-		MSD								
		0	1	2	3	4	5	6	7	
		000	001	010	011	100	101	110	111	
LSD	0	0000	NUL	DLE	(SP)	0	@	P	`	p
	1	0001	SOH	DC1	!	1	A	Q	a	q
	2	0010	STX	DC2	"	2	B	R	b	r
	3	0011	ETX	DC3	#	3	C	S	c	s
	4	0100	EOT	DC4	\$	4	D	T	d	t
	5	0101	ENQ	NAK	%	5	E	U	e	u
	6	0110	ACK	SYN	&	6	F	V	f	v
	7	0111	BEL	ETB	'	7	G	W	g	w
	8	1000	BS	CAN	(	8	H	X	h	x
	9	1001	HT	EM	)	9	I	Y	i	y
	A	1010	LF	SUB	*	:	J	Z	j	z
	B	1011	VT	ESC	+	;	K	[	k	{
	C	1100	FF	FS	,	<	L	\(¥)	l	
	D	1101	CR	GS	-	=	M	]	m	}
	E	1110	SO	RS	.	>	N	^	n	~
	F	1111	SI	US	/	?	O	_	o	DEL

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

I  
INDEX

## Appendix 4 Considerations of GX Works2 and Differences with GX Developer

Q CPU L CPU Remote Head FX

This section describes the considerations when using GX Works2 and the differences between GX Works2 and GX Developer.

### Appendix 4.1 Before using GX Works2

Compared with GX Developer, GX Works2 has some differences in supported CPU modules, features, and operability. Please review the following considerations prior to use.

For (Intelligent) indicated in the Reference column, refer to the following manual.

 GX Works2 Version 1 Operating Manual (Intelligent Function Module)

Item to be confirmed	Reference
Supported CPU modules	Appendix 4.2
Unsupported features	Appendix 4.3
Supported project types	Appendix 4.4
Using project functions	
Programming languages supported by each project type	Appendix 4.5
Using Ladder Diagram	
Using Sequential Function Chart	
Using labels	
Using function blocks	
Using device comments	Appendix 4.6
Using device memory	Appendix 4.7
Using device initial values	Appendix 4.8
Using search/replace function	Appendix 4.9
Using online function	Appendix 4.10
Using monitoring/debugging function	Appendix 4.11
Using printing function	Appendix 4.12
Copying saved project data	Appendix 4.13
Using change programmable controller type function	Appendix 4.14
Using program check function	Appendix 4.15
Using IC memory card function	Appendix 4.16
Compatibility with GX Developer	Appendix 4.17
Compatibility with GX IEC Developer	Appendix 4.18
Compatibility with GX Configurator-QP	(Intelligent)
Key operation	Appendix 4.19
Program titles	Appendix 4.20



## Appendix 4.2 Supported CPU modules

The following CPU modules are supported by GX Works2.

Programmable controller series	Programmable controller type
QCPU (Q mode)	Basic model QCPU (Q00J, Q00, Q01)
	High Performance model QCPU (Q02, Q02H, Q06H, Q12H, Q25H)
	Universal model QCPU (Q00UJ, Q00U, Q01U, Q02U, Q03UD, Q03UDE, Q03UDV, Q04UDH, Q04UDEH, Q04UDV, Q06UDH, Q06UDEH, Q06UDV, Q10UDH, Q10UDEH, Q13UDH, Q13UDEH, Q13UDV, Q20UDH, Q20UDEH, Q26UDH, Q26UDEH, Q26UDV, Q50UDEH, Q100UDEH)
	Universal model process CPU (Q04UDPV, Q06UDPV, Q13UDPV, Q26UDPV)
	Remote I/O (QJ72LP25, QJ72BR15)
	Process CPU (Q02PH, Q06PH, Q12PH, Q25PH)
	Redundant CPU (Q12PRH, Q25PRH)
LCPU	L02S, L02S-P, L02, L02-P, L06, L06-P, L26, L26-P, L26-BT, L26-PBT, LJ72GF15-T2, LJ72MS15
FXCPU	FX0S, FX0, FX0N, FX1, FX1S, FX1N, FX1NC, FXU, FX2C, FX2N, FX2NC, FX3S, FX3G, FX3GC, FX3U, FX3UC

The following CPU modules are supported by starting GX Developer from GX Works2.  
For details of using the following CPU modules, refer to Appendix 14.

Programmable controller series	Programmable controller type
QCPU (A mode)	All programmable controller types
QSCPU	All programmable controller types
QnACPU	All programmable controller types
ACPU	All programmable controller types
Motion controller (SCPU)	All programmable controller types
CNC (M6, M7)	All programmable controller types

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## Appendix 4.3 Unsupported features

The following table shows the features that are not supported by GX Works2. Use GX Developer, GX Simulator, or GX Configurator for the following features.

Unsupported feature		Alternate S/W
Debugging function for ladder program	Timing chart monitoring function	GX Simulator
	Serial communication function	
	Device manager function	
Intelligent function module programming function	Protocol FB support	GX Configurator-SC
Device initial value	Device memory registration	GX Developer
Password	Password registration for data in project	
Interaction with GX Explorer	Boot by GX Explorer	
MEDOC print format import	Import in MEDOC print format	
Online	Intelligent module diagnostics from system monitor	GX Developer GX Configurator
Sampling trace	Sampling trace conditionally on step number	GX Developer

\* In addition to the features mentioned above, the following features are not supported by FXCPU.

- Configuration function
- Sampling trace function

## Appendix 4.4 Supported project types

The following table shows the supported project types in GX Works2.

Project type	Description
Simple project	–
Without labels	This is the equivalent of the "Do not use label" project of GX Developer. 1) When a project created in the "Do not use label" of GX Developer is read with GX Works2, the project becomes the Simple project (without labels). 2) When a project created in the Simple project (without labels) of GX Works2 is read with GX Developer, the project becomes the "Do not use label" project.
With labels*1	This is the equivalent of the "Use label" project of GX Developer.*2 1) When a project created in the "Use label" of GX Developer is read with GX Works2, the project becomes the Simple project (with labels). 2) When a project created in the Simple project (with labels) of GX Works2 is read with GX Developer, the project becomes the "Use label" project.
Structured project*3	In GX Works2, 'structured programming' is available. The structured programming proceeds while creating POUs and combining them (registering tasks in the program file). The projects created in 'Structured project' of GX Works2 cannot be read with GX Developer.

\*1 : Not supported by FX0, FX0S, FX0N, FXU, and FX2C.

\*2 : "Use label" projects of GX Developer are not supported by FXCPU.

\*3 : Not supported by FX1.

### ■ Using project functions

Before using the project functions in GX Works2, please review the following considerations.

Function	Description (differences between GX Developer and GX Works2)	
	GX Developer	GX Works2
Protect projects	By installing as 'monitoring only', projects were protected on each personal computer.	By setting projects as 'read-only' with the 'Security' function, project-by-project protection is now available.
Change project types	Project types cannot be changed from "Do not use label" to "Use label".	The following project type changes are now available. 1) Project type change from 'Simple project (without labels)' to 'Simple project (with labels)' 2) Project type change from 'Simple project (with labels)' to 'Structured project'*1
Read GX Developer format projects	–	Selecting [Project] ⇒ [Intelligent Function Module] ⇒ [Read GX Configurator-QP Data] enables GX Configurator-QP format data to be read out. *GX Developer starts and a project is opened when a project of the following CPU types is specified: ACPU, QnACPU, QCPU (A mode), Motion Controller (SCPU), CNC (M6/M7), and Safety CPU.
Read GX Configurator-QP format projects*2	–	Selecting [Project] ⇒ [Intelligent Function Module] ⇒ [Read GX Configurator-QP Data] enables GX Configurator-QP format data to be read out.
Copy data in a project to different projects	It was enabled on the project copy dialog.	Copy and paste is now available on the Navigation window.

\*1 : Direct project type change from 'Simple project (without labels)' to 'Structured project' is not available.

\*2 : Not supported by FXCPU.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

## Appendix 4.5 Programming languages supported by each project type

The following table shows the programming languages that are supported by each project type of GX Works2.

Project type	Supported programming language
Simple project	–
Without labels	Ladder Diagram, Sequential Function Chart (MELSAP3, MELSAP-L)* <sup>1</sup> , Sequential Function Chart (FXCPU)* <sup>2</sup>
With labels	Ladder Diagram, Sequential Function Chart (MELSAP3, MELSAP-L)* <sup>1</sup> , Structured Text* <sup>1</sup>
	<b>Supported program element</b>
	Label, structure, function block
Structured project	Ladder Diagram* <sup>1</sup> , Sequential Function Chart (MELSAP3, MELSAP-L)* <sup>1</sup> , Structured Ladder/FBD, Structured Text
	<b>Supported program element</b>
	Label, structure, function block, function, library

\*1 : Not supported by FXCPU.

\*2 : Not supported by QCPU (Q mode)/LCPU.

The following programming languages are not supported by GX Works2.  
Use GX Developer for the following programming languages.

Unsupported programming language	Description	Alternate S/W
List	<ol style="list-style-type: none"> <li>1) If GX Works2 reads out a program created with lists in GX Developer, it can be displayed or edited as a ladder program.</li> <li>2) If GX Developer reads out a program created with ladder programs in GX Works2, it can be displayed or edited in list program.</li> </ol>	GX Developer

## ■ Using Ladder Diagram

Before using Ladder Diagram in GX Works2, please review the following considerations.

Function	Description (differences between GX Developer and GX Works2)	
	GX Developer	GX Works2
Program giving devices an alias	It was enabled by the 'Alias' function.	Please use 'Label'.
Segment a part of program into POU's (macros)	It was enabled by the 'Macro definition/import' function.	Please use 'Function Block'.
Find/Replace instructions/devices/labels	Find was enabled by directly typing an instruction/device/label in 'Read mode'.	Pressing the <b>[Space]</b> key on the ladder editor allows the simple find.
		The mode can be switched to "Read Mode" by setting the option. Select "Use the Switching Ladder Edit Mode (Read, Write, Monitor, Monitor (Write))" under "Program Editor" ⇒ "Ladder" ⇒ "Ladder Diagram" in the option setting.
Check use status of device/label	It was enabled by the 'Cross Reference List' function and 'List of Used Devices' function.	Please select [Find/Replace] ⇒ [Cross Reference], or [Find/Replace] ⇒ [Device List].
Select the range specified with the drag-and-drop operation	It was enabled by left-clicking the mouse while holding down the <b>[Ctrl]</b> key.	Selecting the frame of the target range enables the drag-and-drop operation.
Select the range starting from the cursor specified by mouse under read status	It was enabled using the mouse while holding down the <b>[Shift]</b> key.	The range can be selected using only the mouse without pressing the <b>[Shift]</b> key.
Verify	-	The verify result window clearly shows the following: 'unmatched area of the programs', 'only verify source contains the program' and 'only verify destination contains the program'.
Register to Watch window	-	Devices/labels in the ladder block at the cursor position are automatically registered to the Watch window. To use this function, set "Setting for Automatic Registration to Watch Window" under "Monitor" ⇒ "Ladder" in the option setting.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

—

INDEX

## ■ Using Sequential Function Chart

Before using Sequential Function Chart (MELSAP3, MELSAP-L) or Sequential Function Chart (FXCPU) in GX Works2, please review the following considerations.

Function	Description (differences between GX Developer and GX Works2)	
	GX Developer	GX Works2
Change block number	It was enabled by the 'copy and paste' function in block list.	Each block data is displayed on the Navigation window, and the block number can be changed in the property of each block data. * Selecting [View] ⇒ [Open SFC Blocklist] can display the block list equivalent to that of GX Developer.
Open a start source block by block start	No corresponding function.	Selecting [View] ⇒ [Back to Start SFC Block] can open it.
Online change using SFC program	No corresponding function.	In SFC program, online change is possible in SFC block unit. Please execute from the menu of "Online Change".
Select the range specified with the drag-and-drop operation	"[Ctrl]+left click" allows the drag and drop operation.	Selecting the frame of the target range enables the drag-and-drop operation.
Select the range starting from the cursor specified by mouse under read status	Select a range by using the mouse while pressing the [Shift] key.	Able to select a range without pressing the [Shift] key.
Display action/transition condition programs	–	Multiple Zooms (operation output/transition condition data) can be simultaneously displayed. * Changing the "Setting of Zoom Display" option can switch the display on a window in the same way as GX Developer.
Copy and paste Ladder programs in Zoom editor	Unable to paste.	Able to paste. In some cases, ladder block could not be displayed correctly.
Monitor SFC diagram editor and Zoom editor	Monitor of two areas was enabled by selecting [Online] ⇒ [Monitor] ⇒ [Start Monitoring] (F3) in either of SFC diagram editor area or action output/transition condition program editor area.	Please select [Online] ⇒ [Monitor] ⇒ [Start Monitoring] (F3) in each of SFC diagram editor and Zoom editor.

## ■ Using labels

Before using labels in GX Works2, please review the following considerations.

Function	Description (differences between GX Developer and GX Works2)	
	GX Developer	GX Works2
Check devices automatically assigned labels	It was enabled by the 'Show assigned device' function of label editor.	Please check on the ladder editor by selecting [View] ⇒ [Device Display].
Automatically assigned devices for input variables, output variables, and input/output variables of function blocks	Devices are automatically assigned in the order that they are registered on the FB variable (FB label) setting window.	Labels registered on the Function/FB Label Setting screen are sorted in the order of 'VAR_INPUT', 'VAR_IN_OUT', 'VAR_OUTPUT', 'VAR', and devices are automatically assigned.
Import/Export device comments to labels	It was enabled by the 'device comment import' function and 'device comment export' function.	Please use the copy and paste on the label editor and device comment editor.
Use pointer type labels	Local pointers were assigned.	Common pointers are now assigned. For projects with labels, points are set by default in "Common Pointer" in the "PLC Parameter" ⇒ "PLC System" setting. (Points set by default differ vary according to the programmable controller type.)
Unusable reserved words for label name	The definition of reserved words are different between GX Developer and GX Works2.	

## ■ Using function blocks

Before using function blocks in GX Works2, please review the following considerations.

Function	Description
Use function blocks created with Ladder Diagram	Function blocks created with ladder can be used for ladder program, Structured Ladder/FBD program, ST program, and SFC program operation outputs. For FXCPU, they can be used for ladder programs only.  * When using function blocks created with Ladder Diagram for ladder, Structured Ladder/FBD or ST programs, select [Tool] ⇒ [Options], and select "Enable calling function block and using inline ST" under "Compile" ⇒ "Basic Setting".
Use function blocks created with Structured Ladder/FBD	Function blocks created with Structured Ladder/FBD can be used for ladder programs, Structured Ladder/FBD programs and ST programs.  * When using function blocks created with Structured Ladder/FBD for ladder programs, select [Tool] ⇒ [Options], and select "Enable calling function block and using inline ST" under "Compile" ⇒ "Basic Setting".
Use function blocks created with ST	Function blocks created with ST can be used for ladder programs, Structured Ladder/FBD programs, and ST programs. For FXCPU, they can be used for Structured Ladder/FBD programs and ST programs.  * When using function blocks created with Structured Text for ladder programs, select [Tool] ⇒ [Options], and select "Enable calling function block and using inline ST" under "Compile" ⇒ "Basic Setting".
Set function block call option	When the VAR_IN_OUT input variable and output variable have different label/device, the input variable value is always equal to the output variable value. This function is not supported by FXCPU.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

—

INDEX

## Appendix 4.6 Using device comments

Before using device comments in GX Works2, please review the following considerations.

Function	Description (differences between GX Developer and GX Works2)	
	GX Developer	GX Works2
Sample comment	Sample comments of special relay/special register were provided in project format.	Comments of special relay/special register and intelligent function module can be imported by the 'Import from Sample Comment' function on the device comment editor.

## Appendix 4.7 Using device memory

Before using the device memory in GX Works2, please review the following considerations.

Function	Description
Device memory display	Multiple device ranges can be displayed on a window.  * By selecting "All Range" when entering a device, all the device range can be displayed on one window in the same way as that of GX Developer.
Copy and past device memory data to Excel	To copy and paste device memory data to Excel, please select [Tool] ⇒ [Read from Excel File] / [Write to Excel File].

## Appendix 4.8 Using device initial values

Before using device initial values in GX Works2, please review the following considerations.

Function	Description (differences between GX Developer and GX Works2)	
	GX Developer	GX Works2
Maximum amount of device initial value data to be created	Only 1 data was able to be created.	Up to 800 data can be created.
Restriction of device number	It was able to create within the range of maximum points for each programmable controller of devices.	It now can be created within the range of PLC parameter device setting.
PLC write/read IC memory card write/read	Only 1 data was able to be read and written.	Selected multiple data can be read and written.



## Appendix 4.9 Using search/replace function

Before using the search/replace function in GX Works2, please review the following considerations.

Function	Description (differences between GX Developer and GX Works2)	
	GX Developer	GX Works2
All Find	The batch search function was not available.	The batch search function is enabled by "All Find".
Specified Range Replacing	The replace function is enabled within a range of the specified step numbers.	The replace function is enabled within the selected range in a ladder program.
Find String	The following were the search targets: 1. Statements 2. Notes	The search targets are added as follows: 1. Statements 2. Notes 3. Device/Label names 4. Device/Label comments 5. Instruction names 6. Data types
Replace Device Device Batch Replace	The following devices could not be specified for "Find Device" or "Replace Device": devices with digit, index setting, or indirect specification.	The following devices can be specified for "Find Device" or "Replace Device": devices with digit, index setting, or indirect specification. Note that, however, one of the specification needs to be a label.
Device Batch Replace	The device batch replace function is enabled by specifying a device for "Find Device" and a label for "Replace Device", and specifying two or more points for the number of points to be replaced.	1 is the only value that can be set for the number of points to be replaced when a label is specified for "Replace Device".
Find/Replace	In ladder editor, find/replace function is executed in line order (from left to right, top to bottom) regardless of the step number.	In ladder editor, find/replace function is executed in step number order.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

## Appendix 4.10 Using online function

Before using the online function in GX Works2, please review the following considerations.

Function	Description (differences between GX Developer and GX Works2)	
	GX Developer	GX Works2
Connection destination setting	A project was able to contain only 1 'transfer setup' information.	A project can contain multiple pieces of 'connection destination' information. To change 'connection destination' information, select 'Connection Destination' on the Navigation window.
Data write/read for intelligent function module	Data write/read was not able to be executed for CPU modules and intelligent function modules at once.	Selecting [Online] ⇒ [Write to PLC], allows simultaneous data write for CPU modules and intelligent function modules. Selecting [Online] ⇒ [Read from PLC], allows simultaneous data read for CPU modules and intelligent function modules.
Flash ROM data write of CPU module	It was enabled by the 'PLC write (Flash ROM)' function.	The 'PLC write (Flash ROM)' function is now integrated in the 'Write to PLC' function. Please select [Online] ⇒ [Write to PLC].
<u>Remote Operation</u> screen <u>PLC Diagnostics</u> screen <u>System Monitor</u> screen	–	Selecting [Online] ⇒ [Remote Operation] and [Diagnostics] ⇒ [System Monitor] / [PLC Diagnostics] can display the module image and the programmable controller CPU operation status is now easy to see. The remote operation, memory operation, and clock setup can be started from the <u>PLC Diagnostics</u> screen.
System Monitor	As the system monitoring function was not supported by LCPU, [Diagnostics] ⇒ [System Monitor] could not be selected.	The system monitoring function has been supported by LCPU and the module image can be displayed by selecting [Diagnostics] ⇒ [System Monitor].
PLC Diagnostics	The continuation error information display function of "PLC Diagnostics" was not supported by LCPU.	Continuation error information can be displayed using the "PLC Diagnostics" function of LCPU.
Register/Cancel Display Module Menu	Registration /cancellation function of display module menus was not supported by LCPU.	Registration/cancellation function of display module menus has been supported by LCPU. Select [Online] ⇒ [Register/Cancel Display Module Menu].
Read from PLC	–	Symbolic information in GX Developer format does not include SFC programs. Please read on the 'Simple project (without labels)'. If symbolic information of GX Developer or GX IEC Developer is read out, the project becomes uncompiled. The Read from PLC function in Simple projects (with labels) and Structured projects is supported by FXCPU of the following models only. For FX3U/FX3UC (Version 3.00 or later) GX Developer starts and a new project is created with data read from the programmable controller CPU when a programmable controller series of the following CPU types is specified: ACPU, QnACPU, QCPU (A mode), Motion Controller (SCPU), CNC (M6/M7), and Safety CPU.
Write to PLC	–	Writing symbolic information to programmable controller CPU is supported by FXCPU of the following models only. For FX3U/FX3UC (Version 3.00 or later)

## Appendix 4.11 Using monitoring/debugging function

Before using the monitoring/debugging function in GX Works2, please review the following considerations.

Function	Description
Entry data monitoring	The 'entry data monitoring' function is now a dockable window as a 'watch' function so that it can be displayed without overlapping with the program editor.
	Device/label is now enabled to be entered by dragging and dropping from the program editor and the ON/OFF status of bit device and current values of word device can be modified on the monitoring window.
Device batch monitoring Buffer batch monitoring	The 'device batch monitor' and 'buffer memory batch monitoring' functions are now integrated to realize the same operability.
	ON/OFF status of bit device and current values of word device can be modified on the monitoring window.
Debugging function*1	The debugging function can be executed by starting the simulation function.
	The break point setting and the break device setting functions become dockable windows, and they can be displayed without overlapping the program editor.
	The debugging function such as step execution can be executed from the "Debug Function" toolbar.
	The STEP-RUN switch is not displayed on the GX Simulator2 screen. The operating status of the simulation switches to STEP-RUN automatically by executing the debugging from the "Debug Function" toolbar.
Monitor Condition Setting/Monitor Stop Condition Setting	The <u>Monitor Stop Condition</u> screen cannot be closed while setting the monitor stop condition.
	The 'monitor stop condition' function cannot be performed when the monitoring function is not being executed.
	The <u>Monitor Condition Setting</u> screen or the <u>Monitor Stop Condition Setting</u> screen cannot be opened when the following function is being performed or the screen is being opened.
	<ul style="list-style-type: none"> <li>• Online program change/program memory transfer</li> <li>• Intelligent function module monitoring</li> <li>• Program list monitoring</li> <li>• Interrupt program list monitoring</li> <li>• SFC all block batch monitoring</li> <li>• The <u>Modify Value</u> screen</li> <li>• The <u>Forced Input Output Registration/Cancellation</u> screen</li> <li>• Sampling trace</li> <li>• The <u>CC-Link Diagnostics</u> screen</li> </ul>
	The <u>Monitor Condition Setting</u> screen or the <u>Monitor Stop Condition Setting</u> screen cannot be opened in MELSAP-L.

\*1 : Not supported by FXCPU.

## Appendix 4.12 Using printing function

Before using the printing function in GX Works2, please review the following considerations.

Function	Description
Additional information print such as statement and device comment	For the Print Window function, displayed image is subject to print/print window preview. To print with additional information such as statement and device comment, please put the desired information on the screen and then select [Project] ⇒ [Print Window] / [Print Window Preview].

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

I

INDEX

## Appendix 4.13 Copying saved project data

Before copying project data saved in GX Works2, please review the following considerations.

Function	Description (differences between GX Developer and GX Works2)	
	GX Developer	GX Works2
Copy saved project data	Save project data was able to be copied by copying files under the project name folder.	<p>Please copy all the workspace name folders and "workspacelist.xml" created in the same hierarchy as the workspace name folders.</p> <p>* When only workspace name folders or project name folders are copied, it is enabled to open the project in the copy destination. However, if saving after editing, the workspace name and the project name need to be specified again.</p> <p>A project data can be copied by saving data as a single project with the "Save as a Single File Format Project" function on the <u>Save As</u> screen.</p>

## Appendix 4.14 Using PLC type change function

Before using the PLC type change function in GX Works2, please review the following considerations.

Function	Description (differences between GX Developer and GX Works2)	
	GX Developer	GX Works2
Use PLC type change function	Intelligent function module data could not be transmitted.	Intelligent function module data can be transmitted in PLC type conversion of Q series PLC and L series PLC.

## Appendix 4.15 Using program check function

Before using the program check function in GX Works2, please review the following considerations.

Function	Description (differences between GX Developer and GX Works2)	
	GX Developer	GX Works2
Program check	Programs which follow the END instruction and do not affect sequence control were checked.	Programs which affect sequence control up to the END instruction are checked. Programs which follow the END instruction and do not affect sequence control are not checked.
	The duplicated coil error occurs when the same local label is used at two or more locations.	Since the same local label can be used at two or more locations when the function block is called with the same instance, the duplicated error does not occur.

## Appendix 4.16 Using IC memory card function

Before using the IC memory card function in GX Works2, please review the following considerations.

Function	Description (differences between GX Developer and GX Works2)	
	GX Developer	GX Works2
Read IC Memory Card	Symbolic information could not be read.	Symbolic information can be read.
Write IC Memory Card	Symbolic information could not be written.	Symbolic information can be written.
	Passwords could not be set for LCPUs.	Passwords can be set for LCPUs.

## Appendix 4.17 Compatibility with GX Developer

For the compatibility between GX Developer and GX Works2, please review the following considerations.

An error may occur at a compilation when a project which contains ST programs created in GX Developer is opened in GX Works2. For modifying instructions which cause a compilation error, refer to Appendix 19.

Function	Description
Open other project	Before opening a GX Developer "Use label" project of which a program and function block have the same name, please change the data name in GX Developer.
	Function names of Structured Text are different between GX Developer and GX Works2. Please compile and correct errors. Alternatively, select "Use Dedicated Instruction for GX Developer, GX IEC Developer" under [Tool] ⇒ [Options] ⇒ "Project" ⇒ "Common Setting" ⇒ "Other Project Dedicated Instruction Setting".
	For a program which contains a utilized FB, the compiled program is not identical with the program compiled with GX Developer. To conform the compiled program to that compiled with GX Developer, select [Tool] ⇒ [Options] ⇒ "Compile" ⇒ "Basic Setting" and clear "Enable calling function block and using inline ST " in "Function Block Call".
	For Q00UJ, Q00U, and Q01U projects, a compilation error may occur if the string type is used for the Boolean expression (conditional expression) in the conditional syntax or iteration syntax of the ST program. When an error occurs, create a ladder program with a string comparison function block whose operation result is a Boolean value, and correct the program by using this operation result for the failed Boolean expression (conditional expression) in the conditional syntax or iteration syntax.
	The setting of 'steps secured for Online program change' which is set on the [Read from PLC]/[Write to PLC] screen of GX Developer is not set. Set the setting of 'steps secured for Online program change' on the [Read from PLC]/[Write to PLC] screen after performing the Open Other Project function in GX Works2.
	Local labels of timer, counter, retentive timer, and pointer cannot be used for function blocks of ladder program to be utilized in an ST program. Change local labels to global labels.
	Before opening a project in which constants are set to the structures, delete the constants with GX Developer.
Export to GX Developer format file	Target projects are: 1) Simple project (without labels) 2) Simple project (with labels)*1 However, SFC programs can only be saved when the blocks are converted or programs are compiled.
	To execute, the following requirements must not be satisfied in the global label settings. 1) No device is set. 2) The lengths of label name exceeds 16 characters. 3) Label name contains a device name or reserved word. 4) An invalid character is used. 5) Data type that is not supported by GX Developer is used. 6) A value that is not constant is used in the constant.
	The projects that does not correspond to the following condition can be saved. • The label which is declared with VER_RETAIN is used.
	Data registered to the global label is set as "Auto External" for all the local labels.
	Projects which include inline structured text cannot be saved in GX Developer format.
	Projects which include ladder programs whose function block calls function block cannot be saved in GX Developer format.

\*1 : Not supported by FXCPU.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

## Appendix 4.18 Compatibility with GX IEC Developer

For the compatibility between GX IEC Developer and GX Works2, please review the following considerations. Projects for FXCPU created with GX IEC Developer cannot be opened with GX Works2.

Function	Description
Open other project	Function names of Structured Text are different between GX IEC Developer and GX Works2. Please compile and correct errors.
User library	Before using GX IEC Developer user libraries with passwords enabled, please disable the passwords in GX IEC Developer.

## Appendix 4.19 Key operation

This section explains the differences of key operation between GX Developer and GX Works2.

Function		Description	Shortcut key		
			GX Developer	GX Works2	
Edit	Read mode	Change to the read mode.	<b>[Shift]</b> + <b>[F2]</b>	<b>[Shift]</b> + <b>[F2]</b> *1	
	Write mode	Change to the write mode.	<b>[F2]</b>	<b>[F2]</b> *1	
Find/ Replace	Cross reference	Display the cross reference.	–	<b>[Ctrl]</b> + <b>[E]</b>	
	Device List	Display the device list.	–	<b>[Ctrl]</b> + <b>[D]</b>	
Convert Block	Block conversion (SFC block being edited)	Convert the SFC block being edited.	<b>[F4]</b>	<b>[Ctrl]</b> + <b>[Alt]</b> + <b>[F4]</b>	
View	Project data list	Switch display/non-display of project data list.	<b>[Alt]</b> + <b>[O]</b>	–	
	Switch between project data list and window	Switch the project data list and each window.	<b>[Alt]</b> + <b>[7]</b>	–	
	Switch ladder program/list	Switch the ladder/list screen.	<b>[Alt]</b> + <b>[F1]</b>	–	
Online	Monitor	Start Monitor (all windows)	Execute the program monitoring for all the opened programs.	<b>[Ctrl]</b> + <b>[F3]</b>	–
		Monitor (write mode)	Change to the write mode during program monitoring.	<b>[Shift]</b> + <b>[F3]</b>	<b>[Shift]</b> + <b>[F3]</b> *1
		Stop monitor (all windows)	Stop the program monitoring for all the opened programs.	<b>[Ctrl]</b> + <b>[Alt]</b> + <b>[F3]</b>	–
	Debug	Device test	Execute the device forced ON/OFF or the current value modification.	<b>[Alt]</b> + <b>[1]</b>	–
		Skip execution	Run selected sequence programs in skip execution.	<b>[Alt]</b> + <b>[2]</b>	–
		Partial execution	Run sequence programs partially.	<b>[Alt]</b> + <b>[3]</b>	–
		Step run	Run the programmable controller CPU in step run.	<b>[Alt]</b> + <b>[4]</b>	–
Remote operation	Perform remote operations.	<b>[Alt]</b> + <b>[6]</b>	–		

\*1 : In GX Works2, select "Use the Switching Ladder Edit Mode (Read, Write, Monitor, Monitor (Write))" under "Program Editor" ⇒ "Ladder" ⇒ "Ladder Diagram" in the option setting to switch the read mode/write mode of the ladder editor and the SFC diagram editor.

## Appendix 4.20 Program titles

---

A title of data created under each execution type of Program Setting has the equivalent function to program titles of GX Developer. Titles can be set on the Property screen of each data. The title being set is displayed on the Online Data Operation screen and written to/read from programmable controller CPU along with the program.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## Appendix 5 Compatibility with Projects Created with Existing Applications

Q CPU L CPU Remote Head FX

This section explains the compatibility of GX Works2 projects with projects created with existing applications.

### Appendix 5.1 Application compatibility

#### ■ Reading projects created with existing application to GX Works2

##### ● Reading projects created with GX Developer and IEC Developer

The following table shows the applicability of reading project files created with existing applications to GX Works2.

Projects and data created with the CPU types or programming languages not supported by GX Works2 cannot be read.

When ST programs created with GX Developer are read to GX Works2, they are opened as Structured projects with Version 1.08J or earlier and opened as Simple projects with Version 1.12N or later.

(For the method for reading projects created with existing applications, refer to the following section.

☞ Section 4.7)

##### ● GX Developer

○: Applicable  
△: Applicable with restrictions

Programmable controller type	Application	Reading applicability
Basic model QCPU	GX Developer Version 8.00A or later	△*1
High Performance model QCPU, Q12PH, Q25PH	GX Developer Version 8.68W or later	△*1
Q02PH, Q06PH	GX Developer Version 8.17T or later	△*1
Q12PRH, Q25PRH	GX Developer Version 8.45X or later	△*1
Q03UD, Q04UDH, and Q06UDH	GX Developer Version 8.48A or later	△*1
Q02U	GX Developer Version 8.62Q or later	△*1
Q13UDH and Q26UDH	GX Developer Version 8.76E or later	△*1
Q03UDE, Q04UDEH, Q06UDEH, Q13UDEH, and Q26UDEH	GX Developer Version 8.88S or later	△*1
Q00UJ, Q00U, Q01U, Q10UDH, Q10UDEH, Q20UDH, and Q20UDEH	GX Developer Version 8.25B or later	○
L02, L26-BT	GX Developer Version 8.72A or later	○
FX3U and FX3UC	GX Developer Version 8.00A or later	○
FX3G		
FX0, FX0s, FX0N, FX1, FXU, FX2C, FX1S, FX1N, FX1NC, FX2N, and FX2NC		

\*1 : When MELSAP-L format SFC programs are read with Version 1.24A or earlier, they are opened in the MELSAP3 format.




● GX IEC Developer

○: Applicable

Programmable controller type	Application	Reading applicability
Basic model QCPU High Performance model QCPU, Q12PH, Q25PH	GX IEC Developer Version 7.00A or later	○
Q03UD, Q04UDH, and Q06UDH	GX IEC Developer Version 7.03D	○
Q02U	GX IEC Developer Version 7.03D	○
Q13UDH and Q26UDH	GX IEC Developer Version 7.03D	○
Q03UDE, Q04UDEH, Q06UDEH, Q13UDEH, and Q26UDEH	GX IEC Developer Version 7.03D	○

● Reading projects created with GX Configurator

GX Configurator flash ROM setting saved files (\*.UMD) cannot be read in GX Works2.  
 To use GX Configurator flash ROM setting saved files in GX Works2, write the data to the intelligent function module with GX Configurator, and then read the data using GX Works2.  
 (Reading intelligent function module data  Section 15.1.4)

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

## ■ Reading projects created with GX Works2 to existing applications

### ● Reading projects using GX Developer and IEC Developer

Projects created with GX Works2 can be read to GX Developer by saving them using "Export to GX Developer Format File". (☞ Section 4.7)

Reading projects to GX IEC Developer or non-Windows applications such as GPPQ is not possible.

When reading projects with GX Developer, application versions that can read projects differ according to the programmable controller type of the project. The following table shows the relation between the programmable controller types of project and the read-applicable versions.

○: Applicable  
△: Applicable with restrictions

Programmable controller type	Application	Reading applicability
Basic model QCPU High Performance model QCPU, Q12PH, Q25PH	GX Developer Version 8.00A or later	△*1
Q02PH, Q06PH	GX Developer Version 8.68W or later	△*1
Q12PRH, Q25PRH	GX Developer Version 8.17T or later	△*1
Q03UD, Q04UDH, and Q06UDH	GX Developer Version 8.45X or later	△*1
Q02U	GX Developer Version 8.48A or later	△*1
Q13UDH and Q26UDH	GX Developer Version 8.62Q or later	△*1
Q03UDE, Q04UDEH, Q06UDEH, Q13UDEH, and Q26UDEH	GX Developer Version 8.68W or later	△*1
Q00UJ, Q00U, Q01U, Q10UDH, Q10UDEH, Q20UDH, and Q20UDEH	GX Developer Version 8.76E or later	△*1
L02, L26-BT	GX Developer Version 8.88S or later	△*1
FX3U and FX3UC	GX Developer Version 8.25B or later	○
FX3G	GX Developer Version 8.72A or later	○
FX0, FX0S, FX0N, FX1, FXU, FX2C, FX1S, FX1N, FX1NC, FX2N, and FX2NC	GX Developer Version 8.00A or later	○

\*1: For the restrictions in reading, refer to "SW□D5C-GPPW Compatibility" of the GX Developer Operating Manual.

### ● Reading projects using GX Configurator

As projects cannot be saved in formats such as the GX Configurator-QP format and the GX Configurator flash ROM setting saved file format (\*.UMD) in GX Works2, data set in GX Works2 cannot be read using GX Configurator.

To use GX Works2 data in GX Configurator, write the data to the intelligent function module with GX Works2, and then read the data using GX Configurator.

(Writing intelligent function module data ☞ Section 15.1.4)

## Appendix 6 Compatibility of Data Read from Programmable Controller CPU

Q CPU L CPU Remote Head FX

This section explains the compatibility between the data written on the programmable controller CPU using GX Developer or GX IEC Developer and the data read using GX Works2.

### Appendix 6.1 Application compatibility

#### ■ Reading data written on the programmable controller CPU using existing applications to GX Works2

The following table shows the applicability of reading data written on the programmable controller CPU using existing applications to GX Works2.

Data created with the CPU types or programming languages not supported by GX Works2 cannot be read.

##### ● GX Developer

○: Applicable  
△: Applicable with restrictions

Programmable controller type	Application	Reading applicability
Basic model QCPU High Performance model QCPU, Q12PH, Q25PH	GX Developer Version 8.00A or later	△*1
Q02PH, Q06PH	GX Developer Version 8.68W or later	△*1
Q12PRH, Q25PRH	GX Developer Version 8.17T or later	△*1
Q03UD, Q04UDH, and Q06UDH	GX Developer Version 8.45X or later	△*1
Q02U	GX Developer Version 8.48A or later	△*1
Q13UDH and Q26UDH	GX Developer Version 8.62Q or later	△*1
Q03UDE, Q04UDEH, Q06UDEH, Q13UDEH, and Q26UDEH	GX Developer Version 8.68W or later	△*1
Q00UJ, Q00U, Q01U, Q10UDH, Q10UDEH, Q20UDH, and Q20UDEH	GX Developer Version 8.48A or later	△*1
L02, L26-BT	GX Developer Version 8.88S or later	△*1
FX3U and FX3UC	GX Developer Version 8.25B or later	○
FX3G	GX Developer Version 8.72A or later	○
FX1S, FX1N, FX1NC	GX Developer Version 6.00A or later	○
FX0, FX0S, FX0N, FX1, FXU, FX2C, FX2N, and FX2NC	GX Developer Version 2.00A or later	○

\*1 : When MELSAP-L format SFC programs are read with Version 1.24A or earlier, they are opened in the MELSAP3 format.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

## ● GX IEC Developer

○: Applicable

Programmable controller type	Application	Reading applicability
Basic model QCPU High Performance model QCPU, Q12PH, Q25PH	GX IEC Developer Version 7.00A or later	○
Q03UD, Q04UDH, and Q06UDH	GX IEC Developer Version 7.03D	○
Q02U	GX IEC Developer Version 7.03D	○
Q13UDH and Q26UDH	GX IEC Developer Version 7.03D	○
Q03UDE, Q04UDEH, Q06UDEH, Q13UDEH, and Q26UDEH	GX IEC Developer Version 7.03D	○

## ■ Reading data written on the programmable controller CPU using GX Works2 to existing applications

The following table shows the applicability of reading data written on the programmable controller CPU using GX Works2 to existing applications.

Data created with the CPU types or programming languages not supported by existing applications cannot be read.

### ● GX Developer

△: Applicable with restrictions

Programmable controller type	Application	Reading applicability
Basic model QCPU High Performance model QCPU, Q12PH, Q25PH	GX Developer Version 8.00A or later	△*1, *2, *3
Q02PH, Q06PH	GX Developer Version 8.68W or later	△*1, *2, *3
Q12PRH, Q25PRH	GX Developer Version 8.17T or later	△*1, *2, *3
Q03UD, Q04UDH, and Q06UDH	GX Developer Version 8.45X or later	△*1, *2, *3
Q02U	GX Developer Version 8.48A or later	△*1, *2, *3
Q13UDH and Q26UDH	GX Developer Version 8.62Q or later	△*1, *2, *3
Q03UDE, Q04UDEH, Q06UDEH, Q13UDEH, and Q26UDEH	GX Developer Version 8.68W or later	△*1, *2, *3
Q00UJ, Q00U, Q01U, Q10UDH, Q10UDEH, Q20UDH, and Q20UDEH	GX Developer Version 8.48A or later	△*1, *2, *3, *4
L02, L26-BT	GX Developer Version 8.88S or later	△*1, *2, *3
FX3U and FX3UC	GX Developer Version 8.25B or later	△*1, *4
FX3G	GX Developer Version 8.72A or later	△*1
FX3s	GX Developer Version 8.72A or later*5	△*1
FX1S, FX1N, FX1NC	GX Developer Version 6.00A or later	△*1
FX0, FX0S, FX0N, FX1, FXU, FX2C, FX2N, and FX2NC	GX Developer Version 2.00A or later	△*1

\*1 : Only execution programs can be read when programs written in Simple project (with labels) or Structured project are read from the programmable controller CPU.

They can be displayed/edited in ladder program or list.

\*2 : Programs cannot be read to GX Developer Version 8.03D or later if projects are opened with the setting of "Use label". To enable reading of programs to GX Developer Version 8.03D or later, create projects without the "Use label" setting.

\*3 : When Structured Ladder/FBD or ST programs are read from a programmable controller CPU using existing applications, there may be cases where ladder programs cannot be restored. Be sure to check the programs after they have been read from the programmable controller CPU using existing applications. When programs are read from a programmable controller CPU using GX Developer, ladder blocks which cannot be displayed as ladder programs are displayed in yellow.

\*4 : When a project including a block password to which the execution program protection setting was enabled is written, the execution program cannot be read.

\*5 : When reading the data written on FX3s using GX Developer, use FX3G project of GX Developer.

## ● GX IEC Developer

△: Applicable with restrictions

Programmable controller type	Application	Reading applicability
Basic model QCPU High Performance model QCPU, Q12PH, Q25PH	GX IEC Developer Version 7.00A or later	△*1
Q03UD, Q04UDH, and Q06UDH	GX IEC Developer Version 7.03D	△*1
Q02U	GX IEC Developer Version 7.03D	△*1
Q13UDH and Q26UDH	GX IEC Developer Version 7.03D	△*1
Q03UDE, Q04UDEH, Q06UDEH, Q13UDEH, and Q26UDEH	GX IEC Developer Version 7.03D	△*1
FX0, FX0S, FX0N, FX1, FXU, FX2C, FX2N, and FX2NC	GX Developer Version 2.00A or later	△*1

\*1 : Only execution programs can be read.  
They can be displayed/edited as MELSEC-IL programs.

## Appendix 6.2 Data compatibility

### ■ Reading data written on the programmable controller CPU using GX Developer to GX Works2

The following table shows the reading applicability depending on the label setting when reading data written on the programmable controller CPU using GX Developer to GX Works2. Data created with the CPU types or programming languages not supported by GX Works2 cannot be read.

#### ● Reading data with labels

This function is not supported by FXCPU.

○: Applicable  
 △: Applicable with restrictions  
 ×: Not applicable

Data		Project type of GX Works2		
		Simple project		Structured project
		Without labels	With labels	
Label program	Label program (GX Developer format symbolic information)	×	△*3,*5	△*3,*5
Program	Ladder program	△*4	×*5	×*5
	SFC program	△*1,*2	×*3	×*3
	ST Program	△*4	×*5	×*5
Parameter	PLC/Network/Remote password/Redundant parameter	○	○	○
	Intelligent function module parameter	○	○	○
Device comment	Common comment (Global device comment)	○	○	○
	Comment by program (Local device comment)	○	○	○
Device memory	Device memory	○	○	○
Device initial value	Device initial value	○	○	○

- \*1 : When MELSAP-L format SFC programs are read with Version 1.24A or earlier, they are opened in the MELSAP3 format.
- \*2 : Block statements written with GX Developer are read as SFC block comments in GX Works2.
- \*3 : SFC programs are not included in label programs of GX Developer. Use 'Simple project (without labels)' when reading programs in GX Works2.
- \*4 : When a ladder program or ST program, in which labels of GX Developer are used, is read in Simple project (without labels), it becomes a ladder program without labels. By editing this ladder program and writing it to a programmable controller CPU again, this program becomes inconsistent with the label program written to a programmable controller CPU using GX Developer.
- \*5 : Ladder programs and ST programs, in which labels of GX Developer are used, are included in label programs. Read GX Developer format symbolic information when reading programs in GX Works2.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

● Reading data without labels (QCPU (Q mode))

○: Applicable  
 △: Applicable with restrictions  
 ×: Not applicable

Data		Project type of GX Works2		
		Simple project		Structured project
		Without labels	With labels	
Program	Ladder program	○	×	×
	SFC program	△*1, *2	×	×
Parameter	PLC/Network/Remote password/ Redundant parameter	○	○	○
	Intelligent function module parameter	○	○	○
Device comment	Common comment (Global device comment)	○	○	○
	Comment by program (Local device comment)	○	○	○
Device memory	Device memory	○	○	○
Device initial value	Device initial value	○	○	○

\*1 : When MELSAP-L format SFC programs are read with Version 1.24A or earlier, they are opened in the MELSAP3 format.

\*2 : Block statements written with GX Developer are read as SFC block comments in GX Works2.

● Reading data without labels (FXCPU)

○: Applicable  
 ×: Not applicable

Data		Project type of GX Works2		
		Simple project		Structured project
		Without labels	With labels	
Program	Program	○	×	×
Parameter	PLC parameter	○	×	×
Device comment	Common comment (Global device comment)	○	×	×
	Comment by program (Local device comment)	×	×	×
Device memory	Device memory	○	×	×



## ■ Reading data written on the programmable controller CPU using GX IEC Developer to GX Works2

The following table shows the applicability of reading data written on the programmable controller CPU using GX IEC Developer to GX Works2.

Data created with the CPU types or programming languages not supported by GX Works2 cannot be read.

### ● QCPU (Q mode)

○: Applicable  
 △: Applicable with restrictions  
 ×: Not applicable

Data		Project type of GX Works2		
		Simple project		Structured project
		Without labels	With labels	
Parameter	PLC parameter	○	○	○
	Network parameter	○	○	○
	Intelligent function module parameter	○	○	○
Program	Program file	○*1	×	×
Symbolic information (Symbolic data)	-	×	×	△*2

\*1: Only actual programs are read.

\*2: Programs which contain data not supported by GX Works2 cannot be read.

### ● FXCPU

○: Applicable  
 ×: Not applicable

Data		Project type of GX Works2	
		Simple project (Without labels)	Structured project
Parameter	PLC parameter	○	×
Program	Program file	○	×
Symbolic information (Symbolic data)	-	×	×

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## ■ Reading data written on the programmable controller CPU using GX Works2 to existing applications

The following table shows the applicability of reading data written on the programmable controller CPU using GX Works2 to existing applications.

Data created with the CPU types or programming languages not supported by existing applications cannot be read.

### ● GX Developer

○: Applicable  
 △: Applicable with restrictions  
 ×: Not applicable  
 -: No corresponding data

Data	Existing applications			
	QCPU (Q mode)	LCPU	FXCPU	
Symbolic information	–	×	×	
Program	Program/Program file	△ <sup>*1,*2,*3</sup>	△ <sup>*1,*2,*3</sup>	△ <sup>*1,*3</sup>
	SFC program/SFC program file	△ <sup>*2,*4</sup>	△ <sup>*2,*4</sup>	△ <sup>*5</sup>
Parameter	PLC parameter	○	○	△ <sup>*6</sup>
	Network parameter	○	○	×
	Remote password	○	○	-
	Redundant parameter	○	-	-
	Intelligent function module parameter	○	○	-
Device comment	Global device comment (Common comment)	○	○	○
	Local device comment (Comment by program)	○	○	×
Device memory	Device memory	○	○	○

\*1 : Only execution programs can be read.

They can be displayed/edited in ladder program or list.

\*2 : Programs cannot be read to GX Developer Version 8.03D or later if projects are opened with the setting of "Use label". To enable reading of programs to GX Developer Version 8.03D or later, create projects without the "Use label" setting.

\*3 : When Structured Ladder/FBD or ST programs are read from a programmable controller CPU using existing applications, they are read as ladder programs, but there may be cases where the ladder programs cannot be restored. Be sure to check the programs after they have been read from the programmable controller CPU using existing applications. When programs are read from a programmable controller CPU using GX Developer, ladder blocks which cannot be displayed as ladder programs are displayed in yellow.

\*4 : SFC block titles set in "Simple project (with labels)" are not restored when programs are read from a programmable controller CPU in GX Developer. They are restored when the device comments are read using GX Developer, after they have been set to the BL device and written in GX Works2.

\*5 : SFC block titles are not restored when programs are read from a programmable controller CPU in GX Developer. The transition condition numbers are re-sorted in ascending order.

\*6 : Ethernet port setting cannot be read.

● GX IEC Developer

○: Applicable  
 △: Applicable with restrictions  
 ×: Not applicable

Data	Existing applications	
	QCPU (Q mode)	FXCPU
Symbolic information	–	×
Program	Program/Program file	△*1
	Program file	–
	SFC program/SFC program file	×
Parameter	PLC/Network/Remote password	○
	PLC parameter	–
	Intelligent function module parameter	○
Device comment	Global device comment (Common comment)	×
	Local device comment (Comment by program)	×
Device memory	Device memory	○

\*1 : Only execution programs can be read.  
 They can be displayed/edited as MELSEC-IL programs.

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

## Appendix 7 Compatibility with Existing Applications

Q CPU L CPU Remote Head FX

This section explains the considerations when handling GX Works2 projects in earlier version of GX Works2.

Read the considerations in each following item to handle projects.

Note that, depending on the combination of project-created version and project-handled version, considerations for both versions need to be read.

For example, when handling the GX Works2 Version 1.08J project in GX Works2 Version 1.05F, read the considerations of '■ Handling GX Works2 Version 1.08J projects in GX Works2 Version 1.05F' and '■ Handling GX Works2 Version 1.12N projects in GX Works2 Version 1.08J or earlier'.

### ■ Handling GX Works2 Version 1.08J projects in GX Works2 Version 1.05F

Function	Considerations
Open	<ul style="list-style-type: none"> <li>Projects for Q00UJ, Q00U, Q01U, Q10UDH, Q10UDEH, Q20UDH, Q20UDEH, and FXCPU cannot be opened in GX Works2 Version 1.05F.</li> <li>Projects whose path includes a semicolon (;) cannot be opened in GX Works2 Version 1.05F. Before opening a project in GX Works2 Version 1.05F, perform 'Save As' with GX Works2 Version 1.08J or later so that its path does not include a semicolon (;).</li> </ul>
Project Revision	<p>The project revision function cannot be used when the length the full path of the project file (Project.gd2) exceeds 256 bytes.</p> <p>Before using the project revision function with GX Works2 Version 1.05F, perform 'Save As' in GX Works2 Version 1.08J or later so that the length of the project file is 255 bytes or less.</p>
Parameter	<p>When a project in which the following parameters are set is opened in GX Works2 Version 1.05F, the parameters are changed to the default settings.</p> <ul style="list-style-type: none"> <li>When the duplicated network number is specified for 'Network No.' of the CC IE Control on the <a href="#">MELSECNET/CC IE/Ethernet Module Configuration</a> screen.</li> <li>When any of 'Twist' is selected for MELSECNET/H in the baud rate setting on the <a href="#">MELSECNET/CC IE/Ethernet Module Configuration</a> screen.</li> <li>When "Use serial communication" is selected in the serial communication setting with Q02U.</li> <li>When the PLC module change setting in the PLC system setting is specified with Universal model QCPU.</li> <li>When index registers are specified as local devices in the device setting with Universal model QCPU.</li> <li>When "Socket Communication" is selected for 'Open System' in the open setting of the built-in Ethernet port setting in projects with Built-in Ethernet port QCPU.</li> </ul>
Instruction	<p>When an instruction added due to Universal model QCPU (the first five digits of the serial number is '10102' or higher) compatible is used in a project, an instruction code error occurs as the project is opened in GX Works2 Version 1.05F.</p>

■ Handling GX Works2 Version 1.12N projects in GX Works2 Version 1.08J or earlier

Function	Considerations
Open	<ul style="list-style-type: none"> <li>Simple projects (with labels) written in Structured Text cannot be opened in GX Works2 Version 1.08J or earlier.</li> <li>Projects that include inline structured text programs cannot be opened in GX Works2 Version 1.08J or earlier.</li> <li>Simple projects (with labels) for FXCPU or projects for the FXCPU containing Sequential Function Chart cannot be opened in GX Works2 Version 1.08J or earlier.</li> </ul>
Intelligent function module data	Newly added items in data of Q62AD-DGH/Q66AD-DG module cannot be displayed and changed in GX Works2 Version 1.08J or earlier. In addition, data of items newly added since Version 1.10L or later may be lost when data are written to the module in GX Works2 Version 1.05F or earlier.
Write to PLC/Read from PLC	Symbolic information of projects which include inline structured text programs and are created and written to the programmable controller CPU in GX Works2 Version 1.12N or later cannot be read from the programmable controller CPU.

■ Handling GX Works2 Version 1.15R projects in GX Works2 Version 1.12N or earlier

Function	Considerations
Open	<ul style="list-style-type: none"> <li>When a project is opened in GX Works2 Version 1.12N or earlier, system labels are read as global labels. If a project which is saved after rows of global label are moved or deleted in GX Works2 Version 1.12N or earlier, is opened in GX Works2 Version 1.15R or later, the relation with system labels is disabled. If a project which is saved after global labels are edited in GX Works2 Version 1.12N or earlier, is opened in GX Works2 Version 1.15R or later, the relation with system labels can be resolved by executing the verification synchronous function.</li> <li>Contact instructions newly added for Structured Ladder and ST are not supported by GX Works2 Version 1.12N or earlier. A project which contains newly added contact instructions cannot be opened in GX Works2 Version 1.12N or earlier even if they have already been deleted.</li> </ul>
Connection destination setting	When a project is opened in GX Works2 Version 1.12N or earlier, the connection destination setting to use the GOT (Ethernet) transparent is changed. Reconfigure the connection destination setting according to the actual communication route.
Write to PLC/Read from PLC	Symbolic information of projects which contain contact instructions newly added for Structured Ladder and ST cannot be read from the programmable controller CPU in GX Works2 Version 1.12N or earlier.
Library	A user library which contains contact instructions newly added for Structured Ladder and ST cannot be opened in GX Works2 Version 1.12N or earlier.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## ■ Handling GX Works2 Version 1.24A projects in GX Works2 Version 1.15R or earlier

Function	Considerations
Open	<ul style="list-style-type: none"> <li>Projects for LCPUC cannot be opened in GX Works2 Version 1.15R or earlier.</li> <li>Simple projects (with labels) for FXCPU that include inline structured text programs cannot be opened in GX Works2 Version 1.15R or earlier.</li> </ul>
Intelligent function module data	When a project which contains the switch setting of Q62DA-FG/Q66DA-G module set to "4 to 20mA (extended mode)" or "1 to 5V (extended mode)" is opened in GX Works2 Version 1.15R or earlier, the setting is reset to default ("4 to 20mA").
Connection destination setting	When a project for FX3U/FX3UC is opened in GX Works2 Version 1.15R or earlier, the connection destination setting which is set for the Ethernet connection is reset to default. Reconfigure the connection destination setting according to the actual communication route.

## ■ Handling GX Works2 Version 1.31H projects in GX Works2 Version 1.24A or earlier

Function	Considerations
Open	<ul style="list-style-type: none"> <li>Projects for Q50UDEH, Q100UDEH, and LJ72GF15-T2 cannot be opened in GX Works2 Version 1.24A or earlier.</li> <li>Projects for LCPUC in which system labels are set cannot be opened in GX Works2 Version 1.24A or earlier.</li> <li>When "MELSAP-L (Instruction Format)" or "MELSAP-L (Start Conditions Format)" is selected as the SFC display format, SFC is opened as MELSAP3 in GX Works2 Version 1.24A or earlier.</li> </ul>
Parameter	When a project in which "CC IE Field (Master Station)" or "CC IE Field (Local Station)" is set in the network parameter is opened in GX Works2 Version 1.24A or earlier, the parameters are changed to the default settings.
Intelligent function module data	<ul style="list-style-type: none"> <li>When a project which contains LD62, LD62D, LD75D4, LD75P4, or LD77MH4 is opened in GX Works2 Version 1.24A or earlier, these modules become reserved modules.</li> <li>Projects cannot be handled in GX Works2 Version 1.24A or earlier when "Disconnection detection mode setting" and "Disconnection detection setting value" are set in the parameter setting of Q62DA-FG module.</li> <li>Projects cannot be handled in GX Works2 Version 1.24A or earlier when the following parameters are set in the parameter setting of QJ71C24N/QJ71C24N-R2. <ul style="list-style-type: none"> <li>The echo back permit/prohibit specification or execution history option specification in the various control specification</li> <li>The predefined protocol function error code, send data storage area or receive data storage area in the auto refresh</li> </ul> </li> </ul>

■ Handling GX Works2 Version 1.40S projects in GX Works2 Version 1.31H or earlier

Function	Considerations
Open	<ul style="list-style-type: none"> <li>Projects for remote I/O module cannot be opened in GX Works2 Version 1.31H or earlier.</li> <li>Projects for Universal model QCPU (except for Q00U, Q00UJ, Q01U, Q02U) in which "Act at Block Multi-Activated" is set for SFC program property cannot be opened in GX Works2 Version 1.31H or earlier.</li> <li>Be aware the following considerations when handling a project in which system labels are used for FXCPU. System labels are read as global labels when a project is opened in GX Works2 Version 1.12N or earlier. If a project in which rows of global label are moved or deleted is saved in GX Works2 Version 1.12N or earlier, the relation with system labels is disabled. If a project is opened in GX Works2 Version 1.15R - 1.40S, system label information is resolved, but the operations related to system label functions cannot be performed. If a project which is saved after global labels are edited in GX Works2 Version 1.31H or earlier, is opened in GX Works2 Version 1.40S or later, the relation with system labels can be resolved by executing the verification synchronous function.</li> </ul>
Connection destination setting	When a project in which the communication route via Ethernet adapter module is set is opened in GX Works2 Version 1.31H or earlier, the communication route is changed to programmable controller direct connection setting.
Parameter	<ul style="list-style-type: none"> <li>When a project in which the number of points between 1K (1024) and 7K (7168) or exceeds 8K (8192) is set for S device on the PLC parameter is opened in GX Works2 Version 1.31H or earlier, the parameters are changed to the default settings.</li> <li>When a project in which "CC IE Control Ext. Mode (Control Station)" or "CC IE Control Ext. Mode (Normal Station)" is set in the network parameter is opened in GX Works2 Version 1.31H or earlier, the setting is deleted.</li> </ul>
Device comment	For Universal model QCPU, when a project in which bit-specified word device comments are set is opened in GX Works2 Version 1.31H or earlier, the bit-specified word device comments are deleted.
Build	<ul style="list-style-type: none"> <li>When a project in which the same name is used for data name and label name is opened and compiled in GX Works2 Version 1.31H or earlier, a C4110 error occurs. Compile the program after changing the data name and label name.</li> <li>When a project in which devices set with the "Device/Label Automatic-Assign Setting" function are used is opened and compiled in GX Works2 Version 1.31H or earlier, an error occurs. Compile the program after changing the devices not to duplicate with the ones set with the "Device/Label Automatic-Assign Setting" function.</li> </ul>

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## ■ Handling GX Works2 Version 1.48A projects in GX Works2 Version 1.44W or earlier

Function	Considerations
Open	<ul style="list-style-type: none"> <li>When a ladder program whose "Display Connection of Ladder Diagram" setting is set to 13 or more is opened in GX Works2 Version 1.44W or earlier, the program is read with the 11 contacts as the number of displayed contacts.</li> <li>An FXCPU Simple project (with labels) which contains multiple programs cannot be opened in GX Works2 Version 1.44W or earlier.</li> <li>Even when an FXCPU Simple project (with labels) contains only a single program, if the program data name is not "MAIN", the project cannot be opened in GX Works2 Version 1.44W or earlier.</li> </ul>
Intelligent function module data	When a project which contains QD65PD2 or LD77MH16 is opened in GX Works2 Version 1.44W or earlier, the module becomes a reserved module.
Connection destination setting	<ul style="list-style-type: none"> <li>When a project in which the communication route via CC-Link IE Field Network board is set is opened in GX Works2 Version 1.44W or earlier, the communication route is changed to programmable controller direct connection setting.</li> <li>When a project in which the communication route via GOT from Ethernet board is set is opened in GX Works2 Version 1.44W or earlier, the PLC side I/F of the connection destination setting is changed to CPU module. "GOT Transparent" is displayed on the status bar. This change does not affect the communication, however, correct the connection destination setting according to the actual communication route.</li> </ul>
Write to PLC/Read from PLC	<ul style="list-style-type: none"> <li>When a ladder program whose "Display Connection of Ladder Diagram" setting is set to 13 or more is read from a programmable controller CPU using GX Works2 Version 1.44W or earlier, the program is displayed as an improper ladder program.</li> <li>When a project which is written to a programmable controller CPU using the high-speed mode is read from the programmable controller CPU using GX Works2 Version 1.44W or earlier, the symbolic information cannot be read.</li> </ul>
Language selection	<p>When a project with a condition described below is opened in GX Works2 Version 1.44W or earlier, the operation is not ensured.</p> <ul style="list-style-type: none"> <li>A language other than Japanese is selected, and characters other than one-byte characters are used.</li> <li>Two or more types of two-byte characters are mixed.</li> </ul>

## ■ Handling GX Works2 Version 1.53F projects in GX Works2 Version 1.49B or earlier

Function	Considerations
Open	A project in which multiple devices are selected with the "Device/Label Automatic-Assign Setting" function cannot be opened in GX Works2 Version 1.49B or earlier.
Intelligent function module data	When a project which contains QJ71MT91 or QJ71MB91 is opened in GX Works2 Version 1.49B or earlier, the module becomes a reserved module.
Connection destination setting	When a project in which the communication route via CC-Link IE Field Network master/local module is set for LCPU is opened in GX Works2 Version 1.49B or earlier, the communication route is changed to programmable controller direct connection setting.
Parameter	When a project in which "CC IE Field (Master Station)" and "CC IE Field (Local Station)" are set in the network parameter of LCPU is opened in GX Works2 Version 1.49B or earlier, the network parameters are changed to default settings.
Write to PLC/Read from PLC	A project in which multiple devices are selected with the "Device/Label Automatic-Assign Setting" function cannot be read from a programmable controller CPU in GX Works2 Version 1.49B or earlier.



■ **Handling GX Works2 Version 1.62Q projects in GX Works2 Version 1.55H or earlier**

Function	Considerations
Open	<ul style="list-style-type: none"> <li>Structured projects in which the operation to display/hide the left power rail is performed on the Structured Ladder/FBD editor cannot be opened in GX Works2 Version 1.55H or earlier.</li> <li>For FXCPU, a project in which a block password with the validated setting for "Read-protect the execution program" exists cannot be opened in GX Works2 Version 1.55H or earlier.</li> </ul>
Intelligent function module data	<ul style="list-style-type: none"> <li>A project which contains Q64TCTTN, Q64TCTTBWN, Q64TCRTN, or Q64TCRTBWN opens as a project of Q64TCTTN, Q64TCTTBWN, Q64TCRTN, Q64TCRTBWN respectively. Added items cannot be displayed or changed in GX Works2 Version 1.55H or earlier.</li> <li>When a project which contains L60TCTT4, L60TCTT4BW, L60TCRT4, or L60TCRT4BW is opened in GX Works2 Version 1.55H or earlier, those modules become reserved modules.</li> </ul>
Parameter	<ul style="list-style-type: none"> <li>When a project in which the simple PLC communication setting is set on the PLC parameter of LCPU is opened in GX Works2 Version 1.55H or earlier, the parameters are changed to the default settings.</li> <li>When a project in which the serial communication setting is set on the PLC parameter of QnUD(H)CPU is opened in GX Works2 Version 1.55H or earlier, the parameters are changed to the default settings.</li> </ul>

■ **Handling GX Works2 Version 1.64S projects in GX Works2 Version 1.62Q or earlier**

Function	Considerations
Parameter	<p>Projects cannot be handled in GX Works2 Version 1.62Q or earlier when the following parameters are set.</p> <ul style="list-style-type: none"> <li>When "Branch Module" is set for the I/O assignment setting on PLC parameter of LCPU.</li> </ul>
Intelligent function module data	<p>When a project which contains QD75P1N, QD75P2N, QD75P4N, QD75D1N, QD75D2N, or QD75D4N is opened in GX Works2 Version 1.62Q or earlier, these modules become reserved modules.</p>
Device comment	<p>For LCPU, when a project in which bit-specified word device comments are set is opened in GX Works2 Version 1.62Q or earlier, the bit-specified word device comments are deleted.</p>
Print	<p>String patterns are printed as character strings when a project in which string pattern is set to the header/footer is opened in GX Works2 Version 1.62Q or earlier. Delete the entered string patterns and set the setting again.</p>
Write to PLC/Read from PLC	<p>For projects of LCPU, device comment files which contain bit-specified comments cannot be read from the programmable controller CPU in GX Works2 Version 1.62Q or earlier.</p>

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

## ■ Handling GX Works2 Version 1.73B projects in GX Works2 Version 1.64S or earlier

Function	Considerations
Open	<ul style="list-style-type: none"> <li>When a project which contains Q64ADH is opened in GX Works2 Version 1.64S or earlier, the module becomes a reserved module.</li> <li>Projects in which the auto refresh parameter of temperature control module is set in the Setting item reduction mode cannot be opened in GX Works2 Version 1.64S or earlier.</li> <li>Projects in which parameters are set in the FX3U/FX3UC network parameter cannot be opened in GX Works2 Version 1.64S or earlier.</li> </ul>
Parameter	<p>When a project in which the following parameters are set is opened in GX Works2 Version 1.64S or earlier, the parameters are changed to the default settings.</p> <ul style="list-style-type: none"> <li>When the station information of CC-Link is set on the CC-Link Configuration window.</li> <li>When "Branch Module" is set on the &lt;&lt;I/O Assignment&gt;&gt; tab of PLC parameter for LCPU.</li> </ul>
Compile	An error occurs when a program in which function blocks of ladder program are used in a Structured Ladder/FBD program, or function blocks of Structured Ladder/FBD program are used in a ladder program, is opened and compiled in GX Works2 Version 1.64S or earlier.
IC memory card write/read	IC memory card data to which a password is set cannot be read in GX Works2 Version 1.64S or earlier.

## ■ Handling GX Works2 Version 1.77F projects in GX Works2 Version 1.75D or earlier

Function	Considerations
Parameter	<p>When a project in which the following parameters are set is opened in GX Works2 Version 1.75D or earlier, the parameters are changed to the default settings.</p> <ul style="list-style-type: none"> <li>When "Use" is selected for the IP Packet Transfer setting on the &lt;&lt;Built-in Ethernet Port Setting&gt;&gt; tab of PLC parameter.</li> <li>When "CC IE Field (Sub-Master Station)" is selected for "Network Type" in the network parameter.</li> <li>When "Sub-Master Station" is selected for "Station Type" of "Network Configuration Settings".</li> <li>When the IP address is set for "Network Operation Settings".</li> </ul>
Intelligent function module data	When a project which contains Q68CT, QD77MS2, QD77MS4, QD77MS16, LD75P1, LD75P2, LD75D1, or LD75D2 is opened in GX Works2 Version 1.75D or earlier, these modules become reserved modules.

■ Handling GX Works2 Version 1.87R projects in GX Works2 Version 1.77F or earlier

Function	Considerations
Open	<ul style="list-style-type: none"> <li>• When opening a project in which the extended mode for device comments is set in GX Works2 Version 1.77F or earlier, the comments which exceeded the number of points of device comment that can be set in the standard mode are deleted as described below.</li> <li>• When the number of points of device comment per device exceeds the number of points that can be set in the standard mode, points over 32K points are deleted. All bit-specified comments set to the device type which corresponds to the point at 32K + 1 are deleted.</li> <li>• When the number of points of device comment per file exceeds the number of points that can be set in the standard mode, points over 1024K points are deleted. All bit-specified comments set to the device type which corresponds to the point at 1024K + 1 are deleted.</li> <li>• Saved projects in which an element is added or a comment is edited for a structure registered to a system label cannot be opened in GX Works2 Version 1.77F or earlier.</li> <li>• Projects in which structure array global labels are registered as system labels cannot be opened in GX Works2 Version 1.77F or earlier.</li> <li>• The following functions cannot be used when a project which includes ladder programs whose function block calls function block is opened in GX Works2 Version 1.77F or earlier.                         <ul style="list-style-type: none"> <li>• Watch</li> <li>• Monitor</li> <li>• Modify value</li> <li>• Sampling trace</li> <li>• PLC Diagnostics</li> <li>• Cross reference</li> </ul> </li> <li>• Projects for Q02PH, Q06PH, Q12PH, Q12PRH, Q25PH, and Q25PRH cannot be opened in GX Works2 Version 1.77F or earlier.</li> <li>• Projects in which parameters are set in the FX3G/FX3GC network parameter cannot be opened in GX Works2 Version 1.77F or earlier.</li> </ul>
Global label	<p>When any of the following system labels is registered, the system label data base cannot be connected from the project in GX Works2 Version 1.77F or earlier.</p> <ul style="list-style-type: none"> <li>• A system label in which an element is added or a comment is edited for a structure registered to a system label.</li> <li>• A system label in which a structure array global label is set to the data type.</li> </ul>
Verify	<p>Project data of GX Works2 Version 1.87R cannot be verified against that of GX Works2 Version 1.77F or earlier because of different naming methods of block data name in SFC program. Copy the names of block data of project opened in GX Works2 Version 1.87R, paste them to block data of project opened in GX Works2 Version 1.77F or earlier as a block data name, and execute [Verify].</p>
Write to PLC/Read from PLC	<p>The following functions cannot be used when a project which includes ladder programs whose function block calls function block is read from a programmable controller CPU using GX Works2 Version 1.77F or earlier.</p> <ul style="list-style-type: none"> <li>• Watch</li> <li>• Monitor</li> <li>• Modify value</li> <li>• Sampling trace</li> <li>• PLC Diagnostics</li> <li>• Cross reference</li> </ul>
Parameter	<p>When a project in which "CC IE Field (Local Station)" is selected for "Network Type", and "Specify station No. by program" is selected for 'specification method for station number' in the network parameter is opened in GX Works2 Version 1.77F or earlier, the parameters are changed to the default settings.</p>
Intelligent function module data	<p>When a project which contains QD73A1 is opened in GX Works2 Version 1.77F or earlier, the module becomes a reserved module.</p>

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## ■ Handling GX Works2 Version 1.91V projects in GX Works2 Version 1.87R or earlier

Function	Considerations
Open	Simple projects (with labels) for Q02PH, Q06PH, Q12PH, Q12PRH, Q25PH, and Q25PRH cannot be opened in GX Works2 Version 1.87R or earlier.
Write to PLC/Read from PLC	When using GX Works2 Version 1.87R or earlier, data cannot be written to/read from a Process CPU or Redundant CPU to which symbolic information of Simple project (with labels) is written. Delete the symbolic information with the delete PLC data function before writing/reading data to/from the programmable controller CPU.
Parameter	<ul style="list-style-type: none"> <li>• When a project in which the following parameters are set is opened in GX Works2 Version 1.87R or earlier, the parameters are changed to the default settings.</li> <li>• When the network configuration of CC-Link IE Field Network is set on the CC IE Field Configuration window.</li> <li>• When the Ethernet adapter setting is set on the PLC parameter of FX3G, FX3GC, FX3U, or FX3UC.</li> <li>• CSV files exported by the parameter processing of device station on the CC-Link Configuration window cannot be imported in GX Works2 Version 1.87R or earlier.</li> </ul>
Intelligent function module data	When a project which contains QE81WH, QE84WH, QE81WH4W, QE83WH4W, or QE82LG is opened in GX Works2 Version 1.87R or earlier, these modules become reserved modules.

■ Handling GX Works2 Version 1.98C projects in GX Works2 Version 1.91V or earlier

Function	Considerations
Open	<ul style="list-style-type: none"> <li>• The following projects cannot be opened in GX Works2 Version 1.91V or earlier.                             <ul style="list-style-type: none"> <li>• Structured projects for Q02PH, Q06PH, Q12PH, Q12PRH, Q25PH, and Q25PRH.</li> <li>• Projects for Q03UDV, Q04UDV, Q06UDV, Q13UDV, Q26UDV, L02S, L06, L26, and LJ72MS15.</li> </ul> </li> <li>• When a project in which the reflection/reference targets of device comments are set to 'PLC parameter setting' is opened in GX Works2 Version 1.91V or earlier, the reflection/reference targets are set to "Local".</li> <li>• The following functions may not be performed normally when a project, in which an inline structured text program is called from the function block created in a ladder program, or a function block created in an ST program is called from the function block created in a ladder program, is opened in GX Works2 Version 1.98C or earlier.                             <ul style="list-style-type: none"> <li>• Watch</li> <li>• Monitor</li> <li>• Modify value</li> <li>• Sampling trace</li> <li>• PLC Diagnostics</li> <li>• Cross reference</li> <li>• Print</li> <li>• Deletion of inline structured text box in function block of ladder program</li> </ul> </li> </ul>
Write to PLC/Read from PLC	<ul style="list-style-type: none"> <li>• When using GX Works2 Version 1.91V or earlier, data of the following projects cannot be written to a programmable controller CPU.                             <ul style="list-style-type: none"> <li>• QCPU project in which the IP address is set for "Network Operation Settings" of CC IE Control network parameter</li> <li>• LCPU project in which Ethernet is set for the network parameter</li> <li>• LCPU project in which the IP packet transfer is set for "Built-in Ethernet Port Setting" of PLC parameter</li> <li>• LCPU project in which the IP address is set for "Network Operation Settings" of CC-Link IE Field Network parameter (master station, sub-master station)</li> </ul> </li> <li>• When using GX Works2 Version 1.91V or earlier, data cannot be written to/read from a Process CPU or Redundant CPU to which symbolic information of Structured project is written. Delete the symbolic information with the delete PLC data function before writing/reading data to/from the programmable controller CPU.</li> </ul>
Verify	<p>When any of the following projects is opened in GX Works2 Version 1.91V or earlier, the programmable controller data, projects, and revisions cannot be verified.</p> <ul style="list-style-type: none"> <li>• LCPU project in which the IP packet transfer is set for "Built-in Ethernet Port Setting" of PLC parameter</li> <li>• LCPU project in which the sub-master station is set for the network configuration of CC-Link IE Field Network parameter (master station, sub-master station)</li> <li>• LCPU project in which the IP address is set for "Network Operation Settings" of CC-Link IE Field Network parameter (master station, sub-master station)</li> </ul>
Parameter	<ul style="list-style-type: none"> <li>• When any of the following project is opened in GX Works2 Version 1.91V or earlier, the parameters are set to default.                             <ul style="list-style-type: none"> <li>• QCPU project in which the IP address is set for "Network Operation Settings" of CC IE Control network parameter</li> <li>• LCPU project in which Ethernet is set for the network parameter</li> <li>• LCPU project in which the IP packet transfer is set for "Built-in Ethernet Port Setting" of PLC parameter</li> <li>• LCPU project in which the sub-master station is set for the network configuration of CC-Link IE Field Network parameter (master station, sub-master station)</li> <li>• LCPU project in which the IP address is set for "Network Operation Settings" of CC-Link IE Field Network parameter (master station, sub-master station)</li> <li>• LCPU project in which the Auto Detect Setting of the Connected Device is set for "Operation Setting" of CC-Link network parameter</li> <li>• Project contains AnyWireASLINK configuration data</li> </ul> </li> <li>• When a project in which the following parameter is set is opened in GX Works2 Version 1.91V or earlier, the parameters are changed to the default settings.                             <ul style="list-style-type: none"> <li>• CC IE Field (Motion Master Station) is set in the network parameter of Universal model QCPU.</li> </ul> </li> </ul>

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
—	INDEX

Function	Considerations
Intelligent function module data	<ul style="list-style-type: none"> <li>When a project which contains QD77GF16, Q64DAH, L60AD4-2GH, QJ51AW12AL, or LJ51AW12AL is opened in GX Works2 Version 1.91V or earlier, these modules become reserved modules</li> <li>QCPU waveform output data created in GX Works2 Version 1.98C or later cannot be read in GX Works2 Version 1.91V or earlier.</li> </ul>
Remote password	When a project in which the remote password for LJ71E71-100 is set is opened in GX Works2 Version 1.91V or earlier, the module is changed to "LCPU" (Ethernet Built-in CPU).

**■ Handling GX Works2 Version 1.492N projects in GX Works2 Version 1.98C or earlier**

Function	Considerations
Open	<p>The following projects cannot be opened in GX Works2 Version 1.98C or earlier</p> <ul style="list-style-type: none"> <li>Project for Q04UDPV, Q06UDPV, Q13UDPV, Q26UDPV, and FX3s.</li> </ul>
Parameter	<p>When any of the following project is opened in GX Works2 Version 1.98C or earlier, the parameter settings are reset to default.</p> <ul style="list-style-type: none"> <li>A project in which "Communication protocol" is set to "Fixed Buffer Communication Procedure", or in the range of 1 to 1024 is set to "Destination Port No." for open setting of Ethernet network parameter.</li> <li>Projects which include Ethernet configuration data.</li> </ul>
Intelligent function module data	<ul style="list-style-type: none"> <li>When a project which contains L60AD2DA2, LD77MS2, LD77MS4, or LD77MS16 is opened in GX Works2 Version 1.98C or earlier, these modules become reserved modules.</li> <li>Waveform output data of L60AD2DA2 created in GX Works2 Version 1.492N or later cannot be read in GX Works2 Version 1.95Z or earlier.</li> <li>Waveform output data of L60AD2DA2 created in GX Works2 Version 1.492N or later cannot be read from the device memory or a data for memory card to GX Works2 Version 1.98C.</li> </ul>
Compile	<p>When the project in which devices/labels are used for indexes in structure array labels is compiled with GX Works2 Version 1.98C or earlier, the program operation may be changed depending on the programmable controller type or the index setting.</p> <p>Review the program where over 65,536 array elements are accessed.</p>

**■ Handling GX Works2 Version 1.499V projects in GX Works2 Version 1.493P or earlier**

Function	Considerations
Language selection	When the project in which Chinese (traditional characters) is selected and the characters other than one-byte characters are used is opened with Japanese or English GX Works2 Version 1.493P or earlier, the operation is not ensured.

■ Handling GX Works2 Version 1.501X projects in GX Works2 Version 1.499V or earlier

Function	Considerations
Open	<ul style="list-style-type: none"> <li>Projects for LCPU (except for L02S/L02S-P, L02/L02-P) in which "Act at Block Multi-Activated" is set for SFC program property cannot be opened in GX Works2 Version 1.499V or earlier.</li> <li>Projects for FXCPU in which the settings of intelligent function module is included cannot be opened in GX Works2 Version 1.499V or earlier.</li> </ul>
Parameter	<p>When a project in which the following parameters are set is opened in GX Works2 Version 1.499V, the parameters are changed to the default settings.</p> <ul style="list-style-type: none"> <li>A project in which the number of points between 1K (1024) and 7K (7168) is set for S device on the PLC parameter of L02S/S02S-P and L02/L02-P</li> <li>A project in which the number of points between 1K (1024) and 7K (7168) or exceeds 8K (8192) is set for S device on the PLC parameter of L06/L06-P, L26/L26-P, and L26-BT/L26-PBT</li> <li>A project in which "Communication protocol" is set to the open system of the open setting on the &lt;&lt;Built-in Ethernet Port Setting&gt;&gt; tab of PLC parameter.</li> <li>A project in which "Communication protocol" is set to "Select Function" on the &lt;&lt;Built-in Serial Setting&gt;&gt; tab of PLC parameter.</li> <li>A project in which, except for "Not Used", is set to "Select Function" on the &lt;&lt;Adapter Serial Setting&gt;&gt; tab of PLC parameter.</li> <li>A CC IE Filed project which includes data of CC-Link Configuration or AnyWireASLINK Configuration</li> <li>A project in which CC IE Field head module or GOT2000 series is set using CC IE Field Configuration window</li> <li>A project in which GOT2000 series is set using CC-Link Configuration window</li> <li>A project in which "CC IE Field (Motion Master Station)" is set to network type of CC-Link IE Field Network, and network configuration settings are set using CC IE Field Configuration window</li> </ul>

■ Handling GX Works2 Version 1.507D projects in GX Works2 Version 1.501X or earlier

Function	Considerations
Intelligent function module data	When a project, in which FX3U-20SSC-H or FX-ENET series is included, is opened in GX Works2 Version 1.51X or earlier, it will be a reserved module.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## ■ Handling GX Works2 Version 1.513K projects in GX Works2 Version 1.507D or earlier

Function	Considerations
Parameter	<p>When any of the following projects is opened in GX Works2 Version 1.507D or earlier, the parameters are set to default.</p> <ul style="list-style-type: none"> <li>L06, L06-P, L26, L26-P, L26-BT, or L26-PBT project in which "Use Pointer Extended Setting" is set in Device of PLC parameter</li> <li>Project in which AnyWireASLINK Configuration is created to the bridge module (NZ2AW1C2AL) on the CC-Link Configuration window</li> </ul>
Intelligent function module data	<p>When a project, which includes L60MD4-G, L60ADVL8, or L60ADIL8, is opened with GX Works2 Version 1.507D or earlier, it will be a reserved module.</p>
Instruction	<p>When any of the following projects is opened in GX Works2 Version 1.507D or earlier, an instruction code error occurs in the ladder block.</p> <ul style="list-style-type: none"> <li>Project in which any of the instructions (SMOV(P), CMP(P), DCMP(P), ZCP(P), DZCP(P)) supported by High-speed Universal model QCPU and Universal model process CPU with a serial number whose first five digits are '16043' or higher, and LCPUCPU with a serial number whose first five digits are '16042' or higher is used.</li> </ul>
Read from PLC	<p>In GX Works2 Version 1.507D or earlier, an error will occur when compiling a project with data in the following project read from a programmable controller CPU.</p> <ul style="list-style-type: none"> <li>Project including a Structured Ladder/FBD program or an ST program which uses the instruction (SP.READ, SP.WRITE) that is supported by High-speed Universal model QCPU and Universal model process CPU with a serial number whose first five digits are '16043' or higher.</li> </ul>
Print	<p>The task setting data set to the batch print screen of FXCPU are not printed.</p>

## ■ Handling GX Works2 Version 1.521T projects in GX Works2 Version 1.513K or earlier

Function	Considerations
Connection destination setting	<p>When a project is opened in GX Works2 Version 1.513K or earlier, the connection destination setting via RCPUCPU is changed to programmable controller direct connection setting.</p>



**■ Handling GX Works2 Version 1.525X projects in GX Works2 Version 1.521T or earlier**

Function	Considerations
Parameter	<p>When any of the following projects is opened in GX Works2 Version 1.521T or earlier, the parameters are set to default.</p> <ul style="list-style-type: none"> <li>An LCPU project in which FTP Client Setting, E-mail Setting, and/or DNS Setting is configured on the Built-in Ethernet Port Setting of PLC parameter.</li> <li>An LCPU project in which "Carry out fuse blown check" is not selected in the PLC RAS setting of PLC parameter.</li> <li>An LCPU project in which "Continue" is selected in "Fuse Blown" in the PLC RAS setting of PLC parameter.</li> </ul>
Instruction	<p>When any of the following projects is opened in GX Works2 Version 1.521T or earlier, an instruction code error occurs in the ladder block.</p> <ul style="list-style-type: none"> <li>A project in which an instruction (ECMP(P), EDCMP(P), EZCP(P), EDZCP(P), SFTR(P), SFTL(P), WSFR(P), WSFL(P), CCD(P), CRC(P), TCMP(P), TZCP(P), HOURM, D HOURM, PID) supported by High-speed Universal model QCPU, Universal model process CPU, and LCPU with a serial number whose first five digits are '16112' or higher is used.</li> </ul>
Connection destination setting	<p>When a project is opened in GX Works2 Version 1.521T or earlier, the connection destination setting to use the GOT (Ethernet) transparent set in Redundant CPU is changed to GOT (Bus) transparent.</p> <p>When a project is opened in GX Works2 Version 1.521T or earlier, the connection destination setting to use the GOT (CC-Link IE Control) transparent is changed to programmable controller direct connection setting.</p>
Read from PLC	<p>In GX Works2 Version 1.507D or earlier, an error will occur when compiling a project with data in the following project read from a programmable controller CPU.</p> <ul style="list-style-type: none"> <li>A project in which an instruction (ECMP(P), EDCMP(P), EZCP(P), EDZCP(P), SFTR(P), SFTL(P), WSFR(P), WSFL(P), CCD(P), CRC(P), TCMP(P), TZCP(P), HOURM, D HOURM, PID) supported by High-speed Universal model QCPU, Universal model process CPU, and LCPU with a serial number whose first five digits are '16112' or higher is used.</li> <li>A project in which an instruction (SP.FTPPUT, SP.FTPGET, SP.MLSEND, SP.MLRECV, SP.MLOPEADR, SP.MLGETADR) supported by LCPU with a serial number whose first five digits are '16112' or higher is used in a Structured ladder/FBD program or ST program.</li> </ul>

**■ Handling GX Works2 Version 1.530C projects in GX Works2 Version 1.525X or earlier**

Function	Considerations
Parameter	<p>When any of the following projects is opened in GX Works2 Version 1.525X or earlier, the parameters are set to default.</p> <ul style="list-style-type: none"> <li>A project in which the AnyWireASLINK configuration is created for CC-Link IE Field Network-AnyWireASLINK bridge module on the CC IE Field Configuration window</li> </ul>

**■ Handling GX Works2 Version 1.535H projects in GX Works2 Version 1.531D or earlier**

Function	Considerations
Parameter	<p>When any of the following projects is opened in GX Works2 Version 1.531D or earlier, the parameters are set to default.</p> <ul style="list-style-type: none"> <li>A project for High-speed Universal model QCPU or Universal model process CPU for which the MELSOFT Connection Extended Setting in the Built-in Ethernet Port Setting of PLC parameter is set to "Use".</li> </ul>

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

### ■ Handling GX Works2 Version 1.540N projects in GX Works2 Version 1.536J or earlier

Function	Considerations
Intelligent function module data	When a project, which includes QD77GF4 or QD77GF8, is opened with GX Works2 Version 1.536J or earlier, it will be a reserved module.

### ■ Handling GX Works2 Version 1.545T projects in GX Works2 Version 1.542Q or earlier

Function	Considerations
Intelligent function module data	<ul style="list-style-type: none"> <li>Newly added items in data of Q64ADH module cannot be displayed and changed in GX Works2 Version 1.542Q or earlier.</li> <li>When a project which contains L60DAVL8, or L60DAIL8 is opened in GX Works2 Version 1.542Q or earlier, these modules become reserved modules. Waveform output data of L60DAVL8 or L60DAIL8 created in GX Works2 Version 1.545T or later cannot be read in GX Works2 Version 1.542Q or earlier.</li> </ul>
Connection destination setting	When a project in which the communication route via GOT (CC-Link IE Field) transparent is set is opened in GX Works2 Version 1.542Q or earlier, the communication route is changed to programmable controller direct connection setting.

### ■ Handling GX Works2 Version 1.550Y projects in GX Works2 Version 1.545T or earlier

Function	Considerations
Parameter	When a project, which includes Ethernet configuration data of High-speed Universal model QCPU or Universal model process CPU, is opened with GX Works2 Version 1.545T or earlier, the parameters are set to default.

### ■ Handling GX Works2 Version 1.555D projects in GX Works2 Version 1.551Z or earlier

Function	Considerations
Open Project	A project to which a block password was set cannot be opened in GX Works2 Version 1.551Z or earlier.
Project Verify	The naming rule of block data for an SFC program opened by selecting [Open Other Project] differs between GX Works2 Version 1.555D and GX Works2 Version 1.551Z or earlier. Even with the same GX Developer format projects, they cannot be verified if one of them was opened by selecting "Open Other Project" and saved in GX Works2 Version 1.555D and the other one was opened in the same method and saved in GX Works2 Version 1.551Z or earlier. It is because of the names of their block data which were named according to their own naming rules. Copy the name of block data of project opened in GX Works2 Version 1.555D, paste it to block data of project opened in GX Works2 Version 1.550Y or earlier as a block data name, and execute [Verify].
Parameter	Parameters of a project used for High-speed Universal model QCPU, Universal model process CPU, and Built-in Ethernet port LCPU return to the defaults when the CC-Link IEF Basic setting is set for them on the <<Built-in Ethernet Port Setting>> tab of PLC parameter and the project is opened in GX Works2 Version 1.551Z or earlier.
Read from PLC	<p>In GX Works2 Version 1.555D or earlier, an error will occur when compiling a project with data in the following project read from a programmable controller CPU.</p> <ul style="list-style-type: none"> <li>Project including a Structured Ladder/FBD program or an ST program which uses the instruction (SP.SLMPSND) that is supported by High-speed Universal model QCPU, Universal model process CPU, and LCPU with a serial number whose first five digits are '18112' or higher.</li> </ul>

■ Handling GX Works2 Version 1.560J projects in GX Works2 Version 1.555D or earlier

Function	Considerations
Intelligent function module data	When a project which contains LD40PD01 is opened in GX Works2 Version 1.555D or earlier, these modules become reserved modules.
Open Project	For High-speed Universal model QCPU and Universal model process CPU, a project including a block password to which the execution program protection setting is enabled cannot be opened in GX Works2 Version 1.555D or earlier.

■ Handling GX Works2 Version 1.566Q projects in GX Works2 Version 1.560J or earlier

Function	Considerations
Connection destination setting	When a project for which both a personal computer is connected to a GOT by Ethernet and "via GOT(Ethernet) transparent mode" is set in "Detail setting for GOT and PLC connection" is opened in GX Works2 Version 1.560J or earlier, the communication route will be changed to the programmable controller direct connection setting.
Parameter	When any of the following projects is opened in GX Works2 Version 1.560J or earlier, the parameters are set to default. <ul style="list-style-type: none"> <li>Project for which group No.2 to No.4 are set in "CC-Link IEF Basic Setting" on the &lt;&lt;Built-in Ethernet Port Setting&gt;&gt; tab of "PLC Parameter" and which is used for High-speed Universal model QCPU and Universal model process CPU. (However, when a project for which only group No.1 is set is opened in GX Works2 Version 1.560J or 1.555D, the communication route will not be changed.)</li> <li>Project for which nine or more stations are set in "CC-Link IEF Basic Setting" on the &lt;&lt;Built-in Ethernet Port Setting&gt;&gt; tab of "PLC Parameter" and which is used for a built-in Ethernet port LCPU. (However, when a project for which eight or less stations are set is opened in GX Works2 Version 1.560J or 1.555D, the communication route will not be changed.)</li> </ul>
	When any of the following projects is opened in GX Works2 Version 1.560J or earlier, the parameters are set to default. <ul style="list-style-type: none"> <li>For High-speed Universal model QCPU and Universal model process CPU, the operation history of a CPU module can be saved by setting the item on the &lt;&lt;PLC RAS&gt;&gt; tab of "PLC Parameter".</li> <li>For High-speed Universal model QCPU and Universal model process CPU, a device range to prohibit device writing from an external device can be set on the &lt;&lt;Device Setting&gt;&gt; tab of "PLC Parameter" is selected.</li> </ul>
	In GX Works2 Version 1.560J or earlier, an error will occur when compiling a project with data in the following project read from a programmable controller CPU. <ul style="list-style-type: none"> <li>Project including the instructions (DATE2SEC(P), SEC2DATE(P)) that are supported by High-speed Universal model QCPU and Universal model process CPU with a serial number of which the first five digits are '19042' or higher.</li> </ul>
Read from PLC	

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## ■ Handling GX Works2 Version 1.576A projects in GX Works2 Version 1.535H or earlier

Function	Considerations
Parameter	<p>When opening any of the following projects in GX Works2 Version 1.535H or earlier, the parameters are changed to the default.</p> <ul style="list-style-type: none"> <li>A project for High-speed Universal model QCPU and Universal model process CPU for which the simple PLC communication setting has been configured in the built-in Ethernet port setting of PLC parameter.</li> <li>A built-in Ethernet LCPU project for which "SLMP-Compatible Device (QnA Compatible 3E Frame)" has been set as the communication destination in the module type of the simple PLC communication setting in built-in Ethernet port setting of PLC parameter.</li> <li>A built-in Ethernet LCPU project for which "MELSEC iQ-R (Built-in Ethernet Function)" has been set as the communication destination in the module type of the simple PLC communication setting in built-in Ethernet port setting of PLC parameter.</li> </ul>

## ■ Handling GX Works2 Version 1.580E projects in GX Works2 Version 1.577B or earlier

Function	Considerations
Parameter	<p>When opening any of the following projects in GX Works2 Version 1.577B or earlier, the parameters are changed to the default.</p> <ul style="list-style-type: none"> <li>A project for High-speed Universal model QCPU, Universal model process CPU, and Ethernet Built-in LCPU for which "MELSEC iQ-F (Built-in Ethernet Function)" has been set as the communication destination in the module type of the simple PLC communication setting in the built-in Ethernet port setting of PLC parameter.</li> </ul>
Read from PLC	<p>In GX Works2 Version 1.577B or earlier, an error will occur when compiling a project with data in the following project read from a programmable controller CPU.</p> <ul style="list-style-type: none"> <li>A project including a Structured Ladder/FBD program or an ST program which uses the instruction (SP.LOGNAMER, SP.LOGFILES) that is supported by High-speed Universal model QCPU and Universal model process CPU whose first five digits of a serial number are '20073' or higher.</li> </ul>

## ■ Handling GX Works2 Version 1.585K projects in GX Works2 Version 1.580E or earlier

Function	Considerations
Connection destination setting	<p>When an Ethernet adapter is set for an Ethernet Board in PC side I/F and a project is opened in GX Works2 Version 1.580E or earlier, the Ethernet board operates in the default (Not Specified) settings.</p>

## ■ Handling GX Works2 Version 1.610L projects in GX Works2 Version 1.606G or earlier

Function	Considerations
Open Project	<p>A project to which "Enable the security check for the project" is enabled cannot be opened in GX Works2 Version 1.606G or earlier.</p>

## ■ Handling GX Works2 Version 1.615R projects in GX Works2 Version 1.612N or earlier

Function	Considerations
Parameter	<p>When a project in which "Disable Using Port Setting" is set on the PLC parameter of High-speed Universal model QCPU and Universal model process CPU is opened in GX Works2 Version 1.612N or earlier, the parameters are changed to the default settings.</p>

## Appendix 8 Considerations When Saving Projects in GX Developer Format

Q CPU

L CPU

Remote

Head

FX

This section explains the considerations applied when saving projects in GX Developer format. In cases other than those listed below when data cannot be saved, a message is displayed, and saving is canceled. In such cases, follow the instructions of the message.

GX Works2 data		Considerations	
Project	Title	The 33rd and later characters are deleted.	
	Comment	Deleted.	
Parameter	Comment	Deleted.	
Intelligent function module	Intelligent function module data	<ul style="list-style-type: none"> <li>QCPU (Q mode)/LCPU Data other than intelligent function module parameters (initial setting, auto refresh) are deleted. QD75P1N, QD75P2N, QD75P4N, QD75D1N, QD75D2N, and QD75D4N are saved as QD75P1, QD75P2, QD75P4, QD75D1, QD75D2, and QD75D4 respectively.</li> <li>FXCPU Deleted.</li> </ul>	
Structured Data Types*1	Comment	Deleted.	
	Label	Comment	The 65th and later characters are deleted. If a line feed is entered, delete anything following the line feed.
Global Label*1	Number of data	The data are combined into one unit.	
	Data name	A fixed character string (label) is created to combine data into one unit.	
	Title	Deleted.	
	Comment	Deleted.	
	Label	Comment	The 65th and later characters are deleted. If a line feed is entered, delete anything following the line feed.
		Remarks	Deleted.
FB instance		Deleted.	
System label information	Deleted.		
FB*1	Comment	Deleted.	
	Label*1	Comment	The 65th and later characters are deleted. If a line feed is entered, delete anything following the line feed.
		FB instance	Deleted*2.
Program	Comment	Deleted.	
	Label*1	Comment	The 65th and later characters are deleted. If a line feed is entered, delete anything following the line feed.
		FB instance	Deleted*2.
SFC program*1	Program	Unconverted/uncompiled programs are deleted.	
	Comment	Deleted.	
SFC block*1	Data name	Deleted.	
	Comment	Converted to a block statement. (Characters exceeding 10 lines times 65 characters are deleted.)	
Device Memory	Comment	Deleted.	
	Duplicated devices	Latter device is preferred.	
Connection destination setting	Connection destination data	The settings other than the current connection settings are deleted. The settings which are not supported by GX Developer are changed to programmable controller direct connection setting.	

\*1 : Not supported by FXCPU.

\*2 : The function block instances created for global labels in GX Works2 are created as local labels in GX Developer. However, in GX Developer, the function block instances are not displayed on the local label setting screen.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

## Appendix 8.1 ST instruction table for GX Works2 and GX Developer

Instructions that can be used in ST programs differ in between GX Works2 and GX Developer. As a result, an error may occur when a project that includes an ST program and is saved in GX Developer format is read and compiled with GX Developer. In such case, correct the ST program according to the following table.

GX Works2	GX Developer	GX Works2	GX Developer	GX Works2	GX Developer
ACOS	ACOS <sup>*1</sup>	DFLT	DFLT_M	INC	INC_M
ASIN	ASIN <sup>*1</sup>	DFRO	DFRO_M	LEFT	LEFT <sup>*1</sup>
ATAN	ATAN <sup>*1</sup>	DGBIN	DGBIN_M	LEN	LEN <sup>*1</sup>
BACOS	BACOS_MD	DGRY	DGRY_M	LIMITATION	LIMIT
BAND	BAND_MD	DI	DI_M	MAXIMUM	MAX
BASIN	BASIN_MD	DINC	DINC_M	MIDR	MIDR_M
BATAN	BATAN_MD	DIS	DIS_M	MIDW	MIDW_M
BCD	BCD_M	DLIMIT	DLIMIT_MD	MINIMUM	MIN
BCOS	BCOS_MD	DMAX	DMAX_M	NDIS	NDIS_M
BDSQR	BDSQR_MD	DMIN	DMIN_M	NEG	NEG_M
BIN	BIN_M	DNEG	DNEG_M	NUNI	NUNI_M
BKAND	BKAND_M	DOR	DOR_M	OUT	OUT_M
BKBCD	BKBCD_M	DRCL	DRCL_M	PLOW	PLOW_M
BKBIN	BKBIN_M	DRCR	DRCR_M	POFF	POFF_M
BKOR	BKOR_M	DROL	DROL_M	PSCAN	PSCAN_M
BKRST	BKRST_M	DROR	DROR_M	PSTOP	PSTOP_M
BKXNR	BKXNR_M	DSER	DSER_M	QCDSET	QCDSET_M
BKXOR	BKXOR_M	DSFL	DSFL_M	QDRSET	QDRSET_M
BMOV	BMOV_M	DSFR	DSFR_M	RCL	RCL_M
BRST	BRST_M	DSORT	DSORT_M	RCR	RCR_M
BSET	BSET_M	DSUM	DSUM_M	RFS	RFS_M
BSFL	BSFL_M	DTEST	DTEST_MD	RIGHT	RIGHT <sup>*1</sup>
BSFR	BSFR_M	DTO	DTO_M	RND	RND_M
BSIN	BSIN_MD	DWSUM	DWSUM_M	ROL_E	ROL <sup>*1</sup>
BSQR	BSQR_MD	DXCH	DXCH_M	ROR_E	ROR <sup>*1</sup>
BTAN	BTAN_MD	DXNR	DXNR_M	RSET	RSET_MD
BTOW	BTOW_MD	DXOR	DXOR_M	RST	RST_M
BXCH	BXCH_M	DZONE	DZONE_MD	SECOND	SECOND_M
CML	CML_M	EI	EI_M	SEG	SEG_M
COM	COM_M	EMOD	EMOD_M	SER	SER_M
COS	COS <sup>*1</sup>	ENCO	ENCO_M	SET	SET_M
DATERD	DATERD_MD	ENEG	ENEG_M	SFL	SFL_M
DATEWR	DATEWR_MD	EREXP	EREXP_M	SFR	SFR_M
DBAND	DBAND_MD	ESTR	ESTR_M	SFT	SFT_M
DBCD	DBCD_M	EVAL	EVAL_M	SIN	SIN <sup>*1</sup>
DBIN	DBIN_M	EXP	EXP <sup>*1</sup>	SORT	SORT_M
DBL	DBL_M	FLT	FLT_M	SRND	SRND_M
DCML	DCML_M	FMOV	FMOV_M	STOP	STOP_M
DDEC	DDEC_M	FROM	FROM_M	SUM	SUM_M
DEC	DEC_M	GBIN	GBIN_M	SWAP	SWAP_MD
DECO	DECO_M	GRY	GRY_M	TAN	TAN <sup>*1</sup>
DELTA	DELTA_M	HOUR	HOUR_M	TEST	TEST_MD

GX Works2	GX Developer
UNI	UNI_M
WAND	WAND_M
WDT	WDT_M
WOR	WOR_M

GX Works2	GX Developer
WSUM	WSUM_M
WTOB	WTOB_MD
WXNR	WXNR_M

GX Works2	GX Developer
WXOR	WXOR_M
XCH	XCH_M
ZONE	ZONE_MD

\*1 : Devices/labels need to be changed according to the arguments of GX Developer instructions.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## Appendix 9 Character Strings that cannot be Used for Label Names and Data Names

Q CPU L CPU Remote Head FX

Character strings used for application function names, common instruction names, special instruction names, instructions and so on are called reserved words.

These reserved words cannot be used for label names or data names. If the character string defined as a reserved word is used for a label name or data name, an error occurs during registration or compilation.

The following tables shows character strings that cannot be used for label names or data names. The numbers from ① to ⑨ in the tables indicate the following label names and data names.

- <Label name and data name>
- ① Project file name
- ② Program file name (Simple (without labels))
- ③ Program file name (Simple (with labels))
- ④ Program file name (structure)
- ⑤ Task name
- ⑥ Global label data name
- ⑦ Structure name
- ⑧ POU name
- ⑨ Label name

○: Applicable, △: With restrictions, ×: Not applicable

Category	Character string	①	②	③	④	⑤	⑥	⑦	⑧	⑨
Class identifier	VAR, VAR_RETAIN, VAR_ACCESS, VAR_CONSTANT, VAR_CONSTANT_RETAIN, VAR_INPUT, VAR_INPUT_RETAIN, VAR_OUTPUT, VAR_OUTPUT_RETAIN, VAR_IN_OUT, VAR_EXTERNAL, VAR_EXTERNAL_CONSTANT, VAR_EXTERNAL_CONSTANT_RETAIN, VAR_EXTERNAL_RETAIN, VAR_GLOBAL, VAR_GLOBAL_CONSTANT, VAR_GLOBAL_CONSTANT_RETAIN, VAR_GLOBAL_RETAIN	×	○	×	×	×	×	×	×	×
Data type	BOOL, BYTE, INT, SINT, DINT, LINT, UINT, USINT, UDINT, ULINT, WORD, DWORD, LWORD, ARRAY, REAL, LREAL, TIME, STRING, TIMER, COUNTER, RETENTIVETIMER, POINTER, Bit, Word [Unsigned]/Bit String [16-bit], Double Word [Unsigned]/Bit String [32-bit], Word [Signed], Double Word [Signed], FLOAT (Single Precision), FLOAT (Double Precision), String, Time, Timer, Counter, Retentive Timer, Pointer	○	○	×	×	×	×	×	×	×
Data type hierarchy	ANY, ANY_NUM, ANY_BIT, ANY_REAL, ANY_INT, ANY_DATE	○	○	×	×	×	×	×	×	×
	ANY_SIMPLE, ANY16, ANY32	○	○	○	○	○	○	○	△*1	×
Device name	X, Y, D, M, T, B, C, F, L, P, V, Z, W, I, N, U, J, K, H, E, A, SD, SM, SW, SB, FX, FY, DX, DY, FD, TR, BL, SG, VD, ZR, ZZ*2	○	○	○	○	○	○	○	△*1	×
Character string recognized as device (Device name + Numeral)	Such as X0	○	○	×	×	×	×	×	△*3	×
ST operator	NOT, MOD	○	○	×	×	×	×	×	×	×
	(, ), -	○	○	○	○	○	○	○	△*1	×
IL operator	LD, LDN, ST, STN, S, S1, R, R1, AND, ANDN, OR, ORN, XOR, XORN, ADD, SUB, MUL, DIV, GT, GE, EQ, NE, LE, LT, JMP, JMPC, JMPCN, CAL, CALC, CALCN, RET, RETC, RETCN	×	○	×	×	×	×	×	×	×
	LDI, LDP, LDF, ANI, ANDP, ANDP, ANB, ORI, ORP, ORF, ORB, MPS, MRD, MPP, INV, MEP, MEF, EGP, EGF, OUT(H), SET, RST, PLS, PLF, FF, DELTA(P), SFT(P), MC, MCR, STOP, PAGE, NOP, NOPLF	○	○	○	○	○	○	○	○	△*1



Category	Character string	①	②	③	④	⑤	⑥	⑦	⑧	⑨
Application instruction in GX Works2	Application instructions such as DMOD, PCHK, and INC(P) (MELSEC-Q/L Programming Manual (Common Instructions), MELSEC-Q/L Structured Programming Manual (Common Instructions))	○	○	○	○	○	○	○	△*1	×
SFC instruction	SFCP, SFCPEND, BLOCK, BEND, TRANL, TRANO, TRANA, TRANC, TRANCA, TRANO, SEND, TRANOC, TRANOCA, TRANCO, TRANOC, STEP, STEP, STEPSC, STEPSE, STEPST, STEPR, STEPC, STEPG, STEPI, STEPID, STEPISC, STEPISE, STEPIST, STEPIR, TRANJ, TRANOJ, TRANOCJ, TRANCJ, TRANCOJ, TRANCOJ	○	○	○	○	○	○	○	△*1	×
ST code body	RETURN, IF, THEN, ELSE, ELSIF, END_IF, CASE, OF, END_CASE, FOR, TO, BY, DO, END_FOR, WHILE, END_WHILE, REPEAT, UNTIL, END_REPEAT, EXIT, TYPE, END_TYPE, STRUCT, END_STRUCT, RETAIN, VAR_ACCESS, END_VAR, FUNCTION, END_FUNCTION, FUNCTION_BLOCK, END_FUNCTION_BLOCK, STEP, INITIAL_STEP, END_STEP, TRANSITION, END_TRANSITION, FROM, UNTILWHILE	○	○	×	×	×	×	×	×	×
Function name in application function	Function names in application functions such as AND_E and NOT_E	○	○	○	○	○	○	×	×	×
Function block name in application function	Function block names in application functions such as CTD and CTU	○	○	○	○	○	○	×	×	×
Symbol	/, \, *, ?, <, >,  , ", ;, %, ', ,, tab character	×	×	×	×	×	×	×	×	×
	[, ], ,, =, +, ~, @, {, }, &, ^, ;	○	×	×	×	×	×	×	×	×
	!, #, \$, `	○	○	○	○	○	○	○	○	×
Date and time literal	DATE, DATE_AND_TIME, DT, TIME, TIME_OF_DAY, TOD	×	○	×	×	×	×	×	×	×
Others	ACTION, END_ACTION, CONFIGURATION, END_CONFIGURATION, CONSTANT, F_EDGE, R_EDGE, AT, PROGRAM, WITH, END_PROGRAM, TRUE, FALSE, READ_ONLY, READ_WRITE, RESOURCE, END_RESOURCE, ON, TASK, EN, ENO, BODY_CCE, BODY_FBD, BODY_IL, BODY_LD, BODY_SFC, BODY_ST, END_BODY, END_PARAMETER_SECTION, PARAMETER_SECTION, SINGLE, RETAIN, TRUE, FALSE, INTERVAL, PRIORITY	×	○	×	×	×	×	×	×	×
String that starts with K1 to K8	Such as K1AAA	○	○	○	○	○	○	○	△*1	×
Address	Such as %IX0	○	×	×	×	×	×	×	×	×
Statement in Ladder Diagram	;FB BLK START, ;FB START, ;FB END, ;FB BLK END, ;FB IN, ;FB OUT, ;FB_NAME, ;INSTANCE_NAME, ;FB, ;INSTANCE	○	×	×	×	×	×	×	×	×
Common instruction	Such as MOV	○	○	×	○	○	×	×	△*3	×
Windows® reserved word	COM1, COM2, COM3, COM4, COM5, COM6, COM7, COM8, COM9, LPT1, LPT2, LPT3, LPT4, LPT5, LPT6, LPT7, LPT8, LPT9, AUX, CON, PRN, NUL	×	×	×	×	×	×	×	×	○

\*1 : Functions cannot be used.

\*2 : Whether to handle a device name indexed with ZZ device as a reserved word depends on the parameter setting.  
 When Z device is specified for 32-bit index setting: Not handled as a reserved word  
 When ZZ device is specified for 32-bit index setting: Handled as a reserved word

\*3 : Applicable to Simple projects without labels only.



● Surrogate pair characters and environment dependent characters

Surrogate pair characters and environment dependent characters are not available in GX Works2.

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

## ■ Considerations for using labels

---

- In a function, the same name as the function cannot be used for a label.
- Inapplicable character strings differ between label names and data names such as function block names and structure names. Therefore, if a label name which contains a function block name or a structure name is set when setting a label of instance or structure, an error may occur.
- A space cannot be used.
- A numeral cannot be used at the beginning of label name.
- A label name is not case-sensitive. An error may occur at compilation when the same label names with different cases (example: 'AAA' and 'aaa') are declared.
- In Structured Ladder/FBD and ST programs, the same label name can be used for a global label and local label by setting the following option\*1.
  - \*1 : Select "Use the same label name in global label and local label" under [Tool] ⇒ [Options] ⇒ "Compile" ⇒ "Basic Setting".
- An underscore (\_) cannot be used at the beginning or end of label name.  
Consecutive underscores (\_\_) cannot be used for a data name or a label name.
- For Simple projects, function names and function block names in common instructions and application functions can be used.

# Appendix 10 Restrictions When Changing Programmable Controller Type



\*1 : CC IE Field head module only

The following explains the restrictions applied when changing a programmable controller series or type.

For the restrictions applied when changing a programmable controller type between QCPU (Q mode)/LCPU and QCPU (Q mode)/LCPU, refer to Appendix 10.1 and the following table.

For the restrictions applied when changing a programmable controller type between QCPU (Q mode)/LCPU and CC IE Field head module, refer to Appendix 10.11.

For the restrictions applied when changing a programmable controller type of FXCPU, refer to Appendix 10.12.

Old programmable controller type	New programmable controller type				
	Basic model QCPU	High Performance model QCPU	Process CPU	Redundant CPU	QnUD(H)CPU
Basic model QCPU	Table App.10.9-1	Table App.10.8-4	Table App.10.7-1	Table App.10.6-1	Table App.10.2-7
High Performance model QCPU	Table App.10.9-1 Table App.10.9-2	–	Table App.10.7-1	Table App.10.6-1	Table App.10.2-1
Process CPU	Table App.10.9-1 Table App.10.9-5	Table App.10.8-3	–	Table App.10.6-1 Table App.10.6-3	Table App.10.2-6
Redundant CPU	Table App.10.9-1 Table App.10.9-4	Table App.10.8-2	Table App.10.7-1 Table App.10.7-3	–	Table App.10.2-5
QnUD(H)CPU	Table App.10.9-1 Table App.10.9-3	Table App.10.8-1	Table App.10.7-1	Table App.10.6-1	–
Q00U, Q00UJ, Q01U, Q02U	Table App.10.9-1 Table App.10.9-3	Table App.10.8-1	Table App.10.7-1	Table App.10.6-1	Table App.10.2-2
QnUDE(H)CPU	Table App.10.9-1 Table App.10.9-3	Table App.10.8-1	Table App.10.7-1	Table App.10.6-1	Table App.10.2-3
High-speed Universal model QCPU/ Universal model process CPU	Table App.10.9-1 Table App.10.9-3	Table App.10.8-1 Table App.10.8-5	Table App.10.7-1 Table App.10.7-2	Table App.10.6-1 Table App.10.6-2	Table App.10.2-4
LCPU	Table App.10.9-1 Table App.10.9-6	Table App.10.8-6	Table App.10.7-1 Table App.10.7-4	Table App.10.6-1 Table App.10.6-4	Table App.10.2-8

Old programmable controller type	New programmable controller type			
	Q00U, Q00UJ, Q01U, Q02U	QnUDE(H)CPU	High-speed Universal model QCPU/ Universal model process CPU	LCPU
Basic model QCPU	Table App.10.3-1 Table App.10.3-8	Table App.10.4-6	Table App.10.5-7	Table App.10.10-1 Table App.10.10-9
High Performance model QCPU	Table App.10.3-1 Table App.10.3-2	Table App.10.4-1	Table App.10.5-1	Table App.10.10-1 Table App.10.10-2
Process CPU	Table App.10.3-1 Table App.10.3-7	Table App.10.4-5	Table App.10.5-6	Table App.10.10-1 Table App.10.10-8
Redundant CPU	Table App.10.3-1 Table App.10.3-6	Table App.10.4-4	Table App.10.5-5	Table App.10.10-1 Table App.10.10-7
QnUD(H)CPU	Table App.10.3-1 Table App.10.3-3	–	Table App.10.5-3	Table App.10.10-1 Table App.10.10-3
Q00U, Q00UJ, Q01U, Q02U	Table App.10.3-1	Table App.10.4-2	Table App.10.5-2	Table App.10.10-1 Table App.10.10-4
QnUDE(H)CPU	Table App.10.3-1 Table App.10.3-4	–	Table App.10.5-4	Table App.10.10-1 Table App.10.10-5

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

Old programmable controller type	New programmable controller type			
	Q00U,Q00UJ, Q01U,Q02U	QnUDE(H)CPU	High-speed Universal model QCPU/ Universal model process CPU	LCPU
High-speed Universal model QCPU/ Universal model process CPU	Table App.10.3-1 Table App.10.3-5	Table App.10.4-3	–	Table App.10.10-1 Table App.10.10-6
LCPU	Table App.10.3-1 Table App.10.3-9	Table App.10.4-7	Table App.10.5-8	Table App.10.10-1 Table App.10.10-10

## Appendix 10.1 Common restrictions when changing programmable controller series/types

The following table shows the common restrictions applied when changing a programmable controller series or type.

Table App.10.1-1

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Connection destination setting	<ul style="list-style-type: none"> <li>Connection destination data other than "Connection 1" are deleted. Connection 1 is changed to the setting for accessing the programmable controller CPU directly to a personal computer.</li> <li>If the changed programmable controller type is Basic model QCPU/FXCPU, 'RS-232' is set to "PC side I/F".</li> <li>If the changed programmable controller type is other than Basic model QCPU/FXCPU, 'USB' is set for "PC side I/F".</li> <li>An Ethernet adapter is set to "Not Specified" for Ethernet board in "PC side I/F".</li> </ul>	△	△	△
Compilation status	<ul style="list-style-type: none"> <li>Programs are set in the uncompiled status.</li> </ul>	–	△	△
Saved project status	<ul style="list-style-type: none"> <li>Programs are changed in the project-unsaved status.</li> </ul>	△	△	△
Password/Keyword status	<ul style="list-style-type: none"> <li>Passwords returns to the registered status if unlocked.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>Unsupported instructions, devices outside the range, and unsupported index settings are changed to SM1255 or SD1255 (SM999 or SD999).</li> </ul>	△	–	–
Ladder Diagram	<ul style="list-style-type: none"> <li>If a program exceeds the program capacity of the changed programmable controller type, the exceeding ladder blocks are deleted.</li> </ul>	△	–	–
	<ul style="list-style-type: none"> <li>A ladder block containing an unsupported instruction is displayed in yellow. (Motion dedicated sequence instructions for changing from QnUD(H)CPU or Built-in Ethernet port QCPU to LCPU are excluded.)</li> <li>Instructions with devices outside the range or unsupported index settings are deleted, and the ladder block is displayed in yellow.</li> </ul>	–	△	△
Structured Ladder/FBD	<ul style="list-style-type: none"> <li>An x mark is appended on an element of an unsupported instruction.</li> </ul>	–	–	△
Library	<ul style="list-style-type: none"> <li>Common instructions/application functions are changed to libraries appropriate for the changed programmable controller type.</li> </ul>	–	–	△

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Global Device Comment	<ul style="list-style-type: none"> <li>Devices not supported by the changed programmable controller type and those outside the range are deleted.</li> </ul>	△	△	△
Local Device Comment				
Device Initial Value				
PLC Parameter Network Parameter	<ul style="list-style-type: none"> <li>Settings are changed to those appropriate for the changed programmable controller type.</li> <li>The default values in the changed programmable controller series/type are set to the data which cannot be edited in the changed programmable controller series/type.</li> <li>The module models and points of Input, Output, and I/O Mix displayed on the &lt;&lt;I/O Assignment&gt;&gt; tab are not changed depending on the programmable controller series.</li> <li>Network types which cannot be set for the changed programmable controller type are deleted.</li> <li>When the module set as "Valid Module During Other Station Access" is to be deleted at the programmable controller type change (module not supported by the changed programmable controller type), the first module is set as the valid module.</li> <li>If the number of device points set for the refresh device is outside the range or the device is not available, the setting for the refresh device is deleted.</li> </ul>	△	△	△
Device/Label Automatic-Assign Setting	<ul style="list-style-type: none"> <li>Settings are changed to those appropriate for the changed programmable controller type.</li> <li>The default values in the changed programmable controller series/type are set to the data which cannot be edited in the changed programmable controller series/type.</li> <li>When the programmable controller type is changed from the project in which "Pointer Extended Setting for Automatic-Assign Device" is set to the project that does not have "Pointer Extended Setting for Automatic-Assign Device", the pointer assignment range is changed to those appropriate for the changed programmable controller type.</li> </ul>	-	△	△

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## Appendix 10.2 Restrictions when changing to QnUD(H)CPU

The following tables show the restrictions applied when changing a programmable controller series/type to QnUD(H)CPU.

### ■ Changing from High Performance model QCPU

Table App.10.2-1

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	<ul style="list-style-type: none"> <li>If "Convert motion dedicated sequence instruction" is selected, S.instructions are converted to D.instructions. (Appendix 11)</li> </ul>	△	–	–
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property settings "SFC Program Type Setting", "Periodic Execution Block", and "Act at Step Multi-Activated" are deleted.</li> </ul>	△	△	△
PLC Parameter	–	–	–	–
PLC System	<ul style="list-style-type: none"> <li>If the constant scan time is set in the PLC RAS setting, "Execute it while waiting for constant scan setting" is set to the service processing setting in the PLC System setting.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If "Low Speed" is set to "Execute Type" in the Program setting, it is changed to "Standby".</li> </ul>	△	△	△
Boot File	<ul style="list-style-type: none"> <li>If "Standard ROM" is set to "Transfer from", it is changed to "Memory Card (ROM)".</li> </ul>	△	△	△

### ■ Changing from Q00U, Q00UJ, Q01U, or Q02U

Table App.10.2-2

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	<ul style="list-style-type: none"> <li>A series-compatible SM/SD devices (SM/SD1000 to SM/SD1255) are changed to the corresponding devices for Q series.</li> <li>If "Convert motion dedicated sequence instruction" is selected, S.instructions are converted to D.instructions. (Appendix 11)</li> </ul>	△	–	–
Remote Password	<ul style="list-style-type: none"> <li>Any existing settings are cleared.</li> </ul>	△	△	△

■ Changing from QnUDE(H)CPU

Table App.10.2-3

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Remote Password	<ul style="list-style-type: none"> <li>Only the settings of Ethernet Built-in CPU are cleared.</li> </ul>	△	△	△

■ Changing from High-speed Universal model QCPU or Universal model process CPU

Table App.10.2-4

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Remote Password	<ul style="list-style-type: none"> <li>Only the settings of Ethernet Built-in CPU are cleared.</li> </ul>	△	△	△
PLC Parameter	–	–	–	–
Device	<ul style="list-style-type: none"> <li>If the value exceeds the capacity of changed programmable controller type is set for "File Register Extended Setting", the maximum value is set and all points are set as file register (ZR(R)). The setting of the latch range is cleared.</li> </ul>	△	△	△
Built-in Ethernet Port Setting	<ul style="list-style-type: none"> <li>Any existing settings in "CC-Link IEF Basic Setting" are deleted.</li> </ul>	△	△	△
Block Password	<ul style="list-style-type: none"> <li>For a project including a block password for which the execution program protection setting was enabled, the programmable controller type cannot be changed to one other than a high-speed universal model QCPU, a universal model process CPU, and an LCPU.</li> </ul>	△	△	△

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
—	INDEX

## ■ Changing from Redundant CPU

Table App.10.2-5

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property settings "SFC Program Type Setting", "Periodic Execution Block", and "Act at Step Multi-Activated" are deleted.</li> </ul>	△	△	△
PLC Parameter	–	–	–	–
PLC System	<ul style="list-style-type: none"> <li>If the constant scan time is set in the PLC RAS setting, "Execute it while waiting for constant scan setting" is set to the service processing setting in the PLC System setting.</li> </ul>	△	△	△
Boot File	<ul style="list-style-type: none"> <li>If "Standard ROM" is set to "Transfer from", it is changed to "Memory Card (ROM)".</li> </ul>	△	△	△
I/O Assignment	<ul style="list-style-type: none"> <li>Settings on the slot 0 are deleted.</li> <li>If any slot after the slot 1 is set, "Empty" is set for "Type" and "0 Point" is set for "Points" on the slot 0.</li> </ul>	△	△	△
Network Parameter	–	–	–	–
Ethernet	<ul style="list-style-type: none"> <li>"Ethernet (Main Base)" or "Ethernet (Extension Base)" is changed to "Ethernet".</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>"Master station (Extension Base)" is changed to "Master Station".</li> </ul>	△	△	△



■ Changing from Process CPU

Table App.10.2-6

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	<ul style="list-style-type: none"> <li>If "Convert motion dedicated sequence instruction" is selected, S.instructions are converted to D.instructions. (Appendix 11)</li> </ul>	△	-	-
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property settings "SFC Program Type Setting", "Periodic Execution Block", and "Act at Step Multi-Activated" are deleted.</li> </ul>	△	△	△
PLC Parameter	-	-	-	-
PLC System	<ul style="list-style-type: none"> <li>If the constant scan time is set in the PLC RAS setting, "Execute it while waiting for constant scan setting" is set to the service processing setting in the PLC System setting.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If "Low Speed" is set to "Execute Type" in the Program setting, it is changed to "Standby".</li> </ul>	△	△	△
Boot File	<ul style="list-style-type: none"> <li>If "Standard ROM" is set to "Transfer from", it is changed to "Memory Card (ROM)".</li> </ul>	△	△	△

■ Changing from Basic model QCPU

Table App.10.2-7

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	<ul style="list-style-type: none"> <li>If "Convert motion dedicated sequence instruction" is selected, S.instructions are converted to D.instructions. (Except for Q00J. Appendix 11)</li> </ul>	△	-	-
PLC Parameter	-	-	-	-
PLC File	<ul style="list-style-type: none"> <li>When changing from Q00 or Q01, "Use the following file" is selected and "Corresponding Memory: Standard RAM", "File Name: MAIN", and "Capacity: 64K Points" are set in the file register setting.</li> </ul>	△	△	△
Boot File	<ul style="list-style-type: none"> <li>If "Do boot from standard ROM" is selected before changing the programmable controller type, "Type: Sequence", "Data Name: MAIN", "Transfer From: Memory Card (ROM)", and "Transfer To: Program Memory" are set.</li> </ul>	△	△	△

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

## ■ Changing from LCPU

Table App.10.2-8

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Remote Password	<ul style="list-style-type: none"> <li>When changing from L02S/L02S-P or L02/L02-P, any existing settings are cleared.</li> <li>When changing from L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, the following settings are set. <ul style="list-style-type: none"> <li>The settings of the built-in Ethernet are cleared.</li> <li>The settings of LJ71C24 are replaced to the settings of QJ71C24/CMO.</li> <li>The settings of LJ71E71 are replaced to the settings of QJ71E71.</li> </ul> </li> </ul>	△	△	△
PLC Parameter	–	–	–	–
I/O Assignment	<ul style="list-style-type: none"> <li>Settings of "Built-in I/O Function Setting" and "Built-in CC-Link Setting" are deleted.</li> </ul>	△	△	△
Built-in Ethernet Port Setting	<ul style="list-style-type: none"> <li>When changing from Built-in Ethernet port LCPU, any existing settings in "CC-Link IEF Basic Setting" are deleted.</li> </ul>	△	△	△
Network Parameter	–	–	–	–
CC-Link IE Field Network	<ul style="list-style-type: none"> <li>If the number of modules is one and "Start I/O No." is outside the range, its maximum value is set. If the number of modules is two, "Start I/O No." is set starting from 0000.</li> <li>The IP address setting of "Network Operation Settings" for CC IE Field (Master Station) is deleted.</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>If "H/W Test" or "Loop Test" is set to "Mode", the setting is deleted.</li> </ul>	△	△	△
Block Password	<ul style="list-style-type: none"> <li>For a project including a block password for which the execution program protection setting was enabled, the programmable controller type cannot be changed to one other than a high-speed universal model QCPU, a universal model process CPU, and an LCPU.</li> </ul>	△	△	△

## Appendix 10.3 Restrictions when changing to Q00U, Q00UJ, Q01U, or Q02U

The following tables show the restrictions applied when changing a programmable controller series/type to Q00U, Q00UJ, Q01U, or Q02U.

### Common restrictions when changing to Q00U, Q00UJ, Q01U, or Q02U

Table App.10.3-1

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Remote Password	• Any existing settings are cleared.	△	△	△
PLC Parameter	–	–	–	–
I/O Assignment	• If a multiple CPU is set to "Type", it is deleted and closed up. • If a value which exceeds the maximum base number for the changed programmable controller type is set, the exceeding base settings are deleted.	△	△	△
Multiple CPU	• If the number of multiple CPUs exceeds the allowable number, the settings are set to default.	△	△	△
Network Parameter	–	–	–	–
Ethernet	• When changing to Q02U, the third and later Ethernet modules in the module settings are deleted. • When changing to Q00UJ/Q00U/Q01U, the second and later Ethernet modules in the module setting are deleted.	△	△	△
MELSECNET/10(H), CC-Link IE Controller Network	• When changing to Q02U, the third and later modules out of total of MELSECNET/10(H) and CC-Link IE Controller Network modules are deleted. • When changing to Q00UJ/Q00U/Q01U, the second and later modules out of total of MELSECNET/10(H) and CC-Link IE Controller Network modules are deleted.	△	△	△
CC-Link	• When changing to Q02U, the fifth and later modules are deleted. • When changing to Q00UJ/Q00U/Q01U, the third and later modules are deleted.	△	△	△

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## ■ Changing from High Performance model QCPU

Table App.10.3-2


△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	—	—	—	—
Sequential Function Chart	• The property settings "SFC Program Type Setting", "Periodic Execution Block", "Act at Block Multi-Activated", and "Act at Step Multi-Activated" are deleted.	△	△	△
PLC Parameter	—	—	—	—
PLC System	• If the constant scan time is set in the PLC RAS setting, "Execute it while waiting for constant scan setting" is set to the service processing setting in the PLC System setting.	△	△	△
Program	• If the number of programs exceeds the allowable number, the exceeding settings are deleted. • If "Low Speed" is set to "Execute Type" in the Program setting, it is changed to "Standby".	△	△	△
Boot File	• If "Standard ROM" is set to "Transfer from", it is changed to "Memory Card (ROM)". (Q02U only)	△	△	△

## ■ Changing from QnUD(H)CPU

Table App.10.3-3


△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	• If "Convert motion dedicated sequence instruction" is selected, D.instructions are converted to S.instructions. (Except for Q00UJ.  Appendix 11)	△	—	—
Sequential Function Chart	• The property setting "Act at Block Multi-Activated" is deleted.	△	△	△
PLC Parameter	—	—	—	—
PLC File	• If "Capacity" exceeds 16K points in "File used for SP.DEVST/S.DEVLD Instruction", the setting is set to 16K points for Q02U, and 1K points for Q00U, Q00UJ, and Q01U.	△	△	△
Program	• If the number of programs exceeds the allowable number, the settings are set to default.	△	△	△
Device	• If the points exceeding 8K points are specified for S device, the setting is set to 8K points.	△	△	△

■ Changing from QnUDE(H)CPU

Table App.10.3-4

△: With restrictions


Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	<ul style="list-style-type: none"> <li>If "Convert motion dedicated sequence instruction" is selected, D.instructions are converted to S.instructions. (Except for Q00UJ.  Appendix 11)</li> </ul>	△	-	-
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property setting "Act at Block Multi-Activated" is deleted.</li> </ul>	△	△	△
PLC Parameter	-	-	-	-
PLC System	<ul style="list-style-type: none"> <li>If a device that exceed the range of the Device setting is set to "Latch Data Backup Operation Valid Contact", the setting is deleted.</li> </ul>	△	△	△
PLC File	<ul style="list-style-type: none"> <li>If the capacity exceeds 16K points in "File used for SP.DEVST/S.DEVLD Instruction", the setting is set to 16K points for Q02U, and 1K points for Q00U, Q00UJ, and Q01U.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If the number of programs exceeds the allowable number, the settings are set to default.</li> </ul>	△	△	△
Device	<ul style="list-style-type: none"> <li>If the points exceeding 8K points are specified for S device, the setting is set to 8K points.</li> </ul>	△	△	△

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

■ Changing from High-speed Universal model QCPU or Universal model process CPU

Table App.10.3-5

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	<ul style="list-style-type: none"> <li>If "Convert motion dedicated sequence instruction" is selected, D.instructions are converted to S.instructions. (Except for Q00UJ.  Appendix 11)</li> </ul>	△	–	–
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property setting "Act at Block Multi-Activated" is deleted.</li> </ul>	△	△	△
Remote Password	<ul style="list-style-type: none"> <li>Any existing settings are cleared.</li> </ul>	△	△	△
PLC Parameter	–	–	–	–
PLC System	<ul style="list-style-type: none"> <li>If a device that exceed the range of the Device setting is set to "Latch Data Backup Operation Valid Contact", the setting is deleted.</li> </ul>	△	△	△
PLC File	<ul style="list-style-type: none"> <li>If the capacity exceeds 16K points in "File used for SP.DEVST/ S.DEVLD Instruction", the setting is set to 16K points for Q02U, and 1K points for Q00U, Q00UJ, and Q01U.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If the number of programs exceeds the allowable number, the settings are set to default.</li> </ul>	△	△	△
Device	<ul style="list-style-type: none"> <li>If the value exceeds the capacity of changed programmable controller type is set for "File Register Extended Setting", the maximum value is set and all points are set as file register (ZR(R)). The setting of the latch range is cleared.</li> <li>If the points exceeding 8K points are specified for S device, the setting is set to 8K points.</li> </ul>	△	△	△
Built-in Ethernet Port Setting	<ul style="list-style-type: none"> <li>Any existing settings in "CC-Link IEF Basic Setting" are deleted.</li> </ul>	△	△	△
Block Password	<ul style="list-style-type: none"> <li>For a project including a block password for which the execution program protection setting was enabled, the programmable controller type cannot be changed to one other than a high-speed universal model QCPU, a universal model process CPU, and an LCPU.</li> </ul>	△	△	△

■ Changing from Redundant CPU

Table App.10.3-6

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property settings "SFC Program Type Setting", "Periodic Execution Block", "Act at Block Multi-Activated", and "Act at Step Multi-Activated" are deleted.</li> </ul>	△	△	△
PLC Parameter	–	–	–	–
PLC System	<ul style="list-style-type: none"> <li>If the constant scan time is set in the PLC RAS setting, "Execute it while waiting for constant scan setting" is set to the service processing setting in the PLC System setting.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If the number of programs exceeds the allowable number, the exceeding settings are deleted.</li> </ul>	△	△	△
Boot File	<ul style="list-style-type: none"> <li>If "Standard ROM" is set to "Transfer from", it is changed to "Memory Card (ROM)".</li> </ul>	△	△	△
I/O Assignment	<ul style="list-style-type: none"> <li>Settings on the slot 0 are deleted.</li> <li>If any slot after the slot 1 is set, "Empty" is set for "Type" and "0 Point" is set for "Points" on the slot 0.</li> </ul>	△	△	△
Network Parameter	–	–	–	–
Ethernet	<ul style="list-style-type: none"> <li>"Ethernet (Main Base)" or "Ethernet (Extension Base)" is changed to "Ethernet".</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>"Master station (Extension Base)" is changed to "Master Station".</li> </ul>	△	△	△

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

## ■ Changing from Process CPU

Table App.10.3-7

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property settings "SFC Program Type Setting", "Periodic Execution Block", "Act at Block Multi-Activated", and "Act at Step Multi-Activated" are deleted.</li> </ul>	△	△	△
PLC Parameter	–	–	–	–
PLC System	<ul style="list-style-type: none"> <li>If the constant scan time is set in the PLC RAS setting, "Execute it while waiting for constant scan setting" is set to the service processing setting in the PLC System setting.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If the number of programs exceeds the allowable number, the exceeding settings are deleted.</li> <li>If "Low Speed" is set to "Execute Type" in the Program setting, it is changed to "Standby".</li> </ul>	△	△	△
Boot File	<ul style="list-style-type: none"> <li>If "Standard ROM" is set to "Transfer from", it is changed to "Memory Card (ROM)".</li> </ul>	△	△	△

## ■ Changing from Basic model QCPU

Table App.10.3-8

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
PLC Parameter	–	–	–	–
PLC File	<ul style="list-style-type: none"> <li>When changing from Q00 or Q01 to other than Q00UJ, "Use the following file" is selected and "Corresponding Memory: Standard RAM", "File Name: MAIN", and "Capacity: 64K Points" are set in the File Register setting.</li> <li>When changing from Q00 or Q01 to Q00UJ, "Not Used" is selected in the File Register setting.</li> </ul>	△	△	△
Device/Label Automatic-Assign Setting	<ul style="list-style-type: none"> <li>When changing from Q00 or Q01 to Q00UJ, the default value is set.</li> </ul>	–	△	△



■ Changing from LCPU

Table App.10.3-9

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property setting "Act at Block Multi-Activated" is deleted.</li> </ul>	△	△	△
Remote Password	<ul style="list-style-type: none"> <li>When changing from L02/L02-P to Q00U or Q01U, the remote password set for the built-in Ethernet of CPU module is cleared.</li> <li>When changing from L02S/L02S-P or L02/L02-P to Q00U or Q01U, the following settings are set.                             <ul style="list-style-type: none"> <li>The settings of LJ71C24 are replaced to the settings of QJ71C24/CMO.</li> <li>The settings of LJ71E71 are replaced to the settings of QJ71E71.</li> </ul> </li> </ul>	△	△	△
PLC Parameter	–	–	–	–
PLC System	<ul style="list-style-type: none"> <li>If "Start I/O No." in the interrupt pointer setting of the intelligent function module setting is outside the range, the setting is deleted.</li> <li>When changing to Q00UJ, if the number of points is outside the range, its maximum point is set.</li> </ul>	△	△	△
PLC File	<ul style="list-style-type: none"> <li>When changing to Q00U, Q00UJ, or Q01U, if an item other than "Program Memory" or "Standard ROM" is set to "Corresponding Memory" in the initial device value setting, it is changed to "Program Memory".</li> <li>When changing to Q00U, Q00UJ, or Q01U, if the capacity exceeds 1K points in "File used for SP.DEVST/S.DEVLD Instruction", the setting is set to 1K point.</li> <li>When changing from L06/L06-P, L26/L26-P, or L26-BT/L26-PBT to Q02U, if the capacity exceeds 16K points in "File used for SP.DEVST/ S.DEVLD Instruction", the setting is set to 16K points.</li> </ul>	△	△	△
PLC RAS	<ul style="list-style-type: none"> <li>When changing to Q00UJ, "System Memory" is set to "Corresponding Memory".</li> <li>When changing to Q00U, Q00UJ, or Q01U, if the number of samplings is outside the range, its maximum number is set.</li> <li>When changing to Q00UJ, if the number of revisions is outside the range, its maximum number is set. If the number of revisions is less than '40', '40' is set.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If the number of programs exceeds the allowable number, the exceeded programs are deleted.</li> </ul>	△	△	△
Device	<ul style="list-style-type: none"> <li>If the points exceeding 8K points are specified for S device, the setting is set to 8K points.</li> </ul>	△	△	△
I/O Assignment	<ul style="list-style-type: none"> <li>Settings of "Built-in I/O Function Setting" and "Built-in CC-Link Setting" are deleted.</li> </ul>	△	△	△
Built-in Ethernet Port Setting	<ul style="list-style-type: none"> <li>When changing from Built-in Ethernet port LCPU, any existing settings of "CC-Link IEF Basic Setting" are deleted.</li> </ul>	△	△	△

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Network Parameter	–	–	–	–
CC-Link IE Field Network	<ul style="list-style-type: none"> <li>If the number of modules is one and "Start I/O No." is outside the range, its maximum value is set. If the number of modules is two, "Start I/O No." is set starting from 0000.</li> <li>The IP address setting of "Network Operation Settings" for CC IE Field (Master Station) is deleted.</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>If "H/W Test" or "Loop Test" is set to "Mode", the setting is deleted.</li> <li>When changing to Q00UJ, or when changing from L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, if the number of modules is one and "Start I/O No." is outside the range, its maximum value is set. If the number of modules is two or more and the start I/O number is outside the range, "Start I/O No." is set starting from 0000.</li> <li>When changing from L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, if the number of slots exceeds the maximum number of slots of the changed programmable controller type, the exceeded setting is deleted.</li> </ul>	△	△	△
Block Password	<ul style="list-style-type: none"> <li>For a project including a block password for which the execution program protection setting was enabled, the programmable controller type cannot be changed to one other than a high-speed universal model QCPU, a universal model process CPU, and an LCPU.</li> </ul>	△	△	△

## Appendix 10.4 Restrictions when changing to QnUDE(H)CPU

The following tables show the restrictions applied when changing a programmable controller series/type to QnUDE(H)CPU.

### ■ Changing from High Performance model QCPU

Table App.10.4-1

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	<ul style="list-style-type: none"> <li>If "Convert motion dedicated sequence instruction" is selected, S.instructions are converted to D.instructions. (Appendix 11)</li> </ul>	△	-	-
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property settings "SFC Program Type Setting", "Periodic Execution Block", and "Act at Step Multi-Activated" are deleted.</li> </ul>	△	△	△
PLC Parameter	-	-	-	-
PLC System	<ul style="list-style-type: none"> <li>If the constant scan time is set in the PLC RAS setting, "Execute it while waiting for constant scan setting" is set to the service processing setting in the PLC System setting.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If "Low speed" is set to "Execute Type" in the Program setting, it is changed to "Standby".</li> </ul>	△	△	△
Boot File	<ul style="list-style-type: none"> <li>If "Standard ROM" is set to "Transfer from", it is changed to "Memory Card (ROM)".</li> </ul>	△	△	△

### ■ Changing from Q00U, Q00UJ, Q01U, or Q02U

Table App.10.4-2

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	<ul style="list-style-type: none"> <li>A series-compatible SM/SD devices (SM/SD1000 to SM/SD1255) are changed to the corresponding devices for Q series.</li> <li>If "Convert motion dedicated sequence instruction" is selected, S.instructions are converted to D.instructions. (Appendix 11)</li> </ul>	△	-	-
Remote Password	<ul style="list-style-type: none"> <li>Any existing settings are cleared.</li> </ul>	△	△	△

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

■ **Changing from High-speed Universal model QCPU or Universal model process CPU**

Table App.10.4-3

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
PLC Parameter	–	–	–	–
Device	<ul style="list-style-type: none"> <li>If the value exceeds the capacity of changed programmable controller type is set for "File Register Extended Setting", the maximum value is set and all points are set as file register (ZR(R)). The setting of the latch range is cleared.</li> </ul>	△	△	△
Built-in Ethernet Port Setting	<ul style="list-style-type: none"> <li>If "Communication protocol" is set to "Open System" for open setting, the settings of the rows are set to default.</li> <li>Any existing settings in "Ethernet Conf." are deleted.</li> <li>Any existing settings in "CC-Link IEF Basic Setting" are deleted.</li> </ul>	△	△	△
Block Password	<ul style="list-style-type: none"> <li>For a project including a block password for which the execution program protection setting was enabled, the programmable controller type cannot be changed to one other than a high-speed universal model QCPU, a universal model process CPU, and an LCPU.</li> </ul>	△	△	△

■ **Changing from Redundant CPU**

Table App.10.4-4

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property settings "SFC Program Type Setting", "Periodic Execution Block", and "Act at Step Multi-Activated" are deleted.</li> </ul>	△	△	△
PLC Parameter	–	–	–	–
PLC System	<ul style="list-style-type: none"> <li>If the constant scan time is set in the PLC RAS setting, "Execute it while waiting for constant scan setting" is set to the service processing setting in the PLC System setting.</li> </ul>	△	△	△
Boot File	<ul style="list-style-type: none"> <li>If "Standard ROM" is set to "Transfer from", it is changed to "Memory Card (ROM)".</li> </ul>	△	△	△
I/O Assignment	<ul style="list-style-type: none"> <li>Settings on the slot 0 are deleted.</li> <li>If any slot after the slot 1 is set, "Empty" is set for "Type" and "0 Point" is set for "Points" on the slot 0.</li> </ul>	△	△	△
Network Parameter	–	–	–	–
Ethernet	<ul style="list-style-type: none"> <li>"Ethernet (Main Base)" or "Ethernet (Extension Base)" is changed to "Ethernet".</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>"Master station (Extension Base)" is changed to "Master Station".</li> </ul>	△	△	△

## ■ Changing from Process CPU

Table App.10.4-5

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	<ul style="list-style-type: none"> <li>If "Convert motion dedicated sequence instruction" is selected, S.instructions are converted to D.instructions. (Appendix 11)</li> </ul>	△	-	-
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property settings "SFC Program Type Setting", "Periodic Execution Block", and "Act at Step Multi-Activated" are deleted.</li> </ul>	△	△	△
PLC Parameter	-	-	-	-
PLC System	<ul style="list-style-type: none"> <li>If the constant scan time is set in the PLC RAS setting, "Execute it while waiting for constant scan setting" is set to the service processing setting in the PLC System setting.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If "Low Speed" is set to "Execute Type" in the Program setting, it is changed to "Standby".</li> </ul>	△	△	△
Boot File	<ul style="list-style-type: none"> <li>If "Standard ROM" is set to "Transfer from", it is changed to "Memory Card (ROM)".</li> </ul>	△	△	△

## ■ Changing from Basic model QCPU

Table App.10.4-6

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	<ul style="list-style-type: none"> <li>If "Convert motion dedicated sequence instruction" is selected, S.instructions are converted to D.instructions. (Except for Q00J. Appendix 11)</li> </ul>	△	-	-
PLC Parameter	-	-	-	-
PLC File	<ul style="list-style-type: none"> <li>When changing from Q00 or Q01, "Use the following file" is selected and "Corresponding Memory: Standard RAM", "File Name: MAIN", and "Capacity: 64K Points" are set in the file register setting.</li> </ul>	△	△	△

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

—

INDEX

## ■ Changing from LCPU

Table App.10.4-7

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Remote Password	<ul style="list-style-type: none"> <li>When changing from L02S/L02S-P or L02/L02-P, any existing settings are cleared.</li> <li>When changing from L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, the following settings are set. <ul style="list-style-type: none"> <li>The settings of the built-in Ethernet are replaced to the settings appropriate for the changed programmable controller type.</li> <li>The settings of LJ71C24 are replaced to the settings of QJ71C24/CMO.</li> <li>The settings of LJ71E71 are replaced to the settings of QJ71E71.</li> </ul> </li> </ul>	△	△	△
PLC Parameter	—	—	—	—
I/O Assignment	<ul style="list-style-type: none"> <li>Settings of "Built-in I/O Function Setting" and "Built-in CC-Link Setting" are deleted.</li> </ul>	△	△	△
Built-in Ethernet Port Setting	<ul style="list-style-type: none"> <li>Any existing settings of "Ethernet Conf." are deleted.</li> <li>When changing from Built-in Ethernet port LCPU, any existing settings of "CC-Link IEF Basic Setting" are deleted.</li> </ul>	△	△	△
Network Parameter	—	—	—	—
CC-Link IE Field Network	<ul style="list-style-type: none"> <li>If the number of modules is one and "Start I/O No." is outside the range, its maximum value is set. If the number of modules is two, "Start I/O No." is set starting from 0000.</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>If "H/W Test" or "Loop Test" is set to "Mode", the setting is deleted.</li> </ul>	△	△	△
Block Password	<ul style="list-style-type: none"> <li>For a project including a block password for which the execution program protection setting was enabled, the programmable controller type cannot be changed to one other than a high-speed universal model QCPU, a universal model process CPU, and an LCPU.</li> </ul>	△	△	△

## Appendix 10.5 Restrictions when changing to High-speed Universal model QCPU or Universal model process CPU

The following tables show the restrictions applied when changing a programmable controller series/type to High-speed Universal model QCPU or Universal model process CPU.

### ■ Changing from High Performance model QCPU

Table App.10.5-1

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	<ul style="list-style-type: none"> <li>If "Convert motion dedicated sequence instruction" is selected, S.instructions are converted to D.instructions. (➡ Appendix 11)</li> </ul>	△	-	-
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property settings of "SFC Program Type Setting", "Periodic Execution Block", and "Act at Step Multi-Activated" are deleted.</li> </ul>	△	△	△
PLC Parameter	-	-	-	-
PLC System	<ul style="list-style-type: none"> <li>If the constant scan time is set in the PLC RAS setting, "Execute it while waiting for constant scan setting" is set to the service processing setting in the PLC System setting.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If "Low speed" is set to "Execute Type" in the Program setting, it is changed to "Standby".</li> </ul>	△	△	△
Boot File	<ul style="list-style-type: none"> <li>The setting of "Transfer From" is set to "Memory Card (SD)".</li> </ul>	△	△	△

### ■ Changing from Q00U, Q00UJ, Q01U, or Q02U

Table App.10.5-2

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	<ul style="list-style-type: none"> <li>A series-compatible SM/SD devices (SM/SD1000 to SM/SD1255) are changed to the corresponding devices for Q series.</li> <li>If "Convert motion dedicated sequence instruction" is selected, S.instructions are converted to D.instructions. (➡ Appendix 11)</li> </ul>	△	-	-
Remote Password	<ul style="list-style-type: none"> <li>Any existing settings are cleared.</li> </ul>	△	△	△

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## ■ Changing from QnUD(H)CPU

Table App.10.5-3

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
PLC Parameter	–	–	–	–
Boot File	• The setting of "Transfer From" is set to "Memory Card (SD)".	△	△	△

## ■ Changing from QnUDE(H)CPU

Table App.10.5-4

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
PLC Parameter	–	–	–	–
Boot File	• The setting of "Transfer From" is set to "Memory Card (SD)".	△	△	△

## ■ Changing from Redundant CPU

Table App.10.5-5

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Sequential Function Chart	• The property settings of "SFC Program Type Setting", "Periodic Execution Block", and "Act at Step Multi-Activated" are deleted.	△	△	△
PLC Parameter	–	–	–	–
PLC System	• If the constant scan time is set in the PLC RAS setting, "Execute it while waiting for constant scan setting" is set to the service processing setting in the PLC System setting.	△	△	△
Boot File	• The setting of "Transfer From" is set to "Memory Card (SD)".	△	△	△
I/O Assignment	• Settings on the slot 0 are deleted. • If any slot after the slot 1 is set, "Empty" is set for "Type" and "0 Point" is set for "Points" on the slot 0.	△	△	△
Network Parameter	–	–	–	–
Ethernet	• "Ethernet (Main Base)" or "Ethernet (Extension Base)" is changed to "Ethernet".	△	△	△
CC-Link	• "Master station (Extension Base)" is changed to "Master Station".	△	△	△



■ Changing from Process CPU

Table App.10.5-6

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	If "Convert motion dedicated sequence instruction" is selected, S.instructions are converted to D.instructions. (Appendix 11)	△	-	-
Sequential Function Chart	• The property settings of "SFC Program Type Setting", "Periodic Execution Block", and "Act at Step Multi-Activated" are deleted.	△	△	△
PLC Parameter	-	-	-	-
PLC System	• If the constant scan time is set in the PLC RAS setting, "Execute it while waiting for constant scan setting" is set to the service processing setting in the PLC System setting.	△	△	△
Program	• If "Low Speed" is set to "Execute Type" in the Program setting, it is changed to "Standby".	△	△	△
Boot File	• "Transfer from" is set to "Memory Card (SD)".	△	△	△

■ Changing from Basic model QCPU

Table App.10.5-7

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Remote Password	If "Convert motion dedicated sequence instruction" is selected, S.instructions are converted to D.instructions. (Except for Q00J. Appendix 11)	△	-	-
PLC Parameter	-	-	-	-
PLC File	• When changing from Q00 or Q01, "Use the following file" is selected and "Corresponding Memory: Standard RAM", "File Name: MAIN", and "Capacity: 64K Points" are set in the file register setting.	△	△	△
Boot File	If "Do boot from standard ROM" is selected before changing the programmable controller type, "Type: Sequence", "Data Name: MAIN", "Transfer From: Memory Card (ROM)", and "Transfer To: Program Memory" are set.	△	△	△

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## ■ Changing from LCPU

Table App.10.5-8

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Remote Password	<ul style="list-style-type: none"> <li>When changing from L02S/L02S-P or L02/L02-P, any existing settings are cleared.</li> <li>When changing from L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, the following settings are set.               <ul style="list-style-type: none"> <li>The settings of the built-in Ethernet are replaced to the settings appropriate for the changed programmable controller type.</li> <li>The settings of LJ71C24 are replaced to the settings of QJ71C24/CMO.</li> <li>The settings of LJ71E71 are replaced to the settings of QJ71E71.</li> </ul> </li> </ul>	△	△	△
PLC Parameter	—	—	—	—
I/O Assignment	<ul style="list-style-type: none"> <li>Settings of "Built-in I/O Function Setting" and "Built-in CC-Link Setting" are deleted.</li> </ul>	△	△	△
Network Parameter	—	—	—	—
CC-Link IE Field Network	<ul style="list-style-type: none"> <li>If the number of modules is one and "Start I/O No." is outside the range, its maximum value is set. If the number of modules is two or more, "Start I/O No." is set starting from 0000.</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>If "H/W Test" or "Loop Test" is set to "Mode", the setting is deleted.</li> </ul>	△	△	△

## Appendix 10.6 Restrictions when changing to Redundant CPU

The following tables show the restrictions applied when changing a programmable controller series/type to Redundant CPU.

### Common restrictions when changing to Redundant CPU

Table App.10.6-1

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Ladder	<ul style="list-style-type: none"> <li>A series-compatible SM/SD devices (SM/SD1000 to SM/SD1255) are changed to the corresponding devices for Q series.</li> <li>Unsupported instructions are changed to the OUT instructions.</li> </ul>	△	△	△
PLC Parameter	–	–	–	–
I/O Assignment	<ul style="list-style-type: none"> <li>Settings on the slot 0 are deleted.</li> <li>"Redundant" is set for "Type" and "0 Point" is set for "Points" on the slot 0. Note that, if the slot 0 is set, "Type" of the slot 0 on the <u>Switch Setting for I/O and Intelligent Function Module</u> screen and the <u>Intelligent Function Module Detailed Setting</u> screen is set to "Empty".</li> </ul>	△	△	△
Network Parameter	–	–	–	–
Ethernet	<ul style="list-style-type: none"> <li>"Ethernet" is changed to "Ethernet (Main Base)".</li> <li>Set a number (system A station number + 1) for the system B station number. If the system A station number is 64, set 1.</li> <li>Assign the IP address as indicated below according to the address of system A.                             <ul style="list-style-type: none"> <li>If the address of system A is 255.255.255.255, assign the same address to the system B.</li> <li>If the address of system A is 0.0.0.255 or 255.255.255.254, assign 192.0.1.254 to the system B.</li> <li>If the address of system A is *.**.254, assign *.**.253 to the system B. (*.*.*. is the same numerical string for system A and B.)</li> <li>If the address of system A is *.**.255, assign *.**.254 to the system B. (*.*.*. is the same numerical string for system A and B.)</li> <li>If the address of system A is other than any of the above addresses, assign the address (4th number of system A address + 1) to the system B.</li> </ul> </li> </ul>	△	△	△
CC-Link IE Controller Network	<ul style="list-style-type: none"> <li>If the station number is 64, 63 is set. If 63 is set on the higher number side in the network range assignment setting, "Disable" is set for "Pairing".</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>"Master Station" is changed to "Master station (Extension Base)".</li> </ul>	△	△	△

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## ■ Changing from High-speed Universal model QCPU or Universal model process CPU

Table App.10.6-2

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Remote Password	• Only the settings of Ethernet Built-in CPU are cleared.	△	△	△
PLC Parameter	–	–	–	–
Device	• If the value exceeds the capacity of changed programmable controller type is set for "File Register Extended Setting", the maximum value is set and all points are set as file register (ZR(R)). The setting of the latch range is cleared.	△	△	△
Built-in Ethernet Port Setting	• Any existing settings of "CC-Link IEF Basic Setting" are deleted.	△	△	△

## ■ Changing from Process CPU

Table App.10.6-3

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
PLC Parameter	–	–	–	–
PLC RAS	• If the value of "Capacity to be checked at one time" under "Memory Check" exceeds the maximum value, set the maximum value.	△	△	△
Program	• If "Low Speed" is set to "Execute Type" in the Program setting, it is changed to "Standby". • If the number of programs exceeds the allowable number, the exceeding settings are deleted.	△	△	△

## ■ Changing from LCPU

Table App.10.6-4

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
PLC Parameter	–	–	–	–
Built-in Ethernet Port Setting	• When changing from Built-in Ethernet port LCPU, any existing settings of "CC-Link IEF Basic Setting" are deleted.	△	△	△
Block Password	• For a project including a block password for which the execution program protection setting was enabled, the programmable controller type cannot be changed to one other than a high-speed universal model QCPU, a universal model process CPU, and an LCPU.	△	△	△

## Appendix 10.7 Restrictions when changing to Process CPU

The following tables show the restrictions applied when changing a programmable controller series/type to Process CPU.

### Common restrictions when changing to Process CPU

Table App.10.7-1

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
PLC Parameter	–	–	–	–
Program	• If the number of programs exceeds the allowable number, the exceeding settings are deleted.	△	△	△

### Changing from High-speed Universal model QCPU or Universal model process CPU

Table App.10.7-2

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Remote Password	• Only the settings of Ethernet Built-in CPU are cleared.	△	△	△
PLC Parameter	–	–	–	–
Device	• If the value exceeds the capacity of changed programmable controller type is set for "File Register Extended Setting", the maximum value is set and all points are set as file register (ZR(R)). The setting of the latch range is cleared.	△	△	△
Built-in Ethernet Port Setting	• Any existing settings of "CC-Link IEF Basic Setting" are deleted.	△	△	△
Block Password	• For a project including a block password for which the execution program protection setting was enabled, the programmable controller type cannot be changed to one other than a high-speed universal model QCPU, a universal model process CPU, and an LCPU.	△	△	△

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## ■ Changing from Redundant CPU

Table App.10.7-3

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
PLC Parameter	–	–	–	–
PC RAS	<ul style="list-style-type: none"> <li>If the value of "Capacity to be checked at one time" under "Memory Check" exceeds the maximum value, set the maximum value.</li> </ul>	△	△	△
I/O Assignment	<ul style="list-style-type: none"> <li>Settings on the slot 0 are deleted.</li> <li>If any slot after the slot 1 is set, "Empty" is set for "Type" and "0 Point" is set for "Points" on the slot 0.</li> </ul>	△	△	△
Network Parameter	–	–	–	–
Ethernet	<ul style="list-style-type: none"> <li>"Ethernet (Main Base)" or "Ethernet (Extension Base)" is changed to "Ethernet".</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>"Master station (Extension Base)" is changed to "Master Station".</li> </ul>	△	△	△

## ■ Changing from LCPU

Table App.10.7-4

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
PLC Parameter	–	–	–	–
Built-in Ethernet Port Setting	<ul style="list-style-type: none"> <li>When changing from Built-in Ethernet port LCPU, any existing settings of "CC-Link IEF Basic Setting" are deleted.</li> </ul>	△	△	△
Block Password	<ul style="list-style-type: none"> <li>For a project including a block password for which the execution program protection setting was enabled, the programmable controller type cannot be changed to one other than a high-speed universal model QCPU, a universal model process CPU, and an LCPU.</li> </ul>	△	△	△

## Appendix 10.8 Restrictions when changing to High Performance model QCPU

The following tables show the restrictions applied when changing a programmable controller series/type to High Performance model QCPU.

### ■ Changing from Universal model QCPU

Table App.10.8-1

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	<ul style="list-style-type: none"> <li>If "Convert motion dedicated sequence instruction" is selected, D.instructions are converted to S.instructions. (Except for Q00U, Q00UJ, Q01U, and Q02U. (Appendix 11))</li> </ul>	△	-	-
Device comment	Bit-specified word device comments are deleted.	△	△	△
Remote Password	Only the settings of Ethernet Built-in CPU are cleared.	△	△	△
PLC Parameter	-	-	-	-
PLC System	<ul style="list-style-type: none"> <li>The setting value of "High Speed" in the timer limit setting is rounded up to the range 0.1 to 100ms. (Example: 0.01ms → 0.1ms)</li> </ul>	△	△	△
PLC File	<ul style="list-style-type: none"> <li>If the capacity of the file register exceeds 1019K points, the setting is set to 1018K points.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>When changing to Q02, Q02H, or Q06H, the Program setting and file usability setting for programs exceed the supported program number are deleted.</li> </ul>	△	△	△
Device	<ul style="list-style-type: none"> <li>8K is specified for S device.</li> </ul>	△	△	△
Network Parameter	-	-	-	-
Ethernet	<ul style="list-style-type: none"> <li>In the news setting in the E-mail setting, condition devices outside the device range in the changed programmable controller type are deleted.</li> </ul>	△	△	△
CC-Link IE Controller Network	<ul style="list-style-type: none"> <li>The third and later CC-Link IE Controller Network modules in the module setting are deleted.</li> <li>Modules whose station numbers are set in programs ("Specify station No. by program") are deleted.</li> <li>When "Total stations" is 65 or more, 64 is set.</li> <li>The 65th and later settings are deleted in the network range assignment setting.</li> <li>The 65th and later I/O master stations are deleted in the LX/LY setting in the network range assignment setting.</li> <li>When '0800' or larger is specified for "Start" of SB/SW in the PLC side device range in the refresh parameters setting, the specified range is deleted. When '0800' or larger is specified for "End" of SB/SW, it is replaced to '07FF'. Devices out of the range are also deleted.</li> <li>The settings of "Network Operation Settings" are deleted.</li> </ul>	△	△	△
MELSECNET/10(H)	<ul style="list-style-type: none"> <li>When '0800' or larger is specified for "Start" of SB/SW in the PLC side device range in the refresh parameters setting, the specified range is deleted. When '0800' or larger is specified for "End" of SB/SW, it is replaced to '07FF'. Devices out of the range are also deleted.</li> </ul>	△	△	△

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

■ Changing from Redundant CPU

Table App.10.8-2

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
PLC Parameter	–	–	–	–
Program	<ul style="list-style-type: none"> <li>If the number of programs exceeds the allowable number, the exceeding settings are deleted.</li> </ul>	△	△	△
I/O Assignment	<ul style="list-style-type: none"> <li>Settings on the slot 0 are deleted.</li> <li>If any slot after the slot 1 is set, "Empty" is set for "Type" and "0 Point" is set for "Points" on the slot 0.</li> </ul>	△	△	△
Network Parameter	–	–	–	–
Ethernet	<ul style="list-style-type: none"> <li>"Ethernet (Main Base)" or "Ethernet (Extension Base)" is changed to "Ethernet".</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>"Master station (Extension Base)" is changed to "Master Station".</li> </ul>	△	△	△

■ Changing from Process CPU

Table App.10.8-3

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
PLC Parameter	–	–	–	–
Program	<ul style="list-style-type: none"> <li>If "Low Speed" is set to "Execute Type" in the Program setting, it is changed to "Standby".</li> <li>If the number of programs exceeds the allowable number, the exceeding settings are deleted.</li> </ul>	△	△	△



■ Changing from Basic model QCPU

Table App.10.8-4

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
PLC Parameter	–	–	–	–
PLC File	<ul style="list-style-type: none"> <li>When changing from Q00 or Q01, "Use the following file" is selected and "Corresponding Memory: Standard RAM", "File Name: MAIN", and "Capacity: 64K Points" are set in the file register setting.</li> </ul>	△	△	△

■ Changing from High-speed Universal model QCPU or Universal model process CPU

Table App.10.8-5

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
PLC Parameter	–	–	–	–
Built-in Ethernet Port Setting	<ul style="list-style-type: none"> <li>Any existing settings of "CC-Link IEF Basic Setting" are deleted.</li> </ul>	△	△	△
Block Password	<ul style="list-style-type: none"> <li>For a project including a block password for which the execution program protection setting was enabled, the programmable controller type cannot be changed to one other than a high-speed universal model QCPU, a universal model process CPU, and an LCPU.</li> </ul>	△	△	△

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
INDEX	INDEX

## ■ Changing from LCPU

Table App.10.8-6

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Device comment	Bit-specified word device comments are deleted.	△	△	△
Remote Password	<ul style="list-style-type: none"> <li>When changing from L02S/L02S-P or L02/L02-P, any existing settings are cleared.</li> <li>When changing from L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, the following settings are set. <ul style="list-style-type: none"> <li>The settings of the built-in Ethernet are cleared.</li> <li>The settings of LJ71C24 are replaced to the settings of QJ71C24/CMO.</li> <li>The settings of LJ71E71 are replaced to the settings of QJ71E71.</li> </ul> </li> </ul>	△	△	△
PLC Parameter	–	–	–	–
Boot File	<ul style="list-style-type: none"> <li>When changing from L02/L02-P, L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, if 'Symbolic Information' is set to "Type", the setting is deleted. If "Standard ROM" is set to "Transfer To", it is changed to "Program Memory".</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If the number of programs exceeds the allowable number, the exceeded programs are deleted.</li> </ul>	△	△	△
Device	<ul style="list-style-type: none"> <li>8K is specified for S device.</li> </ul>	△	△	△
I/O Assignment	<ul style="list-style-type: none"> <li>Settings of "Built-in I/O Function Setting" and "Built-in CC-Link Setting" are deleted.</li> </ul>	△	△	△
Built-in Ethernet Port Setting	<ul style="list-style-type: none"> <li>When changing from Built-in Ethernet port LCPU, any existing settings of "CC-Link IEF Basic Setting" are deleted.</li> </ul>	△	△	△
Network Parameter	–	–	–	–
CC-Link	<ul style="list-style-type: none"> <li>If "H/W Test" or "Loop Test" is set to "Mode", the setting is deleted.</li> </ul>	△	△	△
Block Password	<ul style="list-style-type: none"> <li>For a project including a block password for which the execution program protection setting was enabled, the programmable controller type cannot be changed to one other than a high-speed universal model QCPU, a universal model process CPU, and an LCPU.</li> </ul>	△	△	△

## Appendix 10.9 Restrictions when changing to Basic model QCPU

The following tables show the restrictions applied when changing a programmable controller series/type to Basic model QCPU.

### Common restrictions when changing to Basic model QCPU

Table App.10.9-1

△: With restrictions

Item	Restrictions	Project type							
		Simple project		Structured project					
		Without labels	With labels						
Program	<ul style="list-style-type: none"> <li>When changing to Q00J, file registers (R/ZR) are changed to SD999.</li> </ul>	△	–	–					
Device Initial Value	<ul style="list-style-type: none"> <li>If the name of the device initial value data is other than 'MAIN', the file is deleted.</li> <li>If the setting exceeds the editable range of device initial values in the changed programmable controller type, the exceeding range is deleted.</li> </ul>	△	△	△					
Global Device Comment	<ul style="list-style-type: none"> <li>Global device comments are deleted.</li> </ul>	△	△	△					
Remote Password	<ul style="list-style-type: none"> <li>Any existing settings are cleared.</li> </ul>	△	△	△					
PLC Parameter	–	–	–	–					
<table border="1" style="width: 100%;"> <tr> <td style="width: 15%;">PLC File</td> <td> <ul style="list-style-type: none"> <li>If an item other than "Not Used" is set in the initial device value setting, it is changed to "Used".</li> </ul> </td> <td>△</td> <td>△</td> <td>△</td> </tr> </table>	PLC File	<ul style="list-style-type: none"> <li>If an item other than "Not Used" is set in the initial device value setting, it is changed to "Used".</li> </ul>	△	△	△				
PLC File	<ul style="list-style-type: none"> <li>If an item other than "Not Used" is set in the initial device value setting, it is changed to "Used".</li> </ul>	△	△	△					
Device/Label Automatic-Assign Setting	<ul style="list-style-type: none"> <li>If the Device setting or the setting for the file register capacity in the PLC File setting in the PLC parameter is changed, the default value is set.</li> </ul>	–	△	△					

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## ■ Changing from High Performance model QCPU

Table App.10.9-2

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Ladder Diagram	<ul style="list-style-type: none"> <li>If instructions not supported by the changed programmable controller type are used, they are deleted and displayed in yellow.</li> </ul>	–	△	△
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property settings "SFC Program Type Setting", "Periodic Execution Block", "Act at Block Multi-Activated" and "Act at Step Multi-Activated" are deleted.</li> </ul>	△	△	△
	<ul style="list-style-type: none"> <li>The block title in the property setting is deleted.</li> <li>If device points not supported by Q00J/Q00/Q01 are used for "Block Information" in the property setting, the setting is deleted.</li> </ul>	△	–	–
PLC Parameter	–	–	–	–
PLC System	<ul style="list-style-type: none"> <li>The setting values of "Fixed Scan Interval" are rounded out to the one in "System Interrupt Settings".</li> </ul>	△	△	△
Boot File	<ul style="list-style-type: none"> <li>If "Type: Sequence", "Data Name: MAIN", "Transfer From: Standard ROM", and "Transfer To: Program Memory" are set before changing the programmable controller type, "Do boot from standard ROM" is selected.</li> </ul>	△	△	△

■ Changing from Universal model QCPU

Table App.10.9-3

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	<ul style="list-style-type: none"> <li>If "Convert motion dedicated sequence instruction" is selected, D.instructions are converted to S.instructions. (Except for Q00U, Q00UJ, Q01U, and Q02U.  Appendix 11)</li> </ul>	△	-	-
Ladder Diagram	<ul style="list-style-type: none"> <li>If instructions not supported by the changed programmable controller type are used, they are deleted and displayed in yellow.</li> </ul>	-	△	△
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property setting "Act at Block Multi-Activated" is deleted.</li> </ul>	△	△	△
	<ul style="list-style-type: none"> <li>The property setting "Block Setting" is deleted.</li> <li>If device points not supported by Q00J/Q00/Q01 are used, the setting is deleted.</li> </ul>	△	-	-
Device comment	Bit-specified word device comments are deleted.	△	△	△
PLC Parameter	-	-	-	-
PLC System	<ul style="list-style-type: none"> <li>The setting value is rounded out to the tenth in "Timer Limit Setting (High Speed)".</li> <li>The setting values of "Fixed Scan Interval" are rounded out to the one in "System Interrupt Settings".</li> </ul>	△	△	△
Boot File	<ul style="list-style-type: none"> <li>Any specified settings are deleted.</li> </ul>	△	△	△
Device	<ul style="list-style-type: none"> <li>2K is set for S device.</li> </ul>	△	△	△
Built-in Ethernet Port Setting	<ul style="list-style-type: none"> <li>Any existing settings of "CC-Link IEF Basic Setting" are deleted.</li> </ul>	△	△	△
Block Password	<ul style="list-style-type: none"> <li>For a project including a block password for which the execution program protection setting was enabled, the programmable controller type cannot be changed to one other than a high-speed universal model QCPU, a universal model process CPU, and an LCPU.</li> </ul>	△	△	△

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

## ■ Changing from Redundant CPU

Table App.10.9-4

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Ladder Diagram	<ul style="list-style-type: none"> <li>If instructions not supported by the changed programmable controller type are used, they are deleted and displayed in yellow.</li> </ul>	–	△	△
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property settings "SFC Program Type Setting", "Periodic Execution Block", "Act at Block Multi-Activated" and "Act at Step Multi-Activated" are deleted.</li> </ul>	△	△	△
	<ul style="list-style-type: none"> <li>The block title in the property setting is deleted.</li> <li>If device points not supported by Q00J/Q00/Q01 are used for "Block Information" in the property setting, the setting is deleted.</li> </ul>	△	–	–
PLC Parameter	–	–	–	–
PLC System	<ul style="list-style-type: none"> <li>The setting values of "Fixed Scan Interval" are rounded out to the one in "System Interrupt Settings".</li> </ul>	△	△	△
Boot File	<ul style="list-style-type: none"> <li>If "Type: Sequence", "Data Name: MAIN", "Transfer From: Standard ROM", and "Transfer To: Program Memory" are set before changing the programmable controller type, "Do boot from standard ROM" is selected.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If the number of programs exceeds the allowable number, the exceeding settings are deleted.</li> </ul>	△	△	△
I/O Assignment	<ul style="list-style-type: none"> <li>Settings on the slot 0 are deleted.</li> <li>If any slot after the slot 1 is set, "Empty" is set for "Type" and "0 Point" is set for "Points" on the slot 0.</li> </ul>	△	△	△
Network Parameter	–	–	–	–
Ethernet	<ul style="list-style-type: none"> <li>"Ethernet (Main Base)" or "Ethernet (Extension Base)" is changed to "Ethernet".</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>"Master station (Extension Base)" is changed to "Master Station".</li> </ul>	△	△	△

■ Changing from Process CPU

Table App.10.9-5

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Ladder Diagram	<ul style="list-style-type: none"> <li>If instructions not supported by the changed programmable controller type are used, they are deleted and displayed in yellow.</li> </ul>	–	△	△
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property settings "SFC Program Type Setting", "Periodic Execution Block", "Act at Block Multi-Activated" and "Act at Step Multi-Activated" are deleted.</li> </ul>	△	△	△
	<ul style="list-style-type: none"> <li>The block title in the property setting is deleted.</li> <li>If device points not supported by Q00J/Q00/Q01 are used for "Block Information" in the property setting, the setting is deleted.</li> </ul>	△	–	–
PLC Parameter	–	–	–	–
PLC System	<ul style="list-style-type: none"> <li>The setting values of "Fixed Scan Interval" are rounded out to the one in "System Interrupt Settings".</li> </ul>	△	△	△
Boot File	<ul style="list-style-type: none"> <li>If "Type: Sequence", "Data Name: MAIN", "Transfer From: Standard ROM", and "Transfer To: Program Memory" are set before changing the programmable controller type, "Do boot from standard ROM" is selected.</li> </ul>	△	△	△

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## ■ Changing from LCPU

Table App.10.9-6

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Sequential Function Chart	<ul style="list-style-type: none"> <li>The property setting "Act at Block Multi-Activated" is deleted.</li> </ul>	△	△	△
Device comment	Bit-specified word device comments are deleted.	△	△	△
PLC Parameter	–	–	–	–
PLC System	<ul style="list-style-type: none"> <li>If "Start I/O No." in the interrupt pointer setting of the intelligent function module setting is outside the range, the setting is deleted.</li> <li>When changing to Q00J, if the number of points is outside the range, its maximum point is set.</li> </ul>	△	△	△
Boot File	<ul style="list-style-type: none"> <li>If "Type: Sequence", "Data Name: MAIN", "Transfer From: Standard ROM", and "Transfer To: Program Memory" are set before changing the programmable controller type, "Do boot from standard ROM" is selected.</li> </ul>	△	△	△
Device	<ul style="list-style-type: none"> <li>S device is set to 2K points.</li> </ul>	△	△	△
I/O Assignment	<ul style="list-style-type: none"> <li>Settings of "Built-in I/O Function Setting" and "Built-in CC-Link Setting" are deleted.</li> </ul>	△	△	△
Built-in Ethernet Port Setting	<ul style="list-style-type: none"> <li>When changing from Built-in Ethernet port LCPU, any existing settings of "CC-Link IEF Basic Setting" are deleted.</li> </ul>	△	△	△
Network Parameter	–	–	–	–
CC-Link	<ul style="list-style-type: none"> <li>If "H/W Test" or "Loop Test" is set to "Mode", the setting is deleted.</li> <li>When changing to Q00J, or when changing from L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, if the number of modules is one and "Start I/O No." is outside the range, its maximum value is set. If the number of modules is two or more and the start I/O number is outside the range, "Start I/O No." is set starting from 0000.</li> <li>When changing from L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, if the number of slots exceeds the maximum number of slots of the changed programmable controller type, the exceeded setting is deleted.</li> </ul>	△	△	△
Block Password	<ul style="list-style-type: none"> <li>For a project including a block password for which the execution program protection setting was enabled, the programmable controller type cannot be changed to one other than a high-speed universal model QCPU, a universal model process CPU, and an LCPU.</li> </ul>	△	△	△



## Appendix 10.10 Restrictions when changing to LCPU

The following tables show the restrictions applied when changing a programmable controller series/type to LCPU.

### Common restrictions when changing to LCPU

Table App.10.10-1

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
PLC Parameter	–	–	–	–
PLC System	<ul style="list-style-type: none"> <li>If "Start I/O No." in the interrupt pointer setting of the intelligent function module setting is outside the range, the setting is deleted.</li> <li>When changing to L02S/L02S-P or L02/L02-P, if "Backup Start Setup Contact" and "Backup Start Contact" in the PLC module change setting are outside the range, the device settings are deleted.</li> </ul>	△	△	△
PLC File	<ul style="list-style-type: none"> <li>If "Use the same file name as the program" is set in the file register setting, it is changed to "Not Used".</li> <li>If an item other than "Memory Card (ROM)" and "Standard ROM" is set to "Corresponding Memory" in the comment file used in a comment setting, it is changed to "Memory Card (SD)".</li> <li>If "Memory Card (RAM)" is set to "Corresponding Memory" in the initial device value setting, it is changed to "Memory Card (SD)".</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If "Low Speed" is set to "Execute Type" in the Program setting, it is changed to "Standby".</li> </ul>	△	△	△
Device	<ul style="list-style-type: none"> <li>If the capacity of the file register setting before changing the programmable controller type exceeds the maximum capacity of the setting of the changed programmable controller type, the following settings are set.                             <ul style="list-style-type: none"> <li>The number of normal device points is set to default.</li> <li>The number of extended device points is set to the maximum point that can be set for file register.</li> <li>The settings for Latch (1) and Latch (2) are initialized.</li> </ul> </li> </ul>	△	△	△
I/O Assignment	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P, L02/L02-P, L06/L06-P, or L26/L26-P, "Type" of the slot 1 is set to "Built-in I/O Function", and "Points" is set to "16 Points". All settings of start XY are deleted.</li> <li>When changing to L26-BT/L26-PBT, "Type" of the slot 1 is set to "Built-in I/O Function", and "Points" is set to "32 Points". All settings of start XY are deleted.</li> </ul>	△	△	△
Network Parameter	–	–	–	–
Ethernet	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, the second and later Ethernet modules in the module settings are deleted.</li> <li>When changing to L06, L26, or L26-BT/L26-PBT, the third and later Ethernet modules in the module settings are deleted.</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, if the number of modules is one and "Start I/O No." is outside the range, its maximum value is set. If the number of modules is two or more and the start I/O number is outside the range, "Start I/O No." is set starting from 0000.</li> </ul>	△	△	△

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Device/Label Automatic-Assign Setting	<ul style="list-style-type: none"> <li>If the Device setting or the setting for the file register capacity in the PLC File setting in the PLC parameter is changed, the default value is set.</li> </ul>	–	△	△

## ■ Changing from High Performance model QCPU

Table App.10.10-2

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Sequential Function Chart	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, property settings "SFC Program Type Setting", "Periodic Execution Block", "Act at Block Multi-Activated", and "Act at Step Multi-Activated" are deleted.</li> <li>When changing to L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, property settings "SFC Program Type Setting", "Periodic Execution Block", and "Act at Step Multi-Activated" are deleted.</li> </ul>	△	△	△
Remote Password	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, any existing settings are cleared.</li> <li>When changing to L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, the following settings are set.                             <ul style="list-style-type: none"> <li>The settings of the Ethernet module are cleared.</li> <li>The settings of QJ71C24/CMO are replaced to the settings of LJ71C24.</li> <li>The settings of QJ71E71 are replaced to the settings of LJ71E71.</li> </ul> </li> </ul>	△	△	△
PLC Parameter	–	–	–	–
Boot File	<ul style="list-style-type: none"> <li>When changing to L02/L02-P, L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, the setting of "Transfer From" in the Boot File setting is changed to "Memory Card (SD)".</li> </ul>	△	△	△
PLC System	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, if the number of points is outside the range, its maximum point is set.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If the number of programs exceeds the allowable number, the exceeded programs are deleted.</li> </ul>	△	△	△
Network Parameter	–	–	–	–
CC-Link	<ul style="list-style-type: none"> <li>If the number of slots exceeds the maximum number of slots of the changed programmable controller type, the exceeded setting is deleted.</li> </ul>	△	△	△

■ Changing from QnUD(H)CPU

Table App.10.10-3

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Sequential Function Chart	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, the property setting "Act at Block Multi-Activated" is deleted.</li> </ul>	△	△	△
Remote Password	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, any existing settings are cleared.</li> <li>When changing to L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, the settings of Ethernet module are deleted. The settings of QJ71C24/CMO are replaced to the settings of LJ71C24.</li> </ul>	△	△	△
PLC Parameter	–	–	–	–
Boot File	<ul style="list-style-type: none"> <li>When changing to L02/L02-P, L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, the setting of "Transfer From" in the Boot File setting is changed to "Memory Card (SD)".</li> </ul>	△	△	△
Device	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, if the points that exceeds 8K points are specified for S device, the setting is set to 8K points.</li> </ul>	△	△	△
PLC System	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, if the number of points is outside the range, its maximum point is set.</li> </ul>	△	△	△
PLC File	<ul style="list-style-type: none"> <li>If the file capacity of file register is outside the range, its maximum capacity is set, and the drive is changed to "Standard RAM".</li> <li>When changing to L02/L02-P, L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, if "Memory Card (RAM)" is set to "Corresponding Memory" in the initial device value setting, it is changed to "Memory Card (SD)".</li> <li>When changing to L02S/L02S-P, if an item other than "Program Memory" or "Standard ROM" is set to "Corresponding Memory" in the initial device value setting, it is changed to "Standard ROM".</li> <li>When changing to L02S/L02S-P or L02/L02-P, if the capacity exceeds 16K points in "File used for SP.DEVST/S.DEVLD Instruction", the setting is set to 16K point.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If the number of programs exceeds the allowable number, the exceeded programs are deleted.</li> </ul>	△	△	△
Network Parameter	–	–	–	–
CC-Link IE Field Network	<ul style="list-style-type: none"> <li>If the number of modules is one and "Start I/O No." is outside the range, its maximum value is set. If the number of modules is two, "Start I/O No." is set starting from 0000.</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>If the number of slots exceeds the maximum number of slots of the changed programmable controller type, the exceeded setting is deleted.</li> </ul>	△	△	△

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

—

INDEX

■ Changing from Q00U, Q00UJ, Q01U, or Q02U

Table App.10.10-4

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Remote Password	<ul style="list-style-type: none"> <li>When changing from Q00U or Q01U to L02S/L02S-P or L02/L02-P, the following settings are set.                             <ul style="list-style-type: none"> <li>The settings of QJ71C24/CMO are replaced to the settings of LJ71C24.</li> <li>The settings of QJ71E71 are replaced to the settings of LJ71E71.</li> </ul> </li> <li>When changing from Q00UJ or Q02U to L02S/L02S-P or L02/L02-P, any existing settings are cleared.</li> <li>When changing to L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, any existing settings are cleared.</li> </ul>	△	△	△
PLC Parameter	—	—	—	—
Boot File	<ul style="list-style-type: none"> <li>When changing from Q02U to L02/L02-P, L06/L06-P, L26/L26-P, or L26- BT/L26-PBT, the setting of "Transfer From" in the Boot File setting is changed to "Memory Card (SD)".</li> </ul>	△	△	△
PLC System	<ul style="list-style-type: none"> <li>When changing from Q00U, Q01U, or Q02U to L02S/L02S-P or L02/L02-P, if the number of points is outside the range, its maximum point is set.</li> <li>When changing from Q02U, if "Start I/O No." in the interrupt pointer setting of the intelligent function module setting is outside the range, the setting is deleted.</li> </ul>	△	△	△
PLC File	<ul style="list-style-type: none"> <li>When changing from Q02U, if the file capacity of file register is outside the range, its maximum capacity is set, and the drive is changed to "Standard RAM".</li> <li>When changing from Q02U to L02/L02-P, L06/L06-P, L26/L26-P, or L26- BT/L26-PBT, if an item other than "Memory Card (ROM)" and "Standard ROM" is set to "Corresponding Memory" in the comment file used in a comment setting, it is changed to "Memory Card (SD)".</li> </ul>	△	△	△
Network Parameter	—	—	—	—
CC-Link IE Field Network	<ul style="list-style-type: none"> <li>If the number of modules is one and "Start I/O No." is outside the range, its maximum value is set. If the number of modules is two, "Start I/O No." is set starting from 0000.</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>When changing from Q02U to L02S/L02S-P or L02/L02-P, if the number of modules is one and "Start I/O No." is outside the range, its maximum value is set. If the number of modules is two or more and the start I/O number is outside the range, "Start I/O No." is set starting from 0000.</li> <li>When changing from Q02U to L02S/L02S-P or L02/L02-P, if the number of slots exceeds the maximum number of slots of the changed programmable controller type, the exceeded setting is deleted.</li> </ul>	△	△	△

■ Changing from QnUDE(H)CPU

Table App.10.10-5

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Sequential Function Chart	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, the property setting "Act at Block Multi-Activated" is deleted.</li> </ul>	△	△	△
Remote Password	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, any existing settings are cleared.</li> <li>When changing to L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, the following settings are set                             <ul style="list-style-type: none"> <li>The settings of the built-in Ethernet are replaced to the settings appropriate for the changed programmable controller type.</li> <li>The settings of QJ71C24/CMO are replaced to the settings of LJ71C24.</li> <li>The settings of QJ71E71 are replaced to the settings of LJ71E71.</li> </ul> </li> </ul>	△	△	△
PLC Parameter	–	–	–	–
PLC System	<ul style="list-style-type: none"> <li>If a device that exceeds the range of the Device setting is set to "Latch Data Backup Operation Valid Contact", the setting is deleted.</li> <li>When changing to L02S/L02S-P or L02/L02-P, if the number of points is outside the range, its maximum point is set.</li> </ul>	△	△	△
Boot File	<ul style="list-style-type: none"> <li>When changing to L02/L02-P, L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, the setting of "Transfer From" in the Boot File setting is changed to "Memory Card (SD)".</li> </ul>	△	△	△
Device	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, if the points that exceeds 8K points are specified for S device, the setting is set to 8K points.</li> </ul>	△	△	△
Built-in Ethernet Port Setting	<ul style="list-style-type: none"> <li>If the IP address is outside the range of 0.0.0.1 to 223.255.255.254, the default is set.</li> </ul>	△	△	△
PLC File	<ul style="list-style-type: none"> <li>If the file capacity of file register is outside the range, its maximum capacity is set, and the drive is changed to "Standard RAM".</li> <li>When changing to L02/L02-P, L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, if an item other than "Memory Card (ROM)" and "Standard ROM" is set to "Corresponding Memory" in the comment file used in a comment setting, it is changed to "Memory Card (SD)".</li> <li>When changing to L02S/L02S-P or L02/L02-P, if the capacity exceeds 16K points in "File used for SP.DEVST/S.DEVLD Instruction", the setting is set to 16K point.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If the number of programs exceeds the allowable number, the exceeded programs are deleted.</li> </ul>	△	△	△
Network Parameter	–	–	–	–
CC-Link IE Field Network	<ul style="list-style-type: none"> <li>If the number of modules is one and "Start I/O No." is outside the range, its maximum value is set. If the number of modules is two, "Start I/O No." is set starting from 0000.</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>If the number of slots exceeds the maximum number of slots of the changed programmable controller type, the exceeded setting is deleted.</li> </ul>	△	△	△

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
INDEX	INDEX

## ■ Changing from High-speed Universal model QCPU or Universal model process CPU

Table App.10.10-6

△ : With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Sequential Function Chart	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, the property setting "Act at Block Multi-Activated" is deleted.</li> </ul>	△	△	△
Remote Password	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, any existing settings are cleared.</li> <li>When changing to L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, the following settings are set. <ul style="list-style-type: none"> <li>The settings of the built-in Ethernet are replaced to the settings appropriate for the changed programmable controller type.</li> <li>The settings of QJ71C24/CMO are replaced to the settings of LJ71C24.</li> <li>The settings of QJ71E71 are replaced to the settings of LJ71E71.</li> </ul> </li> </ul>	△	△	△
PLC Parameter	–	–	–	–
PLC System	<ul style="list-style-type: none"> <li>If a device that exceed the range of the Device setting is set to "Latch Data Backup Operation Valid Contact", the setting is deleted.</li> <li>When changing to L02S/L02S-P or L02/L02-P, if the number of points is outside the range, its maximum point is set.</li> </ul>	△	△	△
Device	<ul style="list-style-type: none"> <li>If the value exceeds the capacity of changed programmable controller type is set for "File Register Extended Setting", the maximum value is set and all points are set as file register (ZR(R)). The setting of the latch range is cleared.</li> <li>When changing to L02S/L02S-P or L02/L02-P, if the points that exceeds 8K points are specified for S device, the setting is set to 8K points.</li> </ul>	△	△	△
Built-in Ethernet Port Setting	<ul style="list-style-type: none"> <li>If the IP address is outside the range of 0.0.0.1 to 223.255.255.254, the default is set.</li> </ul>	△	△	△
PLC File	<ul style="list-style-type: none"> <li>If the file capacity of file register is outside the range, its maximum capacity is set, and the drive is changed to "Standard RAM".</li> <li>When changing to L02S/L02S-P or L02/L02-P, if the capacity exceeds 16K points in "File used for SP.DEVST/S.DEVLD Instruction", the setting is set to 16K point.</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If the number of programs exceeds the allowable number, the exceeded programs are deleted.</li> </ul>	△	△	△
Network Parameter	–	–	–	–
CC-Link IE Field Network	<ul style="list-style-type: none"> <li>If the number of modules is one and "Start I/O No." is outside the range, its maximum value is set. If the number of modules is two or more, "Start I/O No." is set starting from 0000.</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>If the number of slots exceeds the maximum number of slots of the changed programmable controller type, the exceeded setting is deleted.</li> </ul>	△	△	△

■ Changing from Redundant CPU

Table App.10.10-7

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Sequential Function Chart	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, property settings "SFC Program Type Setting", "Periodic Execution Block", "Act at Block Multi-Activated", and "Act at Step Multi-Activated" are deleted.</li> <li>When changing to L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, property settings "SFC Program Type Setting", "Periodic Execution Block", and "Act at Step Multi-Activated" are deleted.</li> </ul>	△	△	△
Remote Password	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, any existing settings are cleared.</li> <li>When changing to L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, the following settings are set.                             <ul style="list-style-type: none"> <li>The settings of QJ71C24/CMO are replaced to the settings of LJ71C24.</li> <li>The settings of QJ71E71 are replaced to the settings of LJ71E71.</li> </ul> </li> </ul>	△	△	△
PLC Parameter	–	–	–	–
Boot File	<ul style="list-style-type: none"> <li>The setting of "Transfer From" in the Boot File setting is changed to "Memory Card (SD)".</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If the number of programs exceeds the allowable number, the exceeding settings are deleted.</li> </ul>	△	△	△
PLC File	<ul style="list-style-type: none"> <li>When changing to L02/L02-P, L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, if "Memory Card (RAM)" is set to "Corresponding Memory" in the initial device value setting, it is changed to "Memory Card (SD)".</li> <li>When changing to L02S/L02S-P, if an item other than "Program Memory" or "Standard ROM" is set to "Corresponding Memory" in the initial device value setting, it is changed to "Standard ROM".</li> </ul>	△	△	△
Network Parameter	–	–	–	–
Ethernet	<ul style="list-style-type: none"> <li>"Ethernet (Main Base)" or "Ethernet (Extension Base)" is changed to "Ethernet".</li> </ul>	△	△	△
CC-Link	<ul style="list-style-type: none"> <li>"Master station (Extension Base)" is changed to "Master Station".</li> </ul>	△	△	△

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
INDEX	INDEX

## ■ Changing from Process CPU

Table App.10.10-8

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	—	—	—	—
Sequential Function Chart	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, property settings "SFC Program Type Setting", "Periodic Execution Block", "Act at Block Multi-Activated", and "Act at Step Multi-Activated" are deleted.</li> <li>When changing to L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, property settings "SFC Program Type Setting", "Periodic Execution Block", and "Act at Step Multi-Activated" are deleted.</li> </ul>	△	△	△
Remote Password	<ul style="list-style-type: none"> <li>When changing to L02S/L02S-P or L02/L02-P, any existing settings are cleared.</li> <li>When changing to L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, the following settings are set. <ul style="list-style-type: none"> <li>The settings of QJ71C24/CMO are replaced to the settings of LJ71C24.</li> <li>The settings of QJ71E71 are replaced to the settings of LJ71E71.</li> </ul> </li> </ul>	△	△	△
PLC Parameter	—	—	—	—
Boot File	<ul style="list-style-type: none"> <li>The setting of "Transfer From" in the Boot File setting is changed to "Memory Card (SD)".</li> </ul>	△	△	△
Program	<ul style="list-style-type: none"> <li>If the number of programs exceeds the allowable number, the exceeding settings are deleted.</li> </ul>	△	△	△
PLC File	<ul style="list-style-type: none"> <li>When changing to L02/L02-P, L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, if "Memory Card (RAM)" is set to "Corresponding Memory" in the initial device value setting, it is changed to "Memory Card (SD)".</li> <li>When changing to L02S/L02S-P, if an item other than "Program Memory" or "Standard ROM" is set to "Corresponding Memory" in the initial device value setting, it is changed to "Standard ROM"</li> </ul>	△	△	△



■ Changing from Basic model QCPU

Table App.10.10-9

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Remote Password	• Any existing settings are cleared.	△	△	△
PLC Parameter	–	–	–	–
PLC File	• When changing from Q00 or Q01, "Use the following file" is selected and "Corresponding Memory: Standard RAM" and "File Name: MAIN" are set in the file register setting. • If "Used" is set in the initial device value setting, "Use the following file" is selected and "Corresponding Memory: Program Memory" and "File Name: MAIN" are set.	△	△	△
PLC System	• When changing from Q00 or Q01 to L02S/L02S-P or L02/L02-P, if the number of points is outside the range, its maximum point is set.	△	△	△
Boot File	• When changing to L02/L02-P, L06/L06-P, L26/L26-P, or L26-BT/L26-PBT, if "Do boot from standard ROM" is selected before changing the programmable controller type, "Type: Sequence", "Data Name: MAIN", "Transfer From: Memory Card (SD)", and "Transfer To: Program Memory" are set.	△	△	△

■ Changing from LCPU

Table App.10.10-10

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Sequential Function Chart	• When changing to L02S/L02S-P or L02/L02-P, the property setting "Act at Block Multi-Activated" is deleted.	△	△	△
PLC Parameter	–	–	–	–
Device	• When changing to L02S/L02S-P or L02/L02-P, if the points that exceeds 8K points are specified for S device, the setting is set to 8K points.	△	△	△
Built-in Ethernet Port Setting	• When changing from Built-in Ethernet port LCPU to L02S/L02S-P, any existing settings in "CC-Link IEF Basic Setting" are deleted.	△	△	△

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## Appendix 10.11 Restrictions when changing between QCPU (Q mode)/LCPU and CC IE Field head module

The following tables show the restrictions applied when changing QCPU (Q mode)/LCPU to CC IE Field head module and when changing communication head module to QCPU (Q mode)/LCPU.

### ■ Changing from QCPU (Q mode)/LCPU to CC IE Field head module

Table App.10.11-1

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Device Comment	• All data are deleted.			
Device Memory		△	–	–
Device Initial Value				
Remote Password	• Any existing settings are cleared.	△	–	–
PLC Parameter, Network Parameter	• All parameters are set to default.	△	–	–

### ■ Changing from CC IE Field head module to QCPU (Q mode)/LCPU

Table App.10.11-2

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Remote Password	• Any existing settings are cleared.	△	–	–
PLC Parameter, Network Parameter	• All parameters are set to default.	△	–	–

## Appendix 10.12 Restrictions when changing to FXCPU (FXCPU ↔ FXCPU)

The following tables show the restrictions applied when changing FXCPU to FXCPU.

Table App.10.12-1

△: With restrictions

Item	Restrictions	Project type		
		Simple project		Structured project
		Without labels	With labels	
Program	–	–	–	–
Ladder Diagram	• Programs which exceed the program capacity of the changed programmable controller type are deleted.	△	–	–
Global Device Comment	• Devices not supported and these outside the range are deleted.	△	△	△
Local Device Comment				
PLC Parameter	–	–	–	–
Memory Capacity	• If the program capacity set before changing the programmable controller type is not supported by the changed programmable controller type, it is changed to the maximum value of the changed programmable controller type.	△	△	△
Ethernet Port	• When the device range set in the log record setting cannot be applied as it is after the programmable controller type is changed, the log record setting is set to default.	△	△	△
Network Parameter	–	–	–	–
CC-Link	• When the number of stations set for "Station Information Setting" exceeds the maximum number for the programmable controller type, all CC-Link parameter settings are set to default.	△	△	△
Special Module (Intelligent Function Module)	Intelligent function module data is deleted.	△	△	△
System label	• FX3G, FX3GC, FX3U, and FX3UC whose projects contain system labels cannot be changed to FX0, FX0S, FX0N, FX1, FXU, FX2C, FX1S, FX1N, FX1NC, FX2N, FX2NC or FX3S.	–	△	△
Block password	• The programmable controller type cannot be changed to other than FX3U and FX3UC if the written project includes a block password to which the execution program protection setting was enabled.	–	△	△

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX

## Appendix 11 Instruction Conversion Lists



The following tables show the instructions that can be converted when changing the programmable controller type.

### Appendix 11.1 Instruction conversion for Universal model QCPU ↔ CPU other than Universal model QCPU conversion

This section shows the lists of instructions which are converted based on selecting/clearing "Convert motion dedicated sequence instruction" when the programmable controller type of a Simple project (without label) is changed.

#### ■ Instruction conversion list for conversion to Universal model QCPU

	Basic model QCPU (Except for Q00J), High Performance model QCPU, Process CPU, Universal model QCPU (Q00U, Q01U, Q02U)	Universal model QCPU (Except for Q00U, Q00UJ, Q01U, Q02U)		
		Before conversion	After conversion	
			Selected	Cleared
Motion dedicated instruction	S(P).SFCS	D(P).SFCS	S(P).SFCS	
	S(P).SVST	D(P).SVST	S(P).SVST	
	S(P).CHGV	D(P).CHGV	S(P).CHGV	
	S(P).CHGT	D(P).CHGT	S(P).CHGT	
	S(P).CHGA	D(P).CHGA	S(P).CHGA	
	S(P).DDWR	D(P).DDWR	S(P).DDWR	
	S(P).DDRD	D(P).DDRD	S(P).DDRD	
	S(P).GINT	D(P).GINT	S(P).GINT	

■ Instruction conversion list for conversion from Universal model QCPU

	Universal model QCPU (Except for Q00U, Q00UJ, Q01U, Q02U)	Basic model QCPU (Except for Q00J), High Performance model QCPU, Process CPU, Universal model QCPU (Q00U, Q01U Q02U)	
	Before conversion	After conversion	
		Selected	Cleared
Motion dedicated instruction	D(P).SFCS	S(P).SFCS*1	SM1255
	D(P).SVST	S(P).SVST*2	SM1255
	D(P).CHGV	S(P).CHGV*2	SM1255
	D(P).CHGT	S(P).CHGT*2	SM1255
	D(P).CHGA	S(P).CHGA*2	SM1255
	D(P).DDWR	S(P).DDWR*3	SM1255
	D(P).DDRD	S(P).DDRD*3	SM1255
	D(P).GINT	S(P).GINT*4	SM1255

- \*1 : When the number of arguments is 2, correct the arguments after the programmable controller type is changed.
- \*2 : When the number of arguments is 3, correct the arguments after the programmable controller type is changed.
- \*3 : When a character string is used in an argument, correct the argument after the programmable controller type is changed.
- \*4 : When the number of arguments is 3 or more, correct the arguments after the programmable controller type is changed.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

—

INDEX

## Appendix 11.2 Instruction conversion for Redundant CPU ↔ CPU other than Redundant CPU conversion

### ■ Instruction conversion list for conversion to Redundant CPU

The following instructions are converted to "OUT SM1255".

	Description	Instruction name
QCPU instruction	Program load	PLOADP
	Program unload	PUNLOADP
	Load + unload	PSWAPP
Motion dedicated instruction	Data write to host CPU shared memory	S.TO
	Other CPU device data read to host CPU device	S.DDRD
	Host CPU device data write to other CPU device	S.DDWR
	Motion SFC program start request	S.SFCS
	Torque limit value change during operation/stop in real mode	S.CHGT
	Servo program start request	S.SVST
	Axis speed change during positioning or JOG operation	S.CHGV
	Current value change for stopping axis/synchronous encoder/cam axis	S.CHGA
Display instruction	Other CPU interrupt program start request	S.GINT
	ASCII code print instruction	PR
Peripheral device instruction	Comment print instruction	PRC
	Key input from peripheral device	KEY
Other convenient instruction	1-phase input up/down counter	UDCNT1
	2-phase input up/down counter	UDCNT2
	Teaching timer	TTMR
	Special function timer	STMR
	Rotary table shortest direction control	ROTC
	Ramp signal	RAMP
	Pulse density measurement	SPD
	Fixed cycle pulse output	PLSY
	Pulse width modulation	PWM
	Matrix input	MTR
Program control instruction	Program low-speed execution registration instruction	PLOW

■ Instruction conversion list for conversion from Redundant CPU

	Before conversion	After conversion		
	Redundant CPU	Basic model QCPU	High Performance model QCPU	Process CPU
Control system switching instruction	SP.CONTSW	OUT SM999	OUT SM1255	OUT SM1255
PID control instruction	PIDINIT	PIDINIT	PIDINIT	
	PIDCONT	PIDCONT	PIDCONT	
	PIDSTOP	PIDSTOP	PIDSTOP	
	PIDRUN	PIDRUN	PIDRUN	
	PIDPRMW	PIDPRMW	PIDPRMW	
	S.PIDINIT	S.PIDINIT	S.PIDINIT	
	S.PIDCONT	S.PIDCONT	S.PIDCONT	
	S.PIDSTOP	S.PIDSTOP	S.PIDSTOP	
	S.PIDRUN	S.PIDRUN	S.PIDRUN	
S.PIDPRMW	S.PIDPRMW	S.PIDPRMW		

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

## Appendix 12 Functions Added Since Previous Versions

Q CPU L CPU Remote Head FX

This section shows major functions added/changed with upgrade.

For (Simple), (FB), (Structured), (Intelligent), and (iQSS) described in the Reference column, refer to the following manuals respectively.

(Simple) ...GX Works2 Version 1 Operating Manual (Simple Project)  
 (FB) ...GX Works2 Version 1 Operating Manual (Simple Project, Function Block)  
 (Structured)...GX Works2 Version 1 Operating Manual (Structured Project)  
 (Intelligent) ...GX Works2 Version 1 Operating Manual (Intelligent Function Module)  
 (iQSS) ...iQ Sensor Solution Reference Manual

Version	Major function added/changed	Description	Reference	
Version 1.05F	Label comment display	Label comments can be displayed in Structured projects.	(Structured)	
Version 1.08J	Programmable controller type	Q00UJ, Q00U, Q01U, Q10UDH, Q10UDEH, Q20UDH, Q20UDEH, and FX series are supported.	–	
	Intelligent function module	Q68TD-G-H02 is supported.	–	
	Change PLC Type	The programmable controller type can be changed from Universal model QCPU to High Performance model QCPU.	Section 4.2.8	
	Verify	The parts that do not match can be searched.	Section 4.2.7 Section 4.6.5 Section 15.2	
	Parameter		The following parameters are supported by Universal model QCPU. <ul style="list-style-type: none"> <li>The CPU module can be replaced using a memory card.</li> <li>Index registers can be specified as local devices.</li> <li>The A-PLC compatibility Setting is supported.</li> </ul>	Section 6.1.1
			Twist-bus-compatible modules are supported by MELSECNET/H.	Section 6.3.1
	Ladder		With the easy edit function, the following functions can be operated by a one-step operation (menu/shortcut key). <ul style="list-style-type: none"> <li>Draw line</li> <li>Change open/close contact</li> <li>Switch statement/note type</li> <li>Instruction partial edit</li> </ul>	(Simple)
			Ladder blocks can be displayed/hidden in units of one ladder block.	
			The ladder editor and function block can be displayed horizontally.	
			The instruction help can be opened from the menu.	
	ST		Arguments of a template can be selected one-by-one by the menu or shortcut key.	(Structured)
	Structured Ladder		The wrapping positions for printing can be checked on the Structured Ladder editor.	
	Monitor		The program list can be monitored.	Section 17.4
The interrupt program list monitor can be monitored.			Section 17.5	
The intelligent function modules can be monitored.			Section 17.7	
Debug		The forced input/output can be registered/canceled.	Section 19.2	
		The device test with execution condition is supported by the Universal model QCPU.	Section 19.3	



Version	Major function added/changed	Description	Reference	
Version 1.08J	CC-Link/ CC-Link/LT Diagnostics	The screen for the CC-Link/CC-Link/LT diagnostics is modified.	Section 21.6	
		The CC-Link/CC-Link/LT diagnostics support the following functions. <ul style="list-style-type: none"> <li>Obtain transmission speed setting</li> <li>Status logging</li> <li>Create check sheet</li> </ul>		
	System monitor	The error reset function can be performed on the <u>Module's Detailed Information</u> screen.	Section 21.9	
	Shortcut key customize	With the shortcut key customize function, shortcut keys can be registered arbitrarily.	Section 3.2.8	
	Parameter	The socket communication through Ethernet is supported by Built-in Ethernet port QCPU.	Section 6.1.1	
	FB library	FB libraries are supported.	Section 13.1.1 (FB)	
Version 1.12N	Programmable controller type	Q00J, Q00, and Q01 are supported.	-	
	Intelligent function module	Q64AD2DA and Q61LD are supported.	-	
	Programming language	<ul style="list-style-type: none"> <li>Structured Text is supported by Simple projects (with labels) of QCPU (Q mode).</li> <li>Sequential Function Chart is supported by Simple projects (without labels) of FXCPU.</li> </ul>	(Simple)	
	Project type	Simple projects (with labels) are supported by FXCPU.	-	
	Navigation window	The Project window is modified, and its name is changed to Navigation window.	-	
	Change PLC Type	Motion dedicated instructions can be converted when the programmable controller type of a Simple project (without label) is changed.	Section 4.2.8	
	Print	Device initial value can be printed.	Chapter 11	
	Saving projects	The project compression/decompression function is supported.	Section 4.2.4	
	Parameter	The module error history collection function for the intelligent function module is supported by Universal model QCPU.	Section 6.1.1	
	Program editor	The default font color of labels is changed.	-	
	Ladder	The following instructions are supported. <ul style="list-style-type: none"> <li>Rising pulse close instruction</li> <li>Falling pulse close instruction</li> <li>Rising pulse close branch instruction</li> <li>Falling pulse close branch instruction</li> </ul>	<ul style="list-style-type: none"> <li>Simplified edit of devices/labels is supported by the <u>Enter Symbol</u> screen.</li> <li>An undefined label can be registered following an element entry operation.</li> <li>A list of possible candidates of instructions/labels can be displayed at entering elements.</li> <li>A tooltip for arguments of an instruction can be displayed at entering instructions.</li> </ul>	(Simple)
			The line statement list function is supported.	
			The cursor can jump to the start of the next ladder block or the start of the previous ladder block.	
			The change TC setting function is supported.	
The Inline structured text function is supported.				
SFC	<ul style="list-style-type: none"> <li>The SFC editor window and the Zoom editor window can be displayed vertically at opening the SFC window.</li> <li>An SFC block can be displayed automatically at auto scroll monitoring.</li> </ul>			

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

Version	Major function added/ changed	Description	Reference
Version 1.12N	ST	The bookmark list function is supported.	(Structured)
	Structured Ladder	A list of possible candidates of instructions/labels can be displayed at entering elements.	
	All Device Display	In a ladder program or Structured Ladder program, the display of labels on all program editors being opened can be switched to the device display simultaneously.	(Simple)
	Find/Replace	In all programming languages, Find String/Replace String, Find Device/Replace Device, Find Instruction/Replace Instruction, and Change Open/Close Contact are supported.	Section 10.3
	Device Memory	A character string can be entered to device memory.	Section 7.2.3
		The FILL function is supported.	Section 7.2.4
	Write to PLC	In a project (with labels), file sizes can be displayed/hidden on the Write to PLC screen.	Section 15.1
	Confirm Memory Size	The memory size required when data is written to the programmable controller CPU can be calculated.	Section 15.10
	Monitor	Detailed information of such as an error can be confirmed from the Intelligent Function Module Monitor window.	Section 17.7
	Simulation function	The minimized display at start up of simulation is supported.	Section 18.2
		The saving/reading device memory/buffer memory function is supported.	Section 18.2.1 Section 18.2.2
		The I/O system setting function is supported.	Chapter 22
	Scan Time Measurement	The scan time measurement function is supported.	Section 19.5
	CC-Link IE Control Diagnostics	The <u>Logging</u> screen of another station can be displayed.	Section 21.3
	CC-Link/ CC-Link/LT Diagnostics	<ul style="list-style-type: none"> <li>Up to 64 modules can be displayed.</li> <li>The system configuration can be output in a check sheet.</li> </ul>	Section 21.6
	System monitor	The module information at time of the error occurrence can be displayed in the error history list.	Section 21.9
	Shortcut key customize	User-created shortcut key settings can be registered to a template.	Section 3.2.8
Intelligent function module tool	<ul style="list-style-type: none"> <li>The Q61LD two-point calibration setting of the analog module is supported.</li> <li>The auto tuning function of the temperature control module is supported.</li> <li>The preset function of the counter module is supported.</li> <li>The positioning test, wave trace, location trace, offline simulation, automatic command speed calculation, and automatic sub arc calculation of QD75 positioning module are supported.</li> <li>The circuit trace function of the serial communication module is supported.</li> </ul>	(Intelligent)	
FB library	Components of the FB libraries can be imported to a project being edited using the function to obtain the libraries to a project.	Chapter 13 (FB)	

Version	Major function added/changed	Description	Reference
Version 1.15R	Parameter	The function to apply the parameters of MELSOFT Navigator is supported.	Section 6.1
	Transfer setting	The GOT (Ethernet) transparent mode is supported.	Section 14.9.1
	ST	The following instructions are supported. <ul style="list-style-type: none"> <li>• Negated rising edge instruction</li> <li>• Negated falling edge instruction</li> </ul>	(Structured)
	Structured Ladder	The following contact symbols are added. <ul style="list-style-type: none"> <li>• Rising edge</li> <li>• Falling edge</li> <li>• Negated rising edge</li> <li>• Negated falling edge</li> </ul>	
		The following instructions are supported. <ul style="list-style-type: none"> <li>• Negated rising edge instruction</li> <li>• Negated falling edge instruction</li> </ul>	
Global label	System labels are supported.	(Simple) (Structured)	
Version 1.24A	Programmable controller type	L02 and L26-BT are supported.	–
	Intelligent function module	L64AD4, L60DA4, LJ71C24, and LJ71C24-R2 are supported.	(Intelligent)
	Ladder	<ul style="list-style-type: none"> <li>• The Inline structured text function is supported by FXCPU.</li> <li>• The following functions are supported by the Inline structured text function.                             <ul style="list-style-type: none"> <li>• Verifying projects</li> <li>• Verifying revisions</li> <li>• Replacing character strings</li> </ul> </li> </ul>	Section 4.2.7 Section 4.6 Section 10.3.3
	ST	<ul style="list-style-type: none"> <li>• The compilation result can be displayed in list format.</li> <li>• The ST control syntax templates are supported.</li> </ul>	(Simple)
	Structured Ladder	<ul style="list-style-type: none"> <li>• The compilation result can be displayed in list format.</li> <li>• Function blocks can be dragged and dropped from the Project view.</li> </ul>	(Structured)
	Saving projects	A title of the change history of the project can automatically be set when it is overwritten.	Section 4.2.3
	Device List	<ul style="list-style-type: none"> <li>• The number of uses of a coil which uses the device can be displayed.</li> <li>• Devices which are used in the parameters can be indicated.</li> </ul>	Section 10.2
	Colors and fonts	The color and font settings can be reset to default.	Section 3.2.7
	Write to PLC	A project can automatically be saved after it is written to the programmable controller CPU.	Chapter 15
	Simulation function	The simulation function is supported by FXCPU.	Chapter 18 Chapter 22 Appendix 2
	Intelligent function module tools	<ul style="list-style-type: none"> <li>• The offset/gain setting can be performed from the menu.</li> <li>• The predefined protocol support function of the serial communication module is supported.</li> </ul>	(Intelligent)
	Help	The detailed explanation of instructions can be opened from the program editor or the Element Selection window.	–

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
INDEX	INDEX

Version	Major function added/ changed	Description	Reference
Version 1.31H	Programmable controller type	Q50UDEH, Q100UDEH, and LJ72GF15-T2 are supported.	–
	Intelligent function module	LD62, LD62D, LD75P4, LD75D4, and LD77MH4 are supported.	(Intelligent)
	Ladder	In projects (with labels), the function which enables the device display in uncompiled state is supported.	–
	SFC	The display format "MELSAP-L (Instruction Format)" / "MELSAP-L (Start Conditions Format)" are supported.	(Simple)
	Global labels	System labels are supported by LCPUC.	(Simple) (Structured)
	Change PLC Type	The programmable controller type of a project which contains intelligent function modules can be changed between programmable controller series.	Section 4.2.8
	Parameter	In the network parameter, "CC IE Field (Master Station)" and "CC IE Field (Local Station)" are supported by Universal model QCPU.	Section 6.3
	Intelligent function module data	<ul style="list-style-type: none"> <li>The disconnection detection mode setting and Disconnection detection setting value setting are supported by Q62DA-FG.</li> <li>The following settings are supported by QJ71C24N/ QJ71C24N-R2. <ul style="list-style-type: none"> <li>The echo back permit/prohibit specification and the execution history option specification are supported by the various control specification.</li> <li>The predefined protocol function error code, the send data storage area, and the receive data storage area are supported by the auto refresh.</li> </ul> </li> </ul>	(Intelligent)
	Cross Reference	In projects (with labels), the cross reference information can be displayed in uncompiled state.	Section 10.1
	Local Device Batch Read	The function which reads local device data from the programmable controller CPU and saves the data on the personal computer is supported by Universal model QCPU.	Section 15.12
	CC IE Field Diagnostics	The CC-Link IE Field Network diagnostics is supported by Universal model QCPU.	Section 21.4
Options	For QCPU (Q mode)/LCPUC, the following option is added. [Tool] ⇒ [Options] ⇒ "PLC Read/Write" ⇒ "When writing to PLC after a Rebuild All operation, clear the device ranges set in the Device/Label Auto-Assign setting to 0."	Section 15.1.8 Section 12.2 (Simple) (Structured)	
Version 1.40S	Operating environment	Windows® 7 is supported.	–
	Programmable controller type	Remote I/O module is supported.	–
	Ethernet adapter module configuration tool	Ethernet adapter module configuration tool is supported.	Section 20.8
	Label	The Read from CSV File and Write to CSV File functions are supported.	(Simple) (Structured)
	Device comment	Bit-specified word device comments are supported by Universal model QCPU.	Section 9.2.1 Section 15.1.3
	Ladder	The template function in the inline structured text program is supported.	(Structured)
		The drag-and-drop operation from the ladder editor is changed.	Section 17.6.2
	SFC	"Act at Block Multi-Activated" can be set for Universal model QCPU.	(Simple)
	ST	The menu title [Create Template] is changed to [Display Template].	(Structured)
	Structured Ladder	<ul style="list-style-type: none"> <li>The line connection function in "Select Mode" is supported.</li> <li>The automatic line connection function when entering elements is supported.</li> </ul>	(Structured) (Structured)

Version	Major function added/changed	Description	Reference
Version 1.40S	Compile	A compilation error does not occur when the same name is used for label name and data name.	-
		The option to check whether devices are used exceeding the device range assigned to labels in the data transfer instruction such as DMOV is added.	Section 12.2
	Opening existing projects	Projects in the workspace folder/project folder which is copied or moved using Windows® Explorer can be forcibly opened.	Section 4.2.2
	Opening projects in other formats	GX Developer option setting "Copy source/display source of reference during comment edit" is utilized to GX Works2 option setting: "Program Editor" ⇒ "Ladder/SFC" ⇒ "Comment" ⇒ "Reference of Device Comment".	Section 4.7.1
	Verify	Intelligent function module parameters (initial setting, auto refresh), QD75/LD75 positioning module set data can be verified in the following verification function. <ul style="list-style-type: none"> <li>Project verification</li> <li>Revision verification</li> <li>Programmable controller CPU data verification</li> </ul>	Section 4.2.7 Section 4.6.5 Section 15.2
	Parameter	The extended setting of step relay (S device) is supported by Universal model QCPU.	-
		"CC IE Control Ext. Mode (Control station)" and "CC IE Control Ext. Mode (Normal Station)" are added.	-
		The loopback function setting is added to the supplementary setting of CC-Link IE Field.	-
	Cross Reference	The Cross Reference window can be displayed vertically.	Section 10.1
	Find/Replace	The focus is not moved to the editor side after executing the search/replace function.	Section 10.3.1 Section 10.3.2 Section 10.3.3 Section 10.3.4
		The device search/replace function can be executed for indexed devices without canceling "Digit" or "Double Word" option.	Section 10.3.1
		The search function can be executed on different items when the devices are being displayed on the ladder editor.	-
		Find Device, Replace Device, Find Instruction, Replace Instruction, Change Open/Close Contact, and Device Batch Replace functions are supported by the inline structured text function.	Section 10.3
	Online Program Change	SFC block Online program change is supported by Universal model QCPU.	Section 15.9.1
Simulation function	Local device data can be read.	Section 15.12	
Global label	System labels are supported by FX3G, FX3U, and FX3UC.	(Simple) (Structured)	

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

Version	Major function added/ changed	Description	Reference
Version 1.48A	Intelligent function module	QD65PD2 and LD77MH16 are supported.	(Intelligent)
	Navigation window	<ul style="list-style-type: none"> <li>Titles set in the property are displayed on the Navigation window.</li> <li>The color of the characters on the title bar is displayed in red when an uncompiled data exists.</li> </ul>	Section 3.2.5
	Open other project	The secured steps for Online program change and the writing range of device comment set in GX Developer can be utilized.	Section 4.7.1
	Transfer setting	CC-Link IE Field Network board is supported.	Section 2.2 Section 2.3 Section 14.1
		Ethernet connection between personal computer and GOT is supported.	Section 14.9.1 Section 14.9.2
	Device comment	Sample comments of input/output signals can be utilized for intelligent function module.	Section 9.5.2
	Ladder	<ul style="list-style-type: none"> <li>The number of displayed contacts in a ladder program can be set to 13, 17, or 21 contacts.</li> <li>For FXCPU Simple project (with labels), execution program can be divided into multiple programs.</li> </ul>	(Simple)
	Verify	<p>The following functions are supported on the <u>Verify Result</u> screen.</p> <ul style="list-style-type: none"> <li>Copy data</li> <li>Write data to CSV file</li> </ul>	Section 4.2.7
	Print	<p>The following information can be added when printing a ladder program.</p> <ul style="list-style-type: none"> <li>Device comment</li> <li>Statement/note</li> <li>Contact/coil usage destination</li> </ul>	Section 11.8.1
		The print preview and the print functions are supported on the <u>Device List</u> screen.	Section 11.9 Section 11.7
	Cross reference	For project without labels, a device on which the cursor is placed in the program editor can be searched automatically.	Section 10.1
	Write to PLC/Online program change	<ul style="list-style-type: none"> <li>'High-speed mode' is supported when writing symbolic information to a programmable controller CPU.</li> <li>A default setting of target memory can be set in the option setting for Online program change.</li> </ul>	Section 15.1.5
	Watch window	<ul style="list-style-type: none"> <li>The automatic registration function is supported.</li> <li>The list of devices/labels registered to Watch window can be write to/read from CSV files.</li> </ul>	Section 17.6.2 Section 17.6.4
	PLC diagnostics	When the error jump is executed from the <u>PLC Diagnostics</u> screen, the <u>PLC Diagnostics</u> screen is down sized to be able to specify the error location in the program easily.	Section 21.1
	Intelligent function module tool	<ul style="list-style-type: none"> <li>The monitoring function (positioning monitor) dedicated to QD75/LD75 positioning module is supported.</li> <li>The user protocol library function is supported for the predefined protocol support function.</li> </ul>	(Intelligent)
Language selection	<p>Characters of the following languages are not corrupted by selecting a project language.</p> <ul style="list-style-type: none"> <li>English</li> <li>Chinese (simplified characters)</li> <li>Korean</li> </ul>	Section 3.3 Appendix 18	

Version	Major function added/changed	Description	Reference
Version 1.53F	Incorporation with GX Developer	GX Developer can be installed at the same time as installation of GX Works2.	Appendix 14
		GX Developer is used for the following functions when the programmable controller type is not supported by GX Works2. <ul style="list-style-type: none"> <li>• Creating a new project</li> <li>• Opening a project</li> <li>• Opening a project in other formats</li> <li>• Creating a new project with data read from programmable controller CPU</li> </ul>	Section 4.2.1 Section 4.2.2 Section 4.7.1
	Intelligent function module	QJ71MT91 and QJ71MB91 are supported.	(Intelligent)
	Ladder	Changes of function block names and deletions of function blocks are automatically applied to the target program.	-
		Changes of the function block label setting are applied to the target program at compilation.	-
	SFC	When copying and pasting SFC block data, whether to overwrite block data with the same block number, or to add data with unused block number can be selected.	-
	Structured Ladder	Operability of the <u>Label Registration/Selection</u> screen is improved.	(Structured)
	Print	The print function to batch print project data is supported.	Chapter 11
		The print preview and the print functions are supported on the <u>Cross Reference</u> screen.	Section 10.1
	Parameter	In the network parameter, "CC IE Field (Master Station)" and "CC IE Field (Local Station)" are supported by LCPU.	Section 6.3
	Search/Replace	The search/replace function can be executed for digit-specified bit devices, devices with index setting, and devices with indirect specification. Note that either a searched device or a replaced device needs to be a label when replacing devices.	Section 10.3
		Devices, instructions, strings, contacts, and coils can be searched from the shortcut menu by right-clicking the ladder editor or SFC (Zoom) editor.	
		The default setting for "Find In" is changed to "(Entire Project)".	
	Debug	The debugging function can be executed during the program simulation.	Section 19.6
	CC IE Field Diagnostics	LJ71GF11-T2 is supported.	Section 21.4
"Selected Station Communication Status Monitor" function is supported by Ethernet adapter module.			
Device/label automatic-assign setting	Multiple devices can be set in the device/label automatic assign setting for QCPU (Q mode) and LCPU.	(Simple) (Structured)	
Language selection	The applicability of data names and label names to be used in a language-changed project is checked when selecting the language.	-	
	The applicability of language of the data name in a project to which the data is pasted is checked when data are copied between projects.	-	

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

Version	Major function added/ changed	Description	Reference
Version 1.62Q	Project	A project can be overwritten when a project is saved with an existing project name.	Section 4.2.3
		A project can be saved in the single file format.	Section 4.2
	Programmable controller type	L02-P and L26-PBT are supported.	–
	Intelligent function module	Q64TCTTN, Q64TCRTN, Q64TCTTBWN, Q64TCRTBWN, L60TCTT4, L60TCTT4BW, L60TCRT4, and L60TCRT4BW are supported.	(Intelligent)
	Comment	The automatic start function which converts the language at the entry of device comments, statements and notes is supported.	Section 12.2
	Device comment	When a device comment is edited in a ladder or SFC program, the edited information is reflected to the referred device comment.	Section 9.2.2
	Ladder	"Read Mode", "Write Mode", "Monitor Mode", and "Monitor (Write Mode)" are supported.	(Simple)
		Line statements can be displayed on the Navigation window.	
		The initial value for the <u>Enter HLine</u> screen and the <u>Delete HLine</u> screen can be set to "1".	
		Entry or deletion of horizontal line can be stopped at the instruction or vertical line.	
		The option setting to disable the display of note on the <u>Enter Symbol</u> screen when editing a coil instruction is added.	
	SFC	"Read Mode", "Write Mode", "Monitor Mode", and "Monitor (Write Mode)" are supported.	(Simple)
		An SFC diagram and a Zoom editor can be tiled horizontally.	
		The jump step search function is added.	
	Structured Ladder	The display of the programming language name is changed from "Structured Ladder" to "Structured Ladder/FBD".	(Structured)
		The function to display/hide the left power rail is added.	
		Labels and devices assigned to labels can be displayed simultaneously.	
	Label	The program does not become in an uncompiled status even when information in "Comment" and "Remark" is changed.	(Simple) (Structured)
		Cells can be selected and copied on the label editor.	–
	Print	The following data can be batch printed. <ul style="list-style-type: none"> <li>• Cover</li> <li>• PLC parameter</li> <li>• Network parameter</li> <li>• Structured Ladder/FBD</li> <li>• Device memory</li> <li>• Device initial value</li> <li>• TC setting value</li> <li>• Device list</li> <li>• Cross reference</li> <li>• Project content list</li> <li>• Product information list</li> </ul>	Chapter 11
When printing ladder programs, blank device comment lines are not printed in the default setting.			
Parameter	The simple PLC communication setting is supported by LCPU.	Section 6.1	
	The serial communication setting is supported by QnUD(H)CPU.	Section 6.1.1	
Device List	When searching for devices in a specified program, device comments can be entered in the device list.	Section 10.2	
	When searching for devices in a specified program, device comments of devices which are not used in the program can be deleted.		



Version	Major function added/changed	Description	Reference
Version 1.62Q	Search/Replace	The function to search/replace devices/labels/instructions downward from the top of the editor is added.	Section 10.3
		Data can also be searched in other programs in the project with the space key search function on the ladder editor.	(Simple)
	Write to PLC/Read from PLC	Symbolic information can be written to/read from a programmable controller CPU with FX3U/FX3UC version 3.00 or later.	Section 15.1
	CC IE Field Diagnostics	The configuration including CC-Link IE Field Network communication units can be diagnosed.	Section 21.4
	Block password	Execution programs can be protected on FX3U/FX3UC version 3.00 or later.	Section 4.12
	Intelligent function module Tool	The sensor correction function of temperature control module is supported.	(Intelligent)
	Help	The MELSOFT help function is supported.	Section 3.4
Version 1.64S	Product Makeup	Data are supplied with two CDs.	GX Works2 Installation Instructions
	Operation Environment	Required HDD free space for the installation is changed to 2.5GB or more.	
	Intelligent function module	QD75P1N, QD75P2N, QD75P4N, QD75D1N, QD75D2N, and QD75D4N are supported.	(Intelligent)
	Print	<ul style="list-style-type: none"> <li>Print job output can be selected.</li> <li>Print conditions for device memory data are added.</li> <li>Whether to print or not to print 'start destination block' can be selected on the SFC block list.</li> <li>Setting values of timer, retentive timer, and counter can be printed according to devices when printing TC setting values.</li> </ul>	Chapter 11
	Parameter	<ul style="list-style-type: none"> <li>For LCPU, "Branch Module" can be selected for the I/O assignment setting on PLC parameter.</li> </ul>	Section 6.1.1
	Intelligent function module Data	QD75/LD75 positioning module data can be saved to/read from the file.	(Intelligent)
	Device comment	<ul style="list-style-type: none"> <li>For LCPU, bit-specified word device comment is supported.</li> <li>Device comments can be saved to/read from the file.</li> </ul>	Section 9.2.1 Section 15.1.3
	Transfer setting	A personal computer can be connected to a programmable controller CPU via a phone line.	Section 14.10
	Verify	<p>For QCPU (Q mode)/LCPU, the following functions are supported.</p> <ul style="list-style-type: none"> <li>The following data can be verified when verifying projects or revisions. <ul style="list-style-type: none"> <li>Device comment</li> <li>Device memory</li> </ul> </li> <li>The following data can be verified when verifying programmable controller data. <ul style="list-style-type: none"> <li>Device comment</li> <li>Device memory</li> <li>File register</li> </ul> </li> </ul>	Section 4.2.7 Section 4.6.5 Section 15.2
System monitor	For LCPU, extension blocks can be monitored.	Section 21.9	

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

Version	Major function added/ changed	Description	Reference
Version 1.73B	Intelligent function module	<ul style="list-style-type: none"> <li>Q64ADH is supported.</li> <li>A parameter item is added for Q62HLC.</li> </ul>	(Intelligent)
	Transfer Setup	For FX3U and FX3UC, programmable controller CPU connections via CC-Link are supported.	Section 14.3
		For FXCPU, the Ethernet connection between a personal computer and a GOT is supported.	Section 14.9
	Ladder	<ul style="list-style-type: none"> <li>Ladder blocks can be pasted consecutively with incremented device numbers on the ladder editor.</li> <li>Ladder programs can be saved to/read from CSV files in list format</li> </ul>	(Simple)
	SFC	<ul style="list-style-type: none"> <li>SFC blocks can be copied/pasted on the SFC block list.</li> <li>SFC diagrams can be converted in SFC block unit.</li> </ul>	
	Structured Ladder	Function blocks of ladder program can be used in a Structured Ladder program, and function blocks of Structured Ladder program can be used in a ladder program.	(Structured)
	Parameter	<ul style="list-style-type: none"> <li>Station information of CC-Link is displayed graphically on the CC-Link Configuration window.</li> <li>Assignment information of refresh devices of CC-Link can be checked easily in the Device Reference window.</li> <li>Default parameters can be set in batch to the PLC parameter and the network parameter.</li> </ul>	Section 6.3.3 Section 6.3.4 Section 6.7
		For FXCPU, the CC-Link setting is supported by the network parameter.	Section 6.3
		The I/O assignment setting and the acknowledge XY assignment of PLC parameter can be saved to CSV files.	Section 6.6
	Device comment	Device comment data being displayed can be deleted in batch.	Section 9.3.2
	Cross reference	<ul style="list-style-type: none"> <li>For Simple projects (with labels), the time to create cross reference information can be reduced by selecting "Fast Find". Cross reference information can be created even when a program is uncompiled.</li> <li>Cross reference of SFC program block information is supported.</li> <li>Elements of instructions in which devices are used in a ladder program can be displayed.</li> </ul>	Section 10.1
	Device List	The device points to be searched can be selected.	Section 10.2
	Write to PLC	The number of characters of device comment to be written can be specified when writing data to a programmable controller CPU.	Section 15.1.3
	Monitor	<ul style="list-style-type: none"> <li>The Entry Ladder Monitor function to monitor registered ladder blocks is supported by Simple project (without labels).</li> <li>For QCPU (Q mode)/LCP, monitoring condition/monitoring stop condition can be set.</li> </ul>	(Simple)
	CC-Link/ CC-Link/LT Diagnostics	For FXCPU, the CC-Link/CC-Link/LT diagnostic is supported.	Section 21.6
	Write/read IC memory card data	<ul style="list-style-type: none"> <li>A password can be set to data when writing data to an IC memory card.</li> <li>Data can be written to/read from an IC memory card by specifying a folder.</li> <li>Symbolic information can be written to/read from an IC memory card.</li> </ul>	Section 15.11.1
Options	The setting to enable compilation when opening a project contains ST programs of GX Developer is added.	Section 12.2	
Merge Data	Multiple ladder program data or device comment data can be merged and added to the project.	Section 4.3.5	
Intelligent function module data	The Setting item reduction mode can be set for the auto refresh parameter of temperature control.	(Intelligent)	

Version	Major function added/changed	Description	Reference
Version 1.77F	Programmable controller type	FX3GC is supported.	-
	Intelligent function module	Q68CT, LD75P1, LD75P2, LD75D1, LD75D2, QD77MS2, QD77MS4, and QD77MS16 are supported.	(Intelligent)
	Parameter	The IP Packet Transfer setting can be set on the <<Built-in Ethernet Port Setting>> tab of PLC parameter.	Section 6.1.1
		<ul style="list-style-type: none"> <li>CC IE Field (sub-master station) is supported by Universal model QCPU in the network parameter.</li> <li>The IP Packet Transfer setting can be set in the network parameter for Built-in Ethernet port QCPU in CC-Link IE Field Network.</li> </ul>	Section 6.3.1
		The operation at reconnection can be set in "Network Configuration Settings" for Universal model QCPU when "CC-IE Filed (Master Station)" is selected for "Network Type".	-
	Intelligent function module data	Positioning module data can be saved as a GX Configurator-QP format project file.	(Intelligent)
	Label	<ul style="list-style-type: none"> <li>Labels can be sorted in ascending or descending order.</li> <li>Blank rows below the last row to which the label is set on the label setting editor can be deleted to a single blank row.</li> </ul>	(Simple) (Structured)
	Read from PLC	When a project, in which the setting of "Compile" under [Tool] => [Options] has been changed, is read from a programmable controller CPU, the project will not be an uncompiled project.	-
	CC IE Field Diagnostics	Sub-master stations are supported.	Section 21.4
		The IP communication test is supported.	Section 21.4.2
Version 1.87R	Toolbar	Editing screens can be displayed from the toolbar in Simple projects.	Section 3.2.2
	Navigation window	Tasks in a program file can be sorted in the execution order.	Section 3.2.5
	Open other project	<ul style="list-style-type: none"> <li>For QCPU (Q mode)/LCPU, GX Developer projects with GX Works2 invalid characters can be opened.</li> <li>SFC block names are set with sequential number without appending a program name.</li> <li>A project can be opened with the connection destination settings saved in the GX Developer format.</li> </ul>	Section 4.7.1
	Device Memory	Device values can be set by specifying a device range on the cell	Section 7.2.2
	Device comment	The setting method of "Specify the Reference/Reflection" is improved.	Section 9.1.1
		The number of points of device comment that can be set in the project can be extended.	Section 9.4
		Applicable number of characters to be entered is limited for the device comment editing mode.	Section 9.2.2
	Find/Replace	Block information set on the <u>Property</u> screen of SFC block can be searched.	
	Ladder	<ul style="list-style-type: none"> <li>Labels and devices can be displayed simultaneously.</li> <li>Detailed information of the label can be displayed with the tooltip when the cursor is placed on the label.</li> <li>List of instructions/labels and tooltip for instructions can be displayed/hidden when entering an element.</li> <li>Device comments can be copied and pasted along with the copied elements.</li> <li>Programs in ladder block unit can be displayed/edited in the list format.</li> <li>The cursor position does not change when switching the mode to "Read Mode", "Write Mode", "Monitor Mode", or "Monitor (Write Mode)" in the ladder editor.</li> </ul>	(Simple)
		A function block can be called from a function block in the ladder program.	(Structured) (FB)

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

Version	Major function added/ changed	Description	Reference
Version 1.87R	SFC	<ul style="list-style-type: none"> <li>SFC step/transition comments can be pasted along with the copied blocks on the SFC block list.</li> <li>Text size on the editing screen can be changed.</li> <li>The comment or the step number on the <u>Enter SFC Symbol</u> screen can be displayed as it is in selected status when changing the SFC symbol in MELSAP3.</li> </ul>	(Simple)
	Inline structured text	The compilation result can be displayed from the shortcut menu.	
	ST	The compilation result can be displayed from the shortcut menu.	
	Structured Ladder	<ul style="list-style-type: none"> <li>The compilation result can be displayed from the shortcut menu.</li> <li>The tool button to connect lines automatically is added.</li> </ul>	(Structured)
	Security	Access authority of multiple items can be set in batch.	Section 4.10.4
	Block password	A block password can be set for POU's in batch.	Section 4.12.1
	Cross Reference	<ul style="list-style-type: none"> <li>Devices set in simple PLC communication setting of PLC parameter can be searched.</li> <li>A search range can be specified in program file unit.</li> <li>Block start steps of SFC blocks can be searched.</li> <li>The setting to search devices other than the start device is added under "Find Condition" on the &lt;&lt;Condition Setting&gt;&gt; tab.</li> </ul>	Section 10.1
	Device List	<ul style="list-style-type: none"> <li>Devices set in simple PLC communication setting of PLC parameter can be searched.</li> <li>All SFC blocks are searched when an SFC program is set for the search location.</li> </ul>	Section 10.2
	Monitor	<ul style="list-style-type: none"> <li>The display format can be changed by the button on the <u>Device/Buffer Memory Batch Monitor</u> screen.</li> <li>Device comments of monitored devices can be displayed on the <u>Device/Buffer Memory Batch Monitor</u> screen.</li> </ul>	Section 17.3
		Devices and labels on the SFC editor window are automatically registered to the Watch window.	Section 17.6.2
	Options	The setting in which the program cache memory is checked and automatically fixed when a program is written to a programmable controller CPU is added.	Section 12.2
		For FXCPU, the following option can be set. When reading a project saved with GX Works 2 which does not support the following option, the item is selected. [Tool] ⇒ [Options] ⇒ "PLC Read/Write" ⇒ "When writing to PLC after a Rebuild All operation, clear the device ranges set in the Device/Label Auto-Assign setting to 0."	Section 15.1.8 Section 12.2 (Simple) (Structured)
	Read from PLC	Programs which are closed when performing the read from PLC function are reopened.	–
Installation	When upgrading GX Works2, the information of color and fonts of the previous version is retained.	–	

Version	Major function added/changed	Description	Reference
Version 1.87R	Programmable controller type	For Simple project (without labels), Q02PH, Q06PH, Q12PH, Q12PRH, Q25PH, and Q25PRH are supported.	–
	Intelligent function module	QD73A1 is supported.	(Intelligent)
	Verify	For FXCPU, the following functions are supported. <ul style="list-style-type: none"> <li>The following data can be verified when verifying programmable controller data, projects, or revisions.                             <ul style="list-style-type: none"> <li>Device comment</li> <li>Device memory</li> </ul> </li> </ul>	Section 4.2.7 Section 4.6.5 Section 15.2
	Saving projects in other formats	A project in GX Developer format can be saved along with the connection destination settings.	Section 4.8
	Transfer Setup	For FX3G and FX3GC, a programmable controller CPU can be connected via CC-Link.	Section 14.3
	Write/read IC memory card data	For LCPUC, projects can be saved on/loaded from SD memory card using the batch save/batch load function.	Section 15.11.2
	Print	The print function can be activated from the toolbar or the shortcut menu.	Chapter 11
		The following data can be printed in batch. <ul style="list-style-type: none"> <li>Redundant parameter</li> <li>Program setting</li> <li>User library content list</li> </ul>	
		User libraries can be printed for the following print items. <ul style="list-style-type: none"> <li>ST</li> <li>Structured Ladder/FBD</li> <li>FB/FUN program</li> <li>Label</li> </ul>	
		For MELSAP3 and MELSAP-L, SFC block lists of Structured project can be printed.	
	Parameter	For MELSAP3 and MELSAP-L, SFC program settings can be printed when "Property (SFC Program)" is selected under SFC Diagram Print Item for printing MELSAP3 or MELSAP-L.	Section 11.5.8 Section 11.5.9
		The following functions are added to the I/O assignment setting. <ul style="list-style-type: none"> <li>The I/O assignment setting and the base setting can be set by selecting a programmable controller type, module, and module type.</li> <li>Intelligent function module data on the Navigation window are updated regarding added/deleted/changed modules.</li> </ul>	Section 6.1.1 (Intelligent)
		The editing operations (Undo/Cut/Paste) can be performed on the MELSECNET/CC IE/Ethernet Module Configuration screen.	Section 6.3
		A number of columns to be displayed on the Setting for the <u>CC-Link List</u> screen can be changed to either 4 or 2 columns according to the option setting.	
		A number of rows to be displayed on the <u>CC-Link station information</u> screen can be changed to either 16 or 8 rows according to the option setting.	Section 6.3.1
		A station number can be set for local station in the CC-Link IE setting of a program.	
	The operability of the CC-Link Configuration window is improved.	Section 6.3.3	
	Label	Unused labels can be extracted and batch deleted.	(Simple)
Devices assigned to structure are not cleared even when elements of structure are changed on the <u>Structure Setting</u> screen.		(Simple) (Structured)	
Color and Font	The import and export functions are added.	Section 3.2.7	
Help	FXCPU instruction help is supported by the GX Works2 help function.	Section 3.4.1	

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

Version	Major function added/changed	Description	Reference
Version 1.87R	Intelligent function module tool	Waveform output data can be created for analog module L60DA4.	(Intelligent)
	Structured Ladder/FBD or ST	Step relay devices can be monitored.	(Structured)
	Global label	<ul style="list-style-type: none"> <li>The operability of system label registration/deregistration is improved.</li> <li>For structures registered to data type of system label, elements of structure can be added and comments can be edited.</li> <li>Structure array can be used for system label.</li> </ul>	(Simple) (Structured)
Version 1.91V	Programmable controller type	For Simple project (with labels), Process CPU (Q02PH, Q06PH, Q12PH, Q25PH) and Redundant CPU (Q12PRH, Q25PRH) are supported.	–
	Toolbar	All toolbars can be displayed. The display positions of toolbars can be maintained.	Section 3.2.2
	Transfer Setup	For FX3G, FX3GC, FX3U, and FX3UC, a CPU can be connected via Ethernet adapter.	Section 14.2.2
	Intelligent function module	<ul style="list-style-type: none"> <li>Energy measuring modules (QE81WH, QE81WH4W, QE82LG, QE83WH4W, and QE84WH) are supported.</li> <li>The number of parameter settings for the initial setting of temperature control modules (Q64TCTTN, Q64TCTTBWN, Q64TCRTN, Q64TCRTBWN, L60TCTT4, L60TCTT4BW, L60TCRT4, and L60TCRT4BW) is added by 1.</li> </ul>	(Intelligent)
	Device comment	A target memory to write data to a programmable controller CPU can be specified in advance.	Section 15.1.7
	Instruction	<ul style="list-style-type: none"> <li>For Universal model QCPU and LCPU, the data write/read instruction for devices targeted for auto-refresh is supported.</li> <li>For Universal model QCPU (excluding Q00UJ, Q00U, Q01U, and Q02U), programs with motion dedicated instructions (Command generation axis speed change during positioning or JOG operation, Present value change of stopped command generation axis) can be used.</li> </ul>	–
	Parameter	The Ethernet adapter setting is supported by FX3G, FX3GC, FX3U, and FX3UC.	Section 6.1.1
	Network Parameter	Network configuration of CC-Link IE Field Network can be set graphically on the CC IE Field Configuration window.	Section 6.3.2
		Parameter data set on the CC-Link Configuration window can be copied.	–
	Global label	Duplications of device names assigned to global labels can be checked.	(Simple) (Structured)
		Registered system labels can be deleted.	–
Ladder	<ul style="list-style-type: none"> <li>When "A-PLC Compatibility Setting" on the &lt;&lt;PLC System&gt;&gt; tab of PLC parameter is not selected, entries of special relays/special registers can be checked on the <u>Enter Symbol</u> screen and the <u>Enter List</u> screen.</li> <li>The [Undo] operation can be performed up to 30 times when editing a program on the ladder editor.</li> <li>Device comments can be displayed/hidden using tooltips on the ladder editor.</li> </ul>	(Simple)	
SFC	<ul style="list-style-type: none"> <li>The number of contacts to be displayed on a single rung can be changed on the SFC (Zoom) editor window.</li> <li>The window display operations of the SFC editor window and the Zoom editor window are linked.</li> <li>Device comments can be displayed/hidden using tooltips on the Zoom editor window.</li> </ul>		

Version	Major function added/changed	Description	Reference
Version 1.91V	ST	• VAR_OUTPUT can be used for an argument of function block.	(Simple) (Structured)
		• Device names, monitored values, and device comments can be checked using tooltips on the ST editor.	(Structured)
	Structured Ladder/FBD	Device comments can be checked using tooltips on the Structured Ladder/FBD editor.	
	Compile	The usage of automatically assigned devices is displayed after programs are compiled.	(Simple) (Structured)
	Verify	Among the rows with mismatched devices in program files of project with labels, the cursor skips the rows whose mismatched devices are within the range of devices automatically assigned to labels.	Section 4.2.7 Section 4.6.5
	Cross Reference	Constant (K) and constant (H) can be specified and searched for devices/labels.	-
		• Two or more search locations can be selected. • The search result can be displayed in the order of program setting.	Section 10.1
	Device List	• Items (contacts, coils, etc.) can be displayed/hidden. • Two or more search locations can be selected.	Section 10.2
		The default setting for "Find In" is set as "Current window".	-
	Find/Replace	Devices, such as pointers, which are not related to the search option can be searched disregarding the option setting such as "Digit" and "Multiple word".	Section 10.3.1
		Two or more search locations can be selected.	Section 10.3
	Online Program Change	For Universal model QCPU (excluding Q00UJ/Q00U/Q01UCPU)/LCPU, the changes can be applied to the boot source after performing Online program change.	Section 15.9.1
	Monitor	ON/OFF status of device names of contacts/coils can be displayed with the monitoring function of ladder program.	(Simple)
	Sampling Trace	<ul style="list-style-type: none"> <li>• CSV files can be output in the format which can be used to read data from GX LogViewer.</li> <li>• Changes on global device comments or label comments of global labels/local labels are applied to device comments or label comments on the <u>Sampling Trace</u> screen.</li> <li>• After data under the "Device/Label" column is edited on the <u>Sampling Trace</u> screen, the cursor moves to the next row.</li> <li>• Two or more data can be selected to be copied or to change settings of trend graph registration on the <u>Sampling Trace</u> screen.</li> <li>• When scrolling vertically on the <u>Sampling Trace</u> screen, the vertical axis information line is not scrolled.</li> <li>• The cursor jumps to the specified position by entering a value to the cell of 'currently selected number of data acquisitions'.</li> <li>• The setting to cancel the display of the confirmation message at the sampling trace start is applicable.</li> <li>• The trace result on the <u>Sampling Trace</u> screen can be scrolled using the shortcut keys.</li> </ul>	Section 19.4
	Ethernet Diagnostics	The Ethernet adapter diagnostics is supported by FX3G, FX3GC, FX3U, and FX3UC.	Section 21.7 Section 21.7.2 Section 21.7.3
CC IE Field Diagnostics	<ul style="list-style-type: none"> <li>• Remote device station is supported.</li> <li>• The display of data link unexecuted stations is modified.</li> </ul>	Section 21.4	
CC-Link/ CC-Link/LT Diagnostics	The CC-Link diagnostics is continued on CC-Link modules mounted on the slots following the empty slot on the extension base unit.	Section 21.6	
System monitor	Q24DHCCPU-V can be monitored with QCPU (except for Q00JCPU and Q00UJCPU).	Section 21.9	
Merge Data	Information of "Target Data List" can be displayed on tooltips.	Section 4.3.5	

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

Version	Major function added/changed	Description	Reference
Version 1.98C	Incorporation with PX Developer	For Process CPU (Q02PH, Q06PH, Q12PH, Q25PH) and Redundant CPU (Q12PRH, Q25PRH), the function to incorporate with PX Developer is supported.	Appendix 20
	Programmable controller type	<ul style="list-style-type: none"> <li>High-speed Universal model QCPU (Q03UDV, Q04UDV, Q06UDV, Q13UDV, Q26UDV) is supported.</li> <li>L02S, L06, L26, and LJ72MS15 are supported.</li> <li>For Structured project, Process CPU (Q02PH, Q06PH, Q12PH, Q25PH) and Redundant CPU (Q12PRH, Q25PRH) are supported.</li> </ul>	–
	Transfer Setup	For FXCPU, the GOT (Ethernet) transparent function is supported.	Section 14.9.1
	Intelligent function module	<ul style="list-style-type: none"> <li>L60AD4-2GH, Q64DAH, QD77GF16, QJ51AW12AL, and LJ51AW12AL are supported.</li> <li>The auto refresh item is added for QD77MS2, QD77MS4, and QD77MS16.</li> </ul>	(Intelligent)
	Security	For High-speed Universal model QCPU (Q03UDV, Q04UDV, Q06UDV, Q13UDV, Q26UDV), projects and programmable controller CPUs can be locked/unlocked with security keys.	Section 4.11 Section 16.5
	Menu	Menu names and positions are unified between GX Works2 and iQ Works.	–
	Parameter	For LCPU, the IP packet transfer setting on the <<Built-in Ethernet Port Setting>> tab of PLC Parameter is supported.	Section 6.1.1
		<ul style="list-style-type: none"> <li>For Universal model QCPU, the network operation setting is supported by the CC IE Control network parameter.</li> <li>For LCPU, Ethernet can be set in the network parameter.</li> <li>For LCPU, CC IE Field (Sub-Master Station) is supported by the network parameter.</li> <li>For LCPU, the IP address setting is supported by "Network Operation Settings" of CC-Link IE Field Network parameter (master station, sub-master station).</li> </ul>	Section 6.3.1
		<ul style="list-style-type: none"> <li>Network configuration of AnyWireASLINK can be set graphically on the AnyWireASLINK Configuration window.</li> <li>The configuration of the actual system connected to CC-Link can be applied to the CC-Link Configuration window.</li> </ul>	Section 6.3.3 (iQSS)
		For Universal model QCPU, CC IE Field (motion master station) is supported in the network parameter.	–
	Write to PLC	The set values of XY devices can be written when writing data to a programmable controller CPU on which the simulation function is in operation.	Section 15.1.2
	Block password	For FXCPU, a block password can be set for POU's in batch.	Section 4.12.1
	Ladder	<ul style="list-style-type: none"> <li>For FXCPU, programs in ladder block unit can be displayed/edited in the list format.</li> <li>The different sections of the same program can be monitored simultaneously using the reference window of the ladder editor.</li> <li>The cursor position can be jumped to the position where the next specified device/label is used only with the shortcut key.</li> </ul>	(Simple)
		<ul style="list-style-type: none"> <li>Inline structured text programs can be called from function blocks created in ladder programs.</li> <li>Function blocks created in ST programs can be called from function blocks created in ladder programs.</li> </ul>	–
	SFC	For FXCPU, SFC diagrams can be converted in SFC block unit.	(Simple)
ST	Monitoring conditions can be set.	(Structured)	
Structured Ladder/FBD	<ul style="list-style-type: none"> <li>Temporary arguments can be assigned for the arguments when calling function blocks in Structured project.</li> <li>Monitoring conditions can be set.</li> </ul>		
CC IE Control Diagnostics	The IP communication test is supported.	Section 21.3	



Version	Major function added/changed	Description	Reference
Version 1.98C	CC IE Field Diagnostics	CC-Link IE Field Network CC-Link Bridge module, CC-Link IE Field Network High Speed Counter module, and Simple Motion module are supported.	Section 21.4
	Ethernet Diagnostics	L series Ethernet module is supported.	Section 21.7.1
	Sensor/Device Monitor	The function to monitor iQSS-compatible devices which are connected with AnyWireASLINK or CC-Link is supported.	Section 21.8 (iQSS)
	Print	Operation outputs and transition conditions can be appended on the print of SFC diagram.	Section 11.5.8
	Intelligent function module tool	Waveform output data of QCPU (Q mode) can be created for analog module Q64DAH.	(Intelligent)
	FB library	For QCPU (Q mode)/LCPUCPU Simple project (with labels), FBs created in another project can be added to the project being edited on the <u>Install</u> screen.	(FB)
	Unused label list	For Structured project, extracted unused labels can be deleted in batch.	(Structured)
	Cross reference	When the Auto-tracking mode is selected, cross reference information can be updated only when the cursor is moved by clicking the mouse or pressing the key.	Section 10.1.2
	Watch	The display format (number display (1/0)/ON/OFF display/symbol display (●/○)) of the current value of bit device can be changed.	Section 17.6.4
	Monitor	The program can be verified with the program on the programmable controller CPU before starting the monitoring of the Structured Ladder/FBD editor or the ST editor.	(Structured)
	Intelligent function module monitor	For QD73A1, the required items for the accumulated pulse error detection function can be monitored.	-
	Shortcut key customize	The template on which the MEDOC format shortcut keys can be set is added.	Section 3.2.8
	Options	For QCPU (Q mode)/LCPUCPU, by setting the reference/reflection targets of device comments for 'PLC parameter setting', device comments can be referred/reflected according to the range of local devices specified on the <<Device>> tab of PLC parameter.	Section 12.2
Version 1.492N	Operating environment	Windows® 8 is supported.	-
	Incorporation with PX Developer	For Universal model process CPU (Q04UDPV, Q06UDPV, Q13UDPV, Q26UDPV), the function to incorporate with PX Developer is supported.	-
	Programmable controller type	Q04UDPV, Q06UDPV, Q13UDPV, Q26UDPV, L02S-P, L06-P, L26-P, and FX3s are supported.	-
	Parameter	<ul style="list-style-type: none"> <li>The function to verify the actual system configuration connected to AnyWireASLINK and the configuration being displayed on the AnyWireASLINK Configuration window is supported.</li> <li>Assignment information of refresh devices of AnyWireASLINK can be checked easily in the Device Reference window.</li> </ul>	(Intelligent) (iQSS)
		<ul style="list-style-type: none"> <li>The function to verify the actual system configuration connected to CC-Link and the configuration being displayed on the CC-Link Configuration window is supported.</li> <li>The parameter settings for the equipment connected to the communication module.</li> </ul>	Section 6.3.3 (iQSS)
		For LCPUCPU, the open setting of the built-in Ethernet port setting can be set graphically on the Ethernet Configuration window.	Section 6.1.3 (iQSS)
	Intelligent function module	L60AD2DA2, LD77MS2, LD77MS4, and LD77MS16 are supported.	(Intelligent)
Device comment	The line wrapping of the device comment for display can be displayed on the device comment editor.	Section 9.2.1	

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

Version	Major function added/changed	Description	Reference
Version 1.492N	ST	<ul style="list-style-type: none"> <li>When entering an instruction of ST program, the instructions which can be entered are displayed.</li> <li>For Universal model QCPU/LCPU, in case 32-bit index setting is enabled, over 65,536 array elements with structure array can be accessed.</li> </ul>	–
	Structured Ladder/FBD	When the Auto connect function is enabled, the selected element can be moved/copied without lines connected.	(Structured)
		<ul style="list-style-type: none"> <li>The elements can be copied between projects.</li> <li>When editing a variable or an instance name, the labels which can be entered are displayed.</li> <li>For Universal model QCPU/LCPU, in case 32-bit index setting is enabled, over 65,536 array elements with structure array can be accessed.</li> </ul>	–
	Simulation function	For Universal model process CPU, the simulation function is supported.	Chapter 18
	Sensor/Device Monitor	The function to monitor iQSS-compatible devices which are connected to Ethernet is supported.	Section 21.8 (iQSS)
	Intelligent function module	Waveform output data of L60AD2DA2 can be created.	(Intelligent)
	Predefined protocol support function	The predefined protocol support function for Ethernet modules is supported.	(Intelligent)
Version 1.499V	Parameter	The Change Module function is supported on the Ethernet Configuration window.	Section 6.1.3
	Structured Ladder/FBD	Devices, addresses, and/or label comments can be displayed with label. Also, addresses and/or device comments can be displayed with devices on the Structured Ladder/FBD editor.	(Structured)
	FB library	For QCPU (Q mode)/LCPU Simple project (with labels), the function to add the FB created with the project being edited to other projects is supported on the Export FB to Library (Project) screen.	(FB)
	Cross Reference	The cross reference function can be performed when a ladder editor being edited (in uncompiled state) exists.	Section 10.1
		The setting to search the constant (K and H) is added for search condition on the <<Condition Setting>> tab.	Section 10.1.2
	Write to PLC	Write to PLC can be performed when a ladder editor being edited (in uncompiled state) exists.	Section 15.1
	Read from PLC	When reading intelligent function module parameters, the recommended module models of the specific modules can be displayed.	Section 15.1.4
	Monitor	For MELSAP-L (Instruction Format), bit devices can be monitored on the SFC diagram editor.	(Simple)
Language selection	The data created with Chinese (traditional characters) can be displayed without character corruption by selecting the project language.	Section 3.3 Appendix 18	

Version	Major function added/changed	Description	Reference
Version 1.501X	Navigation window	For FXCPU, Special Module (Intelligent Function Module) is supported.	Section 4.1.3
	Intelligent function module	<ul style="list-style-type: none"> <li>One initial setting of the temperature control modules (Q64TCTTN, Q64TCRTN, Q64TCTTBWN, Q64TCRTBWN, L60TCTT4, L60TCTT4BW, L60TCRT4, and L60TCRT4BW) is added.</li> <li>FX3U-128ASL-M is supported.</li> </ul>	(Intelligent)
	SFC	For LCPU (except for L02S/L02S-P and L02/L02-P), the settings of operation mode for "Act at Block Multi-Activated" can be changed.	(Simple)
	Structured Ladder/FBD	Ladder block comments can be displayed on the ladder block list.	(Structured)
	Parameter	For LCPU, the extended setting of step relay (S device) is supported.	-
		When "CC IE Field (Motion Master Station)" is set to network type, setting the network configuration using CC IE Field configuration window is supported.	Section 6.3.2
		For CC IE Field head module, setting the network configuration using CC-Link configuration window or AnyWireASLINK configuration window is supported.	Section 6.3.3 (Intelligent)
	Device Memory	After performing "Read from PLC" or opening other format project, a number of columns of editor can be set when opening the device memory editor at the first time.	Section 4.7.1 Section 15.1.8
	Project	The operability or screen layout of the project operation (New, Open, Close, Save, Save As, Delete) are standardized among MELSOFT products.	Section 4.2.1 Section 4.2.2 Section 4.2.3 Section 4.2.5
	Colors and fonts	The font size can be changed on the font setting of Structured ladder/FBD editor and ST editor.	Section 3.2.7
	Online Program Change	For LCPU (except for L02S/L02S-P and L02/L02-P), online change of SFC block is supported.	Section 15.9.1
Monitor	When opening other program editors during monitoring, monitor can be started automatically.	Section 17.2	
Simulation function	For LCPU, the settings for branch modules are supported.	Appendix 2	
Predefined protocol support function	Predefined protocol support function for built-in/adaptor serial and built-in Ethernet is supported.	(Intelligent)	
Version 1.507D	Operating environment	Windows® 8.1 is supported.	-
	Intelligent function module	FX3U-20SSC-H and FX-ENET series are supported.	(Intelligent)
	Ladder	<ul style="list-style-type: none"> <li>Statement/note type can be changed for all programs in the project by clicking the [Change All] button on the Switch Statement/Note Type screen.</li> <li>When "Use the Switching Ladder Edit Mode (Read, Write, Monitor, Monitor (Write))" is selected, stopped monitors can be restarted by pressing shortcut keys.</li> </ul>	(Simple)
		Watch	The columns to display the registration status of forced I/O and current values in binary, octal, decimal, hexadecimal, real, character string, and time are added.
	Registration of the next device/label of the registered device/label using shortcut keys is supported.		Section 17.6.2
	When bit devices or bit type labels are ON during monitoring, the background color of the row is changed to the color set to "Color and fonts".		-

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

Version	Major function added/changed	Description	Reference
Version 1.513K	Intelligent function module	L60MD4-G, L60ADVL8, and L60ADIL8 are supported.	(Intelligent)
	Instruction	<ul style="list-style-type: none"> <li>For High-speed Universal model QCPU and Universal model process CPU with a serial number whose first five digits are '16043' or higher and LCPU with a serial number whose first five digits are '16042', SMOV(P), CMP(P), DCMP(P), ZCP(P), and DZCP(P) are supported.</li> <li>For High-speed Universal model QCPU and Universal model process CPU with a serial number whose first five digits are '16043' or higher, SP.READ and SP.WRITE are supported.</li> </ul>	–
	FB library	For FXCPU Simple project (with labels), FBs created in another project can be added to the project being edited on the <u>Install</u> screen.	(FB)
	Print	For FXCPU Simple project, program settings can be printed in batch.	Section 11.5.6
	View	The display positions of dockable windows can be returned to their default.	Section 3.2.4
	CC IE Field Diagnostics	For the master/local station, occurrence of received frame error can be displayed.	Section 21.4
	Device/label automatic-assign setting	For L06, L06-P, L26, L26-P, L26-BT, and L26-PBT, pointer assignment range can be extended in "Pointer Extended Setting for Automatic-Assign Device" of PLC parameter.	Section 6.1.1
	Confirm Memory Size	The memory size of local devices and sampling trace can be displayed.	Section 15.10.3
	Options	The option to set the communication route to programmable controller direct connection setting when creating a new project is added.	Section 12.2
The option that do not check duplicated coils for SET instructions at program check or compiling all programs is added.		(Simple) (Structured)	
Version 1.521T	Transfer Setup	The connection route via RCPUCPU is supported.	–
	Tool bar	The selection status of the tool bar that indicates the display status of docking window/project data can be saved in the project.	Section 3.2.2
	Intelligent function module data	When reading GX Configurator-QP data, the I/O address set to GX Configurator-QP is reflected to the start X/Y address and mounted slot number on the <u>New Module</u> screen.	(Intelligent)
	Device comment	Device comments which are not used in the project can be deleted in batch.	Section 9.3.3
		Extended devices (U\G, BL\S, BL\TR, J\X, J\Y, J\B, J\W, J\SB, J\SW) are distinguished with the point of the extension part and regarded as different devices even if they are the same device type. Therefore, the device comments of each extended device are treated as a different device comments of devices in the CPU module.	–
	Ladder	The mode of the program which contains unconverted ladder blocks can be switched between Write mode and Monitor (write mode).	(Simple)
	Open other project	When reading a GX Developer format project, whether to enable the option to call a function block can be selected.	–
	Save project in GX Developer format	The project which contains unconverted programs or function blocks can be saved.	Appendix 4.17
	Device List	Device comments which are not used in the project can be deleted in device units.	Section 10.2
	Read from PLC	Device comments in the project can be replaced with the device comments read from the programmable controller CPU.	Section 12.2
Monitor	In MELSAP-L (instruction format) or MELSAP-L (start conditions format), word devices and labels can be monitored.	(Simple)	
	For LCPUCPU, the Realtime Monitor function of GX LogViewer can be started up.	Section 17.9	

Version	Major function added/changed	Description	Reference
Version 1.521T	CC IE Field Diagnostics	<ul style="list-style-type: none"> <li>The occurrence of received frame error in the device station can be displayed.</li> <li>Display of device station can be switched between station type and device name.</li> </ul>	Section 21.4
	Options	<ul style="list-style-type: none"> <li>Whether to always write the source information at Online program change or not can be selected.</li> <li>Whether to display the completion message or not at closing the progress dialog of Read from PLC/Write to PLC can be selected.</li> </ul>	Section 12.2
		When "When writing to PLC after a Rebuild All operation, clear the device ranges set in the Device/Label Auto-Assign setting to 0." is selected, the message that indicates clearing device values to '0' when data is written to the programmable controller CPU is displayed on the Write to PLC screen or option screen displayed after compiling all programs.	-
Version 1.525X	Parameter	For LCPUs (except for L02S/L02S-P), file transfer function (FTP client) and e-mail function are supported.	Section 6.1.1
		For LCPUs, LA1S extension base unit is supported.	-
	Instruction	<ul style="list-style-type: none"> <li>For High-speed Universal model QCPU, Universal model process CPU, and LCPUs with a serial number whose first five digits are '16112' or higher, ECMP(P), EDCMP(P), EZCP(P), EDZCP(P), SFTR(P), SFTL(P), WSFR(P), WSFL(P), CCD(P), CRC(P), TCMP(P), TZCP(P), HOURM, DHOURLM, and PID are supported.</li> <li>For LCPUs with a serial number whose first five digits are '16112' or higher, SP.FTPPUT, SP.FTPGET, SP.MLSEND, SP.MLRECV, SP.MLOPEADR, and SP.MLGETADR are supported.</li> </ul>	-
		Transfer Setup	For Redundant CPU, Ethernet connection between GOT and programmable controller CPU is supported.
	The GOT (CC-Link IE Control) transparent function is supported.		Section 14.9.3
	Replace	Devices which are specified with multiple points can be replaced in SFC block information.	-
	Compile	After a compilation, projects can be saved automatically.	(Simple) (Structured)
	Write to PLC	For FXCPU, the number of device comments and maximum number of comments to be written can be displayed.	Section 15.1.3
	Debug	The result after switching ON/OFF status of bit devices by pressing the <b>[Shift]</b> key + <b>[Enter]</b> key after selecting a bit device or double-clicking a bit device while pressing the <b>[Shift]</b> key on the ladder editor, ST editor, and Structured Ladder/FBD editor can be checked on the <u>Modify Value</u> screen.	Section 19.1.1
	System monitor	For LCPUs, the configuration on which LA1S extension base unit is used can be displayed.	Section 21.9
	Confirm Memory Size	For FXCPU, the number of device comments and maximum number of comments to be written can be displayed.	Section 15.10.4
Predefined protocol support function	A protocol setting file of other format can be opened.	(Intelligent)	

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

Version	Major function added/changed	Description	Reference
Version 1.530C	Parameter	The function to apply the actual system configuration connected to the CC-Link IE Field Network to the CC IE Field Configuration window is supported.	Section 6.3.2 (iQSS)
	Ladder/SFC/ST/Structured Ladder/FBD	When entering an instruction/label in the project with labels, press the <b>[Enter]</b> key or <b>[Tab]</b> key while the instruction/label option is displayed, the instruction/label displayed on the top is inserted automatically.	–
	Ladder	When changing an FB instance name on the ladder editor, whether to change all the instance names with the same name or change only the selected FB instance can be selected.	(FB)
	SFC	When changing a step number on the Enter SFC Symbol screen/Enter SFC Symbol/Enter Program screen, whether to overwrite the comment which has been set to the step number before the change to the comment of the step number after the change can be selected.	–
		Step number can be sorted for all blocks. Additionally, the step number in an inactive block can be sorted.	(Simple)
	Library	When the data name of the global label is duplicated between the library file to be installed and project, the data name can be changed at installation of user library.	(Structured)
	Device List	The search location where the search is completed normally is retained while the project is open on the Device List screen.	–
	Compile	Programs other than compilation target, functions, function blocks, and structures are displayed in blue at compilation.	(Simple) (Structured)
Read from PLC/Write to PLC/Verify/Delete	For Structured project, the read from PLC/write to PLC/verify/delete function can be performed without checking the password.	Section 12.2	
Sensor/Device Monitor	The function to monitor iQSS-compatible devices which are connected to CC-Link IE Field Network is supported.	(iQSS)	
Version 1.535H	Parameter	MELSOFT Connection Extended function is supported.	Section 6.1.1
	Intelligent function module	L60RD8 is supported.	(Intelligent)
	Monitor	"Word Multi-point" display format can be switched with a button on the <u>Device/Buffer Memory Batch Monitor</u> screen.	Section 17.3
	CC IE Field Diagnostics	For the station status, "Error station (Illegal ring connection detected)" and "Error station (Minor/Moderate/Major)" can be displayed simultaneously.	–
	Intelligent function module tool	<ul style="list-style-type: none"> <li>Free Conversion Characteristics Function and Free Operation Function added in L60AD2DA2 are supported.</li> <li>2-point Sensor Compensation Value Registration Function is supported.</li> </ul>	(Intelligent)
Version 1.540N	Intelligent function module	QD77GF4 and QD77GF8 are supported.	(Intelligent)
	Parameter	The parameter processing of device stations can be performed while the programmable controller CPU set as a connection target is in RUN status.	Section 6.3.2 Section 6.3.3
	SFC	The display position of the SFC diagram editor window and the Zoom editor window can be returned to the initial status.	Section 1.3.3 (Simple)
		For simple project, the block with the same name can be overwritten and pasted over on the SFC block list.	(Simple)
	Device comment	All the local device comments can be written/read in a batch.	Section 9.6
	Profile Management	The registered profile can be deleted.	Section 4.13.2
	Options	The option to copy device comment including the hidden bit specification information is added.	Section 12.2
When <u>Input Device Comment</u> screen is displayed on the ladder editor and the Zoom editor window, whether to display the Device/Label Comment field in editing status or not can be selected.		Section 12.2	
Version 1.542Q	Options	Whether to always write the symbolic information on the Write to PLC window can be selected.	Section 12.2

Version	Major function added/changed	Description	Reference
Version 1.545T	Operating environment	Windows® 10 is supported.	-
	Intelligent function module	<ul style="list-style-type: none"> <li>L60DAVL8 and L60DAIL8 are supported.</li> <li>The number of the initial setting for Q64ADH is added by 1.</li> </ul>	(Intelligent)
	Change PLC Type	In <<Multiple CPU Setting>> of the PLC parameter, <<Communication Area Setting (Refresh Setting)>> for High Performance model QCPU or Process CPU can be converted to <<Multiple CPU High Speed Transmission Area Setting>> for Universal model QCPU (except for Q00UJ, Q00U, Q01U, and Q02U).	-
		When changing from Basic model QCPU, High Performance model QCPU, and Process CPU to Universal model QCPU, the number of points of B and W can be changed in "Refresh Parameters" of MELSECNET/H under "Network Parameter" according to <<Device>> in PLC parameter.	-
	Transfer Setup	The GOT (CC-Link IE Field) transparent mode is supported.	Section 14.9.4
	Print	The number of header/footer rows that can be entered is changed from 3 to 7.	Section 11.4
Version 1.550Y	Verify	For program files of a project with labels, the rows with mismatches within the range of device/label automatic-assign setting can be displayed in a different background color.	Section 4.2.7
	Parameter	For High-speed Universal model QCPU and Universal model process CPU, the open setting of the built-in Ethernet port setting can be set graphically on the Ethernet Configuration window.	Section 6.1.3 (iQSS)
	Incorporation with iQ AppPortal	iQ AppPortal information files can be output when saving projects.	Section 4.3.6
Version 1.555D	Open Other Project	A block number for an SFC block assigned in a GX Developer format project is retained.	Section 4.7.1
	Parameter	The CC-Link IEF Basic setting can be set on the <<Built-in Ethernet Port Setting>> tab of PLC parameter.	Section 6.1.4
	Instruction	The SP.SLMPSND instruction is supported by High-speed Universal model QCPU, Universal model process CPU, and LCPU whose first five digits of a serial number are '18112' or higher.	-
	Monitor	For High-speed Universal model QCPU and Universal model process CPU, a program can be started and stopped by using the program list monitor function.	Section 17.4
	CC-Link IEF Basic Diagnostics	CC-Link IE Field Network Basic can be diagnosed.	Section 21.5
	Block Passwords	Execution programs can be protected on LCPU.	Section 4.12.2
Version 1.560J	Intelligent function module	LD40PD01 is supported.	(Intelligent)
	Block Passwords	Execution programs can be protected on High-speed Universal model QCPU and Universal model process CPU.	Section 4.12.2

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

Version	Major function added/ changed	Description	Reference
Version 1.566Q	Parameter	The number of remote stations that can be set in 'CC-Link IEF Basic Setting' on the <<Built-in Ethernet Port Setting>> tab of "PLC Parameter" is increased as follows: <ul style="list-style-type: none"> <li>• 64 stations for High-speed Universal model QCPUs and Universal model process CPUs</li> <li>• 16 stations for Ethernet built-in LCPUs</li> </ul>	Section 6.1.4
		<ul style="list-style-type: none"> <li>• A function to apply the actual system configuration connected in CC-Link IE Field Network Basic to the CC-Link IEF Basic Configuration window is supported.</li> <li>• A function to apply the communication setting set in the CC-Link IEF Basic Configuration window to remote stations is supported.</li> </ul>	Section 6.1.4
		<ul style="list-style-type: none"> <li>• For High-speed Universal model QCPUs and Universal model process CPUs, the operation history of a CPU module can be saved by setting the item on the &lt;&lt;PLC RAS&gt;&gt; tab of "PLC Parameter".</li> <li>• For High-speed Universal model QCPUs and Universal model process CPUs, a device range to prohibit device writing from an external device can be set on the &lt;&lt;Device Setting&gt;&gt; tab of "PLC Parameter".</li> </ul>	Section 6.1.1
	Instruction	The DATE2SEC(P) instruction and the SEC2DATE(P) instruction are supported by High-speed Universal model QCPU and Universal model process CPU whose first five digits of a serial number are '19042' or higher.	–
	Connection destination setting	The GOT (Ethernet) transparent function can be performed when a personal computer and a GOT are connected by Ethernet.	Section 14.9.1
	Cross Reference	The value set for "Start Device to Store Predefined Protocol Operation Status" in "Open Setting", "Built-in Serial Setting", and "Adapter Serial Setting" on the <<Built-in Ethernet Port Setting>> tab of "PLC Parameter" can be searched.	Section 10.1
	Device List	The value set for "Start Device to Store Predefined Protocol Operation Status" in "Open Setting", "Built-in Serial Setting", and "Adapter Serial Setting" on the <<Built-in Ethernet Port Setting>> tab of "PLC Parameter" can be searched.	Section 10.2
	Colors and fonts	<ul style="list-style-type: none"> <li>• Colors of texts, backgrounds, grids, and devices in an SFC block list can be changed in "Color Setting" on the SFC editor.</li> <li>• Colors of device names and label names while monitoring an inline ST are changed by following the setting for "Normal Text and Symbol" in "Color Setting" of the ladder editor.</li> </ul>	Section 3.2.7
	Structured Ladder	On the Structured Ladder/FBD editor, the display item in functions/function blocks can be switched between input/output labels or comments.	(Structured)
PLC diagnostics	For High-speed Universal model QCPUs and Universal model process CPUs, the operation history of a CPU module can be displayed.	Section 21.1.1	
Version 1.570U	Product Makeup	Data is supplied with three DVDs.	GX Works2 Installation Instructions
	SFC	In an SFC block list, a block number can be searched.	(Simple)



Version	Major function added/changed	Description	Reference
Version 1.576A	Save project in GX Developer format	The value of the secured steps for Online program change can be saved.	Section 4.8
	Parameter	For High-speed Universal model QCPUs and Universal model process CPUs, the simple PLC communication setting is supported.	Section 6.1.1
		In the simple PLC communication setting for LCPUs, "MELSEC-iQ-R (Built-in Ethernet Function)" or "SLMP-Compatible Device (QnA Compatible 3E Frame)" can be selected.	
		For High-speed Universal model QCPUs and Universal model process CPUs, a function to apply an actual system configuration on the CC-Link IE Field Network to the CC IE Field Configuration window is supported.	Section 6.3.2 (iQSS)
		For High-speed Universal model QCPUs and Universal model process CPUs, a function to verify an actual system configuration on the CC-Link IE Field Network with the CC IE Field Configuration window is supported.	
		For High-speed Universal model QCPUs and Universal model process CPUs, the parameters of the device stations selected in the CC IE Field Configuration window can be backed up to a memory card.	
		For High-speed Universal model QCPUs and Universal model process CPUs, the parameters of device stations that were backed up with the CC IE Field Configuration window can be restored.	
	Ladder	In the continuous paste function, cut or copied ladder blocks are pasted as follows. <ul style="list-style-type: none"> <li>• If a bit-specified word device number becomes greater than 'F' then it is incremented and carried up.</li> <li>• For an indexed device, the index number is not incremented, but the device number is.</li> </ul>	(Simple)
		Text color (color/monochrome) in inline structured text boxes can be switched in [View] ⇒ [ST Monochrome Display].	
	ST	Text color (color/monochrome) on an ST editor can be switched in [View] ⇒ [ST Monochrome Display].	(Structured)
FB library	For a Simple project (with labels), an FB for which a block password has been set can be added to the project being edited.	(FB)	
Sensor/Device Monitor	For High-speed Universal model QCPUs and Universal model process CPUs, a function to monitor devices supporting iQSS on CC-Link IE Field Network is supported.	Section 21.8 (iQSS)	

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

Version	Major function added/ changed	Description	Reference
Version 1.580E	Parameter	"MELSEC iQ-F (Built-in Ethernet Function)" can be selected as the communication destination in the simple PLC communication setting in a High-speed Universal model QCPU project, a Universal model process CPU project, and an LCPU project.	Section 6.1.1
		For MELSOFT Navigator, the subnet mask pattern and the default router IP address can be applied to the Built-in Ethernet Port Setting of PLC parameter even if the parameters are applied without connecting to the CC-Link IEF Basic Configuration.	–
		A link device can be reassigned in the CC IE Field Configuration window.	Section 6.3.2
	Instruction	The SP.LOGNAMER instruction and SP.LOGFILES instruction are supported by High-speed Universal model QCPU and Universal model process CPU whose first five digits of a serial number are '20073' or higher.	–
	Property	The program title of the program setting and the POU can be linked.	Section 4.3.6
	Device comment	Text size on the device comment editor can be changed.	Section 9.1.3
	Ladder	The mode of all open windows can be switched between "Read Mode" and "Write Mode".	(Simple)
	SFC	The mode of all open windows can be switched between "Read Mode" and "Write Mode".	(Simple)
	Read from PLC	The remaining steps for Online program change can be read in a Simple project (with labels) and a Structured project.	Section 15.1.6
	Verify	For Q series and L series, projects between different programmable controller types can be verified.	Section 4.2.7
Copy and paste	For Q series and L series, project data between different programmable controller types can be copied and pasted.	Section 4.3.2	
Version 1.585K	Parameter	An object name can be displayed or hidden from the list of devices on CC IE Field Configuration window.	Section 6.3.2
	Connection destination setting	An Ethernet adapter to communicate with a CPU module can be selected.	Section 14.2.2 Section 14.6
	Sensor/Device Monitor	The following functions are supported by AnyWireASLINK. <ul style="list-style-type: none"> <li>The display format of monitoring value in "Monitoring Information" can be selected from "Bit", "Word Decimal Number Signed", "Word Decimal Number Unsigned" or "Word Hexadecimal Number".</li> <li>Character strings set in a profile can be displayed in the status of "Monitoring Information".</li> </ul>	(iQSS)
	Print	A device list can be printed including used devices filtered with AND or OR condition.	Section 11.5.18
Version 1.595V	Operating environment	Windows XP and Windows Vista are no longer supported.	–
Version 1.610L	Operating environment	Required HDD free space for the installation is changed to 3GB or more.	GX Works2 Installation Instructions
	Options	<ul style="list-style-type: none"> <li>The setting to display the data to be written at the time of PLC write is added.</li> <li>The setting to enable the security check for a project is added.</li> </ul>	Section 12.2
Version 1.615R	Operating environment	Windows® 11 is supported.	–
	Parameter	For High-speed Universal model QCPU and Universal model process CPU, "Disable Using Port Setting" is supported.	Section 6.1.1
Version 1.620W	Operating environment	Windows 8.1, Windows 8, and Windows 7 are no longer supported.	–
		Windows 10 IoT Enterprise 2019 LTSC is supported.	GX Works2 Installation Instructions
	Parameter	Assignment information of refresh devices of CC-Link IE Field Network can be checked easily in the Device Reference window.	Section 6.3.4

## Appendix 13 Supported Versions of Modules

Q CPU L CPU Remote Head FX

The following table shows the modules which are supported according to the upgrades. Modules can be used in the corresponding and later versions of GX Works2.

Supported version	Supported module	
	CPU module/Remote I/O module/ Communication head module	Intelligent function module
Version 1.05F	Q02(H), Q02U, Q03UD, Q03UDE, Q04UDH, Q04UDEH, Q06H, Q06UDH, Q06UDEH, Q12H, Q13UDH, Q13UDEH, Q25H, Q26UDH, Q26UDEH	<ul style="list-style-type: none"> <li>Analog Q64AD, Q68ADV, Q68ADI, Q64AD-GH, Q62AD-DGH, Q68AD-G, Q66AD-DG, Q62DAN, Q64DAN, Q68DAVN, Q68DAIN, Q62DA, Q64DA, Q68DAV, Q68DAI, Q62DA-FG, Q66DA-G</li> <li>Temperature input Q64RD, Q64RD-G, Q64TD, Q64TDV-GH, Q68TD-G-H01, Q68RD3-G</li> <li>Temperature control Q64TCTT, Q64TCTTBW, Q64TCRT, Q64TCRTBW, Q62HLC</li> <li>Counter QD62, QD62E, QD62D, QD63P6, QD64D2, QD60P8-G</li> <li>QD75 type positioning QD75P1, QD75P2, QD75P4, QD75D1, QD75D2, QD75D4, QD75M1, QD75M2, QD75M4, QD75MH1, QD75MH2, QD75MH4</li> <li>QD70 type positioning QD70P4, QD70P8, QD70D4, QD70D8, QD72P3C3</li> <li>Serial communication/modem interface QJ71C24N, QJ71C24N-R2, QJ71C24N-R4, QJ71C24, QJ71C24-R2</li> <li>AS-i master QJ71AS92</li> <li>FL-net (OPCN-2) interface QJ71FL71-F01, QJ71FL71-T-F01, QJ71FL71-B2-F01, QJ71FL71-B5-F01, QJ71FL71, QJ71FL71-T, QJ71FL71-B2, QJ71FL71-B5</li> </ul>
Version 1.08J	Q00UJ, Q00U, Q01U, Q10UDH, Q10UDEH, Q20UDH, Q20UDEH	<ul style="list-style-type: none"> <li>Temperature input Q68TD-G-H02</li> </ul>
	FX0, FX0s, FX0N, FX1, FXU, FX2c, FX1s, FX1N, FX1NC, FX2N, FX2NC, FX3G, FX3U, FX3UC	–
Version 1.12N	Q00J, Q00, Q01	<ul style="list-style-type: none"> <li>Analog Q64AD2DA, Q61LD</li> </ul>
Version 1.15R	–	–
Version 1.24A	L02, L26-BT	<ul style="list-style-type: none"> <li>Analog L64AD4, L60DA4</li> <li>Serial communication LJ71C24, LJ71C24-R2</li> </ul>
Version 131H	Q50UDEH, Q100UDEH	–
	LJ72GF15-T2	<ul style="list-style-type: none"> <li>Counter LD62, LD62D</li> <li>LD75 type positioning LD75P4, LD75D4</li> <li>Simple motion LD77MH4</li> </ul>
Version 1.40S	QJ72LP25, QJ72BR15	–

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

Supported version	Supported module	
	CPU module/Remote I/O module/ Communication head module	Intelligent function module
Version 1.48A	–	<ul style="list-style-type: none"> <li>Counter QD65PD2</li> <li>Simple motion LD77MH16</li> </ul>
Version 1.53F	–	<ul style="list-style-type: none"> <li>MODBUS interface QJ71MT91, QJ71MB91</li> </ul>
Version 1.62Q	–	<ul style="list-style-type: none"> <li>Temperature control Q64TCTTN, Q64TCRTN, Q64TCTTBWN, Q64TCRTBWN,</li> </ul>
	L02-P, L26-PBT	<ul style="list-style-type: none"> <li>Temperature control L60TCTT4, L60TCTT4BW, L60TCRT4, L60TCRT4BW</li> </ul>
Version 1.64S	–	<ul style="list-style-type: none"> <li>QD75 type positioning QD75P1N, QD75P2N, QD75P4N, QD75D1N, QD75D2N, QD75D4N</li> </ul>
Version 1.73B	–	<ul style="list-style-type: none"> <li>Analog Q64ADH</li> </ul>
Version 1.77F	–	<ul style="list-style-type: none"> <li>Analog Q68CT</li> <li>Simple motion QD77MS2, QD77MS4, QD77MS16</li> </ul>
	–	<ul style="list-style-type: none"> <li>LD75 type positioning LD75P1, LD75P2, LD75D1, LD75D2</li> </ul>
	FX3GC	–
Version 1.87R	Q02PH*1, Q06PH*1, Q12PH *1, Q25PH*1, Q12PRH*1, Q25PRH*1	<ul style="list-style-type: none"> <li>QD70 type positioning QD73A1</li> </ul>
Version 1.91V	Q02PH*2, Q06PH*2, Q12PH*2, Q25PH*2, Q12PRH*2, Q25PRH*2	<ul style="list-style-type: none"> <li>Energy measuring QE81WH, QE81WH4W, QE84WH, QE83WH4W, QE82LG</li> </ul>
Version 1.98C	Q02PH*3, Q06PH*3, Q12PH*3, Q25PH*3, Q12PRH*3, Q25PRH*3, Q03UDV, Q04UDV, Q06UDV, Q13UDV, Q26UDV	<ul style="list-style-type: none"> <li>Analog Q64DAH</li> <li>Simple motion QD77GF16</li> <li>AnyWireASLINK interface QJ51AW12AL</li> </ul>
	L02S, L06, L26, LJ72MS15	<ul style="list-style-type: none"> <li>Analog L60AD4-2GH</li> <li>AnyWireASLINK interface LJ51AW12AL</li> </ul>
Version 1.492N	Q04UDPV, Q06UDPV, Q13UDPV, Q26UDPV	–
	L02S-P, L06-P, L26-P	<ul style="list-style-type: none"> <li>Analog L60AD2DA2</li> <li>Simple motion LD77MS2, LD77MS4, LD77MS16</li> </ul>
	FX3S	–
Version 1.501X	–	<ul style="list-style-type: none"> <li>AnyWireASLINK interface FX3U-128ASL-M</li> </ul>
Version 1.507D	–	<ul style="list-style-type: none"> <li>Positioning FX3U-20SSC-H</li> <li>Ethernet FX-ENET series</li> </ul>
Version 1.513K	–	<ul style="list-style-type: none"> <li>Multiple input L60MD4-G</li> <li>Analog L60ADVL8, L60ADIL8</li> </ul>

Supported version	Supported module	
	CPU module/Remote I/O module/ Communication head module	Intelligent function module
Version 1.535H	–	• Temperature input L60RD8
Version 1.540N	–	• Simple motion QD77GF4, QD77GF8
Version 1.545T	–	• Analog L60DAVL8,L60DAIL8
Version 1.560J	–	• Counter LD40PD01
Version 1.576A	–	• DeviceNet QJ71DN91

- \*1 : Simple projects (without labels) are supported.
- \*2 : Simple projects are supported.
- \*3 : Simple projects and Structured projects are supported.

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

## Appendix 14 Procedure to Use GX Works2 Unsupported Programmable Controller Type



For programmable controller types which are not supported by GX Works2 (CPUs such as ACPU, QnACPU, and Safety CPU), use GX Developer.

When GX Developer Version 8.95Z or later is installed, and a new project is created in GX Works2 with a selection of an unsupported programmable controller type, GX Developer starts automatically and a new project is created. (☞ Section 4.2.1)

### Appendix 14.1 Installing GX Developer

GX Developer is included on the GX Works2 DVD and CD.

For details on how to install GX Developer, refer to the following manual.

☞ GX Developer Version 8 Operating Manual (Startup)

At installation, use the same product ID as GX Works2.

#### ■ For GX Works2 Version 1.570U or later

The installation file is included in the "Disk2\GXD1" folder on the DVD. The following shows the installation procedure.

#### Operating procedure

- Run "Disk2\GXD1\SETUP.EXE" on the DVD.

The installation of GX Developer starts.

#### Point

##### ● Installing updated version of GX Works2

When installing GX Developer at the same time as the installation of updated version of GX Works2, the product version of GX Developer needs to be installed in advance.

When the product version of GX Developer is not installed, install GX Developer from the product version CD, or install GX Developer included on the GX Works2 DVD before installing the updated version of GX Works2.

■ **For GX Works2 Version 1.521T or later and Version 1.568S or earlier**

The installation file is included in the "GXD1" folder on the CD (Disc 2). The following shows the installation procedure.

**Operating procedure**

- **Run "GXD1\SETUP.EXE" on the CD (Disc 2).**

The installation of GX Developer starts.

*Point*

● **Installing updated version of GX Works2**

When installing GX Developer at the same time as the installation of updated version of GX Works2, the product version of GX Developer needs to be installed in advance.

When the product version of GX Developer is not installed, install GX Developer from the product version CD, or install GX Developer included on the GX Works2 CD (Disc 2) before installing the updated version of GX Works2.

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX


## ■ For GX Works2 Version 1.50C or later, or Version 1.53K or earlier

GX Developer can be installed at installation of GX Works2 by the following procedure.

### Operating procedure

#### 1. Select "Install GX Developer" on the following screen displayed at installation of GX Works2.

Select the items in "Select Component" as necessary.



#### 2. Click the button and proceed the installation.

GX Developer is installed after the completion of GX Works2 installation.

### Point

#### ● When installing GX Developer separately

The installation file is included on the CD (Disc 1) of GX Works2.  
Install GX Developer by running "`\\support\GD1\SETUP.EXE`".



## ■ For GX Works2 Version 1.48A or earlier

The installation file is included in the "Others" folder on the CD. The following is the installation procedure.

### Operating procedure

1. **Copy the GX Developer compressed file on the CD to the HDD on the personal computer.**

The path for the GX Developer compressed file on the CD is "\Others\d8-xxx.dat"\*1.

\*1: "xxx" is an alphanumeric string.

2. **Change the extension of the copied file from "dat" to "exe".**  
The file name is changed from "d8-xxx.dat" to "d8-xxx.exe".
3. **Double-click the "d8-xxx.exe" file and decompress the file to the specified folder.**
4. **Run the decompressed "SETUP.EXE" file.**

The installation of GX Developer starts.

## Appendix 14.2 Utilizing programs of GX Works2 unsupported programmable controller type in GX Works2

Programs of GX Works2 unsupported programmable controller type created with GX Developer can be utilized in GX Works2 by the following procedure.

The following is an example of utilizing an ACPU program created with GX Developer in the QCPU (Q mode) project of GX Works2.

### Operating procedure

1. **Change the programmable controller type of the project from ACPU to QCPU (Q mode) with GX Developer.**

To change the programmable controller type, select [Project] ⇒ [Change PLC type].

2. **Save the project with GX Developer.**

To save the project, select [Project] ⇒ [Save As].

3. **With GX Works2, read the project for QCPU (Q mode) created with GX Developer.**

To read a GX Developer project with GX Works2, select [Project] ⇒ [Open Other Data] ⇒ [Open Other Project]. (☞ Section 4.7.1)

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

## Appendix 15 Considerations of installation and uninstallation

Q CPU L CPU Remote Head FX

### Appendix 15.1 Considerations of installation

---

This following explains the considerations of installation.

#### ■ Installing a MELSOFT product for the first time

---

At the first installation of a MELSOFT product, the following screen may be displayed during installation. To continue the installation, click the  button on the Software Installation screen. (We have checked the operation and assured that the system operates without any problems by performing this procedure.)


The Software Installation screen may be displayed behind another screen. Press the  +  keys to bring it to the front.



## ■ Procedure for continuing installation when it is not completed correctly


When the installation of a MELSOFT product or another software is not completed correctly, the following screen is displayed and the installation cannot continue unless the personal computer is restarted.

In this case, restart the personal computer and start the installation again.



## ■ Considerations after the installation

When the following screen is displayed after the completion of the installation, select "This program installed correctly" and restart the personal computer.



When "Reinstall using recommended settings" is erroneously selected, the Windows XP SP2 compatibility mode is automatically set.

Disable the Windows XP SP2 compatibility mode, and perform the reinstallation. The following shows the example of the procedure.

17  
MONITORING18  
SIMULATING  
PROGRAMS19  
DEBUGGING  
PROGRAMS20  
OPERATING  
PROGRAMMABLE  
CONTROLLER CPU21  
DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS22  
SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICESA  
APPENDIX

INDEX

### Operating procedure



1. Right-click on the `setup.exe` icon of the installation target on Windows® Explorer.

The `setup Properties` screen is displayed.

2. Click the  button on the <<Compatibility>> tab.

3. Clear "Run this program in compatibility mode for:" and click the  button.

4. Click the  button.



## Appendix 15.2 Considerations of uninstallation

The following explains the considerations of uninstallation.

### ■ Uninstalling GX Works2 at the same time as the uninstallation of iQ Works or GX Works3

If the version of GX Works2 is upgraded individually, GX Works2 may not be displayed on the screen for selecting products to be uninstalled when uninstalling iQ Works or GX Works3.

In this case, uninstall GX Works2 from the control panel.

The conditions of version combinations in which the symptom occurs are as follows:

- GX Works2: Version 1.601B or earlier is upgraded to Version 1.605F or later.
- iQ Works: Version 2.74C or earlier is installed.
- GX Works3: Version 1.076E or earlier is installed.

## Appendix 16 USB Driver Installation

In order to communicate with a programmable controller CPU via USB, a USB driver needs to be installed.

The following explains the example of the procedure to install the USB driver.

For the installation procedure of USB driver for FX-USB-AW and FX3U-USB-BD, refer to the following manual.

☞ **FX-USB-AW/FX3U-USB-BD USER'S MANUAL - USB Driver Installation Edition**

### Operating procedure

1. Connect the personal computer and the programmable controller CPU with USB cable, and then turn ON the programmable controller CPU.
2. Right-click "Unknown Device" and click "Update driver" in Windows Device Manager.
3. Select "Browse my computer for drivers" on the **Update Drivers** screen, and specify 'Easysocket\USBDrivers' in the folder where GX Works2 is installed on the next screen.

When an installation folder is not changed at installation, the installation folder is as follows:

- 64-bit version operating system: C:\Program Files (x86)\MELSOFT\Easysocket\USBDrivers
- 32-bit version operating system: C:\Program Files\MELSOFT\Easysocket\USBDrivers

If multiple MELSOFT products are already installed, specify 'Easysocket\USBDrivers' which is in the folder of the first product installed.

If 'Easysocket\USBDrivers' does not exist, search for 'USBDrivers' in the Windows explorer.

17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX

INDEX

## Appendix 17 Considerations When Using English Version of GX Works2

Q CPU L CPU Remote Head FX

This section explains the considerations when using project data, which is created in Japanese version of GX Works2, in English version of GX Works2.

Refer to the considerations described in this section when using Japanese version of GX Works2 Version 1.42U or earlier, or English version of GX Works2 Version 1.44W or earlier.

Note that, however, project data created in Japanese version of GX Works2 Version 1.45X or later which satisfy the following conditions can be used in English version of GX Works2 Version 1.48A or later.

- Data names listed in the section 'Section Appendix 16.1' match with the project language selected for the "Language Selection" function.
- The font of the project language selected for the "Language Selection" function is installed in the operating system.

Use the programmable controller types applicable to English version of GX Works2 when using project data created in Japanese version of GX Works2 in English version of GX Works2.

## Appendix 17.1 Data to which double byte character and half-width Japanese kana character are applicable

The following tables show all data to which double byte characters are applicable. When data described in the following table contains a double byte character, any symptom described in Appendix 17.2 occur.

When using Japanese version of GX Works2 Version 1.42U or earlier, or English version of GX Works2 Version 1.44W or earlier, refer to the considerations in Appendix 17.2.




However, if a project data created in Japanese version of GX Works2 satisfies the following conditions, the project can be used in English version of GX Works2 Version 1.48A or later without any symptom described in Appendix 17.2.

- When the language used for data with ○ indicated in the 'Project language is unchangeable' column of the following table matches with the project language set for "Language Selection".
- When the font of the specified project language is installed to the operating system.

Note that; however, when data other than alphanumeric character is used for the data with ○ indicated in the 'Project language is unchangeable' column of the following table, an error occurs at the change of project language for Japanese version of GX Works2 Version 1.45X or later. Change the project language after correcting the data name to match the changed project language.

### ● Data to which double byte character and half-width Japanese kana character are applicable

○: Unchangeable –: Changeable

Item	Data name	Changeable/ unchangeable project language	
Workspace	Workspace name	–	
Project	GX Works2 project name	–	
	GX Developer project name	–	
	Compressed project name	–	
	Property (Title/Comment)	–	
Project revision	Detailed information (Title/Comment)	–	
Program	Program name	○	
	Ladder, ST, Structured Ladder/FBD, SFC (Zoom)	Statement/Note/Comment/Label name	–
		FB instance name	–
	SFC	SFC block name	○
		SFC step/Transition comment	–
Property (Block information)	–		
Parameter	 ● PLC parameter data	–	
	 ● Network parameter data	–	
	Property (Title/Comment)	–	
Intelligent function module data	 ● Intelligent function module data	–	
Device comment	Local device comment name	–	
	Device comment	–	
Device memory	Device memory name	–	
	Property (Title/Comment)	–	
Device initial value	Device initial value name	–	
	Comment	–	

17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX

INDEX

Item	Data name	Changeable/ unchangeable project language
Global label/Local label/Structure	Global label name/Structure name	○
	Label name	○
	Constant value	–
	Data type	–
	Comment	–
	Remark	–
FB/FUN	Function block name/Function name	○
	Property (Result Type)	–
Program file/Task (Structured project)	Program file name/Task name	○
	Program name	○
	Comment	–
User library (Structured project)	User library name	○
	Library file name (*.SUL)	–
	Property (Help path)	–
Intelligent function module tool	–	–
QD75/LD75 positioning module	Wave trace file name	–
	Location trace file name	–
Serial communication module	Circuit trace data	–
	Protocol setting file name (Predefined protocol support function)	–
	Manufacturer/Model/Protocol name/Package name/ Element name (Predefined protocol support function)	–
User data (Example: *.xls)	File name	–
Backup data for PLC Module Change Setting function	Title	–
Target memory for online operations	Title	–
IC memory card drive for IC memory card operation	Title	–
I/O system setting	I/O system setting file name	–
CSV file that can be created in Diagnostic function	Product information in System monitor	–
	PLC diagnostics	–
	Module error history	–
Shortcut key	Template file name	–



● PLC parameter data

○: Unchangeable --: Changeable

Tab name	Item	Data name	Changeable/ unchangeable project language
PLC Name	-	Label	-
		Comment	-
PLC System	PLC Module Change Setting	Title Setting	-
PLC File	File Register	File Name	-
	Comment File Used in a Command	File Name	-
	Initial Device Value	File Name	-
	File for Local Device	File Name	-
PLC RAS	Error History	File Name	-
Boot File	-	Data Name	-
Program	-	Program Name	-
I/O Assignment	I/O Assignment	Type	-
	Base Setting	Model Name	-
		Power Model Name	-
		Extension Cable	-

● Network parameter data

○: Unchangeable --: Changeable

Type	Item	Data name	Changeable/ unchangeable project language
Ethernet/CC IE/MELSECNET	Network Range Assignment	Parameter Name	-
	Network Configuration Settings	Alias	-
		Comment	-
	Network Operation Settings	Parameter Name	-
	Station Inherent Parameters	Parameter Name	-
	FTP Parameters	Login Name	-
	E-mail Setting	SMTP Server Name	-
POP Server Name		-	
	News Setting	Attached File Name	-
CC-Link	Operation Setting	Parameter Name	-

● Intelligent function module data

○: Unchangeable --: Changeable

Module type	Item	Data name	Changeable/ unchangeable project language
Positioning module	Positioning Data	Positioning Comment	-
Serial communication module/Modem interface module	Modem Function	Initialization command	-
		Telephone number	-
		Message	-
		Comment	-
	User Register Frame Content	User registration frame	-
FL-net (OPCN-2) interface module	Parameter	Node name (Equipment name)	-

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

## Appendix 17.2 Considerations

---

The English version of GX Works2 (SW1DND-GXW2-E and SW1DNC-GXW2-E) does not support double byte character and half-width Japanese kana character. Therefore, when using the project data, which has been created in the Japanese version of GX Works2 (SW1DND-GXW2-J and SW1DNC-GXW2-J) using double byte character or half-width Japanese kana character, in the English version of GX Works2, change all the double byte character and half-width Japanese kana character to single byte alphanumeric character in the Japanese version of GX Works2. After characters are changed, execute [Compile] ⇒ [Rebuild All] or [Build] in the Japanese version of GX Works2 and save the project in a condition without any errors.

The following are the considerations when reading project data, in which double byte character or half-width Japanese kana character is used, from the programmable controller CPU.

- The symbolic information created in the Japanese version of GX Works2 and written to the programmable controller CPU, cannot be read to the English version of GX Works2. In this case, save the project created in the Japanese version of GX Works2 using the English version of GX Works2, then write the symbolic information to the programmable controller CPU.


### ■ Symptom example

---

The following are examples when using the project data, which is created using double byte character or half-width Japanese kana character, in the English version of GX Works2.


● **Displayed as garbled characters**

When double byte character or half-width Japanese kana character is set in the statement or label, they are displayed as garbled characters.




● **Data name is not displayed**

When double byte character or half-width Japanese kana character is used in data names of user library files, data names cannot be displayed and user library cannot be operated.



● **Data cannot be opened**

When opening saved project data in which double byte character or half-width Japanese kana character is used in workspace names, project names, or file names, the message shown below may be displayed and the project cannot be opened.



● **Compilation error**

When compiling the project data in which double byte character or half-width Japanese kana character is used in label names, compilation error occurs and compilation cannot be completed normally.

<English version of GX Works2>

Output					
Rebuild All					
No.	Result	Data Name	Class	Content	Error Code
1	Error	Global1	Global label check	Invalid data name/label name '?????????????1'	C5043
2	Error	Global1	Global label check	Invalid data name/label name '?????????????2'	C5043
3	Error	Global1	Global label check	Invalid data name/label name '?????????????3'	C5043
Error: 3, Warning: 0, CheckWarning: 0					

17 MONITORING  
18 SIMULATING PROGRAMS  
19 DEBUGGING PROGRAMS  
20 OPERATING PROGRAMMABLE CONTROLLER CPU  
21 DIAGNOSING PROGRAMMABLE CONTROLLER STATUS  
22 SIMULATING OPERATIONS OF EXTERNAL DEVICES  
APPENDIX  
INDEX

## Appendix 18 Considerations for Selecting Project Language

Q CPU L CPU Remote Head FX

This section explains the considerations for selecting a project language. 'language of GX Works2' in the table indicates the language of installed GX Works2.

Category	Item	Considerations
OS	The language pack is not installed.	All characters of the selected language are corrupted.
Programmable controller CPU	File name	When a file with a name using other than Japanese characters or one-byte alphanumeric characters is written to a programmable controller CPU, the file cannot be read from the programmable controller CPU, and the performance of the online function may not be normal.
Operation after installation	Language of Windows® operating system and 'language of GX Works2' are different.	When using GX Works2 in Japanese language, check the following settings. <ul style="list-style-type: none"> <li>• "Language for non-Unicode programs"*1 of Windows® operating system is set to Japanese.</li> <li>• The project language is set to Japanese under [Tool] ⇒ [Language Selection] in GX Works2.</li> </ul>
		When using the following functions, use alphanumeric characters or Japanese characters for folder names and file names. <ul style="list-style-type: none"> <li>• Open data in other format</li> <li>• Save project in GX Developer format</li> <li>• Read/write IC memory card</li> <li>• Local device batch read + save CSV</li> </ul>
		For "Language for non-Unicode programs"*1 setting, set the same language as the one set for the 'language of GX Works2' in advance. By this setting, error messages can be displayed in the 'language of GX Works2'.
Entered language	Mixing different languages	Only one language with double-byte characters can be used in a project. Japanese, Chinese (simplified characters), Chinese (traditional characters), and Korean cannot be mixed. A language with one-byte characters and a language with double byte characters can be mixed. For example, English (one-byte alphanumeric characters) and Japanese.
	When entering data in a language other than the one set for the project language.	The operation is ensured only when the project language which is set for the language selection is used. Do not use characters of the language other than the one set for the project language. Note that alphanumeric characters and one-byte symbols can be used in all languages.

Category	Item	Considerations
Font	Korean is selected for project language. (Regarding the font 'BatangChe' which is set automatically.)	Including fixed characters such as menus, some of the characters of Japanese and Chinese (simplified characters) are displayed in smaller size.
	Displayed characters are different depending on the font even when they are the same character.	Displayed characters may be different between the ones on the screen in which font can be changed and the ones on the screen in which font cannot be changed. Change the font on the <u>Color and Font</u> screen. Example) With Korean is selected as the project language, when "精" is entered in the label editor and a compilation error is performed, "精" is displayed on the Output window.
	The font size of some characters is different in Windows® 10 or later.	The entered text may be truncated on the screen on which fonts cannot be specified. When the font size of some characters is different in Windows® 10 or later, install Supplemental Fonts that is supported by 'language of GX Works2' from Windows® Settings. Example) [Apps] ⇒ [Apps & features] ⇒ [Optional features] ⇒ [Add a feature] in Windows® Settings
Function	[Verify] Projects whose project languages are different are verified.	When the same character strings with double-byte character are verified, the result will be a match, however, the character strings may not be displayed normally. Select the same language for projects to be verified.
	[Install] User library which contains characters of different language is imported to project.	The operation of user library import is ensured when the project language set for the language selection is used for user library file names and data in the user library. User library which contains file names and data with alphanumeric characters and one-byte symbol can be used in a project in any language.
	[Read from PLC], [Read IC Memory Card] Data contains characters in different language is imported, and the Read from PLC or Read IC Memory Card is executed.	The operation of Read from PLC or Read IC Memory Card function is ensured when the project language set for the language selection is used for characters in a target data. Set the same language as the one used in a target data to be read. Target data of the data read function which contains alphanumeric characters and one-byte symbol can be used in a project in any language.
	[Open Other Project] The project language selected for "Language Selection" and the operating system language are different.	Other format projects which can be opened in GX Works2: projects whose data name and label name are written in alphanumeric code.
	[Read from CSV File] (When reading a program which is written in list format.)	The operation is ensured only when the project languages for the Write to CSV File function and Read from CSV File function are the same.
Project language selection	A language is selected while the project is being displayed.	Screens which are opened from the Project view and the User Library view are closed automatically when a language is selected. Close all other open screens. The selected language is applied by reopening the screens.
	Data names, label names	When characters other than alphanumeric characters are used for data names and label names in a project before selecting a project language, the operation is not ensured after the language is selected.
	Simulation function	Project language setting is invalidated.
	Interaction with CPU Module Logging Configuration Tool	
	Interaction with Ethernet adapter module configuration tool	
	Predefined protocol support function	
Interaction with iQ Works		

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
I	INDEX

- \*1 : Set "Language for non-Unicode programs" on Windows Control Panel.  
Example) From Windows® Control Panel, select [Clock, Language, and Region] ⇒ [Region and Language] ⇒ <<Administrative>> ⇒ "Language for non-Unicode programs".

## Appendix 19 Modifying Instructions of Projects in Other Formats



This section explains instructions which require modification and how to modify them when using projects in other formats in GX Works2.

An X mark may appear on a POU or an error may occur at a compilation when a project which contains ST programs or Structured Ladder/FBD programs created in GX Developer or GX IEC Developer is opened in GX Works2. In this case, instructions or arguments need to be modified. The following table shows the modification methods and reference sections. For instructions which require modification, read the corresponding reference.

Modification method	Reference
Replacing instruction names	Appendix 19.1
Adding devices/labels	Appendix 19.2
Changing positions of devices/labels	Appendix 19.3
Changing arguments to constants	Appendix 19.4
Changing label data types to double-precision real number	Appendix 19.5
Changing label data types	Appendix 19.6
Changing number of array elements of array data type labels	Appendix 19.7
Changing label data type to array data type	Appendix 19.8

### ● Compiling programs with instructions which do not require modification

For the instructions which do not require modification, perform the following operation to compile programs without correcting the programs.

Select "Use Dedicated Instruction for GX Developer, GX IEC Developer" under [Tool] ⇒ [Options] ⇒ "Project" ⇒ "Common Setting", and restart GX Works2.

17  
MONITORING18  
SIMULATING  
PROGRAMS19  
DEBUGGING  
PROGRAMS20  
OPERATING  
PROGRAMMABLE  
CONTROLLER CPU21  
DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS22  
SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICESA  
APPENDIX

INDEX

## Appendix 19.1 Replacing instruction names


When using any of the following GX Developer or GX IEC Developer instruction, replace the instruction with the GX Works2 instruction.

Instruction to be replaced GX Developer instruction/GX IEC Developer instruction	GX Works2 instruction
LIMIT	LIMITATION
MAX	MAXIMUM
MIN	MINIMUM

### ● Replacing an instruction in Structured Ladder/FBD program


#### Operation

1. Select an instruction to be modified.



2. Select [Edit] ⇒ [Input Instruction].

The Input Instruction [Replace] screen is displayed.




3. Enter a GX Works2 instruction name.



4. Click the **OK** button.

The instruction is replaced with the GX Works2 instruction.



### ● Replacing an instruction in ST program

#### Operation

- Replace the instruction with the GX Works2 instruction.

`Real4:=LIMIT(Real1, Real2, Real3);`     $\Rightarrow$     `Real4:=LIMITATION(Real1, Real2, Real3);`

#### Point

#### ● Considerations when replacing instructions in Structured Ladder/FBD programs

The size of function/function block may be changed. Adjust the position of function/function block if a function/function block with a replaced instruction overlaps with the connected function/function block.

#### ● Replacing instructions in Structured Ladder/FBD programs

The Input Instruction [Replace] screen can also be displayed by selecting an instruction and entering an instruction name from the keyboard.

#### ● Replacing instructions using the Replace Instruction function

Instructions can also be replaced using the Replace Instruction function. (  Section 10.3.2)



## Appendix 19.2 Adding devices/labels

When using any of the following GX Developer or GX IEC Developer instruction, add or change device/label according to the argument of the GX Works2 instruction.


For Structured Ladder/FBD programs, instructions also need to be changed.

Instruction to be modified	GX Works2 instruction
GX Developer instruction/GX IEC Developer instruction	
COS	COS
LEFT	LEFT
LEN	LEN
RIGHT	RIGHT
ROL	ROL_E
ROR	ROR_E
SIN	SIN
TAN	TAN
ACOS	ACOS
ASIN	ASIN
ATAN	ATAN
EXP	EXP


### ● Modifying an instruction in Structured Ladder/FBD program

#### Operation


1. Replace the instruction with the GX Works2 instruction. (☞ Appendix 19.1)



2. Connect the device/label set to EN to the argument  $\textcircled{s}$ .
3. Connect the device/label set to ENO to the argument  $\textcircled{d}$ .



4. Select [Edit] ⇒ [ladder Symbol] ⇒ [Input Label] ( $\textcircled{UARR=s}$ ), and add an input label to EN.
5. Set TRUE to EN.



17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

**● Modifying an instruction in ST program****Operation**

- **Adjust the position of the argument, and add TRUE to EN.**

`w_Real1:=COS(w_Real2);`  $\Rightarrow$  `COS(TRUE,w_Real2,w_Real1);`

In GX Works2, a return value of an instruction is ENO, not an operation result.  
Programs in which instructions are nested should be rewritten as shown below.

<ST before modification>

```
Var_Real := COS(Var_s_Real) + 1.23;
```

<ST after modification>

```
COS(TRUE, Var_s_Real, Var_cos_Real);Var_Real := Var_cos_Real + 1.23;
```

## Appendix 19.3 Changing positions of devices/labels

When using any of the following GX IEC Developer instruction, replace the instruction with the GX Works2 instruction, and change the position of device/label according to the corresponding argument.

Instruction to be modified GX IEC Developer instruction	GX Works2 instruction	Argument with different position	New position for argument
GETE_M	G_GETE	s2	Change the position of the device/label from the right side to the left side of the POU according to the position of the argument.
GETEP_M	GP_GETE	s2	
BUFRCV_M	ZP_BUFRCV	s2	
BUFSND_M	ZP_BUFSND	s3	
CLOSE_M	ZP_CLOSE	s2	Change the position of the device/label from the left side to the right side of the POU according to the position of the argument.
RISEND_MD	G_RISEND	d1	
RISEND_P_MD	GP_RISEND	d1	
RITO_MD	G_RITO	d	
RITO_P_MD	GP_RITO	d	


### ● Modifying an instruction in Structured Ladder/FBD program

#### Operation

1. Replace the instruction with the GX Works2 instruction. (☞ Appendix 19.1)



2. Change the position of the device/label according to the argument of the instruction. If an input label or output label does not exist at the position of argument, add it by selecting [Edit] ⇒ [Ladder Symbol] ⇒ [Input Label] (☞) / [Output Label] (☞). For G\_GETE in the following example, move "D12" of the argument (d) to (s2), and move "M12" which is not connected to the argument (d).



### ● Modifying an instruction in ST program

#### Operation

- Replace the instruction with the GX Works2 instruction.

GETE\_M(M1, H08, Label3, D12, M2); → G\_GETE(M1, H08, Label3, D12, M2);

Only for RISEND(\_P)\_MD, switch the positions of 4th argument and 5th argument.

## Appendix 19.4 Changing arguments to constants


When using any of the following GX IEC Developer instruction, replace the instruction with the GX Works2 instruction, and change the data type of argument to constant.

Instruction to be modified GX IEC Developer instruction	GX Works2 instruction	Argument to which constant is to be set
MEAN_M	MEAN	n
MEANP_M	MEANP	n
BMOV_E	BMOV_E	n

### ● Modifying an instruction in Structured Ladder/FBD program

#### Operation

1. Replace the instruction with the GX Works2 instruction. (☞ Appendix 19.1)



2. Change the argument n to constant. When a label is set to the argument n, change the class of the label to "VAR\_CONSTANT" or "VAR\_GLOBAL\_CONSTANT" on the label setting editor.

	Class	Label Name	Data Type	Constant
1	VAR	s_Word1	Word(Signed)	...
2	VAR_CONSTANT	n_Word2	Word(Signed)	0
3	VAR	d_Word1	Word(Signed)	...

### ● Modifying an instruction in ST program

#### Operation

1. Replace the instruction with the GX Works2 instruction.

MEAN\_M(TRUE, s\_Word1, n\_Word2, d\_Word1); → MEAN(TRUE, s\_Word1, n\_Word2, d\_Word1);

2. Change the argument n to constant. When a label is set to the argument n, change the class of the label to "VAR\_CONSTANT" or "VAR\_GLOBAL\_CONSTANT" on the label setting editor.

## Appendix 19.5 Changing label data types to double-precision real number

When using any of the following GX IEC Developer instruction, replace the instruction with the GX Works2 instruction, and change the data type of argument to double-precision real number.

Instruction to be modified GX IEC Developer instruction	GX Works2 instruction	Argument to which double-precision real number is to be set
LD_EDEQ_M	LDED=*1	s1, s2
LD_EDGE_M	LDED>=*1	
LD_EDGT_M	LDED>*1	
LD_EDLE_M	LDED<=*1	
LD_EDLT_M	LDED<*1	
LD_EDNE_M	LDED<>*1	
AND_EDEQ_M	ANDED=*1	
AND_EDGE_M	ANDED>=*1	
AND_EDGT_M	ANDED>*1	
AND_EDLE_M	ANDED<=*1	
AND_EDLT_M	ANDED<*1	
AND_EDNE_M	ANDED<>*1	
OR_EDEQ_M	ORED=*1	
OR_EDGE_M	ORED>=*1	
OR_EDGT_M	ORED>*1	
OR_EDLE_M	ORED<=*1	
OR_EDLT_M	ORED<*1	
OR_EDNE_M	ORED<>*1	
EDPLUS_M	_*2	s1, s2
EDPLUSP_M	_*2	s1, s2, d
EDPLUS_3_M	ED+*1	
EDPLUSP_3_M	ED+P*1	
EDMINUS_M	_*2	s, d
EDMINUSP_M	_*2	s1, s2, d
EDMINUS_3_M	ED-*1	
EDMINUSP_3_M	ED-P*1	
EDDIV_M	ED/^1	s1, s2, d
EDDIVP_M	ED/P*1	
EDMUL_M	ED*1	
EDMULP_M	ED*P*1	d
FLTD_M	FLTD	
FLTDP_M	FLTDP	
DFLTD_M	DFLTD	
DFLTDP_M	DFLTDP	
EDNEG_M	EDNEG	
EDNEGP_M	EDNEGP	
EDMOV_M	EDMOV	
EDMOVP_M	EDMOVP	

\*1 : For ST program, the instruction does not need to be changed to a GX Works2 instruction.

\*2 : The instruction does not need to be changed to a GX Works2 instruction.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A


APPENDIX

INDEX

● Modifying an instruction in Structured Ladder/FBD program

**Operation**

1. Replace the instruction with the GX Works2 instruction. (☞ Appendix 19.1)



2. Change the class of the label to "FLOAT (Double Precision)" on the label setting editor.

	Class	Label Name	Data Type
1	VAR	label4	FLOAT (Double Precision)
2	VAR	label12	FLOAT (Double Precision)

● Modifying an instruction in ST program

**Operation**

1. Replace the instruction with the GX Works2 instruction.



2. Change the class of the label to "FLOAT (Double Precision)" on the label setting editor.

## Appendix 19.6 Changing label data types


When using any of the following GX IEC Developer instruction, replace the instruction with the GX Works2 instruction, and change the data type according to the data type of the argument.

Instruction to be modified GX IEC Developer instruction	GX Works2 instruction	Argument whose data type is to be changed	Argument data type	
			Before change	After change
FLTD_M	FLTD	s	ANY16	Word [signed]
FLTDP_M	FLTDP	s	ANY16	Word [signed]
DFLTD_M	DFLTD	s	ANY32	Double word [signed]
DFLTDP_M	DFLTDP	s	ANY32	Double word [signed]
OUT_M	OUT	d	ANY_SIMPLE	Bit

### ● Modifying an instruction in Structured Ladder/FBD program

#### Operation

1. Replace the instruction with the GX Works2 instruction. (☞ Appendix 19.1)



2. Change the data type of the label to the corresponding data type on the label setting editor.

	Class	Label Name	Data Type
1	VAR	label7	Word[Signed]
2	VAR	label12	FLOAT (Double Precision)

### ● Modifying an instruction in ST program

#### Operation

1. Replace the instruction with the GX Works2 instruction.

FLTD\_M(M5, label7, label12);    ⇨    FLTD(M5, label7, label12);

2. Change the data type of the label to the corresponding data type on the label setting editor.

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

## Appendix 19.7 Changing number of array elements of array data type labels

When using any of the following GX IEC Developer instruction, replace the instruction with the GX Works2 instruction, and change the number of array elements according to the data type of the argument.


Instruction to be modified GX IEC Developer instruction	GX Works2 instruction	Argument whose number of array elements is to be changed	Argument data type	
			Before change	After change
REQ_JP_M	JP_REQ	s2	ARRAY[1..7] OF ANY16	ANY16(0..5)*1
	JP_REQ	d1	ARRAY[1..4] OF ANY16	
REQ_UP_M	GP_REQ	s2	ARRAY[1..7] OF ANY16	
	GP_REQ	d1	ARRAY[1..4] OF ANY16	

\*1 : The index of the array does not need to be started from 0 if the number of array elements matches. A change of the program is not necessary when the index of the array is set to 1 to match with the previous index.

### ● Modifying an instruction in Structured Ladder/FBD program

#### Operation

1. Replace the instruction with the GX Works2 instruction. (☞ Appendix 19.1)



2. Change the number of array element of the array data type label on the label setting editor.

	Class	Label Name	Data Type
1	VAR	label10	Word(Signed)[1..18]
2	VAR	label11	Word(Unsigned)/Bit String[16-bit][1..6]
3	VAR	label12	Word(Unsigned)/Bit String[16-bit][1..6]

### ● Modifying an instruction in ST program

#### Operation

1. Replace the instruction with the GX Works2 instruction.

REQ\_JP\_M(M6,H00,label10,label11,label12,M2); → JP\_REQ(M6,H00,label10,label11,label12,M2);

2. Change the number of array element of the array data type label on the label setting editor.

#### Point

### ● Considerations when changing the number of array elements

When the number of array elements is reduced by the modification, the program needs to be modified according to the change.

Example: For the argument ④ of REQ\_JP\_M, the program which accesses the 7th array element needs to be modified.



## Appendix 19.8 Changing label data type to array data type

When using any of the following GX IEC Developer instruction, replace the instruction with the GX Works2 instruction, and change the data type of the argument to the array data type.

Instruction to be modified GX IEC Developer instruction	GX Works2 instruction	Argument whose data type is to be changed to array data type	Argument data type	
			Before change	After change
TEACH1_P_M	ZP_TEACH1	s	ANY16	ANY16(0..3)
TEACH2_P_M	ZP_TEACH2	s		
TEACH3_P_M	ZP_TEACH3	s		
TEACH4_P_M	ZP_TEACH4	s		
PSTR1_P_M	ZP_PSTR1	s	ANY16	ARRAY[0..2] OF ANY16
PSTR2_P_M	ZP_PSTR2	s		
PSTR3_P_M	ZP_PSTR3	s		
PSTR4_P_M	ZP_PSTR4	s		
BIDIN_M	G_BIDIN	d2	BOOL	ARRAY[0..1] OF BOOL
BIDINP_M	GP_BIDIN	d2		
BIDOUT_M	G_BIDOUT	d		
BIDOUTP_M	GP_BIDOUT	d		
INPUT_M	G_INPUT	d2		
ONDEMAND_M	G_ONDEMAND	d		
ONDEMANDP_M	GP_ONDEMAND	d		
OUTPUT_M	G_OUTPUT	d		
OUTPUTP_M	GP_OUTPUT	d		
PRR_M	G_PRR	d		
PRRP_M	GP_PRR	d		
PUTE_M	G_PUTE	d		
PUTEP_M	GP_PUTE	d		
READ_JP_M	JP_READ	d2		
READ_UP_M	GP_READ	d2		
RECV_JP_M	JP_RECV	d2		
RECV_UP_M	GP_RECV	d2		
REMFR_MD	Z_REMFR	d2		
REMFR_P_MD	ZP_REMFR	d2		
REMTO_MD	Z_REMTO	d2		
REMTO_P_MD	ZP_REMTO	d2		
REQ_JP_M	JP_REQ	d2		
REQ_UP_M	GP_REQ	d2		
SEND_JP_M	JP_SEND	d		
SEND_UP_M	GP_SEND	d		
SREAD_JP_M	JP_SREAD	d2		
SREAD_UP_M	GP_SREAD	d2		
SWRITE_JP_M	JP_SWRITE	d2		
SWRITE_UP_M	GP_SWRITE	d2		
WRITE_JP_M	JP_WRITE	d2		
WRITE_UP_M	GP_WRITE	d2		
ZNRD_J_M	J_ZNRD	d2		
ZNRD_JP_M	JP_ZNRD	d2		
ZNWR_J_M	J_ZNWR	d2		
ZNWR_JP_M	JP_ZNWR	d2		

17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX


I

INDEX

## ● Modifying an instruction in Structured Ladder/FBD program

### Operation

1. Replace the instruction with the GX Works2 instruction. (☞ Appendix 19.1)



2. Change the label data type to array data type on the label setting editor.

	Class	Label Name	Data Type
1	VAR	label5	[WordSigned][0..3]
2	VAR	label6	Bit[0..1]

## ● Modifying an instruction in ST program

### Operation

1. Replace the instruction with the GX Works2 instruction.

TEACH1\_P\_M(M7,"0",label5,label6);    ➡    ZP\_TEACH1(M7,"0",label5,label6);

2. Change the label data type to array data type on the label setting editor.

### Point

#### ● Considerations when changing data type

Since the label data type is changed to array data type, labels used in the program needs to be modified according to the array data type.

## Appendix 20 Considerations When Using Projects Created in PX Developer



\*1 : Process CPU, Redundant CPU, and Universal model process CPU only

This section explains the considerations when using projects created in PX Developer in GX Works2.

### ■ When starting GX Works2 from PX Developer

#### 1) The following menus cannot be selected.

- [Project] ⇒ [New]
- [Project] ⇒ [Open]
- [Project] ⇒ [Close]
- [Project] ⇒ [Save As]
- [Project] ⇒ [Change PLC Type]
- [Project] ⇒ [Open Other Data] ⇒ [Open Other Project]
- [Project] ⇒ [(Recently used files 1 to 4)]

#### 2) Global labels and programs whose name starts with '#FBDQ' cannot be edited.

### ■ When starting GX Works2 independently

#### 1) For PX Developer incorporated projects, the following menu cannot be selected.

- [Project] ⇒ [Change PLC Type]

#### 2) Global labels and programs whose name starts with '#FBDQ' cannot be edited.

### ■ Project files incorporated with PX Developer

#### 1) For PX Developer incorporated projects, the projects are always in the single file format.

### ■ Automatically assigned devices

#### 1) For PX Developer incorporated projects, do not specify the device range used as the system resource of PX Developer as the device range for devices automatically assigned to labels of GX Works2.

### ■ Redundant parameters

#### 1) For PX Developer incorporated projects, consider the following restrictions.

- Register the user devices which require the tracking to the tracking blocks No. 1 to 32.
- The tracking device setting is fixed to "Device Detail Setting".
  - The tracking block No. 33 to 64 cannot be changed.

17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX

INDEX

## ■ Security

---

- 1) **When setting security to the GX Works2 project, register the user name and the password same as the security level name and the password set in PX Developer.**  
The security level name of PX Developer can be copied on the [Set Login Password](#) screen of PX Developer.  
When the security level name and the password of PX Developer is not registered as the same security level in the security setting of GX Works2, the compilation and the online operation cannot be performed.
- 2) **Do not register block passwords for programs whose name starts with '#FBDQ'.**

## ■ Simulation function

---

- 1) **For PX Developer incorporated projects, file registers are written to the simulator by the PLC Write function when the simulation is started.**
- 2) **When executing the step execution of the simulation, execute the simulation from GX Works2.**

# Appendix 21 Troubleshooting

Q CPU L CPU Remote Head FX

This section shows the errors which may occur when using GX Works2 and their corrective actions.

Symptom	Check point	Corrective action
Contents in the screen may not be displayed properly. (For example, overlapping of icons, text overflowing from the frame of a button, etc.)	Is the size of the text and other items in the screen set to a value other than 100% (96 DPI, 9 pt etc.) in Windows settings?	<ul style="list-style-type: none"> <li>Set the value to 100% (96 DPI, 9 pt etc.).</li> <li>For Windows 10 (version 1703 or later)*1 or later, the display of GX Works2 can be displayed with high DPI scaling by using a function of the operating system.*2</li> </ul> (Example) ① Select and right-click 'GD2.exe'*3, and select [Properties] from the shortcut menu. ② Click <input type="button" value="Change high DPI settings"/> in the <<Compatibility>> tab. ③ Select the checkbox of "Override high DPI scaling behavior. Scaling performed by:", then select "System" from the pull-down list. ④ Click the <input type="button" value="OK"/> button.

\*1: The Windows version can be checked by the following procedure.  
(Example)

- ① Enter "winver" in the search box of Windows, and select it from the menu.
- ② Check the version in the displayed screen.

\*2: The display of GX Works2 will be blurred by enlarging.

Additionally, when a window size such as a docked window size is changed, a part of the display may be distorted. The following lists the setting values for "Change the size of text, apps, and other items" and the recommended display resolution for each setting value in Windows 10 or later.

- Setting value: 100%, display resolution: 1024 × 768 dots or more
- Setting value: 125%, display resolution: 1900 × 1200 dots or more
- Setting value: 150%, display resolution: 1900 × 1200 dots or more
- Setting value: 175%, display resolution: 2880 × 1620 dots or more
- Setting value: 200%, display resolution: 2880 × 1620 dots or more
- Setting value: 225%, display resolution: 3840 × 2160 dots or more
- Setting value: 250%, display resolution: 3840 × 2160 dots or more

\*3: 'GD2.exe' is stored in the folder where GX Works2 has been installed.

The following is an example of a storage location.

- 64-bit version operating system: C:\Program Files (x86)\MELSOFT\GPPW2\GD2.exe
- 32-bit version operating system: C:\Program Files\MELSOFT\GPPW2\GD2.exe

17  
MONITORING

18  
SIMULATING PROGRAMS

19  
DEBUGGING PROGRAMS

20  
OPERATING PROGRAMMABLE CONTROLLER CPU

21  
DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22  
SIMULATING OPERATIONS OF EXTERNAL DEVICES

A  
APPENDIX

INDEX



---

# INDEX

17	MONITORING
18	SIMULATING PROGRAMS
19	DEBUGGING PROGRAMS
20	OPERATING PROGRAMMABLE CONTROLLER CPU
21	DIAGNOSING PROGRAMMABLE CONTROLLER STATUS
22	SIMULATING OPERATIONS OF EXTERNAL DEVICES
A	APPENDIX
INDEX	

**[A]**

access authority ..... 4-70  
 Access levels ..... 4-62  
 accessing a programmable controller CPU ..... 14-2  
 accessing a programmable controller CPU via GOT ... 14-40  
   FXCPU ..... 14-42  
   QCPU (Q mode)/LCPU ..... 14-43, 14-45  
 Accessing Programmable Controller CPU via Phone  
 Line ..... 14-50  
 accessing the programmable controller CPU on the host  
 station ..... 14-8  
   FXCPU ..... 14-10  
   QCPU (Q mode)/LCPU ..... 14-9  
 Acknowledge XY Assignment ..... 6-3, 6-18, 6-37, 6-39  
 Administrators ..... 4-62  
 All Find ..... 10-17  
 All Replace ..... 10-17  
 Allocating memory for Online program change ..... 15-7  
 Always ON ..... 22-30  
 ASCII Code ..... App-61  
 ATA card ..... 15-36, 15-74

**[B]**

backup ..... 4-47  
 backup device memory ..... 18-6  
 block password ..... 4-81, 4-82  
 buffer memory ..... 12-13, 17-8  
 Build ..... 5-9

**[C]**

Cable test ..... 21-45  
 Canceling keyword ..... 16-16  
 canceling password ..... 16-6, 16-11  
 CC IE Field Configuration window ..... 6-46  
 CC-Link Configuration window ..... 6-60  
 CC-Link IE ..... A-36, 6-37  
 CC-Link IEF Basic Diagnostics ..... 21-51  
 change ..... 22-21  
 Change Project Type ..... 4-46  
 Change to General CC-Link Module ..... 6-64  
 Changing colors ..... 3-24  
 Changing fonts ..... 3-24  
 Changing Modules Online ..... 21-104  
 Changing project data names ..... 4-38  
 Characters for password ..... 6-75  
 Check Parameter ..... 6-76  
 Clear All Parameters ..... 6-79  
 Clear All (All Devices) ..... 9-15  
 Closing projects ..... 4-20  
 Command Execution of Device Station ..... 6-57, 6-67  
 Comment verify type ..... 15-33  
 comments by program ..... 9-4  
 common comments ..... 9-4

communication head module ..... A-36, 6-12  
 Communication test ..... 21-22, 21-32, 21-43  
 compare source ..... 22-11  
 Compatibility ..... App-78, App-81  
 Compile ..... 5-9, 12-16  
 Compile Condition ..... 12-17  
 compression ..... 4-16  
 condition ..... 22-4  
 Configurations for USB connection ..... 2-4  
 connecting station information ..... 21-52, 21-54  
 Connection Channel List ..... 14-4  
 Connection Destination view ..... 3-20  
 Connection from an I/F Boards ..... 2-14  
 Connection test ..... 14-5  
 conventional debugging ..... 22-2  
 Copy ..... 4-36, 4-37  
 COS curve ..... 22-21  
 Creating check sheets ..... 21-63  
 Creating projects ..... 4-9  
 Cross Reference ..... 10-2  
 cycle scan ..... 22-21

**[D]**

data entry method for direct data entry ..... 22-14  
 Data Names ..... App-110  
 Data Paste ..... 4-36  
 Data Security Setting ..... 4-70  
 debugging ..... 18-2  
 debugging with I/O system setting function ..... 22-2  
 decompressing ..... 4-16, 4-17  
 decompressing divided compressed files ..... 4-18  
 Delete ..... 4-38  
 Delete PLC Data ..... 15-34  
 Delete PLC User Data ..... 15-36  
 Deleting Device Comments ..... 9-15  
 Deleting projects ..... 4-19  
 Deleting revision information ..... 4-51  
 Developers (Level 1) ..... 4-62  
 Developers (Level 2) ..... 4-62  
 Developers (Level 3) ..... 4-62  
 device batch replace ..... 10-29  
 Device Comment ..... 9-2, 12-8  
 Device Comment Display Format ..... 12-9  
 device comment editing mode ..... 9-13  
 device comment to be referenced ..... 9-6  
 Device Initial Values ..... 8-2  
 device list ..... 10-13  
 device memory ..... 7-2, 8-4, 8-5  
 device memory editor ..... 7-14  
 device of which a value is to be changed ..... 22-14  
 Device Specification screen ..... 22-11  
 device test with execution condition ..... 19-10  
 device value input ..... 22-8  
 devices that can be replaced or batch replaced ..... 10-21



diagnosing bridge modules .....	21-56
Diagnosing CC-Link and CC-Link/LT .....	21-53
Diagnosing CC-Link IE Controller Network .....	21-28
Diagnosing CC-Link IE Field Network .....	21-38, 21-51
Diagnosing Ethernet .....	21-66
Diagnosing Programmable Controller CPU .....	21-2
Digit .....	10-18
direct data entry .....	22-11
disabled scans .....	22-22
Display Format .....	12-13
Display Lines of Monitored Current Value .....	12-13
display size .....	7-10, 7-13
Displaying editing screens with the toolbar .....	3-10
dockable windows .....	3-17
duplicated coil .....	12-8

## [E]

edit timing chart format .....	22-15, 22-17
enabling high-speed monitoring from another station .....	20-9
enabling Online program change of multiple blocks .....	20-9
English Version of GX Works2 .....	App-204
Enter Device screen .....	22-17
Error History .....	21-68
error history monitoring .....	21-24
Error icons .....	21-10, 21-98
Error Information .....	21-4
Ethernet adapter .....	A-36
Ethernet adapter module .....	A-36
Ethernet Adapter Module Configuration Tool .....	20-18
examples of device search .....	10-20
examples of instruction search .....	10-24
execution type .....	4-5, 4-8
Export CSV Data .....	19-26
Export to GX Developer Format File .....	4-60
Export to ROM Format .....	15-35
Extending Number of Points of Device Comment .....	9-16

## [F]

FB libraries .....	13-3
File Password 32 .....	16-8
file under editing .....	22-8
file under execution .....	22-8
Filtering condition .....	10-12
Filtering display .....	10-11
Format types .....	20-9
Formatting a memory card .....	20-9
Functions to Protect Data .....	16-2
FX manuals .....	3-32
FX series .....	A-35

## [G]

global device comment .....	9-2
GOT transparent function .....	14-40

GX LogViewer format CSV file .....	19-26
GX Simulator .....	22-9, 22-23, 22-30
GX Simulator2 .....	A-35
GX Works2 format CSV file .....	19-26

## [I]

inline structured text .....	10-17
instruction conversion list .....	App-162
intelligent function module .....	4-45, 15-15
invalid character .....	4-58
IP communication test .....	21-33, 21-44
I/O system setting file .....	22-27, 22-30

## [K]

keep .....	22-15
------------	-------

## [L]

L series .....	A-35
Label Names .....	App-110
label programming .....	1-5
ladder editing mode .....	9-14
Latch Data Backup .....	15-40
LED status .....	21-69
Libraries .....	13-2
link direct device .....	12-12, 12-13
Link start/stop .....	21-34
List of device stations .....	6-70
List of link devices .....	6-70
Logging .....	21-36
Logging in projects .....	4-69
logs .....	10-31, 10-33
Loop test .....	21-18
loop test/transmission speed test .....	21-59
Loopback test .....	21-84

## [M]

Managing block passwords .....	4-82
MELSECNET Diagnostics .....	21-14
Merge Data .....	4-39
module error history .....	21-95, 21-96
module error history collection function .....	21-95, 21-96, 21-102
Monitoring Intelligent Function Modules .....	17-26
Monitoring Interrupt Program List .....	17-15
Monitoring line (host station) .....	21-53
Monitoring Program List .....	17-12
Monitoring Value .....	12-13
Multiple word .....	10-18

## [N]

Navigation window .....	3-4, 3-20
Network event history .....	21-47

17

MONITORING

18

SIMULATING PROGRAMS

19

DEBUGGING PROGRAMS

20

OPERATING PROGRAMMABLE CONTROLLER CPU

21

DIAGNOSING PROGRAMMABLE CONTROLLER STATUS

22

SIMULATING OPERATIONS OF EXTERNAL DEVICES

A

APPENDIX

INDEX

network parameter .....	6-37
CC-Link .....	6-44, 6-45
CC-Link IE .....	6-41
Ethernet .....	6-43
MELSECNET/10 .....	6-42
MELSECNET/H .....	6-42
Remote I/O .....	6-43
Network route .....	14-4
Network test .....	21-16
New .....	4-34
New project creation with data read from programmable controller CPU .....	4-11
number of contacts .....	12-9
number of scans .....	22-17
number of scans of timing chart .....	22-22
<b>[O]</b>	
obtain transmission speed setting .....	21-60
Online Program Change .....	5-9, 15-45, 15-46, 15-48, 20-9
ON/OFF cycle .....	22-20
Opening existing projects .....	4-12
Opening projects in other formats .....	4-56
operation histories .....	21-7
option (find/replace) .....	10-18, 10-25
Options .....	12-2
Other station .....	14-4
other station information .....	21-26
Other Station (Co-existence Network) .....	14-4
Other Station (Single Network) .....	14-4
<b>[P]</b>	
Parameter Processing of Device Station .....	6-55, 6-65
parameter status .....	21-67, 21-73
Parameter Verify Level .....	15-32
Password .....	16-3, 16-8
paste .....	4-36, 4-37
PC side I/F .....	14-3
PING test .....	21-79
PLC Diagnostics .....	21-2, 21-9
PLC Direct Coupled Setting .....	14-5
PLC Memory Operation .....	20-10, 20-13
PLC parameter .....	6-2
communication head module .....	6-12
FXCPU .....	6-15
QCPU (Q mode)/LCPU .....	6-5
remote I/O module .....	6-13
PLC Status Information .....	21-4
Precautions on replacing .....	10-24
Print Preview .....	11-38
Print Window Preview .....	11-43
Profile .....	4-89
Program Memory Batch Download .....	15-38
programming languages .....	2-21
Project .....	4-5

Project view .....	3-20
properties .....	4-42
protocol status .....	21-78
Push Button .....	22-30
PX Developer .....	App-225

**[Q]**

Q series .....	A-35
QnH -> QnU Conversion Support Tool .....	4-32

**[R]**

Read Device Memory from PLC .....	7-16
Read from CSV File .....	9-20
Read from PLC .....	15-2
Read from PLC (trace data) .....	19-29
Read PLC Data .....	6-14
Read PLC User Data .....	15-36
Rebuild All .....	5-9
received e-mail information .....	21-70
Redundant Operation .....	20-6
redundant parameter .....	6-36
Registering and Monitoring Devices .....	17-16
Registering Keyword .....	16-14
Registering Password .....	16-4, 16-9
registering/canceling forced input/output .....	19-7, 19-9
remote I/O module .....	A-36, 6-13, 19-9, 21-2
Remote Operation .....	20-2, 20-8
Remote Password .....	6-74
remove memory card .....	20-3
Replace General CC-Link Module .....	6-63
Reserved station function enable .....	21-49
Resetting security .....	4-66
Restoring projects .....	4-49
Restrictions when Changing Programmable Controller Types .....	App-113
Result .....	10-31, 10-33
RS-232 cables	
QCPU (Q mode)/LCPU .....	2-6
RS-422 .....	2-7

**[S]**

sample comment .....	9-17
Sampling Trace .....	19-14
Sampling Trace Setting .....	19-15
Saving projects .....	4-14, 4-15
Saving the selection status of the files .....	15-6
SD memory card .....	15-36, 15-74, 15-77
Security .....	4-62
Security key .....	4-72
Select station network device status display .....	21-31
selected station communication status monitor .....	21-39, 21-42
selected station error information .....	21-54

selected station information .....	21-54
send e-mail information .....	21-71
sequence action .....	22-4
Set Clock .....	20-14
Setting character strings .....	7-11
Setting conditions .....	22-11
Setting Connection Destinations .....	14-2
Setting device values by setting device range .....	7-8
Setting device values in units of points .....	7-7
Setting Printer .....	11-4, 11-7
Setting verification test .....	21-19
Setting/changing block passwords .....	4-83
shortcut keys .....	App-2
simulation function .....	18-2, App-22
SIN curve .....	22-21
Sorting data .....	3-21
special debugging sequence program .....	22-2
Split into volumes of the following size .....	4-16
SRAM card .....	15-74
standard ROM .....	15-36
Start Monitoring .....	17-7
Start Trace .....	19-22
Station order check test .....	21-21
status bar .....	3-23
status logging .....	21-61
status of each connection .....	21-68, 21-74
status of each protocol .....	21-69
Switch Chart/Detail .....	19-24
Switching display format .....	7-13
Symbolic information .....	15-19
System Configuration .....	6-64
System error history .....	21-102
System image(s) .....	14-5
System Monitor .....	21-89

## [T]

target simulator setting .....	22-9
template .....	3-28, 3-29
temporary error invalid station setting/restore .....	21-50
timing chart .....	22-15
timing chart data file .....	22-23
timing chart input .....	22-8, 22-15
timing of bit devices .....	22-20
timing of word devices .....	22-21
timing setting .....	22-20
toolbars .....	3-5, App-2
Tooltip .....	3-11
Trace Setting .....	19-15, 19-16
trigonometric function .....	22-21

## [U]

Unlocking a remote password .....	15-5
Unlocking block passwords .....	4-84, 4-85
unlocking keyword temporarily .....	16-17

unlocking password temporarily .....	16-7, 16-12
USB cables	
FX3U/FX3UC .....	2-5
QCPU (Q mode)/LCPU .....	2-4
USB Driver .....	App-203
USB/Serial Port .....	2-2
User Libraries .....	13-4
User Library view .....	3-20
User Management .....	4-65, 4-66
Users .....	4-62
Utilizing Data .....	4-53
Utilizing existing data to set parameters of multiple CPU .....	6-14
Utilizing Projects .....	4-53

## [V]

Verify with PLC .....	15-29
Verifying project data .....	4-20
Verifying project level .....	4-23
Verifying revisions .....	4-51

## [W]

Warning .....	12-16
warning codes .....	12-16
Watch .....	17-16
windows .....	3-16
Word Device Setting screen .....	22-14
work window .....	3-11
Write Device Memory to PLC .....	7-16, 7-17
Write PLC User Data .....	15-36
Write to CSV File .....	9-19
Write to PLC .....	15-2
Write to PLC (trace data) .....	19-29, 19-32
written in units of files with Online program change .....	15-54

## [Extension]

*.DAT .....	22-23
*.IOS .....	22-27, 22-30

17

MONITORING

18

SIMULATING  
PROGRAMS

19

DEBUGGING  
PROGRAMS

20

OPERATING  
PROGRAMMABLE  
CONTROLLER CPU

21

DIAGNOSING  
PROGRAMMABLE  
CONTROLLER STATUS

22

SIMULATING  
OPERATIONS OF  
EXTERNAL DEVICES

A

APPENDIX

INDEX

# TRADEMARKS

---

Adobe and Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Microsoft, Excel, Windows, Windows Vista, and Windows XP are trademarks of the Microsoft group of companies.

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as <sup>™</sup> or <sup>®</sup> are not specified in this manual.

# COPYRIGHTS

---

The screens (screenshots) are used in accordance with the Microsoft Corporation guideline.

SPREAD

Copyright © 2004 FarPoint Technologies, Inc.

VS-FlexGrid Pro 8.0J

Copyright © 2001-2003 ComponentOne LLC.



SH(NA)-080779ENG-AQ(2305)KWIX

MODEL:GXW2-VER1-O-KY-E

MODEL CODE: 13JU63

## **mitsubishi electric corporation**

HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN  
NAGOYA WORKS: 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA 461-8670, JAPAN

When exported from Japan, this manual does not require application to the  
Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.