



Programmable Controller

MELSEC iQ-R
series

**MELSEC iQ-R Channel Isolated Analog-Digital
Converter Module (With Signal Conditioning
Function) User's Manual (Application)**

-R60AD6-DG



SAFETY PRECAUTIONS

(Read these precautions before using this product.)

Before using this product, please read this manual and the relevant manuals carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product only. For the safety precautions of the programmable controller system, refer to the MELSEC iQ-R Module Configuration Manual.

In this manual, the safety precautions are classified into two levels: "⚠️ WARNING" and "⚠️ CAUTION".

 WARNING	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
 CAUTION	Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage.

Under some circumstances, failure to observe the precautions given under "⚠️ CAUTION" may lead to serious consequences.

Observe the precautions of both levels because they are important for personal and system safety.

Make sure that the end users read this manual and then keep the manual in a safe place for future reference.

[Design Precautions]

WARNING

- Configure safety circuits external to the programmable controller to ensure that the entire system operates safely even when a fault occurs in the external power supply or the programmable controller. Failure to do so may result in an accident due to an incorrect output or malfunction.
 - (1) Emergency stop circuits, protection circuits, and protective interlock circuits for conflicting operations (such as forward/reverse rotations or upper/lower limit positioning) must be configured external to the programmable controller.
 - (2) When the programmable controller detects an abnormal condition, it stops the operation and all outputs are:
 - Turned off if the overcurrent or overvoltage protection of the power supply module is activated.
 - Held or turned off according to the parameter setting if the self-diagnostic function of the CPU module detects an error such as a watchdog timer error.
 - (3) All outputs may be turned on if an error occurs in a part, such as an I/O control part, where the CPU module cannot detect any error. To ensure safety operation in such a case, provide a safety mechanism or a fail-safe circuit external to the programmable controller. For a fail-safe circuit example, refer to "General Safety Requirements" in the MELSEC iQ-R Module Configuration Manual.
 - (4) Outputs may remain on or off due to a failure of a component such as a relay and transistor in an output circuit. Configure an external circuit for monitoring output signals that could cause a serious accident.
 - In an output circuit, when a load current exceeding the rated current or an overcurrent caused by a load short-circuit flows for a long time, it may cause smoke and fire. To prevent this, configure an external safety circuit, such as a fuse.
 - Configure a circuit so that the programmable controller is turned on first and then the external power supply. If the external power supply is turned on first, an accident may occur due to an incorrect output or malfunction.
 - Configure a circuit so that the external power supply is turned off first and then the programmable controller. If the programmable controller is turned off first, an accident may occur due to an incorrect output or malfunction.
 - For the operating status of each station after a communication failure, refer to manuals for the network used. For the manuals, please consult your local Mitsubishi representative. Incorrect output or malfunction due to a communication failure may result in an accident.
 - When connecting an external device with a CPU module or intelligent function module to modify data of a running programmable controller, configure an interlock circuit in the program to ensure that the entire system will always operate safely. For other forms of control (such as program modification, parameter change, forced output, or operating status change) of a running programmable controller, read the relevant manuals carefully and ensure that the operation is safe before proceeding. Improper operation may damage machines or cause accidents. When a Safety CPU is used, data cannot be modified while the Safety CPU is in SAFETY MODE.
 - Especially, when a remote programmable controller is controlled by an external device, immediate action cannot be taken if a problem occurs in the programmable controller due to a communication failure. To prevent this, configure an interlock circuit in the program, and determine corrective actions to be taken between the external device and CPU module in case of a communication failure.
-

[Design Precautions]

WARNING

- Do not write any data to the "system area" and "write prohibited area" of the buffer memory in the module. Also, do not use any "use prohibited" signals as an output signal from the CPU module to each module. Doing so may cause malfunction of the programmable controller system. For the "system area", "write prohibited area", and the "use prohibited" signals, refer to the user's manual for the module used. For areas used for safety communications, they are protected from being written by users, and thus safety communications failure caused by data writing does not occur.
 - If a communication cable is disconnected, the network may be unstable, resulting in a communication failure of multiple stations. Configure an interlock circuit in the program to ensure that the entire system will always operate safely even if communications fail. Incorrect output or malfunction due to a communication failure may result in an accident. When safety communications are used, an interlock by the safety station interlock function protects the system from an incorrect output or malfunction.
 - When using the module in the system where a 2-wire transmitter is not connected, use the module where the current input range is set. If the actual system configuration is not consistent with the range setting, it may cause an electric shock.
-

[Design Precautions]

CAUTION

- Do not install the control lines or communication cables together with the main circuit lines or power cables. Doing so may result in malfunction due to electromagnetic interference. Keep a distance of 100mm or more between those cables.
 - During control of an inductive load such as a lamp, heater, or solenoid valve, a large current (approximately ten times greater than normal) may flow when the output is turned from off to on. Therefore, use a module that has a sufficient current rating.
 - After the CPU module is powered on or is reset, the time taken to enter the RUN status varies depending on the system configuration, parameter settings, and/or program size. Design circuits so that the entire system will always operate safely, regardless of the time.
 - Do not power off the programmable controller or reset the CPU module while the settings are being written. Doing so will make the data in the flash ROM and SD memory card undefined. The values need to be set in the buffer memory and written to the flash ROM and SD memory card again. Doing so also may cause malfunction or failure of the module.
 - When changing the operating status of the CPU module from external devices (such as the remote RUN/STOP functions), select "Do Not Open by Program" for "Opening Method" of "Module Parameter". If "Open by Program" is selected, an execution of the remote STOP function causes the communication line to close. Consequently, the CPU module cannot reopen the communication line, and the external device cannot execute the remote RUN.
-

[Security Precautions]

WARNING

- To maintain the security (confidentiality, integrity, and availability) of the programmable controller and the system against unauthorized access, denial-of-service (DoS) attacks, computer viruses, and other cyberattacks from external devices via the network, take appropriate measures such as firewalls, virtual private networks (VPNs), and antivirus solutions.
-

[Installation Precautions]

WARNING

- Shut off the external power supply (all phases) used in the system before mounting or removing the module. Failure to do so may result in electric shock or cause the module to fail or malfunction.
-

[Installation Precautions]

CAUTION

- Use the programmable controller in an environment that meets the general specifications in the MELSEC iQ-R Module Configuration Manual. Failure to do so may result in electric shock, fire, malfunction, or damage to or deterioration of the product.
 - To mount a module, place the concave part(s) located at the bottom onto the guide(s) of the base unit, and push in the module until the hook(s) located at the top snaps into place. Incorrect interconnection may cause malfunction, failure, or drop of the module.
 - To mount a module with no module fixing hook, place the concave part(s) located at the bottom onto the guide(s) of the base unit, push in the module, and fix it with screw(s). Incorrect interconnection may cause malfunction, failure, or drop of the module.
 - When using the programmable controller in an environment of frequent vibrations, fix the module with a screw.
 - Tighten the screws within the specified torque range. Undertightening can cause drop of the component or wire, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction. For the specified torque range, refer to the MELSEC iQ-R Module Configuration Manual.
 - When using an extension cable, connect it to the extension cable connector of the base unit securely. Check the connection for looseness. Poor contact may cause malfunction.
 - When using an SD memory card, fully insert it into the SD memory card slot. Check that it is inserted completely. Poor contact may cause malfunction.
 - Securely insert an extended SRAM cassette or a battery-less option cassette into the cassette connector of the CPU module. After insertion, close the cassette cover and check that the cassette is inserted completely. Poor contact may cause malfunction.
 - Beware that the module could be very hot while power is on and immediately after power-off.
 - Do not directly touch any conductive parts and electronic components of the module, SD memory card, extended SRAM cassette, battery-less option cassette, or connector. Doing so can cause malfunction or failure of the module.
-

[Wiring Precautions]

WARNING

- Shut off the external power supply (all phases) used in the system before installation and wiring. Failure to do so may result in electric shock or cause the module to fail or malfunction.
- After installation and wiring, attach a blank cover module (RG60) to each empty slot before powering on the system for operation. Also, attach an extension connector protective cover^{*1} to each unused extension cable connector as necessary. Directly touching any conductive parts of the connectors while power is on may result in electric shock.

*1 For details, please consult your local Mitsubishi Electric representative.

[Wiring Precautions]

CAUTION

- Individually ground the FG and LG terminals of the programmable controller with a ground resistance of 100 ohms or less. Failure to do so may result in electric shock or malfunction.
 - Use applicable solderless terminals and tighten them within the specified torque range. If any spade solderless terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure.
 - Check the rated voltage and signal layout before wiring to the module, and connect the cables correctly. Connecting a power supply with a different voltage rating or incorrect wiring may cause fire or failure.
 - Connectors for external devices must be crimped or pressed with the tool specified by the manufacturer, or must be correctly soldered. Incomplete connections may cause short circuit, fire, or malfunction.
 - Securely connect the connector to the module. Poor contact may cause malfunction.
 - Do not install the control lines or communication cables together with the main circuit lines or power cables. Doing so may result in malfunction due to noise. Keep a distance of 100mm or more between those cables.
 - Place the cables in a duct or clamp them. If not, dangling cables may swing or inadvertently be pulled, resulting in malfunction or damage to modules or cables.
In addition, the weight of the cables may put stress on modules in an environment of strong vibrations and shocks.
Do not clamp the extension cables with the jacket stripped. Doing so may change the characteristics of the cables, resulting in malfunction.
 - Check the interface type and correctly connect the cable. Incorrect wiring (connecting the cable to an incorrect interface) may cause failure of the module and external device.
 - Tighten the terminal screws or connector screws within the specified torque range. Undertightening can cause drop of the screw, short circuit, fire, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, fire, or malfunction.
 - When disconnecting the cable from the module, do not pull the cable by the cable part. For the cable with connector, hold the connector part of the cable. For the cable connected to the terminal block, loosen the terminal screw. Pulling the cable connected to the module may result in malfunction or damage to the module or cable.
 - Prevent foreign matter such as dust or wire chips from entering the module. Such foreign matter can cause a fire, failure, or malfunction.
 - When a protective film is attached to the top of the module, remove it before system operation. If not, inadequate heat dissipation of the module may cause a fire, failure, or malfunction.
 - Programmable controllers must be installed in control panels. Connect the main power supply to the power supply module in the control panel through a relay terminal block. Wiring and replacement of a power supply module must be performed by qualified maintenance personnel with knowledge of protection against electric shock. For wiring, refer to the MELSEC iQ-R Module Configuration Manual.
 - For Ethernet cables to be used in the system, select the ones that meet the specifications in the user's manual for the module used. If not, normal data transmission is not guaranteed.
 - Individually ground the shielded cables of the programmable controller with a ground resistance of 100 ohms or less. Failure to do so may result in electric shock or malfunction.
-

[Startup and Maintenance Precautions]

WARNING

- Do not touch any terminal while power is on. Doing so will cause electric shock or malfunction.
 - Correctly connect the battery connector. Do not charge, disassemble, heat, short-circuit, solder, or throw the battery into the fire. Also, do not expose it to liquid or strong shock. Doing so will cause the battery to produce heat, explode, ignite, or leak, resulting in injury and fire.
 - Shut off the external power supply (all phases) used in the system before cleaning the module or retightening the terminal screws, connector screws, or module fixing screws. Failure to do so may result in electric shock.
-

[Startup and Maintenance Precautions]

CAUTION

- When connecting an external device with a CPU module or intelligent function module to modify data of a running programmable controller, configure an interlock circuit in the program to ensure that the entire system will always operate safely. For other forms of control (such as program modification, parameter change, forced output, or operating status change) of a running programmable controller, read the relevant manuals carefully and ensure that the operation is safe before proceeding. Improper operation may damage machines or cause accidents.
 - Especially, when a remote programmable controller is controlled by an external device, immediate action cannot be taken if a problem occurs in the programmable controller due to a communication failure. To prevent this, configure an interlock circuit in the program, and determine corrective actions to be taken between the external device and CPU module in case of a communication failure.
 - Do not disassemble or modify the modules. Doing so may cause failure, malfunction, injury, or a fire.
 - Use any radio communication device such as a cellular phone or PHS (Personal Handy-phone System) 25cm or more away in all directions from the programmable controller. Failure to do so may cause malfunction.
 - Shut off the external power supply (all phases) used in the system before mounting or removing the module. Failure to do so may cause the module to fail or malfunction.
 - Tighten the screws within the specified torque range. Undertightening can cause drop of the component or wire, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
 - After the first use of the product, do not perform each of the following operations more than 50 times (IEC 61131-2/JIS B 3502 compliant).
Exceeding the limit may cause malfunction.
 - Mounting/removing the module to/from the base unit
 - Inserting/removing the extended SRAM cassette or battery-less option cassette to/from the CPU module
 - Mounting/removing the terminal block to/from the module
 - Connecting/disconnecting the extension cable to/from the base unit
 - After the first use of the product, do not insert/remove the SD memory card to/from the CPU module more than 500 times. Exceeding the limit may cause malfunction.
 - Do not touch the metal terminals on the back side of the SD memory card. Doing so may cause malfunction or failure of the module.
 - Do not touch the integrated circuits on the circuit board of an extended SRAM cassette or a battery-less option cassette. Doing so may cause malfunction or failure of the module.
 - Do not drop or apply shock to the battery to be installed in the module. Doing so may damage the battery, causing the battery fluid to leak inside the battery. If the battery is dropped or any shock is applied to it, dispose of it without using.
 - Startup and maintenance of a control panel must be performed by qualified maintenance personnel with knowledge of protection against electric shock. Lock the control panel so that only qualified maintenance personnel can operate it.
-

[Startup and Maintenance Precautions]

CAUTION

- Before handling the module, touch a conducting object such as a grounded metal to discharge the static electricity from the human body. Wearing a grounded antistatic wrist strap is recommended. Failure to discharge the static electricity may cause the module to fail or malfunction.
 - After unpacking, eliminate static electricity from the module to prevent electrostatic discharge from affecting the module. If an electrostatically charged module comes in contact with a grounded metal object, a sudden electrostatic discharge of the module may cause failure.
For details on how to eliminate static electricity from the module, refer to the following.
Antistatic Precautions Before Using MELSEC iQ-R Series Products (FA-A-0368)
 - Use a clean and dry cloth to wipe off dirt on the module.
-

[Operating Precautions]

CAUTION

- When changing data and operating status, and modifying program of the running programmable controller from an external device such as a personal computer connected to an intelligent function module, read relevant manuals carefully and ensure the safety before operation. Incorrect change or modification may cause system malfunction, damage to the machines, or accidents.
 - Do not power off the programmable controller or reset the CPU module while the setting values in the buffer memory are being written to the flash ROM in the module. Doing so will make the data in the flash ROM and SD memory card undefined. The values need to be set in the buffer memory and written to the flash ROM and SD memory card again. Doing so can cause malfunction or failure of the module.
-

[Disposal Precautions]

CAUTION

- When disposing of this product, treat it as industrial waste.
 - When disposing of batteries, separate them from other wastes according to the local regulations. For details on battery regulations in EU member states, refer to the MELSEC iQ-R Module Configuration Manual.
-

[Transportation Precautions]

CAUTION

- When transporting lithium batteries, follow the transportation regulations. For details on the regulated models, refer to the MELSEC iQ-R Module Configuration Manual.
 - The halogens (such as fluorine, chlorine, bromine, and iodine), which are contained in a fumigant used for disinfection and pest control of wood packaging materials, may cause failure of the product. Prevent the entry of fumigant residues into the product or consider other methods (such as heat treatment) instead of fumigation. The disinfection and pest control measures must be applied to unprocessed raw wood.
-

CONDITIONS OF USE FOR THE PRODUCT

- (1) MELSEC programmable controller ("the PRODUCT") shall be used in conditions;
- i) where any problem, fault or failure occurring in the PRODUCT, if any, shall not lead to any major or serious accident; and
 - ii) where the backup and fail-safe function are systematically or automatically provided outside of the PRODUCT for the case of any problem, fault or failure occurring in the PRODUCT.
- (2) The PRODUCT has been designed and manufactured for the purpose of being used in general industries. MITSUBISHI ELECTRIC SHALL HAVE NO RESPONSIBILITY OR LIABILITY (INCLUDING, BUT NOT LIMITED TO ANY AND ALL RESPONSIBILITY OR LIABILITY BASED ON CONTRACT, WARRANTY, TORT, PRODUCT LIABILITY) FOR ANY INJURY OR DEATH TO PERSONS OR LOSS OR DAMAGE TO PROPERTY CAUSED BY the PRODUCT THAT ARE OPERATED OR USED IN APPLICATION NOT INTENDED OR EXCLUDED BY INSTRUCTIONS, PRECAUTIONS, OR WARNING CONTAINED IN MITSUBISHI ELECTRIC USER'S, INSTRUCTION AND/OR SAFETY MANUALS, TECHNICAL BULLETINS AND GUIDELINES FOR the PRODUCT.
- ("Prohibited Application")
- Prohibited Applications include, but not limited to, the use of the PRODUCT in;
- Nuclear Power Plants and any other power plants operated by Power companies, and/or any other cases in which the public could be affected if any problem or fault occurs in the PRODUCT.
 - Railway companies or Public service purposes, and/or any other cases in which establishment of a special quality assurance system is required by the Purchaser or End User.
 - Aircraft or Aerospace, Medical applications, Train equipment, transport equipment such as Elevator and Escalator, Incineration and Fuel devices, Vehicles, Manned transportation, Equipment for Recreation and Amusement, and Safety devices, handling of Nuclear or Hazardous Materials or Chemicals, Mining and Drilling, and/or other applications where there is a significant risk of injury to the public or property.
- Notwithstanding the above restrictions, Mitsubishi Electric may in its sole discretion, authorize use of the PRODUCT in one or more of the Prohibited Applications, provided that the usage of the PRODUCT is limited only for the specific applications agreed to by Mitsubishi Electric and provided further that no special quality assurance or fail-safe, redundant or other safety features which exceed the general specifications of the PRODUCTS are required. For details, please contact the Mitsubishi Electric representative in your region.
- (3) Mitsubishi Electric shall have no responsibility or liability for any problems involving programmable controller trouble and system trouble caused by DoS attacks, unauthorized access, computer viruses, and other cyberattacks.

INTRODUCTION

Thank you for purchasing the Mitsubishi Electric MELSEC iQ-R series programmable controllers.

This manual describes the functions, parameter settings, and troubleshooting of the relevant product listed below.


Before using this product, please read this manual and the relevant manuals carefully and develop familiarity with the functions and performance of the MELSEC iQ-R series programmable controller to handle the product correctly.

When applying the program examples provided in this manual to an actual system, ensure the applicability and confirm that it will not cause system control problems.

Please make sure that the end users read this manual.

Point

Unless otherwise specified, this manual provides program examples in which the I/O numbers of X/Y0 to X/YF are assigned to the A/D converter module. Assign I/O numbers when applying the program examples to an actual system. For I/O number assignment, refer to the following.

 MELSEC iQ-R Module Configuration Manual

Relevant product

R60AD6-DG

CONTENTS

SAFETY PRECAUTIONS	1
CONDITIONS OF USE FOR THE PRODUCT	10
INTRODUCTION	11
RELEVANT MANUALS	14
TERMS	15
GENERIC TERMS AND ABBREVIATIONS	15

CHAPTER 1 FUNCTIONS 16

1.1 Processing of Each Function	17
1.2 Range Switching Function	18
1.3 A/D Conversion Enable/Disable Setting Function	19
1.4 Conversion Start Time Setting Function	20
1.5 A/D Conversion Method	22
1.6 Scaling Function	27
1.7 Warning Output Function	30
Process alarm	30
Rate alarm	33
1.8 Input Signal Error Detection Function	38
When the function is used in the Q compatible mode	46
1.9 Shift Function	50
1.10 Digital Clipping Function	52
1.11 Difference Conversion Function	54
1.12 Maximum Value/Minimum Value Hold Function	58
1.13 External Power Supply Interruption Detection Function	59
1.14 Supply Power Temporary Stop Function	60
1.15 Logging Function	63
Stopping the logging operation	68
Logging hold request	71
Level trigger	72
Initial settings of the logging function	75
Logging read function	76
Saving to a CSV file	83
Displaying logging data	84
1.16 Interrupt Function	85
1.17 Error History Function	88
1.18 Module Event History Collection Function	91
1.19 Backing up, Saving, and Restoring Offset/Gain Values	92
When the module-specific backup parameter is used	92
When the module-specific backup parameter is not used	95
1.20 Q Compatible Mode Function	99

CHAPTER 2 PARAMETER SETTINGS 100

2.1 Parameter Setting Procedure	100
2.2 Basic Setting	100
2.3 Application Setting	101
2.4 Interrupt Setting	102
2.5 Refresh Setting	103
Refresh processing time	104

CHAPTER 3 TROUBLESHOOTING	105
3.1 Troubleshooting with the LEDs	105
3.2 Checking the State of the Module	106
3.3 Troubleshooting by Symptom	108
When the A/D converter module does not start up	108
When the RUN LED flashes or turns off	108
When the ERR LED turns on	109
When the ALM LED turns on or flashes	109
When a digital output value cannot be read	110
When the digital output value does not fall within the range of accuracy	113
3.4 List of Error Codes	114
3.5 List of Alarm Codes	117
APPENDICES	118
Appendix 1 Module Label	118
Appendix 2 I/O Signals	120
List of I/O signals	120
Details of input signals	122
Details of output signals	132
Appendix 3 Buffer Memory	134
List of buffer memory addresses	134
Details of buffer memory addresses	149
Appendix 4 Dedicated Instructions	210
Instruction list	210
Appendix 5 Operation Examples of When the Remote Head Module Is Mounted	211
System configuration example	211
Setting in the master station	212
Setting in the intelligent device station	215
Checking the network status	218
Program examples	218
Appendix 6 Using the Module in the Redundant System with Redundant Extension Base Unit	223
Restrictions on functions and specifications	223
Precautions	223
INDEX	224
REVISIONS	226
WARRANTY	227
TRADEMARKS	228

RELEVANT MANUALS

Manual name [manual number]	Description	Available form
MELSEC iQ-R Channel Isolated Analog-Digital Converter Module (With Signal Conditioning Function) User's Manual (Application) [SH-082300ENG] (this manual)	Functions, parameter settings, troubleshooting, I/O signals, and buffer memory of the A/D converter module	Print book e-Manual PDF
MELSEC iQ-R Module Configuration Manual [SH-081262ENG]	Common information on the hardware configuration of all modules, overview of each system configuration, and specifications of the power supply module, base unit, SD memory card, and battery	Print book e-Manual PDF
MELSEC iQ-R Channel Isolated Analog-Digital Converter Module (With Signal Conditioning Function) User's Manual (Startup) [SH-082298ENG]	Performance specifications, procedures before operation, wiring, operation examples, and offset/gain setting of the A/D converter module	Print book e-Manual PDF
MELSEC iQ-R Programming Manual (Module Dedicated Instructions) [SH-081976ENG]	Dedicated instructions for the intelligent function modules	e-Manual PDF
MELSEC iQ-R Analog-Digital Converter Module/Digital-Analog Converter Module Function Block Reference [BCN-P5999-0375]	Function blocks of the A/D converter module and D/A converter module	e-Manual PDF
GX Works3 Operating Manual [SH-081215ENG]	System configuration, parameter settings, and online operations of GX Works3	e-Manual PDF
MELSEC iQ-R Online Module Change Manual [SH-081501ENG]	The online module change, which allows a module to be changed without stopping the system for MELSEC iQ-R series programmable controllers	Print book e-Manual PDF

Point

e-Manual refers to the Mitsubishi Electric FA electronic book manuals that can be browsed using a dedicated tool.

e-Manual has the following features:

- Required information can be cross-searched in multiple manuals.
- Other manuals can be accessed from the links in the manual.
- The hardware specifications of each part can be found from the product figures.
- Pages that users often browse can be bookmarked.
- Sample programs can be copied to an engineering tool.

TERMS

Unless otherwise specified, this manual uses the following terms.

Term	Description
Buffer memory	Memory in an intelligent function module for storing data such as setting values and monitored values. When integrated into the CPU module, this memory refers to a memory for storing data such as setting values and monitored values of the Ethernet function, and data used for data communication of the multiple CPU system function.
Engineering tool	A tool used for setting up programmable controllers, programming, debugging, and maintenance
Global label	A label that is valid for all the program data when multiple program data are created in the project. There are two types of global label: a module specific label (module label), which is generated automatically by GX Works3, and an optional label, which can be created for any specified device.
Module label	A label that represents one of memory areas (I/O signals and buffer memory areas) specific to each module in a given character string. For the module used, GX Works3 automatically generates this label, which can be used as a global label.
Normal mode	A mode used for normal A/D conversion. In the engineering tool, the item name of the mode is displayed as "Normal mode (A/D conversion processing)".
Offset/gain setting mode	A mode used for performing the offset/gain setting
Q compatible mode	A mode in which the module operates with the buffer memory map converted to the equivalent one of the MELSEC-Q series
R mode	A mode in which the module operates with the buffer memory map that has been newly laid out in the MELSEC iQ-R series
Redundant system with redundant extension base unit	A redundant system that is configured using extension base unit(s)
User range	An analog input range where any value can be set. This range can be set in the offset/gain setting.
Watchdog timer error	The watchdog timer is a timer with which the module itself monitors whether the module's internal processing is performed correctly. The watchdog timer error is an error that occurs when internal processing is not processed correctly.

GENERIC TERMS AND ABBREVIATIONS

Unless otherwise specified, this manual uses the following generic terms and abbreviations.

Generic term/abbreviation	Description
A/D converter module	An abbreviation for the MELSEC iQ-R series channel isolated analog-digital converter module
Current input range	A generic term for the analog input range for current input that does not use a 2-wire transmitter
2-wire transmitter range	A generic term for the analog input range for current input that uses a 2-wire transmitter
Remote head module	An abbreviation for the RJ72GF15-T2 CC-Link IE Field Network remote head module

1 FUNCTIONS

This chapter describes the functions of the A/D converter module and the setting procedures for those functions. For details on the I/O signals and the buffer memory, refer to the following.

☞ Page 120 I/O Signals

☞ Page 134 Buffer Memory

Point

- This chapter describes buffer memory addresses for CH1. For details on the buffer memory addresses after CH2, refer to the following.

☞ Page 134 List of buffer memory addresses


- Numerical values corresponding to the channel where an error has occurred and the error description fit in the □ and △ of an error code and alarm code described in this chapter. For details on the numerical values, refer to the following.

☞ Page 114 List of Error Codes

☞ Page 117 List of Alarm Codes

1.1 Processing of Each Function

The functions are processed in the order shown below. If multiple functions are enabled, the output of the first processed function is used as the input of the next function.



Digital output value (32 bits)

These values are the digital values after the sampling processing, each averaging processing, or primary delay filter has been performed.

Digital output value

These values are the 16-bit digital output values that were converted from 32-bit digital output values.

Digital operation value

These values are obtained by operating a digital output value using the digital clipping function, scaling function, shift function, or difference conversion function. When each function is not used, the same value as the digital output value is stored.

Maximum and minimum value

The maximum and minimum values of the digital operation values are stored.

Logging data

When the logging function is used, digital output values or digital operation values are collected.

1.2 Range Switching Function

This function allows the input range of analog input to be switched for each channel. Switching the range makes it possible to change the I/O conversion characteristics.

Operation

Analog input values are converted to digital values within the set input range, and the converted values are stored in the following areas.

- 'CH1 Digital output value' (Un\G400)
- 'CH1 Digital operation value' (Un\G402)
- 'CH1 Digital output value (32 bits)' (Un\G410, Un\G411)

The data of 32768 or more cannot be output to 'CH1 Digital output value' (Un\G400) or 'CH1 Digital operation value' (Un\G402).

To check the data of 32768 or more, monitor 'CH1 Digital output value (32 bits)' (Un\G410, Un\G411).

Point

Digital output values (32768 to 36767) in the extended mode can be monitored within the range of 'CH1 Digital operation value' (Un\G402) with the shift function or scaling function.

For details, refer to the following.

☞ Page 50 Shift Function

☞ Page 27 Scaling Function

Setting procedure

Set the input range to be used in the "Input range setting".

☞ [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Basic setting] ⇒ [Range switching function]

Item	Setting value
Input range setting	4 to 20mA (2-wire transmitter input)
	4 to 20mA (current input)
	0 to 20mA (current input)
	4 to 20mA (extended mode) (2-wire transmitter input)
	4 to 20mA (extended mode) (current input)
	User range setting (current input)
	User range setting (2-wire transmitter input)

After the data is written, the range is switched when the programmable controller power supply is turned off and on or when the CPU module is reset.

Point

The range can be switched or set with the following buffer memory areas.

- 'CH1 Range setting' (Un\G598)
- 'CH1 Range setting monitor' (Un\G430)

For details on the buffer memory addresses, refer to the following.

☞ Page 202 CH1 Range setting

☞ Page 164 CH1 Range setting monitor

Precautions

The input range cannot be changed for channels with A/D conversion disabled.

To change the input range, set "A/D conversion enable/disable setting" to "A/D conversion enable", and turn on and off 'Operating condition setting request' (Y9).

1.3 A/D Conversion Enable/Disable Setting Function

This function controls whether to enable or disable the A/D conversion for each channel.
Disabling the A/D conversion for unused channels reduces the conversion cycles.

Operation


The power supply requirements for 2-wire transmitter are turned on/off with a combination of 'CH1 Range setting' (Un\G598) and 'CH1 A/D conversion enable/disable setting' (Un\G500).

'CH1 Range setting' (Un\G598)	'CH1 A/D conversion enable/disable setting' (Un\G500)	CH1 Power supply requirements for 2-wire transmitter
<ul style="list-style-type: none"> • 4 to 20mA (2-wire transmitter input) • 4 to 20mA (extended mode) (2-wire transmitter input) • User range setting (2-wire transmitter input) 	A/D conversion enable	On*1
	A/D conversion disable	Off
<ul style="list-style-type: none"> • 4 to 20mA (current input) • 0 to 20mA (current input) • 4 to 20mA (extended mode) (current input) • User range setting (current input) 	A/D conversion enable	Off
	A/D conversion disable	Off

*1 When the external power supply is off or the power supply is temporarily stopped, the power supply requirements for 2-wire transmitter are not performed.





Setting procedure

1. Set "A/D conversion enable/disable setting" to "A/D conversion enable" or "A/D conversion disable".

 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Basic setting] ⇒ [A/D conversion enable/disable setting function]

Precautions

For a channel set to the 2-wire transmitter range, even when A/D conversion enabled (0) is set for 'CH1 A/D conversion enable/disable setting' (Un\G500), if any of the following factors occurs, A/D conversion is not performed and the state turns to A/D conversion stop. ('CH1 Digital output value' (Un\G400) and 'CH1 Digital operation value' (Un\G402) hold the current values.)

- The start of conversion by the conversion start time setting function is awaited. ( Page 20 Conversion Start Time Setting Function)
- The external power supply is turned off. ( Page 19 A/D Conversion Enable/Disable Setting Function)
- The power supply requirements for 2-wire transmitter are temporarily stopped by the supply power temporary stop function. ( Page 60 Supply Power Temporary Stop Function)
- Input signal error detection is in progress. ( Page 38 Input Signal Error Detection Function)

Point

To perform the power supply requirements for 2-wire transmitter, check the wiring and settings first, and turn on and off 'Operating condition setting request' (Y9). Note that when 'Operating condition setting request' (Y9) is turned on and off, the power supply requirements for 2-wire transmitter turn on before A/D conversion starts.

1.4 Conversion Start Time Setting Function

Setting the A/D conversion start time makes it possible to start A/D conversion from the time an output from the 2-wire transmitter becomes stable.

This setting is enabled only for a channel set to the 2-wire transmission range. The setting is ignored for a channel set to any other range.

Operation

Even when A/D conversion enabled (0) is set for 'CH1 A/D conversion enable/disable setting' (Un\G500)', A/D conversion is not performed until the time set in 'CH1 Conversion start time setting (for 2-wire transmitter)' (Un\G532) passes. In this case, 'A/D conversion completed flag' (Un\G42) turns to A/D conversion in progress or not used (0), and 0 is stored in 'CH1 Digital output value' (Un\G400).

Note that A/D conversion starts after the set time passes.

When the first A/D conversion is completed, 'A/D conversion completed flag' (Un\G42) turns to A/D conversion completed (1). The time until 'A/D conversion completed flag' (Un\G42) turns on when 'CH1 Conversion start time setting (for 2-wire transmitter)' (Un\G532) is set is a value obtained by adding the conversion start time and conversion cycle.

Point

- Consider the time required for an output to become stable after the 2-wire transmitter powers on and the warm-up time for the 2-wire transmitter when setting 'CH1 Conversion start time setting (for 2-wire transmitter)' (Un\G532).
- Even if there is a channel where A/D conversion is not performed because of the conversion start time setting function, the conversion cycle does not change.


Operation examples

This section shows examples of operations when the following are set.

- Input range: 4 to 20mA (2-wire transmitter input)
- A/D conversion-enabled channel: CH1
- 'CH1 Averaging processing specification' (Un\G501): Sampling processing (0)

■When the time required for an output to become stable after the 2-wire transmitter powers on is 500ms

Ex.




(1) When the conversion start time is 0ms, A/D conversion starts at that point.

(2) When the conversion start time is 500ms, A/D conversion starts at that point.

■When the external power supply is turned off and on

Ex.



(1) The conversion start time is awaited again from the beginning.

After the time set in 'CH1 Conversion start time setting (for 2-wire transmitter)' (Un\G532) passes from the time the external power supply is turned off and on, A/D conversion starts.

■When 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (Un\G473) is set to Trigger request (1) and the supply power stops

After the time set in 'CH1 Conversion start time setting (for 2-wire transmitter)' (Un\G532) passes from the time the setting is changed from Trigger request (1) to No request (0), A/D conversion starts. The operation example is the same as the one when the external power supply is turned off and on.

Setting procedure

1. For "Conversion start time setting", set a value in the range 0 to 3276.7.

☞ [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Basic setting] ⇒ [Conversion starting time setting function]

1.5 A/D Conversion Method

An A/D conversion method can be set for each channel.

Sampling processing

This function converts analog input values to digital values at every sampling period and stores the digital output values in buffer memory areas.

Point

The sampling period is "Conversion speed (10ms) × number of conversion enabled channels".

Whether to enable or disable the A/D conversion can be set for each channel. Disabling the A/D conversion for unused channels reduces the conversion cycles.

Conversion cycle that applies when CH1 to CH3 is set to A/D conversion enabled

- $10 \times 3 = 30$ (ms)

The conversion cycle is 30 (ms).

Digital output values and digital operation values of CH1 to CH3 are updated every 30ms.

Averaging processing

The A/D converter module performs the averaging processing on digital output values for each channel. The processed values are stored in the buffer memory area.

The following three types of averaging processing are provided.

- Time average
- Count average
- Moving average

■Time average

The A/D converter module executes the A/D conversion for the setting time, and performs the averaging processing on the total value excluding the maximum and the minimum values. The processed values are stored in the buffer memory area.

- Setting time

Set a value that satisfies the following condition.

Lower limit value \geq Conversion speed \times Number of conversion enabled channels \times Minimum processing times (4 times)

Ex.

The following shows the lower limit value to be set for when CH1 to CH6 are used.

$$10 \text{ (ms)} \times 6 \text{ (CH)} \times 4 \text{ (times)} = 240 \text{ (ms)}$$

- Processing times

The number of processing times within the set time changes depending on the number of channels where the A/D conversion is enabled.

$$\text{Processing times (times)} = \text{Setting time} \div (\text{Number of conversion enabled channels} \times \text{Conversion speed})$$

Ex.

The following table shows the processing times with the setting below.

Item	Setting
Number of channels where the A/D conversion is enabled	Four channels (CH1 to CH4)
Setting time	250ms

$$250 \text{ (ms)} \div (4 \text{ (CH)} \times 10 \text{ (ms)}) = 6.25 \text{ (times)}^{*1}$$

*1 Values after the decimal point are omitted.

Conversion is processed 6 times and the mean value is output.

Point

When the number of processing times is less than 4 due to the set time, a time average setting range error (error code: 192□H) occurs. The value 0 is stored in the following buffer memory areas.

- 'CH1 Digital output value' (Un\G400)
- 'CH1 Digital operation value' (Un\G402)
- 'CH1 Digital output value (32 bits)' (Un\G410, Un\G411)

Count average

The A/D converter module executes the A/D conversion for a set number of times, and performs the averaging processing on the total value excluding the maximum and the minimum values. The processed values are stored in the buffer memory area. The time taken for the mean value calculated through the average processing to be stored in the buffer memory changes depending on the number of channels where the A/D conversion is enabled.

Processing time = Set number of times × (Number of conversion enabled channels × Conversion speed)

Ex.

The processing time calculated with the settings in the table is shown below.

Item	Setting
Number of channels where the A/D conversion is enabled	Four channels (CH1 to CH4)
Set number of times	Five times

5 (times) × (4 (CH) × 10 (ms)) = 200 (ms)

A mean value is output every 200ms.


Point

Because the count average requires a sum of at least two counts excluding the maximum and minimum values, the set number of times should be four or more.

Moving average

The A/D converter module averages digital output values taken at every sampling period for a specified number of times, and stores the mean value in the buffer memory area. Since the averaging processing is performed on a moving set of sampling, the latest digital output values can be obtained.

The following figure shows the moving average processing of when the set number of times is five.



Primary delay filter

Depending on the set time constant, transient noise of analog input is smoothed. The smoothed digital output values are stored in the buffer memory area.

Time constant is the time taken for the digital output value to reach 63.2% of the steady-state value.

The following shows the relational expressions of time constants and digital output values.

■When $n = 1$ *1

$$Y_n = 0$$

■When $n = 2$

$$Y_n = X_{n-1} + \frac{\Delta t}{\Delta t + TA} (X_n - X_{n-1})$$

■When $n \geq 3$

$$Y_n = Y_{n-1} + \frac{\Delta t}{\Delta t + TA} (X_n - Y_{n-1})$$

Y_n : Current digital output value

Y_{n-1} : Last digital output value

n : Number of samplings

X_n : Digital output value before smoothing

X_{n-1} : Last digital output value before smoothing

ΔT : Conversion time

TA : Time constant


*1 The corresponding bit of 'A/D conversion completed flag' (Un\G42) turns on when $n \geq 2$.

Ex.

Digital output value when an analog input value is changed from 4 to 6mA

For the input range of 4 to 20mA (2-wire transmission input), the following figure shows the change of the digital output value with the time constant set to 40ms.


After 40ms from the analog input value becoming 6mA, the digital output value reaches 63.2% of the digital output value of when the sampling processing is selected.



Setting procedure


■ Sampling processing

Set "Averaging processing specification" to "Sampling processing".

 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Basic setting] ⇒ [A/D conversion method]

■ Averaging processing and primary delay filter

1. Set "Averaging processing specification" to "Time average", "Count average", "Moving average", or "Primary delay filter".

 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Basic setting] ⇒ [A/D conversion method]

2. Set a value for "Time average/Count average/Moving average/Primary delay filter constant setting".

Item	Setting range
Time average	40 to 5000 (ms) ^{*1}
Count average	4 to 500 (times)
Moving average	2 to 200 (times)
Primary delay filter	1 to 500 (times)

In a channel where a value out of the setting range is set, a time average setting range error (error code: 192□H), count average setting range error (error code: 193□H), moving average setting range error (error code: 194□H), or primary delay filter constant setting range error (error code: 195□H) occurs.

*1 Set a value greater than the value calculated by the following formula as the time average.
 $10\text{ms} \times 4 \text{ times} \times \text{Number of channels used}$

Point

Set a primary delay filter constant for the primary delay filter. The value of the time constant (ms) is the product of the primary delay filter constant and the sampling cycle.

1.6 Scaling Function

This function performs the scale conversion on digital output values. The values are converted within a specified range between a scaling upper limit value and scaling lower limit value. This function helps reduce the time taken for creating a scale conversion program.

The converted values are stored in 'CH1 Digital operation value' (Un\G402).

Concept of scaling setting

For the scaling lower limit value, set a value corresponding to the lower limit value of the input range (0).

For the scaling upper limit value, set a value corresponding to the upper limit value of the input range (32000).

Calculating the scaling value

The scale conversion is based on the following formula. (In scale conversion, values are rounded to the nearest whole number.)

$$D_Y = \frac{D_X \times (S_H - S_L)}{D_{Max}} + S_L$$

D_X : Digital output value

D_Y : Scaling value (Digital operation value)

D_{Max} : Maximum digital output value of the input range in use

S_H : Scaling upper limit value

S_L : Scaling lower limit value


Although the range of the digital output value in the extended mode is -8000 to 36000, this function performs the scale conversion for digital output values within the range of 0 to 32000.

Point

When the calculated digital operation value exceeds 32767, the value 32767 is stored as the digital operation value. When the calculated digital operation value falls below -32768, the value -32768 is stored.

Setting procedure

1. Set "Scaling enable/disable setting" to "Enable".

 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Application setting] ⇒ [Scaling setting]

2. Set values for "Scaling upper limit value" and "Scaling lower limit value".

Item	Setting range
Scaling upper limit value	-32000 to 32000
Scaling lower limit value	


Point

- Even when the scaling upper limit value and the scaling lower limit value are set so that the change is greater than the resolution, the resolution will not increase.
- If the relation between the values is the scaling lower limit value > the scaling upper limit value, the scale conversion can be performed according to a negative slope.
- Set the scaling with the condition "Scaling upper limit value ≠ Scaling lower limit value".

Setting example

Ex.

When 20000 is set to the scaling upper limit value and 4000 is set to the scaling lower limit value for an A/D converter module with the input range set to 0 to 20mA (current input)




Input current (mA)	Digital output value *1	Digital operation value (scaling value)
0	0	4000
4	6400	7200
8	12800	10400
12	19200	13600
16	25600	16800
20	32000	20000

*1 These values are also applied to the case of digital output values (32 bits).

Ex.

When 20000 is set to the scaling upper limit value and 4000 is set to the scaling lower limit value for an A/D converter module with the input range set to 4 to 20mA (extended mode) (2-wire transmitter input)




Input current (mA)	Digital output value		Digital operation value (scaling value)
	16 bits	32 bits	
0	-8000	-8000	0
4	0	0	4000
8	8000	8000	8000
12	16000	16000	12000
16	24000	24000	16000
20	32000	32000	20000
22	32767*1	36000	22000

*1 Because the value exceeds the range of -32768 to 32767, the value is fixed to 32767 (the upper limit value).

Ex.

When 32000 is set to the scaling upper limit value and -32000 is set to the scaling lower limit value for an A/D converter module with the input range set to 4 to 20mA (extended mode) (2-wire transmitter input)



Current input (mA)	Digital output value		Digital operation value (scaling value)
	16 bits	32 bits	
0	-8000	-8000	-32768 ^{*1}
4	0	0	-32000
8	8000	8000	-16000
12	16000	16000	0
16	24000	24000	16000
20	32000	32000	32000
20.24	32480	32480	32767 ^{*2}
22	32767 ^{*2}	36000	32767 ^{*2}

*1 Because the value falls below the range of -32768 to 32767, the value is fixed to -32768 (the lower limit value).

*2 Because the value exceeds the range of -32768 to 32767, the value is fixed to 32767 (the upper limit value).

Point


When the scaling function is used with the digital clipping function, the scale conversion is performed on the digital operation values after digital clipping.

1.7 Warning Output Function

This section describes process alarms and rate alarms used for the warning output function.

Process alarm

This function outputs a warning when a digital operation value enters the preset warning output range.



Operation

■ Operation performed when a warning is output

When a digital operation value is equal to or greater than 'CH1 Process alarm upper upper limit value' (Un\G514), or the value is equal to or smaller than 'CH1 Process alarm lower lower limit value' (Un\G520) and the value enters the alarm output range, a warning is output as follows.

- Alarm ON (1) is stored in 'Warning output flag (Process alarm upper limit)' (Un\G36) or 'Warning output flag (Process alarm lower limit)' (Un\G37).
- 'Warning output signal' (X8) turns on.
- The ALM LED turns on.

In addition, an alarm code is stored in 'Latest alarm code' (Un\G2).

For details on the alarm codes, refer to the following.

 Page 117 List of Alarm Codes

Point

The A/D conversion on a channel where a warning was output continues.

■ Operation after a warning was output

After a warning was output, if the digital operation value does not satisfy the warning output condition due to being smaller than 'CH1 Process alarm upper lower limit value' (Un\G516) or being greater than 'CH1 Process alarm lower upper limit value' (Un\G518), Normal (0) is stored in a bit position corresponding to the channel number of 'Warning output flag (Process alarm upper limit)' (Un\G36) or 'Warning output flag (Process alarm lower limit)' (Un\G37).

In addition, when all the bits of 'Warning output flag (Process alarm upper limit)' (Un\G36) and 'Warning output flag (Process alarm lower limit)' (Un\G37) return to Normal (0), 'Warning output signal' (X8) turns off and the ALM LED turns off. However, the alarm code stored in 'Latest alarm code' (Un\G2) is not cleared. To clear the alarm code, turn on and off 'Error clear request (YF)' after all the bits of 'Warning output flag (Process alarm upper limit)' (Un\G36) and 'Warning output flag (Process alarm lower limit)' (Un\G37) return to Normal (0).

Detection cycle


When time average is specified, the function works at every interval of the time (for averaging). When count average is specified, the function works at every count (for averaging).

When the sampling processing, moving average, and primary delay filter is specified, this function works at every sampling cycle.

Detection target for outputting a warning

When the digital clipping function, scaling function, shift function, or difference conversion function is used, the digital operation value obtained after digital clipping, scale conversion, shift-and-add, or difference conversion is performed is the detection target for outputting a warning. Set values for 'CH1 Process alarm upper upper limit value' (Un\G514), 'CH1 Process alarm upper lower limit value' (Un\G516), 'CH1 Process alarm lower upper limit value' (Un\G518), and 'CH1 Process alarm lower lower limit value' (Un\G520) while considering the digital clipping, scale conversion, shift-and-add, and difference conversion.

Setting procedure

1. Set "Warning output setting (Process alarm)" to "Enable".
 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Application setting] ⇒ [Warning output function (Process alarm)]
2. Set values for "Process alarm upper upper limit value", "Process alarm upper lower limit value", "Process alarm lower upper limit value", and "Process alarm lower lower limit value".


Item	Setting range
Process alarm upper upper limit value	-32768 to 32767
Process alarm upper lower limit value	
Process alarm lower upper limit value	
Process alarm lower lower limit value	

Point

Set values within the range satisfying the condition "Process alarm upper upper limit value \geq Process alarm upper lower limit value \geq Process alarm lower upper limit value \geq Process alarm lower lower limit value". If a value out of the range is set, a process alarm upper lower limit value setting range error (error code: 1B△□H) occurs.

Rate alarm

This function outputs a warning when the change rate of a digital output value is equal to or greater than the rate alarm upper limit value, or the rate is equal to or smaller than the rate alarm lower limit value.



Operation

■ Operation performed when a warning is output

Digital output values are monitored on the rate alarm warning detection cycle. When a change rate of a digital output value (from a previous value) is equal to or more than the rate alarm upper limit value, or the rate is equal to or less than the rate alarm lower limit value, a warning is output as follows.

- Alarm ON (1) is stored in 'Warning output flag (Rate alarm upper limit)' (Un\G38) or 'Warning output flag (Rate alarm lower limit)' (Un\G39).
- 'Warning output signal' (X8) turns on.
- The ALM LED turns on.

In addition, an alarm code is stored in 'Latest alarm code' (Un\G2).

For details on the alarm codes, refer to the following.

 Page 117 List of Alarm Codes

Point

The A/D conversion on a channel where a warning was output continues.

■ Operation after a warning was output

After a warning was output, if the change rate of a digital output value does not satisfy the warning output conditions due to being smaller than the rate alarm upper limit value or being greater than the rate alarm lower limit value, Normal (0) is stored in a bit position corresponding to the channel number of 'Warning output flag (Rate alarm upper limit)' (Un\G38) or 'Warning output flag (Rate alarm lower limit)' (Un\G39).

In addition, when all 'Warning output flag (Rate alarm upper limit)' (Un\G38) and 'Warning output flag (Rate alarm lower limit)' (Un\G39) return to Normal (0), 'Warning output signal' (X8) turns off and the ALM LED turns off. However, the alarm code stored in 'Latest alarm code' (Un\G2) is not cleared. To clear the alarm code, turn on and off 'Error clear request (YF)' after all the bits of 'Warning output flag (Rate alarm upper limit)' (Un\G38) and 'Warning output flag (Rate alarm lower limit)' (Un\G39) return to Normal (0).

Detection cycle

Set the rate alarm warning detection cycle in 'CH1 Rate alarm warning detection cycle setting' (Un\G522).

The rate alarm warning detection cycle is the value calculated by multiplying the set value by the conversion cycle.

Ex.

The rate alarm warning detection cycle under the following conditions

- A/D conversion-enabled channels: CH1 to CH3
- 'CH1 Rate alarm warning detection cycle setting' (Un\G522): 5 (times)

The rate alarm warning detection cycle is 150ms. (10ms × 3 (CH) × 5 (times))

Digital output values are compared in 150ms intervals to check the change rate.

Judgment of rate alarm

A change rate is judged with 'CH1 Rate alarm upper limit value' (Un\G524) and 'CH1 Rate alarm lower limit value' (Un\G526) converted to digital values per rate alarm warning detection cycle.

The following shows the conversion formula of judgment values used for the rate alarm detection.

$$\text{Value used for judgement at each Rate alarm warning detection cycle [digit]} = \left(\frac{R_H \text{ or } R_L}{1000} \right) \times D_{\text{Max}}$$

Item	Description
R _H	Rate alarm upper limit value (Unit: 0.1%)
R _L	Rate alarm lower limit value (Unit: 0.1%)
D _{Max}	Maximum digital output value of the input range <ul style="list-style-type: none"> • Other than extended mode: 32000 • Extended mode: 36000

Point

Values after the decimal point are omitted.

Ex.

The judgment value under the following conditions

- Input range: 4 to 20mA (2-wire transmitter input)
- A/D conversion-enabled channel: CH1
- 'CH1 Averaging processing specification' (Un\G501): Sampling processing (0)
- 'CH1 Rate alarm warning detection cycle setting' (Un\G522): 5 (times)
- 'CH1 Rate alarm upper limit value' (Un\G524): 250 (25.0%)
- 'CH1 Rate alarm lower limit value' (Un\G526): 50 (5.0%)

$$\text{Upper limit value: } \frac{250}{1000} \times 32000 = 8000 \text{ (digit)}$$

$$\text{Lower limit value: } \frac{50}{1000} \times 32000 = 1600 \text{ (digit)}$$

The present value is compared to the previous value (50ms) in a rate alarm warning detection cycle of 50ms (sampling period 10ms × 5). A digital value is judged if it increases 8000 digits (25.0%) or more, or if the increase is 1600 digits (5.0%) or less from the previous value. (When the maximum digital output value is 32000)

Use the following formula to calculate a change rate to be set based on the change amount of current to detect a warning.

$$\text{Change rate to be set (0.1\%)} = \left(\frac{\text{Change amount (mA) of the current to detect a warning}}{\text{Gain current (mA) - Offset current (mA)}} \times 1000 \right)^{*1}$$

*1 Values after the decimal point are omitted.


Application examples of rate alarms

A rate alarm serves to monitor that the variation rate of a digital output value lies in a limited range as shown below:

Ex.

To monitor that a rising rate of a digital output value is within the specified range


Change rate of the digital output value (%)



Ex.

To monitor that a drop rate of a digital output value is within the specified range


Change rate of the digital output value (%)



Ex.


To monitor that a change rate of a digital output value is within the specified range

Change rate of the digital output value (%)



Setting procedure

1. Set "Warning output setting (Rate alarm)" to "Enable".

 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Application setting] ⇒ [Warning output function (Rate alarm)]

2. Set a warning detection cycle of rate alarms.

Set the cycle in "Rate alarm warning detection cycle setting".

Item	Setting range
Rate alarm warning detection cycle setting	1 to 32000 (times)

Point

In the channel where a value out of the range is set, a rate alarm warning detection cycle setting range error (error code: 1B9□H) occurs.

3. Set values for "Rate alarm upper limit value" and "Rate alarm lower limit value".

Set a value for the maximum value of the digital output value in increments of 0.1%.

- Other than extended mode of the input range: 32000
- Extended mode of the input range: 36000

Item	Setting range
Rate alarm upper limit value	-3276.8 to 3276.7 (%)
Rate alarm lower limit value	


Point

Set values within the range satisfying the condition "Rate alarm upper limit value > Rate alarm lower limit value".

If a value out of the range is set, a rate alarm upper/lower limit setting value inversion error (error code: 1BA□H) occurs.

1.8 Input Signal Error Detection Function

This function outputs an alarm when an analog input value exceeds the preset range.



Point





Errors can be cleared also using 'Input signal error detection auto-clear enable/disable setting' (Un\G302). For details, refer to the following.

Page 41 Clearing input signal errors

Detection method

One of the following detection methods can be selected.

1

Detection method	Detection condition
0: Disable	Input signal errors are not detected.
1: Upper and lower limit detection	<p>An input signal error is detected when the analog input value is equal to or greater than the input signal error detection upper limit value, or when the analog input value is equal to or smaller than the input signal error detection lower limit value.</p> 
2: Lower limit detection	<p>An input signal error is detected when the analog input value is equal to or smaller than the input signal error detection lower limit value.</p> 
3: Upper limit detection	<p>An input signal error is detected when the analog input value is equal to or greater than the input signal error detection upper limit value.</p> 
4: Simple disconnection detection	<p>Simple disconnection detection is performed. For details, refer to the following.  Page 40 Simple disconnection detection</p>


Simple disconnection detection

Outputs an alarm when an analog input value is 2mA or smaller.

By combining this function with the extended mode in the input range setting, simple disconnection detection is enabled.

When an analog input value satisfies either of the following conditions, a disconnection occurs and 'Input signal error detection flag' (Un\G40) turns on.

Input range	Disconnection detection value
4 to 20mA (extended mode) (2-wire transmitter input)	Analog input value \leq 2mA
4 to 20mA (extended mode) (current input)	



The settings for 'CH1 Input signal error detection lower limit set value' (Un\G529) and 'CH1 Input signal error detection upper limit set value' (Un\G530) are ignored.

Notification

When an input signal error is detected, an error is notified as follows.

- Input signal error (1) is stored in the corresponding bit of 'Input signal error detection flag' (Un\G40).
- 'Input signal error detection signal' (XC) turns on.
- The ALM LED flashes.

In addition, an alarm code is stored in 'Latest alarm code' (Un\G2). Alarm codes are stored whenever the analog input satisfies the condition for the input signal error detection.

For details on the alarm codes, refer to the following.

 Page 117 List of Alarm Codes

Operation

On the channel where an error is detected, the last digital output value and digital operation value just before the error was detected are stored.

When the analog input does not satisfy the condition of the input signal error detection, the A/D conversion resumes regardless of the reset on 'Input signal error detection flag' (Un\G40) and 'Input signal error detection signal' (XC). (The ALM LED remains flashing.)

Point

- When an input signal error occurs, the digital output value and digital operation value are not updated.
- The A/D conversion continues on the channel where no Input signal error is detected.
- Whether an input signal error occurred is judged with the value when the first A/D conversion is completed. Thus, the corresponding bit of 'A/D conversion completed flag' (Un\G42) turns on even when an input signal error is detected.

Detection cycle

This function works at every sampling cycle.

Clearing input signal errors

One of the following methods for clearing input signal errors can be selected by setting 'Input signal error detection auto-clear enable/disable setting' (Un\G302).

■When 'Input signal error detection auto-clear enable/disable setting' (Un\G302) is set to Enable (0)

After the analog input value returns within the setting range, the A/D converter module arranges the following status automatically. After the analog input value returns within the setting range, turning on and off 'Error clear request' (YF) is not required.

- 'Input signal error detection flag' (Un\G40) is cleared.
- 'Input signal error detection signal' (XC) turns off.
- The ALM LED turns off.

Point


'Latest alarm code' (Un\G2) is not cleared.

After the analog input value returns within the setting range, turn on and off 'Error clear request' (YF) to clear 'Latest alarm code' (Un\G2).

Ex.

The following figure shows the operation when an analog input value falls below 2.4mA and returns within the normal range under the following condition.

- 'Input signal error detection auto-clear enable/disable setting' (Un\G302): Enable (0)
- Input range: 4 to 20mA
- 'CH1 Input signal error detection setting' (Un\G528): Upper and lower limit detection (1)
- Input signal error detection lower limit value: 2.4mA



■When 'Input signal error detection auto-clear enable/disable setting' (Un\G302) is set to Disable (1)

After the analog input value returns within the set range, turn on and off 'Error clear request' (YF). The A/D converter module arranges the following status when an input signal error is cleared.

- 'Input signal error detection flag' (Un\G40) is cleared.
- 'Input signal error detection signal' (XC) turns off.
- The ALM LED turns off.
- 'Latest alarm code' (Un\G2) is cleared.

Setting the input signal error detection upper or lower limit value

■Input signal error detection upper limit value

Set the input signal error detection upper limit value by 1 (0.1%) based on the input signal error detection upper limit set value. This value is calculated by adding "Analog input range width (Gain value - Offset value) × input signal error detection upper limit set value (%)" to the gain value of each range. Only a value which is equal to or greater than the gain value can be set. To calculate the input signal error detection upper limit set value based on the input signal error detection upper limit value, use the following formula.

$$\text{Input signal error detection upper limit setting value} = \frac{\text{Input signal error detection upper limit value} - \text{Gain value of each range}}{\text{Gain value of each range} - \text{Offset value of each range}} \times 1000$$

■Input signal error detection lower limit value

Set the input signal error detection lower limit value by 1 (0.1%) based on the input signal error detection lower limit set value. This value is calculated by subtracting "Analog input range width (Gain value - Offset value) × Input signal error detection lower limit set value (%)" from the lower limit value of each range. Only the value which is equal to or smaller than the lower limit value of the range can be set.

To calculate the input signal error detection lower limit set value based on the input signal error detection lower limit value, use the following formula.

$$\text{Input signal error detection lower limit setting value} = \frac{\text{Lower limit value of each range} - \text{Input signal error detection lower limit value}}{\text{Gain value of each range} - \text{Offset value of each range}} \times 1000$$

The following table lists the lower limit value, offset value, and gain value for each range.


Input range		Lower limit value	Offset value	Gain value
Current	0 to 20mA	0mA		20mA
	4 to 20mA	4mA		20mA
	4 to 20mA (extended mode)	4mA		20mA
	User range setting	Analog input value set as an offset value		Analog input value set as a gain value

Point

When 'CH1 Input signal error detection setting' (Un\G528) is set to Upper and lower limit detection (1) and the same value is set for 'CH1 Input signal error detection lower limit set value' (Un\G529) and 'CH1 Input signal error detection upper limit set value' (Un\G530), the same operation as the one performed with the following setting can be performed.


- Setting 'CH1 Input signal error detection extension/input signal error detection setting' (Un\G47) to Upper limit value/lower limit value same (0) in the Q compatible mode

For details on the Q compatible mode, refer to the following.

 Page 46 When the function is used in the Q compatible mode

Setting procedure

1. Select a detection method in "Input signal error detection setting".

 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Application setting] ⇒ [Input signal error detection function]

2. Set values for "Input signal error detection lower limit setting value" and "Input signal error detection upper limit setting value".

Item	Setting range
Input signal error detection lower limit setting value	0.0 to 25.0 (%)
Input signal error detection upper limit setting value	

3. Set "Input signal error detection auto-clear enable/disable setting" to "Enable" or "Disable".

Point

In the channel where a value out of the range is set, an input signal error detection setting value range error (error code: 1C1□H) occurs.

Setting example

■ Setting example of the input signal error detection

In the channel where the following values are set, an input error is detected when an analog input value exceeds 21.2mA or falls below 0.4mA.

Item	Setting value
Input range	4 to 20mA
'Input signal error detection auto-clear enable/disable setting' (Un\G302)	Disable (1)
'CH1 Input signal error detection setting' (Un\G528)	Upper and lower limit detection (1)

Assign the following values in a formula to determine the input signal error detection lower limit set value and input signal error detection upper limit set value.

- Input signal error detection lower limit value: 0.4mA
- Input signal error detection upper limit value: 21.2mA
- Offset value: 4.0mA
- Gain value: 20.0mA



For details on the calculation formula, refer to the following.

Page 43 Setting the input signal error detection upper or lower limit value

[Calculation of lower limit value]

$$\begin{aligned} \text{Input signal error detection lower limit} &= \frac{4.0 - 0.4}{20.0 - 4.0} \times 1000 \\ \text{setting value} & \\ &= 225 \text{ (22.5\%)} \end{aligned}$$


Thus, set 'CH1 Input signal error detection lower limit set value' (Un\G529) to 225 (22.5%).

[Calculation of upper limit value]

$$\begin{aligned} \text{Input signal error detection upper limit} &= \frac{21.2 - 20.0}{20.0 - 4.0} \times 1000 \\ \text{setting value} & \\ &= 75 \text{ (7.5\%)} \end{aligned}$$

Thus, set 'CH1 Input signal error detection upper limit set value' (Un\G530) to 75 (7.5%).

The following figure shows the operation of the input signal error detection.



When the function is used in the Q compatible mode

When the input signal error detection function is used in the Q compatible mode, the operation is different from that in the R mode. The following describes only the items that have differences in operation.

Detection condition

An input signal error is detected when the analog input value is equal to or greater than the input signal error detection upper limit value, or when the analog input value is equal to or smaller than the input signal error detection lower limit value.

Detection method

Select a detection method in 'Input signal error detection extension/input signal error detection setting' (Un\G47).

Detection method	Description
0: Upper limit value/ lower limit value same	<p>The input signal error detection upper limit value and input signal error detection lower limit value are calculated from the same input signal error detection setting value.</p> <p>Thus, the same range can be set for A and B in the figure below.</p> <ul style="list-style-type: none"> Input signal error detection setting value: 100 (10%)
1: Upper limit value/ lower limit value different	<p>The input signal error detection upper limit value and input signal error detection lower limit value are calculated from different input signal error detection setting values.</p> <p>Thus, different ranges can be set for A and B in the figure below.</p> <ul style="list-style-type: none"> Input signal error detection setting value for the input signal error detection upper limit value: 100 (10%) Input signal error detection setting value for the input signal error detection lower limit value: 150 (15%)

Point

For details on the input signal error detection upper limit value and input signal error detection lower limit value, refer to the following.

👉 Page 191 CH1 Input signal error detection setting value/lower limit set value [Q compatible mode]

Notification

When an input signal error is detected, an error is notified as follows.

- Input signal error (1) is stored in the corresponding bit of 'Input signal error detection flag' (Un\G49).
- 'Input signal error detection signal' (XC) turns on.
- The corresponding bit of 'A/D conversion completed flag' (Un\G10) turns off.
- The ALM LED flashes.

In addition, an alarm code is stored in 'Latest alarm code' (Un\G3750).

For details on the alarm codes, refer to the following.

 Page 117 List of Alarm Codes

Operation

On the channel where an error is detected, the last digital output value and digital operation value just before the error was detected are stored. Also, the corresponding bit of 'A/D conversion completed flag' (Un\G10) turns off.

When the analog input does not satisfy the condition of the input signal error detection, the A/D conversion resumes regardless of the reset on 'Input signal error detection flag' (Un\G49) and 'Input signal error detection signal' (XC). (The ALM LED remains flashing.)

Clearing input signal errors

One of the following methods for clearing input signal errors can be selected by setting 'Input signal error detection auto-clear enable/disable setting' (Un\G162).

■When 'Input signal error detection auto-clear enable/disable setting' (Un\G162) is set to Enable (0)

After the analog input value returns within the setting range, the A/D converter module arranges the following status automatically. After the analog input value returns within the setting range, turning on and off 'Error clear request' (YF) is not required.

- 'Input signal error detection flag' (Un\G49) is cleared.
- 'Input signal error detection signal' (XC) turns off.
- The ALM LED turns off.

Point


'Latest alarm code' (Un\G3750) is not cleared.

After the analog input value returns within the setting range, turn on and off 'Error clear request' (YF) to clear 'Latest alarm code' (Un\G3750).

Ex.

The following figure shows the operation when an analog input value falls below 2.4mA and returns within the normal range under the following condition.

- 'Input signal error detection auto-clear enable/disable setting' (Un\G162): Enable (0)
- Input range: 4 to 20mA
- 'Input signal error detection extension/input signal error detection setting' (Un\G47): Upper limit value/lower limit value same, Enable (0000H)
- Input signal error detection lower limit value: 2.4mA



■When 'Input signal error detection auto-clear enable/disable setting' (Un\G162) is set to Disable (1)

After the analog input value returns within the set range, turn on and off 'Error clear request' (YF).

The A/D converter module arranges the following status when an input signal error is cleared.

- 'Input signal error detection flag' (Un\G49) is cleared.
- 'Input signal error detection signal' (XC) turns off.
- The ALM LED turns off.
- 'Latest alarm code' (Un\G3750) is cleared.

Setting example

■ Setting example of the input signal error detection

In the channel where the following values are set, an input error is detected when an analog input value exceeds 21.6mA or falls below 0.8mA.


Item	Setting value
Mode	Q compatible mode
Input range	4 to 20mA
'Input signal error detection auto-clear enable/disable setting' (Un\G162)	Disable (1)
'Input signal error detection extension/input signal error detection setting' (Un\G47)	Upper limit value/lower limit value different (1)

Assign the following values in a formula to determine the input signal error detection setting value from the input signal error detection upper limit value and input signal error detection lower limit value.

- Input signal error detection upper limit value: 21.6mA
- Input signal error detection lower limit value: 0.8mA
- Offset value: 4.0mA
- Gain value: 20.0mA

Point

For details on the calculation formula, refer to the following.

 Page 43 Setting the input signal error detection upper or lower limit value

[Calculation of lower limit value]

$$\begin{aligned} \text{Input signal error detection setting value} &= \frac{4.0 - 0.8}{20.0 - 4.0} \times 1000 \\ &= 200 \text{ (20.0\%)} \end{aligned}$$


Thus, set 'CH1 Input signal error detection setting value/CH1 Input signal error detection lower limit set value' (Un\G142) to the determined input signal error detection setting value (200 (20.0%)).

[Calculation of upper limit value]

$$\begin{aligned} \text{Input signal error detection setting value} &= \frac{21.6 - 20.0}{20.0 - 4.0} \times 1000 \\ &= 100 \text{ (10.0\%)} \end{aligned}$$

Thus, set 'CH1 Input signal error detection upper limit setting' (Un\G150) to the determined input signal error detection setting value (100 (10.0%)).

The following figure shows the operation with the determined input signal error detection setting values.



1.9 Shift Function

This function adds (shifts) a set conversion value shift amount to a digital output value and stores the result in the buffer memory area. The digital operation value reflects the change in the conversion value shift amount on a realtime basis. Therefore, fine adjustment can be easily performed when the system starts.

Operation

A set conversion value shift amount is added to the digital operation value. The digital operation value with shift addition is stored in 'CH1 Digital operation value' (Un\G402). The conversion value shift amount is added in every sampling cycle for sampling processing and is added in every averaging processing cycle for averaging processing. After that, the added values are stored in 'CH1 Digital operation value' (Un\G402). If a value is set to the conversion value shift amount, the conversion value shift amount is added regardless of turning on and off 'Operating condition setting request' (Y9).

Setting procedure

Set a value for "Conversion value shift amount".


[Navigation window] ⇨ [Parameter] ⇨ [Module Information] ⇨ Module model name ⇨ [Application setting] ⇨ [Shift function]

Item	Setting range
Conversion value shift amount	-32768 to 32767

Setting example

Ex.

When the I/O characteristics are adjusted in a channel where the input range of 0 to 20mA (current input) is set by the shift function



(1) 'CH1 Digital output value' (Un\G400)
 +
 'CH1 Conversion value shift amount' (Un\G472) "+10"
 ↓
 (2) 'CH1 Digital operation value' (Un\G402)


Current input (mA)	Digital output value*1	Digital operation value
0	-10	0
20	31990	32000

*1 These values are also applied to the case of digital output values (32 bits).

Ex.

When the following values are used for the A/D converter module with the input range of 4 to 20mA (2-wire transmission input)

- 'CH1 Scaling enable/disable setting' (Un\G504): Enable (0)
- 'CH1 Scaling upper limit value' (Un\G506): 12000
- 'CH1 Scaling lower limit value' (Un\G508): 2000
- 'CH1 Conversion value shift amount' (Un\G472): 2000



- (1) 'CH1 Digital output value' (Un\G400)
Scaling
0 to 32000
↓
2000 to 12000
(2) Value after scaling
'CH1 Conversion value shift amount' (Un\G472) "+2000"
↓
(3) 'CH1 Digital operation value' (Un\G402)

Current input (mA)	Digital output value ^{*1}	Value after scaling	Digital operation value
0	0	2000	4000
4	6400	4000	6000
8	12800	6000	8000
12	19200	8000	10000
16	25600	10000	12000
20	32000	12000	14000

*1 These values are also applied to the case of digital output values (32 bits).

Point

When the shift function is used with the digital clipping function and scaling function, shift-and-add is performed on the value obtained after digital clipping and scale conversion. Therefore, the range of the digital operation value is determined as -32768 to 32767.

For a setting example of when the digital clipping function, scaling function, and shift function are used together, refer to the following.

 Page 53 Setting example

1.10 Digital Clipping Function

This function fixes the digital operation value with the maximum digital output value and the minimum digital output value when the corresponding current exceeds the input range.

List of output ranges

The following table lists the output ranges of the digital operation values when the digital clipping function is enabled with each range.

Input range	Output range of digital operation values	
	Digital clipping function is enabled	Digital clipping function is disabled
4 to 20mA (2-wire transmitter input)	0 to 32000	-768 to 32767
4 to 20mA (current input)		
0 to 20mA (current input)		
User range setting (current input)		
User range setting (2-wire transmitter input)		
4 to 20mA (extended mode) (2-wire transmitter input)	-8000 to 32767 ^{*1}	-8768 to 32767
4 to 20mA (extended mode) (current input)		

*1 Since the digital clipping function is effective with the value 36000 (22mA) in the extended mode, the output range is -8000 to 32767.


Point

When the determined digital operation value is out of the range of -32768 to 32767, the digital clipping function is performed to the following values.

- When the digital operation value is 32767 or greater: 32767
- When the digital operation value is -32768 or smaller: -32768

Setting procedure

Set "Digital clipping enable/disable setting" to "Enable".


 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Application setting] ⇒ [Digital clipping function]

Setting example

Ex.

When the following values are used for the A/D converter module with the input range of 4 to 20mA (2-wire transmission input)

- 'CH1 Scaling enable/disable setting' (Un\G504): Enable (0)
- 'CH1 Scaling upper limit value' (Un\G506): 12000
- 'CH1 Scaling lower limit value' (Un\G508): 2000
- 'CH1 Conversion value shift amount' (Un\G472): 2000
- 'CH1 Digital clipping enable/disable setting' (Un\G510): Enable (0)



- (1) 'CH1 Digital output value' (Un\G400)
Digital clipping
-768 to 32767
↓
0 to 32000
- (2) Value after digital clipping
Scaling
0 to 32000
↓
2000 to 12000
- (3) Value after scaling
'CH1 Conversion value shift amount' (Un\G472) "+2000"
↓
4000 to 14000
- (4) 'CH1 Digital operation value' (Un\G402)

Input current (mA)	Digital output value *1	Digital operation value
3.616	-768	4000
4	0	4000
8	8000	6500
12	16000	9000
16	24000	11500
20	32000	14000
20.384	32767	14000

*1 These values are also applied to the case of digital output values (32 bits).


Point

When the digital clipping function is used with the scaling function, shift function, and difference conversion function, scale conversion, shift-and-add, and difference conversion are performed on the value obtained after digital clipping.

1.11 Difference Conversion Function

This function subtracts a difference conversion reference value from a digital operation value and stores the acquired value in the buffer memory area.

The digital operation value at the start of this function is treated as 0 (reference value). Thereafter, values that increased or decreased from the reference value are stored in the buffer memory.



Operation

The digital operation value at the start of the difference conversion (the data stored inside the A/D converter module before the difference conversion starts) is determined as a difference conversion reference value. The value acquired by subtracting the difference conversion reference value from the digital operation value is stored in 'CH1 Digital operation value' (UnG402). At the start of this function, the digital operation value is 0 (because the digital operation value and the difference conversion reference value have the same value at the start).

- Digital operation value after difference conversion = Digital operation value - Difference conversion reference value

Starting the difference conversion

1. Change 'CH1 Difference conversion trigger' (UnG470) from No request (0) to Trigger request (1).

The rise of No request (0) → Trigger request (1) is detected as a trigger. When the trigger is detected, the digital operation value at the start is output to the difference conversion reference value. The value acquired by subtracting the difference conversion reference value from the digital operation value is stored in 'CH1 Digital operation value' (UnG402). After the value is stored, 'CH1 Difference conversion status flag' (UnG408) turns to Converting difference (1).


Stopping the difference conversion

1. Change 'CH1 Difference conversion trigger' (UnG470) from Trigger request (1) to No request (0).

The fall of Trigger request (1) → No request (0) is detected as a trigger. When the trigger is detected, the difference conversion stops, and 'CH1 Difference conversion status flag' (UnG408) turns to Not converted (0). Thereafter, the digital operation value is stored as it is in 'CH1 Digital operation value' (UnG402).


■Operations of when an input signal error occurs

When an input signal error occurs, even if 'CH1 Difference conversion trigger' (Un\G470) changes from No request (0) to Trigger request (1), the difference conversion does not start. After the input signal error returns to the normal value, change 'CH1 Difference conversion trigger' (Un\G470) from No request (0) to Trigger request (1) again. If an input signal error occurs in the status of Trigger request (1), the difference conversion starts at the timing when the input signal error returns to the normal value, treating the digital operation value as the difference conversion reference value.



■ Operations of when 'Operating condition setting request' (Y9) is turned on and off


- During the difference conversion, even when 'Operating condition setting request' (Y9) is turned on and off, the difference conversion continues without updating the difference conversion reference value. To update the difference conversion reference value, restart the difference conversion by changing 'CH1 Difference conversion trigger' (Un\G470) from Trigger request (1) to No request (0), and Trigger request (1) again.
- 'CH1 Difference conversion trigger' (Un\G470) does not become valid even when the trigger changes from No request (0) to Trigger request (1) when 'Operating condition setting request' (Y9) is turned on. After turning on and off 'Operating condition setting request' (Y9), change 'CH1 Difference conversion trigger' (Un\G470) from No request (0) to Trigger request (1) again.



■ Operations of CH1 Maximum value (Un\G404) and CH1 Minimum value (Un\G406)

When the difference conversion starts, the maximum value and the minimum value of the values acquired by the difference conversion are stored in 'CH1 Maximum value' (Un\G404) and 'CH1 Minimum value' (Un\G406). By turning on 'Maximum value/minimum value reset request' (YD), the maximum value and the minimum value after the start of the difference conversion can be checked.

When 'Maximum value/minimum value reset request' (YD) is not turned on, the maximum values and minimum values before and after difference conversion are mixed.



■ Operation of when the averaging processing is set

If the difference conversion starts after the averaging processing is set, the digital operation value at the completed of the averaging processing is determined as 'CH1 Difference conversion reference value' (Un\G432). 'CH1 Difference conversion status flag' (Un\G408) turns to Converting difference (1).

Point

- The difference conversion function can be started at any timing.
- When the difference conversion function is used with the digital clipping function, scaling function, and shift function, each digital operation value is determined as a difference conversion reference value and used for the difference conversion.
- Even though the digital clipping function, scaling function, and shift function are enabled during the difference conversion, the value in 'CH1 Difference conversion reference value' (Un\G432) is not updated. To update the value in 'CH1 Difference conversion reference value' (Un\G432), stop the difference conversion and restart it again.

1.12 Maximum Value/Minimum Value Hold Function

This function stores the maximum and minimum values of digital operation values in the buffer memory area for each channel. Time average and count average are processed on the averaging processing cycle. The values of the sampling processing, moving average, and primary delay filter are updated on the sampling cycle.

Resetting the maximum value and the minimum value

Turn on and off 'Maximum value/minimum value reset request' (YD) or 'Operating condition setting request' (Y9) to update the maximum value and minimum value with the current value.

Turning on 'Maximum value/minimum value reset request' (YD) turns on 'Maximum value/minimum value reset completed flag' (XD).

Values to be the maximum value and the minimum value

The maximum and minimum values of digital operation values are stored in the buffer memory.

When the digital clipping function, scaling function, shift function, or difference conversion function is used, the maximum value and minimum value of each function are stored.

Point

Even while A/D conversion is stopped, the maximum value and minimum value can be reset.

However, because the values when A/D conversion is stopped are held in the digital operation values, when 'Maximum value/minimum value reset request' (YD) is turned on and off, the maximum value and minimum value are updated with the held values.

1.13 External Power Supply Interruption Detection Function

This function detects the state in which 24VDC from the external power supply is not supplied or is stopped.

When an external power supply interruption is detected, 'External power supply READY flag' (X6) turns off, and for the 2-wire transmitter range, A/D conversion processing and power supply requirements for 2-wire transmitter are not performed. (A/D conversion processing for the current input range not using the 2-wire transmitter is performed.)

Operation

When 200ms passes after an input from the external power supply, 'External power supply READY flag' (X6) turns on.

When there is no input from the external power supply, or when 200ms does not pass after an input from the external power supply, it is judged as a state of external power supply interruption and 'External power supply READY flag' (X6) turns off.

When an input from the external power supply stops, it is judged as a state of external power supply interruption and 'External power supply READY flag' (X6) turns off.


Point

- When 'External power supply READY flag' (X6) is off, A/D conversion for the 2-wire transmitter range stops and 'A/D conversion completed flag' (XE) turns off.
- Even if there is a channel where A/D conversion is not performed because the external power supply is off, the conversion cycle does not change.

Precautions

If the external power supply does not satisfy the requirements of the performance specifications, it may be judged as a state of external power supply interruption.

For details on the performance specifications for the external power supply, refer to the following.

 MELSEC iQ-R Channel Isolated Analog-Digital Converter Module (With Signal Conditioning Function) User's Manual (Startup)

1.14 Supply Power Temporary Stop Function

This function temporarily stops power supply requirements for 2-wire transmitter and A/D conversion for each channel. This function makes it possible to replace the 2-wire transmitter safely while keeping A/D conversion for other channels running.


It is enabled only for a channel set to the 2-wire transmission range.

Operation

■Channel set to the 2-wire transmission range


While 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (Un\G473) is set to Trigger request (1), the power supply requirements for 2-wire transmitter is stopped and A/D conversion stops. In this case, 'CH1 Supply power temporary stop status flag (for 2-wire transmitter)' (Un\G412) is changed to Temporarily stopped (1).

When 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (Un\G473) is set to No request (0), a supply power output to the 2-wire transmitter starts, and after the warm-up time set in 'CH1 Conversion start time setting (for 2-wire transmitter)' (Un\G532) passes, A/D conversion starts. When a supply power output to the 2-wire transmitter starts, 'CH1 Supply power temporary stop status flag (for 2-wire transmitter)' (Un\G412) is changed to Not stopped (0).



Ex.


When 'Operating condition setting request' (Y9) is turned on and off while 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (UnG473) is set to Trigger request (1)



(1) Because 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (UnG473) is set to Trigger request (1), the supply power to the 2-wire transmitter is not turned on.

Ex.

When 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (Un\G473) is changed to Trigger request (1) while 'Operating condition setting request' (Y9) is being turned on and off



(1) Because 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (Un\G473) is set to Trigger request (1) while 'Operating condition setting request' (Y9) is on, the supply power to the 2-wire transmitter is turned off.

Point

- When the supply power is temporarily stopped, A/D conversion stops and 'A/D conversion completed flag' (Un\G42) turns off. When A/D conversion is stopped, 'CH1 Digital output value' (Un\G400) and 'CH1 Digital operation value' (Un\G402) are held.
- Even if there is a channel where A/D conversion is not performed because the external power supply is temporarily turned off, the conversion cycle does not change.
- When the external power supply is off, regardless of the setting of 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (Un\G473), the supply power to the 2-wire transmitter turns off, and A/D conversion stops as well.
- Note that when the system is powered off and on, 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (Un\G473) turns to the default value of No request (0), a state in which a supply power can be output to the 2-wire transmitter. To temporarily stop the supply power, after starting the module, set 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (Un\G473) to Trigger request (1).

Channel set to the current input range

The setting of 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (Un\G473) is ignored.

Precautions

When the supply power temporary stop function stops and restarts A/D conversion for a channel where averaging processing is set, the updating of digital output values resumes when the values used for averaging processing are all acquired.

1.15 Logging Function

This function logs (records) digital output values or digital operation values. Data of 1000 points can be logged for each channel. Logging data are stored in the buffer memory area. In addition, the data collection can be stopped by using the status change of the data as a trigger. This function also helps the error analysis since the data before and after the occurrence of an error is held.

Using function blocks (FBs) enables saving the data stored in the buffer memory as a CSV file.


Logging function

■Collecting logging data

Logging data is collected as follows.

- 1000 points of the latest digital output values or digital operation values can be always collected for each channel.
- The data can be collected at intervals of 10ms at a minimum and of 3600s at a maximum.

An address where the latest/oldest data is stored can be checked with the latest/head pointer.



Logging data are stored in the buffer memory area. When the number of stored data points is 1001 or greater, data is sequentially overwritten from address 0 with new data.


■Stopping the logging operation

The logging data is refreshed at high speed during logging. Stop logging when the logging data needs to be referred without paying attention to the refreshing cycle.

Logging can be stopped by the hold trigger.

- A hold trigger allows two options: Logging hold request or Level trigger.
- The number of data points to be collected after a hold trigger occurs can be set.

Logging data are stored in buffer memory areas.



■Saving logging data into a CSV file


The data in 'CH1 Logging data' (Un\G10000 to Un\G10999) disappears when the module is powered off. However, the data can be saved in a CSV file by using function blocks (FBs).

Operation of logging

■ Starting logging data collection

Logging data collection starts when 'CH1 Logging enable/disable setting' (Un\G535) is set to Enable (0) and 'Operating condition setting request' (Y9) is turned on and off.

The data in 'CH1 Digital output value' (Un\G400) or 'CH1 Digital operation value' (Un\G402) is stored in 'CH1 Logging data' (Un\G10000 to Un\G10999) on the set logging cycle. The data in 'CH1 Digital output value (32 bits)' (Un\G410, Un\G411) cannot be logged.



■ Logging data

Logging data are stored in the following buffer memory areas.

When the number of stored data points is 10001 or greater, the data is overwritten with new data from the head of the storage area of the corresponding channel.

Channel	Storage area for logging data
CH1	Un\G10000 to Un\G10999
CH2	Un\G11000 to Un\G11999
CH3	Un\G12000 to Un\G12999
CH4	Un\G13000 to Un\G13999
CH5	Un\G14000 to Un\G14999
CH6	Un\G15000 to Un\G15999

If logging has been performed even once, all the logging data above are cleared to 0 at the timing when 'Operating condition setting request' (Y9) is turned on.

Logging data setting

Select a data type to be collected with 'CH1 Logging data setting' (Un\G536).

- Digital output value (0)
- Digital operation value (1)

Logging cycle

■Logging cycle setting

Set the logging cycle with 'CH1 Logging cycle setting value' (Un\G537) and 'CH1 Logging cycle unit setting' (Un\G538). The following table lists the setting range for each cycle.

Setting value of CH1 Logging cycle unit setting	Setting range of CH1 Logging cycle setting value
ms (1)	10 to 32767
s (2)	1 to 3600

The logging cycle must be an integral multiple of the conversion cycle. Even if the setting is not an integral multiple, the actual logging cycle is adjusted to the integral multiple of the conversion cycle within a limit of the set logging cycle.

The following table lists the conversion cycle for each A/D conversion method.

Conversion method	Conversion cycle
Sampling processing	Number of conversion enabled channels × Conversion speed
Time average	$\left(\frac{\text{Time set in Time average} / \text{Count average} / \text{Moving average} / \text{Primary delay filter constant setting}}{\text{Number of conversion enabled channels} \times \text{Conversion speed}} \right)^{*1} \times \text{Number of conversion enabled channels} \times \text{Conversion speed}$
Count average	(The count set to CH1 Time average/Count average/Moving average/Primary delay filter constant setting (Un\G502)) × (Number of conversion enabled channels × Conversion speed)
Moving average	Number of conversion enabled channels × Conversion speed
Primary delay filter	Number of conversion enabled channels × Conversion speed

*1 Values after the decimal point are omitted.

Ex.

With the following settings, the conversion cycle is 60ms and the actual logging cycle is every 6960ms (integral multiple of 60ms).

- Conversion enabled channel: CH1 to CH6
- Conversion processing specification: Sampling processing
- 'CH1 Logging cycle setting value' (Un\G537): 7000
- Logging cycle unit setting: ms

The following values are stored in 'CH1 Logging cycle monitored value' (Un\G441, Un\G442).

Address	Item	Stored value
441	CH1 Logging cycle monitored value	s
442		ms
		6
		960

■When the logging function becomes disabled

The logging is not performed when even one of the following errors occurs after the logging function is enabled and 'Operating condition setting request' (Y9) is turned on and off.

- Error code (192□H to 195□H): Setting errors of 'CH1 Time average/Count average/Moving average/Primary delay filter constant setting' (Un\G502)
- Error code (1D0□H to 1D6□H): Setting errors of the logging function
- Error code (1D8□H to 1D9□H): Setting errors of the logging read function


Point

When 'Operating condition setting request' (Y9) is turned on and off on the condition that the logging cycle determined by 'CH1 Logging cycle setting value' (Un\G537) and 'CH1 Logging cycle unit setting' (Un\G538) is shorter than the conversion cycle, an error occurs and logging does not start. A logging cycle setting disable error (error code: 1D2□H) is stored in 'Latest error code' (Un\G0), and 'Error flag' (XF) and the ERR LED turn on.


■Number of logging data

With 'CH1 Number of logging data' (Un\G436), the number of valid data points in 'CH1 Logging data' (Un\G10000 to Un\G10999) can be checked.

When the number of collected data points is less than 1000



When the number of collected data points is 1001 or greater



The number of logging data increases by one each time new data is stored.


When 'CH1 Logging data' (Un\G10000 to Un\G10999) becomes full (Number of logging data = 1000), the next data is stored in the start address of 'CH1 Logging data' (Un\G10000 to Un\G10999), and the logging operation continues overwriting the existing data. In this case, the number of logging data is fixed to 1000.

■Head pointer and latest pointer


The storage locations of the oldest data and the latest data in 'CH1 Logging data' (Un\G10000 to Un\G10999) can be checked with the following buffer memory areas.

Buffer memory area	Description
'CH1 Head pointer' (Un\G434)	The buffer memory address of the oldest data in 'CH1 Logging data' (Un\G10000 to Un\G10999) can be checked with this buffer memory area. The offset value (0 to 999) counted from the start address of 'CH1 Logging data' (Un\G10000 to Un\G10999) is stored.
'CH1 Latest pointer' (Un\G435)	The buffer memory address of the latest data in 'CH1 Logging data' (Un\G10000 to Un\G10999) can be checked with this buffer memory area. The offset value (0 to 999) counted from the start address of 'CH1 Logging data' (Un\G10000 to Un\G10999) is stored.

When the number of collected data points is less than 1000



When the number of collected data points is 1001 or greater



'CH1 Head pointer' (Un\G434) does not change until 'CH1 Logging data' (Un\G10000 to Un\G10999) becomes full after the logging start. (Fixed to 0)

'CH1 Head pointer' (Un\G434) moves by one point when 'CH1 Logging data' (Un\G10000 to Un\G10999) becomes full and overwriting the data starts from the start address.

■Checking logging data without stopping the logging operation

Logging data can be checked during the logging operation with 'CH1 Head pointer' (Un\G434), 'CH1 Latest pointer' (Un\G435), and 'CH1 Number of logging data' (Un\G436).

To check logging data during logging operation, follow the precautions below because logging data may be refreshed while data is being read out.

- Set the cycle to 'CH1 Logging cycle setting value' (Un\G537) so that data checking and reading surely complete before logging data is refreshed. If the logging cycle is short, logging data may be refreshed during data checking and reading.
- After obtaining the logging data which needs to be checked, monitor the variation of 'CH1 Head pointer' (Un\G434) or 'CH1 Number of logging data' (Un\G436), and obtain logging data just after the stored value has changed.
- If the data refreshed and the data being checked do not synchronize due to the relationship between the logging cycle and the scan time of the CPU module, adjust the logging cycle.

Stop the logging operation when the logging data needs to be checked without paying attention to the logging cycle. (☞
Page 68 Stopping the logging operation)

Stopping the logging operation

Logging operation stops (holds) when the preset trigger condition is satisfied and the set points of the data are collected.


A trigger that is generated when the condition is satisfied is called a hold trigger.

To generate a hold trigger, the following two methods are available.

☞ Page 71 Logging hold request

☞ Page 72 Level trigger

When a hold trigger is detected during data collection, the logging operation stops after the points of the data set in 'CH1 Post-trigger logging points' (Un\G539) are collected.



Post-trigger logging points

Set the number of data collected in the period from the detection of a hold trigger to logging operation stop to 'CH1 Post-trigger logging points' (Un\G539).

Checking that the logging has stopped

Check that 'CH1 Logging hold flag' (Un\G409) is ON (1).


Checking data when a hold trigger has occurred

The storage location of the data when a hold trigger has occurred can be checked with 'CH1 Trigger pointer' (Un\G437). The offset value counted from the start address of 'CH1 Logging data' (Un\G10000 to Un\G10999) is stored in 'CH1 Trigger pointer' (Un\G437).

Ex.

The value stored in 'CH1 Trigger pointer' (Un\G437) when the logging operation stops under the following conditions

- 'CH1 Post-trigger logging points' (Un\G539): 655 points
- The data location where a hold trigger has occurred: 350th data



Checking the trigger generation time

The trigger generation time can be checked with 'CH1 Trigger generation time' (Un\G444 to Un\G448).

Ex.

When 'CH1 Trigger generation time' (Un\G444 to Un\G448) is monitored

	b15	...	b8	b7	...	b0
'CH1 Trigger generation time (First/Last two digits of the year)' (Un\G444)	First two digits of the year			Last two digits of the year		
'CH1 Trigger generation time (Month/Day)' (Un\G445)	Month			Day		
'CH1 Trigger generation time (Hour/Minute)' (Un\G446)	Hour			Minute		
'CH1 Trigger generation time (Second/Day of the week)' (Un\G447)	Second			Day of the week		
'CH1 Trigger generation time (Millisecond)' (Un\G448)	Millisecond (higher-order digits)			Millisecond (lower-order digits)		


- First two digits of the year, last two digits of the year, month, day, hour, minute, second, and millisecond are all stored in the BCD code.
- In the day of the week segment, one of the following values in the BCD code indicating the corresponding day is stored. Sunday: 00H, Monday: 01H, Tuesday: 02H, Wednesday: 03H, Thursday: 04H, Friday: 05H, Saturday: 06H

Resuming the logging


It may take time until ON (1) is stored in 'CH1 Logging hold flag' (Un\G409) after 'CH1 Logging hold request' (Un\G471) is changed from off to on.

To resume logging, check that ON (1) is stored in 'CH1 Logging hold flag' (Un\G409) and change 'CH1 Logging hold request' (Un\G471) from on to off. After logging resumes, the value is stored from the head buffer memory area of 'CH1 Logging data' (Un\G10000 to Un\G10999).

In addition, OFF (0) is stored in 'CH1 Logging hold flag' (Un\G409).



Logging does not stop when 'CH1 Logging hold request' (Un\G471) is changed from on to off before ON (1) is stored in 'CH1 Logging hold flag' (Un\G409).



■ Buffer memory area status when logging resumes


The following table shows the buffer memory area status when logging resumes.

Buffer memory area	Value status
'CH1 Head pointer' (Un\G434)	Values are initialized.
'CH1 Latest pointer' (Un\G435)	
'CH1 Number of logging data' (Un\G436)	
'CH1 Trigger pointer' (Un\G437)	
'CH1 Trigger generation time' (Un\G444 to Un\G448)	
'CH1 Logging data' (Un\G10000 to Un\G10999)	The values before logging resumes are not initialized. After logging resumes, values are stored from the start address of 'CH1 Logging data' (Un\G10000 to Un\G10999). To refer to the logging data, check which area has valid data with 'CH1 Number of logging data' (Un\G436).

Logging hold request

A hold trigger is generated from a program at any timing.

Logging starts when ON (1) is set to 'CH1 Logging hold request' (Un\G471) and stops after a preset number of the data is collected.



Point

- The following delay time occurs until the A/D converter module receives a hold trigger after the value in 'CH1 Logging hold request' (Un\G471) is changed from OFF (0) to ON (1).
Trigger delay = Logging cycle (Cycle at which logging is actually performed) + Scan time of the CPU module
- When 'CH1 Logging hold request' (Un\G471) is changed from ON (1) to OFF (0) before 'CH1 Logging hold flag' (Un\G409) turns to ON (1), the data set in 'CH1 Post-trigger logging points' (Un\G539) is not held after logging, and logging resumes soon.
- If a value other than OFF (0) and ON (1) is set to 'CH1 Logging hold request' (Un\G471), an error occurs. A logging hold request range error (error code: 1D7□H) is stored in 'Latest error code' (Un\G0), and 'Error flag' (XF) and the ERR LED turn on.

Checking that the logging has stopped

Check that 'CH1 Logging hold flag' (Un\G409) is ON (1).

Point

To refer to the logging data from the CPU module, hold (stop) the logging operation and check that ON (1) is stored in 'CH1 Logging hold flag' (Un\G409).

Level trigger

When a value in the monitored buffer memory area of the A/D converter module satisfies a preset condition, a hold trigger is generated.

A level trigger is monitored on the refreshing cycle of the digital output value or the digital operation value.

Initial setting of a level trigger

■ Setting a target to be monitored

As a condition to generate a hold trigger, set the buffer memory address to be monitored to 'CH1 Trigger data' (Un\G541).

Item	Setting range
'CH1 Trigger data' (Un\G541)	0 to 9999

To monitor a device value of a module other than the A/D converter module such as a device of the CPU module, set as follows.

- Set a value between 90 and 99 (Level data□ (Un\G90 to Un\G99)) to 'CH1 Trigger data' (Un\G541).
- Write a value of the monitored device to Level data□ (Un\G90 to Un\G99) by using the MOV instruction.

Item	Setting range
Level data□ (Un\G90 to Un\G99)	-32768 to 32767

Ex.

Application example of Level data□ (Un\G90 to Un\G99)

To monitor the data register D100 in the CPU module and operate the level trigger in CH1, create a program as follows.


1. Set 91 (buffer memory address of Level data 1) to 'CH1 Trigger data' (Un\G541). (When Level data 1 is used)
2. Store the storage data of D100 in 'Level data 1' (Un\G91) by the program continuously.

Point

Specify appropriate data such as 'CH1 Digital output value' (Un\G400), 'CH1 Digital operation value' (Un\G402), or Level data□ (Un\G90 to Un\G99) to 'CH1 Trigger data' (Un\G541). When a setting area or a system area is specified, the normal operation is not guaranteed.

■Setting the monitoring condition

Set a condition to generate a hold trigger in 'CH1 Level trigger condition setting' (Un\G540).



(a) A hold trigger is generated when the relation between the values changes from "Stored value of a buffer memory area to be monitored \leq Trigger setting value" to "Stored value of a buffer memory area to be monitored $>$ Trigger setting value".

(b) A hold trigger is generated when the relation between the values changes from "Stored value of a buffer memory area to be monitored \geq Trigger setting value" to "Stored value of a buffer memory area to be monitored $<$ Trigger setting value".


Setting value	Description
Rise (1)	A hold trigger is generated under the condition (a).
Fall (2)	A hold trigger is generated under the condition (b).
Rise and fall (3)	A hold trigger is generated under the condition (a) or (b).

Set a value where a hold trigger is generated to 'CH1 Trigger setting value' (Un\G542).

Item	Setting range
'CH1 Trigger setting value' (Un\G542)	-32768 to 32767

Point

The following figure shows the relation between setting items to be configured for the initial setting of a level trigger.




To generate a hold trigger when a value in 'CH1 Digital output value' (Un\G400) is greater than 10000, set as follows.

- 'CH1 Level trigger condition setting' (Un\G540): Rise (1)
- 'CH1 Trigger data' (Un\G541): 400
- 'CH1 Trigger setting value' (Un\G542): 10000

Operation of a level trigger


To use a level trigger, set ON (1) to 'CH1 Logging hold request' (Un\G471) in advance. At the point where ON (1) has been set to 'CH1 Logging hold request' (Un\G471), the module becomes the trigger condition wait status.

Data collection starts when the trigger condition has been satisfied, and stops when the set points of the data have been collected.



Point

A level trigger is detected on the refreshing cycle of the digital output value or the digital operation value. Therefore, the data when a hold trigger is generated may not be stored in 'CH1 Logging data' (Un\G10000 to Un\G10999) depending on the setting of the logging cycle. To store the data at the timing when a hold trigger is generated in 'CH1 Logging data' (Un\G10000 to Un\G10999), arrange related settings so that the conversion cycle of the monitoring target value (trigger data) and the logging cycle (actual logging cycle) have the same time period.



(1) The data at the timing when a trigger is generated is not stored in the buffer memory area.

- To refer to the logging data from the CPU module, hold (stop) the logging operation and check that ON (1) is stored in 'CH1 Logging hold flag' (Un\G409).

■Checking that the logging has stopped



Check that 'CH1 Logging hold flag' (Un\G409) is ON (1).

Initial settings of the logging function

The following describes the initial setting procedure to use the logging function.

1

Setting procedure

1. Set "A/D conversion enable/disable setting" to "A/D conversion enable".
 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Basic setting] ⇒ [A/D conversion enable/disable setting function]
2. Set "Logging enable/disable setting" to "Enable".
 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Application setting] ⇒ [Logging function]
3. Set the target data to be logged in "Logging data setting". Set either "Digital output value" or "Digital operation value" for each channel.
4. Set the cycle to store the logging data to "Logging cycle setting value".
5. Select a unit of the logging cycle setting value in "Logging cycle unit setting".
6. Set a condition to generate a hold trigger in "Level trigger condition setting". To use 'CH1 Logging hold request' (Un\G471), set "Disable". To use the level trigger, set "Level trigger (condition: Rise)", "Level trigger (condition: Fall)", or "Level trigger (condition: Rise and fall)".
7. Set a number of the data points to be collected for the time period from the occurrence of a hold trigger to logging stop in "Post-trigger logging points".
8. Set a buffer memory address to be monitored with a level trigger to "Trigger data".
9. Set whether to enable or disable the logging read function in "Read interrupt enable/disable setting"
10. Set a level where a level trigger operates for "Trigger setting value".

Logging read function

This function makes it possible to store more than 1000 points of logging data without stopping logging by transferring the device data to the file register of the CPU module during logging. This function reduces the takt time in a test demanding high-speed conversion.

Overview of the logging read function

After logging starts, an interrupt request is sent to the CPU module and an interrupt program is executed every time the preset number of data to be read is logged.

The A/D converter module has 16 points of the interrupt factor (SI) corresponding to the logging reading of each channel. For the setting of interrupt pointers, refer to the following.

☞ Page 76 Setting interrupt pointers

Setting interrupt pointers

Assign the interrupt factors (SI) of the A/D converter module and interrupt pointers of the CPU module using the interrupt pointer setting of the engineering tool.

The interrupt function must be set when the logging read function is used.

Starting the logging read function

To use the logging read function, set 'CH1 Loading interrupt enable/disable setting' (Un\G544) to Enable (0) and set a number of logging points to generate an interrupt in 'CH1 Logging read points setting value' (Un\G545). This function starts when 'Operating condition setting request' (Y9) is turned on and off.

■The number of logging read points

Set a value whose integral multiple is 1000 in 'CH1 Logging read points setting value' (Un\G545). The setting range is from 1 to 1000.

When a value whose integral multiple is not 1000 is set, the number of the actual logging read points is forced to become a maximum value whose integral multiple is 1000 within the set value. The value of the number of logging read points is stored in 'CH1 Logging read points monitored value' (Un\G440).

Logging read points setting value	Logging read points monitored value
100	100
90	50
110	100
650	500
400	250

Data checking method

■Current logging read pointer

- The head pointer read from 'CH1 Logging data' (Un\G10000 to Un\G10999) with the interrupt processing is stored in 'CH1 Current logging read pointer' (Un\G438).
- The default value of 'CH1 Current logging read pointer' (Un\G438) is -1.
- Every time the same number of data as the value stored in 'CH1 Logging read points monitored value' (Un\G440) is logged, a value calculated by the following formula is stored in 'CH1 Current logging read pointer' (Un\G438).

CH1 Current logging read pointer = CH1 Latest pointer - CH1 Logging read points monitored value + 1

■Previous logging read pointer

- 'CH1 Current logging read pointer' (Un\G438) at the timing when the previous read pointer detection interrupt occurs is stored in 'CH1 Previous logging read pointer' (Un\G439).
- The default value of 'CH1 Previous logging read pointer' (Un\G439) is -1.
- 'CH1 Previous logging read pointer' (Un\G439) is used to detect the overlap of the logging read pointer detection interrupt processing.

Ex.

The values to be stored in each pointer at every detection interrupt when the logging read detection starts with 'CH1 Logging read points setting value' (Un\G545) being set to 100

Occurrence of read pointer detection interrupts	Previous logging read pointer	Current logging read pointer	Latest pointer	Relative address	Buffer memory area
Default value	-1	-1	0	0	1st data
First time	-1	0	99	99	100th data
Second time	0	100	199	199	200th data
Third time	100	200	299	299	300th data
⋮	⋮	⋮	⋮	⋮	⋮
10th time	800	900	999	999	1000th data
11th time	900	0	99	99	100th data
12th time	0	100	199	199	200th data


Operation

The logging read function starts by setting interrupt pointers and turning on and off 'Operating condition setting request' (Y9). This function repeats its operation every time the same number of data as the logging read points monitored value is logged.

Ex.

The following figure shows the operation when the logging read function is used under the following conditions.

- A/D conversion-enabled channel: CH1
- 'CH1 Logging read points setting value' (Un\G545): 100 points



- (1) The timing that the first interrupt processing occurs
- (2) The timing that the second interrupt processing occurs
- (3) The timing that the third interrupt processing occurs

Setting procedure

To use the logging read function, both the logging read function and the interrupt setting must be set.

1. Set "Condition target setting" to "Logging read".

[Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Interrupt setting]

2. Set "A/D conversion enable/disable setting" to "A/D conversion enable".

[Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Basic setting] ⇒ [A/D conversion enable/disable setting]

3. Set "Logging enable/disable setting" to "Enable".

[Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Application setting] ⇒ [Logging function]

4. Set the target data to be logged in "Logging data setting".

5. Set the cycle to store the logging data to "Logging cycle setting value".

6. Set "Read interrupt enable/disable setting" to "Enable".

7. Set the number of logging points that generate a read interrupt in "Logging read points setting value".

Setting example


Ex.

When an interrupt program that is executed when the data of CH1 Logging read points monitored value is logged is assigned to the interrupt pointer I50

• Label settings

Classification	Label name	Description	Device																																													
Module Label	RCPU.stSM.bAlways_ON	Always ON	SM400																																													
	RCPU.stSM.bAfter_RUN1_Scan_ON	ON for one scan after RUN	SM402																																													
	R60ADDG_1.unInterruptFactorMask_D[0].0	Interrupt factor mask [1]	U0\G124																																													
	R60ADDG_1.unInterruptFactorDetectionFlag_D[0].0	Interrupt factor detection flag [1]	U0\G4																																													
	R60ADDG_1.unInterruptFactorResetRequest_D[0].0	Interrupt factor reset request [1]	U0\G156																																													
	R60ADDG_1.stnMonitor_D[0].wThisLoggingLoadPointer_D	CH1 Current logging read pointer	U0\G438																																													
	R60ADDG_1.stnMonitor_D[0].uLoggingLoadPointsMonitorValue_D	CH1 Logging read points monitored value	U0\G440																																													
Label to be defined	Define global labels as shown below:																																															
	<table border="1"> <thead> <tr> <th></th> <th>Label Name</th> <th>Data Type</th> <th>Class</th> <th>Assign (Device/Label)</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>G_uLoggingReadPoints</td> <td>Word [Unsigned]/Bit String [16-bit]</td> <td>VAR_GLOBAL</td> <td>D10</td> </tr> <tr> <td>2</td> <td>G_udLoggingReadPointsTemporary</td> <td>Double Word [Unsigned]/Bit String [32-bit]</td> <td>VAR_GLOBAL</td> <td>D12</td> </tr> <tr> <td>3</td> <td>G_udWritePosition</td> <td>Double Word [Unsigned]/Bit String [32-bit]</td> <td>VAR_GLOBAL</td> <td>D20</td> </tr> <tr> <td>4</td> <td>G_udSaveFileRegisterMaxValue</td> <td>Double Word [Unsigned]/Bit String [32-bit]</td> <td>VAR_GLOBAL</td> <td>D30</td> </tr> <tr> <td>5</td> <td>G_wThisTimeLoggingReadPointIndex</td> <td>Word [Signed]</td> <td>VAR_GLOBAL</td> <td>Z0</td> </tr> <tr> <td>6</td> <td>G_udWritePositionIndex</td> <td>Double Word [Unsigned]/Bit String [32-bit]</td> <td>VAR_GLOBAL</td> <td>Z4</td> </tr> <tr> <td>7</td> <td>G_wLoggingReadMonitorValuePlusIndex</td> <td>Word [Signed]</td> <td>VAR_GLOBAL</td> <td>U0\G1000Z0</td> </tr> <tr> <td>8</td> <td>G_wSaveFileRegisterPlusIndex</td> <td>Word [Signed]</td> <td>VAR_GLOBAL_RETAIN</td> <td>ZR0ZZ4</td> </tr> </tbody> </table>		Label Name	Data Type	Class	Assign (Device/Label)	1	G_uLoggingReadPoints	Word [Unsigned]/Bit String [16-bit]	VAR_GLOBAL	D10	2	G_udLoggingReadPointsTemporary	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	D12	3	G_udWritePosition	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	D20	4	G_udSaveFileRegisterMaxValue	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	D30	5	G_wThisTimeLoggingReadPointIndex	Word [Signed]	VAR_GLOBAL	Z0	6	G_udWritePositionIndex	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	Z4	7	G_wLoggingReadMonitorValuePlusIndex	Word [Signed]	VAR_GLOBAL	U0\G1000Z0	8	G_wSaveFileRegisterPlusIndex	Word [Signed]	VAR_GLOBAL_RETAIN	ZR0ZZ4		
	Label Name	Data Type	Class	Assign (Device/Label)																																												
1	G_uLoggingReadPoints	Word [Unsigned]/Bit String [16-bit]	VAR_GLOBAL	D10																																												
2	G_udLoggingReadPointsTemporary	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	D12																																												
3	G_udWritePosition	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	D20																																												
4	G_udSaveFileRegisterMaxValue	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	D30																																												
5	G_wThisTimeLoggingReadPointIndex	Word [Signed]	VAR_GLOBAL	Z0																																												
6	G_udWritePositionIndex	Double Word [Unsigned]/Bit String [32-bit]	VAR_GLOBAL	Z4																																												
7	G_wLoggingReadMonitorValuePlusIndex	Word [Signed]	VAR_GLOBAL	U0\G1000Z0																																												
8	G_wSaveFileRegisterPlusIndex	Word [Signed]	VAR_GLOBAL_RETAIN	ZR0ZZ4																																												
	Set the class of 'G_wSaveFileRegisterPlusIndex' to VAR_GLOBAL_RETAIN. If the class is set to VAR_GLOBAL, the program operates normally. However, if the option in global label consistency check is set to "Yes", a conversion error occurs.																																															
	"Tool" ⇒ "Options" ⇒ "Convert" ⇒ "Basic Setting" ⇒ "Operational Setting" ⇒ "Check the Consistency of Global Label"																																															

• Program example



(0) Enable only the interrupt pointer I50.

Initialize the variable for storing the logging read points monitor value (word [unsigned]) and the write position of the save destination file register.

Set the maximum number of stored save destination file registers.

Clear 'Interrupt factor mask [1]' (U0\G124).

(18)	D>_U	G_udSaveFileRegisterMaxValue D30	G_udWritePosition D20	MOV	R60ADDG_1.stnMonitor_D [0].wThisLoggingLoadPointer_D U0\G438	G_wThisTimeLoggingReadPointIndex Z0	
				MOV	R60ADDG_1.stnMonitor_D [0].uLoggingLoadPointsMonitorValue_D U0\G440	G_uLoggingReadPoints D10	
				DMOV	G_udWritePosition D20	G_udWritePositionIndex Z4	
				BMOV	G_wLoggingReadMonitorValuePlusIndex U0\G10000Z0	G_wSaveFileRegisterPlusIndex ZR0ZZ4	G_uLoggingReadPoints D10
				UINT2UDINT	G_uLoggingReadPoints D10	G_udLoggingReadPointsTemporary D12	
				D+_U	G_udLoggingReadPointsTemporary D12	G_udWritePosition D20	

(18) Store 'CH1 Current logging read pointer' (U0\G438) in the index register.

Store 'CH1 Logging read points monitored value' (U0\G440) in the register.

Store the write position of the save destination file register in the index register.

Store 'CH1 Logging data' (U0\G10000 to U0\G10999) for the logging read points monitored value in the save destination file register.

Add the points of the logging read points monitored value to the write position of the save destination file register and store the obtained value as the write position for the next logging.



(45) Turn on 'Interrupt factor reset request [1]' (U0\G156) when 'Interrupt factor detection flag [1]' (U0\G4) turns on.

Saving to a CSV file

The logging data stored in the buffer memory areas can be saved to a CSV file by using function blocks (FBs). The save data is sorted in a time series, where the logging data can be easily checked.

However, function blocks (FBs) can be executed only when the logging operation is stopped. During the logging operation, the execution of function blocks (FBs) is disabled.

Saving a CSV file

To save a CSV file, an SD memory card is required.

CSV files are saved in an SD memory card installed in the CPU module. CSV files cannot be saved in the built-in memory of the CPU module.

Saving procedure

1. Check that ON (1) is stored in 'CH1 Logging hold flag' (Un\G409).
2. Execute the function block (FB).


Point

If the execution state of the function block (FB) is maintained, logging data can be saved in the CSV file every time logging stops.

Data to be saved in a CSV file

The logging data stored in the buffer memory areas is saved.

For how to check the logging data, refer to the following.

 Page 69 Checking data when a hold trigger has occurred

CSV file name

CSV files saved with the function block (FB) are named as follows.

AD□□△△○○○.CSV

Object
CH

Consecutive numbers*1

First two digits of the start I/O number of the A/D converter module (expressed in four hexadecimal digits)

*1 The maximum number of the consecutive numbers can be set with the input label i_Max_Number (maximum number of saving files) of the function block (FB).

Ex.

The file name under the following condition is AD4506006.CSV.

- Start I/O number of the A/D converter module: 0450H
- Target channel: 6
- Saving to a CSV file: 6th time

Displaying logging data

The CSV file output with the logging function can be displayed graphically by reading the file through GX LogViewer. For how to display the logging data with GX LogViewer, refer to the following.

 GX LogViewer Version 1 Operating Manual

1.16 Interrupt Function

This function executes an interrupt program of the CPU module when an interrupt factor such as an input signal error or warning output is detected.

For the A/D converter module, the maximum number of interrupt pointers available is 16 per module.

Operation

■Detecting an interrupt factor


When an interrupt factor occurs, an interrupt request is sent to the CPU module at the same time as 'Interrupt factor detection flag [n]' (Un\G4 to Un\G19) is turned to Interrupt factor (1).

■How to reset an interrupt factor

When Reset request (1) is set to 'Interrupt factor reset request [n]' (Un\G156 to Un\G171) corresponding to the interrupt factor, the specified interrupt factor is reset and 'Interrupt factor detection flag [n]' (Un\G4 to Un\G19) changes to No interrupt factor (0).

Setting procedure

To use the interrupt function, set "Condition target setting", "Condition target channel setting", "Interrupt factor transaction setting", and "Interrupt pointer" in the engineering tool. After completing the settings, write the project to enable the settings.

 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Interrupt setting]


The following table shows the setting items on the interrupt setting window.

Item	Description
Condition target setting	Select a factor of the target for the interrupt detection.
Condition target channel setting	Select a target channel when the condition target setting for the interrupt detection is channel specification.
Interrupt factor transaction setting	Set an interrupt request for when the same interrupt factor occurs during the interrupt factor detection.
Interrupt pointer	Specify the number of an interrupt pointer that is initiated at the detection of an interrupt factor.

■Condition target setting

Select a factor of the condition target setting for the interrupt detection.


For details on the factors to be detected, refer to the following.

 Page 157 Condition target setting [n]

■Condition target channel setting

Select a target channel when the condition target setting for the interrupt detection is channel specification.

For details on the settings, refer to the following.

 Page 158 Condition target channel setting [n]


■Interrupt factor transaction setting

Set an interrupt request for when the same interrupt factor occurs during the interrupt factor detection.

- With "Interrupt reissue requests (0)", if the same interrupt factor occurs during the interrupt factor detection, an interrupt request is sent to the CPU module again.
- With "No interrupt reissue request (1)", if the same interrupt factor occurs during the interrupt factor detection, an interrupt request is not sent to the CPU module.

■Interrupt pointer

Specify the number of an interrupt pointer that is initiated at the detection of an interrupt factor. For details on the interrupt pointers, refer to the following.

 MELSEC iQ-R CPU Module User's Manual (Application)

- If 'Condition target setting [n]' (Un\G232 to Un\G247) is Disable (0), an interrupt request is not sent to the CPU module.
- To reset the interrupt factor, set Reset request (1) until 'Interrupt factor detection flag [n]' (Un\G4 to Un\G19) changes to No interrupt factor (0).
- Resetting interrupt factors is executed only when 'Interrupt factor reset request [n]' (Un\G156 to Un\G171) changes from No reset request (0) to Reset request (1).
- Multiple interrupt pointers can also share the same setting of 'Condition target setting [n]' (Un\G232 to Un\G247). When interrupts with the same settings occur in 'Condition target setting [n]' (Un\G232 to Un\G247), the interrupt program is executed in order of the priority of the interrupt pointers. For the priority of the interrupt pointers, refer to the following.

📖 MELSEC iQ-R CPU Module User's Manual (Application)

- When All channels (0) is set for 'Condition target channel setting [n]' (Un\G264 to Un\G279) and an interrupt detection target is set for each channel of 'Condition target setting [n]' (Un\G232 to Un\G247), the interrupt requests that have the same interrupt factor are sent to the CPU module if warnings are issued in multiple channels. In this case, the CPU module executes multiple interrupt programs and judges that the program cannot be normally finished due to the scan monitoring function of the CPU module, and a CPU module error may occur. When a CPU error occurs, refer to the following.

📖 MELSEC iQ-R CPU Module User's Manual (Application)

Setting example

Ex.

If the interrupt program (I51) is executed when an error occurs in any channel

- Parameter setting

Set "Interrupt setting" as follows.

No.	Condition target setting	Condition target channel setting	Interrupt pointer
2	Error flag	All channels	I51


- Label settings

Classification	Label name	Description	Device
Module Label	RCPU.stSM.bAlways_ON	Always ON	SM400
	RCPU.stSM.bAfter_RUN1_Scan_ON	ON for one scan after RUN	SM402
	R60ADDG_1.unInterruptFactorMask_D[1].0	Interrupt factor mask [2]	U0\G125.0
	R60ADDG_1.unInterruptFactorResetRequest_D[1].0	Interrupt factor reset request [2]	U0\G157.0

Label to be defined

Define global labels as shown below:

	Label Name	Data Type	Class	Assign (Device/Label)
1	G_b_ErrorDetection	Bit	VAR_GLOBAL	F0



- (0) Enable only the interrupt pointer I51.
- (10) Turn on 'Interrupt factor reset request [2]' (U0\G157). Performs the processing of when an error is detected.

1.17 Error History Function

This function records errors and alarms that occurred in the A/D converter module to store them into the buffer memory area. Up to 16 errors and alarms are stored.

Operation

When an error occurs, the error code and the error time are stored from 'Error history 1' (Un\G3600 to Un\G3609) in order.

When an alarm occurs, the alarm code and the alarm time are stored from 'Alarm history 1' (Un\G3760 to Un\G3769) in order.

- Detail of the error code assignment

	b15	...	b8 b7	...	b0
Un\G3600	Error code				
Un\G3601	First two digits of the year		Last two digits of the year		
Un\G3602	Month		Day		
Un\G3603	Hour		Minute		
Un\G3604	Second		Day of the week		
Un\G3605	Millisecond (higher-order digits)		Millisecond (lower-order digits)		
Un\G3606	System area				
:					
:					
Un\G3609					

- Detail of the alarm code assignment

	b15	...	b8 b7	...	b0
Un\G3760	Alarm code				
Un\G3761	First two digits of the year		Last two digits of the year		
Un\G3762	Month		Day		
Un\G3763	Hour		Minute		
Un\G3764	Second		Day of the week		
Un\G3765	Millisecond (higher-order digits)		Millisecond (lower-order digits)		
Un\G3766	System area				
:					
:					
Un\G3769					

Ex.

Storing example of error history and alarm history

Item	Description	Storage example*1
First two digits of the year/Last two digits of the year	Stored in BCD code.	2015H
Month/Day		131H
Hour/Minute		1234H
Second		56H
Day of the week	One of the following values is stored in BCD code. Sunday: 0, Monday: 1, Tuesday: 2, Wednesday: 3 Thursday: 4, Friday: 5, Saturday: 6	6H
Millisecond (upper)	Stored in BCD code.	7H
Millisecond (lower)		89H

*1 Values stored when an error occurs at 12:34:56.789 on Saturday, January 31st, 2015.


The start address of Error history where the latest error is stored can be checked in 'Latest address of error history' (Un\G1).

The start address of Alarm history where the latest alarm is stored can be checked in 'Latest address of alarm history' (Un\G3).

Ex.

When the third error occurs:


The third error is stored in Error history 3, and the value 3620 (start address of Error history 3) is stored to 'Latest address of error history' (Un\G1).



Ex.

When the 17th error occurs:

The 17th error is stored in Error history 1, and the value 3600 (start address of Error history 1) is stored to 'Latest address of error history' (Un\G1).

**Point**

- Once the error history storage area becomes full, subsequent error information will overwrite the existing data, starting from 'Error history 1' (Un\G3600 to Un\G3609), and continues sequentially thereafter. The histories to be overwritten are deleted.
- The same processing is performed for Alarm history when an alarm occurs.
- The stored error history is cleared when the A/D converter module is powered off, or when the CPU module is reset.

1.18 Module Event History Collection Function

This function collects generated errors, alarms or executed operations in the A/D converter module as event information in the CPU module.


The CPU module collects the event information caused in the A/D converter module and keeps them in the data memory inside of the CPU module or an SD memory card.

The event information collected by the CPU module can be displayed on an engineering tool to check the occurrence history in a time series.

Event type	Classification	Description
System	Error	Self-diagnostics error detected in each module
	Warning	Warning (alarm) detected in each module
	Information	Operation normally detected by the system not classified as an error or a warning, or operation performed automatically by the system
Security	Warning	Operation that is judged as an unauthorized access to each module.
	Information	Operation that could not be judged as a successful unlock of a password or unauthorized access
Operation	Warning	Among operations performed on modules, delete operation (data clear) that is not judged as an error by self-diagnostics but likely to change the behavior
	Information	Operations performed by users to change the system operation or configuration in the offset/gain setting.

Setting procedure

The event history function can be set from the event history setting window of the engineering tool. For the setting method, refer to the following.

 MELSEC iQ-R CPU Module User's Manual (Application)

Displaying event history

Access to the menu window of the engineering tool. For details on the operating procedure and how to view the contents, refer to the following.

 GX Works3 Operating Manual

List of event history data

The following table lists the events that would occur in the A/D converter module when the event type is set to "Operation"

Event code	Event classification	Event name	Description	Additional information
20010	Information	Offset/gain setting execution	In the user range setting, offset/gain values have been set.	Total number of writes
20100	Information	Error clear	Error clear request has been issued.	—

1.19 Backing up, Saving, and Restoring Offset/Gain Values

The A/D converter module is capable of backing up, saving, and restoring offset/gain values of the user range setting.

- Back up: Creates a module-specific backup parameter and saves offset/gain values.
- Save: Saves the offset/gain information, registered in this module by making the offset/gain setting, in the CPU module.
- Restoration: Writes the information backed up and saved in the CPU module to this module.

In the event that the A/D converter module fails and needs to be replaced, the offset/gain values of the failed A/D converter module can be restored onto the new A/D converter module.

However, if the offset/gain values are saved and restored, the accuracy after the restoration decreases by approximately three times compared to that before the restoration. Reconfigure the offset/gain setting when required.


Only when the model where the offset/gain values are to be saved and the model where the offset/gain values are to be restored are the same, the offset/gain values can be saved and restored.

Each procedure differs depending on whether a module-specific backup parameter is used or not.

When the module-specific backup parameter is used

Offset/gain values are automatically restored when the failed module is replaced with a new one using the online module change.

For details on the online module change, refer to the following.

 MELSEC iQ-R Online Module Change Manual

Details of the module-specific backup parameter

A module-specific backup parameter is a file created in an SD memory card or the data memory of the control CPU. The contents of the parameter are the offset/gain value of the user range stored in the flash memory of the A/D converter module. The file name of a module-specific backup parameter is determined as follows based on the start I/O number of the A/D converter module.

UBPmmmn.BPR

- mmm indicates a value calculated by dividing the module I/O No. by 10H (3 digits in hexadecimal).
- nn indicates a consecutive number of the module-specific backup parameters for each module and is fixed to 00.

Creating and updating a module-specific backup parameter

A module-specific backup parameter is created or updated when the offset/gain values stored in the flash memory of the A/D converter module are updated.

Timing when backup data is created or updated	Description
When the offset/gain setting is completed with "Offset/gain setting" of the engineering tool	A module-specific backup parameter is created or updated when the offset/gain setting is completed with "Offset/gain setting" of the engineering tool.
When 'User range write request' (YA) is turned on in the offset/gain setting mode	A module-specific backup parameter is created or updated when the offset/gain values of the user range are changed in the offset/gain setting mode.
When 'User range write request' (YA) is turned on in the normal mode	When 'User range write request' (YA) is turned on in the normal mode, the offset/gain values of the user range are restored based on the settings of the buffer memory areas (CH1 Factory default setting offset value (L) to CH6 User range setting gain value (H)). At this timing, module-specific backup parameters are updated.
When the G(P).OGSTOR instruction is executed in the normal mode	When the G(P).OGSTOR instruction is executed in the normal mode, the offset/gain values of the user range are restored. At this timing, module-specific backup parameters are updated.
When a new module is recognized after the online module change	When a new module is mounted and recognized after the online module change, the offset/gain values of the user range are restored. At this timing, module-specific backup parameters are updated.


When no module-specific backup parameter exists in the data memory of the control CPU and a module-specific backup parameter needs to be created with the current setting, change the mode of the A/D converter module to the offset/gain setting mode and turn on 'User range write request' (YA). A module-specific backup parameter is created with the current setting of the flash memory.

■Precautions

- If the creation of a module-specific backup parameter fails because the data memory of the control CPU does not have sufficient free space or the module-specific backup parameter is being used, a module-specific backup parameter creation error (error code: 17E1H) occurs.
- When the mode switches from the offset/gain setting mode to the normal mode, A/D conversion does not start (the state becomes A/D conversion disabled internally). Because the values set in the buffer memory do not change before and after mode switching, operation is performed with the previous settings by turning on and off 'Operating condition setting request' (Y9).

Reading of module-specific backup parameters

To read a module-specific backup parameter and restore offset/gain values, set "Auto restore of Offset/gain setting with the module change" to "Enable" in advance.

 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Application setting] ⇒ [Online module change]

■Read timing

Module-specific backup parameters are read when a new module is mounted and recognized after the online module change. When the programmable controller is powered off and the module is replaced with a new one, module-specific backup parameters are not read.

■Precautions

When the module-specific backup parameter for the target slot does not exist in an SD memory card or the data memory of the control CPU, the subsequent restoration of the offset/gain values is not performed. If the offset/gain values cannot be restored even though the module-specific backup parameter exists, a module-specific backup parameter restore error (error code: 17E0H) occurs.

Restoration of the offset/gain values of the user range

When the reading of module-specific backup parameters is completed with no errors, the values are converted (restored) into the offset/gain values of the user range for the new module, and stored in the flash memory. At the same timing, the module-specific backup parameter in the data memory of the control CPU is updated with the setting of the new module.

Restrictions on the module-specific backup parameter

Offset/gain values cannot be backed up or restored with a module-specific backup parameter in the following cases.

- When the control CPU is not the process CPU
- When the programmable controller is powered off and the A/D converter module is replaced with a new one
- When "Auto restore of Offset/gain setting with the module change" is set to "Disable"

In any of the cases above, back up or restore offset/gain values by the following method.

 Page 95 When the module-specific backup parameter is not used


When the module-specific backup parameter is not used

Back up or restore offset/gain values by one of the following methods.


- Saving and restoring by dedicated instructions
- Saving and restoring by reading from and writing to the buffer memory

With the method above, offset/gain values can be restored to a new module, or the offset/gain values set in one module can be applied to the other modules in the same system.


- To restore offset/gain values onto a new replaced module:



1. Save offset/gain values.



2. Power off the programmable controller, and replace the A/D converter module with a new one.




3. Restore the offset/gain values.


- To apply the offset/gain values set in one module to the other modules in the same system:

Ex.

When the offset/gain values in module No.1 are applied to modules No.2 to No.4



1. Save the offset/gain values in module No.1.



2. Apply the offset/gain values to modules No.2 to No.4

Saving and restoring by dedicated instructions

Use the dedicated instruction G(P).OGLoad to temporarily save the offset/gain values of the source A/D converter module to the internal device of the CPU, then use G(P).OGStor to write the values to the destination A/D converter module.

Prevent the saved offset/gain setting data from being deleted, by one of the following methods before replacing the modules:

- Use latch settings for the internal device of the destination module.
- Save the data onto an SD memory card. (To write data: use the SP.FWRITE instruction. To read data: use the SP.FREAD instruction.)
- Store the saved data.

For use of dedicated instructions, refer to the following.

 MELSEC iQ-R Programming Manual (Module Dedicated Instructions)

Saving and restoring by reading from and writing to the buffer memory

Use CH1 Factory default setting offset value (L) to CH6 User range setting gain value (H) and 'User range write request' (YA) to read the offset/gain values from the source A/D converter module. Use the buffer memory again to write the values to the destination A/D converter module.

The following describes the procedure for using the buffer memory.

■To restore offset/gain values onto a new replaced module:

- When restoring offset/gain values onto the source A/D converter module
 1. Turn on and off 'Operating condition setting request' (Y9).
 2. Save the stored values of CH1 Factory default setting offset value (L) to CH6 User range setting gain value (H).
- When the power of the module is off
 3. Replace the A/D converter module.
- When restoring offset/gain values onto the source A/D converter module
 4. Write the data saved in CH1 Factory default setting offset value (L) to CH6 User range setting gain value (H).
 5. Turn on 'User range write request' (YA).
 6. Check that 'Offset/gain setting mode status flag' (XA) is on.
 7. Turn off 'User range write request (YA)'.
 8. Check whether the destination A/D converter module operates with the offset/gain values that are restored.

Point

When replacing modules, prevent the saved offset/gain setting data from being deleted, by one of the following methods before powering off the module.

- Use latch settings for the internal device of the destination module.
- Save the data onto an SD memory card. (To write data: use the SP.FWRITE instruction. To read data: use the SP.FREAD instruction.)
- Store the saved data.

■To apply the offset/gain values set in one module to the other modules in the same system:

- When restoring offset/gain values onto the source A/D converter module
 1. Turn on and off 'Operating condition setting request' (Y9).
 2. Save the stored values of CH1 Factory default setting offset value (L) to CH6 User range setting gain value (H).
- When restoring offset/gain values onto the destination A/D converter module
 3. Write the data saved in CH1 Factory default setting offset value (L) to CH6 User range setting gain value (H).
 4. Turn on 'User range write request' (YA).
 5. Check that 'Offset/gain setting mode status flag' (XA) is on.
 6. Turn off 'User range write request (YA)'.
 7. Check whether the destination A/D converter module operates with the offset/gain values that are restored.

Range reference table

The following describes the range reference tables used for saving and restoring offset/gain values.

■Factory default setting

The following describes the buffer memory addresses of the factory default setting.

'CH1 Factory default setting offset value (L)' (Un\G4004) to 'CH6 Factory default setting gain value (H)' (Un\G4027)

Address (decimal)						Description	Range type	Analog value	Reference value (hexadecimal)
CH1	CH2	CH3	CH4	CH5	CH6				
4004	4008	4012	4016	4020	4024	Factory default setting offset value	Current	0mA	801AF7H
4005	4009	4013	4017	4021	4025				
4006	4010	4014	4018	4022	4026	Factory default setting gain value	Current	20mA	D45FE9H
4007	4011	4015	4019	4023	4027				

■User range setting

The following describes the buffer memory addresses of the user range setting.

'CH1 User range setting offset value (L)' (Un\G4028) to 'CH6 User range setting gain value (H)' (Un\G4051)

Address (decimal)						Description	Range type	Analog value	Reference value (hexadecimal)
CH1	CH2	CH3	CH4	CH5	CH6				
4028	4032	4036	4040	4044	4048	User range setting offset value	Current	4mA	90F58DH
4029	4033	4037	4041	4045	4049				
4030	4034	4038	4042	4046	4050	User range setting gain value	Current	20mA	D45FE9H
4031	4035	4039	4043	4047	4051				

1.20 Q Compatible Mode Function

This function allows setting the buffer memory addresses of the A/D converter module same as the buffer memory addresses of the MELSEC-Q series.

This compatibility makes it possible to reuse sequence programs that have exhibited high performance on the MELSEC-Q series modules.

The following table lists the compatible modules of the MELSEC-Q series.

A/D converter module of the MELSEC iQ-R series	Compatible A/D converter module
R60AD6-DG	Q66AD-DG

Operation

Only the buffer memory assignment is changed in the Q compatible mode.

- The I/O signal assignment is the same as that of the R mode. Some signals have been changed. However, the signals that change the module operation maintain the compatibility. Therefore, when a MELSEC-Q series sequence program is diverted, a significant modification of the sequence program is not required. The following table shows a difference between the R60AD6-DG and Q66AD-DG.


Device number	R60AD6-DG	Q66AD-DG
X7	Use prohibited	High resolution mode status flag (ON: High resolution mode, OFF: Normal resolution mode)

Point

- When a MELSEC-Q series sequence program is diverted, check digital output values and the operation timing and modify the sequence program if necessary because the specifications such as the resolution and update timing are changed.
- When a MELSEC-Q series sequence program is diverted and an error code is set as the operating condition or interlock condition, the program does not operate normally.
- When the Q compatible mode function is enabled, a program that uses FB or labels cannot be created. When FB or labels is used, create a program in the R mode.

Setting procedure

1. When adding a new module, select the module whose module name has "(Q)" at the end.

 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Right-click ⇒ [Add New Module]

2. Configure the same parameter setting as the one of when the R mode is used.
3. Restart the CPU module after the module parameter is written.

Point

- During the module operation, the mode cannot be switched between the R mode and Q compatible mode.
- The project of the compatible A/D converter module created by GX Works2 can be read with the other format read function of GX Works3. The read project keeps various settings of the compatible A/D converter module as the settings of the A/D converter module of the MELSEC iQ-R series. The settings to be kept are the switch setting, parameter setting, auto refresh setting, and I/O assignment setting.

2 PARAMETER SETTINGS

Set the parameters of each channel.

Setting parameters here eliminates the need to program them.

2.1 Parameter Setting Procedure

1. Add an A/D converter module to the engineering tool.

[Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Right-click ⇒ [Add New Module]

2. There are four types of parameter setting: basic setting, application setting, interrupt setting, and refresh setting. Choose the desired type from the tree in the following window to set parameters.

[Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Select the A/D converter module.

3. Use the engineering tool to write the settings to the CPU module.

[Online] ⇒ [Write to PLC]

4. Reset the CPU module or turn off and on the power to apply the settings.

2.2 Basic Setting

Setting procedure

Open "Basic setting" of the engineering tool.

1. Start Module Parameter.

[Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Basic setting]

Setting Item	CH1	CH2	CH3	CH4	CH5	CH6
Range switching function	The input range of the analog input can be set for each channel and the input conversion attribute can be set.					
Input range setting	4 to 20mA (for 2-wire) 4 to 20mA (for 2-wire) 4 to 20mA (for 2-wire) 4 to 20mA (for 2-wire) 4 to 20mA (for 2-wire) 4 to 20mA (for 2-wire)					
Operation mode setting function	The two operation modes, "Normal mode" to execute the normal A/D conversion and "Offset/gain setting" to execute the offset/gain setting.					
Operation mode setting	Normal mode (A/D conversion process)					
A/D conversion enable/disable setting function	Set whether to enable or disable the output of the A/D conversion value.					
A/D conversion enable/disable setting	A/D conversion enable A/D conversion disable A/D conversion enable A/D conversion disable A/D conversion enable A/D conversion disable					
A/D conversion method	Set the A/D conversion control method.					
Average processing setting	Sampling process! Sampling process! Sampling process! Sampling process! Sampling process! Sampling processing					
Time average/Count average/Moving average/	0	0	0	0	0	0
Conversion starting time setting function	Set the time necessary from when the used 2-wire transmitter powers on until its output stabilizes.					
Conversion starting time setting (for 2-wire transmitter)	3.0 s	3.0 s	3.0 s	3.0 s	3.0 s	3.0 s

2. Click the item to be changed to enter the setting value.

- Item where a value is selected from the pull-down list

Click [▼] button of the item to be set, and from the pull-down list that appears, select the value.

- Item where a value is entered into the text box

Double-click the item to be set to enter the numeric value.

2.3 Application Setting

Setting procedure

Open "Application setting" of the engineering tool.

1. Start Module Parameter.

[Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Module model name ⇒ [Application setting]

Setting Item	CH1	CH2	CH3	CH4	CH5	CH6
Scaling function	Configure the setting for the scaling at the A/D conversion.					
Scaling enable/disable setting	Disable	Disable	Disable	Disable	Disable	Disable
Scaling upper limit value	0	0	0	0	0	0
Scaling lower limit value	0	0	0	0	0	0
Shift function	Configure the setting for the shift function at the A/D conversion.					
Conversion value shift	0	0	0	0	0	0
Digital clipping function	Configure the setting for the digital clipping function at the A/D conversion.					
Digitalclip enable/disable setting	Disable	Disable	Disable	Disable	Disable	Disable
Warning output function (Process alarm)	Set an alert at the A/D conversion.					
Warning output setting (Process alarm)	Disable	Disable	Disable	Disable	Disable	Disable
Process alarm upper upper limit value	0	0	0	0	0	0
Process alarm upper lower limit value	0	0	0	0	0	0
Process alarm lower upper limit value	0	0	0	0	0	0
Process alarm lower lower limit value	0	0	0	0	0	0
Warning output function (Rate alarm)	Set an alert at the A/D conversion.					
Warning output setting (Rate alarm)	Disable	Disable	Disable	Disable	Disable	Disable
Rate alarm detection cycle setting	0 times	0 times	0 times	0 times	0 times	0 times
Rate alarm upper limit value	0.0 %	0.0 %	0.0 %	0.0 %	0.0 %	0.0 %
Rate alarm lower limit value	0.0 %	0.0 %	0.0 %	0.0 %	0.0 %	0.0 %
Input signal error detection function	Configure the setting for the input signal at the A/D conversion.					
Input signal error detection setting	Disable	Disable	Disable	Disable	Disable	Disable
Input signal error detection lower limit setting value	5.0 %	5.0 %	5.0 %	5.0 %	5.0 %	5.0 %
Input signal error detection upper limit setting value	5.0 %	5.0 %	5.0 %	5.0 %	5.0 %	5.0 %
Input signal error detection auto clear enable/disable setting	Disable	Disable	Disable	Disable	Disable	Disable
Logging function	Configure the setting for the logging function at the A/D conversion.					
Logging enable/disable setting	Disable	Disable	Disable	Disable	Disable	Disable
Logging data setting	Digital operation	Digital operation	Digital operation	Digital operation	Digital operation	Digital operation value
Logging cycle setting value	60 ms	60 ms	60 ms	60 ms	60 ms	60 ms
Logging cycle unit setting	ms	ms	ms	ms	ms	ms
Level trigger condition setting	Disable	Disable	Disable	Disable	Disable	Disable
Logging points after trigger	500	500	500	500	500	500
Trigger data	402	602	802	1002	1202	1402
Trigger setting value	0	0	0	0	0	0
Logging read enable/disable setting	Disable	Disable	Disable	Disable	Disable	Disable
Logging read points setting value	100	100	100	100	100	100
Online module change	The module can be changed without the system being stopped.					
Auto restore of Offset/ gain setting with the module change	Enable	Enable	Enable	Enable	Enable	Enable

2. Click the item to be changed to enter the setting value.

- Item where a value is selected from the pull-down list

Click [▼] button of the item to be set, and from the pull-down list that appears, select the value.

- Item where a value is entered into the text box


Double-click the item to be set to enter the numeric value.

2.4 Interrupt Setting

Setting procedure

Open "Interrupt setting" of the engineering tool.

1. Start Module Parameter.

 [Navigation window] ⇨ [Parameter] ⇨ [Module Information] ⇨ Module model name ⇨ [Interrupt setting]

No.	Condition target setting	Condition target channel setting	Interrupt factor transaction setting	Interrupt pointer
1	Disable	All CH specification	Interrupt reissue requests	
2	Disable	All CH specification	Interrupt reissue requests	
3	Disable	All CH specification	Interrupt reissue requests	
4	Disable	All CH specification	Interrupt reissue requests	
5	Disable	All CH specification	Interrupt reissue requests	
6	Disable	All CH specification	Interrupt reissue requests	
7	Disable	All CH specification	Interrupt reissue requests	
8	Disable	All CH specification	Interrupt reissue requests	
9	Disable	All CH specification	Interrupt reissue requests	
10	Disable	All CH specification	Interrupt reissue requests	
11	Disable	All CH specification	Interrupt reissue requests	
12	Disable	All CH specification	Interrupt reissue requests	
13	Disable	All CH specification	Interrupt reissue requests	
14	Disable	All CH specification	Interrupt reissue requests	
15	Disable	All CH specification	Interrupt reissue requests	
16	Disable	All CH specification	Interrupt reissue requests	

2. Click the interrupt setting number (No.1 to 16) to be changed to enter the setting value.

- Item where a value is selected from the pull-down list

Click [▼] button of the item to be set, and from the pull-down list that appears, select the value.

- Item where a value is entered into the text box

Double-click the item to be set to enter the numeric value.

2.5 Refresh Setting


Setting procedure

Set the buffer memory area of the A/D converter module to be refreshed.

This refresh setting eliminates the need for reading/writing data by programming.

1. Start Module Parameter.

 [Navigation window] ⇨ [Parameter] ⇨ [Module Information] ⇨ Module model name ⇨ [Refresh settings]



Item	CH1	CH2	CH3	CH4	CH5	CH6
Refresh at the set timing:						
Transfer to the intelligent function module.	Transfer the buffer memory data to the specified device.					
Transfer to the CPU.	Transfer the buffer memory data to the specified device.					
Refresh Timing	Set refresh timing.					
Refresh Timing	At the Execution Time of END Instruction					
Refresh Group [n](n: 1-64)	1					
Refresh Timing (I/O)	Specify the timing which transfers the I/O device data.					
Refresh Timing	Based on Refresh Timing (Buffer Memory)					

2. Click "Target", and set the auto refresh destination.

- When "Refresh Destination" is "Module Label"

Set whether to enable or disable the refresh by setting "Level data 0" to Enable or Disable.

- When "Refresh Destination" is "Refresh Data Register (RD)"

The transfer destinations of all items are automatically set by setting the start device to "Top Device Name".

- When "Refresh Destination" is "Specified Device"

Double-click the item to be set to enter the refresh destination device.

3. Click "Refresh Timing" to set the timing to refresh.

Set "Refresh Timing" to "At the Execution Time of END Instruction" or "At the Execution Time of Specified Program".


When "At the Execution Time of Specified Program" is set, double-click "Refresh Group [n](n: 1-64)" and set a value of 1 to 64.

Point

When the refresh is enabled, the values of the refresh destination are enabled at the refresh timing set with the engineering tool. At this time, the buffer memory areas are overwritten with the values of the refresh destination. To change the value in the refresh target buffer memory area, create a program to change the module label of the refresh destination and the device value.

Refresh processing time

The refresh processing time [μs] is a constituent of the scan time of the CPU module. For details on the scan time, refer to the following.

 MELSEC iQ-R CPU Module User's Manual (Application)

The refresh processing time [μs], which is taken for refresh, is given by:

- Refresh processing time [μs] = Refresh read time (time for transferring refresh data to the CPU module) + Refresh write time (time for transferring refresh data to the intelligent function module)

The refresh read time and refresh write time vary depending on the settings of "Target".


When "Target" is "Module Label" or "Refresh Data Register (RD)"

The following table shows the refresh read time and refresh write time with an R□CPU used.

Model	Classification	When using the refresh settings
R60AD6-DG	Refresh read time	23.14 μs
	Refresh write time	13.44 μs
R60AD6-DG (Q compatible mode)	Refresh read time	24.96 μs
	Refresh write time	11.70 μs

When "Target" is "Device"

Calculate the refresh read time and refresh write time according to the number of items and the number of their transfer data (in units of word) that are set to be refreshed. For the calculation method, refer to the following.

 MELSEC iQ-R CPU Module User's Manual (Application)

3 TROUBLESHOOTING

This chapter describes errors that may occur in the use of the A/D converter module and those troubleshooting.

3.1 Troubleshooting with the LEDs

Check the state of the LEDs to narrow down the possible causes of the trouble. This step is the first diagnostics before using the engineering tool.

A state of the A/D converter module can be checked with the RUN LED, ERR LED, and ALM LED. The following table shows the correspondence of these LEDs and a state of the A/D converter module.

Name	Description
RUN LED	Indicates the operating status of the module. On: Normal operation Flashing (1s cycles): In offset/gain setting mode Flashing (400ms cycles): Selected as a module for the online module change Off: 5V power supply interrupted, watchdog timer error occurred, or exchanging the module is allowed in the process of the online module change.
ERR LED	Indicates the error status of the module.*1 On: Error occurred Off: Normal operation
ALM LED	Indicates the alarm status of the module.*2 On: Warning (process alarm or rate alarm) issued Flashing: Input signal error detection Off: Normal operation

*1 For details, refer to the following.

 Page 114 List of Error Codes

*2 For details, refer to the following.

 Page 117 List of Alarm Codes


3.2 Checking the State of the Module


The following functions are available in the "Module Diagnostics" window of the A/D converter module.

Function	Application
Error Information	Displays the details of the currently occurring error. Clicking the [Event History] button displays the errors that have occurred on the network and the history of the errors detected and the operations executed on each module.
Module Information List	Displays each status information of the A/D converter module.

Error Information

Check the description and the actions for the errors that have occurred.


 [Diagnostics] ⇒ [System Monitor] ⇒ Right-click the module to be checked. ⇒ "Module Diagnostics"



Item	Description
Status	Major: An error such as a hardware failure or memory failure. The module stops operating.
	Moderate: An error, such as a parameter error, which affects module operation. The module stops operating.
	Minor: An error such as a communication failure. The module continues operating.
Detailed Information	Displays detailed information about each error (maximum of 3 pieces).
Cause	Displays the details of the cause of each error.
Action	Displays actions against the error.

Module Information List

Switch to the "Module Information List" tab to display each status information of the A/D converter module.



Item	Description
LED information	Displays the LED status of the A/D converter module.
Input signal error detection	Displays the detection status for the input signal errors of the A/D converter module for each channel.

3.3 Troubleshooting by Symptom

When the A/D converter module does not start up


Check item	Action
Check that five seconds have passed since the power supply module is powered off.	After the power supply module is powered off, wait at least five seconds before turning on the input power supply to the power supply module.

When the RUN LED flashes or turns off

When flashing


Check item	Cause	Action
Check whether the module is in offset/gain setting mode.	In the module parameter setting of the engineering tool, the programmable controller power supply has been turned off and on, or the CPU module has been reset when "Operation mode setting" is "Offset/gain setting mode".	In the module parameter setting of the engineering tool, set "Operation mode setting" to "Normal mode (A/D conversion processing)" and turn off and on the programmable controller power supply, or reset the CPU module.
	The G(P).OFFGAN instruction has been executed with the mode switched to offset/gain setting mode.	Review the program that uses the G(P).OFFGAN instruction to check whether the mode has been switched erroneously.
	The value in 'Mode switching setting' (Un\G296, Un\G297) has been changed and the mode has been switched to the offset/gain setting mode.	Review the program that uses 'Mode switching setting' (Un\G296, Un\G297) to check whether the mode has been switched erroneously.
Check whether the module is selected as a target module for the online module change.	The base number and slot number of the A/D converter module have been set in Module selection (base unit No.) (SD1600) or Module selection (slot No.) (SD1601).	Turn on Module selection cancel request flag (SM1615).

When turning off

Check item	Action
Check whether the power is supplied.	Check that the supply voltage of the power supply module is within the rated range.
Check whether the capacity of the power supply module is enough.	Calculate the current consumption of mounted modules, such as the CPU module, I/O modules, and intelligent function modules to check that the power capacity is enough.
Check whether the module is mounted properly.	Check the mounting state of the module.
Check whether the module is during online module change and is ready for the online module change.	Perform the online module change. For details, refer to the following manual.  MELSEC iQ-R Online Module Change Manual
Check whether the weight of the cables is putting stress on modules.	Place cables connected to modules in a duct or clamp them so that their weight does not put stress on modules.
Cases other than the above	Reset the CPU module, and check if the RUN LED turns on. If the RUN LED still remains off, the possible cause is a failure of the module. Please consult your local Mitsubishi representative.


When the ERR LED turns on

When turning on


Check item	Action
Check whether any error has occurred.	Check 'Latest error code' (Un\G0) and take actions described in the list of error codes.  Page 114 List of Error Codes

When the ALM LED turns on or flashes

When turning on

Check item	Action
Check whether any warning has been issued.	Check 'Warning output flag (process alarm upper limit)' (Un\G36), 'Warning output flag (process alarm lower limit)' (Un\G37), 'Warning output flag (rate alarm upper limit)' (Un\G38), and 'Warning output flag (rate alarm lower limit)' (Un\G39). Take actions described in the list of alarm codes.  Page 117 List of Alarm Codes

When flashing

Check item	Action
Check whether any input signal error has occurred.	Check 'Input signal error detection signal' (XC) or 'Input signal error detection flag' (Un\G40). Take actions described in the list of alarm codes.  Page 117 List of Alarm Codes

When a digital output value cannot be read

Check according to the following flow.

Check procedure	Check details
<pre> graph TD Start([When digital output values cannot be read]) --> Step1[Check the stored value in 'CH1 Digital output value' (Un\G400).] Step1 -.-> Note1[Monitor the buffer memory area with the monitor function*1 of the engineering tool.] Step1 --> Step2{Are the stored digital output values corresponding to the analog input?} Step2 -- YES --> Result1[(1) The read program has an error or the CPU module is in STOP status.] Step2 -- NO --> Step3[1] </pre>	<p>■Step 1: Checking the digital output values Check the following.</p> <ul style="list-style-type: none"> • Whether the digital output values are stored in the buffer memory area • Whether the program for reading digital output values has an error
<pre> graph TD Step3[1] --> Step2[Check a stored value in 'A/D conversion completed flag' (Un\G42).] Step2 -.-> Note2[Monitor the buffer memory area with the monitor function*1 of the engineering tool.] Step2 --> Step3{Is 'A/D conversion in progress or not used (0)' stored?} Step3 -- YES --> Result2[(2) A/D conversion is not enabled.] Step3 -- NO --> Step4[2] </pre>	<p>■Step 2: Checking the status of conversion Check the execution status of A/D conversion inside the module such as whether A/D conversion is performed in the A/D converter module.</p>
<pre> graph TD Step4[2] --> Step3[Check the stored value in 'CH1 Range setting monitor' (Un\G430).] Step3 -.-> Note3[Monitor the buffer memory area with the monitor function*1 of the engineering tool.] Step3 --> Step4{Is the set input range matched with the analog input?} Step4 -- YES --> Result3[(3) Check and correct the wiring and offset/gain setting.] Step4 -- NO --> Result4[(4) The analog input is not matched with the input range setting.] </pre>	<p>■Step 3: Checking the input range setting Check whether the input range suitable for the analog input is set.</p>

*1 Monitor the buffer memory area by using "Device/buffer memory batch monitor" or "Intelligent function module monitor".

Check item 1

The read program has an error, or the CPU module is in the STOP state. Check the following items.

Check item	Action
Check whether the CPU module is in the STOP state.	Change the state of the CPU module to RUN.
Check whether the program for reading digital output values has an error.	Check 'CH1 Digital output value' (Un\G400) using the monitor function of the engineering tool ("Device/buffer memory batch monitor" or "Intelligent function module monitor"). If the digital output value is stored without being converted from the analog input value, review and correct the read program.
Check whether the auto refresh setting is correct.	If the auto refresh is set to transfer 'CH1 Digital output value' (Un\G400) to the device of the CPU module, review and correct the auto refresh setting.

Check item 2



A/D conversion is not enabled. Check the following items.

Check item	Action
Check whether A/D conversion disable (1) is set in 'CH1 A/D conversion enable/disable setting' (Un\G500) of the channel where a value is to be input.	Check 'CH1 A/D conversion enable/disable setting' (Un\G500) using the monitor function of the engineering tool ("Device/buffer memory batch monitor" or "Intelligent function module monitor"). If A/D conversion disable (1) is set, change the setting to A/D conversion enabled (0) using the engineering tool or a program.
Check whether 'Operating condition setting request' (Y9) has been executed after parameter change.	Turn on and off ^{*1} 'Operating condition setting request' (Y9) and check that a digital output value is stored in 'CH1 Digital output value' (Un\G400) using the engineering tool. If the stored value is correct, further check the program to see if the description related to 'Operating condition setting request' (Y9) is proper.
Check whether the 24VDC external power supply is applied.	If the input range setting is the 2-wire transmitter input, check 'External power supply READY flag' (X6). If the flag is off, supply a voltage of 24VDC to the external power supply terminal (between terminal numbers A19 and 20 or B19 and 20).
Check whether a great value is set in 'CH1 Conversion start time setting (for 2-wire transmitter)' (Un\G532).	When the input range setting is the 2-wire transmitter input, check the value set in 'CH1 Conversion start time setting (for 2-wire transmitter)' (Un\G532). The digital output value and digital operation value are not updated until the set time passes.
Check whether the supply power is temporarily stopped.	When the input range setting is the 2-wire transmitter input, check the value set in 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (Un\G473). If "1: Trigger request" is set, the digital output value and digital operation value are not updated.

*1 If 'Operating condition setting request' (Y9) is in an on state, A/D conversion does not start. Turn (Y9) on, check the off state of 'Operating condition setting completed flag' (X9), and be sure to turn (Y9) off.

Check item 3

Review and correct the wiring and offset/gain setting. Check the following items.

Check item	Action
Check whether the terminal screws are loose.	Retighten the terminal screws within the range of the specified torques.
Check that the cables are connected to the correct terminals.	Review and correct the wiring by referring to the examples of external wiring.  MELSEC iQ-R Channel Isolated Analog-Digital Converter Module (With Signal Conditioning Function) User's Manual (Startup)
Check whether there is any problem with the wiring, such as looseness or disconnection of signal lines and analog signal lines connected to the 2-wire transmitter.	Identify the faulty area of signal lines by a visual check and continuity check.
Check whether the offset/gain setting of the user range is correct.	If the input range setting is the user range, turn on and off 'Operating condition setting request' (Y9), and check 'CH1 User range setting offset value (L)' (Un\G4028) to 'CH1 User range setting gain value (H)' (Un\G4031) comparing with the range reference table. If the stored values are not desired offset/gain values, perform the offset/gain setting again. For the range reference table, refer to the following.  Page 98 Range reference table

Check item 4

The analog input and input range setting do not match. Check the following items.

Check item	Action
Check whether the setting for the module parameter "Input range setting" is correct.	Check the module parameter "Input range setting", and set it again if it is not correct.
Check whether the program has an error when the input range in 'CH1 Range setting' (Un\G598) is set from the program.	Check 'CH1 Range setting' (Un\G598) using the monitor function of the engineering tool ("Device/buffer memory batch monitor" or "Intelligent function module monitor"). If the set value is not correct, set a correct value using the engineering tool or a program.
Check whether 'Operating condition setting request' (Y9) has been executed after parameter change.	Turn on and off ^{*1} 'Operating condition setting request' (Y9) and check that a digital output value is stored in 'CH1 Digital output value' (Un\G400) using the engineering tool. If the stored value is correct, further check the program to see if the description related to 'Operating condition setting request' (Y9) is proper.

*1 If 'Operating condition setting request' (Y9) is in an on state, A/D conversion does not start. Turn (Y9) on, check the off state of 'Operating condition setting completed flag' (X9), and be sure to turn (Y9) off.

Point

If digital output values cannot be read even after the above actions are taken, the possible cause is a failure of the module. Please consult your local Mitsubishi representative.

When the digital output value does not fall within the range of accuracy

Check item	Action
Check whether any measures have been taken to reduce noise.	To reduce noise, take measures such as the use of shielded cables for connection.

3.4 List of Error Codes

If an error occurs during operation, the A/D converter module stores the error code into 'Latest error code' (Un\G0) of the buffer memory. In addition, 'Error flag' (XF) turns on. Turning on 'Error clear request' (YF) clears the error code of 'Latest error code' (Un\G0), and 'Error flag' (XF) turns off.

Error codes of the A/D converter module are classified in minor errors or moderate errors.

- Minor error: This error is caused by the setting failure of programs and parameters. The A/D conversion continues with the parameter setting before the change. (1000H to 1FFFH)
- Moderate error: An error such as hardware failure. The A/D conversion does not continue. (3000H to 3FFFH)

The following table lists the error codes that may be stored.

□ in error codes: This symbol indicates the number of the channel where an error has occurred. A numerical value of 0 to 5 is used to correspond to CH1 to CH6.

(CH1: 0, CH2: 1, CH3: 2, CH4: 3, CH5: 4, CH6: 5)

△ in error codes: For what this symbol indicates, refer to Description and cause.

Error code	Error name	Description and cause	Action
0000H	—	There is no error.	—
1080H	Number of writes to offset/gain settings reach limit error	The number of the offset/gain settings has exceeded the guaranteed maximum number.	Any further setting of offset/gain values may not be reflected correctly.
17E0H	Module-specific backup parameter restore error	Offset/gain values cannot be restored with the module-specific backup parameter.	The module-specific backup parameter file may be damaged. Readjust the user range.
17E1H	Module-specific backup parameter creation error	The module-specific backup parameter has not been created.	Check the free space on the data memory of the control CPU and the SD memory card, and recreate a module-specific backup parameter. For how to create module-specific backup parameters, refer to the following. ☞ Page 92 Backing up, Saving, and Restoring Offset/Gain Values
180△H	Interrupt factor generation setting range error	A value other than 0 to 1 is set in Interrupt factor generation setting [n]. △ indicates the interrupt setting related in the error as below: 0: Setting 1 to F: Setting 16	Set Interrupt factor generation setting [n] to 0 or 1.
181△H	Condition target setting range error	A value other than 0 to 8 is set in Condition target setting [n]. △ indicates the interrupt setting related in the error as below: 0: Setting 1 to F: Setting 16	Set Condition target setting [n] to 0 to 8.
182△H	Condition target channel setting range error	A value other than 0 to 6 is set in Condition target channel setting [n]. △ indicates the interrupt setting related in the error as below: 0: Setting 1 to F: Setting 16	Set Condition target channel setting [n] to 0 to 6.
1860H	G(P).OGSTOR instruction execution error in offset/gain setting mode	The G(P).OGSTOR instruction has been executed in offset/gain setting mode.	Do not execute the G(P).OGSTOR instruction in the offset/gain setting mode.
1861H	Offset/gain setting continuous write occurrence error	The G(P).OGSTOR instruction has been executed continuously or a setting value has been continuously written to the flash memory 26 times or more in the offset/gain setting.	For the G(P).OGSTOR instruction, execute it only once per module. For the offset/gain setting, write the setting value only once per setting.
1862H	Model mismatch error at the execution of OGSTOR	The G(P).OGSTOR instruction has been executed on a module different from the one on which the G(P).OGLOAD instruction was executed. The G(P).OGSTOR instruction has been executed ahead of the G(P).OGLOAD instruction.	Execute the G(P).OGLOAD and G(P).OGSTOR instructions on the same module. As the other way, execute the G(P).OGLOAD instruction on the module whose data is to be restored, and then execute the G(P).OGSTOR instruction on the module to which the data is to be restored.
190□H	Range setting range error	A value out of the range is set in CH□ Range setting.	Set CH□ Range setting to the following values: 0, 6, 7, A, C, E, or F (hexadecimal)
191□H	Averaging processing specification setting range error	A value other than 0 to 4 is set in CH□ Averaging processing specification.	Set CH□ Averaging processing specification to 0 to 4.

Error code	Error name	Description and cause	Action
192□H	Time average setting range error	When the time average is selected in CH□ Averaging processing specification, CH□ Time average/Count average/Moving average/Primary delay filter constant setting is set to the following value: A value other than 40 to 5000 A value smaller than "4 × Number of channels used × Conversion speed" (ms)	Set CH□ Time average/Count average/Moving average/Primary delay filter constant setting to the following value: 40 to 5000 A value equal to or larger than "4 × Number of channels used × Conversion speed" (ms)
193□H	Count average setting range error	When the count average is selected in CH□ Averaging processing specification, a value other than 4 to 500 is set in CH□ Time average/Count average/Moving average/Primary delay filter constant setting.	Set CH□ Time average/Count average/Moving average/Primary delay filter constant setting to 4 to 500.
194□H	Moving average setting range error	When the moving average is selected in CH□ Averaging processing specification, a value other than 2 to 200 is set in CH□ Time average/Count average/Moving average/Primary delay filter constant setting.	Set CH□ Time average/Count average/Moving average/Primary delay filter constant setting to 2 to 200.
195□H	Primary delay filter constant setting range error	When the primary delay filter is selected in CH□ Averaging processing specification, a value other than 1 to 500 is set in CH□ Time average/Count average/Moving average/Primary delay filter constant setting.	Set CH□ Time average/Count average/Moving average/Primary delay filter constant setting to 1 to 500.
1A0□H	Scaling enable/disable setting range error	A value other than 0 and 1 is set in CH□ Scaling enable/disable setting.	Set CH□ Scaling enable/disable setting to 0 or 1.
1A1□H	Scaling setting range error	A value other than -32000 to 32000 is set in CH□ Scaling lower limit value and/or CH□ Scaling upper limit value.	Set CH□ Scaling lower limit value and CH□ Scaling upper limit value to -32000 to 32000.
1A2□H	Scaling upper/lower limit value setting error	CH□ Scaling upper limit value and CH□ Scaling lower limit value are set as the scaling upper limit value = the scaling lower limit value.	Set CH□ Scaling upper limit value and CH□ Scaling lower limit value as the scaling upper limit value ≠ the scaling lower limit value.
1A5□H	Digital clipping enable/disable setting range error	A value other than 0 and 1 is set in CH□ Digital clipping enable/disable setting.	Set CH□ Digital clipping enable/disable setting to 0 or 1.
1A7□H	Difference conversion trigger setting range error	A value other than 0 and 1 is set in CH□ Difference conversion trigger.	Set CH□ Difference conversion trigger to 0 or 1.
1B0□H	Warning output setting (Process alarm) range error	A value other than 0 and 1 is set in CH□ Warning output setting (Process alarm).	Set CH□ Warning output setting (Process alarm) to 0 or 1.
1B△□H	Process alarm upper lower limit value setting range error	The values set in CH□ Process alarm upper upper limit value to CH□ Process alarm lower lower limit value do not satisfy the following condition: Upper upper limit value ≥ Upper lower limit value ≥ Lower upper limit value ≥ Lower lower limit value △ indicates that the set values are as follows: 1: Process alarm lower lower limit value > Process alarm lower upper limit value 2: Process alarm lower upper limit value > Process alarm upper lower limit value 3: Process alarm upper lower limit value > Process alarm upper upper limit value	Set CH□ Process alarm upper upper limit value to CH□ Process alarm lower lower limit value so that the values satisfy the following condition: Upper upper limit value ≥ Upper lower limit value ≥ Lower upper limit value ≥ Lower lower limit value
1B8□H	Warning output setting (rate alarm) range error	A value other than 0 and 1 is set in CH□ Warning output setting (Rate alarm).	Set CH□ Warning output setting (Rate alarm) to 0 or 1.
1B9□H	Rate alarm warning detection cycle setting range error	A value other than 1 to 32000 is set in CH□ Rate alarm warning detection cycle setting.	Set CH□ Rate alarm warning detection cycle setting to 1 to 32000.
1BA□H	Rate alarm upper/lower limit setting value inversion error	CH□ Rate alarm upper limit value and CH□ Rate alarm lower limit value are set as Lower limit value ≥ Upper limit value.	Set CH□ Rate alarm upper limit value and CH□ Rate alarm lower limit value as Lower limit value < Upper limit value.
1C0□H	Input signal error detection setting range error	A value other than 0 to 4 is set in CH□ Input signal error detection setting.	Set CH□ Input signal error detection setting value to 0 to 4.
1C1□H	Input signal error detection setting value range error	A value other than 0 to 250 is set in CH□ Input signal error detection setting.	Set CH□ Input signal error detection setting value to 0 to 250.
1C6□H	Disconnection detection enabled range setting range error	Simple disconnection detection is set in CH□ Input signal error detection setting, and the value set in CH□ Input range setting is other than the following: • 4 to 20mA (extended mode) (2-wire transmitter input) • 4 to 20mA (extended mode) (current input)	For channels for simple disconnection detection using the input signal error detection function, set CH□ Input range setting to either of the following: • 4 to 20mA (extended mode) (2-wire transmitter input) • 4 to 20mA (extended mode) (current input)
1C8□H	Conversion start time setting range error	A value other than 0 to 32767 is set in CH□ Conversion start time setting (for 2-wire transmitter).	Set CH□ Conversion start time setting (for 2-wire transmitter) to 0 to 32767.

Error code	Error name	Description and cause	Action
1C9□H	Supply power temporary stop trigger setting range error	A value other than 0 to 1 is set in CH□ Supply power temporary stop trigger (for 2-wire transmitter).	Set CH□ Supply power temporary stop trigger (for 2-wire transmitter) to 0 to 1.
1D0□H	Logging enable/disable setting range error	A value other than 0 and 1 is set in CH□ Logging enable/disable setting.	Set CH□ Logging enable/disable setting to 0 or 1.
1D1□H	Logging cycle setting value range error	A value out of the range is set in CH□ Logging cycle setting value and/or CH□ Logging cycle unit setting.	Set one or both of CH□ Logging cycle setting value and CH□ Logging cycle unit setting to the values within the range.
1D2□H	Logging cycle setting disable error	CH□ Logging cycle setting value and CH□ Logging cycle unit setting are set so that the set logging cycle falls below the conversion cycle.	Set CH□ Logging cycle setting value and CH□ Logging cycle unit setting so that the logging cycle is not less than the conversion cycle of the object to be logged.
1D3□H	Logging data setting range error	A value other than 0 and 1 is set in CH□ Logging data setting.	Set CH□ Logging data setting to 0 or 1.
1D4□H	Post-trigger logging points setting range error	A value other than 1 to 1000 is set in CH□ Post-trigger logging points.	Set CH□ Post-trigger logging points to 1 to 1000.
1D5□H	Level trigger condition setting range error	A value other than 0 to 3 is set in CH□ Level trigger condition setting.	Set CH□ Level trigger condition setting to 0 to 3.
1D6□H	Trigger data setting range error	A value other than 0 to 9999 is set in CH□ Trigger data.	Set CH□ Trigger data to 0 to 9999.
1D7□H	Logging hold request range error	A value other than 0 and 1 is set in CH□ Logging hold request.	Set CH□ Logging hold request to 0 or 1.
1D8□H	Loading interrupt enable/disable setting range error	A value other than 0 and 1 is set in CH□ Loading interrupt enable/disable setting.	Set CH□ Loading interrupt enable/disable setting to 0 or 1.
1D9□H	Logging read points setting value range error	A value other than 1 to 1000 is set in CH□ Logging read points setting value.	Set CH□ Logging read points setting value to 1 to 1000.
1E50H	Offset/gain setting channel specification error	In the offset/gain setting, "1: Setting channel" is set for both CH□ Offset/gain setting mode (offset specification) and CH□ Offset/gain setting mode (gain specification), or "0: Disable" is set.	Correctly set CH□ Offset/gain setting mode (offset specification) and CH□ Offset/gain setting mode (gain specification).
1E51H	User range data invalid (CH identification disabled)	An invalid value is set in the offset/gain setting. The number of the channel in which this error occurs cannot be identified.	Perform the offset/gain setting again for all channels where the user range is set. If the error occurs again, the possible cause is a failure of the module. Please consult your local Mitsubishi representative.
1E6□H	User range data invalid (CH identification allowed)	An invalid value is set in CH□ Offset/gain setting.	Perform the offset/gain setting again for the channels where the error has occurred. If the error occurs again, the possible cause is a failure of the module. Please consult your local Mitsubishi representative.
1E7□H	Offset/gain value inversion error	The offset value and gain value to be saved in the flash memory are as follows: Offset value \geq Gain value	Perform the offset/gain setting again so that the following condition is satisfied: Offset value < Gain value When the 2-wire transmitter is connected, check whether 24VDC is supplied from the external power supply.
1E8□H	Offset/gain setting channel range error	A value other than 0 and 1 is set in CH□ Offset/gain setting mode (offset specification) and CH□ Offset/gain setting mode (gain specification).	Set CH□ Offset/gain setting mode (offset specification) and CH□ Offset/gain setting mode (gain specification) to 0 or 1.
1F00H	Hardware failure (minor)	A hardware failure (minor) has occurred in the module.	The module may be affected by noise. Review and adjust the cable wiring and the installation environment of the programmable controllers. After the adjustment, turn on and off 'Error clear request' (YF) to eliminate this error and resume the conversion. If the error occurs again, the possible cause is a failure of the module. Please consult your local Mitsubishi representative.
3001H	Hardware failure (moderate)	A hardware failure (moderate) has occurred in the module.	Power off and on the module. If the error occurs again, the possible cause is a failure of the module. Please consult your local Mitsubishi representative.
3030H	Flash memory error	The data in the flash memory is abnormal.	Check the digital output values. If the values are abnormal, please consult your local Mitsubishi representative.

3.5 List of Alarm Codes

If an alarm occurs during operation, the A/D converter module stores the alarm code into 'Latest alarm code' (Un\G2) of the buffer memory. Turning on 'Error clear request' (YF) clears the alarm code of 'Latest alarm code' (Un\G2).

□ in alarm codes: This symbol indicates the number of the channel where an alarm has occurred. A numerical value of 0 to 5 is used to correspond to CH1 to CH6.

(CH1: 0, CH2: 1, CH3: 2, CH4: 3, CH5: 4, CH6: 5)

Alarm code	Alarm name	Description and cause	Action
080□H	Process alarm (upper limit)	The process alarm (upper limit) has occurred in CH□.	Adjust CH□ Digital operation value to fall within the set range. As a result, the corresponding bit of CH□ Warning output flag (process alarm upper limit) or CH□ Warning output flag (process alarm lower limit) and 'Warning output signal' (X8) turn off.
081□H	Process alarm (lower limit)	The process alarm (lower limit) has occurred in CH□.	
082□H	Rate alarm (upper limit)	The rate alarm (upper limit) has occurred in CH□.	Adjust the change rate in CH□ Digital output value to fall within the set range. As a result, the corresponding bit of CH□ Warning output flag (rate alarm upper limit) or CH□ Warning output flag (rate alarm lower limit) and 'Warning output signal' (X8) turn off.
083□H	Rate alarm (lower limit)	The rate alarm (lower limit) has occurred in CH□.	
090□H	Input signal error detection (upper limit)	An input signal error (upper limit) has been detected in CH□.	The following operations are performed by turning on and off 'Error clear request' (YF) after the analog input value returns within the setting range. <ul style="list-style-type: none"> • All the bits of CH□ Input signal error detection flag are set to Normal (0). • 'Input signal error detection signal' (XC) turns off. • 'Latest alarm code' (Un\G2) is cleared.
091□H	Input signal error detection (lower limit)	An input signal error (lower limit) has been detected in CH□.	
0A0□H	Input signal error detection (disconnection)	An input signal error (disconnection) has been detected in CH□.	

APPENDICES

Appendix 1 Module Label

The functions of the A/D converter module can be set by using module labels.

Module labels of I/O signals

The module label name of an I/O signal is defined with the following structure:

"Module name"_"Module number".b"Label name" or "Module name"_"Module number".b"Label name"_D

Ex.

R60ADDG_1.bModuleREADY_D

■Module name

The character string of a module model name is given.

■Module number

A number starting from 1 is added to identify modules that have the same module name.

■Label name

The label identifier unique to a module is given.

■_D

This string indicates that the module label is for the direct access input (DX) or direct access output (DY). A module label without the string is for the input (X) or output (Y) of the refresh processing.

Module labels of buffer memory areas

The module label name of a buffer memory area is defined with the following structure:

"Module name"_"Module number"."Data type"_D["(Channel)"]."Data format""Label name"_D

Ex.

R60ADDG_1.stnMonitor_D[0].wDigitalOutputValue_D

■Module name

The character string of a module model name is given.

■Module number

A number starting from 1 is added to identify modules that have the same module name.

■Data type

The data type to sort a buffer memory area is given. Each data type is as follows:

Data type	Description
stnMonitor	Monitor
stnControl	Control
stnSetting	Setting

■Channel

The channel number corresponding to a module label is given. A numerical value of 0 to 5 is used to correspond to CH1 to CH6.

(CH1: 0, CH2: 1, CH3: 2, CH4: 3, CH5: 4, CH6: 5)

■Data format

The string that represents the data size of a buffer memory area is given. Each data format is as follows:


Data format	Description
u	Word [Unsigned]/Bit string [16-bit]
w	Word [Signed]
d	Double word [Signed]
z	System area

■Label name

The label identifier unique to a module is given.

■_D

This string indicates that the module label is for the direct access. A module label without the string is for the auto refresh. The following table shows the differences between the auto refresh and direct access.

Type	Description	Access timing	Example
Auto refresh	Values that are read from or written to the module label are reflected in the module collectively at the auto refresh. The run time of the program can be reduced. To use the auto refresh, set "Target" to "Module Label" in "Refresh settings" of "Module Parameter".	At auto refresh	R60ADDG_1.stnMonitor[0].wDigitalOutputValue
Direct access	Values that are read from or written to the module label is reflected in the module instantly. Compared with the auto refresh, the run time of the program becomes longer. However, the responsiveness is high. For the instruction processing time, refer to the following.  MELSEC iQ-R Programming Manual (CPU Module Instructions, Standard Functions/Function Blocks)	At reading/writing from/to the module label	R60ADDG_1.stnMonitor_D[0].wDigitalOutputValue_D

Appendix 2 I/O Signals

List of I/O signals

The following table lists the I/O signals of the A/D converter module.

For details on the I/O signals, refer to the following.

☞ Page 122 Details of input signals

☞ Page 132 Details of output signals

Point

- The I/O number (X/Y) described below shows the case that the start I/O number of the A/D converter module is set to "0".
- Do not use the "Use prohibited" signals shown below because the system uses them. If users use (turn on) the signals, the functions of the A/D converter module cannot be guaranteed.

Input signal

Device number	Signal name	
X0	Module READY	
X1	Use prohibited	
X2	Use prohibited	
X3	Use prohibited	
X4	Use prohibited	
X5	Use prohibited	
X6	External power supply READY flag	
X7	Use prohibited	
X8	Warning output signal	
X9	Operating condition setting completed flag	
XA	Offset/gain setting mode status flag	
XB	Channel change completed flag	
XC	In the normal mode	Input signal error detection signal
	In the offset/gain setting mode	Offset/gain change completed flag
XD	Maximum value/minimum value reset completed flag	
XE	A/D conversion completed flag	
XF	Error flag	

Output signal

Device number	Signal name
Y0	Use prohibited
Y1	Use prohibited
Y2	Use prohibited
Y3	Use prohibited
Y4	Use prohibited
Y5	Use prohibited
Y6	Use prohibited
Y7	Use prohibited
Y8	Use prohibited
Y9	Operating condition setting request
YA	User range write request
YB	Channel change request
YC	Offset/gain change request
YD	Maximum value/minimum value reset request
YE	Use prohibited
YF	Error clear request

Details of input signals

The following describes the details of the input signals for the A/D converter module which are assigned to the CPU module. The I/O numbers (X/Y) described in Appendix 2 are for the case when the start I/O number of the A/D converter module is set to 0.

Point

This section describes buffer memory addresses for CH1.

For details on the buffer memory addresses after CH2, refer to the following.

 Page 134 List of buffer memory addresses

Module READY

'Module READY' (X0) turns on to indicate the preparation for the A/D conversion is completed after the power-on or after the reset operation of the CPU module.

In the following cases, 'Module READY' (X0) turns off.

- In the offset/gain setting mode (In this case, the A/D conversion is performed.)
- When a watchdog timer error occurs in the A/D converter module (In this case, the A/D conversion is not performed.)


■Device number

The following shows the device number of this input signal.

Signal name	CH1 to CH6
Module READY	X0

External power supply READY flag

- When the external power supply is off, or when 200ms have not passed after it is turned on, 'External power supply READY flag' (X6) remains turned off, and for the 2-wire transmitter range channel, neither A/D conversion processing nor power supply to the 2-wire transmitter is performed. In this case, 'A/D conversion completed flag' (XE) turns off.
- When the external power supply is turned on and 200ms have passed, 'External power supply READY flag' (X6) turns on, and for the 2-wire transmitter range channel where conversion is enabled, A/D conversion processing and power supply to the 2-wire transmitter start.



(1) A/D conversion processing is not performed until the time set in 'CH1 Conversion start time setting (for 2-wire transmitter)' (Un\G532) is passed.

- When the external power supply is turned off, 'External power supply READY flag' (X6) turns off, and for the 2-wire transmitter range, A/D conversion processing and power supply to the 2-wire transmitter stop. In this case, 'A/D conversion completed flag' (XE) turns off.
- For the current input range channel, even if the external power supply is off, A/D conversion processing is performed. Even if the external power supply is turned off, A/D conversion processing continues, and 'A/D conversion completed flag' (XE) remains turned on.

A

Point

- The A/D conversion processing status change by turning on/off the external power supply can be checked with 'A/D conversion completed flag' (XE).
- If the external power supply does not satisfy the requirements of the performance specifications, 'External power supply READY flag' (X6) does not turn on. For details on the performance specifications, refer to the following.

📖 MELSEC iQ-R Channel Isolated Analog-Digital Converter Module (With Signal Conditioning Function) User's Manual (Startup)

Device number

The following shows the device number of this input signal.

Signal name	CH1 to CH6
External power supply READY flag	X6

Warning output signal

'Warning output signal' (X8) turns on when the process alarm or rate alarm has been detected. When the warning output function is disabled for all channels, 'Warning output signal' (X8) always turns off.

■Device number

The following shows the device number of this input signal.


Signal name	CH1 to CH6
Warning output signal	X8

■Process alarm

- 'Warning output signal' (X8) turns on when digital operation values of the A/D conversion enabled channels exceed the ranges set for 'CH1 Process alarm upper upper limit value' (Un\G514) to 'CH1 Process alarm lower lower limit value' (Un\G520) after 'CH1 Warning output setting (process alarm)' (Un\G512) is enabled. The ALM LED also turns on along with the on of the signal.
- Warning output signal (X8) turns off when the digital operation values fall within the setting range for all the A/D conversion enabled channels. The ALM LED also turns off along with the off of the signal.

■Rate alarm

- 'Warning output signal' (X8) turns on when the change rate of the digital output values of the A/D conversion enabled channels exceed the ranges set for 'CH1 Rate alarm upper limit value' (Un\G524) to 'CH1 Rate alarm lower limit value' (Un\G526) after 'CH1 Warning output setting (rate alarm)' (Un\G513) is enabled. The ALM LED also turns on along with the on of the signal.
- Warning output signal (X8) turns off when the change rate of the digital output values falls within the setting range for all the A/D conversion enabled channels. The ALM LED also turns off along with the off of the signal.



Operating condition setting completed flag

■ Device number

The following shows the device number of this input signal.


Signal name	CH1 to CH6
Operating condition setting completed flag	X9

When changing values of the buffer memory, use Operating condition setting completed flag (X9) as an interlock condition to turn on and off 'Operating condition setting request' (Y9). For the buffer memory addresses which require turning on and off of 'Operating condition setting request' (Y9) to enable the changed values, refer to the following.

☞ Page 134 List of buffer memory addresses

When 'Operating condition setting completed flag' (X9) is off, the A/D conversion is not performed.

When 'Operating condition setting request' (Y9) is on, 'Operating condition setting completed flag' (X9) turns off.



Offset/gain setting mode status flag

■Device number

The following shows the device number of this input signal.

Signal name	CH1 to CH6
Offset/gain setting mode status flag	XA

■In the offset/gain setting mode


When registering the value, which has been adjusted with the offset/gain setting, use Offset/gain setting mode status flag (XA) as an interlock condition to turn on and off 'User range write request' (YA).

When the offset/gain setting is configured from the offset/gain setting window of an engineering tool, the setting is performed properly on the window. Therefore, a program is not required to perform the setting.

When a sequence program used for the MELSEC-Q series A/D converter module is utilized to configure the offset/gain setting, check that this flag is used as an interlock.

For the sequence programs for the MELSEC-Q series A/D converter module, refer to the following.

📖 MELSEC-Q Channel Isolated Analog-Digital Converter Module/Channel Isolated Analog-Digital Converter Module (With Signal Conditioning Function) User's Manual




■In the normal mode

In the user range setting restoration, use Offset/gain setting mode status flag (XA) as an interlock condition to turn on and off 'User range write request' (YA).

For user range setting restoration, refer to the following.

📖 Page 92 Backing up, Saving, and Restoring Offset/Gain Values




Channel change completed flag


When changing a channel to perform the offset/gain setting, use Channel change completed flag (XB) as an interlock condition to turn on and off 'Channel change request' (YB).

When the offset/gain setting is configured from the offset/gain setting window of an engineering tool, the setting is performed properly on the window. Therefore, a program is not required to perform the setting.

When a sequence program used for the MELSEC-Q series A/D converter module is utilized to configure the offset/gain setting, check that this flag is used as an interlock.

For the sequence programs for the MELSEC-Q series A/D converter module, refer to the following.

 MELSEC-Q Channel Isolated Analog-Digital Converter Module/Channel Isolated Analog-Digital Converter Module (With Signal Conditioning Function) User's Manual



■Device number

The following shows the device number of this input signal.

Signal name	CH1 to CH6
Channel change completed flag	XB

Input signal error detection signal

■Device number

The following shows the device number of this input signal in the normal mode.

Signal name	CH1 to CH6
Input signal error detection signal	XC

■Turning on 'Input signal error detection signal' (XC)

Input signal error detection signal (XC) turns on when an analog input value exceeds the range set with 'CH1 Input signal error detection lower limit set value' (Un\G529) or 'CH1 Input signal error detection upper limit set value' (Un\G530) in any channel which has been A/D conversion-enabled, after the detection condition is set in 'CH1 Input signal error detection setting' (Un\G528). When the simple disconnection detection is set, the signal ignores the settings for 'CH1 Input signal error detection lower limit set value' (Un\G529) and 'CH1 Input signal error detection upper limit set value' (Un\G530) and turns on at the disconnection detection.


When 'Input signal error detection signal' (XC) turns on, the following operations are performed.

- 'CH1 Digital output value' (Un\G400) and 'CH1 Digital operation value' (Un\G402) hold the digital value just before the error was detected.
- The ALM LED flashes.
- In Q compatible mode, the corresponding bit of 'A/D conversion completed flag' (Un\G10) turns off. In R mode, the corresponding bit of 'A/D conversion completed flag' (Un\G42) remains on.

■Turning off 'Input signal error detection signal' (XC)

When 'Input signal error detection signal' (XC) turns off, the following operations are performed.

- The ALM LED turns off.
- 'Latest alarm code' (Un\G2) is cleared.



■'Input signal error detection auto-clear enable/disable setting' (Un\G302) is set to Disable (1)

The following operations are performed by turning on and off 'Error clear request' (YF) after the cause of the input signal error is eliminated and the analog input value returns within the setting range.

- 'Input signal error detection signal' (XC) turns off.
- 'Input signal error detection flag' (Un\G40) turns off.
- The ALM LED turns off.
- 'Latest alarm code' (Un\G2) is cleared.

■'Input signal error detection auto-clear enable/disable setting' (Un\G302) is set to Enable (0)

The following operations are performed after the cause of the input signal error is eliminated and the analog input value returns within the setting range.

- 'Input signal error detection signal' (XC) turns off.
- 'Input signal error detection flag' (Un\G40) turns off.
- The ALM LED turns off.


Point

- Averaging processing starts over after the A/D conversion resumes.
- 'Input signal error detection signal' (XC) operates only when the input signal error detection function is enabled. When the input signal error detection function is disabled, 'Input signal error detection signal' (XC) always turns off.

Offset/gain change completed flag

When changing the offset/gain value, use Offset/gain change completed flag (XC) as an interlock condition to turn on and off 'Offset/gain change request' (YC).

When the offset/gain setting is configured from the offset/gain setting window of an engineering tool, the setting is performed properly on the window. Therefore, a program is not required to perform the setting.



■Device number


The following shows the device number of this input signal in the offset/gain setting mode.

Signal name	CH1 to CH6
Offset/gain change completed flag	XC

Maximum value/minimum value reset completed flag

Maximum value/minimum value reset completed flag (XD) turns on after the maximum and minimum values stored in 'CH1 Maximum value' (Un\G404) and 'CH1 Minimum value' (Un\G406) are reset by turning on 'Maximum value/minimum value reset request' (YD).

The flag turns off when 'Maximum value/minimum value reset request' (YD) is turned off.



■Device number

The following shows the device number of this input signal.

Signal name	CH1 to CH6
Maximum value/minimum value reset completed flag	XD

A/D conversion completed flag

A/D conversion completed flag (XE) turns on when all conversion enabled channels are converted.

Device number


The following shows the device number of this input signal.

Signal name	CH1 to CH6
A/D conversion completed flag	XE

Error flag

'Error flag' (XF) turns on when an error occurs.

Turn on and off 'Error clear request' (YF) to clear 'Latest error code' (Un\G0) and 'Latest alarm code' (Un\G2).



Device number

The following shows the device number of this input signal.

Signal name	CH1 to CH6
Error flag	XF



Details of output signals

The following describes the details of the output signals for the A/D converter module which are assigned to the CPU module. The I/O numbers (X/Y) described in Appendix 2 are for the case when the start I/O number of the A/D converter module is set to 0.

Point

This section describes buffer memory addresses for CH1.

For details on the buffer memory addresses after CH2, refer to the following.

☞ Page 134 List of buffer memory addresses

Operating condition setting request

Turn on and off Operating condition setting request (Y9) to enable the setting of the A/D converter module.

For the timing of turning the signal on and off, refer to the following.

☞ Page 125 Operating condition setting completed flag

For details on the buffer memory areas to be enabled, refer to the following.

☞ Page 134 List of buffer memory addresses

■Device number

The following shows the device number of this output signal.

Signal name	CH1 to CH6
Operating condition setting request	Y9

User range write request

■Device number

The following shows the device number of this output signal.

Signal name	CH1 to CH6
User range write request	YA

■In the offset/gain setting mode

Turn on and off User range write request (YA) to register values adjusted with the offset/gain setting in the A/D converter module. The data is written to the flash memory when this signal is turned on.

For the timing of turning the signal on and off, refer to the following.

☞ Page 126 In the offset/gain setting mode

■In the normal mode

Turn on and off User range write request (YA) to restore the user range.

For the timing of turning the signal on and off, refer to the following.

☞ Page 126 In the normal mode

Channel change request

Turn on and off Channel change request (YB) to change a channel to perform the offset/gain setting.

For the timing of turning the signal on and off, refer to the following.

☞ Page 127 Channel change completed flag

■Device number

The following shows the device number of this output signal.

Signal name	CH1 to CH6
Channel change request	YB

Offset/gain change request

Turn on and off Offset/gain change request (YC) to change the offset/gain value.

For the timing of turning the signal on and off, refer to the following.

☞ Page 130 Offset/gain change completed flag

■Device number

The following shows the device number of this output signal.

Signal name	CH1 to CH6
Offset/gain change request	YC

Maximum value/minimum value reset request

Turn on and off 'Maximum value/minimum value reset request' (YD) to clear the maximum and minimum values stored in 'CH1 Maximum value' (Un\G404) and 'CH1 Minimum value' (Un\G406).

For the timing of turning the signal on and off, refer to the following.

☞ Page 130 Maximum value/minimum value reset completed flag

■Device number

The following shows the device number of this output signal.

Signal name	CH1 to CH6
Maximum value/minimum value reset request	YD

Error clear request

Turn on and off Error clear request (YF) to clear 'Error flag' (XF), 'Input signal error detection signal' (XC), 'Latest error code' (Un\G0), and 'Latest alarm code' (Un\G2). For the timing of turning the signal on and off, refer to the following.

☞ Page 128 Input signal error detection signal

☞ Page 131 Error flag

■Device number


The following shows the device number of this output signal.

Signal name	CH1 to CH6
Error clear request	YF

Appendix 3 Buffer Memory

List of buffer memory addresses

The following table lists the buffer memory addresses of the A/D converter module. For details on the buffer memory addresses, refer to the following.

 Page 149 Details of buffer memory addresses

The buffer memory areas of the A/D converter module are classified by the following data types.

Data type	Description	
Setting data	Description	Set this data according to the connected device and the use of the system.
	Read/write attribute	Data can be read and written from/to this area.
	Setting procedure	Set this data using an engineering tool or in a program.
	Setting timing	After changing the values, turn on and off 'Operating condition setting request' (Y9) to enable the set values.
Control data	Description	Use this data to control the A/D converter module.
	Read/write attribute	Data can be read and written from/to this area.
	Setting procedure	Set this data using an engineering tool or in a program.
	Setting timing	As soon as the values are changed, the set values become enabled.
Monitor data	Description	Use this data to monitor the status of the A/D converter module.
	Read/write attribute	Writing data is only allowed. Reading data is not allowed.
	Setting procedure	—
	Setting timing	—
User range setting data	Description	Use this data to update the user range setting of the A/D converter module.
	Read/write attribute	Data can be read and written from/to this area.
	Setting procedure	Set this data using an engineering tool or in a program.
	Setting timing	After changing the values, turn on and off 'User range write request' (YA) to enable the set values.

Point

Do not write data to the system areas and areas whose data types are monitor in the buffer memory. Writing data into these areas can cause the malfunction of the module.

In R mode

■Un\G0 to Un\G399

Address (decimal)	Address (hexadecimal)	Name	Default value	Data type	Auto refresh
0	0H	Latest error code	0	Monitor	○
1	1H	Latest address of error history	0	Monitor	○
2	2H	Latest alarm code	0	Monitor	○
3	3H	Latest address of alarm history	0	Monitor	○
4 to 19	4H to 13H	Interrupt factor detection flag [n] ^{*1}	0	Monitor	○
20 to 35	14H to 23H	System area	—	—	—
36	24H	Warning output flag (Process alarm upper limit)	0000H	Monitor	○
37	25H	Warning output flag (Process alarm lower limit)	0000H	Monitor	○
38	26H	Warning output flag (Rate alarm upper limit)	0000H	Monitor	○
39	27H	Warning output flag (Rate alarm lower limit)	0000H	Monitor	○
40	28H	Input signal error detection flag	0000H	Monitor	○
41	29H	System area	—	—	—
42	2AH	A/D conversion completed flag	0000H	Monitor	○
43 to 69	2BH to 45H	System area	—	—	—
70	46H	RUN LED status monitor	0000H	Monitor	×
71	47H	ERR LED status monitor	0000H	Monitor	×
72	48H	ALM LED status monitor	0000H	Monitor	×
73 to 89	49H to 59H	System area	—	—	—
90	5AH	Level data 0	0	Control	○
91	5BH	Level data 1	0	Control	○
92	5CH	Level data 2	0	Control	○
93	5DH	Level data 3	0	Control	○
94	5EH	Level data 4	0	Control	○
95	5FH	Level data 5	0	Control	○
96	60H	Level data 6	0	Control	○
97	61H	Level data 7	0	Control	○
98	62H	Level data 8	0	Control	○
99	63H	Level data 9	0	Control	○
100 to 123	64H to 7BH	System area	—	—	—
124 to 139	7CH to 8BH	Interrupt factor mask [n] ^{*1}	0	Control	×
140 to 155	8CH to 9BH	System area	—	—	—
156 to 171	9CH to ABH	Interrupt factor reset request [n] ^{*1}	0	Control	×
172 to 199	ACH to C7H	System area	—	—	—
200 to 215	C8H to D7H	Interrupt factor generation setting [n] ^{*1}	0	Setting	×
216 to 231	D8H to E7H	System area	—	—	—
232 to 247	E8H to F7H	Condition target setting [n] ^{*1}	0	Setting	×
248 to 263	F8H to 107H	System area	—	—	—
264 to 279	108H to 117H	Condition target channel setting [n] ^{*1}	0	Setting	×
280 to 295	118H to 127H	System area	—	—	—
296	128H	Mode switching setting (L)	0	Setting	×
297	129H	Mode switching setting (H)	0	Setting	×
298 to 301	12AH to 12DH	System area	—	—	—
302	12EH	Input signal error detection auto-clear enable/disable setting	1	Setting	×
303 to 399	12FH to 18FH	System area	—	—	—

*1 [n] in the table indicates an interrupt setting number. (n = 1 to 16)

■Un\G400 to Un\G3599

Address Decimal (hexadecimal)						Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4	CH5	CH6				
400 (190H)	600 (258H)	800 (320H)	1000 (3E8H)	1200 (4B0H)	1400 (578H)	CH□ Digital output value	0	Monitor	○
401 (191H)	601 (259H)	801 (321H)	1001 (3E9H)	1201 (4B1H)	1401 (579H)	System area	—	—	—
402 (192H)	602 (25AH)	802 (322H)	1002 (3EAH)	1202 (4B2H)	1402 (57AH)	CH□ Digital operation value	0	Monitor	○
403 (193H)	603 (25BH)	803 (323H)	1003 (3EBH)	1203 (4B3H)	1403 (57BH)	System area	—	—	—
404 (194H)	604 (25CH)	804 (324H)	1004 (3ECH)	1204 (4B4H)	1404 (57CH)	CH□ Maximum value	0	Monitor	○
405 (195H)	605 (25DH)	805 (325H)	1005 (3EDH)	1205 (4B5H)	1405 (57DH)	System area	—	—	—
406 (196H)	606 (25EH)	806 (326H)	1006 (3EEH)	1206 (4B6H)	1406 (57EH)	CH□ Minimum value	0	Monitor	○
407 (197H)	607 (25FH)	807 (327H)	1007 (3EFH)	1207 (4B7H)	1407 (57FH)	System area	—	—	—
408 (198H)	608 (260H)	808 (328H)	1008 (3F0H)	1208 (4B8H)	1408 (580H)	CH□ Difference conversion status flag	0	Monitor	○
409 (199H)	609 (261H)	809 (329H)	1009 (3F1H)	1209 (4B9H)	1409 (581H)	CH□ Logging hold flag	0	Monitor	○
410 (19AH)	610 (262H)	810 (32AH)	1010 (3F2H)	1210 (4BAH)	1410 (582H)	CH□ Digital output value (32 bits) (L)	0	Monitor	○
411 (19BH)	611 (263H)	811 (32BH)	1011 (3F3H)	1211 (4BBH)	1411 (583H)	CH□ Digital output value (32 bits) (H)	0	Monitor	○
412 (19CH)	612 (264H)	812 (32CH)	1012 (3F4H)	1212 (4BCH)	1412 (584H)	CH□ Supply power temporary stop status flag (for 2-wire transmitter)	0	Monitor	○
413 to 429 (19DH to 1ADH)	613 to 629 (265H to 275H)	813 to 829 (32DH to 33DH)	1013 to 1029 (3F5H to 405H)	1213 to 1229 (4BDH to 4CDH)	1413 to 1429 (585H to 595H)	System area	—	—	—
430 (1AEH)	630 (276H)	830 (33EH)	1030 (406H)	1230 (4CEH)	1430 (596H)	CH□ Range setting monitor	0000H	Monitor	×
431 (1AFH)	631 (277H)	831 (33FH)	1031 (407H)	1231 (4CFH)	1431 (597H)	System area	—	—	—
432 (1B0H)	632 (278H)	832 (340H)	1032 (408H)	1232 (4D0H)	1432 (598H)	CH□ Difference conversion reference value	0000H	Monitor	×
433 (1B1H)	633 (279H)	833 (341H)	1033 (409H)	1233 (4D1H)	1433 (599H)	System area	—	—	—
434 (1B2H)	634 (27AH)	834 (342H)	1034 (40AH)	1234 (4D2H)	1434 (59AH)	CH□ Head pointer	0	Monitor	×
435 (1B3H)	635 (27BH)	835 (343H)	1035 (40BH)	1235 (4D3H)	1435 (59BH)	CH□ Latest pointer	0	Monitor	×
436 (1B4H)	636 (27CH)	836 (344H)	1036 (40CH)	1236 (4D4H)	1436 (59CH)	CH□ Number of logging data	0	Monitor	×
437 (1B5H)	637 (27DH)	837 (345H)	1037 (40DH)	1237 (4D5H)	1437 (59DH)	CH□ Trigger pointer	0	Monitor	×
438 (1B6H)	638 (27EH)	838 (346H)	1038 (40EH)	1238 (4D6H)	1438 (59EH)	CH□ Current logging read pointer	-1	Monitor	×
439 (1B7H)	639 (27FH)	839 (347H)	1039 (40FH)	1239 (4D7H)	1439 (59FH)	CH□ Previous logging read pointer	-1	Monitor	×
440 (1B8H)	640 (280H)	840 (348H)	1040 (410H)	1240 (4D8H)	1440 (5A0H)	CH□ Logging read points monitored value	0	Monitor	×
441 (1B9H)	641 (281H)	841 (349H)	1041 (411H)	1241 (4D9H)	1441 (5A1H)	CH□ Logging cycle monitored value (s)	0	Monitor	×
442 (1BAH)	642 (282H)	842 (34AH)	1042 (412H)	1242 (4DAH)	1442 (5A2H)	CH□ Logging cycle monitored value (ms)	0	Monitor	×

Address Decimal (hexadecimal)						Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4	CH5	CH6				
443 (1BBH)	643 (283H)	843 (34BH)	1043 (413H)	1243 (4DBH)	1443 (5A3H)	System area	—	—	—
444 (1BCH)	644 (284H)	844 (34CH)	1044 (414H)	1244 (4DCH)	1444 (5A4H)	CH□ Trigger generation time (First/Last two digits of the year)	0	Monitor	×
445 (1BDH)	645 (285H)	845 (34DH)	1045 (415H)	1245 (4DDH)	1445 (5A5H)	CH□ Trigger generation time (Month/Day)	0	Monitor	×
446 (1BEH)	646 (286H)	846 (34EH)	1046 (416H)	1246 (4DEH)	1446 (5A6H)	CH□ Trigger generation time (Hour/Minute)	0	Monitor	×
447 (1BFH)	647 (287H)	847 (34FH)	1047 (417H)	1247 (4DFH)	1447 (5A7H)	CH□ Trigger generation time (Second/Day of the week)	0	Monitor	×
448 (1C0H)	648 (288H)	848 (350H)	1048 (418H)	1248 (4E0H)	1448 (5A8H)	CH□ Trigger generation time (Millisecond)	0	Monitor	×
449 to 469 (1C1H to 1D5H)	649 to 669 (289H to 29DH)	849 to 869 (351H to 365H)	1049 to 1069 (419H to 42DH)	1249 to 1269 (4E1H to 4F5H)	1449 to 1469 (5A9H to 5BDH)	System area	—	—	—
470 (1D6H)	670 (29EH)	870 (366H)	1070 (42EH)	1270 (4F6H)	1470 (5BEH)	CH□ Difference conversion trigger	0	Control	○
471 (1D7H)	671 (29FH)	871 (367H)	1071 (42FH)	1271 (4F7H)	1471 (5BFH)	CH□ Logging hold request	0	Control	○
472 (1D8H)	672 (2A0H)	872 (368H)	1072 (430H)	1272 (4F8H)	1472 (5C0H)	CH□ Conversion value shift amount	0	Control	○
473 (1D9H)	673 (2A1H)	873 (369H)	1073 (431H)	1273 (4F9H)	1473 (5C1H)	CH□ Supply power temporary stop trigger (for 2-wire transmitter)	0	Control	○
474 to 499 (1DAH to 1F3H)	674 to 699 (2A2H to 2BBH)	874 to 899 (36AH to 383H)	1074 to 1099 (432H to 44BH)	1274 to 1299 (4FAH to 513H)	1474 to 1499 (5C2H to 5DBH)	System area	—	—	—
500 (1F4H)	700 (2BCH)	900 (384H)	1100 (44CH)	1300 (514H)	1500 (5DCH)	CH□ A/D conversion enable/ disable setting	1	Setting	×
501 (1F5H)	701 (2BDH)	901 (385H)	1101 (44DH)	1301 (515H)	1501 (5DDH)	CH□ Averaging processing specification	0	Setting	×
502 (1F6H)	702 (2BEH)	902 (386H)	1102 (44EH)	1302 (516H)	1502 (5DEH)	CH□ Time average/Count average/Moving average/Primary delay filter constant setting	0	Setting	×
503 (1F7H)	703 (2BFH)	903 (387H)	1103 (44FH)	1303 (517H)	1503 (5DFH)	System area	—	—	—
504 (1F8H)	704 (2C0H)	904 (388H)	1104 (450H)	1304 (518H)	1504 (5E0H)	CH□ Scaling enable/disable setting	1	Setting	×
505 (1F9H)	705 (2C1H)	905 (389H)	1105 (451H)	1305 (519H)	1505 (5E1H)	System area	—	—	—
506 (1FAH)	706 (2C2H)	906 (38AH)	1106 (452H)	1306 (51AH)	1506 (5E2H)	CH□ Scaling upper limit value	0	Setting	×
507 (1FBH)	707 (2C3H)	907 (38BH)	1107 (453H)	1307 (51BH)	1507 (5E3H)	System area	—	—	—
508 (1FCH)	708 (2C4H)	908 (38CH)	1108 (454H)	1308 (51CH)	1508 (5E4H)	CH□ Scaling lower limit value	0	Setting	×
509 (1FDH)	709 (2C5H)	909 (38DH)	1109 (455H)	1309 (51DH)	1509 (5E5H)	System area	—	—	—
510 (1FEH)	710 (2C6H)	910 (38EH)	1110 (456H)	1310 (51EH)	1510 (5E6H)	CH□ Digital clipping enable/ disable setting	1	Setting	×
511 (1FFH)	711 (2C7H)	911 (38FH)	1111 (457H)	1311 (51FH)	1511 (5E7H)	System area	—	—	—
512 (200H)	712 (2C8H)	912 (390H)	1112 (458H)	1312 (520H)	1512 (5E8H)	CH□ Warning output setting (Process alarm)	1	Setting	×
513 (201H)	713 (2C9H)	913 (391H)	1113 (459H)	1313 (521H)	1513 (5E9H)	CH□ Warning output setting (Rate alarm)	1	Setting	×
514 (202H)	714 (2CAH)	914 (392H)	1114 (45AH)	1314 (522H)	1514 (5EAH)	CH□ Process alarm upper upper limit value	0	Setting	×



Address Decimal (hexadecimal)						Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4	CH5	CH6				
515 (203H)	715 (2CBH)	915 (393H)	1115 (45BH)	1315 (523H)	1515 (5EBH)	System area	—	—	—
516 (204H)	716 (2CCH)	916 (394H)	1116 (45CH)	1316 (524H)	1516 (5ECH)	CH□ Process alarm upper lower limit value	0	Setting	×
517 (205H)	717 (2CDH)	917 (395H)	1117 (45DH)	1317 (525H)	1517 (5EDH)	System area	—	—	—
518 (206H)	718 (2CEH)	918 (396H)	1118 (45EH)	1318 (526H)	1518 (5EEH)	CH□ Process alarm lower upper limit value	0	Setting	×
519 (207H)	719 (2CFH)	919 (397H)	1119 (45FH)	1319 (527H)	1519 (5EFH)	System area	—	—	—
520 (208H)	720 (2D0H)	920 (398H)	1120 (460H)	1320 (528H)	1520 (5F0H)	CH□ Process alarm lower lower limit value	0	Setting	×
521 (209H)	721 (2D1H)	921 (399H)	1121 (461H)	1321 (529H)	1521 (5F1H)	System area	—	—	—
522 (20AH)	722 (2D2H)	922 (39AH)	1122 (462H)	1322 (52AH)	1522 (5F2H)	CH□ Rate alarm warning detection cycle setting	0	Setting	×
523 (20BH)	723 (2D3H)	923 (39BH)	1123 (463H)	1323 (52BH)	1523 (5F3H)	System area	—	—	—
524 (20CH)	724 (2D4H)	924 (39CH)	1124 (464H)	1324 (52CH)	1524 (5F4H)	CH□ Rate alarm upper limit value	0	Setting	×
525 (20DH)	725 (2D5H)	925 (39DH)	1125 (465H)	1325 (52DH)	1525 (5F5H)	System area	—	—	—
526 (20EH)	726 (2D6H)	926 (39EH)	1126 (466H)	1326 (52EH)	1526 (5F6H)	CH□ Rate alarm lower limit value	0	Setting	×
527 (20FH)	727 (2D7H)	927 (39FH)	1127 (467H)	1327 (52FH)	1527 (5F7H)	System area	—	—	—
528 (210H)	728 (2D8H)	928 (3A0H)	1128 (468H)	1328 (530H)	1528 (5F8H)	CH□ Input signal error detection setting	0	Setting	×
529 (211H)	729 (2D9H)	929 (3A1H)	1129 (469H)	1329 (531H)	1529 (5F9H)	CH□ Input signal error detection lower limit set value	50	Setting	×
530 (212H)	730 (2DAH)	930 (3A2H)	1130 (46AH)	1330 (532H)	1530 (5FAH)	CH□ Input signal error detection upper limit set value	50	Setting	×
531 (213H)	731 (2DBH)	931 (3A3H)	1131 (46BH)	1331 (533H)	1531 (5FBH)	System area	—	—	—
532 (214H)	732 (2DCH)	932 (3A4H)	1132 (46CH)	1332 (534H)	1532 (5FCH)	CH□ Conversion start time setting (for 2-wire transmitter)	30	Setting	×
533 to 534 (215H to 216H)	733 to 734 (2DDH to 2DEH)	933 to 934 (3A5H to 3A6H)	1133 to 1134 (46DH to 46EH)	1333 to 1334 (535H to 536H)	1533 to 1534 (5FDH to 5FEH)	System area	—	—	—
535 (217H)	735 (2DFH)	935 (3A7H)	1135 (46FH)	1335 (537H)	1535 (5FFH)	CH□ Logging enable/disable setting	1	Setting	×
536 (218H)	736 (2E0H)	936 (3A8H)	1136 (470H)	1336 (538H)	1536 (600H)	CH□ Logging data setting	1	Setting	×
537 (219H)	737 (2E1H)	937 (3A9H)	1137 (471H)	1337 (539H)	1537 (601H)	CH□ Logging cycle setting value	160	Setting	×
538 (21AH)	738 (2E2H)	938 (3AAH)	1138 (472H)	1338 (53AH)	1538 (602H)	CH□ Logging cycle unit setting	1	Setting	×
539 (21BH)	739 (2E3H)	939 (3ABH)	1139 (473H)	1339 (53BH)	1539 (603H)	CH□ Post-trigger logging points	500	Setting	×
540 (21CH)	740 (2E4H)	940 (3ACH)	1140 (474H)	1340 (53CH)	1540 (604H)	CH□ Level trigger condition setting	0	Setting	×
541 (21DH)	741 (2E5H)	941 (3ADH)	1141 (475H)	1341 (53DH)	1541 (605H)	CH□ Trigger data	*1	Setting	×
542 (21EH)	742 (2E6H)	942 (3AEH)	1142 (476H)	1342 (53EH)	1542 (606H)	CH□ Trigger setting value	0	Setting	×
543 (21FH)	743 (2E7H)	943 (3AFH)	1143 (477H)	1343 (53FH)	1543 (607H)	System area	—	—	—

Address Decimal (hexadecimal)						Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4	CH5	CH6				
544 (220H)	744 (2E8H)	944 (3B0H)	1144 (478H)	1344 (540H)	1544 (608H)	CH□ Loading interrupt enable/ disable setting	1	Setting	×
545 (221H)	745 (2E9H)	945 (3B1H)	1145 (479H)	1345 (541H)	1545 (609H)	CH□ Logging read points setting value	100	Setting	×
546 to 597 (222H to 255H)	746 to 797 (2EAH to 31DH)	946 to 997 (3B2H to 3E5H)	1146 to 1197 (47AH to 4ADH)	1346 to 1397 (542H to 575H)	1546 to 1597 (60AH to 63DH)	System area	—	—	—
598 (256H)	798 (31EH)	998 (3E6H)	1198 (4AEH)	1398 (576H)	1598 (63EH)	CH□ Range setting	0	Setting	×
599 (257H)	799 (31FH)	999 (3E7H)	1199 (4AFH)	1399 (577H)	1599 (63FH)	System area	—	—	—

*1 The following shows the default values.

CH1: 402, CH2: 602, CH3: 802, CH4: 1002, CH5: 1202, CH6: 1402

■Error history (Un\G3600 to Un\G3759)

Address (decimal)	Address (hexadecimal)	Name			Default value	Data type	Auto refresh	
3600	E10H	Error history 1	Error code			0	Monitor	×
3601	E11H		Error time	First two digits of the year	Last two digits of the year			
3602	E12H			Month	Day			
3603	E13H			Hour	Minute			
3604	E14H			Second	Day of the week			
3605	E15H			Millisecond				
3606 to 3609	E16H to E19H	System area			—	—	—	
3610 to 3615	E1AH to E1FH	Error history 2	Same as error history 1			0	Monitor	×
3616 to 3619	E20H to E23H	System area			—	—	—	
3620 to 3625	E24H to E29H	Error history 3	Same as error history 1			0	Monitor	×
3626 to 3629	E2AH to E2DH	System area			—	—	—	
3630 to 3635	E2EH to E33H	Error history 4	Same as error history 1			0	Monitor	×
3636 to 3639	E34H to E37H	System area			—	—	—	
3640 to 3645	E38H to E3DH	Error history 5	Same as error history 1			0	Monitor	×
3646 to 3649	E3EH to E41H	System area			—	—	—	
3650 to 3655	E42H to E47H	Error history 6	Same as error history 1			0	Monitor	×
3656 to 3659	E48H to E4BH	System area			—	—	—	
3660 to 3665	E4CH to E51H	Error history 7	Same as error history 1			0	Monitor	×
3666 to 3669	E52H to E55H	System area			—	—	—	
3670 to 3675	E56H to E5BH	Error history 8	Same as error history 1			0	Monitor	×
3676 to 3679	E5CH to E5FH	System area			—	—	—	
3680 to 3685	E60H to E65H	Error history 9	Same as error history 1			0	Monitor	×
3686 to 3689	E66H to E69H	System area			—	—	—	
3690 to 3695	E6AH to E6FH	Error history 10	Same as error history 1			0	Monitor	×
3696 to 3699	E70H to E73H	System area			—	—	—	
3700 to 3705	E74H to E79H	Error history 11	Same as error history 1			0	Monitor	×
3706 to 3709	E7AH to E7DH	System area			—	—	—	
3710 to 3715	E7EH to E83H	Error history 12	Same as error history 1			0	Monitor	×
3716 to 3719	E84H to E87H	System area			—	—	—	
3720 to 3725	E88H to E8DH	Error history 13	Same as error history 1			0	Monitor	×
3726 to 3729	E8EH to E91H	System area			—	—	—	
3730 to 3735	E92H to E97H	Error history 14	Same as error history 1			0	Monitor	×
3736 to 3739	E98H to E9BH	System area			—	—	—	
3740 to 3745	E9CH to EA1H	Error history 15	Same as error history 1			0	Monitor	×
3746 to 3749	EA2H to EA5H	System area			—	—	—	
3750 to 3755	EA6H to EABH	Error history 16	Same as error history 1			0	Monitor	×
3756 to 3759	EACH to EAFH	System area			—	—	—	

■ Alarm history (Un\G3760 to Un\G3999)

Address (decimal)	Address (hexadecimal)	Name				Default value	Data type	Auto refresh
3760	EB0H	Alarm history 1	Alarm code			0	Monitor	×
3761	EB1H		Alarm time	First two digits of the year	Last two digits of the year			
3762	EB2H			Month	Day			
3763	EB3H			Hour	Minute			
3764	EB4H			Second	Day of the week			
3765	EB5H			Millisecond				
3766 to 3769	EB6H to EB9H	System area				—	—	—
3770 to 3775	EBAH to EBFH	Alarm history 2	Same as alarm history 1			0	Monitor	×
3776 to 3779	EC0H to EC3H	System area				—	—	—
3780 to 3785	EC4H to EC9H	Alarm history 3	Same as alarm history 1			0	Monitor	×
3786 to 3789	ECAH to ECDH	System area				—	—	—
3790 to 3795	ECEH to ED3H	Alarm history 4	Same as alarm history 1			0	Monitor	×
3796 to 3799	ED4H to ED7H	System area				—	—	—
3800 to 3805	ED8H to EDDH	Alarm history 5	Same as alarm history 1			0	Monitor	×
3806 to 3809	EDEH to EE1H	System area				—	—	—
3810 to 3815	EE2H to EE7H	Alarm history 6	Same as alarm history 1			0	Monitor	×
3816 to 3819	EE8H to EEBH	System area				—	—	—
3820 to 3825	EECH to EF1H	Alarm history 7	Same as alarm history 1			0	Monitor	×
3826 to 3829	EF2H to EF5H	System area				—	—	—
3830 to 3835	EF6H to EFBH	Alarm history 8	Same as alarm history 1			0	Monitor	×
3836 to 3839	EFCH to EFFH	System area				—	—	—
3840 to 3845	F00H to F05H	Alarm history 9	Same as alarm history 1			0	Monitor	×
3846 to 3849	F06H to F09H	System area				—	—	—
3850 to 3855	F0AH to F0FH	Alarm history 10	Same as alarm history 1			0	Monitor	×
3856 to 3859	F10H to F13H	System area				—	—	—
3860 to 3865	F14H to F19H	Alarm history 11	Same as alarm history 1			0	Monitor	×
3866 to 3869	F1AH to F1DH	System area				—	—	—
3870 to 3875	F1EH to F23H	Alarm history 12	Same as alarm history 1			0	Monitor	×
3876 to 3879	F24H to F27H	System area				—	—	—
3880 to 3885	F28H to F2DH	Alarm history 13	Same as alarm history 1			0	Monitor	×
3886 to 3889	F2EH to F31H	System area				—	—	—
3890 to 3895	F32H to F37H	Alarm history 14	Same as alarm history 1			0	Monitor	×
3896 to 3899	F38H to F3BH	System area				—	—	—
3900 to 3905	F3CH to F41H	Alarm history 15	Same as alarm history 1			0	Monitor	×
3906 to 3909	F42H to F45H	System area				—	—	—
3910 to 3915	F46H to F4BH	Alarm history 16	Same as alarm history 1			0	Monitor	×
3916 to 3999	F4CH to F9FH	System area				—	—	—

■Offset/gain setting (Un\G4000 to Un\G4131)

Address Decimal (hexadecimal)						Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4	CH5	CH6				
4000 to 4003 (FA0H to FA3H)						System area	—	—	—
4004 (FA4H)	4008 (FA8H)	4012 (FACH)	4016 (FB0H)	4020 (FB4H)	4024 (FB8H)	CH□ Factory default setting offset value (L)	0	User range setting	×
4005 (FA5H)	4009 (FA9H)	4013 (FADH)	4017 (FB1H)	4021 (FB5H)	4025 (FB9H)	CH□ Factory default setting offset value (H)	0	User range setting	×
4006 (FA6H)	4010 (FAAH)	4014 (FAEH)	4018 (FB2H)	4022 (FB6H)	4026 (FBAH)	CH□ Factory default setting gain value (L)	0	User range setting	×
4007 (FA7H)	4011 (FABH)	4015 (FAFH)	4019 (FB3H)	4023 (FB7H)	4027 (FBBH)	CH□ Factory default setting gain value (H)	0	User range setting	×
4028 (FBCH)	4032 (FC0H)	4036 (FC4H)	4040 (FC8H)	4044 (FCCH)	4048 (FD0H)	CH□ User range setting offset value (L)	0	User range setting	×
4029 (FBDH)	4033 (FC1H)	4037 (FC5H)	4041 (FC9H)	4045 (FCDH)	4049 (FD1H)	CH□ User range setting offset value (H)	0	User range setting	×
4030 (FBEH)	4034 (FC2H)	4038 (FC6H)	4042 (FCAH)	4046 (FCEH)	4050 (FD2H)	CH□ User range setting gain value (L)	0	User range setting	×
4031 (FBFH)	4035 (FC3H)	4039 (FC7H)	4043 (FCBH)	4047 (FCFH)	4051 (FD3H)	CH□ User range setting gain value (H)	0	User range setting	×
4052 to 4131 (FD4H to 1023H)						System area	—	—	—

■Un\G4132 to Un\G9999

Address Decimal (hexadecimal)						Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4	CH5	CH6				
4132 (1024H)	4134 (1026H)	4136 (1028H)	4138 (102AH)	4140 (102CH)	4142 (102EH)	CH□ Offset/gain setting mode (offset specification)	0	Setting	×
4133 (1025H)	4135 (1027H)	4137 (1029H)	4139 (102BH)	4141 (102DH)	4143 (102FH)	CH□ Offset/gain setting mode (gain specification)	0	Setting	×
4144 to 9999 (1030H to 270FH)						System area	—	—	—

■Logging data (Un\G10000 to Un\G15999)

Address Decimal (hexadecimal)						Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4	CH5	CH6				
10000 to 10999 (2710H to 2AF7H)	11000 to 11999 (2AF8H to 2EDFH)	12000 to 12999 (2EE0H to 32C7H)	13000 to 13999 (32C8H to 36AFH)	14000 to 14999 (36B0H to 3A97H)	15000 to 15999 (3A98H to 3E7FH)	CH□ Logging data	0	Monitor	×

■Un\G16000 to Un\G29999

Address Decimal (hexadecimal)						Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4	CH5	CH6				
16000 to 29999 (3E80H to 752FH)						System area	—	—	—

In Q compatible mode

■Un\G0 to Un\G199

Address Decimal (hexadecimal)						Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4	CH5	CH6				
0 (0H)						A/D conversion enable/disable setting	003FH	Setting	×
1 (1H)	2 (2H)	3 (3H)	4 (4H)	5 (5H)	6 (6H)	CH□ Time average/Count average/Moving average/Primary delay filter constant setting	0	Setting	×
7 to 9 (7H to 9H)						System area	—	—	—
10 (AH)						A/D conversion completed flag	0000H	Monitor	○
11 (BH)	12 (CH)	13 (DH)	14 (EH)	15 (FH)	16 (10H)	CH□ Digital output value	0	Monitor	○
17 to 18 (11H to 12H)						System area	—	—	—
19 (13H)						Latest error code	0	Monitor	○
20 (14H)				21 (15H)		Range setting monitor	0000H	Monitor	×
22 (16H)						Offset/gain setting mode (offset specification)	0000H	Setting	×
23 (17H)						Offset/gain setting mode (gain specification)	0000H	Setting	×
24 (18H)				25 (19H)		Averaging processing specification	0	Setting	×
26 to 28 (1AH to 1CH)						System area	—	—	—
29 (1DH)						Digital clipping enable/disable setting	003FH	Setting	×
30 (1EH)	32 (20H)	34 (22H)	36 (24H)	38 (26H)	40 (28H)	CH□ Maximum value	0	Monitor	○
31 (1FH)	33 (21H)	35 (23H)	37 (25H)	39 (27H)	41 (29H)	CH□ Minimum value	0	Monitor	○
42 to 46 (2AH to 2EH)						System area	—	—	—
47 (2FH)						Input signal error detection extension/input signal error detection setting	003FH	Setting	×
48 (30H) (b13 to b8: Rate alarm/b5 to b0: Process alarm)						Warning output setting (Process alarm) Warning output setting (Rate alarm)	3F3FH	Setting	×
49 (31H)						Input signal error detection flag	0000H	Monitor	○
50 (32H)						Warning output flag (Process alarm)	0000H	Monitor	○
51 (33H)						Warning output flag (Rate alarm)	0000H	Monitor	○
52 (34H)						System area	—	—	—
53 (35H)						Scaling enable/disable setting	003FH	Setting	×
54 (36H)	55 (37H)	56 (38H)	57 (39H)	58 (3AH)	59 (3BH)	CH□ Digital operation value	0	Monitor	○
60 to 61 (3CH to 3DH)						System area	—	—	—
62 (3EH)	64 (40H)	66 (42H)	68 (44H)	70 (46H)	72 (48H)	CH□ Scaling lower limit value	0	Setting	×
63 (3FH)	65 (41H)	67 (43H)	69 (45H)	71 (47H)	73 (49H)	CH□ Scaling upper limit value	0	Setting	×
74 to 77 (4AH to 4DH)						System area	—	—	—
78 (4EH)	79 (4FH)	80 (50H)	81 (51H)	82 (52H)	83 (53H)	CH□ Conversion start time setting (for 2-wire transmitter)	30	Setting	×
84 to 85 (54H to 55H)						System area	—	—	—
86 (56H)	90 (5AH)	94 (5EH)	98 (62H)	102 (66H)	106 (6AH)	CH□ Process alarm lower lower limit value	0	Setting	×
87 (57H)	91 (5BH)	95 (5FH)	99 (63H)	103 (67H)	107 (6BH)	CH□ Process alarm lower upper limit value	0	Setting	×

A

Address Decimal (hexadecimal)						Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4	CH5	CH6				
88 (58H)	92 (5CH)	96 (60H)	100 (64H)	104 (68H)	108 (6CH)	CH□ Process alarm upper lower limit value	0	Setting	×
89 (59H)	93 (5DH)	97 (61H)	101 (65H)	105 (69H)	109 (6DH)	CH□ Process alarm upper upper limit value	0	Setting	×
110 to 117 (6EH to 75H)						System area	—	—	—
118 (76H)	119 (77H)	120 (78H)	121 (79H)	122 (7AH)	123 (7BH)	CH□ Rate alarm warning detection cycle setting	0	Setting	×
124 to 125 (7CH to 7DH)						System area	—	—	—
126 (7EH)	128 (80H)	130 (82H)	132 (84H)	134 (86H)	136 (88H)	CH□ Rate alarm upper limit value	0	Setting	×
127 (7FH)	129 (81H)	131 (83H)	133 (85H)	135 (87H)	137 (89H)	CH□ Rate alarm lower limit value	0	Setting	×
138 to 141 (8AH to 8DH)						System area	—	—	—
142 (8EH)	143 (8FH)	144 (90H)	145 (91H)	146 (92H)	147 (93H)	CH□ Input signal error detection setting value/CH□ Input signal error detection lower limit set value	50	Setting	×
148 to 149 (94H to 95H)						System area	—	—	—
150 (96H)	151 (97H)	152 (98H)	153 (99H)	154 (9AH)	155 (9BH)	CH□ Input signal error detection upper limit set value	50	Setting	×
156 to 157 (9CH to 9DH)						System area	—	—	—
158 (9EH)						Mode switching setting (L)	0	Setting	×
159 (9FH)						Mode switching setting (H)	0	Setting	×
160 to 161 (A0H to A1H)						System area	—	—	—
162 (A2H)						Input signal error detection auto- clear enable/disable setting	1	Setting	×
163 (A3H)						System area	—	—	—
164 (A4H)	165 (A5H)	166 (A6H)	167 (A7H)	168 (A8H)	169 (A9H)	CH□ Conversion value shift amount	0	Control	○
170 to 171 (AAH to ABH)						System area	—	—	—
172 (ACH)	173 (ADH)	174 (AEH)	175 (AFH)	176 (B0H)	177 (B1H)	CH□ Difference conversion trigger	0	Control	○
178 to 179 (B2H to B3H)						System area	—	—	—
180 (B4H)	181 (B5H)	182 (B6H)	183 (B7H)	184 (B8H)	185 (B9H)	CH□ Difference conversion reference value	0	Monitor	×
186 to 189 (BAH to BDH)						System area	—	—	—
190 (BEH)	191 (BFH)	192 (C0H)	193 (C1H)	194 (C2H)	195 (C3H)	CH□ Difference conversion status flag	0	Monitor	○
196 to 199 (C4H to C7H)						System area	—	—	—

■Un\G200 to Un\G999

Address Decimal (hexadecimal)						Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4	CH5	CH6				
200 to 201 (C8H to C9H)						System area	—	—	—
202 (CAH)	206 (CEH)	210 (D2H)	214 (D6H)	218 (DAH)	222 (DEH)	CH□ Factory default setting offset value (L)	0	User range setting	×
203 (CBH)	207 (CFH)	211 (D3H)	215 (D7H)	219 (DBH)	223 (DFH)	CH□ Factory default setting offset value (H)	0	User range setting	×
204 (CCH)	208 (D0H)	212 (D4H)	216 (D8H)	220 (DCH)	224 (E0H)	CH□ Factory default setting gain value (L)	0	User range setting	×
205 (CDH)	209 (D1H)	213 (D5H)	217 (D9H)	221 (DDH)	225 (E1H)	CH□ Factory default setting gain value (H)	0	User range setting	×
226 (E2H)	230 (E6H)	234 (EAH)	238 (EEH)	242 (F2H)	246 (F6H)	CH□ User range setting offset value (L)	0	User range setting	×
227 (E3H)	231 (E7H)	235 (EBH)	239 (EFH)	243 (F3H)	247 (F7H)	CH□ User range setting offset value (H)	0	User range setting	×
228 (E4H)	232 (E8H)	236 (ECH)	240 (F0H)	244 (F4H)	248 (F8H)	CH□ User range setting gain value (L)	0	User range setting	×
229 (E5H)	233 (E9H)	237 (EDH)	241 (F1H)	245 (F5H)	249 (F9H)	CH□ User range setting gain value (H)	0	User range setting	×
250 to 299 (FAH to 12BH)						System area	—	—	—
300 (12CH)	302 (12EH)	304 (130H)	306 (132H)	308 (134H)	310 (136H)	CH□ Digital output value (32 bits) (L)	0	Monitor	○
301 (12DH)	303 (12FH)	305 (131H)	307 (133H)	309 (135H)	311 (137H)	CH□ Digital output value (32 bits) (H)	0	Monitor	○
312 to 319 (138H to 13FH)						System area	—	—	—
320 (140H)						RUN LED status monitor	0	Monitor	×
321 (141H)						ERR LED status monitor	0	Monitor	×
322 (142H)						ALM LED status monitor	0	Monitor	×
323 to 329 (143H to 149H)						System area	—	—	—
330 (14AH)	331 (14BH)	332 (14CH)	333 (14DH)	334 (14EH)	335 (14FH)	CH□ Supply power temporary stop trigger (for 2-wire transmitter)	0	Control	○
336 to 339 (150H to 153H)						System area	—	—	—
340 (154H)	341 (155H)	342 (156H)	343 (157H)	344 (158H)	345 (159H)	CH□ Supply power temporary stop status flag (for 2-wire transmitter)	0	Monitor	○
346 to 401 (15AH to 191H)						System area	—	—	—
402 (192H)				403 (193H)		Range setting	0	Setting	×
404 to 999 (194H to 3E7H)						System area	—	—	—

■Un\G1000 to Un\G4999

Address Decimal (hexadecimal)						Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4	CH5	CH6				
1000 (3E8H)	1001 (3E9H)	1002 (3EAH)	1003 (3EBH)	1004 (3ECH)	1005 (3EDH)	CH□ Logging enable/disable setting	1	Setting	×
1006 to 1007 (3EEH to 3EFH)						System area	—	—	—
1008 (3F0H)	1009 (3F1H)	1010 (3F2H)	1011 (3F3H)	1012 (3F4H)	1013 (3F5H)	CH□ Logging hold request	0	Control	○
1014 to 1015 (3F6H to 3F7H)						System area	—	—	—
1016 (3F8H)	1017 (3F9H)	1018 (3FAH)	1019 (3FBH)	1020 (3FCH)	1021 (3FDH)	CH□ Logging hold flag	0	Monitor	○
1022 to 1023 (3FEH to 3FFH)						System area	—	—	—
1024 (400H)	1025 (401H)	1026 (402H)	1027 (403H)	1028 (404H)	1029 (405H)	CH□ Logging data setting	1	Setting	×
1030 to 1031 (406H to 407H)						System area	—	—	—
1032 (408H)	1033 (409H)	1034 (40AH)	1035 (40BH)	1036 (40CH)	1037 (40DH)	CH□ Logging cycle setting value	60	Setting	×
1038 to 1039 (40EH to 40FH)						System area	—	—	—
1040 (410H)	1041 (411H)	1042 (412H)	1043 (413H)	1044 (414H)	1045 (415H)	CH□ Logging cycle unit setting	1	Setting	×
1046 to 1047 (416H to 417H)						System area	—	—	—
1048 (418H)	1049 (419H)	1050 (41AH)	1051 (41BH)	1052 (41CH)	1053 (41DH)	CH□ Post-trigger logging points	500	Setting	×
1054 to 1055 (41EH to 41FH)						System area	—	—	—
1056 (420H)	1057 (421H)	1058 (422H)	1059 (423H)	1060 (424H)	1061 (425H)	CH□ Level trigger condition setting	0	Setting	×
1062 to 1063 (426H to 427H)						System area	—	—	—
1064 (428H)	1065 (429H)	1066 (42AH)	1067 (42BH)	1068 (42CH)	1069 (42DH)	CH□ Trigger data	*1	Setting	×
1070 to 1071 (42EH to 42FH)						System area	—	—	—
1072 to 1081 (430H to 439H)						Level data 0 to 9	0	Control	○
1082 (43AH)	1083 (43BH)	1084 (43CH)	1085 (43DH)	1086 (43EH)	1087 (43FH)	CH□ Trigger setting value	0	Setting	×
1088 to 1089 (440H to 441H)						System area	—	—	—
1090 (442H)	1091 (443H)	1092 (444H)	1093 (445H)	1094 (446H)	1095 (447H)	CH□ Head pointer	0	Monitor	×
1096 to 1097 (448H to 449H)						System area	—	—	—
1098 (44AH)	1099 (44BH)	1100 (44CH)	1101 (44DH)	1102 (44EH)	1103 (44FH)	CH□ Latest pointer	0	Monitor	×
1104 to 1105 (450H to 451H)						System area	—	—	—
1106 (452H)	1107 (453H)	1108 (454H)	1109 (455H)	1110 (456H)	1111 (457H)	CH□ Number of logging data	0	Monitor	×
1112 to 1113 (458H to 459H)						System area	—	—	—
1114 (45AH)	1115 (45BH)	1116 (45CH)	1117 (45DH)	1118 (45EH)	1119 (45FH)	CH□ Trigger pointer	0	Monitor	×
1120 to 1121 (460H to 461H)						System area	—	—	—
1122 (462H)	1125 (465H)	1128 (468H)	1131 (46BH)	1134 (46EH)	1137 (471H)	CH□ Logging cycle monitored value (s)	0	Monitor	×
1123 (463H)	1126 (466H)	1129 (469H)	1132 (46CH)	1135 (46FH)	1138 (472H)	CH□ Logging cycle monitored value (ms)	0	Monitor	×
1124 (464H)	1127 (467H)	1130 (46AH)	1133 (46DH)	1136 (470H)	1139 (473H)	System area	—	—	—
1140 to 1153 (474H to 481H)						System area	—	—	—
1154 (482H)	1158 (486H)	1162 (48AH)	1166 (48EH)	1170 (492H)	1174 (496H)	CH□ Trigger generation time (First/Last two digits of the year)	0	Monitor	×
1155 (483H)	1159 (487H)	1163 (48BH)	1167 (48FH)	1171 (493H)	1175 (497H)	CH□ Trigger generation time (Month/Day)	0	Monitor	×

Address Decimal (hexadecimal)						Name	Default value	Data type	Auto refresh
CH1	CH2	CH3	CH4	CH5	CH6				
1156 (484H)	1160 (488H)	1164 (48CH)	1168 (490H)	1172 (494H)	1176 (498H)	CH□ Trigger generation time (Hour/Minute)	0	Monitor	×
1157 (485H)	1161 (489H)	1165 (48DH)	1169 (491H)	1173 (495H)	1177 (499H)	CH□ Trigger generation time (Second/Day of the week)	0	Monitor	×
1178 to 1185 (49AH to 4A1H)						System area	—	—	—
1186 (4A2H)	1187 (4A3H)	1188 (4A4H)	1189 (4A5H)	1190 (4A6H)	1191 (4A7H)	CH□ Trigger generation time (Millisecond)	0	Monitor	×
1192 to 1199 (4A8H to 4AFH)						System area	—	—	—
1200 (4B0H)	1201 (4B1H)	1202 (4B2H)	1203 (4B3H)	1204 (4B4H)	1205 (4B5H)	CH□ Loading interrupt enable/ disable setting	1	Setting	×
1206 to 1207 (4B6H to 4B7H)						System area	—	—	—
1208 (4B8H)	1209 (4B9H)	1210 (4BAH)	1211 (4BBH)	1212 (4BCH)	1213 (4BDH)	CH□ Logging read points setting value	100	Setting	×
1214 to 1215 (4BEH to 4BFH)						System area	—	—	—
1216 (4C0H)	1217 (4C1H)	1218 (4C2H)	1219 (4C3H)	1220 (4C4H)	1221 (4C5H)	CH□ Current logging read pointer	-1	Setting	×
1222 to 1223 (4C6H to 4C7H)						System area	—	—	—
1224 (4C8H)	1225 (4C9H)	1226 (4CAH)	1227 (4CBH)	1228 (4CCH)	1229 (4CDH)	CH□ Previous logging read pointer	-1	Setting	×
1230 to 1231 (4CEH to 4CFH)						System area	—	—	—
1232 (4D0H)	1233 (4D1H)	1234 (4D2H)	1235 (4D3H)	1236 (4D4H)	1237 (4D5H)	CH□ Logging read points monitored value	0	Monitor	×
1238 to 1799 (4D6H to 707H)						System area	—	—	—
1800 (708H)						Latest address of error history	0	Monitor	○
1801 to 1809 (709H to 711H)						System area	—	—	—
1810 to 1969 (712H to 7B1H)						Error history 1 to 16	0	Monitor	×
1970 to 3749 (7B2H to EA5H)						System area	—	—	—
3750 (EA6H)						Latest alarm code	0	Monitor	○
3751 (EA7H)						Latest address of alarm history	0	Monitor	○
3752 to 3759 (EA8H to EAFH)						System area	—	—	—
3760 to 3919 (EB0H to F4FH)						Alarm history 1 to 16	0	Monitor	×
3920 to 3999 (F50H to F9FH)						System area	—	—	—
4000 to 4015 (FA0H to FAFH)						Interrupt factor detection flag [n] ^{*2}	0	Monitor	○
4016 to 4031 (FB0H to FBFH)						System area	—	—	—
4032 to 4047 (FC0H to FCFH)						Interrupt factor mask [n] ^{*2}	0	Control	×
4048 to 4063 (FD0H to FDFH)						System area	—	—	—
4064 to 4079 (FE0H to FEFH)						Interrupt factor reset request [n] ^{*2}	0	Control	×
4080 to 4095 (FF0H to FFFH)						System area	—	—	—
4096 to 4111 (1000H to 100FH)						Interrupt factor generation setting [n] ^{*2}	0	Setting	×
4112 to 4127 (1010H to 101FH)						System area	—	—	—
4128 to 4143 (1020H to 102FH)						Condition target setting [n] ^{*2}	0	Setting	×
4144 to 4159 (1030H to 103FH)						System area	—	—	—
4160 to 4175 (1040H to 104FH)						Condition target channel setting [n] ^{*2}	0	Setting	×
4176 to 4999 (1050H to 1387H)						System area	—	—	—

*1 The following shows the default values.

CH1: 54, CH2: 55, CH3: 56, CH4: 57, CH5: 58, CH6: 59

*2 [n] in the table indicates an interrupt setting number. (n = 1 to 16)

■ Logging data (Un\G5000 to Un\G10999)

Address Decimal (hexadecimal)	Name	Default value	Data type	Auto refresh
5000 to 5999 (1388H to 176FH)	CH1 Logging data	0	Monitor	×
6000 to 6999 (1770H to 1B57H)	CH2 Logging data	0	Monitor	×
7000 to 7999 (1B58H to 1F3FH)	CH3 Logging data	0	Monitor	×
8000 to 8999 (1F40H to 2327H)	CH4 Logging data	0	Monitor	×
9000 to 9999 (2328H to 270FH)	CH5 Logging data	0	Monitor	×
10000 to 10999 (2710H to 2AF7H)	CH6 Logging data	0	Monitor	×

Details of buffer memory addresses

The following describes the details of the buffer memory addresses of the A/D converter module.



This section describes buffer memory addresses for CH1.

Latest error code

The latest error code detected in the A/D converter module is stored. For details, refer to the following.

Page 114 List of Error Codes

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 0
- Q compatible mode: 19

■Clearing an error

Turn on and off 'Error clear request' (YF).

Latest address of error history

Among Error history □ (Un\G3600 to Un\G3759), a buffer memory address which stores the latest error code is stored. In the Q compatible mode, the error history is stored in Un\G1810 to Un\G1969.

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 1
- Q compatible mode: 1800

Latest alarm code

The latest alarm code detected in the A/D converter module is stored. For details, refer to the following.

Page 117 List of Alarm Codes

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 2
- Q compatible mode: 3750

■Clearing an alarm

Turn on and off 'Error clear request' (YF).

Latest address of alarm history

Among Alarm history □ (Un\G3760 to Un\G3999), a buffer memory address which stores the latest alarm code is stored.

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 3
- Q compatible mode: 3751

Interrupt factor detection flag [n]

The detection status of the interrupt factor is stored.

Monitored value	Description
0	No interrupt factor
1	Interrupt factor

When an interrupt factor occurs, an interrupt request is sent to the CPU module at the same time as 'Interrupt factor detection flag [n]' (Un\G4 to Un\G19) is turned to Interrupt factor (1).

"n" indicates an interrupt setting number. (n = 1 to 16)

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 4 to 19
- Q compatible mode: 4000 to 4015

Warning output flag (Process alarm upper limit)

The upper limit alarm of the process alarm can be checked for each channel.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)										CH6 upper limit value	CH5 upper limit value	CH4 upper limit value	CH3 upper limit value	CH2 upper limit value	CH1 upper limit value

- 0: Normal
- 1: Alarm ON

■Buffer memory address

The following shows the buffer memory address of this area.

R mode: 36

■Warning output flag status

- When the value is out of the range specified in the process alarm upper upper limit value, Alarm ON (1) is stored in 'Warning output flag (Process alarm upper limit)' (Un\G36) corresponding to each channel.
- When a warning is detected in any channel where the A/D conversion and the warning output setting (Process alarm) are enabled, 'Warning output signal' (X8) also turns on.

■Clearing Warning output flag

- When the digital operation value returns within the setting range, the flag is automatically cleared.
- When 'Operating condition setting request' (Y9) is turned on and off, the flag is cleared.

Warning output flag (Process alarm lower limit)

The lower limit alarm of the process alarm can be checked for each channel.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)										CH6 lower limit value	CH5 lower limit value	CH4 lower limit value	CH3 lower limit value	CH2 lower limit value	CH1 lower limit value

0: Normal

1: Alarm ON

■Buffer memory address

The following shows the buffer memory address of this area.

R mode: 37

■Warning output flag status

- When the value is out of the range specified in the process alarm lower limit value, Alarm ON (1) is stored in 'Warning output flag (Process alarm lower limit)' (Un\G37) corresponding to each channel.
- When a warning is detected in any channel where the A/D conversion and the warning output setting (Process alarm) are enabled, 'Warning output signal' (X8) also turns on.

■Clearing Warning output flag

- When the digital operation value returns within the setting range, the flag is automatically cleared.
- When 'Operating condition setting request' (Y9) is turned on and off, the flag is cleared.

Warning output flag (Process alarm) [Q compatible mode]

When the Q compatible mode function is used, the upper/lower limit alarm of the process alarm can be checked.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)				CH6 lower limit value	CH6 upper limit value	CH5 lower limit value	CH5 upper limit value	CH4 lower limit value	CH4 upper limit value	CH3 lower limit value	CH3 upper limit value	CH2 lower limit value	CH2 upper limit value	CH1 lower limit value	CH1 upper limit value

0: Normal

1: Alarm ON

■Buffer memory address

The following shows the buffer memory address of this area.

Q compatible mode: 50

■Warning output flag status

- When the value is out of the range specified in the process alarm upper limit value or process alarm lower limit value, Alarm ON (1) is stored in 'Warning output flag (Process alarm)' (Un\G50) corresponding to each channel.
- When a warning is detected in any channel where the A/D conversion and the warning output setting (Process alarm) are enabled, 'Warning output signal' (X8) also turns on.

■Clearing Warning output flag

- When the digital operation value returns within the setting range, the flag is automatically cleared.
- When 'Operating condition setting request' (Y9) is turned on and off, the flag is cleared.

Warning output flag (Rate alarm upper limit)

The upper limit alarm of the rate alarm can be checked for each channel.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)										CH6 upper limit value	CH5 upper limit value	CH4 upper limit value	CH3 upper limit value	CH2 upper limit value	CH1 upper limit value

0: Normal
1: Alarm ON

■Buffer memory address

The following shows the buffer memory address of this area.

R mode: 38

■Warning output flag status

- When the value is out of the range specified in the rate alarm upper limit value, Alarm ON (1) is stored in 'Warning output flag (Rate alarm upper limit)' (Un\G38) corresponding to each channel.
- When a warning is detected in any channel where the A/D conversion and the warning output setting (Rate alarm) are enabled, 'Warning output signal' (X8) also turns on.

■Clearing Warning output flag

- When the change rate of the digital output value returns within the setting range, the flag is automatically cleared.
- When 'Operating condition setting request' (Y9) is turned on and off, the flag is cleared.

Warning output flag (Rate alarm lower limit)

The lower limit alarm of the rate alarm can be checked for each channel.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)										CH6 lower limit value	CH5 lower limit value	CH4 lower limit value	CH3 lower limit value	CH2 lower limit value	CH1 lower limit value

0: Normal
1: Alarm ON

■Buffer memory address

The following shows the buffer memory address of this area.

R mode: 39

■Warning output flag status

- When the value is out of the range specified in the rate alarm lower limit value, Alarm ON (1) is stored in 'Warning output flag (Rate alarm lower limit)' (Un\G39) corresponding to each channel.
- When a warning is detected in any channel where the A/D conversion and the warning output setting (Rate alarm) are enabled, 'Warning output signal' (X8) also turns on.

■Clearing Warning output flag

- When the change rate of the digital output value returns within the setting range, the flag is automatically cleared.
- When 'Operating condition setting request' (Y9) is turned on and off, the flag is cleared.

Warning output flag (Rate alarm) [Q compatible mode]

When the Q compatible mode function is used, the upper/lower limit alarm of the rate alarm can be checked.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)				CH6 lower limit value	CH6 upper limit value	CH5 lower limit value	CH5 upper limit value	CH4 lower limit value	CH4 upper limit value	CH3 lower limit value	CH3 upper limit value	CH2 lower limit value	CH2 upper limit value	CH1 lower limit value	CH1 upper limit value

0: Normal

1: Alarm ON

■Buffer memory address

The following shows the buffer memory address of this area.

Q compatible mode: 51

■Warning output flag status

- When the value is out of the range specified in the rate alarm upper limit value or rate alarm lower limit value, Alarm ON (1) is stored in Warning output flag (Rate alarm) corresponding to each channel.
- When a warning is detected in any channel where the A/D conversion and the warning output setting (Rate alarm) are enabled, 'Warning output signal' (X8) also turns on.

■Clearing Warning output flag

- When the change rate of the digital output value returns within the setting range, the flag is automatically cleared.
- When 'Operating condition setting request' (Y9) is turned on and off, the flag is cleared.

Input signal error detection flag

The status of an input signal can be checked for each channel.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)										CH6	CH5	CH4	CH3	CH2	CH1

0: Normal

1: Input signal error

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 40
- Q compatible mode: 49

■Input signal error detection flag status

- When an analog input value out of the range specified in Input signal error detection setting value is detected, Input signal error (1) is stored in 'Input signal error detection flag' (Un\G40) corresponding to each channel.
- When an error is detected in any channel where the A/D conversion and the input signal error detection are enabled, 'Input signal error detection signal' (XC) turns on.

■Clearing Input signal error detection flag

'Input signal error detection flag' (Un\G40) is turned off by turning on and off 'Error clear request' (YF) after the analog input value returns within the setting range.

When 'Operating condition setting request' (Y9) is turned on and off, 'Input signal error detection flag' (Un\G40) is also cleared.

A/D conversion completed flag

The A/D conversion status can be checked.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)										CH6	CH5	CH4	CH3	CH2	CH1

0: A/D conversion in progress or not used
1: A/D conversion completed

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 42
- Q compatible mode: 10

■A/D conversion completed flag status

When the first A/D conversion is completed in the channel where the A/D conversion is enabled, the flag turns to A/D conversion completed (1). 'A/D conversion completed flag' (XE) turns on when the conversion of all the channels where the A/D conversion is enabled is completed.

■Clearing A/D conversion completed flag

Turning on and off 'Operating condition setting request' (Y9) turns the flag back to the default (A/D conversion in progress or not used (0)), and when the first A/D conversion has completed, the flag turns to A/D conversion completed (1) again.

■Precautions on the 2-wire transmitter range

For the 2-wire transmitter range channel where the external power supply is off or Trigger request (1) is set for 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (Un\G473)^{*1}, because A/D conversion does not start even when conversion is enabled, 'A/D conversion completed flag' (Un\G42) turns into A/D conversion in progress or not used (0).

*1 In Q compatible mode, it becomes 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (Un\G330).

RUN LED status monitor

The current RUN LED status is stored.

Monitored value	Description
0	Off
1	On
2	Flashing (1s cycles)
3	Flashing (400ms cycles)

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 70
- Q compatible mode: 320

ERR LED status monitor

The current ERR LED status is stored.

Monitored value	Description
0	Off
1	On
2	Flashing (1s cycles)
3	Flashing (400ms cycles)

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 71
- Q compatible mode: 321

ALM LED status monitor

The current ALM LED status is stored.

Monitored value	Description
0	Off
1	On
2	Flashing (1s cycles)
3	Flashing (400ms cycles)

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 72
- Q compatible mode: 322

Level data 0 to 9

This area stores data to be monitored when a level trigger of the logging function is used. Ten types of data are available: 'Level data 0' (Un\G90) to 'Level data 9' (Un\G99). Use the area to generate triggers while monitoring the values of devices other than the A/D converter module.

For details on the logging function, refer to the following.

 Page 63 Logging Function

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 90 to 99
- Q compatible mode: 1072 to 1081

■Setting range

The setting range is from -32768 to 32767.

■Default value

The default value is 0 for all channels.

Interrupt factor mask [n]

Set Interrupt factor mask to be used.

Setting value	Setting content
0	Mask (Interrupt unused)
1	Mask clear (Interrupt used)

When 'Interrupt factor mask [n]' (Un\G124 to Un\G139) is changed to Mask clear (Interrupt used) (1) and an interrupt factor occurs, an interrupt request is sent to the CPU module. When the set value is two or larger, the setting is regarded as Mask clear (Interrupt used) (1).

"n" indicates an interrupt setting number. (n = 1 to 16)

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 124 to 139
- Q compatible mode: 4032 to 4047

■Default value

The default value is set to Mask (Interrupt unused) (0) for all channels.

Interrupt factor reset request [n]

An interrupt factor reset request is sent.

Setting value	Setting content
0	No reset request
1	Reset request

When Reset request (1) is set to 'Interrupt factor reset request [n]' (Un\G156 to Un\G171) corresponding to the interrupt factor, the interrupt factor corresponding to the specified interrupt is reset. After that, 'Interrupt factor reset request [n]' (Un\G156 to Un\G171) turns to No reset request (0). When the set value is two or larger, the setting is regarded as Reset request (1).

Interrupt factors can be reset by turning on and off 'Operating condition setting request' (Y9).

"n" indicates an interrupt setting number. (n = 1 to 16)

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 156 to 171
- Q compatible mode: 4064 to 4079

■Default value

The default value is No reset request (0) for all channels.

Interrupt factor generation setting [n]

Set an interrupt request for when the same interrupt factor occurs during the interrupt factor detection.

Setting value	Setting content
0	Interrupt resend request
1	No interrupt resend request

When 'Interrupt factor generation setting [n]' (Un\G200 to Un\G215) is Interrupt resend request (0) and the same interrupt factor occurs during the interrupt factor detection, an interrupt request is sent to the CPU module again.

If a value other than the above is set, an interrupt factor generation setting range error (error code: 180△H) occurs.

"n" indicates an interrupt setting number. (n = 1 to 16)

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 200 to 215
- Q compatible mode: 4096 to 4111

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is Interrupt resend request (0) for all channels.

Condition target setting [n]

Set an interrupt factor to be detected.

Setting value	Setting content
0	Disable
1	Error flag (XF)
2	Warning output flag (Process alarm)
3	Warning output flag (Rate alarm)
4	Input signal error detection flag
5	A/D conversion completed
6	Logging hold flag
7	Logging read
8	External power supply READY flag (X6)

If a value other than the above is set, a condition target setting range error (error code: 181△H) occurs.

An interrupt request is sent to the CPU module when 'Error flag' (XF) or the buffer memory area set to 'Condition target setting [n]' (Un\G232 to Un\G247) is turned on, and when 'External power supply READY flag' (X6) is turned off. When A/D conversion completed (5) is set, an interrupt request is sent with 'A/D conversion completed flag' (Un\G42) on.

"n" indicates an interrupt setting number. (n = 1 to 16)

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 232 to 247
- Q compatible mode: 4128 to 4143

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is Disable (0) for all channels.

Condition target channel setting [n]

Set a channel where an interrupt is detected.

Setting value	Setting content
0	All channels
1	CH1
2	CH2
3	CH3
4	CH4
5	CH5
6	CH6

When a factor for the channel specification is set to 'Condition target setting [n]' (Un\G232 to Un\G247), an interrupt factor in the channel set by this area is monitored. When a factor of the input signal (X) is set, the setting in this area is ignored.

If a value other than the above is set, a condition target channel setting range error (error code: 182△H) occurs.

"n" indicates an interrupt setting number. (n = 1 to 16)

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 264 to 279
- Q compatible mode: 4160 to 4175

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is All channels (0) for all channels.

Mode switching setting (L)

Set a setting value for the mode to be switched.

Switching mode	Setting value
Normal mode	5260H
Offset/gain setting mode	4144H



If a value other than the above is set, the mode is not switched and only the operating condition is changed.

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 296
- Q compatible mode: 158

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■After the mode is switched

When the mode is switched, this area is cleared to 0 and 'Operating condition setting completed flag' (X9) turns off.

After checking that 'Operating condition setting completed flag' (X9) is off, turn off 'Operating condition setting request' (Y9).

Mode switching setting (H)

Set a setting value for the mode to be switched.

Switching mode	Setting value
Normal mode	4144H
Offset/gain setting mode	5260H



If a value other than the above is set, the mode is not switched and only the operating condition is changed.

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 297
- Q compatible mode: 159

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■After the mode is switched

When the mode is switched, this area is cleared to 0 and 'Operating condition setting completed flag' (X9) turns off.

After checking that 'Operating condition setting completed flag' (X9) is off, turn off 'Operating condition setting request' (Y9).

Input signal error detection auto-clear enable/disable setting

Set whether to enable or disable auto-clearing of input signal errors by using the input signal error detection function.

For details on the input signal error detection function, refer to the following.

Page 38 Input Signal Error Detection Function

Setting value	Setting content
0	Enable
1	Disable

If a value other than the above is set, the value is regarded as Disable (1).

■Buffer memory address

The following shows the buffer memory address of this area.

- R mode: 302
- Q compatible mode: 162

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is Disable (1).

CH1 Digital output value

The A/D-converted digital output value is stored in 16-bit signed binary value.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
(1)	Data section														

- (1) Sign bit
• 0: Positive
• 1: Negative

■ Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Digital output value

CH1	CH2	CH3	CH4	CH5	CH6
400	600	800	1000	1200	1400

- CH□ Digital output value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
11	12	13	14	15	16

■ Refreshing cycle

If averaging processing is performed, values are updated at every averaging processing cycle, but if not performed, values are updated at every sampling cycle.

CH1 Digital operation value

A digital operation value obtained by the scaling function, shift function, digital clipping function, or difference conversion function is stored in 16-bit signed binary value.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
(1)	Data section														

- (1) Sign bit
• 0: Positive
• 1: Negative

■ Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Digital operation value

CH1	CH2	CH3	CH4	CH5	CH6
402	602	802	1002	1202	1402

- CH□ Digital operation value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
54	55	56	57	58	59



When the scaling function, shift function, digital clipping function, or difference conversion function is not used, a value which is the same as the one in 'CH1 Digital output value' (Un\G400) is stored.

CH1 Maximum value

The maximum value of the digital operation value is stored in 16-bit signed binary value.

In the following cases, 'CH1 Maximum value' (Un\G404) is updated with the current value.

- When 'Operating condition setting request' (Y9) is turned on and off and the setting is changed
- When 'Maximum value/minimum value reset request' (YD) is turned on and off

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
(1)	Data section														

- (1) Sign bit
- 0: Positive
 - 1: Negative

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Maximum value

CH1	CH2	CH3	CH4	CH5	CH6
404	604	804	1004	1204	1404

- CH□ Maximum value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
30	32	34	36	38	40

CH1 Minimum value

The minimum value of the digital operation value is stored in 16-bit signed binary value.

In the following cases, 'CH1 Minimum value' (Un\G406) is updated with the current value.

- When 'Operating condition setting request' (Y9) is turned on and off and the setting is changed
- When 'Maximum value/minimum value reset request' (YD) is turned on and off

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
(1)	Data section														

- (1) Sign bit
- 0: Positive
 - 1: Negative

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Minimum value

CH1	CH2	CH3	CH4	CH5	CH6
406	606	806	1006	1206	1406

- CH□ Minimum value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
31	33	35	37	39	41

Point

- For the channel to which the averaging processing is specified, the maximum and minimum values are stored at every averaging processing time.
- When the scaling function, shift function, digital clipping function, or difference conversion function is used, values calculated by each function are stored in Maximum value and Minimum value.

CH1 Difference conversion status flag

The difference conversion status can be checked.

Monitored value	Description
0	Not converted
1	Converting difference

When the difference conversion starts after 'CH1 Difference conversion trigger' (Un\G470) is changed from No request (0) to Trigger request (1), 'CH1 Difference conversion status flag' (Un\G408) corresponding to the channel turns to Converting difference (1).

When 'CH1 Difference conversion trigger' (Un\G470) is changed from Trigger request (1) to No request (0), 'CH1 Difference conversion status flag' (Un\G408) is changed from Converting difference (1) to Not converted (0).

'CH1 Difference conversion status flag' (Un\G408) is Converting difference (1) during the difference conversion; Not converted (0) if not during the difference conversion.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Difference conversion status flag

CH1	CH2	CH3	CH4	CH5	CH6
408	608	808	1008	1208	1408

- CH□ Difference conversion status flag (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
190	191	192	193	194	195

CH1 Logging hold flag

The logging holding status can be checked.

For details on the logging function, refer to the following.

 Page 63 Logging Function

Monitored value	Description
0	Off
1	On

When a state in which data is collected in 'CH1 Logging data' (Un\G10000 to Un\G10999) changes to the stop state, 'CH1 Logging hold flag' (Un\G409) is turned to ON (1).

When logging restarts by changing 'CH1 Logging hold request' (Un\G471) from ON (1) to OFF (0), 'CH1 Logging hold flag' (Un\G409) is turned to OFF (0).

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Logging hold flag

CH1	CH2	CH3	CH4	CH5	CH6
409	609	809	1009	1209	1409

- CH□ Logging hold flag (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1016	1017	1018	1019	1020	1021

CH1 Digital output value (32 bits)

The A/D-converted digital output value is stored in 32-bit signed binary value.

b31	b30	b29	b28	b27	b26	b25	b24	b23	b22	b21	b20	b19	b18	b17	b16
(1)	Data section														
b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
Data section															

- (1) Sign bit
 • 0: Positive
 • 1: Negative

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Digital output value (32 bits)

CH1	CH2	CH3	CH4	CH5	CH6
410 to 411	610 to 611	810 to 811	1010 to 1011	1210 to 1211	1410 to 1411

- CH□ Digital output value (32 bits) (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
300 to 301	302 to 303	304 to 305	306 to 307	308 to 309	310 to 311

■Refreshing cycle

If averaging processing is performed, values are updated at every averaging processing cycle, but if not performed, values are updated at every sampling cycle.

CH1 Supply power temporary stop status flag (for 2-wire transmitter)

The temporary stop status of the supply power can be checked.

Monitored value	Description
0	Not stopped
1	Temporarily stopped

- When 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (Un\G473) is changed from No request (0) to Trigger request (1) and the power supply requirements for 2-wire transmitter temporarily stops, 'CH1 Supply power temporary stop status flag (for 2-wire transmitter)' (Un\G412) becomes Temporarily stopped (1).
- When 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (Un\G473) is changed from Trigger request (1) to No request (0), 'CH1 Supply power temporary stop status flag (for 2-wire transmitter)' (Un\G412) is changed from Temporarily stopped (1) to Not stopped (0).
- While the power supply requirements for 2-wire transmitter is temporarily stopped, 'CH1 Supply power temporary stop status flag (for 2-wire transmitter)' (Un\G412) is Temporarily stopped (1), and if otherwise, the flag is Not stopped (0).

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Supply power temporary stop status flag (for 2-wire transmitter)

CH1	CH2	CH3	CH4	CH5	CH6
412	612	812	1012	1212	1412

- CH□ Supply power temporary stop status flag (for 2-wire transmitter) (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
340	341	342	343	344	345

A

CH1 Range setting monitor

The input range value set to the input range setting or 'CH1 Range setting' (Un\G598) can be checked.

Monitored value	Description
0H	4 to 20mA (2-wire transmitter input)
6H	4 to 20mA (current input)
7H	0 to 20mA (current input)
AH	4 to 20mA (extended mode) (2-wire transmitter input)
CH	4 to 20mA (extended mode) (current input)
EH	User range setting (current input)
FH	User range setting (2-wire transmitter input)

■ Buffer memory address

The following shows the buffer memory address of this area.

CH□ Range setting monitor

CH1	CH2	CH3	CH4	CH5	CH6
430	630	830	1030	1230	1430

Range setting monitor [Q compatible mode]

When the Q compatible mode function is used, the input range value set in the input range setting can be checked.

The monitored value of the input range is the same as the one for the R mode.

■ Buffer memory address

The following shows the buffer memory address of this area.

- Buffer memory address: 20

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
CH4				CH3				CH2				CH1			

- Buffer memory address: 21

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)								CH6				CH5			



Bits corresponding to the channels with A/D conversion disabled in this area will not be updated because the input range cannot be changed for channels with A/D conversion disabled. For details, refer to the following.

☞ Page 18 Range Switching Function

CH1 Difference conversion reference value

This area stores 'CH1 Digital operation value' (Un\G402) at the start of the difference conversion as the difference conversion reference value.

The difference conversion reference value is updated when 'CH1 Difference conversion trigger' (Un\G470) is turned from No request (0) to Trigger request (1).

■ Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Difference conversion reference value

CH1	CH2	CH3	CH4	CH5	CH6
432	632	832	1032	1232	1432

- CH□ Difference conversion reference value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
180	181	182	183	184	185

■ Setting range

The setting range is from -32768 to 32767.

Point

Even if 'CH1 Difference conversion status flag' (Un\G408) is turned from Converting difference (1) to Not converted (0), 'CH1 Difference conversion reference value' (Un\G432) is not cleared.

CH1 Head pointer

The buffer memory address of the oldest data in 'CH1 Logging data' (Un\G10000 to Un\G10999) can be checked with this buffer memory area.

The offset value counted from the start address of 'CH1 Logging data' (Un\G10000 to Un\G10999) is stored.

■ Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Head pointer


CH1	CH2	CH3	CH4	CH5	CH6
434	634	834	1034	1234	1434

- CH□ Head pointer (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1090	1091	1092	1093	1094	1095

Ex.

When the value of 'CH2 Head pointer' (Un\G634) is 550



Point

- The value in 'CH1 Head pointer' (Un\G434) is fixed to 0 since the oldest data is stored in the start address of 'CH1 Logging data' (Un\G10000 to Un\G10999) while the data of the first 1000 points is being logged from the beginning of the logging. On and after the 1001st data, 'CH1 Head pointer' (Un\G434) increases one by one each time data is stored.
- When 'CH1 Logging hold request' (Un\G471) is turned off, 'CH1 Head pointer' (Un\G434) is cleared to 0.

CH1 Latest pointer

The buffer memory address of the latest data in 'CH1 Logging data' (Un\G10000 to Un\G10999) can be checked with this buffer memory area.

The offset value counted from the start address of 'CH1 Logging data' (Un\G10000 to Un\G10999) is stored.

■ Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Latest pointer


CH1	CH2	CH3	CH4	CH5	CH6
435	635	835	1035	1235	1435

- CH□ Latest pointer (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1098	1099	1100	1101	1102	1103

Ex.

When the value of 'CH2 Latest pointer' (Un\G635) is 549



Point

- 'CH1 Latest pointer' (Un\G435) increases one by one each time data is stored from beginning of the logging.
- When 'CH1 Logging hold request' (Un\G471) is turned off, 'CH1 Latest pointer' (Un\G435) is cleared to 0.

A

CH1 Number of logging data

The number of data stored in the logging data storage area can be checked during the logging.

'CH1 Number of logging data' (Un\G436) increases one by one each time data is stored from beginning of the logging.

When the value in the logging data storage area reaches 1000, 'CH1 Number of logging data' (Un\G436) is fixed to 1000 since the value is overwritten from the head again.

For details on the logging function, refer to the following.

 Page 63 Logging Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Number of logging data

CH1	CH2	CH3	CH4	CH5	CH6
436	636	836	1036	1236	1436

- CH□ Number of logging data (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1106	1107	1108	1109	1110	1111

Point

When 'CH1 Logging hold request' (Un\G471) is turned off, 'CH1 Number of logging data' (Un\G436) is cleared to 0.

CH1 Trigger pointer

The buffer memory address of the data of when a hold trigger is executed in 'CH1 Logging data' (Un\G10000 to Un\G10999) can be checked with this buffer memory area.

The difference between the address of the buffer memory which stores the data of when a hold trigger is executed and the start address in 'CH1 Logging data' (Un\G10000 to Un\G10999) is stored.

For details on the logging function, refer to the following.

 Page 63 Logging Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Trigger pointer

CH1	CH2	CH3	CH4	CH5	CH6
437	637	837	1037	1237	1437

- CH□ Trigger pointer (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1114	1115	1116	1117	1118	1119

Point

When 'CH1 Logging hold request' (Un\G471) is turned off, 'CH1 Trigger pointer' (Un\G437) is cleared to 0.

CH1 Current logging read pointer

Each time an amount equivalent to the logging read points monitored value is logged, a value calculated by the following formula is stored.

CH1 Current logging read pointer = CH1 Latest pointer - CH1 Logging read points monitored value + 1

For details on the logging function, refer to the following.

 Page 63 Logging Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Current logging read pointer

CH1	CH2	CH3	CH4	CH5	CH6
438	638	838	1038	1238	1438

- CH□ Current logging read pointer (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1216	1217	1218	1219	1220	1221

CH1 Previous logging read pointer

A before-update current logging read pointer is stored just before an interrupt to the CPU module causes the update.

For details on the logging function, refer to the following.

 Page 63 Logging Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Previous logging read pointer

CH1	CH2	CH3	CH4	CH5	CH6
439	639	839	1039	1239	1439

- CH□ Previous logging read pointer (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1224	1225	1226	1227	1228	1229

CH1 Logging read points monitored value

The number of the actual logging read points is stored.

When 'Operating condition setting request' (Y9) is turned on and off, a value is not stored in the channel where the logging read function is disabled.

For details on the logging function, refer to the following.

 Page 63 Logging Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Logging read points monitored value

CH1	CH2	CH3	CH4	CH5	CH6
440	640	840	1040	1240	1440

- CH□ Logging read points monitored value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1232	1233	1234	1235	1236	1237

CH1 Logging cycle monitored value

This area stores the actual logging cycle which is calculated from the refreshing cycle of data to be logged. When 'Operating condition setting request' (Y9) is turned on and off, the actual logging cycle is stored in Logging cycle monitored value in the corresponding channel where the logging function is enabled.

For details on the logging function, refer to the following.

☞ Page 63 Logging Function

The following values are stored in 'CH1 Logging cycle monitored value' (Un\G441, Un\G442).

	b15	...	b0
'CH1 Logging cycle monitor value (s)' (Un\G441)	s		
'CH1 Logging cycle monitor value (ms)' (Un\G442)	ms		

■ Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Logging cycle monitored value (s)

CH1	CH2	CH3	CH4	CH5	CH6
441	641	841	1041	1241	1441

- CH□ Logging cycle monitored value (ms)

CH1	CH2	CH3	CH4	CH5	CH6
442	642	842	1042	1242	1442

- CH□ Logging cycle monitored value (s) (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1122	1125	1128	1131	1134	1137

- CH□ Logging cycle monitored value (ms) (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1123	1126	1129	1132	1135	1138

CH1 Trigger generation time

The time when a trigger is generated is recorded.

For details on the logging function, refer to the following.

☞ Page 63 Logging Function

	b15	...	b8	b7	...	b0
'CH1 Trigger generation time (First/Last two digits of the year)' (Un\G444)	First two digits of the year			Last two digits of the year		
'CH1 Trigger generation time (Month/Day)' (Un\G445)	Month			Day		
'CH1 Trigger generation time (Hour/Minute)' (Un\G446)	Hour			Minute		
'CH1 Trigger generation time (Second/Day of the week)' (Un\G447)	Second			Day of the week		
'CH1 Trigger generation time (Millisecond)' (Un\G448)	Millisecond (higher-order digits)			Millisecond (lower-order digits)		

Item	Description	Storage example*1
First two digits of the year/Last two digits of the year	Stored in BCD code.	2015H
Month/Day		131H
Hour/Minute		1234H
Second		56H
Day of the week	One of the following values is stored in BCD code. Sunday: 0, Monday: 1, Tuesday: 2, Wednesday: 3 Thursday: 4, Friday: 5, Saturday: 6	6H
Millisecond (upper)	Stored in BCD code.	7H
Millisecond (lower)		89H

*1 Values stored when an error occurs at 12:34:56.789 on Saturday, January 31st, 2015.

■ Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Trigger generation time (First/Last two digits of the year)

CH1	CH2	CH3	CH4	CH5	CH6
444	644	844	1044	1244	1444

- CH□ Trigger generation time (Month/Day)

CH1	CH2	CH3	CH4	CH5	CH6
445	645	845	1045	1245	1445

- CH□ Trigger generation time (Hour/Minute)

CH1	CH2	CH3	CH4	CH5	CH6
446	646	846	1046	1246	1446

- CH□ Trigger generation time (Second/Day of the week)

CH1	CH2	CH3	CH4	CH5	CH6
447	647	847	1047	1247	1447

- CH□ Trigger generation time (Millisecond)

CH1	CH2	CH3	CH4	CH5	CH6
448	648	848	1048	1248	1448

- CH□ Trigger generation time (First/Last two digits of the year) (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1154	1158	1162	1166	1170	1174

- CH□ Trigger generation time (Month/Day) (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1155	1159	1163	1167	1171	1175

- CH□ Trigger generation time (Hour/Minute) (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1156	1160	1164	1168	1172	1176

- CH□ Trigger generation time (Second/Day of the week) (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1157	1161	1165	1169	1173	1177

- CH□ Trigger generation time (Millisecond) (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1186	1187	1188	1189	1190	1191



- Time units shorter than one millisecond are not recorded.
- When 'CH1 Logging hold request' (Un\G471) is turned off, 'CH1 Trigger generation time' (Un\G444 to Un\G448) is cleared to 0.

CH1 Difference conversion trigger

Use this buffer memory area as a trigger to start or stop the difference conversion.

For details on the difference conversion function, refer to the following.

☞ Page 54 Difference Conversion Function

Setting value	Setting content
0	No request
1	Trigger request

If a value other than the above is set, a difference conversion trigger setting range error (error code: 1A7□H) occurs.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Difference conversion trigger

CH1	CH2	CH3	CH4	CH5	CH6
470	670	870	1070	1270	1470

- CH□ Difference conversion trigger (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
172	173	174	175	176	177

■Starting and stopping the difference conversion

- The difference conversion starts when 'CH1 Difference conversion trigger' (Un\G470) is changed from No request (0) to Trigger request (1).
- The difference conversion stops when 'CH1 Difference conversion trigger' (Un\G470) is changed from Trigger request (1) to No request (0).

■Default value

The default value is No request (0) for all channels.

CH1 Logging hold request

Use this buffer memory area as a trigger to hold (stop) logging at any timing during the logging.

For details on the logging function, refer to the following.

 Page 63 Logging Function

Setting value	Setting content
0	Off
1	On

If a value other than the above is set, a logging hold request range error (error code: 1D7□H) occurs.

When 'CH1 Logging enable/disable setting' (Un\G535) is set to Disable (1), the setting for 'CH1 Logging hold request' (Un\G471) is ignored.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Logging hold request

CH1	CH2	CH3	CH4	CH5	CH6
471	671	871	1071	1271	1471

- CH□ Logging hold request (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1008	1009	1010	1011	1012	1013

■Operation of the logging hold processing

- When Disable (0) is set to 'CH1 Level trigger condition setting' (Un\G540), the logging hold processing starts by turning on 'CH1 Logging hold request' (Un\G471).
- When a value other than Disable (0) is set to 'CH1 Hold trigger condition setting' (Un\G540), the logging hold processing starts after 'CH1 Logging hold request' (Un\G471) is turned on and the set trigger condition is satisfied. When the level trigger is enabled, use this buffer memory area as an interlock condition to operate the level trigger.
- If 'CH1 Logging hold request' (Un\G471) is turned off during the logging hold processing, the hold (stop) status is cleared and the logging restarts.

■Default value

The default value is OFF (0) for all channels.



The stop status of the logging can be checked with 'CH1 Logging hold flag' (Un\G409).


A

CH1 Conversion value shift amount

Set 'CH1 Conversion value shift amount' (Un\G472) used for the shift function.

The digital operation value to which the conversion value shift amount is applied is stored in 'CH1 Digital operation value' (Un\G402).

For details on the shift function, refer to the following.

 Page 50 Shift Function

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
(1)	Data section														

(1) Sign bit

- 0: Positive
- 1: Negative

■ Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Conversion value shift amount

CH1	CH2	CH3	CH4	CH5	CH6
472	672	872	1072	1272	1472

- CH□ Conversion value shift amount (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
164	165	166	167	168	169

■ Setting range

The setting range is from -32768 to 32767.

■ Enabling the setting

Regardless of turning on and off 'Operating condition setting request' (Y9), the set conversion value shift amount takes effect.

■ Default value

The default value is 0 for all channels.

CH1 Supply power temporary stop trigger (for 2-wire transmitter)

Use this buffer memory area as a trigger to output or stop the supply power.

This area is enabled when the channel whose input range setting is set to the 2-wire transmitter range is set to A/D conversion enabled (0).

Setting value	Setting content
0	No request
1	Trigger request

If a value other than the above is set, a supply power temporary stop trigger setting range error (error code: 1C9□H) occurs.

■ Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Supply power temporary stop trigger (for 2-wire transmitter)

CH1	CH2	CH3	CH4	CH5	CH6
473	673	873	1073	1273	1473

- CH□ Supply power temporary stop trigger (for 2-wire transmitter) (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
330	331	332	333	334	335

■ Outputting/stopping the supply power

- When 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (Un\G473) is changed from No request (0) to Trigger request (1), the supply power stops.
- When 'CH1 Supply power temporary stop trigger (for 2-wire transmitter)' (Un\G473) is changed from Trigger request (1) to No request (0), the supply power is output.

■ Default value

The default value is No request (0) for all channels.

CH1 A/D conversion enable/disable setting

Set whether to enable or disable the A/D conversion.

For a channel where the 2-wire transmitter input range is set for the input range setting, when A/D conversion enabled (0) is set, the power is supplied to the 2-wire transmitter.

For details on the A/D conversion enable/disable setting function, refer to the following.

☞ Page 19 A/D Conversion Enable/Disable Setting Function

Setting value	Setting content
0	A/D conversion enable
1	A/D conversion disable

When a value other than the ones above is set, CH1 A/D conversion enable/disable setting (Un\G500) is turned to A/D conversion disable (1).

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ A/D conversion enable/disable setting

CH1	CH2	CH3	CH4	CH5	CH6
500	700	900	1100	1300	1500

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is A/D conversion disable (1) for all channels.

A/D conversion enable/disable setting [Q compatible mode]

When the Q compatible mode function is used, set whether to enable or disable the A/D conversion.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)										CH6	CH5	CH4	CH3	CH2	CH1

The setting value of the A/D conversion enable/disable setting is the same as the one for the R mode.

■Buffer memory address

The following shows the buffer memory address of this area.

Q compatible mode: 0

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is A/D conversion disabled (1).

CH1 Averaging processing specification

Select processing to be performed among the sampling processing, averaging processing, and filter processing. Averaging processing consists of time average, count average, and moving average.

Setting value	Setting content
0	Sampling processing
1	Time average
2	Count average
3	Moving average
4	Primary delay filter

If a value other than the above is set, an averaging processing specification setting range error (error code: 191□H) occurs.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Averaging processing specification

CH1	CH2	CH3	CH4	CH5	CH6
501	701	901	1101	1301	1501

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is Sampling processing (0) for all channels.

Averaging processing specification [Q compatible mode]

In the Q compatible mode, set which processing is to be used, sampling processing, averaging processing, or filter processing.

The setting value of the averaging processing specification is the same as the one for the R mode.

■Buffer memory address

The following shows the buffer memory address of this area.

- Buffer memory address: 24

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
CH4				CH3				CH2				CH1			

- Buffer memory address: 25

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)								CH6				CH5			

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is Sampling processing (0).

CH1 Time average/Count average/Moving average/Primary delay filter constant setting

Configure the time (for averaging), count (for averaging), moving average count, and primary delay filter constant when a value other than Sampling processing (0) is set for 'CH1 Averaging processing specification' (Un\G501).

The following table lists the setting ranges.

Setting value	Setting content
40 to 5000 (ms)	Time average
4 to 500 (times)	Count average
2 to 200 (times)	Moving average
1 to 500 (times)	Primary delay filter constant

If a value other than the above is set, any of a time average setting range error (error code: 192□H), count average setting range error (error code: 193□H), moving average setting range error (error code: 194□H), or primary delay filter constant setting range error (error code: 195□H) occurs, and the A/D conversion processing is performed with the setting before the occurrence of the error.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Time average/Count average/Moving average/Primary delay filter constant setting

CH1	CH2	CH3	CH4	CH5	CH6
502	702	902	1102	1302	1502

- CH□ Time average/Count average/Moving average/Primary delay filter constant setting (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1	2	3	4	5	6

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 0 for all channels.



- Set a primary delay filter constant for the primary delay filter. The value of the time constant (ms) is the product of the primary delay filter constant and the sampling cycle.
- Since the default value is 0, change the setting value according to the processing method.
- The setting for this area is ignored in the channel where Sampling processing (0) is set to 'CH1 Averaging processing specification' (Un\G501).

CH1 Scaling enable/disable setting

Set whether to enable or disable the scaling.

For details on the scaling function, refer to the following.

☞ Page 27 Scaling Function

Setting value	Setting content
0	Enable
1	Disable

If a value other than the above is set, a scaling enable/disable setting range error (error code: 1A0□H) occurs.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Scaling enable/disable setting

CH1	CH2	CH3	CH4	CH5	CH6
504	704	904	1104	1304	1504

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is Disable (1) for all channels.

Scaling enable/disable setting [Q compatible mode]

When the Q compatible mode function is used, set whether to enable or disable the scaling.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)										CH6	CH5	CH4	CH3	CH2	CH1

The setting value of the scaling enable/disable setting is the same as the one for the R mode.

■Buffer memory address

The following shows the buffer memory address of this area.

Q compatible mode: 53

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is Disable (1).

CH1 Scaling upper limit value

Set an upper limit value for the range of the scale conversion.

For details on the scaling function, refer to the following.

☞ Page 27 Scaling Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Scaling upper limit value

CH1	CH2	CH3	CH4	CH5	CH6
506	706	906	1106	1306	1506

- CH□ Scaling upper limit value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
63	65	67	69	71	73

■Setting range

The setting range is from -32000 to 32000.

In the channel where a value out of the range is set, a scaling setting range error (error code: 1A1□H) occurs.

In the channel where a set value does not satisfy the condition "the scaling upper limit value ≠ the scaling lower limit value", a scaling upper/lower limit value setting error (error code: 1A2□H) occurs.

When 'CH1 Scaling enable/disable setting' (Un\G504) is set to Disable (1), the setting for 'CH1 Scaling upper limit value' (Un\G506) is ignored.

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 0 for all channels.

CH1 Scaling lower limit value

Set a lower limit value for the range of the scale conversion.

For details on the scaling function, refer to the following.

☞ Page 27 Scaling Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Scaling lower limit value

CH1	CH2	CH3	CH4	CH5	CH6
508	708	908	1108	1308	1508

- CH□ Scaling lower limit value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
62	64	66	68	70	72

■Setting range

The setting range is from -32000 to 32000.

In the channel where a value out of the range is set, a scaling setting range error (error code: 1A1□H) occurs.

In the channel where a set value does not satisfy the condition "the scaling upper limit value ≠ the scaling lower limit value", a scaling upper/lower limit value setting error (error code: 1A2□H) occurs.

When 'CH1 Scaling enable/disable setting' (Un\G504) is set to Disable (1), the setting for 'CH1 Scaling lower limit value' (Un\G508) is ignored.

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 0 for all channels.

CH1 Digital clipping enable/disable setting

Set whether to enable or disable the digital clipping function.

For details on the digital clipping function, refer to the following.

☞ Page 52 Digital Clipping Function

Setting value	Setting content
0	Enable
1	Disable

If a value other than the above is set, a digital clipping enable/disable setting range error (error code: 1A5□H) occurs.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Digital clipping enable/disable setting

CH1	CH2	CH3	CH4	CH5	CH6
510	710	910	1110	1310	1510

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is Disable (1) for all channels.

Digital clipping enable/disable setting [Q compatible mode]

When the Q compatible mode function is used, set whether to enable or disable the digital clipping function.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)										CH6	CH5	CH4	CH3	CH2	CH1

The setting value of the digital clipping enable/disable setting is the same as the one for the R mode.

■Buffer memory address

The following shows the buffer memory address of this area.

Q compatible mode: 29

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is Disable (1).

CH1 Warning output setting (Process alarm)

Set whether to enable or disable the warning output of the process alarm.

For details on the warning output function, refer to the following.

☞ Page 30 Warning Output Function

Setting value	Setting content
0	Enable
1	Disable

If a value other than the above is set, a warning output setting (Process alarm) range error (error code: 1B0□H) occurs.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Warning output setting (Process alarm)

CH1	CH2	CH3	CH4	CH5	CH6
512	712	912	1112	1312	1512

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is Disable (1) for all channels.

CH1 Warning output setting (Rate alarm)

Set whether to enable or disable the warning output of the rate alarm.

For details on the warning output function, refer to the following.

☞ Page 30 Warning Output Function

Setting value	Setting content
0	Enable
1	Disable

If a value other than the above is set, a warning output setting (Rate alarm) range error (error code: 1B8□H) occurs.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Warning output setting (Rate alarm)

CH1	CH2	CH3	CH4	CH5	CH6	CH7
513	713	913	1113	1313	1513	1713

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is Disable (1) for all channels.

Warning output setting [Q compatible mode]

When the Q compatible mode function is used, set whether to enable or disable the warning output of process alarms and rate alarms.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)		CH6	CH5	CH4	CH3	CH2	CH1	0 (fixed)		CH6	CH5	CH4	CH3	CH2	CH1

(b0 to b5) 0: Process alarm enabled, 1: Process alarm disabled

(b8 to b13) 0: Rate alarm enabled, 1: Rate alarm disabled

■Buffer memory address

The following shows the buffer memory address of this area.

Q compatible mode: 48

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).


■Default value

- b0 to b5: The default value is Process alarm disabled (1).
- b8 to b13: The default value is Rate alarm disabled (1).

CH1 Process alarm upper upper limit value

Set an upper upper limit value of the warning output function (Process alarm).

For details on the warning output function, refer to the following.

 Page 30 Warning Output Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Process alarm upper upper limit value

CH1	CH2	CH3	CH4	CH5	CH6
514	714	914	1114	1314	1514

- CH□ Process alarm upper upper limit value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
89	93	97	101	105	109

■Setting range

The setting range is from -32768 to 32767.

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 0 for all channels.

CH1 Process alarm upper lower limit value

Set an upper lower limit value of the warning output function (Process alarm).

For details on the warning output function, refer to the following.

☞ Page 30 Warning Output Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Process alarm upper lower limit value

CH1	CH2	CH3	CH4	CH5	CH6
516	716	916	1116	1316	1516

- CH□ Process alarm upper lower limit value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
88	92	96	100	104	108

■Setting range

The setting range is from -32768 to 32767.

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 0 for all channels.

CH1 Process alarm lower upper limit value

Set a lower upper limit value of the warning output function (Process alarm).

For details on the warning output function, refer to the following.

☞ Page 30 Warning Output Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Process alarm lower upper limit value

CH1	CH2	CH3	CH4	CH5	CH6
518	718	918	1118	1318	1518

- CH□ Process alarm lower upper limit value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
87	91	95	99	103	107

■Setting range

The setting range is from -32768 to 32767.

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).


■Default value

The default value is 0 for all channels.

CH1 Process alarm lower lower limit value

Set a lower lower limit value of the warning output function (Process alarm).

For details on the warning output function, refer to the following.

 Page 30 Warning Output Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Process alarm lower lower limit value

CH1	CH2	CH3	CH4	CH5	CH6
520	720	920	1120	1320	1520

- CH□ Process alarm lower lower limit value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
86	90	94	98	102	106

■Setting range

The setting range is from -32768 to 32767.

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 0 for all channels.

Point

- When using the process alarm, configure the 4-step settings for the process alarm upper upper limit value, upper lower limit value, lower upper limit value, and lower lower value.
- In the channel where a set value does not satisfy the condition "the upper upper limit value \geq the upper lower limit value \geq the lower upper limit value \geq the lower lower limit value", a process alarm upper lower limit value setting range error (error code: 1B△□H) occurs.
- Since the default value is 0, change the setting value.
- When the scaling function, shift function, digital clipping function, or difference conversion function is used, warning targets are digital operation values to which the operation of each function is reflected. Be sure to consider operation results of each function to set values.

CH1 Rate alarm warning detection cycle setting

Set the cycle to check the change rate of digital output values.

The value of the cycle to detect a rate alarm warning is the product of the value in 'CH1 Rate alarm warning detection cycle setting' (Un\G522) and the conversion cycle.

■ Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Rate alarm warning detection cycle setting

CH1	CH2	CH3	CH4	CH5	CH6
522	722	922	1122	1322	1522

- CH□ Rate alarm warning detection cycle setting (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
118	119	120	121	122	123

■ Setting range

The setting range is from 1 to 32000 (times).

■ Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■ Default value

The default value is 0 for all channels.

Point

- In the channel where a value out of the range is set, a rate alarm warning detection cycle setting range error (error code: 1B9□H) occurs.
- Since the default value is 0, change the setting value when setting the rate alarm function.

CH1 Rate alarm upper limit value

Set an upper limit value of the change rate of digital output values to detect a rate alarm.

For details on the warning output function, refer to the following.

 Page 30 Warning Output Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Rate alarm upper limit value

CH1	CH2	CH3	CH4	CH5	CH6
524	724	924	1124	1324	1524

- CH□ Rate alarm upper limit value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
126	128	130	132	134	136

■Setting range

The setting range is from -32768 to 32767 (-3276.8 to 3276.7%). (Set it in a unit of 0.1%.)

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 0 for all channels.

CH1 Rate alarm lower limit value

Set a lower limit value of the change rate of digital output values to detect a rate alarm.

For details on the warning output function, refer to the following.

 Page 30 Warning Output Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Rate alarm lower limit value

CH1	CH2	CH3	CH4	CH5	CH6
526	726	926	1126	1326	1526

- CH□ Rate alarm lower limit value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
127	129	131	133	135	137

■Setting range

The setting range is from -32768 to 32767 (-3276.8 to 3276.7%). (Set it in a unit of 0.1%.)

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 0 for all channels.

Point

- When using the rate alarm, configure the 2-step settings for the rate alarm upper limit value and lower limit value.
- In the channel where a set value does not satisfy the condition "the rate alarm lower limit value \geq the rate alarm upper limit value", a rate alarm upper/lower limit setting value inversion error (error code: 1BA□H) occurs.
- Since the default value is 0, change the setting value.

CH1 Input signal error detection setting

Set a condition for detecting an input signal error.

For details on the input signal error detection function, refer to the following.

☞ Page 38 Input Signal Error Detection Function

Setting value	Setting content
0	Disable
1	Upper and lower limit detection
2	Lower limit detection
3	Upper limit detection
4	Simple disconnection detection

If a value other than the above is set, an input signal error detection setting range error (error code: 1C0□H) occurs.

If Simple disconnection detection (4) is selected for the channel where the input range setting is other than the extended mode, a disconnection detection enabled range setting range error (error code: 1C6□H) occurs.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Input signal error detection setting

CH1	CH2	CH3	CH4	CH5	CH6
528	728	928	1128	1328	1528

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is Disable (0) for all channels.

CH1 Input signal error detection setting value/lower limit set value [Q compatible mode]

When the Q compatible mode function is used, set a condition for detecting an input signal error.

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)		CH6	CH5	CH4	CH3	CH2	CH1	0 (fixed)		CH6	CH5	CH4	CH3	CH2	CH1

(b0 to b5) 0: Enabled, 1: Disabled

(b8 to b13) 0: Upper limit value/lower limit value same, 1: Upper limit value/lower limit value different

- When Upper limit value/lower limit value same (0) is set

The input signal error detection upper limit value and the input signal error detection lower limit value are calculated by using 'CH1 Input signal error detection setting value/CH1 Input signal error detection lower limit set value' (Un\G142). In that case, 'CH1 Input signal error detection upper limit set value' (Un\G150) is ignored.

- When Upper limit value/lower limit value different (1) is set

The input signal error detection upper limit value is calculated by using 'CH1 Input signal error detection upper limit set value' (Un\G150).

The input signal error detection lower limit value is calculated by using 'CH1 Input signal error detection setting value/CH1 Input signal error detection lower limit set value' (Un\G142).

■Buffer memory address

The following shows the buffer memory address of this area.

Q compatible mode: 47

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

- b0 to b5: The default value is Disabled (1).
- b8 to b13: The default value is Upper limit value/lower limit value same (0).

CH1 Input signal error detection lower limit set value

Set a lower limit value to detect an error for the input analog value.

For details on the input signal error detection function, refer to the following.

☞ Page 38 Input Signal Error Detection Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Input signal error detection lower limit set value

CH1	CH2	CH3	CH4	CH5	CH6
529	729	929	1129	1329	1529

■Setting range

The setting range is from 0 to 250 (0 to 25.0%). Set it in a unit of 1 (0.1%).

For example, set 150 in the buffer memory area to set 15%.

In the channel where a value out of the range is set, an input signal error detection setting value range error (error code: 1C1□H) occurs.

The input signal error detection lower limit value is calculated by using the input signal error detection lower limit set value as follows. The input signal error detection lower limit value to be calculated varies depending on the input range used.

Input signal error detection lower limit value = Lower limit value of each range^{*1} - (Gain value of each range - Offset value of each range) × (Input signal error detection lower limit set value/1000)

*1 The lower limit value in the 4 to 20mA (extended mode) range is the same as the lower limit value between 4 and 20mA.

Ex.

When 'CH1 Input signal error detection lower limit set value' (Un\G529) is set to 100 (10%)

Range used: 4 to 20mA

The input signal error detection lower limit value is calculated as follows:

$$\text{Input signal error detection lower limit value} = 4 - (20 - 4) \times \frac{100}{1000} = 2.4\text{mA}$$

Detection conditions vary depending on the setting of 'CH1 Input signal error detection setting' (Un\G528) as follows:

- When 'CH1 Input signal error detection setting' (Un\G528) is set to Upper and lower limit detection (1), the detection is performed with both the input signal error detection upper limit value and the input signal error detection lower limit value.
- When 'CH1 Input signal error detection setting' (Un\G528) is set to Lower limit detection (2), the detection is performed only with the input signal error detection lower limit value.
- When 'CH1 Input signal error detection setting' (Un\G528) is set to Upper limit detection (3), the value set in this area is ignored.
- When 'CH1 Input signal error detection setting' (Un\G528) is set to Simple disconnection detection (4), the value set in this area is ignored.

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 50 for all channels.

CH1 Input signal error detection setting value/lower limit set value [Q compatible mode]

In the Q compatible mode, set a value to detect an error for the input analog value.

The operation varies depending on the value set in 'CH1 Input signal error detection extension/input signal error detection setting' (Un\G47).

■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4	CH5	CH6
CH□ Input signal error detection setting value/CH□ Input signal error detection lower limit set value (in Q compatible mode)	142	143	144	145	146	147

■Setting range

The setting range is from 0 to 250 (0 to 25.0%). Set it in a unit of 1 (0.1%).

For example, set 150 in the buffer memory area to set 15%.

In the channel where a value out of the range is set, an input signal error detection setting value range error (error code: 1C1□H) occurs.

- When 'CH1 Input signal error detection extension/input signal error detection setting' (Un\G47) is set to Upper limit value/lower limit value same (0)

The area is used to set the input signal error detection setting value.

The input signal error detection upper limit value and the input signal error detection lower limit value are calculated as follows: The calculated values vary depending on the input range used.

Input signal error detection upper limit value =

Gain value of each range + (Gain value of each range - Offset value of each range) × (Input signal error detection set value^{*1}/1000)

Input signal error detection lower limit value =

Lower limit value of each range - (Gain value of each range - Offset value of each range) × (Input signal error detection set value^{*1}/1000)

*1 The input signal error detection setting value is set in this area.

- When 'CH1 Input signal error detection extension/input signal error detection setting' (Un\G47) is set to Upper limit value/lower limit value different (1)

The area is used to set the input signal error detection lower limit set value.

Setting 251 disables the input signal error detection.

The input signal error detection upper limit value and the input signal error detection lower limit value are calculated as follows: The calculated values vary depending on the input range used.

Input signal error detection upper limit value =

Gain value of each range + (Gain value of each range - Offset value of each range) × (Upper limit set value^{*1}/1000)

Input signal error detection lower limit value =

Lower limit value of each range - (Gain value of each range - Offset value of each range) × (Lower limit set value^{*2}/1000)

*1 The upper limit set value is the value set in 'CH1 Input signal error detection upper limit set value' (Un\G150).

*2 The lower limit set value is the value set in this area.

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 50 for all channels.

CH1 Input signal error detection upper limit set value

Set an upper limit value to detect an error for the input analog value.

For details on the input signal error detection function, refer to the following.

☞ Page 38 Input Signal Error Detection Function

■ Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Input signal error detection upper limit set value

CH1	CH2	CH3	CH4	CH5	CH6
530	730	930	1130	1330	1530

■ Setting range

The setting range is from 0 to 250 (0 to 25.0%). Set it in a unit of 1 (0.1%).

For example, set 150 in the buffer memory area to set 15%.

In the channel where a value out of the range is set, an input signal error detection setting value range error (error code: 1C1□H) occurs.

The input signal error detection upper limit value is calculated by using the input signal error detection upper limit set value as follows. The input signal error detection upper limit value to be calculated varies depending on the input range used.

Input signal error detection upper limit value = Gain value of each range + (Gain value of each range - Offset value of each range) × (Input signal error detection upper limit set value/1000)

Ex.

When 'CH1 Input signal error detection upper limit set value' (Un\G530) is set to 100 (10%)

Range used: 4 to 20mA

The input signal error detection upper limit value is calculated as follows:

$$\text{Input signal error detection upper limit value} = 20 + (20 - 4) \times \frac{100}{1000} = 21.6\text{mA}$$

Detection conditions vary depending on the setting of 'CH1 Input signal error detection setting' (Un\G528) as follows:

- When 'CH1 Input signal error detection setting' (Un\G528) is set to Upper and lower limit detection (1), the detection is performed with both the input signal error detection upper limit value and the input signal error detection lower limit value.
- When 'CH1 Input signal error detection setting' (Un\G528) is set to Lower limit detection (2), the value set in this area is ignored.
- When 'CH1 Input signal error detection setting' (Un\G528) is set to Upper limit detection (3), the detection is performed only with the input signal error detection upper limit value.
- When 'CH1 Input signal error detection setting' (Un\G528) is set to Simple disconnection detection (4), the value set in this area is ignored.

■ Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■ Default value

The default value is 50 for all channels.

CH1 Input signal error detection upper limit set value [Q compatible mode]

In the Q compatible mode, set an upper limit value to detect an input signal error.

The operation varies depending on the value set in 'CH1 Input signal error detection extension/input signal error detection setting' (Un\G47).

- When Upper limit value/lower limit value same (0) is set

The value set in this area is ignored.

- When Upper limit value/lower limit value different (1) is set

Set an upper limit value to detect an input signal error.

■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4	CH5	CH6
CH□ Input signal error detection upper limit set value (in Q compatible mode)	150	151	152	153	154	155

■Setting range

The setting range is from 0 to 250 (0 to 25.0%). Set it in a unit of 1 (0.1%).

In the channel where a value out of the range is set, an input signal error detection setting value range error (error code: 1C1□H) occurs.

However, setting 251 disables the input signal error detection.

For the setting method, refer to the following.

☞ Page 191 CH1 Input signal error detection setting value/lower limit set value [Q compatible mode]

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 50 for all channels.

CH1 Conversion start time setting (for 2-wire transmitter)

Set the time (warm-up time) required for an output to become stable after the 2-wire transmitter is powered on.

This area is enabled when the channel whose input range setting is set to the 2-wire transmitter input range is set to A/D conversion enabled (0).

Setting value	Setting content
0 to 32767	0 to 3276.7 seconds (0 to 54 minute 36.7 seconds)

- If a value other than the above is set, a conversion start time setting range error (error code: 1C8□H) occurs, and the A/D conversion processing is performed in the state before the error occurrence.
- Set the values in increments of 100ms.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Conversion start time setting (for 2-wire transmitter)

CH1	CH2	CH3	CH4	CH5	CH6
532	732	932	1132	1332	1532

- CH□ Conversion start time setting (for 2-wire transmitter) (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
78	79	80	81	82	83

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default is 30 (3 seconds) for all channels.

CH1 Logging enable/disable setting

Set whether to enable or disable the logging function.

For details on the logging function, refer to the following.

☞ Page 63 Logging Function

Setting value	Setting content
0	Enable
1	Disable

If a value other than the above is set, a logging enable/disable setting range error (error code: 1D0□H) occurs.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Logging enable/disable setting

CH1	CH2	CH3	CH4	CH5	CH6
535	735	935	1135	1335	1535

- CH□ Logging enable/disable setting (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1000	1001	1002	1003	1004	1005

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is Disable (1) for all channels.

CH1 Logging data setting

Determine the target to be collected: digital output value or digital operation value.

For details on the logging function, refer to the following.

☞ Page 63 Logging Function

Setting value	Setting content
0	Digital output value
1	Digital operation value

If a value other than the above is set, a logging data setting range error (error code: 1D3□H) occurs.

When 'CH1 Logging enable/disable setting' (Un\G535) is set to Disable (1), the setting for 'CH1 Logging data setting' (Un\G536) is ignored.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Logging data setting

CH1	CH2	CH3	CH4	CH5	CH6
536	736	936	1136	1336	1536

- CH□ Logging data setting (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1024	1025	1026	1027	1028	1029

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is Digital operation value (1) for all channels.

CH1 Logging cycle setting value

Set a cycle for storing the logging data.

For details on the logging function, refer to the following.

 Page 63 Logging Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Logging cycle setting value

CH1	CH2	CH3	CH4	CH5	CH6
537	737	937	1137	1337	1537

- CH□ Logging cycle setting value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1032	1033	1034	1035	1036	1037

■Setting range

The setting range varies depending on the setting in 'CH1 Logging cycle unit setting' (Un\G538).

CH1 Logging cycle unit setting (Un\G538)	Setting range
ms (1)	10 to 32767
s (2)	1 to 3600

- If a value out of the range is set, a logging cycle setting value range error (error code: 1D1□H) occurs. Logging cannot be performed.
- If the set logging cycle is below the update cycle of data to be logged, a logging cycle setting disable error (error code: 1D2□H) occurs. Logging cannot be performed.

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 60 for all channels.

CH1 Logging cycle unit setting

Set a cycle unit for storing the logging data.

For details on the logging function, refer to the following.

☞ Page 63 Logging Function

Setting value	Setting content
1	ms
2	s

- If a value out of the range is set, a logging cycle setting value range error (error code: 1D1□H) occurs. Logging cannot be performed.
- If the set logging cycle is below the update cycle of data to be logged, a logging cycle setting disable error (error code: 1D2□H) occurs. Logging cannot be performed.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Logging cycle unit setting

CH1	CH2	CH3	CH4	CH5	CH6
538	738	938	1138	1338	1538

- CH□ Logging cycle unit setting (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1040	1041	1042	1043	1044	1045

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default is ms (1) for all channels.

CH1 Post-trigger logging points

Set a number of data points collected for the time period from the occurrence of a hold trigger to the logging stop.

For details on the logging function, refer to the following.

☞ Page 63 Logging Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Post-trigger logging points

CH1	CH2	CH3	CH4	CH5	CH6
539	739	939	1139	1339	1539

- CH□ Post-trigger logging points (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1048	1049	1050	1051	1052	1053

■Setting range

The setting range is from 1 to 1000.

If a value out of the range is set, a post-trigger logging points setting range error (error code: 1D4□H) occurs. Logging cannot be performed.

When 'CH1 Logging enable/disable setting' (Un\G535) is set to Disable (1), the setting for 'CH1 Post-trigger logging points' (Un\G539) is ignored.

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 500 for all channels.

CH1 Level trigger condition setting

Set the condition for the occurrence of a hold trigger when using the level trigger in the logging function.

To use the level trigger, set Level trigger condition setting to either level of Level trigger (condition: Rise) (1), Level trigger (condition: Fall) (2), or Level trigger (condition: Rise and fall) (3).

For details on the logging function, refer to the following.

 Page 63 Logging Function

Setting value	Setting content
0	Disable
1	Level trigger (condition: Rise)
2	Level trigger (condition: Fall)
3	Level trigger (condition: Rise and fall)

If a value other than the above is set, a level trigger condition setting range error (error code: 1D5□H) occurs.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Level trigger condition setting

CH1	CH2	CH3	CH4	CH5	CH6
540	740	940	1140	1340	1540

- CH□ Level trigger condition setting (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1056	1057	1058	1059	1060	1061

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is Disable (0) for all channels.

CH1 Trigger data

Set a buffer memory address to be monitored using a level trigger.

Set the buffer memory address where the target data for monitoring is stored.

For details on the logging function, refer to the following.

 Page 63 Logging Function

■ Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Trigger data

CH1	CH2	CH3	CH4	CH5	CH6
541	741	941	1141	1341	1541

■ Setting range

The setting range is from 0 to 9999.

If a value out of the range is set, a trigger data setting range error (error code: 1D6□H) occurs. Logging cannot be performed.

When 'CH1 Logging enable/disable setting' (Un\G535) is set to Disable (1), the setting for 'CH1 Trigger data' (Un\G541) is ignored.

■ Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■ Default value

The default values are set as shown below.

Channel	Default value	Buffer memory area to be monitored
CH1	402	'CH1 Digital operation value' (Un\G402)
CH2	602	'CH2 Digital operation value' (Un\G602)
CH3	802	'CH3 Digital operation value' (Un\G802)
CH4	1002	'CH4 Digital operation value' (Un\G1002)
CH5	1202	'CH5 Digital operation value' (Un\G1202)
CH6	1402	'CH6 Digital operation value' (Un\G1402)

CH1 Trigger data [Q compatible mode]

In the Q compatible mode, set a buffer memory address to be monitored using a level trigger.

Set the buffer memory address where the target data for monitoring is stored.

■Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	CH1	CH2	CH3	CH4	CH5	CH6
CH1 Trigger data (in Q compatible mode)	1064	1065	1066	1067	1068	1069

■Setting range

The setting range is from 0 to 9999.

If a value out of the range is set, a trigger data setting range error (error code: 1D6□H) occurs. Logging cannot be performed. When 'CH1 Logging enable/disable setting' (Un\G1000) is set to Disable (1), the setting for 'CH1 Trigger data' (Un\G1064) is ignored.

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default values are set as shown below.

Channel	Default value	Buffer memory area to be monitored
CH1	54	CH1 Digital operation value (Un\G54)
CH2	55	CH2 Digital operation value (Un\G55)
CH3	56	CH3 Digital operation value (Un\G56)
CH4	57	CH4 Digital operation value (Un\G57)
CH5	58	CH5 Digital operation value (Un\G58)
CH6	59	CH6 Digital operation value (Un\G59)

CH1 Trigger setting value

Set a level to generate a level trigger.

For details on the logging function, refer to the following.

☞ Page 63 Logging Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Trigger setting value

CH1	CH2	CH3	CH4	CH5	CH6
542	742	942	1142	1342	1542

- CH□ Trigger setting value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1082	1083	1084	1085	1086	1087

■Setting range

The setting range is from -32768 to 32767.

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 0 for all channels.

CH1 Loading interrupt enable/disable setting

Set whether to enable or disable the logging read function.

For details on the logging function, refer to the following.

 Page 63 Logging Function

Setting value	Setting content
0	Enable
1	Disable

- If a value other than the above is set, a read interrupt enable/disable setting range error (error code: 1D8□H) occurs. Logging cannot be performed.
- When CH1 Logging read enable/disable setting (Un\G544) is set to Enable (0), an interrupt is generated and sent to the CPU module by setting a read pointer each time an amount equivalent to the logging read points setting value is logged.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Loading interrupt enable/disable setting

CH1	CH2	CH3	CH4	CH5	CH6
544	744	944	1144	1344	1544

- CH□ Loading interrupt enable/disable setting (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1200	1201	1202	1203	1204	1205

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is Disable (1) for all channels.



The interrupt pointer to be used is preset but can be changed. To change the interrupt pointer, set the corresponding interrupt pointer with the engineering tool.

CH1 Logging read points setting value

An interrupt is generated to the CPU module each time data is logged for the set number of data points.

For details on the logging function, refer to the following.

☞ Page 63 Logging Function

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Logging read points setting value

CH1	CH2	CH3	CH4	CH5	CH6
545	745	945	1145	1345	1545

- CH□ Logging read points setting value (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
1208	1209	1210	1211	1212	1213

■Setting range

The setting range is from 1 to 1000.

If a value out of the range is set, a logging read points setting value range error (error code: 1D9□H) occurs. Logging cannot be performed.

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 100 for all channels.

CH1 Range setting

This area is for setting an input range.

Input range	Setting value
4 to 20mA (2-wire transmitter input)	0H
4 to 20mA (current input)	6H
0 to 20mA (current input)	7H
4 to 20mA (extended mode) (2-wire transmitter input)	AH
4 to 20mA (extended mode) (current input)	CH
User range setting (current input)	EH
User range setting (2-wire transmitter input)	FH

- If a value other than the above is set, a range setting range error (error code: 190□H) occurs.
- The input range cannot be changed for channels with A/D conversion disabled. To change the input range, set 'CH1 A/D conversion enable/disable setting' (Un\G500) to A/D conversion enable (0), and turn on and off 'Operating condition setting request' (Y9).

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Range setting

CH1	CH2	CH3	CH4	CH5	CH6
598	798	998	1198	1398	1598

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 4 to 20mA (2-wire transmitter input) (0H) for all channels.

Range setting [Q compatible mode]

When the Q compatible mode function is used, this area is for setting an input range.

The range setting value is the same as the one for the R mode.

■Buffer memory address

The following shows the buffer memory address of this area.

- Buffer memory address: 402

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
CH4				CH3				CH2				CH1			

- Buffer memory address: 403

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)								CH6				CH5			

The input range cannot be changed for channels with A/D conversion disabled. To change the input range, set the bit corresponding to the channel of 'A/D conversion enable/disable setting [Q compatible mode]' (Un\G0) to A/D conversion enable (0), and turn on and off 'Operating condition setting request' (Y9).

■Enabling the setting

Turn on and off 'Operating condition setting request' (Y9).

■Default value

The default value is 4 to 20mA (2-wire transmitter input) (0H) for all channels.

Error history

Up to 16 errors that occurred in the module are recorded.

	b15	...	b8 b7	...	b0
Un\G3600	Error code				
Un\G3601	First two digits of the year		Last two digits of the year		
Un\G3602	Month		Day		
Un\G3603	Hour		Minute		
Un\G3604	Second		Day of the week		
Un\G3605	Millisecond (higher-order digits)		Millisecond (lower-order digits)		
Un\G3606	System area				
⋮					
Un\G3609					

Item	Description	Storage example ^{*1}
First two digits of the year/Last two digits of the year	Stored in BCD code.	2015H
Month/Day		131H
Hour/Minute		1234H
Second		56H
Day of the week	One of the following values is stored in BCD code. Sunday: 0, Monday: 1, Tuesday: 2, Wednesday: 3 Thursday: 4, Friday: 5, Saturday: 6	6H
Millisecond (upper)	Stored in BCD code.	7H
Millisecond (lower)		89H

*1 Values stored when an error occurs at 12:34:56.789 on Saturday, January 31st, 2015.

■ Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	No.1 to No.16
Error history	3600 to 3759
Error history (in Q compatible mode)	1810 to 1969

Alarm history

Up to 16 alarms that occurred in the module are recorded.

	b15	...	b8 b7	...	b0
Un\G3760	Alarm code				
Un\G3761	First two digits of the year		Last two digits of the year		
Un\G3762	Month		Day		
Un\G3763	Hour		Minute		
Un\G3764	Second		Day of the week		
Un\G3765	Millisecond (higher-order digits)		Millisecond (lower-order digits)		
Un\G3766	System area				
:					
:					
Un\G3769					

Item	Description	Storage example *1
First two digits of the year/Last two digits of the year	Stored in BCD code.	2015H
Month/Day		131H
Hour/Minute		1234H
Second		56H
Day of the week	One of the following values is stored in BCD code. Sunday: 0, Monday: 1, Tuesday: 2, Wednesday: 3 Thursday: 4, Friday: 5, Saturday: 6	6H
Millisecond (upper)	Stored in BCD code.	7H
Millisecond (lower)		89H

*1 Values stored when an alarm occurs at 12:34:56.789 on Saturday, January 31st, 2015.

■ Buffer memory address

The following shows the buffer memory address of this area.

Buffer memory name	No.1 to No.16
Alarm history	3760 to 3919
Alarm history (in Q compatible mode)	3760 to 3919

A

CH1 User range setting

This area restores the offset/gain setting value in user range setting.

■Buffer memory address

The following shows the buffer memory address of this area.


Buffer memory name	CH1	CH2	CH3	CH4	CH5	CH6
CH□ Factory default setting offset value (L) (H)	4004	4008	4012	4016	4020	4024
	4005	4009	4013	4017	4021	4025
CH□ Factory default setting gain value (L) (H)	4006	4010	4014	4018	4022	4026
	4007	4011	4015	4019	4023	4027
CH□ User range setting offset value (L) (H)	4028	4032	4036	4040	4044	4048
	4029	4033	4037	4041	4045	4049
CH□ User range setting gain value (L) (H)	4030	4034	4038	4042	4046	4050
	4031	4035	4039	4043	4047	4051
CH□ Factory default setting offset value (L) (H) (in Q compatible mode)	202	206	210	214	218	222
	203	207	211	215	219	223
CH□ Factory default setting gain value (L) (H) (in Q compatible mode)	204	208	212	216	220	224
	205	209	213	217	221	225
CH□ User range setting offset value (L) (H) (in Q compatible mode)	226	230	234	238	242	246
	227	231	235	239	243	247
CH□ User range setting gain value (L) (H) (in Q compatible mode)	228	232	236	240	244	248
	229	233	237	241	245	249

When the following operations are performed, the data to be used is stored (saved).

- Writing the initial setting by engineering tool
- Turning on 'Operating condition setting request' (Y9) (Data is not saved when the mode is switched from the normal mode to the offset/gain setting mode by 'Mode switching setting' (Un\G296, Un\G297).)
- Writing an offset/gain value in the offset/gain setting mode (When 'User range write request' (YA) is turned on)

When restoring the offset/gain setting value in user range setting, set the same data as the saved data in this area to the corresponding area of the A/D converter module that is the restoration destination.

For the offset/gain setting, refer to the following.

 MELSEC iQ-R Channel Isolated Analog-Digital Converter Module User's Manual (Startup)

■Default value

The default value is 0 for all channels.

CH1 Offset/gain setting mode

Specify the channel where the offset/gain setting is adjusted.

- Offset/gain setting mode (offset specification): Channel to adjust the offset
- Offset/gain setting mode (gain specification): Channel to adjust the gain

Setting	Setting content
0	Disable
1	Setting channel

Set one of the offset specification or gain specification to the Setting channel (1), and the other to Disable (0). When a value other than 0 and 1 is set, an offset/gain setting channel range error (error code: 1E8□H) occurs.

Multiple channels can be set at the same time. In that case, set the offset specification and gain specification separately. The offset specification and gain specification cannot be set at the same time.

In the following cases, an offset/gain setting channel specification error (error code: 1E50H) occurs. Also, the ON/OFF status of the power supply requirements for 2-wire transmitter does not change.

- When both the offset specification and gain specification of the same channel are set to Setting channel (1)
- When Disable (0) is set for all channels
- When both the offset specification and gain specification of multiple channels are set to Setting channel (1) at the same time

Also when 'Offset/gain change request' (YC) is turned on before 'Channel change request' (YB) is turned on, an offset/gain setting channel specification error (error code: 1E50H) occurs. In this case, the last value is the set value.

■Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Offset/gain setting mode (offset specification)

CH1	CH2	CH3	CH4	CH5	CH6
4132	4134	4136	4138	4140	4142

- CH□ Offset/gain setting mode (gain specification)

CH1	CH2	CH3	CH4	CH5	CH6
4133	4135	4137	4139	4141	4143

■Enabling the setting

Turn on 'Channel change request' (YB).

■Default value

The default value is Disable (0) for all channels.

Offset/gain setting mode [Q compatible mode]

When the Q compatible mode function is used, specify the channel where the offset/gain setting is adjusted.
The setting value of the offset/gain setting mode is the same as the one for the R mode.

■Buffer memory address

The following shows the buffer memory address of this area.

- Buffer memory address: 22 (offset specification)

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)										CH6	CH5	CH4	CH3	CH2	CH1

- Buffer memory address: 23 (gain specification)

b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
0 (fixed)										CH6	CH5	CH4	CH3	CH2	CH1

■Enabling the setting

Turn on 'Channel change request' (YB).

■Default value

The default value is Disable (0).



When the offset/gain setting is configured from the offset/gain setting window of an engineering tool, the setting is performed properly on the window. Therefore, a program is not required to perform the setting. When a sequence program used for the MELSEC-Q series A/D converter module is utilized to configure the offset/gain setting, check that an appropriate value has been set in this area.

For the sequence programs for the MELSEC-Q series A/D converter module, refer to the following.

MELSEC-Q Channel Isolated Analog-Digital Converter Module/Channel Isolated Analog-Digital Converter Module (With Signal Conditioning Function) User's Manual

CH1 Logging data

This area stores the data logged by the logging function.

Up to 1000 points of data can be stored per channel. When the number of stored data points is 1001 or greater, data is continuously collected overwriting the data from the head.

For details on the logging function, refer to the following.

 Page 63 Logging Function

■ Buffer memory address

The following shows the buffer memory address of this area.

- CH□ Logging data

CH1	CH2	CH3	CH4	CH5	CH6
10000 to 10999	11000 to 11999	12000 to 12999	13000 to 13999	14000 to 14999	15000 to 15999

- CH□ Logging data (in Q compatible mode)

CH1	CH2	CH3	CH4	CH5	CH6
5000 to 5999	6000 to 6999	7000 to 7999	8000 to 8999	9000 to 9999	10000 to 10999

Point

- When 'Operating condition setting request' (Y9) is turned on, the logging data in all the channels are cleared.
- When Logging hold request is turned off while 'CH1 Logging hold flag' (Un\G409) is on, data logging resumes. In this case, the logged data is not cleared.


Appendix 4 Dedicated Instructions

Instruction list

The following table lists the dedicated instructions that can be used in the A/D converter module.

Instruction	Description
G(P).OFFGAN	Switches normal mode to offset/gain setting mode. Switches offset/gain setting mode to normal mode.
G(P).OGLOAD	Reads out the offset/gain setting value in the user range setting to write it into the CPU module.
G(P).OGSTOR	Restores the offset/gain setting value in the user range setting stored in the CPU module into the A/D converter module.

For details on the dedicated instructions, refer to the following.


 MELSEC iQ-R Programming Manual (Module Dedicated Instructions)

Appendix 5 Operation Examples of When the Remote Head Module Is Mounted

This section describes operation examples of when the remote head module is mounted.

System configuration example

The following system configuration is used to explain an example of operation.



(1) Master station (Network number 1, station number 0)

- Power supply module: R61P
- CPU module: R04CPU
- Master/local module: RJ71GF11-T2 (Start I/O number: 0000H to 001FH)
- Input module: RX10 (Start I/O number: 0020H to 002FH)

(2) Intelligent device station (Network number 1, station number 1)

- Power supply module: R61P
- Remote head module: RJ72GF15-T2
- A/D converter module: R60AD6-DG (Start I/O number: 0000H to 000FH*¹)


*¹ In the RX/RV setting of the master station, set 1000H to 100FH as the start I/O number of the A/D converter module.

Setting in the master station


Connect the engineering tool to the CPU module of the master station and set parameters.

1. Create the project with the following settings.


 [Project] ⇒ [New]




2. Click the [Setting Change] button and set the module to use the module labels.
3. Click the [OK] button in the following window to add the module labels of the CPU module.




4. Add the master/local module with the following settings.

 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Right-click ⇒ [Add New Module]



5. Click the [OK] button in the following window to add the module labels of the master/local module.



6. Set "Required Settings" of the module parameter of the master/local module as shown below.

[Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [RJ71GF11-T2] ⇒ [Required Settings]

Item	Setting
Station Type	
Station Type	Master Station
Network No.	
Network No.	1
Station No.	
Setting Method	Parameter Editor
Station No.	0
Parameter Setting Method	
Setting Method of Basic/Application Settings	Parameter Editor


7. Set "Network Configuration Settings" of the module parameter of the master/local module as shown below.








[Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [RJ71GF11-T2] ⇒ [Basic setting] ⇒ [Network Configuration Settings]

No.	Model Name	STA#	Station Type	RX/RX Setting			RWw/RWw Setting			Refresh Device				Reserved/Error System	Invalid Switching	Monitoring Target	Pairing	Network Synchronous Communication	Alias	Comment	Station-specific mode setting
				Points	Start	End	Points	Start	End	RX	RY	RWw	RWr								
0	Host Station	0	Master Station																		
1	RJ72GF15-T2	1	Intelligent Device Station	256	0000	00FF	256	0000	00FF					No Setting				Asynchronous			




8. Set "Refresh settings" of the module parameter of the master/local module as shown below.

 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [RJ71GF11-T2] ⇒ [Basic setting] ⇒ [Refresh settings]


No.	Link Side					CPU Side				
	Device Name	Points	Start	End		Target	Device Name	Points	Start	End
-	SB	512	00000	001FF		Module Lab				
-	SW	512	00000	001FF		Module Lab				
1	RX	256	00000	000FF		Specify Dev	X	256	01000	010FF
2	RY	256	00000	000FF		Specify Dev	Y	256	01000	010FF
3	RWr	256	00000	000FF		Specify Dev	W	256	00000	000FF
4	RWw	256	00000	000FF		Specify Dev	W	256	01000	010FF
5										

9. Write the set parameters to the CPU module on the master station. Then reset the CPU module or power off and on the system.

 [Online] ⇒ [Write to PLC]

Point 

For parameters of the master/local module which are not described in this procedure, set default values. For details on parameters of the master/local module, refer to the following.


 MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

Setting in the intelligent device station

Connect the engineering tool to the remote head module of the intelligent device station and set parameters.

1. Create the project with the following settings.

[Project] ⇒ [New]




2. Set "Network Required Setting" of "CPU Parameter" of the remote head module as shown below.

[Navigation window] ⇒ [Parameter] ⇒ [RJ72GF15-T2] ⇒ [CPU Parameter] ⇒ [Network Required Setting]


Item	Setting
Network No.	1
Station No.	1

3. Add the A/D converter module with the following settings.

[Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Right-click ⇒ [Add New Module]



4. Configure the setting not to use the module labels.



5. Set "Basic setting" of the module parameter of the A/D converter module as shown below.

[Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [R60AD6-DG] ⇒ [Basic setting]

Setting Item	CH1	CH2	CH3	CH4	CH5	CH6
Range switching function	The input range of the analog input can be set for each channel and the input conversion attribute can be set.					
Input range setting	4 to 20mA (for 2-wire) 4 to 20mA (for 2-wire) 4 to 20mA (for 2-wire) 4 to 20mA (for 2-wire) 4 to 20mA (for 2-wire) 4 to 20mA (for 2-wire)					
Operation mode setting function	The two operation modes, "Normal mode" to execute the normal A/D conversion and "Offset/gain set" to execute the offset/gain setting.					
Operation mode setting	Normal mode (A/D conversion process)					
A/D conversion enable/disable setting function	Set whether to enable or disable the output of the A/D conversion value.					
A/D conversion enable/disable setting	A/D conversion enable A/D conversion enable A/D conversion enable A/D conversion enable A/D conversion enable A/D conversion enable					
A/D conversion method	Set the A/D conversion control method.					
Average processing setting	Sampling process: Sampling process: Count average Sampling process: Moving average Sampling process: Moving average					
Time average/Count average/Moving average/	0	0	50 times	0	10 times	0
Conversion starting time setting function	Set the time necessary from when the used 2-wire transmitter powers on until its output stabilizes.					
Conversion starting time setting (for 2-wire transmitter)	10.0 s	3.0 s	3.0 s	3.0 s	3.0 s	3.0 s

6. Set "Application setting" of the module parameter of the A/D converter module as shown below.

[Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [R60AD6-DG] ⇒ [Application setting]

Setting Item	CH1	CH2	CH3	CH4	CH5	CH6
Scaling function	Configure the setting for the scaling at the A/D conversion.					
Scaling enable/disable setting	Disable	Disable	Disable	Disable	Enable	Disable
Scaling upper limit value	0	0	0	0	16000	0
Scaling lower limit value	0	0	0	0	2000	0
Shift function	Configure the setting for the shift function at the A/D conversion.					
Conversion value shift	0	0	0	0	2000	0
Digital clipping function	Configure the setting for the digital clipping function at the A/D conversion.					
Digitalclip enable/disable setting	Disable	Disable	Disable	Disable	Enable	Disable
Warning output function (Process alarm)	Set an alert at the A/D conversion.					
Warning output setting (Process alarm)	Disable	Disable	Enable	Disable	Disable	Disable
Process alarm upper upper limit value	0	0	32000	0	0	0
Process alarm upper lower limit value	0	0	20000	0	0	0
Process alarm lower upper limit value	0	0	4000	0	0	0
Process alarm lower lower limit value	0	0	0	0	0	0
Warning output function (Rate alarm)	Set an alert at the A/D conversion.					
Warning output setting (Rate alarm)	Enable	Disable	Disable	Disable	Disable	Disable
Rate alarm detection cycle setting	400 times	0 times	0 times	0 times	0 times	0 times
Rate alarm upper limit value	250.0 %	0.0 %	0.0 %	0.0 %	0.0 %	0.0 %
Rate alarm lower limit value	-5.0 %	0.0 %	0.0 %	0.0 %	0.0 %	0.0 %
Input signal error detection function	Configure the setting for the input signal at the A/D conversion.					
Input signal error detection setting	Upper limit detect: Disable	Disable	Disable	Disable	Disable	Disable
Input signal error detection lower limit setting value	5.0 %	5.0 %	5.0 %	5.0 %	5.0 %	5.0 %
Input signal error detection upper limit setting value	8.0 %	5.0 %	5.0 %	5.0 %	5.0 %	5.0 %
Input signal error detection auto clear enable/disable setting	Disable					
Logging function	Configure the setting for the logging function at the A/D conversion.					
Logging enable/disable setting	Disable	Disable	Disable	Disable	Disable	Disable
Logging data setting	Digital operation	Digital operation	Digital operation	Digital operation	Digital operation	Digital operation
Logging cycle setting value	60 ms	60 ms	60 ms	60 ms	60 ms	60 ms
Logging cycle unit setting	ms	ms	ms	ms	ms	ms
Level trigger condition setting	Disable	Disable	Disable	Disable	Disable	Disable
Logging points after trigger	500	500	500	500	500	500
Trigger data	402	602	802	1002	1202	1402
Trigger setting value	0	0	0	0	0	0
Logging read enable/disable setting	Disable	Disable	Disable	Disable	Disable	Disable
Logging read points setting value	100	100	100	100	100	100
Online module change	The module can be changed without the system being stopped.					
Auto restore of Offset/gain setting with the module change	Disable					

7. Set "Refresh settings" of the module parameter of the A/D converter module as shown below.

[Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [R60AD6-DG] ⇒ [Refresh settings]

Setting Item						
Target	Device					
	Number of transfers to intelligent function module				0	
	Number of transfers to CPU				13	
Item	CH1	CH2	CH3	CH4	CH5	CH6
Refresh at the set timing.						
Transfer to the intelligent function module.	Transfer the buffer memory data to the specified device.					
Transfer to the CPU.	Transfer the buffer memory data to the specified device.					
Latest error code	W1020					
Latest address of error history						
Latest alarm code						
Latest address of alarm history						
Interrupt factor detection flag 1						
Interrupt factor detection flag 2						
Interrupt factor detection flag 3						
Interrupt factor detection flag 4						
Interrupt factor detection flag 5						
Interrupt factor detection flag 6						
Interrupt factor detection flag 7						
Interrupt factor detection flag 8						
Interrupt factor detection flag 9						
Interrupt factor detection flag 10						
Interrupt factor detection flag 11						
Interrupt factor detection flag 12						
Interrupt factor detection flag 13						
Interrupt factor detection flag 14						
Interrupt factor detection flag 15						
Interrupt factor detection flag 16						
Warning output flag (Process alarm upper limit)	W1010					
Warning output flag (Process alarm lower limit)	W1011					
Warning output flag (Rate alarm upper limit)	W1012					
Warning output flag (Rate alarm lower limit)	W1013					
Input signal error detection flag	W1014					
A/D conversion completed flag	W1000					
Digital output value	W1001		W1002			
Digital operation value					W1003	
Maximum value					W1005	
Minimum value					W1006	
Difference conversion state flag						
Logging hold flag						
Digital output value (32bit)						
Supply power temporary stop state flag (for 2-wire transmitter)						
Refresh Timing	Set refresh timing.					
Refresh Timing	-					
Refresh Group [n](n: 1-64)	1					
Refresh Timing (I/O)	Specify the timing which transfers the I/O device data.					
Refresh Timing	Based on Refresh Timing (Buffer Memory)					

8. Write the set parameters to the remote head module on the intelligent device station. Then reset the remote head module or turn off and on the power.

[Online] ⇒ [Write to PLC]

Point

For parameters of the remote head module which are not described in this procedure, set default values. For details on parameters of the remote head module, refer to the following.


MELSEC iQ-R CC-Link IE Field Network Remote Head Module User's Manual (Application)



Checking the network status

After setting parameters to the master station and the intelligent device station, check whether data link is normally performed between the master station and the intelligent device station. Check the network status using the CC-Link IE Field Network diagnostics of the engineering tool.

For how to perform the CC-Link IE Field Network diagnostics from the master station, refer to the following.

 MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

Program examples

For the program examples, the module labels of the master/local module are used.

Write the programs to the CPU module on the master station.

Classification	Label name	Description	Device																																																																																																																																																																																																								
Module Label	GF11_1.bSts_DataLinkError	Data link error status of own station	SB0049																																																																																																																																																																																																								
	GF11_1.bnSts_DataLinkError_Station[1]	Data link status of each station (station number 1)	SW00B0.0																																																																																																																																																																																																								
Labels to be defined	Define global labels as shown below:																																																																																																																																																																																																										
	<table border="1"> <thead> <tr> <th></th> <th>Label Name</th> <th>Data Type</th> <th>Class</th> <th>Assign (Device/Label)</th> </tr> </thead> <tbody> <tr><td>1</td><td>CH1_DigOutValTempArea</td><td>Word [Signed]</td><td>VAR_GLOBAL</td><td>D11</td></tr> <tr><td>2</td><td>CH3_DigOutValTempArea</td><td>Word [Signed]</td><td>VAR_GLOBAL</td><td>D12</td></tr> <tr><td>3</td><td>CH5_DigCalcValTempArea</td><td>Word [Signed]</td><td>VAR_GLOBAL</td><td>D13</td></tr> <tr><td>4</td><td>CH6_DigOutValTempArea</td><td>Word [Signed]</td><td>VAR_GLOBAL</td><td>D14</td></tr> <tr><td>5</td><td>CH5_DigMaxValTempArea</td><td>Word [Signed]</td><td>VAR_GLOBAL</td><td>D15</td></tr> <tr><td>6</td><td>CH5_DigMinValTempArea</td><td>Word [Signed]</td><td>VAR_GLOBAL</td><td>D16</td></tr> <tr><td>7</td><td>CH3_ProcAlmUpLimit</td><td>Bit</td><td>VAR_GLOBAL</td><td>F0</td></tr> <tr><td>8</td><td>CH3_ProcAlmLowLimit</td><td>Bit</td><td>VAR_GLOBAL</td><td>F1</td></tr> <tr><td>9</td><td>CH1_RateAlmUpLimit</td><td>Bit</td><td>VAR_GLOBAL</td><td>F2</td></tr> <tr><td>10</td><td>CH1_RateAlmLowLimit</td><td>Bit</td><td>VAR_GLOBAL</td><td>F3</td></tr> <tr><td>11</td><td>CH1_InputSigErr</td><td>Bit</td><td>VAR_GLOBAL</td><td>F4</td></tr> <tr><td>12</td><td>Connect_FormationFlg_St1</td><td>Bit</td><td>VAR_GLOBAL</td><td>M0</td></tr> <tr><td>13</td><td>CH1_AD_conversionCompletedFlag</td><td>Bit</td><td>VAR_GLOBAL</td><td>W1000.0</td></tr> <tr><td>14</td><td>CH3_AD_conversionCompletedFlag</td><td>Bit</td><td>VAR_GLOBAL</td><td>W1000.2</td></tr> <tr><td>15</td><td>CH5_AD_conversionCompletedFlag</td><td>Bit</td><td>VAR_GLOBAL</td><td>W1000.4</td></tr> <tr><td>16</td><td>CH6_AD_conversionCompletedFlag</td><td>Bit</td><td>VAR_GLOBAL</td><td>W1000.5</td></tr> <tr><td>17</td><td>CH1_DigOutVal</td><td>Word [Signed]</td><td>VAR_GLOBAL</td><td>W1001</td></tr> <tr><td>18</td><td>CH3_DigOutVal</td><td>Word [Signed]</td><td>VAR_GLOBAL</td><td>W1002</td></tr> <tr><td>19</td><td>CH5_DigCalcVal</td><td>Word [Signed]</td><td>VAR_GLOBAL</td><td>W1003</td></tr> <tr><td>20</td><td>CH6_DigOutVal</td><td>Word [Signed]</td><td>VAR_GLOBAL</td><td>W1004</td></tr> <tr><td>21</td><td>CH5_DigMaxVal</td><td>Word [Signed]</td><td>VAR_GLOBAL</td><td>W1005</td></tr> <tr><td>22</td><td>CH5_DigMinVal</td><td>Word [Signed]</td><td>VAR_GLOBAL</td><td>W1006</td></tr> <tr><td>23</td><td>CH3_WarningOutputFlagProcessAlarmUpperLimit</td><td>Bit</td><td>VAR_GLOBAL</td><td>W1010.2</td></tr> <tr><td>24</td><td>CH3_WarningOutputFlagProcessAlarmLowerLimit</td><td>Bit</td><td>VAR_GLOBAL</td><td>W1011.2</td></tr> <tr><td>25</td><td>CH1_WarningOutputFlagRateAlarmUpperLimit</td><td>Bit</td><td>VAR_GLOBAL</td><td>W1012.0</td></tr> <tr><td>26</td><td>CH1_WarningOutputFlagRateAlarmLowerLimit</td><td>Bit</td><td>VAR_GLOBAL</td><td>W1013.0</td></tr> <tr><td>27</td><td>CH1_InputSignalErrorDetectionFlag</td><td>Bit</td><td>VAR_GLOBAL</td><td>W1014.0</td></tr> <tr><td>28</td><td>DigitOutValSig</td><td>Bit</td><td>VAR_GLOBAL</td><td>X20</td></tr> <tr><td>29</td><td>MaxMinReadSig</td><td>Bit</td><td>VAR_GLOBAL</td><td>X21</td></tr> <tr><td>30</td><td>MaxMinResetSig</td><td>Bit</td><td>VAR_GLOBAL</td><td>X22</td></tr> <tr><td>31</td><td>ErrResetSig</td><td>Bit</td><td>VAR_GLOBAL</td><td>X23</td></tr> <tr><td>32</td><td>ModuleREADY</td><td>Bit</td><td>VAR_GLOBAL</td><td>X1000</td></tr> <tr><td>33</td><td>InputSignalErrorDetectionSignal</td><td>Bit</td><td>VAR_GLOBAL</td><td>X100C</td></tr> <tr><td>34</td><td>MaxValueMinValueResetCompletedFlag</td><td>Bit</td><td>VAR_GLOBAL</td><td>X100D</td></tr> <tr><td>35</td><td>A_D_conversionCompletedFlag</td><td>Bit</td><td>VAR_GLOBAL</td><td>X100E</td></tr> <tr><td>36</td><td>ErrorFlag</td><td>Bit</td><td>VAR_GLOBAL</td><td>X100F</td></tr> <tr><td>37</td><td>OperatingConditionSettingRequest</td><td>Bit</td><td>VAR_GLOBAL</td><td>Y1009</td></tr> <tr><td>38</td><td>MaxValueMinValueResetRequest</td><td>Bit</td><td>VAR_GLOBAL</td><td>Y100D</td></tr> <tr><td>39</td><td>ErrorClearRequest</td><td>Bit</td><td>VAR_GLOBAL</td><td>Y100F</td></tr> </tbody> </table>		Label Name	Data Type	Class	Assign (Device/Label)	1	CH1_DigOutValTempArea	Word [Signed]	VAR_GLOBAL	D11	2	CH3_DigOutValTempArea	Word [Signed]	VAR_GLOBAL	D12	3	CH5_DigCalcValTempArea	Word [Signed]	VAR_GLOBAL	D13	4	CH6_DigOutValTempArea	Word [Signed]	VAR_GLOBAL	D14	5	CH5_DigMaxValTempArea	Word [Signed]	VAR_GLOBAL	D15	6	CH5_DigMinValTempArea	Word [Signed]	VAR_GLOBAL	D16	7	CH3_ProcAlmUpLimit	Bit	VAR_GLOBAL	F0	8	CH3_ProcAlmLowLimit	Bit	VAR_GLOBAL	F1	9	CH1_RateAlmUpLimit	Bit	VAR_GLOBAL	F2	10	CH1_RateAlmLowLimit	Bit	VAR_GLOBAL	F3	11	CH1_InputSigErr	Bit	VAR_GLOBAL	F4	12	Connect_FormationFlg_St1	Bit	VAR_GLOBAL	M0	13	CH1_AD_conversionCompletedFlag	Bit	VAR_GLOBAL	W1000.0	14	CH3_AD_conversionCompletedFlag	Bit	VAR_GLOBAL	W1000.2	15	CH5_AD_conversionCompletedFlag	Bit	VAR_GLOBAL	W1000.4	16	CH6_AD_conversionCompletedFlag	Bit	VAR_GLOBAL	W1000.5	17	CH1_DigOutVal	Word [Signed]	VAR_GLOBAL	W1001	18	CH3_DigOutVal	Word [Signed]	VAR_GLOBAL	W1002	19	CH5_DigCalcVal	Word [Signed]	VAR_GLOBAL	W1003	20	CH6_DigOutVal	Word [Signed]	VAR_GLOBAL	W1004	21	CH5_DigMaxVal	Word [Signed]	VAR_GLOBAL	W1005	22	CH5_DigMinVal	Word [Signed]	VAR_GLOBAL	W1006	23	CH3_WarningOutputFlagProcessAlarmUpperLimit	Bit	VAR_GLOBAL	W1010.2	24	CH3_WarningOutputFlagProcessAlarmLowerLimit	Bit	VAR_GLOBAL	W1011.2	25	CH1_WarningOutputFlagRateAlarmUpperLimit	Bit	VAR_GLOBAL	W1012.0	26	CH1_WarningOutputFlagRateAlarmLowerLimit	Bit	VAR_GLOBAL	W1013.0	27	CH1_InputSignalErrorDetectionFlag	Bit	VAR_GLOBAL	W1014.0	28	DigitOutValSig	Bit	VAR_GLOBAL	X20	29	MaxMinReadSig	Bit	VAR_GLOBAL	X21	30	MaxMinResetSig	Bit	VAR_GLOBAL	X22	31	ErrResetSig	Bit	VAR_GLOBAL	X23	32	ModuleREADY	Bit	VAR_GLOBAL	X1000	33	InputSignalErrorDetectionSignal	Bit	VAR_GLOBAL	X100C	34	MaxValueMinValueResetCompletedFlag	Bit	VAR_GLOBAL	X100D	35	A_D_conversionCompletedFlag	Bit	VAR_GLOBAL	X100E	36	ErrorFlag	Bit	VAR_GLOBAL	X100F	37	OperatingConditionSettingRequest	Bit	VAR_GLOBAL	Y1009	38	MaxValueMinValueResetRequest	Bit	VAR_GLOBAL	Y100D	39	ErrorClearRequest	Bit	VAR_GLOBAL	Y100F		
	Label Name	Data Type	Class	Assign (Device/Label)																																																																																																																																																																																																							
1	CH1_DigOutValTempArea	Word [Signed]	VAR_GLOBAL	D11																																																																																																																																																																																																							
2	CH3_DigOutValTempArea	Word [Signed]	VAR_GLOBAL	D12																																																																																																																																																																																																							
3	CH5_DigCalcValTempArea	Word [Signed]	VAR_GLOBAL	D13																																																																																																																																																																																																							
4	CH6_DigOutValTempArea	Word [Signed]	VAR_GLOBAL	D14																																																																																																																																																																																																							
5	CH5_DigMaxValTempArea	Word [Signed]	VAR_GLOBAL	D15																																																																																																																																																																																																							
6	CH5_DigMinValTempArea	Word [Signed]	VAR_GLOBAL	D16																																																																																																																																																																																																							
7	CH3_ProcAlmUpLimit	Bit	VAR_GLOBAL	F0																																																																																																																																																																																																							
8	CH3_ProcAlmLowLimit	Bit	VAR_GLOBAL	F1																																																																																																																																																																																																							
9	CH1_RateAlmUpLimit	Bit	VAR_GLOBAL	F2																																																																																																																																																																																																							
10	CH1_RateAlmLowLimit	Bit	VAR_GLOBAL	F3																																																																																																																																																																																																							
11	CH1_InputSigErr	Bit	VAR_GLOBAL	F4																																																																																																																																																																																																							
12	Connect_FormationFlg_St1	Bit	VAR_GLOBAL	M0																																																																																																																																																																																																							
13	CH1_AD_conversionCompletedFlag	Bit	VAR_GLOBAL	W1000.0																																																																																																																																																																																																							
14	CH3_AD_conversionCompletedFlag	Bit	VAR_GLOBAL	W1000.2																																																																																																																																																																																																							
15	CH5_AD_conversionCompletedFlag	Bit	VAR_GLOBAL	W1000.4																																																																																																																																																																																																							
16	CH6_AD_conversionCompletedFlag	Bit	VAR_GLOBAL	W1000.5																																																																																																																																																																																																							
17	CH1_DigOutVal	Word [Signed]	VAR_GLOBAL	W1001																																																																																																																																																																																																							
18	CH3_DigOutVal	Word [Signed]	VAR_GLOBAL	W1002																																																																																																																																																																																																							
19	CH5_DigCalcVal	Word [Signed]	VAR_GLOBAL	W1003																																																																																																																																																																																																							
20	CH6_DigOutVal	Word [Signed]	VAR_GLOBAL	W1004																																																																																																																																																																																																							
21	CH5_DigMaxVal	Word [Signed]	VAR_GLOBAL	W1005																																																																																																																																																																																																							
22	CH5_DigMinVal	Word [Signed]	VAR_GLOBAL	W1006																																																																																																																																																																																																							
23	CH3_WarningOutputFlagProcessAlarmUpperLimit	Bit	VAR_GLOBAL	W1010.2																																																																																																																																																																																																							
24	CH3_WarningOutputFlagProcessAlarmLowerLimit	Bit	VAR_GLOBAL	W1011.2																																																																																																																																																																																																							
25	CH1_WarningOutputFlagRateAlarmUpperLimit	Bit	VAR_GLOBAL	W1012.0																																																																																																																																																																																																							
26	CH1_WarningOutputFlagRateAlarmLowerLimit	Bit	VAR_GLOBAL	W1013.0																																																																																																																																																																																																							
27	CH1_InputSignalErrorDetectionFlag	Bit	VAR_GLOBAL	W1014.0																																																																																																																																																																																																							
28	DigitOutValSig	Bit	VAR_GLOBAL	X20																																																																																																																																																																																																							
29	MaxMinReadSig	Bit	VAR_GLOBAL	X21																																																																																																																																																																																																							
30	MaxMinResetSig	Bit	VAR_GLOBAL	X22																																																																																																																																																																																																							
31	ErrResetSig	Bit	VAR_GLOBAL	X23																																																																																																																																																																																																							
32	ModuleREADY	Bit	VAR_GLOBAL	X1000																																																																																																																																																																																																							
33	InputSignalErrorDetectionSignal	Bit	VAR_GLOBAL	X100C																																																																																																																																																																																																							
34	MaxValueMinValueResetCompletedFlag	Bit	VAR_GLOBAL	X100D																																																																																																																																																																																																							
35	A_D_conversionCompletedFlag	Bit	VAR_GLOBAL	X100E																																																																																																																																																																																																							
36	ErrorFlag	Bit	VAR_GLOBAL	X100F																																																																																																																																																																																																							
37	OperatingConditionSettingRequest	Bit	VAR_GLOBAL	Y1009																																																																																																																																																																																																							
38	MaxValueMinValueResetRequest	Bit	VAR_GLOBAL	Y100D																																																																																																																																																																																																							
39	ErrorClearRequest	Bit	VAR_GLOBAL	Y100F																																																																																																																																																																																																							

Common program

The following figure shows an example of the program to check the data link status of the remote head module (station number 1).




(0) Checks the data link status of the remote head module (station number 1).

Add the MCR instruction shown below to the last of the program.



Program example 1

This program is an example to read and save the digital output values of CH1, CH3, and CH6, and the digital operation value of CH5.




(6) Reads values of CH1 Digital output value, CH3 Digital output value, CH5 Digital operation value, and CH6 Digital output value.

A

Program example 2

The following figure shows an example of the program to read a maximum value and a minimum value of CH5 and clear the values after reading out them.




(26) Reads values of CH5 Maximum value and CH5 Minimum value.

(35) Turns on 'Maximum value/minimum value reset request' (Y100D).

(38) Turns off 'Maximum value/minimum value reset request' (Y100D).

Program example 3

The following figure shows an example of the program to perform operations reacting to a warning if a warning (process alarm upper/lower limit) occurs in CH3.




(41) Performs a processing of when a warning (process alarm upper limit) has occurred in CH3.

(46) Performs a processing of when a warning (process alarm lower limit) has occurred in CH3.

Program example 4

The following figure shows an example of the program to perform operations reacting to a warning if a warning (rate alarm upper/lower limit) occurs in CH1.




(51) Performs a processing of when a warning (rate alarm upper limit) has occurred in CH1.

(56) Performs a processing of when a warning (rate alarm lower limit) has occurred in CH1.



Program example 5

The following figure shows an example of the program to clear Input signal error detection flag, Error flag, and Latest error code if an input signal error is detected in CH1 or an error occurs in any of the channels.



(61) Performs a processing of when an input signal error was detected in CH1.

(66) Turns on 'Error clear request' (Y100F).

(71) Turns off 'Error clear request' (Y100F).

Appendix 6 Using the Module in the Redundant System with Redundant Extension Base Unit

This chapter describes restrictions and precautions for using the A/D converter module that is mounted on the extension base unit in the redundant system.

Restrictions on functions and specifications

Functions

Function	Restriction
Logging function	Cannot be used. When the function is used, proper operation cannot be guaranteed.
Interrupt function	The interrupt program cannot be executed.
Backing up, saving, and restoring offset/gain values	The function cannot be used for either of the following cases. <ul style="list-style-type: none">• When using the module-specific backup parameter• When saving and restoring the values using the dedicated instruction instead of the module-specific backup parameter

Dedicated instructions

Any dedicated instructions of the A/D converter module cannot be used.

Module FBs

Name	Restriction
M+R60ADDG_SetLoggingParam	Cannot be used.
M+R60ADDG_SaveLogging	When the FB is used, proper operation cannot be guaranteed.

Module parameter

■Application setting

Set "Auto restore of Offset/gain setting with the module change" to "Disable".

Precautions


When configuring the offset/gain setting

Connect the engineering tool to the CPU module of the control system.


The engineering tool cannot recognize the A/D converter module if it is connected to the CPU module of the standby system.

Program examples

Unless otherwise specified, program examples provided in this manual and the following manual are for when the module is used in the single CPU system or in the multiple CPU system.

 MELSEC iQ-R Channel Isolated Analog-Digital Converter Module (With Signal Conditioning Function) User's Manual (Startup)

When using the module in the redundant system, refer to the following manual and observe the precautions on programming for when using the Process CPU (redundant mode).

 MELSEC iQ-R CPU Module User's Manual (Application)

Signal flow tracking setting

When using the module FBs and applying the program examples to an actual system, set "Signal Flow Memory Tracking Setting" to "Transfer". If not, the module FBs and programs may not work properly when system switching occurs.

 [CPU Parameter] ⇨ [Redundant System Settings] ⇨ [Tracking Setting]

INDEX

A

A/D conversion completed flag	131, 154
Alarm history	205
ALM LED status monitor	155
Averaging processing	22

C

CH1 A/D conversion enable/disable setting	176
CH1 Averaging processing specification	177
CH1 Conversion start time setting (for 2-wire transmitter)	193
CH1 Conversion value shift amount	174
CH1 Current logging read pointer	169
CH1 Difference conversion reference value	165
CH1 Difference conversion status flag	162
CH1 Difference conversion trigger	172
CH1 Digital clipping enable/disable setting	182
CH1 Digital operation value	160
CH1 Digital output value	160
CH1 Digital output value (32 bits)	163
CH1 Head pointer	166
CH1 Input signal error detection lower limit set value	190
CH1 Input signal error detection setting	189
CH1 Input signal error detection setting value/lower limit set value	189
CH1 Input signal error detection upper limit set value	192
CH1 Latest pointer	167
CH1 Level trigger condition setting	198
CH1 Loading interrupt enable/disable setting	201
CH1 Logging cycle monitored value	170
CH1 Logging cycle setting value	195
CH1 Logging cycle unit setting	196
CH1 Logging data	209
CH1 Logging data setting	194
CH1 Logging enable/disable setting	194
CH1 Logging hold flag	162
CH1 Logging hold request	173
CH1 Logging read points monitored value	169
CH1 Logging read points setting value	202
CH1 Maximum value	161
CH1 Minimum value	161
CH1 Number of logging data	168
CH1 Offset/gain setting mode	207
CH1 Post-trigger logging points	197
CH1 Previous logging read pointer	169
CH1 Process alarm lower lower limit value	186
CH1 Process alarm lower upper limit value	185
CH1 Process alarm upper lower limit value	185
CH1 Process alarm upper upper limit value	184
CH1 Range setting	202
CH1 Range setting monitor	164
CH1 Rate alarm lower limit value	188
CH1 Rate alarm upper limit value	188
CH1 Rate alarm warning detection cycle setting	187
CH1 Scaling enable/disable setting	179
CH1 Scaling lower limit value	181
CH1 Scaling upper limit value	180

CH1 Supply power temporary stop status flag	163
CH1 Supply power temporary stop trigger (for 2-wire transmitter)	175
CH1 Time average/Count average/Moving average/Primary delay filter constant setting	178
CH1 Trigger data	199
CH1 Trigger generation time	170
CH1 Trigger pointer	168
CH1 Trigger setting value	200
CH1 User range setting	206
CH1 Warning output setting (Process alarm)	183
CH1 Warning output setting (Rate alarm)	183
Channel change completed flag	127
Channel change request	133
Condition target channel setting	158
Condition target setting	157
Count average	24

D

Digital operation value	17
Digital output value	17

E

ERR LED status monitor	155
Error clear request	133
Error flag	131
Error history	204
External power supply READY flag	123

I

Input signal error detection auto-clear enable/disable setting	159
Input signal error detection flag	153
Input signal error detection signal	128
Interrupt factor detection flag	150
Interrupt factor generation setting	157
Interrupt factor mask	156
Interrupt factor reset request	156

L

Latest address of alarm history	149
Latest address of error history	149
Latest alarm code	149
Latest error code	149
Level data 0 to 9	155
Logging data	17

M

Maximum and minimum value	17
Maximum value/minimum value reset completed flag	130
Maximum value/minimum value reset request	133
Mode switching setting (H)	159
Mode switching setting (L)	158
Module READY	122
Moving average	24

O

Offset/gain change completed flag	130
Offset/gain change request	133
Offset/gain setting mode status flag	126
Operating condition setting completed flag.	125
Operating condition setting request.	132

P

Primary delay filter	25
Process alarm	30

Q

CH1 Input signal error detection setting value/CH1 Input signal error detection lower limit set value	191
---	-----

R

Range reference table	98
Rate alarm	33
RUN LED status monitor	154

S

Sampling processing	22
Simple disconnection detection	40

T

Time average	23
------------------------	----

U

User range write request	132
------------------------------------	-----

W

Warning output flag (Process alarm lower limit)	151
Warning output flag (Process alarm upper limit)	150
Warning output flag (Rate alarm lower limit).	152
Warning output flag (Rate alarm upper limit)	152
Warning output signal	124



REVISIONS

*The manual number is given on the bottom left of the back cover.

Revision date	*Manual number	Description
May 2020	SH(NA)-082300ENG-A	First edition
October 2020	SH(NA)-082300ENG-B	■Added or modified parts SAFETY PRECAUTIONS, CONDITIONS OF USE FOR THE PRODUCT, RELEVANT MANUALS, Appendix 6
February 2024	SH(NA)-082300ENG-C	■Added or modified parts SAFETY PRECAUTIONS, Section 1.15, 1.16, Appendix 1

Japanese manual number: SH-082299-C

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2020 MITSUBISHI ELECTRIC CORPORATION

WARRANTY

Please confirm the following product warranty details before using this product.

1. Gratis Warranty Term and Gratis Warranty Range

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the sales representative or Mitsubishi Service Company.

However, if repairs are required onsite at domestic or overseas location, expenses to send an engineer will be solely at the customer's discretion. Mitsubishi shall not be held responsible for any re-commissioning, maintenance, or testing on-site that involves replacement of the failed module.

[Gratis Warranty Term]

The gratis warranty term of the product shall be for one year after the date of purchase or delivery to a designated place. Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be eighteen (18) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

[Gratis Warranty Range]

- (1) The range shall be limited to normal use within the usage state, usage methods and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (2) Even within the gratis warranty term, repairs shall be charged for in the following cases.
 1. Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
 2. Failure caused by unapproved modifications, etc., to the product by the user.
 3. When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
 4. Failure that could have been avoided if consumable parts (battery, backlight, fuse, etc.) designated in the instruction manual had been correctly serviced or replaced.
 5. Failure caused by external irresistible forces such as fires or abnormal voltages, and Failure caused by force majeure such as earthquakes, lightning, wind and water damage.
 6. Failure caused by reasons unpredictable by scientific technology standards at time of shipment from Mitsubishi.
 7. Any other failure found not to be the responsibility of Mitsubishi or that admitted not to be so by the user.

2. Onerous repair term after discontinuation of production

- (1) Mitsubishi shall accept onerous product repairs for seven (7) years after production of the product is discontinued. Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.
- (2) Product supply (including repair parts) is not available after production is discontinued.

3. Overseas service

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center. Note that the repair conditions at each FA Center may differ.

4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

5. Changes in product specifications

The specifications given in the catalogs, manuals or technical documents are subject to change without prior notice.

TRADEMARKS

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as [™] or [®] are not specified in this manual.

SH(NA)-082300ENG-C(2402)MEE

MODEL: R60AD6-DG-U-OU-E

MODEL CODE: 13JX3F

mitsubishi electric corporation

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the
Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.