MITSUBISHI



GRAPHIC OPERATION TERMINAL



GOT1000 Series Extended/Option Functions Manual





(Always read these precautions before using this equipment.)

Before using this product, please read this manual and the relevant manuals introduced in this manual carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product.

In this manual, the safety precautions are ranked as "WARNING" and "CAUTION".

⚠ WARNING

Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Note that the <u>fi</u> caution level may lead to a serious accident according to the circumstances. Always follow the instructions of both levels because they are important to personal safety.

Please save this manual to make it accessible when required and always forward it to the end user.

[DESIGN PRECAUTIONS]

Some failures of the GOT, communication unit or cable may keep the outputs on or off. An external monitoring circuit should be provided to check for output signals which may lead to a serious accident.

Not doing so can cause an accident due to false output or malfunction.

• If a communication fault (including cable disconnection) occurs during monitoring on the GOT, communication between the GOT and PLC CPU is suspended and the GOT becomes inoperative. For bus connection: The CPU becomes faulty and the GOT becomes inoperative.

For other than bus connection: The GOT becomes inoperative.

A system where the GOT is used should be configured to perform any significant operation to the system by using the switches of a device other than the GOT on the assumption that a GOT communication fault will occur.

Not doing so can cause an accident due to false output or malfunction.

Do not use the GOT as the warning device that may cause a serious accident.
 An independent and redundant hardware or mechanical interlock is required to configure the device that displays and outputs serious warning.

Failure to observe this instruction may result in an accident due to incorrect output or malfunction.

[DESIGN PRECAUTIONS]

WARNING

Incorrect operation of the touch switch(s) may lead to a serious accident if the GOT backlight is gone
out.

When the GOT backlight goes out, the POWER LED flickers (green/orange) and the display section turns black and causes the monitor screen to appear blank, while the input of the touch switch(s) remains active.

This may confuse an operator in thinking that the GOT is in "screensaver" mode, who then tries to release the GOT from this mode by touching the display section, which may cause a touch switch to operate.

Note that the following occurs on the GOT when the backlight goes out.

The POWER LED flickers (green/orange) and the monitor screen appears blank.

• The display section of the GT16 is an analog-resistive type touch panel.

If you touch the display section simultaneously in 2 points or more, the switch that is located around the center of the touched point, if any, may operate.

Do not touch the display section in 2 points or more simultaneously.

Doing so may cause an accident due to incorrect output or malfunction.

• When programs or parameters of the controller (such as a PLC) that is monitored by the GOT are changed, be sure to reset the GOT or shut off the power of the GOT at the same time.
Not doing so can cause an accident due to false output or malfunction.

CAUTION

- Do not bundle the control and communication cables with main-circuit, power or other wiring.
 Run the above cables separately from such wiring and keep them a minimum of 100mm apart.
 Not doing so noise can cause a malfunction.
- Do not press the GOT display section with a pointed material as a pen or driver.
 Doing so can result in a damage or failure of the display section.

[MOUNTING PRECAUTIONS]

WARNING

- Be sure to shut off all phases of the external power supply used by the system before mounting or removing the GOT to/from the panel.
 - Not doing so can cause the GOT to fail or malfunction.
- Be sure to shut off all phases of the external power supply used by the system before mounting or removing the communication unit, option function board or multi-color display board onto/from the GOT. Not doing so can cause the unit to fail or malfunction.
- Before mounting an optional function board or Multi-color display board, wear a static discharge wrist strap to prevent the board from being damaged by static electricity.

[MOUNTING PRECAUTIONS]

CAUTION

 Use the GOT in the environment that satisfies the general specifications described in the User's Manual.

Not doing so can cause an electric shock, fire, malfunction or product damage or deterioration.

When mounting the GOT to the control panel, tighten the mounting screws in the specified torque range.

Undertightening can cause the GOT to drop, short circuit or malfunction.

Overtightening can cause a drop, short circuit or malfunction due to the damage of the screws or the GOT.

- When loading the communication unit or option unit to the GOT (GT16, GT15), fit it to the extension interface of the GOT and tighten the mounting screws in the specified torque range.
 Undertightening can cause the GOT to drop, short circuit or malfunction.
 Overtightening can cause a drop, failure or malfunction due to the damage of the screws or unit.
- When mounting the multi-color display board onto the GOT (GT15), connect it to the corresponding connector securely and tighten the mounting screws within the specified torque range.
 Loose tightening may cause the unit and/or GOT to malfunction due to poor contact.
 Overtightening may damage the screws, unit and/or GOT; they might malfunction.
- When mounting the option function board onto the GOT (GT16), connect it to the corresponding connector securely and tighten the mounting screws within the specified torque range.
- When mounting an optional function board onto the GOT(GT15), fully connect it to the connector until you hear a click.
- When mounting an optional function board onto the GOT(GT11), fully connect it to the connector.
- When inserting a CF card into the GOT(GT16, GT15, GT11), push it into the CF card interface of GOT until the CF card eject button will pop out.
 Failure to do so may cause a malfunction due to poor contact.
- When inserting/removing a CF card into/from the GOT(GT16, GT15, GT11), turn the CF card access switch off in advance.

Failure to do so may corrupt data within the CF card.

- When removing a CF card from the GOT, make sure to support the CF card by hand, as it may pop out
 - Failure to do so may cause the CF card to drop from the GOT and break.
- When installing a USB memory to the GOT(GT16), make sure to install the USB memory to the USB interface firmly.
 - Failure to do so may cause a malfunction due to poor contact.
- Before removing the USB memory from the GOT(GT16), operate the utility screen for removal. After the successful completion dialog box is displayed, remove the memory by hand carefully. Failure to do so may cause the USB memory to drop, resulting in a damage or failure of the memory.

[MOUNTING PRECAUTIONS]

CAUTION

- For closing the USB environmental protection cover, fix the cover by pushing the △ mark on the latch firmly to comply with the protective structure.
- Remove the protective film of the GOT.
 When the user continues using the GOT with the protective film, the film may not be removed.
- Operate and store the GOT in environments without direct sunlight, high temperature, dust, humidity, and vibrations.
- Use the protective cover for oil when the GOTs (GT16, GT15, GT11 and GT10) are used in the environment with oil or chemicals.
 - Not doing so can cause failures or malfunction due to the infiltration of oil or chemicals.

[WIRING PRECAUTIONS]

<u>∱</u>WARNING

Be sure to shut off all phases of the external power supply used by the system before wiring. Failure to do so may result in an electric shock, product damage or malfunctions.

⚠ CAUTION

- Please make sure to ground FG terminal and LG terminal and protective ground terminal of the GOT power supply section by applying Class D Grounding (Class 3 Grounding Method) or higher which is used exclusively for the GOT.
 - Not doing so may cause an electric shock or malfunction.
- Be sure to tighten any unused terminal screws with a torque of 0.5 to 0.8N•m.
 Failure to do so may cause a short circuit due to contact with a solderless terminal.
- Use applicable solderless terminals and tighten them with the specified torque.
 If any solderless spade terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure.
- Correctly wire the GOT power supply section after confirming the rated voltage and terminal arrangement of the product.
 - Not doing so can cause a fire or failure.
- Tighten the terminal screws of the GOT power supply section in the specified torque range.
 Undertightening can cause a short circuit or malfunction.
 Overtightening can cause a short circuit or malfunction due to the damage of the screws or the GOT.
- Exercise care to avoid foreign matter such as chips and wire offcuts entering the GOT. Not doing so can cause a fire, failure or malfunction.

[WIRING PRECAUTIONS]

CAUTION

■ The module has an ingress prevention label on its top to prevent foreign matter, such as wire offcuts, from entering the module during wiring.

Do not peel this label during wiring.

Before starting system operation, be sure to peel this label because of heat dissipation.

Plug the bus connection cable by inserting it into the connector of the connected unit until it "clicks".
 After plugging, check that it has been inserted snugly.

Not doing so can cause a malfunction due to a contact fault.

Plug the communication cable into the connector of the connected unit and tighten the mounting and terminal screws in the specified torque range.

Undertightening can cause a short circuit or malfunction.

Overtightening can cause a short circuit or malfunction due to the damage of the screws or unit.

Plug the QnA/ACPU/Motion controller (A series) bus connection cable by inserting it into the connector of the connected unit until it "clicks".

After plugging, check that it has been inserted snugly.

Not doing so can cause a malfunction due to a contact fault.

[TEST OPERATION PRECAUTIONS]

/ WARNING

• Before performing the test operations of the user creation monitor screen (such as turning ON or OFF bit device, changing the word device current value, changing the settings or current values of the timer or counter, and changing the buffer memory current value), read through the manual carefully and make yourself familiar with the operation method.

During test operation, never change the data of the devices which are used to perform significant operation for the system.

False output or malfunction can cause an accident.

[STARTUP/MAINTENANCE PRECAUTIONS]

WARNING

- When power is on, do not touch the terminals.
 Doing so can cause an electric shock or malfunction.
- Correctly connect the battery connector.
 Do not charge, disassemble, heat, short-circuit, solder, or throw the battery into the fire.
 Doing so will cause the battery to produce heat, explode, or ignite, resulting in injury and fire.
- Before starting cleaning or terminal screw retightening, always switch off the power externally in all phases.

Not switching the power off in all phases can cause a unit failure or malfunction.

Undertightening can cause a short circuit or malfunction.

Overtightening can cause a short circuit or malfunction due to the damage of the screws or unit.

CAUTION

- Do not disassemble or modify the unit.
 Doing so can cause a failure, malfunction, injury or fire.
- Do not touch the conductive and electronic parts of the unit directly.
 Doing so can cause a unit malfunction or failure.
- The cables connected to the unit must be run in ducts or clamped.
 Not doing so can cause the unit or cable to be damaged due to the dangling, motion or accidental pulling of the cables or can cause a malfunction due to a cable connection fault.
- When unplugging the cable connected to the unit, do not hold and pull the cable portion. Doing so can cause the unit or cable to be damaged or can cause a malfunction due to a cable connection fault.
- Do not drop or apply strong impact to the unit.
 Doing so may damage the unit.
- Do not drop or give an impact to the battery mounted to the unit.
 Doing so may damage the battery, causing the battery fluid to leak inside the battery.
 If the battery is dropped or given an impact, dispose of it without using.
- Before touching the unit, always touch grounded metal, etc. to discharge static electricity from human body, etc.

Not doing so can cause the unit to fail or malfunction.

- Replace battery with GT15-BAT(GT16, GT15) or GT11-50BAT(GT11, GT10) by Mitsubishi electric Co. only.
 - Use of another battery may present a risk of fire or explosion.
- Dispose of used battery promptly.
 Keep away from children. Do not disassemble and do not dispose of in fire.

[TOUCH PANEL PRECAUTIONS]

CAUTION

For the analog-resistive film type touch panels, normally the adjustment is not required. However, the difference between a touched position and the object position may occur as the period of use elapses.

When any difference between a touched position and the object position occurs, execute the touch panel calibration.

When any difference between a touched position and the object position occurs, other object may be activated.

This may cause an unexpected operation due to incorrect output or malfunction.

[BACKLIGHT REPLACEMENT PRECAUTIONS]

WARNING

• Be sure to shut off all phases of the external power supply of the GOT (and the PLC CPU in the case of a bus topology) and remove the GOT from the control panel before replacing the backlight (when using the GOT with the backlight replaceable by the user).

Not doing so can cause an electric shock.

Replacing a backlight without removing the GOT from the control panel can cause the backlight or control panel to drop, resulting in an injury.

CAUTION

Wear gloves for the backlight replacement when using the GOT with the backlight replaceable by the user.

Not doing so can cause an injury.

 Before replacing a backlight, allow 5 minutes or more after turning off the GOT when using the GOT with the backlight replaceable by the user.

Not doing so can cause a burn from heat of the backlight.

[DISPOSAL PRECAUTIONS]

CAUTION

- When disposing of the product, handle it as industrial waste.
- When disposing of this product, treat it as industrial waste.
 When disposing of batteries, separate them from other wastes according to the local regulations.

(For details of the battery directive in EU member states, refer to the User's Manual of the GOT to be used.)

[TRANSPORTATION PRECAUTIONS]

CAUTION

- When transporting lithium batteries, make sure to treat them based on the transport regulations. (For details on models subject to restrictions, refer to the User's Manual for the GOT you are using.)
- Make sure to transport the GOT main unit and/or relevant unit(s) in the manner they will not be exposed to the impact exceeding the impact resistance described in the general specifications of the User's Manual, as they are precision devices.

Failure to do so may cause the unit to fail.

Check if the unit operates correctly after transportation.

* The manual number is given on the bottom left of the back cover.

Print Date	* Manual Number	Revision
Mar., 2005	SH(NA)-080544ENG-A	First edition
Mar., 2005 Oct., 2005	SH(NA)-080544ENG-A SH(NA)-080544ENG-B	Compatible with GT Designer2 Version2.18U. Partial corrections Abbreviations and generic terms in this manual, Chapter1, Section 1.1.1, 1.1.2, 1.1.3, 2.1, 2.2.1, 2.2.2, 2.3.1, 2.4.2, 2.4.3, 2.4.4, 2.4.5, 2.5, 2.5.1, 2.5.3, 2.6.1, 2.7.1, 2.8.1, 2.9.2, 2.9.3, 2.9.4, 2.9.5, 3.1, 3.2.1, 3.2.2, 3.3, 3.3.1, 3.3.2, 3.3.3, 3.4.1, 3.8, 4.1, 4.2.1, 4.3, 4.3.1, 4.3.2, 4.4.1, 4.4.2, 4.4.7, 4.7.3, App.1, INDEX Partial additions Section 2.6, 2.7, 2.8, 3.4, 3.5.4 Additions Section 2.2.3, 3.2.3, 3.2.4, 4.2.2, 4.4.6, Chapter 5, 6, 7, 8, 9, 10 Section 2.2.3 → 2.2.4, Section 5.1 → 2.10, Section 3.3.4 → 3.3.3, Section 3.4.3 → 3.4.2, Section 4.2.2 → 4.2.3, Section 4.4.6 → 4.4.7, Section 4.4.7 →
Jan., 2006	SH(NA)-080544ENG-C	4.4.8, Section 5.2 → 3.8, Section 5.3 → 4.7 Compatible with GT Designer2 Version2.27D. Partial corrections About Manuals, Abbreviations and generic terms in this manual, How to read this manual, Section 3.1, 3.4.2, 4.4.6, 5.4.12, 7.4.1, 8.4.11, 9.2.1, 9.4.8, 10.2.1, App1 Additions Section 1.1.4, 3.5.7
Jun., 2006	SH(NA)-080544ENG-D	Compatible with GT Designer2 Version2.32J. Partial corrections About Manuals, Abbreviations and generic terms in this manual, How to read this manual, Section 1.1.1, 1.1.2, 2.3.1, 3.2.1, 3.3.2, 4.1, 5.1, 5.3, 6.1, 6.2.2, 6.4.1, 6.4.2, 7.1, 7.2.1, 7.2.4, 8.2.1, 8.4.2, 8.4.11, 10.2.1, 10.2.3, App1 Additions Chapter 1, Section 2.1, 3.2.4, 8.2.3, 9.2.1
Nov., 2006	SH(NA)-080544ENG-E	Compatible with GT Designer2 Version2.43V. Partial corrections Section 2.2.4, 3.1, 3.2.4, 3.3.2, 3.6, 3.8, 6.2.2, 7.2.3, 8.2.2 Partial additions Section 3.3.1, 3.3.3, 3.4.1

(Continued to next page)

Print Date	* Manual Number	Revision
May, 2007	SH(NA)-080544ENG-F	Compatible with GT Designer2 Version 2.58L
		Partial corrections
		Section 1.1.1, 1.1.2, 2.1, 2.2.1, 2.5.1, 2.6.1, 2.7.1, 2.8.1, 2.9.3, 3.1, 3.2.1, 3.2.4,
		3.3.1, 3.3.3, 3.3.4, 3.4.1, 3.4.2, 3.5.1 to 3.5.7, 3.6.1 to 3.6.7, 3.7.1, 4.2.1, 5.2.1,
		5.3, 5.4.9 to 5.4.11, 7.1, 8.2.1, 8.4.11, 9.2.1, 9.4.8
		Partial additions
		Section 5.2.3, 5.4.1
		Additions
		Section 3.3.5, 3.8, 5.4.12, 14.10, Chapter 11
		Section 3.8 → 3.9, Section 5.4.12 → 5.4.13, Section 5.4.13 → 5.4.14
Aug., 2007	SH(NA)-080544ENG-G	Compatible with GT Designer2 Version 2.63R
		Partial corrections
		Section 3.2.1, 8.2.3, 8.3, 8.4.1, 8.4.6
		Partial additions
		Chapter 1, Section 1.1.1, 1.1.2, 1.1.4, 2.2.3, 3.2.2, 3.2.3, 3.2.4, 6.2.2, 6.2.3,
		8.2.1, 8.4.4, 10.2.1, 10.2.2, 10.2.3, 10.4, 10.5, 11.2.1, App1
		Additions
		Section 11.5, Chapter 12
		Section 11.5 → 11.6
Dec., 2007	SH(NA)-080544ENG-H	Compatible with GT Designer2 Version 2.72A
,	, , , , , , , , , , , , , , , , , , , ,	Partial corrections
		Section 1.1.3, 1.1.4, 3.2.1, 3.3.3, 10.2, 10.2.1, 11.3.1, 11.3.2, 11.4.1, 11.5.2,
		11.5.3, 12.4
		Partial additions
		Section 1.1.1, 1.1.2, 2.1, 2.3.1, 3.2.4, 3.4.1, 11.1, 11.2.1, 11.2.3, 11.3.3
		Addition
		Additions Section 11.3.4
Feb., 2008	SH(NA)-080544ENG-I	Compatible with GT Designer2 Version 2.77F
1 CD., 2000	311(1VA)-0003+4E1VG-1	Partial corrections
		Section 1.1.3, 2.2.3, 3.2.3, 7.2.3
		Partial additions
		Chapter 1, Section 1.1.1, 1.1.2, 1.1.4, 2.2.1, 3.1, 3.2.1, 6.2.1, 6.2.2, 7.1, 7.2.1, 7.2.2, 7.2.4, 7.4.1 to 7.4.9, 8.2, App1
		Additions
		Chapter 13
		(Continued to next page

Print Date	* Manual Number	Revision
Jun., 2008	SH(NA)-080544ENG-J	Compatible with GT Designer2 Version 2.82L Partial corrections Section 3.2.2, 3.7, 6.4.4, 7.2.1, 11.2.1, 11.3.3
		Partial additions Section 1.1.1, 1.1.2, 2.2.1, 3.2.4, 6.2.1, 6.3, 6.4.1, 6.4.2, 6.4.3, 11.2.3, 11.6, 13.2.1, App1
Oct., 2008	SH(NA)-080544ENG-K	Compatible with GT Designer2 Version 2.90U. Partial corrections Section 1.1.3, 2.1, 2.3.1, 3.3.1, 4.4.1, 5.5, 6.3, 7.3, 8.3, 9.3, 10.3, 11.1, 11.3.1, 11.3.4, 11.4.1, 11.4.3, 11.6, 12.3, 13.1, 13.3.1, 13.5.1, 13.5.2, 13.6.1, 13.6.3, 13.7.1 → 13.7.3
		Partial additions Section 1.1.1, 1.1.2, 2.2.1, 3.2.1, 3.5.4, 4.1, 4.2.1, 4.3.1, 4.4.6, 5.1, 5.2.3, 5.3, 5.4.1, 5.4.10, 5.4.13, 6.2.1, 7.2.1, 8.2.1, 9.2.1, 10.2.1, 10.2.3, 11.2.1, 11.3.2, 12.2.3, 13.2.1, 13.2.2, 13.8, 13.9, App1
Dec., 2008	SH(NA)-080544ENG-L	Compatible with GT Designer2 Version 2.91V Partial corrections Section 10.2.3, 12.2.2, 13.2.4 Partial additions Section 1.1.2, 2.2.1, 3.2.1, 5.2.1, 6.2.1, 7.2.1, 8.2.1, 9.2.1, 10.2.1, 11.2.1, 12.2.1, 13.2.1, App1, 1.1, 1.2
Mar., 2009	SH(NA)-080544ENG-M	Compatible with GT Designer2 Version 2.96A Partial corrections Section 3.2.1, 6.2.1, 7.2.1, 10.2.2, 11.2.2, 11.5.2, 12.3 Partial additions Chapter 1, Section 1.1.1, 1.1.2, 1.1.4, 8.2.1, 11.2.1, 12.2.3, 12.4, 12.5, 12.2.1 Additions Chapter 14
Sep., 2010	SH(NA)-080544ENG-N	Partial corrections How to read this manual, App1
Sep., 2012	SH(NA)-080544ENG-O	Partial corrections SAFETY PRECAUTIONS changed, Section 8.2.1, 8.4.4

Japanese Manual Version SH-080541-V

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

INTRODUCTION

Thank you for choosing Mitsubishi Graphic Operation Terminal (Mitsubishi GOT).

Read this manual and make sure you understand the functions and performance of the GOT thoroughly in advance to ensure correct use.

CONTENTS

SA	AFETY	PRECA	AUTIONS	A - 1			
RE	EVISIC	NS		A - 9			
INTRODUCTION							
C	ONTEN	NTS		A - 12			
About Manuals							
			IS AND GENERIC TERMS				
			manual				
<u> </u>	OVE	RVIEV	V	1 - 1 to 1 - 12			
<u></u>							
	1.1		e Using Each Function Each function and related manuals				
		1.1.1 1.1.2	Hardware and OS' required for each function				
		1.1.2	Outline of procedure to the operation of each function				
		1.1.4	Displayable languages for each function				
<u>-</u> 2.	SYS	TEM N	IONITOR	2 - 1 to 2 - 60			
	2.1						
	2.2			2 - 6			
		2.2.1	System configuration				
		2.2.2	Devices that can be monitored	2 - 18			
		2.2.3	Access range				
		2.2.4	Precautions	2 - 18			
	2.3	Displa	ау	2 - 20			
		2.3.1	Outline until starting the system monitor	2 - 20			
	2.4	Opera	ation Procedure Common to the System Monitor Screens	2 - 23			
		2.4.1	Functional change menu screen				
		2.4.2	Entering monitor devices (specifying monitor stations and devices)				
		2.4.3	Key window setting columns and operation procedure				
		2.4.4	Switching the display format (DEC/HEX) and comment/no-comment display				
		2.4.5	Quick test operation of monitor devices				
		2.4.6	Changing screens				
	2.5		Monitor	2 - 35			
		2.5.1	Information displayed on the Entry Monitor screen and key functions				
		2.5.2	Procedure for entry monitor basic operation				
		2.5.3	Deleting entry devices				
	2.6		Monitor	2 - 40			
		2.6.1	Information displayed on the Batch Monitor screen and key functions	0 44			
		2.6.2	Procedure for batch monitor basic operation	7 - 44			

	2.7	IC M	onitor (Monitoring Timers and Counters)	2 - 45
		2.7.1	Information displayed on the TC Monitor screen and key functions	2 - 45
		2.7.2	Procedure for TC monitor basic operation	2 - 48
		2.7.3	Procedure for canceling TC monitor keywords	2 - 49
	2.8	вм м	Ionitor (Monitoring Buffer Memory)	2 - 50
		2.8.1	Information displayed on the BM Monitor screen and key functions	2 - 50
		2.8.2	Procedure for BM monitor basic operation	
	2.9	Test (Operation	2 - 53
		2.9.1	Procedure for displaying the test menu screen and the setting key window scre	
		2.9.2	Information displayed on the test menu screen and key functions	
		2.9.3	Information and set items displayed on each setting key window screen	
		2.9.4	Test operation procedure	
		2.9.5	Test operation basic procedure	
	2.10	Error	Messages and Corrective Action	2 - 60
3.	LAD	DER N	MONITOR FUNCTION :	3 - 1 to 3 - 75
	3.1	Featu	ires	3 - 1
	3.2		fications	3 - 4
	3.2	3.2.1		
		3.2.1	System configuration Devices and range that can be monitored	
		3.2.2	Access range	
		3.2.4	Precautions	
	3.3			3 - 16
	3.3	Displa		
		3.3.1	Outline until the start	
		3.3.2 3.3.3	Setting and deleting media for saving ladder data	
		3.3.4	Display Searching from the monitor screen	
		3.3.5	Reading comment files from CF cards	
	3.4		ation Procedure Common	3 - 38
	3.4			
		3.4.1	Information and key functions displayed on the screen	
		3.4.2	Hard copy output	
	3.5		hing the Display Format	3 - 46
		3.5.1	Display switching of 16-bit (one-word)/32-bit (two-word) modules	
		3.5.2	Display switching of decimal numbers/hexadecimal numbers	
		3.5.3	Switching comment/no-comment display	
		3.5.4 3.5.5	Displaying 32 characters of comments	
		3.5.6	Displaying notes Displaying statements	
		3.5.7	Language switching of the sequence program (MELSEC-Q/QnA ladder monito	
	3.6		sh Operation	2 5
	0.0	3.6.1	Device search	
		3.6.2	Contact point search	
		3.6.3	Coil search	
		3.6.4	Step search	
		3.6.5	Ladder end search	
		3.6.6	Defect search	
		3.6.7	Touch search	
	3.7		Operation	2 70
	J.1	3.7.1	Displaying the test menu screen	
	20	_		
	3.8	Local	Device Monitor	3 - 71

		3.8.1	Operation procedure for local device monitor	3 - 71
	3.9	Error	Messages and Corrective Action	3 - 74
4.	MEL	SEC-	A LIST EDITOR	4 - 1 to 4 - 38
	4.1	Featu	ıres	4 - 1
	4.2	Spec	ifications	4 - 3
		4.2.1	System configuration	4 - 3
		4.2.2	Access range	
		4.2.3	Precautions	4 - 5
	4.3	Displ	ay	4 - 6
		4.3.1	Outline until the start	
		4.3.2	Operation of keyword input	
	4.4	Oper	ation Methods	4 - 10
		4.4.1	Key arrangement and a list of key functions	
		4.4.2	Display format of the display area	
		4.4.3	Switching valid keys (upper/lower functions)	4 - 15
		4.4.4	Selection and operation of modes	
		4.4.5	Command input procedures	
		4.4.6	Hard copy output	
		4.4.7	Action if an incorrect key is input	
		4.4.8	List of functions	4 - 20
	4.5		Operation	
		4.5.1	Reading sequence programs	
		4.5.2	Changing (Overwriting) commands	
		4.5.3	Adding (Inserting) commands	
		4.5.4 4.5.5	Deleting commands	
		4.5.6	PLC memory all clear	
	4.6		f Operation Procedures	1 28
		4.6.1	Common operation	
		4.6.1	Operation in write mode (W)	
		4.6.3	Operation in read mode (R)	
		4.6.4	Operation in insert mode (I)	
		4.6.5	Operation in delete mode (D)	
		4.6.6	Operation in parameter mode (P)	
		4.6.7	Operation in other mode (O)	4 - 32
	4.7	Error	Messages and Corrective Actions	4 - 33
		4.7.1	Error messages and corrective actions in direct CPU connection	4 - 33
		4.7.2	PLC CPU error messages and troubleshooting	4 - 36
		4.7.3	Error using list editor function on the link system	4 - 37
5.	MEL	SEC-F	X LIST EDITOR	5 - 1 to 5 - 34
	5.1	Featu	ures	5 - 1
	5.2	Spec	ifications	5 - 3
		5.2.1	System configuration	
		5.2.2	Access range	
		5.2.3	Precautions	
	5.3	Displ		5 - 6
	5.4		ation Procedures	5 - 9
			Key arrangement and a list of key functions	5 0

		5.4.2	Selection and operation of modes	5 - 12
		5.4.3	Sequence program display	
		5.4.4	Searching commands and devices	
		5.4.5	Writing commands	
		5.4.6	Changing operands, set values	
		5.4.7	Deleting commands	
		5.4.8	Sequence program all clear	
		5.4.9	PLC diagnostics	
		5.4.10	Parameter setting	
		5.4.11	<u> </u>	
			List monitor	
			Hard copy output	
			Action for an incorrect key input	
	5.5		Messages and Corrective Actions	5 - 33
<u></u>			ENT MODULE MONITOR	6 - 1 to 6 - 116
<u> </u>	6.1	Featu		6 - 1
	6.2		fications Sustant configuration	
		6.2.1	System configuration	
		6.2.2	Access range	
		6.2.3	Precautions	
	6.3	Displa	ay	6 - 11
	6.4		ation of Each Intelligent Module Monitor Screen	6 - 15
		6.4.1	Composition of the system configuration screen and key functions	
		6.4.2	Setting method for other station monitoring	
		6.4.3	Composition of PC Information monitor screen and key functions	
		6.4.4	Composition of the unit detail info screen and key functions	
		6.4.5	Composition of the intelligent module monitor screen and key functions	
		6.4.6	Specifying a module to monitor and selecting monitor menu	
		6.4.7	Testing of the intelligent function module	6 - 25
	6.5	Intelli	gent Module Monitor Screens	6 - 27
		6.5.1	A62DA-S1 module monitoring	6 - 27
		6.5.2	A68AD module monitoring	
		6.5.3	A68ADN module monitoring	
		6.5.4	A68RD module monitoring	
		6.5.5	A84AD module monitoring	
		6.5.6	A616AD module monitoring	
		6.5.7	A616TD module monitoring	
		6.5.8	A616DAV module monitoring	
		6.5.9	A616DAI module monitoring	
			A61LS module monitoring	
			A62LS module monitoring	
			AD61 module monitoring	
			AD70 module monitoring	
			AD70D module monitoring	
			AD71 module monitoring	
			AD72/A1SD71 module monitoring	
			AJ71PT32-S3 module monitoring	
			A1SD61 module monitoring	
			A1S64AD module monitoring	
			A1S62DA module monitoring	
			A1SD70 module monitoring	
		6.5.22	A1S62RD module monitoring	6 - 59

		6.5.23 A1SJ71PT32-S3 module monitoring	6 - 60
		6.5.24 A1S63ADA module monitoring	
		6.5.25 AD75P/A1SD75P module monitoring	
		6.5.26 AJ71ID1(ID2)-R4/A1SJ71ID1(ID2)-R4 module monitoring	
		6.5.27 A1S68DAV module monitoring	
		6.5.28 A1S68DAI module monitoring	
		6.5.30 A1S64TCTT(BW)/A1S64TCRT(BW)-S1 monitoring	
		6.5.31 Q68ADV/Q68ADI/Q64AD module monitoring	
		6.5.32 Q62DA/Q64DA module monitoring	
		6.5.33 QD62D/QD62E/QD62 module monitoring	
		6.5.34 QD75P/QD75D module monitoring	
		6.5.35 QD75M module monitoring	
		6.5.36 QD75MH module monitoring	
	6.6	Operating I/O Module Monitor Screen	
		6.6.1 Specifying the module to be monitored	6 - 113
		6.6.2 Monitor screen configuration and key functions	
	6.7	Error Messages and Corrective Action	6 - 115
_		•	
<u> </u>	NEI	WORK MONITOR	7 - 1 to 7 - 30
	7.1	Features	7 - 1
	7.2	Specifications	7 - 3
		7.2.1 System configuration	
		7.2.2 Network information that can be monitored	
		7.2.3 Access range	
		7.2.4 Precautions	7 - 7
	7.3	Display	7 - 9
	7.4	Operation Procedures	7 - 12
		7.4.1 Line monitor	7 - 12
		7.4.2 Detailed monitor	7 - 15
		7.4.3 Other station monitor	7 - 23
		7.4.4 Other station communication status monitor	
		7.4.5 Other station data link status monitor	
		7.4.6 Other station parameter status monitor	
		7.4.7 Other station CPU operation status monitor	
		7.4.8 Other station CPU RUN status monitor	
		7.4.9 Other station loop status monitor	
	7.5	Error Message and Corrective Action	7 - 30
8.	Q M	OTION MONITOR	8 - 1 to 8 - 26
	8.1	Features	8 - 1
	8.2	Specifications	8 - 3
		8.2.1 System configuration	
		8.2.2 Access range	
		8.2.3 Precautions	
	8.3	Display	8 - 6
	8.4	Operation Procedures	8 - 9
		8.4.1 System configuration screen layout	
		8.4.2 Monitor Menu screen	
		8 4 3 Present Value Monitor screen	8 - 11

		8.4.4	SFC Error History screen	8 - 12
		8.4.5	Error List screen	8 - 13
		8.4.6	Error List Designated-Axis screen	
		8.4.7	Positioning Monitor screen	
		8.4.8	Servo Monitor screen	
		8.4.9 8.4.10	Present Value History Monitor screen	
		8.4.11	S .	
	8.5		Messages and Corrective Action	8 - 26
9.	SER	VO AN	MPLIFIER MONITOR	9 - 1 to 9 - 44
	9.1	Featu	ıres	9 - 1
	9.2	Speci	ifications	9 - 3
		9.2.1	System configuration	9 - 3
		9.2.2	Access range	
		9.2.3	Precautions	9 - 11
	9.3	Displa	ау	9 - 12
	9.4	Opera		9 - 15
		9.4.1	Servo amplifier monitor	
		9.4.2	Setup	
		9.4.3	Monitor functions	
		9.4.4	Alarm function	
		9.4.5	Diagnostics function	
		9.4.6	Parameter setting	
		9.4.7 9.4.8	Test operations Hard copy output	
	9.5		Messages and Corrective Action	9 - 44
10	. CN		NITOR FUNCTIONS	10 - 1 to 10 - 10
	10.1	Featu		10 - 1
	10.2		ifications	10 - 2
		10.2.1	System configuration	
		10.2.1	Access range	
		10.2.2	Precautions	
	10.3	Displa		10 - 6
	10.4	Opera	ation Procedures	10 - 8
	10.5	Error	Messages and Corrective Action	10 - 10
11	. BA	CKUP	/RESTORE	11 - 1 to 11 - 37
	11.1	Featu	ıres	
	11.2	Speci	ifications	11 - 3
		11.2.1	System configuration	
		11.2.2	Access range	
		11.2.3	Precautions	
	11.3	Displa	ay Operation	11 - 12
		11.3.1	Outline before starting	
		11.3.2	Setting storage location for backup data	
		4400	Security and password	
		11.3.3	Security and password	

	11.4 Operation Procedures	11 - 27
	11.4.1 Main menu	11 - 27
	11.4.2 Progress screen (backup)	
	11.4.3 Data list (restoration)	
	11.4.4 Progress screen (restoration)	
	11.5 Backup Data Conversion Tool	11 - 31
	11.5.1 Operating environment	
	11.5.2 How to install and start Backup Data Conversion Tool	
	11.5.3 How to use Backup Data Conversion Tool	
	11.5.4 Precautions	
	11.6 Errors and Corrective Actions	11 - 36
12	2. CNC DATA I/O	12 - 1 to 12 - 13
	12.1 Features	12 - 1
	12.2 Specifications	12 - 2
	12.2.1 System configuration	12 - 2
	12.2.2 Access range	
	12.2.3 Precautions	12 - 3
	12.3 Display	12 - 5
	12.4 Operation Procedures	12 - 7
	12.5 Error Messages and Corrective Actions	12 - 12
1:	3. SFC MONITOR	13 - 1 to 13 - 42
	13.1 Features	13 - 1
	13.2 Specifications	13 - 4
	13.2.1 System configuration	
	13.2.2 Devices and range that can be monitored	
	13.2.3 Access range	13 - 8
	13.2.4 Precautions	13 - 8
	13.3 Display Operation	13 - 9
	13.3.1 Outline before starting	13 - 9
	13.3.2 Setting SFC data storage location	13 - 12
	13.3.3 Reading comment files from CF card	13 - 13
	13.4 Setting Display Format	13 - 15
	13.4.1 Switching languages of SFC programs	
	13.4.2 Setting display mode of SFC programs	13 - 15
	13.4.3 Setting zoom comment display mode	13 - 15
	13.4.4 Switching display formats between decimal and hexadecimal numbers	
	13.4.5 Setting automatic scroll mode	
	13.5 How to Operate PLC Read Screen	13 - 17
	13.5.1 Displayed contents	13 - 17
	13.5.2 Key functions	
	13.6 How to Operate Block List Screen	
	13.6.1 Displayed contents	
	13.6.2 Key functions	
	13.6.3 Menus	
	13.7 How to Operate SFC Diagram Monitor Screen	
	13.7.1 Displayed contents	13 - 25
	15 / / KAVIIIICIONS	עני בין

13.7.3 Menus	13 - 29
13.8 Test Operation	13 - 38
13.9 Error Messages and Corrective Action	13 - 41
14. LADDER EDITOR	14 - 1 to 14 - 54
14.1 Features	14 - 1
14.2 Specifications	14 - 3
14.2.1 System configuration	
14.2.2 Devices and range that can be monitored	14 - 5
14.2.3 Access range	14 - 6
14.2.4 Precautions	14 - 6
14.3 Display Operation	14 - 8
14.3.1 Outline before starting	
14.3.2 Setting ladder data storage location	14 - 12
14.3.3 Reading comment files from CF card	14 - 13
14.4 Setting Display Format	14 - 15
14.4.1 Switching languages of sequence programs	
14.4.2 Switching comment display mode	14 - 15
14.4.3 Switching display formats between decimal and hexadecimal numbers	14 - 15
14.5 How to Operate PLC Read Screen	14 - 16
14.5.1 Displayed contents	14 - 16
14.5.2 Key functions	14 - 19
14.6 How to Operate Ladder Monitor Screen	14 - 22
14.6.1 Displayed contents	
14.6.2 Key functions	
14.6.3 Menus	14 - 23
14.7 How to Operate Ladder Editor Screen	14 - 27
14.7.1 Displayed contents	
14.7.2 Key functions	
14.7.3 Menus	14 - 37
14.8 Test Operation	14 - 49
14.9 Error Messages and Corrective Action	14 - 51
APPENDICES App	o - 1 to App - 39
Appendix1 List of Functions Added by GT Designer2 Version Upgrade (For GOT1000) Series)App - 1
Appendix.1.1GT16, GT15, GT SoftGOT1000, and GT11	App - 1
Appendix.1.2For GT10	App - 36
INDEX Index	- 1 to Index - 10

About Manuals

The following manuals are also related to this product.

If necessary, order them by quoting the details in the tables below.

The manual in PDF-format is included in the GT Works2 and GT Designer2 products.

Related Manuals

Manual Name		Manual Number (Model Code)		
GT16 User's Manual (Hardware)				
Describes the GT16 hardware-relevant contents, including the specifications, part names, wiring, external dimensions, and option devices.	, mounting, power supply	SH-080928ENG (1D7MD3)		
	(Sold separately)			
GT16 User's Manual (Basic Utility)				
Describes the GT16 utility-relevant contents, including the screen settings, operation method settings, program/ data management, and self check function.				
	(Sold separately)			
GT15 User's Manual				
 -Describes the GT15 hardware-relevant contents, including the specifications, part name supply wiring, external dimensions, and option devices. -Describes the GT15 functions, including the utility. 	es, mounting, power	SH-080528ENG (1D7M23)		
, , ,	(Sold separately)			
GT11 User's Manual				
 -Describes the GT11 hardware-relevant contents, including the specifications, part name supply wiring, external dimensions, and option devices. -Describes the GT11 functions, including the utility. 	s, mounting, power	JY997D17501 (09R815)		
2000.000 0.00 0.11 10.000.0, 110.0000.0, 110.000.0, 110.000.0, 110.000.0, 110.000.0, 110.000.0, 110.	(Sold separately)			
GT11 Handy GOT User's Manual -Describes the Handy GOT hardware-relevant contents, including the system configurati names, mounting, power supply wiring, external dimensions, and option devices. -Describes the Handy GOT functions, including the utility, and how to make cables.	ons, specifications, part (Sold separately)	JY997D20101 JY997D20102 (09R817)		
GT10 User's Manual				
 -Describes the GT10 hardware-relevant contents, including the specifications, part name supply wiring, external dimensions, and option devices. -Describes the GT10 functions, including the utility. 	es, mounting, power	JY997D24701 (09R819)		
	(Sold separately)			
GT SoftGOT1000 Version2 Operating Manual				
Describes the screen configuration, functions and using method of GT SoftGOT1000.	(Sold separately)	SH-080602ENG (1D7M48)		
GT Designer2 Version2 Basic Operation/Data Transfer Manual (For GOT1000 Series)				
Describes methods of the GT Designer2 installation operation, basic operation for drawing to GOT1000 series	ng and transmitting data	SH-080529ENG (1D7M24)		
	(Sold separately)			
GT Designer2 Version2 Screen Design Manual (For GOT1000 Series) (1/3, 2/3, 3/3) Describes specifications and settings of each object function applicable to GOT1000 ser	ani a	SH-080530ENG (1D7M25)		
Describes specifications and settings of each object function applicable to GOT 1000 ser	(Sold separately)	(10111120)		

(Continued to next page)

Manual Name				
GOT1000 Series Connection Manual (1/3, 2/3, 3/3) Describes system configurations of the connection method applicable to GOT1000 series and cable creation (Sold separately)				
GOT1000 Series Gateway Functions Manual Describes specifications, system comfigurations and setting method of the gateway function. (Sold separately)				
GOT1000 Series MES Interface Function Manual Describes the specifications, system configurations, and setting method of GT MES interface function. (Sold separately)	SH-080654ENG (1D7M63)			

ABBREVIATIONS AND GENERIC TERMS

Abbreviations and generic terms used in this manual are as follows:

■ GOT

GT 56RGOT1000 Abbreviation of GT 160RGOT1000	Abbreviations and generic terms		ic terms	Description
GT1685 GT1685M-S Abbreviation of GT1685M-STBA, GT1685M-STBD		GT SoftGOT1000		Abbreviation of GT SoftGOT1000
GT1675H-S GT1675M-S Abbreviation of GT1675M-STBA, GT1675M-STBD		GT1695	GT1695M-X	Abbreviation of GT1695M-XTBA, GT1695M-XTBD
GT1675 GT1675M-V Abbreviation of GT1675M-VTBA, GT1675M-VTBD		GT1685	GT1685M-S	Abbreviation of GT1685M-STBA, GT1685M-STBD
GT1655M-Y Abbreviation of GT1657M-VTBA, GT1655M-VTBD		CT1675	GT1675M-S	Abbreviation of GT1675M-STBA, GT1675M-STBD
GT1665M-V Abbreviation of GT1665M-VTBA, GT1665M-VTBD		G11075	GT1675M-V	Abbreviation of GT1675M-VTBA, GT1675M-VTBD
GT1665M-V Abbreviation of GT1665M-VTBA, GT1665M-VTBD		CT1665	GT1665M-S	Abbreviation of GT1665M-STBA, GT1665M-STBD
GT1595 GT1595-X Abbreviation of GT1595-XTBA, GT1595-XTBD		G11005	GT1665M-V	Abbreviation of GT1665M-VTBA, GT1665M-VTBD
GT1585 GT1585V-S Abbreviation of GT1585V-STBA, GT1585V-STBD		GT16□□,	GT16	Abbreviation of GT1695, GT1685, GT1675, GT1665
GT1585 GT1585-S Abbreviation of GT1585-STBA, GT1585-STBD GT1570-S Abbreviation of GT1575-V-STBA, GT1575-V-STBD GT1575-V Abbreviation of GT1575-V-STBA, GT1575-V-STBD GT1572-V-N Abbreviation of GT1575-V-NBA, GT1575-V-NBD GT1560-V Abbreviation of GT1585-V-NBA, GT1572-V-NBD GT1561-V-STBA, GT1562-V-NBA, GT1562-V-NBD GT1562-V-N Abbreviation of GT1562-V-NBA, GT1562-V-NBD GT1550-V Abbreviation of GT1562-V-NBA, GT1562-V-NBD GT1550-V Abbreviation of GT1550-V-STBD GT1150-V Abbreviation of GT1550-V-STBD GT1150-V Abbreviation of GT1155-V-STBD GT1150-V Abbreviation of GT1155-V-STBD GT1150-V Abbreviation of GT1155-V-STBD GT1150-V Abbreviation of GT1155-V-STBD GT110-V Abbreviation of GT1155-V-STBD GT1150-V Abbreviation of GT1150-V-STBD GT1050-V Abbreviation of GT1150-V-STBD GT1050-V Abbreviation of GT1050-V-SBD GT1040-V Abbrevi		GT1595	GT1595-X	Abbreviation of GT1595-XTBA, GT1595-XTBD
GT1585-S Abbreviation of GT1585-STBA, GT1585-STBD		074505	GT1585V-S	Abbreviation of GT1585V-STBA, GT1585V-STBD
GT1575-S Abbreviation of GT1575-STBD		G11585	GT1585-S	Abbreviation of GT1585-STBA, GT1585-STBD
GT157□ GT1575-V Abbreviation of GT1575-VTBA, GT1575-VTBD			GT1575V-S	Abbreviation of GT1575V-STBA, GT1575V-STBD
GT1575-VN Abbreviation of GT1575-VNBD			GT1575-S	Abbreviation of GT1575-STBA, GT1575-STBD
GT1572-VN Abbreviation of GT1572-VNBA, GT1572-VNBD		GT157□	GT1575-V	Abbreviation of GT1575-VTBA, GT1575-VTBD
GOT1000 Series GT156-V GT156-V Abbreviation of GT1565-VTBD, GT1565-VTBD GT1562-VN Abbreviation of GT1562-VNBA, GT1562-VNBD GT155-V Abbreviation of GT1555-VTBD GT155-Q Abbreviation of GT1555-QTBD, GT1555-QSBD GT155-Q Abbreviation of GT1555-QTBD, GT1555-QSBD GT150-Q Abbreviation of GT1595, GT1585, GT157-, GT156-, GT155- GT115-Q GT115-Q GT115-Q GT115-Q GT115-Q GT115-QTBD, GT1155-QSBD, GT1155-QSBD, GT1155-QTBDA, GT1155-QSBDA, GT115-QTBDA, GT1155-QTBDA, GT115-QTBDA, GT105-QTBDA, GT105			GT1575-VN	Abbreviation of GT1575-VNBA, GT1575-VNBD
GT156 GT1562-VN Abbreviation of GT1562-VNBA, GT1562-VNBD			GT1572-VN	Abbreviation of GT1572-VNBA, GT1572-VNBD
GT1562-VN Abbreviation of GT1562-VNBA, GT1562-VNBD		07450	GT1565-V	Abbreviation of GT1565-VTBA, GT1565-VTBD
GT1555-V Abbreviation of GT1555-VIBD		GT156□	GT1562-VN	Abbreviation of GT1562-VNBA, GT1562-VNBD
GT1550-Q Abbreviation of GT1550-QLBD	GOT1000 Series		GT1555-V	Abbreviation of GT1555-VTBD
GT15□□, GT15		GT155□	GT1555-Q	Abbreviation of GT1555-QTBD, GT1555-QSBD
GT115□ GT1155-Q Abbreviation of GT1155-QTBDQ, GT1155-QSBDQ, GT1155-QTBDA, GT1155-QSBDA, GT1155-QTBDA, GT1155-QTBDA, GT1155-QSBDA, GT1155-QTBDA, GT1155-QTBDA, GT1155-QSBDA, GT1150-QLBDQ, GT1150-QLBDA, GT1150-QLBD GT11			GT1550-Q	Abbreviation of GT1550-QLBD
GT115□ GT1155-Q GT1155-QTBD, GT1155-QSBD GT1150-Q Abbreviation of GT1150-QLBDQ, GT1150-QLBDA, GT1150-QLBD GT11		GT15□□,	GT15	Abbreviation of GT1595, GT1585, GT157□, GT156□, GT155□
GT1150-Q Abbreviation of GT1150-QLBDQ, GT1150-QLBDA, GT1150-QLBD		GT115□	GT1155-Q	
Handy GOT			GT1150-Q	Abbreviation of GT1150-QLBDQ, GT1150-QLBDA, GT1150-QLBD
GOT		GT11	GT1155HS-Q	Abbreviation of GT1155HS-QSBD
GT105D GT105D Abbreviation of GT1055-QSBD GT105D-Q Abbreviation of GT105D-QBBD GT104D GT104D-Q Abbreviation of GT1045-QSBD GT104D-Q Abbreviation of GT104D-QBBD GT1030 Abbreviation of GT1030-LBD, GT1030-LBDW, GT1030-LBDW2 GT1020 Abbreviation of GT1020-LBD, GT1020-LBD2, GT1020-LBDW, GT10		1	GT1150HS-Q	Abbreviation of GT1150HS-QLBD
GT105□ GT105□-Q Abbreviation of GT1050-QBBD GT104□ GT1045-Q Abbreviation of GT1045-QSBD GT1040-Q Abbreviation of GT1040-QBBD GT1030 Abbreviation of GT1030-LBD, GT1030-LBDW, GT1030-LBDW2 GT1020 Abbreviation of GT1020-LBD, GT1020-LBD2, GT1020-LBDW, GT1020-LBDW, GT1020-LBDW2, GT1020-LBDW2, GT1020-LBLW GT10□□, GT10 Abbreviation of GT105□, GT104□, GT1030, GT1020 GOT900 Series Abbreviation of GOT-A900 series, GOT-F900 series		GT11□□,	GT11	Abbreviation of GT1155-Q, GT1150-Q, GT11 Handy GOT
GT1050-Q Abbreviation of GT1050-QBBD			GT1055-Q	Abbreviation of GT1055-QSBD
GT104□ GT1040-Q Abbreviation of GT1040-QBBD		GT105□	GT1050-Q	Abbreviation of GT1050-QBBD
GT1040-Q Abbreviation of GT1040-QBBD			GT1045-Q	Abbreviation of GT1045-QSBD
GT1020 Abbreviation of GT1020-LBD, GT1020-LBD2, GT1020-LBDW, GT1020-LBDW2, GT1020-LBDW2, GT1020-LBLW GT10□□, GT10 Abbreviation of GT105□, GT104□, GT1030, GT1020 GOT900 Series Abbreviation of GOT-A900 series, GOT-F900 series		GT104□	GT1040-Q	Abbreviation of GT1040-QBBD
GT1020 GT1020-LBDW2, GT1020-LBLW GT10□□, GT10 Abbreviation of GT105□, GT104□, GT1030, GT1020 GOT900 Series Abbreviation of GOT-A900 series, GOT-F900 series		GT1030	l	Abbreviation of GT1030-LBD, GT1030-LBD2, GT1030-LBDW, GT1030-LBDW2
GT1020-LBDW2, GT1020-LBLW GT10□□, GT10 Abbreviation of GT105□, GT104□, GT1030, GT1020 GOT900 Series Abbreviation of GOT-A900 series, GOT-F900 series		CT1020		Abbreviation of GT1020-LBD, GT1020-LBD2, GT1020-LBL, GT1020-LBDW,
GOT900 Series Abbreviation of GOT-A900 series, GOT-F900 series		G11020		GT1020-LBDW2, GT1020-LBLW
		GT10□□, GT10		Abbreviation of GT105□, GT104□, GT1030, GT1020
GOT800 Series Abbreviation of GOT-800 series	GOT900 Series			Abbreviation of GOT-A900 series, GOT-F900 series
	GOT800 Series			Abbreviation of GOT-800 series

■ Communication unit

Abbreviations and generic terms		D	escription	
Bus connection unit	GT15-QBUS, GT15-75QBUSL,	GT15-QBUS2, GT15-75QBUS2L,	GT15-ABUS, GT15-75ABUSL,	GT15-ABUS2, GT15-75ABUS2L
Serial communication unit	GT15-RS2-9P,	GT15-RS4-9S,	GT15-RS4-TE	
RS-422 conversion unit	GT15-RS2T4-9P,	GT15-RS2T4-25P		
Ethernet communication unit	GT15-J71E71-100			
MELSECNET/H communication unit	GT15-J71LP23-25,	GT15-J71BR13		
MELSECNET/10 communication unit	GT15-75J71LP23-Z*1,	GT15-75J71BR13-2	<u>z</u> *2	
CC-Link IE controller network communication unit	GT15-J71GP23-SX			
CC-Link communication unit	GT15-J61BT13,	GT15-75J61BT13-Z	•*3 -	
Interface converter unit	GT15-75IF900			
Serial multi-drop connection unit	GT01-RS4-M			
Connection Conversion Adapter	GT10-9PT5S			

- *1 A9GT-QJ71LP23 + GT15-75IF900 set
- *2 A9GT-QJ71BR13 + GT15-75IF900 set
- *3 A8GT-J61BT13 + GT15-75IF900 set

Option unit

Abbreviation	Abbreviations and generic terms		Description
Printer unit		GT15-PRN	
	Video input unit	GT16M-V4,	GT15V-75V4
Video/RGB unit	RGB input unit	GT16M-R2,	GT15V-75R1
VIGEO/NGB UIIII	Video/RGB input unit	GT16M-V4R1,	GT15V-75V4R1
	RGB output unit	GT16M-ROUT,	GT15V-75ROUT
Multimedia unit	Multimedia unit		
CF card unit		GT15-CFCD	
CF card extension	CF card extension unit ^{*1}		
External I/O unit		GT15-DIO,	GT15-DIOR
Sound output unit	Sound output unit		
Fingerprint unit		GT15-80FPA	

^{*1} GT15-CFEX + GT15-CFEXIF + GT15-C08CF set.

Option

Abbreviatio				D	escriptio	n			
Memory card	CF card	GT05-MEM-16MC, GT05-MEM-32MC, GT05-MEM-64MC, GT05-MEM-128MC,							
·		GT05-MEN		GT05-I	MEM-512MC	, GT05-N	MEM-1GC,	GT05-	MEM-2GC
Memory card ada	ptor	GT05-MEN							
Option function bo	oard	GT16-MES	,	GT15-F	,		15-QFNB,		GT15-QFNB16M,
		GT15-QFN	,		QFNB48M,	GT	15-MESB48	И,	GT11-50FNB
Battery		GT15-BAT	,	GT11-5					
			GT16-90F	,	GT16-90PS	,	GT16-90PS	•	GT16-90PSGW,
		For	GT16-80F	,	GT16-80PS		GT16-80PS	- ,	GT16-80PSGW,
		GT16	GT16-70F		GT16-70P3		GT16-70PS	•	GT16-70PSGW,
			GT16-60F		GT16-60P3		GT16-60PS		GT16-60PSGW
			GT15-90F	,	GT15-90PS	,	GT15-90PS	- ,	GT15-90PSGW,
		For	GT15-80F		GT15-80PS		GT15-80PS		GT15-80PSGW,
		GT15	GT15-70F	,	GT15-70PS		GT15-70PS		GT15-70PSGW,
Protective Sheet			GT15-60F	,	GT15-60PS		GT15-60PS	,	GT15-60PSGW,
			GT15-50F		GT15-50PS		GT15-50PS		GT15-50PSGW
		For GT11	GT11-50F		GT11-50PS	SGB,	GT11-50PS	CW,	GT11-50PSGW,
			GT11H-50	PSC					
			GT10-50F	PSCB,	GT10-50P9	SGB,	GT10-50PS	CW,	GT10-50PSGW,
		For	GT10-40F	PSCB,	GT10-40PS	SGB,	GT10-40PS	CW,	GT10-40PSGW,
		GT10	GT10-30F	PSCB,	GT10-30P3	SGB,	GT10-30PS	CW,	GT10-30PSGW,
			GT10-20F	PSCB,	GT10-20PS	SGB,	GT10-20PS	CW,	GT10-20PSGW
Protective cover for	or oil	GT05-90P	CO,	GT05-8	30PCO,	GT05-7	70PCO,	GT05-	60PCO,
		GT05-50P	СО						
USB environment	al protection cover	GT16-UC0	OV,	GT15-l	JCOV,	GT11-5	50UCOV		
Stand		GT15-90S	TAND,	GT15-8	BOSTAND,	GT15-7	70STAND,	A9GT-	50STAND,
Otaria		GT05-50S	TAND						
Attachment		GT15-70A	TT-98,	GT15-7	70ATT-87,	GT15-6	60ATT-97,	GT15-	60ATT-96,
Attachment		GT15-60A	TT-87,	GT15-6	60ATT-77,	7, GT15-50ATT-95W,		GT15-50ATT-85	
		GT16-90X	LTT,	GT16-8	BOSLTT,	GT15-9	OXLTT,	GT15-	80SLTT,
Backlight		GT16-70S	LTT,	GT16-7	70VLTT,	GT16-6	SOSLTT,	GT16-	60VLTT,
Dacklight		GT15-70S	LTT,	GT15-7	70VLTT,	GT15-7	70VLTN,	GT15-	60VLTT,
		GT15-60V	LTN						
Multi-color display	board	GT15-XHN	IB,	GT15-\	/HNB				
Connector conver	sion box	GT11H-CN	IB-37S						
Emergency stop s	sw guard cover	GT11H-50ESCOV							
Memory loader		GT10-LDR							
Memory board		GT10-50F	MB						

Software

Abbreviations and generic terms	Description
GT Works2 Version□	SW□D5C-GTWK2-E, SW□D5C-GTWK2-EV
GT Designer2 Version□	SW□D5C-GTD2-E, SW□D5C-GTD2-EV
GT Designer2	Abbreviation of screen drawing software GT Designer2 for GOT1000/GOT900 series
GT Converter2	Abbreviation of data conversion software GT Converter2 for GOT1000/GOT900 series
GT Simulator2	Abbreviation of screen simulator GT Simulator 2 for GOT1000 / GOT900 series
GT SoftGOT1000	Abbreviation of monitoring software GT SoftGOT1000
GT SoftGOT2	Abbreviation of monitoring software GT SoftGOT2
GX Developer	Abbreviation of SW□D5C-GPPW-E(-EV)/SW□D5F-GPPW-E type software package
GX Simulator	Abbreviation of SW□D5C-LLT-E(-EV) type ladder logic test tool function software packages
GA Simulator	(SW5D5C-LLT (-EV) or later versions)
Document Converter	Abbreviation of document data conversion software Document Converter for GOT1000 series
PX Developer	Abbreviation of SW□D5C-FBDQ-E type FBD software package for process control

■ License key (for GT SoftGOT1000)

Abbreviations and generic terms	Description
License	GT15-SGTKEY-U, GT15-SGTKEY-P

■ License key (for GT SoftGOT2)

Abbreviations and generic terms	Description
License key	A9GTSOFT-LKEY-P (For DOS/V PC)
License key FD	SW5D5F-SGLKEY-J (For PC CPU module)

Others

Abbreviations and generic terms		Description
OMRON PLC		Abbreviation of PLC manufactured by OMRON Corporation
KEYENCE PLC		Abbreviation of PLC manufactured by KEYENCE CORPORATION
KOYO EI PLC		Abbreviation of PLC manufactured by KOYO ELECTRONICS INDUSTRIES CO., LTD.
SHARP PLC		Abbreviation of PLC manufactured by Sharp Manufacturing Systems Corporation
JTEKT PLC		Abbreviation of PLC manufactured by JTEKT Corporation
TOSHIBA PLC		Abbreviation of PLC manufactured by TOSHIBA CORPORATION
TOSHIBA MAC	HINE PLC	Abbreviation of PLC manufactured by TOSHIBA MACHINE CO., LTD.
HITACHI IES PI	LC	Abbreviation of PLC manufactured by Hitachi Industrial Equipment Systems Co., Ltd.
HITACHI PLC		Abbreviation of PLC manufactured by Hitachi, Ltd.
FUJI FA PLC		Abbreviation of PLC manufactured by Fuji Electric FA Components & Systems Co., Ltd.
PANASONIC PI	LC	Abbreviation of PLC manufactured by Panasonic Electric Works Co., Ltd.
YASKAWA PLC	,	Abbreviation of PLC manufactured by YASKAWA Electric Corporation
YOKOGAWA P	LC	Abbreviation of PLC manufactured by Yokogawa Electric Corporation
ALLEN-BRADL	EY PLC	Abbreviation of Allen-Bradley PLC manufactured by Rockwell Automation, Inc.
GE FANUC PLO	2	Abbreviation of PLC manufactured by GE Fanuc Automation Corporation
LS IS PLC		Abbreviation of PLC manufactured by LS Industrial Systems Co., Ltd.
SCHNEIDER P	LC	Abbreviation of PLC manufactured by Schneider Electric SA
SIEMENS PLC		Abbreviation of PLC manufactured by Siemens AG
	OMRON temperature controller	Abbreviation of temperature controller manufactured by OMRON Corporation
	SHINKO indicating controller	Abbreviation of temperature controller manufactured by Shinko Technos Co., Ltd.
	CHINO controller	Abbreviation of temperature controller manufactured by CHINO CORPORATION
Temperature	FUJI SYS temperature controller	Abbreviation of temperature controller manufactured by Fuji Electric Systems Co., Ltd.
controller	YAMATAKE temperature controller	Abbreviation of temperature controller manufactured by Yamatake Corporation
	YOKOGAWA temperature controller	Abbreviation of temperature controller manufactured by Yokogawa Electric Corporation
	RKC temperature controller	Abbreviation of temperature controller manufactured by RKC INSTRUMENT INC.
PC CPU module	e	Abbreviation of PC CPU Unit manufactured by CONTEC CO., LTD
GOT (server)		Abbreviation of GOTs that use the server function
GOT (client)		Abbreviation of GOTs that use the client function
Windows [®] font		Abbreviation of TrueType font and OpenType font available for Windows [®] (Differs from the True Type fonts settable with GT Designer2)
Intelligent function module		Indicates the modules other than the PLC CPU, power supply module and I/O module that are mounted to the base unit.
MODBUS [®] /TCP		Generic term for the protocol designed to use MODBUS [®] protocol messages on a TCP/IP network.

1 Functions


This manual describes functions available for GT Designer2 Version2.96A.

For the added functions by the product version upgrade, refer to the list of functions added by GT Designer2 version upgrade in Appendices.

In addition, GT Designer2 Version2.98C supports the multimedia function of recording and playing video files with sound, and GT Works3 Version1.14Q supports the multidrop connection on GT16 and GT15.

2 Symbols

Following symbols are used in this manual.



OVERVIEW

This manual describes the following functions available on a GOT system in which the standard monitor OS, an Extended function OS, an Option OS, and the Communication driver are installed.

- · System monitor
- · Ladder monitor
- · A list editor
- · FX list editor
- · Intelligent module monitor
- · Network monitor
- · Q motion monitor
- · Servo amplifer monitor
- · CNC monitor
- · Backup/restore
- · CNC data I/O
- SFC monitor
- · Ladder editor

The monitor functions explained herein are intended to troubleshoot the PLC system and to streamline maintenance operations.



(1) Precautions for using each function

Some functions are not available depending on the GOT used, target CPU or connection form.

For option function boards, functions available on each GOT, and restrictions on each target CPU and connection form, see the appropriate chapter.

(2) Display examples in this manual In this manual, with a few special exceptions, explanations are given primarily using the GTI575-V screens.

1.1 Before Using Each Function

1.1.1 Each function and related manuals

The difference between the extended and option functions of the GOT is shown below.

• Extended functions: Functions available by installing an Extended function OS.

• Option functions : Functions available by connecting an option function board (including a board with

add-on memory).

Many of the option functions require an Option OS to be installed.

For a description of each function, see the appropriate manual listed below.

1 Manuals describing functions and how to set them

Category	Function name	Reference
	Bar code	OT Pasience O Ventine To Consen Pasient Manual
	RFID	GT Designer 2 Version ☐ Screen Design Manual
	System monitor	Chapter 2
	Stroke font	
	Video display	
	RGB display	GT Designer2 Version ☐ Screen Design Manual
	Remote personal computer operation	
	Multimedia	
	Backup/restore	Chapter11
	CNC data I/O	Chapter12
	Operator authentication	
	Sound output	OT Design and Manager
	External I/O/operation panel	- GT Designer2 Version □ Screen Design Manual
	Device data transfer	1
	Maintenance timing setting	GT15 User's Manual
Extended functions	Multi-channel	
Extended functions	KANJI regions	
	Operation log	
	Document display	
	Kana-kanji conversion*1	
	Kana-kanji conversion (enhanced version)	GT Designer 2 Version Screen Design Manual
	Historical Trend Graph	
	Logging	
	Recipe	
	Advanced Recipe	
	Object Script	
	Ladder monitor	Chapter 3
	A list editor	Chapter 4
	FX list editor	Chapter 5
	Intelligent module monitor	Chapter 6
	Network monitor	Chapter 7
	Q motion monitor	Chapter 8

(Continued to next page)

Category	Function name	Reference
	Servo amplifer monitor	Chapter 9
	CNC monitor	Chapter 10
Option functions	SFC monitor	Chapter 13
Option functions	Ladder editor	Chapter 14
	Gateway	GOT1000 Series Gateway Functions Manual
	MES interface	GOT1000 Series MES Interface Function Manual

2 Manuals describing how to connect an option function board

GOT	Reference manual					
GT16	GT16 User's Manual (Hardware)					
GT15	GT15 User's Manual					
GT11	GT11 User's Manual					

3 Manuals describing how to install each OS

OS	Reference manual				
Extended function OS	CT Designer 2 Version Design Operation/Data Transfer Manual				
Option OS	GT Designer 2 Version □ Basic Operation/Data Transfer Manual				

1.1.2 Hardware and OS' required for each function

To use each function, extended function OS, or option OS and option function board is required. For installing the extended function OS or option OS on the GOT, make sure that the user area of the specified drive has enough free space for the OS memory space shown on the next page. For details of data transfer, refer to the following.

> GT Designer 2 Basic Operation/Data Transfer Manual Subsection 8.1.2 Drive capacity required for data transfer

The following shows the option function boards applicable to each GOT.

GOT	Option function board
GT16	GT16-MESB
GT15	GT15-FNB, GT15-QFNB, GT15-QFNB16M, GT15-QFNB32M, GT15-QFNB48M, GT15-MESB48M
GT11	GT11-50FNB
GT10	Not required

An option function board (GT15-FNB or GT11-50FNB) is built in the following GOTs.

GOT	Model	Description		
GT15 ^{*1}	All models			
	GT1155-QTBDQ, GT1155-QTBDA, GT1155-QSBDQ, GT1155-QSBDA, GT1150-QLBDQ, GT1150-QLBDA	Function version D or later		
GT11	GT1155-QTBD	Hardware Version A or later		
	GT1155HS-QSBD, GT1150HS-QLBD	Hardware Version B or later		
	GT1155-QSBD, GT1150-QLBD	Hardware Version C or later		

^{*1} For using an option function board built in the GOT, the latest standard monitor OS must be installed on the GOT. For OS versions, refer to the following.

Appendix1 List of Functions Added by GT Designer2 Version Upgrade (For GOT1000

Option functions operated with the GT15-FNB or GT11-50FNB can be used without installing an additional option function board.

For using functions operated with the GT16-MESB, GT15-QFNB(□ M), or GT15-MESB48M, and for adding more memory to the GT15, install an applicable option function board.

An additional option function board can be installed on the GOT with a built-in option function board. (An option function board inapplicable to the GOT cannot be used. (An option function board for the GT11 cannot be installed on the GT15.))

For how to check function versions and hardware versions, refer to the following manuals.

📝 GT15 User's Manual GT11 User's Manual GT11 Handy GOT User's Manual 1 For GT16

○: Required (Either one) x: Unusable

	Extended function OS /	OS memory spa	ice (user area)*1	user area) ^{*1} Option function board	
Function name	option OS name	Built-in flash memory (ROM)	User memory (RAM)	GT16-MESB	
Bar code	Bar code	50KB	84KB	Not required	
RFID	RFID	50KB	166KB	Not required	
System monitor	System monitor		450KB 692KB		
Report	Report	150KB	235KB	Not required Not required	
Printer	Printer	552KB	1104KB	Not required	
rinitei	Stroke Font Support Data	300 KB	400 KB	Not required	
	Stroke Standard Font(JPN)	2160KB	2160KB	Not required	
	Stroke Standard	2100115	210010	Not required	
*2	Font(JPN)(supporting Hangul)	3175KB 3175KB		Not required	
Stroke font ^{*2}	Stroke Standard Font(China GB)	1474KB	1474KB	Not required	
	Stroke Standard Font(China GB)(supporting Hangul)	2016KB	2016KB	Not required	
Video display	X 11 0 0 7	000:17	100:57		
RGB display	Video/RGB	298KB	480KB	Not required	
Multimedia	Multimedia	298KB	1074KB	Not required	
Remote personal computer	Video/RGB	298KB	480KB	Not required	
operation	PC Remote Operation	50KB	84KB	Not required	
Backup/restore	Backup/Restore	420KB	766KB	Not required	
	Operator authentication	460KB	730KB	Not required	
Operator Authentication	Fingerprint Authentication	270KB	616KB	Not required	
Sound Output	Sound Output	100KB	200KB	Not required	
External I/O / Operation Panel	External I/O / Operation Panel	70KB	100KB	Not required	
·	CNC Data I/O	210KB	383KB	Not required	
CNC data I/O	GOT Platform Library	77KB	200KB	Not required	
Device data transfer	Device Data Transfer	50KB	100KB	Not required	
Maintenance timing setting	Not required	-	-	Not required	
Multi-channel	Not required	-	-	Not required	
	Standard Font (China GB)	1280KB	1280KB	Not required	
	Standard Font (China Big5)	1920KB	1920KB	Not required	
	Standard Font (Japanese)	1280KB	1280KB	Not required	
KANJI regions	Stroke Font (JPN)	1037KB	1037KB	Not required	
	Stroke Font (China GB5)	1248KB	1248KB	Not required	
	Stroke Font (China Big5)	1680KB	1680KB	Not required	
	Operation Log	384KB	1221KB	Not required	
Operation log	Device name converter	400KB	800KB	Not required	
Document display	Document Display	150KB	3072KB	Not required	
Kana-kanji conversion	KANA KANJI(JPN)	, , , , , ,	-0.2.0		
(enhanced version)	(Enhanced Version)	1242KB	2774KB	Not required	
Historical Trend Graph	Not required	-	-	Not required	
Logging	Logging	380KB	710KB	Not required	
Recipe	Recipe	70KB	100KB	Not required	
Advanced Recipe	Advanced Recipe	310KB	1187KB	Not required	

(Continued to next page)

	5 t 1 t 15 15 00 t	OS memory sp	ace (user area)	Option function board	
Function name	Extended function OS / option OS name	Built-in flash memory (ROM)	User memory (RAM)	GT16-MESB	
Object Script	Object Script	180KB 360KB		Not required	
	Ladder monitor for MELSEC-A	342KB	674KB	Not required	
Ladder monitor	Ladder monitor for MELSEC-FX	342KB	674KB	Not required	
	Ladder monitor for MELSEC-Q/QnA	590KB	4170KB	Not required	
	GOT Platform Library	77KB	200KB	Not required	
Ladder editor*3	Ladder editor	2567KB	8192KB	Not required	
Ladder editor °	GOT Function Expansion Library	4729KB	19381KB	Not required	
A list editor	List editor for MELSEC-A	542KB	1024KB	Not required	
FX list editor	List editor for MELSEC-FX	542KB 1024KB		Not required	
Intelligent module monitor	Intelligent module monitor	390KB	770KB	Not required	
Network monitor	Network monitor	210KB	370KB	Not required	
Q motion monitor	Q motion monitor	390KB 770KB		Not required	
Servo amplifier monitor	Servo amplifier monitor	390KB 770KB		Not required	
CNC monitor	CNC monitor 390KB 770KB		770KB	Not required	
	GOT Platform Library	77KB	200KB	Not required	
SFC monitor*4	SFC monitor	442KB	2108KB	Not required	
SFC monitor *	GOT Function Expansion Library	4729KB	19381KB	Not required	
	Gateway (Server, Client)	50KB	100KB	Not required	
Gateway	Gateway (Mail)	50KB 100KB		Not required	
	Gateway (FTP)	50KB	84KB	Not required	
MES interface	MES Interface	1598KB	13461KB	0	

^{*1} The OS memory space differs between the built-in flash memory (ROM) and the user memory (RAM).

When writing data, including the OS, communication drivers, and project data, from the built-in flash memory (ROM) to the user memory (RAM), the OS data size increases. Make sure that the total data size does not exceed the user memory (RAM) capacity.

For how to use fonts and the setting method, refer to the following manual.

^{*2} For using fonts, install option fonts if necessary.

GT Designer2 Version ☐ Screen Design Manual (2.3 Specifications of Applicable Characters)

^{*3} For using the ladder editor, install all the OSs of [GOT Platform Library], [Ladder editor], and [GOT Function Expansion Library] on the GOT.

^{*4} For using the SFC monitor, install all the OSs of [GOT Platform Library], [SFC monitor], and [GOT Function Expansion Library] on the GOT.

2 For GT15

For GOTs with built-in option function boards, refer to the following.

Section 1.1.2 Hardware and OS' required for each function

○: Required (Either one) x: Unusable

Bar code RFID System monitor Report Printer Stroke font*6	Extended function OS / option OS name Bar code RFID System monitor Report Printer	OS memory space (user area) 84KB 166KB 746KB	GT15-FNB	Option function board GT15-QFNB GT15-QFNB□M Not required	GT15-MESB48M		
Bar code RFID System monitor Report Printer	Bar code RFID System monitor Report Printer	(user area) 84KB 166KB 746KB	GT15-FNB	GT15-QFNB□M	GT15-MESB48M		
RFID System monitor Report Printer	RFID System monitor Report Printer	166KB 746KB		Not required			
System monitor Report Printer	System monitor Report Printer	746KB					
Report Printer	Report Printer			Not required			
Printer	Printer	2251/D		Not required			
		235KB		Not required			
Stroke font ^{*6}		1104KB		Not required			
Stroke font ^{*6}	Stroke Font Support Data	400 KB	Not required				
Stroke font ^{*6}	Stroke Standard Font(JPN)	2160KB		Not required			
Stroke lont	Stroke Standard Font(JPN)(supporting Hangul)	3175KB		Not required			
	Stroke Standard Font(China GB)	1474KB		Not required			
	Stroke Standard Font(China GB)(supporting Hangul)	2016KB		Not required			
Video display ^{*2}	Video/RGB	512KB		Not required			
RGB display*2	Video/NGB	SIZKB	Not required				
Remote personal computer	Video/RGB	512KB	Not required				
operation*2	PC Remote Operation	84KB	Not required				
Backup/restore	Backup/Restore	820KB	Not required				
Operator Authoritication	Operator authentication	784KB	Not required				
Operator Authentication -	Fingerprint Authentication	616KB	Not required				
Sound Output	Sound Output	200KB	Not required				
External I/O / Operation Panel	External I/O / Operation Panel	100KB	Not required				
CNC data I/O*1	CNC Data I/O	437KB					
CNC data I/O	GOT Platform Library	100KB					
Device data transfer	Device Data Transfer	100KB	Not required				
Maintenance timing setting	Not required	1	0	0	0		
Multi-channel	Not required	1	×	0	0		
	Standard Font (China GB)	1280KB	0	0	0		
	Standard Font (China Big5)	1920KB	0	0	0		
	Standard Font (Japanese)	1280KB	0	0	0		
KANJI regions	Stroke Font (JPN)	1037KB	0	0	0		
	Stroke Font (China GB5)	1248KB	0	0	0		
	Stroke Font (China Big5)	1680KB	0	0	0		
	Operation Log	1218KB	0	0	0		
Operation log	Device name converter	800KB	0	0	0		
Document display	Document Display	2048KB	× 0 0				
Kana-kanji conversion ^{*4}	KANA KANJI(JPN)*4	1223KB	0	0	0		
Kana-kanji conversion	KANA KANJI(JPN)	3.12					
(enhanced version)*4	(Enhanced Version)*4	2774KB	0 0 0				

(Continued to next page)

		OS memory	Option function board			
Function name	Extended function OS / option OS name	space (user area)	GT15-FNB	GT15-QFNB GT15-QFNB□M	GT15-MESB48M	
Historical Trend Graph	Not required	-	0	0	0	
Logging	Logging	740KB	0	0	0	
Recipe	Recipe	100KB	0	0	0	
Advanced Recipe	Advanced Recipe	1241KB	0	0	0	
Object Script	Object Script	360KB	0	0	0	
	Ladder monitor for MELSEC-A	523KB	0	0	0	
Ladder monitor ^{*3}	Ladder monitor for MELSEC-FX	592KB	0	0	0	
	Ladder monitor for MELSEC-Q/QnA	1082KB	×	0	0	
	GOT Platform Library	100KB	Not required			
Ladder editor	Ladder editor	5121KB	×	0	0	
Ladder editor	GOT Function Expansion Library	4729KB	×	0	0	
A list editor	List editor for MELSEC-A	1058KB	0	0	0	
FX list editor	List editor for MELSEC-FX	1058KB	0	0	0	
Intelligent module monitor*3	Intelligent module monitor	384KB	0	0	0	
Network monitor	Network monitor	324KB	0	0	0	
Q motion monitor	Q motion monitor	607KB	0	0	0	
Servo amplifier monitor	Servo amplifier monitor	524KB	0	0	0	
CNC monitor*1	CNC monitor	588KB	0	0	0	
	GOT Platform Library	100KB	Not required			
SFC monitor*3*7	SFC monitor	1373KB	×	0	0	
	GOT Function Expansion Library	4729KB	×	0	0	
Gateway	Gateway (Server, Client)	100KB	0	0	0	
	Gateway (Mail)	100KB	0	0	0	
	Gateway (FTP)	64KB	0	0	0	
MES interface	MES Interface	3196KB	×	×	O ^{*5}	

 $^{^{\}star}1$ Applicable to the GT1595-X, GT1585V-S, GT1585-S, GT1575V-S, and GT1575-S only.

For how to use fonts and the setting method, refer to the following manual.

GT Designer2 Version ☐ Screen Design Manual (2.3 Specifications of Applicable Characters)

 $^{^{\}ast}2$ Applicable to the GT1585V-S and GT1575V-S only.

 $^{^{*}3}$ Inapplicable to the GT1555-Q and GT1550-Q.

^{*4} This function is dedicated to Japanese version.

^{*5} A capacity of 8218KB in the add-on memory (48MB) of the GT15-MESB48M is used for the MES interface function operation.

^{*6} For using fonts, install option fonts if necessary.

*7 For using the SFC monitor function, a capacity of 6201KB or more is required in the user area of the specified drive for installing the extended function OS and option OS. (For using the GOT with the built-in flash memory of 5MB, set the OS boot drive to [A: Standard CF Card].)

For operating GOT Function Expansion Library (option OS), a capacity of 8192KB is required in the user area of the GOT memory. (A total memory capacity of 14393KB is required for using the SFC monitor function.)

Therefore, the following settings are required depending on the GOT to be used.

GOT	Required setting
GT1575-VN, GT1572-VN, GT1562-VN	Setting the OS boot drive to [A: Standard CF Card] Memory expansion (Installing an option function board with add-on memory)
Other than the above	Memory expansion (Installing an option function board with add-on memory)

For setting the OS boot drive, refer to the following.

GT Designer2 Version Basic Operation/Data Transfer Manual (Chapter 8 TRANSFERRING DATA)

*8 For using the ladder editor function, a capacity of 9949KB or more is required in the user area of the specified drive for installing the extended function OS and option OS.

A total memory capacity of 21212KB is required for using the ladder editor function.

Therefore, to use the ladder editor function, set the OS boot drive to [A: Standard CF Card] and mount an option function board with 16MB or more memory on the GOT.

3 For GT11

For GOTs with built-in option function boards, refer to the following.

Section 1.1.2 Hardware and OS' required for each function

○: Required - : Unusable

	Extended function OS/	OS memory	Option function board
Function name	Option OS name	space (user area)	GT11-50FNB
Bar code	Bar code		Not required
RFID	RFID		Not required
System monitor	System monitor	21/5	Not required
Recipe	Recipe	0KB	0
A list editor*1	List editor for MELSEC-A		0
FX list editor*2	List editor for MELSEC-FX		0

^{*1} Inapplicable to the GT1155-QTBDQ, GT1155-QSBDQ, and GT1150-QLBDQ.

4 For GT10

Function name	Extended function OS/ Option OS name	OS memory capacity (user area)	Option function board
Bar code	Not required	-	Not required
Recipe	Not required	-	Not required
FX list editor *1	Not required	-	Not required


^{*1} Inapplicable to the GT1030 and GT1020.

^{*9} The GT1555-V does not support the function.

^{*2} Inapplicable to the GT1155-QTBDQ, GT1155-QTBDA, GT1155-QSBDQ, GT1155-QSBDA, GT1150-QLBDQ, and GT1150-QLBDA.

1.1.3 Outline of procedure to the operation of each function

Before operating each function, download the required Extended function OS or Option OS into the GOT according to the procedure shown below, and connect required hardware to the GOT.



Project data can be also downloaded/uploaded via Ethernet.

For download/upload of project data via Ethernet, BootOS and standard monitor OS should be installed in the GOT in advance so that the GOT and PC can communicate with each other via Ethernet by setting Communication Settings.

Refer to the following manual for details.

GT Designer2 Version Basic Operation/Data Transfer Manual (Chapter 8 TRANSFERRING DATA)

* 2 The B drive cannot be set as the OS boot drive.



Precautions for setting OS boot drive to [A: Standard CF Card]

(1) GOT startup time

When the OS boot drive is set to [A: Standard CF Card], the GOT startup time with the A drive takes longer than that with the C drive.

The GOT startup time with the A drive differs depending on the CF card type, the numbers of extended function OSs and option OSs, and project data size.

(2) Handling CF card during booting OS

Do not remove the CF card and do not turn off the CF card access switch during booting the OS.

Doing so causes the boot to fail. As a result, the GOT does not start correctly.

(3) Corrective actions when OS cannot be booted

The OS cannot be booted in the following conditions.

Take the following corrective actions, and then boot the OS again.

Condition	Corrective action
The type of the GOT to be used differs from the GOT type data set with GT Designer2 stored in the CF card.	Select the same GOT type as the GOT to be used in the Communicate with Memory Card screen. Select OSs and project data to be downloaded, and then download the selected data to the CF card.
The OS boot drive has insufficient free space.	Mount an option function board with add-on memory on the GOT or delete unnecessary data.
The CF card access switch is off.	Turn on the CF card access switch.

1.1.4 Displayable languages for each function

Languages available for each function are shown in the following table. For details of font data and displayable language, refer to the following.

GT Designer2 Version ☐ Screen Design Manual (2.3.1 Fonts)

(O: Displayed, x: Not displayed, Eng.: Displayed in English)

		Function	Japanese	English	Chinese (Simplified)	Chinese (Traditional)	German	Korean
	U	tility function	0	0	0	0	0	0
	Sy	stem monitor	0	0	0	0	0	0
	Ва	ackup/restore	0	0	0	0	0	0
r	La	dder monitor						
	· File name	Ladder monitor for MELSEC-A	0	0	×	×	×	×
	· Comment	Ladder monitor for MELSEC-FX	0	0	×	×	×	×
	· Note · Statement	Ladder monitor for MELSEC-Q/QnA	0	0	×	×	×	O*1
		Ladder monitor for MELSEC-A ^{*3}	0	0	Eng.	Eng.	Eng.	Eng.
	Other than the above	Ladder monitor for MELSEC-FX	0	0	0	0	0	0
	above	Ladder monitor for MELSEC-Q/QnA	0	0	0	0	0	0
	Д	\ list editor*3	0	0	Eng.	Eng.	Eng.	Eng.
	F	X list editor	0	0	0	0	0	0
	Intelliger	nt module monitor*3	0	0	Eng.	Eng.	Eng.	Eng.
	Ne	twork monitor	0	0	0	0	0	0
	Q m	otion monitor ^{*3}	0	0	Eng.	Eng.	Eng.	Eng.
	Servo a	amplifier monitor ^{*3}	0	0	Eng.	Eng.	Eng.	Eng.
	C	CNC monitor						
		Monitor area	*2	*2	*2	*2	*2	*2
	Ot	her than the above	0	0	0	0	0	0
	С	NC data I/O	0	0	0	Eng.	Eng.	Eng.
	S	SFC monitor	0	0	0	0	0	0
	L	adder editor	0	0	0	0	0	0

^{*1} For further information, see the following:

Section 3.5.7 Language switching of the sequence program (MELSEC-Q/QnA ladder monitor)

- *2 The displayable language depends on the setting of the CNC side. (The language used on the monitor area is not linked to the language setting of [GOT setup].)

 For the CNC settings, refer to the manual of CNC (C70, C6/C64) to be connected.
- *3 For displaying the system screen for the function in English, install the OS for the function on the GOT with the English version of GT Designer2.

2. SYSTEM MONITOR











2.1 Features

The system monitor function is capable of monitoring and changing the devices within a target controller. It is intended to troubleshoot the controller system and to streamline maintenance operations. By installing the system monitor, an extended function OS, from GT Designer 2 into the GOT, you can monitor and test the devices of the controller and the buffer memory of the intelligent function module.

1 Any device on four dedicated screens can be monitored.

The system monitor function comprises four monitors - entry monitor, batch monitor, TC monitor, and BM monitor, and you can monitor any device according to the application.

Entry monitor

(On the GT15)

DEVICE MONITOR TEST MENU FORM SET

ChNo.[1]NetNo.[0]ST [FF]CPUNo.[0]

D 15 -2147483645 DW

Z 1 -32767

X 1 ●

M 25 O

W 200 100

R 50 68378428 DW

D 0 3 DW

B 10 O

The entry monitor function monitors up to 8 controller devices entered by the user in a single window.

(Section 2.5 Entry Monitor)

TC monitor

(On the GT15)

TC MONITOR TEST MENU FORM SET

ChNo.[1]NetNo.[0]ST [FF]CPUNo.[0]

FILE NAME[MAIN .QPG]

T 0 PV 0 SV 25 ++ O

[Operation start]

T 1 PV 30 SV 30 +- O

[Products Line A]

T 2 PV 0 SV ++ O

[Products Line B]

T 3 PV 0 SV ++ O

[Products Line B]

The TC monitor function monitors the present value, set value, contact point, and coil of up to 8 controller timers (T)/ counters (C) from the device number specified by the user in a single window.

(Section 2.7 TC Monitor (Monitoring Timers and Counters))

Batch monitor (On the GT15)


BATCH MONITOR TEST MENU FORM SET ChNo.[1] NetNo.[0] ST [FF] CPUNo.[0]

D 10 32767 D 18 -500
D 11 0 D 19 3234
D 12 0 D 20 0
D 13 -1 D 21 0
D 14 0 D 22 0
D 15 3 D 23 -32768
D 16 3256 D 24 0
D 17 0 D 25 0

The batch monitor function monitors up to 16 controller devices from the device number specified by the user in a single window.

(Section 2.6 Batch Monitor)

BM monitor (monitoring Buffer memory)
(On the GT15)



The BM monitor function monitors up to 16 devices from the initial device number in the buffer memory of the intelligent function module specified by the user in a single window.

(Section 2.8 BM Monitor (Monitoring Buffer Memory))




(1) Displaying the system monitor screen of the GT16 or GT15 Display methods differ depending on the GOT.

For the GOT with VGA or higher resolution, the monitor screen is divided into four windows. The GOT can simultaneously display four different kinds of monitor screens.

For the GT1555-VTBD, the monitor screen can be switched between the full and quad modes with the button for switching the number of monitor screens.

For the GOT with QVGA resolution, the GOT can display one of the four monitor screens as a full screen.





(GOT with VGA or higher resolution)

(GOT with QVGA resolution)

For GT1555-VTBD

(a) Full mode

When starting the system monitor, the GOT displays the monitor screen in the full mode.


The GOT displays one of the four monitor screens.

The screen display size differs depending on the monitor screen to be displayed.*1

(b) Quad mode

With the button for switching the number of monitor screens, the monitor screen is divided into four windows. The GOT can simultaneously display the four kinds of monitor screens.





(Full mode)

(Quad mode)

The monitor screen in the full mode is four times bigger than each monitor screen in the quad


For displaying screens commonly used in the system, including the key window, the monitor screen size in the full mode is the same as each monitor screen size in the guad mode.

For details of switching the number of the monitor screens, refer to the following.

Section 2.3.1 Outline until starting the system monitor

(2) Displaying the system monitor screen of the GT11

The GOT can display one of the four monitor screens as a full screen.





2 Data can be changed by test operation.

For further information, see the following:

Section 2.9 Test Operation

(Test example)






- Testing a bit device
 A device specified by the user is turned on and off.
- (2) Testing a word device
 A specified value is written to a device specified by the user.
- (3) Testing a timer/counter Specified values are written as the present and set values of a device specified by the user.
- (4) Testing buffer memory
 A specified value is written to buffer memory specified by the user.
- The display format and device comment/no-comment display can be switched. For further information, see the following:

Section 2.4.4 Switching the display format (DEC/HEX) and comment/no-comment display

(Test example)

When the entry monitor is displayed (comment display)



When the entry monitor is displayed (hexadecimal display)

DEVICE MONITOR TEST MENU FORM SET ChNo.[1]NetNo.[0]ST [FF]CPUNo.[0]

D 15 H 0CB80003 DW
Z 1 H 8001
X 1 •
M 25 ○
W 200 H 0064
R 50 H 04135F3C DW
D 0 H 00000003 DW
B 10 ○

- (1) Switching the display format
 - Word device values are displayed in decimal or hexadecimal numbers on the entry, batch, TC, and BM monitors.
- (2) Device comment display

 Comments written in the controller are displayed when a controller device is monitored.

4 Other stations can be monitored.

You can monitor other stations in the data link system containing the GOT (or GOT-connected station), network system or CC-Link system.

For further information about the connection forms that can be monitored, see the following:

Section 2.2.1 System configuration

2.2 Specifications

2.2.1 System configuration

This subsection describes the controller names and the connection forms between the GOT and the controller that can be covered by the system monitor function.

For further information about communication units and cables for each connection form, see the following:

GOT1000 Series Connection Manual

1 Target controller

Controller
QCPU (Q mode), Q series motion controller CPU
QSCPU*1
QnACPU
ACPU/QCPU (A mode), A series motion controller CPU
FXCPU
Remote I.O station (MELSECNET/H system)
MELDAS C6/C64

^{*1} The GOT cannot write data to devices in the QSCPU. (The test operation is not available.)

2 Connection type

(1) When the GOT is connected to a QCPU (Q mode), Q series motion controller CPU, or QSCPU

 $(\bigcirc : \mathsf{Available}, \ \triangle : \mathsf{Partly} \ \mathsf{restricted}, \ \times : \mathsf{Unavailable})$

F	unction						С	onnect	ion type	e betwe	en GO	T and	controll	er						
Name	Description		us ection 9	conne	t CPU ection 9	lir conn	puter nk ection 9	conne	ernet ection	MEL NE conne MEL NET	T/H ection, SEC T/10	CC-Lin	nk IE* ⁵		6*9		*7*9	mult conn	OT idrop ection	Reference section
		GT16 GT15	GT11	GT16 GT15	1(2111	GT16 GT15	GT11	GT16 GT15		GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	1(2111	GT16 GT15		
Entry	Monitoring present values by entering devices to be monitored in advance	0	0	0	0	0	0			Δ*2		0				0	0			2.5
Batch monitor	Monitoring the present value of n devices from a specified device																			2.6
TC monitor	Monitoring the present value, set value, contact point, and coil of m devices from a specified device																			2.7
BM monitor	Monitoring the present value of x devices in specified buffer memory of a specified intelligent function module	Δ*1	Δ*1	Δ*1	Δ*1	Δ*1	Δ*1	△*4	×	∆*1 *2	×	Δ*1	×	△*4	×	Δ*1	Δ*1	×	×	2.8
Data change by test	Setting/ Resetting bit devices					0	0													
operation	Changing the present value of word devices and buffer memory					Δ*3	Δ*3													
	Changing the present value of TC (possible during TC monitoring) Changing the set value of TC (possible during TC monitoring)*	Δ*4	Δ*4	Δ*4	Δ*4	△*4	△*4			△*²² *4		Δ*4				△*4	Δ*4			2.9
Quick test	Changing device values by performing a quick test																			2.4.5

Fu	inction						C	onnect	ion type	e betwe	en GO	T and	controll	er						
										MEL				CC	Link c	onnect	ion			
Name	Description	Bu conne	ection	Direct		Com lir conne	nk ection		ernet ection	conne MEL NET	ection, SEC 7/10	CC-Lir	nk IE ^{*5}	ID [*]	6*9	G4 ³	*7*9	G(multi conne	drop	Reference section
		GT16 GT15	I (i I 11	GT16 GT15	[(4]11	GT16 GT15	[(4] 11	GT16 GT15	I (÷ I 11	GT16 GT15	(3111	GT16 GT15	[(4]11	GT16 GT15	I (i I 11	GT16 GT15	I (i I 11	GT16 GT15	I (i I 11	
Display switching	Displaying device comments Displaying word device and buffer memory values in decimal or hexadecimal	△*4	Δ*4	△*4	△*4	△*4	△*4	△*4	×	∆*² *4	×	△*4	×	△*4	×	△*4	△*4	×	×	2.4.4

- These items cannot be monitored when a motion controller (Q series) is monitored.
- *2 When the GOT is connected to the MELSECNET/10, use a QCPU and a network module (QJ71LP21, QJ71LP21-25, QJ71LP21S-25, QJ71LP21G, QJ71BR11) of function version B or a later version.
- *3 The present value of Z cannot be changed. None of the connection types supports V.
- *4 When a motion controller (Q series) is connected, device comments cannot be displayed.
- *5 Indicates the CC-Link IE controller network connection.
- *6 Indicates CC-Link connection (Intelligent device station).
- *7 Indicates CC-Link connection (via G4).
- *8 When a QCPU redundant system is used, data of the set value cannot be changed.
- *9 The QSCPU does not support the connection type.

(2) When the GOT is connected to a QnACPU

(⊜: Available, △: Partly restricted, x: Unavailable)

F	unction					(Connec	tion forr	n betwe	en GO	T and c	controlle	er					
Name	Description		us ection		t CPU ection	lir	puter nk ection		ernet ection	NE	SEC F/10 ection		C-Link o	connect G	ion 4* ⁵	mult	OT idrop ection	Reference section
		GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	1 (3111	GT16 GT15	GT11	
Entry monitor	Monitoring present values by entering devices to be monitored in advance									Δ*2								2.5
Batch monitor	Monitoring the present value of n devices from a specified device																	2.6
TC monitor	Monitoring the present value, set value, contact point, and coil of m devices from a specified device					0	0											2.7
BM monitor	Monitoring the present value of x devices in specified buffer memory of a specified intelligent function module	∆* ³	Δ* ³	∆* ³	∆* ³			△ *3	×	∆ ∗ 1 ∗2	×	Δ* ³	×	∆* ³	×	×	×	2.8
Data change by	Setting/Resetting bit devices																	
test operation	Changing the present value of word devices and buffer memory					Δ*2	Δ*2											
	Changing the present value of TC (possible during TC monitoring)									∆ ∗ 2 ∗3								2.9
	Changing the set value of TC (possible during TC monitoring)					Δ*3	△*3											
Quick test	Changing device values by performing a quick test																	2.4.5

F	unction					(Connec	tion forr	n betwe	en GO	T and c	ontrolle	r					
Name	Description	Conne	us ection		t CPU ection	lir	puter nk ection		ernet ection	NE	SEC Г/10 ection	CC	C-Link o	onnecti G4		G(multi conne		Reference section
		GT16 GT15	I GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	I GT 11	GT16 GT15	GT11	
Display switching	Displaying device comments																	
	Displaying word device and buffer memory values in decimal or hexadecimal	Δ*3	Δ*3	Δ*3	Δ*3	Δ*3	Δ*3	Δ*3	×	∆ ∗ 2 ∗3	×	Δ*3	×	Δ*3	×	×	×	2.4.4

- *1 When the GOT is connected to the MELSECNET/10, use a QCPU and a network module (QJ71LP21, QJ71LP21-25, QJ71LP21S-25, QJ71LP21G, QJ71BR11) of function version B or a later version.
- *2 The present value of Z cannot be changed. None of the connection forms supports V.
- *3 When the GOT is connected to a QnACPU whose date shown on the rating plate is earlier than 9707B, device comments cannot be displayed.
- *4 Indicates CC-Link connection (Intelligent device station).
- *5 Indicates CC-Link connection (via G4).

(3) When the GOT is connected to a ACPU/QCPU (A mode) or A series motion controller CPU

 $(\bigcirc : \mathsf{Available}, \ \triangle : \mathsf{Partly} \ \mathsf{restricted}, \ \times : \mathsf{Unavailable})$

	unction					(Connec	tion forr	n betwe	en GO	T and c	ontrolle	r					
Name	Description	Conne	us ection	Direct		lir	puter nk ection		ernet ection	NE	SEC T/10 ection	CC	C-Link o		ion 4* ⁴	mult	OT idrop ection	Reference section
		GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	
Entry monitor	Monitoring present values by entering devices to be monitored in advance	0	0	0	0	Δ* ²	Δ* ²			0				0				2.5
Batch monitor	Monitoring the present value of n devices from a specified device																	2.6
TC monitor	Monitoring the present value, set value, contact point, and coil of m devices from a specified device																	2.7
BM monitor	Monitoring the present value of x devices in specified buffer memory of a specified intelligent function module	Δ*1	Δ*1	△*1	△*1	Δ*1	Δ*1			Δ*1				Δ*1				2.8
Data change by	Setting/Resetting bit devices					0	0		×		×	0	×		×	×	×	
test operation	Changing the present value of word devices and buffer memory					Δ*2	Δ*2	0	^				^			^	^	
	Changing the present value of TC (possible during TC monitoring)					0	0											2.9
	Changing the set value of TC (possible during TC monitoring)	0	0	0	0					0				0				
Quick test	Changing device values by performing a quick test					Δ*2	Δ*2											2.4.5
Display switching	Displaying device comments																	
	Displaying word device and buffer memory values in decimal or hexadecimal					0	0											2.4.4

^{*1} These items cannot be monitored when an A motion controller CPU is monitored.

^{*2} V, Z, and A cannot be monitored, or their present values cannot be changed.

^{*3} Indicates CC-Link connection (Intelligent device station).

^{*4} Indicates CC-Link connection (via G4).

(4) When the GOT is connected to an FXCPU

 $(\bigcirc : \mathsf{Available}, \ \underline{\wedge} : \mathsf{Partly} \ \mathsf{restricted}, \ \mathbf{\times} : \mathsf{Unavailable})$

	Function	Connecti	on form betwe	en GOT and	controller	
Name	Description	Direct CPU	connection		ultidrop	Reference section
Name	Description	GT16 GT15	GT11	GT16 GT15	GT11	
Entry monitor	Monitoring present values by entering devices to be monitored in advance	Δ* ²	∆* ²	×	×	2.5
Batch monitor	Monitoring the present value of n devices from a specified device					2.6
TC monitor	Monitoring the present value, set value, contact point, and coil of m devices from a specified device	Δ*1*2	Δ*1*2	×	×	2.7
BM monitor	Monitoring the present value of x devices in specified buffer memory of a specified special function unit/block	×	×	×	×	2.8
	Setting/Resetting bit devices	△*2	△ *2			
	Changing the present value of word devices and buffer memory					
Data change by test operation	Changing the present value of TC (possible during TC monitoring)	Δ *2	Δ*2	×	×	2.9
	Changing the set value of TC (possible during TC monitoring)	×	×			
Quick test	Changing device values by performing a quick test	Δ*2	Δ*2	×	×	2.4.5
	Displaying device comments	×	×			
Display switching	Displaying word device and buffer memory values in decimal or hexadecimal	△*2	Δ*2	×	×	2.4.4

^{*1} The set value and coil of T/C cannot be monitored.

^{*2} V, Z, and A cannot be monitored, or their present values cannot be changed.

(5) When the GOT is connected to a remote I/O station of MELSECNET/H system

(\bigcirc : Available, \triangle : Partly restricted, \times : Unavailable)

	Function					(Connec	tion forn	n betwe	een GO	T and c	ontroller					
Name Description		Bus connection		Direct CPU connection		Computer link connection		Ethernet connection		MELSEC NET/H connection, MELSEC NET/10 connection		CC-Link o	G4*3		GOT multidrop connection		Reference section
		GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15		GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT16 GT15	GT11	GT16 GT15	GT11	
Entry monitor	Monitoring present values by entering devices to be monitored in advance																2.5
Batch monitor	Monitoring the present value of n devices from a specified device																2.6
TC monitor	Monitoring the present value, set value, contact point, and coil of m devices from a specified device					0	0										2.7
BM monitor	Monitoring the present value of x devices in specified buffer memory of a specified intelligent function module	×	×	0	0						;	×			×	×	2.8
Data change	Setting/Resetting bit devices																,
by test operation	Changing the present value of word devices and buffer memory					Δ*1	Δ*1										
	Changing the present value of TC (possible during TC monitoring)																2.9
	Changing the set value of TC (possible during TC monitoring)*4					0	0										
Quick test	Changing device values by performing a quick test																2.4.5

	Function					(Connec	tion for	n betwe	en GO	T and c	ontrolle	r					
											MELSEC NET/H		CC-Link conr		on			
Name	Description	Bus connection		Direct CPU connection		Computer link connection		Ethernet connection		connection, MELSEC NET/10 connection		ID* ²		G4* ³		GOT multidrop connection		Reference section
		GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	I GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	I GT 11	GT16 GT15	I GT11	GT16 GT15	GT11	
Display switching	Displaying device comments																	
	Displaying word device and buffer memory values in decimal or hexadecimal	×	×	0	0	0	0				;	<				×	×	2.4.4

- *1 The present value of V and Z cannot be changed.
- *2 Indicates CC-Link connection (Intelligent device station).
- *3 Indicates CC-Link connection (via G4).
- *4 When a QCPU redundant system is used, data of the set value cannot be changed.

(6) When the GOT is connected to a MELDAS C6/C64

(○: Available, △: Partly restricted, x: Unavailable)

F	unction						Connec	tion forr	n betwe	een GO	T and c	ontrolle	r						
Name	Description		us ection		t CPU ection	lii	puter nk ection		ernet ection	NE.	SEC T/10 ection	CC		connecti G4	ion 1* ²	mult	OT idrop ection	Reference section	
	·	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11		
Entry monitor	Monitoring present values by entering devices to be monitored in advance			0		×	×	0		0		0			×			2.5	
Batch monitor	Monitoring the present value of n devices from a specified device							×								×	×	2.6	
TC monitor	Monitoring the present value, set value, contact point, and coil of m devices from a specified device			×						×		×						2.7	
BM monitor	Monitoring the present value of x devices in specified buffer memory of a specified intelligent function module	×	×		×				×		×		×	×				2.8	
Data change by test operation	Setting/Resetting bit devices Changing the present value of word devices and buffer memory			0					0		0		0						
	Changing the present value of TC (possible during TC monitoring)																		
	Changing the set value of TC (possible during TC monitoring)			×				×		×		×							
Quick test	Changing device values by performing a quick test			0						0		0		0					

F	unction		Connection form between GOT and controller															
Name	Description	Bus connection		Direct CPU connection		Computer link connection		Ethernet connection		MELSEC NET/10 connection		CC-Link o		G4* ²		GOT multidrop connection		Reference section
		GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	I GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	I GT11	GT16 GT15	GT11	
Display switching	Displaying device comments Displaying word device and buffer memory values in decimal or hexadecimal	×	×	0	×	×	×	0	×	0	×	0	×	×	×	×	×	2.4.4

^{*1} Indicates CC-Link connection (Intelligent device station).

^{*2} Indicates CC-Link connection (via G4).

3 Required Extended function OS

(1) The Extended function OS shown in the table below is required.

		OS memory sp	ace (user area)	Option function board						
Extended function OS	GT	16								
	Built-in flash User memory		GT15	GT11	GT16	GT15	GT11			
	memory (ROM)	(RAM)								
System monitor	450KB	692KB	746KB	0KB	Not required	Not required	Not required			

(2) Install the Extended function OS.

Install System monitor (Extended function OS) in the GOT.

For a detailed installation procedure, see the following:

Section 1.1.3 Outline of procedure to the operation of each function

Before transferring data from GT Designer 2 to the GOT (installing OS', downloading project data), it is necessary to confirm the free capacity of the user area in the specified drive and the size of the data to be transferred.

For further information, see the following:

GT Designer 2 Basic Operation/Data Transfer Manual Subsection 8.1.2 Drive capacity required for data transfer

2.2.2 Devices that can be monitored

For further information about the monitor device names that can be monitored and the scope, see the following:

GT Designer2 Version

Screen Design Manual

2.2.3 Access range

With Universal model QCPU, the GOT can monitor up to 64 stations.

When the GOT is connected to the remote I/O station in MELSECNET/H network system, only the master station can be monitored.

The access range other than above is the same as the access range when the GOT is connected to a controller.

Refer to the following manual for details of the access range.


GT Designer2 Version

Screen Design Manual (2.7 Controller that can be monitored and the Access Range)

2.2.4 Precautions


- (1) Monitoring and testing real number data
 - Real number data cannot be monitored and tested.
 - All word devices containing real number data are monitored in integer data (binary data).
- (2) Monitoring devices in 32-bit (two-word) module
 - When monitoring word devices (T, C, D, W, etc.) in 32-bit (two-word) module, those with 32 bits of data remaining are monitored.
 - Devices with 16 bits (one-word) of data remaining are not monitored.
 - If an odd number is specified for the first monitor device number, the last device number of the specified controller will not be displayed.

(Example) When the data entry of the A2NCPU is monitored in units of 32 bits from odd numbers (D1, D3 ...)



(3) Changing the T/C set values of large-size and small-size QnACPUs and displaying device comments

The T/C set values of QnACPUs whose date on the CPU rating plate is after [9707B] can be changed, and device comments can be displayed. <Information on the rating plate>



- (4) Programs capable of changing timer/counter set values
 - Only the main program can change the timer/counter set values of AnNCPUs, AnACPUs, and AnUCPUS.
 - When executing multiple programs with the QCPU (Q mode) and QnACPU, setting values of timer/counter can be changed only to the program (scan execution type program set at the lowest number among them in parameter settings of GX Developer) whose file name is displayed on the TC Monitor screen.

Note that a file to be displayed cannot be changed on the GOT.


- (5) Z0 of QCPUs and QnACPUs and Z0 and V0 of ACPUs
 - Z0 of QCPUs and QnACPUs and Z0 and V0 of ACPUs are displayed as Z and V respectively.

2.3 Display

This section describes the operation procedure from turning on the power to the GOT to system monitor display.

2.3.1 Outline until starting the system monitor

This subsection describes the flow until the system monitor function screen is displayed after System monitor (Extended function OS) is installed in the GOT.




From previous page

Changing monitor screen from full mode to quad mode (For GT1555-VTBD)




For the GT1555-VTBD, the monitor screen can be switched between the full and quad modes with the button for switching the number of monitor screens When the monitor screen is switched to the full mode, the GOT displays a monitor screen displayed on the upper left in the quad mode in the full mode.*1

screen in the full mode.



The button for switching the number of monitor screens

The monitor screen is switched between the full and quad modes with the button for switching the number of monitor screens.



*1 The monitor screen in the full mode is four times bigger than each monitor screen in the quad mode. For displaying screens commonly used in the system, including the key window, the monitor screen size in the full mode is the same as each monitor screen size in the quad mode.

Point P

(1) How to display the utility

For how to display the utility, refer to the following.

GT16 User's Manual (Basic Utility) (1.3 Utility Display)
GT15 User's Manual (9.3 Utility Display)
GT11 User's Manual (9.3 Utility Display)


- (2) Displaying the start screen on the GT16 and GT15 If you reactivate the system monitor function without turning off the power to the GOT, the last displayed screen appears.
- (3) Displaying communication setting window
 After turning on the GOT, the communication setting window is displayed at the first startup of the system monitor only.
 For displaying the communication setting window at the second or later startup, touch the ENTRY button on the system monitor screen.
- (4) If the project data has not been downloaded

 The system monitor can be started from the utility even if the project data has not been downloaded to the GOT.

2.4 Operation Procedure Common to the System Monitor Screens

2.4.1 Functional change menu screen

This subsection describes the configuration of the functional change menu screen and the functions of the keys displayed on it.



The table below describes the functions of the keys displayed on the functional change menu screen.


Key	Function									
DEV/MON	Performs entry monitoring in the Entry Monitor window.									
DEV MON	Section 2.5 Entry Monitor									
DATMON	Performs batch monitoring in the Batch Monitor window.									
BAT MON	Section 2.6 Batch Monitor									
TO MON	Performs TC monitoring in the TC Monitor window.									
TC MON	Section 2.7 TC Monitor (Monitoring Timers and Counters)									
DMMON	Performs buffer memory monitoring in the BM Monitor window.									
BM MON	Section 2.8 BM Monitor (Monitoring Buffer Memory)									
	The system monitor function is deactivated, and the screen returns to Main Menu									
END	of the utility.									
-	If the system is activated from the User screen, the screen returns to it.									

2.4.2 Entering monitor devices (specifying monitor stations and devices)


This subsection describes how to specify network numbers, monitor stations, and monitor devices by taking the Entry Monitor window as an example.

The procedure for specifying network numbers, monitor stations, and monitor devices is the same even if other items than the "entry monitor."

(Example) Entering a monitor device when the entry monitor is used



(From previous page)



Set 1) to 9) as shown in the table below, and then touch the Enter key. For the operation of key windows, see the following:

Section 2.4.3 Key window setting columns and operation procedure

				De	scription of setting									
No.	Item	Bus	Direct CPU	Computer link	Ethernet	MELSECNET/H connection, MELSECNET/10		-Link ection						
		connection	Connection	connection	connection	connection	ID* ²	G4* ³						
1)* ¹	Channel No.	Sets the chann	nel number of th	ne controller tarç	geted to the system monitor.									
2)	Network No.		0		1 to 239	0: Host loop 1 to 255: Specified loop		0						
3)* ⁴	Station No.		FF		1 to 64	FF: When the host station is selected 0: When the control station is selected 1 to 64: When a normal station is selected	is se 0: When mas stati sele 1 to 64: loca	t station elected the ster ion is ected						
4)	CPU No.			only when the sy		to multiple QCPUs. It i	s not nece	essary						
5)	Data range				wo-word) module. one-word) module.									
6)* ¹	Device name	Cat the marrie	and number of	the device to be	manitara d									
7)*1	Device number	Set the name a	and number of	the device to be	monitored.									
8)*1	I/O number	When the initia	When the initial I/O signal of module is displayed with three digits, specify the first two digits.											
9)*1	Initial device number	Set the initial of	levice number	of the buffer mer	mory in decimal.									

For devices that can be set, see the following:

GT Designer 2 Version ☐ Screen Design Manual (Section 2.9 Devices that can be set)

- Indicates CC-Link connection (Intelligent device station).
- *2 *3 Indicates CC-Link connection (via G4).
- When the station No. is set to the host station (FF), set the network No. to 0.




Displaying the data range

The Entry Monitor, Batch Monitor, TC Monitor, and BM Monitor screens display the data range as shown below.

: 32-bit (two-word) module Nothing displayed: 16-bit (one-word) module



(Continued to next page)





(1) Retaining entered information


If the system monitor function is reactivated without turning off the power to the GOT, the last displayed information will be retained.

If the power to the GOT is turned on again and the system monitor function is reactivated, the last displayed information will be deleted.

(2) Entry unit of monitor devices Each monitor device is entered in a combination of a network number and a CPU station number. If the CPU station number is changed, the entered monitor device will become invalid.

2.4.3 Key window setting columns and operation procedure

- 1 Operating the key window
- Using the and keys, move the cursor to the item you want to set.
 The displayed keyboard depends on the position of the cursor as shown below.



- 2 If necessary, enter numbers or characters from the keyboard.
 - Del key: Used to delete a character of the entered information.
 - AC key: Used to delete all characters under the cursor.
 - The ▲/▼ keys without a description do not function.
- 3 Entry is completed by touching the Enter key.
- 4 The keyboard closes by touching the $\overline{\times}$ key.

2.4.4 Switching the display format (DEC/HEX) and comment/no-comment display


This subsection describes how to switch the display format and comment/no-comment display.

The Entry Monitor window is taken here as an example to describe the specification of a monitor station and a monitor device when the system monitor function is executed.

The procedure for switching the display format (DEC/HEX) and comment display when another item is selected. (Example of switching when the entry monitor is selected)

Switching the display format from DEC to HEX

Switching no-comment display to comment display





(1) Changing the comment or comment capacity of the controller
If you change a comment or comment capacity of the controller after the system

monitor function is activated, the comment may not be properly displayed on each monitor screen.

After a comment or comment capacity is changed, turn off the GOT and turn it on again.

(2) Switching the display format (DEC/HEX)

The present value of word devices and the present value and set value of timers/counters will be displayed in decimal or hexadecimal numbers.

(3) Switching comment/no-comment display

The comments written to the target controller will be displayed or not be displayed. (Priority of comment display: Extension comment > Comment)

- (4) Comment/No-comment display
 - (a) The BM monitor does not display comments.
 - (b) Comments will not be displayed when any of the CPUs listed below is monitored.
 - FXCPU
 - QnACPU or Q series motion controller CPU whose date on the rating plate is earlier than 9707B
 - (c) Comments will not be displayed when any of the devices listed below is monitored.
 - Internal device of the GOT (GB, GD, GS)
 - Host device (B, W, SB, SW) when the MELSECNET/H or MELSECNET/10 is connected
 - Host device (X,Y, WW, WR) when a CC-Link is connected
 - (d) Displaying the comments of QCPUs (Q02CPU, Q02HCPU, Q06HCPU, Q12HCPU, Q25HCPU, Q12PHCPU, Q25PHCPU, Q12PRHCPU, Q05PRHCPU, Q02UCPU, Q03UDCPU, Q04UDHCPU, Q06UDHCPU)

Comments will not be displayed when the following PLC parameters (PLC file settings) are set:

- When the comment file is set to "Not used"
- When the comment file is set to "Use the same file name as the program"
- When a password is set to the comment file
- When a comment file is stored in program memory
- (e) Displaying the comments of QCPUs (Q00JCPU, Q00CPU, Q01CPU)

Comments will not be displayed when the following PLC parameter (PLC file setting) is set:

- When the comment file "MAIN" does not exist in the program memory
- (f) Displaying the comments of QnACPUs

With a QnACPU whose date on the rating plate is earlier than 9707B, comments cannot be displayed.

Use a QnACPU whose date on the rating plate is 9707B or later.

Also, comments will not be displayed when the following settings are made to the PLC parameter (PLC file setting) is set.

- When the comment file is not set "Not used"
- When the comment file is set to "Use the same file name as the program"
- When a keyword is entered for each memory

WARNING

 Before performing the quick test operations of the system monitor function (such as turning ON or OFF bit device, changing the word device current value, changing the settings or current values of the timer or counter, and changing the buffer memory current value), read through the manual carefully and make yourself familiar with the operation method.


During quick test operation, never change the data of the devices which are used to perform significant operation for the system.


False output or malfunction can cause an accident.

The quick test operation procedure for monitor devices is described below.


The Entry Monitor screen is taken as an example to describe quick test operation when the system monitor function is executed.

The operation procedure is the same even if the batch monitor, TC monitor or BM monitor is selected. (Example of quick test operation when the entry monitor is selected)






Change the status of bit device X001 from off (\bigcirc) to on (\bullet) .




(2) Quick test of word devices (Operation example)

Change the device value of word device W200 from 43 to 100. Conditions: Data range: 16 bits, device value display format: decimal number



(Continued to next page)





Effective number of digits of device values that can be changed


If an entered value exceeds the corresponding number of digits specified below, the device value cannot be changed.


[Decimal number]

16-bit (one-word) module : Six digits (including a digit for a sign) 32-bit (two-word) module : Ten digits (including a digit for a sign)

[Hexadecimal number]

16-bit (one-word) module : Four digits 32-bit (two-word) module : Eight digits






2.5 Entry Monitor

The device monitor is a function to enter devices to be monitored in advance and monitor only entered devices.

This section describes how to activate the entry monitor when the system monitor function is executed.

2.5.1 Information displayed on the Entry Monitor screen and key functions

(1) The information displayed on the Entry Monitor screen is described below. For the key functions, see the page that follows.



For further information about items 1) to 11) shown above, see the page that follows.

(2) The following table describes the key functions displayed on the Entry Monitor screen.


Key switch	Function
TECT	Activates the Quick test operation.
TEST	Section 2.4.5 Quick test operation of monitor devices
	Switches the screen to the functional change menu screen to activate another monitor function or terminate the
MENU	system monitor function.
	Section 2.4.6 Changing screens
	Switches the screen to the display format switching screen to change the value display format (DEC/HEX) on the
FORM	Entry Monitor screen or comment/no-comment display.
	Section 2.4.4 Switching the display format (DEC/HEX) and comment/no-comment display
	Switches the screen to the Device entry screen to enter monitor devices or delete or test entry devices.
	- Entering monitor devices: Section 2.4.2 Entering monitor devices (specifying monitor stations and
SET	devices)
	- Deleting entry devices: Section 2.5.3 Deleting entry devices
	· Test operation: Section 2.9 Test Operation
	Scroll displayed information upward or downward by a line to display the preceding or next monitor device that is
	not currently displayed. When five or more monitor devices are entered, these switches are available when their
	comments are displayed.
	: Scrolls information upward by a line.
	: Scrolls information downward by a line.

(3) The following table below describes the range of display of items 1) to 11) displayed

		Description of setting						
No.	Item	Bus connection	Direct CPU connection	Computer link connection	Ethernet connection	MELSECNET/H connection, MELSECNET/10 connection		Link ection G4 * ²
1)	Channel No.	Sets the cha	ets the channel number of the controller targeted to the entry monitor.					
2)	Network No.	0			1 to 239	0: Host loop 1 to 255: Specified loop	0	
3)	Station No.	FF			1 to 64	FF: When the host station is selected 0: When the control station is selected 1 to 64: When a normal station is selected	selec 0: When maste is selection	station is ted the er station ected When a station is
4)	CPU No.	0 to 4: This item must be set only when the system is connected to multiple QCPUs. It is not necessary when the system is connected to another CPU.						
5)	Comment	Displays a comment (maximum number of characters: 16 one-byte characters) A comment is displayed when "DISPLAY" is selected for comment display on the display format switching screen.				nat		
6)	Data range		DW: Indicates that the device value is a 32-bit (two-word) module. Nothing displayed: Indicates that the device value is a 16-bit (one-word) module.					
7)	Word device value	[Decimal number] 16-bit (one-word) module: Six digits (including a digit for a sign) are displayed. (Display example: - 12345) 32-bit (two-word) module: Ten digits (including a digit for a sign) are displayed. (Display example: - 123456789) [Hexadecimal number] 16-bit (one-word) module: Four digits are displayed. (Display example: H AB12) 32-bit (two-word) module: Eight digits are displayed. (Display example: H ABCDE123)						
8)	Bit device ON/OFF	○: ON ●: OFF						
9)	Device No.	Up to eight o	levices can be	e monitored w	th regard to each C	PU station number.		
10)	Device name		For further information about device numbers and names that can be entered: GT Designer 2 Version Screen Design Manual					
11)	Monitor display area		mments are d ents are displ	. , .	o eight devices can o four devices can			

^{*1:} Indicates CC-Link connection (Intelligent device station).

^{*2:} Indicates CC-Link connection (via G4).





If more than eight devices are registered

You can register up to eight entry devices.


If more than eight devices are registered, the oldest ones will be deleted one by one, and the eight latest entry devices will be monitored.

If necessary, delete unnecessary entry devices and re-enter ones you want to monitor.

2.5.3 Deleting entry devices

This subsection describes how to delete entry devices.

Deleting entry devices with the system monitor function executed is described below.





2.6 Batch Monitor

The batch monitor is a function to specify the head device of any device range to perform monitoring. This section describes how to operate the batch monitor when the system monitor function is executed.

2.6.1 Information displayed on the Batch Monitor screen and key functions

(1) The information displayed on the Batch Monitor screen is described below.





For further information about items 1) to 11) shown above, see the page that follows.



Number of devices displayed on a single screen

The number of devices displayed on a single screen depends on the setting of the data range, as shown below.

Word devices (16-bit): 16 devices (no comments displayed), eight devices

(comments displayed)

Word devices (32-bit): Eight devices (no comments displayed), four devices

(comments displayed)

Bit devices : 16 devices (no comments displayed), eight devices

(comments displayed)

For further information about the setting of the data range, see the following:

Section 2.4.2 Entering monitor devices (specifying monitor stations and devices)

(2) The following table describes the key functions displayed on the Batch Monitor screen.


Key switch	Function
TEOT	Activates the Quick test operation.
TEST	Section 2.4.5 Quick test operation of monitor devices
	Switches the screen to the functional change menu screen to activate another monitor function or terminate the
MENU	system monitor function.
	Section 2.4.6 Changing screens
	Switches the screen to the display format switching screen to change the value display format (DEC/HEX) on the
FORM	Batch Monitor screen or comment/no-comment display.
	Section 2.4.4 Switching the display format (DEC/HEX) and comment/no-comment display
	Switches the screen to the Device entry screen to enter or test monitor devices.
OFT	· Entering monitor devices : Section 2.4.2 Entering monitor devices (specifying monitor stations and
SET	devices)
	· Test operation : Section 2.9 Test Operation
	Scroll displayed information upward or downward by a line to display the preceding or next monitor device that is
	not currently displayed. When five or more monitor devices are entered, these switches are available when their
	comments are displayed.
	: Scrolls information upward by a line.
	: Scrolls information downward by a line.

(3) The following table below describes the range of display of items 1) to 11) displayed.

					Description of set	ting		
No.	Item	Dus		Computer	Ethernet	MELSECNET/H connection,	CC-Link connection	
		connection	connection	connection	connection	MELSECNET/10 connection	ID* ¹	G4* ²
1)	Channel No.	Sets the channel	Sets the channel number of the controller targeted to the batch monitor.					
2)	Net No.	0			1 to 239	0: Host loop 1 to 255: Specified loop	0	
3)	Station No.	FF			1 to 64	FF: When the host station is selected 0: When the control station is selected 1 to 64: When a normal station is selected	FF: When station select 0: When the station select 1 to 64: When the select 1 select select select	n is ed ne master n is ed hen a station is
4)	CPU No.	0 to 4: This item must be set only when the system is connected to multiple QCPUs. It is not necessary when the system is connected to another CPU.					en the	
5)	Bit device ON/OFF	○: ON •: OFF						
6)	Comment	Displays a comment (maximum number of characters: 16 one-byte characters). A comment is displayed when "DISPLAY" is selected for comment display on the display format switching screen.				screen.		
7)	Word device value	[Decimal number] 16-bit (one-word) module: Six digits (including a digit for a sign) are displayed. (Display example: -12345) 32-bit (two-word) module: Ten digits (including a digit for a sign) are displayed. (Display example: -123456789) [Hexadecimal number] 16-bit (one-word) module: Four digits are displayed. (Display example: H AB12) 32-bit (two-word) module: Eight digits are displayed. (Display example: H ABCDE123)					789)	
8)	Device No.	· ·			ta range is word (16	,		
9)	Device name		nation about de		data range is two-wo	ord (32 bits). be entered:	ner 2 Versi	on 🗆
10)	Data range	DW: Indicates that the device value is a 32-bit (two-word) module. Nothing displayed: Indicates that the device value is a 16-bit (one-word) module.						
11)	Monitor display area	When no comments are displayed : Up to 16 devices can be displayed at a time (monitor module: one-word). Up to eight devices can be displayed at a time (monitor module: two-word). : Up to eight devices can be displayed at a time (monitor module: one-word). Up to four devices can be displayed at a time (monitor module: two-word).						

^{1:} Indicates CC-Link connection (Intelligent device station).

^{*2:} Indicates CC-Link connection (via G4).




2.7 TC Monitor (Monitoring Timers and Counters)

The TC monitor is a function to monitor only timers (T) and counters (C). This section describes how to operate the TC monitor when the system monitor function is executed.

2.7.1 Information displayed on the TC Monitor screen and key functions

(1) The information displayed on the TC Monitor screen is described below.



For further information about items 1) to 12) shown above, see the page that follows.

(2) The following table describes the key functions displayed on the TC Monitor screen.


Key switch	Function
TEST	Activates the Quick test operation. Section 2.4.5 Quick test operation of monitor devices
MENU	Switches the screen to the functional change menu screen to activate another monitor function or terminate the system monitor function. Section 2.4.6 Changing screens
FORM	Switches the screen to the display format switching screen to change the value display format (DEC/HEX) on the TC Monitor screen or comment/no-comment display. Section 2.4.4 Switching the display format (DEC/HEX) and comment/no-comment display
SET	Switches the screen to the Device entry screen to enter or test monitor devices. • Entering monitor devices: Section 2.4.2 Entering monitor devices (specifying monitor stations and devices) • Test operation: Section 2.9 Test Operation • Canceling keywords: Section 2.7.3 Procedure for canceling TC monitor keywords
A V	Scroll displayed information upward or downward by a line to display the preceding or next monitor device that is not currently displayed. When five or more monitor devices are entered, these switches are available when their comments are displayed. Scrolls information upward by a line. Scrolls information downward by a line.

(3) The following table below describes the range of display of items 1) to 12) displayed.

		Description of setting						
No.	Item	Bus	Direct CPU	Computer	Ethernet	connection, con		Link ection
		connection	connection connection	connection	MELSECNET/10 connection	ID* ¹	G4* ²	
1)	Channel No.	Sets the channel number of the controller targeted to the TC monitor.						
2)	Network No.	0			1 to 239	0: Host loop 1 to 255: Specified loop	0	_
3)	Station No.	FF			1 to 64	FF: When the host station is selected 0: When the control station is selected 1 to 64: When a normal station is selected	FF: When station selecte 0: When the station selecte 1 to 64: When the selecte station selecte selecte selecte selecte selecte selecte station selecte	is ed ne master is ed hen a tation is
4)	CPU No.	0 to 4: This item must be set only when the system is connected to multiple QCPUs. It is not necessary when system is connected to another CPU.				when the		
5)	Comment		•			e-byte characters). ment display on the display f	ormat switc	hing
6)	Set value	[Decimal number Four digits are continued in	lisplayed. (Dis umber]		•			
7)	Present value	[Decimal number] Four digits are displayed. (Display example: 1234) [Hexadecimal number] Four digits are displayed. (Display example: H AB12) (Present values cannot be monitored when the CPU is an FXCPU.)						
8)	Device No.	Up to eight devi	ces can be en	tered.				
9)	Device name	For further infor Screen Design		evice number	s and names that	can be entered: GT [Designer 2 \	/ersion □
10)	File name	When the CPU When the CPU		n	ames, the initial fil	ill be displayed. When there le name to be executed will b " will always be displayed.		•
11)	Contact point and coil on/off		is an FXCPU,	contact point	s and coils canno	t be monitored.)		
12)	Monitor display area	When no comm When comment	•		•	be displayed at a time. be displayed at a time.		

Indicates CC-Link connection (Intelligent device station).


Indicates CC-Link connection (via G4).





2.7.3 Procedure for canceling TC monitor keywords

When the target controller is a QCPU and a password is entered in the sequence program, the keyword must be canceled to display the set values of timers and counters.

The procedure for canceling keywords is described below.







- Enter the password entered in the sequence program at 1).
 - A-Z key: Touch this key to enter alphabetic characters A to Z (uppercase).
 - a-z key: Touch this key to enter alphabetic characters a to z (lowercase).
 - 0-9 key : Touch this key to enter numbers 1 to 9.
 - Del key: Use this key to delete an entered character.
 - AC key: Use this key to delete all characters under the cursor.
- 2 Entry is completed by touching the Enter key, and the keyboard closes.


2.8 BM Monitor (Monitoring Buffer Memory)

The BM monitor (buffer memory monitor) is a function to monitor the buffer memory of special function modules.

This section describes how to operate the BM monitor when the system monitor function is executed.

2.8.1 Information displayed on the BM Monitor screen and key functions

(1) The information displayed on the BM Monitor screen is described below.



For further information about items 1) to 8) shown above, see the page that follows.

(2) The following table describes the key functions displayed on the BM Monitor screen.


Key switch	Function					
TEST	Activates the Quick test operation.					
IEST	Section 2.4.5 Quick test operation of monitor devices					
	Switches the screen to the functional change menu screen to activate another monitor function or terminate the					
MENU	system monitor function.					
	Section 2.4.6 Changing screens					
	Switches the screen to the display format switching screen to change the value display format (DEC/HEX) on the					
FORM	BM Monitor screen or comment/no-comment display.					
	Section 2.4.4 Switching the display format (DEC/HEX) and comment/no-comment display					
	Switches the screen to the Device entry screen to enter or test monitor devices.					
SET	· Entering monitor devices: Section 2.4.2 Entering monitor devices (specifying monitor stations and					
SET	devices)					
	· Test operation: Section 2.9 Test Operation					
	Scroll displayed information upward or downward by a line to display the preceding or next monitor device that is					
	not currently displayed. When five or more monitor devices are entered, these switches are available when their					
	comments are displayed.					
	: Scrolls information upward by a line.					
	: Scrolls information downward by a line.					

(3) The following table below describes the range of display of items 1) to 8) displayed.

				[Description of se	tting		
No.	Item	Bus	Direct CPU	Computer link	Ethernet	MELSECNET/H connection, MELSECNET/10	CC-Link connection	
		connection	connection	connection	connection	connection	ID* ¹	G4 * ²
1)	Channel No.	Sets the channe	el number of th	e controller targ	eted to the BM mo	onitor.		
2)	Network No.	0			1 to 239	0: Host loop 1 to 255: Specified loop	0	
3)	Station No.	FF		1 to 64	FF: When the host station is selected 0: When the control station is selected 1 to 64: When a normal station is selected	FF: When the host station is selected 0: When the master station is selected 1 to 64: When a local station is selected		
4)	CPU No.	0 to 4: This item must be set only when the system is connected to multiple QCPUs. It is not necessary when the system is connected to another CPU.				when the		
5)	Word device value	[Decimal number four digits (incluing Hexadecimal number four digits are discounted to the control of the contr	uding a digit for umber]		olayed. (Display ex	xample: 1234)		
6)	Device No.	Up to 16 device	s can be enter	ed. (When the C	CPU is an FXCPU	, devices cannot be entered	.)	
7)	Device name	For further information about device numbers and names that can be entered: GT Designer 2 Version Screen Design Manual					'ersion □	
8)	Monitor display area	Up to 16 device	s can be displa	ayed at a time.				

Indicates CC-Link connection (Intelligent device station).

Indicates CC-Link connection (via G4).



2.9 Test Operation

WARNING

 Before performing the quick test operations of the system monitor functin (such as turning ON or OFF bit device, changing the word device current value, changing the settings or current values of the timer or counter, and changing the buffer memory current value), read through the manual carefully and make yourself familiar with the operation method.


During test operation, never change the data of the devices which are used to perform significant operation for the system.

False output or malfunction can cause an accident.

You can specify and test any station and device that can be monitored during monitoring by the system monitor function. This section describes how to test the bit or word devices of the controller or the buffer memory of the intelligent function unit.


2.9.1 Procedure for displaying the test menu screen and the setting key window screen

This subsection describes how to display the test menu screen and the setting key window screen.




1 Touch SET .

(When performing test operation from the Entry Monitor screen)



2 Touch TEST .



Enter

The test menu screen appears.

Touch SET/RST, SET VAL, VALUE 16, VALUE 32, BM VAL 16 or BM VAL 32.

Operation example: touch SET VAL .

For a detailed description of each key function, see the following:

Section 2.9.2 Information displayed on the test menu screen and key functions

4 The setting key window screen appears.

Display example: set value operation screen of T (timer) and C (counter)

For further infomation about each setting key window, see the following:

Section 2.9.2 Information displayed on the test menu screen and key functions

For further information about the test operation procedure, see the following:

Section 2.9.4 Test operation procedure

2.9.2 Information displayed on the test menu screen and key functions

(1) Test menu screen



The table shown below describes the key functions.

Key	Function
MENU	Switches the screen to the functional change menu screen to activate another monitor function or terminate the system monitor function. Section 2.4.6 Changing screens
FORM	Switches the screen to the display format switching screen to change the value display format (DEC/HEX) or comment/no-comment display. Section 2.4.4 Switching the display format (DEC/HEX) and comment/no-comment display
SET	Switches the screen to the Device entry screen.
SET/RST	Displays the screen for bit device on/off operation.
SET VAL	Displays the Set value operation screen for T (timers) and C (counters).
VALUE 16	Displays the Present value operation screen for word devices. Data range: 16-bit (one-word) module
VALUE 32	Displays the Present value operation screen for word devices. Data range: 32-bit (two-word) module
BM VAL 16	Displays the Present value operation screen for buffer memory. Data range: 16-bit (one-word) module
BM VAL 32	Displays the Present value operation screen for buffer memory. Data range: 32-bit (two-word) module
CANCEL	Terminates the test menu screen and displays each monitor screen.

8) Sets a T/C set value.

2.9.3 Information and set items displayed on each setting key window screen


The information and set items on the setting key window screen to be used for each test are described below.

ChNo.[1]NetNo. DEVICE[**1**][

(1) Information displayed on each setting key window screen



Screen for bit device on/off operation



Displays whether decimal or hexadecimal is selected.


D: Decimal H: Hexadecimal

SET VAL

Set value operation screen for timers and counters




Present value operation screen for word devices (16-bit (one-word) module/32-bit (two-word) module)



Enter

BM VAL 16 BM VAL 32

Present value operation screen for buffer memory (16-bit (one-word) module/32-bit (two-word) module)





(2) Set items on the setting key window screen The table shown below describes details of the set items mentioned on the preceding page.

		Description of setting						
No.	Item	Bus	Direct CPU	Computer	Ethernet	MELSECNET/H connection, MELSECNET/10		Link ection
		connection	connection	connection	connection	MELSECNET/10 connection	ID *1	G4 * ²
1)	Channel No.	Sets the chann	el number of	the controller	targeted to the test of	pperation.		
2)	Net No.	0	1 to 239 0: Host loop 1 to 255: Specified loc				0	
3)	Station number	FF			1 to 64	FF: When the host station is selected 0: When the control station is selected 1 to 64: When a normal station is selected	FF: When the hos station is selected 0: When the master station is selected 1 to 64: When a local station is selected	
4)	CPU No.	0 to 4: This item must be set only when the system is connected to multiple QCPUs. It is not need the system is connected to another CPU.				not necess	ary when	
5)	On/Off setting	Set "1": On, Set "0": Off						
6)	Device No.	For further info	For further information about device numbers and names that can be entered:					
7)	Device name	GT De	signer 2 Versi	ion Screen	n Design Manual			
8)	T/C set value	[Decimal number] 16-bit (one-word) module: Six digits (including a digit for a sign) are set. (Entry example: -12345) 32-bit (two-word) module: Ten digits (including a digit for a sign) are set. (Entry example: -123456789) [D] displayed in the number entry box indicates that the entry is decimal. [Hexadecimal number] 16-bit (one-word) module: Four digits are set. (Entry example: H AB12) 32-bit (two-word) module: Eight digits are set. (Entry example: H ABCDE123) [H] displayed in the number entry box indicates that the entry is hexadecimal.						
9)	Word device present value	[Decimal number] 16-bit (one-word) module: Six digits (including a digit for a sign) are set. (Entry example: -12345) 32-bit (two-word) module: Ten digits (including a digit for a sign) are set. (Entry example: -123456789) [D] displayed in the number entry box indicates that the entry is decimal. [Hexadecimal number] 16-bit (one-word) module: Four digits are set. (Entry example: H AB12) 32-bit (two-word) module: Eight digits are set. (Entry example: H ABCDE123) [H] displayed in the number entry box indicates that the entry is hexadecimal.				789)		
10)	Initial I/O signal of module	Set the first two digits of the three-digit initial I/O signal of the module.						
11)	Initial device number of buffer memory	Set the numbe	Set the number in a decimal number.					

^{*1:} Indicates CC-Link connection (Intelligent device station).


^{*2:} Indicates CC-Link connection (via G4).

2.9.4 Test operation procedure

Test operation takes place by setting on the setting key window screen the name and number of a device, initial device number of the buffer memory, and the initial I/O of the module or entering change values. This subsection takes a change of set values as an example to describe the test operation procedure.

- Touch the SET VAL key on the test menu screen. The setting key window screen appears.
- ② Using the ◀ and ▶ keys, move the cursor to the item you want to set.

The keyboard displayed depends on the position of the cursor, as shown below.




- If necessary, enter numbers or characters on the keyboard.
 - Del key: Use the Del key to delete an entered character.
 - AC key: Use the AC key to delete all characters under the cursor.
 - The ▲/▼ and the keys on which nothing is displayed are not available.
 - For further information about the setting ranges, see the following:
 - Section 2.9.3 Information and set items displayed on each setting key window screen
- 4 Entry is completed by touching the Enter key.
- ullet The keyboard closes by touching the oxdot key.


Point P

Operating the set values of timers and counters

- (1) Time-up/Count-up status Even if a set value or present value is changed after a timer or counter is up, the time-up or count-up status does not change. The present status is retained.
- (2) Changing an index qualifierOnly the constant part of a T/C set value with a qualifier can be changed. The index qualifier cannot be changed.(Example) Change the set value of T5 from 300 to 200.




(3) Operation when a password is entered for the controller When the target controller is a QCPU, the Keyword Release screen appears. Enter the password.



- Enter the password entered in the sequence program at 1).
 - A-Z key: Touch this key to enter alphabetic characters A to Z (uppercase).
 - a-z key: Touch this key to enter alphabetic characters a to z (lowercase).
 - 0-9 key: Touch this key to enter numbers 1 to 9.
 - Del key : Use this key to delete an entered character.
 - AC key : Use this key to delete all characters under the cursor.
- 2 Entry is completed by touching the Enter key, and the keyboard closes.

2.9.5 Test operation basic procedure



2.10 Error Messages and Corrective Action

This section describes the error messages displayed when the system monitor function is executed, and corrective action.

Error message	Description	Corrective action
PLC communications error	Communication could not be established with the PLC CPU.	 (1) Connections between the PLC CPU and the GOT (disconnected or cut cables). (2) Has an error occurred in the PLC CPU? (3) Refer to the following manual for confirming whether the error has occurred in network. GT16 User's Manual (Hardware) GT15 User's Manual GT11 User's Manual

3. LADDER MONITOR FUNCTION



3.1 Features

The ladder monitor enables you to monitor the sequence program within the target controller and change device values.


It is intended to troubleshoot and maintain the PLC system efficiently.

The features of the ladder monitor are shown below.

1 The program with ladder symbols can be monitored

You can monitor PLC CPU programs in ladder diagram format and save displayed screens in BMP or JPEG format. ([Section 3.4 Operation Procedure Common)


(Display example)




2 The display format, device comment display and language can be switched

The following can be switched. (Section 3.5 Switching the Display Format)

- Display format of device values, timer and counter values
- · Comment display/non-display of the target device
- · Language used for items of the sequence program such as file name and comments





(1) Switching the display format

The present value of a word device is displayed in a decimal of hexadecimal number in the lower area of the screen.

(Subsection 3.5.2 Display switching of decimal numbers/hexadecimal numbers)

(2) Device comment display

Comments of the devices used in the sequence program (comments written in the controller) are displayed.

(Subsection 3.5.3 Switching comment/no-comment display)

Comment file data stored in a CF card can also be displayed when the MELSEC-Q/QnA ladder monitor is used.(Subsection 3.3.5 Reading comment files from CF cards)

(3) Language switching (for MELSEC-Q/QnA ladder monitor only)

In the MELSEC-Q/QnA ladder monitor, language switching (Japanese/Korean) is available for displaying the following items of a sequence program.

(To switch the language, register the following items with the language (Japanese/Korean) used for the PLC READING DATA DISPLAY. To display Korean, for example, register the following items with Korean on GX Developer.)

- File name
- Title
- Comment
- Note
- Statement

Items other than the above (such as menu) are displayed with the language set on [GOT setup].

(Section 3.5.7 Language switching of the sequence program (MELSEC-Q/QnA ladder monitor))

3 Other stations can be monitored

You can use the ladder monitor on other station in the data link system containing the GOT (or GOT-connected station), network system or CC-Link system.

For further information about the connection forms available for the ladder monitor, see the following:

Subsection 3.2.1 System configuration

4 Enhanced interaction with objects

(1) One-touch ladder jump function


Only by touching an object on a user-created screen, a target device can be searched and displayed.

In addition, in the case of the Q/QnA ladder monitor, searching is performed only when the monitor target of the sequence program that has been read and the monitor target that is set on the object match, enabling more accurate search.

Even a person who is not the operator familiar with the equipment inside can trace the source of the equipment error without fail by simple operations, reducing time to stop the error.

Example) Coil searching by touching a touch switch

(User-created screen)



(2) Real-time program searching from advanced alarm display, touch switch (for the Q/QnA ladder monitor only)

PLC data can be read automatically and programs to be read can be specified.

When a Japanese or English file name is specified, the corresponding program can be read. Accordingly, the specified program can be read to be searched and the search result is displayed on the monitor screen by a simple operation as selecting a displayed alarm and then touch the key code switch.

5 Multiple files can be read

By reading multiple PLC CPU files in advance, reading of another program from the PLC CPU is not needed every time the program display is switched, and comment display can be switched automatically.

This enables more efficient ladder monitoring, reducing the operation time.

3.2 Specifications

3.2.1 System configuration

This section describes the system configuration of the ladder monitor.

For connection type settings and precautions regarding the communication unit/cable and connection type, see the following manual.

GOT1000 Series Connection Manual

1 Target controller

Controller
QCPU (Q mode)*1, motion controller (Q series)*2
QSCPU*3
QnACPU
ACPU/QCPU (A mode), motion controller (A series)
FXCPU*4
CNC (C70, C6/C64)*5

- *1 When the GOT is connected to a QCPU set on a redundant type extension base unit, the ladder monitor function cannot be used.
- *2 For the motion controller CPU (Q series), only the PLC CPU area (CPU No.1) in the Q170MCPU can be monitored.
- *3 The GOT cannot write data to devices in the QSCPU.
- *4 The FX3G does not support the ladder monitor function.
- *5 Use the function version A2 or later.

2 Connection type

(1) When the GOT is connected to a QCPU (Q mode), a motion controller (Q series)^{*1}, or a QSCPU (○: Available, △: Partly restricted, **x**: Unavailable)

F	unction	Connection type between GOT and controller									
	Description	Bus connection *7	Direct CPU connection *7	Computer link connection *7	Ethernet	MELSEC NET/H connection ,MELSEC NET/10 connection	CC-Link IE*4	CC-Link connection		GOT	Reference section
Name					connection			ID*5*7	G4 ^{*6*7}	multidrop connection	COUCH
Search operation	Device search, defect search, etc.	0			0	Δ*2	0	0	0	×	3.6
Display switching	Displaying word devices in DEC or HEX		0		0	Δ*2	0	0	0	×	3.5
Switching	Displaying device comments, etc.		0		0	Δ*2	0	0	0	×	
Test operation	Changing device values, etc.	△*3			0	△*2*3	0	Δ*3	0	×	3.7
Local device monitor	Monitoring local devices	0			0	Δ*2	0	0	0	×	3.8
Hard copy	Storing ladder monitor screen in BMP/JPEG format or printing it with a printer	0			0	Δ*2	0	0	0	×	3.4.2

- *1 For the motion controller CPU (Q series), only the PLC CPU area (CPU No.1) in the Q170MCPU can be monitored.
- *2 For the MELSECNET/10 connection, use a QCPU and network module (QJ71LP21, QJ71LP21-25, QJ71LP21S-25, and QJ71BR11) with the function version B or later.
- *3 The present value of Z cannot be changed. V cannot be turned ON or OFF.
- *4 Indicates the CC-Link IE controller network connection.
- *5 Indicates CC-Link connection (Intelligent device station).
- *6 Indicates CC-Link connection (via G4).
- *7 The QSCPU does not support the connection type.

(2) When the GOT is connected to a QnACPU

(○: Available, △: Partly restricted, ×: Unavailable)

	Function	Connection form between GOT and controller								
	Description	Bus connection	Direct CPU connection	Computer link connection	Ethernet	MELSEC NET/10 connection	CC-Link c	onnection	GOT multidrop connection	Reference section
Name					connection		ID*2	G4 ^{*3}		Section
Search operation	Device search, defect search, etc.		0		0	0	0	×	×	3.6
Display switching	Displaying word devices in DEC or HEX		0		0	0	0	×	×	3.5
switching	Displaying device comments, etc.		0		0	0	0	×	×	
Test operation	Changing device values, etc.	△*1			0	Δ*1	Δ*1	×	×	3.7
Local device monitor	Monitoring local devices	×			×	×	×	×	×	-
Hard copy	Storing ladder monitor screen in BMP/JPEG format or printing it with a printer	0			0	0	0	×	×	3.4.2

- *1 The present value of Z cannot be changed. V cannot be turned on or off.
- *2 Indicates CC-Link connection (Intelligent device station).
- *3 Indicates CC-Link connection (via G4).

(3) When the GOT is connected to an ACPU/QCPU (A mode) and an A series motion controller CPU (○: Available, △: Partly restricted, χ: Unavailable)

	Function	Connection form between GOT and controller								
	Description	Bus	Direct CPU connection	Computer link connection	Ethernet connection	MELSEC NET/10 connection	CC-Link o	connection	GOT multidrop connection	Reference section
Name		connection					ID ^{*4}	G4 ^{*5}		Codion
Search operation	Device search, defect search, etc.				0	0	0	×	×	3.6
Display	Displaying word devices in DEC or HEX	0		Δ*3	0	0	0	×	×	3.5
switching*1	Displaying device comments, etc.				0	0	0	×	×	
Test operation	Changing device values, etc.		△*2		0	Δ*2	△*2	×	×	3.7
Hard copy	Storing ladder monitor screen in BMP/JPEG format or printing it with a printer	0			0	0	0	×	×	3.4.2

^{*1} If the total capacity of parameters, sequence programs, T/C set values, comments, and extension comments is 144 Kbytes or over, comments cannot be correctly displayed.

^{*2} The present value of V and Z cannot be changed.

^{*3} Subprograms 2 and 3 of the A4UCPU (in computer link connection) cannot be ladder-monitored.

^{*4} Indicates CC-Link connection (Intelligent device station).

^{*5} Indicates CC-Link connection (via G4).

(4) When the GOT is connected to an FXCPU

(○: Available, △: Partly restricted, ★: Unavailable)

	Function	Connection form between GOT and co	Reference	
Name	Description	Direct CPU connection	GOT multidrop connection	section
Search operation	Device search, defect search, etc.		×	3.6
Display	Displaying word devices in DEC or HEX	0	×	3.5
switching	Displaying device comments, etc.	0	×	3.3
Test operation	Changing device values, etc.	∆*¹*²	×	3.7
Hard copy	Storing ladder monitor screen in BMP/JPEG format or printing it with a printer	0	×	3.4.2

^{*1} The present value of V and Z cannot be changed.

(5) When the GOT is connected to a CNC

(a) When the GOT is connected to a CNC C70

(○: Available, △: Partly restricted, ★: Unavailable)

ı	unction			Connecti	on form betwee	n GOT and co	ntroller				
Name	Description	Bus connection	Direct CPU	Computer link	Ethernet connection*4	MELSEC NET/10	CC-Link IE*5	CC-Link connection		GOT multidrop	Reference section
		connection	connection	connection	connection	connection		ID*6	G4 ^{*7}	connection	
Search operation	Device search, defect search, etc.	0			0	Δ*2	0	0	0	×	3.6
Display	Displaying word devices in DEC or HEX		0		0	△*2	0	0	0	×	3.5
switching	Displaying device comments, etc.		0		×	△*2	0	0	0		
Test operation	Changing device values, etc.	△*3			0	△*2*3	0	Δ*3	0	×	3.7
Hard copy	Storing ladder monitor screen in BMP/JPEG format or printing it with a printer	0			0	△*2	0	0	0	×	3.4.2

^{*1} Available with the multiple CPU system including a QCPU (Q mode).

^{*2} The set values of T and C cannot be changed.

^{*2} For the MELSECNET/10 connection, use a QCPU and network module (QJ71LP21, QJ71LP21-25, QJ71LP21S-25, and QJ71BR11) with the function version B or later.

^{*3} The present value of Z cannot be changed. V cannot be turned ON or OFF.

^{*4} Available with the Display I/F connection only.

^{*5} Indicates the CC-Link IE controller network connection.

^{*6} Indicates CC-Link connection (Intelligent device station).

⁷ Indicates CC-Link connection (via G4).

(b) When the GOT is connected to a MELDAS C6/C64

(○: Available, △: Partly restricted, ★: Unavailable)

	Function	Connection form between GOT and controller								
None	D tutto .	Bus	Direct CPU connection	Computer link connection	Ethernet connection	MELSEC NET/10 connection	CC-Link connection		GOT	Reference section
Name	Description	connection					ID ^{*4}	G4 ^{*5}	multidrop connection	
Search operation	Device search, defect search, etc.	×	0	×	0	O*1	0	×	×	3.6
Display	Displaying word devices in DEC or HEX	×	0	×	0	O*1	0	×	×	3.5
switching*1	Displaying device comments, etc.	×	0	×	0	0	0	×	×	
Test operation	Changing device values, etc.	×	△*2*3	×	△*2*3	Δ*1*2*3	Δ*2*3	×	×	3.7
Hard copy	Storing ladder monitor screen in BMP/JPEG format or printing it with a printer	×	0	×	0	O*1	0	×	×	3.4.2

^{*1} For the MELSECNET/10 connection, use a QCPU and network module (QJ71LP21, QJ71LP21-25, QJ71LP21S-25, and QJ71BR11) with the function version B or later.

^{*2} The present value of Z cannot be changed. V cannot be turned ON or OFF.

^{*3} The set values of T and C cannot be changed.

^{*4} Indicates CC-Link connection (Intelligent device station).

^{*5} Indicates CC-Link connection (via G4).

3 Required option OS' and option function boards

The option function OS' and option function boards shown in the table below are required.

	OS m	OS memory space (user area)		Option function board		
Option OS	GT	16				
Cpiloti GC	Built-in flash memory (ROM)	User memory (RAM)	GT15	GT16		GT15
Ladder monitor for MELSEC-A	342KB	674KB	523KB	Not required	GT15-FNB, GT15-QFNB16M.	GT15-QFNB, GT15-QFNB32M.
Ladder monitor for MELSEC-FX	342KB	674KB	592KB	Not required	GT15-QFNB48M,	GT15-MESB48M
Ladder monitor for MELSEC-Q/QnA	590KB	4170KB	1082KB	Not required	GT15-QFNB, GT15-QFNB32M, GT15-MESB48M	GT15-QFNB16M, GT15-QFNB48M,

(1) Option OS

Install the option OS in the above table to the GOT.

Refer to the following manual for the procedure for installing the option OS.

GT Designer2 Version ☐ Basic Operation/Data Transfer Manual (8. TRANSFERRING DATA)

(2) OS memory space

The available memory space shown in the table above is required in the user area to install the option OS to the GOT.

Refer to the following manual for the procedure for checking the available memory space of the user area and information about the data using other user areas.

☐ GT Designer2 Version ☐ Basic Operation/Data Transfer Manual (8. TRANSFERRING DATA)

(3) Option function board

(a) For GT16

No option function board is required.

(b) For GT15

Mount one of the option function boards in the above table on the GOT. For the GOTs with a built-in option function board, refer to the following.

1.1.2 Hardware and OS' required for each function

For how to mount an option function board on the GOT, refer to the following manual.

GT15 User's Manual (8.10 Option Function Board)

4 Display screen for the ladder monitor

A sequence program of up to 8 lines (one line: up to 11 contacts (12 or more contacts will be looped back)) is displayed on a single screen.

In addition, the current values of up to 8 word devices (9 or more devices are displayed by switching the display with the arrow key) etc. are displayed.

For the GT1695M-X, GT1685M-S, GT1595-X, GT1585V-S, GT1585-S, GT1575V-S, or GT1575-S, the MELSEC-Q/QnA ladder monitor displays a sequence program of up to 15 lines (one line: up to 11 contacts (12 or more contacts will be looped back)) on a single screen.

3.2.2 Devices and range that can be monitored

(1) MELSEC-A ladder monitor

 $(\bigcirc : \mathsf{Possible}, \, \bigstar : \mathsf{Impossible})$

Device	Device range	Ladder display	Device monitor display	Search operation
Input	X000 to XFFF (hexadecimal)	0	0	0
Output	Y000 to YFFF (hexadecimal)	0	0	0
Internal relay	M0 to M8191			
Latch relay	L0 to L8191	0	0	0
Step relay	S0 to S8191			
Special internet relay	M9000 to M9255	0	0	0
Link relay	B0000 to B1FFF (hexadecimal)	0	0	0
Timer	T0 to T2047	0	0	0
Counter	C0 to C1023	0	0	0
Data register	D0 to D8191	0	0	0
Special data register	D9000 to D9255	0	0	0
Link register	W0000 to W1FFF (hexadecimal)	0	0	0
Annunciator	F0 to F2047	0	0	0
File register	R0 to R8191	0	0	0
Accumulator	A0 to A1	0	0	0
Index register	V to V1 to V6	0	0	0
Index register	Z to Z1 to Z6	0	0	0
Nesting	N0 to N7	0	×	×
Pointer	P0 to P255	0	×	×
Interrupt pointer	I0 to I31	0	×	×

(2) MELSEC-FX ladder monitor

 $(\bigcirc$: Possible, \times : Impossible)

Device	Device range	Ladder display	Device monitor display	Search operation
Input	X000 to X337 (octadecimal)	0	0	0
Output	Y000 to Y337 (octadecimal)	0	0	0
Auxiliary relay	M0 to M8511	0	0	0
State	S0 to S4095	0	0	0
Timer contact	T0 to T511	0	0	0
Counter contact	C0 to C255	0	0	0
Data register	D0 to D8511	0	0	0
Index register	V0 to V7	0	0	0
Index register	Z0 to Z7	0	0	0
Nesting	N0 to N7	0	×	×
Pointer	P0 to P4095	0	×	×
Interrupt pointer	100* to 130* (four points) : Fx0 100* to 150* (six points) : Fx1, Fx2 16** to 18** (three points) : Fx1, Fx2 1010 to 1060 (six points) : Fx1, Fx2	0	×	×
Extension register	R0 to R32767	0	0	0

(3) MELSEC-Q/QnA ladder monitor

(○: Possible, **X**: Impossible)

Device	Device range	Ladder display	Device monitor display	Search operation
Input	X0 to 1FFF, DX0 to 1FFF	0	0	0
Output	Y0 to 1FFF, DY0 to 1FFF	0	0	0
Internal relay	M0 to 32767	0	0	0
Latch relay	L0 to 8191	0	0	0
Link relay	B0 to 7FFF	0	0	0
Timer	T0 to 2047	0	0	0
Retentive timer	ST0 to 2047	0	0	0
Counter	C0 to 1023	0	0	0
Data register	D0 to 12287	0	0	0
Link register	W0 to 1FFF	0	0	0
Annunciator	F0 to 2047	0	0	0
Edge relay	V0 to 2047	0	×	0
	R0 to 32767	0	0	0
File register	ZR0 to 32767	0	0	0
	ZR32768 to 4184063	0	0	×
Extended data register	D0 to 32767	0	0	O *1
Extended link register	W0 to 7FFF	0	0	O *1
Link special relay	SB0 to 7FF	0	0	0
Link special register	SW0 to 7FF	0	0	0
Step relay	S0 to 8191	0	0	0
	Z0 to 15	0	0	0
Index register	Z16 to 19	0	0	O *1
	ZZ0 to 18	0	×	O*2
Special relay	SM0 to 2047	0	0	0
Special data register	SD0 to 2047	0	0	0
Function input	FX0 to F	0	×	0
Function output	FY0 to F	0	×	0
Function register	FD0 to 4	0	×	0
Link direct device	J 🗆 🗆 ¥ 🗆 🗆	0	×	×
Intelligent function module	U 🗆 🗆 ¥ 🗆 🗆	0	.,	V
Intelligent function module	U3En 🗆 🗆 🗆	0	×	×
Nesting	N0 to 14	0	×	×
Pointer	P0 to 4095	0	×	×
Interrupt pointer	I0 to 255	0	×	×
SFC block device	BL0 to 319	0	×	0
SFC transition device	TR0 to 511	0	×	0
Network No. device	J0 to 255	0	×	×
	U0 to FF			
I/O No. device	3E0 to 3E3	0	×	×
Macro registration device	VD0 to	0	×	×

^{*1} For searching devices with the menu for the ladder monitor, the device number cannot be specified.

When a sequence program has Z and ZZ, specifying Z searches both Z and ZZ.

^{*2} Search ZZ by specifying Z. (For searching ZZ0, specify Z0. For searching ZZ1, specify Z1.) ZZ0 is not searched by specifying Z1.

3.2.3 Access range

With Universal model QCPU, the GOT can monitor up to 64 stations.

The access range other than the above is the same as the access range when the GOT is connected to a controller.

Refer to the following manual for details of the access range.

GT Designer2 Version ☐ Screen Design Manual (2.7 Controllers that can be monitored and the Access Range)

3.2.4 Precautions

(1) Inapplicable GOT

The ladder monitor cannot be used with the GT1555-Q and GT1550-Q.

(2) Precautions to be taken while the ladder monitor is activated

While the ladder monitor is activated, do not perform the following for the GOT.


Otherwise, the stored data may be deleted or the ladder monitor may not operate normally.

- Turning the CF card access switch (ON, OFF)
- · Installing/removing the CF card
- (3) Ladder display

Up to 24 lines can be displayed per ladder block.

If a sequence program is written in which 24 or more lines are used in a ladder block, the ladder cannot be correctly displayed. It is advisable to divide such programs.

- (4) When the system is connected to an FXCPU
 - (a) During PLC reading, only the host station is read.
 - (b) An STL (step ladder) command, a dedicated command for the FXCPU, is displayed as shown below.



(c) How an INV command is displayed

Ladder monitoring by GOT



- (d) When searching an STL command, use "S (state)" in a device search.
- (e) The 32-bit counters are displayed in 32-bit fixed display in the device monitor.
- (f) When using FX3U(C), if the memory capacity is set to 32,000 or higher with the GX Developer PLC parameters, sequence programs cannot be displayed.

When displaying a sequence program with the GOT, set the memory capacity to 16,000 or less.

(g) Changes to T/C set values are reflected on the ladder monitor display only when they are made with the system monitor or test function.

When a value is changed by numerical input or other object, the change is reflected on the display after the GOT is restarted.

(5) When reading multiple files

- (a) Continuous searching in multiple sequence programs is allowed only for device search, contact search, coil search, and touch search.
- (b) For searching in multiple sequence programs, the GOT can display search results of the

previously searched program by touching the Back key.

The GOT cannot display search results of multiple programs on one screen.

When programs are switched, the currently displayed search results of the program disappear from the screen.

- (c) For returning to the search results of the previously searched program by touching the Back key during searching in multiple sequence programs, the touch operation is canceled when the previously searched program is deleted.
- (d) For defect search, when multiple sequence programs have been read, searching is performed continuously in the program that is searched and displayed first.
 Continuous searching in multiple programs is not performed.
- (e) Automatical reading and seaching of a specified sequence program is allowed only for the special function switch and advanced alarm display.
- (f) If the monitor target is changed to another PLC, all the files that have been stored in the drive of the GOT are deleted when data are read from the PLC.
- (g) Without changing the monitor target PLC CPU, files stored in the drive of the GOT will not be deleted by changing the read target drive.

When all files are read from the monitor target PLC CPU with the automatic PLC read setting made, therefore, the programs to be searched and the monitor target programs may not match.

In such a case, delete unnecessary files on the file list window.

- (h) The ladder data storable capacity differs according to the ladder data storage destination.
 - Built-in flash memory (C drive) :Up to 4MB
 - Standard CF card (A drive/B drive) :Up to the CF card available space
- (i) Up to 512 files of ladder data including those displayed on the GOT (up to 3 files) can be stored in the storage destination drive.

When 511 files of ladder data are stored and another ladder data is displayed on the GOT, therefore, storing a new ladder data is not allowed.

(6) Reading comment files

- (a) Comment data can be read from a CF card only with the MELSEC-Q/QnA ladder monitor.
- (b) Only files with the file names (program names) with one-byte alphanumeric characters are applicable to the GOT.
 - When project data are created on GX Developer, use only one-byte alphanumeric characters for file names (program names).
- (c) When the data save location is set to [None], save only one comment file in a CF card. Multiple comment files cannot be read.

- (7) Monitoring local devices
 - (a) When a sequence program stored in a PLC CPU is changed, be sure to read the program with the GOT.
 - When the sequence program in the PLC CPU is changed after reading the sequence program with the GOT, the GOT may not correctly monitor local devices.
 - (b) For monitoring local devices, do not monitor the same local device in the same PLC CPU simultaneously with multiple GOTs and GX Developer.
 - (c) When the same local device in the same PLC CPU is simultaneously monitored with multiple GOTs and GX Developer, the GOT cannot correctly monitor the devices.
- (8) Changing set values of timer and counter when monitoring multiple programs For monitoring multiple programs, set values of all the target programs can be changed by switching displayed programs when the test menu screen is opened from the ladder monitor screen.




Reflecting value changes in display of ladder monitor screen

For opening the test menu screen from the system monitor screen or user-created screen, even if the set values of the timer and counter are changed, the changed values are not reflected in the display of the ladder monitor screen.

For reflecting the changed values in the display of the ladder monitor screen, read the program again.

- (9) Precautions for Universal model QCPU Even though Universal model QCPU processes 64-bit data, the GOT cannot monitor the 64-bit data.
- (10) Precautions for QSCPU
 - (a) The GOT cannot write data to the devices in the QSCPU.
 - (b) For a safety function block, only the FB definition name is displayed in the application instruction format.

The program in the safety function block is not displayed.



(c) The following shows the GOT operation when the program in a safety function block has the target of the search operation.

Search operation	GOT operation
Device search Contact point search Coil search	The GOT adds and displays the ladder block that shows the FB definition name in the application instruction format in the last row. For the continuous search, when the program in the safety function block has multiple target devices, the ladder block is added to the last row only one time.
Step search	The GOT displays the ladder block that shows the FB definition name in the application instruction format corresponding to the searched step.
Defect search	The GOT adds and displays the ladder block that shows the FB definition name in the application instruction format in the last row and ends the defect search. (The operaiton is the same as that when all the defective devices are searched.)

3.3 Display


This section describes the operation procedure from turning on the power to the GOT to ladder monitor function display.

3.3.1 Outline until the start

1 Operation for display

(1) Normal operation

This subsection describes the flow until the ladder monitor operation screen is displayed after a ladder monitor (Option OS) is installed in the GOT.





(1) How to display the utility

For how to display the utility, refer to the following.

GT16 User's Manual (Basic Utility) (1.3 Utility Display)
GT15 User's Manual (9.3 Utility Display)


- (2) How to make PLC reading unnecessary when turning the GOT power on again With the MELSEC-Q/QnA ladder monitor, you can save ladder monitor data to a memory card or internal flash memory.
 - If you save the data beforehand, it is not necessary to read the PLC when switching the GOT power on again.

(3.3.2 Setting and deleting media for saving ladder data)

(3) If the project data has not been downloaded The ladder monitor can be started from the utility even if the project data has not been downloaded to the GOT.

(2) Searching from the monitor screen

The following describes the operation procedures of ladder search using the advanced alarm display, alarm list display, alarm history display, and touch switch.



^{*}When the automatic PLC read setting is not made, ladder data must be read in advance.



(1) Before searching

When searching program files and displaying the result from the advanced alarm or touch switch with the Q/QnA ladder monitor, programs are read automatically and searched by using the automatic PLC read setting. Programs need not be read in advance.

(2) When powering on the GOT again

When searching program files with the A/FX ladder monitor or with the Q/QnA ladder monitor for which the automatic PLC read setting is made with [None] set as the data storage destination, PLC reading is required every time powering on the GOT.

For the Q/QnA ladder monitor, setting data storage destination eliminates the need of PLC reading when the GOT is powered on again.


For settings of automatic PLC read and data storage destination, refer to the following manual.

GT Designer2 Version2 Screen Design Manual

2 Changing screens

The following describes screen changes of (1) Normal operation using an example of the Q/QnA ladder monitor.

Screen changes of the A/FX ladder monitor is the same.



3.3.2 Setting and deleting media for saving ladder data

1 Setting the ladder data storage destination

(1) Setting for the Q/QnA ladder monitor

Up to 512 files of data used for the ladder monitor function (sequence programs, device comments) can be stored in a selected drive.

The ladder data storable capacity differs according to the ladder data storage destination.

- Built-in flash memory (C drive)
- :Up to 4MB
- Standard CF card (A drive/B drive) :Up to the CF card available space

Storing ladder data eliminates the need to read ladder data from the PLC CPU every time powering on the GOT, reducing the time before executing the ladder monitor.

For the ladder data storage destination setting, refer to the following manual.

When setting with the utility

GT16 User's Manual (Basic Utility) (Section 4.2.1 Q/L/QnA ladder monitor setting)
GT15 User's Manual (Section 11.7 Q/QnA Ladder Monitor)

When setting with GT Designer2

GT Designer2 Version ☐ Screen Design Manual (Section 3.8 Setting of GOT Display and Operations (GOT Setup))



Precautions when the ladder data storage destination is set to [None]

- Only one sequence file and comment file of ladder data can be read in the GOT.
- When searching program files using the one-touch ladder jump function, specify a file to be searched.
- (2) Setting for the A/FX ladder monitor

Ladder data cannot be stored.

For the A/FX ladder monitor, data for ladder monitoring are deleted every time the GOT is powered on again.

2 Deleting ladder data

Ladder data can be deleted with the ladder monitor screen or the utility. For deletion of ladder data, refer to the following.

When deleting with the ladder monitor screen

Section 3.3.3 Display

When deleting with the utility


GT16 User's Manual (Basic Utility) (Section 4.2.1 Q/L/QnA ladder monitor setting)
GT15 User's Manual (Section 11.7 Q/QnA Ladder Monitor)


3.3.3 Display

This subsection describes the procedure for reading the PLC to read the sequence program from the target controller when the ladder monitor is executed, and until the ladder monitor screen is displayed. The operation of reading the PLC depends on the controller type.


When the MELSEC-A/FX ladder monitor is executed

The MELSEC-A ladder monitor is taken as an example to describe the operation procedure.





- The communication setting window is displayed.
 - The name of the Communication driver installed in the GOT is displayed.
 - Touch "ChNo." on the communication setting window and set the channel number of the controller targeted to the ladder monitor.
- 2 Touch the ▶ key, and move the cursor to "NETWK No []."



3 Set the network number of the target controller and the CPU station number according to the table shown below.

	Connection form						
Setting	Bus connection	Direct CPU connection	Computer link connection	Ethernet connection	CC-Link (intelligent device station)	MELSEC NET/10 connection	
NETWK No	0			1 to 239	0	0: Host loop 1 to 255: Specified loop	
STATION*1	FF		1 to 64	0: When the master station is selected 1 to 64: When a local station is selected FF: When the host station is selected	0: When the control station is selected 1 to 64: When a normal station is selected		

^{*1} When the station No. is set to the host station (FF), set the network No. to 0. For the operation of the key window, see the following:

Subsection 2.4.3 Key window setting columns and operation procedure

Entry is completed by touching the Enter key, and the key window closes.

3

(From previous page)


PLC reading screen



- 5 Touch the →, ←, ↑, and ↓ keys to specify the following items listed under "READ SECTION."
 - Sequence program
 (In the case of the MELSEC-A ladder monitor)
 Main program
 Subprogram 1
 Subprogram 2 (A4U)
 Subprogram 3 (A4U)

(In the case of the MELSEC-FX ladder monitor) Main program (fixed)

 SETTING/NON SETTING for comment reading In the case of the FXCPU




6 After the items under "READ SECTION" are specified, touch the key.



Displaying the ladder monitor screen

The MELSEC-FX ladder monitor screen displays the sequence program that was executed when the PLC was read. If any of the set values of the sequence program is changed, re-read the PLC. Changes to set values are displayed on the screen when the MELSEC-A ladder monitor is executed.

It is not necessary to re-read the PLC.



Enter the keyword registered in the target controller.

(In the case of the MELSEC-A ladder monitor)

The data entered can be corrected with the following keys:

Del key: Used to delete a character of the entered information.

AC key: Used to delete all characters entered.

(In the case of the MELSEC-FX ladder monitor)


Touch the Keyword key to enter the keyword registered in the target PLC CPU.

Refer to the following manual for the FX CPU keywords.


J 1

GT16 User's Manual (Basic Utility) (3.2 Communication Detail Setting)

GT15 User's Manual (10.2.3 Display contents of communication detail settings)



3






Reading the PLC in the following operations

Once the PLC is read, you do not have to read it in the following operations. However, it must be re-read after you read it and then downloaded project data and when the power to the GOT is turned on again.

2 When the MELSEC-Q/QnA ladder monitor is executed


The MELSEC-Q ladder monitor is taken as an example to describe the operation procedure. With regard to the MELSEC-QnA ladder monitor, if any keyword is entered in the target controller, it must be entered after 6.




- 1) Select and touch \overline{YES} or \overline{NO} as described below.
 - To use stored ladder data, touch YES.
 - · To delete stored ladder data and read new ladder data, touch NO.

- 2 Select and touch YES or NO as described below.
 - To delete stored ladder data, touch YES .
 - To keep stored ladder data, touch NO.

3





(Continued to next page)

- The communication setting window is displayed.
 - The name of the Communication driver installed in the GOT is displayed.
 - · Set the channel number of the controller targeted to the ladder monitor.
- Touch the ▶ key, and move the cursor to "NETWK No []."
- 5 Set the network number of the target controller, the CPU station number, and the CPU number according to the table shown below.

	Setting range						
	Connection form						
Setting	Bus connection, Direct CPU connection, Computer link connection	Ethernet connection	MELSEC NET/H, MELSEC NET/10 connection	CC-Link IE controller network connection	CC-Link (intelligent device station)		
NETWK No	0	1 to 239	0: Host loop 1 to 255: Specified loop	1 to 239	0		
STATION*1	FF	1 to 64	0: When the control station is selected 1 to 64: When a normal station is selected	1 to 120	0: When the master station is selected 1 to 64: When a local station is selected		
CPU No	0 to 4 (Set this item only for the MELSEC-Q ladder monitor.)						

^{*1} When the station No. is set to the host station (FF), set the network No. to 0.

For the operation of the key window, see the following:

Subsection 2.4.3 Key window setting columns and operation procedure

6 Entry is completed by touching the Enter key, and the key window closes.




In the case of Ethernet connection

Set a monitor target using GT Designer2 in advance. For further information about the

setting of monitor target, see the following:

> GOT1000 Series **Connection Manual**



The PLC reading screen is displayed.

Touch the SetUp key. The setting window appears.



Displaying the ladder monitor screen

When the drive for storing ladder data is set to [C: Flash Memory], the ladder monitor screen displays the sequence program at the time of reading data from the PLC.

If any of the set values of the sequence program is changed, re-read the PLC.


When the drive for storing ladder data is set to [A: Built-in CF card] or [B:Memory card], changes of the set values are reflected in the screen display.

Rereading data from the PLC is not required.

8 The setting window appears. Make settings for the initial activation of the ladder monitor.*

The settings shown below switch each time you touch the






*This setting is invalid when the automatic PLC read setting is made or a searched file is specified, when performing coil search or defect search from the key code switch or the special function switch set for the advanced alarm display.

- 9 The After the setting is completed, touch the \boxtimes button to close the Setting window.
- Using the Drive key, select the target drive (applicable memory) in which the ladder data to be monitored is saved.

3



The drive selection window is displayed. Enter the target drive (applicable memory).

Drive number setting range: 0 to 4

Del key :Used to delete a character of the entered

information.

AC key :Used to delete all characters under the cursor.

Enter key :Registers the entered information.

When any keyword is set for the selected drive, enter the keyword.

If canceling the entry, reading of the drive is canceled.

12 A list of the files stored in the selected drive is displayed. Using the keys shown below, select the file data you want to read.

 ↑ key
 :Moves the cursor upward.

 ↓ key
 :Moves the cursor downward.

 Page↑ key
 :Displays the preceding page.

 Page↓ key
 :Displays the following page.

SEL. key :Select/Cancel is switched by moving the cursor and touching this key.

cursor and touching this key.

Select All key :Selects all the files in the drive.

Cancel All key :Cancels all the file selections.

READ key :Starts the reading of the file data selected.

CF Cmnt. Read key

:Starts reading a comment file from a CF card.

Caru.

Set the drive to be used for reading the comment file in [Q/QnA ladder monitor] of the utility or [GOT Setup] of GT Designer2.

GT16 User's Manual (Basic Utility) (4.2.1 Q/L/QnA Ladder Monitor setting)
GT15 User's Manual (11.7 Q/QnA Ladder Monitor)
GT Desinger2 Version ☐ Screen Design Manual (Setting of GOT Display and Operations (GOT Setup))

For reading comment files from CF cards, refer to the following.

Subsection 3.3.5 Reading comment files from CF cards




Multiple ladder data storable

Multiple sequence and comment programs can be read. For the PLC read setting, refer to the following manuals.

GT16 User's Manual (Basic Utility)
GT15 User's Manual

GT Designer2 Version ☐ Screen Design Manual



13 Enter the password entered in the target controller. In the case of the QCPU, a password is entered in the sequence and comment files.



When entering passwords for multiple files

When reading multiple files with passwords set, enter passwords for respective programs.
Canceling an entry cancels the reading of the file.

A-Z key :Uppercase alphabetic characters

a-z key :Lowercase alphabetic characters

The data entered can be corrected with the following keys:

:Used to delete a character of the entered information.

AC key :Used to delete all characters entered.

14 The sequence program is read.


Del key

- The message "READING PROGRAM" is displayed.
- The entire size of the program and the portion already read are displayed.

Portion already read/entire program size

- The reading of the PLC stops by touching the Break key.
- 15 After sequence programs are read, the message "OPERATION COMPLETE" is displayed.

3





Reading the PLC in the following operations

Once the PLC is read with the power to the GOT turned on, you do not have to read it in the following operations.

3.3.4 Searching from the monitor screen

When starting a ladder monitor with object, coil-search/defect search can be automatically performed to the read sequence program and the result can be displayed on the monitor.

1 Usable objects and functions list

The following table shows the types of objects can be searched from a monitor screen and functions usable in each object.

For object setting to display searching result on ladder monitor, refer to the following manual.

GT Designer2 Version ☐ Screen Design Manual

(1) MELSEC-Q/QnA ladder monitor

(O: Applicable x: Inapplicable)

Object	Function					
Object	Automatic PLC read	Specify Search File	Coil	Factor		
Special Function Switch	o ^{*1}	0	0	0		
Advanced Alarm Display	O ^{*1}	0	0	0		
Alarm List	×	×	0	×		
History	×	×	0	×		

^{*1} For reading comment files from CF cards, refer to the following.

Subsection 3.3.5 Reading comment files from CF cards

(2) MELSEC-A/FX ladder monitor

(O: Applicable x: Inapplicable)

Object	Function					
Object	Automatic PLC read	Specify Search File	Coil	Factor		
Special Function Switch	×	×	0	×		
Advanced Alarm Display	×	×	0	×		
Alarm List	×	×	0	×		
History	×	×	0	×		

2 Searching operation


(1) When displaying searching result with the Advanced Alarm Display or Special Function Switch The following explains the procedure from touching the Key Code Switch for advanced alarm display or Special Function Switch and performing coil-search or defect search to display of a ladder block.*

The following flowchart explains the operation when the destination to save the ladder block data is specified.

* When performing MELSEC-A/FX ladder monitor, the operation is the same when displaying the searching result with Alarm List or History explained (2) .

3

The following explains the operation taking MELSEC-Q ladder monitor as an example.



After coil-search, monitoring of the displayed ladder starts automatically. (During MELSEC-A/FX ladder monitor, touching the monitor key starts the same operation.)

- Touch a key in monitor screen.
 The operation differs depending on object setting.
 - (1) When the Automatic PLC read setting is made
 - (a) When [Specify Search File] is selected Reads the specified sequence program.
 - (b) When [Specify Search File] is not selected Reads all sequence programs in the program memory of the target controller. For setting method of Automatic PLC read, refer to the following manual.
 - GT Designer2 Version□ Screen Design Manual
 - (2) When the Automatic PLC read setting is not made

Searching starts only when the monitor target of the sequence program that has been read and the monitor target that is set for searching on the object match.

When they are mismatch, an error message appears.

Read again to match the monitor target for searching on the PLC reading screen.


- When a keyword is registered to the read target drive, enter the keyword.
 - To read a file to which a password is registered, enter the password.

If canceling the entry, reading of the drive or file is canceled.

- After the read program is searched, the result is displayed.
- 4 Touching the button searches consecutively.

 Touching the Exit button completes searching halfway.
- If the searched device is not found in the read program, the message "DEVICE NOT FOUND" appears and searching is completed.

After searching, the program that has been read first is displayed on the ladder monitor screen.



 After coil-search, monitoring of the ladder displayed is started automatically. When multiple read programs exist, the dialog box which asks about searching for other programs appears.

Touching the OK button starts searching to all other read programs.

- According to the order of the programs that have been read first, searching is started to the next file and the result is displayed.
- 8 Touching the searches consecutively.

 Touching the Exit button completes searching halfway.



Ladder display during consecutive search

When displaying the ladder block in the next sequence file, the previous search results are cleared. (Section 3.6.3 Coil search)



If the searched device is not found in all read programs, the message "DEVICE NOT FOUND" appears and searching is completed.

After searching, the program that has been read first is displayed on the ladder monitor screen.

(2) When displaying searching result with Alarm List/History The following explains the procedure from touching the Key Code Switch for user alarm display and performing coil-search of sequence program to display of a ladder block.



Program to be searched


In Alarm List/History, coil-search is performed to the sequence program that has been displayed on the ladder monitor last among the read sequence programs. However, when no ladder programs have not been displayed, coil-search is performed to the sequence program that has been read first.

Therefore, the file to be searched has to be read from the PLC reading screen beforehand.

For setting from the PLC reading screen, refer to the following section.

3.3.3 Display

The following explains the operation taking MELSEC-Q ladder monitor as an example.



* After coil-search, monitoring of the ladder displayed is started automatically. (For the A/FX ladder monitor, touching the Mon. key provides the same operation.)

- 1 Touch a key in monitor screen.
- Searching stats only when the monitor target of the sequence program that has been read and the monitor target that is set on the object match. When they are mismatch, an error message appears. Read again to match the monitor target for searching on the PLC reading screen. In MELSEC-A/FX ladder monitor, an error message does not appear even they are mismatch, and searching continues.

Searching result is displayed.

- 4 Touching the button searches consecutively.

 Touching the Exit button completes searching halfway.
- If the searched device is not found, the message "DEVICE NOT FOUND" appears and searching is completed.

After searching, the normal ladder monitor screen is displayed.


3

3.3.5 Reading comment files from CF cards

A comment file to be used for the ladder monitor can be read from a CF card installed on the GOT. Using a comment file stored in a CF card has the following advantages.


- The processing time is shorter than the one for reading a comment file from a PLC CPU.
- Writing comment file data into a PLC CPU is not required, so less memory of the PLC CPU is used.
- 1 Procedure for using comment files stored in CF cards

The following shows the procedure for using a comment file stored in a CF card.




Create a folder with the folder name of CIRCMNT in a CF card.

When the CIRCMNT folder already exists, creating a new CIRCMNT folder is not required.



Copy a comment file (.wcd) from the project data of GX Developer.



- 3 Save the copied comment file in the CIRCMNT folder created in the CF card.
- Install the CF card with the comment file on the GOT.
- 5 Read the comment file with the ladder monitor.



When using comment files stored in CF cards

When comment files exist both in a CF card and a PLC, the comment file to be used may not be read.

For using a comment file stored in a CF card, do not write comment file data into a PLC.

3.4 Operation Procedure Common

This section describes the information and key functions displayed on the ladder monitor screen. The display screen of the ladder monitor varies slightly with the GOT used. This chapter mainly uses the screen of the GT1575-V for explanation.


3.4.1 Information and key functions displayed on the screen

The ladder monitor screen depends on the controller type.



After executing PLC reading, if the controller comment or comment capacity is changed, the comment may not be correctly displayed on the ladder monitor screen. When changing the comment or comment capacity, re-start the GOT.

- (1) When the MELSEC-A/FX ladder monitor is executed
 - (a) Display monitor



When comment is not displayed :maximum 8 lines
When comment is displayed :maximum 3 lines

ON/OFF status display for ladder monitor

- * The MCR command is normally displayed as \mathbf{H} .

The information shown in the table below is displayed.


No.	Description
1)	Sequence program is displayed. A maximum of 11 contact points is displayed in one line of a ladder; for 12 contact points or more, move to the next line. When a comment display is specified, a comment is also displayed; expanded comments are given priority. For the method of displaying comments, see the following: Subsection 3.5.3 Switching comment/no-comment display
2)	A maximum of eight devices is displayed for the word device current value, timer and counter current value (upper row), and set value (lower row). When the set value is an indirect specification, the value of the indirectly specified device is displayed. To switch between decimal and hexadecimal for the displayed value, see the following: Subsection 3.5.2 Display switching of decimal numbers/hexadecimal numbers
3)	Display the keys used with the operation on the ladder monitor screen shown in (b) (Touch input).
4)	The display step number (left) and the remaining step number (right) are displayed.

(b) Key functions (when the MELSEC-A/FX ladder monitor is executed)

Key	Function
Exit	Returns the screen to the one displayed when the ladder monitor was activated.
PLCRD.	Switches the screen to the PLC reading screen to read from the controller the sequence program to be monitored. For further information about PLC reading, see the following: Subsection 3.3.3 Display
Mon.	Starts monitoring the displayed sequence program.
Menu	Displays the Menu window for ladder monitor (This section (2)).
List	Starts the list editor for A/FX. For details on the A/FX list editor, refer to the following. Chapter 4 MELSEC-A LIST EDITOR Chapter 5 MELSEC-FX LIST EDITOR
\uparrow	Scrolls the information upward by a ladder block.
	Scrolls the information downward by a ladder block.
← →	When the number of devices whose present and set values are within the display range shown in 2) on the preceding page is nine or more, the devices to be displayed are switched.
	Scrolls the information downward by a screen. In search operation, a search is continuously performed under the same conditions.
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, see the following: Subsection 3.4.2 Hard copy output
Cancel Print	The operation of this key is invalid.

(2) When the MELSEC-Q/QnA ladder monitor is executed

(a) Display screen




For the number of characters of comments and comment display, see the following:


Subsection 3.5.3 Switching comment/
no-comment display

Subsection 3.5.4 Displaying 32
characters of comments

ON/OFF status display for ladder monitor

- * The MCR command is normally displayed as +11-.





For the number of characters of comments and comment display, see the following:

Subsection 3.5.3 Switching comment/
no-comment display
Subsection 3.5.4 Displaying 32
characters of comments

ON/OFF status display for ladder monitor

- * The MCR command is normally displayed as +1-.

The information shown in the table below is displayed.

No.	Function
1)	Sequence program is displayed. A maximum of 11 contact points is displayed in one line of a ladder; for 12 contact points or more, move to the next line. When [Comment Display] is specified, comments are also displayed. For the method of displaying comments, see the following: Subsection 3.5.3 Switching comment/no-comment display.
2)	A maximum of eight devices is displayed for the word device current value, timer and counter current value (upper row), and set value (lower row). When the set value is an indirect specification, the value of the indirectly specified device is displayed. To switch between decimal and hexadecimal for the displayed value, see the following: Subsection 3.5.2 Display switching of decimal numbers/hexadecimal numbers.
3)	The current status of monitoring local devices is displayed. "*" blinks just to the right of the local device monitor status display during communicating with a PLC CPU. Nothing is displayed without monitoring. • Auto setting(program names). : A local device is monitored. (The active program name is displayed.) • Local device monitor not executed. : A local device is not monitored. • Local device monitor is not supported. : The PLC CPU being used is inapplicable to the local device. For switching the local device monitor between execution and non-execution states, refer to the following. This section (3)

No.	Function
4)	Display the keys used with the operation on the ladder monitor screen shown in (b) (Touch input).
5)	The Ch No., the network No., the station No. and CPU No. are displayed. (Only when the MELSEC-Q ladder monitor function is executed.)
6)	The drive is displayed.
7)	The file name of the PLC program is displayed.
8)	The total number of steps in the current monitor PLC program is displayed.

(b) Key functions (when the MELSEC-Q/QnA ladder monitor is executed)


No.	Function
Exit	Returns the screen to the one displayed when the ladder monitor was activated.
PLCRD.	Switches the screen to the PLC reading screen to read from the controller the sequence program to be monitored. For further information about PLC reading, see the following: Subsection 3.3.3 Display
Mon.	Starts monitoring the displayed sequence program.
Menu	Displays the Menu window for ladder monitor (Fig. This section (2)).
← →	When the number of devices whose present and set values are within the display range shown in 2) on the preceding page is nine or more, the devices to be displayed are switched.
\uparrow \downarrow	Scroll the information upward and downward by a ladder block.
	Scrolls the information downward by a screen. In search operation, a search is continuously performed under the same conditions.
Sea. Back	Displays back past device/contact point/coil searches or touch searches by one.
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, see the following: Subsection 3.4.2 Hard copy output
Cancel Print	The operation of this key is invalid.
JUMP1 JUMP1	Jump the information upward and downward by ten ladder blocks.
List	Displays the program list window (This section (3))



About the Back key (Only when the MELSEC-Q/QnA ladder monitor is executed.) (1) Continuous device search by key Immediately after the Back key has been pressed to go back in the history, a continuous device search using the 🛁 key cannot be executed. (2) Number of histories that can be gone back Sea. Using the Back key, you can go back into the history up to 100 ladders. (3) Clearing search history When any of the following operations is performed, the search history is cleared to return to the normal ladder display. (When a single ladder block takes up more than one screen, scrolling can be made within the block.) • When the JUMP1 JUMP1 key is touched. • When a step search, END search or defect search is executed. · When a comment display is changed. • When a new file is read by touching PLCRD. . (4) Returning search results during searching in multiple sequence programs (a) Displaying search results For searching in multiple sequence programs, the GOT can display search results of the previously searched program by touching the Back key. The GOT cannot display search results of multiple programs on one screen. When programs are switched, the currently displayed search results of the program disappear from the screen. (b) When searching program is deleted For returning to the search results of the previously searched program by touching the Back key during searching in multiple sequence programs, the touch operation is canceled when the previously searched program is deleted.

(3) Menu window for the ladder monitor

(a) Display screen




(b) Key functions

	Key	Function
	Dev.Sea.	Displays the ladder block containing the specified device.
		Subsection 3.6.1 Device search
		Displays the ladder block containing the specified device.
	Cont.Sea	Subsection 3.6.2 Contact point search
		Displays the ladder block containing the specified coil.
	Coil.Sea.	Subsection 3.6.3 Coil search
Search operation		Displays the ladder block containing the specified step number.
operation	Step.Sea	Subsection 3.6.4 Step search
	End.Sea.	Displays the last ladder block of the sequence program.
		Subsection 3.6.5 Ladder end search
	Xref.	Searches the ladder blocks for the status of continuity/non-continuity of the contact point that
		turned on or off the coil on the sequence program.
		Subsection 3.6.6 Defect search
		Switches the word device and timer/counter values displayed on the ladder monitor
	16/32Bit	screen to the 16-bit (one-word) or 32-bit (two-word) module.
		Subsection 3.5.1 Display switching of 16-bit (one-word)/32-bit (two-word) modules
	Dec.Hex.	Switches the word device and timer/counter values displayed on the ladder monitor screen to
		decimal or hexadecimal numbers. Subsection 3.5.2 Display switching of decimal
		numbers/hexadecimal numbers
	Cmnt.	Switches whether to display the comments added to the word and bit devices displayed on the
Display		ladder monitor screen. Subsection 3.5.3 Switching comment/no-comment display
format	Cmnt.32	Displays the 32 characters of the comments to the word and bit devices displayed on the ladder
switching		monitor screen. For further information, see Subsection 3.5.4 Displaying 32 characters
		of comments This key is not displayed when the MELSEC-A and MELSEC-FX ladder monitor.
		Switches whether to display integrated notes on the sequence program.
	Note	Peripheral notes are represented by *. Subsection 3.5.5 Displaying notes
		This key is not displayed when the MELSEC-A and MELSEC-FX ladder monitor.
		Switches whether to display integrated statements on the sequence program.
	Statement	Peripheral statements are represented by *. Subsection 3.5.6 Displaying statements
		This key is not displayed when the MELSEC-A and MELSEC-FX ladder monitor.
Test	TEST	Changes device values on the screen when the ladder monitor is executed. For further
operation		information, see the following:
		Section 3.7 Test Operation
Local device		Switches the local device monitor between execution and non-execution states.
monitor	Local Dev.	Section 3.8 Local Device Monitor
		The key is not displayed with the MELSEC-QnA ladder monitor.

(4) Program list window

(a) Display screen



The following table shows the display details.


No.	Function
1)	Displays saved sequence program name.
2)	Displays the keys used in the program list window's operation. (Touch input) Besides key touch, a program name can be selected by touching the program name directly.


(b) Key functions

Key	Function	
Switch	Switches to the selected ladder monitor screen.	
\uparrow	Scrolls the display upward or downward by a file.	
JUMP T	Scrolls the display upward or downward by a page.	
JUMP↓	Sololis the display apward of downward by a page.	

3.4.2 Hard copy output


This section describes how to store a ladder monitor screen to the memory card in BMP/JPEG file format or print it with a printer.





- Install the extended function OS (Printer) to the GOT when printing a ladder monitor screen.
- The output target (memory card/printer) of hard copy can be set in Hard Copy of GT Designer2.

For details of hard copy setting, refer to the following manuals.



• When outputting a hard copy, the display can be inverted between white and black. For invert colors setting, refer to the following manual.

GT Designer2 Version Screen Design Manual (Section 13.2 Hard Copy)

3.5 Switching the Display Format

You can switch the display format (16-bit (one-word) module/32-bit (two word) module or decimal number/ hexadecimal number) of word device and timer/counter values displayed on the ladder monitor screen, and whether to display the comments to the target devices.

3.5.1 Display switching of 16-bit (one-word)/32-bit (two-word) modules


During monitoring, the present values of word devices (except timers and counters) are displayed in the 16-bit or 32-bit module. These modules switch alternately each time you press the 16/32Bit key.



Displaying timers and counters

You cannot switch the 16-bit (one-word) or 32-bit (two-word) module with regard to the present and set values of timers and counters. The GOT automatically selects to display them in the 16-bit (one-word) or 32-bit (two-word) module.

(Operation example: Switch 16-bit (one-word) module display to 32-bit (two-word) module display.)



1 Touch Mon. .

2 Touch Menu.


3 Touch 16/32Bit.

The word devices are displayed in the 32-bit (two-word) module.

3.5.2 Display switching of decimal numbers/hexadecimal numbers


During monitoring, the present values of word devices and the present values (upper values) and set values (lower values) of timers/counters are displayed in decimal or hexadecimal numbers. The display formats switch alternately each time you press the Dec.Hex. key.

(Example of operation: Switching the decimal display to the hexadecimal display.)




Coil,Sea.

Touch
"Dec.Hex."




Touch Menu .






3.5.3 Switching comment/no-comment display

Comments written in the target controller are displayed. Comment display and no-comment display switch alternately each time you press the Cmnt. key.







3 Comments are displayed. Each comment is displayed in five characters on three lines.



Priority of comment display

- (1) For the MELSEC-Q/QnA ladder monitor
 Either of Common Comment or Comment by program can be selected.
 For the setting of comment display priority, refer to the following manual.


 GT16 User's Manual (Basic Utility) (4.2.1 Q/L/QnA ladder monitor setting)


 GT15 User's Manual (11.7 Q/QnA Ladder Monitor)
- (2) For the MELSEC-A ladder monitor
 The comment display priority is as follows.
 Extension comment > Comment in Kanji or kana

3.5.4 Displaying 32 characters of comments


Comments can be displayed in 32 characters when the MELSEC-Q/QnA ladder monitor is executed. They are not displayed when the MELSEC-A/FX ladder monitor is executed.


(1) Procedure for displaying 32 characters of comments





2 Touch Cmnt.32.





Display example of 32 characters of comment

A comment is displayed in eight characters on four lines.

(2) Comment display when the MELSEC-Q/QnA ladder monitor is executed

Comments are displayed as shown below when you touch each of the Cmnt. and Cmnt.32 keys.

Present comment display status	Key operation	Comment display after key operation			
	Touch the Cmnt. key.	Comments displayed			
No comments displayed	Touch the Cmnt.32 key.	32 characters of comments displayed			
Outros and a displayed	Touch the Cmnt. key.	No comments displayed			
Comments displayed	Touch the Cmnt.32 key.	32 characters of comments displayed			
32 characters of comments displayed	Touch the Cmnt. key.	Comments displayed			
32 Gharacters of confinents displayed	Cmnt.32 key.	No 32 characters of comments displayed			

(3) Numbers of lines and contact points that can be displayed when the MELSEC-Q/QnA ladder monitor is executed

The table below shows the numbers of lines and contact points that can be displayed in the statuses of no comments displayed, comments displayed, and 32 characters of comments displayed.


	No commen	its displayed	Comments	s displayed	32 characters of comments displayed		
GOT	Number of lines that can be displayed	Maximum number of contact points displayed	Number of lines displayed	Maximum number of contact points displayed	Number of lines displayed	Maximum number of contact points displayed	
GT1695M-X GT1685M-S GT1595-X GT1585V-S GT1585-S GT1575V-S GT1575-S	15	11	6	11	5	6	
GT1575-V GT1575-VN GT1572-VN GT1565-V GT1562-VN	8	11	3	11	2	6	


3.5.5 Displaying notes

Notes in the sequence program can be displayed when the MELSEC-Q/QnA ladder monitor is executed. This subsection describes the operation procedure for displaying notes.

Notes cannot be displayed when the MELSEC-A/FX ladder monitor is executed.

Peripheral notes are represented by "*."





2 Touch Note .


3 Peripheral/Integrated notes are displayed.


3.5.6 Displaying statements

Statements in the sequence program can be displayed when the MELSEC-Q/QnA ladder monitor is executed. This subsection describes the operation procedure for displaying statements. Statements cannot be displayed when the MELSEC-A/FX ladder monitor is executed.


The following statements cannot be displayed and are represented by "*."

- · Peripheral statements
- I statements (peripheral) and P statements (peripheral)









Peripheral/Integrated statements are displayed.

Peripheral statements are represented by "*."

I/P statements are displayed.
I statements (peripheral) and P statements (peripheral) are represented by "*."

3


3.5.7 Language switching of the sequence program (MELSEC-Q/QnA ladder monitor)


In the MELSEC-Q/QnA ladder monitor, language switching (Japanese/Korean) is available for displaying the following items of a sequence program.

(To switch the language, register the following items with the language (Japanese/Korean) used for the PLC READING DATA DISPLAY. To display Korean, for example, register the following items with Korean on GX Developer.)


- · File name
- Title
- Comment
- Note
- Statement

Items other than the above (such as menu) are displayed with the language set on [GOT setup].






(Continued to next page)



The setting window appears. Perform the PLC READING DATA DISPLAY.
The settings shown below switch with every touching of the key.



- * The language set at [GOT setup] is displayed.
- 3 After completing the setting, touch the ⊠ button to close the setting window.
- 4 The display is switched.

3

3.6 Search Operation

This section describes device search, contact point search, coil search, step search, ladder end search, defect search, and touch search.



(1) Searching among multiple programs

Search can be performed to multiple sequence programs read from PLC CPU. For searchable items among multiple programs, refer to the following section.

3.2 Specifications


(2) Searching in the specified program (only for the MELSEC-Q/QnA ladder monitor) Search can be automatically performed to a program by specifying the file to be searched with a object such as the Special Function Switch.

3.3.4 Searching from the monitor screen

3.6.1 Device search

Device search displays the ladder block that contains a specified device.

<Operation procedure>





- 2 Touch Dev.Sea. .
- 3 Using the ◀ and ▶ keys, switch the input area, and enter a device name and its number. *1
 Example: Specify D0.
 - After the device name and its number are
- entered, touch the Enter key. Input is completed, and the keyboard closes.
 - *1 The data entered can be corrected with the following keys:
 - Del key: Used to delete a character of the entered information.
 - AC key: Used to delete all characters entered.
- The ladder block containing the specified device is displayed.

 The device is highlighted as shown in the display example below.

 (Display example)



Only the ladder block(s) found in the subsequent sequence

file is displayed.




(1) Continuous read based on the same device
 After a search, a continuous search can be performed based on the same device
 by touching on the screen.
 If you touch another key, the continuous read function will be canceled.

(2) Ladder monitor display after a search

The ladder block containing the searched device is displayed.

Example) 1) When the entered device you want to search is "D0"



2) When the same search is continued



When searching multiple files with the MELSEC-Q/QnA ladder monitor, displaying the ladder block of the subsequent sequence file clears the previous display.




(3) Indirect specification device read Indirect specification devices (index register (Z)) cannot be specified and read when the MELSEC-Q/QnA ladder monitor is executed.

3.6.2 Contact point search

Contact search displays the ladder block that contains a specified contact point.

<Operation procedure>







- 3 Using the ◀ and ▶ keys, switch the input area, and enter a device name and its number. *1
 Example: Specify X1.
- 4 After the device name and its number are entered, touch the Enter key. Input is completed, and the keyboard closes.
 - *1 The data entered can be corrected with the following keys:

Del key: Used to delete a character of the entered information.

AC key: Used to delete all characters entered.

5 The ladder block containing the specified contact point is displayed.

The contact point is highlighted as shown in the display example below. (Display example)

X1

3

Only the ladder block(s) found in the subsequent sequence


file is displayed.




- (1) Continuous read based on the same contact point After a search, a continuous search can be performed based on the same contact point by touching on the screen.
 If you touch another key, the continuous read function will be canceled.
- (2) Ladder monitor display after a search

 The ladder block containing the searched contact point is displayed.

Example) 1) When the entered contact point you want to search is "X1"



2) When the same search is continued





When searching multiple files with the MELSEC-Q/QnA ladder monitor, displaying the ladder block of the subsequent sequence file clears the previous display.



Coil search displays the ladder block that contains a specified coil.

<Operation procedure>





2 Touch Coil.Sea.

- 3 Using the ◀ and ▶ keys, switch the input area, and Enter a device name and its number.*1
 Example: Specify T0.
- 4 After the device name and its number are entered, touch the Enter key. Input is completed, and the keyboard closes.
 - *1 The data entered can be corrected with the following keys:

Del key: Used to delete a character of the entered information.

AC key: Used to delete all characters entered.

The ladder block containing the specified coil is displayed.

The coil name is highlighted as shown in the display example below. (Display example)

T0




(1) Continuous read based on the same coil After a search, a continuous search can be performed based on the same coil by touching on the screen.

If you touch another key, the continuous read function will be canceled.


(2) Ladder monitor display after a search

The ladder block containing the searched coil is displayed.

Example) 1) When the entered coil you want to search is "M120"



2) When the same search is continued



When searching multiple files with the MELSEC-Q/QnA ladder monitor, displaying the ladder block of the subsequent sequence file clears the previous display.




 Only the ladder block(s) found in the subsequent sequence file is displayed.

3.6.4 Step search

Step search displays the ladder block that contains a specified step number.

<Operation procedure>



- 1 Touch Menu.
- 2 Touch Step.Sea. .


- 3 Enter a step number.*1 Example: Specify step No. 40.
- 4 After the step number is entered, touch the Enter key. Input is completed, and the keyboard closes.
 - *1 The data entered can be corrected with the following keys:
 - Del key: Used to delete a character of the entered information.
 - AC key: Used to delete all characters entered.
- The ladder block is displayed with the specified step number at the top.
 (Display example)

The ladder block of step No. 40 is displayed.

3.6.5 Ladder end search

Ladder end search displays the last ladder block of the sequence program.

<Operation procedure>






- Touch Menu.
- 2 Touch End.Sea.

- 3 The last ladder block of the sequence program is displayed.
 - MELSEC-Q/QnA ladder monitor
 The ladder block of the end command is displayed.
 - •MELSEC-A/FX ladder monitor The last ladder block is displayed (the end command is not displayed). The message "CIRCUIT_END" will be displayed.

3.6.6 Defect search

Defect search searches the ladder block for the status of conductive/non-conductive of the contact point that turned on or off the coil on the sequence program.

<Operation procedure>



- 1 Touch Mon. .
- 2 Touch Menu.

- 3 Touch Xref.
- Select a coil, if necessary.
 Using the and keys, switch the input area, and enter the device name and its number of the selected coil.*1
 Example: Specify M120.
- After the device name and its number are entered, touch the Enter key. Input is completed, and the keyboard closes.
 - *1 The data entered can be corrected with the following keys:
 - Del key: Used to delete a character of the entered information.
 - AC key: Used to delete all characters entered.
- 6 A search for the device begins, and the research result is displayed.

To cancel a defect search, touch ESC.

During a defect search, all key operations except ESC and Exit are invalid.



Operation before a defect search

In the case of the MELSEC-A/FX ladder monitor, touch Mon. before starting a defect search.

If you touch $\boxed{\text{Xref.}}$ without touching $\boxed{\text{Mon.}}$, the message "NO MONITORING" will be displayed.


(1) Search result

Search results reveal any occurrences of the search device. They are useful when you determine whether a defective device is conductive or nonconductive. If any occurrence of the search device is not found as a result of the search, a message appears on-screen, telling that "PROGRAM NOT FOUND."

(a) When an occurrence of the search device is found:

If an occurrence of the search device is found as a result of the search, the search for another defective device will automatically be started.

Example: After searching for Device M120 that is in the OFF state, "M669" will be displayed as a device that caused a failure.



The next defect is automatically

searched

After searching for Coil M120 that is in the OFF state, "M669" is displayed as a device that is not conductive.

Example: MARGI

* After searching for a device that is in the ON state, a device that is conductive is displayed. The entire field of the device name and number is highlighted onscreen.

Example: M669

After searching for Coil M669 that is in the OFF state, "M111" is displayed as a device that is not conductive.

Example: 1111

When there is no more defect, the "FACTOR SEARCH STOP" will be displayed, and the defect search will end.

(b) When two occurrences of the search device are found.
If there are two or more devices that caused a failure, the "the defect search is interrupted" message appears and the defect search is terminated.

Example: After searching for Device M120 that is in the OFF state, "M669" and "M23" will be displayed as devices that caused a failure.



After searching for coil M120 that is in the OFF state, "M669" and "M23" are displayed as devices that are not conductive.

Example: **1**669, **1**28

* After searching for a device that is in the ON state, devices that are conductive are displayed. The entire field of the device name and number is highlighted on-screen.B

Example: M669 , M23

When resuming the defect search, specify either of the found contacts M669 and X0025. After touching ESC to change it into Menu, execute the defect search.



Precautions for making defect search

- (1) When the contact point searched is a b contact point If a B-contact is found defective as a result of the defect search, a search for the cause of the ON/OFF state will be automatically switched.
- (2) Screen display after a defect search After the end of the defect search, the GOT stops monitor and displays the search result. Hence, the monitor screen of the GOT shows the result retained during the defect search.
- - appear at the start or the end of the search results.
 - When viewing the start of search results: "This is the start of search results."
 - When viewing the end of the search results: "This is the end of search results."
- (4) Display of contact point and coil ON/OFF
 - 1) During automatic search execution
 - MELSEC-A/FX ladder monitor: Displays ON/OFF in the entire ladder displayed on the screen.
 - MELSEC-Q/QnA ladder monitor: Displays ON/OFF in the ladder displayed last.
 - 2) During search result display

The ON/OFF of the ladder block searched last and the monitor results of word devices are displayed.

(5) Switching the Menu / ESC key switch

When the defect serch starts, Menu change into ESC.

Touch ESC during the defect search to stop the defect search and display the search result.

Further, touch ESC to change ESC into Menu and display the normal ladder.

- (6) Screen display during a defect search
 - 1) If the display data exceeds one screen during the defect search The screen is scrolled automatically.
 - 2) If the ladder step searched during the defect search exceeds one screen
 - MELSEC-A/FX ladder monitor: The screen is scrolled automatically to the last line of the ladder step.
 - MELSEC-Q/QnA ladder monitor: The screen is not scrolled automatically to display the ladder step.
- (7) Screen display when you touch the ESC key

Touching ESC can stop the defect search. Search results are continuously displayed on-screen until ESC is touched.

The ladder step searched last is displayed as described below.

- MELSEC-A/FX ladder monitor: ON/OFF display is not provided.
- MELSEC-Q/QnA ladder monitor: ON/OFF display is provided.

3.6.7 Touch search


Touch search is a function to search the coil of the same device by touching a contact point displayed on the ladder monitor screen, or to search the contact point of the same device by touching a coil.


You can search sequence program from the first to last steps.

This function is valid whenever a ladder monitor is normally displayed.




- Touch search is not available when the MELSEC-A/FX ladder monitor is executed.
- Touch search is not available for commands or word devices except contact points and coils.
- Touch search is not available when defect search is used.
 (To use touch search, touch ESC) to deactivate defect search.)
- (1) Contact point search → coil search










(The searched device is highlighted.)

Display example: M120




You can continuously search the ladder in the downward direction by touching
.


When there is no more contact point of the same device in which the touched contact point exists, the message "DEVICE NOT FOUND" will be displayed.


The next coil is displayed.

3


(2) Operation procedure (coil touch → contact point search)







When searching multiple files with the MELSEC-Q/QnA ladder monitor, displaying the ladder block of the subsequent sequence file clears the previous display.



Touch a coil on the screen.

2 The contact point of the same device in which the coil exists is searched, and the ladder block containing the searched contact point is added to the ladder blocks displayed.

(The searched device is highlighted.)

3 You can continuously search the ladder in the downward direction by touching

When there is no more contact point of the same device in which the touched coil exists, the message "DEVICE NOT FOUND" will be displayed.

3.7 Test Operation

You can change device values and turn on and off bit devices on the screen when the ladder monitor is executed. This section describes how to display the test menu screen.

For the procedure for changing device values and turning on and off bit devices, see the following.

Section 2.9 Test Operation




Before test operation

Timer and counter values cannot be changed during MELSEC-FX ladder monitoring.

With the MELSEC-Q/QnA ladder monitor function, the GOT cannot write data to the devices in the QSCPU.


3.7.1 Displaying the test menu screen

Displaying the test menu screen
 The procedure for displaying the test menu screen during ladder monitoring is described below.









3 The test menu screen is displayed.
Change device values by operating the window.

For further information about the operation procedure, see the following:

Section 2.9 Test Operation



The present and set values of word devices are hidden behind the test menu screen.

You can display hidden present and set values by scrolling them to the right or left using the \frown or \rightarrow key.

Test menu screen

3.8 Local Device Monitor

The GOT can monitor local devices with the MELSEC-Q ladder monitor. For local devices, refer to an applicable programmable controller manual.



Monitoring local devices

Local devices can be monitored only with the ladder monitor.


Operations for monitoring local devices cannot be executed on the user-created screen.

3.8.1 Operation procedure for local device monitor

Every time the Local Dev. key is pressed, the local device monitor is switched between execution and non-execution states.

1 Starting local device monitor

The following shows how to start the local device monitor.




(Continued to next page)

1 Touch Mon. .

2 Touch Menu.

3 Touch Local Dev.



4 The local device monitor is started.

For changing a sequence program to be monitored, touch List, and then change sequence programs on the program list window.

6 The local device monitor is started with the changed sequence program.



How to monitor local devices when ladder monitor starts

With setting the GOT setup, the GOT can start monitoring local devices when the ladder monitor starts.


For settings for monitoring local devices when the ladder monitor starts, refer to the following manual.


GT16 User's Manual (Basic Utility) (4.2.1 Q/L/QnA ladder monitor setting)

GT15 User's Manual (Section 11.7 Q/QnA Ladder Monitor)

2 Ending local device monitor

The following shows how to end the local device monitor.







- 3 End the local device monitor.

 The local device monitor is ended with the
 - following operations.

 - When touching PLCRD. key



When ladder monitor screen is switched to other screens during executing local device monitor

When the ladder monitor screen is switched to other screens because of communication errors and others during monitoring local devices, the GOT keeps monitoring local devices.

For switching the local device monitor to non-execution state, restart the ladder monitor, and then switch the local device monitor to non-execution state.

(Continued to next page)

3.9 Error Messages and Corrective Action

This section describes the error messages displayed when the ladder monitor function is executed, and corrective action.

Error message	Description	Corrective action
ENTRY CODE MISMATCH	The specified keyword is different from the keyword that is registered in the object PLC CPU.	Check the keyword that is registered in the object PLC CPU and specify again.
FILE NOT FOUND	(1) An attempt was made to switch to the ladder monitor screen when a sequence program had not been read. (2) When the file is selected and the "Read" key is pressed, the selected file does not exist in the PLC drive.	Read the sequence program that written in the object PLC CPU. (Ex.) A sub-sequence program can only be specified as A3 CPU/A4UCPU.
PLC COMMUNICATION ERROR	(1) Cannot communicate with PLC CPU of the specified network No. or station No. (2) The specified drive does not exist.	Check and correct the following: (1) Does the specified PLC CPU exist? (2) Is it online? (Data communication status?) (3) Has an error occurred? (4) Is CPU No. correct? (5) Power on the GOT again. and so on.
LOCK ON OTHER MACHINE. PLEASE CANSEL	File is locked with the peripheral equipment (GX Developer, GPPQ).	After reading and writing with the peripheral equipment (GX Developer, GPPQ), read the file again.
NOT EXISTING DRIVE, DRIVE ERROR	(1) The specified drive does not exist.(2) The specified drive is faulty.	(1) Check whether the specified drive exists or not.(2) Check whether the specified drive is faulty or not.
ENTRY CODE MISMATCH	The specified file password differs from the one registered as the file password of the corresponding PLC CPU.	Confirm the file password registered to the drive of the corresponding PLC CPU, and specify it again.
FILE NOT FOUND	 (1) When reading file from PLC CPU After selecting a file and pressing the "Read" key, the selected file does not exist in the PLC CPU drive. When starting ladder monitor from the monitor screen, the selected file does not exist in the PLC CPU drive. (2) When reading file from CF card No CF cards are inserted in the specified drive. No comment files are stored in the CF card. 	 (1) When reading file from PLC CPU Perform [Read from PLC] on the network No./station number input screen to update the file list. Change the specified drive (Target memory). Check the sequence program in the PLC CPU. (2) When reading file from CF card Check if a CF card is inserted in the specified drive. Check if comment files are stored in the CF card.
USE BY OTHER MACHINE. PLEASE CANCEL	The sequence or comment is being used by the peripheral device (GX Developer).	Perform file read again after completion of read/write from/to the peripheral device (GX Developer).
2M bytes of comments were read since they exceeded 2M bytes.	Only 2M bytes of the comment file was read because its size is greater than 2M bytes.	Reduce the comments to bring the size of the comment file down below 2 Mbytes.
Outside CPU reset/device range/ special module illegal access	The accessed special module is faulty or does not exist.	Check the system configuration.
FILE ACCESS ERROR. CONFIRM DRIVE.	The access error to file has occurred.	When the storage location of ladder data is set to [A: Standard CF Card] or [B: Extended Memory Card], check that the CF card is properly inserted. • Check if the CF card is properly inserted in the drive set for reading comment files.
INSUFFICIENT SAVING DRIVE CAPACITY.	Capacity of free disk of saving destination is insufficient.	Confirm the capacity of free disk of saving destination, increase the amount of free disk.
FILE ACCESS <do not="" out="" plug="" pull="" the=""></do>	File being accessed.	Do not turn off the power during message display. Wait until the message display goes out.

(Continued to next page)

Error message	Description	Corrective action
No END instruction.	The sequence program has no END instruction.	Check the sequence program with the peripheral device (GX Developer).
Instruction code abnormal.	The sequence program has an abnormal command code.	Check the sequence program with the peripheral device (GX Developer).
Ladder creation bad.	The sequence program has an abnormal circuit.	Check the sequence program with the peripheral device (GX Developer).
Please release the keyword.	Communication is not possible because a keyword is registered in the target PLC. (For FX3U(C) only)	Release the keyword for the target PLC.
THE KEYWORD IS REGISTERED.	A keyword is set to the PLC that is targeted to the PLC reading on the PLC reading screen.	Release the keyword for the target PLC.
Cannot read multiple files.	Data Save Location is set to [None].	 (1) When reading file from PLC CPU Read only one program file or one comment file. (2) When reading file from CF card No CF cards are inserted in the specified drive. No comment files are stored in the CF card.
Number of files exceeds 512. Aborting · · ·	The number of read file exceeds the maximum number of files can be treated in ladder monitor (512).	Delete superfluous files and perform reading again.
This is not a specified program.	When starting ladder monitor from a monitor, the monitor target of the specified device and that of the program already read to the GOT do not match.	Read the program again.
The specified file does not exist.	An invalid program is specified during monitoring local devices.	Check the sequence program in the PLC CPU, and then read the program again.
Local device monitor error.	An error occurs during monitoring local devices.	Check the settings in the PLC CPU, and read the program again.
Local device monitor is not supported.	The PLC CPU does not support the local device monitor function.	Check manuals for the PLC CPU.
	1	1

4. MELSEC-A LIST EDITOR











4.1 Features

The MELSEC-A list editor enables you to change the sequence program in the ACPU/QCPU (A mode). This function is intended to troubleshoot the PLC system and to streamline maintenance operations. By installing list editor for MELSEC-A, an Option OS, from GT Designer2 into the GOT, you can edit the ACPU/QCPU (A mode) PLC program.

The features of the MELSEC-A list editor are described below.

1 Parameters and sequence programs are easy to maintain.

You can check or partly correct, change or add PLC CPU parameters and sequence programs simply by operating keys.


You can easily edit sequence programs without preparing any peripheral unit other than the GOT.

Example of changing sequence program commands

2 Combination with the ladder monitor

You can open the MELSEC-A List Editor window from the Ladder Monitor screen with a single touch, and can edit PLC program while checking the ladder.

You can also display a list from the step line displayed by the ladder monitor.





3 Other stations are accessible.

You can edit the sequence program for other stations in the data link system containing the GOT (or GOT-connected station), network system or CC-Link system.

4 Help function

A convenient help function is supported, which enables you to read, write, insert, and delete data as you select menus.

5 Comment for each device can be displayed.

Comment of the device at the cursor position can be displayed.



4.2 Specifications

4.2.1 System configuration

This subsection describes the PLC CPU series names and the connection forms between the GOT and the PLC for which the MELSEC-A list editor is available.

For further information about communication units and cables for each connection form, see the following:

GOT1000 Series Connection Manual

1 Targeted PLC

PLC
ACPU/QCPU (A mode)*1*2

- *1 Motion controller CPUs cannot be connected. The message "MOTION CONTROLLER NOT SUPPORTED" will be displayed when the MELSEC-A list editor function is activated.
- *2 When the PLC is A2USH-S1, it operates within the range of A3U; when the PLC is the A2SH-S1, A2SH, A1SH, or A1SJH, it operates within the range of A3N.

2 Connection forms

When the GOT is connected to an ACPU/QCPU (A mode)

(O: Available, x: Unavailable)

						Con	nection	form bet	ween GO	OT and P	LC					
	Bus Direct (connection*1*3 connect		Direct CPU		Computer link connection		Ethernet connection		MELSEC NET/10 connection*1*2		CC-Link connection*1*2			GOT		
Function name			ection	ID*4							G4*5		multidrop connection			
	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11	GT16 GT15	GT11
MELSEC-A list editor	0	0	0	0	×	×	0	×	0	×	0	×	×	×	×	×

^{*1} When the PLC is the A2SH-S1/A2SH/A1SH/A1SJH, use a CPU of version E or a later version. Programs cannot be written to CPUs of version D or an earlier version.

^{*2} When the PLC is A3N, A2N-S1, A2N, or A1N, it can not be used.

^{*3} When the PLC is QCPU (A mode), it cannot be used.

^{*4} Indicates CC-Link connection (Intelligent device station).

^{*5} Indicates CC-Link connection (via G4).

3 Required option OS and option function board

The option OS and option function board shown below are required.

Option OS		OS memory sp	ace (user area)	Option function board			
	GT	16					
	Built-in flash memory (ROM)			GT11	GT16	GT15	GT11
MELSEC-A list editor	542KB	1024KB	1058KB	0KB	Not required	GT15-FNB, GT15-QFNB, GT15-QFNB16M, GT15-QFNB32M, GT15-QFNB48M, GT15-MESB48M	GT11-50FNB

(1) Option OS

Install the option OS in the above table to the GOT.

Refer to the following manual for the procedure for installing the option OS.

GT Designer2 Version Basic Operation/Data Transfer Manual (8. TRANSFERRING DATA)

(2) OS memory space

The available memory space shown in the table above is required in the user area to install the option OS to the GOT.

Refer to the following manual for the procedure for checking the available memory space of the user area and information about the data using other user areas.

GT Designer2 Version ☐ Basic Operation/Data Transfer Manual (8. TRANSFERRING DATA)

- (3) Option function board
 - (a) For GT16

No option function board is required.

(b) For GT15 and GT11

Mount one of the option function boards in the above table on the GOT.

For the GOTs with a built-in option function board, refer to the following.

1.1.2 Hardware and OS' required for each function

For how to mount an option function board on the GOT, refer to the following manual.

GT15 User's Manual (8.10 Option Function Board)

GT11 User's Manual (8.3 Option Function Board)

4.2.2 Access range

The access range is the same as the access range when the GOT is connected to a controller. Refer to the following manual for details of the access range.

GT Designer2 Version ☐ Screen Design Manual (2.7 Controllers that can be monitored and the Access Range)

4.2.3 Precautions

The points of precaution when using MELSEC-A list editor are described.

- (1) Reading the MELSEC-A list editor by specifying a command

 The MELSEC-A list editor cannot be ready by specifying a dedicated command.
- (2) Using the MELSEC-A list editor together with the ladder monitor Even if you execute the MELSEC-A list editor with the ladder monitor activated, edited information will not be reflected on the Ladder Monitor screen. To reflect such edited information, perform the PLC reading of the ladder monitor again.
- (3) Executing the MELSEC-A list editor

 Execute the MELSEC-A list editor when the target PLC is not running.


 It cannot be executed when the PLC is running.
- (4) Changing sequence programs/parameters using another peripheral equipment When using the MELSEC-A list editor, do not change programs or parameters in the PLC CPU from other peripheral equipment. If you change programs or parameters, either reset the GOT main unit or set the PLC No. again. If you carelessly change the program on one PLC from multiple units of peripheral equipment (including GOT), the contents of the program in the PLC CPU and the peripheral equipment may not be the same, resulting in an unintended operation of the PLC CPU.
- (5) Writing sequence programs
 Sequence programs cannot be written when the target CPU is operating EEPROM.


NETWORK MONITOR

4.3 Display

4.3.1 Outline until the start

This subsection describes an outline until the system monitor screen is displayed after List editor for MEL-SEC-A (Option OS) is installed in the GOT.





*1 The communication setting window is not displayed when starting from the ladder monitor.



(1) How to display the utility

For how to display the utility, refer to the following.

GT16 User's manual (Basic Utility) (1.3 Utility Display)
GT15 User's manual (9.3 Utility Display)
GT11 User's manual (9.3 Utility Display)

(2) Displaying communication setting window


After turning on the GOT, the communication setting window is displayed at the first startup of the MELSEC-A list editor only. For displaying the communication setting window at the second or later startup, touch the Ch: button on the MELSEC-A list editor screen.

(3) If the project data has not been downloaded The A list editor can be started from the utility even if the project data has not been downloaded to the GOT.


4.3.2 Operation of keyword input

If a keyword is registered in the ACPU when the connected ACPU or the ACPU PLC No. No. corresponding to the operation is changed, the GOT requests for input of the registered keyword. Input the keyword registered in the ACPU and press the GO key. If a keyword is not registered in the ACPU, this operation is not required.

Procedure for inputting the keyword for the MELSEC-A list editor



^{*1} When the input keyword does not match with the registered keyword, only the following operations in subsection 4.6.7 can be allowed.





When you forgot the keyword entered in the ACPU

• Even if you are unsure of the keyword entered in the ACPU, you cannot delete it independently. If deleting user data, including sequence programs, does not cause any inconvenience to you, clear (delete) the entered keyword by <PLC memory all clear.>

Note that <PLC memory all clear> clears user data, including sequence programs, as well.

For further information about PLC memory all clear, see the following:

Section 4.5.6 PLC memory all clear


• When you know the keyword and want to change it or add a new keyword, see the following:

Section 4.6.1 Common operation


4.4 Operation Methods

4.4.1 Key arrangement and a list of key functions

- The arrangement and functions of the keys displayed on the MELSEC-A List Editor window are described below.
 - (a) Key arrangement and functions for GT16 and GT15



(b) Key arrangement and functions for the GT11



The functions of these keys are the same as those of the keys for the GT15. For a summary of the functions, see the preceding page.

- (2) How to express keys and key operation descriptions The keys for the MELSEC-A list editor and operation procedures are described in text in a simplified manner as shown below.
 - (a) Some keys, such as [RST] and [MOV], are available for two different purposes.

 Operate such keys with either the upper or lower function indicated on them valid according to the operation. In descriptions, only the necessary functions are indicated on keys.

 (Example of description)

When entering the character "M," the $\frac{MOV}{M}$ key is indicated as $\frac{M}{M}$ in the description.

Make upper or lower functions valid by using the SHIFT key or the SET key. For further information about the procedure for making upper or lower functions valid, see the following:

Section 4.4.3 Switching valid keys (upper/lower functions)

(b) The expression $\[\] \xrightarrow{\text{Key 1}} \] \xrightarrow{\text{Key n}} \]$ means touching keys from $\[\] \]$ to $\[\]$ in order.


(Example of description)

The example of description shown below indicates that SET must be touched first, F second, o third, and GO finally.

SET + F + 0 + R + SP + K + 5 + GO

4.4.2 Display format of the display area

The following describes the position and content of each data field in the MELSEC-A list editor display area




(1) Mode and valid key display


The following describes the mode and valid key display.


The mode display shows the MELSEC-A list editor mode selected by the user.


The valid key display shows which of the two functions assigned to each key is currently available: the function indicated at the upper part of the key or the function indicated at the lower part of the key.





With regard to keys framed in dotted lines in the figure shown at the left, the valid key display indicates which of the two functions assigned to each key is valid:













To switch between two functions of keys (functions indicated at upper and lower parts of the keys), press the SHIFT and SET keys.

Section 4.4.3 Switching valid keys (upper/lower functions)

(2) The cursor appears

The cursor appears and is highlighted during data input.

(3) Indication of the selected line

When a program list is displayed, the line currently selected for editing is indicated by " > " appearing immediately after the step number.

You can use the ↑ and ↓ keys to move " ▶ " up and down.

(4) Step number display

A step number is displayed as a decimal number.

On the 1st and 2nd lines in the display area, significant digits in the lower four digits of a step number are displayed.

On the 3rd and 4th lines in the display area, up to five significant digits in a step number are displayed.



(5) Device display

Two or more device specifications attached to a basic or application instruction are displayed using the same step number.


For information on the step numbers, see Paragraph (4) above.

(6) Display of data input from the keys

Data input from the keys will appear at the cursor position. As more characters are input, the cursor moves to the right.

The cursor appears as " \| \| ".

Example: The user enters SET 1 0



(7) Shifting of data to the left during the input of a program

When the user inputs a program, the codes entered before a touch on the GO key will appear on the 4th (bottom) line of the display area.

If the codes cannot appear on a single line, the display on the 4th line only will shift by a single character position to the left each time the user touches a key. (Each character that goes out of the display area by the left-shift operation is retained in the memory.)

W	1	1	5			М	5					Χ	0	0	0	5]	
*	1	2	0		L	D						M	3							
	1	2	1	\blacktriangleright	Ν	0	Ρ													
P	Κ	2	1	4	7	4	8	3	6	4	7		D	1	0	0	0			
1		Th	e u	se	r ha	as (ent	ere	ed '	'DN	10	VP	Κź	214	174	83	64	7 C)1000	O".

You can move " \blacksquare " in the specified direction (right or left) with the (\leftarrow) or (\rightarrow) key.

(8) Display of an error message

An error message will appear on the 4th line of the display area.

An error message on the display is cleared when you press any key. Then the display resumes the state before the appearance of the error message.

When an error message is displayed, take action according to the procedure described in the following section:

Section 4.7 Error Messages and Corrective Actions

4.4.3 Switching valid keys (upper/lower functions)

Make valid the upper or lower function of keys available for two different purposes to operate the MELSEC-A list editor.

(1) Switching the upper and lower functions of mode keys In general, the upper functions of mode keys are valid.
To make the lower function of a mode key valid, touch the SHIFT key and then the mode key.
During switching of the upper and lower functions of mode keys, the mark on the valid keys remains .

(2) Switching the upper and lower functions of command/device keys
Switch the upper and lower functions of command/device keys using the keys shown below, if
necessary.

SHIFT: Makes the upper function valid.

SET: Makes the lower function valid.

* The keys shown below can be operated even if the lower function of a key is valid.

(You do not need to operate the SHIFT key.)

• Comparison symbol keys at the input of comparison operation commands: ⟨ , ▷ , □

•Minus key in command source data: □

For further information about the display of valid keys, see the following:

□ Section 4.4.2 Display format of the display area

- (3) Valid command/device keys after setting each mode Valid command/device keys after setting each mode are shown below.
 - (a) Valid keys after setting read, write, and insert modes.The upper functions of the command/device keys are valid.If necessary, switch the upper and lower functions of necessary keys for operation.
 - (b) Valid keys after setting parameter, other, and help modes.The lower functions of the command/device keys are valid.If necessary, switch the upper and lower functions of necessary keys for operation.

4.4.4 Selection and operation of modes

Select appropriate modes of the MELSEC-A list editor for the operations described in Sections 4.5 and 4.6.

You can change modes as you desire during any of the operations described in Sections 4.5 and 4.6, so that you can continue operations while changing modes.

READ	Read mode
WRITE	Write mode
INSERT	Insert mode
DELETE	Delete mode
PARAM	Parameter mode
OTHER	Other mode



Mode key input is always valid.

Input of the mode key clears the input data except for the step numbers. The display returns to the initial status of the mode selection.

4.4.5 Command input procedures

Command input procedures can be classified as follows:

- 1) Input the command key to use the command on the key.
- 2) Input the alphanumeric keys corresponding to each character of command sequentially.
- 3) Select and input the command to be used from the Help function.

Command input procedures for 1) and 2) above are as follows.

For command input procedure 3) from the Help function, refer to Section 4.4.5 Command input procedures




When the command is input, the input details are displayed at the 4th line (the bottom line) on the display. In the following description, the input of SP key may be omitted when a blank space between the input command and the cursor position is automatically inserted. Refer to the example in each description.

- (1) For command code only
 - (a) When the command available on the keyboard is input

Command → GO

(Ex) When END is input




- (b) When the command not available on the keyboard is input
 - (Ex) When FOR K5 is input



(2) For command code and device (1)

Command → SP → DEVICE → DEVICE No. → GO


(Ex) When LD X0 is input




(3) For commands other than above

Input the SP key between the command and the device, the source data, and the destination data.


(Ex 1) When FMOV K2 DO K5 is input




(Ex 2) When OUT T1 K10 is input








(Ex 4) When LD = K10 D10 is input



(Ex 5) When ANDD<=H7FFF D20 is input




(4) Handling of devices M, L and S

Devices M, L and S in the Test, Monitor, Write and Insert modes change the display depending on the set parameters.

If LD L0 is input for the parameter setting of M0 to 999 and L1000 to L2047, the result is LD M0.

(5) For extension timer/extension counter of AnA and AnUCPU When the extension timer (T256 to T2047) and the extension counter (C256 to C1023) are input as the first device of the command, input the first device and the device number.

(Ex) When OUT T256 D500 is input





When the extension timer and the extension counter are used, be sure to set the 257 points or more and the setting value device (D, W, R) on the parameter for both the timer and the counter.

4.4.6 Hard copy output



Screens of the MELSEC-A list editor can be stored to a memory card in BMP/JPEG file format or printed with a printer.

Refer to the following for the hard copy.

- Starting the MELSEC-A list editor from the ladder monitor (3.4.2 Hard copy output)
- Setting the hard copy with GT Designer2.

(☐ GT Designer2 Version ☐ Screen Design Manual (Section 13.2 Hard Copy))

4.4.7 Action if an incorrect key is input

If an incorrect key is input, cancel the input contents.

1 Operation

- (1) Before touching the GO key (before reading/writing the input contents)

 Before touching the GO key, touch the CLEAR key.
- (2) After touching the GO key (after reading/writing the input contents)
 Write the command again. (5.4.5 Writing commands)
 Commands finalized by writing and inserting operations are revised (overwritten) with the program writing.



When the CLEAR key is input in the parameter mode, the GOT stops the process. To continue the operation, carry on the key input.

List of functions 4.4.8


The table below shows the functions available for each mode.

Mode (mode display)	Function					
	Writes, adds, or modifies a program.					
	Changes a device used at the selected step in the program.					
NA '' (140)	Displays a list of instructions that start with the specified character and allows the user to choose from them.					
Write (W)	Reads a program after allowing the user to specify a step number.					
	Declares the specified part of the program NOP.					
	Displays a comment for the specified device.					
	Reads a program after allowing the user to specify a step number.					
	Reads a program after allowing the user to specify an instruction used.					
D (D)	Reads a program after allowing the user to specify a device used.					
Read (R)	Automatically scrolls the display of a program that has been read up to a specified step.					
	Corresponds to program read and automatic scroll functions described above.					
	Displays a comment for the specified device.					
	Inserts a new program into the displayed program.					
	Displays a list of instructions that start with the specified character and allows the user to choose from them.					
1 (0)	Reads a program after allowing the user to specify a step number.					
Insert (I)	Moves the selected part of the program to a specified part of the program.					
	Copies the selected part of the program to a specified part of the program.					
	Displays a comment for the specified device.					
	Deletes a program at the specified step.					
	Deletes the specified block in the program.					
Delete (D)	Deletes all NOP instructions found in program codes described before the END instruction. (NOPLF instructions will not be deleted.)					
	Displays a comment for the specified device.					
	Clears all parameters in the ACPU only.					
Parameter (P)	Sets or changes various parameters like those for the memory capacity, timer/counter, and latching range.					
	Sets or changes a keyword.					
	Changes values set to timer/counter devices.					
	Displays details of an error in the ACPU and the associated step number.					
	Checks duplex coils, instruction codes, and other elements in the program.					
	With regard to a special function unit of the specified I/O number, monitors the contents of the buffer memory at the specified address.					
	Monitors the ACPU clock (D9025 through D9027).					
Others (O)	Clears all contents of the ACPU memory and resets it to the initial state.					
, ,	Clears the program (Main/Sub) currently selected.					
	Clears all device memories except for special-D, special-M, and R.					
	Switches the target ACPU in GOT operations in each mode.					
	Switches the target program (Main/Sub) in GOT operations in each mode.					
	Forcibly changes the ACPU running status between RUN and STOP.					
	Performs a read or write operation to the ACPU memory in the machine language.					

Basic Operation 4.5


This section takes an easy operation example to describe the basic operation of the MELSEC-A list editor.


Reading sequence programs 4.5.1



4.5.2 Changing (Overwriting) commands


The example shown below is used to describe how to change sequence program commands.






4.5.3 Adding (Inserting) commands


The example shown below is used to describe how to add sequence program commands.






4.5.4 **Deleting commands**

The example shown below is used to describe how to delete sequence program commands.






4.5.5 Using the help function

HELP is input to use the Help function.

Input of HELP displays the Help function menus in each mode. Select the corresponding item for execution.

(1) Reading the command in the sequence program

Example of reading the area using the "MOV" command in the sequence program.



(2) Displaying comment The following example shows the procedure of displaying the comment in the Read mode. [Operation example]

<Key operation>

1 Input the HELP key in the Read mode. HELP

Select "2: COMMENT DISPLAY". 2

3 Select "1: YES". 1

4 Move the cursor to the following step. **+**

<Display>

HELP MENU 1: READ 2: COMMENT DISPLAY CLEAR:END

1: YES 2: NO CLEAR:END HELP:MENU

0►LD X0000 1 OUT Y0020 2 LD X0000 Motor start limit

0 LD X0000 1►OUT Y0020 2 LD X0000 Motor start check

* * *COMMENT DISP.* * *

Display the comment of the device at the cursor position.

4.5.6 PLC memory all clear

When input of a keyword is requested, all parameters and sequence programs can be cleared together with the keyword registered in the ACPU using the operation below.

[Operation example]


Display the keyword input request.



- 2 Stop operation of ACPU Set the target ACPU to the stop status.
- Operation of PC memory all clear
 Input "ALLCLR" and press the GO key.

Display of PC memory all clear process

When the GOT starts clearing the process, the display in the left appears. "*" column and the total number of bytes change sequentially.



Completion of PC memory all clear process

When the GOT completes the clearing process, the screen in the left appears.

(status before the mode selection)

```
** MODE SELECTION **
(READ) (INS) (PARAM)
PRESS MODE KEY
```

6 If necessary, start the next operation.

4.6 List of Operation Procedures

4.6.1 Common operation

	Details	Purpose	Procedures (key input sequence)
	Input of keyword at start-up	Input when the keyword is registered in the ACPU.	Keyword → GO
Basic	Mode selection Switching of valid key	Select the mode.	Mode key (READ , INSERT, PARAM) SHIFT → Mode key (WRITE, DELETE, OTHERS)
	Switching of valid key	Switch the valid key (function indicated at the upper/lower part of the key) by a user.	SHIFT or SET
operation	Action for incorrect input	Perform the operation for incorrect key input.	CLEAR, Mode key or SHIFT → Mode key
	Operation of command help function	Perform operation with the Help function command specification.	Perform program display HELP 1 1 1 I I plut the capital letter operation in the Write/Insert mode. of the command. GO 1 I plut the capital plut the corresponding command number.
	Display of Comment	Display the comment stored in the ACPU.	Perform program display operation → HELP → 2 ↑ 1 in the Write/Read/Insert/Delete mode.
	Command code only	Input the command code only.	Command → GO
Command	Command code and 1 device	Input the command code and 1 device.	Command → SP → Device → Device No. → GO
Command input operation	Other than above (command key input)	Input the command other than above with the command key.	Input the SP between the device, the source data and the destination.
	Other than above (device key input)	Input the command other than above without the command key.	Input the SP between the command, the device, the source data and the destination.

4.6.2 Operation in write mode (W)

Details	Purpose	Procedures (key input sequence)
Continuous write in NOP	Set the specified range in the program to NOP.	Program display → HELP → 1 → 2 in the Write mode 1 → Start step specification → GO → Final step specification → GO 2 → Start step specification → GO
Write/modify (change) of program	Write the new program/modify (change)	SHIFT → WRITE → SET → Step number → GO → GO mand

4.6.3 Operation in read mode (R)

Details	Purpose	Procedures (key input sequence)
Command reading with the specified step number	Read the command of the specified step number in the program.	READ → SET → Step number → GO → GO
Read the command with the specified command.	Read the specified command in the program.	READ → Command → Device → Device number → GO
Read the command with the specified device.	Read the command with the specified device used in the program.	READ → SET → Device → Device number → GO → GO
Automatic scroll	Display the program with automatic scroll.	Read operation above SET SET Step number SET SET SP SET SP

NETWORK MONITOR

4.6.4 Operation in insert mode (I)

Details	Purpose	Procedures (key input sequence)
Insert a command in the program.	Insert a command in the program.	INSERT → Step number → GO → Com → GO mand
Move the program.	Move the whole program.	Display the program → HELP → 1 → 2 → Specify the movement in the Insert mode. start step. GO → Specify the movement → GO → Specify the movement → GO destination step.
Copy the program.	Copy the program.	Display the program → HELP → 1 → 3 → Specify the in the Insert mode. copy start step. GO → Specify the → GO → Specify the copy → GO destination step.

4.6.5 Operation in delete mode (D)

Details	Purpose	Procedures (key input sequence)
Delete a command from the program.	Delete a command from the program.	SHIFT → DELETE → Step number → GO → GO → → → → → → → → → → → → → → →
Delete the specified range of the program.	Specify the range of the program for deletion.	Display the program → HELP → 1 → 1 → Specify the in the Delete mode. deletion start step. GO → Specify the deletion → GO end step.
Delete the whole NOP.	Delete the whole NOP in the program.	Display the program → HELP → 1 → 2 in the Delete mode.

4.6.6 Operation in parameter mode (P)

Details	Purpose	Procedures (key input sequence)
Clearing all parameters	Return the parameters to the initial setting status.	
Parameter setting (for A0J2HCPU)	Set the parameters for the A0J2HCPU.	PARAM → 2 → 1)
Setting of latch range	Select the latch range from "No latch", "1/2 latch" and "All latch".	$1) \rightarrow 1 \qquad \qquad \downarrow \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \downarrow \qquad \qquad \downarrow \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \qquad \downarrow \qquad \qquad$
Setting of step relay	Set the availability (S1536 to 2047) of the step relay.	$1) \rightarrow 2 \rightarrow \bigcirc \bigcirc$
Completion of setting	When the parameter setting is complete, write the PLC CPU.	2) Setting for multiple items is also available. CLEAR → END → ♠ GO (End of writing is displayed.)
Parameter setting (other than A0J2HCPU)	Set the parameters other than A0J2HCPU.	PARAM → 2 → 1)
Setting of memory capacity	Set the main sequence program capacity and the file register capacity.	1)→1 → Capacity→GO→END→2) (For main, input unit: 1K step) 1)→1 → ↓ → Capacity→GO→END→2) (For sub, input unit: 1K step) 1)→1 → ↓ → points → GO→END→2) (For file register, input unit: 1K point)
M, L, S setting (other than AnA, AnUCPU)	Set the top device number used in the latch relay/step relay.	1) → 2 → Top number of L → GO → Top number of S→ GO → 2)
M, L, S setting (AnA, AnUCPU only)	Set the top device number used in the latch relay/step relay/internal relay.	1) \rightarrow 2 \rightarrow Top number of L \rightarrow GO \rightarrow Top number of S \rightarrow GO \rightarrow Top number of M \rightarrow GO \rightarrow 2)
Timer setting (other than AnACPU)	Set the top device used in the low speed/high speed/ retentive timers.	1) → 3 → Top number of timer → GO → 2)
Timer setting (AnACPU))	Set the number of timers used, the top device number that stores the setting value after T256, and the top device used in the low speed/highspeed/retentive timers.	1) → 3 → No. of timers → GO → Top device for storage of setting values Top number of timer → GO → 2)
Counter setting (AnACPU only)	Set the number of counters used, and the top device number that stores the setting value after C255.	1) → 4 → No. of counters → GO → Top device for storage → GO → 2) of setting values
Setting of latch range WDT setting	Set the range of the device for latch setting.	1) → 5 → Top number of latch → GO → 2) → END → END
WDT setting (other than AnA, AnU)	Set the value of the watchdog timer in the unit of 10 ms.	1) → 6 → WDT value → GO → 2) (input unit: 10 ms)
Setting of I/O control system (only for A3HCPU and A3MCPU)	Set the I/O control system.	1) → 7 → ♠ GO → 2)
Completion of setting (write)	When parameter setting is complete, write the PLC CPU.	2) Setting for multiple items is also available. CLEAR → END → ♠ GO (End of writing is displayed.)

4.6.7 Operation in other mode (O)

Details	Purpose	Procedures (key input sequence)
Error check	Operation that checks the error step number/error code for the current error in the ACPU. (other than AnA and AnUCPU)	SHIFT - OTHER 2 - 1 (Except AnA, AnUCPU) (AnA, AnUCPU)
Program check	Check the program(double coil, command code, END command).	SHIFT → OTHER → 2 → 2 → GO → Step number
Buffer memory batch monitoring	Monitor the buffer memory details of the special function unit.	SHIFT → OTHER → 3 → 1 → 2 → Y → Top I/O → SP number of unit H → Buffer memory → GO → ↑ → A address
Clock monitor	Monitor the clock data of the ACPU.	$\boxed{\text{SHIFT}} \rightarrow \boxed{\text{OTHER}} \rightarrow \boxed{3} \rightarrow \boxed{1} \rightarrow \boxed{3}$
Clearing of all PC memories	Clear all memories in the ACPU.	$\boxed{\text{SHIFT}} \rightarrow \boxed{\text{OTHER}} \rightarrow \boxed{3} \rightarrow \boxed{2} \rightarrow \boxed{60} \rightarrow \boxed{\uparrow} \rightarrow \boxed{60}$
Clearing of all programs	Clear all sequence program, microcomputer program and T/C setting value areas.	$\boxed{\text{SHIFT}} \rightarrow \boxed{\text{OTHER}} \rightarrow \boxed{3} \rightarrow \boxed{2} \rightarrow \boxed{4} \rightarrow \boxed{\text{GO}}$
Clearing of all device memories	Clear all details of the bit device and the word device in the ACPU.	$\boxed{\text{SHIFT}} \rightarrow \boxed{\text{OTHER}} \rightarrow \boxed{3} \rightarrow \boxed{2} \rightarrow \boxed{3} \rightarrow \boxed{4} \rightarrow \boxed{\text{GO}}$
PLC No. setting	Set the PLC No. of other stations for access on the MELSECNET II (/B) or MELSECNET/10.	SHIFT → OTHER → 3
Main/sub-program switching	Select the main/sub- program displayed on the list edit screen.	SHIFT - OTHER - 3 - 3 - 2 + FGO
Remote run/stop	Operate the run/stop status of the ACPU from the GOT.	SHIFT - OTHER - 3 - 4 - 1 F GO
Read/write of machine language	Specify the memory address (absolute address) of the ACPU. Read the memory details and write the machine language to the memory.	SHIFT → OTHER → 3 → 4 → 3 → SET → Address — GO → GO → (hexadecimal) — Machine — GO (hexadecimal) — GO → Ianguage code

4.7 Error Messages and Corrective Actions

4.7.1 Error messages and corrective actions in direct CPU connection


If an error is detected with the MELSEC-A list editor during operation of each mode, an error message appears at the 4th line of the display.

Error messages, display conditions and corrective actions are displayed below. If an error message appears, take the following actions to resume operation.

- Check the error message.
- 2 Remove the cause of the error.
- Input the corresponding key.

 (The error message disappears. The screen returns to the status before error.)

(Example)



Error message	Description	Corrective action
Address error	In machine language writing, the address which was tried to be written was at the write-protect area.	Set the correct address.
No corresponding program	The specified command was not found.	Check the program.
Memory cassette check	In communication with the CPU for clearing the keyword or writing the parameter, the memory cassette is insufficient or not mounted.	(1) Mount the memory cassette properly. (2) Replace the memory cassette with a new one.
Step over error	The set step number is larger than the maximum step number.	Set the correct step number.
Setting error	Setting value is not correct.	Set the correct value.
Not selectable	The function which cannot be executed was selected.	Select other function.
Operation error	The set device symbol is incorrect.	Perform the correct key operation.
Device error	The specified command was not found. The device number exceeds the range.	(1) Set the correct device symbol. (2) Set the number within the range of CPU device.
Identical coil	The identical coil is found in the sequence program.	Proceed to the next operation if it does not affect the control. Correct the program if it affects the control.
Command error	When the program is read, it cannot be converted to the proper command.	When the CPU has detected the error, stop running of the operation. After resetting the CPU, check the command around the error. Write the correct command. (For check of the error step, refer to 4.6.7.)
Command setting error	The command set at the time of read, write or insert is not correct.	Set the correct command.
Memory protect	When writing in the Write or the Insert/Delete mode, the memory protect switch in the memory cassette is ON.	Turn OFF the memory protect switch in the memory cassette.
Capacity over	Memory assignment set in the parameter exceeded the capacity of the memory cassette.	Set the parameter within the capacity of the memory cassette.
No END command	There is no END command.	Write the END command at the last step of the program.
PLC communication error	When the list editor function is started, proper communication with the PLC is not made.	Restart the list editor function. If communication is not made properly, check the following: (1) GOT main unit (2) Connection of the cable (3) CPU main unit (if any error has occurred)
PLC COMM ERROR PLEASE CLOSE	When the editor for MELSEC-A is started, proper communication with the CPU is not made.	Close and restart the editor for MELSEC-A. If communication is not made properly, check the following: (1) GOT main unit (2) Connection of the cable (3) CPU main unit
PC write error	Correct writing was not made in the Write or Insert mode.	(1) Check the setting of RAM/ROM.(2) Check the RAM mounting.(3) Check the setting of the memory protect switch in the CPU.
PLC is running	Writing, insertion or deletion was attempted during running of the CPU.	Stop the CPU.
PC No. error	The PLC number is set to other station.	Change the PLC number and set the station for access to the host.

(Continued to next page)

Error message	Description	Corrective action
**KS over	The value exceeding the range of the program capacity by **K steps was attempted to be set.	Reduce the program capacity by **K steps for setting.
**KP over	The value exceeding the range of the file register capacity by **K points was attempted to be set.	The value exceeding the range of the file register capacity by **K points was attempted to be set.
Not available for QnACPU. Set the PLC No.	The CPU at the list edit destination is QnACPU.	Set the PLC number and change the station for access.
The keyword is not input. Set the PLC No.	The "GO" key was pressed without input of the keyword on the keyword input screen.	Set the PLC number and change the station for list edit. Or select the same station and input the keyword.
The PLC parameter was changed. Read the ladder monitor again.	The PLC parameter exceeding the file (R) register capacity was set.	Restart the GOT system if required.
The PLC parameter was changed. Restart the GOT system.	The capacity of the file (R) register was set.	Read the ladder monitor on the PLC again if required.
The PLC program was edited. Read the ladder monitor again.	Edit the PLC program.	Read the ladder monitor on the PLC again if required.

4.7.2 PLC CPU error messages and troubleshooting

When the error step read in other mode is performed, the error message and the error step of the current error in the ACPU are displayed.

Error messages, error details and corrective actions are displayed below. If an error message appears, take the following actions to resume operation.

- Check the error message.
- If the error code is not displayed, check the error code of special register D9008 with the system monitor function (Refer to Chapter 2.).
- Remove the cause of the error.


(Display)

(1) Example of display for an error in the CPU other than AnA and AnU


```
Mode is displayed (other mode).

O ERR. STEP = 25
SP. UNIT DOWN
ERR. CODE = 41
Error message is displayed.
Error code is displayed (error code of D9008).
```

(2) Example of display for an error in the AnA or AnUCPU



(3) Example of next display for the display of "\u03b4" above (error history is available)





When an error message of the PLC CPU appears, refer to the ACPU programming manual (Common Command) and the user's manual for each CPU for corrective actions.

4.7.3 Error using list editor function on the link system

When the MELSEC-A list editor is used on the link system, the "PLC communication error (**)" may appear. In this case, check the error details and the corrective actions.

Error No.	Error message	Corrective action			
2	Time-out error: No response to the request	Check the cable wiring.			
4	Process cancel: New process request was given to the list editor function while the CPU is processing.	Perform correct key operations on the GOT.			
5	Sum check error: A sum check error from the link communication has occurred.	There may be noise interference. Check the system again.			
16	PLC No. error: There is no station corresponding to the PLC number.	Check the PLC number setting. Set the correct number.			
19	This error may occur when the ACPU is reset during monitoring.	Perform the monitor setting again.			
24	Remote error: Although remote stop/pause is performed from the computer link unit, remote run/stop is additionally performed.	Perform the remote run/stop/pause from either unit.			
25	Refer to the next page for error messages and actions. After confirming the device value explained at the next page with t	he system monitor function, take action.			
32	Link error: While the slave station is monitoring the master station, the master station is reset.	Perform the monitor setting again.			
34	EEPROM failure: The EEPROM, cannot be written due to EEPROM failure.	Replace the EEPROM with a new one.			

[Detailed description of error No. "25"]

If error number "25" appears, the following causes are possible. Check the details and the corrective actions.

(1) When connected to the master station

Device number	Description	Details					
M9210	Link card error (for master station)	OFF: Normal ON: Error	The control depends on whether there is an error at the hardware of the link card. The link card in the CPU link unit is judged at the CPU. Replace the link unit.				
M9224	Link status	OFF: Online ON: Offline, station-to- station test, or self- loopback test	The control depends on whether the master station itself is online or offline, or in the station-to-station mode or the self-loopback mode. Check the mode switch.				
M9227	Loop test status	OFF: Not executed ON: Forward loop test and reverse loop test are being executed.	The control depends on whether the master station itself is executing the forward loop test or the reverse loop test.				

(2) When connected to the local station

Device number	Description	Details					
M9211	Link card error (for local station)	OFF: Normal ON: Error	The control depends on whether there is an error at the hardware of the link card. The link card in the CPU link unit is judged at the CPU. Replace the link unit.				
M9240	Link status	OFF: Online ON: Offline, station-to- station test, or self- loopback test	The control depends on whether the local station itself is online or offline, or in the station-to-station mode or the self-loopback mode. Check the mode switch.				
M9257	Loop test status	OFF: Not executed ON: Forward loop test and reverse loop test are being executed.	The control depends on whether the local station itself is executing the forward loop test or the reverse loop test.				

(3) When connected to the CPU in MELSECNET/10

An error in the MELSECNET/10 is reported using a four digit (hexadecimal) error number. For details of the errors and corrective actions, see the MELSECNET/10 Network System Reference Manual.

If an error code not listed in the previous page is displayed, contact the nearest of our system service centers, agents, and branch offices.

5. MELSEC-FX LIST EDITOR



5.1 Features

The MELSEC-FX list editor enables you to change the sequence program in the FX PLC.

This function is intended to troubleshoot the PLC system and to streamline maintenance operations. By installing list editor for MELSEC-A, an Option OS, from GT Designer2 into the GOT, you can edit the FX PLC program.

The features of the MELSEC-FX list editor are described below.

1 Parameters and sequence programs are easy to maintain.

You can check or partly correct, change or add FX PLC CPU parameters and sequence programs simply by operating keys.

You can easily edit sequence programs without preparing any peripheral unit other than the GOT.

(Example of changing sequence program commands)




2 Combination with the ladder monitor





You can open the MELSEC-FX List Editor window from the Ladder Monitor screen with a single touch. You can edit PLC program while checking the ladder.


You can also display a list from the step line displayed by the ladder monitor.



5

3 Errors that occur during list editing can be checked easily.


Error messages, error codes, and number of steps for errors that occur in the FX PLC can be checked. Details can be checked immediately even for errors that occur during list editing.



4 Commands and devices can be searched and displayed.

Commands and devices used in sequence programs can be searched.

The correction position can be searched for cases such as when you want to correct a specific device.



Specifications 5.2

System configuration 5.2.1

This section describes the system configuration of the MELSEC-FX list editor. For further information about communication units and cables for each connection form, see the following.

F GOT1000 Series Connection Manual

Controllers that can be edited with the MELSEC-FX list editor

	Target controller	
FXCPU		

2 Connection forms

(C: Available, x: Unavailable)

Function name		Connection form between GOT and PLC							
Name	Description	Bus connection	Direct CPU connection	Computer link connection	link Ethernet connection		CC-Link connection		GOT multidrop connection
				COTTTECTION		connection	ID ^{*1}	G4 ^{*2}	
MELSEC- FX list editor	Sequence program writing, parameter setting, PLC diagnostics and keyword registration, etc.	×	0			×			×

^{*1} Indicates CC-Link connection (Intelligent device station).

3 Required option OS and option function board

The option OS and option function board shown below are required.

Option OS	OS memory space (user area)				Option function board				
	GT16								
	Built-in flash memory (ROM)	User memory (RAM)	GT15	GT11	GT10	GT16	GT15	GT11	GT10
MELSEC-FX list editor	542KB	1024KB	1058KB	0KB	Not required	Not required	GT15-FNB, GT15-QFNB, GT15- QFNB16M, GT15- QFNB32M, GT15- QFNB48M, GT15-MESB48M	GT11-50FNB	Not required

(1) Option OS

(a) For GT16, GT15, and GT11

Install the option OS in the above table to the GOT.

Refer to the following manual for the procedure for installing the option OS.

📝 GT Designer2 Version 🗆 Basic Operation/Data Transfer Manual (8. TRANSFERRING DATA)

^{*2} Indicates CC-Link connection (via G4).

(b) For GT10
Installing the option OS is not required.

(2) OS memory space

The available memory space shown in the table above is required in the user area to install the option OS to the GOT.

Refer to the following manual for the procedure for checking the available memory space of the user area and information about the data using other user areas.

GT Designer2 Version ☐ Basic Operation/Data Transfer Manual (8. TRANSFERRING DATA)

(3) Option function board

(a) For GT16 and GT10

No option function board is required.

(b) For GT15 and GT11

Mount one of the option function boards in the above table on the GOT.

For the GOTs with a built-in option function board, refer to the following.

1.1.2 Hardware and OS' required for each function

For how to mount an option function board on the GOT, refer to the following manual.

GT15 User's Manual (8.10 Option Function Board)

GT11 User's Manual (8.3 Option Function Board)

4 Functions list and monitor conditions

The following shows the memory that can be monitored by the MELSEC-FX list editor and the FX PLC status conditions.

(\bigcirc : Can be monitored \triangle : Can be monitored under certain conditions \times : Cannot be monitored)

			Memory that car	n be monitored *2			
Function		Built-in memory	RAM memory cassette	EEPROM memory cassette, flash memory cassette	EPROM memory cassette	FX PLC status	Reference
sequence programs	rograms earching commands/ evices	0	0	0	0	RUN/ STOP	Section 5.4.3 Section 5.4.4
sequence C	nds	0	0	△*1	×	For Stop only	Section 5.4.5 Section 5.4.6 Section 5.4.5 Section 5.4.7 Section 5.4.7
PLC diagnostics Display		0	0	0	0	RUN/ STOP	Section 5.4.9
Parameter setting		0	0	△*1	×	For Stop only	Section 5.4.10
Keyword	·	0	0	0	0	RUN/ STOP	Section 5.4.11

- *1 The operation is available only when the protect switch is OFF.
- *2 The available memory differs depending on the FX PLC being used. For further information, see the following manual.

The hardware manual of the FX PLC being used

5.2.2 Access range

The access range is the same as the access range when the GOT is connected to a controller. Refer to the following manual for details of the access range.

GT Designer2 Version ☐ Screen Design Manual (2.7 Controllers that can be monitored and the Access Range)

5.2.3 Precautions

(1) Inapplicable GOT

The FX list editor function cannot be used with the GT1030 and GT1020.

(2) Using other peripheral equipment for sequence program/parameter change When using the MELSEC-FX list editor, do not change programs or parameters in the PLC CPU from other peripheral equipment.

If you make a change, temporarily exit the MELSEC-FX list editor after the change is made, then start the MELSEC-FX list editor again.

If you carelessly change the program on one PLC from multiple units of peripheral equipment (including GOT), the contents of the program in the PLC CPU and the peripheral equipment may not be the same, resulting in an unintended operation of the PLC CPU.

(3) Sequence program change

Stop the FX PLC before changing (writing, inserting, deleting) a sequence program or changing parameters.

Operation is not possible with the FX PLC running.

(4) If you press the GO key but the system does not proceed to the next operation (for example, a search)

Check the input contents (applied instruction number, device value, etc.).

(5) When used together with the ladder monitor

Even if you execute the MELSEC-FX list editor with the ladder monitor activated, edited information will not be reflected on the Ladder Monitor screen.

To reflect such edited information, perform the PLC reading of the ladder monitor again.

(6) When using list monitor


Only devices to be used for basic instructions can be monitored.

The status of devices (word, bit) to be used for application instructions cannot be monitored.

5.3 Display

1 Outline until the start

This subsection describes an outline until the system monitor screen is displayed after List editor for MEL-SEC-FX (Option OS) is installed in the GOT.



Point P

(1) How to display the utility

For how to display the utility, refer to the following.

GT16 User's manual (Basic Utility) (1.3 Utility Display)

GT15 User's manual (9.3 Utility Display)

GT11 User's manual (9.3 Utility Display)

GT10 User's manual (8.2 Utility Display)

(2) Displaying communication setting window

After turning on the GOT, the communication setting window is displayed at the first startup of the MELSEC-FX list editor only.


For displaying the communication setting window at the second or later startup, touch [ChNo.] on the MELSEC-FX list editor screen. (5.4 Operation Method)

(3) If the project data has not been downloaded

The MELSEC-FX list editor can be started from the utility even if the project data has not been downloaded to the GOT.

2 Change screens

This section describes how to change the screen.



With setting special function switches (FX list monitor), the list monitor can be started on the monitor screen. When the list monitor is started on the monitor screen, the list editor cannot be used. For how to set special function switches, refer to the following manual.

GT Designer2 Version Screen Design Manual (6.2 Touch Switch)

5.4 Operation Procedures


This section describes the contents of the MELSEC-FX list editor and the key functions displayed on the screen.

The display screen of the MELSEC-FX list editor varies slightly with the GOT used. This chapter mainly uses the screen of the GT1575-V for explanation.

5.4.1 Key arrangement and a list of key functions

The arrangement and functions of the keys displayed on the MELSEC-FX List Editor window are described below.

1 Displayed contents



No.	Item	Description
	Channel No.	Displays the currently selected channel number.
1)	निर्वि निर्वि	Touching "ChNo." displays the communication setting window. The communication setting window is not displayed if the MELSEC-FX list editor is started from the ladder monitor.
2)	2) Mode	Displays a mode for MELSEC-FX list editor. (🛒 5.4.2 Selection and operation of modes)
2)		[Monitor] is displayed when the list monitor is executed.(Section 5.4.12 List monitor)
3)	Error message	Displays the contents of errors that occur with the MELSEC-FX list editor.
	Life incasage	(5.5 Error Messages and Corrective Action)
4)	List display area	Displays the sequence program in list format (12 digits).
	z.o. a.op.ay aroa	The position (line) that can be edited is displayed with a bar.
5)	Key area	Displays the keys that can be used with the MELSEC-FX list editor.

2 Key functions


The table below shows the functions of the keys that are used for the operation on the MELSEC-FX list editor screen.

Key	Function
ChNo.[1]	Displays the communication setting window. The communication setting window is not displayed if the MELSEC-FX list editor is started from the ladder monitor.
MODE	Selects a mode for MELSEC-FX list editor. (5.4.2 Selection and operation of modes)
OP	Displays the PLC diagnostics, parameter setting, and keyword selection menu.
MORE	Switches between command keyboard 1 and command keyboard 2. ([] 3 "Keyboard switching" in this section)
CLR	When inputting commands: Cancels the key input when only part of the command has been input. (
SP	Space key. This key is used when setting timers and counters, writing applied commands, etc.
STEP	Displays the list from a specified step No. when the step No. is input.
	Moves the list display area bar up and down and switches the line being edited.
60	Determines the key operation.
LD to INV ,	Inputs commands, device names, etc. The key contents depend on the input contents. The commands that can be used differ depending on the target FX PLC. Refer to the manual for the FX PLC to be used.
×	Exits the MELSEC-FX list editor.

3 Keyboard switching

Touching the MORE button switches the command keyboard 1 and command keyboard 2.

When you touch the button for a keyboard function, the optimum keyboard for input for that function is displayed automatically.



5.4.2 Selection and operation of modes

The MELSEC-FX list editor has four modes: READ, WRITE, INSERT, and DELETE.


Select an appropriate mode for the intended operation.

For more information on the mode to select, refer to the function operations from subsection 5.4.3 onward.

1 How to change modes

Touch the MODE button.

Each time you touch this button, the mode changes.



2 In the case the mode cannot be changed

In the following cases, only READ mode is allowed.

If you try to change to other than READ mode, an error message is displayed.

To change to other than READ mode, take the action below.

Error Message	Description	Corrective action
PLC is running	The FX PLC is in the RUN status.	Stop the FX PLC.
Can not write.	The protect switch of the EEPROM memory cassette is on.	Switch off the protect switch of the EEPROM memory cassette.
Carriot write.	The EPROM memory cassette is enabled.	Set a memory other than EPROM as the memory to write to.

5.4.3 Sequence program display

Sequence programs are read from the FX PLC to the GOT and displayed.

There are two displaying methods: specifying the step number, and scrolling one screen at a time.


1 Display using cursor keys

(1) Operation

Scroll with a or

(2) Example

Scroll one line upward or downward.




2 Display specifying the step number

(1) Operation

(2) Example

Displaying step number 123.





When the specified step number is the operand of an applied instruction

If the specified step number is a timer (T) or counter (C) set value or the operand of an applied instruction, that command section is displayed at the head.


3 Display scrolling one screen at a time

(1) Operation



(2) Example

Displaying with scrolling one screen at a time.



5.4.4 Searching commands and devices

Displays a command or device by searching it in sequence program from Step 0.


1 Command search

(1) Operation

*1 If the command you want to search for is not on the keyboard, touch the MORE key to switch to the other keyboard. When searching for an applied instruction, touch the FNC key and input the applied instruction number. When searching for a label, touch P or 1 and input the pointer number.

- *2 Input only when searching for commands requiring a device name and device number.
- *3 After the search results are displayed, you can continue searching with the same conditions by touching the GO key. Touching any key other than the GO key ends the search.

(2) Example Searching for LD M8000





Pointer (P, I) searches

For pointer searches, only labels are searched.

Pointers specified as operands in applied instructions are not searched.


2 Device search

(1) Operation

*1 After the search results are displayed, you can continue searching with the same conditions by touching the GO key.

Touching any key other than the GO key ends the search.

(2) Example Searching for LD M8000





Devices that cannot be searched

The following devices cannot be searched.

- · Pointers, interrupt pointers
- · Constant K, constant H, constant E
- · Bit devices with specifying numbers only
- · Special function unit/block buffer memory
- · Devices specified with the operand of an applied instruction

Pointers and interrupt pointers can be searched for with command searches.

("Command search" in this section)

5.4.5 Writing commands

Writes a sequence program to the FX PLC. (Overwrite/Insert)

1 Writing basic commands

- (1) Operations
 - (a) Inputting command only (Ex.: ANB, ORB command etc.)

```
Stop the FX PLC | — MODE Input the command GO

For overwriting: (WRITE mode)
For insertion: (INSERT mode)
```

(b) Inputting command and device (LD, AND commands etc.)

(c) Inputting command, No. 1 device, No. 2 device (MC, OUT (T, C) commands, etc.)




Moving the cursor to the position to write the command

When starting to write a command, place the cursor on the command line (the line on which the step number is displayed).


You cannot write a command with the cursor on an operand or set value line.

2 LDI	М	100		Command line (Place the cursor on this line.)
3 MOV			12	
	D	0		
	D	10		Operand, set value line (Cannot operate on this line.)


- (2) Example
 - (a) Writing ORB command



(b) Inputting LD X000



(c) Inputting OUT T100 K19



2 Writing applied instructions

(1) Operations

^{*2} When a command specifies multiple devices for operations, input the SP key followed by the device name and device number.



(1) Moving the cursor to the position to write the command

When starting to write a command, place the cursor on the command line (the line on which the step number is displayed).

You cannot write a command with the cursor on any other line.


2	LDI		М	100		Command line (Place the cursor on this line.)
3	MOV				12	Continuand line (Flace the cursor on this line.)
		D		0		
		D		10		Operand, set value line (Cannot operate on this line.)

(1) Commands using a text string constant for a command operand (such as ASC command)

With the MELSEC-FX list editor, text string constants cannot be written as operands. (such as ASC commands)

Use GX Developer for writing such commands.

(2) Example Input "DMOVP D0 D2".



^{*1} The MOV command is FNC12.

^{*1} D (double word command) and P (pulse execution format command) can also be input after the applied instruction number is input. Inputting in the order P → D is also possible.

5.4.6 Changing operands, set values

Changes the operand section of an applied instruction and OUT (T, C) command set value.

1 Operation

*1 For decimal numbers, input K, then the number.


For hexadecimal numbers, input H, then the number.



Moving the cursor to the line on which the operand or set value is to be changed


When starting to change an operand or a set value, place the cursor on the line of the operand or set value to be changed (the line on which the step number is not displayed).

If you place the cursor on the command line, the input operation is not possible.



2 Example

Changing "MOV D0 D10" to "MOV D0 D123"



5.4.7 Deleting commands

Deletes one command at a time from a sequence program.

1 Operation



When moving the cursor to the position where the command is to be deleted.


Place the cursor on the command line (the line on which the step number is displayed).

You cannot delete the command if the cursor is placed on the line of an operand or set value.

2 LD	N	l 100		Command line (Place the cursor on this line.)
3 MC	V		12	J
	D	0		1)
	D	10		Operand, set value line (Cannot operate on this line.

2 Example

Deleting "OUT T10 K100"




5.4.8 Sequence program all clear

Clears all the sequence programs.

1 Operation

2 Example

Clears all the sequence programs.





Items cleared when All Clear for a sequence program is performed

When All Clear is executed, the parameters before program execution are initialized and Latch Clear is executed.


The memory space becomes the default value, the comment area a 0 block, the file register space a 0 block, and keywords unregistered.

After All Clear, set the above parameters etc. again.

5.4.9 PLC diagnostics

Displays the FX PLC error message, error code, and step at which the error occurred.


1 Operation



2 PLC diagnostics screen

The following describes the contents displayed on the PLC diagnostics screen and the function of onscreen key.

(1) Displayed contents



No.	Item Display contents			
1)	Error message	Displays the error message. (I/O configuration error/PLC hardware error/PC/HPP communication error/Serial communication error/Parameter error/Syntax error/Circuit error/Operation error)		
2)	Detail	Displays the error code.		
3)	Step	Displays the step number in the sequence program at which the error occurred. (This is displayed only for a syntax error, circuit error, or operation error.)		



Error details

For details on an FX PLC error, refer to the manual below.

Programming manual for the FX CPU used

(2) Key functions

The table below shows the functions of the keys that are used for the operation on the PLC diagnostics screen.

Key	Function
X	Exits the PLC diagnostics.

5.4.10 Parameter setting

Sets FX PLC parameters.

1 Parameters that can be changed and change targets

(1) Parameters that can be changed

The parameters that can be changed with the MELSEC-FX list editor and the target FX PLCs are as follows.

(○: Can be set/changed X: Cannot be set/changed)


	Target CPU									
Item	FX0(S) /FX0N	FX1	FX2(C)	FX1S	FX1N(C)	FX2N(C)	FX3G	FX3U(C)		
Memory space setting	×	0	0	×	×	0	0	0		
File register space setting	o ^{*1}	×	0	0	0	0	0	0		
Latch range setting	×*2	0	0	×*2	×*2	0	×	0		
RUN terminal setting	×	×	×	0	0	0	0	0		
Initialization of parameters	0	0	0	0	0	0	0	0		

^{*1} When connecting an FX0(S), set "0". Setting other than "0" causes a parameter error.

(2) Change targets

When a memory cassette is mounted, the parameters in the memory cassette are targeted for changes.

2 Operation




^{*1} When checking parameters (not changing), it is not necessary to stop the PLC.

^{*2} When the parameters are initialized, the display on the MELSEC-FX list editor is different from the FX PLC default values, but do not change the latch range. Changing the latch range causes an error.

3 Parameter setting screen

The following describes the contents displayed on the PLC diagnostics screen and the function of onscreen keys.

(1) Displayed contents



No.	Item	Display contents
1)	Memory capacity	Sets the memory space (number of steps). If you touch the *K section, you can change the memory space.
2)	File reg. capacity	Sets the memory space (number of blocks) allocated to the file register. Touch the □ section and input the number of blocks.
3)	Latch range	Sets the latch range (power failure hold area). Touch the number display section and input the value.
4)	RUN terminal input	Sets whether or not to use one of the FX PLC input terminals for RUN input. Touch the □ section and set the device to be set for the RUN terminal.
5)	Default	Initializes the parameters



Memory space for kana comments after changing memory space, file register space

If the memory space is set smaller than the total of the file register space and kana comment space, the kana comment space is automatically reduced.

(With the MELSEC-FX list editor, the kana comment space is not displayed.)

Note that if any setting as described below is made, the kana comment space is reduced.

(Settings that reduce kana comment space and the kana comment space after setting change)

Settings resulting in Nm < Nf \times 500 + Nk \times 500 + 500

Kana comment space (steps) after setting change =
$$\frac{\text{Nm - Nf x 500 - 500}}{\text{500}}$$

Nm: Memory space after change (steps)

Nf: File register space after change (blocks)

Nk: Comment space before change (blocks)



Settable range and default value

The settable range and the default value depend on the FX PLC type.

Refer to the following manual for details of the settable range and the default value.

Programming manual for the FX PLC used

(2) Key functions

The table below shows the functions of the keys that are used for the operation on the parameter setting screen.

Key	Function
Default	Initializes the parameters
OK	Completes the changed setting contents.
×	Ends parameter setting.

5.4.11 Keywords

Registers, deletes, releases protection for, and sets protection for the FX PLC keywords.

Function usability of the MELSEC-FX list editor for keyword protection levels


The functions that can be used with the MELSEC-FX list editor depend on the keyword protection level.

(O: Available, X: Unavailable)

			Keyword protection level						
	Function	All operation protect (All on-line operation protect) *2	(All on-line operation (Read/write protect)		Keyword not registered/keyword protection canceled	Reference			
Reading	Displaying sequence programs	×	×	0	0	5.4.3			
sequence programs	Searching commands/ devices	×	×	0	0	5.4.4			
Writing	Writing commands	×	×	×	0	5.4.5			
sequence programs	Changing operands/set values	×	×	×	0	5.4.6			
Inserting com	mands	×	×	×	0	5.4.5			
Deleting comr	g commands ×		×	×	0	5.4.7			
Sequence program all clear		×	×	×	0	5.4.8			
PLC diagnostics		O*1	0	0	0	5.4.9			
Parameter set	tting	×	×	×	0	5.4.10			

^{*1} When the 2nd keyword is set to an FX PLC that supports 2nd keyword, it becomes "X" (cannot be used).

2 Operation



^{*2} The names within the parentheses () are for when a keyword + 2nd keyword is set.

3 Keyword screen and protection level

When [Keyword setup] is selected with the MELSEC-FX list editor, the keyword screen is displayed. Refer to the following manual for the procedure for keyword operations.

GT16 User's Manual (Basic Utility) (3.2.3 Display contents of communication detail setting)

GT15 User's Manual (10.2.3 Display contents of communication detail settings) GT11 User's Manual (10.2.3 Display contents of communication detail settings) GT10 User's Manual (11.4 Keyword)



Keywords

Refer to the following manual for details of keyword.


Programming manual for the FX PLC used


Q MOTION MONITOR

5.4.12 List monitor

The status of contacts and coils in a sequence program is displayed.

1 Operation





When the list monitor is started on the FX list editor screen, the step numbers displayed on the FX list editor screen is displayed on the list monitor screen.




Starting list monitor with special function switches (FX list monitor)

With setting special function switches (FX list monitor), the list monitor can be started on the monitor screen.

When the list monitor is started on the monitor screen, the list editor cannot be used. For how to set special function switches, refer to the following manual.

2 Displays and key functions

The following describes the displays for the list monitor.



No.	Item	Display contents
1)	List display area ^{*1}	The status of contacts and coils is displayed on the left of device displays.
2)	Keys	The same operations as in the READ mode of the FX list editor can be executed. Section 5.4.3 Sequence program display
3)	×	Ends the list monitor. When the list monitor is executed on the FX list editor screen, the screen is switched to the FX list editor screen.

*1 The status of contacts and coils is displayed as below.

	5	Status			
Type of instructio	Description	■ Displayed	Not displayed		
LD, AND, ORC(ontact instruction (Normal open))	Contact	ON	OFF		
LDI, ANI, ORI(Contact instruction (Normal close))	Contact	OFF	ON		
OUT, SET	TC: Coil	ON	OFF		
001, 321	Except TC: Contact	ON	OFF		
	TC: Reset	ON	OFF		
RST	Word device	Value: 0	Value: Except 0		
	Except TC and word device: Contac	OFF	ON		
MC, STL	Contact	ON	OFF		
LDP, ANDP, ORP, LDF, ANDF, ORF (Rise or fall contact instruction)	Not monitored	Always ■ r	not displayed		

5.4.13 Hard copy output



Screens of the MELSEC-FX list editor can be stored to a memory card in BMP/JPEG file format or printed with a printer.

Refer to the following for the hard copy.

- Starting the MELSEC-FX list editor from the ladder monitor (3.4.2 Hard copy output)
- Setting the hard copy with GT Designer2

GT Designer2 Version Screen Design Manual (Section 13.2 Hard Copy)

5.4.14 Action for an incorrect key input

If an incorrect key is input, cancel the input contents.

1 Operation

- (1) Before touching the GO key (before reading/writing the input contents) Before touching the GO key, touch the CLR key.
- (2) After touching the GO key (after reading/writing the input contents) Write the command again. (5 5.4.5 Writing commands) Commands finalized by writing and inserting operations are revised (overwritten) with the program writing.

5.5 Error Messages and Corrective Actions

This section describes the error messages displayed when the MELSEC-FX list editor is executed, and corrective action.

Error Messeage	Description	Corrective action
Can not display while protected. Can not operate while protected.	The all-operation protect, anti-plagiarism, or incorrect write protect keyword is set.	Check the protected operation. Clear the keyword protection or delete the keyword. Section 5.4.11 Keywords
PLC parameter error.	An FX PLC parameter is defective.	Set correct parameters in the FX PLC.
PLC communications error.	The communication with the FX PLC is defective.	Check the FX PLC, cable, and GOT for abnormality. Check whether the communication settings are correct or not.
PLC is running.	A writing operation etc. has been made while the FX PLC is running.	Stop the FX PLC.
Can not write.	The memory to write to is EPROM. The protect switch of the EEPROM is on.	Set other than EPROM for the memory to write to. Switch off the protect switch of the EEPROM.
Step number is out of a range.	The specified step number exceeded the maximum number.	Specify a step number below the maximum value.
Not found.	The specified command cannot be found.	Proceed to the next operation.
Not found.	The specified device cannot be found.	Proceed to the next operation.
Step overflow.	The program may exceed the available space. (Writing is not executed.)	Check the program memory space and delete commands to keep it within the space. Section 5.4.7 Deleting commands
Command error.	An invalid command (non-existent command) was specified.	Input the correct command.



How to erase an error message

An error message is not erased even if the cause of the error is eliminated. To erase an error message, touch a key on the MELSEC-FX list editor screen.

IVIEIVIO			

6. INTELLIGENT MODULE MONITOR











6.1 Features

With the intelligent module monitor, you can use dedicated screens to monitor the buffer memory of the intelligent function module and make changes to the data.

In addition, you can monitor the signal statuses of the I/O modules.

The features of the intelligent module monitor are described below.

1 Realized monitoring with dedicated screens

You can monitor the intelligent function module(s) and I/O module(s) and make changes to the data using dedicated screens.

There is no need to create screens for monitoring or data changes, thereby reducing the drawing workload.

(1) For intelligent function module

As a menu of monitor items is displayed, select an item from the menu, and the corresponding monitor screen is then displayed.

Details of the buffer memory and the I/O signal statuses between the buffer memory and the PLC CPU are displayed in text, numerical values, and graphs on the monitor screens.

Select a monitor from the menu



Select a menu


Monitor screen



(2) For I/O module

The status of I/O signals to and from an external module is monitored.

Monitor screen



2 Enabled data change by write operations

The values are written into the buffer memory of the intelligent function module by writing values from the monitor screen.

(Writing example)










3 Enabled project data reusing for the intelligent module monitor

Intelligent module monitor data is saved in the following directory in a personal computer with GT Designer2 installed. (Saved as a G1 file)

Select writing

Because the following data can be edited with GT Designer2, you can use part of the data for project data. (It is recommended that you copy the data to prevent accidental deletion of the data.)



6.2 Specifications

6.2.1 System configuration

This section describes the system configuration of the intelligent module monitor.

For connection type settings and precautions regarding the communication unit/cable and connection type, see the following manual.

GOT1000 Series Connection Manual

1 Targeted equipments for the intelligent module monitor

(1) PLC CPU

PLC
QCPU (Q mode), motion controller (Q series)*1
QSCPU
QnACPU*2
ACPU/QCPU (A mode)

^{*1} For the motion controller CPU (Q series), only the PLC CPU area (CPU No.1) in the Q170MCPU can be monitored.

(2) Intelligent module

For QCPU (A mode)), QnACPU, and ACPU	For QCPU (Q mode)			
A62DA-S1,	A68AD,	Q64AD,	Q68ADV,		
A68ADN,	A68RD,	Q68ADI,	QD62,		
A84AD,	A616AD,	Q64DA,	Q62DA,		
A616TD,	A616DAV,	QD62D,	QD62E,		
A616DAI,	A61LS,	QD75D,	QD75P,		
A62LS,	AD61,	QD75MH,	QD75M,		
AD70,	AD70D,	Output module,	Input module,		
AD71,	AD72,				
A1SD71,	A1SD61,				
A1S64AD,	A1S62DA,				
A1SD70,	A1S62RD,				
A1SJ71PT32-S3,	A1S63ADA,				
AJ71PT32-S3,	AD75P*1,				
A1SD75P*2,	AJ71ID1-R4,				
AJ71ID2-R4	A1SJ71ID1-R4,				
A1SJ71ID2-R4,	A1S68DAV,				
A1S68DAI,	A1S68AD,				
A1S64TCTT(BW)-S1,	A1S64TCRT(BW)-S1				
Input module,	Output module,				

^{*1:} AD75M1 (M2/M3) can be monitored in the range of AD75P1 (P2/P3).

You can use the system monitor [BM MONITOR] to monitor intelligent function modules other than those listed above.

^{*2:} You cannot use Q4ARCPU.

^{*2:} A1SD75M1 (M2/M3) can be monitored in the range of A1SD75P1 (P2/P3).

2 Connection type

(○: Available, ×: Unavailable)

	Function	Connection type between GOT and PLC CPU								
	Description	Bus Direct CPU connection*5 connection*5	Com	Computer	F 4b 4	MELSEC NET/H		CC-Link connection		GOT multidrop connection
Name			link connection*5	Ethernet connection	connection, MELSEC NET/10 connection	CC-Link IE ^{*2}	ID*3*5	G4 ^{*4*5}		
Intelligent module monitor	Monitors buffer memory of intelligent function module and signal statuses of I/O modules	0	0	0	0	△*1	0	0	0	×

- For the MELSECNET/10 connection, use a QCPU and network module (QJ71LP21, QJ71LP21-25, QJ71LP21S-25, and QJ71BR11) with the function version B or later.
- *2 Indicates the CC-Link IE controller network connection.
- *3 Indicates CC-Link connection (Intelligent device station).
- Indicates CC-Link connection (via G4).
- The QSCPU does not support the connection type.

Required option OS and option function board

The option OS and option function board shown below are required.

	OS memory space (user area)			Option function board			
Option OS	GT16						
Орион ОЗ	Built-in flash memory (ROM)	User memory (RAM)	GT15	GT16	GT15		
Intelligent module monitor	390KB	770KB	384KB	Not required	GT15-FNB, GT15-QFNB16M, GT15-QFNB48M,	GT15-QFNB, GT15-QFNB32M, GT15-MESB48M	

(1) Option OS

Install the option OS in the above table to the GOT.

Refer to the following manual for the procedure for installing the option OS.

GT Designer2 Version 🗆 Basic Operation/Data Transfer Manual (8. TRANSFERRING DATA)

(2) OS memory space

The available memory space shown in the table above is required in the user area to install the option OS to the GOT.

Refer to the following manual for the procedure for checking the available memory space of the user area and information about the data using other user areas.

GT Designer2 Version ☐ Basic Operation/Data Transfer Manual (8. TRANSFERRING DATA)

(3) Option function board

(a) For GT16

No option function board is required.

(b) For GT15

Mount one of the option function boards in the above table on the GOT. For the GOTs with a built-in option function board, refer to the following.

1.1.2 Hardware and OS' required for each function

For how to mount an option function board on the GOT, refer to the following manual.

GT15 User's Manual (8.10 Option Function Board)

4 Required memory space for use of the intelligent module monitor

The memory space of the intelligent module monitor data is indicated below.

The memory space required for storing data into the internal memory of the GOT is the same as the memory space required for storing data into the hard disk of a personal computer.

For QCPU (A mode), QnACPU, and ACPU			For QCPU (Q mode)			
Stored	l screen data	Memory space (KB)	Stored screen data		Memory space (KB)	
Intelligent module	monitor data common	21.0	Intelligent module monitor data common			13.4
information				ormation		10.1
1 to 2	"A62DA-S1"	7.2		400 to 402	"Q68ADV/Q68ADI/ Q64AD"	19.7
3 to 5	"A68AD"	11.0		403 to 405	"Q62DA/Q64DA"	14.1
6 to 8	"A68ADN"	17.4		406 to 407	"QD62D/QD62E/ QD62"	17.7
9 to 11	"A68RD"	19.0		408 to 430	"QD75P/QD75D"	572.8
12 to 15	"A84AD"	21.8		431 to 467	"QD75M"	454
16 to 34	"A616AD"	136.6		1001 to 1031	"QD75MH"	427.3
35 to 62	"A616TD"	254.1		Input module		0.0
63 to 65	"A616DAV"	18.1 ^{*3}		Output module		0.0
66 to 68	"A616DAI"	17.6 ^{*3}			-	-
69 to 70	"A61LS"	15.6			-	-
71 to 75	"A62LS"	79.0			-	-
76	"AD61"	8.4			-	-
77 to 79	"AD70"	22.2			-	-
80 to 83	"AD70D"	31.9			=	-
84 to 108	"AD71"	662.5			-	-
109 to 133	"AD72 (A1SD71)"	665.5			=	-
134 to 139	"AJ71PT32-S3"	47.2			-	-
146 to 150	"A1SD61"	40.8			-	-
151 to 153	"A1S64AD"	13.8			-	-
154	"A1S62DA"	5.6			-	-
155 to 157	"A1SD70"	22.9			-	-
158 to 160	"A1S62RD"	13.3			-	-
161 to 166	"A1SJ71PT32-S3"	46.9			-	-
167 to 169	"A1S63ADA"	18.1			-	-
170 to 206	"AD75P ^{*1} "	621.7			-	-
207 to 210	"AJ71ID ^{*2} "	43.8			-	-
211 to 213	"A1S68DAV"	13.3 ^{*3}			-	-
214 to 216	"A1S68DAI"	13.2 ^{*3}			-	-
217 to 219	"A1S68AD"	10.6			-	-
220 to 225	"A1S64TCTT/RT-S1"	52.7			-	-
Input module		0.0			-	-
Output module	e	0.0			-	-

^{*1} Use the screen for AD75P to monitor A1SD75P.

^{*2} Use the screen for AJ71ID to monitor A1SJ71ID.

^{*3} Downloading any of these enables monitoring both intelligent function modules.

6.2.2 Access range

When using bus connection/direct CPU connection/computer link connection

- The intelligent module monitor can monitor intelligent function modules on the bases of the connected station and other stations.
- · The intelligent module monitor can only monitor systems of the following combinations when computer link connection is applied.

PLC CPU used	Computer link/serial communication module used ^{*1}
QCPU (Q mode)	QJ71C24
QCPU (A mode)	A1SJ71UC24
QnACPU	AJ71QC24, A1SJ71QC24
ACPU	AJ71UC24, A1SJ71UC24
	AJ71C24-S8, A1SJ71C24, A1SCPUC24-R2, A2CCPUC24

For details of module names, refer to the GOT1000 Series Connection Manual.

- The following restrictions apply when monitoring other stations of MELSECNET/II data link systems. Only the host and master stations can be monitored when the connected station is a local station. Regardless of the type of connected station, no stations other than ACPU can be monitored.
- When connected to a remote I/O station on the MELSECNET/H network system, the remote I/O station on the MELSECNET/H network system is displayed as QCPU in the system configuration display of the intelligent module monitor.
- A diagnosis of the remote I/O station on the MELSECNET/H network system is not performed.
- Intelligent function modules on the base of remote I/O stations other than those on the MELSECNET/ H network system are not monitored.

When using MELSECNET/H, MELSECNET/10, or CC-Link IE controller network connection

- The intelligent module monitor can monitor intelligent function modules on the bases of the control station and normal stations.
- To monitor another network, routing parameters have to be set to the GOT side and PLC side. (Only with the MELSECNET/H communication unit or CC-Link IE controller network communication unit) For routing paramater setting, refer to the following manuals.

Routing parameter setting for the GOT

GOT1000 Series Connection Manual (6.2 Preparatory Procedures for Monitoring)

Routing parameter setting for PLC CPU

For MELSECNET/H communication unit

GOD Corresponding MELSECNET/H Network System Reference Manual (PLC to PLC network)

For CC-Link IE controller network communication unit

CC-Link IE Controller Network Reference Manual

3 When using CC-Link connection (Intelligent device station/via G4)

 The intelligent module monitor can monitor intelligent function modules on the bases of the master station and local stations.

4 When using Ethernet connection

 The intelligent module monitor can monitor the intelligent function module on the base of the PLC CPU assigned the IP address.

(The station assigned in the Ethernet setting of GT Designer2 can be monitored.)

To monitor another network, routing parameters have to be set to the GOT side and PLC side.
 For routing parameter setting, refer to the following manuals.
 Routing parameter setting for the GOT

GOT1000 Series Connection Manual (6.2 Preparatory Procedures for Monitoring)
Routing parameter setting for PLC CPU

Q Corresponding MELSECNET/H Network System Reference Manual (PLC to PLC network)

- When the intelligent module monitor monitors the master station of the MELSECNET/ II network on which any remote I/O station exists
 - Be sure to assign I/O when the master station is AnN or AnACPU.
 If I/O is not assigned, the system configuration of the intelligent module monitor will not be displayed correctly.
 - Intelligent function modules on the base of remote I/O stations are not monitored.
- 6 With Universal model QCPU

With Universal model QCPU, the GOT can monitor up to 64 stations.

6.2.3 Precautions

1 Inapplicable GOT

The intelligent module monitor function cannot be used with the GT1555-Q and GT1550-Q.

2 Special function modules that cannot be monitored

Modules displayed as "SP" on the System Configuration screen cannot be monitored using the intelligent module monitor.

To monitor these modules, use the system monitor function [BM MONITOR].

3 Display when connecting the small building-block type CPU

This precaution pertains to a situation where an extension base unit for a large building block type is connected to a small building-block type CPU (such as the A1SCPU) in the station connected to the GOT.

In this case, the intelligent function module on the large extension base unit is displayed on the System Configuration screen with the model name of the same type of the small building-block type intelligent function module.

If there is no small building-block type intelligent function module, "SP" is displayed and the object module cannot be monitored.

(Example)

Installed module Model name displayed

AD72 → A1SD71 AJ71ID → A1SJ71ID AJ71PT32-S3 → A1SJ71PT32-S3 AD75P → A1SD75P

A68ADN [CH1 to CH8] \rightarrow A1S64AD [CH1 to CH4] A68RD [CH1 to CH8] \rightarrow A1S62RD [CH1 to CH2]

4 Monitoring intelligent function modules with restrictions

(1) When monitoring AD71 (S1, S2, S7)
When the previous slot of the AD71 module is an empty slot, monitoring is performed in the

- (a) The AD71 is treated as the AD72, and "AD72" is displayed on the System Configuration screen.
 - In this case, select "AD72" that corresponds to the actual installed position.
- (b) The monitor screen that displays as shown (a) above is a screen for the AD72. The number obtained by subtracting 10_H from the I/O signal number on the display is the number for when installing the AD71 in slot 0.
 - * To prevent the AD71 from being treated as the AD72, execute "Shift the installation position of AD71 forward" or "In the I/O assignments, assign 16 points to the previous empty slot of the AD71".

(2) When monitoring the A68AD, A68ADN, or A68RD used with a small building-block type PLC CPU The GOT recognizes the intelligent function module installed in a large building-block type extension base unit connected to a small building-block type PLC CPU (e.g. A1SCPU) as a small building-block type intelligent function module to monitor it.

Hence, there are the following precautions for the A68AD, A68ADN, and A68RD.

Intelligent function module	Precautions
A68AD	The A68AD cannot be displayed correctly because the buffer memory configuration differs between the A68AD and A1S68AD.
A68ADN	Among CH1 to CH8 of the A68ADN, CH5 to CH8 cannot be displayed because the A1S64AD has only CH1 to CH4.
A68RD	Among CH1 to CH8 of the A68RD, CH3 to CH8 cannot be displayed because the A1S62RD has only CH1 to CH2.

The above intelligent function modules can be monitored properly if they are installed in a base unit connected to a large building block type PLC CPU (e.g. AnUCPU).

- (3) When monitoring the A1SD75M, AD75M Displayed as A1SD75P or AD75P when the A1SD75M or AD75M is installed. The A1SD75M or AD75M can be monitored within the monitoring range of the A1SD75P or AD75P.
- (4) When monitoring the A81CPU

 The A81CPU is monitored in the following way.

Item	64 points in first half	64 points in last half	
Treatment of	Treated as a module that cannot be	Treated as an input module	
A81CPU	monitored.	Treated as an input module.	
System	Displayer #0s a sigl X X ¹ 3#	Display Bloom CA V 7	
Configuration screen	Displays "Special X, Y [ᄀᆲ"	Displays "Input 64 X []"	
Monitoring	Disabled	Enabled as inputs	

- (5) When monitoring an I/O module
 - (a) Only the output signal can be monitored for an I/O module for which "Output []" is displayed on the System Configuration screen.


For input signals, monitor X of the PLC CPU device with the system monitor function.

5 Editing and reusing intelligent module monitor data

The project data for the intelligent module monitor cannot be edited by modifying or adding an object. However, the data can be used on a user-created monitor screen.

6 Precautions for I/O allocation setting

(1) Even when I/O numbers are set at random as shown below, in the case the GOT is connected to the QnACPU, the start XY numbers are displayed in order on the System Configuration screen. When performing intelligent module monitoring, always perform the I/O allocation in order from slot 0.



- (2) If the slot assigned with outputs in I/O assignment is not fitted with a module, the GOT displays it as input. (Common to ACPU and QnACPU)
- 7 Display provided when the QA1S6 ☐ extension base unit is used with the QCPU (Q mode)

This precaution pertains to a situation where the QA1S6

extension base unit is connected to the QCPU (Q mode) in a station connected to the GOT.

In this case, the abbreviated format is displayed for the following intelligent function modules on the System Configuration screen.

You can use the unit detail information to check the full format of the module displayed with the abbreviated format.


Unsupported intelligent function modules are displayed as "SP", and the corresponding modules cannot be monitored.


Installed module	Model name displayed
A1S63ADA	63ADA
A1SJ71PT32-S3	J71PT32-
A1SJ71ID1-R4	J71ID
A1SJ71ID2-R4-S1	37110
A1S64TCTT(BW)-S1	64TCTT/R
A1S64TCRT(BW)-S1	- 041CTT/R

6.3 Display

1 Operation procedure until the start of the intelligent module monitor

This subsection describes the flow until the operation screen for the intelligent module monitor is displayed after the intelligent module monitor (Option OS) is installed in the GOT.







(1) How to display the utility

For how to display the utility, refer to the following.

GT16 User's manual (Basic Utility) (1.3 Utility Display)
GT15 User's manual (9.3 Utility Display)

(2) Displaying communication setting window

After turning on the GOT, the communication setting window is displayed at the first startup of the intelligent module monitor only.

For displaying the communication setting window at the second or later startup,

touch the $\frac{\text{ChNET}}{\text{PLCNo.}}$ button on the intelligent module monitor screen.


(6.4 Operation of Each Intelligent Module Monitor Screen)

(3) If the project data has not been downloaded

The intelligent module monitor can be started from the utility even if the project data has not been downloaded to the GOT.

2 Changing screens

The following describes how to change the screen.



6.4 Operation of Each Intelligent Module Monitor Screen


This section describes the operations of the screens when using the intelligent module monitor.

6.4.1 Composition of the system configuration screen and key functions

This section describes the configuration of the System Configuration screen that is displayed after startup of the intelligent module monitor and the functions of the keys displayed on the screen.

1 When using the QCPU (Q mode) or QSCPU

(1) Displayed contents



The model name of the module and related data are displayed at the end of the module data readout from the PLC CPU.

(The OS executes it automatically.)
When connected to the
MELSECNET/H or MELSECNET/10,
the screen in Section 6.4.2 is
displayed.

Item	Description	
1)	Displays the network number and station number of the monitored station.	
2)	Displays the model name, I/O points, and start I/O number for the modules installed in the monitored station. For an intelligent function module that cannot be monitored, the model name is displayed as "SP". The display position of the module becomes the key to switch to the screen where the monitoring of that module is performed. (Touch input) Displays the CPU Nos. for the CPUs and the control CPU number for the installed modules when there are multiple CPU systems.	
3)	Display keys used for the operations on the System Configuration screen shown in (2). (Touch input)	


(2) Key functions

The table below shows the functions of the keys that are used with the operation on the DEVICE MONITOR screen.

Key	Function	
END	Closes the monitoring and returns the screen to the one for starting the intelligent module monitor.	
CHNET PLCNo	Displays the communication setting window.	
QCPU	The screen switches to the PC Information monitor screen. (Refer to Section 6.4.3.)	
Module display position	In intelligent module monitor mode: Switches to the screen where the intelligent module monitoring for that module is performed. In unit detail info mode: Switches to the screen displaying detailed information of the selected module.	
Info. mode	Switches the System Configuration screen to Info. mode. (Refer to Section 6.4.4.)	
Basic mode	Switches the System Configuration screen to Basic mode.	
	Scrolls the display one stage up or down to display the system configuration of the currently undisplayed stage immediately before/after the currently displayed stage. Operations can be performed when the system configuration has three or more extension bases. Scrolls one stage up. Scrolls one stage down.	

2 When using the QCPU (A mode), QnACPU, and ACPU

(1) Displayed contents



The model name of the module and related data are displayed at the end of the module data readout from the PLC CPU. (The OS executes it automatically.)

When connected to MELSECNET/10, the screen shown in Section 6.4.2 is displayed.

Item	Description	
1)	Displays the network number and station number of the monitored station.	
2)	For modules installed in the monitored station, the model name and start No. of I/O signals are displayed for the intelligent function module, "IN"/"OUT" and the I/O points for the I/O module. For an intelligent function module that cannot be monitored, "SP" and the start No. of the I/O signal are displayed.	
	The display position of the module becomes the key to switch to the screen where the monitoring of that module is performed. (Touch input)	
3)	Display keys used for the operation on the System Configuration screen shown in (2). (Touch input)	

(2) Key functions

The table below shows the functions of the keys that are used for the operation on the System Configuration screen.


Key	Function		
END	Closes the monitoring and returns the screen to the one for starting the intelligent module monitor.		
CHNET PLCNo	Displays the communication setting window.		
Module display position	Switches to the screen where the intelligent module monitoring for that module is performed.		
	Scrolls the display one stage up or down to display the system configuration of the currently undisplayed stage immediately before/after the currently displayed stage. Operations can be performed when the system configuration has three or more extension bases. I Scrolls one stage up.		

6.4.2 Setting method for other station monitoring

The setting method to perform other station monitoring during intelligent module monitoring is described below

<Intelligent module monitor>

When using MELSECNET/10 connection



Touch [Intelligent module monitor] to display the System Configuration screen.

Depending on the connection method, the screen that is first displayed different, as indicated below.

Bus connection and direct CPU connection	The base of the connected station is displayed.
Ethernet connection	The base of the station set as the host is displayed.
CC-Link connection (via G4)	The base of the master station is displayed.
MELSECNET/H connection, MELSECNET/10 connection CC-Link IE controller network connection CC-Link connection (Intelligent device station)	No system configuration display

The following operations are always required for MELSECNET/H, MELSECNET/10 and CC-Link connections.

- 1) Touch ChNET to display the window shown in 2).
- 2) Touch to switch to the window for network setup. (To monitor another channel number or other station, touch the channel number you want to monitor and switch to the network setup window.) Touch an alphanumeric key to specify the network number and PLC station

Alphanumeric key ... Enters the network number and PLC station number.

Selects the input area.

Sets the area value.

For data link system

NETWK No. : 0
Station No. : FF (Host)
: 0 (Master station)
: 1 to 64 (Local station)

For network system*2

NETWK No : 0 (Host loop)
: 1 to 255 (Specified loop)

Station No. : FF (Host)
: 0 (Control station number)
: 1 to 64: (Control station/normal station)

For Ethernet connection*1

NETWK No. : 1 to 239

Station No. : 1 to 64

For CC-Link system

NETWK No. : 0
Station No. : 0 (Master station)

*1 You need to set a monitor target using GT Designer2 in advance.

number

For ACPU monitoring, specify the network number/station number set using GT Designer2. Refer to the following for details of the monitor target setting for Ethernet connection.

GOT1000 Series Connection Manual (10. ETHERNET CONNECTION)

*2 When the station No. is set to the host station (FF), set the network No. to 0.

When the setting is finished, the system configuration of the specified station is displayed. Refer to Section 6.4.6 for further operations.

6.4.3 Composition of PC Information monitor screen and key functions


This section describes the structure of the PC Information monitor screen that is displayed by specifying the QCPU (Q mode) or QSCPU on the System Configuration screen, and the key functions displayed on the screen.

The GOT displays the PC Information monitor screen only when using the following controllers.

- QCPU (Q mode)
- QSCPU

1 When using the QCPU (Q mode)

(1) Displayed contents



Item	Description	
1)	Displays the network number and station number of the monitored station.	
2)	Displays the operating status, error information and other information of the targeted PLC CPU. Up to 100 error information events can be displayed.	
3)	Displays keys used for the operations on the PC Information monitor screen shown in 2 . (Touch input)	

(2) Key functions

The table below shows the functions of the keys that are used for the operation on the System Configuration screen.

Key	Function
END	Closes the monitoring and returns the screen to the one for starting the intelligent module monitor.
Sys. Conf.	Switches the screen to the System Configuration screen. (Refer to Section 6.4.1.)
	Scrolls the display one page up or down.
	s : Scrolls one page up.
	▼ : Scrolls one page down.

2 When using the QSCPU

(1) PC Information monitor screen

(a) Displayed contents



Item	Description		
1)	Displays the channel number, network number, and station number of the monitored station.		
2)	Displays the keys that are used for the operation on the System Configuration screen shown in		
	(b). Displays the QSCPU operation status. (RUN/STOP)		
3)	. ,		
4)	Displays the safety CPU operation mode. (Safety mode/Test mode) Displays the error being occurred.		
	Displays the error b	eing occurred.	
	Touching the error of	lisplays the Error details screen.(This section 2 (3))	
	No.	: Displays the error code.	
5)	Detail	: Displays the detail code of the error log.	
,		([] is displayed when no detail code exists.)	
	Error cause	: Displays the error details.	
		Touching the item displays the Error details screen.	
	Date, Time	: Displays the date and the time that the error occurs.	
6)	Set the items to be displayed in the log list.(This section 2 (1)(b))		
	Displays the operati	on status, error information, and others of the monitored PLC CPU. (Log list)	
	Туре	: Displays the log types. (Ope: Operation log, Err: Error log)	
	No.	: Displays the operation codes or error codes.	
	Detail	: Displays the 4-digit detail codes of the operation logs or the error logs for	
		the errors occurred in the CC-Link Safety system remote I/O module.	
		([] is displayed when no detail code exists.)	
	Operation/Error message		
7)		: Displays the operation details or error messages.	
		Displays "BROKEN OPERATION/ERROR LOG" when the log data is	
		damaged.	
	Date, Time	: Displays the dates and the time of operations or the dates and time that errors occur.	
	Touching an operati	on log displays the Operation details screen.(This section 2 (2))	
_	Touching an error lo	g displays the Error details screen.(This section (3))	


(b) Key functions

The table below shows the functions of the keys that are used for the operation on the System Configuration screen.

Key	Function							
END	Closes the monitoring and returns the screen to the one for starting the intelligent module monitor.							
Sys. Conf.	Switches the screen to the System Configuration screen. (Refer to Section 6.4.1.)							
	Switches the log types to be displayed in the log list.							
N: 1 C:11 1	All log : Displays all the logs (error logs, operation logs).							
Display filter	Error log : Displays the error logs only.							
	Operation log : Displays the operation logs only.							
Order display	Sorts the log list in ascending or descending order.							
	Switches the numbers of logs displayed in the log list.							
	32 items : Displays the latest 32 logs.							
Log	100 items : Displays the latest 100 logs.							
	(When the number of displayed logs is switched from 100 to 32, 100 logs are displayed before							
	touching the Update key.)							
	Obtains the latest log information from the PLC CPU and updates the log list.							
<u>Update</u>	(The displayed log data before touching the Update key is deleted.)							
	Scrolls the display one page up or down.							
lack	▲ : Scrolls one page up.							
	: Scrolls one page down.							

(2) Operation details screen

(a) Displayed contents




Item	Description
1)	Displays the channel number, network number, and station number of the monitored station.
2)	Displays the keys that are used for the operation on the System Configuration screen shown in
2)	(b).
3)	Displays the detailed operating information according to the operation log information stored in
3)	the QSCPU.

(b) Key functions

Key	Function
END	Closes the monitoring and returns the screen to the one for starting the intelligent module monitor.
RET	Returns the screen to the PC Information monitor screen.

(3) Error details screen

(a) Displayed contents



Item	Description
1)	Displays the channel number, network number, and station number of the monitored station.
2)	Displays the keys that are used for the operation on the System Configuration screen shown in
2)	(b).
	Displays the common error information and the individual error information according to the
	information stored in SD4 and subsequent devices of the QSCPU.
	For the common error information and the individual error information, refer to the following
	manual.
3)	QSCPU User's Manual (Function Explanation, Program Fundamentals)
	When the individual error information for the safety remote I/O station is displayed, the numerical
	notation of the displayed data can be switched between decimal and hexadecimal numbers.
	(When the CC-Link Safety system master module cannot receive the error information from the
	safety remote I/O station, [****] is displayed for unreceived items.)

(b) Key functions

Key	Function
END	Closes the monitoring and returns the screen to the one for starting the intelligent module
LIND	monitor.
RET	Returns the screen to the PC Information monitor screen.
	Switches the numerical notation of the displayed data between decimal and hexadecimal
Display switch	numbers. (Only when the individual error information for the safety remote I/O station is
	displayed)

6.4.4 Composition of the unit detail info screen and key functions

This section describes the structure of the Unit Detail Info screen that is displayed by specifying a module on the System Configuration screen at Info. mode, and the key functions displayed on the screen.

The GOT displays the Unit Detail Info screen only when using the following controllers.

• QCPU (Q mode)

QSCPU

1 Displayed contents



Item	Description
1)	Displays the network number and station number of the monitored station.
2)	Displays the operating status, error information and other information of the targeted PLC CPU. Up to 10 error information events can be displayed.
3)	Displays keys used for the operations on the System Configuration screen shown in 2. (Touch input)

2 Key functions


The table below shows the functions of keys that are used for the operations on the System Configuration screen.

Key Function				
END	Closes the monitoring and returns the screen to the one for starting the intelligent module monitor.			
Sys. Conf.	Switches the screen to the System Configuration screen. (Refer to Section 6.4.1.)			

6.4.5 Composition of the intelligent module monitor screen and key functions

This section describes the structure of the monitor screen that is displayed by specifying a module on the System Configuration screen (in Basic mode when the QCPU (Q mode) is used), and the key functions displayed on the screen.

1 Displayed contents (for A68RD)



All data are displayed when the readout from the intelligent function module is completed. (The OS executes it automatically.)

Item	Description
1)	Displays the model name of the module being monitored.
	Displays the buffer memory data of the module in its current form or in a graph.
2)	The status of I/O signals to and from PLC CPU is monitored.
	When testing, execute testing after moving the cursor to the display position of the target data.
3)	Displays keys used for the operations on the monitor screen shown in 2. (Touch input)

2 Key functions


The table below shows the functions of keys that are used for the operations on the monitor screen.

Key	Function
END	Closes the monitoring and returns the screen to the one for starting the intelligent module monitor.
MON I TI MENU	Closes the current monitor and returns to the screen displaying monitor menu. This operation can only be used when the intelligent function module has a monitor menu.
Data Chg.	Starts changing (writing) the current values of the buffer memory of the intelligent function module displayed on the screen.
SET/ RESET	Starts testing (SET/RST) of the I/O signal between the PLC CPU and the intelligent function module.

6.4.6 Specifying a module to monitor and selecting monitor menu

This section uses the positioning module (AD71) as an example to describe the operations when starting the intelligent module monitor to monitor a desired module.

Operation procedure



See Sec.6.4.1


From among the modules installed in the corresponding base unit, specify the intelligent function module whose format is displayed.

*: For modules where the format is not displayed, monitor with the system monitor function (See

Specify input/output modules according to Sec. 6.6.

- (2) Specify the menu corresponding to the type of data to be monitored.
- With modules for which the monitor menu cannot all be displayed in one screen, touch the 🛕 🔻 keys at the right of the screen to scroll the display menu.

Specify menu to be monitored (Touch display position of menu.)



Proceed to Sec. 6.4.7 and Sec. 6.5

- (4) Check the contents of the display. Carry out the subsequent operation according to Sec. 6.5.
- Carry out tests for the displayed data according to Sec.6.4.7.
 - Change current value of buffer memory
 - Turn output signal from PLC CPU on and off

6.4.7 Testing of the intelligent function module

№ WARNING

 When testing the operation (changing a current buffer memory value) of the intelligent module monitor, read this manual carefully to fully understand the operation.

For devices that perform significant operations for the system, never perform test operation to change data.


Doing so can cause accidents due to false outputs or malfunctions.


Testing can be performed for all buffer memory data displayed on the current monitor screen. This section describes the operations for changing the current value of the buffer memory and turning on and off the output signal from the PLC CPU to the intelligent function module.



- (1) Perform testing for the buffer memory that can be written from the PLC CPU and output signals that are output from the PLC CPU.
- (2) It is recommended that testing be performed with the PLC CPU in STOP status. If the PLC CPU is tested during RUN status, the test monitor display returns to display values output from the sequence program and output statuses.

Operation procedure





When Data Chg. is touched (changes current value of buffer memory)

- All of the following operations can be carried out by touching the keys in the displayed key window.

- (2) Use the numeric keys to specify the value to be changed. (*2) The DEL key can be used to clear individual characters among those input.

When \fbox{RESET} is touched (tests the I/O signal)

- All of the following operations can be carried out by touching the keys in the displayed key window.
- When you touch ⊠ at the upper left of the key window, the key window closes and the display returns to the monitor screen.
- (1) Use the alphabetic character keys to specify the name of the device to be tested, and then touch . (*1)
- (2) Use the numeric keys to specify the device number, and then touch ightharpoonspice.
- (3) Use the numeric keys to specify "Set" or "Reset".

0: OFF 1: ON

1 Do not perform the following tests.

If these tests are performed, the module may not operate correctly or the buffer memory/input signal may return to the output value/output status from the intelligent function module.

- 1) Testing of read-only buffer memory from the PLC CPU.
- 2) Testing of input signals from the intelligent function module to the PLC CPU.
- When testing buffer memory data, specify the change value in the following way.
 -) For data where 16/32 bits are displayed with one number, specify a new value in decimal format.
 - For data where one number of 16/32 bits is displayed as a percent, such as with an A/D conversion module, specify a new value corresponding to the percentage in decimal format.
 Example:

When the set value of the offset or gain is 0 to 2000 and you intend to change it to "50%", input "1000".

3) For data where 16 bits are displayed with "0" or "1" for each bit, specify a new value with changing the data to a decimal.

6.5 Intelligent Module Monitor Screens

6.5.1 A62DA-S1 module monitoring

0	NI-	Buffer mem	ory address
Screen example	No.	DEC	HEX
2) 1)	1)	0, 1	0000, 0001
	2)	2 to 5	0002 to 0005
A62DA-S1 Operation Monitor Screen RESET Chg. MENU END	3)	-	-
Channel 1 Output Voltage check 0 Current check 2) Channel 2 Output Voltage check 1 Current check 2)		-	-
ISET/ Data MONITICE	1)	0, 1	0000, 0001
A62DA-S1 Graph Monitor Screen RESET Chg. MENU ENU	2)	2, 4	0002, 0004
Output [%] Under Over Error	3)	3, 5	0003, 0005
0 25 50 75 100 Channel 1	4)	-	-
1) — Channel 2			
() WDT Error			
4)	-	-	-

Buffer memory address Screen example No. DEC HEX 0001 1) 2) 2 to 9 0002 to 0009 Sample/Average Time/Count 3) 10 to 17 000A to 0011 Sample/Average Count/Time 8765432187654321 0000001111101000 0:Sampling 1:Averaging 4) 0000 0 5) 34 0022 Count/Time Value Input Status [%] Writing Data Error 00 2) 3) 1) Outputs (Y) 10 to 17 000A to 0011 1) 2) Input [%] Channel 3 WDT Error 2)

A68AD module monitoring

6.5.2

		Buffer mem	ory address
Screen example	No.	DEC	HEX
	1)	0	0000
A68ADN Operation Monitor Screen SET/ Data MONIT END SET/ Chg. MENU	2)	1	0001
1) — Channel 87654321 Setting 0000011010100100 0:Disabled 1:Enabled	3)	2 to 9	0002 to 0009
Setting	4)	10 to 17	000A to 0011
	5)	18	0012
	6)	20	0014
Count/Time	-	-	-
3)	1)	_	-
A68ADN Input/Output Monitor Screen Inputs (X)	- 1)	- 10 to 17	- 000A to 0011
A68ADN Graph Monitor Screen SEST Chg. MENU END			
Resolution 1 2 3	2) 3)	20	0014
Input [%] 0 . 50 . 100 0 . 50 . 100 0 . 50 . 100	4)	-	-
Channel 1 Channel 2 Channel 3 Channel 5 Channel 6 Channel 7 Channel 8 Resolution Selection 0 Error WDT Error	-	<u>-</u>	-

Screen example				NIa	Buffer memory address	
			No.	DEC	HEX	
		ISET/ Data MONIT		1)	10 to 17	000A to 0011
	A68RD Operation Monitor Screen	RESET Chg. MENU END	-	2)	18 to 33	0012 to 0021
	Temp. Value Temp. Value Time/ Count	Disabled/Enabled 87654321 0000000000000000001		3)	2 to 9	0002 to 0009
	1 1) 0.0 2) 0.000 3) 0	1: Enabled 0: Disabled	-4) -	4)	0	0000
		Conversion 87654321 00000000000000000000001		5)	35	0023
	3 0.0 0.000 0	1: Completed 0: Not Completed	-5)	6)	1	0001
	4 0.0 0.000 0 5 0.0 0000.000 0	Average/Sample Time/Count 87654321B7654321 0000000000000000000000		7)	-	-
	6 0.0 0.000 1		- 6)	8)	34	0022
	7 0.0 0.000 1	1: Averaging		9)	36	0024
	8 0.0 0.000 0	[] CH1 disconn. [] CH5 disconn. [] CH2 disconn. [] CH6 disconn.		10)	-	-
') —	[]WDT Error Temp. Sensor Type 0	CH3 disconn. CH7 disconn.				
				-	-	-
	8) 9)	10)				
		SET/ Data MONIT END		1)	-	-
	A68RD Input/Output Monitor Screen	RESET Chg. MENU J				
) —	Inputs (X) 	Outputs (Y) 10 11 12 Error Reset 13 14 15 16 17 18 19 14 18 10 10 11 11				
′ į	J2 Write Data Error 12 J3 CH1 Disconnected 13 J4 CH2 Disconnected 14 J4 CH2 Disconnected 14	12 Error Reset				
	04 CH2 Disconnected 14 D4 D5 CH3 Disconnected 15 D5	14 15				
	D5 CH3 Disconnected 15	16 17				
	08 CH6 Disconnected 18	18 19				
	DA CH8 Disconnected TA DA DB DB	1A 1B		_	-	_
	DOWDT Error 10	1D 1E				
	OF IF OF	IF				
				1)	10 to 17	000A to 0011
	A68RD Graph Monitor Screen	SET/ Data MONIT END	F	2)	0	000A to 0011
	I T 11 I	Disabled/Enabled 87654321 000000000000000000000000000000000000	-	3)	35	0000
	e a 500	1: Enabled 0: Disabled	-2)	4)	1	0023
	p u 400 -	Conversion 87654321 000000000000001	-	7)	<u>'</u>	-
	a c 200 - 1)	00000000000000001 1: Completed 0: Not Completed	-3)	5)	34	0022
	u 100 –		-	6)	36	0024
		Sample/Average Count/Time 8765432187654321 00000000000000000000000	-4)	7)	-	-
	-100 -	1: Averaging 1: Time Average	''	')	-	-
	-180 1 2 3 4 5 6 7 8					
		[] CH1 disconn. [] CH5 disconn. [] CH2 disconn.		1		
₀ _	MDT Error Temp. Sensor Type 0	CH3 disconn. CH7 disconn.		J		


A68RD module monitoring

6)

7)

6.5.4


	No.	Buffer mem	ory address
Screen example		DEC	HEX
	1)	10 to 13	000A to 000D
1) 1) 2)	2)	18 to 21	0012 to 0015
A84AD Operation Moni or Screen SEET/ Data MONIT END	3)	28 to 31	001C to 001F
Input/Output Status [%] Temp. Value Module O/P O/P	4)	22 to 25	0016 to 0019
-3)	5)	22 to 25	0016 to 0019
Channel 2 0.0 50.0 0 0 0 0 4)	6)	26	001A
Channel 3 0.0 50.0 0 0 0 0 50.0	7)	27	001A 001B
Channel 4 0.0 50.0 0 0 0 0			
Loaded 02.04.05.10.12 06.07,16.17 18.1A.1C Writing Data Error OH:0 Code: 0 15.14.1F.	8)	-	-
	9)	-	-
Channel	•	-	-
7) 8)	1)	1	0001
SET/ Data MONITI EAD	1) 2)	2 to 5	0001 0002 to 0005
AS4AD Setting Monitor Screen RESET Chg. MENU END	2)		
Processing Mode Count/ Offset Gain Time [X] [X]	3)	32, 34, 36, 38	0020, 0022, 0024, 0026
Sample/Average		33, 35,	0024, 0020
CH 4321 4321 Channel 2 0 0 0	4)	33, 35, 37, 39	0021, 0023,
0: Sampling 1: Count Average Channel 4 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	1	-	-
	1)	-	-
Inputs (X)		-	-




				Buffer me	emory address
Screen example		No	DEC	HEX	
			1)	15	000F
A616AD Operation Mo	onitor Screen	ISET/ Data MONIT RESET Chg. MENU END	2)	4	0004
		Error Code 0	-4) 3)	48 to 63	0030 to 003F
1) — Enable 000000 0: Di	1) —— Enable 000000000000000000000000000000000000	4)	5	0005	
Data Format FEDCB Setting 000000	A9876543210 00000000000		5) 5)	6	0006
		<u> </u>	6)	3	0003
	For Data Format 0: Refer		7)	0,1	0000, 0001
CH 0 0.0 CH 1 0.0 CH 2 0.0	0.0 CH 8 0.0 CH 9 0.0 CH A	0.0 0.0 0.0 0.0	8)	2	0002
OH 2 0.0 OH 3 0.0 OH 5 0.0 OH 6 0.0 OH 7 0.0	0.0 (서 B 0.0 (서 C 0.0 (서 D 0.0 (서 E 0.0 (서 F	0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0	-	-	-
			1)	16 to 23	0010 to 0017
A616AD Operation Mo	onitor Screen CONNECT	SET/ Data MONIT END RESET Chg. MENU	2)	4	0004
1) — FEDCB/	A9876543210 00000000000 sabled 1: Enabled	Error Code 0	4) 3)	256 to 383	0100 to 017F
1) — Enable 000000	sabled 1: Enabled	Error FEDCBA9876543210 CNT No. 00000000000000000	-5) 4)	5	0005
2) — Data Format Setting 000000	*	0 11 11	-6) 5)	6	0006
Input Status [%]	For Data Format 0: Refer Format 1: Refer		6)	3	0003
CH O O O			7)	0	0000
CH 1 0.0 CH 2 0.0	0.0	0.0 0.0 0.0 0.0	8)	1	0001
CH 3 3) 0.0 CH 4 0.0 CH 5 0.0	0.0 CH B 0.0 CH C	0.0 0.0 0.0 0.0 0.0	9)	2	0002
CH 1 0.0 CH 2 0.0 CH 3 3) 0.0 CH 4 0.0 CH 5 0.0 CH 6 0.0 CH 7 0.0	0.0 CH F	0.0 0.0 0.0	-	-	-
			1)	-	-
A616AD Input/Outpu Input 1) — 00 WDT Error 01 READY 02 Error 03 04 05 06 07 08 09 0A 08 00C 00D 0E 0F		Outputs (Y) Outputs (Y)	-	-	-



		Buffer mem	ory address
Screen example		DEC	HEX
	1)	15	000F
ASSET Data MONIT END	1)	0	0000
ADIOID Operation Monitor Screen INPULU-F RESELLUTE, MENU	2)	1	
1) —— Conversion 0000011111000000 Front Is 2010 1: Employ 1: Empl	3)		0001
Channel No. FEDCBA9876543210	4)	2	0002
2) — Data Format 000000000000000000000000000000000000	5)	4	0004
Input Status For Data Format 0: Refer to left hand side values [%] Format 1: Refer to right hand side values	6)	112 to 127	0070 to 007F
CH 0 0.0 50.0 CH 8 0.0 50.0 CH 9 0.0 50.0	7)	-	-
GH 1 0.0 50.0 GH 9 0.0 50.0 50.0 GH 2 0.0 50.0 GH 8 0.0 50.0 50.0 GH 3 0.0 50.0 GH 8 0.0 50.0 50.0	8)	-	-
CH 4 6 0.0 50.0 CH 5 6 0.0 50.0 CH 5 0.0 50.0 CH 5 0.0 50.0 50.0 50.0	9)	-	-
CH 0 0.0 50.0 CH 8 0.0 50.0 50.0 CH 8 0.0 50.0 CH 1 0.0 50.0 CH 9 0.0	-	-	
	1)		_
1) — SETY Data MONIT END A616TD Operation Monitor Screen CONNECT No.0 RESET Chg. MENU END	<u> </u>	16 to 23	0010 to 0017
	2)		
Channel No. FEDCBA9876543210 Conversion 0000000111110100 Enable 0: Disabled 1: Enabled Digital Value Err 0000000000000000000000000000000000	3)	0	0000
Discontinuity Err 000000000000000 - 7) * Disc.Error Enable 0000000000000 - 8)	4)	384 to 511	0180 to 01FF
3) — Data Format 000000000000 0:Normal/Disabled 1:Break/Enabled	5)	80 to 87	0050 to 0057
Input Status [%] Temp. Value Input Status [%] Temp. Value Format 0 Format 1 [C] Format 0 Format 1 [C]	6)	96 to 103	0060 to 0067
CH 0 0.0 50.0 0.0 CH 8 0.0 50.0 0.0 CH 9 0.0 50.0 0.0 CH 2 0.0 50.0 0.0 CH 8 0.0 50.0 0.0 CH 2 0.0 50.0 0.0 CH 8 0.0 50.0 0.0 CH 9 0.0 CH 9 0.0 50.0 0.0 CH 9 0.0 CH	7)	64 to 71	0040 to 0047
CH 3 4\ 0.0 50.0 0.0 \(\oldsymbol{Q}\) CH B 4\ \oldsymbol{Q}\) 0.0 50.0 0.0 \(\oldsymbol{Q}\)	8)	32 to 39	0020 to 0027
CH 4 I 1 0 0 I 50 0 I 0 0 1 CH C I 1 0 0 I 50 0 I 0 0 1 I	9)	512 to 639	0200 to 027F
CH 5 0.0 50.0 0.0 CH D 0.0 50.0 0.0 CH 6 0.0 50.0 0.0 CH E 0.0 50.0 0.0 CH 7 0.0 50.0 0.0 CH F 0.0 50.0 0.0	10)	48 to 63	0030 to 003F
Digital Output/Temp.Value D=0: 0.0 C D=4000: 0.0 C	11)	-	-
10) 11)	-	-	-
	1)	-	-
A616TD Input/Output Monitor Screen	-	-	-








A616DAV module monitoring

6.5.8

6.5.9 A616DAI module monitoring

Refer to the following for further information about the screen for A616DAI and the buffer memory address. 6.5.8 A616DAV module monitoring



6.5.11 A62LS module monitoring

Screen example		Buffer memory address	
		DEC	HEX
	1)	-	-
A62LS Operation Monitor Screen CH No.0-3 RESET Chg. MENU	2)	7	0007
	2)	4	0004
X10 WDT Error Y21 Posit. Start Y25 LS 0/P Enable Sensor BIN Pos. 2 - 4) Y22 Posit. Stop Y26 Error Reset X12 Up.Lim Err Y27 Fwd Jog StartY27 P1 Disable X13 Lo.Lim Err Y24 Rev Jog StartY28 P2 Disable X14 Sensor Err X15 Corre. Err X15 Corre. Err X16 Posit. Err Code LS Output 0000000000000000 Pr.S. No. 0 0p. Mode 43210 Op. Satting 0000000000000000 Pr.S. No. 0 0p. Mode 43210 Op. Satting 000000000000000000000000000000000000	3)	8	0008
1) — X14 Sensor Err X15 Corre, Err Frror 3) FFD0849876543210 Target Stop Pos. 2 — 6)	4)	2	0002
	5)	0	0000
2) MAX ON CHO OFF MAX ON CH 1 OFF MAX ON CH 2 OFF MAX ON CH 3 OFF	6)	10	000A
	7)	9	0009
10)	8)	5	0005
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	9)	6	0006
10) 65	10)	12 to 667	000C to 029B
	-	-	-
	1)		_
Self Self	-	-	-


6.5.12 AD61 module monitoring

Saraan	Screen example No.		Buffer mem	ory address
Screen	example	No.	DEC	HEX
		1)	4, 5,	0004, 0005,
AD61 Operation Monitor Screen	SEI/ Data MONII RESET Chg. MENU END	1)	36, 37	0024, 0025
	et Value Mode Mode 0 a 1 8: 1-Phase	2)	6, 7,	0006, 0007,
Channel 1	0 3) 8: 1-Phase 0 18: 2-Phase	2)	38, 39	0026, 0027
Inputs (X) 00 CH1 Count Greater[0	Outputs (Y) 00 10 CH1 Equal Reset	3)	3, 35	0003, 0023
00 CH1 Count Greater 10 01 CH1 Count Equal 11 02 CH1 Count Less 12 03 CH1 Ext. Preset 13	01 11 CH1 Preset Cmd. 02 12 CH1 Equal O/P	4)	-	-
33 CH1 Ext. Preset 13 4) —94 CH2 Count Greater 14 55 CH2 Count Equal 15 56 CH2 Count Less 16 37 CH2 Ext. Preset 17 38 99 19 0A 1A 0B 1C 3D 1C 3D 1E 0F	10 CH1 Equal Reset	-	-	-


		Buffer mem	emory address		
Screen example	No.	DEC	HEX		
	1)	-	-		
AD70 Positioning & Parameter Data Monitor Screen RESET/ Data MONIT	2)	100. 101	0064, 0065		
	3)	102, 103	0066, 0067		
Y12 Forward Start	4)	106, 107	006A, 006B		
Y14 Fwd. Jog Start Y15 Rev. Jog Start Error Counter 4) 0 Velocity 0 PLS/s	<u> </u>	61, 62	-		
X05 Posit. Complete Pos.Address P1 5) 0 Jog Velocity 0 PLS/s — 16)	5)	·	003D, 003E		
1) — X02 Zero Rtn Request Pos.Address P2 6) 0 Upper Limit 2147483647 — 17) Y10 Zero Rtn Start Lower Limit 0 — 18)	6)	65, 66	0041, 0042		
X03 Zero Rtn Comple. Pos. Velocity V1 7) OPLS/s Gear Ratio 1: 1 1 19)	7)	63, 64	003F, 0040		
Y17 Stop Volocity V2 8) 0 PLS/s Velocity Limit 20000 PLS/s Velocity Limit 20000 PLS/s	8)	67, 68	0043, 0044		
9)	9)	60	003C		
10) Y1C V/P Switchover V/P Mode 0	10)	111	006F		
X07 Excessive Error X08 Error Detection Error Code 1: 0 2: 0 Positioning Mode 0 24)	11)	104	0068		
2-1)	12)	105	0069		
	13)	80, 81	0050, 0051		
	14)	88, 89	0058, 0059		
11) 12)	15)	82, 83	0052, 0053		
	16)	84, 85	0054, 0055		
	17)	0, 1	0000, 0001		
	18)	2, 3	0002, 0003		
	19)	4, 5	0004, 0005		
	20)	20, 21	0014, 0015		
	21)	22	0016		
	22)	23	0017		
	23)	24	0018		
	24)	25	0019		
SET/ Data MONIT END	1)	-	-		
AD/O Zero Return Data Monitor Screen RESEL Ong. WEND	2)	100, 101	0064, 0065		
Y11 Ab.Posit. Start Y12 Forward Start Y13 Reverse Start Actual Position 3) 0 Travel Dist. 0 14)	3)	102, 103	0066, 0067		
Y14 Fwd. Jog Start Frror Counter 4) 0 Velocity 0 PLS/s - 15)	4)	106, 107	006A, 006B		
Y16 Vel/Pos Restart	5)	61, 62	003D, 003E		
1) X02 Zero Rtn Request Pos.Address P2 6) 0 Travel Dist. After Near Zero	6)	65, 66	0041, 0042		
X03 Zero Rtn Start X03 Zero Rtn Comple. Pos.Velocity V1 7) 0 PLS/s Point Signal Turned UN 0 17)	7)	63, 64	003F, 0040		
Y17 Stop X04 BUSY Pos.Velocity V2 8) 0 PLS/s Travel Dist. After Near Zero Point Signal ON	8)	67, 68	0043, 0044		
0 + 18)	9)	60	003C		
0: Positioning	10)	111	006F		
XOO WDT Error 1: Velocity Zero Rtn Vel. 0 PLS/s 20) XO7 Excessive Error	11)	104	0068		
21)	12)	105	0069		
	13)	80, 81	0050, 0051		
	14)	88, 89	0058, 0059		
10) 11) 12)	15)	82, 83	0052, 0053		
	16)	84, 85	0054, 0055		
	17)	108, 109	006C, 006D		
	18)	46, 47	002E, 002F		
	19)	40, 41	0028, 0029		
	20)	42, 43	002A, 002B		
	21)	44, 45	002C, 002D		

Screen example	No.	Buffer mer	mory address
Screen example	INO.	DEC	HEX
	1)	-	-
Input Output Monitor Screen Sest Output Sest Output	-	-	-

		Buffer memory address			
Screen example	No.	DEC	HEX		
	1)	-			
SET/ Data MONIT END	2)	100, 101	0064, 0065		
AUTUU POSITIONINg Data Monitor Screen RESEL Ung. WENU	3)	102, 103	0066, 0067		
Y11 Posit. Start Feed Position 2) 0 Present Value 0	5) 3) 4)	104, 105	0068, 0069		
Y13 Reverse Start Y14 Fwd. Jog Start Actual Position 3) 0 Travel Dist. 0 — 16	5)	61, 62	003D, 003E		
Y15 Rev. Jog Start Y16 Vel/Pos Restart		65, 66	003D, 003E		
XOb Posit. Complete Pos.Address P1 5)		63, 64	0041, 0042 003F, 0040		
1) — X02 Zero Rtn Request Pos.Address P2 6) 0 Torque Limit 0% — 1s		67, 68	003F, 0040		
Y10 Zero Rtn Start		60	003C		
,	' 3)	119	0030		
Y17 Stop	, 10)	120	0077		
Y1B Servo OFF	,,	121	0078		
Y1C V/P Switchover	·	122	0079 007A		
X00 WDT Error	44)	123	007A		
X08 Error Detection Err.Qode 1: 0 2: 0 S: 0 S/Switch 000000000000000000000000000000000000	15)	80, 81	0050, 0051		
	16)	86, 87	0056, 0057		
		,	,		
	17)	82, 83 84, 85	0052, 0053 0054, 0055		
I I I I 10) 11) 12) 13) 14)	19)	89	0054, 0055		
,,,	20)	110	006E		
	21)	111	006F		
	22)	112	0007		
	23)	113	0070		
	24)	125	007T		
	25)	126	007B		
	1)	-	007L		
ADZOD Z Data Monitor Consort SET/ Data MONIT END	2)	100, 101	0064, 0065		
AD70D Zero Return Data Monitor Screen RESET Chg. MENU	3)	102, 103	0066, 0067		
Y11 Posit. Start Feed Position 2) 0 Present Value 0 16	6) 3) 4)	104, 105	0068, 0069		
Y13 Reverse Start Y14 Fwd. Jog Start	7) 4) 5)	30, 31	001E, 001F		
Y15 Rev. Jog Start Y16 Vel/Pos Restart		32, 33	0020, 0021		
XOb Posit. Complete Zero Address 5)		34, 35	0020, 0021		
1) — X02 Zero Rtn Request Zero Rtn Vel. 6) 10000 PLS/s Torque Limit 0 % — 20		108, 109	006C, 006D		
Y10 Zero Rtn Start Creep Velocity 7) 1000 PLS/s Motor Speed 0 rpm - 2		106, 109	006C, 006B		
Y17 Stop Zero Rtn Dist. 8) 0 Motor Current 0% 22	' 3)	36, 37	0024, 0025		
X04 BUSY	10)	119	0024, 0023		
Y1B Servo OFF	′ · · / 	120	0077		
Y1C V/P Switchover		121	0078		
X00 WDT Error	4.4	122	0079 007A		
X08 Error Detection	15)	123	007A		
	16)	80, 81	0050, 0051		
	17)	86, 87	0056, 0057		
	18)	82, 83	0052, 0053		
11) 12) 13) 14) 15)	19)	84, 85	0054, 0055		
	20)	89	0059		
	21)	110	006E		
	22)	111	006F		
	23)	112	0070		
	24)	113	0070		
	25)	125	007D		
	26)	126	007E		
	20)	120	UOTE		




			Buffer mem	ory address	
Screen example	No.	X axis		Y axis	
		DEC	HEX	DEC	HEX
	1)	-	-	-	-
AD71 Positioning Data Monitor Screen SEST Data MONIT END	2)	47	002F	347	015B
X Y 3)X Axis 4) Y Axis X Y 01 0 0	3)	48	0030	348	015C
Y10 Y11 Posit. Start Exec.Data No. 0 Pt 0 0 Pt 0 02 0 0 0 Y12 Interpolation 03 0 0	4)	39	0027	339	0153
X02 X03 Posit. Compl. Present Value 5) 0 0 04 0 0 05 0 0	5)	602	025A	604	025C
Y10 Y11 Posit. Start	5)	603	025B	605	025D
Y17 Y19 Fwd. Jog Start Output Speed 8) 0 0 10 0	6)	41	0029	341	0155
Y18 MMA Rev.Jog Start Speed Limit 9) 0 0 12 0 0	6)	42	002A	342	0156
Y15 Y16 Stop Speed Change 10) 0 12 0 0 1 1 0 0 1 1 0 0 0 1 1 0 0 0 1 1 0 0 0 1 1 0 0 0 1 1 0 0 0 1 1 0 0 0 1 1 0 0 0 1 1 0 0 0 1 1 0 0 0 1 1 0 0 0 1 1 0 0 0 1 1 0 0 0 0 1 1 0 0 0 0 1 1 0 0 0 0 1 1 0 0 0 0 0 1 1 0 0 0 0 0 1 1 0 0 0 0 0 0 1 0	7)	7912	1EE8	7922	1EF2
XOF XOF M Code ON	7)	7913	1EE9	7923	1EF3
	8)	600	0258	601	0259
XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX	9)	7874	1EC2	7894	1ED6
	10)	40	0028	340	0154
	11)	44	002C	344	0158
2) 13) 14) 15)	12)	7875	1EC3	7895	1ED7
2) 13) 14) 13)	13)	46	002E	346	015A
	14)	45	002D	345	0159
		0	0000	300	012C
	15)	to	to	to	to
		37	0025	337	0151
ISET/ (Data MONIT)	1)	-	-	-	-
AD71 Zero Return Data Monitor Screen RESET Chair MENU END	2)	47	002F	347	015B
X Y 3) X Axis 4) Y Axis X Axis Zero Data ABC Y10 Y11 Posit, Start Exec.Data No. 535 Pt 0 335 Pt 0 1111111111111111111111111111111111	3)	48	0030	348	015C
Y10 Y11 Posit. Start Evec.Data No. 535 Pt 0 535 Pt 0 11111111111111111 ——————————————————	4)	39	0027	339	0153
1) — - 105 107 Zero Request Change Value 6) 0 0 01000000000000000000000000000000	5)	602	025A	604	025C
Y13 Y14 Zero Start X0C X0D Zero Complete Zero Address 7)		603	025B	605	025D
1 Mech. Stop Y17 Y19 Fwd. Jog Start Y18 Y1A Rev. Jog Start Speed Limit 9) 120 120 1 Stop/Signal	6)	41	0029	341	0155
Y15 Y16 Stop		42	002A	342	0156
X08 X09 Pos. Started Speed Change 10) 1000 -11149 Torque Limit X6 X15: 10 -16)	7)	7912	1EE8	7922	1EF2
XOE XOF M Code ON		7913	1EE9	7923	1EF3
X00 WDT Err Man.Pulse X00 WD	8)	600	0258	601	0259
Error Y:Disable	9)	7874	1EC2	7894	1ED6
	10)	40	0028	340	0154
	11)	7914	1EEA	7924	1EF4
2) 13) 14)	12)	7915	1EEB	7925	1EF5
	13)	46	002E	346	015A
	14)	45	002D	345	0159
	15)	7918	1EEE	7928	1EF8
	16)	7917	1EED	7927	1EF7
	17)	7916	1EEC	7926	1EF6



No. X axis Y axis DEC HEX DEC				Buffer mem	ory address	
10 - -	Screen example	No.	Ха	ixis	Υa	axis
MOT Positioning Data Monitor Screen Motion Motion			DEC	HEX	DEC	HEX
Second S		1)	-	-	-	-
1	Inputs (X)	-	-	-	-	-
A272 10B0 6272 1880 100	AD/1 Positioning Data Monitor Screen No.UI RESEL Ung. WENU	1)	to	to	to	to
008 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	001 7000 10 50 00 001 001 00 0 0 0 0 0 0 0 0					
008 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	003	2)	to	to	to	to
3872 0F20 5872 16F0 5) to to to to to 4271 10AF 6271 187F	007			_		_
3872 0F20 5872 16F0 5) to to to to to 4271 10AF 6271 187F	009 0 0 0 0 009 0 0 0 0 0 0 0 0 0 0 0 0	3)				
3872 0F20 5872 16F0 5) to to to to to 4271 10AF 6271 187F	011 2000 0 0 0 0 011 0 0 0 0 0 0 0 0 0 0	-/				
3872 0F20 5872 16F0 5) to to to to to 4271 10AF 6271 187F	014 0 0 0 0 014 3000 100 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0					_
3872 0F20 5872 16F0 5) to to to to to 4271 10AF 6271 187F	016 0 0 0 0 016 0 0 0 0 0	4)				
3872 0F20 5872 16F0 5) to to to to to 4271 10AF 6271 187F	018 0 0 0 0 018 0 0 0 0 0 0 0 0 0 0 0 0	'				
5) to to to to 4271 10AF 6271 187F	020 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		3872	0F20	5872	16F0
		5)				
			4271	10AF	6271	187F
1) 2) 3) 4) 5)			_	_	_	_

6.5.16 AD72/A1SD71 module monitoring

			Buffer mem	ory address	
Screen example	No.	Χá	axis	Y axis	
·	-	DEC	HEX	DEC	HEX
	1)	-	-	-	-
AD72/A1SD71 Positioning Data Monitor Screen RESET Chg. MENU END	2)	47	002F	347	015B
X Y 3)X Axis4) Y Axis X Y	3)	48	0030	348	015C
Y20 Y21 Posit. Start Exec.Data No. 855 Pt 0 855 Pt 0 02 767 280 Y22 Interpolation 03 280 280	4)	39	0027	339	0153
X12 X13 Posit. Compl. Present Value 5) 15528176 15528176 04 280 280 05 408 280		602	025A	604	025C
1) — Tie Mi Zero Request Change Value 6) -16711936 -16711936 06 408 280 723 Y24 Zero Start XIC XID Zero Complete Zero Address 7) 252645135 -252645135 08 280 280	5)	603	025B	605	025D
X1C XID Zero Complete Zero Address 7) 252645135 -252645135 08 280 280 Y27 Y29 Fwd.Jog Start Y28 Y2A Rev.Jog Start Output Speed 8) 0 0 10 280 280 Y25 Y26 Stop 11 280 280 12 280 12 280 13 280 14 280 15 280 15 280 15 280 16 280 17 280 18 280	0)	41	0029	341	0155
	6)	42	002A	342	0156
X18 X19 Pos. Started 13 280 280	7)	7912	1EE8	7922	1EF2
XIE XIF M Code ON 15 280 280	7)	7913	1EE9	7923	1EF3
Jog Spd.Limit:12) -3856 18 280 280	8)	600	0258	601	0259
WOT Err Man.Pulse	9)	7874	1EC2	7894	1ED6
	10)	40	0028	340	0154
	11)	44	002C	344	0158
2) 13) 14) 15)	12)	7875	1EC3	7895	1ED7
2) 13) 14) 13)	13)	46	002E	346	015A
	14)	45	002D	345	0159
		0	0000	300	012C
	15)	to	to	to	to
		37	0025	337	0151
SET/ Data MONIT FAD	1)	<u>-</u>	-	-	-
AD72/A1SD71 Zero Return Data Monitor Screen RESET Chg. MENU Co.	2)	47	002F	347	015B
X Y 3 X Axis 4 Y Axis X Axis Zero Data ABC Y20 Y21 Posit. Start Exec.Data No. 895 Pt 0 895 Pt 0 000011111000011111	3)	48	0030	348	015C
Y20 Y21 Posit. Start Exec.Data No. 855 Pt 0 855 Pt 0 00000111100001111	4)	39	0027	339	0153
i ' APC	5)	602	025A	604	025C
1) — X16 X17 Zero Request Y23 Y24 Zero Start X1C X1D Zero Complete Y27 Y29 Fwd.Jog Start Y28 Y2A Rev.Jog Start Y28 Y2A Rev.Jog Start Output Speed 8) 0 0 0 8:0 Fwd. 1: Rev.		603	025B	605	025D
125 126 Stop	6)	41	0029	341	0155
XI8 XI9 Pos. Started		42 7912	002A 1EE8	342 7922	0156 1EF2
X14 X15 BUSY Speed Change 10) -256 -256 Torque Limit X1E X1F M Code 0N Zeroing Speed 11) 0 0 Y Axis: 855 16)	7)	7912	1EE9	7922	1EF2
X22 X23 Excessive Err	8)	600	0258	601	0259
WOT Err Man.Pulse	9)	7874	1EC2	7894	1ED6
XIB Error YID Sable	10)	40	0028	340	0154
	11)	7914	1EEA	7924	1EF4
	12)	7914	1EEB	7924	1EF5
2) 13) 14)	13)	46	002E	346	015A
	14)	45	002D	345	0159
	15)	7918	1EEE	7928	1EF8
	16)	7917	1EED	7927	1EF7
	17)	7916	1EEC	7926	1EF6
	,				•



			Buffer mem	ory address	
Screen example	No.	Χa	ıxis	Y a	ixis
		DEC	HEX	DEC	HEX
	1)	-	-	-	-
Inputs (X)	-	-	-		
		5072	13D0	7072	1BA0
AD72/A1SD71 Positioning Data Monitor Screen No.01 AD72/A1SD71 Positioning Data Monitor Screen No.01 SET/ Data MONIT END	1)	to	to	to	to
X Address Speed Dwell M Code * Y Address Speed Dwell M Code *		5871	16EF	7871	1EBF
001 0 0 0 0 C 001 0 0 0 C 0 C 002 0 0 0 C 0 C 003 0 0 0 C 002 0 0 0 0 C 003 0 0 0 C 004 0 0 0 C 004 0 0 0 0 C 004 0 0 0 0		4272	10B0	6272	1880
004 0 0 0 0 0 004 0 0 0 0 0 0 0 0 0 0 0	2)	to	to	to	to
001 0 0 0 0 C 001 0 0 0 C 001 0 0 0 C 0 C		4671	123F	6671	1A0F
006 0 0 0 C 006 0 0 0 C 007 0 </td <td>2)</td> <td>4672</td> <td>1240</td> <td>6672</td> <td>1A10</td>	2)	4672	1240	6672	1A10
009 0 0 0 0 0 0 009 0 0 0 0 0 0 0 0 0 0	3)	to	to	to	to
006 0 0 0 C 006 0 0 0 C 007 0 </td <td></td> <td>5071</td> <td>13CF</td> <td>7071</td> <td>1B9F</td>		5071	13CF	7071	1B9F
	4)	3872 to	0F20 to	5872 to	16F0 to
	7)	4271	10AF	6271	187F
018 0		3872	0F20	5872	16F0
	5)	to	to	to	to
		4271	10AF	6271	187F
1) 2) 3) 4) 5)	-	-	-	-	-

Ourse surrell	NI-	Buffer mem	ory address
Screen example	No.	DEC	HEX
	1)	-	-
AJ71PT32-S3 I/O Monitor Scr. (I/O Dedicated Mode) Inputs (X)	-	-	-
	1)	0	0000
A FIDTO COLLIS DATA MANIFERD COLLIS DATA MONITOR END	1) 2)	70 to 77	0046 to 004D
AJ/PISZ-55 LINK Data Monitor Screen RESEL URS. MENU	3)	195	00C3
Remote I/O Units Card Data ST :8:7:6:5:4:3:2:1: Accumulative Faulty Station Detection O: Normal 1: Error ST :8:7:6:5:4:3:2:1: FEDCBA9876543210	4)	107	006B
8 -	-	90 to 93	005A to 005D
2) — 24 -1760bcbbbcbcbcbcbcbcbcbcbcbcbcbcbcbcbcbcbc	5)	100 to 103	
#8 -41000000000000000000000000000000000000	6)		0064 to 0067
56 -49000000000000000000000000000000000000	7) 8)	598 599	0256 0257
Card Data: 00 No Fence Unit or No initial communication 01 Input, partial refresh or remote terminal 10 Output remote unit Accumulative Input Error Detection Accumulative Input Error Detection FDCB49876543210 0000000000000000000000000000000000	-	-	-
	1)	10 to 41	000A to 0029
AJ71PT32-S3 Batch Refresh Data Monitor Screen RESET Chg. MENU END	2)	110 to 141	006E to 008D
Station Transmission Data Receive Data Rece	-	-	-

Coroon overnole	No	Buffer men	nory address
Screen example	No.	DEC	HEX
	1)	300 to 363	012C to 016E
AJ71PT32-S3 Partial Refresh Data Monitor Scr.(1-8) SET/ Data MONIT END	2)	600 to 663	0258 to 0297
Station	-	-	-
	1)	-	-
AJ71PT32-83 I/O Monitor Screen (Extension Mode) Inputs (X) O1 Tx. Comp lete No. 1 1 16 Tx. Complete No. 1200 Tx. Request No. 1 17 Read Complete 17 Read Complete 18 Tx. Complete No. 12 18 Read Request 19 Read Complete 18 Tx. Complete No. 1302 Tx. Request No. 2 18 Tx. Complete No. 1302 Tx. Request No. 2 19 Read Complete 18 Tx. Request No. 13 18 Tx. Complete No. 1404 Tx. Request No. 14 18 Read Complete 18 Tx. Complete No. 15 18 Read Request 19 Read Complete 19 Read Request 10 Read Request 19 Read Complete 19 Read Complete 19 Read Request 19 Read Complete 19 Read Complete 19 Read Request 19 Read Complete 19 Read Complete 19 Read Request 19 Read Complete 19 Read Request 19 Read Request 19 Read Complete 19 Read Request	-	-	-

Caraga ayamala	Na	Buffer mem	ory address
Screen example	No.	DEC	HEX
	1)	-	-
A1SD61 Operation Monitor Screen (CH1,2) SEL/7 Data MONII END ASSET Chg. MENU END	2)	-	-
Y10 Count Enable Y15 Limit Switch Output Y14 Counter Function Start Value 714 Counter Function Start Counter Function	3)	11	000B
Y12 Preset Command Counter Setting: O 5) Count Value 65536—8)	4)	12 to 147	000C to 0093
1) — 0: No setting Value	5)	5	0005
XOA External Preset Y16 Reset Ext. Preset 2: Sampling counter 3: Periodic pulse counter 3: Periodic pulse counter	6)	-	-
Y17 Frron Reset	7)	0, 1	0000, 0001
2) — WDT Error LS. 0/P 87654321 0: A-Phase I/P and status 0.0000000 decremental count	8)	2, 3	0002, 0003
No. of No. of Dogs ON CH.1 OFF Dogs ON CH.2 OFF 1/P	9)	6, 7	0006, 0007
0 2: 2-Phase I/P X 1 D 0 0 0 0 0 0 0 3: 2-Phase I/P X 2	10)	8, 9	0008, 0009
0 1 0 0 1 65536 0 4: 2-Phase I/P X 4 3 0 0 4: 3	11)	4	0004
4)	-	-	-
CCT / Cote (MANUT)	1)	-	-
Als061 Input / Output Monitor Screen Sest Chg. MRN Chg	-	-	-

	Buffer me		fer memory address		
Screen example	No.	DEC	HEX		
	1)	0	0000		
A1S64AD Operation Monitor Screen RESET Chg. MENU END	2)	1	0001		
Channel No 4321 0: A/D Conversion Disabled	3)	2 to 5	0002 to 0005		
Setting 0000011010100100 1: A/D Conversion Enabled Sample/Average Time/Count Sample/Average Time/Count	4)	10 to 13	000A to 000D		
	5)	18	0012		
Setting 00001001 11000100 1: Averaging 1: Time Average	6)	20	0014		
Time/Count Input Status [X] Input Status [X] Resolution 2 Resolution 3	-	-	-		
	1)		-		
Als64AD Input/Output Monitor Screen SELV Data MANU BID	- 1)	- 10 to 13	- 000A to 000D		
AISSAAD Cook Maritan Const			-		
A1S64AD Graph Monitor Screen RESET Che. MENU EVU	3)	<u>-</u>	0014		
Input [%] 0 . 50 . 100 0 . 50 . 100 0 . 50 . 100	4)		-		
Channel 1 Channel 2 Channel 3 Channel 4 Resolution Setting: 0 Error WDT Error	-	-	-		

6.5.19 A1S64AD module monitoring

6.5.20 A1S62DA module monitoring

Caraon	ovemble	No.	Buffer mem	ory address
Scieen	example	INO.	DEC	HEX
	OCT / I DOWN THE WORLD	1)	0	0000
A1S62DA Operation Monitor Screen	RESET Chg. MENU END	2)	1	0001
Analog Output Enable/Disable	Channel 1 Channel 2	3)	2	0002
Channel No. 21	2) Digital I/P 3) Digital I/P	4)	=	-
0000011010100100	2500 1000	5)		
X00 WDT Error Flag 4) ——X01 D/A Conversion READY	DT Error Flag Y10 CH2 D/A Output Enable Flag /Y1 CH1 D/A Output Enable Flag /Y16 Error Flag Y18 Error Reset			
V Output [%] AC Output [%] Channel 1 0 50 100 Channel 1 0 50 100 1/4000 3	7)	1, 2	0001, 0002	
	1/ 4000 8)	8)	1, 2	0001, 0002
6) — 1/8000 7) — 1/12000 Channel 2 0 50 100	1/ 8000 1/12000 1 50 100	9)		
5) — 1/4000 6) — 1/8000	1/ 4000 1/ 8000 1/ 8000	10)		
7) — 1/12000	1/12000 - 10)	11)	10	000A
CH1 Check Code CH2 Check Code C8 0 Resoluti	on Setting 0[1:1/4000,2:1/8000,3:1/12000]	12)	11	000B
		13)	9	0009
	 13)	-	-	-
, 12)	,			

6.5.21 A1SD70 module monitoring

Refer to the following for further information about the screen for A1SD70 and the buffer memory address. 6.5.13 AD70 module monitoring

		Buffer mem	ory address
Screen example	No.	DEC	HEX
	1)	10, 11	000A, 000B
A1S62RD Operation Monitor Screen RESET Chg. MENU END	2)	18 to 21	0012 to 0015
Temp. Value [C] Temp. Value [C] Time/ Disabled/Enabled 21	3)	2, 3	0002, 0003
(16 bits) (32 bits) Count 0000000010011010 1 1) 360.0 2) 380.487 3) 0 1: Enabled 0: Disabled	4)	0	0000
2 600.0 600.000 1 Conversion 21 00000000000000000000000000000000000	5)	35	0023
0000000000001 + 5)	6)	1	0001
1: Completed 0: Not Completed Average/Sample Time/Count	_,	-	-
21 21 00000011 1101000	7)	34	0022
1: Averaging 1: Time Average	8)	36	0024
	9)	-	-
CH.1 Disconnection detection CH.2 Disconnection detection CH.2 Disconnection detection			
7) — HError Code: 100 0:New JIS,DIN 1:01d JIS			
	-	-	-
8) 9)			
6) 9)			
	1)	-	-
A1S62RD Input/Output Monitor Screen RESET Chg. MENU END			
Inputs (X)			
03			
95 5 5 6 6 6 7 7 7 7 7 7 7			
08 18 08 18 19 19 19 19 19 19 1			
22 Error Detection 2		_	_
		-	-
OF IF DF IF			
ecctivis shorts the transfer of the transfer o	1)	10, 11	000A, 000B
A1862RD Graph Monitor Screen RESET Chg. MENU END	2)	0	0000
T V 500 Disabled/Enabled 21 0000000010011010	3)	35	0023
m 1 400 _ 1: Enabled 0: Disabled	4)	1	0001
p u 100 e e 300 - Conversion 21 - 3)	5)	-	-
t C 200 - 1: Completed 0: Not Completed	٥,	34	0022
u 100 - Average/Sample Time/Count	6)	36	0024
e	7)	=	-
-100 - 1: Averaging 4) 1: Time Average 0: Sampling 0: Count Average			
1 2 Channel 1 disconnected			
Channel 2 disconnected Channel 2 disconnec			
5) —		-	_
		•	_
6) 7)			
U)			

6.5.23 A1SJ71PT32-S3 module monitoring

Refer to the following for further information about the screen for A1SJ71PT32-S3 and the buffer memory address.

6.5.17 AJ71PT32-S3 module monitoring

		Buffer mem	ory address
Screen example	No.	DEC	HEX
	1)	0	0000
A1S63ADA Operation Monitor Screen SESET/ IData WONIT END	2)	15	000F
Enable 0: Disable 1: Enable A/D Conversion 0: Not Completed 1: Completed	3)	1	0001
CH No. 321 CH 21 - 2)	4)	2, 3	0002, 0003
	5)	11, 12	000B, 000C
Sample/Average Time/Count Sample/Average Count/Time	6)	4	0004
Setting 0000001111101000 1: Averaging 1: Time Average	7)	5	0005
Time/Count Input Status [%] Input Status [%] Input Status [%] Value Resolution 1 Resolution 2 Resolution 3	8)	10	000A
4) — CH 1 0 3.0 1.5 1.0 CH 2 1 3.0 1.5 1.0	9)	13	000D
5) — Upper Limit Lower Limit Digital Value Simple Loop Contro	10)	16	0010
CH 3 1000 7\000 8\1000 9\1000	11)	14	000E
6) Error Code 500 Resolution Setting 0 [1:1/4000,2:1/8000,3:1/12000]	11)	14	000L
10) 11)	-	-	-
	1)	-	-
A1S63ADA Simple Loop Control Monitor Screen RESET Data MONIT END	2)	6	0006
Exec.Enable 0: Disabled 1: Enabled Point Channel 1 Channel 3	3)	7, 8, 9	0007, 0008, 0009
1) — Y11 0 Coordinate Coordinate Coordinate	4)		
0: Normal 1 1 0 9	5)	18 to 37	0012 to 0025
1: y = AX1 + BX2 + C 2: y = AX1 + C 3 0 0	6)	17	0011
2) - 1: y = AX1 + BX2 + C 2: y = AX1 + C 3: y = AX1 + C 32: y = AX1 + C 4 0 0 5 0 0 A. B. C : Constant	7)	16	0010
A, B, C : Constant y : CH3 D/A Digital Value 8 100 1 X1 : CH1 A/D Digital Value 9 0	8)	14	000E
3) — Constant A 1.00	-	-	-
	1)	-	-
Inputs (X)	-	-	-

1) 800 0320 900 0384 1 801 0321 901 0386 1 2) 812 032C 912 0390 1 2) 813 0320 913 0380 1 4) 807 0327 907 0380 1 3) 808 0328 909 0380 1 4) 807 0327 907 0388 1 4) 807 0327 907 0388 1 4) 807 0327 907 0388 1 4) 807 0327 907 0388 1 4) 807 0327 907 0388 1 5) 808 0328 909 0380 1 6) 808 0328 909 0380 1 6) 808 0328 909 0380 1 7) 829 0330 929 0380 1 7) 829 0330 929 0380 1 7) 829 0330 929 0381 1 7)					But	fer mem	ory addre	ess	
1) 800 0320 900 0384 1 801 0321 901 0385 1 2) 812 032C 912 0390 1 3) 801 0321 901 0385 1 2) 813 0320 913 0391 1 3) 809 0329 909 0380 1 4) 807 0327 907 038 038C 1 4) 807 0327 907 038 038C 1 5) 808 0328 908 038C 1 7) 829 0330 929 038A 1 7) 820 0330 929 03A 1 7) 820 0330 929 03A 1 7) 820 0330 92	Screer	example	No.	Ax	s 1	Ax	is 2	Ax	is 3
1)				DEC	HEX	DEC	HEX	DEC	HEX
10			1)	800	0320	900	0384	1000	03E8
2)	AD75P Operation Monitor Scre	SET/ Data MONIT en RESET Chg. MENU END	')	801	0321	901	0385	1001	03E9
3) 809 0329 909 0380 1 4) 807 0327 907 0388 1 5) 808 0328 908 0380 1 5) 808 0328 908 0380 1 7) 829 0330 929 0341 1 8) 808 0328 908 0380 1 7) 829 0330 929 0341 1 8) 90 100 111) 7) 80 90 100 111) 1)	[×10 ⁻ -1 um]	is 1 Axis 2 Axis 3	2)	812	032C	912	0390	1012	03F4
2)	[× 10^-5 deg]	567800 12345678 90 1234567890	2)	813	032D	913	0391	1013	03F5
4) 807 0327 907 0328 1 A	[× 10^-2 mm/min] [× 10^-3 inch/min]		3)	809	0329	909	038D	1009	03F1
Action Status From Name Micros Status Status From Name Micros Status Stat	2) — Axis Speed [x 10^-3 deg/min] [PLS/sec]	234567 12345 67 1234567	4)	807	0327	907	038B	1007	03EF
3)		Frror Warning M Code	5)	808				1008	03F0
No. Pattern Method Acc Dec	#1 Stand By	12 12 1234	<u> </u>					1006	03EE
10	#3 Stand By	4) 12 3) 12 0) 1234	<u> </u>	829	033D	929	03A1	1029	0405
7) 8) 9) 10) 11) 11)	#1 123 Positioning Comp	0 0	9)	838	0346	938	03AA	1038	040E
ADTEP I/O Monitor Screen Set Start	7) 8)	9) 10) 11)	,	-	-	-	-	-	-
No.			1)	-	-	-	-	-	-
AD75P Basic Parameter 1 SET Data MONIT EDD Parameter Valid Range 1Axis 2Axis 3Axis 1) — Unit 0:mm 1:inch 2:degree 3:PUSE 0 0 0 0 0 4 3 0003 153 0099 3 2) — Pulse Per Revolution 1 to 65535 [PLS] 1234 1234 1234 1234 1234 1234 1234 1234	00 AD75 Ready 10 01Axis#1 Started 11 02Axis#2 " 12 03Axis#3 " 13 04Axis#1 BUSY 14 05Axis#2 " 16 07Axis#1 Completed 17 09Axis#3 " 19 0Axis#3 " 19 0Axis#1 Error 1A 0BAxis#2 " 18 00Axis#2 " 18 00Axis#1 Error 1A 0BAxis#2 " 18 00Axis#3 " 19 00Axis#3 " 10 00Ax	01						- 300	- 012C
Parameter Valid Range 1Axis 2Axis 3Axis 1) — Unit 2:degree 3:PULSE 0 0 0 0 4) 3 0003 153 0099 3 2) — Pulse Per Revolution 1 to 65535 [PLS] 1234 1234 1234 1234 1234 1234 1234 1234	ADZED Paris Davistan 1	SET/ Data MONIT END						301	012D
1) — Unit 0:mm 1:inch 2:degree 3:PULSE 0 0 0 0 4) 3 0003 153 0099 3 2) — Pulse Per Revolution 1 to 65535 [PLS] 1234 1234 1234 5) 4 0004 154 009A 3 3) — Travel Per Revolution 0:		1Axis 2Axis 3Axis	<u> </u>					302	012E
2) - Pulse Per Revolution 1 to 65535	0:mm 1:inch 1) Unit 2:degree		<u> </u>					303	012F
2) — Pulse Per Revolution 1 to 65535	3:PULSE	, , , , , , , , , , , , , , , , , , ,	<u> </u>					304	0130
3) — Travel Per Revolution 1 to 65535 [× 10^-1 um] [× 10^-5 inch] [× 10^-5 degree] [FLS]	Revolution 1 to 00000	1234 1234 1234	<u> </u>					305	0131
Multiplier 100: x100 1000: x100 123	3) — Travel Per 1 to 65535 × 10 - 1 µm]	1234 1234 1234							
3:A/B Mode(1)	Multiplier 100: x100 1000: x1000								
6) — Notation 1:Reverse Pulses 0 0 0 0	3:A/B Mode(1) (a) Rotation 0:Forward Pulses	0 0 0	-	-	-	-	-	-	-

6.5.25 AD75P/A1SD75P module monitoring

		Buffer memory address							
Screen example	No.	Axi	s 1	Axi	s 2	Axi	s 3		
·		DEC	HEX	DEC	HEX	DEC	HEX		
		6	0006	156	009C	306	0132		
SET/ Data MO AD75P Basic Parameter 2 RESET Chg. ME	INIT END 1)	7	0007	157	009D	307	0133		
Parameter Valid Range 1Axis 2Axis 3	Axis	8	8000	158	009E	308	0134		
1 to 600000000	2)	9	0009	159	009F	309	0135		
[×10^-2 mm/min] 1 to 600000000	3)	10	000A	160	00A0	310	0136		
1) — Speed Limit $\begin{bmatrix} x \hat{10}^{\circ} - \hat{3} & \text{inch}/m_{\text{in}} \end{bmatrix}$ 1 to 600000000 12345678 123458678 12 12458678	2345678	11	000B	161	00A1	311	0137		
1 to 1000000 [PLS/sec]									
2)Accel.Time #0	123456								
2) /000000 [msec]									
3) — Decel.Time #0	123456								
	-	-	-	-	-	-	-		
	1)	15	000F	165	00A5	315	013B		
SET/ Data MO	NIT END ON	16	0010	166	00A6	316	013C		
Parameter	Axis3 2)	17	0011	167	00A7	317	013D		
Compensation L×10"-5 degree]	12345	18	0012	168	8A00	318	013E		
2) — Upper S/W		19	0013	169	00A9	319	013F		
2) — Opper 37W [x 10°-5 inch] 1234567890 1234567890 1 Stroke Limit [PLS]	1234567890 4)	20	0014	170	00AA	320	0140		
0 to 35999999 [× 10^-5 degree] -2147483648	5)	21	0015	171	00AB	321	0141		
to 2147483647	6)	24	0018	174	00AE	324	0144		
' Stroke Limit PLS]	1234567890								
0 to 35999999 [× 10^-5 degree] 4) — S/WStrokeLimModel0:ValComman 1:ValMechan 0: 1									
5) — S/WStrokeLimit 0:Disabled 1:Enabled 0 0	0								
6) — Torque Limit 1 to 500 [%] 123 123	123	-	-	-	-	-	-		
		36	0024	186	00BA	336	0150		
SET/ Data WO AD75P Extended Parameter 2 RESET Chg. WE	NIT END 1)	to	to	to	to	to	to		
	Axis3	41	0029	191	00BF	341	0155		
Accel_Time#1 1 to 65535 123456 123456	123456	42	002A	192	00C0	342	0156		
	2)	to	to	to	to	to	to		
1) { Accel.Time#2	123456	47	002F	197	00C5	347	015B		
Accel.Time#3	123456								
Decel.Time#1 1 to 65535 123456 123456 123456	123456								
2) Decel Time#2	123456								
Decel.Time#3	 123456 -	_	-	_	_	_	-		
/8388608 [msec]									
+									
	I	1							

		Buffer memory address							
Screen example	No.	Ax	s 1	Ax	is 2	Axi	s 3		
		DEC	HEX	DEC	HEX	DEC	HEX		
	1)	70	0046	220	00DC	370	0172		
AD75P OPR Basic Parameter RESET Chg. MENU END	2)	71	0047	221	00DD	371	0173		
Parameter Valid Range 1Axis 2Axis 3Axis 0:D0G 4:Count#1	3)	72	0048	222	00DE	372	0174		
0:DOG 4:Count#1 1) — Method 1:Stopper#1 5:Count#2 0 0 0	0)	73	0049	223	00DF	373	0175		
1) — Method 2:Stopper#2 3:Stopper#3 2) — Direction 0:Foruard 1:Reverse 0 0 0	4)	74	004A	224	00E0	374	0176		
	.,	75	004B	225	00E1	375	0177		
3) — Address [×10°-5 inch] 1231456789 123456789 123456789	5)	76	004C	226	00E2	376	0178		
0 to 35999999 [×10^-5 deg]		77	004D	227	00E3	377	0179		
0 to 35999999	6)	78	004E	228	00E4	378	017A		
1 to 1000000									
5) — Creep Speed [x 10 -3 inch/min] 123456789 123456789 123456789 123456789									
6) — Return Retry 0:No Retry 1:retry	_	-	-	-	_	-	_		
	4.	70	00.45	000	0055	070	0475		
ACCED OOD Extraded Description	1)	79	004F	229	00E5	379	017B		
AD75P OPR Extended Parameter RESET Chg. MENU Parameter Valid Range 1Axis 2Axis 3Axis	2)	86	0056	236	00EC	386	0182		
OPR 0 to 85535 r 3 1234 1234 1234	3)	80	0050	230	00E6	380	017C		
2) OPR	4)	81 82	0051 0052	231	00E7 00E8	381 382	017D 017E		
2) Torque Limit [%] 12 12 12 12 3) — Travel Distance 2147483647 [×10°-5 inch] 123456789 123456789 123456789	4) 5)	83	0052	232	00E9	383	017E		
PLSI:	3)	84	0054	234	00EA	384	0180		
4) — OPR	6)	85	0055	235	00EB	385	0181		
5) — OPR 0 to 3 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		- 00	0000	200	OOLD	000	0101		
OP Distance to 2147483647									
6) — From Zero [×10^-1 µm] [×10^1 inch] 1234567890 1234567890 1234567890									
0 to 35999999 [×10^-5 deg]	_	-	-	-	_	-	_		
	1)	816	0330	916	0394	1016	03F8		
AD75P External Input/Output . Status Info RESET Chg. MGNUT END	2)	817	0331	917	0395	1017	03F9		
[External I/O] [Status Info]									
#1 #2 #3 #1 #2 #3									
Drive Unit Ready OFF OFF ON V-Control ON OFF OFF Zero Phase Signal ON OFF OFF OFF V/P Switch Latch OFF ON OFF In-Positio Signal OFF OFF OFF OM In-Position OFF OFF OFF OFF Stop Signal OFF OFF OFF ON OPR Request OFF ON OFF OFF OFF Upper Limit ON ON ON Axis Warning OFF OFF OFF OFF OFF OFF OFF OFF OFF OF									
Zero Phase Signal ON OFF OFF V/P Switch Latch OFF ON OFF In-Positio Signal OFF OFF OFF OM In-Position OFF OFF OFF OFF OWN OFF OFF OFF OWN OFF OFF OFF OFF OWN									
DOG Signal OFF OFF OFF OFR Request OFF ON OFF Stop Signal OFF OFF ON OPR Completion OFF OFF OFF Upper Limit ON ON ON Axis Warning OFF OFF ON Lower Limit ON OFF OFF Speed Change O OFF OFF OFF External Start ON ON ON UP ABS Over ON OFF ON UVP Switch ON OFF OFF OFF OFF OFF OFF OFF OFF OFF									
Lower Limit ON OFF OFF Speed Change O OFF OFF OFF External Start ON ON ON OP ABS Over ON OFF ON V/P Switch ON OFF OFF OP ABS Under OFF OFF OFF									
DCC Signal Output ON ON ON	_	_	_	_	_	_	_		
1) 2)									

			But	ffer mem	ory addr	ess	
Screen example	No.	Ax	is 1	1	is 2		is 3
Corcer example	110.	DEC	HEX	DEC	HEX	DEC	HEX
		818	0332	918	0396	1018	03FA
AD75P Destination . Mechanical Val RESET Chg. MENU	1)	819	0333	919	0397	1019	03FB
		802	0322	902	0386	1002	03EA
Axis1 Axis2 Axis3	2)	803	0323	903	0387	1003	03EB
[×10 ² -1 µm] 1) — Destina [×10 ² -5 inch]							
Mechanical [× 10^-1 ym]							
2)							
	-	-	-	-	-	-	-
SET/IData WWWT	1)	820	0334	920	0398	1020	03FC
AD75P Output Speed RESET Chg. MENU END		821	0335	921	0399	1021	03FD
Axis1 Axis2 Axis3	2)	810	032A	910	038E	1010	03F2
[\times 10^-2 mm/min]		811	032B	911	038F	1011	03F3
7 Speed [×10 -3 deg/min] [PLS/sec]	3)	812	032C	912	0390	1012	03F4
Speed		813	032D	913	0391	1013	03F5
[PLS/sec] [×10^-2 mm/min]							
3) — Axis [x 10 -3 inct/min]							
1 20/ 300/							
	-	-	-	-	-	-	-
	1	44-1	0.400	4001	0.45 :	407	0.450
SET/ Data MONITI END	1)	1154	0482	1204	04B4	1254	04E6
AD 15P AXIS CONTROL Data NEBEL MINE, WELL		1155	0483	1205	04B5	1255	04E7 04E8
Axis1 Axis2 Axis3	2)	1156 1157	0484 0485	1206 1207	04B6 04B7	1256 1257	04E8
1) — [× 10 ⁻ 1 μm] Correcting [× 10 ⁻ 5 inch] 0 0 0 Address [× 10 ⁻ 5 deg]	3)	1157	0465	1207	04B7	1257	04E9
[×10°-2 mm/min]	4)	1172	0494	1209	04B9	1272	04EB
2) — Correcting(×10 -3 inch/min) 0 0 0 0 0 0 Speed [×10^-3 deg/min] 0 0 0 0 0 0 0 0 0 0 0	5)	1173	0495	1223	04C0	1272	04F9
3) — Speed Dump (%) 12 12 0 4) — Step Valid Flag 0:Disable 0 0 0	6)	1175	0497	1225	04C9	1275	04FB
(5) Stop Mode 0:Dec Unit 0	7)	1171	0493	1221	04C5	1271	04F7
o) or o O:Completed	-,			 -			
6) — skip Command 1:Reg 0 0 0 0 7) — EXT.Start Enable 0:Disable 0 0 0 0							
	-	-	-	-	-	-	-
	<u> </u>						



		Buffer memory address							
Screen example	No.	Axi			is 2	Axis 3			
· ·		DEC	HEX	DEC	HEX	DEC	HEX		
		624	0270	624	0270	624	0270		
AD75P Error History . Warning History RESET Chg. MENU END	1)	to	to	to	to	to	to		
[Error History] [Warning History]		687	02AF	687	02AF	687	02AF		
No. Ax. Code Time No. Ax. Code Time		689	02B1	689	02B1	689	02B1		
1 1 0 00:00:00.00 1 0 0 00:00:00.00 2 2 0 0 00:00:00.00	2)	to	to	to	to	to	to		
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$		752	02F0	752	02F0	752	02F0		
1 1 0 00:00:00:00 1 0 0 00:00:00.00 0 0 0 0 0 0 0 0 0 0 0 0	-	-	-	-	-	-	-		
		543	021F	543	021F	543	021F		
AD75P Start Error, Start History RESET Chg. MEMU	1)	to	to	to	to	to	to		
AD75P Start Error, Start History SESET Chg. MENU EU [Start Error History] [Start History]	- /	622	026E	622	026E	622	026E		
No.Ax. Start Mode Time Res. No.Ax. Start Mode Time Res.		462	01CE	462	01CE	462	01CE		
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	2)	to	to	to	to	to	to		
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$		541	021D	541	021D	541	021D		
1 1 00 0 00:00:00:00 0 0 1 0 00 00:00:00.00 0 0 0 0 00:00:00.00 0 0 0	-			-	-	-	-		
	1)	1300	0514	2300	08FC	3300	0CE4		
AD75P Positioning Information Monitor Screen W58ET Chg. WENT END	2)	to	to	to	to	to	to		
No. Pat Me	-		08FB	3299	OCE3	-	10CB		

			Buffer mem	ory address	
Screen example	1)	ıxis			
'		DEC	HEX	DEC	HEX
	1)	-	-	-	-
AJ71ID	-		-	-	-
	1)	0	0000	4000	0FA0
ISST/ (Data (MINIT)	0)	1	0001	4001	0FA1
AJ/IID Set Up Information Monitor Screen Rassel Ung. Flature Valid range CH1 CH2	2)	2	0002	4002	0FA2
Valid range CH1 CH2	3)	8	8000	4008	0FA8
• • • • • • • • • • • • • • • • • • • •	4)	22	0016	4022	0FB6
3) — Retry 0~32767 0 0	4)	23	0017	4023	0FB7
4) — Total Communica. 0 0	5 \	4	0004	4004	0FA4
5) ————————————————————————————————————	5)	5	0005	4005	0FA5
6) ————————————————————————————————————	6)	-	-	4010	0FAA
7) ————————————————————————————————————	7)	12	000C	4012	0FAC
Err Record Latst		14	000E	4014	0FAE
Past 1	8)	to	to	to	to
8) ——- Past2 Past3 Past3		18	0012	4018	0FB2
Past4	-	-	-	-	-
		100	0064	4100	1004
AJ71ID Movement Monitor Screen CH1 SET Chg. MENU END	1)				to
		163	00A3	4163	1043
Addr Data Addr Data Addr Data Addr Data K 1000 H FFFF K 1166 H 0 K 1322 H 0 K 148 H 0 K 149 H 0 K 1012 H 0 K 117 H 0 K 133 H 0 K 149 H 0 K 102 H 0 K 118 H 0 K 134 H 0 K 150 H 0 K 102 H 0 K 119 H 0 K 135 H 0 K 150 H 0 K 105 H 0	-	-	-	-	<u>-</u>

6.5.26 AJ71ID1(ID2)-R4/A1SJ71ID1(ID2)-R4 module monitoring

		N-	Buffer men	nory address
S	creen example	NO.	DEC	HEX
		1)	0	0000
A1S68DAV Movement Monitor Scre	SET/ Data MON gen RESET Chg. ME	2)	1 to 8	0001 to 0008
С Н 87	<u> </u>	3)	10 to 17	000A to 0011
Analog Output OOG	0 : Enabled	No. DEC 1) 0 2) 1 to 8 3) 10 to 17 4) 10 to 17 Low Limit 1) - 11 Enable 12 Enable 13 Enable 14 Enable 15 Enable 16 Enable 17 Enable 17 Enable 18 Enable 19 Enable 19 Enable 10 Enable 10 Enable 10 Enable 11 Enable 12 Enable 13 Enable 14 Enable 15 Enable 16 Enable 17 Enable 18 Enable 19 Enable 19 Enable 19 Enable 10 Enable 10 Enable 10 Enable 11 Enable 12 Enable 13 Enable 14 Enable 15 Enable 16 Enable 17 Enable		000A to 0011
1) —	1: Disabled but Status [%] Up Limit Low		-	-
		1)	-	-
A1S68DAV Input/Output Monitor S	SET/ Data MON Goreen RESET Chg. ME	IT I		
DO WDT Error 10 11 12 12 13 13 14 15 15 16 16 17 17 18 18 19 19 19 10 10 10 10 10	00 10 CH1 Enab 01 11 CH2 Enab 02 12 CH3 Enab 03 13 CH4 Enab 04 14 CH5 Enab 05 15 CH6 Enab 06 16 CH7 Enab 07 17 CH8 Enab 09 19 0A 1A 08 18 00 10 00 10 00 10 00 10 00 10 00 10 00 10 00 10 00 10 00 10 00 10 00 10 00 10 00 10	-	-	-
	SET/ (Data MON	IT I		0001 to 0008
A1S68DAV Graph Monitor Screen Output [%] 0	RESET Chg. ME	2)		0000
CH 1 CH 2 CH 3 CH 4 CH 5 CH 6 CH 7 CH 8 CH 8 CH 8 765432 Analog Output CH 8 7000000	0 : Enabled WOT E	-	-	-
2)	3)			

6.5.28 A1S68DAI module monitoring

Refer to the following for further information about the screen for A1S68DAI and the buffer memory address. 6.5.27 A1S68DAV module monitoring

		Buffer me	mory address
Screen example	No.	2) 2 0002 3) 2 0002 4) 28 0010 5) 10 to 17 000A to 0 6) 20 to 27 0014 to 0	
	1)		0000
ISET/ Data MONI A1S8SAD Movement Monitor Screen RESET Chg. MEN	Ti	2	0002
C H 87654321		2	0002
1) A/D Conversion 0000001 0: Disabled 1: Enabled	4)	28	001C
2) A/D Method OOOOOOO 0: Sampling 1: Averaging	^{1g} 5)	10 to 17	000A to 0011
3) — Averaging 00000000 0: Number 1: Time	6)	20 to 27	0014 to 001B
4) A/D Conversion OOOOOOO 0: Incomplete 1: Complete Averaging Time/Number Input Status [%	7)	1	0001
CH 1		-	-
	1)	_	
A1568AD Input/Output Monitor Screen X		-	-
A1S68AD Graph Monitor Screen RESET Dag. MEN	TI -		
A1S68AD Graph Monitor Screen Input [%] CH 1 CH 2 CH 3 CH 4 1) CH 5 CH 6 CH 7 CH 8 WDT Error		-	-

6.5.30 A1S64TCTT(BW)/A1S64TCRT(BW)-S1 monitoring

									Buffe	r mem	ory add	dress		
	Screen	example				No.	Cl	- 11	CI	1 2	CI	- 13	CI	H4
							DEC	HEX	DEC	HEX	DEC	HEX	DEC	HEX
						1)	32	0020	64	0040	96	0060	128	0080
A1S64TCTT/RT-S1 Operation N	Monitor Scre	en (ALL CH)	SET/ RESET	Data M Chg.	MENU END	2)	32	0020	64	0040	96	0060	128	0080
	CH1	CH2	CH3		CH4	3)	1	0001	2	0002	3	0003	4	0004
1) — Input range 2) — Measurement unit	°C	Wre5-26 °C	°C		JPt100 °C	4)	9	0009	10	000A	11	000B	12	000C
3) — Decimal point position	0	0	0		0	5)	34	0022	66	0042	98	0062	130	0082
Temp. Decimal point =0	0	0	C)	0	6)	13	000D	14	000E	15	000F	16	0010
4) — process — Decimal (PV) point =1	0.0	0.0)		7)								
5) — Set value point =0	120	0)		8)	-	-	-	-	-	-	-	-
setting Decimal (SV) point =1	12.0	0.0)		-,								
6) — Manipulation value(MV)	100 0	100 0		100 0	100									
7) — Alert occurrence flag				 _										
8) — Write error flag						_	_	_	_	_	_	_		
						1)	5	0005	6	0006	7	0007	8	0008
A1S64TCTT/RT-S1 Alert detai			SET/ RESET	Data Data	MENU END									
		CH1	CH2	CH3	CH4									
PV exceeds the specified ter measurement range in	the input r	ange.			•									
PV is below the specified to measurement range in	emperature													
Hardware error occurs.														
Alert alarm 1 is turned on.			•	•	•									
1) Alert alarm 2 is turned on.			•											
Alert alarm 3 is turned on.						_					_		1	
Alert alarm 4 is turned on.					<u> </u>	-	_	_	_	-	_	_	-	-
The heater disconnection alo	arm is detect													
The loop disconnection is de	etected.													
The"current error when the output is	off"isdeted	eted.												

Screen example No.	No.	Buffer memory address							
		CH1		CH2		CH3		CH4	
	DEC	HEX	DEC	HEX	DEC	HEX	DEC	HEX	
	1)	32	0020	64	0040	96	0060	128	0800
4) 8) 5) 12)	2)	32	0020	64	0040	96	0060	128	0800
	3)	1	0001	2	0002	3	0003	4	0004
A1S64TCTT/RT-S1 (peration Monitor Screen(CH1) SET/ Data VONIT END	4)	9	0009	10	000A	11	000B	12	000C
1) — Input range Measurement unit Dec. point position 0 - 3)	5)	34	0022	66	0042	98	0062	130	0082
Pro.Val. Dec.P.P.=0 400 Set Val.Dec.P.P.=0 \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	6)	13	000D	14	000E	15	000F	16	0010
7) — Proportinal s.(P) 0.0% Integral time(I) 0 sec Derivative time(D) 0 sec 9) 10) — Write error From address 2 Cause Write is allow only in the set mod 12)	7)	35	0023	67	0043	99	0063	131	0083
11) — Alert alarm No 1 2 3 4	8)	36	0024	68	0044	100	0064	132	0084
13) — Set.Val.Dec.P.P.=0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	9)	37	0025	69	0045	101	0065	133	0085
14) — Mode setting O O O O	10)	-	-	-	-	-	-	-	-
15) — Heat.cur.pro.vli Heat.val.com.set Output Upper 0.0 % - 18) CT selection 0 400.0 Å 0.0 Å Limiter Lower 0.0 % - 19)	11)	0	0000	0	0000	0	0000	0	0000
1 40.00 A 0.00 A Alert occurrence flag Normal Graph	12)	0	0000	0	0000	0	0000	0	0000
20) PV		38	0026	70	0046	102	0066	134	0086
400 -2000 0 8000	13)	to 41	to 0029	to 73	to 0049	to 105	to 0069	to 137	to 0089
		160	00A0	160	00A0	160	00A0	160	00A0
	14)	to	to	to	to	to	to	to	to
10) (7)		163	00A3	163	00A3	163	00A3	163	00A3
16) 17)	15)	57	0039	89	0059	121	0079	153	0099
	16)	25	0019	26	001A	27	001B	28	001C
	17)	171	00AB	172	00AC	173	00AD	174	00AE
	18)	42	002A	74	004A	106	006A	138	008A
	10)	43	002B	75	004B	107	006B	139	008B
	19)	-	-	-	-	-	-	-	-
	20)	9	0009	10	000A	11	000B	12	0000

6.5.31 Q68ADV/Q68ADI/Q64AD module monitoring


Caraca ayamala	No.	Buffer memory address			
Screen example		DEC	HEX		
	1)	0	0000		
Q68ADV/Q68ADI/Q64AD Operation Monitor SET/ Data MONIT END 6)	2)	10	000A		
Ohannely 8 7 8 5 4 3 2 1 SERRORX A/U conv 100 1000 1000 0 Used 170FT A/U conv 100 0 Used 170FT A/U conv 100 0 Used 170FT A/	3)	9	0009		
2) — complete Didididididididi i completed CHI 2500 0 0 0	4)	9	0009		
3) — Average GOOOOOO 1 0: samp ling CH2 0 0 0	5)	20, 21	0014, 0015		
4) — selfting	6)	19	0013		
	7)	1 to 8	0001 to 0008		
Channel 8 3 7 8 5 4 3 2 1. Setting range HEX COORD ACCOUNT Time Court Output Minimum Max mum.	8)	11 to 18	000B to 0012		
034 to 20(ma)/719 to 20(ma)/21 to 5(9) 339 to 5(9) /4:-10 to +10(9) 510 to +10(9)/F:User range setting 047 0 0 0	9)	30, 32, 34, 36, 38, 40, 42, 44	001E, 0020, 0022, 0024, 0026, 0028, 002A, 002C		
	10)	31, 33, 35, 37, 39, 41, 43, 45	001F, 0021, 0023, 0025, 0027, 0029, 002B, 002D		
5) 7) 8) 9) 10)	-	-	-		
	1)	-	-		
OSBADV/088ADI/084AD Input/Output Monitor X OO Module READY OS High resolution OI Temp. drift comp. O9 Operation set OS OB Ch. change done OF OF OF CHAPT COMP. OF STREET Chg. OF Chg	- 1)	- 11 to 18	- 000B to 0012		
Q68ADV/Q68ADI/Q64AD Graph Monitor	2)	-	-		
CH1: CH2: CH3: CH3: CH3: CH3: CH3: CH3: CH3: CH3	-	<u>-</u>	-		

	П	Buffer mem	ory address
Screen example	No.	DEC	HEX
	1)	0	0000
Q62DA/Q64DA Operation Monitor SET/ Data MONIT Chg. MENU END	2)	20	0014
Channe OError code (1002	3)	1 to 4	0001 to 0004
1) — D/A 01100 0:enable 1:diseble	4)	11 to 14	000B to 000E
014 to 20(mA) 1:0to20(mA)	5)	19	0013
2) — 3 0000 014 to 20(mk) 1:0to20(mk) 2:1 to 5(V) 3:0 to 5(V) 4:-10to+10(V) 14:-10to+10(V) 5:0t value Gyer Under Gyer Und	-	-	-
Q62DA/Q64DA Input/Output Monitor	1)	-	-
Module READY No Op.cond.set done No Offset/vain mode No Op.cond.set done No Op.cond.set req, No Op.cond.set r	-	-	-
Q62DA/Q64DA Graph Monitor	1)	11 to 14	000B to 000E
4) —	2)	11 to 14	000B to 000E
CHI	3)	1 to 4	0001 to 0004
3) {	-	- -	-


Buffer memory address Screen example No. DEC HEX 00 to 01 0000 to 0001 1) QD62D/QD62E/QD62 Operation Monitor 32 to 33 0020 to 0021 02 to 03 0002 to 0003 2) 34 to 35 0022 to 0023 2) 3) 04 to 05 0004 to 0005 4) 3) 36 to 37 0024 to 0025 5) 06 to 07 0006 to 0007 4) 0026 to 0027 38 to 39 5) 10, 42 000A, 002A 8) 000C to 000D 12 to 13 10) 6) 002C to 002D 44 to 45 14 to 15 000E to 000F 7) 002E to 002F 46 to 47 16 to 17 0010 to 0011 8) 48 to 49 0030 to 0031 12) 13) 14) 18 to 19 0012 to 0013 9) 50 to 51 0032 to 0033 20 to 21 0014 to 0015 10) 52 to 53 0034 to 0035 22 to 23 0016 to 0017 11) 54 to 55 0036 to 0037 12) 08, 40 0008, 0028 13) 11, 43 000B, 002B 14) 09, 41 0009, 0029 1) QD62D/QD62E/QD62 Input/Output Monitor 1)

6.5.33 QD62D/QD62E/QD62 module monitoring


		Buffer memory address				
Screen example	No.	DEC	HEX			
		800 to 801	0320 to 0321			
QD75P/QD75D Operation Monitor SET/ Data MONIT FND -2)		900 to 901	0384 to 0385			
1) Axis Start No. Operation pattern	1)	1000 to 1001	03E8 to 03E9			
2 0 0 0 2 0 Positioning comp 2 0 Positioning comp		1100 to 1101	044C to 044D			
4 0 0 0 Positioning comp (un)(xi(t) (mm/mix)(xi(t) 4 0 Positioning comp 8)		812 to 813	032C to 032D			
unit (degree)::10* (degree/min)::10* (inch)::10* (inch)::10* (inch)::10* (pulse)::10* (pulse)::20* (pulse):20* (pulse)::20* (pulse)::20* (pulse)::20* (pulse)::20* (pulse)::20* (pulse)::20		912 to 913	0390 to 0391			
3) — (pulse) ** (pulse) ** (2)	1012 to 1013	03F4 to 03F5			
Axis Status Standby Axis Control system Int. Acc. Dec. Axis Control system Axis Axi		1112 to 1113	0458 to 0459			
Axis St. tus Stands 2	3)	809, 909, 1009, 1109	0329, 038D, 03F1, 0455			
Axis Stitus Stands 4 For : Warping: O Mepde:	4)	806, 906, 1006, 1106	0326, 038A, 03EE, 0452			
	5)	807, 907, 1007, 1107	0327, 038B, 03EF, 0453			
	6)	808, 908, 1008, 1108	0328, 038C, 03F0, 0454			
4) 5) 6) 9) 10) 11) 12)	7)	829, 929, 1029, 1129	033D, 03A1, 0405, 0469			
	8) to 12)	838, 938, 1038, 1138	0346, 03AA, 040E, 0472			
QD75P/QD75D Input/Output Monitor	1)	-	-			
CD75 READY CD7	-	-	-			
QD75P/QD75D Basic parameters 1 SET/ Chg. MCNUT END	1)	0, 150, 300, 450	0000, 0096, 012C, 01C2			
1) — Unit 2 0 0 0 Rotation 0 0 0 0 6) Setting as the Park of the Company of the C	2)	4, 154, 304, 454	0004, 009A, 0130, 01C6			
setting Otmm 1:inch 2:degree 3:pulse setting 1:Reverse run pulse output	3)	1, 151, 301, 451	0001, 0097, 012D, 01C3			
mode 24A p./B p.(multiple of 4) 34A p./B p.(multiple of 1)	4)	2, 152, 302, 452	0002, 0098, 012E, 01C4			
Movement amount exist paris at start Lem	5)	3, 153, 303, 453	0003, 0099, 012F, 01C5			
Movement 4) — amount per rotation(Al) assass #[0**[/mg/(deg)] range	6)	5, 155, 305, 455	0005, 009B, 0131, 01C7			
5) — Unit (Am) 0 0 0 to 1000000 (pulse/sec):*1 magnification 17/10/1097/1005/fold	7)	6, 156, 306, 456	0006, 009C, 0132, 01C8			
	-	-	-			




Caroon quantile	Na	Buffer mem	nory address
Screen example	No.	DEC	HEX
		36 to 41	0024 to 0029
QD75P/QD75D Detailed parameters 2-1 SET/ Data MONIT END MENU END		186 to 191	00BA to 00BF
Acc. Axis1 Axis2 Axis3 Axis4 J08:speed limit.value	1)	336 to 341	0150 to 0155
1 123 0 0 0 Axis4 0		486 to 491	01E6 to 01EB
1) { 2		42 to 47	002A to 002F
3 0 0 0 range (degree/min) :=10* Setting range fo 1000000 (oulse/sec):=[192 to 197	00C0 to 00C5
1 to 8383808(msec)	2)	342 to 347	0156 to 015B
Desi Axis1 Axis2 Axis3 Axis4 Item		492 to 497	01EC to 01F0
1 0 0 0 time select 0 0 0 0 (1 to 3 -4)		48 to 49	0030 to 0031
2) { 2		198 to 199	00C6 to 00C7
Setting range	3)	348 to 349	015C to 015D
1 to 3383803(msec)		498 to 499	01F2 to 01F3
	4)	50, 200, 350, 500	0032, 00C8, 015E, 01F4
	5)	51, 201, 351, 501	0033, 00C9, 015F, 01F5
QD75P/QD75D Detailed parameters 2-2	1)	52, 202, 352, 502	0034, 00CA, 0160, 01F6
tem 4x.34x.34x.34x.43et range Allowed circular int. error width Acc/Dec Type 0 0 0 0 0 PRamp Axis: A	2)	53, 203, 353, 503	0035, 00CB, 0161, 01F7
2) — S-pattern 7 0 0 0 0 0 1-100(2) 3 (µm):=101 8) 3) — Judgern -1 0 0 0 0 0 0 Normal Setting 0 to 100000 (inch):=101	3)	56, 206, 356, 506	0038, 00CE, 0164, 01FA
4) — stop 2 0 0 0 1:Sudden range range (degree):=10	4)	57, 207, 357, 507	0039, 00CF, 0165, 01FB
6) — Sudden stop deceleration time External command function selection Axis: A	5)	58, 208, 358, 508	003A, 00D0, 0166, 01FC
1 to 5333693 (ms) 7) Rosition:complete signal output time: Axis1 Axis2 Axis3 Axis4 2/5peed-position, position-speed	6)	54, 204, 354, 504	0036, 00CC, 0162, 01F8
0 0 0 0 sitching request 3/5kip request	7)	59, 209, 359, 509	003B, 00D1, 0167, 01FD
		60 to 61	003C to 003D
		210 to 211	00D2 to 00D3
	8)	360 to 361	0168 to 0169
		510 to 511	01FE to 01FF
	9)	62, 212, 362, 512	003E, 00D4, 016A, 0200



	Ī., Ī	Buffer men	nory address
Screen example	No.	DEC	HEX
QD75P/QD75D I/O signal & Status	1)	816, 916, 1016, 1116	0330, 0394, 03F8, 045C
External input/output signal Status Teem Axx1 Ax.2 Ax.3 Ax.4 Item Ax.1 Ax.2 Ax.3 Ax.4	2)	817, 917, 1017, 1117	0331, 0395, 03F9, 045D
Upper limit signal	-	-	-
		818 to 819	0332 to 0333
QD75P/QD75D Axis monitor data-1 SET/ Data MONIT FND 2)		918 to 919	0396 to 0397
1) Target value Machine feed valve litem 4x.1 4x.2 4x.3 4x.4 Note	1)	1018 to 1019	03FA to 03FB
Axis 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		1118 to 1119	045E to 045F
Axiss 0 0 0 In speed 0 0 0 0 0 0 0 0 0 0 1: In -7)		802 to 803	0322 to 0323
(µm):*10" (degree):*10" (inch):*10" (pulse):*1		902 to 903	0386 to 0387
Citistive to spaise yet	2)	1002 to 1003	03EA to 03EB
Target spd Current spd Feedrate		1102 to 1103	044E to 044F
Axis2 0 0		820 to 821	0334 to 0335
Axis3		920 to 921	0398 to 0399
(mm/min):*10* (slegree/min):*10* (inch/min):*10* (pulse/see):*1	3)	1020 to 1021	03FC to 03FD
(1101 AIIII) **10		1120 to 1121	0460 to 0461
		810 to 811	032A to 032B
		910 to 911	038E to 038F
2) 4) 5)	4)	1010 to 1011	03F2 to 03F3
3) 4) 5)		1110 to 1111	0456 to 0457
		812 to 813	032C to 032D
		912 to 913	0390 to 0391
	5)	1012 to 1013	03F4 to 03F5
		1112 to 1113	0458 to 0459
	6)	830, 930, 1030, 1130	033E, 03A2, 0406, 046A
	7)	831, 931, 1031, 1131	033F, 03A3, 0407, 046B




Caraca	Screen example	No	Buffer memory address	
Screen 6	imple	No.	DEC	HEX
			1530 to 1531	05FA to 05FB
QD75P/QD75D Position-speed control	SET/ Data MONIT END END		1630 to 1631	065E to 065F
RSSC speedschange neg(ster		1) -	1730 to 1731	06C2 to 06C3
Axis3 0 Axis4 0			1830 to 1831	0726 to 0727
0 to 2000000000 (mm/min):*:10* (inch/min):*:10* (degree/min):*:10* 0 to 1000000 (pulse/sec):*:1		2)	817, 917, 1017, 1117	0331, 0395, 03F9, 045D
Item Ax. T Ax. 2 Ax. 3 Ax. 4		3)	817, 917, 1017, 1117	0331, 0395, 03F9, 045D
2) — Position-speed switching latch 3) — In speed control		4)	1532, 1632, 1732, 1832	05FC, 0660, 06C4, 0728
4) Position-speed 0 0 0 0 0 0 0 0 0		-	-	-
			1506 to 1507	05E2 to 05E3
QD75P/QD75D Axis control data-1	SET/ Data MONIT END RESET Chg. MENU		1606 to 1607	0646 to 0647
New current value	litem Ax.1Ax.2Ax.3Ax.4 Set value	1)	1706 to 1707	06AA to 06AB
Axis3	rg.boost 0 0 0 1 to 300(%) — 3)		1806 to 1807	070E to 070F
1) { Setting	p mode 0 0 0 0 0 1:data No 4)		1514 to 1515	05EA to 05EB
range to 2147483647 (pulse):*1 0 to 35999999 (degree):*10*	.g 1:Valid 5)	2)	1614 to 1615	064E to 064F
	p start 0 0 0 0 0 0:Comp eted 1:Continue 6)	2)	1714 to 1715	06B2 to 06B3
New speed value Axis1 0 Axis2 0	Item Ax.1Ax.2Ax.3Ax.4 Set value.		1814 to 1815	0716 to 0717
2) {	ip command 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	3)	1513, 1613, 1713, 1813	05E9, 064D, 06B1, 0715
Setting (inch/min):*10* (degree/min):*10* 0 to 1000000 (pulse/sec):*1	command Will William W	4)	1544, 1644, 1744, 1844	0608, 066C, 06D0, 0734
		5)	1545, 1645, 1745, 1845	0609, 066D, 06D1, 0735
		6)	1546, 1646, 1746, 1846	060A, 066E, 06D2, 0736
		7)	1547, 1647, 1747, 1847	060B, 066F, 06D3, 0737
		8)	1505, 1605, 1705, 1805	05E1, 0645, 06A9, 070D




		Buffer mem	ory address
Screen example	No.	DEC	HEX
QD75P/QD75D Axis control data-4 SET/ Data MONIT END	1)	1517, 1617, 1717, 1817	05ED, 0651, 06B5, 0719
Inching movement amount [arget position change value (Address)]		1518 to 1519	05EE to 05EF
Axis: 0 Axis2 0 Axis2 0 Axis2 0 Axis3 0 Axis4 0 Axis3 0 Axis4 0	2)	1618 to 1619	0652 to 0653
1) { to 65535	2)	1718 to 1719	06B6 to 06B7
Setting (um):*10-1 [inch]:*10-8		1818 to 1819	071A to 071B
(*ABS 0to85999999(degree):*10°)		1534 to 1535	05FE to 05FF
JOS speed Sarzet position change value (Speed)	3)	1634 to 1635	0662 to 0663
Axis 0 Axis 1 0 Axis 1 0 Axis 2 0 Axis 3 0 Axis 4 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	"	1734 to 1735	06C6 to 06C7
2) Setting 0 to 2000000000 (mm/min):*10° Setting 0 to 20000000000 (mm/min):*10° (inch/min):*10° (inch/min):*10° (degree/min):*10° (degree/		1834 to 1835	072A to 072B
range (degree/min)**10 setting (degree/min)**10 range 0 to 1000000 (pulse/seo)**1		1536 to 1537	0600 to 0601
	4)	1636 to 1637	0664 to 0665
		1736 to 1737	06C8 to 06C9
		1836 to 1837	072C to 072D
	-	-	=
	1)	1212 to 1291	04BC to 050B
1) } Start Sind Fine Sudge 10 Start Sind Fine Sudge 10 Start Sind Fine Sudge 11 Start Sind Fine Sudge 12 Start Sind Fine Sudge 13 Start Sind Fine Sudge 14 Start Sind Fine Sudge 15 Start Sind Fine Sudge 16 Start Sind Fine Sudge 17 Start Sind Fine Sudge 18 Start Sind Fine Sudge 19 Start Sind Fine Sudge 10 Start Sind Fine Sudge 11 Start Sind Fine Sudge 12 Start Sind Fine Sudge 13 Start Sind Fine Sudge 14 Start Sind Fine Sudge 15 Start Sind Fine Sudge 16 Start Sind Fine Sudge 17 Start Sind Fine Sudge 18 Start Sind Fine Sudge 19 Start Sind Fine Sudge 10 Start Sind Fine Sudge 10 Start Sind Fine Sudge 10 Start Sind Fine Sudge 11 Start Sind Fine Sudge 12 Start Sind Fine Sudge 13 Start Sind Fine Sudge 14 Start Sind Fine Sudge 15 Start Sind Fine Sudge 16 Start Sind Fine Sudge 17 Start Sind Fine Sudge 18 Start Sind Fine Sudge 19 Start Sind Fine Sudge 10 Start Sind Fine Sudge 10 Start Sind Fine Sudge 10 Start Sind S	-	-	-
SET/ Data MONIT Con	1)	1293 to 1356	050D to 054C
QD75P/QD75D Error & Warning History Epsilon History (10:to:7) Warning History (10:to:7)	2)	1358 to 1421	054E to 058D
No. Axis Code	-	-	-

Screen 6	ovample	No.	Buffer memory address	
Screen	example	NO.	DEC	HEX
QD75P/QD75D Positioning data Axis: Axis:	AREA SET/ Data MONIT END CHG RESET Chg. MENU END Axiso N. Patt Int. Sont Rec Dec. Dwell Medde	1)	2000 to 2002, 2004 to 2012, 2014 to 2022, 2024 to 2029	07D0 to 07D2, 07D4 to 07DC, 07DE to 07E6, 07E8 to 07ED,
1) {	Address Are address Instrusored 0 0 0 0 0 0 0 0 0	2)	8000 to 8002, 8004 to 8012, 8014 to 8022, 8024 to 8029	1F40 to 1F42, 1F44 to 1F4C, 1F4E to 1F56, 1F58 to 1F5D
Axis2 100 Patt. Int. Dont Acc. Due II Moode	Axist No PattLint, Cont Axc. Dec. Dwell Moode Address Axc address Instr. seed	3)	14000 to 14002, 14004 to 14012, 14014 to 14022, 14024 to 14029	36B0 to 36B2, 36B4 to 36BC, 36BE to 36C6, 36C8 to 36CD
		4)	20000 to 20002, 20004 to 20012, 20014 to 20022, 20024 to 20029	4E20 to 4E22, 4E24 to 4E2C, 4E2E to 4E36, 4E38 to 4E3D
		-	-	-


			Buffer mem	ory address
Screen	example	No.	DEC	HEX
			800 to 801	0320 to 0321
QD75M Operation Monitor	SET/ Data MONIT END SESEN CHEST CHEST CHEST	2)	900 to 901	0384 to 0385
1) — Aris Gurnent feed val. Axis feedrate	Axis Start No. Operation pattern	1)	1000 to 1001	03E8 to 03E9
	Positioning comp		1100 to 1101	044C to 044D
3 0 65538000 4 0 0	2 0 Positioning comp 3 0 Positioning comp		812 to 813	032C to 032D
		3)	912 to 913	0390 to 0391
(µm):*10-1 (mm/min):*10* (degree):*10* (degree):*10* (pulse):*1 (pulse):*10* (pulse):*1 (pulse/sec):*1		7) 2)	1012 to 1013	03F4 to 03F5
3) —			1112 to 1113	0458 to 0459
AxisStatus <mark>Standby 1 Err.: Warning: 0 Mcode: 0</mark>	Axis Control system Axis fime time		809, 909,	0329, 038D,
Axis Status Standbr 2 Err.: Warning: Mepde: 0	1 ABS2 1 0 0 2 FFFD4 1 0 0	3)	1009, 1109	03F1, 0455
Axis Status Standby	3 LOOP 1 0 0	4)	806, 906,	0326, 038A,
Axis Status Standby	4 END	4)	1006, 1106	03EE, 0452
4 Err.: Warping: 0 Mcode: 0		5)	807, 907,	0327, 038B,
		3)	1007, 1107	03EF, 0453
		6)	808, 908,	0328, 038C,
			1008, 1108	03F0, 0454
4) 5) 6)	9) 10) 11) 12)	7)	829, 929,	033D, 03A1,
, , ,	, , , ,	- 0	1029, 1129	0405, 0469
		8) to	838, 938,	0346, 03AA,
		12)	1038, 1138	040E, 0472
	CET / Cotto MONITO	1)	-	-
QD75M Input/Output Monitor	RESET Chg. MENU END			
CD75 READY	## DEPLOY *** Company ***	-	-	-
QD75M Basic parameters 1	SET/ Data MONIT RESET Chg. MENU	1)	0, 150, 300, 450	0000, 0096, 012C, 01C2
1) — Unit 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		2)	2 to 3, 152 to 153, 302 to 303, 452 to 453	0002 to 0003, 0098 to 0099, 012E to 012F 01C4 to 01C7
Movement amount per pulse Bulse/hotation(Ap) Axis: Axis: Axis:	Movement amount per pulse Movement amount per rotation (AID) Exist Axist O	3)	1, 151, 301, 451	0001, 0097, 012D, 01C3
3) {	Axis3	4)	4 to 5, 154 to 155, 304 to 305, 454 to 455	0004 to 0005, 009A to 009B, 0130 to 0131, 01C6 to 01C7
		-	-	-




One or support	NI-	Buffer mem	nory address
Screen example	No.	DEC	HEX
		36 to 41	0024 to 0029
OD75M Detailed parameters 2-1 SET/ Data MONIT END Chg. MENU END		186 to 191	00BA to 00BF
Acc. Axisi Axis2 Axis3 Axis4 DOG.speed limit.value	1)	336 to 341	0150 to 0155
1 123 0 0 0 Axis 0 Axis 0		486 to 491	01E6 to 01EB
1) { 2		42 to 47	002A to 002F
range (degree/min):*10° Setting range to		192 to 197	00C0 to 00C5
1 to 3383808(msee)	2)	342 to 347	0156 to 015B
Dec. Axisi Axis2 Axis3 Axis4 Ittem Ax.14x.26x.34x.49et range		492 to 497	01EC to 01F0
1 0 0 0 0 time select 0 0 0 0 0 to 3		48 to 49	0030 to 0031
2) 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	2)	198 to 199	00C6 to 00C7
Setting range	3)	348 to 349	015C to 015D
1 to 3338608(msec)		498 to 499	01F2 to 01F3
	4)	50, 200, 350, 500	0032, 00C8, 015E, 01F4
	5)	51, 501, 351, 501	0033, 01F5, 015F, 01F5
OD75M Detailed parameters 2-2 SET/ Data MONIT END	1)	52, 202, 352, 502	0034, 00CA, 0160, 01F6
1) — Acc/Dec Type 0 0 0 0 0 Ramp If Down Axis Axis	2)	53, 203, 353, 503	0035, 00CB, 0161, 01F7
2) — S-pattern % 0 0 0 0 1-100(%) 3) — Sudden 1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	3)	56, 206, 356, 506	0038, 00CE, 0164, 01FA
4) — stop 2 0 0 0 0 1:3udden Talige (prilse):+1	4)	57, 207, 357, 507	0039, 00CF, 0165, 01FB
6) — Sudden stop deceleration time External command function selection Axis Axis Axis Axis Axis Axis Axis Axis	5)	58, 208, 358, 508	003A, 00D0, 0166, 01FC
1 to 8888308 (ms)	6)	54 to 55, 204 to 205, 354 to 355, 504 to 505	0036 to 0037, 00CC to 00CD, 0162 to 0163, 01F8 to 01F9
	7)	59, 209, 359, 509	003B, 00D1, 0167, 01FD
		60 to 61	003C to 003D
	0,	210 to 211	00D2 to 00D3
	8)	360 to 361	0168 to 0169
		510 to 511	01FE to 01FF
	9)	62, 212, 362, 512	003E, 00D4, 016A, 0200
	10)	64 to 65, 214 to 215, 364 to 365, 514 to 515	0040 to 0041, 00D6 to 00D7, 016C to 016D, 0202 to 0203





Corpor average		Buffer men	nory address
Screen example	No.	DEC	HEX
	1)	816, 916,	0330, 0394,
0D75M I/O signal & Status SET/ Data MONIT END Chg. MENU	.,	1016, 1116	03F8, 045C
External input/output signal Status Item Ax.: [Ax.2[Ax.3] Ax.4] Item [Ax.: [Ax.2[Ax.3] Ax.4]	2)	817, 917, 1017, 1117	0331, 0395, 03F9, 045D
Lower limit signal	-	1017, 1117 -	- -
1) — Axis monitor data—1 SET/ Cata MONITOR END — 2) Axis monitor data—1 SET/ Cata MONITOR END — 2) Axis monitor data—1 SET/ Cata MONITOR END — 2) Axis monitor data—1 SET/ Cata MONITOR END — 2) Axis monitor data—1 SET/ Cata MONITOR END — 2)	1) -	818 to 819 918 to 919 1018 to 1019	0332 to 0333 0396 to 0397 03FA to 03FB
Axis2 conf. flag		1118 to 1119	045E to 045F
Axis4 0 chg.proc. 1:In		802 to 803	0322 to 0323
(μm):*10 ⁻¹ (degree):*10 ⁻⁶ (inch):*10 ⁻⁶ (pulse):*1	2)	902 to 903	0386 to 0387
		1002 to 1003	03EA to 03EB
Axisi ———————————————————————————————————		1102 to 1103	044E to 044F
Axis2 0 0 655 86000 656 88000		820 to 821	0334 to 0335
Axist 0 0	3)	920 to 921	0398 to 0399
(mm/min):*10* (degree/min):*10* (inch/min):*10* (pulse/seo):*1		1020 to 1021	03FC to 03FD
		1120 to 1121	0460 to 0461
		810 to 811	032A to 032B
	4)	910 to 911	038E to 038F
3) 4) 5)		1010 to 1011	03F2 to 03F3
		1110 to 1111	0456 to 0457
		812 to 813	032C to 032D
	5)	912 to 913	0390 to 0391
	"	1012 to 1013	03F4 to 03F5
		1112 to 1113	0458 to 0459
	6)	830, 930, 1030, 1130	033E, 03A2, 0406, 046A
	7)	831, 931, 1031, 1131	033F, 03A3, 0407, 046B



		Buffer mem	ory address
Screen example	No.	DEC	HEX
QD75M Axis monitor data-4 QD75M Axis monitor data-4 QD75M Axis monitor data-4 QD75M Axis monitor data-4		870, 970, 1070, 1170	0366, 03CA, 042E, 0492
Parameter error No. (B)I 9:0K TERKOR) IServo status Item Ax. I Ax. 2 Ax. 3 Ax. 4		871, 971, 1071, 1171	0367, 03CB, 042F, 0493
	1)	872, 972, 1072, 1172	0368, 03CC, 0430, 0494
No. S S S S S S S S S		873, 973, 1073, 1173	0369, 03CD, 0431, 0495
Parameter error No. (BIT 020K 1:ERROR) Regenerative 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		874, 974, 1074, 1174	036A, 03CE, 0432, 0496
1	2)	877, 977, 1077, 1177	036D, 03D1, 0435, 0499
00000000000000000000000000000000000000	3)	878, 978, 1078, 1178	036E, 03D2, 0436, 049A
	4)	879, 979, 1079, 1179	036F, 03D3, 0437, 049B
	5)	880, 980, 1080, 1180	0370, 03D4, 0438, 049C
		824 to 825	0338 to 0339
QD75M OPR RESET Chg. MENU END	1)	924 to 925	039C to 039D
1) — Francia Travel after NPO UN	1)	1024 to 1025	0400 to 0401
		1124 to 1125	0464 to 0465
3 0 0	2)	826, 926, 1026, 1126	033A, 039E, 0402, 0466
(um:*10*) (inch:*10*) (degree:*10*) (pulse:*1) [www. Forsue.NmitNears/Doper.cover	3) 4)	816, 916, 1016, 1116	0330, 0394, 03F8, 045C
2 000 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	-	-	-
		814 to 815	032E to 032F
QD75M Speed-position control SET/ Pata MONIT END	4	914 to 915	0392 to 0393
SPSC potditioning amount litem Ax.1 Ax.2 Ax.3 Ax.4	1)	1014 to 1015	03F6 to 03F7
Axisi Speed-position switching latch 3)		1114 to 1115	045A to 045B
1) { Axis3		1526 to 1527	05F6 to 05F7
(um)::10" (degree)::10" switching enable 0:Disable 1:Enable (inch)::10" (pulse)::1	2)	1626 to 1627	065A to 065B
		1726 to 1727	06BE to 06BF
SPSS movement amount schange restisters. Axis 1		1826 to 1827	0722 to 0723
2) {	3)	817, 917, 1017, 1117	0331, 0395, 03F9, 045D
range 0 to 2147490047 (degree):*10** (pulse):*1	4)	817, 917, 1017, 1117	0331, 0395, 03F9, 045D
	5)	1528, 1628, 1728, 1828	05F8, 065C, 06C0, 0724
	-	-	-








Caraon avanula	NI-	Buffer memory address	
Screen example	No.	DEC	HEX
QD75M Positioning data AREA SET/ Data ONIT END Axis3 Axis4 Axis5 Axis5 Axis5 Axis5 Axis5 Axis5 Axis5	1)	2000 to 2002, 2004 to 2012, 2014 to 2022, 2024 to 2029	07D0 to 07D2, 07D4 to 07DC, 07DE to 07E6, 07E8 to 07ED
1) {	2)	8000 to 8002, 8004 to 8012, 8014 to 8022, 8024 to 8029	1F40 to 1F42, 1F44 to 1F4C, 1F4E to 1F56, 1F58 to 1F5D
Axis2 No Patt Int. Contlace. Dec Due Meode	3)	14000 to 14002, 14004 to 14012, 14014 to 14022, 14024 to 14029	36B0 to 36B2, 36B4 to 36BC, 36BE to 36C6, 36C8 to 36CD
	4)	20000 to 20002, 20004 to 20012, 20014 to 20022, 20024 to 20029	4E20 to 4E22, 4E24 to 4E2C, 4E2E to 4E36, 4E38 to 4E3D
	-	-	-
QD75M Servo basic parameter	1)	30100, 30200, 30300, 30400	07594, 075F8 0765C, 076C0
1) — Servo series DRHM IRHM ZR-26 3R-26 4R-24 Rotation direction Divergous with inverse of others — 9) Axis	2)	30101, 30201, 30301, 30401	07595, 075F9 0765D, 076C1
Axis 1 Axis 2 Axis 3 Axis 4 Axis 4 Ruto tuning MR-H-BNA - 12-0: MR-H-BNA -	3) 4)	30102, 30202, 30302, 30402	07596, 075FA 0765E, 076C2
4) External dynamic brake 0.1% 1/54 0. Axis 0.	5)	30103, 30203, 30303, 30403	07597, 075FB 0765F, 076C3
Motor type Axiss Axiss Axiss Motor Axiss	6)	30104, 30204, 30304, 30404	07598, 075FC 07660, 076C4
6) — Motor capacity 0000 - FFFF	7)	30105, 30205, 30305, 30405	07599, 075FD 07661, 076C5
8) — reedback pulse consequence of section and section	8)	30106, 30206, 30306, 30406	0759A, 075FE 07662, 076C6
	9)	30107, 30207, 30307, 30407	0759B, 075FF 07663, 076C7
	10)	30108, 30208, 30308, 30408	0759C, 07600 07664, 076C8
	11)	30109, 30209, 30309, 30409	0759D, 07601 07665, 076C9





Caraon average	NI-	Buffer memory address	
Screen example	No	DEC	HEX
QD75M Servo extended parameter(Part2) Serial communication baudrate PI-PID control switch-over	1) to 4)	30133, 30233, 30333, 30433	075B5, 07619 0767D, 076E1
0: \$600[bps] 1:19200[bps]	5)	30134, 30234, 30334, 30434	075B6, 0761A 0767E, 076E2
2) — Serial communication response delay 02 nx 1 2 2 2 2 2 2 2 2 2	6)	30136, 30236, 30336, 30436	075B8, 0761C 07680, 076E4
3) — Encoder output pulse setting 0.000tput pulse setting	7)	30138, 30238, 30338, 30438	075BA, 0761E 07682, 076E6
11Uivision ratio setting Axisi	-	-	-
QD75M Servo extended parameter 2 SET/ Data MONIT END	1)	30143, 30243, 30343, 30443	075BF, 07623 07687, 076EB
Slight vibration control selection Position loop gain 2 changing ratio MAX 8 11 11 12 13 14 14 15 15 15 15 15 15	2)	30144, 30244, 30344, 30444	075C0, 07624 07688, 076EC
Special control of the superior control selection 2 Axis Axi	3)	30145, 30245, 30345, 30445	075C1, 07605 07689, 076ED
Axis 0 Axis 2 Axis 3 Axis 4 Encoder output palses direction 3) — Foltage compensation 0 - 100 [X] Axis 4 Axis 1 Axis 2 Axis 3 Axis 3 Axis 4 Axis 1 Axis 2 Axis 3 Axis 4 Axis 3 Axis 4 Axis 3 Axis 4 Axis 3 Axis 4 Axis 4 Axis 4 Axis 5 A	4)	30149, 30249, 30349, 30449	075C5, 07629 0768D, 076F1
4) Gairn changing (Unadid 1814. simal for controlle Notich filter MR-J2S-B, MR-J2M-B selection 20mm frequency 30mp pulse 40mbd pard frequency 0 in - 0100000000 00:500000 00:500000 00:500000 00:500000 00:500000 00:50000 00:50000 00:50000 00:50000 00:50000 00:50000 00:500000 00:50000 00:50000 00:50000 00:50000 00:50000 00:50000 00:500000 00:50000 00:50000 00:50000 00:50000 00:50000 00:50000 00:500000 00:50000 00:50000 00:50000 00:50000 00:50000 00:50000 00:500000 00:50000 00:50000 00:50000 00:50000 00:50000 00:50000 00:500000 00:50000 00:50000 00:50000 00:50000 00:50000 00:50000 00:5000000 00:50000 00:50000 00:50000 00:50000000 00:500000 00:50000 00:500000 00:500000 00:5000000 00:50000 00:50000 00:500000 00:500000	5)	30150, 30250, 30350, 30450	075C6, 0762A 0768E, 076F2
Axis	6)	30151, 30251, 30351, 30451	075C7, 0762B 0768F, 076F3
7) — Load moment of inertia ratio 0 - 3000 *10-1 representation Axis 1 Maxis 2 Maxis 3 Maxis 4 Maxis 2 Maxis 3 Maxis 4 Maxis 4 Maxis 2 Maxis 3 Maxis 4 Maxis 4 Maxis 4 Maxis 4 Maxis 4 Maxis 4 Maxis 5 Maxis 6 Maxis 6 Maxis 6 Maxis 7 Maxis 8 Maxis 8 Maxis 8 Maxis 9	7)	30152, 30252, 30352, 30452	075C8, 0762C 07690, 076F4
	8)	30153, 30253, 30353, 30453	075C9, 0762D 07691, 076F5
	9)	30154, 30254, 30354, 30454	075CA, 0762E 07692, 076F5
	10)	30155, 30255, 30355, 30455	075CB, 0762F 07693, 076F6
	11)	30160, 30260, 30360, 30460	075D0, 07634 07698, 076FC
	12)	30161, 30261, 30361, 30461	075D1, 07635 07699, 076FD


Buffer memory address Screen example No. DEC HEX 800, 812 320, 32C 1) QD75MH Operation Monitor 2) 900, 912 384, 390 3) 1000, 1012 3E8, 3F4 1) 2) 3) 4) · 11) · 12) 4) 1100, 1112 44C, 458 806 to 809 326 to 329 5) 6) 906 to 909 38A to 38D 7) 1006 to 1009 3EE to 3F1 5) 1106 to 1109 452 to 455 8) 6) 9) 1431 597 10) 829, 838 33D, 346 8) 11) 929, 938 3A1, 3AA 12) 1029, 1038 405, 40E 9) 13) 1129, 1138 469, 472 14) 838 346 938 15) ЗАА 16) 1038 40E 17) 1138 472 1) QD75MH Input/Output Monitor 1) 0, 150, 300, 450 0, 96, 12C, 1C2 1) QD75MH Basic parameters 1 2 to 3, 152 to 153, 2 to 3, 98 to 99, 2) 12E to 12F, 1C4 to 1C5 302 to 303, 452 to 453 3) 1, 151, 301, 451 1, 97, 12D, 1C3 4 to 5, 154 to 155, 4 to 5, 9A to 9B, 4) 304 to 305, 454 to 455 130 to 131, 1C6 to 1C7 } 4) 2) 3)


6.5.36 QD75MH module monitoring

















_		Buffer		memory address	
Screen o	kample	No.	DEC	HEX	
	SETA hata Miniti	1)	1212 to 1216	4BC to 4C0	
QD75MH Start History	RESET Chg. MENU END	2)	1217 to 1221	4C1 to 4C5	
Start History (0 to 7) No.ax Start Kind Time Judge		3)	1222 to 1226	4C6 to 4CA	
1) 00 00 00 00 00 00 00 00 00 00 00 00 00		4)	1227 to 1231	4CB to 4CF	
3) — 2 0 00 0 0 00 00 0 0 4) — 0 0 0 0 0 0 0 0 0 5) — 0 0 0 0 0 0 0 0		5)	1232 to 1236	4D0 to 4D4	
6) 7 0 00 0 0 00 00 0		6)	1237 to 1241	4D5 to 4D9	
8) — 7 0 00 0 00:00:00		7)	1242 to 1246	4DA to 4DE	
Start History (8 to 15) No.Ax.Start Kind Time Judge		8)	1247 to 1251	4DF to 4E3	
9) 00 00 00 00 00 00 00 00 00 00 00 00 00		9)	1252 to 1256	4E4 to 4E8	
12) — ## 0 00 0 0 00 00 0 0 0 0 0 0 0 0 0 0		10)	1257 to 1261	4E9 to 4ED	
14) — 6 00 00 00 00 00 00 00 00 00 00 00 00 0		11)	1262 to 1266	4EE to 4F2	
16) — 15 00 00 00 00 00 00		12)	1267 to 1271	4F3 to 4F7	
		13)	1272 to 1276	4F8 to 4FC	
		14)	1277 to 1281	4FD to 501	
		15)	1282 to 1286	502 to 506	
		16)	1287 to 1291	507 to 50B	
		-	-	-	
	ISST/ I Pata (MONIT)	1)	1293 to 1296	50D to 510	
QD75MH Error & Warning History	RESET Chg. MENU END	2)	1297 to 1300	511 to 514	
Error History (0 to 7.) No. Axis Code Time	Warming History (0 to 7) balaxis Code Time	3)	1301 to 1304	515 to 518	
1) 0 0 00:00:00	7 O 0 0 00:00:00 17) 1 O 0 00:00:00 18)	4)	1305 to 1308	519 to 51C	
3) — 0 0 00.00.00 4) — 0 0 0 00.00.00 5) — 0 0 00.00.00	2 0 0 0 00:00:00 19) 3 0 0 0 00:00:00 20) 4 0 0 00:00:00 21)	5)	1309 to 1312	51D to 520	
6) — 5 0 0 00:00:00	5 0 0 0 00:00:00 - 22) 6 0 0 00:00:00 - 23)	6)	1313 to 1316	521 to 524	
8) — 7 0 0 00:00:00	7 0 0 00:00:00	7)	1317 to 1320	525 to 528	
Error History (8 to 15) No. Axis Code Time	Warming History (3 to 15) b. Axis Code Time	8)	1321 to 1324	529 to 52C	
9) —	3 0 0 00:00:00 25) 9 0 0 00:00:00 26) 10 0 00:00:00 27)	9)	1325 to 1328	52D to 530	
12) — (1) 0 0 00:00:00 13) — (12) 0 0 00:00:00	221) 0 0 00:00:00 — 28) 12 0 0 00:00:00 — 29)	10)	1329 to 1332	531 to 534	
14) 0 0 00:00:00	0 00:00:00 — 30) 4 0 0 00:00:00 — 31)	11)	1333 to 1336	535 to 538	
16) — 15 0 0 00:00:00	32)	12)	1337 to 1340	539 to 53C	
		13)	1341 to 1344	53D to 540	
		14)	1345 to 1348	541 to 544	
		15)	1349 to 1352	545 to 548	
		16)	1353 to 1356	549 to 54C	
		17)	1358 to 1361	54E to 551	
		18)	1362 to 1365	552 to 555	
		19)	1366 to 1369	556 to 559	
		20)	1370 to 1373	55A to 55D	
		21)	1374 to 1377	55E to 561	
		22)	1378 to 1381	562 to 565	
		23)	1382 to 1385	566 to 569	
		24)	1386 to 1389	56A to 56D	
		25) 26)	1390 to 1393 1394 to 1397	56E to 571 572 to 575	
		27)	1398 to 1401	576 to 579	
		28)	1402 to 1405	57A to 57D	
		29)	1406 to 1409	57E to 581	
		30)	1410 to 1413	582 to 585	
		31)	1414 to 1417	586 to 589	
		32)	1418 to 1421	58A to 58D	
		-	-	-	

	T., T	Buffer mem	ory address
Screen example	No.	DEC	HEX
ADDA OPEN OPEN OF A MANUAL		2000 to 2002,	7D0 to 7D2,
QD75MH Positioning data CHG RESET Chg. MCNU END	1)	2004 to 2009	7D4 to 7D9
Axis:	0)	2010 to 2012,	7DA to 7DC,
Address Arc. address Instruspeed Address Arc. address Instruspeed	2)	2014 to 2019	7DE to 7E3
1) {	2)	2020 to 2022,	7E4 to 7E6,
2) {	3)	2024 to 2029	7E8 to 7ED
3) {	4)	8000 to 8002,	1F40 to 1F41,
Axis2 Axis4 Mak Ratt lint. Cont Acc. Dec. Duell Moode M. Ratt lint. Cont Acc. Dec. Duell Moode	4)	8004 to 8009	1F44 to 1F49
Address Arc. address Instruspeed Address Arc. address Instruspeed	5)	8010 to 8012,	1F4A to 1F4C,
4) {	5)	8014 to 8019	1F4E to 1F53
5) {	6)	8020 to 8022,	1F54 to 1F56,
6) {	6)	8024 to 8029	1F58 to 1F5D
	7)	14000 to 14002,	36B0 to 36B2,
	7)	14004 to 14009	36B4 to 36B9
	8)	14010 to 14012,	36BA to 36BB,
	0)	14014 to 14019	36BE to 36C3,
	9)	14020 to 14022,	36C4 to 36C6,
	٠,	14024 to 14029	36C8 to 36CD
	10)	20000 to 20002,	4E20 to 4E22,
	<u> </u>	20004 to 20009	4E24 to 4E29
	11)	20010 to 20012,	4E2A to 4E2C,
		20014 to 20019	4E2E to 4E33
	12)	20020 to 20022,	4E34 to 4E36,
		20024 to 20029	4E38 to 4E3D
	-	-	-
QD75MH Servo parameter Basic setting SET/ Data MONIT END Chg. MENU END	1)	30100, 30300,	7594, 765C,
Item Axis1 Axis2 Axis3 Axis4 Setting range		30500, 30700	7724, 77EC
1) — Services 	2)	30102, 30302 30502 30702	7596, 765E, 7726, 77EE
2) — Reservative Urane 0 0 0 0 0 05:1/R-R830 06:1/R-R830		30103, 30303	7797, 765F,
3) 08:MR-F881 09:MR-F881 09:MR-F881 3) 08:MR-F881 09:MR-F881 09:MR	3)	30503, 30703	7737, 7031, 7727, 77EF
4) — Eurocuselections 4-1 0 0 0 0:Valid 1:Invalid Emergency stop inputs 0 0 0 0 0:Valid 1:Invalid		30104, 30304,	7798, 7660,
5) — Bain adjustment 0 0 0 0 0 Interpolation	4)	30504, 30704	7728, 77F0
2:Auto tuning2		30108, 30308,	759C, 7664,
6) — (5) (16 × 32 Low Middle High Life × 30 Hz × 400 Hz	5)	30508, 30708	772C, 77F4
7) — (3) (3) (3) (3) (4) (4) (5) (5) (6) (6) (7) (7) (7) (7) (7) (7) (7) (7) (7) (7	0)	30109, 30309,	759D, 7665,
8) — 	6)	30509, 30709	772D, 77F5
	7)	30110, 30310,	7591, 7666,
	7)	30510, 30710	772E, 77F6
	8)	30114, 30314,	75A2, 766A,
	3)	30514, 30714	7732, 77FA
	9)	30115, 30315,	75A3, 766B,
	٥,	30515, 30715	7733, 77FB
	-	<u>-</u>	-

	Screen example		Buffer men	Buffer memory address	
			DEC HEX		
ODZE	MH Servo parameter Gain/Filter-1	1)	30119, 30319,	75A7, 766F,	
טוי עוט	RESET OF RENO	1)	30519, 30719	7737, 77FF	
	Item Axis1 Axis2 Axis3 Axis4 Setting range Offilter Off	3)	30120, 30320,	75A8, 7670,	
1)	s an duning mode 0 0 0 0 1:Filter tuning 2:Manual	2)	30520 30720	7738, 7800	
2) — Wilhi	0:Vibration control OFF	2)	30122, 30322,	75AA, 7672,	
Sem	srol tuning mode 0 0 0 1:Vibration etrl tuning 2:Manual	3)	30522, 30722	773A, 7802	
3) — Eee	0	4)	30124, 30324,	75AC, 7674,	
5) —	0	4)	30524, 30724	773C, 7804	
6) — — — 7) — — — — — — — — — — — — — — —	Compagnition	5)	30125, 30325,	75AD, 7675,	
8) — — — — — — — — — — — — — — — — — — —	5 0 0 1 to 10000(×10 ⁻¹) [ms]	3)	30525, 30725	773D, 7805	
0) —	2Hansesseuppress	6)	30126, 30326,	75AE, 7676,	
1) —	-nane-seppe - 0 0 0 0 100 to 4500[hz]	0)	30526, 30726	773E, 7806	
Z) Low	tass filter 0 0 0 0 0*Automatic setting	7)	30127, 30327,	75AF, 7677,	
89 2 06	AND THE PROPERTY SELLING		30527, 30727	773F, 7807	
		8)	30128, 30328,	75B0, 7678,	
		9,	30528, 30728	7740, 7808	
		9)	30129, 30329,	75B1, 7679,	
			30529, 30729	7741, 7809	
		10)	30131, 30331,	75B3, 767B,	
		, ,	30531, 30731	7743, 780B	
		11)	30133, 30333,	75B5, 767D,	
			30533, 30733	7745, 780D	
		12)	30136, 30336,	75B8, 7680,	
			30536, 30736	7748, 7810	
		13)	30141, 30341,	75BD, 7685,	
			30541, 30741	774D, 7815	
		- 1)	30132, 30332,	75B4, 767C,	
QD75	MH Servo parameter Gain/Filter-2	1) 2)	30532, 30732	7744, 780C	
	litem Axis Axis Axis Axis Axis Axis Setting range	3)	30332, 30732	7744,7000	
1) —	Notich deoth	4)	30134, 30334,	75B6, 767E,	
e ca	selection	5)	30534, 30734	7746, 780E	
2) — 🚟	Notehwidth 0 0 0 $\frac{\text{Smited}}{\alpha=2}$ $\frac{-}{\alpha=3}$ $\frac{\text{Wide}}{\alpha=4}$ $\frac{-}{\alpha=5}$		30137, 30337,	75B9, 7681,	
3) —	Resonance suppression 0 0 0 0 lavelid 1:Velid	6)	30537, 30737	7749, 7811	
, 80 to	0 1 2 3		30138, 30338,	75BA, 7682,	
4) —	Se setion	7)	30538, 30738	774A, 7812	
5)	Notice under 0 0 0 0 0 1 2 3 Similar → Wide	8)	30142, 30342,	75BE, 7686,	
2) 10000	Selection	9)	30542, 30742	774E, 7816	
7) – 🚃	7531755 16-64 0 0 0 0 1 to 1000(×10 ⁻¹)[Hz]				
8) —	0 0 0 0 0 0 0 0 0 0				
9)	Selection 0 0 0 3:PID control is a luays valid.	-	-	-	

	Carran avample		u.	Buffer mem	nory address
	Screen example		No. –	DEC	HEX
	SET/ Data MONITI CON		4)	30145, 30345,	75C1, 7689,
	OD75MH Servo parameter Gain/Filter-3 RESET Chg. MENU END		1)	30545, 30745	7751, 7819
) —			0)	30146, 30346,	75C2, 768A,
<u> </u>	0 0 0 0 to 100 ms	'	2)	30546, 30746	7752, 781A
) —	boad inersia ratio to gain switch servo 0 0 0 0 to 3000(×10-1)		27	30147, 30347,	75C3, 768B
) —	0 0 2 0 1 to 2000[rad/s]	,	3)	30547, 30747	7753, 781B
) —	3,255 (n) (251,251,251,251,251,251,251,251,251,251,		4)	30148, 30348,	75C4, 768C
·) —	Wibsetton From cotup 0 0 0 1 to 1000(×10 ⁻¹)[Hz]	'	4)	30548, 30748	7754, 781C
s) —	0 0 0 1 to 1000(×10 ⁻¹)[Hz]		5)	30149, 30349,	75C5, 768D
	Item Axisi Axis2 Axis3 Axis4		3)	30549, 30749	7755, 781D
	Gain changing selection 0 0 0 0	9)	6)	30150, 30350,	75C6, 768E
	01:Control command by the controller is effective. 02:Command frequency is more than R627.	Ľ	0)	30550, 30750	7756, 781E
	### 193:(Motor encoder unit)Droop pulse is more than PB27. ### 194:Model speed is more than PB27.	.	7)	30151, 30351,	75C7, 768F,
	12:Command frequency is less than P627. 13:Indictor encoder unitityprop pulse is less than P627.		''	30551, 30751	7757, 781F
	144Model speed is less than PB27.		8)	30152, 30352,	75C8, 7690
			٥,	30552, 30752	7758, 7820
			9)	30144, 30344,	75C0, 7688,
		Ľ	•,	30544, 30744	7750, 7818
			-	_	
					-
	007FMM4 Sarva parameter Ev. cetting_1		1)	30164, 30364,	- 75D4, 769C
	0D75MH Servo parameter Ex. setting-1 OD75MH Servo parameter Ex. setting-1 OD75MH Servo parameter Ex. setting-1 OD75MH Servo parameter Ex. setting-1		1)	30164, 30364, 30564, 30764	
) —	0D75MH Servo parameter Ex. setting-1 SET/ Data CONT END		_	30564, 30764 30165, 30365,	7764, 782C 75D5, 769D
) —			1)	30564, 30764	7764, 782C 75D5, 769D
,		; ;	2)	30564, 30764 30165, 30365, 30565, 30765 30166, 30366,	7764, 782C 75D5, 769D 7765, 782D 75D6, 769E
e) — s) —	Second Color Second Color	; ;	2)	30564, 30764 30165, 30365, 30565, 30765	7764, 782C 75D5, 769D 7765, 782D 75D6, 769E
e) — s) —	Filen	;	2) 3) 4)	30564, 30764 30165, 30365, 30565, 30765 30166, 30366, 30566, 30766 30167, 30367,	7764, 782C 75D5, 769D 7765, 782D 75D6, 769E 7766, 782E 75D7, 769F,
<u> </u>	Serial encoder cable	;	2)	30564, 30764 30165, 30365, 30565, 30765 30166, 30366, 30566, 30766	7764, 782C 75D5, 769D 7765, 782D 75D6, 769E 7766, 782E 75D7, 769F,
s) — s) —	Item Axis Axis2 Axis3 Axis4 Setting range	;	2) 3) 4) 5)	30564, 30764 30165, 30365, 30565, 30765 30166, 30366, 30566, 30766 30167, 30367, 30567, 30767 30168, 30368,	7764, 782C 75D5, 769D 7765, 782D 75D6, 769E 7766, 782E 75D7, 769F, 7767, 782F
i) — i) — i) —	Files	;	2) 3) 4)	30564, 30764 30165, 30365, 30565, 30765 30166, 30366, 30566, 30766 30167, 30367, 30567, 30767	7764, 782C 75D5, 769D 7765, 782D 75D6, 769E 7766, 782E 75D7, 769F, 7767, 782F 75D8, 76A0
(i) — (ii) — (ii) — (ii) — (iii) —	Serial encoder cable	;	2) 3) 4) 5)	30564, 30764 30165, 30365, 30565, 30765 30166, 30366, 30566, 30766 30167, 30367, 30567, 30767 30168, 30368, 30568, 30768 30170, 30370,	7764, 782C 75D5, 769D, 7765, 782D 75D6, 769E, 7766, 782E 75D7, 769F, 7767, 782F 75D8, 76A0, 7768, 7830 75DA, 76A2
(i) — (ii) — (ii) — (ii) — (iii) —	Serial encoder cable	;	2) 3) 4) 5)	30564, 30764 30165, 30365, 30565, 30765 30166, 30366, 30566, 30766 30167, 30367, 30567, 30767 30168, 30368, 30568, 30768	75D4, 769C, 7764, 782C 75D5, 769D, 7765, 782D 75D6, 769E, 7766, 782E 75D7, 769F, 7767, 782F 75D8, 76A0, 7768, 7830 75DA, 76A2 776A, 7832
(i) — (ii) — (ii) — (ii) — (iii) —	Serial encoder cable	;	2) 3) 4) 5)	30564, 30764 30165, 30365, 30565, 30765 30166, 30366, 30566, 30766 30167, 30367, 30567, 30767 30168, 30368, 30568, 30768 30170, 30370,	7764, 782C 75D5, 769D, 7765, 782D 75D6, 769E, 7766, 782E 75D7, 769F, 7767, 782F 75D8, 76A0, 7768, 7830 75DA, 76A2

Screen example	No.	Buffer memory address	
	INO.	DEC	HEX
QD75MH Servo parameter Ex. setting-2 SET/ Data MONIT END	1)	30174, 30374, 30574, 30774	75DE, 76A6, 776E, 7836
Item	2)	30175, 30375, 30575, 30775	75DF, 76A7, 776F, 7837
Arialog monitor output selection(chl) Arialog monitor output selection(chl) Arialog monitor output selection(chl2)	3)	30172, 30372, 30572, 30772	75DC, 76A4, 776C, 7834
### Setting range ### OfServo motor speed(±8W/max. speed) 1:Torque(±8W/max. torque) 2:Servo motor speed(*8W/max. speed)	4)	30173, 30373, 30573, 30773	75DD, 76A5, 776D, 7835
3:Torque(+630/max. torque) 4:Surrent command(±80/max. curre) 5:Sommand speed(±80/max. curre) 5:Sommand speed(±80/max. curre) 6:Droop puls(±100/100puls[Encoder unit]) 7:Droop puls(±100/1000puls[Encoder unit]) 3:Droop puls(±100/1000puls[Encoder unit]) 6:Droop puls(±100/10000puls[Encoder unit]) 4:Feedback position(±100/100,000,000puls[Encoder unit]) 6:Feedback position(±100/10,000,000puls[Encoder unit]) 6:Feedback position(±100/10,000,000puls[Encoder unit]) 6:Feedback position(±100/10,000,000puls[Encoder unit]) 6:Feedback position(±100/100,000,000puls[Encoder unit]) 6:Feedback position(±100/100,000,000puls[Encoder unit]) 6:Feedback position(±100/100,000,000puls[Encoder unit]) 6:Feedback position(±100/100,000,000puls[Encoder unit]) 6:Feedback position(±100/100,000puls[Encoder unit])	-	-	-
QD75MH Servo parameter I/O setting SET/ Data MONIT END MENJ END	1)	30202, 30402, 30602, 30802	75FA, 76C2, 778A, 7852
	2)	30203, 30403, 30603, 30803	75FB, 76C3, 778B, 7853
Output signal device selection 8. Setting range O:Always OFF 7:TLC(Limiting torque) 3:WB(Warning)	3)	30204, 30404, 30604, 30804	75FC, 76C4, 778C, 7854
2480(Servo is Oil) 3480(Servo is Oil) 3480(Servo is Oil) 3480(Trouble) 410PC (In-position) 5488(Electromagnetic brake interlock) 5488(Electromagnetic brake) 5488(External dynamic brake) 114889(Absolute position erasing)	-	-	-


Operating I/O Module Monitor Screen 6.6

This section describes the operation of the various screens in the intelligent module monitor function, when monitoring input or output modules.

Specifying the module to be monitored 6.6.1

This section describes how to start monitoring for an input or output module with the intelligent module monitor function.

Operation procedure




- From among the modules installed in the corresponding base unit, specify the module whose "Input" or "Output"
 - Refer to Section 6.4.1 for the way to specify the intelligent function module.
- (2) For information on confirming the displayed contents and subsequent operation, please see Sec. 6.6.2.
 - * Tests cannot be conducted on input or output modules.

6.6.2 Monitor screen configuration and key functions

This section describes the configuration of monitor screens displayed by specifying the input module on the system configuration screen, and explains the functions of keys displayed on the screen.

1 Displayed contents (for an input module)



Item	Description						
1)	Displays the type of object module (input or output module).						
2)	Displays the name of the signal being monitored (X or Y).						
3)	Displays the number and status of the I/O signal.						
4)	Displays keys used for the operations on the monitor screen shown in 2 . (Touch input)						

2 Key functions

The table below shows the functions of keys that are used for the operations on the monitor screen.

Key Function					
END	Closes the monitoring and returns the screen to the one for starting the intelligent module monitor.				
Sys. Conf.	Closes the current monitor and returns to the System Configuration screen.				

6.7 Error Messages and Corrective Action

This section describes the error messages displayed when the intelligent module monitor is executed, and corrective action.

Error message	Description	Corrective action		
Communication channel setup error	There is no channel for communication.	Check that the channel number is correctly set in the Communication Settings.		
Communications error	Communication could not be established with the PLC CPU.	Check the connection status between the PLC CPU and the GOT (disconnected or cut cables). Has an error occurred in the PLC CPU?		
Monitor Data Can Not Find	The special data (intelligent module monitor data) has not been downloaded to the GOT.	Download the special data (intelligent module monitor data) to the GOT.		

MEMO			

7. NETWORK MONITOR








7.1 Features

The network monitor function enables the GOT to monitor and display the statuses of the MELSECNET/H, MELSECNET/10, MELSECNET(II), and CC-Link IE controller networks.


The features of the network monitor are described below.

Selectable from detailed monitoring or other station monitoring for a desired network by the line monitor

The line monitor enables you to monitor the statuses of all network lines connected to the host. In addition, you can also perform detailed monitoring of a desired network and monitoring of other stations by touch input on the line monitor.



(GOT wirh VGA or higher resolution)



(GOT wirh QVGA resolution)

2 Monitoring available for the detailed network information with the detailed monitor Dedicated monitor screens are displayed according to the network type of the connected host.

Network type: MELSECNET(II), master station


MELSECNET(II), local station

MELSECNET/10 and MELSECNET/H, control station and normal station

MELSECNET/10 and MELSECNET/H, remote master station

CC-Link IE controller network, control station and normal station

(Display example)




Monitoring available for other stations statuses with the other station monitor You can monitor the following statuses of other stations connected to the network.

- · Communication status of each station
- · Data link status of each station
- · Parameter status of each station
- · CPU action status of each station
- · CPU RUN status of each station
- · Loop status of each station

Other station monitor menu



Other station communication status monitor



7.2 Specifications

7.2.1 System configuration

This section describes the system configuration of the network monitor.

For connection type settings and precautions regarding the communication unit/cable and connection type, see the following manual.

GOT1000 Series Connection Manual

1 Target controller

Controller
QCPU (Q mode), motion controller (Q series)*1
QnACPU
ACPU/QCPU (A mode)
Motion controller (A series)

¹ For the motion controller CPU (Q series), only the PLC CPU area (CPU No.1) in the Q170MCPU can be monitored.

2 Connection type

(1) When the GOT is connected to a QCPU (Q mode), motion controller (Q series)*1, QnACPU, or motion controller (A series)

(○: Available, △: Partly restricted, X: Unavailable)

	Function	Connection type between GOT and controller									
Name	Description	Bus	Direct CPU connection	Computer	Ethernet	MELSECNET/H connection, MELSECNET/10 connection	CC-Link IE*2	CC-Link connection		GOT multidrop	
	2 description	connection		connection	connection			ID ^{*3}	G4 ^{*4}	connection	
Network monitor	Monitors the statuses of the following networks. • MELSECNET/H network • MELSECNET/10 network • MELSECNET(II) network • CC-Link IE controller network	0	0	0	0	∆*5	0	0	0	×	

^{*1} For the motion controller CPU (Q series), only the PLC CPU area (CPU No.1) in the Q170MCPU can be monitored.

^{*2} Indicates the CC-Link IE controller network connection.

^{*3} Indicates CC-Link connection (Intelligent device station).

^{*4} Indicates CC-Link connection (via G4).

When the GOT is connected to the MELSECNET/H or MELSECNET/10, use a QCPU and a network module (QJ71LP21, QJ71LP21-25, QJ71LP21S-25, QJ71LP21G, or QJ71BR11) of function version B or a later version.

(2) When the GOT is connected to an ACPU/QCPU (A mode)

(○: Available, △: Partly restricted, ★: Unavailable)

Function		Connection type between GOT and controller							
	Description	Bus	Direct CPU connection	Computer link connection	Ethernet connection	MELSECNET/10 connection	CC-Link connection		GOT
Name		connection					ID ^{*1}	G4*2	multidrop connection
Network monitor	Monitoring the network status of MELSECNET/H, MELSECNET/10 and MELSECNET(II)	0	0	△*3	0	0	0	0	×

- *1 Indicates CC-Link connection (Intelligent device station).
- *2 Indicates CC-Link connection (via G4).
- *3 Monitoring is not possible when the target CPU is AnUCPU and a MELSECNET/10 network module is used.

3 Required option OS and option function board

The option OS and option function board shown below are required.

	OS memory space (user area)			Option function board			
Option OS	GT16						
	Built-in flash memory (ROM)	User memory (RAM)	GT15	GT16	GT15		
Network monitor	210KB	370KB	324KB	Not required	GT15-FNB, GT15-QFNB16M, GT15-QFNB48M,	GT15-QFNB, GT15-QFNB32M, GT15-MESB48M	

(1) Option OS

Install the option OS in the above table to the GOT.

Refer to the following manual for the procedure for installing the option OS.

GT Designer2 Version
Basic Operation/Data Transfer Manual (8. TRANSFERRING DATA)

(2) OS memory space

The available memory space shown in the table above is required in the user area to install the option OS to the GOT.

Refer to the following manual for the procedure for checking the available memory space of the user area and information about the data using other user areas.

GT Designer2 Version Basic Operation/Data Transfer Manual (8. TRANSFERRING DATA)

(3) Option function board

(a) For GT16

No option function board is required.

(b) For GT15

Mount one of the option function boards in the above table on the GOT.

For the GOTs with a built-in option function board, refer to the following.

1.1.2 Hardware and OS' required for each function

For how to mount an option function board on the GOT, refer to the following manual.

GT15 User's Manual (8.10 Option Function Board)

7.2.2 Network information that can be monitored

The network information that can be monitored with the network monitor and the link types are as follows.

(○: Can be monitored, ×: Cannot be monitored)

	Function	Network Information	MELSEC NET(II) master station	MELSEC NET(II) local station	MELSEC NET/10, MELSEC NET/H control station	MELSEC NET/10, MELSEC NET/H normal station	MELSEC NET/10, MELSEC NET/H remote master station	CC-Link IE control station*3	CC-Link IE normal station ^{*3}
		Network category display	0	0	0	0	0	0	0
		Network number display	×	×	0	0	0	0	0
		Station number display	0	0	0	0	0	0	0
		Host operation mode	0	0	0	0	0	0	0
Lir	e monitor	Host loop line status	0	0	0	0	0	0	0
		Loopback execution status	0	0	0	0	0	0	0
		Link scan time display	0	×	0	0	0	0	0
		Data link system loop status	0	×	0	0	0	0	0
		Host communication status	×	O*1	×	×	×	×	×
		Host number	0	0	0	0	0	0	0
	Host	Host	0	0	×	×	×	×	×
	information	Network number	×	×	0	0	0	0	0
		Group number	×	×	0	0	×	0	0
		Specified control station	×	×	0	0	×	0	0
		Current control station	×	×	0	0	×	0	0
	Control station information	Communication information	×	×	0	0	×	0	0
	mormaton	Sub-control-station link	×	×	0	0	×	0	0
Detailed monitor		Remote-I/O-master-station station number	×	×	0	0	×	0	0
iled m		Total of linked stations	0	0	0	0	0	0	0
Deta		Largest connected stations	×	×	0	0	0	0	0
	Data link	Largest data-linked station	×	×	0	0	0	0	0
	information	Communication status	×	0	0	0	0	0	0
		Causes of interrupted communication	×	×	0	0	0	0	0
		Causes of data link stoppage	×	×	0	0	0	0	0
	Constant link scan	Constant link scan	×	×	0	0	0	0	0
	BWY receive	BWY from the master station	×	0	×	×	×	×	×
	BW receive	BW from the master station in the higher loop	×	0	×	×	×	×	×

(Continued to next page)

	Function	Network Information	MELSECNE T(II) master station	MELSECNE T(II) local station	MELSECNE T/10, MELSECNE T/H control station	MELSECNE T/10, MELSECNE T/H normal Station	MELSECNE T/10, MELSECNE T/H remote master station	CC-Link IE control station*3	CC-Link IE normal station*3
		Forward loop status	0	0	O*2	O*2	O*2	O*4	O*4
		Reverse loop status	0	0	O*2	O*2	O*2	O*4	O*4
	Loopback	Loopback station (forward loop)	0	×	O*2	O*2	O*2	O*4	O*4
itor		Loopback station (reverse loop)	0	×	O*2	O*2	O*2	O*4	O*4
Detailed monitor		Loop switching frequency	0	×	O*2	O*2	O*2	0	0
etaile		Parameter settings	×	×	0	0	×	0	0
		Designation of reserved station	×	×	0	0	0	0	0
	Host status	Communications mode	×	×	0	0	0	0	0
		Designation of transmission	×	×	O*2	O*2	O*2	0	0
		Transmission status	×	×	O*2	O*2	O*2	0	0
		Communication status of each station	0	×	0	0	0	0	0
		Communications status of each station	×	×	0	0	0	0	0
	ner station	Parameter status of each station	0	×	0	0	0	0	0
mo	nitor	CPU action status of each station	0	0	0	0	×	0	0
		CPU RUN status of each station	0	0	0	0	×	0	0
		Loop status of each station	0	×	O*2	O*2	O*2	×	×

- Monitoring is only possible when connected to a MELSECNET(II) local station. *1
- *2 Monitoring is possible only when using a MELSECNET/H or MELSECNET/10 loop system.
- *3 Indicates the CC-Link IE controller network connection.
- The loop names vary depending on the network system to be monitored as shown below. *4

MELSECNET/H, MELSECNET/10, MELSECNET(II) network systems	CC-Link IE controller network			
Forward loop	OUT-side loop			
Reverse loop	IN-side loop			

7.2.3 Access range

In bus connection, direct CPU connection, computer link connection, or Ethernet connection, only the host station can be monitored.

In MELSECNET/H connection or MELSECNET/10 connection, only the control station can be monitored.

In CC-Link connection (Intelligent device station), only the master station can be monitored.


In CC-Link connection (via G4), only the host and master stations can be monitored.

When the GOT is connected to the remote I/O station in MELSECNET/H network system, no stations can be monitored.

The GOT cannot monitor stations on the MELSECNET/G network system.

The access range other than above is the same as the access range when the GOT is connected to a controller

Refer to the following manual for details of the access range.



7.2.4 Precautions

(1) Station monitored as the host

The station monitored as the host differs depending on the connection type.

Connection type	Station monitored as the host
Bus connection, direct CPU connection, computer link connection	Connected station (target)
Ethernet connection	Station set as the host with the Ethernet setting of GT Designer2
MELSECNET/H connection, MELSECNET/10 connection CC-Link IE controller network connection	Control station
CC-Link connection (Intelligent device station), CC-Link connection (Via G4)	Master station

(2) When the network monitor cannot be displayed correctly

The network monitor cannot be displayed correctly in the following cases.

- (a) When the network module is performing offline testing The network monitor cannot be displayed correctly during offline testing. Set the network module mode to online.
- (b) When the network parameter has been changed

The network monitor cannot be displayed correctly when the network parameter is changed. Restart the network monitor.

(c) When there is a network parameter error

The network monitor cannot be displayed correctly when there is a network parameter error. Review the network parameter.

(d) When the network parameter has not been set to the QCPU

The network monitor cannot be displayed correctly when the network parameter is not set to the QCPU.

Be sure to set the network parameter when monitoring the network with the GOT.

- (e) When changing the head addresses on CPU side to which refresh parameter is set The Network monitor cannot be displayed correctly if the SB and SW head addresses of CPU side are changed while refresh parameter is set in the network parameter for the QCPU. To monitor the network with the GOT, set the head addresses of SB and SW on CPU side to default.
- (f) When mounting MELSECNET/H network module and MELSECNET/G network module on same base unit

The GOT cannot monitor the network status.

For monitoring the network status, execute the network diagnostics with GX Developer.

(3) When monitoring MELSECNET/H

Even if a network module on the MELSECNET/H is being monitored, a MELSECNET/10 display is provided in either of the following cases:

- The normal station has been started due to a communication error (cable disconnection, etc.)
- The monitor target is the remote master station.
- (4) When monitoring MELSECNET(II)


When connected to a QnACPU and the master station of the MELSECNET(II), monitoring cannot be done with the keyword being defined.

(5) When the CPU type of the connection target of the GOT is AnNCPU or AnACPU Even when using the network module of the MELSECNET/10, the network information that can be monitored is the content of the MELSECNET(II).

7.3 Display

Operations for display

This section describes the flow until the operation screen for the network monitor is displayed after the network monitor (Option OS) is installed in the GOT.





(1) How to display the utility


For how to display the utility, refer to the following.

GT16 User's manual (Basic Utility) (1.3 Utility Display)
GT15 User's manual (9.3 Utility Display)

- (2) Displaying communication setting window
 After turning on the GOT, the communication setting window is displayed at the first startup of the network monitor only.

 For displaying the communication setting window at the second or later startup, touch the Ch: button on the network monitor screen. (7.4 Operation Procedures)
- (3) If the project data has not been downloaded The network monitor can be started from the utility even if the project data has not been downloaded to the GOT.

2 Changing screens



7.4 Operation Procedures

This section describes the information and key functions displayed on the network monitor screen. The display on the network monitor screen varies slightly depending on the GOT used, and a screen for the GT1575-V is used for the descriptions in this section.


7.4.1 Line monitor

This section describes the structure of the monitor screen and the common operations used when executing the line monitor.

1 Display contents and keys functions


This section describes the line monitor screen configuration and the function of keys displayed on the screen after starting the network monitor.

(1) Displayed contents



No.	Display contents		
1)	This shows the operation mode of the	e host. (On-line, Off-line, Test ^{*1})	
2)	This shows the status of the F-loop (F	Forward loop). (OK, NG) ^{*2}	
3)	This shows the status of the R-loop (I	Reverse loop). (OK, NG)*2	
4)	This shows whether the loopback was executed or not. (Executed, Not executed)		
5)	This shows the link scan time required for the control station and the normal station, for the remote master station and the remote I/O station, and for the master station and all the sub-stations. Maximum (the maximum value of link scan time) Minimum (the minimum value of link scan time) Current (the current value of link scan time)		
6)	P-MTR WAIT: Read Cyclic com: Norr	s of the host. (Only for MELSECNET(II) local station) dy to receive parameters from the master station. nal communication imunication is suspended because the host is disconnected.	
7)	This shows the network category, network number, and station number.		

(Continued to next page)



- *1 [Test] is only displayed when using MELSECNET(II).

 When using a system other than MELSECNET(II), [Off-line] is displayed even during testing of the forward or reverse loop.
- *2 The loop names vary depending on the network system to be monitored as shown below.

MELSECNET/H, MELSECNET/10, MELSECNET(II) network systems	CC-Link IE controller network
Forward loop	OUT-side loop
Reverse loop	IN-side loop



When the GOT target is AnACPU or AnNCPU

"MELSECNET(II)" is displayed even if a MELSECNET/10 network module is installed.

In addition, if there is a master station and local station, module 1 of the line monitor is displayed as "Master station".

Network module		Display on the GOT	
1st module	2nd module	Module 1	Module 2
Local station	Master station	Master station	Local station

(2) Key functions

This section describes the function of keys to be used for the line monitor operations.

Key	Function
END	Exits the line monitor and returns to the screen where the network monitor function was started.
<pre><mode> OnLin <floop> OK <rloop> OK <rloop back=""> No per <ls time=""> Max 86ms Min 17ms Curr 20ms</ls></rloop></rloop></floop></mode></pre>	Switches to the detailed monitor screen that corresponds to the module displayed on the current monitor screen. This key is effective for each screen.
	Switches to the other station monitor menu that corresponds to the network displayed on the current monitor screen. This key is effective for each screen.
Ch:1	Displays the communication setting window.
<mark>(PU: 1</mark> 2 3 4	Changes the monitoring destination CPU using the controller number. (For multi-CPU system connection only) The controller number is displayed according to the number of CPUs loaded.


7.4.2 Detailed monitor

This section describes the detailed monitor and the common operations used when executing the line monitor.

1 Display contents and keys functions: acting as a MELSECNET/H or MELSECNET/10 Control station/normal station

This section describes the contents of the detailed monitor and the function of on-screen keys. All these are displayed and used when the host acts as the control station/normal station on the MELSECNET/H, MELSECNET/10.

(1) Displayed contents



No.	Item	Display contents	
1)	TsSt' Info	This Station's #Network #Group #	: Indicates the station number of the host.: Indicates the network number.: Indicates the group number.
2)	Ctrl St Info	Spc Ctrlr Sta Curr Ctrl Sta Com Info SubCtrl Sta Com Rmt I/OMstSt*1	 Indicates the station number of the station that is specified as a control station. Indicates the station number of a station that is currently acting as the control station. Indicates whether the host is communicating with the control station or the sub-control station. Indicates whether there is a sub-control station link. Displays the station number of the remote I/O master station for X/Y communication block1 and block 2. Displays "None" when there is no setting.
3)	D-Link Info	Total of L-Sta Largest Nrm Sta Largest DL-Sta Com Status Causes of Ssp Causes of Stop	Indicates the maximum number of the stations to be linked. The maximum number is defined by common parameters. Indicates the maximum station number of the station performing a communication in a normal condition. Indicates the maximum station number of the station that is data-linked. Shows the current communications status of the host. (D-Link in prog/D-Link Stop (A)/D-Link Stop (H)/B-Pass excut/Disconnection/Loop test/Set Conf. test/Sta Odr. Conf./Com. test/Offline test/Reset. in prgr.) Indicates the causes why the communications were interrupted. This indicates "Normal" if communications are normal. (Normal/Offline/Offline Test/Line error/Disconnection/Initialize/Others (error codes)) Indicates the causes why the data link was stopped. This indicates "Normal" if communications are normal. (Stop disignat/No common para/Host Para error/Host CPU error/Com. suspension/Others)

For details of *1, refer to the following page.

(Continued to next page)

No.	Item	Display contents
4)	Constant LS	Indicates the predetermined time of constant link scans.
5)	LoopBK Info*2	 FLoop Shows the status of the forward loop lines of the host. (Normal/LoopBK Trans/D-Link Impo) RLoop Shows the status of the reverse loop lines of the host. (Normal/LoopBK Trans/D-Link Impo) FLoop Back Station Indicates the station number of a station that executes the loopback along the forward loop. Displays "" when the loopback is operating normally. RLoop Back Station Indicates the station number of a station that executes the loopback along the reverse loop. Displays "" when the loopback is operating normally. # of Loop Switching Indicates the cumulative number of times for which loops have been switched.
6)	TsSt' Sta	 Parameter Setting Reserved Sta Indicates the availability of a reserved station. (Have/None) Communication Mode Indicates either "Normal mode" or "Constant LS." Transmission Mode Indicates either "Normal Trans" or "Multiple Trans."*2 Transmission Stat Indicates either "Normal Trans" or "Multiple Trans."*2

^{*1} This is not displayed when the CPU type of the GOT connection target is AnNCPU or AnACPU

(2) Key functions


Key	Function
Returns to the line monitor.	
Exits the detailed monitor and returns to the screen where the network monitor fund executed.	

^{*2 &}quot;---" is displayed when coaxial bus connections are established.

2 Display contents and keys functions: acting as a MELSECNET/H, MELSECNET/10 remote master station

This section describes the screen configuration of the detailed monitor and the function of on-screen keys when the host acts as the remote master station on the MELSECNET/H, MELSECNET/10.

(1) Displayed contents



No.	Item		Display contents
1)	TsStí Info	This Sations #Network #Group #	: Indicates the station number of the host.: Indicates the network number.: Not displayed. ("" is displayed.)
2)	Ctrl St Info	Spc Ctrl StaCurr Ctrl StaCom InfoSubCtrl-Sta Com	: Not displayed. ("" is displayed.)
3)	D-Link Info	 Total of L-Sta Largest Nrm Sta Largest DL-Sta Com Status Causes of Ssp Causes of Stop 	 Indicates the maximum number of the stations to be linked, which is set by common parameters. Indicates the maximum station number of the station that is connected in a normal condition. Indicates the maximum station number of the station that is performing data link. Shows the current communications status of the host. (D-Link in prog/D-Link Stop (A)/D-Link Stop (H)/B-Pass excut/Disconnection/Loop test/Set Conf. test/Sta Odr. Conf./Com. test/Offline test/Reset. in prgr.) Indicates the causes why the communications were interrupted. This indicates "Normal" if communications are normal. (Normal/Offline/Offline Test/Line error/Disconnection/Initialize/Others (error codes)) Indicates the causes why the data link was stopped. This indicates "Normal" if communications are normal. (Stop disignat/No common para/Host Para error/Host CPU error/Com. suspension/Others (error codes))
4)	Constant LS	Indicates the predetermined time of constant link scans.	

(Continued to next page)

No.	Item		Display contents
	LoopBK Info*1	• FLoop	: Shows the status of the forward loop lines of the host. (Normal/LoopBK Trans/D-Link Impo)
		RLoop	: Shows the status of the reverse loop lines of the host. (Normal/LoopBK Trans/D-Link Impo)
5)		 FLoop Back Station 	: Indicates the station number of a station that executes the loopback along the forward loop.
σ,		 RLoop Back Station 	Displays "" when the loopback is operating normally. : Indicates the station number of a station that executes the loopback
		- NEOOP Back Station	along the reverse loop.
			Displays "" when the loopback is operating normally.
		# of Loop Switching	: Indicates the cumulative number of times for which loops have been switched.
		 Parameter Setting 	: Not displayed. ("" is displayed.)
	TsSt' Sta	 Reserved Sta 	: Indicates the availability of a reserved station. (Have/None)
6)		 Communication Mode 	: Indicates either "Normal mode" or "Constant LS."
		 Transmission Mode 	: Indicates either "Normal Trans" or "Multiple Trans."*1
		 Transmission Stat 	: Indicates either "Normal Trans" or "Multiple Trans."*1

[&]quot;---" is displayed when coaxial bus connections are established.

(2) Key functions

Key	Function
Returns to the line monitor.	
Exits the detailed monitor and returns to the screen where the network monitor started.	

Display contents and keys functions: acting as a MELSECNET(II) master station

This section describes the screen configuration of the detailed monitor and the function of on-screen keys when the host acts as the master station on the MELSECNET(II).

(1) Displayed contents




No.	Item	Display contents	
1)	TsStí Info	This Station(s # : This shows the station number of the host. This Station(s : Indicates the category of the host.	
2)	D-Link Info	Indicates the maximum number of the stations to be linked, which is defined by comparameters.	mon
3)	LoopBK Info	 FLoop Shows the status of the forward loop lines of the host. (Note: RLoop Shows the status of the reverse loop lines of the host. (Note: RLoop Back Station) Indicates the station number of a station that executes the along the forward loop.	lormal/NG) le loopback le loopback

(2) Key functions

Key	Function
Returns to the line monitor.	
Exits the detailed monitor and returns to the screen where the network monitor fun started.	

Display contents and keys functions: acting as a MELSECNET(II) local station
This section describes the screen configuration of the detailed monitor and the function of on-screen keys when the host acts as the local station on the MELSECNET(II).

(1) Displayed contents



No.	Item	Display contents
1)	TsStí Info	This Station's # : Indicates the station number of the host. This Station's : Indicates the category of the host.
2)	D-Link Info	Total of L-Sta : Indicates the maximum number of the stations to be linked, which is defined by common parameters.
3)	Com status	This shows the communication status of the host. (Parameter wait/Cyclic comm/Com. suspension)
4)	BWY From Master	This shows the status of receiving Device BWY from the master station. OK: Data is being received by cyclic communication. NG: Unable to receive because the host is disconnected, etc.
5)	BW From Hostmaster	This shows the status of receiving Device BW from the master station of a dual-layer system. OK: Data is being received by cyclic communication. NG: Unable to receive because the host is disconnected, etc.
6)	LoopBK Info	 FLoop Shows the status of the forward loop lines of the host. (Normal/NG) RLoop Shows the status of the reverse loop lines of the host. (Normal/NG) FLoop Back Station Not displayed. ("" is displayed.) # of Loop Switching Not displayed. ("" is displayed.)


(2) Key functions

Key	Function
RET	Returns to the line monitor.
END	Exits the detailed monitor and returns to the screen where the network monitor function was started.

Display contents and keys functions when monitoring CC-Link IE controller network

This section describes the screen configuration of the detailed monitor and the functions of on-screen keys when the GOT monitors a control station or normal station on the CC-Link IE controller network set as the host station.

(1) Displayed contents



No.	Item		Display contents
1)	TsSt' Info	This Station's# NetWork# Group#	Displays the host station number.Displays the network number.Displays the group number.
2)	CtrlSt Info	Spc Ctrl Sta Curr Ctrl Sta Com Info SubCtrl Sta Com Rmtl/OMstSta	 Displays the station number set as the control station. Displays the station number of the station currently operating as the control station. Displays whether the GOT communicates with the control station or sub-control station. Not displayed ([] is displayed.) Displays the station numbers of the I/O master stations for block 1 and block 2. [None] is displayed with no setting.
3)	D-Link Info	 Total of L-Sta Largest Nrm Sta Largest DL-Sta Com Status 	 Displays the total number of stations on the monitored network set for common parameters. Displays the maximum station number of the station communicating normally. Displays the maximum station number of the station performing a data link. Displays the current communication status of the host station. (D-Link in prog., D-Link stopped, B-Pass excut, B-Pass stopped, Offline test, Offline)
		• Cause of Ssp ^{*1}	: Displays the reason for the interrupted communication. [Normal Comm] is displayed with normal communications. (Cable disconnet, Wrong cable, Checking cables, Disconnet/retrn, Offline mode, Offline test, Self-check mode)
		• Cause of Stop*2	: Displays the reason for the interrupted data link. [Normal] is displayed with normal data links. (Stop disignat, D-Link time up, Testing line, Param not rcvd, Invlid Host No., Set Rsvd Sta., Dup Host No., Dup CtrlSta No., Sta No. not set, Invlid NTWK No., Host Para error, Params in comm., CPU stop error, CPU pwr stp err)

(Continued to next page)

No.	Item		Display contents
4)	Constant LS	Displays the set contact link scan	time.
	LoopBK Info	• OUT Loop	: Displays the OUT-side loop line status of the host station. (Normal, LoopBK Trans, All Sta. NG)
		• IN Loop	: Displays the IN-side loop line status of the host station. (Normal, LoopBK Trans, All Sta. NG)
5)		OUT Loop Back Sta.	Displays the station number of the OUT-side loopback station.
			[] is displayed with normal loopbacks.
		■ IN Loop Back Sta.	: Displays the station number of the IN-side loopback station. [] is displayed with normal loopbacks.
		#of Loop Switching	: Displays the accumulated number of switching loops.
6)	TsSt' Sta	Parameter Setting	: Displays [No parameters], [Common Param], [Unique param], or [Common+unique].
		 Reserved Sta 	: Displays whether a reserved station exists or not.
		 Communication Mode 	: Displays [Normal Mode] or [Constant LS].
		 Transmission Mode 	: Not displayed ([] is displayed.)
		 Transmission Stat 	: Not displayed ([] is displayed.)

When the station is in the hardware test mode, self-loopback test mode, circuit test mode, or station-to-station test mode, [Offline test] is displayed.

(2) Key functions

Key	Function
RET	Returns to the line monitor.
END	Exits the detailed monitor and returns to the screen where the network monitor function was started.

^{*2} For duplication of the control station or station number, [Dup CtrlSta No.] is displayed.

7.4.3 Other station monitor


This section describes the structure of the monitor screen and the common operations used when executing the other station monitor.

1 Display contents and keys functions: other station monitor menu

This section describes the other station monitor menu screen and the function of on-screen keys. The menu screen for the other station monitor is displayed by touching a module number displayed on the host monitor screen.

By this other station monitor menu, each of the other station monitor can be specified.

(1) Displayed contents



No.	Item	Display contents
1)	COM STA	Switches to the communication status monitor for other stations.*1 (7.4.4 Other station communication status monitor)
2)	D-Link	Switches to the data link status monitor for other stations.*2 (7.4.5 Other station data link status monitor)
3)	P-MTR	Switches to the parameter status monitor for other stations.*1 ([
4)	CPU OP	Switches to the CPU operation status monitor for other stations.*3 (7.4.7 Other station CPU operation status monitor)
5)	CPU RUN	Switches to the CPU RUN status monitor for other stations.*3 (7.4.8 Other station CPU RUN status monitor)
6)	Loop	Switches to the loop status monitor for other stations.*4 (7.4.9 Other station loop status monitor)

- *1 This cannot be selected when a MELSECNET(II) local station is selected using the line monitor.
- *2 This cannot be selected when a MELSECNET(II) master station or local station is selected using the line monitor.
- *3 This cannot be selected when a remote I/O station is selected using the line monitor.
- *4 The other station loop status monitor is not available in the following conditions.
 - When a local station on the MELSECNET(II)network system is selected using the line monitor
 - When a MELSECNET network system with coaxial cables is used
 - When a station on the CC-Link IE controller network is selected using the line monitor

(2) Key functions

The table below shows the function of keys to be used for the other station monitor operations.

Key	Function
to 🕥	Switches to each monitor for other stations.
RET	Returns to the line monitor.
END	Exits the other station monitor screen and returns to the screen where the network monitor function was started.

7.4.4 Other station communication status monitor

This section describes the screen configuration of the other station communication status monitor and the function of keys displayed on it.

This screen cannot be displayed for a MELSECNET(II) local station.

(1) Displayed contents



No.	Display contents
1)	Displays the communication status by station number. (OK/ERR) The station numbers displayed do not indicate the number of station numbers in the network, rather the maximum number of communication stations.
2)	Any station in an abnormal condition is highlighted.
3)	Reserved stations are displayed as normal stations.

(2) Key functions

The table below shows the functions of the keys that are used for the other station communications status monitor operations.

Key	Function
RET	Returns to the other station monitor.
END	Exits the other station communication statuses monitor screen and returns to the screen where the network monitor was started.
Y A	Switches the screen display of stations. (1 to 80 stations/81 to 120 stations)

7.4.5 Other station data link status monitor

This section describes the screen configuration of the other station data link status monitor and the function of on-screen keys.

This screen cannot be displayed for a MELSECNET(II) master station or local station.

(1) Displayed contents



No.	Display contents
1)	Displays the data link status by station number. (OK/NO) The station numbers displayed do not indicate the number of station numbers in the network, rather the maximum number of communication stations.
2)	Any station to which data link is not performed is highlighted.
3)	Reserved stations are displayed as having a data link established.

(2) Key functions

The table below shows the function of keys that are used for the operations of other station data link status monitor.


Key	Function
RET	Returns to the other station monitor.
END	Exits the other station data link status monitor screen and returns to the screen where the network monitor was started.
V A	Switches the screen display of stations. (1 to 80 stations/81 to 120 stations)

7.4.6 Other station parameter status monitor

This section describes the screen configuration of the other station parameter status monitor and the function of on-screen keys.

This screen cannot be displayed for a MELSECNET(II) local station.

(1) Displayed contents



No.	Display contents
1)	Displays the parameter status by station number. The station numbers displayed do not indicate the number of station numbers in the network, rather the maximum number of communication stations.
2)	Any station whose parameters are monitored is highlighted.*1
3)	Any station in an abnormal condition is highlighted.
4)	Reserved stations are displayed as normal stations.

^{*1} Only [Parameter Err Sta.] is displayed when connecting to a MELSECNET(II) master station.

(2) Key functions

The table below shows the function of keys that are used for the operations of the other station parameter status monitor.


Key	Function
RET	Returns to the other station monitor.
END	Exits the other station parameter status monitor screen and returns to the screen where the network monitor was started.
V A	Switches the screen display of stations. (1 to 80 stations/81 to 120 stations)

7.4.7 Other station CPU operation status monitor

This section describes the screen configuration of the other station CPU operation status monitor and the function of on-screen keys.

This screen cannot be displayed for a remote I/O network system.

(1) Displayed contents



No.	Display contents
1)	Displays the CPU operation status by station number. (OK/ERR) The station number displayed does not indicate the station number in the network, rather the maximum number of communication stations.
2)	Any station that stays in an abnormal condition or out of operation is highlighted.
3)	Reserved stations and unconnected stations are displayed as normal stations.

(2) Key functions


The table below shows the function of keys that are used for the operations of the other station CPU operation status monitor.

Key	Function				
RET	Returns to the other station monitor.				
END	Exits the other station CPU operation status monitor screen and returns to the screen where the network monitor was started.				
V A	Switches the screen display of stations. (1 to 80 stations/81 to 120 stations)				

7.4.8 Other station CPU RUN status monitor

This section describes the other station CPU RUN status monitor and the function of on-screen keys. This screen cannot be displayed for a remote I/O network system.

(1) Displayed contents



No.	Display contents
1)	Displays the CPU operation status by station number. (RUN/STOP) "DOWN" is displayed for stations with communication errors. Up to 64 stations are displayed regardless of the number of stations in a network.
2)	"" is displayed for a reserved station and the statuses of stations beyond the maximum communication stations, or when a MELSECNET(II) local station has been selected in the line monitor.

(2) Key functions

The table below shows the function of keys that are used for the operations of the other station CPU RUN status monitor.

Key	Function
RET	Returns to the other station monitor.
END	Exits the other station CPU RUN status monitor screen and returns to the screen where the network monitor was started.
V A	Switches the screen display of stations. (1 to 80 stations/81 to 120 stations)


7.4.9 Other station loop status monitor

This section describes the screen configuration of the other station loop status monitor and the function of on-screen keys.

The other station loop status monitor is not available in the following conditions.

- When a local station on the MELSECNET(II)network system is selected using the line monitor
- · When a MELSECNET network system with coaxial cables is used
- · When a station on the CC-Link IE controller network is selected using the line monitor

(1) Displayed contents



No.	Display contents
1)	The F-loop (forward loop) status and the R-loop (reverse loop) status are displayed.
2)	The station numbers displayed do not indicate the number of station numbers in the network, rather the maximum number of communication stations.
3)	Any station that stays in an abnormal condition is highlighted.
4)	Reserved stations are displayed as normal stations.

(2) Key functions

The table below shows the function of keys that are used for the operations of the other station loop status monitor.

Key	Function					
RET	Returns to the other station monitor.					
END	Exits the other station loop status monitor screen and returns to the screen where the network monitor was started.					

7.5 Error Message and Corrective Action

The following shows the error messages that are displayed during the network monitor operation and how to handle them.

Error message	Contents of error	Action to take				
Communication channel setup error	There is no channel for communication.	Set the channel number in the Communication Settings of the utility.				
Can not Communication	Communication could not be established with the PLC CPU.	 Check the connections between the controller and the GOT for disconnected connectors and cables. Check if an error has occurred in the controller. 				
A keyword has been set in the parameter when monitoring the MELSECNET(II) master station of the QnACPU.		Release the set keyword.				

8. Q MOTION MONITOR



8.1 Features


The Q motion monitor enables the servo monitoring and parameter setting of the motion controller CPU. The following are the features of the Q motion monitor.

Various servo monitor data can be displayed on multiple monitor screens
The Q motion monitor function has multiple monitor screens, on which you can monitor servo data in a

(Display examples)

variety of patterns.


Present Value Monitor



 Monitors and displays the feed current values and actual current values of all running axes.

(8.4.3 Present Value Monitor screen)

Positioning Monitor



Monitors the details of the positioning data set to any axis.
 \$\mathbb{F}\$ 8.4.7 Positioning Monitor screen)


Error List



 Displays the history of errors that occurred on and after the leading edge of PLC ready (M2000).

(8.4.5 Error List screen)

Error List Designated-Axis




Displays the latest errors that occurred on the specified axis.

(8.4.6 Error List Designated-Axis screen)

8


2 Servo parameters can be changed by writing

(Write example: Disabling the auto tuning function)



Feed Forward Gain

Auto Tuning Mode1



Speed Integral Comp Notch Filter Feed Forward Gain



Parameter setting screen

Change auto tuning from "1" to "2" (No Auto).

3

7.0[To Motor] 70 rad/sec

D

▲ ▶

E F

· +/- Enter Del AC

Parameter setting is changed.

- By performing writing from the parameter setting screen, write the servo parameter setting (basic parameters/adjustment parameters) to the motion controller CPU.
- To change a servo parameter setting, enter the necessary numerical value or option number from the automatically displayed key window, and write it to the motion controller CPU.

8.2 Specifications

8.2.1 System configuration

This chapter describes the system configuration of the Q motion monitor.

For connection type settings and precautions regarding the communication unit/cable and connection type, see the following manual.

GOT1000 Series Connection Manual

1 Target motion controller CPU of the Q motion monitor

Motion controller CPU*1*2

Q172CPU, Q173CPU, Q172CPUN, Q173CPUN, Q172HCPU, Q173HCPU, Q172DCPU, Q173DCPU, Q170MCPU

- *1 For the Q172CPU and Q173CPU, only the following production number module can be used.
 - For bus connection and direct CPU connection
 - Q172CPU: Production number K****** or later
 - Q173CPU: Production number J****** or later
 - For a connection other than bus connection and direct CPU connection Q172CPU: Production number N******* or later
 - Q173CPU: Production number M****** or later
- *2 When using SV13 or SV22 with the Q172CPU, Q173CPU, Q172CPUN, or Q173CPUN, install the following version of the OS.

SW6RN-SV13Q : 00H or later (00E or later when using the Q172CPU or Q173CPU with a bus connection or direct CPU connection)

SW6RN-SV22Q : 00H or later (00E or later when using the Q172CPU or Q173CPU with a bus connection or direct CPU connection)

2 Connection type

(1) When the GOT is connected to a QCPU (Q mode), QnACPU, or motion controller CPU

 $(\bigcirc : \mathsf{Available}, \, \triangle : \mathsf{Partly} \; \mathsf{restricted}, \; \pmb{\times} : \mathsf{Unavailable})$

Function		Connection type between GOT and controller								
Name	Description	Bus Direct CPU connection		Computer	Ethernet	MELSECNET/H connection,	CC-Link	CC-Link connection		GOT multidrop connection
			connection	connection	MELSECNET/10 connection	IE ^{*1}	ID ^{*2}	G4*3		
Servo monitor	Monitors the present value, positioning error and other servorelated items on a variety of monitor screens.		△*4		0	0	0	0	×	×
Parameter settings	Changes the setting of the servo parameter.									

- *1 Indicates the CC-Link IE controller network connection.
- *2 Indicates CC-Link connection (Intelligent device station).
- *3 Indicates CC-Link connection (via G4).
- *4 Only the motion controller CPU on the host station can be monitored. Monitoring or setting of parameters of other station cannot be performed.

3 Required option OS and option function board

The option function OS and option function board shown below are required.

Option OS	OS memory space (user area)		Option function board			
	GT16					
	Built-in flash memory (ROM)	User memory (RAM)	GT15	GT16	GT15	
Q motion monitor	390KB	770KB	607KB	Not required	GT15-FNB, GT15-QFNB16M, GT15-QFNB48M,	GT15-QFNB, GT15-QFNB32M, GT15-MESB48M

(1) Option OS

Install the option OS in the above table to the GOT.

Refer to the following manual for the procedure for installing the option OS.

GT Designer2 Version

Basic Operation/Data Transfer Manual (8. TRANSFERRING DATA)

(2) OS memory space

The available memory space shown in the table above is required in the user area to install the option OS to the GOT.

Refer to the following manual for the procedure for checking the available memory space of the user area and information about the data using other user areas.

GT Designer2 Version
Basic Operation/Data Transfer Manual (8. TRANSFERRING DATA)

(3) Option function board

(a) For GT16

No option function board is required.

(b) For GT15

Mount one of the option function boards in the above table on the GOT.

For the GOTs with a built-in option function board, refer to the following.

1.1.2 Hardware and OS' required for each function

For how to mount an option function board on the GOT, refer to the following manual.

GT15 User's Manual (8.10 Option Function Board)

4 Required special data

The following special data is required.

Special data	GOT	Memory space (KB)
	GT1695M-X, GT1685M-S, GT1675M-S, GT1665M-S, GT1595-X, GT1585V-2, GT1585-S, GT1575V-S, GT1575-S	398
Motion monitor data	GT1675M-V, GT1665M-V, GT1575-V, GT1575-VN, GT1572-VN, GT1565-V, GT1562-VN, GT1555-V	396
	GT1555-Q, GT1550-Q	168

(1) Special data

Download the special data indicated in the table above to the GOT.


Refer to the following manual for the procedure for downloading the data.

GT Designer2 Version ☐ Basic Operation/Data Transfer Manual (8. TRANSFERRING DATA)

(2) Memory space for special data

The available memory space shown in the table above is required in the user area to download the special data to the GOT.

Refer to the following manual for the procedure for checking the available memory space of the user area and information about the data using other user areas.



8.2.2 Access range

In bus connection, direct CPU connection, or computer link connection, only the motion controller CPU on host station can be monitored. (Monitoring of other stations cannot be performed.)

For the MELSECNET/H, MELSECNET/10, and CC-Link IE controller network connections, the GOT can monitor the motion controller CPU on the control station only.

In CC-Link connection (Intelligent device station), only the motion controller CPU in master station can be monitored.

In Ethernet connection, only the motion controller CPU in host station can be monitored.

The access range other than that mentioned above is the same as the access range when the GOT is connected to a controller.

Refer to the following manual for details of the access range.

GT Designer2 Version ☐ Screen Design Manual (2.7 Controllers that can be Monitored and Access Range)


8.2.3 Precautions


- (1) Main OS software package for motion controller The only Main OS software package that can be used is SV13 or SV22.
- (2) When using GT1555-Q and GT1550-Q The present value history monitor is not supported.
- (3) When setting parameters for Q172HCPU or Q173HCPU When setting parameters for Q172HCPU or Q173HCPU, after parameter entry, set the switch on the CPU to STOP and RUN again, or reset the CPU.

8.3 Display

1 Operations for display

This section describes the flow until the Q motion monitor operation screen is displayed after the Q motion monitor (Option OS) is installed in the GOT.







(1) How to display the utility

For how to display the utility, refer to the following.

GT16 User's manual (Basic Utility) (1.3 Utility Display)
GT15 User's manual (9.3 Utility Display)

(2) Displaying communication setting window

After turning on the GOT, the communication setting window is displayed at the first startup of the Q motion monitor only.


For displaying the communication setting window at the second or later startup,

touch the $\fbox{Ch:}$ button on the Q motion monitor screen. ($\fbox{2}$ 8.4 Operation Procedures)

(3) If the project data has not been downloaded

The Q motion monitor can be started from the utility even if the project data has not been downloaded to the GOT.

2 Changing screens





Screen displayed at next startup

At next startup, the last exited screen is displayed.

However, the last exited screen will not be displayed when the GOT is restarted due to an installation of the OS, turning the GOT power from off to on, or a reset.

8.4 Operation Procedures

This section explains screen operations to be performed when using the Q motion monitor.


The display screen of the Q motion monitor varies slightly with the GOT used.

This section mainly uses the screen of the GT1575-V for explanation.

8.4.1 System configuration screen layout

This section describes the configuration of the System Configuration screen that is displayed after startup of the Q motion monitor and the functions of the keys displayed on the screen.

1 Displayed contents



No.	Description
1)	The CPU numbers are displayed for CPUs and the control CPU number for the installed module. To choose the motion controller CPU for servo monitor/servo parameter setting, touch the respective display position.
2)	Displays the keys used with the operation on the System Configuration screen shown in [2]. (Touch input)

2 Key functions


The table below shows the functions of the keys that are used for the operation on the System Configuration screen.

Key	Function		
Ch: 2 Displays the communication setting window.			
END	Exits the monitor and returns to the screen where the Q motion monitor was started.		
02540773 1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Selects the motion controller CPU where servo monitor/servo parameter setting is performed.		
	Changes the System Configuration screen to the monitor menu screen.		
Motion Monitor	(8.4.2 Monitor Menu screen)		
	Changes the System Configuration screen to parameter setting screen.		
Parameter Set.	(S 8.4.10 Parameter setting screen)		
	Scrolls the display one stage up or down to display the system configuration of the currently		
	undisplayed stage immediately before/after the currently displayed stage.		
	Scrolls down one stage.		
	▼ : Scrolls up one stage.		

8.4.2 Monitor Menu screen

The Q motion monitor allows you to monitor various servo monitor data on multiple monitor screens. To display any of the monitor screens, make a selection on the monitor menu screen.

(Monitor menu screen)




Item	Description	
Present Value Mon.	Monitors and displays the feed current values and actual current values of all running axes. ([3 8.4.3 Present Value Monitor screen)	
SFC Error History	Displays the history of errors that occurred in SFC programs from when the motion CPU was powered on or reset. (8.4.4 SFC Error History screen)	
Error List	Displays the history of errors that occurred on and after the leading edge of PLC ready (M2000). (3 8.4.5 Error List screen)	
Error List Axis	Displays the latest errors that occurred on the specified axis. ([8.4.6 Error List Designated-Axis screen)	
Positioning Monitor	Monitors the details of the positioning data set to any axis. (8.4.7 Positioning Monitor screen)	
Servo Monitor	Monitors the servo monitor/servo amplifier. (8.4.8 Servo Monitor screen)	
Present Value Hist.	Displays the history of encoder present values, servo command values and monitor present values of the ABS axis at servo amplifier power-on/off or at home position return. (8.4.9 Present Value History Monitor screen) Not displayed when using the GT155	

8.4.3 Present Value Monitor screen

This section describes the display data of the Present Value Monitor screen and the key functions displayed on the screen.

1 Displayed contents



No.	Item	Function
1)	Ax	The axis numbers of the running axes being monitored are displayed.
2)	Feed PV/Actual PV	The feed present values or actual present values of the running axes are displayed. Touching the display part of the monitored value switches to the positioning monitor screen of the touched axis number. (8.4.7 Positioning Monitor screen)
3)	SV RDY, ERR DT, SV ERR	Whether the servo ready signals, major/minor errors and servo error detection signals are ON (lit) or OFF (not lit) are displayed. Touching the error indication part " " switches to the Error List Designated-Axis screen of the touched axis number. (8.4.6 Error List Designated-Axis screen)
4)	Bit device screen	The common bit devices are always monitored and displayed. Error detection type bit devices Displayed in red General status type bit devices

2 Key functions

The table below shows the functions of the keys used for operation of the Present Value Monitor screen.

Key	Function
Feed PV Actual PV	Touching the key alternates the monitor item between the "feed present value" and "actual present value". (Only in the real mode)
Mon. Menu	Returns to the monitor menu screen.
END	Exits the present value monitor and returns to the screen where the Q motion monitor was started.
	Switches the displayed axis number. (Displayed only for Q173CPU, Q173HCPU and Q173CPUN monitoring.)
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 8.4.11 Hard copy output
Cancel Print	The operation of this key is invalid.


8

8.4.4 SFC Error History screen

This section describes the display data of the SFC Error History screen and the key functions displayed on the screen.

1 Displayed contents

The SFC Error History screen displays the history of error which occurs in the motion SFC programs.



No.	Item	Description
1)	M/D H:M	Displays the dates and time when SFC errors occurred.
	N/D H.W	The eight latest errors are displayed for the history of errors.
2)	Program No.	Displays the SFC program numbers where SFC errors occurred.
3)	Err Code	Displays the error codes of the errors that occurred.
4)	Error Definition	Displays the definitions of the SFC errors that occurred.

2 Key functions

The table below shows the functions of the keys used for operation of the SFC Error History screen.


Key	Function		
Mon. Menu	Returns to the monitor menu screen.		
END	Exits the SFC Error History screen and returns to the screen where the Q motion monitor was started.		
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: (3.4.11 Hard copy output)		
Cancel Print	The operation of this key is invalid.		
History Clear	Clears the error history. (Only with Q172DCPU and Q173DCPU)		

8.4.5 Error List screen

This section describes the display data of the Error List screen and the key functions displayed on the screen.

1 Displayed contents

The Error List screen displays the error which occurs in the motion controller CPU. (Errors caused in motion SFC programs are also displayed.)



No.	Item	Description
1)	M/D H:M	The dates and time when errors occurred are displayed.
.,	IVI/D I I.IVI	The eight latest errors are displayed.
		The axis numbers and axis types of the axes where errors occurred are
2)	Ax	displayed.
-/	~^	Virtual axis : Virtual
	!	Synchronous encoder axis: Sync
		The servo program numbers that were being executed when the error
3)	SV P. No.	occurred are displayed.
0)	SV P. NO.	The execution destination of the servo program in error is not displayed. Using
		the servo program number, refer to the execution destination.
		Displays the types and error codes of the errors that occurred.
		The error types are displayed as indicated below.
	Err Code	Minor error Minor
		· Major error Major
		Servo error Servo
4)		Servo program setting error Servo P
		Real/virtual switching Switch
		Test mode request error Test
		Manual pulse generator setting error Manual
		· PCPU ERROR P-WDT
		SSCNET ERRORCommunication error
5)	Error Definition	The definitions of the errors that occurred are displayed.
6)	Set Data	The program number in error is displayed if the set data has any errors.

2 Key functions


The table below shows the functions of the keys that are used for the operation on the Error List screen.


Key	Function	
Mon. Menu Returns to the monitor menu screen.		
Exits the Error List screen and returns to the screen where the Q motion monitor was started		
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 8.4.11 Hard copy output	
Cancel Print	The touch operation of this key is invalid.	

8.4.6 Error List Designated-Axis screen

This section describes the display data of the Error List Designated-Axis screen and the key functions displayed on the screen.

1 Displayed contents





No.	Item		Description
1)	Axis No.		Displays the axis number currently being monitored.
2)	Out Module		Displays the output module axis number currently being monitored.
3)	Virt. Axis		Displays the virtual axis number currently being monitored.
4)	Sync. Enco.		Displays the synchronous encoder axis number currently being monitored.
5)	Program No.		Displays the servo program numbers that were being executed when the error occurred.
6)	Err Code		Displays the error codes of the minor/major/servo error, servo program setting error, real/virtual switching error information (error code: hexadecimal), personal computer link communication error code and motion CPU WDT error that are currently occurring.
7)	Error Definition		Displays the definitions of the errors that occurred.
	8) MAN-PLS Axis ERR	Each 1-Pulse 1M Error	Displays the axes where a 1-pulse input magnification setting error occurred.
8)		MAN-PLS AX ERR	Displays the errors of the axis numbers set to the manual pulse generators P1 to P3.
	Each MAN- PLS SM ERF		Displays the errors of the smoothing magnifications set to the manual pulse generators P1 to P3.
9)	Test REQ ERR		Displays the axis numbers that are being started at a test mode request.

2 Key functions


The table below shows the functions of the keys that are used for the operation of the Error List Designated-Axis screen.


Key	Function
(Only in the real mode) Out Module / Virt.Axis / Sync.Enco. 1Ax (Only in the virtual mode) (Display example: When axis 1 is monitored)	Switches the axes to be monitored.
RET	Returns to the previous screen.
Mon. Menu	Returns to the monitor menu screen.
END	Exits the Error List Designated-Axis monitor screen and returns to the screen where the Q motion monitor was started.
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 8.4.11 Hard copy output
Cancel Print	The touch operation of this key is invalid.

8.4.7 Positioning Monitor screen

This section describes the display data of the Positioning Monitor screen and the key functions displayed on the screen.

1 Displayed contents





No.	Item	Description			
		Displays the axis numbers of the running axes being monitored.			
		For the virtual axis, the axis type is displayed.			
1)	Data Item	· Roller			
',	But item	- Ballscrew			
		Rotary table			
		- Cam			
		Displays the data during pos	itioning control of the PCPU.		
		Feed PV	: Target address output to the servo amplifier		
			(value of the roller surface speed for the roller		
			axis)		
		Actual PV	:Actually traveled present value (no value is		
0)	Feed PV	5.40	displayed for the roller axis)		
2)		- Dvt. Counter	: Difference between feed present value and		
		- EXE Prog No.	actual present value : Servo program number in execution		
		Min/Major SV ERR	:Error code of the latest minor/major/servo		
		- Will / Wajor OV LIKIK	error		
		M Code T Limit	:The M code and torque limit of the servo		
			program in execution		
3)	EXE Cam No.	Displays the cam number cu			
4)	EXE Stroke	Displays the stroke amount currently controlled.			
5)	Cam Ax. 1 Rev.	Displays the present value within one cam axis revolution pulse.			
		Displays ON and OFF of the symbols that represent the axis-by-axis contri			
		statuses.			
6)	Status	In the ON status, the symbol is lit green.			
		At error or servo error detection, the symbol is lit red.			
		Displays ON and OFF of the positioning command signals.			
7)	CMD Signal	' '	In the ON status, the signal is lit green.		

2 Key functions


The table below shows the functions of the keys used for operation of the positioning monitor screen.

Key	Function		
Data Item 1Ax (Display example: When axis 1 is monitored)	Changes the axes to be monitored.		
RET	Returns to the previous screen.		
Mon. Menu	Returns to the monitor menu screen.		
END	Exits the positioning monitor and returns to the screen where the Q motion monitor was started.		
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 8.4.11 Hard copy output		
Cancel Print	The operation of this key is invalid.		

8.4.8 Servo Monitor screen

This section describes the display data of the Servo Monitor screen and the key functions displayed on the screen.

1 Displayed contents



No.	Item	Description	
1)	Ax	Displays the axis number currently being monitored.	
2)	Motor Speed	Displays the actual speed of the servo motor.	
3)	Motor Current	Displays the motor current value at the rated current of 100%.	
4)	Servo Alarm	Displays the alarm detected by the servo amplifier.	

2 Key functions


The table below shows the functions of the keys that are used for operation of the servo monitor screen.

Key	Function		
1 Ax (Display example: When axis 1 is monitored)	Changes the axes to be monitored.		
Mon. Menu	Returns to the monitor menu screen.		
END	Exits the servo monitoring and returns to the screen where the Q motion monitor was started.		
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 8.4.11 Hard copy output		
Cancel Print	The operation of this key is invalid.		

8.4.9 Present Value History Monitor screen

This section describes the display data of the Present Value History Monitor screen and the key functions displayed on the screen.

1 Displayed contents



No.	Item	Description		
1)	Ax	Displays the axis number of the axis currently being monitored.		
2)	HP Data	Displays the following values monitored at home position return. Home position return completion time Encoder present value Multi-revolution data of absolute position reference point data Within-one-revolution position of absolute position reference point data Servo command value Monitor present value		
3)	MON Val	Displays the following present monitor values. Present time Encoder present value Present multi-revolution data of encoder present value Present within-one-revolution position of encoder present value Present servo command value Present monitor present value		
4)	PWR ON/PWR OFF	Displays the four past present values of the ABS axis at servo amplifier power-on/off. [At power-on] Power-on time Encoder present value Multi-revolution data of initial encoder Single-revolution data of initial encoder Servo command value after recovery Monitor present value after recovery Alarm occurrence information at present value recovery (error code of minor/major error) [At power-off] Servo amplifier power-off time Encoder present value Multi-revolution data of encoder present value before servo amplifier power-off Single-revolution data of encoder present value before servo amplifier power-off Servo command at servo amplifier power-off Monitor present value at servo amplifier power-off		

2 Key functions

The table below shows the functions of the keys used for operation of the Present Value History Monitor

Key	Function		
1A× (Display example: When axis 1 is monitored)	Changes the axes to be monitored.		
Mon. Menu	Returns to the monitor menu screen.		
END	Exits the Present Value History Monitor screen and returns to the screen where the Q motion monitor was started.		
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 8.4.11 Hard copy output		
Cancel Print	The touch operation of this key is invalid.		


8

8.4.10 Parameter setting screen

You can set the servo parameters (basic parameters/adjustment parameters) of the connected motion controller CPU.

This section describes the display data of the parameter setting screen and the key functions displayed on the screen.

1 Displayed screen




2 Key functions

The table below shows the functions of the keys that are used with the operation on the parameter setting screen.

Key	Function		
CHG	Changes the servo parameter setting of the selected item.		
	Selects the servo parameter setting item.		
AxNo	Changes the axis whose parameter setting will be made.		
Sys. Conf	Returns to the System Configuration screen.		
END	Exits the parameter setting and returns to the screen where the Q motion monitor was started.		
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 8.4.11 Hard copy output		
Cancel Print	The touch operation of this key is invalid.		

3 Inputting the password

The password input key window appears for accessing the parameter setting screen when the password setting data for changing motion parameters is written to the GOT with GT Designer2.



(1) Function

- If the password matches, the parameter setting screen is displayed.
- If the password does not match, an error message is displayed. Touching Sys. Conf returns to the System Configuration screen.
- Only numbers and letters A to F can be used for the password setting. (Up to 8 characters)
- The password for changing the motion parameters is set with GT Designer2.
 Refer to GT Designer2 Version

 □ Screen Design Manual (3.5 Password Setting) for details on setting the password.

(2) Operations

(a) Inputting the password

Touch the key window and enter a password.

After entering the password, touch Enter to set the password.


To edit the input characters, touch Del to delete the characters, and then input the new characters.

(b) Canceling password input

Touch \times to return to the monitor screen.

4 Parameter setting operation


The following describes the procedure of changing the setting of the [Auto Tuning] item as an example of the parameter setting operation.



(Touch)



Enter (Touch) 1





Select the item whose parameter is to be set with the ▲, ▼ keys, and touch the CHG key.

- As the parameter setting window appears, enter the parameter setting with Alphanumeric, and touch Enter to confirm the setting. To cancel the parameter setting operation, touch $|\times|$ at the top right of the screen to close the parameter setting window.
- As the confirmation window appears, touch OK to write the parameter setting to the motion controller CPU. To cancel writing of the parameter setting, touch Cancel


After writing is completed, the parameter setting screen whose display has been updated to the new parameter setting is displayed.

8.4.11 Hard copy output

This section describes how to store a screen to the memory card in BMP/JPEG file format or print it with a printer when executing the Q motion monitor.

Hard copy methods differ depending on the GOT to be used.

(1) GOT with VGA or higher resolution Hard copy output operations are performed by touching the "Print Screen" or "Cancel Print" key displayed on the screen.



(2) GOT with QVGA resolution

Hard copy output operations are performed by turning ON/OFF the start or abort trigger device that has been set in the GT Designer2.



- Install the extended function OS (Printer) to the GOT when printing a Q motion monitor screen.
- The output target (CF card/printer) of hard copy can be set in [Hard Copy] of GT Designer2.

For details of the hard copy setting, refer to the following.

GT16 User's Manual (Basic Utility) (Chapter 6 DATA CONTROL)
GT15 User's Manual (Chapter 13 FILE DISPLAY AND COPY)

GT Designer2 Version Screen Design Manual (Section 13.2 Hard Copy)

8.5 Error Messages and Corrective Action

This section describes the error messages that may be displayed during Q motion monitor operation and their corrective action.

Error message	Error definition	Corrective action	
No. PLC Communications	Communication cannot be established with the PLC CPU of the monitor target.	Check the status of the connection between the controller and the GOT (disconnected or cut cables). Check if an error has occurred in the controller.	
This PLC type is not supported A motion controller CPU that cannot be monitored was selected on the System Configuration screen.		Select a motion controller CPU that can be monitored on the System Configuration screen. (8.2.1 Target motion controller CPU of the Q motion monitor)	
Controller's OS type is different	The motion controller OS installed in the motion controller CPU (Q172CPU, Q173CPU) of the monitor target is other than SV13 or SV22.	Install SV13 or SV22 in the motion controller CPU (Q172CPU, Q173CPU) of the monitor target as the motion controller OS.	
The version of the motion controller OS installed in the motion controller CPU of the monitor target is not compatible with the Q motion monitor.		Install a motion controller OS that is compatible with the Q motion monitor in the motion controller. (GT GT Designer2 Version GC Screen Design Manual (2.7 Controllers that can be Monitored and the Access Range))	
Monitor data not found	The monitor data was not installed or was deleted.	Download the monitor data of the motion monitor.	
Unused axis selected The axis number selected has not been set.		Select the axis number that has been set.Set the axis using the peripheral software.	
It is not possible to select	During servo parameter setting, an item that cannot be set has been selected.	Select an item that can be set.	
Incorrect setting range	A value that is outside the setting range has been set.	Set the value within the setting range.	
Unmatched password	The password that was input as the motion parameter changing password is incorrect.	Input the correct password.	
Communication channel setup error	A communication driver that is compatible with the Q motion monitor is not installed.	Install a compatible communication driver.	



How to clear a displayed error message

For errors that occur with the connection to a controller (communication error, etc.), the error message does not disappear even after the cause of the error has been removed.

To delete the error message, restart the GOT.

9. SERVO AMPLIFIER MONITOR



9.1 Features


Various monitor functions, changes to the parameter settings and test operations can be performed on the servo amplifier connected to the GOT.

The features of the servo amplifier monitor are described below.

Real-time display of the servo amplifier status (9.4.3 9.4.4)

A list of the status of the servo amplifier connected to the GOT and the alarm details can be displayed in real-time.

(Display examples)



- Displays monitor data of the servo amplifier in a list.



Alarm display

 Displays the details (number, name, occurrence time and cause of alarm) of the alarm currently occurring in the servo amplifier.
 The alarm can also be reset. Various diagnostics of the servo amplifier can be performed (\$\subseteq 9.4.5\$)
There are multiple diagnostics functions to enable various diagnostics of the servo amplifier to be performed.
(Display examples)

DI/DO display



• Displays a list of the ON/OFF status of the external I/O signals of the servo amplifier.


Amplifier information display



 Displays the servo amplifier software number and servo motor information (model name, ID and encoder resolution).

Writing of the servo parameters is enabled (\$\subseteq 9.4.6\$)

The servo amplifier parameters can be read, changed and written to the servo amplifier.




4 Various test operations can be performed (59.4.6)


Various test operations can be performed on the connected servo amplifier.

(Display examples)

JOG operation



 The servo amplifier rotates while the Forward or Reverse key is touched. Motor less operation



 Simulates motion of the servo motor within the servo amplifier even when the servo motor is not connected.

9.2 Specifications

9.2.1 System configuration

This section describes the system configuration of the servo amplifier monitor.

For connection type settings and precautions regarding the communication unit/cable and connection type, see the following manual.

GOT1000 Series Connection Manual

1 Servo amplifiers targeted for the servo amplifier monitor

Servo amplifier
MELSERVO-J2-Super series
MELSERVO-J2M series
MELSERVO-J3 series

2 Connection type

(⊜: Available, ★: Unavailable)

Function		Connection type between GOT and servo amplifier	
Name	Description	Direct connection	GOT multidrop connection
Servo amplifier monitor	Servo amplifier monitor, changing the servo parameter settings and test operations	0	×

3 Required option OS and option function board

The option OS and option function board shown below are required.

Option OS	OS memory space (user area)		Option function board			
	GT16					
	Built-in flash memory (ROM)	User memory (RAM)	GT15	GT16	GT15	
Servo amplifier monitor	390KB	770KB	524KB	Not required	GT15-FNB, GT15-QFNB16M, GT15-QFNB48M,	GT15-QFNB, GT15-QFNB32M, GT15-MESB48M

(1) Option OS

Install the option OS in the above table to the GOT.

Refer to the following manual for the procedure for installing the option OS.

GT Designer2 Version Dasic Operation/Data Transfer Manual (8. TRANSFERRING DATA)

(2) OS memory space

The available memory space shown in the table above is required in the user area to install the option OS to the GOT.

Refer to the following manual for the procedure for checking the available memory space of the user area and information about the data using other user areas.

GT Designer2 Version ☐ Basic Operation/Data Transfer Manual (8.TRANSFERRING DATA)

(3) Option function board

(a) For GT16

No option function board is required.

(b) For GT15

Mount one of the option function boards in the above table on the GOT.

For the GOTs with a built-in option function board, refer to the following.

1.1.2 Hardware and OS' required for each function

For how to mount an option function board on the GOT, refer to the following manual.

GT15 User's Manual (8.10 Option Function Board)

4 List of servo amplifier types that can be monitored and functions

The list of servo amplifier types that can be monitored and their functions is shown below.

(O: Monitoring is possible with the servo amplifier monitor X: Monitoring is not possible with the servo amplifier monitor -: Function unavailable)

	Servo Amplifier	MR-J2-S	uper series	MR-J2	MR-J3 series	
Function		MR-J2S-□A	MR-J2S-□CP	MR-J2M-P8A	MR-J2M-□DU	MR-J3-□A
Setup	Model selection	0	0	0	0	0
	Baud rate*1	0	0	0	0	0
	Station No. Selection*1	0	0	-	-	-
Setup	Station selection	0	0	0	0	0
	Axis selection	-	-	0	0	-
	Automatic demo	×	-	-	×	×
	Display all	0	0	0	0	0
	High speed monitor	×	×	×	×	×
Monitor	Multi-axis listing	-	-	×	×	-
	Trend graph	×	×	-	×	×
	I/O Input/Output display*2	-	-	-	-	0
	Display	0	0	0	0	0
Alarm	History	0	0	0	0	0
	Amplifier data	×	×	×	×	×
	I/O display	0	0	0	-	-
	Function device display	-	0	0	0	-
	No motor rotation	×	×	-	×	×
	Total power-on time	×	×	×	×	×
	Software number display	0	0	0	0	0
5	Motor data display	0	0	-	0	0
Diagnostic	Tuning data	×	×	-	×	×
	Amplifier information	0	0	0	0	0
	Absolute encoder data	0	0	-	0	0
	Automatic voltage control	×	-	-	-	-
	Axis name setting	×	×	-	×	×
	Unit composition listing	-	-	0	0	-
	Parameter list	0	0	-	-	0
	Tuning	×	×	-	×	×
	Change list	×	×	×	×	×
	IFU parameter	-	-	0	0	-
_	DRU parameter	-	-	0	0	-
Parameters	Parameter copy	-	-	-	-	×
	Device setting	-	×	×	×	×
	Basic setting	-	-	-	-	0
	Gain/Filter	-	-	-	-	0
	Extension setting	-	-	-	-	0
	I/O setting	-	-	-	-	0
	Jog	0	0	-	0	0
	Positioning	0	0	-	0	0
Test	Operation w/o motor	0	0	-	0	0
	Forced output	0	0	0	-	0
	Program test	×	-	-	×	×
	Single-step feed	-	×	-	-	-

(Continued to next page)

LADDER EDITOR

(O: Monitoring is possible with the servo amplifier monitor X: Monitoring is not possible with the servo amplifier monitor -: Function unavailable)

	Servo Amplifier	MR-J2-Super series		MR-J2N	MR-J3 series	
Function		MR-J2S-□A	MR-J2S-□CP	MR-J2M-P8A	MR-J2M-□DU	MR-J3-□A
Point-data	Point table	-	×	-	-	-
Advanced- function	Machine analyzer	×	-	-	×	×
	Gain search	×	=	-	×	×
	Machine simulation	×	-	-	×	×
	Robust disturbance compensation	-	-	-	-	×

*1 Set the baud rate and station number setting with Communication Settings.

Refer to the following manual for setting Communication Settings.

GT Designer2 Version ☐ Screen Design Manual (3.7 Communication Interface Setting (Communication Settings))

*2 For the MR-J3 series, it is displayed with "I/O display" in "Diagnostic".

5 Required special data

The following special data is required.

(a) When using GT16 \square M-X, GT16 \square M-S, GT16 \square M-V, GT15 \square \square -X, GT15 \square \square V-S, or GT15 \square \square -S

(- : Unavailable)

Function details			Memory space (KB)						
		Stored screen data	For MR-	For MR-	For MR-	For MR-	For MR-		
i dilot	ion details	Stored screen data	J2S-□A	J2S-□CP	J2M-P8A	J2M-□DU	J3-□A		
100			monitoring	monitoring	monitoring	monitoring	monitoring		
	monitor data common				21.0				
Monitor	T	600 "Monitor: ALL"		4.4					
Alarm	Alarm display	602 "Alarm: ALL"			2.6		J3-□A		
	Alarm history	604 "Alarm Hist.: ALL"		1	3.3	1	1		
		610 "I/O Display: S-A"	2.7	-	-	-	-		
		611 "I/O Display: S-CP"	-	3.0	-	-			
	DI/DO display	612 "I/O Display: M-A IFU"	-	-	4.8	-			
		613 "I/O Display: M-A D01"	-	-	-	3.9			
		614 "I/O Display: J3-A"	-	-	-	-	2.8		
	Function device	620 "Function Dev.: S-CP"	-	3.3	-	-	-		
	display	621 "Function Dev.: M-A IFU"	-	-	5.1	-	-		
vo amplifier n Monitor Alarm Diagnostics function		622 "Function Dev.: M-A DRU"	-	-	-	5.1	-		
Diagnostics		630 "Amp inf.: S-A"	2.4	-	-	-	-		
Parameter setting Test Test Parameter setting Test	Amplifior	631 "Amp inf.: S-CP"	-	2.5	-	-	-		
	Amplifier information display	632 "Amp inf.: M-A IFU"	-	-	2.4	-	-		
		633 "Amp inf.: M-A DRU"	-	-	-	2.6	-		
		634 "Amp inf.: J3-A"	-	-	-	-	2.7		
	ABS data display	640 "ABS data: S-A/J3-A"	2.9	-	-	-	2.9		
		642 "ABS data: S-CP"	-	3.4	-	-	-		
		644 "ABS data: M-A DRU"	-	-	-	3.4	-		
	Unit composition	647 "Unit Comp.: M-A IFU"	-	-	3.8	-	-		
	list display	648 "Unit Comp.: M-A DRU"	-	-	-	3.8	-		
		650 "Parameters: S-*"	4	.4	-	-	-		
		651 "Parameters: M-A IFU"	-	-	4	.6	-		
		652 "Parameters: M-A DRU"	-	-	5	.0	-		
Parameter se	etting	653 "Parameter Basic setting: J3-A"	-	-	-	-	5.1		
		654 "Parameters Gain/Filter: J3-A"	-	-	-	-	5.2		
		655 "Parameters Ext. setting: J3-A"	-	-	-	-	5.2		
		656 "Parameters I/O setting: J3-A"	-	-	-	-	5.2		
		660 "JOG operation: S-*/J3-A"	3	.8	_	-	3.8		
	JOG operation	661 "JOG operation: M-A DRU"	-	-	-	3.5	-		
	Positioning	663 "Positioning: S-*"	3	.8	-	-	-		
		664 "Positioning: M-A DRU"	-	-	-	3.6	-		
	operation	665 "Positioning: J3-A"	-	-	-	-	4.3		
	Motor-less	666 "Motor-less op: S-*/J3-A"	2	.7	-	-	2.8		
Test	operation	667 "Motor-less op: M-A DRU"	-	-	-	2.5			
		669 "DO Forced Out: S-A"	4.1	_	-	-			
	DO forced output	670 "DO Forced Out: S-CP"	-	3.8	_	_			
		671 "DO Forced Out: M-A IFU"	_	-	8.2	-			
	2 2	672 "DO Forced Out: M-A D01"	-	-	3.8	-			
	-	673 "DO Forced Out: J3-A"		_	-	_			
Parameter se		673 DO Forced Out: 33-A"	-	_	_	_	4.0		

(b) When using GT15 \square \square -V

(- : Unavailable)

Function details			Memory space (KB)					
		Stored screen data	For MR-	For MR-	For MR-	For MR-	For MR-	
T UTICE	ion details	Glored Screen data	J2S-□A	J2S-□CP	J2M-P8A	J2M-□DU	J3-□A	
			monitoring	monitoring	monitoring	monitoring	monitoring	
	monitor data common	1			21.0			
Monitor	1	600 "Monitor: ALL"	4.4					
Alarm	Alarm display	602 "Alarms: ALL"			2.6		J3- A monitorin	
	Alarm history	604 "Alarms Hist.: ALL"		ı	3.3	1	1	
		610 "I/O Display: S-A"	2.7	-	-	-	-	
		. ,	-	3.0	-	-	-	
	DI/DO display	612 "I/O Display: M-A IFU"	-	-	4.8	-	-	
		613 "I/O Display: M-A D01"	-	-	3.9	-	-	
		614 "I/O Display: J3-A"	-	-	-	-	2.7	
	Forestion devices	620 "Function Dev.: S-CP"	-	3.3	-	-	-	
		621 "Function Dev.: M-A IFU"	-	-	5.3	-	-	
	a.op.ay	622 "Function Dev.: M-A DRU"	-	-	-	5.3	-	
Diagnostics function		630 "Amp inf.: S-A"	2.4	-	-	-	-	
		631 "Amp inf.: S-CP"	-	2.5	-	-	-	
		632 "Amp inf.: M-A IFU"	-	-	2.4	-	-	
	information display	633 "Amp inf.: M-A DRU"	-	-	-	2.6	-	
		634 "I/O Display: J3-A"	-	-	-	-	2.7	
	ABS data display	640 "ABS data: S-A/J3-A"	2.4	-	-	-	2.9	
		642 "ABS data: S-CP"	-	3.4	-	-	-	
		644 "ABS data: M-A DRU"	-	-	-	3.4	-	
	Unit composition	647 "Unit Comp.: M-A IFU"	-	-	3.8	-	-	
	list display	648 "Unit Comp.: M-A DRU"	-	-	-	3.8	-	
1		650 "Parameters: S-*"	4	.4	-	-	-	
		651 "Parameters: M-A IFU"	-	-	4	.6	_	
		652 "Parameters: M-A DRU"	-	-	-	5.0	-	
Parameter se	ettina	653 "Parameters Basic setting: J3-A"	_	_	_	-	5.2	
	3		_	_	_	_	5.2	
			_	_	_	_		
			_	_	_	_		
			3	8	_	_	JDU J3-□A monitoring m	
DI/DO display E1/O Display: S-A" 2.7 -	JOG operation	·		1	_	3.5		
	_	-	_					
	•		+	ı	_	3.6		
					_	-		
	Meter less				_	_	- - - -	
Test		·		ı	_	2.5		
	- Paraman,	· ·			<u>-</u>	-		
	DO forced output		+					
			+		- 0.0	-		
					8.2	-		
			-	-	3.9	-		
		673 "DO Forced Out: J3-A"	-	-	-	-	4.0	

(c) When using GT155 □-V

(- : Unavailable)

	Memo					mory space (KB)			
Function details		Stored screen data	For MR-	For MR-	For MR-	For MR-	For MR-		
i unct	ion details	Stored Screen data	J2S-⊟A	J2S-□CP	J2M-P8A	J2M-□DU	J3-□A		
			monitoring	monitoring	monitoring	monitoring	monitorin		
	monitor data common				42.0				
Monitor	T	600 "Monitor: ALL"							
Alarm	Alarm display	602 "Alarms: ALL"							
	Alarm history	604 "Alarms Hist.: ALL"				ı	J3-□A monitori		
		610 "I/O Display: S-A"	2.2		-	-	-		
		611 "I/O Display: S-CP"	-		-	-	-		
	DI/DO display	612 "I/O Display: M-A IFU"							
			-	-	-	3.1			
			-	-	-	-			
			-		-	-	-		
			-	-		-	-		
			-	-		-	-		
	Function device		-	-		-	-		
	display		-	-	2.7	-	-		
Diagnostics function		625 "Func. Dev. In1: M-A DRU"	-	-	-	3.1	-		
		626 "Func. Dev. In2: M-A DRU"	-	-	-	3.0	-		
		627 "Func. Dev. Out1: M-A DRU"	-	-	-	3.1	For MR- J3- A monitoring		
-		628 "Func. Dev. Out2: M-A DRU"	-	-	-	2.7			
function		630 "Amp inf.: S-A"	1.6	-	-	-			
		631 "Amp inf.: S-CP"	-	1.7	-	-	-		
	Amplifier information display	632 "Amp inf.: M-A IFU"	-	-	1.6	-	-		
		633 "Amp inf.: M-A DRU"	-	-	-	1.8	-		
		634 "Amp. inf.1: J3-A"	-	-	-	-	2.1		
		635 "Amp. inf. 2: J3-A"	J3-A"	-	-	2.1			
		640 "ABS data Cur.: S-A/J3-A"	1.9	-	-	-	1.9		
		641 "ABS data Orig: S-A/J3-A"	2.0	-	-	-	2.0		
	ARS data display	642 "ABS data Cur.: S-CP"	-	2.2	-	-	-		
	ADO data display	643 "ABS data Orig: S-CP"	-	2.2	-	-	-		
		644 "ABS data Cur.: M-A DRU"	-	-	-	2.2	-		
		645 "ABS data Orig: M-A DRU"	-	2.5 1.8 2.3 2.2 -	-				
Function device display Section Section	Unit composition	647 "Unit Comp.: M-A IFU"	-	-	2.8	-	-		
	2.8	-							
		650 "Parameters: S-*"	3	.5	-	-	J3- Property monitorial monitoria		
		651 "Parameters: M-A IFU"	-	-	3.7	-	-		
		652 "Parameters: M-A DRU"	-	-	-	4.0	-		
Parameter se	etting	653 "Parameters Basic setting: J3-A"	-	-	-	-	4.2		
		654 "Parameters Gain/Filter: J3-A"	-	-	-	-	4.2		
		655 "Parameters Ext. setting: J3-A"	-	-	-	-	4.2		
		656 "Parameters I/O setting: J3-A"	-	-	-	-	4.2		
	IOC anati	660 "Jog operation: S-*/J3-A"	2	.8	-	-	2.8		
Function device display Function device display Func. Dev. Out1: M-A IFU 623 "Func. Dev. Out2: M-A IFU 626 "Func. Dev. In1: M-A DF 627 "Func. Dev. In1: M-A DF 628 "Func. Dev. Out1: M-A DF 628 "Func. Dev. Out1: M-A DF 629 "Func. Dev. Out1: M-A DF 629 "Func. Dev. Out1: M-A DF 629 "Func. Dev. Out1: M-A DF 620 "Func. Dev. Out1: M-A DF 620 "Func. Dev. Out1: M-A DF 621 "Func. Dev. Out1: M-A DF 622 "Func. Dev. Out1: M-A DF 623 "Func. Dev. Out2: M-A DF 624 "Func. Dev. Out1: M-A DF 625 "Func. Dev. Out1: M-A DF 630 "Amp inf.: S-A" 631 "Amp inf.: S-A" 632 "Amp inf.: M-A DRU" 633 "Amp inf.: M-A DRU" 634 "Amp. inf.1: J3-A" 640 "ABS data Cur.: S-A/J3- 641 "ABS data Orig: S-A/J3- 641 "ABS data Orig: S-CP" 644 "ABS data Orig: S-CP" 644 "ABS data Orig: M-A DF 645 "ABS data Orig: M-A DRU" 648 "Unit Comp.: M-A DRU" 650 "Parameters: M-A IFU" 651 "Parameters: M-A IFU" 652 "Parameters: M-A DRU" 653 "Parameters Basic setting 656 "Parameters Ext. setting 656 "Parameters I/O setting: 656 "Parameters I/O setting: 660 "Jog operation: M-A DRU" 663 "Positioning: S-"" 664 "Positioning: S-""	661 "Jog operation: M-A DRU"	-	-	-	2.5	-			
		663 "Positioning: S-*"	2	.9	-	-			
	•	664 "Positioning: M-A DRU"	-	-	-	2.6	-		
	operation	665 "Positioning: J3-A"	-	-	-	-	3.3		
T	Motor-less	666 "Motor-less op: S-*/J3-A"	1	.9	-	-	1.9		
Test	operation	667 "Motor-less op: M-A DRU"	-	-	-	1.7	-		
		669 "DO Forced Out: S-A"	3.3	-	-	-	_		
		670 "DO Forced Out: S-CP"	-	3.1	-	-	-		
	DO forced output	671 "DO Forced Out: M-A IFU"	-		6.7	-	-		
		672 "DO Forced Out: M-A D01"	-	-	-	3.0			
		673 "DO Forced Out: J3-A"	_	_	_	-			

(1) Special data

Download the special data indicated in the table above to the GOT.

Refer to the following manual for the procedure for downloading the data.

GT Designer2 Version ☐ Basic Operation/Data Transfer Manual

(8. TRANSFERRING DATA)

(2) Memory space for special data

The available memory space shown in the table above is required in the user area to download the special data to the GOT.

Refer to the following manual for the procedure for checking the available memory space of the user area and information about the data using other user areas.

GT Designer2 Version ☐ Basic Operation/Data Transfer Manual

(8. TRANSFERRING DATA)

9.2.2 Access range

The access range is the same as the access range when the GOT is connected to a controlle	r.
Refer to the following manual for details of the access range.	

GT Designer2 Version ☐ Screen Design Manual (2.7 Controller that can be Monitored and the Accessible Range)

9.2.3 Precautions

(1) Before using the servo amplifier monitor

Read the manual of the connected servo amplifier carefully and make sure you understand the contents before performing servo amplifier monitoring.

(2) Test operation

Be sure to read the precautions listed below before performing a test operation.

9.4.7 Test operations

(3) Time displayed on the servo amplifier monitor

If the time data of the GOT is incorrect, the time on the servo amplifier monitor will not be displayed correctly.

Refer to the following manual for the GOT clock data.

GT Designer2 Version ☐ Screen Design Manual (2.5 Clock Function)

(4) Setting details

Use the same settings for the servo amplifier monitor on the GOT (Setup screen (\$\subseteq 9.4.2\$)) and the servo amplifier.

If the settings are different, proper communications may not be performed.

(5) Servo amplifier monitored


One servo amplifier can be selected to be monitored among 32 servo amplifiers.


If multiple servo amplifiers are connected, select one servo amplifier to monitor.

9.3 Display

1 Operation procedure until the start of the servo amplifier monitor

This section describes the flow until the servo amplifier monitor operation screen is displayed after the servo amplifier monitor (Option OS) is installed in the GOT.







(1) How to display the utility

For how to display the utility, refer to the following.

GT16 User's manual (Basic Utility) (1.3 Utility Display)
GT15 User's manual (9.3 Utility Display)

(2) Displaying communication setting window

After turning on the GOT, the communication setting window is displayed at the first startup of the servo amplifier monitor only.

For displaying the communication setting window at the second or later startup, touch the Ch: button on the servo amplifier monitor screen.


(9.4 Operations of Servo Amplifier Monitor Screens)

(3) If the project data has not been downloaded

The servo amplifier monitor can be started from the utility even if the project data has not been downloaded to the GOT.

2 Changing screens

The following describes how to change the screen.





To exit by touching End

At next startup of the servo amplifier monitor, the last exited screen is displayed. If using the same screen frequently, exiting with the End button is convenient. However, the last exited screen is not displayed if the servo amplifier monitor screen data was deleted due to an installation of the OS, turning the GOT power from off to on, or a reset.

9.4 Operations of Servo Amplifier Monitor Screens

This section describes the operations of the screens when using the servo amplifier monitor.


The display screen of the servo amplifier monitor varies slightly with the GOT used. This section mainly uses the screen of the GT1575-V for explanation.

9.4.1 Servo amplifier monitor

With the servo amplifier monitor, various monitor functions, parameter setting changes and test operations can be performed on the servo amplifier connected to the GOT.

To display a function, make a selection on the function selection menu screen.

(Function selection menu screen)



1) Setup	Selects the servo amplifier type to the IFU station number.	o monitor, the station number setting (station number selection), and
2) Monitor	Displays all monitor data of the se	ervo amplifier in real-time.
3) Alarm	Displays the alarm that is currentl history.	y occurring and the history. Also resets the alarm and clears the
4) Diagnostics	Performs the following various dia	agnostics on the connected servo amplifier.
(9.4.5)	 DI/DO display 	: Displays the ON/OFF status of the external I/O signals.
	 Function device display 	: Displays the ON/OFF status of the I/O function devices.
	 Amplifier information display 	: Displays the model name, ID and encoder resolution of the servo motor connected to the servo amplifier.
	- ABS data display	: Displays the absolute position data of the absolute position detection system.
	 Unit composition list display 	: Displays a list of servo amplifier unit composition.
5) Parameters	Displays the parameter data and	changes the parameter settings.
6) Test	Performs various test operations DO forced output).	(JOG operation, positioning operation, motor-less operation and

9.4.2 Setup

This is used to set the communication with the servo amplifier.




- (1) Before making the settings on the setup screen, also make the same settings on the servo amplifier side.
 - If the settings on this screen and the settings on the servo amplifier do not match, proper communications may not be performed.
- (2) The settings on the setup screen return to the initial state when the GOT is turned off or reset.

After turning on the power to the GOT, perform the settings on the setup screen again.

1 Setup screen

This section describes the display data of the setup screen and the key functions displayed on the screen.

(1) Displayed contents



* [Axis number] and [Capacity setting] cannot be set.

No.	Item	Description
1)	Model	Displays the model of the servo amplifier to be connected.
2)	Station	Displays the station number (00 to 31) of the servo amplifier to communicate with.
3)	IFU Station	Displays the serial communication station number of the IFU (interface unit).

(2) Key functions

The table below shows the functions of the keys that are used for the operations of the setup screen.

Key	Function
Mode 1	Sets the model of the servo amplifier to be connected.
Station	Sets the station number (00 to 31) of the servo amplifier to communicate with.
IFU Station	Sets the serial communication station number of the IFU (interface unit).
Fix	Sets the setup details and returns to the function selection menu screen.
End	Exits the servo amplifier monitor.
Ch:2	Displays the communication setting window.

^{*1:} This is valid only when the MR-J2M A series is connected.


9.4.3 Monitor functions

Displays all monitor data of the servo amplifier in real-time.

1 Monitor screen

The following describes the display data of the monitor screen and the key functions displayed on the screen.

(1) Displayed contents



No.	Item	Description
1)	Cumulative feedback pulses	Counts the feedback pulses from the servo motor encoder and displays the result. • When the set value exceeds "9999999", counting begins from "0". • During reverse rotation, the – sign is added.
2)	Servo motor speed	Displays the speed of the servo motor. The value is displayed with the 0.1r/min unit rounded off. During reverse rotation, the – sign is added.
3)	Droop pulses	Displays the droop pulses of the deviation counter. • During reverse rotation, the – sign is added.
4)	Cumulative command pulses	Counts the position command input pulses and displays the result. Since the value before multiplication of the electrical gear (CMX/CDV) is displayed, it may not match the cumulative feedback pulse display. During reverse rotation command, the – sign is added.
5)	Command pulse frequency	Displays the frequency of the position command input pulse. The value before multiplication of the electrical gear (CMX/CDV) is displayed. During reverse rotation command, the – sign is added.
6)	Analog speed command voltage (during speed control mode)*1	Displays the input voltage of the analog speed command (VC).
6)	Analog speed limit voltage (during torque control mode)*1	Displays the input voltage of the analog speed limit (VLA).
7)	Analog torque command voltage (during position/ speed control mode)*1	Displays the voltage of the analog torque limit (TLA).
	Analog torque limit voltage (during torque control mode)*1	Displays the voltage of the analog torque limit (TC).

(Continued to next page)

^{*1:} This is displayed only when the MR-J2S- $\!\square$ A is connected.

No.	Item	Description
8)	Regenerative load ratio	Displays the ratio of the regenerative power to the permissible regenerative power in %. • The permissible regenerative power differs depending on the presence/absence of the regenerative brake option. Set parameter No. 0 correctly according to the regenerative brake option. (Set to 80% or lower as a guide.)
9)	Effective load ratio	Displays the continuous effective load torque. • The effective value is displayed on the assumption that the rated torque is 100%.
10)	Peak load ratio	Displays the maximum torque generated. • The maximum value for the past 15 seconds is displayed on the assumption that the rated torque is 100%.
11)	Instantaneous torque	Displays the instantaneous torque. • The value of the generated torque is displayed in real time on the assumption that the rated torque is 100%.
12)	Within one-revolution position	Displays the within one-revolution position in the servo motor in pulse units of the encoder. • When the value exceeds the maximum pulse count, it returns to 0.
13)	ABS counter	Displays the distance from the home position (0) in the absolute position detection system as the multi- revolution counter value of the absolute position encoder.
14)	Load inertia moment ratio	Displays the estimated ratio of the servo motor shaft-equivalent load inertia moment to the servo motor's inertia moment.
15)	Bus voltage	Displays the voltage (between P and N) of the main circuit converter.

(2) Key functions

The table below shows the functions of the keys that are used for the operations on the monitor screen.


Key	Function
Clear	Clears the values of [Cumulative feedback pulses] and [Cumulative command pulses] to 0.
Menu	Returns to the function selection menu screen.
End	Exits the servo amplifier monitor.
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 8.4.11 Hard copy output
Cancel Print	The touch operation of this key is invalid.

9.4.4 Alarm function

The following alarms are displayed.

- Alarm display: Displays the alarm that is currently occurring. (This section 1)
- Alarm history: Displays the history of alarms that occurred. (This section 2)

The screen changes as follows after Alarm is selected on the function selection menu screen.



Alarm history screen




If the alarm display screen data has not been downloaded to the GOT, the message "Monitor data not found" is displayed and the subsequent screens are not displayed.

1 Alarm display screen

The following describes the display data of the alarm display screen and the key functions displayed on the screen.

(1) Displayed contents



No.	Item	Description
1)	Alarm Number	Displays the number of the alarm that occurred.
2)	Alarm Name	Displays the name of the alarm that occurred.
3)	Time of Alarm	Displays the date and time when the alarm occurred. • The alarm occurrence time is displayed on the basis of the clock data of the GOT. • If there is an error in the servo amplifier before it is connected to the GOT, an alarm is displayed when the servo amplifier is connected to the GOT. In this case, the time when the servo amplifier is connected to the GOT is displayed as the alarm occurrence time.

(2) Key functions


The table below shows the functions of the keys that are used for operations of the alarm display screen.

Key	Function
Reset	Resets the alarm. • The reset alarm is stored as the latest alarm.
AlarmHist	Changes to the alarm history screen (This section 2).
Menu	Returns to the function selection menu screen.
End	Exits the servo amplifier monitor.
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 9.4.8 Hard copy output
Cancel Print	The touch operation of this key is invalid.

2 Alarm history screen

The following describes the display data of the alarm history screen and the key functions displayed on the screen.

(1) Displayed contents



No.	Item	Description
1)	Seq No.	Displays the alarm history, starting from the latest alarm, in order. • Later alarms have smaller Seq Nos. (0 indicates the latest alarm) • Up to six alarms can be displayed in the alarm history.
2)	Alarm No.	Displays the number of the alarm that occurred.
3)	Alarm Name	Displays the name of the alarm that occurred.
4)	Time (hour)	Displays the energization time of the servo amplifier until alarm occurrence on the assumption that the time at factory shipment is "0".
5)	Detail (hex)	Displays the code for detailed alarm information.

(2) Key functions

The table below shows the functions of the keys that are used for operations of the alarm history screen.

Key	Function
Clear	Clears the alarm history stored in the servo amplifier.
AlarmDisp.	Changes to the Alarm Display screen (This section 1).
Menu	Returns to the function selection menu screen.
End	Exits the servo amplifier monitor.
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 9.4.8 Hard copy output
Cancel Print	The touch operation of this key is invalid.

9.4.5 Diagnostics function

This function performs the following various diagnostics on the connected servo amplifier.


- DI/DO display: Displays the ON/OFF status of the external I/O signals.
 - 1
- Function device display: Displays the ON/OFF status of the I/O function devices.
 - 2)
- Amplifier information display:
- Displays the model name, ID and encoder resolution of the servo motor connected to the servo amplifier.
- ABS data display: Displays the absolute position data of the absolute position detection system.
- Unit composition list display:
- Displays a list of servo amplifier unit compositions.

(1) Changing screens

The screen changes as follows after Diagnostics is selected on the function selection menu screen.

Depending on the model of the connected servo amplifier, some screens may not be displayed. Refer to the following for the screens that cannot be displayed.

9.2.1 List of servo amplifier types that can be monitored and functions



LADDER EDITOR



If the DI/DO display screen data or function device display screen data (only when monitoring the MR-J2M- \square DU) has not been downloaded to the GOT, "Monitor data not found" is displayed and the subsequent screens are not displayed.

1 DI/DO display screen

The following describes the display data of the DI/DO display screen and the key functions displayed on the screen.

(1) Displayed contents



No.	Item	Description
1)	Input/Output Signal	Displays whether the DI/DO signal is ON (lit) or OFF (not lit).

(2) Key functions

The table below shows the functions of the keys that are used for the operations of the DI/DO display screen.


Key	Function
D01 *1	Displays the DI/DO signal of the extension IO unit.
Func.Dev.	Changes to the function device screen (This section 2).
Amp.Inf	Changes to the amplifier information screen (TThis section 3).
UnitCompo.	Changes to the unit composition list screen (FT This section 5).
ABSdata	Changes to the ABS data screen (This section 4).
Menu	Returns to the function selection menu screen.
End	Exits the servo amplifier monitor.
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 9.4.8 Hard copy output
Cancel Print	The touch operation of this key is invalid.


^{*1:} This is displayed only when the MR-J2M A series is connected.

2 Function device display screen

The following describes the display data of the function device display screen and the key functions displayed on the screen.

(1) Displayed contents





[When MR-J2S-□CP is monitored]

No.	Item	Description
1)	Input/Output Function	Displays the ON (■) or OFF (□) status for each I/O signal.

(2) Key functions


The table below shows the functions of the keys that are used for the operations of the function device display screen.

Key	Function
D1/D0	Changes to the DI/DO display screen (FF This section 1).
ABSdata	Changes to the ABS data screen (This section 4).
Amp.Inf	Changes to the amplifier information screen (3).
UnitCompo.	Changes to the unit composition list screen (FT This section 5).
Menu	Returns to the function selection menu screen.
End	Exits the servo amplifier monitor.
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 9.4.8 Hard copy output
Cancel Print	The touch operation of this key is invalid.

3 Amplifier information display screen

The following describes the display data of the amplifier information display screen and the key functions displayed on the screen.

(1) Displayed contents



No.	Item	Description
	Servo amplifier model.*1	Displays the model name of the servo amplifier.
	Amplifier Firmware Version	Displays the software number of the servo amplifier connected to the GOT.
	Accumulated power-on time*1	Displays the cumulative time of the control power-on after the product was shipped from the factory.
4)	Num. of inrush cur. sw. time*1	Displays the number of times the rush relay has been turned on/off after the product was shipped from the factory.
1)	Optional card model ^{*1}	Displays the model name of the option card installed in the servo amplifier. If no option card is installed, then "No connection" is displayed.
	Motor model ^{*2}	Displays the model name of the servo motor connected to the servo amplifier.
	Motor ID*2	Displays the ID of the servo motor connected to the servo amplifier.
	Encoder resolution*2	Displays the encoder resolution of the servo motor connected to the servo amplifier.

^{*1} This is displayed only for the MR-J3 series.

(2) Key functions

The table below shows the functions of the keys that are used for the operations of the amplifier information display screen.


Key	Function
D1/D0	Changes to the DI/DO display screen (FFT This section 1).
ABSdata	Changes to the function device screen (This section 2).
Amp.Inf	Changes to the ABS data screen (This section 4).
UnitCompo.	Changes to the unit composition list screen (This section 5).
Menu	Returns to the function selection menu screen.
End	Exits the servo amplifier monitor.
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 9.4.8 Hard copy output
Cancel Print	The touch operation of this key is invalid.

^{*2} This is not displayed when monitoring the MR-J2M-P8A.

4 ABS data display screen

The following describes the display data of the ABS data display screen and the key functions displayed on the screen.

(1) Displayed contents



No.	Item	Description
1)	Absolute position data	Displays the absolute position data in the absolute position detection system with the following items. • Motor edge pulse value • Command pulse value
2)	Encoder data	Displays the encoder data with the following items. Current position Absolute encoder data CYC (Motor edge pulse value) Number of motor rotations ABS Position at power loss Absolute encoder data CYC0 (Motor edge pulse value) CYC0 (Command pulse value) CYC0 (Command pulse value) Number of motor rotations ABS0

(2) Key functions


The table below shows the functions of the keys that are used for the operations of the ABS data display screen.

Key	Function
D1/D0	Changes to the DI/DO display screen (FTThis section 1).
Func.Dev.	Changes to the function device screen (This section 2).
UnitCompo.	Changes to the unit composition list screen (This section 5).
Amp.Inf	Changes to the amplifier information screen (This section 3).
Menu	Returns to the function selection menu screen.
End	Exits the servo amplifier monitor.
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 9.4.8 Hard copy output
Cancel Print	The touch operation of this key is invalid.

5 Unit composition list display screen

The following describes the display data of the unit composition list screen and the key functions displayed on the screen.

(1) Displayed contents



No.	Item	Description
1)	Type name	Displays the model name of the drive unit (DRU), interface unit (IFU) and option unit installed in each slot.
2)	AxNo.	Displays the axis number of the drive unit (DRU) and interface unit (IFU).
3)	State	Displays status of the drive unit (DRU) and interface unit (IFU) and the alarm/warning number.
4)	Motor model	Displays the model name of the motor connected to the drive unit (DRU).
5)	S/W version	Displays the software number of the drive unit (DRU) and interface unit (IFU).

(2) Key functions

The table below shows the functions of the keys that are used for the operations of the unit composition list screen.


Key	Function
D1/D0	Changes to the DI/DO display screen (This section 1).
ABSdata	Changes to the ABS data screen (This section 4).
Amp.Inf	Changes to the amplifier information screen (FT This section 3).
Func.Dev.	Changes to the function device screen (This section 2).
Menu	Returns to the function selection menu screen.
End	Exits the servo amplifier monitor.
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 9.4.8 Hard copy output
Cancel Print	The touch operation of this key is invalid.

9.4.6 Parameter setting

You can use the parameter setting function to set the servo parameters (basic parameters/expansion parameter 1, 2) of the connected servo amplifier.


The password input key window appears for accessing the parameter setting screen of the servo amplifier monitor when the password is set with GT Designer2.

The screen changes as follows after Parameters is selected on the function selection menu screen.



1 Password input operation procedure

The following describes the procedure for inputting the password for changing the servo parameters.



- (1) Functions
 - If the input password matches, the parameter setting screen is displayed.
 - If the input password does not match, an error message is displayed. Touching x returns to the function selection menu screen.
 - Numerical numbers and letters A to F can be used for a password.
- (2) Operations
 - (a) Inputting the password

Touch 0 to 9 and A to F to input the password.

After inputting the password, touch **Enter** to set the password.

To edit the input characters, touch Del to delete the characters, and then input the new characters.

(b) Canceling password input

Touch X to return to the monitor screen.


2 Parameter setting screen

The following describes the display data of the parameter setting screen and the key functions displayed on the screen.



Parameters with an asterisk (*) preceding the name become valid after the parameters are set and the power of the servo amplifier is turned off and then on again.

(1) Display screen



No.	Item	Description
1)	Pr.	Displays the parameter number.
2)	Name	Displays the parameter name.
3)	Value	Displays the present set value of the parameter.
4)	Unit	Displays the setting unit for each parameter.

(2) Key functions

The table below shows the functions of the keys that are used with the operations on the parameter setting screen.

Key	Function
	Selects the servo parameter setting item.
*	Displays the parameter items with scrolling a page up/down.
Change	Changes the servo parameter settings read to the GOT internal memory.
Write	Writes the servo parameter settings of the selected items to the servo amplifier.
Verify	Matches all parameter values presently displayed on the GOT with the servo amplifier parameter values.
Write All	Writes all parameter values presently displayed on the GOT to the parameters of the servo amplifier.
Read All	Reads all parameter values from the servo amplifier to the GOT and displays those values.
default	Returns all parameter values to their initial values.
Param.IFU /	Switches between the parameter display for the drive unit (DRU) and interface unit (IFU) each time this is touched.
	Selects the slot number of the drive unit (DRU).
Gain/Filter *2	Changes the gain filter parameter.
Ext.setting *2	Changes the extension setting parameter.
I/O setting *2	Changes the I/O setting parameter.
Menu	Returns to the function selection menu screen.
End	Exits the servo amplifier monitor.
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 9.4.8 Hard copy output
Cancel Print	The touch operation of this key is invalid.

^{*1:} This is displayed only when the MR-J2M A series is connected.

^{*2:} This is displayed only when the MR-J3 series is connected.




When default is executed for the MR-J3 series parameters

The operation when default is executed differs depending on the displayed parameter screen, as shown in (1) and (2) below.

- (1) When the basic setting, gain/filter or extension setting parameter screen is displayed:
 - The 000BH processing (reference/writing is possible only for basic setting, gain/filter and extension setting parameter) is performed.
- (2) When the I/O setting parameter screen is displayed: The 000C_H processing (reference/writing is possible for all parameters) is performed.


3 Parameter setting operation

The following describes the procedure of changing the setting of the "Auto tuning" item as an example of the parameter setting operation.




1 Touch the Read All key.

The parameter values within the servo amplifier are displayed on the screen.




2 The parameter read confirmation window is displayed.

Touch the OK key to read the parameter values within the servo amplifier to the GOT.




The read parameter values within the servo amplifier are displayed on the screen.

Parameters that cannot be written or read are not displayed on the parameter setting screen.



APPENDICES



- As the parameter setting window appears, enter the parameter setting with alphanumeric keys, and touch Enter to confirm the setting.

 To cancel the parameter setting operation, touch X to close the parameter setting window.
- The parameter setting is changed on the parameter setting screen. Select the changed parameter item, and touch the Write key. If there are multiple parameter items with changed settings, touch the Write All key to write all parameter items with changed settings.
- A confirmation window appears.

 Touch the OK key to write the parameter setting(s) to the servo amplifier.

 To cancel writing of the parameter setting(s), touch Cancel key.

 This completes the writing operation of the



(1) The changes to the parameter setting are written to the E2PROM of the servo amplifier.

parameter setting.

- Consequently, the written parameter setting is retained even if the power of the amplifier is off.
- (2) If the following parameter settings are changed on the servo amplifier, be sure to also change the settings on the GOT setup screen (\$\subseteq 9.4.2\$) in the same way.

If the settings on the setup screen and the servo amplifier do not match, normal communications with the servo amplifier may not be performed.

- Station number setting
- IFU station number setting

9.4.7 Test operations

This function performs the following test operations on the connected servo amplifier.

• JOG operation : The servo motor rotates while the Forward or Reverse key is touched.

(F This section 3)

• Positioning operation: This operation starts when the Forward or Reverse key is touched, and the servo

motor rotates by the preset distance. (Fig. This section 4)

• Motor-less operation : Simulates the motion of the servo motor within the servo amplifier even when the

servo motor is not connected. (This section 5)


• DO forced output : Forcibly turns the output signals ON/OFF regardless of the output conditions of


the servo amplifier output signals. (FF This section 6)

(1) Changing screens

The screen changes as follows after Test is selected on the function selection menu screen. Depending on the model of the connected servo amplifier, some screens may not be displayed. Refer to the following for the screens that cannot be displayed.

9.2.1 4 List of servo amplifier types that can be monitored and functions





^{*2} Not displayed for MR-J2M-□DU monitor



If the JOG operation screen data has not been downloaded to the GOT, "Monitor data not found" is displayed and the subsequent screens are not displayed.

1 Precautions for test operations

The following describes the precautions when performing a test operation of the servo amplifier monitor.



- Do not operate the servo amplifier switches with wet hands. Doing so can cause an electric shock.
- Do not perform operations with the front cover of the servo amplifier removed.
 Doing so can cause an electric shock since the high-voltage terminals and live parts are exposed.
- Do not open the front cover of the servo amplifier when the power is on or during operation. Doing so can cause an electric shock.

CAUTION

- Be sure to read the precautions for test operation in the manuals of the servo amplifier before performing a test operation.
- Check parameters of the servo amplifier before starting operation.
 Unexpected operations may occur depending on the machine.
- The heat sink, regenerative brake resistor, servo motor and other parts of the servo amplifier may be hot while the power is on or for a period after the power is turned off; therefore, do not touch or bring parts (cables etc.) close to them. Doing so can cause fire or damage to the parts.

(1) Servo on

For test operation of JOG operation/positioning operation, the SON digital input signal of the servo amplifier is turned on automatically in the servo amplifier to start operation, regardless of the ON/ OFF status of the SON signal of the digital I/O signal of the servo amplifier.

In addition, the servo amplifier does not accept any external command pulses and input signals (excluding emergency stop) until the test operation screen is exited.

The SON automatically turns on when touching the Forward or Reverse key on the JOG operation screen or positioning operation screen of the servo amplifier monitor.

(2) Stop



To perform an emergency stop, turn off the emergency stop signal of the servo amplifier or turn off the input power.

- (a) Use the following procedure to stop test operation from the servo amplifier monitor.
 - JOG operation: Release the Forward or Reverse key.
 - Positioning operation: Touch the Pause key.
- (b) The servo motor stops if any of the following states occurs during test operation.
 - The communication cable is disconnected.
 - The screen is switched to another servo amplifier monitor screen or the servo amplifier monitor is exited.

However, during motor-less operation, the test mode is not canceled until the servo amplifier is powered off.

2 Preparations for test operations


When performing test operations, it is necessary to make the test operation settings on the connected servo amplifier.

Refer to the manual of the connected servo amplifier for details of making settings on the servo amplifier to perform test operations.

3 JOG operation screen

This section describes the display data of the JOG operation screen and the key functions displayed on the screen.

(1) Displayed contents



No.	Item	Description
1)	Motor speed	Displays the set speed of the servo motor.
2)	Acc/dec time	Displays the set acceleration/deceleration time constant.
3)	Momentary Switch Operation	Displays how to operate the JOG operation.

(2) Operation

- (a) When selecting Momentary Switch Operation: Selecting Momentary
 - · Start operation

Touch the Forward or Reverse key.

· Stop operation

Release the Forward or Reverse key.

- (b) When selecting Momentary Switch Operation: Not Selecting Momentary
 - · Start operation

Touch the Forward or Reverse key.

· Stop operation

Touch the Pause key.

(3) Key functions


The table below shows the functions of the keys that are used for the operations of the JOG operation screen.

Key	Function
Forward	Runs the servo motor in the forward rotation (CCW) direction.
Reverse	Runs the servo motor in the reverse rotation (CW) direction.
Motor speed	Changes the speed of the servo motor.
Acc/dec time	Changes the acceleration/deceleration time constant.
Momentary Switch Operation: Selecting Momentary Momentary Switch Operation: Not Selecting Momentary	Touching this changes the operation mode (momentary operation/no momentary operation). Momentary Switch Operation: Selecting Momentary The servo motor rotates while the Forward or Reverse key is touched. (Releasing your finger from these keys stops the operation.) Momentary Switch Operation: Not Selecting Momentary The servo motor rotates while the Forward or Reverse key is touched, stops when the Pause key is touched.
Positioning	Changes to the positioning operation screen (This section 4).
Without Motor	Changes to the motor-less operation screen (FTThis section 5).
DO ForcedOutput	Changes to the DO forced output screen (This section 6).
Menu	Returns to the function selection menu screen.
End	Exits the servo amplifier monitor.
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 9.4.8 Hard copy output
Cancel Print	The touch operation of this key is invalid.

4 Positioning operation screen

The following describes the display data of the positioning operation screen and the key functions displayed on the screen.

(1) Displayed contents



No.	Item	Description			
1)	Motor speed	Displays the set speed of the servo motor.			
2)	Acc/dec time	Displays the set acceleration/deceleration time constant.			
3)	Move distance	Displays the set distance.			

(2) Operation

- (a) For MR-J2-Super series and MR-J2M series
 - · Start operation

Touch the Forward or Reverse key.

To resume operation that has been paused, touch the Forward key to resume forward rotation or the Reverse key to resume reverse rotation.

Stop operation

When the set distance has been reached, operation stops.

Touching the Pause key pauses the operation.

If touch the Pause key again after the operation is paused, the remaining distance is erased.

(b) For MR-J3 series

· Start operation

Touch the Forward or Reverse key.

To resume the operation that has been paused, touch the Restart key to resume the rotation.

Stop operation

When the set distance has been reached, operation stops.

Touching the Pause key pauses the operation. If touch the Clear key again after the operation is paused, the remaining distance is erased.

(3) Key functions

The table below shows the functions of the keys that are used for the operations of the positioning operation screen.

Key	Function					
Forward	Runs the servo motor in the forward rotation (CCW) direction.					
Reverse	Runs the servo motor in the reverse rotation (CW) direction.					
Pause *1	Stops the rotation of the servo motor temporarily.					
Restart *2	Resumes the rotation of the paused servo motor.					
Clear *2	Deletes the remaining distance of the paused servo motor.					
Motor speed	Changes the rotation speed of the servo motor.					
Acc/dec time	Changes the acceleration/deceleration time constant.					
Move distance	Changes the distance.					
JOG	Changes to the JOG operation screen (This section 3).					
Without Motor	Changes to the motor-less operation screen (This section 5).					
DO ForcedOutput	Changes to the DO forced output screen (TThis section 6).					
Menu	Returns to the function selection menu screen.					
End	Exits the servo amplifier monitor.					
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 9.4.8 Hard copy output					
Cancel Print	The touch operation of this key is invalid.					


 $^{^{\}star}1$: This is displayed only when the MR-J2-Super series or MR-J2M series is connected.

 $^{^{\}star}2$: This is displayed only when the MR-J3 series is connected.

5 Motor-less operation screen

The following describes the display data of the motor-less operation screen and the key functions displayed on the screen.

(1) Displayed contents



(2) Operation

- · Start operation
 - Touch the Start key.
- · Stop operation

To cancel the motor-less operation, turn the power of the servo amplifier off.

(3) Key functions


The table below shows the functions of the keys that are used for the operations of the motor-less operation screen.

Key	Function
Start	Starts motor-less operation.
JOG	Changes to the JOG operation screen (This section 3).
Positioning	Changes to the positioning operation screen (This section 4).
DO ForcedOutput	Changes to the DO forced output screen (This section 5).
Menu	Returns to the function selection menu screen.
End	Exits the servo amplifier monitor.
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 9.4.8 Hard copy output
Cancel Print	The touch operation of this key is invalid.

6 DO forced output screen

The following describes the display data of the DO forced output screen and the key functions displayed on the screen.

(1) Displayed contents



No.	No. Item Description				
1)	ON/OFF status of output	Displays the ON/OFF status of the servo amplifier output signals.			
1)	signals	After this screen has been switched to another screen, all external I/O signals are turned off.			

(2) Operation

When the name of an output signal is touched, the ON/OFF status of that signal is inverted and written to the servo amplifier.

(3) Key functions

The table below shows the functions of the keys used for the operations of the DO forced output screen.

Key	Function
CN1A-19 (Output signal name)	Touching the signal name of an output signal sets or resets the status for that signal. • If the present output signal is ON, then the signal is turned off (RESET). • If it is OFF, then it is turned on (SET).
D01 *1	Displays the external output signals of the extension I/O unit.
U0G	Changes to the JOG operation screen (This section 3).
Positioning	Changes to the positioning operation screen (This section 4).
Without Motor	Changes to the motor-less operation screen (This section 5).
Menu	Returns to the function selection menu screen.
End	Exits the servo amplifier monitor.
Print Screen	Stores the displayed screen to the memory card in BMP/JPEG file format or prints it with a printer. For further information about hard copies, refer to the following: 9.4.8 Hard copy output
Cancel Print	The touch operation of this key is invalid.


 $^{^{\}star}$ 1: This is displayed only when the MR-J2M-P8A is connected.

9.4.8 Hard copy output

This section describes how to store a screen to the memory card in BMP/JPEG file format or print it with a printer when executing the amplifier monitor.

Hard copy methods differ depending on the GOT to be used.

(1) GOT with VGA or higher resolution Hard copy output operations are performed by touching the "Print Screen" or "Cancel Print" key displayed on the screen.




(2) GOT with QVGA resolution

Hard copy output operations are performed by turning ON/OFF the start or abort trigger device that has been set in the GT Designer2.



- Install the extended function OS (Printer) to the GOT when printing a servo amplifier monitor screen.
- The output target (CF card/printer) of hard copy can be set in [Hard Copy] of GT Designer2.

For details of the hard copy setting, refer to the following.



GT Designer2 Version□ Screen Design Manual (Section 13.2 Hard Copy)

9.5 Error Messages and Corrective Action

This section describes the error messages that may be displayed during servo amplifier monitor operation and their corrective action.

Error message	Error definition	Corrective action		
Monitor data not found	The monitor data have not installed or have been deleted.	Download the monitor data of the servo amplifier monitor.		
It is not possible to set.	An item that cannot be set was selected.	Select an item that can be set.		
No AMP Communications	Communication can not be established with the servo amplifier set as the monitor destination.	 Check the connection state between the servo amplifier and the GOT (connector disconnection, cable wire break). Check if an error has occurred in the servo amplifier. Set the same values to the setup screen on the servo amplifier monitor and the parameter setting on the servo amplifier. 		
This test mode cannot be selected. Operation without Motor rotation.	Another test operation function has started.	Exit the other test operation function.		
SON Make sure that operation is at a stop.	The servo amplifier SON signal is ON.	Turn off the servo amplifier SON signal.		
Incorrect setting range	A value outside the setting range was set when setting the servo parameter of the servo amplifier.	Set the servo parameter of the servo amplifier within the setting range.		
Servo alarm has occurred. Alarm:**	An alarm occurred on the connected servo amplifier.	Reset the alarm on the servo amplifier.		
Unit not found	The drive unit is not installed in the selected slot.	Select the slot where the drive unit is installed.		
Unmatched password	The password that was input as the password for changing the servo amplifier parameter is incorrect.	Input the correct password.		
Can't write to servo amp. Normally.	Failed to write the parameter.	Check the write data. Check the setup information.		
Please confirm forward or reversal stroke end (LSP or LSN)	The servo amplifier LSP/LSN signal is OFF.	Turn on the servo amplifier LSP/LSN signal.		
Communication channel setup error	The channel No. setting or communication driver setting is incorrect.	Check the communication settings.		
It is not possible to select.	 MR-J2M-P8A or MR-J3-A was selected with the station No. selection setting set to [No]. A channel with no station number was selected for the MR-J2M-P8A. 	Set the station No. selection setting to [Yes]. Select a channel with a station number.		

10. CNC MONITOR FUNCTIONS




10.1 Features

Functions, such as Position Display Monitor, Alarm Diagnosis Monitor, Tool Offset/Param, Program Monitor and APLC Release Screen, equivalent to the MELDAS dedicated display are available for the MELDAS connected to the GOT.


Position Display Monitor



Tool Offset Monitor



APLC function



Alarm Diagnosis Monitor



Program Monitor



10.2 Specifications

10.2.1 System configuration

This section describes the target CNC of the CNC monitor and the connection type between the GOT and CNC.

For connection type settings and precautions regarding the communication unit/cable and connection type, refer to the following manual.

GOT1000 Series Connection Manual

1 Target CNC of the CNC monitor

	CNC	
C70, C6/C64		

2 Connection type

(○: Available, X: Unavailable)

Function		Connection type between GOT and CNC							
		Bus	Direct connection	Computer link connection	Ethernet connection	MELSEC NET/10 connection	CC-Link connection		GOT
Name	Details	connection					ID ^{*1}	G4 ^{*2}	multidrop connection
CNC monitor	Monitors the CNC (C70, C6/C64) and changes the parameters	O*3	×	×	0	O ^{*4}	×	×	×

- *1 Indicates CC-Link connection (Intelligent device station).
- *2 Indicates CC-Link connection (via G4).
- *3 Applicable to the CNC C70 only
- *4 Applicable to the CNC C6/C64 only

3 Required option OS and option function board

The option function OS and option function board shown below are required.

	OS memory space (user area)			Option function board		
Option OS	GT16					
Spilon CC	Built-in flash memory (ROM)	User memory (RAM)	GT15	GT16	GT15	
CNC monitor	390KB	770KB	588KB	Not required	GT15-FNB, GT15-QFNB16M, GT15-QFNB48M,	GT15-QFNB, GT15-QFNB32M, GT15-MESB48M

(1) Option OS

Install the option OS in the above table to the GOT.

Refer to the following manual for the procedure for installing the option OS.

GT Designer2 Version
Basic Operation/Data Transfer Manual (8. TRANSFERRING DATA)

(2) OS memory space

The available memory space shown in the table above is required in the user area to install the option OS to the GOT.

Refer to the following manual for the procedure for checking the available memory space of the user area and information about the data using other user areas.

GT Designer2 Version ☐ Basic Operation/Data Transfer Manual (8. TRANSFERRING DATA)

(3) Option function board

(a) For GT16

No option function board is required.

(b) For GT15

Mount one of the option function boards in the above table on the GOT.

For the GOTs with a built-in option function board, refer to the following.

1.1.2 Hardware and OS' required for each function

For how to mount an option function board on the GOT, refer to the following manual.

GT15 User's Manual (8.10 Option Function Board)

4 CNC functions that can be monitored

The CNC monitor function allows the following functions to be monitored. For details of each function, refer to the manual for each CNC.

Item	Description	CNC C70	MELDAS C6/C64
	Position	0	0
	Coordinate	0	0
	Command	0	0
Position Display Monitor	Program search	0	0
Wichitol	PLC switch	×	0
	Common variable	0	0
	Local variable	0	0
	Alarm message	0	0
	Servo monitor	0	0
	Spindle monitor	0	0
	PLC interface diagnosis	0	0
	Absolute position monitor	0	0
	Adjustment	×	0
	NC data sampling	0	×
	Operation history	0	0
Alarm Diagnosis Monitor	Configuration	0	0
WOTHO	Data input	×	0
	Data output	×	0
	Program erase	0	0
	Program file	0	0
	Program copy	0	0
	Flash ATA card I/F	×	0
	Auxiliary axis parameter	×	0
	Auxiliary axis monitor	×	0
	Wear data (L system)	0	0
	Tool length data (L system)	0	0
	Tool nose data (L system)	0	0
	Tool life management (L system)	0	0
	Tool offset (L/M system)	0	0
Tool Offset/Param	Tool registration (L system)	0	0
	Workpiece coordinate	0	0
	Machining parameter	0	0
	I/O parameter	×	0
	Other parameters	0	0
Program Monitor	MDI editing	0	0
APLC Release Screen	APLC Release Screen	0	0

10.2.2 Access range

(1) Bus connection

One GOT can monitor up to two CNCs by switching the CNCs. Up to five GOTs can simultaneously monitor one CNC.

(2) Ethernet connection

One GOT can monitor up to 64 CNCs by switching the CNCs. Up to eight GOTs can simultaneously monitor one CNC.

(3) MELSECNET/10 connection

GOT monitors the control station only.

10.2.3 Precautions

(1) Before using the CNC monitor

Read the manual of the connected CNC carefully and make sure you understand the contents before using the CNC monitor function.

(2) Inapplicable GOT

The CNC monitor cannot be used with the GT1675M-V, GT1665M-V, GT1575-V, GT1575-VN, GT1572-VN, GT156□, and GT155□.

(3) Usable CNC

The CNC monitor is applicable to the CNC C70 and MELDAS C6/C64.

(a) CNC C70

Use the CNC C70 with the system software version of BND-1006W000-A0 or later.


(b) MELDAS C6/64

Use the MELDAS C6/C64 with the system software version of BND-377W010-D0 or later.

10.3 Display

1 Display operations

This section describes the flow until the operation screen of the CNC monitor is displayed after the CNC monitor (Option OS) is installed in the GOT.





(1) How to display the utility

For how to display the utility, refer to the following.

GT16 User's manual (Basic Utility) (1.3 Utility Display)
GT15 User's manual (9.3 Utility Display)

(2) Communication setting window display

The communication setting window is displayed only at initial startup of the CNC monitor after turning on the GOT power.

To display the communication setting window at startup from the second time or after, touch the Ch: button on the CNC monitor screen.


(10.4 Operation Procedures)

(3) If the project data has not been downloaded

The CNC monitor can be started from the utility even if the project data has not been downloaded to the GOT.

2 Changing screens


This section describes how to change the screen.



When exiting the CNC monitor function by touching RET, the last exited screen will be displayed when the CNC monitor function is started next time.

10.4 Operation Procedures

This section describes the display data of the CNC monitor screen and the key functions displayed on the screen.



	Item	Display data
Fund	ction switching area	Selects the function to be displayed and CNC monitor termination.
	MONITOR	Switches the monitor area to position display monitor.
	DIAGN IN/OUT	Switches the monitor area to alarm diagnosis monitor.
	TOOL PARAM	Switches the monitor area to tool compensation parameter.
	EDIT MDI	Switches the monitor area to program monitor.
	FO	Switches the monitor area to the APLC screen. If the monitored CNC unit does not include the APLC release function, the screen turns blank (nothing is displayed). (In this case, use a function switching key to switch the monitor to another function.)
	Ch:1	Displays the communication setting window.
For bus connection The button does not function. (Specify the monitoring target in the communication setting For Ethernet connection Switches the monitor among the CNC units when connected to multiple CNC units. The MELDAS C6/C64 units are switched in the order set in the Ethernet setting of GT De For MELSECNET/10 connection		The button does not function. (Specify the monitoring target in the communication setting window.) For Ethernet connection Switches the monitor among the CNC units when connected to multiple CNC units. The MELDAS C6/C64 units are switched in the order set in the Ethernet setting of GT Designer2.
	RET	Terminates the CNC monitor function and returns to a monitor screen or the utility of the GOT.
Mon	itor area	Functions, such as Position Display Monitor, Alarm Diagnosis Monitor, Tool Offset/Param and Program Monitor, equivalent to the MELDAS dedicated display are available. The graphic and ladder editor functions are not available.
	Menu1 to Menu5	Switches to the monitor that corresponds to the items in the menu area. In the case of the above screen, the menu items are as follows. Menu1: Relative value Menu2: PLC switch Menu3: Common editing Menu4: Local variable Menu5: Menu switching When the MELDAS dedicated display is valid, the "Other display operating" message and "Key operation right" menu are displayed. Select the "Key operation right" menu when operating keys on the GOT.

(Continued to next page)

Item		Display data
•		Switches to the previous page when there are multiple pages displayed on the screen.
		Switches to the next page when there are multiple pages displayed on the screen.
Ke	yboard	Sets data to the monitor area.
	Alabanian sia/a mabalilan	Enters alphabets (upper case only), numerals, spaces or symbols.
	Alphanumeric/symbol key	The grayed symbol can be entered after the Shift key is touched.
	↑ ↓ ← →	Moves the cursor up, down, left or right. (Repeat function is available)
	₩	Moves the cursor to the previous or subsequent block. (Repeat function is available)
	DEL	Deletes one character at the cursor position.
	INS	Switches the Insert mode.
	CAN	Deletes one block while editing machining program.
	C-B	After touching the Shift key, touch the CAN C-B key to delete all blocks being displayed on the screen.
	E08	Enters EOB(;) into the machining program.
	Input	Determines the entry.
	SHIFT	Switches the key function.

10.5 Error Messages and Corrective Action

This section describes the error messages that may be displayed during CNC monitor operation and their corrective action.

If two or more of the following errors have occurred, the error with the higher priority is displayed.

Priority	Error message	Error definition	Corrective action	
Higher	Support communication driver is not installed. (CNC MONITOR)	The compatible communication driver is not installed in the GOT.	Install the compatible communication driver in the GOT. Bus connection: Bus(Q) Ethernet connection: QJ71E71/AJ71(Q)E71, Q17nNC MELSECNET/10 connection: MELSECNET/10	
Lower	The IP address of CNC to monitor is not set up. (CNC MONITOR)	The IP address of the CNC has not been set.	After setting the IP address of the CNC to be monitored in the Ethernet setting of GT Designer2, download the project data to the GOT.	
	Communication channel setup error	There is no channel for communication.	Check that the channel No. is correctly set in the communication settings.	

11. BACKUP/RESTORE



11.1 Features

Setting data, including a sequence program, parameters, and setting values, for a controller connected to the GOT can be saved (backed up) in a CF card or USB memory in the GOT.

The saved data can be restored to the controller if required.

The following shows features of the backup/restore function.



GOT backup

The backup/restore function is applicable to controllers connected to the GOT. For backing up the GOT setting data, use the GOT data package acquisition function.


For the GOT data package acquisition function, refer to the following manual.

GT16 User's Manual (Basic Utility) (Section 4.3.3 GOT data package acquisition)

GT15 User's Manual (Chapter 13 FILE DISPLAY AND COPY)

Backing up or restoring system without personal computer for reducing downtime Setting data for a controller connected to the GOT can be backed up, and the data can be restored to the controller.

With backing up setting data for a controller, the data can be restored to the controller with the GOT connected to the controller even though the controller has to be replaced because of problems, including failures. As a result, the system can be easily restored.




2 Enabling creating the same system without personal computer
With restoring the backed up setting data to controllers in other systems, the same system can be created without a personal computer.

Tuesday

17:30

3 Improving security

When the backup/restore function is used, browsing and changing setting data is limited with a password and the security is improved.




Automatically backing up data with trigger

By setting the trigger device or the days and time, the GOT can automatically back up setting data for controllers.

By controlling the backup with the set trigger device, the GOT can automatically back up setting data for controllers after the data are changed.

By setting the days and time, the GOT can back up setting data for controllers periodically.



11.2 Specifications

11.2.1 System configuration

This section describes the system configuration for the backup/restore function.

For connection type settings, and precautions on the communication unit/cable and connection type, refer to the following manual.

GOT1000 Series Connection Manual

1 Target controller

Controller			
Q series ^{*1*2}	QCPU (Q mode)		
CNC C70	CNC C70		
Motion controller CPU*3*4	Q172CPU, Q173CPU, Q172CPUN, Q173CPUN, Q172HCPU, Q173HCPU, Q172DCPU, Q173DCPU, Q170MCPU		

- *1 Use a PLC CPU with the function version of B or later.
- *2 The backup/restore function cannot be used with the redundant CPU.
- *3 Use the following production number motion controller CPU when using the Q172CPU or Q173CPU.
 - · For bus connection and direct CPU connection
 - Q172CPU: Production number K****** or later
 - Q173CPU: Production number J****** or later
 - For connections other than bus connection and direct CPU connection
 - Q172CPU: Production number N****** or later
 - Q173CPU: Production number M****** or later
- *4 The operation system software of SV13 and SV22 are available only.

Use a motion controller CPU with the following OS installed when using the Q172CPU, Q173CPU, Q172CPUN, or Q173CPUN.

- SW6RN-SV13Q□:00H or later (00E or later for using the Q172CPU or Q173CPU with the bus connection or direct CPU connection)
- SW6RN-SV22Q

 :00H or later (00E or later for using the Q172CPU or Q173CPU with the bus connection or direct CPU connection)

2 Connection type

(○: Applicable, △: Partly restricted, X: Inapplicable)

Function		Connection type between GOT and controller							
Name	Description	Bus	Direct CPU	Computer	Ethernet	MELSECNET/H connection,		Link ection	GOT multidrop
		connection	connection	connection	connection	MELSECNET/10 connection	ID ^{*1}	G4 ^{*2}	connection
Backup/ restore	Backs up setting data for a controller connected to the GOT and restores the data to the controller.	0	0	0	0	×	×	×	×

- *1 Indicates CC-Link connection (Intelligent device station).
- *2 Indicates CC-Link connection (via G4).

3 Required extended function OS

The following extended function OS is required.

	OS memory space (user area)				
Extended function OS	GT16			Option function board	
Extended function 00	Built-in flash	User memory	GT15	Option fanotion board	
	memory (ROM)	(RAM)			
Backup/Restore	420KB	766KB	820KB	Not required	

(1) Extended function OS

Install the extended function OS shown in the above table on the GOT.

For how to install the OS, refer to the following manual.

GT Designer2 Version ☐ Basic Operation/Data Transfer Manual (Chapter 8. TRANSFERRING DATA)

(2) OS memory space

For installing the extended function OS, the available space shown in the above table is required in the user area.

For checking the available space in the user area and the data that uses other user areas, refer to the following manual.

GT Designer2 Version ☐ Basic Operation/Data Transfer Manual (Chapter 8. TRANSFERRING DATA)

Required hardware

The following hardware is required.

GOT	Hardware
GT16	CF card/USB memory
GT15	CF card

5 Data to be backed up and restored

The following shows data to be backed up and restored. Data other than the the following data cannot be backed up and restored.

(1) Basic model QCPU

Item	Description	File name
Parameter	Parameter for operating a programmable controller	PARAM.QPA
Intelligent function module parameter	Parameter for intelligent function modules	IPARAM.QPA
Sequence program	Program that the CPU operates	MAIN.QPG
SFC program	Sequence program with the SFC programming format	MAIN-SFC.QPG
File register	Data stored in file registers	MAIN.QDR
Device comment	Device comment to be stored in a programmable controller	MAIN.QCD
Device initial value	Setting the device initial value	MAIN.QDI

The GOT always restores file register in the Flash card installed in the CPU module without checking if the data are overwritten.

For the file registers in the SRAM card and the standard RAM, you can select whether to restore them. When not restored, the existing file register will be deleted. Therefore, programs of the controller may not work

If a problem occurs in the operation of the controller after restoration, perform the restoration again, including to the file register.

(2) High Performance model QCPU

Item	Description	File name
Parameter	Parameter for operating a programmable controller	PARAM.QPA
Intelligent function module parameter	Parameter for intelligent function modules	IPARAM.QPA
Program	Program that the CPU operates (Including SFC program)	***.QPG
Device comment	Device comment to be stored in a programmable controller	***.QCD
Boot operation specification file	Batch file for starting programs stored in ROM and others	AUTOEXEC.QBT
Device initial value	Setting the device initial value	***.QDI
File register*1	Data stored in file registers	***.QDR
Sampling trace file*2	Sampling trace data that the specified device data is continuously collected with the specified timing	***.QTD
Failure history data*2	Failure history data that are recorded self-diagnostic results	***.QFD
Programmable controller user data	Any user-created data stored in a memory card	***.*** (Optional)

¹ The GOT always restores file register in the Flash card installed in the CPU module without checking if the data are overwritten.

For the file registers in the SRAM card and the standard RAM, you can select whether to restore them.

When not restored, the existing file register will be deleted. Therefore, programs of the controller may not work normally.

If a problem occurs in the operation of the controller after restoration, perform the restoration again, including the file register.

*2 The item can be backed up only.

(3) Universal model QCPU

Item	Description	File name
Parameter	Parameter for operating a programmable controller	PARAM.QPA
Intelligent function module parameter	Parameter for intelligent function modules	IPARAM.QPA
Program	Program that the CPU operates (Including SFC program)	***.QPG
Device comment	Device comment to be stored in a programmable controller	***.QCD
Boot operation specification file	Batch file for starting programs stored in ROM and others	AUTOEXEC.QBT
Device initial value	Setting the device initial value	***.QDI
File register*1	Data stored in file registers	***.QDR
Sampling trace file*2	Sampling trace data that the specified device data is continuously collected with the specified timing	***.QTD
Programmable controller user data	Any user-created data stored in a memory card	***.*** (Optional)
File for storing device data	Device data used for the SP.DEVST and S.DEVLD instructions	DEVSTORE.QST

^{*1} The GOT always restores file register in the Flash card installed in the CPU module without checking if the data are overwritten.

For the file registers in the SRAM card and the standard RAM, you can select whether to restore them.

When not restored, the existing file register will be deleted. Therefore, programs of the controller may not work normally.

If a problem occurs in the operation of the controller after restoration, perform the restoration again, including the file register.

*2 The item can be backed up only.

(4) CNC C70

Item	Description	File name
Machining program	All programs for operating a machine tool with a CNC	ALL.PRG
Parameter	Parameter for operating a CNC	ALL.PRM
Tool offset data	Offset data of the tool length compensation and tool radius compensation	TOOL.OFS
Workpiece offset data	Offset data between the machine coordinate system and workpiece coordinate system	WORK.OFS
Common variable	Macro variables applicable to different machining programs	COMMON.VAR
CNC ladder	User-created PLC program (ladder)	USERPLC.LAD

(5) Q series motion controller CPU

Item	Description	File name
Motion SFC program conversion file (control code)	File where SFC code, G-code and F/FS code files are combined and converted into CPU's Motion SFC program code memory storage format	sfcprog.cod
Motion SFC program conversion file (text)	I converted into CPU's Motion SFC program text memory	
Motion SFC parameter	Motion SFC control parameter setting information files	sfcprmD.bin*1
file	motion of a control parameter setting information med	sfcprm.bin*2
K code file	Internal code files of servo program	svprog.bin
		svsystemD.bin*1
System setting data file	System setting data information files	svsystemH.bin*3
		svsystem.bin*4
High speed read setting	High speed read setting information files	svlatchD.bin*1
file	right speed read setting information mes	svlatch.bin*2
Optional data monitor	Optional data monitor information files	svsysmonD.bin*1
setting file	Optional data monitor information lines	svsysmon.bin*2
	Axis data parameter block information files	svdataD.bin*1
	Axis data parameter block information lines	svdataH.bin*3
Servo data file	Servo parameter information files	svparaH.bin*6
ocivo data ilic	Comic november information files	svdata.bin*4
	Servo parameter information files	svdata2.bin*4
	Limit switch setting data information files	svls.bin
Mechanical system program conversion file	File after conversion of mechanical system program edit information file into internal codes	svmchprm.bin ^{*5}
	Cam data files of cam No.1 to 64	svcamprm.bin*5
Com data conversion file	Cam data files of cam No.101 to 164	svcampr2.bin*5
Cam data conversion file	Cam data files of cam No.201 to 264	svcampr3.bin*5
	Cam data files of cam No.301 to 364	svcampr4.bin*5
Q series PLC common parameter file		
Multiple CPU high speed refresh setting	Multiple CPU high speed refresh setting information files	svrefresh.bin*1

- *1 The data can be backed up or restored only with the Q172DCPU, Q173DCPU, or Q170MCPU.
- *2 The data can be backed up or restored only with the Q172HCPU, Q173HCPU, Q172CPU, Q173CPU, Q172CPUN, or Q173CPUN.
- *3 The data can be backed up or restored only with the Q172HCPU or Q173HCPU.
- *4 The data can be backed up or restored only with the Q172CPU, Q173CPU, Q172CPUN, or Q173CPUN.
- *5 The data can be backed up or restored with the SV22 operating system software only.
- *6 The data can be backed up or restored only with the Q172HCPU, Q173HCPU, Q172DCPU, Q173DCPU, or Q170MCPU.

(6) Data for software

Item	Description	File name
Label program	Data for GX Developer	PROJINFO.CAB
Symbolic data	Symbolic data for PX Developer	#FBDQINF.BIN



(1) Data that cannot be backed up

The GOT cannot back up device current values and data stored in device memories.

For collecting device current values, use the advanced recipe function. For how to use the advanced recipe function, refer to the following manual.

GT Designer2 Version2 Screen Design Manual (Section 12.3 Advanced Recipe Function)

For collecting data stored in device memories, use GX Developer.

(2) Names of files to be backed up

When characters other than the characters defined in the shift JIS code and ASCII code are used for file names, the file names may not be correctly displayed with the data backed up on the GOT.

For using the backup/restore function, use characters in the JIS code and ASCII code for file names.

(3) Backing up data stored in file registers

Because backing up data stored in file registers takes a long time, some file register data may have different time stamps in one backup data. Therefore, synchronism of the data is not assured.

When file register data with the same time stamp are required, take actions with the PLC system. For example, execute a sequence program that stops updating file registers, and then back up data stored in the file registers.

(4) Editing CNC data

The backed up CNC data includes machining programs, parameters, and others. Those data are related one another.

Therefore, when any of the data is changed with a text editor and others, the GOT cannot restore the backed up CNC data to the CNC.

For editing CNC data, use the CNC data I/O function.

12. CNC DATA I/O

(5) Motion controller CPU

(a) OS for motion controller CPU

The OS for the motion controller CPU cannot be backed up or restored. For backing up or restoring setting data for the motion controller CPU, install an appropriate OS on the motion controller CPU in advance.

(b) Backup/restore for motion controller CPU

The GOT backs up or restores data stored in the SRAM built in the motion controller CPU, regardless of the operation mode.

For writing data to the FLASH ROM built in the motion controller CPU, restore the data to the SRAM, and then write the data in the SRAM to the FLASH ROM with MT Developer.

6 Backup data

(1) Storing backup data

When backups for the same channel are executed several times, the backup data are stored in a CF card or USB memory. (Backup data stored in the CF card or USB memory are not overwritten.)

(2) Storing backup data

Backup data are stored in a CF card or USB memory with the following folder structure.

CF card/USB memory Memory card that is in the drive set as the storage location for backup data

BACKUP
SYS1BKUP
YYMMDDXX.....Folder for storing backup data
SYS2BKUP

(3) Folders for backup data

Backup data are stored by the folder, and a folder name (YYMMDDXX) is set as follows. Example) Folder name for the 10th backup data for Ch.1 on November 22nd, 2006 Folder name: 06112209

Folder name		Description
	YY	Backup year (the last two digits of the year)
YYMMDDXX	MM	Backup month (01 to 12)
TTIVIIVIDDAA	DD	Backup date (01 to 31)
	XX	Serial number (00 to 99)

When names of folders for backup data include XX of 99, the backup data cannot be stored. Up to 100 backups can be executed per channel in a day.

11.2.2 Access range

(1) Access range with connection types

The following shows a target controller of the backup/restore execution with each connection type.

Connection type	Target controller
Bus connection, Direct CPU connection, computer link connection, Ethernet connection	Host station

(2) With multi-channel function

With the multi-channel function, the backup and restoration is executed per channel.

(3) Multiple CPU system

When the target controller of the backup/restore is the multiple CPU, the backup is collectively executed for CPU No.1 to 4.

The restoration is executed with specifying target controllers of the restoration (multiple controllers possible).

11.2.3 Precautions

(1) Password for backup/restore

When a password for a controller is changed after setting the password for the backup/restore, set a new password for the backup/restore.

For setting the password for the backup/restore, refer to the following.

Subsection 11.3.3 Security and password

(2) Restoration

(a) Communication status between GOT and target controllers

For restoring data, enable the target controllers of the restoration to communicate with the GOT.

When the target controllers of the restoration cannot communicate with the GOT, the restoration cannot be executed.

(b) STOP status during restoration

CPUs for the programmable controller and motion controller are in the STOP status with the remote STOP before the restoration.

For the CNC C70, the CNC ladder is in the STOP status.

The CPUs and CNC ladder remain in the STOP status after the restoration is completed. Restart the controllers.

(c) When restoration is canceled

When the restoration is canceled, all the data are not restored to the controllers and the controllers may not correctly operate.

When the restoration is canceled, be sure to execute the restoration again.

The CPUs and CNC ladder remain in the STOP status after the restoration is canceled. Restart the controllers.

(d) System configuration with controllers for restoration

Set the same system configuration with the controllers for the restoration as those for the backup.

Failure to do so disables the GOT to restore data to the controllers.

When the system configuration with the controllers for the restoration is the same as those for the backup, the GOT can restore data to the controllers even if the connection type and CH No. for the restoration differ from those for the backup.

(e) Controller operations


Controllers may malfunction by changing set values, device values, and others during the restoration.

Check that data to be restored is the appropriate data, and then execute the restoration with paying attention to the controller operations.

(f) Restoration for a QCPU with factory-settings or whose memory is formatted When using the single CPU system, the restoration can be performed only if the connection type is the bus connection or direct CPU connection.

When using the multiple CPU system, the restoration can be performed only if the connection type is the direct CPU connection.

However, in a multiple CPU system which includes a QCPU with the factory-settings or whose memory is formatted, batch restoration to multiple controllers cannot be performed. Restore each controller with the following procedure.



(3) Operations for backup/restore

(a) Precautions for GT Designer2

Do not execute the following operations with GT Designer2 during the backup/restore.

Operation with GT Designer2			
OS installation,	BootOS installation,	CoreOS installation,	Project download,
Special data download			

When the above operations are executed, the backup/restore is stopped.

- (b) Precautions for GX Developer
 - Do not access the target controller of the backup/restore with GX Developer during the backup/restore.
 - Doing so stops the backup/restore.
 - Do not execute the backup/restore on the GOT while the target controller of the backup/ restore is accessed by GX Developer.
 - Doing so causes a communication error on GX Developer. (The backup/restore is executed.)

(4) Motion controller CPU

(a) Backup

For backing up data for controllers including the motion controller CPU, do not set the motion controller CPU to the installation mode.

When the motion controller CPU is set to the installation mode, the GOT does not back up data for the motion controller CPU. (The GOT backs up data for the other controllers on the same base unit.)

(b) Restoration

For restoring data to controllers including the motion controller CPU, do not set the motion controller CPU to the installation mode or test mode.

Doing so stops the restoration operation of the GOT.

When the restoration is stopped, be sure to execute the restoration again.


Failure to do so causes the GOT not to write all the data into the controllers, resulting in incorrect operations of the controllers.

11.3 Display Operation

11.3.1 Outline before starting

1 Operations before displaying

The following describes the outline for displaying the operation screen for the backup/restore after installing Backup/Restore (extended function OS) on the GOT.





(1) How to display the utility


For how to display the utility, refer to the following.

GT16 User's manual (Basic Utility) (1.3 Utility Display)
GT15 User's manual (9.3 Utility Display)

(2) When GOT has no project data

The backup/restoration can be started with the utility even though the GOT has no project data.

2 Changing screens




11.3.2 Setting storage location for backup data

Set the storage location that backup data are stored. Set the storage location for backup data in the backup/restoration setting of the utility.

Display procedure

- (1) For GT16 Select [Debug] → [Debug setting] → [Backup/restoration setting] from the utility.
- (2) For GT15 Select [GOT setup] → [Backup/restoration setting] from the utility.

2 Settings



Item	Description
Drive for backup setting	Specify the drive for storing backup settings, including parameters and passwords for controllers.
Drive for backup data	Specify the drive for storing backup data.
Trigger backup setting	The GOT automatically backs up data when triggers (Rise, Time) specified for each backup setting are met.
Max. of backup data	Set the maximum number of backup data to be stored. (When 0 is specified, the GOT does not check the number of backup data to be stored.)



Backup/restoration setting


The backup/restoration setting can also be set in the GOT setup on GT Designer2. For the GOT setup of GT Designer2, refer to the following manual.

GT Designer2 Version

Screen Design Manual (Section 3.8 Setting of GOT Display and Operations (GOT Setup))

11.3.3 Security and password

By setting the passwords, the password authentication is available when the backup/restore is executed. The password authentication uses the password for the backup/restore and passwords for controllers.



The following shows the passwords used for the backup/restore.

Password	Description
Password for backup/restore	Password for the backup/restore function Set the password on the GOT at the first backup. Before setting the password, set passwords for controllers in advance.
Passwords for controllers	Passwords set for the files for the target controllers of the backup/restore Set the passwords with software for the controllers when writing the files to the controllers.

After the first backup (after setting the password for the backup/restore), the user has no need to input the passwords for the controllers (The passwords for the controllers are automatically verified.) The following shows the security advantages.

User	Advantage
Administrator No need to disclose the passwords for the controllers to the operator (Preventing anyone other than the administrator to browse or edit setting data to	
Operator	The backup/restore is executed by using the password for the backup/restore only. (No need to input passwords for the controllers)



Before setting password for backup/restore

When the user forgets the password for the backup/restore, the backup/restore cannot be executed.

In that case, execute the backup again by using a formatted or new CF card or USB memory.

For how to set the password for the backup/restore, refer to the following.

This section Setting password for backup/restore

How to use the password for the backup/restore, refer to the following.

This section 2 How to use password for backup/restore


1 Setting password for backup/restore

The password for the backup/restore can be set only when the following condition is satisfied at the first backup.

• When passwords are set for the files for the backup target controller

At the first backup, the password authentication for the controller is required.

The following shows the operating procedure at the first backup.





(1) Setting password

For ensuring the security, setting a password of 8 or more characters that cannot be easily guessed is recommended.

When the password is leaked, the same system can be created. Pay enough attention to managing the password.

- (2) Passwords for motion controller CPU
 - (a) File name

When a password for a motion controller CPU data is input, the GOT does not display the file name.

The GOT displays the data type only.

(b) Setting passwords for data without any contents


When contents of the following motion controller CPU data do not exist, do not set any passwords for the data.

• SFC program • Mechanical system program • Cam data
When passwords are set for the data without any contents, the automatic
password authentication is unavailable when the GOT executes the backup.
As a result, the user must input the passwords each time.

2 How to use password for backup/restore

(1) Backup

The following shows the operating procedure for the backup after setting the password for the backup/restore.






When passwords for controllers are changed

When the password input is cancelled and the backup is stopped, the backed up files until the backup is stopped are all deleted.

(2) Restoration

The following shows the operating procedure for the restoration after setting the password for the backup/restore.






When passwords for controllers are changed

When the password input is cancelled and the restoration is stopped, the restored files until the restoration is stopped remain in the controller.

When only any of the files are restored, the data can be inconsistent in the entire system.



11.3.4 Trigger backup

The GOT can automatically back up setting data for controllers with the trigger device or the days and time set.


Setting the trigger type selects whether to execute the backup with the trigger device or with the days and time.

(1) When trigger type is set to [Rise]

The GOT executes the backup when the set trigger device turns on.

Use the backup with the trigger device for automatically backing up setting data for controllers after the setting data are changed.


Trigger device: X100



(2) When trigger type is set to [Time]

The GOT executes the backup at the specified time on the specified days. Use the backup with the time for backing up setting data periodically.

Setting GOT to back up data at 17:30 on Tuesdays



(3) Maximum number of backup data

With the trigger backup, the maximum number of backup data to be stored can be specified. When the number of backup data exceeds the maximum number of backup data, the GOT automatically deletes the oldest backup data.

Therefore, the GOT does not fail to store the latest backup data.

(4) Comparing and updating backup data

For the backup, the GOT compares the previous backup data with current setting data for each controller on the same base unit.

When the current setting data for any of the controllers differ from the previous backup data, the GOT backs up setting data for all the controllers on the same base unit.


When the current setting data for all the controllers are the same as the previous backup data, the GOT does not execute the backup.

Therefore, the GOT does not store the same backup data.

1 How to set trigger backup

(1) Flow of settings

The following shows the flow of settings for using the trigger backup.





Inputting password for backup/restore

The GOT automatically executes the backup when the trigger condition is met. The password authentication with the password for the backup/restore is not executed.

By executing the password authentication with the password for the backup/restore when setting the trigger backup with the GOT utility, unauthorized users cannot execute the backup.

Without inputting the password for the backup/restore when setting the trigger backup, an error occurs and the GOT does not execute the backup even if the trigger condition is met.

Input the password for the backup/restore in the trigger backup setting of the GOT utility.

For setting the trigger backup with the GOT utility, refer to the following.

GT16 User's Manual (Basic Utility) (Section 4.2.3 Trigger backup settings)

GT15 User's Manual (Section 11.13 Trigger Backup Settings)

(2) Setting items for trigger backup

Set the trigger backup with GT Designer2 and the GOT utility.

For the setting items for GT Designer2, refer to the following.

GT Designer2 Version2 Screen Design Manual (Section 3.8 Setting of GOT Display and Operations (GOT Setup))

For the setting items for the GOT utility, refer to the following.

GT16 User's Manual (Basic Utility) (Section 4.2.3 Trigger backup settings)
GT15 User's Manual (Section 11.13 Trigger Backup Settings)

2 Controlling backup with devices

The GOT controls the trigger backup with devices.

The following shows the devices to be used for the trigger backup.

- Trigger device
- · Process notification device
- · Backup error notification device
- Trigger backup processing setting No. notification (GS657)
- Trigger backup data send delay (GS521)

For the devices and how to set the devices, refer to the following.

GT Designer2 Version2 Screen Design Manual (Section 2.9.1 GOT internal devices)

(Section 3.8 Setting of GOT Display and Operations (GOT Setup))


- (1) When normal backup is executed
 - (a) When trigger type is set to [Rise]

Turn on the trigger device, and then the GOT starts the backup.

When the backup is started, the process notification device turns on.

Turn off the trigger device right after the process notification device turns on. (The trigger device does not automatically turn off.)

When the backup is completed, the process notification device turns off.




(b) When trigger type is set to [Time]

The GOT starts the backup at the time specified for the trigger backup.

When the backup is started, the process notification device turns on, and the time trigger automatically turns off.

When the backup is completed, the process notification device turns off.



(2) Error handling


When an error occurs during the trigger backup, the backup error notification device stores the trigger ID corresponding to the trigger setting set for the backup with the error, and a system alarm occurs.

Check the system alarm, and then remove error causes.

For system alarms and corrective actions, refer to the following manual.

GT15 User's Manual

The backup error notification device stores 0 when the next trigger backup is executed.



(3) Setting send delay time

The backup/restore function can set the delay time for backup communication intervals. Setting of the delay time can reduce the load of other processes (such as monitoring objects) with the backup process.

The actually time set by the set value is listed as follows.

Set value	Delay time
0	None
1 to100	Set value × 5(ms)
101 or more	500(ms)



Setting of trigger backup data send delay

Backup communication times are longer than a default when the trigger backup data send delay is set.

Set the suitable delay time to match the processing condition of backup function and others (such as monitoring objects).

3 Precautions for trigger backup

The following shows precautions for the trigger backup.

(1) GOT operations during trigger backup

The GOT may take a long time to monitor devices and to operate during the trigger backup. Execute the trigger backup when the operator does not operate the GOT.

Updating data with the functions that collect device values, including the logging function, may also take a long time.

(2) Displaying device name on GOT

When the trigger device is set to [Rise], the GOT displays the device name of [??] without the extended function OS of the device name converter installed.

For displaying the device name correctly, install the extended function OS of the device name converter on the GOT.

(3) First backup

The trigger backup is unavailable for the first backup.

Manually execute the first backup, and then set the password for the backup/restore and passwords for controllers. After the settings, set the trigger backup.

(4) Passwords for controllers

When passwords for controllers stored in the backup setting differ from current passwords for the controllers, the backup operation is canceled.

For executing the trigger backup, check that passwords for controllers have no changes. When the backup operation is canceled, manually execute the backup again, and then input correct passwords.

(5) Checking file register changes

When the trigger backup is frequently executed, set [Check the file register changes] to [Not execute] with the GOT utility because data stored in file registers frequently changes.

When [Check the file register changes] is set to [Execute], the GOT backs up data stored in the file registers every time the trigger condition is met even if the other setting data for the controller are not changed.

As a result, the number of backup data increases in the CF card. When the number of backup data exceeds the maximum number of backup data, old backup data are deleted.

For obtaining data stored in file registers only, use the advanced recipe function.

For how to use the advanced recipe function, refer to the following.

GT Designer2 Version2 Screen Design Manual (Section 12.3 Advanced Recipe Function)

(6) Backing up data when CNC and motion controller CPU are on one base unit

When the CNC and/or the motion controller CPU are on one base unit, the GOT does not compare the previous backup data with current setting data for the controllers.


As a result, the GOT executes the backup even if the setting data for the controllers have no changes.

For backing up setting data only when the data are changed, set the trigger type to [Rise]. Create a sequence program so that the trigger device turns on only when the setting data are changed. Therefore, the number of backup data can be minimized.

- (7) Screens that trigger backup can be executed


 The trigger backup can be executed only when the GOT displays a monitor screen.
 - (a) When the trigger condition is met while the GOT displays a screen other than monitor screens, including the utility screen and ladder monitor screen, the GOT does not execute the backup. When a screen other than monitor screens is switched to a monitor screen, the GOT executes the backup.
 - (b) When a monitor screen is switched to a screen other than monitor screens during the trigger backup, the GOT stops the backup and the GOT deletes the data in process. When the screen is switched to a monitor screen, the GOT executes the backup again.
 - (c) When the following are operated, the GOT does not execute the backup even if a screen other than monitor screens is switched to a monitor screen.
 - · Restarting the GOT
 - Changing the trigger backup setting with the GOT utility
- (8) When another trigger condition is met during backup

 The GOT cannot detect that another trigger condition is met.




For ensuring the trigger backup, establish a handshake with the trigger device and the process notification device.

An example of a handshake is shown on the next page.



- The trigger device (Trigger ID: 1) turns on, and then the GOT starts the backup (Trigger ID: 1).
- When the backup is started, the process notification device (Trigger ID: 1) turns on, and the trigger backup processing setting No. notification (GS657) stores the trigger ID.
 When the process notification device turns on, the trigger device (Trigger ID: 1) turns off.
- When the backup (Trigger ID: 1) is completed, the GOT recognizes that the trigger device (Trigger ID: 2) is on and the GOT starts the backup (Trigger ID: 2).
- When the backup is started, the process notification device (Trigger ID: 2) turns on, and the trigger backup processing setting No. notification (GS657) stores the trigger ID. When the process notification device turns on, the trigger device (Trigger ID: 2) turns off.
- (9) When multiple trigger conditions are simultaneously met The GOT executes the backup with the smallest trigger ID first.
- (10) When trigger device is on at GOT startup The GOT recognizes that the trigger condition is met, and then the GOT executes the backup. Create a sequence program so that the trigger device turns off after the GOT checks that the process notification device turns on.



11.4 Operation Procedures

This section describes the backup/restore display details and the functions of the keys displayed on the screen.

The display screen for the backup/restore differs depending on the GOT to be used. This section explains the display screen with the GT1575-V screen.

11.4.1 Main menu

The following describes the display and the key functions on the Bakcup/restoration function: Main menu screen.

1 Display details




	No.	Display details	
Displays the target channel No. of the backup and the setting name for the backup/restore (Fixed).			

Key	Function
Next chnn1	Switches the target channels of the backup/restore.
Backup function	Starts the backup.
Restoration function	Switches the screen to the Restoration function: Data list screen.
GOT data package	Switches the screen to the setting screen of the GOT data package acquisition. GT16 User's Manual (Basic Utility) (Section 4.3.3 GOT data package acquisition) GT15 User's Manual (Section 13.12 GOT Data Package Acquisition) The key is not displayed on the GT1555-Q and GT1550-Q.
Delete backup data	Deletes the oldest data among backup data already stored in a CF card or USB memory in the GOT.
Close	Ends the backup/restore, and then the screen is switched to the backup/restore startup screen.

11.4.2 Progress screen (backup)

This following describes the display details and the key functions on the Backup function: Progress screen.

Display details




No.	Display details	
1)	Displays the setting name for the backup/restore (Fixed).	
2)	Displays the backup data name.	
3)	Displays the channel No., network No., station No., module No., and unit name for the target controller of the backup.	
4)	Displays the target controller status of the backup. : Backup target : Not backup target ×: Access disabled	
5)	Displays the backup progress status. Backing up: The backup is in processing. Aborting: The backup cancellation is in processing. Completed: The backup is completed.	
6)	Displays the file name in processing.	

Key	Function	
Return	Switches the screen to the Backup/restoration function: Main menu screen.	
Cancel	Cancels the backup.	
Close	Ends the backup/restore, and then the screen is switched to the backup/restore startup screen.	

11.4.3 Data list (restoration)

The following describes the display details and the key functions on the Restoration function: Data list screen .

1 Display detail




No.	Display details	
1)	Displays the setting name for the backup/restore (Fixed).	
2)	Displays backup data stored in a CF card or USB memory. Select a backup data to be restored with touching the data.	
3)	Displays the channel No., network No., station No., module No., and unit name for the target controller of the restoration.	
	Displays the target controller status of the restoration. Select a target controller of the restoration with touching the controller.	
4)	●: Restoration target○: Not restoration target×: Access disabled	

Key	Function
A	Scrolls the data list up and down by one line.
Scrolls the data list up and down by one page.	
Multiple selection / Single selection	Switches the number of target controllers of the restoration. Single selection: Select [Single selection] when selecting only one target controller of the restoration. Multiple selection: Select [Multiple selection] when selecting multiple target controllers of the restoration.
Return	Switches the screen to the Backup/restoration function: Main menu screen.
Execute	Starts the restoration.

11.4.4 Progress screen (restoration)

This following describes the display details and the key functions on the Restoration function: Progress screen.

1 Display details



No.	Display details		
1)	Displays the setting name for the backup/restore (Fixed).		
2)	Displays the backup data name.		
3)	Displays the channel No., network No., station No., module No., and unit name for the target controller of the restoration.		
	Displays the target controller status of the restoration.		
	: Restoration target		
4)	○: Not restoration target		
	× : Access disabled		
	? : Restoration failed		
	Displays the restoration progress status.		
	Restoring : The restoration is in processing.		
	Aborting : The restoration cancellation is in processing.		
5)	Completed : The restoration is completed.		
	Abort : The restoration cancellation is completed.		
	Comm.error : The restoration is failed with the communication failed.		
	Data error : The restoration is failed with backup data errors.		
6)	Displays the file name in processing.		

Key	Function
Return	Switches the screen to the Backup/restoration function: Main menu screen.
Cancel	Cancels the restoration.
Close	Ends the backup/restore, and then the screen is switched to the backup/restore startup screen.

11.5 Backup Data Conversion Tool

Backup data are created by the backup/restore function, and the backup data are stored in a CF card. Backup Data Conversion Tool enables the backup data to convert into data editable with GX Developer. The tool also enables backup data edited by GX Developer to convert into data for the restoration on the GOT.



Data to be converted

Only backup data created by the backup/restore function can be converted with Backup Data Conversion Tool.

The following data cannot be converted with Backup Data Conversion Tool.

- Newly-created data by GX Developer
- · Backup data with new files added by GX Developer

11.5.1 Operating environment

Use Backup Data Conversion Tool in the following operating environment.

Item		Description	
Personal computer		PC/AT compatible personal computer that Windows® runs on	
Operating system		Microsoft [®] Windows [®] 2000 Professional Operating System (English version) Microsoft [®] Windows [®] XP Professional Operating System (English version) Microsoft [®] Windows [®] XP Home Edition Operating System (English version)	
Computer			
	CPU	Refer to the following "Applicable operating system and performance required for personal computer".	
	Memory		
Hard d	sk space	500KB or more	
Disk drive		CF card drive	
Display color		High Color (16 bits) or more	
Display		Resolution 640 × 480 dots or more	
Hardware		CF card	
Others		The mouse and keyboard must be compatible with the above OS.	

Applicable operating system and performance required for personal computer

Operating system	Performance required for personal computer	
Operating system	CPU	Memory
Microsoft [®] Windows [®] 2000 Professional Operating System (English version)	Pentium [®] 200MHz or more	64MB or more
Microsoft [®] Windows [®] XP Professional Operating System (English version) Microsoft [®] Windows [®] XP Home Edition Operating System (English version)	Pentium II ® 300MHz or more	128MB or more


11.5.2 How to install and start Backup Data Conversion Tool

Installing Backup Data Conversion Tool is not required. Start Backup Data Conversion Tool with the following procedures.

- Copy BkupRstrDataConv.exe to the hard disk and others on the personal computer. Get the above file from one of the followings.
 - BkupRstrDataConv folder in the Disc2 CD-ROM of GT Works2 or GT Designer2
 - · GTD2 folder on the personal computer
 - MITSUBISHI ELECTRIC FA NETWORK SERVICE website (MELFANSweb website: http://wwwf2.mitsubishielectric.co.jp/english/index.html)
- Double-click the copied BkupRstrDataConv.exe, and then the tool starts. Refer to the following, and set the tool.

1 Setting items

The following shows the setting items of Backup Data Conversion Tool.



Item		Description
Conve	rsion Target	Specify data to be converted.
	Backup Data Folder ^{*1}	Specify the storage location of the backup data (setting data: UNITINFO.G1B) created with the
	Backup Bata i oldei	backup/restore function by clicking the Browse button.
	Target Drive	Select the PLC drive that has setting data to be converted.
Works	pace Drive Setting	Set the settings for editing backup data with GX Developer.
	Drive Name	Specify [IC Card drive] to be specified for [Read IC memory card] and [Write IC memory card] on GX Developer.
	Folder to be assigned to a workspace drive*1	Specify the target folder of [Drive Name] by clicking the Ref. button.
	Drive Assignment	Click the item, and then [Folder to be assigned to a workspace drive] is assigned to [Drive Name]. ([Folder to be assigned to a workspace drive] is automatically assigned to [Drive Name] normally. Use the button when the drive assignment setting is canceled by clicking the Drive Release button and a drive is assigned again.)
	Drive Release	Click the item, and then the drive assignment setting is canceled.
Import (GOT → GX Developer)		Converts the backup data to data editable with GX Developer
Expor	t (GX Developer → GOT)	Converts data edited by GX Developer to data applicable to the backup/restore.
End		Ends Backup Data Conversion Tool.

For details of *1, refer to the following.

*1 Folder name and file name

(a) Number of characters set for folder and file names


The GOT recognizes the file location with a path as shown below.

Set the folder and file names so that the total number of characters in the path is within 78 characters.

The user can set the folder name and file name only.

(Other than the folder and file names are automatically set.)


Example) Path of QPG file to be stored in CF card




2 Operation flow

The following shows the operation flow for Backup Data Conversion Tool.

(1) Editing backup data with GX Developer



(2) Restoring data edited by GX Developer



11.5.4 Precautions

(1) Backup data that Backup Data Conversion Tool cannot be used

The backup data of the CPU without IC memory card cannot be read and written to the IC memory card by GX Developer.

Therefore, these backup data cannot be edited using the Backup Data Conversion Tool and GX Developer.

11.6 Errors and Corrective Actions

1 Common to backup and restoration

Error	Cause	Corrective action
The backup/restore function cannot be used.	The extended function OS of the backup/ restore is not installed on the GOT.	Install the extended function OS on the GOT.
The backup setting is not found.	The backup setting is not stored in the CF card or USB memory in the GOT. No CF card or USB memory is installed to the drive specified for storing the backup setting.	 Install a CF card or USB memory with the backup setting stored. Check the storage location for the backup setting with the utility.
The backup data are not found.	The backup data are not stored in the CF card or USB memory in the GOT. No CF card or USB memory is installed to the drive specified for storing the backup data.	Install a CF card or USB memory with the backup data stored. Check the storage location for the backup data with the utility.
The backup/restore cannot be executed because the user does not know the password for the backup/restore.	The user does not remember the password. The password is incorrect.	Check with the administrator of the system regarding the password for the backup/ restore. Execute the backup again by using a formatted or new CF card or USB memory.
The backup/restore cannot be completed	The communication settings and communication driver for the GOT are incorrectly set.	Check if the communication settings and communication driver for the GOT are correctly set.
because a communication error occurs between the GOT and a controller during the backup/restore.	Because parameters for the controller are incorrectly set, the controller dose not recognize the GOT.	Check if the parameters for the controller is correctly set with tools, including GX Developer, for the controller.
	The controller is turned off.	Turn on the controller.
	The cable is not correctly connected.	Check the cable.

2 Backup

Error	Cause	Corrective action
	No CF card or USB memory is installed to the GOT.	Install a CF card or USB memory to the drive specified for storing the backup setting or backup data.
	The CF card or USB memory does not have free space.	Install a CF card or USB memory with enough free space. Delete unnecessary files in the CF card or USB memory.
The backup data cannot be written into a CF card or USB memory.	The CF card or USB memory is set to write-protect.	Set the CF card or USB memory to writable. The attributes of backup data files stored in the CF card or USB memory cannot be changed with the GOT. Set the files to writable with a personal computer.
	The drive does not exist.	Check if the drive specified for storing the backup setting or backup data exists. (Check if the CF card unit is installed on the GOT.)
Setting data (files and data) cannot be obtained from the controller.	The GOT cannot communicate with the controller.	Check the following. GOT Check if the cable is correctly connected to the GOT. Check if the correct communication driver is installed on the GOT. Check if the communication settings are correctly set. Controller Check if the parameters are set. Check if the cable is correctly connected to the controller. Check if the controller is turned on.
The backup cannot be executed because passwords for files of the controller are set.	The user does not remember the password. The password is incorrect. (The first backup) Passwords for files of the controller are changed.	Check with the administrator of the system regarding the passwords for files of the controller.

3 Restoration


Error	Cause	Corrective action
Setting data (files and data) cannot be written into the controller.	The GOT cannot communicate with the controller.	Check the following. GOT Check if the cable is correctly connected to the GOT. Check if the correct communication driver is installed on the GOT. Check if the communication settings are correctly set. Controller Check if the parameters are set. Check if the cable is correctly connected to the controller. Check if the controller is turned on.
	The target controller of the restoration is a different kind of controller from the target controller of the backup.	 Check if the system configuration for the restoration is the same as that for the backup. Check if the target controller of the restoration is the same as that of the backup or the same kind of controller.
The restoration cannot be executed because passwords for files of the controller are set.	The passwords for files written in the controller are changed.	Check with the administrator of the system regarding the passwords for files of the controller.

12. CNC DATA I/O



12.1 Features

Machining programs, parameters, and others of the CNC connected to the GOT can be copied or deleted.



Copy or delete the CNC data.

12.2 Specifications

12.2.1 System configuration

This section describes the target CNC of the CNC data I/O and the connection types for connecting the GOT to the CNC.

For connection type settings and precautions regarding the communication unit/cable and connection type, see the following manual.

GOT1000 Series Connection Manual

1 Target CNC of CNC data I/O

	CNC	
CNC C70		

2 Connection type

(○: Available, X: Unavailable)

	Function			Conr	nection type be	etween GOT and CNC			
Name	Description	Bus	Direct	Computer link	Ethernet	MELSECNET/10		Link ection	GOT multidrop
		connection	connection	connection	connection	connection	ID*1	G4*2	connection
CNC data	Data I/O between the CNC and GOT	0	×	×	O*3	×	×	×	×

- *1 Indicates CC-Link connection (Intelligent device station).
- *2 Indicates CC-Link connection (via G4).
- *3 Applicable only with the Display I/F connection.

3 Required extended function OS

The following extended function OS is required.

	OS				
Extended function OS	GT16		GT15	Option function board	
	Built-in flash memory (ROM)	User memory (RAM)	9115		
CNC Data I/O	210KB	383KB	437KB	Not required	
GOT Platform Library	77KB	200KB	100KB	Not required	

(1) Extended function OS

Install the extended function OS shown in the above table on the GOT.

For how to install the OS, refer to the following manual.

GT Designer2 Version Basic Operation/Data Transfer Manual (Chapter 8. TRANSFERRING DATA)

(2) OS memory space

For installing the extended function OS, the available space shown in the above table is required in the user area.

For checking the available space in the user area and the data that uses other user areas, refer to the following manual.

GT Designer2 Version Basic Operation/Data Transfer Manual (Chapter 8. TRANSFERRING DATA)

4 Required hardware

The following hardware is required.

GOT	Hardware	
GT16	CF card/USB memory	
GT15	CF card	

5 CNC data that can be input and output

The following data can be input and output with the CNC data I/O function.

For details of the data, refer to the manual for the CNC to be used. .

Description				
Machining program,	Parameter,	Tool offset data,		
Common variable,	Workpiece offset data,	Maintenance data,	Cycle monitor data	

12.2.2 Access range

- (1) Bus connection One GOT can execute the CNC data I/O on up to two CNCs by switching the CNCs.
- (2) Ethernet connection
 One GOT can execute the CNC data I/O on up to 64 CNCs by switching the CNCs.

12.2.3 Precautions

- (1) Before using CNC data I/O Read the manual of the connected CNC carefully and make sure you understand the contents before using the CNC data I/O.
- (2) Inapplicable GOT The CNC data I/O cannot be used with the GT1675M-V, GT1665M-V, GT1575-V, GT1575-VN, GT1572-VN, GT156□, and GT155□.
- (3) Folder name and file name
 - (a) Number of characters set for folder and file names


The GOT recognizes the file location with a path as shown below.

Set the folder and file names so that the total number of characters in the path is within 78 characters.

The user can set the folder name and file name only.

(Other than the folder and file names are automatically set.)

Example) Path of file to be stored in CF card





When setting hierarchy to folder


For setting [Folder Name], enter \ between folder names.

(\ is counted as one character.)

The maximum number of hierarchy levels for creating folders is 20.

(Setting example)

[Folder Name] : Project1 \ abc



(b) Character strings that cannot be set

The following character strings cannot be used in a folder name and a file name. (The character strings cannot be used irrespective of capital or small letters.)

- COM1 to COM9
- LPT1 to LPT9
- AUX
- CON

• NUL

- PRN
- CLOCK\$

The following folder names and file names also cannot be used.

- Folder names starting with G1
- Folder and file names starting with a period or \
- Folder and file names ending with a period or \
- Folder and file names with a period or two periods only
- (4) Protect for data I/O

When the data protection key 1,2, or 3 and edit lock B or C is set, the data I/O is restricted. For the data protection key 1, 2, 3 and edit lock B, C, refer to the following manual.

Manual for CNC to be used


(5) Changing CNC file names

When outputting a file in the CNC and changing the file name, do not change the extension of a maintenance data file. If the extension is changed, the maintenance data file is not recognized.

12.3 Display

1 Display operations

The following describes the outline for displaying the operation screen for the CNC data I/O after installing CNC Data I/O and GOT Platform Library (extended function OS) on the GOT.





(1) How to display the utility

For how to display the utility, refer to the following.

GT16 User's manual (Basic Utility) (1.3 Utility Display)
GT15 User's manual (9.3 Utility Display)

(2) Displaying communication setting window

After turning on the GOT, the communication setting window is displayed at the first startup of the CNC data I/O only.

For displaying the communication setting window at the second or later startup, touch the Ch: button on the CNC data I/O screen.


(12.4 Operation Procedures)

(3) If the project data has not been downloaded

The CNC data I/O can be started from the utility even if the project data has not been downloaded to the GOT.

2 Changing screens

The following describes how to change the screen.




For exiting the CNC data I/O by touching Rtn, the last exited screen is displayed when the CNC data I/O starts next time.

12.4 Operation Procedures

1 Displayed contents

This section describes the display details for the CNC data I/O and the functions of the keys displayed on the screen.



Item	Description		
Ch:1	Displays the communication setting window.		
	• For bus connection		
	Switches CNCs to be monitored when multiple CNCs are connected.		
CNC	The monitoring target is switched in order of the module number.		
Chg	For Ethernet connection		
	Switches CNCs to be monitored when multiple CNCs are connected.		
	The monitoring target is switched in order of the setting for the Ethernet on GT Designer2.		
Rtn	Ends the CNC data I/O, and then the screen is returned to the monitor screen or the screen for the utility of the GOT.		
	Displays the function selection window.		
	Select a function to be executed ([Copy]/[Delete]/[Create a directory]/[USB Drive Stop]*1).		
	• For [Copy] or [Delete]		
	After selecting a function, the selected function is displayed.		
Function	• For [Create a directory]		
	The key window to create any directory is displayed.		
	(Creating a directory)		
	• For [USB Drive Stop]*1		
	The window for confirming to stop the USB drive is displayed.		
	Displays the device selection window.		
Device	Select the target of [Function] ([CNC]/[E:USB Drive]*1/[B:Extend Memory card]/[A:Built in CF card]).		
	After selecting the target, the selected target is displayed.		
	The settings and display details differ depending on the setting for [Device].		
	• For [CNC]		
	Displays the CNC data selection window.		
D:	Select a CNC data that [Function] is executed.		
Directory	After selecting a CNC data, the selected CNC data is displayed.		
	• For [E:USB Drive]*1, [B:Extend Memory card], or [A:Bulit in CF card]		
	Displays the directory selected in the list. (The Directory button cannot be touched.)		
	Up to 28 characters are displayed as the directory.		


Item	Description
	Displays the file name selected in the list.
File name	When outputting a file, the file name can be changed by using a key window.
	(Changing the file name when outputting the file)
	The display details differ depending on the setting for [Device].
	• For [CNC]
	[Entry], [Remain]:
	Displays the number of programs registered and the number of registerable programs left as user-created
	machining programs.
Above the list	[Character], [Remain]:
	Displays the number of characters registered and the number of registerable characters left as user-created
	machining programs. The number of registerable characters left is displayed by 250 characters.
	• For [E:USB Drive]*1, [B:Extend Memory card], or [A:Bulit in CF card]
	[Used(KB)], [Remain]:
	Displays the used space and available space of the memory card.
	Displays the data in the target selected for [Device].
	When [E:USB Drive]*1, [B:Extend Memory card], or [A:Built in CF card] is selected, the directory is displayed as < >.
List	Touching < > displays the data in the directory. (Touching <> displays the upper directory.)
	The copy source device is set to [E:USB Drive]*1, [B:Extend Memory card], or [A:Built in CF card], the directory for the
	file is displayed in the directory field of the copy destination device (CNC).
	Scrolls the list up by one page.
▼	Scrolls the list down by one page.
A 1	Switches the setting targets (blue frame in the left side of the screen) up and down.
Area chg	When [Function] is selected for [Delete], the setting targets cannot be switched.
Refresh	Updates the list.
Exec	Executes the settings.

^{*1} The USB drive is applicable to GT16 only.

2 Creating a directory

Any directory can be created in a CF card or USB memory.

The following explains an example of creating the "SAMPLE01" directory in a CF card.










- Touch the <a>Area chg key to switch the setting target to the CF card.
 - 2 Touch the Function key.
 The function selection window appears.
 - 3 Touch the Create a directory key. A key window appears.
- 4 Input "SAMPLE01".
- Touch the ENTER key.
 The key window is closed.
 The list is updated, and the "SAMPLE01" directory is created.

3 Changing the file name when outputting the file

When copying a file to a CF card or USB memory, the file name in the copy destination device can be changed.

The following explains an example of outputting a CNC machining program file to a directory in a CF card with changing the file name from "ALL.PRG" to "SAMPLE.PRG"."



- Touch the Function key.

 The device selection window appears.

 Set the copy source device to [CNC] and the directory to [Machine program].
- 2 Touch the Area chg key to switch the setting target to the copy destination device.

 Set the copy destination device to [A:Built in CF card].
- 3 Touch "ALL.PRG" in the list.
- Touch the Exec key.

 The copy confirmation window as shown in the left appears.
- Touch the Name Change key.

 (Touching the OK key copies the file with the old file name.)

 A key window appears.
- 6 Touch the AC key to delete the old file name from the input value display area.
- 7 Input "SAMPLE.PRG".
- 8 Touch the ENTER key.
 The key window closes and the copy confirmation window appears.

Touching the OK key starts copying the file with the new file name.

The file name is changed to "SAMPLE.PRG" in the copy destination device.

4 Display details in list

The following shows file names to be displayed in the list on the CNC data I/O screen.

Target data	Description	File name to be displayed in list
Machining program*1	Machining program	ALL.PRG, O_PRG
Parameter	Parameter	ALL.PRM
Tool offset data	Tool offset data	TOOL.OFS
Workpiece offset data	Workpiece offset data	WORK.OFS
Common variable	Common variable	COMMON.VAR
	CNC ladder	USERPLC.LAD
	R resister data	RREG.REG
	C resister data	CREG.REG
Maintenance data	T resister data	TREG.REG
	Operation history data	TRACE.TRC
	CNC sampling data	NCSAMP.CSV
	SRAM data files	SRAM.BIN
	Sampling related package file	ALL.SMP
	Sampling setting file	SAMPLING.PRM
Cycle monitor data	PLC data collection setting file	FLCSAMP.CTF
Cycle monitor data	PLC draw setting file	PLCSAMP.MMG
	PLC collection data file	PLCSAMPH.CSV
	CNC collection data file	NCSAMPH.CSV

^{*1} When the base specifications parameter of #1166 fixpro is set to 1, the fixed cycle program is the target data. When the CNC has machining programs, ALL.PRG is displayed at the top of the list.

12.5 Error Messages and Corrective Actions

The following shows the error messages for the CNC data I/O and the corrective actions.

Error message	Error	Corrective action
Communication error	The GOT fails to communicate with the CNC.	Set the correct connection and settings.
Memory Card not exist	No USB memory, extended memory card, or CF card is inserted into the GOT.	Check that a USB memory, extended memory card, or CF card is inserted into the GOT.
Failed to stop USB drive	The GOT fails to stop the USB drive.	Check the USB memory.
Unable to exec : PLC built in CNC running	The PLC CPU built in the CNC is in operation.	Stop the operation of the PLC CPU built in the CNC, and then execute the CNC data I/O again.
Unable to exec : Program running	The GOT cannot execute the CNC data I/O because the CNC is in operation.	Stop the CNC operation, and then execute the CNC data I/O again.
Out of memory	The capacity of the data to be written exceeds the CNC memory capacity.	Make enough space in the CNC memory by operations, including deleting machining programs, and then execute the CNC data I/O again.
File not found	The file to be copied does not exist.	Set the correct settings, and then execute the CNC data I/O again.
Timeout	The GOT fails to communicate with the CNC.	Check the connection.
Directory illegal	The directory is invalid.	Set the correct directory settings, and then execute the CNC data I/O again.
Data protect	The data is protected.	Check if data protection keys, edit locks, and others turn on. Check if the data is a read-only data. Then, execute the CNC data I/O again.
No. of registration over	The number of registerable programs is exceeded.	Delete unnecessary machining programs, and then execute the CNC data I/O again.
File is not specified	The Exec button is pressed even though a file is not specified.	Specify a file, and then execute the CNC data I/O again.
Some error found in file system	Errors occur in file systems.	File system errors Format the NC memory.
Can not write file	The file cannot be written in the copy destination device.	Check if the copy destination device is ready for data writing. TRACE.TRC and NCSAMP.CSV cannot be copied to the CNC.
Can not write file Format Error	The format is incorrect.	Check the format of the parameter.
Can not write file Range Over	The value is invalid.	Check the set value of the parameter.
Can not write file In sampling	The GOT cannot write the file to the CNC because sampling is in progress.	Write the file to the CNC after sampling is completed.

Error message	Error	Corrective action
Can not write file Can't set superposition waveform	The superposition waveform cannot be set because the parameters of the wave type 1 and the wave type 2 are not matched when inputting the wave type 2. For example, [Superposition] is set to [OFF] in the parameters of the cycle monitor.	Configure the correct parameter settings or input the correct data.
Can not read out file	The file to be copied cannot be read.	Check if the copy source device is ready for data reading.
Filename illegal	The file name is invalid.	Check the file name, and then execute the CNC data I/O again.
Program No. duplicate	The GOT tries to copy ALL.ORG to the CNC, but the machining program with the same number already exists in the CNC, so the GOT cannot execute the CNC data I/O.	Delete the machining program in the CNC, and then execute the CNC data I/O again.
Error	Other errors	Turn off the GOT and CNC. Check data in the CF card and the connection status. Then, execute the CNC data I/O again.

13. SFC MONITOR











13.1 Features


With the SFC monitor function, the GOT can monitor SFC programs of controllers, and changing device values of the programs is available.

The function improves the efficiency in troubleshooting and maintenance of PLC systems with SFC programs.

The following shows features of the SFC monitor function.

1 Displaying SFC programs in SFC diagram format

The GOT can monitor SFC programs of the PLC CPU and display the programs in the SFC diagram format (MELSAP3 or MELSAP-L format).




SFC diagram monitor screen

The following screens are displayed with the SFC monitor function.

- PLC read screen (13.5 How to Operate PLC Read Screen)
- Block list screen (13.6 How to Operate Block List Screen)
- SFC diagram monitor screen (13.7 How to Operate SFC Diagram Monitor Screen)

Touching a step or transition condition on the SFC diagram monitor screen displays an enlarged operation output/transition condition sequence program.



2 Switching display formats, device comment display, and languages

The following are available.

- Switching the display formats of device values
- · Switching whether to display or hide device comments
- Switching languages for file names of SFC programs, comments, and others
- (1) Switching display formats
 On the SFC diagram monitor screen, the display formats for the current values of word devices can be switched between decimal and hexadecimal numbers.
- (2) Switching device comment display Whether to display or hide device comments used in SFC programs can be switched.
- (3) Switching languages

Block titles, file titles, and comments can be displayed in the language set for the language switching in the GOT utility with comment files created with the SJIS code, KS code, and/or ASCII code.

With a CF card storing comment files created with the SJIS code, KS code, and/or ASCII code, comments can be displayed in the language corresponding to any character code in the CF card, regardless of the language set in the GOT utility.


3 Interaction with ladder monitor function

By only selecting a device on the SFC diagram monitor screen and starting the ladder monitor, the GOT can search and display the device in a ladder program.

(Display menu)

The function is useful for searching for a device used within both a SFC program and a ladder program in the ladder program.

Example) When turning on Y22 device with ladder program including interlock circuit



- Finding that the machine stops
- Checking an active step with the SFC monitor
- 3 Checking that the machine operation command (M10) is on
- Touching M10 and starting the ladder monitor
- 5 Finding out that Y22 (machine operation) is off because X1 is off
- 6 Finding out that the machine stops because the door is open (X1 is off)

13.2 Specifications

13.2.1 System configuration

This section describes the system configuration for the SFC monitor function.

For connection type settings, and precautions on the communication unit/cable and connection type, refer to the following manual.

GOT1000 Series Connection Manual

1 Target controller

	Controller	
QCPU (Q mode)*1		

*1 Excluding the Q00UJCPU, Q00UCPU, Q01UCPU, Q10UD(E)HCPU, and Q20UD(E)HCPU
For creating a multiple CPU system with the Q00CPU, Q01CPU, Q02CPU, Q02HCPU, Q06HCPU, Q12HCPU, and/or Q25HCPU, use CPUs with the function version B or later.

2 Connection type

(O: Available, ×: Unavailable)

	Function		Connection form between GOT and controller							
Name	Description	Bus	Direct CPU	CPU link Ethernet		MELSECNET/H connection,	CC- Link	connection		GOT multidrop
	2000.iption	connection	connection	connection	MELSECNET/10 connection*1	IE*2	ID*3	G4*4	connection	
SFC monitor	Monitors SFC programs.	O*5*6	0	0	0	0	0	0	0	×

- *1 For the MELSECNET/10 connection, use a QCPU and network module (QJ71LP21, QJ71LP21-25, QJ71LP21S-25, and QJ71BR11) with the function version B or later.
- *2 Indicates the CC-Link IE controller network connection.
- *3 Indicates CC-Link connection (Intelligent device station).
- *4 Indicates CC-Link connection (via G4).
- *5 The Q12PRHCPU and Q25PRHCPU are not available.

3 Required extended function OS, option OS, and option function board

The following extended function OS, option OS, and option function board are required.

		OS m	OS memory space (user area)		Option function board		
Category	Option OS	Ontion OS GT10		16			
Outegory	орион ос	Built-in flash memory (ROM)	User memory (RAM)	GT15	GT16	GT15	
Extended function OS*1	GOT Platform Library	77KB	200KB	100KB		GT15-QFNB16M,	
	SFC Monitor	442KB	2108KB	1373KB	Not required	GT15-QFNB32M,	
Option OS*1	GOT Function Expansion Library	4729KB	19381KB	4729KB	'	GT15-QFNB48M, GT15-MESB48M	

For using the SFC monitor function, a capacity of 6201KB or more is required in the user area of the specified drive for installing the extended function OS and option OS. (For using the GOT with the built-in flash memory of 5MB, set the OS boot drive to [A: Standard CF Card].)

For operating GOT Function Expansion Library (option OS), a capacity of 8192KB is required in the user area of the GOT memory. (A total memory capacity of 14393KB is required for using the SFC monitor function.) Therefore, the following settings are required depending on the GOT to be used.

GOT	Required setting
GT1575-VN, GT1572-VN, GT1562-VN	Setting the OS boot drive to [A: Standard CF Card] Memory expansion (Installing an option function board with add-on memory)
GT15 other than the above	Memory expansion (Installing an option function board with add-on memory)

For setting the OS boot drive, refer to the following.

GT Designer2 Version Basic Operation/Data Transfer Manual (Chapter 8 TRANSFERRING DATA)

(1) Extended function OS and option OS

Install the above extended OS and option OS on the GOT.

For how to install the operating systems, refer to the following manual.

GT Designer2 Version Basic Operation/Data Transfer Manual (Chapter 8. TRANSFERRING DATA)

(2) OS memory space

For installing the extended function OS and option OS, the available space shown in the above table is required in the user area.

For checking the available space in the user area and the data that uses other user areas, refer to the following manual.

GT Designer2 Version Basic Operation/Data Transfer Manual (Chapter 8. TRANSFERRING DATA)

(3) Option function board

(a) For GT16

No option function board is required.

(b) For GT15

Mount one of the option function boards in the above table on the GOT.

For the GOTs with a built-in option function board, refer to the following.

1.1.2 Hardware and OS' required for each function

For how to mount an option function board on the GOT, refer to the following manual.

GT15 User's Manual (8.10 Option Function Board)

4 Required hardware

The following hardware is required.

Hardware

CF card

13.2.2 Devices and range that can be monitored

(O: Possible, x: Impossible)

			•	31bic, ×. 1111p0331bic)	
Device	Device range	Program display	Device monitor display	Search operation	
Input	X0 to 1FFF, DX0 to FFF	0	0	0	
Output	Y0 to 1FFF, DY0 to FFF	0	0	0	
Internal relay ^{*1}	M0 to 61439	0	0	0	
Latch relay	L0 to 8191	0	0	0	
Link relay*2	B0 to FFFF	0	0	0	
Timer	T0 to 2047	0	0	0	
Retentive timer	ST0 to 2047	0	0	0	
Counter	C0 to 1023	0	0	0	
Data register	D0 to 12287	0	0	0	
Link register	W0 to 1FFF	0	0	0	
Annunciator	F0 to 2047	0	0	0	
Edge relay	V0 to 2047	0	×	0	
	R0 to 32767	0	0	0	
File register*3	ZR0 to 32767	0	0	0	
	ZR32768 to 4184063	0	0	×	
Fotonded data assistes	D0 to 32767	0	0	0	
Extended data register	D32768 to 4212223	0	0	×	
Extension file register	W0 to 7FFF	0	0	0	
Extension file register	W8000 to 4045FF	0	0	×	
Link special relay	SB0 to 7FF	0	0	0	
Link special register	SW0 to 7FF	0	0	0	
Step relay	S0 to 8191, BL □ ¥S □	0	×	0	
Index register*4	Z0 to 19	O *5	0	0	
Special relay	SM0 to 2047	0	0	0	
Special register	SD0 to 2047	0	0	0	
Function input	FX0 to F	0	×	0	
Function output	FY0 to F	0	×	0	
Function register	FD0 to 4	0	×	0	
Link direct device	J 🗆 🖺 ¥ 🗆 🗆	0	×	×	
	U 🗆 🗆 ¥ 🗆 🗆				
Module access device	U3En □ □ ¥ □ □	0	×	×	
Nesting	N0 to 14	×	×	×	
Pointer	P0 to 4095	×	×	×	
Interrupt pointer	10 to 255	×	×	×	
SFC block device	BL0 to 319	0	×	0	
SFC transition device	TR0 to 511, BL □ ¥TR □	0	×	0	
Network No. specification device	J0 to 255	0	×	×	
I/O No. specification device	U0 to 1FF 3E0 to 3E3	0	×	×	
Macro instruction argument device	VD0 to	×	×	×	
- 3		, ,	, , , , , , , , , , , , , , , , , , ,		

^{*1} M8192 to 61439 are applicable to Universal model QCPU only.

^{*2} B2000 to FFFF are applicable to Universal model QCPU only.

^{*3} ZR1042432 to 4184063 are applicable to Universal model QCPU only.

^{*4} Z16 to 19 are applicable to Universal model QCPU only.

^{*5} When a ZZ device is used, "ZZ" can be displayed.

13.2.3 Access range

The access range is the same as the access range when the GOT is connected to a controller. Refer to the following manual for details of the access range.

GT Designer2 Version ☐ Screen Design Manual (2.7 Controllers that can be monitored and the Access Range)

13.2.4 Precautions

(1) Inapplicable GOT

The SFC monitor cannot be used with the GT1555-Q and GT1550-Q.

- (2) Precautions for operations during SFC monitor startup Do not operate the following with the GOT during the SFC monitor startup. Doing so may delete stored data and cause the SFC monitor to operate incorrectly.
 - · Turning on or off the CF card access switch
 - · Inserting or removing a CF card
- (3) Precautions for devices
 - (a) The GOT cannot search for indexing devices.
 - (b) The GOT cannot monitor local devices.
- (4) Precautions for setting [Locus] for line graphs
 The SFC monitor function is not available when [Locus] is set for line graphs.
 For using the SFC monitor function, do not set [Locus] for line graphs.
- (5) Precautions for file names (program names) of comment files to be read Only files with the file names (program names) with one-byte alphanumeric characters are applicable to the GOT.

When project data are created on GX Developer, use only one-byte alphanumeric characters for file names (program names).


13.3 Display Operation


This section describes procedures for displaying the SFC monitor operation screens after turing on the GOT.

13.3.1 Outline before starting

1 Operations before displaying

The following describes the outline for displaying the SFC monitor operation screens after installing GOT Platform Library (extended function OS), SFC Monitor (option OS), and GOT Function Expansion Library (option OS) on the GOT.





Point P

(1) How to display the utility

For how to display the utility, refer to the following.

GT16 User's manual (Basic Utility) (1.3 Utility Display)
GT15 User's manual (9.3 Utility Display)

(2) Reading data from PLC when reclosing GOT Reading data from the PLC is not required when reclosing the GOT power, because SFC programs and comment files are stored in a CF card for the SFC monitor function.


(3.3.2 Setting SFC data storage location)

(3) When GOT has no project data

The SFC monitor can be started with the utility even though the GOT has no project data.

2 Changing screens

The following describes how to change the screen.



13.3.2 Setting SFC data storage location

1 Setting SFC data storage location

The selected drive of the GOT (CF card) can store up to 512 files of SFC data (SFC programs, device comments) used for the SFC monitor function.

SFC data are stored in the storage location that stores ladder data for the ladder monitor function. Only the A drive (standard CF card) or B drive (extended memory card) is available for storing SFC data.

For setting the storage location for ladder data, refer to the following manuals. When setting with GOT utility

GT16 User's Manual (Basic Utility) (Section 4.2.1 Q/L/QnA ladder monitor setting)
GT15 User's Manual (Section 11.7 Q/QnQ Ladder Monitor)

When setting with GT Designer2


GT Designer2 Version ☐ Screen Design Manual (Section 3.8 Setting of GOT Display and Operations (GOT Setup))

13.3.3 Reading comment files from CF card


The SFC monitor function uses comment files stored in a CF card installed in the GOT.

- Procedure for using comment files stored in CF cards

 The following shows the procedure for using a comment file stored in a CF card.
 - (1) When displaying comments in language set for language switching of GOT utility Store comment files in a CF card on the PLC read screen. For how to store comment files in a CF card on the PLC read screen, refer to the following.
 - 13.5 How to Operate PLC Read Screen
 - (2) When displaying comments in any language regardless of language set for language switching of GOT utility



Create a SEQCMNT folder in a CF card. When the SEQCMNT folder already exists, creating a new SEQCMNT folder is not required.





In the SEQCMNT folder, create folders for CH No., network No., station No., and CPU No. of the monitored controller with a hierarchy as shown left.

Item	Folder name
CH No.	CH**
Network No.	NET***
Station No.	ST***
CPU No.	CPU**

Assign numbers to "*" marks. (When the CH No. is 1, the folder name is CH01. When the monitor target is the host station, the folder name is ST255.)

(Continued to next page)







(Example: Storing comment files with ASCII code in the ASCII folder.)

3 In the CPU No. folder, create folders for storing comment files by character code.

Item	Folder name
Folder for SJIS code	SJIS
Folder for KS code	KS
Folder for ASCII code	ASCII

4 Copy a comment file (.wcd) from the project data of GX Developer.

5 Store the copied comment files in the folders for each character code in the CF card.

Comment character code	Storage folder name
SJIS code	SJIS
KS code	KS
ASCII code	ASCII

- 6 Install the CF card with the comment file on the GOT.
- Switch comment files on the SFC diagram monitor screen for displaying the comments in an appropriate language.

13.4 Setting Display Format

The display format of word device values displayed on the SFC diagram monitor screen, language, the display mode of SFC programs, and others can be set.

13.4.1 Switching languages of SFC programs

Languages of comments to be displayed on the SFC monitor screens can be switched during monitoring. For switching languages, comment files in the language to be displayed must be created in advance.

(13.3.3 Reading comment files from CF card)

The following shows the relations between the language selected in the GOT utility and comment files with each character code.

Language	Comment file
Japanese	Comment files with SJIS code
Korean	Comment files with KS code
Other than the above	Comment files with ASCII code

13.4.2 Setting display mode of SFC programs

The display mode of SFC programs on the SFC diagram monitor screen can be set.

(Display menu)

The MELSAP-L program display mode is available regardless of the read SFC program format (MELSAP3, MELSAP-L).

In the MELSAP-L program display mode, operation output/transition condition sequence programs are displayed as [?????] when the GOT displays a SFC program with the MELSAP3 format.

The following shows how the GOT displays sequence programs with and without the MELSAP-L program display mode.

Item	With MELSAP-L program display mode	Without MELSAP-L program display mode
Displayed operation output/transition condition sequence program	The GOT displays a sequence program on the SFC diagram monitor screen.	The GOT displays a sequence program in the zoom window by touching a step or transition condition on the SFC diagram monitor screen.

13.4.3 Setting zoom comment display mode

Whether to display or hide comments and notes in the zoom window can be set.

(13.7.3 Monitoring Mode menu)

13.4.4 Switching display formats between decimal and hexadecimal numbers


The display formats of word device values on the SFC diagram monitor screen can be switched between decimal and hexadecimal numbers.

(Display menu)

13.4.5 Setting automatic scroll mode

The automatic scroll can be switched between enabled or disabled states. In the automatic scroll mode, the GOT displays active steps on the SFC diagram monitor screen by automatically scrolling the screen when all the following conditions are satisfied.

- No active step is displayed on the SFC diagram monitor screen.
- The displayed block has an active step.



The step status becomes inactive.

An active step in the block is displayed by automatically scrolling the screen.

For setting the automatic scroll mode, refer to the following.

For the SFC diagram monitor screen, refer to the following.

13.7 How to Operate SFC Diagram Monitor Screen


13.5 How to Operate PLC Read Screen

On the PLC read screen, the GOT reads SFC programs and comment files used for the SFC monitor function from the PLC.

The following describes how to operate the PLC read screen.

13.5.1 Displayed contents

The following describes the configuration of the PLC read screen displayed after the SFC monitor starts and key functions on the screen.




No.	Item	Description
1)	PLC name	Displays the label set in the PLC name setting for the target PLC CPU.
2)	Target controller	Displays CH No., network No., station No., and CPU No. of the target PLC CPU.
3)	Keys	Keys for operations on the PLC read screen shown in section 13.5.2. (Touch input)
4)	Target drive list (target controller)	Displays the target PLC CPU model and the drives in a list. Selecting a drive displays files within the drive in the file list (target controller). For the drive that stores files selected in the file list (target controller), [*] is displayed to the left of the drive name.
5)	File list (target controller)	Displays the program types, file names, titles, sizes, dates, and times of all the files within the drive selected in the target drive list (target controller). (The date and time show those of updated files.) A file to be read can be selected from the file list. (The selected file is highlighted.) For program files, only SFC program files in the program memory can be selected. For selecting the file name selected in the file list (GOT), the file selection in the file list (GOT) is canceled. When a password is set for the selected file, the password input window appears. (This section (1) Password input window)

(Continued to next page)

No.	Item	Description
6)	Target drive list (GOT)	Displays the drive set for [Data save location] in the MELSEC-Q/QnA ladder monitor settings. (For the SFC monitor function, only the A drive (standard CF card) or B drive (extended memory card) is available.) For the drive that stores files displayed in the file list (GOT), [*] is displayed to the left of the drive name.
7)	File list (GOT)	Displays the program types, file names, titles, sizes, dates, and times of all the files within the drive selected in the target drive list (GOT). (The date and time show those of updated files.) A file to be read can be selected from the file list. (The selected file is highlighted.) For selecting the file name selected in the file list (target controller), the file selection in the file list (target controller) is canceled.
8)	Total file size	Displays the total data size of files selected in the file list (target controller) and file list (GOT).
9)	Number of selected files	Displays the total number of files selected in the file list (target controller) and file list (GOT).
10)	Message display area	Displays error messages and others.

(1) Password input window

(a) Displayed screen



The following table shows the displayed contents.

No.	Item	Description
1)	Password type	Displays the type of the password to be input. (Program password/Comment password)
2)	Password input area	Set the password.
3)	File name	Displays the file name.
4)	Keys	Keys for operations in the password input window shown in (b) (Touch input)

Key	Function
×	Closes the password input window and cancels the password input operation.
Switches the key type to the value.	
Switches the key type to the alphabet (uppercase).	
a-z	Switches the key type to the alphabet (lowercase).
AC	Deletes all the input values and characters.
Del	Deletes an input value or character.
Enter	Verifies the password set in the password input area. When the password verification for the first file is successful, the password verification for the other files is automatically executed with the same password.


13.5.2 Key functions

The following shows the functions of the keys used for operating the PLC read screen.

Key	Function
←Back	Returns the screen to the last screen that is displayed right before the PLC read screen appears. The key is disabled when the last screen is the GOT utility screen or user-created monitor screen.
Select CPU	Displays the communication setting window. ([] 13.5.2 (1) Communication setting window)
×	Exits the SFC monitor and returns the screen to the SFC monitor startup screen.
A V	Scrolls the display area up and down by one line.
* *	Scrolls the display area up and down by one page.
Recommend	Available only when [0:Program Memory] is selected from the target drive list (target controller). Touching the key selects all the SFC program files, common comment files, and comment files for the selected SFC program files in the file list (target controller). When files with the same name are displayed in the file list (target controller) and file list (GOT), touching the key selects a file as shown below. • For SFC program files When the updated dates and times differ between the files, touching the key selects the file in the file list (target controller). When the updated dates and times are the same between the files, touching the key selects the file in the file list (GOT). • For comment files When the updated dates and times differ between the files, touching the key selects the latest file. When the updated dates and times are the same between the files, touching the key selects the file in the file list (GOT).
Proceed	Writes the file selected in the file list (target controller) into the CF card displayed in the target drive list (GOT). The file written into the CF card on the PLC read screen is stored in the SEQDAT folder. After writing, among files other than comment files in the CF card, files that are not selected in the file list (GOT) are deleted. Then, the program list window appears. This section (2) Program list window

(1) Communication setting window

(a) Displayed screen



(When the CH No. is input)

(When the network No., station No., and CPU No. are input)


The following table shows the displayed contents.

No.	Item	Description
1)	CH No. input area	Set the CH No. for the target controller.
2)	Network No. input area	Set the network No. for the target controller.
3)	Station No. input area	Set the station No. of the target controller. When the station No. is set to the host station (FF), set the network No. to 0.
4)	CPU No. input area	Set the CPU No.
5)	CH No. selection key	Select a CH No.
6)	Keys	Keys for operations in the communication setting window shown in (b). (Touch input)

Key	Function	
×	Closes the communication setting window. When any of the CH No., network No., station No., and CPU No. is not input and the monitor	
	target is not set, the communication setting window does not close.	
◆	Moves the cursor among the input areas.	
AC	Deletes all the input values and characters.	
Del	Deletes an input value or character.	
	Moves the cursor when the cursor is in the CH No. input area, network No. input area, or	
F .	station No. input area.	
Enter	When the cursor is in the CPU No. input area and settings for the CH No., network No., and	
	station No. are completed, the communication setting window closes and the PLC read screen	
	appears.	

(2) Program list window
The GOT displays the read SFC programs in a list.

(a) Displayed screen



The following table shows the displayed contents.

No.	Item	Description
1)	SFC program file list	Displays the file names and execution statuses of the read SFC programs. The execution statuses show execution types set for the programs. A touched SFC program file is highlighted.
2)	Keys	Keys for operations in the program list window shown in (b). (Touch input)


Key	Function
A ¥	Scrolls the display area up and down by one line.
Display	Displays the blocks of the SFC program file selected in the SFC program file list on the block list screen. ([] 13.6 How to Operate Block List Screen)

13.6 How to Operate Block List Screen

On the block list screen, the GOT displays blocks within the read SFC program in a list. The following describes how to operate the block list screen.

13.6.1 Displayed contents

The following describes the configuration of the block list screen, menus and key functions on the screen.



No.	Item	Description
1)	PLC name	Displays the label set in the PLC name setting for the target PLC CPU.
2)	Target controller	Displays the CH No., network No., station No., and CPU No of the target PLC CPU as shown below. • CH No. network Nostation No./CPU No.
3)	Program name	Displays the file name (without the extension) of the displayed program.
4)	Keys	Keys for operations on the block list screen shown in section 13.6.2. (Touch input)
5)	Block list	Displays the block numbers and block titles in the displayed program. The block numbers are not displayed with no block. Active blocks are highlighted. Selecting a block title displays the block data on the SFC diagram monitor screen. (3.7 How to Operate SFC Diagram Monitor Screen)
6)	Block information list	Displays block information for each block. When devices are set for the block information, the set devices are displayed in the corresponding cells.
7)	Message display area	Displays error messages and others.

13.6.2 Key functions

The following shows the functions of the keys used for operating the block list screen.

Key	Function	
←Back	Returns the screen to the last screen that is displayed right before the block list screen appears. The key is disabled when the last screen is the GOT utility screen or user-created monitor screen.	
Sets the device test mode. Touching the key in the device test mode cancels the device test mode. (() 3 13.8 Test Operation)		
Display	Displays menus used for operations on the block list screen. (3.6.3 1 Display menu)	
×	Exits the SFC monitor and returns the screen to the SFC monitor startup screen.	
A ¥	Scrolls the display area up and down by one line.	
1 ¥	Scrolls the display area up and down by one page.	

13.6.3 Menus

The following shows operations for the menus displayed on the block list screen.

1 Display menu



Key	Function	Reference section
Comment Change	Displays the comment file list window.	13.7.3 2 (1)
Program List	Displays the program list window.	13.5.2 (2)
PLC Read	Displays the PLC read screen.	13.5

13.7 How to Operate SFC Diagram Monitor Screen


On the SFC diagram monitor screen, the GOT monitors and displays data of the block selected on the block list screen in the SFC diagram.

The following describes how to operate the SFC diagram monitor screen.

13.7.1 Displayed contents

1 SFC diagram monitor screen

The following describes the configuration of the SFC diagram monitor screen, menus and key functions on the screen.



No.	Item	Description
1)	Target controller	Displays the CH No., network No., station No., and CPU No. of the target PLC CPU as shown below. • CH No. network Nostation No./CPU No.
2)	Program name	Displays the file name of the displayed program.
3)	Block No.	Displays the block No. of the displayed block.
4)	Block title	Displays the block title of the displayed block.
5)	Keys	Keys for operations on the SFC diagram monitor screen shown in section 13.7.2. (Touch input)
6)	Block switching tab	Displays the block No. of the block displayed in the SFC diagram display area. Touching a tab displays the corresponding block data in the SFC diagram display area. (Tabs displayed to the right of the touched tab are removed.)
7)	Block information display area	Displays the block information of the displayed block. When the displayed block is in any status of the block information, the corresponding device is highlighted. When the block information is set, the set devices are displayed.
8)	Column No.	Displays the column numbers.
9)	Row No.	Displays the row numbers.

(Continued to next page)

No.	Item	Description
10)	SFC diagram display area	Displays a SFC program in the SFC diagram format. Step display Step No. Step Operation output sequence program*1 7 000 K6 Product counter Comment Jump destination block No. Touching a step displays the zoom window. This section (1) Zoom window) Touching a step with a jump destination block No. displays a block switching tab, and then the jump destination block data is displayed in the SFC diagram display area. Transition condition No. Transition condition No. Transition condition Transition condition sequence program*1 7 aX3 Product detection Comment Touching a transition condition displays the zoom window. (Fig. This section (1) Zoom window)
11)	Device current value display area	Displays the current values of word devices displayed in the SFC diagram display area.
12)	Message display area	Displays error messages and others.
13)	Automatic scroll status display area	Displays [Scrolling automatically] with the automatic scroll mode. Nothing is displayed without the automatic scroll mode. ([] 13.4.5 Setting automatic scroll mode)
14)	Number of active steps	Displays the number of active steps in the displayed block. Touching the item displays the active step list window. ([] 13.7.3 2 (2) Active step list window)

Operation output/transition condition sequence programs are displayed in the MELSAP-L program display mode only.





Displayed contents of SFC diagram monitor screen

(1) Display mode at first display of SFC diagram monitor screen The display mode state at the first display of the SFC diagram monitor screen differs depending on the SFC program format.

SFC program format	State at the first display
MELSAP3 format	Without MELSAP-L program display mode
MELSAP-L format	With MELSAP-L program display mode

For the display mode of SFC programs, refer to the following.

13.4.2 Setting display mode of SFC programs


(2) Comment display at first display of SFC diagram monitor screen The following shows the order of comment files to be used at the first display of the SFC diagram monitor screen after reading data from the PLC. (When the CF card has no comment file, no comment is displayed.)

Priority order	Comment files used for SFC diagram monitor screen
1	Comment files by program within the SEQCMNT folder in the CF card
2	Common comment files within the SEQCMNT folder in the CF card
3	Comment files by program within the SEQDAT folder in the CF card
4	Common comment files within the SEQDAT folder in the CF card

(1) Zoom window

The GOT can display operation output/transition condition sequence programs in the ladder format.

(a) Displayed screen



The following table shows the displayed contents.

No.	Item	Description
1)	Туре	 For displaying operation output sequence program The step number and step comment are displayed. For displaying transition condition sequence program The transition condition number and transition condition comment are displayed.
2)	Ladder program display area	Displays an operation output/transition condition sequence program. Comments and notes are displayed in the zoom comment display mode. ([] 13.7.3 2 Display menu)
3)	Keys	Keys for operations in the zoom window shown in (b). (Touch input)

Key	Function
A V	Scrolls the display area up and down by one line.
A ¥	Scrolls the display area up and down by one page.

13.7.2 Key functions

The following shows the functions of keys used for operating the SFC diagram monitor screen.

Key	Function
←Back	Returns the screen to the last screen that is displayed right before the SFC diagram monitor screen appears. The key is disabled when the last screen is the GOT utility screen or user-created monitor screen.
Sets the device test mode. Touching the key in the device test mode cancels the device test mode. () 3 13.8 Test Operation)	
Search	Displays menus used for operations on the SFC diagram monitor screen. (3.7.3 1 Search menu)
Display	Displays menus used for operations on the SFC diagram monitor screen. (13.7.3 2 Display menu)
Monitoring Mode	Displays menus used for operations on the SFC diagram monitor screen. (3 Monitoring Mode menu)
Exits the SFC monitor and returns the screen to the SFC monitor startup screen.	
Scrolls the display area up and down by one line.	
* *	Scrolls the display area up and down by one page.
4	Scrolls the display area right and left by one column.
₩ ₩	Scrolls the display area right and left by one page.

13.7.3 Menus

The following shows operations for the menus displayed on the SFC diagram monitor screen.


1 Search menu



Key	Function	Reference section
Device Search	Displays the device/contact/coil search window.	This section 1 (1)
Step No. Search	Displays the step No./transition condition No. search window.	This section 1 (2)
Transition No. Search	Displays the step No./transition condition No. search window.	This section 1 (2)
Condition Search	Displays the device/contact/coil search window.	This section 1 (1)
Coil Search	Displays the device/contact/coil search window.	This section 1 (1)
Step List	Displays the step list window.	This section 1 (3)
Block List	Displays the block list screen.	13.6

(1) Device/contact/coil search window The GOT can search for devices in a SFC program.

(a) Displayed screen



The following table shows the displayed contents.

No.	Item	Description
1)	Device input area	Set a device to be searched.
2)	Keys	Keys for operations in the device/contact/coil search window shown in (b) (Touch input)

(b) Key functions

Key	Function	
AC	Deletes all the input values and characters.	
Del	Deletes an input value or character.	
∬–9 Switches the key type to the value.		
A-Z	Switches the key type to the alphabet.	
<u>P</u>	Searches for the input device in the upward direction. When multiple blocks are set, the GOT searches for the device in descending order of the block No. When the device is found without the MELSAP-L program display mode, the GOT displays an operation output/transition condition sequence program corresponding to the step or transition condition with the device in the zoom window.	
<u>P</u>	Search for the input device in the downward direction. When multiple blocks are set, the GOT searches for the device in ascending order of the block	
Enter	No. When the device is found without the MELSAP-L program display mode, the GOT displays an operation output/transition condition sequence program corresponding to the step or transition condition with the device in the zoom window.	




Precautions for device/contact/coil search window

Searching for any bits in word devices is not available. Specify word devices for searching for any bits.

(2) Step No./transition condition No. search window The GOT can search for steps and transition conditions in a block.

(a) Displayed screen




The following table shows the displayed contents.

No.	Item	Description
1)	Block No. input area	Set the block No. of the block to be searched. The GOT searches for a step or transition condition in the set block.
2)	Step No./transition condition No. input area	Set the step No. or transition condition No. of the step or transition condition to be searched.
3)	Keys	Keys for operations in the step No./transition condition No. search window shown in (b) (Touch input)

Key Function		
◆	Moves the cursor among the input areas.	
Enter	When the cursor is in the block No. input area Moves the cursor to the step No./transition condition No. input area. When the cursor is in the step No./transition condition No. input area Searches for a step or transition condition in the set block. When the searched step or transition condition is found, the step No./transition condition No. search window closes and the GOT displays data of the step or transition condition on the SFC diagram monitor screen. (The step or transition condition is highlighted.)	
Del	Deletes an input value or character.	
AC	Deletes all the input values and characters.	

(3) Step list window
The GOT displays steps in a block.

(a) Displayed screen




The following table shows the displayed contents.

No.	Item	Description
1)	Block No.	Displays the block No. of the displayed block.
2)	Keys	Keys for operations in the step list window shown in (b) (Touch input)
3)	Step list	Displays the step numbers and step comments of the steps in the displayed block. Selecting a step searches for the step, and the GOT displays the step data on the SFC diagram monitor screen. (Active steps are highlighted.)

Key	Function
Active Step List	Displays the active step list window.
	This section 2 (2) Active step list window)
* *	Scrolls the display area up and down by one line.

2 Display menu



Key	Function	Reference section
MELSAP-L Program Display	Sets the MELSAP-L program display mode. Touching the key in the MELSAP-L program display mode cancels the MELSAP-L program display mode.	13.4.2
Comment Display in Zoom Window	Sets the zoom comment display mode. Touching the key in the zoom comment display mode cancels the zoom comment display mode.	13.4.3
Comment Change	Displays the comment file list window.	This section 2 (1)
Automatic Scroll	Sets the automatic scroll mode. Touching the key in the automatic scroll mode cancels the automatic scroll mode.	13.4.5
Active Step List	Displays the active step list window.	This section 2 (2)
Active Block List	Displays the active block list window.	This section 1 (3)
Program List	Displays the program list window.	13.5.2 (2)
PLC Read	Displays the PLC read screen.	13.5
Ladder Monitor	Starts the ladder monitor. Touching the key with a device selected can automatically search for the device with the ladder monitor.*1	Chapter 3

^{*1} For the automatic search with the ladder monitor, settings for automatically reading sequence programs are required.

For settings for automatically reading sequence programs, refer to the following.

When setting with GOT utility


GT15 User's Manual (Section 11.7 Q/QnA Ladder Monitor)

When setting with GT Designer2

GT Designer2 Version Screen Design Manual (Section 3.8 Setting of GOT Display and Operations (GOT Setup))

(1) Comment file list window
The GOT displays the comment file list.

(a) Displayed screen



The following table shows the displayed contents.


No.	Item	Description
1)	Comment file list	Among comment files stored in the CF card, the file names and titles of the comment files and common comment files used for the displayed SFC program are displayed. For switching comments, select a comment file to be used. For hiding comments, select [Do not display comments]. A selected comment file is highlighted.
2)	Keys	Keys for operations in the comment file list window shown in (b) (Touch input)

Key	Function
A V	Scrolls the display area up and down by one line.
Apply Changes	Closes the comment file list window and displays the SFC diagram monitor screen with the comments of the file selected from the comment file list.

(2) Active step list window

The GOT displays active steps in the displayed block.

(a) Displayed screen



The following table shows the displayed contents.

No.	Item	Description	
1)	Block No.	Displays the block No. of the displayed block.	
2)	Keys	Keys for operations in the active step list window shown in (b) (Touch input)	
3)	Active step list	Displays the step numbers and step comments of the active steps in the displayed block. Selecting a step searches for the step, and the GOT displays the step data on the SFC diagram monitor screen.	

(b) Key functions

Key	Function
Step List	Displays the step list window.
	This section (3) Step list window)
A V	Scrolls the display area up and down by one line.



Precautions for active step list window

When the statuses of steps change, the displayed contents of the active step list in the active step list window change. Therefore, selecting a step may be difficult depending on the frequency of the step status change.


When selecting a step is difficult, select a step from the step list in the step list window.

This section (3) Step list window

(3) Active block list window

The GOT displays active blocks in the read SFC program.

(a) Displayed screen



The following table shows the displayed contents.

No.	Item	Description
1)	Keys	Keys for operations in the active block list window shown in (b) (Touch input)
2)	Active block list	Displays the block numbers and block titles of active blocks in the read SFC program. Selecting a block displays the block data on the SFC diagram monitor screen.

(b) Key functions

Key	Function
Block List	Displays the block list screen.
	(13.6 How to Operate Block List Screen)
* *	Scrolls the display area up and down by one line.



Precautions for active block list window

When the statuses of blocks change, the displayed contents of the active block list in the active block list window change. Therefore, selecting a block may be difficult depending on the frequency of the block status change.

When selecting a block is difficult, select a block from the block list on the block list screen.

13.6 How to Operate Block List Screen

3 Monitoring Mode menu



Key	Function	Reference section
16-bit integer (DEC)	Displays the device values in the device current value display area as 16-bit decimal numbers.	13.4.4
16-bit integer (HEX)	Displays the device values in the device current value display area as 16-bit hexadecimal numbers.	13.4.4
32-bit integer (DEC)	Displays the device values in the device current value display area as 32-bit decimal numbers.	13.4.4
32-bit integer (HEX)	Displays the device values in the device current value display area as 32-bit hexadecimal numbers.	13.4.4
32-bit real number	Displays the device values in the device current value display area as 32-bit floating-point numbers with the exponential representation.	13.4.4

13.8 Test Operation

In the device test mode of the SFC monitor, device values can be changed on the screen. For setting the device test mode, refer to the following.

13.6.2 Key functions 13.7.2 Key functions

The test operation of devices is available by touching devices on the following screens in the device test mode.

Screen applicable to device test mode	Reference section
Block information list on the block list screen	13.6.1
SFC diagram display area on the SFC diagram monitor screen	13.7.1
Device current value display area on the SFC diagram monitor screen	
Ladder program display area in the zoom window	13.7.1 1 (1)


Touching a device displays the device test window.

- When touching bit devices
 A bit device is switched between ON and OFF states in the device test window.
- (2) When touching word devices

 The GOT writes the value input in the device test window into the selected word device.

1 How to operate device test window

- (1) Bit devices
 - (a) Displayed screen




The following table shows the displayed contents.

No.	Item	Description
1)	Device	Displays the selected device.
2)	Keys	Keys for operations in the device test window shown in (b).

Key	Function
ON	Turns on the bit device and writes the device state to the PLC CPU.
0FF	Turns off the bit device and writes the device state to the PLC CPU.

(2) Word devices

(a) Displayed screen



The following table shows the displayed contents.

No.	Item	Description			
1)	Device	Displays the selected device.			
2)	Device value input area	Set the value to be written into the selected device.			
3)	Input mode Displays the current input mode. (DEC: decimal number. HEX: hexadecimal number)				
4)	Keys	Keys for operations in the device test window shown in (b).			

Key	Function			
×	Closes the device test window.			
DEC/HEX	Switches the input modes. (DEC, HEX)			
Enter	Writes the value input in the device value input area into the PLC CPU.			
Del	Deletes an input value or character.			
AC	Deletes all the input values and characters.			

13.9 Error Messages and Corrective Action

The following shows the error messages for the SFC monitor and the corrective actions.

Error message	Description	Corrective action		
Failed to write the value to the device.	In the device test mode, the GOT fails to write the value into the device of the PLC CPU.	 (1) Check the communications between the GOT and PLC CPU, and make sure that the GOT communicates with the PLC CPU. (2) Check if the target device is writable with prameters of the target PLC CPU. 		
Failed to communicate with CPU.	The GOT cannot communicate with the target PLC CPU.	Check the communications between the GOT and PLC CPU, and make sure that the GOT communicates with the PLC CPU.		
File access error. Confirm the CF card.	A file access error occurs.	 (1) When no CF card is installed, install a CF card. (2) When the CF card access switch is off, turn on the switch. (3) Check if the CF card is formatted with FAT16. When the CF card is not formatted with FAT16, format the CF card with FAT16 and install the card in the GOT. 		
Failed to get the information of CPU because of bad connection.	The GOT fails to collect data from the PLC CPU.	Check the communications between the GOT and PLC CPU, and make sure that the GOT communicates with the PLC CPU.		
Failed to save files because of an insufficient capacity of CF card.	The CF card has insufficient space for storing files.	(1) Delete files in the CF card.(2) Install a large capacity CF card.		
The file(file name) is broken. The file is unselected.	The file read from the CF card is broken.	(1) Do not select broken files.(2) Overwrite the broken file with the unbroken file.		
Failed to write (file name) to CF card.	The GOT fails to write the file into the CF card.	 (1) When no CF card is installed, install a CF card. (2) When the CF card access switch is off, turn on the switch. (3) Check if folders and files within the SEQDAT folder in the CF card are writable. When the folders and files are not writable, make sure that the folders and files are writable. (4) Check if the CF card is formatted with FAT16. When the CF card is not formatted with FAT16, format the CF card with FAT16 and install the card in the GOT. 		
Change the Data save location of Q/QnA ladder monitor to A: or B: The SFC monitor is started with [Data save location] is set to a drive other than [A: Built-in CF card] and [B:Memory card] in the MELSEC-Q/QnA ladder monitor setting.		Set [Data save location] to [A: Built-in CF card] or [B:Memory card] in the MELSEC-Q/QnA ladder monitor setting of the GOT utility.		
The ladder block is too big to display.	The GOT cannot display a sequence program in the zoom window because the program has a ladder block with 25 or more lines.	Split the ladder block.		
The specified block does not exist. Confirm the program. The GOT cannot display the specified block data in the SFC diagram because the specified block does not exist.		Correct the program with GX Developer and operate the GOT for reading the file from the PLC.		

(Continued to next page)

Error message	Description	Corrective action		
The file(file name) is broken. Perform PLC Read and read the file again.	The GOT cannot display the program file data on the block list screen or SFC diagram monitor screen because the program file is broken.	Operate the GOT for reading the file from the PLC.		
The device range has been changed. Please read the file again.	The GOT cannot read the target device values of the SFC monitor because the device range is changed in the PLC parameter setting during the SFC monitor.	Operate the GOT for reading the file from the PLC.		
Cannot read programs other than SFC program.	The program file specified by a key on the block list screen or the SFC diagram monitor screen is not a SFC program.	Specify a SFC program by a key on the block list screen or the SFC diagram monitor screen.		

14. LADDER EDITOR












14.1 Features

With the ladder editor function, the GOT can monitor and edit a sequence program in the ladder diagram format of a controller, and changing current device values of the program is available. The features of the ladder editor are shown below.

Editing sequence programs by using the GOT Editing sequence programs in the ladder diagram format is available.



The following screens are displayed with the ladder editor function.

- PLC read screen (14.5 How to Operate PLC Read Screen)
- Ladder monitor screen (14.6 How to Operate Ladder Monitor Screen)
- Ladder editor screen (14.7 How to Operate Ladder Editor Screen)

2 Switching display formats, device comment display, and languages

The following are available.

- Switching the display formats of device values
- · Switching whether to display or hide device comments
- Switching languages for file names of sequence programs, comments, and others
- (1) Switching display formats

On the Ladder monitor screen, the display formats for the current values of word devices can be switched between decimal and hexadecimal numbers.

(2) Switching device comment display Whether to display or hide device comments used in sequence programs can be switched.


(3) Switching languages

File titles and comments can be displayed in the language set for the language switching in the GOT utility with comment files created with the SJIS code, KS code, GB code, and/or ASCII code. With a CF card storing comment files created with the SJIS code, KS code, GB code, and/or ASCII code, comments can be displayed in the language corresponding to any character code in the CF card, regardless of the language set in the GOT utility.

3 Displaying registered ladder blocks is available

On the Ladder registration monitor window, displaying registered ladder blocks is available.

(14.6.3 Menus)



14.2 Specifications

14.2.1 System configuration

This section describes the system configuration for the ladder editor function.

For connection type settings, and precautions on the communication unit/cable and connection type, refer to the following manual.

GOT1000 Series Connection Manual

1 Target controller

Controller	
QCPU*1	
CNC (C70)	

*1 Excluding the Q02PHCPU, Q06PHCPU, Q12PHCPU, Q25PHCPU, Q12PRHCPU, Q25PHCPU, Q25PHCPU, Q12PRHCPU, Q25PRHCPU, Q00UJCPU, Q00UCPU, Q01UCPU, Q10UD(E)HCPU, and Q20UD(E)HCPU For creating a multiple CPU system with the Q00CPU, Q01CPU, Q02CPU, Q02HCPU, Q06HCPU, Q12HCPU, and/or Q25HCPU, use CPUs with the function version B or later.

2 Connection type

(O: Available, x: Unavailable)

Function		Connection form between GOT and controller								
Name	Description	Bus Direct CPU connection	Computer link connection	Ethernet connection	MELSECNET/H connection, MELSECNET/10 connection*1	CC- Link IE ^{*2}	CC-Link connection		GOT multidrop	
							ID*3	G4 ^{*4}	connection	
Ladder editor	Monitors and edits a sequence program in the ladder diagram format in a controller, or changes current device values of the program.	0	0	0	0	0	0	0	0	×

- *1 For the MELSECNET/10 connection, use a QCPU and network module (QJ71LP21, QJ71LP21-25, QJ71LP21S-25, QJ71LP21G, and QJ71BR11) with the function version B or later.
- *2 Indicates the CC-Link IE controller network connection.
- *3 Indicates CC-Link connection (Intelligent device station).
- *4 Indicates CC-Link connection (via G4).
- *5 With the Q00JCPU, the bus extension connector box (A9GT-QCNB) can be connected to an extension base unit only. (The bus extension connector box cannot be connected to a main base unit.)

Required extended function OS, option OS, and option function board

The following extended function OS, option OS, and option function board are required.

	OS memory space (user area)				Option function board		
Category	GT						
Guidgoly	Built-in flash memory (ROM)	User memory (RAM)	GT15 ^{*1}	GT16	GT15 ^{*1}		
GOT Platform Library	77KB	200KB	100KB		GT15-QFNB16M,		
Ladder editor	2567KB	8192KB	5121KB	Not required	GT15-QFNB32M,		
GOT Function Expansion Library	4729KB	19381KB	4729KB		GT15-QFNB48M, GT15-MESB48M		

*1 For using the ladder editor function, a capacity of 9949KB or more is required in the user area of the specified drive for installing the extended function OS and option OS.

A total memory capacity of 21212KB is required for using the ladder editor function.

For using the ladder editor function, set the OS boot drive to [A: Standard CF Card] and mount an option function board with 16MB or more memory on the GOT.

For setting the OS boot drive, refer to the following.

GT Designer2 Version

Basic Operation/Data Transfer Manual (Chapter 8 TRANSFERRING DATA)

(1) Extended function OS and option OS

Install the above extended OS and option OS on the GOT.

For how to install the operating systems, refer to the following manual.

☐ GT Designer2 Version ☐ Basic Operation/Data Transfer Manual (Chapter 8. TRANSFERRING DATA)

(2) OS memory space

For installing the extended function OS and option OS, the available space shown in the above table is required in the user area.

For checking the available space in the user area and the data that uses other user areas, refer to the following manual.

GT Designer2 Version ☐ Basic Operation/Data Transfer Manual (Chapter 8. TRANSFERRING DATA)

- (3) Option function board
 - (a) For GT16

No option function board is required.

(b) For GT15

Mount one of the option function boards in the above table on the GOT. For the GOTs with a built-in option function board, refer to the following.

1.1.2 Hardware and OS' required for each function

For how to mount an option function board on the GOT, refer to the following manual.

GT15 User's Manual (8.10 Option Function Board)

4 Required hardware

The following hardware is required.

Hardware	
CF card	

14.2.2 Devices and range that can be monitored

(O: Possible, x: Impossible)

				I	
Device ^{*1}	Device range	Program display	Device monitor display	Search operation	
Input	X0 to 1FFF, DX0 to FFF	0	0	0	
Output	Y0 to 1FFF, DY0 to FFF	0	0	0	
Internal relay*1	M0 to 8191 to 61439	0	0	0	
Latch relay	L0 to 8191	0	0	0	
Link relay*2	B0 to 1FFF to EFFF	0	0	0	
Timer	T0 to 2047	0	0	0	
Retentive timer	ST0 to 2047	0	0	0	
Counter	C0 to 1023	0	0	0	
Data register	D0 to 12287	0	0	0	
Link register	W0 to 1FFF	0	0	0	
Annunciator	F0 to 2047	0	0	0	
Edge relay	V0 to 2047	0	×	0	
	R0 to 32767	0	0	0	
File register	ZR0 to 32767	0	0	0	
	ZR32768 to 1042431	0	0	0	
Extended data register	ZR32768 to 4184063	0	0	0	
Exterioed data register	D0 to 32767	0	0	0	
Extension file register	D32768 to 4212223	0	0	0	
Extension life register	W0 to 7FFF	0	0	0	
Link special relay	W8000 to W4045FF	0	0	0	
Link special register	SB0 to 7FF	0	0	0	
Step relay	SW0 to 7FF	0	0	0	
Index register*4	Z0 to 19 Z0 to 15	0	0	0	
Special relay	SM0 to 2047	0	0	0	
Special register	SD0 to 2047	0	0	0	
Function input	FX0 to F	0	×	0	
Function output	FY0 to F	0	×	0	
Function register	FD0 to 4	0	×	0	
Link direct device	J_	0	×	×	
Module access device	J\ U3En\	0	×	×	
Nesting	N0 to 14	0	×	×	
Pointer	P0 to 4095	0	×	×	
Interrupt pointer	I0 to 255	0	×	×	
SFC block device	BL0 to 319	0	×	0	
SFC transition device	TR0 to 511, BL□\TR□	0	×	0	
Network No. specification device	J0 to 255	0	×	×	
I/O No. specification device	U0 to 1FF 3E0 to 3	0	×	×	
Macro instruction argument device	VD0 to	0	×	×	

^{*1} The GOT can monitor local devices. For applicable devices and device ranges, refer to manual of the PLC CPU.

^{*2} The extended data register and extended link register are applicable to Universal model QCPU only.

14.2.3 Access range

The access range is the same as the access range when the GOT is connected to a controller. Refer to the following manual for details of the access range.

GT Designer2 Version ☐ Screen Design Manual (2.7 Controllers that can be monitored and the Access Range)

14.2.4 Precautions

(1) Inapplicable GOT

The ladder editor cannot be used with the GT1555-V, GT1555-Q, and GT1550-Q.

(2) Precautions for operations during SFC monitor startup

Do not operate the following with the GOT during the ladder editor startup.

Doing so may delete stored data and cause the ladder editor function to operate incorrectly.

- · Turning on or off the CF card access switch
- · Inserting or removing a CF card
- (3) Backup

Before editing the program with the ladder editor function, backup the program with the backup/restore function to restore an original sequence program.

(F) 11. BACKUP/RESTORE)

- (4) Precautions for setting [Locus] for line graphs (For GT15)
 For GT15, the ladder editor function is not available when [Locus] is set for line graphs.
 For using the ladder editor function with GT15, do not set [Locus] for line graphs.
- (5) Writing a sequence program into the PLC CPU during the RUN status
 While the PLC CPU is running in operation, the GOT cannot writes the program into the PLC CPU.
 Set the PLC CPU to the STOP status, and write the program into the PLC CPU.

(3 14.7.3 4 Online menu)

(6) Instructions that cannot be displayed or edited by using the ladder editor function For the ladder editor function, ladder blocks that use the following instructions cannot be displayed or edited.

When the following instructions are input during editing, an error message is displayed and the instructions cannot be input.

The program with the following instructions cannot be written into the PLC CPU.

	Objet in America	n-bit shift of n-bit data	SFTBR(P), SFTBL(P)	
Sequence instruction	Shift instruction	n-words shift of n- words data	SFTWR(P), SFTWL(P)	
	Contact instruction	Contact	LDPI, LDFI, ANDPI, ANDFI, ORPI, ORFI	
	Comparison operation instruction	BIN 32-bit block data comparisons	DBKCMP=(P), DBKCMP<>(P), DBKCMP>=(P), DBKCMP>=(P), DBKCMP<(P), DBKCMP<=(P)	
Basic instruction	Arithmetic operation instruction	BIN 32-bit data block addition and subtraction operations	DBK+(P), DBK-(P)	
	Data transfer instruction	Identical 32-bit data block transfers	DFMOV(P)	
	Data processing instruction	Calculation of averages	MEAN(P), DMEAN(P)	
	Special function	Exponentiation operation	POW(P), POWD(P)	
	instruction	Common logarithm operation	LOG10(P), LOG10D(P)	
Application	Data control	Scaling (point-by- point coordinate data)	SCL(P), DSCL(P)	
instruction	Instruction	Scaling (X or Y coordinate data)	SCL2(P), DSCL2(P)	
		Date comparison	LDDT=, ANDDT=, ORDT=, LDDT<>, ANDDT<>, ORDT<>, LDDT>, ANDDT>, ORDT>, LDDT>=, ANDDT>=, ORDT>=, LDDT<, ANDDT<, ORDT<,	
	Clock instruction	Clock comparison	LDTM<=, ANDTM<=, ORTM<, LDTM=, ANDTM=, ORTM=, LDTM<>, ANDTM<>, ORTM<>, LDTM>, ANDTM>, ORTM>, LDTM<=, ANDTM<=, ORTM<=, LDTM>, ANDTM<, ORTM<, LDTM>=, ANDTM>=, ORTM>=,	
QCPU instruction	Select refresh instruction		CCOM(P)	


14.3 Display Operation


This section describes procedures for displaying a sequence program after turing on the GOT.

14.3.1 Outline before starting

1 Operations before displaying

The following describes the outline for displaying the ladder editor operation screens after installing GOT Platform Library (extended function OS), Ladder editor (option OS), and GOT Function Expansion Library (option OS) on the GOT.





Point P

(1) How to display the utility

For how to display the utility, refer to the following.

GT16 User's manual (Basic Utility) (1.3 Utility Display)

GT15 User's manual (9.3 Utility Display)


(2) Reading data from PLC when reclosing GOT

Reading data from the PLC is not required when reclosing the GOT power, because sequence programs and comment files are stored in a CF card for the ladder editor function.

(314.3.2 Setting ladder data storage location)


2 Changing screens

The following describes how to change the screen.



From previous page





14.3.2 Setting ladder data storage location

1 Setting ladder data storage location

Ladder data (sequence programs and device comments) for the ladder editor function are stored in the storage location that stores ladder data for the Q/QnA ladder monitor. Only the A drive (standard CF card) or B drive (extended memory card) is available for storing ladder data.

For setting the storage location for ladder data, refer to the following manuals.

When setting with GOT utility

GT16 User's Manual (Basic Utility) (Section 4.2.1 Q/L/QnA ladder monitor setting)

GT15 User's Manual (Section 11.7 Q/QnQ Ladder Monitor)

When setting with GT Designer2

GT Designer2 Version ☐ Screen Design Manual (Section 3.8 Setting of GOT Display and Operations (GOT Setup))

14.3.3 Reading comment files from CF card

The ladder editor function uses comment files stored in a CF card installed in the GOT.

- Procedure for using comment files stored in CF cards

 The following shows the procedure for using a comment file stored in a CF card.
 - (1) When displaying comments in language set for language switching of GOT utility Store comment files in a CF card on the PLC read screen. For how to store comment files in a CF card on the PLC read screen, refer to the following.

14.5 How to Operate PLC Read Screen

(2) When displaying comments in any language regardless of language set for language switching of GOT utility



Oreate a SEQCMNT folder in a CF card. When the SEQCMNT folder already exists, creating a new SEQCMNT folder is not required.





In the SEQCMNT folder, create folders for CH No., network No., station No., and CPU No. of the monitored controller with a hierarchy as shown left.

Item	Folder name
CH No.	CH**
Network No.	NET***
Station No.	ST***
CPU No.	CPU**

Assign numbers to "*" marks. (When the CH No. is 1, the folder name is CH01. When the monitor target is the host station, the folder name is ST255.)

(Continued to next page)







(Example: Storing comment files with ASCII code in the ASCII folder.)

3 In the CPU No. folder, create folders for storing comment files by character code.

Item	Folder name
Folder for SJIS code	SJIS
Folder for KS code	KS
Folder for GB code	GB
Folder for ASCII code	ASCII

Copy a comment file (.wcd) from the project data of GX Developer.

5 Store the copied comment files in the folders for each character code in the CF card.

Comment character code	Storage folder name
SJIS code	SJIS
KS code	KS
GB code	GB
ASCII code	ASCII

- 6 Install the CF card with the comment file on the GOT.
- Switch comment files on the Ladder monitor screen for displaying the comments in appropriate language.

14.4 Setting Display Format

The display format of word device values displayed on screens for the ladder editor function, language, the display mode of sequence programs, and others can be set.

14.4.1 Switching languages of sequence programs

Languages (Japanese, Korean, or Simplified Chinese) of comments to be displayed on screens for the ladder editor function can be switched when monitoring.

For switching languages, comment files in the language to be displayed must be created in advance.

(3 14.3.3 Reading comment files from CF card)

The following shows the relations between the language selected in the GOT utility and comment files with each character code.

Language	Comment file
Japanese	Comment files with SJIS code
Korean	Comment files with KS code
Simplified Chinese	Comment files with GB code
Other than the above	Comment files with ASCII code

14.4.2 Switching comment display mode

Whether to display or hide comments, notes, and local devices in the Ladder monitor screen and Ladder editor screen can be set.

14.4.3 Switching display formats between decimal and hexadecimal numbers

The display formats of word device values on the Ladder monitor screen can be switched between decimal and hexadecimal numbers.

(Monitoring Mode menu)


14.5 How to Operate PLC Read Screen

On the PLC read screen, the GOT reads sequence programs and comment files used for the ladder editor function from the PLC.

The following describes how to operate the PLC read screen.

14.5.1 Displayed contents

The following describes the configuration of the PLC read screen displayed after the ladder editor starts and key functions on the screen.




No.	Item	Description
1)	PLC name	Displays the label set in the PLC name setting for the target PLC CPU.
2)	Target controller	Displays CH No., network No., station No., and CPU No. of the target PLC CPU.
3)	Keys	Keys for operations on the PLC read screen shown in section 14.5.2. (Touch input)
4)	Target drive list (target controller)	Displays the target PLC CPU model and the drives in a list. Selecting a drive displays files within the drive in the file list (target controller). For the drive that stores files selected in the file list (target controller), [*] is displayed to the left of the drive name.
5)	File list (target controller)	Displays the program types, file names, titles, sizes, dates, and times of all the files within the drive selected in the target drive list (target controller). (The date and time show those of updated files.) A file to be read can be selected from the file list. (The selected file is highlighted.) For program files, only sequence program files in the program memory can be selected. For selecting the file name selected in the file list (GOT), the file selection in the file list (GOT) is canceled. When a password is set for the selected file, the password input window appears.

(Continued to next page)

No.	Item	Description
6)	Target drive list (GOT)	Displays the drive set for [Data save location] in the MELSEC-Q/QnA ladder monitor settings. (For the ladder editor function, only the A drive (standard CF card) or B drive (extended memory card) is available.) For the drive that stores files displayed in the file list (GOT), [*] is displayed to the left of the drive name.
7)	File list (GOT)	Displays the program types, file names, titles, sizes, dates, and times of all the files within the drive selected in the target drive list (GOT). (The date and time show those of updated files.) A file to be read can be selected from the file list. (The selected file is highlighted.) For selecting the file name selected in the file list (target controller), the file selection in the file list (target controller) is canceled.
8)	Total file size	Displays the total data size of files selected in the file list (target controller) and file list (GOT).
9)	Number of selected files	Displays the total number of files selected in the file list (target controller) and file list (GOT).
10)	Message display area	Displays error messages and others.

(1) Password input window

(a) Displayed screen



The following table shows the displayed contents.

No.	Item	Description
1)	Password type	Displays the type of the password to be input. (Program password/Comment password)
2)	Password input area	Set the password.
3)	File name	Displays the file name.
4)	Keys	Keys for operations in the password input window shown in (b) (Touch input)

No.	Description
×	Closes the password input window and cancels the password input operation.
0-9	Switches the key type to the value.
A-Z	Switches the key type to the alphabet (uppercase).
a-z	Switches the key type to the alphabet (lowercase).
AC	Deletes all the input values and characters.
Del	Deletes an input value or character.
Enter	Verifies the password set in the password input area. When the password verification for the first file is successful, the password verification for the other files is automatically executed with the same password.


14.5.2 Key functions

The following shows the functions of the keys used for operating the PLC read screen.

Key	Function
←Back	Returns the screen to the last screen that is displayed right before the PLC read screen appears. The key is disabled when the last screen is the GOT utility screen or user-created monitor screen.
Select CPU	Displays the communication setting window. (This section (1) Communication setting window)
×	Exits the ladder editor and returns the screen to the ladder editor startup screen.
▲ ▼	Scrolls the display area up and down by one line.
* ¥	Scrolls the display area up and down by one page.
Recommend	Available when program files are displayed in the target drive list (target controller). Touching the key selects all the sequence program files, common comment files, and comment files for the selected sequence program files in the file list (target controller). When files with the same name are displayed in the file list (target controller) and file list (GOT), touching the key selects a file as shown below. • For sequence program files When the updated dates and times differ between the files, touching the key selects the file in the file list (target controller). When the updated dates and times are the same between the files, touching the key selects the file in the file list (GOT). • For comment files When the updated dates and times differ between the files, touching the key selects the latest file. When the updated dates and times are the same between the files, touching the key selects the file in the file list (GOT).
Proceed	Writes the file selected in the file list (target controller) into the CF card displayed in the target drive list (GOT). The file written into the CF card on the PLC read screen is stored in the SEQDAT folder. After writing, among files other than comment files in the CF card, files that are not selected in the file list (GOT) are deleted. Then, the program list window appears. (CF) This section (2) Program list window)

(1) Communication setting window

(a) Displayed screen



The following table shows the displayed contents.


No.	Item	Description
1)	CH No. input area	Set the CH No. for the target controller.
2)	Network No. input area	Set the network No. for the target controller.
3)	Station No. input area	Set the station No. of the target controller. When the station No. is set to the host station (FF), set the network No. to 0.
4)	CPU No. input area	Set the CPU No.
5)	CH No. selection key	Select a CH No.
6)	Keys	Keys for operations in the communication setting window shown in (b). (Touch input)

Key	Function	
×	Closes the communication setting window. When any of the CH No., network No., station No., and CPU No. is not input and the monitor target is not set, the communication setting window does not close.	
Moves the cursor among the input areas.		
AC	Deletes all the input values and characters.	
Del	Deletes an input value or character.	
Enter	Moves the cursor when the cursor is in the CH No. input area, network No. input area, or station No. input area. When the cursor is in the CPU No. input area and settings for the CH No., network No., and station No. are completed, the communication setting window closes and the PLC read screen appears.	

(2) Program list window

Displaying the read sequence programs in a list is available.

(a) Displayed screen



The following table shows the displayed contents.

No.	Item	Description
1)	Sequence program file list	Displays the file names and execution statuses of the read sequence programs. The execution statuses show execution types set for the programs. A touched sequence program file is highlighted.
2)	Keys	Keys for operations in the program list window shown in (b). (Touch input)


Key	Function	
×	Closes the Program List window.	
- ▼	Scrolls the display area up and down by one line.	
Display	Displays the sequence program file selected in the sequence program file list on the Ladder monitor screen. ([] 14.6 How to Operate Ladder Monitor Screen)	

14.6 How to Operate Ladder Monitor Screen

On the Ladder monitor screen, the GOT displays the read sequence program. The following describes how to operate the Ladder monitor screen.

14.6.1 Displayed contents

The following describes the configuration of the Ladder monitor screen, menus and key functions on the screen.



No.	Item	Description
1)	PLC name	Displays the label set in the PLC name setting for the target PLC CPU.
2)	Target controller	Displays the CH No., network No., station No., and CPU No of the target PLC CPU as shown below. • CH No. network Nostation No./CPU No.
3)	Program name	Displays the file name of the displayed sequence program.
4)	Number of steps	Displays the number of steps for the displayed sequence program.
5)	Keys	Keys operations for the Ladder monitor screen shown in 14.6.2. (Touch input)
6)	Ladder display area	Displays the read sequence program. The following shows the conductive status Non-conductive status Contact Coil Y10 Instruction*1 — SET MO When contacts, coils, and outputs are the selection status, touching the area displays the device search window. (2) Device search window) Displaying the first step number When the Ladder registration monitor window is opened, the first step number of registerable ladder blocks is highlighted. Touching the area registers the specified ladder block in the window. (1) Ladder registration monitor window)
7)	Current device value display area	Displays the current value of the displayed word device.
8)	Message display area	Displays error messages and others.

¹ The conductive status of the following instructions is displayed only on the screen. SET, RST, PLS, PLF, SFT, SFTP, FF, DELTA, DELTAP, MC

14.6.2 Key functions

The following shows the functions of the keys used for operating the Ladder monitor screen.

Key	Function	
Returns the screen to the last screen that is displayed right before the Ladder monitor screen appear. The key is disabled when the last screen is the GOT utility screen or user-created monitor screen.		
Edit	Displays the Edit menu. Touching [Start editing] displays the Ladder editor screen.	
	14.7 How to Operate Ladder Editor Screen)	
	Sets the device test mode.	
Device test	Touching the key in the device test mode cancels the device test mode.	
	(Fig. 14.8 Test Operation)	
F1 1	Displays the Find menu.	
Find	([14.6.3 2 Find menu)	
	Displays the Display menu.	
Display 	([] 14.6.3 3 Display menu)	
▲ ▼	Scrolls the display area up and down by one line.	
1 ¥	Scrolls the display area up and down by one page.	

14.6.3 Menus

The following shows operations for the menus displayed on the Ladder monitor screen.

1 Edit menu



Key	Function	Reference section
Start editing	Switches to the Ladder editor screen.	14.7

2 Find menu



Key	Function	Reference section
Jump	Displays the jump window.	14.7.3 2 (1)
Find device	Displays the device search window.	14.7.3 2 (2)
Find contact	Displays the device search window	14.7.3 2 (2)
Find coil	Displays the device search window	14.7.3 2 (2)

3 Display menu



Key	Key Function	
Comment	Sets the comment display mode. Touching the key in the comment display mode cancels the comment display mode.	14.4.2
Comment change	Displays the comment file list window.	14.7.3 3 (1)
Ladder registration monitor	Displays the Ladder registration monitor window.	This section 3 (1)
Delete all registered ladder	Deletes all registered ladder blocks in the Ladder registration monitor window.	This section 3 (1)
Program list	Displays the program list window	14.5.2 (2)
PLC read	Displays the PLC read screen.	14.5

(1) Ladder registration monitor window
Displaying or deleting the registered ladder blocks is available.

(a) Displayed screen



The following table shows the displayed contents.

No.	Item	Description
1)	Ladder display area	A ladder block selected on the Ladder monitor screen is added as the last registered ladder block on the Ladder registration monitor window. Touching the first step number displays the dialog box to delete the ladder block.
2)	Keys	Keys for operations in the Ladder registration monitor window shown in (b). (Touch input)

Item	Description
×	Closes the Ladder registration monitor window.
▲ ▼	Scrolls the display area up and down by one line.
1 ¥	Scrolls the display area up and down by one page.
4 F	Scrolls the display area right and left by one column.
₩ >>	Scrolls the display area right and left by one page.

4 Monitoring Mode menu



Key	Function	Reference section
16-bit integer (DEC)	Displays the device values in the device current value display area as 16-bit decimal numbers.	-
16-bit integer (HEX)	Displays the device values in the device current value display area as 16-bit hexadecimal numbers.	-
32-bit integer (DEC)	Displays the device values in the device current value display area as 32-bit decimal numbers.	-
32-bit integer (HEX)	Displays the device values in the device current value display area as 32-bit hexadecimal numbers.	-
32-bit real number	Displays the device values in the device current value display area as 32-bit floating-point numbers with the exponential representation.	-
Local device monitor	Displays local devices monitored by the GOT.	This section (1)

(1) Monitoring local devices

- (a) When the GOT monitors local devices, the scan time increases.
- (b) When local devices are displayed on the screen, touching the Local device monitor key cancels the display of local devices.
- (c) When the Ladder monitor screen is switched to other screen, or the displayed program is switched to other program, the GOT cancels the display of local devices.

14.7 How to Operate Ladder Editor Screen


On the Ladder editor screen, editing sequence programs, finding devices, and displaying comments are available.

The following describes how to operate the Ladder editor screen.

14.7.1 Displayed contents


1 Ladder editor screen

The following describes the configuration of the Ladder editor screen, menus and key functions on the screen.



No.	Item	Description
1)	PLC name	Displays the label set in the PLC name setting for the target PLC CPU.
2)	Target controller	Displays the CH No., network No., station No., and CPU No. of the target PLC CPU as shown below. • CH No. network Nostation No./CPU No.
3)	Drive name	Displays the drive of the controller for the displayed sequence program.
4)	Program name	Displays the file name of the displayed program.
5)	Number of steps	Displays the number of steps for the displayed sequence program.
6)	Keys	Keys for operations for the Ladder editor screen shown in 14.7.2. (Touch input)
7)	Ladder display area	Displays the read sequence program. • Touching a contact, coil, output, and statement highlights the touched position, and displays the Enter ladder program window. ([]] This section (1) Enter ladder program window) • Displaying notes Selecting the comment from the Display menu displays notes. • Displaying the first step number Displays the first step number of ladder blocks. Touching the first step number of ladder blocks highlights the touched position, and displays the Enter ladder program window. ([]] This section (1) Enter ladder program window)
8)	Message display area	Displays error messages and others.

(1) Enter ladder program window Editing sequence programs is available.



(a) Displayed contents

No.	Item	Description
1)	Ladder symbol display area	Displays the ladder symbol selected in the ladder display area.
2)	Text display area	Displays the device or the sequence program selected in the ladder display area.
3)	Keys	Keys for operations in the Enter ladder program window shown in (b). (Touch input)

Key	Function
×	Closes the Enter ladder program window. The displayed contents are not reflected.
41	Touch the key to input a normally open contact.
	Touch the key to input a normally closed contact.
-↑ }	Touch the key to input a leading edge pulse.
-41-	Touch the key to input a trailing edge pulse.
+	Touch the key to input a conversion of operation result to leading edge pulse.
+	Touch the key to input a conversion of operation result to trailing edge pulse.
< >	Touch the key to input a coil.
{ }	Touch the key to input an application instruction.
	Touch the key to input a vertical line.
X	Touch the key to delete a vertical line.

Key	Function
	Touch the key to input a horizontal line.
×	Touch the key to delete a ladder.
Insert row	Inserts one row in the specified position.
Delete row	Deletes the specified row.
Insert column	Inserts one column in the specified position.
Delete column	Deletes the specified column.
ENT	Reflects the displayed contents, and closes the Enter ladder program window.
	Reduces the size of the Enter ladder program window.
_	Changes the Enter ladder program window from the reduced size to the default size.
Cap	Switches the alphabetic characters between the uppercase and the lowercase.


CNC MONITOR FUNCTION

14

(c) Inputting or deleting ladders

· Inputting contacts or instructions

(Operation example: Inputting a contact (X0))






Touch a position to input a contact (X0).

The Enter ladder program window appears.











The contact (X0) is input.


• Deleting contacts or instructions (Operation example: Deleting a contact (X0))








2 The Enter ladder program window appears.




- Touch the key.


 Touch the end position of the contact (X0).
- 4 The contact (X0) is deleted.


• Inputting vertical lines or horizontal lines (Operation example: Inputting a vertical line)












- 3 Touch the key.

 Touch the end position to input the vertical line.
- 4 The vertical line is input.


• Deleting vertical lines or horizontal lines (Operation example: Deleting a vertical line)



1 Touch a position to delete a vertical line.



2 The Enter ladder program window appears.




3 Touch key.

Touch the end position to delete the vertical line.




4 The vertical line is deleted.

• Inputting rows and columns (Operation example: Inputting a row)








Touch a position to insert a row.

2 The Enter ladder program window appears.

3 Touch the Insert row key.

The Enter ladder program window is closed, and the row is inserted.

• Deleting rows and columns (Operation example: Deleting a row)



- Touch a position to delete a row.
- 2 The Enter ladder program window appears.

3 Touch the Delete row key.

The Enter ladder program window is closed, and the row is deleted.

14.7.2 Key functions


The following shows the functions of keys used for operating the Ladder editor screen.

Key	Function
←Back	Returns the screen to the last screen that is displayed right before the Ladder editor screen appears. The key is disabled when the last screen is the GOT utility screen or user-created monitor screen.
Edit	Displays the Edit menu. ([
Find/Replace	Displays the Find/Replace menu. When the Find/Replace menu is displayed, touching the key closes the menu. (Find/Replace menu)
Convert	Converts the editing program to the execution program.
Display	Displays the Display menu. ([] 14.7.3 3 Display menu)
Online Displays the Online menu. ([14.7.3 4 Online menu)	
Exits the Ladder editor screen and returns the screen to the ladder editor startup screen.	
A V	Scrolls the display area up and down by one line.
Scrolls the display area up and down by one page.	

14.7.3 Menus

The following shows operations for the menus displayed on the Ladder editor screen.

1 Edit menu




Key	Function
Undo	Undoes the last edit operation. If the edited contents are converted, the contents cannot be undone.
Check program	Executes the program check to check if programs have consistency or double coils do not exist.

2 Find/Replace menu

Find/Replace		
Jump		
Find device		
Find contact		
Find coil		
Replace device		
Change open/close cantact		

Key	Function	Reference section
Jump	Displays the jump window.	This section 2 (1)
Find device	Displays the device search window.	This section 2 (2)
Find contact	Displays the device search window	This section 2 (2)
Find coil	Displays the device search window	This section 2 (2)
Replace device	Displays the replace device window.	This section 2 (3)
Change open/close cantact	Displays the change open/close contact window.	This section 2 (4)

(1) Jump window



(a) Displayed contents

No.	Item	Description
1)	Jump destination step number input area	Displays the input step number.
2)	Keys	Keys for operations in the jump window shown in (b). (Touch input)

Key	Function
×	Closes the jump window.
Enter	Displays a row that includes the input step number on the center of the ladder display area.
Del	Deletes an input value or character.
AC	Deletes all the input values and characters.

(2) Device search window Searching devices in sequence programs is available.

(a) Displayed screen





(For alphabet input)

(For numerical input)

The following table shows the displayed contents.

No.	Item	Description
1)	Device input area	Set a device to be searched.
2)	Keys	Keys for operations in the device search window shown in (b). (Touch input)

(b) Key functions

Key	Function
AC	Deletes all the input values and characters.
Del	Deletes an input value or character.
0-9	Switches the key type to the value.
A-Z	Switches the key type to the alphabet.
<u>P</u>	Searches the input device in descending order of the step number.
₽	Searches the input device in ascending order of the step number.
Enter	



Precautions for search device window

Searching for any bits in word devices is not available.

Specify word devices for searching for any bits.

(3) Replace device window Replacing a device is available. Once the device is set, the same devices as the set device are changed automatically.





(For alphabet input)

(For numerical input)

(a) Displayed contents

No.	Item	Description
1)	Current device display area	Set a current device.
2)	New device display area	Set a new device.
3)	Keys	Keys for operations in the replace device window shown in (b). (Touch input)

Key	Function
AC	Deletes all the input values and characters.
Del	Deletes an input value or character.
0-9	Switches the key type to the value.
A-Z	Switches the key type to the alphabet (uppercase).
a-z	Switches the key type to the alphabet (lowercase).
•	Touching the key after inputting a current device moves the cursor to the new device display
	area.
Enter	Replaces the current device to the new device.

(4) Change open/close contact window Switching a normally open contact to a normally closed contact is available. The set normally open contact or the normally closed contact can be switched to the other contact automatically.





(For alphabet input)

(For numerical input)

(a) Displayed contents

No.	Item	Description
1)	Device input area	Set a device for changing a normally open contact or a normally closed contact.
2)	Keys	Keys for operations in the the change open/close contact window shown in (b). (Touch input)

Key	Function
AC	Deletes all the input values and characters.
Del	Deletes an input value or character.
0-9	Switches the key type to the value.
A-Z	Switches the key type to the alphabet (uppercase).
a-z	Switches the key type to the alphabet (lowercase).
Enter	Changes a normally open contact or a normally closed contact.


3 Display menu



Key	Function	Reference section
Comment	Sets the comment display mode. Touching the key in the comment display mode cancels the comment display mode.	14.4.2
Comment change	Displays the comment file list window.	This section 3 (1)
Program list	Displays the program list window	14.5.2 (2)
PLC read	Displays the PLC read screen.	14.5

(1) Comment file list window
The GOT displays the comment file list.

(a) Displayed screen



The following table shows the displayed contents.

No.	Item	Description
1)	Comment file list	Among comment files stored in the CF card, the file names and titles of the comment files, and common comment files used for the displayed sequence program are displayed. For switching comments, select a comment file to be used. A selected comment file is highlighted.
2)	Keys	Keys for operations in the comment file list window shown in (b) (Touch input)

Key	Function
×	Closes the Comment file list window.
* *	Scrolls the display area up and down by one line.
Apply changes	Closes the Comment file list window and displays the ladder display area with the comments of the file selected from the comment file list.


4 Online menu

Write to PLC
Verify with PLC
Remote operation
Write the program memory to ROM
Start monitor

Key	Function
Write to PLC	Checks the edited sequence program, and writes the program into the PLC CPU. While the PLC CPU is running in operation, the GOT cannot writes the program into the PLC CPU. Set the PLC CPU to the STOP status, and write the program into the PLC CPU.
Verify with PLC	Verifies the sequence program displayed on the ladder display area and the program in the PLC CPU. If the programs do not match, the Verify result window is displayed. (Fig. This section (1) Verify result window)
Remote operation	Displays the Remote operation window. (This section (2) Remote operation window)
Write the program memory to ROM	Displays the Copy program memory data into ROM window. (Fig. 1) This section (3) Copy program memory data into ROM window)
Start monitor	Displays the Ladder monitor screen. (14.6 How to Operate Ladder Monitor Screen)

(1) Verify result window
Displaying the result of the program verification with the PLC is available.

(a) Displayed screen




The following table shows the displayed contents.

No.	Item	Description
1)	Verification result display area	Displays the unmatched items. Up to 100 items are displayed. The program verification is stopped when unmatched items are more than 100.
2)	Program name display area	Displays the file name of the verified program.
3)	Unmatched item count display area	Displays the number of unmatched items displayed on the Verify result window.
4)	Keys	Keys for operations in the Verify result window shown in (b). (Touch input)

Key	Function
X	Closes the Verify result window.
A V	Scrolls the display area up and down by one line.


- (2) Remote operation window Changing the operation status of the PLC CPU by using the remote operation is available.
 - (a) Displayed screen



The following table shows the displayed contents.

No.	Item	Description
1)	Operation	Select an operation (RUN or STOP key), and touch the Execute key. RUN: The PLC CPU becomes the remote RUN status. STOP: The PLC CPU becomes the remote STOP status.
2)	STOP → RUN operation	Set the status of devices and signals when executing the remote RUN. Device memory Do not clear: The PLC CPU operates device values prior to the remote STOP. Clear all except latch: Clears all device values to zero except the latched devices. Clear all: Clears all device values to zero. Signal flow Save: Keeps signals prior to the remote STOP, and outputs the signals. Turn OFF: Turns off the signal. Turn ON: Turns on the signal.
3)	Execute	Executes the remote RUN or STOP.

- (3) Copy program memory data into ROM window Writing data in the program memory into a ROM is available.
 - (a) Displayed screen



The following table shows the displayed contents.

No.	Item	Description
1)	Target	Touch the target ROM. Standard ROM: Set the standard ROM in the PLC CPU as the target. IC card (ROM): Set the IC memory card (Flash card) inserted in the PLC CPU as the target.
2)	Execute	Touching the key writes data in the program memory into the target ROM.

14.8 Test Operation

In the device test mode, device values can be changed on the screen. For setting the device test mode, refer to the following.

The test operation of devices is available by touching devices on the following screens in the device test mode.

Screen applicable to device test mode	Reference section
Ladder monitor screen	14.6.2


Touching a device displays the device test window.

- When touching bit devices
 A bit device is switched between ON and OFF states in the device test window.
- (2) When touching word devices

 The GOT writes the value input in the device test window into the selected word device.

1 How to operate device test window

- (1) Bit devices
 - (a) Displayed screen



The following table shows the displayed contents.


No.	Item	Description	
1)	Device	Displays the selected device.	
2)	Keys	Keys for operations in the device test window shown in (b).	


(b) Key functions

Key	Function	
Closes the device test window.		
ON	Turns on the bit device and writes the device state to the PLC CPU.	
0FF	Turns off the bit device and writes the device state to the PLC CPU.	

(2) Word devices

(a) Displayed screen





(Monitoring mode : 16-bit integer (DEC))

(Monitoring mode : 32-bit integer (HEX))

The following table shows the displayed contents.

No.	Item	Description	
1)	Device	Displays the selected device.	
2)	Device value input area	Set the value to be written into the selected device.	
3)	Input mode	Displays the current input mode. (DEC: decimal number. HEX: hexadecimal number)	
4)	Keys	Keys for operations in the device test window shown in (b).	

(b) Key functions

Key	Function	
Х	Closes the device test window.	
DEC/HEX	Switches the input modes. (DEC, HEX)	
Enter Writes the value input in the device value input area into the PLC CPU.		
Del	Del Deletes an input value or character.	
AC	AC Deletes all the input values and characters.	

14.9 Error Messages and Corrective Action

The following shows the error messages for the ladder editor and the corrective actions.

1 Error messages for CF card access

Error message	Description	Corrective action	
File access error. Confirm the CF card.	 No CF card is inserted in the GOT. The CF card access switch is off. A CF card with a format error is inserted in the GOT. The CF card has insufficient free space for writing a file. The folder for the ladder editor function in the CF card is write-protected. 	 (1) Insert a CF card without a format error in the GOT. (2) If the CF card access switch is off, turn on the switch. (3) Delete files in the CF card. (4) Insert a CF card with a large capacity. (5) Cancel the write-protect setting for the folder that is used for the ladder editor function in the CF card. 	
Failed to write (file name) to CF card. Confirm the CF card.	 No CF card is inserted in the GOT. The CF card access switch is off. A CF card with a format error is inserted in the GOT. The CF card has insufficient free space for writing a file. The folder for the ladder editor function in the CF card is write-protected. 	 (1) Insert a CF card without a format error in the GOT. (2) If the CF card access switch is off, turn on the switch. (3) Delete files in the CF card. (4) Insert a CF card with a large capacity. (5) Cancel the write-protect setting for the folder that is used for the ladder editor function in the CF card. 	
Failed to save files because of an insufficient capacity of CF card.	The CF card has insufficient free space for writing a file.	(1) Delete files in the CF card.(2) Insert a CF card with a large capacity.	
The file (file name) is broken. The file is unselected.	The read file in the CF card is corrupted.	Read the file from the PLC CPU again.	
The file (file name) is broken. Perform PLC Read and read the file again.	The temporary file used on the Ladder editor screen or the Ladder monitor screen in the CF card is corrupted.	Read the file from the PLC CPU again.	
The file (file name) is broken. Please read the file in the program list again.	The temporary file used on the Ladder editor screen or the Ladder monitor screen in the CF card is corrupted.	Select the program displayed in the Program list window again.	
The file (file name) is broken.	When searching for devices in an undisplayed program, a file in the CF card is corrupted.	Read the file from the PLC CPU again.	
Failed to check program. Confirm the CF card.	The GOT cannot access the temporary file in the CF card during a program check.	 (1) Insert a CF card without a format error in the GOT. (2) If the CF card access switch is off, turn on the switch. (3) Delete files in the CF card. (4) Insert a CF card with a large capacity. (5) Cancel the write-protect setting for the folder that is used for the ladder editor function in the CF card. 	
Failed to verify with PLC. Please check the CF card.	The GOT cannot access the temporary file in the CF card during the PLC program verification.	 (1) Insert a CF card without a format error in the GOT. (2) If the CF card access switch is off, turn on the switch. (3) Delete files in the CF card. (4) Insert a CF card with a large capacity. (5) Cancel the write-protect setting for the folder that is used for the ladder editor function in the CF card. 	
Parameter file is corrupted. Please restart the ladder editor.	The parameter file in the CF card is corrupted.	Exit the ladder editor function, and then start the function again.	

2 Error messages for communication

Error message	Description	Corrective action	
Failed to communicate with CPU.	The GOT cannot communicate with the PLC CPU.	 (1) Check the line status between the GOT and the PLC CPU, and make the GOT communicate with the PLC CPU. (2) Check if the PLC CPU supports the ladder editor function. 	
Failed to communicate with CPU.	The GOT cannot communicate with the PLC CPU.	Check the line status between the GOT and the PLC CPU, and make the GOT communicate with the PLC CPU.	
Failed to get the information of CPU because of bad connection.	The GOT cannot communicate with the PLC CPU.	Check the line status between the GOT and the PLC CPU, and make the GOT communicate with the PLC CPU.	
The CPU protect switch is ON. Turn OFF the protect switch.	The system protect switch of the PLC CPU is on. The PLC CPU is in the boot process.	(1) Turn off the system protect switch of the PLC CPU.(2) Wait until the boot process of the PLC CPU is completed.	
The CPU is not in STOP mode. Please change the CPU to STOP mode.	Any operation that the PLC CPU cannot execute during running is performed.	Set the PLC CPU to the STOP status.	
CPU drive error. Please confirm the drive status.	The target drive does not function.	Format the target drive by using GX Developer.	
The specified file does not exist in the CPU. Please confirm the file in the drive.	The specified file does not exist in the PLC CPU.	Check files in the specified drive of the PLC CPU.	
The specified file in the CPU is invalid. Please confirm the file in the drive.	The specified file in the PLC CPU is corrupted.	Delete the specified file by using GX Developer, and then create the file again.	
You cannot access the file while it is being used by other connected equipment.	Other GOTs or GX Developer access the connected PLC CPU.	Access the file when other devices do not access the connected PLC CPU.	
The data cannot be written to the specified CPU because the total data size may exceed the drive capacity.	The specified drive of the PLC CPU runs out of space.	Reduce the capacity of the file to be written.	
The specified file is invalid.	The specified file in the PLC CPU is corrupted.	Format the target drive by using GX Developer, and then write the specified file.	
There is no consecutive free space in the drive of the specified CPU. Please clean up the drive.	The specified drive of the PLC CPU does not have consecutive free space.	Execute [Arrange PLC memory] with GX Developer.	
Failed to write data to the specified CPU. Please check if the target flash ROM has an error or not.	An error occurs when writing/deleting data to/from the specified drive of the PLC CPU.	Check the specified drive by using GX Developer.	
The specified file does not exist.	The specified drive or file does not exist in the PLC CPU.	Read data from the PLC, and check if the specified drive exists.	
The file (file name) does not exist. Please check if the file exists using PLC Read.	When reading data from the PLC, the program file corresponding to the specified program on the ladder display area does not exist in the PLC CPU.	Read data from the PLC, and check if the specified file exists.	
The specified CPU drive has an error. Please check the drive.	The specified drive of the PLC CPU is faulty.	(1) Execute [Format PLC memory] with GX Developer. (2) If the specified drive is the flash ROM, write data to the PLC (flash ROM) again.	

Error message	Description	Corrective action	
The specified file is under processing.	The specified drive of the PLC CPU is in use.	Execute the same operation later.	
Invalid password.	The password to access the specified file is incorrect.	Input the correct password.	
The specified CPU drive is write-protected.	Data is written to the write-protect drive of the PLC CPU.	Cancel the write-protect setting for the specified drive of the PLC CPU.	
Too many files are being accessed at the same time.	Other devices are accessing too many files in the PLC CPU at the same time.	Reduce the number of files being accessed by other devices.	
The specified CPU drive cannot be accessed.	The specified drive does not exist in the PLC CPU.	Read data from the PLC, and specify a drive that exists in the PLC CPU.	
Failed to access the specified CPU drive. Please check the drive status.	No memory card is inserted in the specified drive of the PLC CPU. The memory card is faulty.	(1) Insert a memory card in the specified drive of the PLC CPU.(2) Format the memory card in the specified drive by using GX Developer.	
The specified CPU drive has an error. Please check the drive status.	The specified drive in the PLC CPU does not function.	Format the specified drive by using GX Developer.	
The specified CPU drive is not formatted.	The specified drive of the PLC CPU is not formatted.	Format the specified drive by using GX Developer.	
CPU memory card is not inserted.	No memory card is inserted in the specified drive of the PLC CPU.	Insert a memory card in the specified drive.	
The type of the CPU memory card is wrong. Please check the memory card.	 An unsupported memory card is inserted in the specified drive of the PLC CPU. No memory card is inserted in the specified drive of the PLC CPU. 	Insert a supported memory card in the specified drive.	
The CPU is write protected. Please remove the protection.	The PLC CPU is write-protected.	Cancel the write-protect setting for the PLC CPU.	
The specified CPU drive cannot be used. Please check the drive.	The specified drive of the PLC CPU does not exist.	Read data from the PLC, and check if the specified drive exists.	
PLC types of the program (file name) and the connected PLC are not the same. Perform PLC Read and read the data again.	The PLC CPU type of the program file stored in the CF card differs from the connected PLC CPU type.	Read a program file that exists in the PLC CPU.	
The program before modification on the GOT and the program being registered on the CPU do not match. Please perform PLC Read and read the program again.	When a program is written into the PLC, the target file does not exist in the PLC CPU, or the type of the program differs from that of the target file.	Read a program file that exists in the PLC CPU	
Failed to write the value to the device.	The GOT cannot write device values to the PLC CPU with the device test.	Read the program being displayed from the PLC again.	
Parameter file is corrupted. The ladder editor cannot be used.	The GOT cannot read parameters from the PLC CPU.	Write the parameters to the PLC CPU by using GX Developer.	

3 Error messages for editing

Error message	Description	Corrective action	
The instruction is incorrect.	The input instruction is incorrect.	Input the correct instruction.	
The specified device is not available.	The input device name is incorrect.	Input the correct device name.	
The device number is out of range.	The device number outside the range is input.	Input the correct device number.	
Statements cannot be entered.	A statement is input.	Do not input a statement.	
Statements cannot be edited.	When a statement is selected, the statement is edited except to delete rows.	Close the Enter ladder program window because the statement cannot be edited except to delete rows.	
Too many rows are being edited. Data cannot be entered.	On the edited ladder, 49 or more rows are input.	Delete rows to be 48 or less per edited ladder.	
The ladder block is too large. Data cannot be entered.	On a ladder block, 25 or more rows are input.	Delete rows to be 24 or less per ladder block.	
The edit position is incorrect.	 A specified position is incorrect to input a ladder. A space of a specified position is too narrow to input a ladder. A start position and end position are not specified in the same column to input a vertical line. An end position is specified in an upper row of the start position to input a vertical line. A start position and end position are not specified in the same row to input a horizontal line. A start position and end position are not specified in the same row to delete a ladder. 	 (1) Input a ladder in a correct position. (2) Insert columns, and then input a ladder. (3) Specify a correct end position for a vertical line or horizontal line, and then input the line. (4) Specify a correct end position, and then delete a ladder. 	
Line statements exist in the ladder program and the data cannot be edited. Please delete the line statements from the ladder program.	A vertical line that overlaps an interlinear statement is input.	Delete the interlinear statement, and then input a vertice line.	
PI devices exist in the ladder program and the data cannot be edited. Please delete the PI devices from the ladder program.	A vertical line that overlaps a pointer or interrupt pointer is input.	Delete the pointer or interrupt pointer, and then input a vertical line.	
There is a ladder block which cannot be displayed in the ladder program. Data cannot be edited.	On a ladder block, 25 or more rows are edited. An incomplete ladder block is edited.	(2) Write the program into the PLC CPU by using GX	

4 Error messages for conversion

Error message	Description	Corrective action	
There is a ladder which cannot be converted.	When a ladder block is converted, the	Complete the ladder block, and then convert the ladder	
Correct the ladder at the cursor position.	ladder block is not completed.	block.	

APPENDICES

Appendix1 List of Functions Added by GT Designer2 Version Upgrade (For GOT1000 Series)

The following describes the functions added by version upgrade of the GT Designer2 Version2.96A (partially including 2.98C).

For function comparisons among GOTs, refer to the following.

GT Designer2 Version
Basic Operation/Data Transfer Manual (App3-2 List of Differences between the GOT1000 series and GOT-900 series functions)

For using the following functions, use GT Designer2 or OS of the corresponding version or later. (Applicable OS versions and communication drivers for GT16, GT15, GT SoftGOT1000, and GT11 are different from those for GT10. The added functions for GT10 are listed separately from those for GT16, GT15, GT SoftGOT1000, and GT11.)



How to use this table

provides the versions of GT Designer2 and OS required for each GOT or communication unit.

and the following provides description for the functions added with the version upgrade, and the versions of GT Designer2 and OS with which the function is compatible.

Regarding 2 and the following, there may be a case where the function is not supported by a particular type of GOT even when the function is compatible with the version.

In such a case, check the version for the function and the version of the GOT, and use GT Designer2 or OS of the later version.

Appendix.1.1 GT16, GT15, GT SoftGOT1000, and GT11

1 Added GOT main unit/Communication unit

Target Models	Version of GT Designer2	Version of OS
GT1695M-XTBA, GT1695M-XTBD	2.90U	Standard monitor OS [04.02.**]
GT1685M-STBA, GT1685M-STBD	2.90U	Standard monitor OS [04.02.**]
GT1675M-STBA, GT1675M-STBD, GT1675M-VTBA, GT1675M-VTBD	2.96A	Standard monitor OS [04.04.**]
GT1665M-STBA, GT1665M-STBD, GT1665M-VTBA, GT1665M-VTBD	2.96A	Standard monitor OS [04.04.**]
GT1595-XTBA	2.18U	Standard monitor OS [02.02.**]
GT1595-XTBD	2.32J	Standard monitor OS [03.00.**]
GT1585-STBD	2.18U	Standard monitor OS [02.02.**]
GT1585V-STBA, GT1585V-STBD	2.32J	Standard monitor OS [03.00.**]
GT1575-STBD	2.18U	Standard monitor OS [02.02.**]
GT1575V-STBA, GT1575V-STBD	2.32J	Standard monitor OS [03.00.**]

		>

Target Models	Version of GT Designer2	Version of OS
GT1575-VTBD	2.18U	Standard monitor OS [02.02.**]
GT1575-VNBA, GT1575-VNBD, GT1572-VNBA, GT1572-VNBD	2.18U	Standard monitor OS [02.02.**]
GT1565-VTBD	2.18U	Standard monitor OS [02.02.**]
GT1562-VNBA, GT1562-VNBD	2.18U	Standard monitor OS [02.02.**]
GT1555-VTBD	2.58L	Standard monitor OS [03.03.**]
GT1555-QTBD, GT1555-QSBD, GT1550-QLBD	2.32J	Standard monitor OS [03.00.**]
GT1155-QTBDQ, GT1155-QSBDQ, GT1155-QTBDA, GT1155-QSBDA GT1150-QLBDQ, GT1150-QLBDA	2.58L	Standard monitor OS [03.03.**]
GT1155-QTBD	2.73B	Standard monitor OS [03.09.**]
GT1155HS-QSBD to GT1150HS-QLBD	2.18U	Standard monitor OS [02.02.**]
GT SoftGOT1000	2.27D	-
GT15-QBUS(2), GT15-ABUS(2), GT15-RS2-9P, GT15-RS4-9S, GT15-RS4-TE	2.18U	Standard monitor OS [02.02.**] Communication driver For communication drivers used in each connection, use [02.02.**] or
GT15-J71GP23-SX	2.77F	Standard monitor OS [03.12.**]
GT01-RS4-M	2.96A	Standard monitor OS [04.03.**] Communication driver Multidrop(Host) [04.04.**] Multidrop(Slave) [04.04.**]
GT16M-V4, GT16M-R2, GT16M-V4R1, GT16M-ROUT	2.90U	Extended function OS Video/RGB [04.02.**]
GT16M-MMR	2.90U	Extended function OS Multimedia [04.02.**]
GT15-CFCD	2.43V	Standard monitor OS [03.01.**] BootOS [03.01.**.M]
GT15-CFEX-C08SET	2.45X	Standard monitor OS [03.02.**] BootOS [03.02.**.N]
GT15-SOUT	2.58L	Extended function OS Sound Output [03.03.**]
GT15-DIO	2.58L	Extended function OS External I/O / Operation Panel [03.03.**]
GT15-DIOR	2.90U	Extended function OS External I/O / Operation Panel [04.02.**]
GT15-80FPA	2.91V	Extended function OS Operator authentication [04.03.**] Fingerprint Authentication [04.03.**]

2 Added connection types

(1) For GT16

Item	Description	Version of GT Designer2	Version of OS
Bus connection	Supporting connection to BUS	2.90U	Communication driver Bus(Q)[04.02.**] Bus(A/QnA) [04.02.**]

Item	Description	Version of GT Designer2	Version of OS
Bus connection	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	2.91V	Communication driver Bus(Q)[04.03.**]
	Supporting connection to Q170MCPU	2.96A	Communication driver Bus(Q)[04.04.**]
	Supporting the direct CPU connection	2.90U	Communication driver A/QnA/Q CPU, QJ71C24 [04.02.**] MELSEC-FX [04.02.**]
Direct connection to CPU	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	2.91V	Communication driver A/QnA/Q CPU, QJ71C24 [04.03.**]
	Supporting connection to Q170MCPU	2.96A	Communication driver A/QnA/Q CPU, QJ71C24 [04.04.**]
Computer link	Supporting the computer link connection	2.90U	Communication driver A/QnA/Q CPU, QJ71C24 [04.02.**] AJ71QC24, MELDAS C6* [04.02.**] AJ71C24/UC24 [04.02.**]
Computer link connection	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	2.91V	Communication driver A/QnA/Q CPU, QJ71C24 [04.03.**]
	Supporting connection to Q170MCPU	2.96A	Communication driver A/QnA/Q CPU, QJ71C24 [04.04.**]
	Supporting connection to MELSECNET/H (PLC to PLC network)	2.90U	Communication driver MELSECNET/H [04.02.**]
MELSECNET/H connection (PLC to PLC network)	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	2.91V	Communication driver MELSECNET/H [04.03.**]
	Supporting connection to Q170MCPU	2.96A	Communication driver MELSECNET/H [04.04.**]
	Supporting connection to MELSECNET/10 PLC to PLC connection)	2.90U	Communication driver MELSECNET/H [04.02.**]
MELSECNET/10 connection (PLC to PLC network)	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	2.91V	Communication driver MELSECNET/H [04.03.**]
	Supporting connection to Q170MCPU	2.96A	Communication driver MELSECNET/H [04.04.**]
	Supporting connection to CC-Link IE controller network	2.90U	Communication driver CC-Link IE Controller Network [04.02.**]
CC-Link IE controller network connection	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	2.91V	Communication driver CC-Link IE Controller Network [04.03.**]
	Supporting connection to Q170MCPU	2.96A	Communication driver CC-Link IE Controller Network [04.04.**]
	Supporting connection to CC-Link (Intelligence device station)	2.90U	Communication driver CC-Link Ver2 (ID) [04.02.**]
CC-Link connection (Intelligent device station)	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	2.91V	Communication driver CC-Link Ver2 (ID) [04.03.**]
	Supporting connection to Q170MCPU	2.96A	Communication driver CC-Link Ver2 (ID) [04.04.**]

Item	Description	Version of GT Designer2	Version of OS
	Supporting connection to CC-Link (Via G4)	2.90U	Communication driver CC-Link(G4) [04.02.**]
CC-Link connection (Via G4)	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	2.91V	Communication driver CC-Link(G4) [04.03.**]
	Supporting connection to Q170MCPU	2.96A	Communication driver CC-Link(G4) [04.04.**]
	Supporting connection to the Ethernet	2.90U	Communication driver Ethernet(MELSEC),Q17nNC, CRnD-700 [04.02.**]
Ethernet connection	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	2.91V	Communication driver Ethernet(MELSEC),Q17nNC, CRnD-700 [04.03.**]
	Supporting connection to Q170MCPU	2.96A	Communication driver Ethernet(MELSEC),Q17nNC, CRnD-700 [04.04.**]
OMRON PLC connection	Supporting connection to OMRON PLC	2.90U	Communication driver OMRON SYSMAC [04.02.**]
KEYENCE PLC connection	Supporting connection to KEYENCE PLC	2.90U	Communication driver KEYENCE KV700/1000 [04.02.**]
KOYO EI PLC connection	Supporting connection to KOYO EI PLC	2.90U	Communication driver KOYO KOSTAC/DL [04.02.**]
SHARP PLC connection	Supporting connection to SHARP PLC	2.90U	Communication driver SHARP JW [04.02.**]
TOSHIBA PLC connection	Supporting connection to TOSHIBA PLC	2.90U	Communication driver TOSHIBA PROSEC T/V [04.02.**]
TOSHIBA MACHINE PLC connection	Supporting connection to TOSHIBA MACHINE PLC	2.90U	Communication driver TOSHIBA MACHINE TCmini [04.02.**]
JTEKT PLC connection	Supporting connection to JTEKT PLC	2.90U	Communication driver JTEKT TOYOPUC-PC [04.02.**]
HITACHI IES PLC connection	Supporting connection to HITACHI IES PLC	2.90U	Communication driver HITACHI HIDIC H [04.02.**] HITACHI HIDIC H (Protocol 2) [04.02.**]
HITACHI PLC connection	Supporting connection to HITACHI PLC	2.90U	Communication driver HITACHI S10mini/S10V [04.02.**]
FUJI FA PLC connection	Supporting connection to FUJI FA PLC	2.90U	Communication driver FUJI MICREX-F [04.02.**]
PANASONIC PLC	Supporting connection to PANASONIC PLC	2.90U	Communication driver MATSUSHITA MEWNET-FP [04.02.**]
connection	Communication driver name has been changed.	2.96A	Communication driver Panasonic MEWNET-FP [04.04.**]
YASKAWA PLC connection	Supporting connection to YASKAWA PLC	2.90U	Communication driver YASKAWA GL/CP9200(SH/H)/ CP9300MS [04.02.**] Ethernet(YASKAWA) [04.02.**]

Item	Description	Version of GT Designer2	Version of OS
YOKOGAWA PLC connection	Supporting connection to YOKOGAWA PLC	2.90U	Communication driver YOKOGAWA FA500/FA-M3/ STARDOM [04.02.**] Ethernet(YOKOGAWA) [04.02.**] MODBUS/TCP [04.02.**]
ALLEN-BRADLEY PLC connection	Supporting connection to ALLEN-BRADLEY PLC	2.90U	Communication driver AB SLC500, AB 1:N [04.02.**] AB MicroLogix [04.02.**] AB Control/CompactLogix [04.02.**] EtherNet/IP(AB) [04.02.**]
GE FANUC PLC connection	Supporting connection to GE FANUC PLC	2.90U	Communication driver GE Fanuc Automation(SNP-X) [04.02.**]
LS IS PLC connection	Supporting connection to LS IS PLC	2.90U	Communication driver LS Industrial Systems MASTER-K[04.02.**]
SCHNEIDER PLC connection	Supporting connection to the MODBUS® /TCP	2.90U	Communication driver MODBUS/TCP [04.02.**]
SIEMENS PLC connection	Supporting connection to SIEMENS PLC	2.90U	Communication driver SIEMENS S7-300/400 [04.02.**] SIEMENS S7-200 [04.02.**]
Microcomputer connection	Supporting connection to a microcomputer	2.90U	Communication driver Computer [04.02.**]
MODBUS® /RTU connection	Supporting MODBUS® /RTU connection	2.96A	Communication driver MODBUS/RTU [04.04.**]
MODBUS® /TCP connection	Supporting connection to the MODBUS® /TCP	2.90U	Communication driver MODBUS/TCP [04.02.**]
OMRON temperature controller connection	Supporting connection to OMRON temperature controller	2.90U	Communication driver OMRON THERMAC / INPANEL NEO [04.02.**]
SHINKO indicating controller connection	Supporting connection to SHINKO indicating controller	2.90U	Communication driver SHINKO TECHNOS CONTROLLER [04.02.**]
CHINO controller connection	Supporting connection to CHINO controller	2.90U	Communication driver CHINO Controllers(MODBUS) [04.02.**]
FUJI SYS temperature controller connection	Supporting connection to FUJI SYS temperature controller	2.90U	Communication driver FUJI PXR/PXG/PXH [04.02.**]
YAMATAKE temperature controller connection	Supporting connection to YAMATAKE temperature controller	2.90U	Communication driver YAMATAKE SDC/DMC [04.02.**]
YOKOGAWA temperature controller connection	Supporting connection to YOKOGAWA temperature controller	2.90U	Communication driver YOKOGAWA GREEN/UT100/ UT2000 [04.02.**]
RKC temperature controller connection	Supporting connection to RKC temperature controller	2.90U	Communication driver RKC SR Mini HG(MODBUS) [04.02.**]
Inverter connection	Supporting connection to inverter	2.90U	Communication driver FREQROL 500/700 [04.02.**]
Robot controller connection	Supporting connection to robot controller	2.90U	Communication driver QJ71E71/AJ71(Q)E71,Q17nNC, CRnD-700 [04.02.**]

Item	Description	Version of GT Designer2	Version of OS
Servo amplifier	Supporting connection to servo amplifier	2.90U	Communication driver MELSERVO-J3, J2S/M [04.02.**]
connection	Supporting connection to MR-J2S-*CL	2.96A	Communication driver MELSERVO-J3, J2S/M [04.04.**]
CNC connection (MELDAS C6/C64)	Supporting connection to CNC (MELDAS C6/C64 series)	2.90U	Communication driver AJ71QC24, MELDAS C6* [04.02.**] MELSECNET/H [04.02.**] CC-Link Ver2 (ID) [04.02.**] Ethernet(MELSEC), Q17nNC, CRnD-700 [04.02.**]
GOT multidrop connection	Supporting the GOT multidrop connection	*1	-
Barcode reader connection	Supporting connection to barcode reader	2.90U	Extended function OS Barcode [04.02.**]
Printer connection	Supporting connection to printer	2.90U	Extended function OS Printer [04.02.**]
	Supporting the FA transparent function via USB	2.90U	Standard monitor OS [04.02.**]
FA transparent	Supporting the Ethernet connection between the GOT and the PLC on GX Developer	2.96A	Standard monitor OS [04.04.**]
External I/O device connection	Supporting connection to external I/O devices	2.90U	Extended function OS External I/O / Operation Panel [04.02.**]
RFID connection	Supporting connection to the RFID controller	2.90U	Extended function OS RFID [04.02.**]

(2) For GT15, GT SoftGOT1000, and GT11

		Version of		GT	GT Soft	G1	Γ11
Item	Description	GT Designer2	Version of OS	15	GOT1000	Bus	Serial
		2.04E	Communication driver Bus(Q)[01.00.**] Bus(A/QnA) [01.00.**]	0	×	×	×
Bus connection	Supporting connection to BUS	2.58L	GT15 Communication driver Bus(Q) [03.03.**] Bus(A/QnA) [03.03.**] GT11 BootOS [03.03.**.P] Standard monitor OS [03.03.**] Communication driver Bus(Q) [03.03.**] Bus(A/QnA) [03.03.**]	0	0	0	×
	Description GT Designer2 Communication driver Bus(Q)[01.00.**] O	0	×				
	Priority order of data load can be set.	2.43V		0	×	0	×
	QCPU Supporting connection to Q17nDCPU	2.63R		0	0	0	×

		Version of		GT	CT Co#	GT11	
Item	Description	GT Designer2	Version of OS	15	GOT1000	Bus	Serial
	Supporting connection to CRnQ-700	2.73B	Communication driver Bus connection Q [03.09.**]	0	0	0	×
	Supporting connection to Q13UDHCPU and Q26UDHCPU	2.77F	Communication driver Bus connection Q [03.12.**]	0	0	0	×
	Supporting connection to Q02PHCPU and Q06PHCPU		Communication driver			Bus O O X X X X X X X	
Bus connection	Supporting connection to Q03UDECPU, Q04UDEHCPU, Q06UDEHCPU, Q13UDEHCPU, and Q26UDEHCPU	2.82L	Bus connection Q [03.13.**]	0	0	0	×
	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	2.91V	Communication driver Bus connection Q [04.03.**]	0	0	Bus	×
	Supporting connection to Q170MCPU	2.96A	Communication driver Bus connection Q [04.04.**]	0	0		×
	Supporting connection to Q172HCPU, Q173HCPU	2.09K	Communication driver A/QnA/QCPU,QJ71C24 [01.02.**]	0	×	ft Bus Bus O O O O O O O O O O O O O O O O O O O	0
	Supporting connection to FX3U series	2.18U	Communication driver MELSEC-FX[02.02.**]	0	0		0
	Supporting automatic system switching for QCPU redundant system	2.32J	Communication driver A/QnA/QCPU, QJ71C24, MELDAS C6* [03.00.**]	0	0	×	0
	Communication driver name has been changed.	2.43V	Communication driver A/QnA/QCPU, QJ71C24 [03.01.**]	0	GT Soft 15 Soft 16 Bus O O O O O O O O O O O O O O X O O X O X X O X X O X X O X X O X X O X X O X X O X X O X X O X X O X X O X X O X X O X X O X X O X X O X X O X X O X X X X	0	
	Supporting connection to Universal model QCPU	0.000	Communication driver		_	Section Sect	_
	Supporting connection to Q17nDCPU Supporting connection to CNC C70	2.63R	A/QnA/QCPU,QJ71C24, MELDASC6*[03.07.**]		O		0
Direct connection to CPU	Supporting connection to CRnQ-700		Communication driver A/QnA/QCPU, QJ71C24 [03.09.**]	0	0		0
	Supporting settings for the number of retries, the timeout time, and delay time	2.73B	Communication driver A/QnA/QCPU, QJ71C24 [03.09.**] MELSEC-FX[03.09.**]	0	×		0
	Supporting connection to Q13UDHCPU and Q26UDHCPU	2.77F	Communication driver A/QnA/QCPU, QJ71C24 [03.12.**]	0	0		0
	Supporting connection to Q02PHCPU and Q06PHCPU						
	Supporting connection to Q03UDECPU, Q04UDEHCPU, Q06UDEHCPU, Q13UDEHCPU, and Q26UDEHCPU	2.82L	Communication driver A/QnA/QCPU, QJ71C24 [03.13.**]	0	0	×	0
	Supporting connection to QS001CPU			×	0	Bus O O O X X X X X X X X	×
	Supporting connection to FX3G series	2.90U	Communication driver MELSEC-FX[04.02.**]	0	0		0
				Conti	nued to r	nevt n	ane)

X	
<u> </u>	

		Version of		GT	GT Soft	G1	T11	
Item	Description	GT Designer2	Version of OS	15	GOT1000	Bus	Serial	
Direct connection	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	2.91V	Communication driver A/QnA/QCPU, QJ71C24 [04.03.**]	0	0	×	0	
to CPU	Supporting connection to Q170MCPU	2.96A	Communication driver A/QnA/QCPU, QJ71C24 [04.04.**]	0	0	×	0	
	Supporting connection to Q172HCPU, Q173HCPU	2.09K	Communication driver A/QnA/QCPU,QJ71C24 [01.02.**]	0	×	×	0	
	Communication driver name has been changed.	2.43V	Communication driver A/QnA/QCPU, QJ71C24 [03.01.**] AJ71QC24, MELDAS C6* [03.01.**]	0	×	×	0	
	Supporting connection to Universal model QCPU Supporting connection to Q17nDCPU Supporting connection to CNC C70 Supporting the redundant system with the	- 2.63R	Communication driver A/QnA/QCPU,QJ71C24, MELDASC6*[03.07.**]	0	0	Bus ×	0	
Computer link connection	redundant type extension base unit Supporting connection to CRnQ-700		Communication driver A/QnA/QCPU, QJ71C24 [03.09.**]	0	0		0	
	Supporting settings for the number of retries, the timeout time, and delay time	2.73B	Communication driver A/QnA/QCPU, QJ71C24 [03.09.**] AJ71QC24, MELDAS C6* [03.09.**] AJ71C24/UC24[03.09.**]	0	×		0	
	Supporting connection to Q13UDHCPU and Q26UDHCPU Supporting connection to QJ71CMON	2.77F	Communication driver A/QnA/QCPU, QJ71C24 [03.12.**]	0	0		0	
	Supporting connection to Q170MCPU	2.96A	Communication driver A/QnA/QCPU, QJ71C24 [04.04.**]	0	0	×	0	
Computer link connection	Supporting connection to Q02PHCPU and Q06PHCPU Supporting connection to Q03UDECPU, Q04UDEHCPU, Q06UDEHCPU, Q13UDEHCPU, and Q26UDEHCPU	2.82L	Communication driver A/QnA/QCPU, QJ71C24 [03.13.**]	0	0	×	0	
Connection	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	2.91V	Communication driver A/QnA/QCPU, QJ71C24 [04.03.**]	0	0	×	0	
	Supporting connection to MELSECNET/H	2.25B	-	×	0	×	×	
MELSECNET/H connection (PLC	(PLC to PLC network)	2.32J	Communication driver MELSECNET/H [03.00.**]	0	0	×	×	
to PLC network)	Supporting routing parameter setting with GT Designer2.	2.43V	Communication driver MELSECNET/H [03.01.**]	0	×	×	×	

		Version of		СТ	OT 0-#	Bus X X X X X X X X X X X X X	Γ11
Item	Description	GT	Version of OS	15	GT Soft GOT1000	Bus	Serial
	Supporting connection to Universal model	Designer2					
	QCPU		Communication driver			Bus X X X X X X X X X X X X X	
	Supporting connection to Q17nDCPU	2.63R	MELSECNET/H[03.07.**]	0	0	×	×
	Supporting connection to CNC C70						
	Supporting connection to CRnQ-700	2.73B	Communication driver MELSECNET/H[03.09.**]	Version of OS	×	×	
	Supporting connection to Q13UDHCPU and Q26UDHCPU	2.77F	Communication driver MELSECNET/H[03.12.**]		×		
MELSECNET/H	Supporting connection to Q02PHCPU and Q06PHCPU		Communication driver MELSECNET/H[03.07.**]				
to PLC network)	Supporting connection to Q03UDECPU, Q04UDEHCPU, Q06UDEHCPU, Q13UDEHCPU, and Q26UDEHCPU	2.82L		×			
	Supporting connection to QS001CPU	-		0	0	Bus X X X X X X X X X X X X X	×
	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	2.91V		15 GOT1000 Bus Serial	×		
	Supporting connection to Q170MCPU	2.96A		0	0	×	×
	Supporting connection to MELSECNET/ 10 PLC to PLC connection)	0.0014	Communication driver	0	0		
	Supporting connection to Q172HCPU, Q173HCPU	2.09K	MELSECNET/10 [01.02.**]		×	×	×
	Supporting automatic system switching for QCPU redundant system	Description	×	×			
	Supporting routing parameter setting with GT Designer2.	2.43V		GT GT Soft GOT1000 Bus O O X O O O X O O X O O O O	×		
	Supporting connection to Universal model QCPU	Description	×	×			
	Supporting connection to Q17nDCPU			0	0	Bus X X X X X X X	×
	Supporting connection to CNC C70	-		0	0	×	×
MELSECNET/10	Supporting connection to CRnQ-700	2.73B		0	0	X	×
to PLC network)	Supporting connection to Universal model QCPU Supporting connection to Universal model QCPU Supporting connection to CRC 70 Supporting connection to CRC 70 Supporting connection to CRO 70 Supporting connection to Q3JUDECPU and Q2BUDECPU QORDERCPU,	×	×				
		0	×	×			
	Q04UDEHCPU, Q06UDEHCPU,	2.82L		0	0	×	×
	Supporting connection to QS001CPU	1		0	0	X	×
connection (PLC	Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and	2.91V		0	0	×	×
	Supporting connection to Q170MCPU	2.96A		0	0	X	×
		•		(Conti	nued to r	next n	age)

GT11

Serial

×

Bus

×

GT Soft

GOT1000

0

GT

15

0

Version of OS

Communication driver

Network[03.12.**]

CC-Link IE Controller

INDEX

	Q06PHCPU							1
CC-Link IE	Supporting connection to Q03UDECPU, Q04UDEHCPU, Q06UDEHCPU, Q13UDEHCPU, and Q26UDEHCPU	2.82L	Communication driver CC-Link IE Controller Network[03.13.**]	0	0	×	×	CNC MONITOR
controller network connection	Supporting connection to QS001CPU			0	0	×	×	CMO
	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	2.91V	Communication driver CC-Link IE Controller Network[04.03.**]	0	0	×	×	1
	Supporting connection to Q170MCPU	2.96A	Communication driver CC-Link IE Controller Network[04.04.**]	0	0	×	×	
	Supporting connection to CC-Link (Intelligence device station)	2.09K	Communication driver		~	~		1
	Supporting connection to Q172HCPU, Q173HCPU	2.091	CC-LINK(ID) [01.02.**]	0	×	×	×	
	Supporting connection to CC-Link Ver.2	2.32J	Communication driver CC-Link Ver2 (ID) [03.00.**]	0	0	×	×	
	Supporting connection to Universal model QCPU							
	Supporting connection to Q17nDCPU	2.63R	Communication driver	0	×	×	×	
	Supporting connection to CNC C70	2.0010	CC-Link Ver2 (ID) [03.07.**]		^	^	^	
	Supporting the redundant system with the redundant type extension base unit							
connection (Intelligent device	Supporting connection to CRnQ-700	2.73B	Communication driver CC-Link Ver2 (ID) [03.09.**]	0	×	×	×	
station)	Supporting connection to Q13UDHCPU and Q26UDHCPU	2.77F	Communication driver CC-Link Ver2 (ID) [03.12.**]	0	×	×	×	1
	Supporting connection to Q02PHCPU and Q06PHCPU		Communication driver CC-Link Ver2 (ID) [03.13.**]					
	Supporting connection to Q03UDECPU, Q04UDEHCPU, Q06UDEHCPU, Q13UDEHCPU, and Q26UDEHCPU	2.82L		0	×	×	×	
	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	2.91V	Communication driver CC-Link Ver2 (ID) [04.03.**]	0	×	×	×	
	Supporting connection to Q170MCPU	2.96A	Communication driver CC-Link Ver2 (ID) [04.04.**]	0	×	×	×	
CC-Link connection (Via	Supporting connection to CC-Link (Via G4)	2.09K	Communication driver			.,		
G4)	Supporting connection to Q172HCPU, Q173HCPU	2.09K	CC-LINK(G4) [01.02.**]	0	×	×	0	
				(Contir	nued to	next p	age)	
						Αp	p - 10	
						• '		

Version of

GT

Designer2

2.77F

Description

Supporting connection to Q02PHCPU and

Supporting connection to CC-Link IE

controller network

Item

		Version of		GT	GT Soft	GT11	
Item	Description	GT Designer2	Version of OS	15	GOT1000	Bus	Serial
	Supporting connection to Universal model QCPU	Designer2					
	Supporting connection to Q17nDCPU		Communication driver				
	Supporting connection to CNC C70	2.63R	CC-Link(G4)[03.07.**]	0	×	×	0
	Supporting the redundant system with the redundant type extension base unit						
	Supporting connection to AJ65BT-R2N						
	Supporting connection to CRnQ-700	2.73B	Communication driver	0	×	×	0
001:-1-	Supporting settings for the number of retries, the timeout time, and delay time		CC-Link(G4)[03.09.**]			• •	J
CC-Link connection (Via G4)	Supporting connection to Q13UDHCPU and Q26UDHCPU	2.77F	Communication driver CC-Link(G4)[03.12.**]	0	×	×	0
C .,	Supporting connection to Q02PHCPU and Q06PHCPU		Communication deiver				
	Supporting connection to Q03UDECPU, Q04UDEHCPU, Q06UDEHCPU, Q13UDEHCPU, and Q26UDEHCPU	2.82L Communication driver CC-Link(G4)[03.13.**]		0	×	×	×
	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	2.91V	Communication driver CC-Link(G4) [04.03.**]	0	×	×	×
	Supporting connection to Q170MCPU	2.96A	Communication driver CC-Link(G4) [04.04.**]	0	×	×	×
	Supporting connection to the Ethernet		Communication driver QJ71E71/AJ71(Q)E71 [01.02.**]		0		
	Supporting connection to Q172HCPU, Q173HCPU	2.09K		0	×	×	×
	Supporting automatic system switching for QCPU redundant system	2.32J	Communication driver QJ71E71/AJ71(Q)E71 [03.00.**]	0	0	×	×
	Supporting routing parameter setting with GT Designer2.	2.43V	Communication driver QJ71E71/AJ71(Q)E71 [03.01.**]	0	0	×	×
	Supporting connection to Universal model QCPU						
	Supporting connection to Q17nDCPU						
Ethernet	Supporting connection to CNC C70		Communication driver		0		
connection	Supporting the redundant system with the redundant type extension base unit	2.63R	QJ71E71/AJ71(Q)E71, Q17nNC[03.07.**]	0		×	×
	Supporting the redundant system with the remote I/O station of the MELSECNET/H network system				×		
	The communication driver name is changed.	2.73B	Communication driver	0	×	×	×
	Supporting connection to CRnQ-700 and CRnD-700	2.735	QJ71E71/AJ71(Q)E71,Q17nNC, CRnD-700 [03.09.**]	0	0	×	×
	Supporting connection to Q13UDHCPU and Q26UDHCPU	2.77F	Communication driver QJ71E71/AJ71(Q)E71,Q17nNC, CRnD-700 [03.12.**]	0	0	×	×
				Conti	nued to r	next n	age)

		Version of		GT	GT Soft	GT11	
Item	Description	GT Designer2	Version of OS	15	GOT1000	Bus	Serial
	The communication driver name is changed.			0	×	×	×
	Supporting connection to Q02PHCPU and Q06PHCPU	2.82L	Communication driver Ethernet(MELSEC),Q17nNC,		0	×	×
	Supporting connection to Q03UDECPU, Q04UDEHCPU, Q06UDEHCPU, Q13UDEHCPU, and Q26UDEHCPU	2.02L	CRnD-700 [03.13.**]	0	0	×	×
Ethernet connection	Supporting connection to QS001CPU			0	0	×	×
	Supporting connection to Q00UJCPU, Q00UCPU, Q01UCPU, Q10UDHCPU, Q20UDHCPU, Q10UDEHCPU, and Q20UDEHCPU	Communication driver 2.91V Ethernet(MELSEC), Q17nNC, CRnD-700 [04.03.**]		0	0	×	×
	Supporting connection to Q170MCPU	2.96A	Communication driver Ethernet(MELSEC), Q17nNC, CRnD-700 [04.04.**]	0	0	×	×
OMRON PLC connection	Extended device range monitored (The setting of TIM or CNT up to 4095, etc.)	2.09K	Communication driver OMRON SYSMAC [01.02.**]	0	0	×	0
	Supporting delay time setting	2.27D	Communication driver OMRON SYSMAC [02.04.**]	0	×	×	0
	Supporting the settings of Retry and Timeout Time.	2.43V	Communication driver OMRON SYSMAC [03.01.**]	0	×	×	0
	Supporting connection to CP1L	2.82L	Communication driver OMRON SYSMAC [03.13.**]	0	×	×	0
KEYENCE PLC	Supporting connection to KEYENCE PLC	2.18U	Communication driver KEYENCE KV700/1000 [02.02.**]	0	×	×	0
connection	Supporting connection to KV-3000 and KV-5000	2.77F	Communication driver KEYENCE KV700/1000 [03.12.**]	0	×	×	0
KOYO EI PLC connection	Supporting connection to KOYO EI PLC	2.82L	Communication driver KOYO KOSTAC/DL [03.13.**]	0	×	×	0
SHARP PLC	Supporting connection to SHARP PLC	2.09K	Communication driver SHARP JW [01.02.**]	0	×	×	0
connection	Supporting settings for the number of retries and the timeout time	2.73B	Communication driver SHARP JW [03.09.**]	0	×	×	0
	Supporting connection to TOSHIBA PLC	2.09K	Communication driver TOSHIBA PROSEC T/V [01.02.**]	0	×	×	0
TOSHIBA PLC connection	Supporting settings for the number of retries, the timeout time, and delay time	2.73B	Communication driver TOSHIBA PROSEC T/V [03.09.**]	0	×	×	0
	Supporting connection to model2000(S2T)	2.77F	Communication driver TOSHIBA PROSEC T/V [03.12.**]	0	×	×	0
TOSHIBA MACHINE PLC connection	Supporting connection to TOSHIBA MACHINE PLC	2.77F	Communication driver TOSHIBA MACHINE TCmini [03.12.**]	0	×	×	0

		Version of		GT	GT Soft	G ⁻	Γ11
Item	Description	GT Designer2	Version of OS	15	G1 S0π GOT1000	Bus	Serial
JTEKT PLC connection	Supporting connection to JTEKT PLC	2.32J	Communication driver JTEKT TOYOPUC-PC [03.00.**]	0	×	×	0
HITACHI IES PLC	Supporting connection to HITACHI IES PLC	2.09K	Communication driver HITACHI HIDIC H [01.02.**] HITACHI HIDIC H (Protocol 2) [01.02.**]	0	×	×	0
connection	Supporting settings for the number of retries, the timeout time, and delay time	2.73B	Communication driver HITACHI HIDIC H [03.09.**] HITACHI HIDIC H (Protocol 2) [03.09.**]	0	×	×	0
HITACHI PLC connection	Supporting connection to HITACHI PLC	2.43V	Communication driver HITACHI S10mini/S10V [03.01.**]	0	×	×	0
FUJI FA PLC connection	Supporting connection to FUJI FA PLC	2.43V	Communication driver FUJI MICREX-F [03.01.**]	0	×	×	0
	Supporting connection to PANASONIC PLC	2.09K	Communication driver MATSUSHITA MEWNET-FP [01.02.**]	0	×	×	0
	Supporting connection to FP- Σ	2.18U	Communication driver MATSUSHITA MEWNET-FP [02.02.**]	0	×	×	0
	Supporting connection to FP-X			0	×	×	0
PANASONIC PLC connection	The device range applicable to monitoring is extended. (Up to 991F for R and up to 911 for WR can be set.)	2.58L	Communication driver MATSUSHITA MEWNET-FP [03.03.**]	0	×	×	0
	Supporting settings for the timeout time and the delay time	2.73B	Communication driver MATSUSHITA MEWNET-FP [03.09.**]	0	×	×	0
	Communication driver name has been changed.	2.96A	Communication driver Panasonic MEWNET-FP [04.04.**]	0	×	×	0
	Supporting connection to MP2000 and MP3000	2.47Z	Communication driver YASKAWA GL/CP9200(SH/H)/ CP9300MS [03.02.**]	0	×	×	0
YASKAWA PLC	Supporting the Ethernet connection	2.47Z	Communication driver Ethernet(YASKAWA) [03.02.**]	0	0	×	×
connection	Supporting settings for the number of retries and the timeout time	2.73B	Communication driver YASKAWA GL/CP9200(SH/H)/ CP9300MS [03.09.**]	0	×	×	0
	Supporting connection to CP-312	2.77F	Communication driver Ethernet(YASKAWA) [03.12.**]	0	×	×	×
	Supporting connection to STARDOM	2.32J	Communication driver YOKOGAWA FA500/FA-M3/ STARDOM [03.00.**]	0	×	×	0
YOKOGAWA PLC connection	Supporting the Ethernet connection	2.47Z	Communication driver Ethernet(YOKOGAWA) [03.02.**]	0	0	×	×
	Supporting connection to the MODBUS® /TCP	2.73B	Communication driver MODBUS/TCP [03.09.**]	0	×	×	×
	1	1	·	Conti	nued to r	nevt r	ane)

		Version of		GT	GT Soft	G1	Γ11
Item	Description	GT Designer2	Version of OS	15	GOT1000	Bus	Serial
	Can use L device by MicroLogix 1000/ 1200/1500 series	2.18U	Communication driver AB MicroLogix [02.02.**]	0	×	×	0
ALLEN- BRADLEY PLC connection	Supporting connection to Control/ CompactLogix	2.58L	Communication driver AB Control/CompactLogix [03.03.**]	0	×	×	0
	Supporting the Ethernet connection	2.63R	Communication driver EtherNet/IP(AB)[03.07.**]	0	×	×	×
GE FANUC PLC connection	Supporting connection to GE FANUC PLC	2.82L	Communication driver GE Fanuc Automation(SNP-X) [03.13.**]	0	×	×	0
LS IS PLC connection	Supporting connection to LS IS PLC	2.90U	Communication driver LS Industrial Systems MASTER-K [04.02.**]	0	×	×	0
SCHNEIDER PLC connection	Supporting connection to the MODBUS® /TCP	2.73B	Communication driver MODBUS/TCP [03.09.**]	0	×	×	×
SIEMENS PLC connection	Supporting connection to SIEMENS S7- 200 series	2.18U	Communication driver SIEMENS S7-200 [02.02.**]	0	×	×	0
Microcomputer connection	Supporting XON/XOFF control Supporting interrupt extension	2.32J	Communication driver Computer [03.00.**]	0	×	×	0
MODBUS® /RTU connection	Supporting MODBUS® /RTU connection	2.96A	Communication driver MODBUS/RTU [04.04.**]	0	×	×	0
MODBUS® /TCP connection	Supporting MODBUS® /TCP connection	2.73B	Communication driver MODBUS/TCP [03.09.**]	0	×	×	×
OMRON	Supporting connection to OMRON temperature controller	2.18U	Communication driver OMRON THERMAC / INPANEL NEO [02.02.**]	0	×	×	0
temperature controller connection	The functions to automatically stop monitoring faulty stations and to disconnect communications with controllers are added.	2.58L	Communication driver OMRON THERMAC/INPANEL NEO [03.03.**]	0	×	×	0
SHINKO	Supporting connection to SHINKO indicating controller	2.43V	Communication driver Shinko Technos Controller [03.01.**]	0	×	×	0
indicating controller connection	The functions to automatically stop monitoring faulty stations and to disconnect communications with controllers are added	2.58L	Communication driver Shinko Technos Controller [03.03.**]	0	×	×	0
CHINO controller connection	Supporting connection to CHINO controller The functions to automatically stop monitoring faulty stations and to disconnect communications with controllers are added	2.58L	Communication driver CHINO Controllers(MODBUS) [03.03.**]	0	×	×	0

		Version of		GT	GT Soft	GT11		
Item	Description	GT Designer2	Version of OS	15	G1 S0π GOT1000	Bus	Serial	
FUJI SYS	Supporting connection to FUJI SYS temperature controller	2.32J	Communication driver FUJI PXR/PXG/PXH [03.00.**]	0	×	×	0	
temperature controller connection	The functions to automatically stop monitoring faulty stations and to disconnect communications with controllers are added	2.58L	Communication driver FUJI PXR/PXG/PXH [03.03.**]	0	×	×	0	
YAMATAKE	Supporting connection to YAMATAKE temperature controller	2.18U	Communication driver YAMATAKE SDC/DMC [02.02.**]	0	×	×	0	
temperature controller connection	The functions to automatically stop monitoring faulty stations and to disconnect communications with controllers are added	2.58L	Communication driver YAMATAKE SDC/DMC [03.03.**]	0	×	×	0	
YOKOGAWA temperature controller connection	Supporting connection to YOKOGAWA temperature controller	2.43V	Communication driver YOKOGAWA GREEN/UT100/ UT2000 [03.01.**]	0	×	×	0	
	The functions to automatically stop monitoring faulty stations and to disconnect communications with controllers are added	2.58L	Communication driver YOKOGAWA GREEN/UT100/ UT2000 [03.03.**]	0	×	×	0	
	Supporting connection to RKC temperature controller	2.18U	Communication driver RKC SR Mini HG(MODBUS) [02.02.**]	0	×	×	0	
RKC temperature controller connection	Supporting connection to SRZ The functions to automatically stop monitoring faulty stations and to disconnect communications with controllers are added	2.58L	Communication driver RKC SR Mini HG(MODBUS) [03.03.**]	0	×	×	0	
	Supporting connection to CB series	2.87R	Communication driver RKC SR Mini HG(MODBUS) [04.03.**]	0	×	×	0	
	Supporting connection to inverter	2.18U	Communication driver FREQROL 500/700 [02.02.**]	0	×	×	0	
Inverter connection	Setting range for Timeout Time has been changed. (3 to 30 seconds → 1 to 30 seconds)	2.43V	Communication driver FREQROL 500/700 [03.01.**]	0	×	×	0	
connection	Supporting connection to E700 series and V500/V500L series	2.63R	Communication driver FREQROL 500/700[03.07.**]	0	×	×	0	
	Supporting connection to D700 series	2.91V	Communication driver FREQROL 500/700 [04.03.**]	0	×	×	0	
	Supporting connection to servo amplifier	2.09K	Communication driver MELSERVO-J2S/M [01.02.**]	0	×	×	0	
Servo amplifier	Supporting connection to MELSERVO-J3 series	2.18U	Communication driver MELSERVO-J3,J2S/M [02.02.**]	0	×	×	0	
connection	Supporting connection to MR-J3-*T series	2.63R	Communication driver MELSERVO-J3, J2S/M [03.07.**]	0	×	×	0	
	Supporting writing to the E ² PROM area in parameter writing	2.32J	Communication driver MELSERVO-J3, J2S/M [03.00.**]	0	×	×	0	
	•			Conti	nued to r	nevt r	ane)	

		Version of			GT Soft	G1	⊺11
Item	Description	GT Designer2	Version of OS	GT 15	GOT1000	Bus	Serial
	Supporting the point table setting for MR-J2S-*CP	2.32J	Communication driver MELSERVO-J3, J2S/M [03.00.**]	0	×	×	0
	Supporting the test run mode	2.32J	Communication driver MELSERVO-J3, J2S/M [03.00.**]	0	×	×	0
Servo amplifier connection	Supporting settings for the number of retries, the timeout time, and delay time	2.73B	Communication driver MELSERVO-J3, J2S/M [03.09.**]	0	×	×	0
	Enables setting the host station address.	2.90U	Communication driver MELSERVO-J3, J2S/M [04.02.**]	0	×	×	0
	Supporting connection to MR-J2S-*CL	2.96A	Communication driver MELSERVO-J3, J2S/M [04.04.**]	0	×	×	0
Robot controller connection	Supporting connection to robot controller	2.77F	Communication driver QJ71E71/AJ71(Q)E71,Q17nNC, CRnD-700 [03.12.**]	0	0	×	×
CNC connection (MELDAS C6/ C64)	Supporting connection to CNC (MELDAS C6/C64 series)	2.18U	Communication driver A/QnA/QCPU, QJ71C24, MELDAS C6* [02.02.**] A/QnAQJ71E71/AJ71(Q)E71 [02.02.**] MELSECNET/10 [02.02.**] CC-Link(ID) [02.02.**]	0	0	×	0
	Communication driver name has been changed.	2.43V	Communication driver AJ71QC24, MELDAS C6* [03.01.**]	0	×	×	0
	Supporting settings for the number of retries, the timeout time, and delay time		Communication driver AJ71QC24, MELDAS C6* [03.09.**]	0	×	×	0
	Communication driver name has been changed.	2.73B	Communication driver QJ71E71/AJ71(Q)E71,Q17nNC, CRnD-700 [03.09.**]	0	×	×	×
GOT multidrop connection	Supporting the GOT multidrop connection	2.96A	Communication driver Multidrop(Host) [04.04.**] Multidrop(Slave) [04.04.**]	× *1	×	×	0
Barcode reader	Supporting connection to barcode reader	2.09K	Extended function OS Barcode [01.02.**]	0	×	0	0
connection	Supporting connection to 2D-code reader	2.27D	Extended function OS Barcode [02.04.**]	0	×	0	0
Printer connection	Supporting connection to printer	2.27D	Extended function OS Printer [02.04.**]	0	×	×	×
	Supporting the FA transparent function via USB	2.09K	GT15 Standard monitor OS [01.02.**] GT11 Standard monitor OS [01.02.**] Boot OS [01.02.**.C]	0	×	0	0
FA transparent	MT Developer (via USB), MR Configurator and FR Configurator are added as compatible software.	2.27D	Standard monitor OS [02.04.**]	0	×	0	0
	GX Configuration and PX Developer are added as compatible software.	2.32J	Standard monitor OS [03.00.**]	0	×	0	0

	5	Version of		GT	GT Soft	GT11	
Item	Description	GT Designer2	Version of OS		GOT1000	Bus	Serial
FA transparent	Supporting the computer link connection between the GOT and PLC on GX Developer	2.77F	Standard monitor OS [03.12.**]	0	×	0	0
	Supporting the computer link connection between the GOT and PLC on PX Developer	2.82L	Standard monitor OS [03.13.**]	0	×	0	0
	FX Configurator-FP is added as compatible software.						
	Supporting the Ethernet connection between the GOT and the PLC on GX Developer	2.96A	Standard monitor OS [04.04.**]	0	×	×	×
Multiple-GT11 connection	Connection with multiple GT11s	2.09K	Standard monitor OS [01.02.**]	×	×	0	0
External I/O device connection	Supporting connection to external I/O devices	2.58L	Extended function OS External I/O / Operation Panel [03.03.**]	0	×	×	×
RFID connection	Supporting connection to the RFID controller	2.73B	Extended function OS RFID [03.09.**]	0	×	0	0

^{*1} This item is supported by GT Works3 Version1.14Q or later.

3 Added GT Designer2 functions

(1) For GT16

Item	Description	Version of GT Designer2	Version of OS
Function for GT Designer2	All GT15 functions added by GT Designer2 Version2.90U or earlier are available.	2.90U	Standard monitor OS [04.02.**]
Project data matching	Project data matching is available between data stored in the personal computer and data opened with GT Designer2.	2.96A	-
Screen preview	Enables switching screens in the Screen Preview window.	2.96A	-
Auxiliary setting	The setting to adjust the order of displaying objects on the GOT to that of the overlapped objects on GT Designer2 is added.	2.96A	-

(2) For GT15, GT SoftGOT1000, and GT11

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
Ethernet download	Downloading the project data via Ethernet	2.09K	Standard monitor OS [01.02.**]	0	×	×
Pacia comment	Copying comments in column unit on Basic Comment or Comment Group, etc.	2.09K	-	0	0	0
Basic comment, comment group	Enables editing the comment group directly in settings for lamps and touch switches.	2.77F	-	0	0	0

O	
0	IC MONITOR NCTION
0	CNC MONITO FUNCTION
	щ
	STOR
0	BACKUP/RESTORE
0	12
0	CNC DATA I/O
0	
0	SFC MONITOR
0	14
×	LADDER EDITOR
0	
0	CES
0	APPENDI
×	
0	
ge) - 18	INDEX
- IÖ	

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
	Improved library structure and added import function	2.09K	-	0	0	0
	Improved user library structure, expanded the user library registration capacity, copying the figure data to the user library, etc.	2.18U	-	0	0	0
	Addition of fixed frame figure	2.18U	-	0	0	0
Library workspace	Enables setting the background color of the figures in the Library Editor screen.	2.47Z	-	0	0	0
	Enables sorting the figure data by subject or function and displaying different-shaped figures in the same color in the image list.	2.58L	-	0	0	0
	Real type data are added to the subject in the library.	2.63R	-	0	0	0
	Project data matching is available between data stored in the GOT and data opened with GT Designer2.	2.09K	Standard monitor OS [01.02.**]	0	0	0
Project data matching	Project data matching is available between the GOT and GT Designer2 even if the minor versions are not matched.	2.82L	-	0	×	0
	Project data matching is available between data stored in the personal computer and data opened with GT Designer2.	2.96A	-	0	0	0
Copy ON → OFF	Enables copying of only characters in lamp display, touch switch and comment display.	2.18U	-	0	0	0
Copy OFF → ON	Enables copying of only comment No. in bit lamp, touch switch, and comment display(bit).	2.73B	-	0	0	0
Import, Export	Enables editing of the settings for advanced alarm observation (advanced user alarm), alarm history, advanced recipe function and recipe function in the CSV file format and other format.	2.18U	-	0	0	0
	Items that can be imported or exported with the advanced alarm observation and alarm history are added. (Device No., comment No., detail No., and others)	2.77F	-	0	0	×
Print	Enables printing of header and footer	2.18U	-	0	0	0
Edit	Enables duplicating and consecutive copying of figures and objects.	2.90U	-	0	0	0
Data View	Enables changing of the settings for the respective objects in grouped objects	2.18U	-	0	0	0
Batch Edit	Enables global replacement of channel No.	2.18U	-	0	0	×
Screen Preview	Enables checking for security level switching and language switching in image after switching	2.18U	-	0	0	0
			(Con	tinue	d to next p	age)

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
Screen preview	Enables switching screens in the Screen Preview window.	2.96A	-	0	0	0
Wizard	Wizard for setting the GOT type, controller type and communication settings when creating a new project	2.18U	-	0	0	0
Screen script, project script	Settings on the Script Edit dialog are available for screen script and project script.	2.27D	-	0	0	×
Auxiliary setting	Setting of maintaining screen numbers of the screens being displayed (System Information) during screen switching is added.	2.27D	-	0	0	0
Auxiliary Setting	The setting to adjust the order of displaying objects on the GOT to that of the overlapped objects on GT Designer2 is added.	2.96A	Standard monitor OS [04.04.**]	0	0	0
	Supports expansion/reduction when multiple objects and shapes are selected.	2.32J	-	0	0	0
Expansion / Reduction	Supports automatically zooming in and out objects and figures suitable for the screen size when the GOT type is changed to a GOT type with different resolution.	2.73B	-	0	0	0
Screen capture	Function for capturing the specified range and loading to GT Designer2	2.43V	-	0	0	0
Zoom	Interval of magnification specification has been changed. +/- buttons have been added. Zoom in/zoom out operations using the "Ctrl key" and "Mouse wheel" have been added.	2.43V	-	0	0	0
Guidelines	Lines to align figures and objects are displayed when arranging a placed figure or object.	2.90U	-	0	0	0
	Holds the previous downloaded drive.	2.47Z	-	0	×	0
Communication	 Enables updating BootOS without the standard monitor OS updated when only BootOS is already installed on the GOT. Enables installing the standard monitor OS, the communication driver, the extended OS or the option OS at once when only BootOS is already installed in the GOT. 	2.58L	BootOS [03.03.**.P]	0	×	0
	Enables installing OSs on the A drive with the OS boot drive set to the A drive.	2.73B	-	0	×	×
Preferences	Enables setting the maximum number of screens to be displayed on GT Designer2.	2.63R	-	0	0	0
Device list	Functions of the collection target selection, jump, file output, and others are added.	2.73B	-	0	0	0

Ų,
Ä
Ξ

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
Text list	Enables displaying the direct input texts in a list.	2.90U	-	0	0	0
Reading BMP or JPEG image data	Enables displaying BMP or JPEG image data reduced to a resolution of 2000 × 1600 or less on GT Designer2.	2.77F	-	0	0	0

4 Added common settings/object functions

(1) For GT16

Item	Description	Version of GT Designer2	Version of OS	
Common setting	All GT15 functions added by GT Designer2 Version2.90U or earlier are available.	2.90U	Standard monitor OS [04.02.**]	
Figure	Supporting logo text	2.96A	Standard monitor OS [04.04.**]	
Standard font	Supporting Chinese(Traditional)(supporting Europe)	2.91V	Standard monitor OS [04.03.**]	
Window screen	Supporting the overlap windows 3, 4, and 5	2.90U	Standard monitor OS [04.02.**]	
	The settable range of GS is extended to the range from GS0 to GS2047.	2.90U	Standard monitor OS [04.02.**]	
GOT internal device	For the GOT multidrop connection, the device to store the GOT station number is added.	*1	-	
	The device to notify the RGB signal input status is added.			
	Devices for the MODBUS® /RTU connection are added.	2.96A	Standard monitor OS [04.04.**]	
Screen switching function	Enables setting the screen switching devices for the overlap windows 3, 4, and 5.	2.90U	Standard monitor OS [04.02.**]	
Station No. Switching Function	Enables setting the station No. switching devices for the overlap windows 3, 4, and 5.	2.90U	Standard monitor OS [04.02.**]	
Cyclene information	System information regarding the overlap windows 3, 4, and 5 is added.	2.90U	Standard monitor OS [04.02.**]	
System information	System information regarding the E drive is added.			
	The system signal 2-3 is added.	2.96A	Standard monitor OS [04.04.**]	
	Supporting the external authentication (RFID) for the operator authentication	0.041/	Extended function OS Operator authentication [04.03.**] RFID [04.03.**]	
Security	Supporting the fingerprint authentication for the operator authentication	2.91V	Extended function OS Operator authentication [04.03.**] Fingerprint Authentication [04.03.**]	
	Enables notifying the login operator name.	2.064	Extended function OS Operator authentication [04.04.**]	
	Supporting the GOT operator management information conversion tool	2.96A	-	
Device setting	Enables reading or writing a device when the 32K-block unit is splitted.	2.91V	Standard monitor OS [04.03.**]	
	Enables setting the multi-channel Ethernet connection.	2.90U	Standard monitor OS [04.02.**]	
Communication settings	Enables setting multiple drivers for external devices, including a bar code reader. (One driver can be set for one type of external device.)	2.96A	Standard monitor OS [04.04.**]	

Item	Description	Version of GT Designer2	Version of OS
RGB display	Enables using up to two channels when the GT16M-R2 is used for the RGB input unit.	2.90U	Standard monitor OS [04.02.**] Extended function OS Video/RGB [04.02.**]
	Function to display or record video images taken by a video camera connected to the multimedia unit and to play video files stored in a CF card.	2.90U	Standard monitor OS [04.02.**] Extended function OS Multimedia [04.02.**]
Multimedia function	Enables sending video files to the personal computer by using the Ethernet interface of the multimedia unit. Enables recording a video image for approximately 1500	2.96A	Standard monitor OS [04.04.**]
	minutes (200 video files). Enables fast-forwarding and playing videos in slow motion.	2.90A	Extended function OS Multimedia [04.04.**]
	Enables recording or playing video files with sound.	2.98C	
Object function	All GT15 functions added by GT Designer2 Version2.90U or earlier are available.*2	2.90U	Standard monitor OS [04.02.**]
	[Batch Self Check], [USB Device Display], and [Multimedia] are added to [Switch Action] of the special function switch. The go to screen switch is applicable to the overlap windows	2.90U	Standard monitor OS [04.02.**]
Touch switch	4, and 5. adder Editor1 and [Operator Management] are added to		
	[Switch Action] of the special function switch.	2.96A	Standard monitor OS [04.04.**]
Numerical display/ Numerical input	Enables setting the asterisk display.	2.96A	Standard monitor OS [04.04.**]
ASCII display / ASCII input	Enables setting the asterisk display.	2.96A	Standard monitor OS [04.04.**]
Historical Trend Graph	Enables displaying logging data at the specified time on a trend graph.	2.96A	Standard monitor OS [04.04.**]
RFID function	Supporting the dedicated protocol (ICU-60S and ICU- 215(Mifare) manufactured by MARS TECHNO SCIENCE Corp.)	2.91V	Extended function OS RFID [04.03.**]
Project Script	The file operation functions (file_copy, file_xcopy) are added.	2.96A	Standard monitor OS [04.04.**]
	Supporting the overlap windows 3, 4, and 5	2.90U	Standard monitor OS [04.02.**]
Screen Script	The file operation functions (file_copy, file_xcopy) are added.	2.96A	Standard monitor OS [04.04.**]
Key Code	The key code for the historical trend graph (Display position time specification jump) is added.	2.96A	Standard monitor OS [04.04.**]

^{*1} This item is supported by GT Works3 Version1.14Q or later.

(2) For GT15, GT SoftGOT1000, and GT11

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
	JPEG file reading enabled	2.09K	Standard monitor OS [01.02.**]	0	0	×
	Function to import IGES format data.	2.43V	-	0	0	0
Figure	Enables adjusting image qualities for reading JPEG files.	2.47Z	-	0	0	×
	Supporting piping	2.73B	Standard monitor OS [03.00.**]	0	0	0
	Enables setting the coordinates and the size using values.	2.90U	-	0	0	0

^{*2} For the ASCII display or ASCII input, the Kana-kanji conversion is not available. Only the Kana-kanji conversion (enhanced version) is available.

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
Figure	Supporting logo text	2.96A	Standard monitor OS [04.04.**]	0	0	0
Object	Enables setting the coordinates and the size using values.	2.90U	-	0	0	0
	Windows [®] fonts applicable	2.09K	Standard monitor OS [01.02.**]	0	0	0
Text	Stroke font applicable	2.43V	Standard monitor OS [03.01.**]	0	0	×
	Enables specifyng of background color.	2.32J	Standard monitor OS [03.00.**]	0	0	0
	The following fonts are supported. Japanese 12dot Japanese 16dot Gothic Japanese 16dot Mincho	2.04E	Standard monitor OS [01.01**]	0	0	0
Standard font	The following fonts are supported. Japanese (supporting Europe) 12dot Japanese (supporting Europe) 16dot Gothic Japanese (supporting Europe) 16dot Mincho Chinese (Simplified) 12dot Chinese (Simplified) 16dot Mincho Chinese (Simplified) (supporting Europe) 12dot Chinese (Simplified) (supporting Europe) 16dot Mincho	2.27D	Standard monitor OS [02.04.**] Boot OS [G]	0	0	0
Standard font	Supporting Chinese (Traditional) (supporting Europe)	2.91V	Standard monitor OS [04.03.**]	0	0	0
TrueType font	Supporting the TrueType numerical font (7-segment)	2.90U	Standard monitor OS [04.02.**] Boot OS [04.02.**U]	0	0	0
	Enables setting the KANJI region.	2.47Z	Standard monitor OS [03.02.**]	0	0	×
	Supporting Thai	2.47Z	Standard monitor OS [03.02.**]	0	0	×
Stroke font	The following font name is changed. • Stroke Standard Font(JPN) • The following fonts are added. • Stroke Standard Font(China GB) • Stroke Standard Font(China GB)(supporting Hangul)	2.58L	Extended function OS Stroke Standard Font [03.03.**]	0	×	×
	The following font is added. • Stroke Font(JPN)	2.58L	Option OS Stroke Font(JPN) [03.03.**]	0	×	×
KANJI Region	Supporting Chinese (Traditional)	2.18U	Standard monitor OS [02.02.**] Option OS Standard Font (China Big5) [02.02.**]	0	0	×
Window screen	Supporting the overlap windows 3, 4, and 5	2.96A	-	×	0	×
GOT internal	System alarm information, printer status information, and GT SoftGOT1000 end device are added.	2.27D	Standard monitor OS [02.04.**]	0	0	0
device	The devices for the trigger buffer of the MES interface are added.	2.47Z	Standard monitor OS [03.02.**] Option OS MES Interface [03.02.**]	0	×	×

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
	The settable range of GS is extended to the range from GS0 to GS2047.	2.96A	-	×	0	×
GOT internal device	For the GOT multidrop connection, the device to store the GOT station number is added.	2.96A	Standard monitor OS [04.04.**]		×	0
	Devices for the MODBUS® /RTU connection are added.	2.96A			×	0
GOT Type	Supporting vertical installation type display	2.18U	Standard monitor OS [02.02.**]	×	×	0
	"ON" and "OFF" can be set.	2.43V	Standard monitor OS [03.01.**]	0	0	0
Screen switching function	Enables setting the screen switching devices for the overlap windows 3, 4, and 5.	2.96A	-	×	0	×
Station No.	Designation of the channel No. for which station No. is switched is possible.	2.18U	Standard monitor OS [02.02.**]	0	×	×
Switching Function	Enables setting the station No. switching devices for the overlap windows 3, 4, and 5.	2.96A	-	×	0	×
		2.00A	Standard monitor OS [01.00.**]	0	0	×
Language	Language switching device can be used.	2.18U	Standard monitor OS [02.02.**]	0	0	0
Switching Device	Enables setting the column No. of the comments to be displayed when the device value is out of range.	2.90U	Standard monitor OS [04.02.**]	0	0	0
Password Setting	Password can be set for the connection of motion controller and servo amplifier.	2.18U	Standard monitor OS [02.02.**]	0	×	0
	System information of report function and print are added.	2.27D	Standard monitor OS [02.04.**]	×	×	0
System	D drive automatic recovery status notification signal is added.	2.32J	Standard monitor OS [03.00.**]	×	×	0
mormation	System information regarding B drive has been added.	2.43V	Standard monitor OS [03.01.**]	0	0	×
	The system signal 2-3 is added.	2.96A	Standard monitor OS [04.04.**]	0	×	×
	The name [Password] is changed to [Security] in the system environment.	2.58L	Standard monitor OS [03.03.**]	0	0	×
	Enables setting the operator authentication.	2.58L	Extended function OS Operator authentication [03.03.**]	0	0	×
Security	Supporting the external authentication (RFID) for the operator authentication	2.91V	Extended function OS Operator authentication [04.03.**] RFID [04.03.**]	0	×	×
Security	Supporting the fingerprint authentication for the operator authentication	2.317	Extended function OS Operator authentication [04.03.**] Fingerprint Authentication [04.03.**]	0	×	×
	Enables notifying the login operator name.	2.96A	Extended function OS Operator authentication [04.04.**]	0	0	×
	Supporting the GOT operator management information conversion tool	2.30%	-	0	0	×
GOT Setup	In clock management, both adjust and broadcast can be set.	2.18U	Standard monitor OS [02.02.**]	0	×	0

APPENDICES	INDEX

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
	Data save device of MELSEC-Q / QnA ladder monitor data can be set at GT Designer2.	2.18U	-	0	×	×
	Automatic program read at the start of ladder monitor for MELSEC-Q/QnA/ Priority Level Comment can be set.	2.43V	-	0	×	×
	Time setting for call key ON until the start up of utility can be set (for 1-point pressing).	2.18U	Standard monitor OS [02.02.**]	0	×	×
GOT Setup	Alarm can be set to be displayed in system language switching or battery drops.	2.27D	Standard monitor OS [02.04.**]	0	0	0
	Enables the backup/restore setting.			0	×	×
	Enables the setting for monitoring local devices.	2.58L	-	0	×	×
	Enables setting the drive for collectively reading comment data.			0	×	×
	Enables settings for the backup trigger setting and the maximum number of backup data.	2.73B	-	0	×	×
Clock Setting	Designation of the channel No. used for adjusting and broadcasting is possible.	2.18U	Standard monitor OS [02.02.**]	0	×	×
	Function for setting any screen for the GOT startup screen	2.09K	Standard monitor OS [01.02.**] Boot OS [01.02.**.C]	0	0	0
Startup Logo	Enables displaying a BMP data stored in the A drive as the startup logo when the OS boot drive is set to the A drive.	2.73B	Boot OS [03.09.**.S]	0	×	×
GT11 Handy GOT Setting	Setting of the grip switch LED of GT11 Handy GOT	2.18U	Standard monitor OS [02.02.**]	×	×	0
Dialog window	System messages to be displayed on GOT can be customized or created by the user.	2.27D	Standard monitor OS [02.04.**]	0	×	0
	Function to save the GOT operation performed by the user as a history	2.32J	Standard monitor OS [03.00.**] Option OS Operation Log [03.00.**]	0	0	×
	Function for converting multiple files	2.43V	-	0	0	×
Operation log	The binary format file output can be converted to CSV/Unicode format file by external control.	2.43V	Standard monitor OS [03.01.**]	0	0	×
	Enables saving the operation log for the operator authentication.	2.58L	Standard monitor OS [03.03.**] Option OS Operation Log [03.03.**] Extended function OS Operator authentication [03.03.**]	0	0	×
Comment	Comment group can be used.	2.00A	Standard monitor OS [02.02.**]	0	0	×
	Comment group can be used.	2.18U	Standard monitor OS [02.02.**]	0	0	0
Part	Enables setting the background color of the figures in the Parts Editor screen.	2.47Z	-	0	0	0

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
	User defined key window display can be switched in synchronization with the language switching device.	2.18U	Standard monitor OS [02.02.**]	0	0	0
Key Window	In the user defined key window, input range (maximum value) and input range (minimum value) are displayed.	2.18U	Standard monitor OS [02.02.**]	0	0	0
	The current value is displayed in the key window.	2.82L	Standard monitor OS [03.13.**]	0	0	0
Device setting	65 or later station numbers in the MELSECNET/G network system can be set with using Universal model QCPU as a relay station.	2.63R	Standard monitor OS [03.07.**]	0	0	×
	Enables reading or writing a device when the 32K-block unit is splitted.	2.91V	Standard monitor OS [04.03.**]	0	0	0
Communication settings	Enables setting multiple drivers for external devices, including a bar code reader. (One driver can be set for one type of external device.)	2.96A	Standard monitor OS [04.04.**]	0	×	×
Object rename	Function to allow setting of object name	2.32J	Standard monitor OS [03.00.**]	0	0	0
Lamp	Windows [®] fonts applicable	2.09K	Standard monitor OS [01.02.**]	0	0	0
	Stroke font applicable	2.43V	Standard monitor OS [03.01.**]	0	0	×
	Figure created as a part can be used to a lamp.	2.43V	Standard monitor OS [03.01.**]	0	0	0
	[Comment Group] can be used.	2.43V	Standard monitor OS [03.01.**]	0	0	0
	Enables specifying the transparent color of a figure when using an image file as a figure.	2.47Z	Standard monitor OS [03.02.**]	0	0	×
	Windows [®] fonts applicable	2.09K	Standard monitor OS [01.02.**]	0	0	0
	Stroke font applicable	2.43V	Standard monitor OS [03.01.**]	0	0	0
Touch switch	Figure created as a part can be used to a touch switch.	2.43V	Standard monitor OS [03.01.**]	0	0	×
	Data change switch can be used.	2.32J	Standard monitor OS [03.00.**]	0	0	0
	[Comment Group] can be used.	2.43V	Standard monitor OS [03.01.**]	0	0	0
	[Adjust Text Size] setting is possible.	2.43V	Standard monitor OS [03.01.**]	0	0	0
	Auto repeat can be used.	2.43V	Standard monitor OS [03.01.**]	0	0	0
	The toutch switch on the ladder monitor with device search function can be used.	2.43V	Standard monitor OS [03.01.**]	0	0	0
Touch switch	[PX Developer Function call] is added to [Switch Action] of the special function switch.	2.47Z	Standard monitor OS [03.02.**]	×	0	×
	Enables specifying the transparent color of a figure when using an image file as a figure.	2.47Z	Standard monitor OS [03.02.**]	0	0	×

	=
	APPENDICES
	INDEX

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
	[FX List Monitor], [Operator Information Management], [Log-in/Log-out (Operator Authentication)], [Password Change (Operator Authentication)], and [Backup/ Restore] are added to [Switch Action] of the special function switch.	2.58L	Standard monitor OS[03.03.**]	0	0	×
Touch switch	The name [Password] is changed to [Password (Security Level)] in [Switch Action] of the special function switch.			0	0	0
	[CNC Data Input/Output] is added to [Switch Action] of the special function switch.	2.63R	Standard monitor OS [03.07.**]	0	×	0
	[SFC Monitor] is added to [Switch Action] of the special function switch.	2.77F	Standard monitor OS [03.12.**]	0	×	0
	[Ladder Editor] and [Operator Management] are added to [Switch Action] of the special function switch.	2.96A	Standard monitor OS [04.04.**]	0	×	×
	Setting to display input value when entering the value at input target object position is possible.	2.32J	Standard monitor OS [03.00.**]	0	×	×
	Format String setting is possible.	2.43V	Standard monitor OS [03.01.**]	0	0	0
Numerical display/ Numerical input	When Bit Trigger is not met, whether to enable "Hold Display" can be selected.	2.43V	Standard monitor OS [03.01.**]	0	0	0
	Enables setting the TrueType Numerical for the font.	2.90U	Standard monitor OS [04.02.**]	0	0	0
	Enables setting the asterisk display.	2.96A	Standard monitor OS [04.04.**]	0	×	×
	Function to store NULL (0x00) at the end of input characters	2.18U	Standard monitor OS [02.02.**]	0	0	0
	Function to convert characters input in Kana into Kanji	2.18U	Standard monitor OS [02.02.**] Option OS KANA KANJI (JP) [02.02.**]	0	0	×
	Alignment setting is added.	2.27D	Standard monitor OS [02.04.**]	0	0	0
ACCII diamber /	Setting for displaying an input value at the input target object position is possible.	2.32J	Standard monitor OS [03.00.**]	0	0	0
ASCII display / ASCII input Kana into Kanji Alignment setting is added. Setting for displaying an input value at the input target object position is possible. When Bit Trigger is not met, whether to enable "Hold Display" can be selected.	2.43V	Standard monitor OS [03.01.**]	0	0	0	
	The character display position during the ASCII input can be set to [Left] or [Right].	2.82L	Standard monitor OS [03.13.**]	0	0	0
	Supporting the Kana-kanji conversion (enhanced version)	2.90U	Standard monitor OS [04.02.**] Option OS KANA KANJI (JPN) (Enhanced Version) [04.02.**]	0	0	×
	Enables setting the asterisk display.	2.96A	Standard monitor OS [04.04.**]	0	0	0
Clock display	Enables setting the TrueType Numerical for the font.	2.90U	Standard monitor OS [04.02.**]	0	0	0
Data List	When Bit Trigger is not met, whether to enable "Hold Display" can be selected.	2.43V	Standard monitor OS [03.01.**]	0	0	0
Comment Display	When Bit Trigger is not met, whether to enable "Hold Display" can be selected.	2.43V	Standard monitor OS [03.01.**]	0	0	0
	The simple comment is added.	2.77F	Standard monitor OS [03.12.**]	0	0	0

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
Advanced alarm popup display	Enables setting whether to enable or disable the display position switching.	2.90U	Standard monitor OS [04.02.**]	0	0	0
User alarm	Number of alarms settable for GT11 is extended to the same as GT15 (Up to 8192 alarms).	2.27D	Standard monitor OS [02.04.**]	0	0	0
	When Bit Trigger is not met, whether to enable "Hold Display" can be selected.	2.43V	Standard monitor OS [03.01.**]	0	0	0
Alarm history	Number of alarms settable for GT11 is extended to the same as GT15 (Up to 3072 alarms).	2.27D	Standard monitor OS [02.04.**]	0	0	0
	Function to save alarm history data to the A drive (standard CF card) for GT11	2.27D	Standard monitor OS [02.04.**]	0	0	0
	Function to display the cursor by touching an alarm, and function to output the corresponding comment No. to a device	2.32J	Standard monitor OS [03.00.**]	0	0	0
	The comment group application	2.73B	Standard monitor OS [03.09.**]	0	0	0
Scrolling alarm display	The scrolling alarm display applicable	2.73B	Standard monitor OS [03.09.**]	×	×	0
Advanced Alarm	Function for detecting alarm even at the fall of bit device with Advanced User Alarm	2.09K	Standard monitor OS [01.02.**]	0	0	×
	Function to display a cursor by touching an alarm and to output the corresponding comment No. to a device.	2.43V	Standard monitor OS [03.01.**]	0	0	×
	The binary format file output can be converted to CSV/Unicode format file by external control.	2.43V	Standard monitor OS [03.01.**]	0	0	×
	For the advanced alarm display, the title row can be set to be hidden.	2.82L	Standard monitor OS [03.13.**]	0	0	×
	For the advanced alarm display, the alarm information in the top row is output if the external output trigger is on when the cursor is hidden.	2.82L	Standard monitor OS [03.13.**]	0	0	×
Parts Display/ Parts Movement	Function for using BMP/JPEG data in memory card as parts	2.09K	Standard monitor OS [01.02.**]	0	0	×
	Settings for BMP/JPEG file parts can be made on each object.	2.43V	Standard monitor OS [03.01.**]	0	0	×
Parts Display/ Parts Movement	When Bit Trigger is not met, whether to enable "Hold Display" can be selected.	2.43V	Standard monitor OS [03.01.**]	0	0	0
	Enables specifying the transparent color of a figure when using an image file as a figure.	2.47Z	Standard monitor OS [03.02.**]	0	0	×
Panelmeter	Windows [®] fonts applicable	2.09K	Standard monitor OS [01.02.**]	0	0	0
	Stroke font applicable	2.43V	Standard monitor OS [03.01.**]	0	0	×
	Up to 101 points can be set for scale, value number.	2.27D	Standard monitor OS [02.04.**]	0	0	0
		Standard monitor OS [03.01.**]	0	0	0	
Level	When Bit Trigger is not met, whether to enable "Hold Display" can be selected.	2.43V	Standard monitor OS [03.01.**]	0	0	0

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
Trend graph	Up to 101 points can be set for scale, value number.	2.27D	Standard monitor OS [02.04.**]	0	0	0
	Function to collect data only when display trigger is met is added.	2.32J	Standard monitor OS [03.00.**]	0	0	0
Line graph	Up to 101 points can be set for scale, value number.	2.27D	Standard monitor OS [02.04.**]	0	0	0
	Function to collect data only when display trigger is met is added.	2.32J	Standard monitor OS [03.00.**]	0	0	0
	When Bit Trigger is not met, whether to enable "Hold Display" can be selected.	2.43V	Standard monitor OS [03.01.**]	0	0	0
	Up to 101 points can be set for scale, value number.	2.27D	Standard monitor OS [02.04.**]	0	0	0
Bar graph	Function to collect data only when display trigger is met is added.	2.32J	Standard monitor OS [03.00.**]	0	0	0
	When Bit Trigger is not met, whether to enable "Hold Display" can be selected.	2.43V	Standard monitor OS [03.01.**]	0	0	0
Statistics graph	Up to 101 points can be set for scale, value number.	2.27D	Standard monitor OS [02.04.**]	0	0	0
	Function to collect data only when display trigger is met is added.	2.32J	Standard monitor OS [03.00.**]	0	0	0
	When Bit Trigger is not met, whether to enable "Hold Display" can be selected.	2.43V	Standard monitor OS [03.01.**]	0	0	0
Scatter graph	Up to 101 points can be set for scale, value number.	2.27D	Standard monitor OS [02.04.**]	0	0	0
	Function to collect data only when display trigger is met is added.	2.32J	Standard monitor OS [03.00.**]	0	0	0
Historical Trend Graph	Function to display the data collected by the logging function in trend graph format	2.18U	Standard monitor OS [02.01.**]	0	0	×
	Enables displaying logging data at the specified time on a trend graph.	2.96A	Standard monitor OS [04.04.**]	0	0	×
Time Action	Second specification and external control are possible.	2.43V	Standard monitor OS [03.01.**]	0	0	0
Logging Function	Function to collect and accumulate device values	2.18U	Standard monitor OS [02.02.**] Option OS Logging [02.02.**]	0	0	×
	Function for converting multiple files	2.43V	-	0	0	×
	The binary/CSV/Unicode format files output can be stored to another folder by external control.	2.43V	Standard monitor OS [03.01.**]	0	0	×
Device data transfer function	Function to read the device value and write in the other device when the trigger condition is satisfied.	2.73B	Extended function OS Device data transfer [03.09.**]	0	×	×
Recipe function	Number of devices settable for one recipe in GT11 is extended to the same as GT15 (Up to 8192 devices).	2.27D	Standard monitor OS [02.04.**] Option OS Recipe [02.04.**]	0	0	0
	Function to save recipe data of GT11 in CSV file format	2.27D	Standard monitor OS [02.04.**] Option OS Recipe [02.04.**]	0	0	0

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
Recipe function	Function to save recipe data to the A drive (standard CF card) for GT11	2.27D	Standard monitor OS [02.04.**] Option OS Recipe [02.04.**]	0	0	0
	The extended function of the existing recipe function	2.09K	Standard monitor OS [01.02.**] Option OS Advanced recipe [01.02.**]	0	0	×
	Function for converting multiple files	2.43V	-	0	0	×
Advanced Recipe	The binary format file output can be converted to CSV/Unicode format file by external control.	2.43V	Standard monitor OS [03.01.**]	0	0	×
	The number of records that can be set is changed to 2000.	2.58L	Standard monitor OS [03.03.**] Option OS Advanced Recipe [03.03.**]	0	0	×
Report function	Function to print the colleted data	2.27D	Standard monitor OS [02.04.**] Extended function OS Report [02.04.**]	0	0	×
Hard copy function	Compatible with the printer output	2.27D	Standard monitor OS [02.04.**] Extended function OS Printer [02.04.**]	0	×	×
	Thumbnail Output can be set.	2.43V	Standard monitor OS [03.01.**]	0	0	×
Operation panel function	Enables setting the operation panel.	2.58L	Extended function OS External I/O / Operation Panel [03.03.**]	0	×	×
Sound output function	Enables setting the sound output.	2.58L	Extended function OS Sound Output [03.03.**]	0	0	×
	Function for loading the data read with bar cord reader to PLC CPU	2.09K	Standard monitor OS [01.00.**]	0	×	0
Barcode	Number of settable devices is extended from 32 to 1024 points.	2.27D	Standard monitor OS [02.04.**]	0	×	0
	Space (0x20) or NULL (0x00) can be selected for blank device.	2.27D	Standard monitor OS [02.04.**]	0	×	0
RFID function	Function to write in the devices which data are read by the RFID reader/writer.	2.73B	Extended function OS RFID [03.09.**]	0	×	0
	Supporting the dedicated protocol (ICU-60S and ICU-215(Mifare) manufactured by MARS TECHNO SCIENCE Corp.)	2.91V	Extended function OS RFID [04.03.**]	0	×	0
Video display	Function to display an image taken by a video camera on the GOT	2.32J	Standard monitor OS [03.00.**] Extended function OS Video/RGB [03.00.**]	0	×	×
RGB display	Function to display the personal computer screen on the GOT	2.32J	Standard monitor OS [03.00.**] Extended function OS Video/RGB [03.00.**]	0	×	×
Remote personal computer operation function	Function to operate the mouse pointer on the personal computer by touching the personal computer screen displayed on the GOT using the RGB display function.	2.82L	Standard monitor OS [03.13.**] Extended function OS PC Remote Operation [03.13.**]	0	×	×
Set overlay screen	Number of screens that can be called on GT11 is extended to the same as GT15 (Up to 2047 screens).	2.27D	Standard monitor OS [02.04.**]	0	0	0

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
	Screen calling setting with dragging is possible.	2.43V	-	0	0	0
Set overlay screen	Specifying of placement position (Front/ Back) for the basic and called screens is possible.	2.43V	Standard monitor OS [03.01.**]	0	0	0
	[Disable background colors of overlay screen when setting an overlay screen] can be set.	2.58L	Standard monitor OS [03.03.**]	0	0	0
Test function	Function for changing device value with displaying test window.	2.09K	Standard monitor OS [02.02.**]	0	×	0
	Function to execute scripts in unit of project file	2.00A 2.18U	Standard monitor OS [01.00.**] Standard monitor OS [02.02.**]	0	0	×
Project Script	Word device values can be converted into data in the specified data type, and the GOT can read or write the data. (Data type conversion function)	2.73B	Standard monitor OS [03.09.**]	0	0	0
	The file operation functions are added.	2.77F	Standard monitor OS [03.12.**]	0	0	0
	The file operation functions (file_copy, file_xcopy) are added.	2.96A	Standard monitor OS [04.04.**]	0	0	0
Screen Script	Function to execute scripts in unit of	2.00A	Standard monitor OS [01.00.**]	0	0	×
	screen	2.18U	Standard monitor OS [02.02.**]	0	0	0
	Word device values can be converted into data in the specified data type, and the GOT can read or write the data. (Data type conversion function)	2.73B	Standard monitor OS [03.09.**]	0	0	0
	The file operation functions are added.	2.77F	Standard monitor OS [03.12.**]	0	0	0
	The file operation functions (file_copy, file_xcopy) are added.	2.96A	Standard monitor OS [04.04.**]	0	0	0
Object Script	Function to execute scripts in unit of object	2.18U	Option OS Object Script [02.02.**]	0	0	×
Object Script	"width", "height", and "decimal_point" are added to the object property.	2.90U	Option OS Object Script [04.02.**]	0	0	×
	Key codes for increment key and decrement key are added.	2.18U	Standard monitor OS [02.02.**]	0	0	0
	Key code for historical trend graph is added.	2.18U	Standard monitor OS [02.02.**]	0	0	×
	Key code used for Kana Kanji conversion is added.	2.18U	Standard monitor OS [02.02.**]	0	0	×
Key Code	Key codes for user ID ascending/ descending order movement of cursor are added.	2.27D	Standard monitor OS [02.04.**]	0	0	0
	Key codes used for the Kana-kanji conversion (enhanced version) are added.	2.90U	Standard monitor OS [04.02.**]	0	0	×
	The key code for the historical trend graph (Display position time specification jump) is added.	2.96A	Standard monitor OS [04.04.**]	0	0	×

5 Other functions added

(1) For GT16

Item	Description	Version of GT Designer2	Version of OS
Other function	All GT15 functions added by GT Designer2 Version2.90U or earlier are available.	2.90U	Standard monitor OS [04.02.**]
Q motion monitor function	Supporting Q170MCPU	2.96A	Option OS Q motion monitor [04.04.**]
Backup/restore function	Enables setting the E drive for the storage location for the backup data or backup setting.	2.90U	Extended function OS Backup/Restore [04.02.**]
backup/restore function	Supporting Q170MCPU	2.96A	Extended function OS Backup/Restore [04.04.**]
CNC data I/O function	Enables specifying the E drive for the target to input or output the CNC data.	2.90U	Extended function OS CNC Data I/O [04.02.**]
CNC data I/O function	Cycle monitor data can be input and output	2.96A	Extended function OS CNC Data I/O [04.04.**]
Ladder editor	Function to edit the sequence program stored in the controller by using the GOT	2.96A	Extended function OS GOT Platform Library [04.04.**] Option OS Ladder editor [04.04.**] GOT Function Expansion Library [04.04.**]
Multi-channel function	Supporting connection to multiple controllers on the Ethernet network	2.90U	Standard monitor OS [04.02.**] Communication driver Use the communication driver, [04.02.**] or later for each connection.
Tag import function	Function to import a tag file created by the third party programming software to GT Designer2, and set a tag as a device.	2.91V	Standard monitor OS [04.03.**]
OS installation	The A drive and E drive are available for installing the OS at power-on.	2.91V	Standard monitor OS [04.03.**] BootOS [04.03.**]

(2) For GT15, GT SoftGOT1000, and GT11

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
Utility	Displays details in OS information, project information, alarm information, hard copy information and advance recipe information properties.	2.18U	Standard monitor OS [02.02.**]	0	×	0
Network unit status display	Function to display the status of MELSECNET/H communication unit and CC-Link communication unit	2.32J	Standard monitor OS [03.00.**]	0	0	×
GOT data package acquisition	Function for copying the installed OS or data in the GOT main unit to the memory card	2.43V	Standard monitor OS [03.01.**] BootOS [03.01.**.M]	0	×	0

LADI	
APPENDICES	
INDEX	

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
Unlimited installation of extended function OSs and option OSs	Extended function OS and option OS can be installed unlimitedly. Extended function OS and option OS can be operated up to 21. (Conventionally, both of above OSs can be installed and operated up to 9. The extended function OS data size is twice as large as other OS data. The logging OS data size is three times as large as other OS data.)	2.18U	BootOS [02.02.**.E]	0	×	×
Unlimited installation of extended function OSs and option OSs	Extended function OS and option OS can be operated up to 32. (The extended function OS data size is twice as large as other OS data. The logging OS data size is three times as large as other OS data.)	2.73B	BootOS [03.09.**.S]	0	×	×
Built-in option function board	GT15-FNB built in the GOT is enabled.	2.58L	BootOS [03.03.**.P] Standard monitor OS [03.03.**]	0	×	×
	Function for monitoring/testing device of PLC CPU or buffer memory of intelligent function module	2.09K	Extended function OS System monitor [01.02.**]	0	×	0
System monitoring	Supporting display of Chinese (Simplified/ Traditional), German, Korean	2.27D	Extended function OS System monitor [02.04.**]	0	×	0
function	Supporting connection to Universal model QCPU	2.63R	Extended function OS System monitor [03.07.**]	0	×	0
	Supporting connection to CC-Link IE controller network	2.77F	Extended function OS System monitor [03.12.**]	0	×	×
	Function to monitor the network status of MELSECNET/H, MELSECNET/10, etc.	2.18U	Option OS Network monitor [02.02.**]	0	×	×
Network monitor function	Supporting display of Chinese (Simplified/ Traditional), German, Korean	2.27D	Option OS Network monitor [02.04.**]	0	×	×
	Enables monitoring the status of the CC-Link IE controller network.	2.77F	Option OS Network monitor [03.12.**]	0	×	×
	Function for displaying sequence program loaded to CPU on GOT	2.09K	Option OS Ladder monitor for MELSEC-A [01.02.**] Ladder monitor for MELSEC-Q /QnA [01.02.**] Ladder monitor for MELSEC-FX [01.02.**]	0	×	×
Ladder monitoring function	Supporting display of Chinese (Simplified/ Traditional), German, Korean	2.27D	Option OS Ladder monitor for MELSEC-Q /QnA [02.04.**] Ladder monitor for MELSEC-FX [02.04.**]	0	×	×
	Supporting language switching (Japanese/Korean) for displaying file name and title of the sequence program	2.27D	Option OS Ladder monitor for MELSEC- Q/QnA [02.04.**]	0	×	×
	Supporting the read of programs/	2.43V	Option OS Ladder monitor for MELSEC- Q/QnA [03.01.**]	0	×	×

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
	Supporting reading comments from CF cards	2.58L	Option OS Ladder monitor for MELSEC-	0	×	×
Ladder monitoring	Supporting monitoring local devices	2.58L	Q/QnA [03.03.**]	0	×	×
function	Supporting connection to Universal model QCPU	2.63R	Option OS Ladder monitor for MELSEC- Q/QnA [03.07.**]	0	×	×
	In searching multiple file programs, the backward search display is possible.		Option OS			
	With MELSEC-QnA ladder monitor, the currently displayed program automatically reflect the set value of TC changed in the test function.	2.73B	Ladder monitor for MELSEC- Q/QnA [03.09.**]	0	×	×
Ladder monitoring function	Supporting connection to CC-Link IE controller network	2.77F	Option OS Ladder monitor for MELSEC- Q/QnA [03.12.**]	0	×	×
	Supporting the safety function block display when using the QS001CPU (Only the FB definition name is displayed in the application instruction format.)	2.82L	Option OS Ladder monitor for MELSEC- Q/QnA [03.13.**]	0	×	×
	The ranges of M and B devices that can be monitored are expanded.	2.82L	Option OS Ladder monitor for MELSEC- Q/QnA [03.13.**]	0	×	×
	Function to monitor and change the data of intelligent function module buffer memory using a dedicated screen	2.18U	Option OS Intelligent module monitor [02.02.**]	0	×	×
Intelligent module	Supporting connection to CC-Link IE controller network	2.77F	Option OS Intelligent module monitor [03.12.**]	0	×	×
	When using the QS001CPU, the PC information monitor screen (Operation details screen, Error details screen) is displayed.	2.82L	Option OS Intelligent module monitor [03.13.**]	0	×	×
List editor for MELSEC-A	Function for displaying/editing sequence program saved from ACPU with list mode	2.09K	Option OS List editor for MELSEC-A [01.02.**]	0	×	0
	Function to display / edit the sequence program read out from the FXCPU in the list mode	2.18U	Option OS List editor for MELSEC-FX [02.02.**]	0	×	0
List editor for MELSEC-FX	Supporting display of Chinese (Simplified)	2.27D	Extended function OS List editor for MELSEC-FX [02.04.**]	0	×	0
	Supporting display of Chinese (Simplified/ Traditional), German and Korean (GT11 supports display of Chinese (Simplified/Traditional) and Korean)	2.27D	Extended function OS List editor for MELSEC-FX [02.04.**]	0	×	0

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
	Function to execute servo monitor and parameter setting for motion controller CPU (Q series)	2.18U	Option OS Q motion monitor [02.02.**]	0	×	×
	Parameter setting is enabled for Q172HCPU/Q173HCPU.	2.32J	Standard monitor OS [03.00.**]	0	×	×
Q motion monitor function	Supporting connection to Q17nDCPU	2.63R	Option OS Q motion monitor [03.07.**]	0	×	×
Tunction	Enables clearing the SFC error history. (Universal model QCPU only)	2.63R	Option OS Q motion monitor [03.07.**]	0	×	×
	Supporting connection to CC-Link IE controller network	2.77F	Option OS Q motion monitor [03.12.**]	0	×	×
	Supporting Q170MCPU	2.96A	Option OS Q motion monitor [04.04.**]	0	×	×
Servo amplifier monitor function	Function to monitor the servo amplifier and also to change parameters, execute test run, etc.	2.18U	Option OS Servo amplifier monitor [02.02.**]	0	×	×
CNC monitor	Function to monitor the MELDAS that is connected to the GOT	2.18U	Option OS CNC monitor [02.02.**]	0	×	×
function	Supporting connection to CNC C70	2.63R	Option OS CNC monitor [03.07.**]	0	×	×
	Function to back up setting data for controllers and to restore the data to the controllers	2.58L	Extended function OS Backup/Restore [03.07.**]	0	×	×
Backup/restore	Supporting Backup Data Conversion Tool	2.63R	-	0	×	×
function	Supporting the trigger backup	2.73B	Extended function OS Backup/Restore [03.09.**]	0	×	×
	Supporting Q170MCPU	2.96A	Extended function OS Backup/Restore [04.04.**]	0	×	×
CNC data I/O	Function to copy or delete data of the CNC that is connected to the GOT	2.63R	Extended function OS CNC Data I/O [03.07.**]	0	×	×
function	Cycle monitor data can be input and output	2.96A	Extended function OS CNC Data I/O [04.04.**]	0	×	×
SFC monitor function	Function to display sequence programs written in the PLC CPU in the SFC diagram format on the GOT	2.77F	Extended function OS GOT Platform Library [03.12.**] Option OS SFC Monitor [03.12.**] GOT Function Expansion Library [03.12.**]	0	×	×
Ladder editor	Function to edit the sequence program stored in the controller by using the GOT	2.96A	[03.12.**] Extended function OS GOT Platform Library [04.04.**] Option OS Ladder editor [04.04.**] GOT Function Expansion Library [04.04.**]		×	×
Multi-channel function	Function to monitor multiple controllers with a single unit of GOT	2.18U	Standard monitor OS [02.02.**] Communication driver Use the communication driver, [02.02.**] or later for each connection.	0	×	×

Item	Description	Version of GT Designer2	Version of OS	GT 15	GT Soft GOT1000	GT 11
Gateway function	Function for monitoring each controller from one GOT/PC or sending a mail from GOT	2.09K	Option OS Gateway function (Mail) [01.02.**] Gateway function (Server, Client) [01.02.**]	0	×	×
	Supporting the FTP server function	2.18U	Option OS Gateway functionFTP [02.02.**]	0	×	×
	Enables transfer of binary data by the FTP server function.	2.32J	Option OS Gateway (FTP) [03.00.**]	0	×	×
Document display function	Function to display document on the GOT	2.32J	Standard monitor OS [03.00.**] Option OS Document Display [03.00.**]	0	0	×
tunction	Image quality adjustment for documents is possible.	2.43V	Standard monitor OS [03.01.**]	0	0	×
	Function to execute data linkage between the control and information systems	2.43V	Standard monitor OS [03.01.**] Option OS MES Interface [03.01.**]	0	×	×
	Oracle 8i, ACCESS2000, ACCESS2003, and MSDE2000 are added to the applicable database. The trigger buffering function is added.	2.47Z	Standard monitor OS [03.02.**] Option OS MES Interface [03.02.**]	0	×	×
MES interface function	Enables setting [Do not sample] for the sampling setting in the device tag settings.		,			
	Industrial SQL Server 9.0 and Microsoft SQL Server 2005 are added as an applicable database.	2.58L	Standard monitor OS [03.03.**] Option OS MES Interface [03.03.**]	0	×	×
	Access 2007 is added as an applicable database. Function to send resource data stored in the GOT to the database	2.82L	Standard monitor OS [03.13.**] Option OS MES Interface [03.13.**]	0	×	×
Tag import function	Function to import a tag file created by the third party programming software to GT Designer2, and set a tag as a device.	2.91V	Standard monitor OS [04.03.**]	0	×	0

Appendix.1.2 For GT10

- GT Designer2 Version 2.43V or later is applicable to GT1020.
- GT Designer2 Version 2.58L or later is applicable to GT1030.
- GT Designer2 Version 2.90U or later is applicable to GT105 □.
- GT Designer2 Version 2.90U or later is applicable to GT104 □.

1 Added GOT main unit

Target Models	Version of GT Designer2	Version of OS
GT1020-LBD, GT1020-LBD2, GT1020-LBL	2.43V	-
GT1020-LBDW, GT1020-LBDW2, GT1020-LBLW	2.58L	-
GT1030-LBD, GT1030-LBD2 , GT1030-LBDW, GT1030-LBDW2	2.58L	-
GT1055-QSBD, GT1050-QBBD	2.90U	-
GT1045-QSBD, GT1040-QBBD	2.90U	-

2 Added connection types

○ : Applicable × : N/A - : Applicable (from the first version)

		<u> </u>				
Item	Description	Version of GT Designer2	Version of OS	GT 105□/ 104□	GT 1030	GT 1020
Direct connection to CPU	Supporting connection to FX3G series	2.90U	Standard monitor OS [01.10.**] Communication driver MELSEC-FX[01.06.**]	0	0	0
Computer link connection	Supporting connection to A series PLC	2.82L	Standard monitor OS [01.09.**] Communication driver AJ71C24/UC24[01.04.**]	-	0	0
CC-Link connection (Via G4)	Supporting connection to CC-Link (Via G4)	2.73B	Standard monitor OS [01.07.**] Communication driver CC-Link(G4)[01.00.**]	-	0	0
GOT multidrop connection	Supporting the GOT multidrop connection	2.96A	Standard monitor OS [01.11.**] Communication driver Multidrop(Host) [01.11.**] Multidrop(Slave) [01.11.**]	0	0	0
Microcomputer connection	Supporting the data formats of Format 1 and Format 2.	2.47Z	Standard monitor OS [01.02.**] Communication driver Computer[01.02.**]	-	-	0
MODBUS® / RTU connection	Supporting MODBUS® /RTU connection	2.96A	Standard monitor OS [01.12.**] MODBUS/ RTU [01.07.**]	0	0	0
OMRON PLC connection	Supporting connection to OMRON PLC	2.47Z	Standard monitor OS [01.02.**] Communication driver OMRON SYSMAC [01.02.**]	-	-	0
KEYENCE PLC connection	Supporting connection to KEYENCE PLC	2.73B	Standard monitor OS [01.07.**] Communication driver KEYENCE KV-700/1000[01.00.**]	-	0	0
Connection	Supporting connection to KV-3000 and KV-5000	2.77F	Communication driver KEYENCE KV700/1000 [01.03.**]	-	0	0

Item	Description	Version of GT Designer2	Version of OS	GT 105□/ 104□	GT 1030	GT 1020
TOSHIBA MACHINE PLC connection	Supporting connection to TOSHIBA MACHINE PLC	2.77F	Communication driver TOSHIBA MACHINE TCmini [01.03.**]	-	0	0
PANASONIC	Supporting connection to PANASONIC PLC	2.73B	Standard monitor OS [01.07.**] Communication driver MATSUSHITA MEWNET-FP [01.00.**]	-	0	0
PLC connection	Communication driver name has been changed.	2.96A	Standard monitor OS [01.12.**] Communication driver Panasonic MEWNET-FP [01.07.**]	0	0	0
YASKAWA PLC connection	Supporting connection to CP9200SH/MP900 series	2.73B	Standard monitor OS [01.07.**] Communication driver	-	0	0
connection	Supporting connection to MP2000/MP900 series	2.73B	YASKAWA MP [01.00.**]	-	0	0
LS IS PLC connection	Supporting connection to LS IS PLC	2.90U	Standard monitor OS [01.07.**] Communication driver LS Industrial Systems MASTER-K [01.05.**]	0	0	0
ALLEN-	Supporting connection to MicroLogix 1000/1200/ 1500 series.	2.58L	Standard monitor OS [01.04.**] Communication driver AB MicroLogix [01.00.**]	-	0	0
BRADLEY PLC connection	Supporting connection to SLC500 series.	2.58L	Standard monitor OS [01.04.**] Communication driver AB SLC 500 [01.00.**]	-	0	0
SIEMENS PLC	Supporting connection to SIEMENS S7-200 series.	2.58L	Standard monitor OS [01.04.**] Communication driver SIEMENS S7-200 [01.00.**]	-	0	0
connection	Supporting connection to SIEMENS S7-300/400 series	2.90U	Standard monitor OS [01.10.**] Communication driver SIEMENS S7-300/400 [01.05.**]	0	0	0
Inverter connection	Supporting connection to inverter	2.73B	Standard monitor OS [01.07.**] Communication driver FREQROL 500/700 [01.00.**]	-	0	0
Servo amplifier connection	Supporting connection to MR-J2S-*CL	2.96A	Standard monitor OS [01.12.**] Communication driver MELSERVO-J3, J2S/M [01.07.**]	0	0	0
Bar code reader connection	Supporting connection to barcode reader	2.77F	Standard monitor OS [01.08.**]	-	0	0

3 Added GT Designer2 functions

Item	Description	Version of GT Designer2	Version of OS	GT 105□/ 104□	GT 1030	GT 1020
Library workspace	Enables setting the background color of the figures in the Library Editor screen.	2.47Z	-	-	-	0
Project data matching	Project data matching is available between data stored in the personal computer and data opened with GT Designer2.	2.96A	-	0	0	0
Screen preview	Enables switching screens in the Screen Preview window.	2.96A	-	0	0	0
	Enables setting [Specify the touch area.].	2.77F	-	-	0	×
Auxiliary setting	For the set overlay screen function, the setting to place the called screen under the basic screen is added.	2.96A		0	0	0
	For the set overlay screen function, the setting to disable the background color of the called screen is added.	2.90A	-	0	0	0
Reading BMP or JPEG image data	Enables displaying BMP or JPEG image data reduced to a resolution of 2000 × 1600 or less on GT Designer2.	2.77F	-	-	0	0
Directly editing comment group	Enables editing the comment group directly in settings for the lamps and touch switches.	2.77F	-	-	0	0

4 Added common settings/object functions

Item	Description	Version of GT Designer2	Version of OS	GT 105□/ 104□	GT 1030	GT 1020
	Supporting piping	2.73B	Standard monitor OS [01.00.**]	-	0	0
Figure	Enables displaying BMP or JPEG image data reduced to a resolution of 2000 × 1600 or less on GT Designer2.	2.77F	Standard monitor OS [01.08.**]	-	0	0
	Supporting logo text	2.96A	Standard monitor OS [01.12.**]	0	0	0
Standard font	Supporting Japanese Supporting Japanese (supporting Europe) Supporting Chinese (Simplified)(supporting Europe) Supporting Chinese (Traditional)(supporting Europe)	2.91V	Standard monitor OS [01.11.**]	0	0	0
	Supporting the TrueType numerical font (Gothic)		Standard monitor OS [01.11.**]	0	0	0
TrueType font	Supporting the TrueType numerical font (7-segment)	2.91V	BootOS [01.11.**.G] Standard monitor OS [01.11.**]	0	0	0
Window screen	Corresponding to the overlap window display and the superimpose display.	2.73B	Standard monitor OS [01.07.**]	-	0	0
GOT internal device	Devices from GS0 to GS1023 are available.	2.96A	Standard monitor OS [01.12.**]	0	0	0
GOT Setup	The key reaction speed can be set.	2.82L	Standard monitor OS [01.09.**]	-	0	0

Item	Description	Version of GT Designer2	Version of OS	GT 105□/ 104□	GT 1030	GT 1020
Clock function	The clock data storage to the GD device is possible.	2.73B	Standard monitor OS [01.07.**]	-	0	0
Numerical	Format String setting is possible.	2.77F	Standard monitor OS [01.08.**]	-	0	0
Display/ Numerical input	Enables setting the asterisk display.	2.96A	Standard monitor OS [01.12.**]	0	0	0
ASCII input	The ASCII input can be set.	2.58L	Standard monitor OS [01.03.**]	-	0	0
A3CII IIIput	Enables setting the asterisk display.	2.96A	Standard monitor OS [01.12.**]	0	0	0
Comment Display	The simple comment is added.	2.77F	Standard monitor OS [01.08.**]	-	0	0
Lamp Display	[Comment Group] can be used.	2.77F	Standard monitor OS [01.08.**]	-	0	0
	Auto repeat can be used.	2.73B	Standard monitor OS [01.07.**]	-	0	0
	[Comment Group] can be used.	2.77F	Standard monitor OS [01.08.**]	-	0	0
Touch switch	The device monitor and debug function can be set for the action setting of the special function switch and the multi action switch.	2.82L	Standard monitor OS [01.09.**]	-	0	0
Graph	The statistics bar graph can be set.	2.58L	Standard monitor OS [01.03.**]	-	-	0
	The statistics pie graph can be set.	2.58L	Standard monitor OS [01.03.**]	-	-	0
Alarm history display	Enables selecting whether to set the scrolling comment display suitable for the message display area.	2.63R	Standard monitor OS [01.06.**]	-	0	0
	Comment group can be used.	2.73B	Standard monitor OS [01.07.**]	-	0	0
Scrolling alarm display	The scrolling alarm display applicable	2.73B	Standard monitor OS [01.07.**]	-	0	0

5 Other functions added

Item	Description	Version of GT Designer2	Version of OS	GT 105□/ 104□	GT 1030	GT 1020
Installing OS	Enables installing the OS without the OS installation screen of the GOT.	2.77F	Standard monitor OS [01.08.**]	-	0	0
	Enables installing or uploading the OS, communication drivers, project data, and others with the GT10-LDR.	2.77F	-	×	0	0
Installing/ uploading with GT10-LDR	Enables installing the OS for the GT10-LDR. Supporting the following fonts when the OS is installed. Japanese Chinese (Simplified)(supporting Europe) Chinese (Traditional)(supporting Europe) TrueType numerical font (7-segment) TrueType numerical font (Gothic)	2.91V	Standard monitor OS [01.11.**]	×	0	0
MELSEC-FX list editor function	Function to display or edit a sequence program read from the FXCPU in the list mode	2.90U	-	0	×	×

INDEX

SYSTEM MONITOR
[A] Access range
[B]
Batch Monitor
[C] Changing screens
[D]
Deleting entry devices
[E]
Entering monitor devices (specifying monitor stations and devices)
נון
Information and set items displayed on each
setting key window
screen and key functions 2-40
Information displayed on the BM Monitor screen and key functions
Information displayed on the Entry Monitor screen and key functions
Information displayed on the TC Monitor
screen and key functions
screen and key functions
[K]
Key window setting columns and operation procedure
[0]
Outline until starting the system monitor 2-20
[P]
Precautions 2-18
Procedure for batch monitor basic operation 2-44 Procedure for BM monitor basic operation 2-52
Procedure for canceling TC monitor keywords 2-49
Procedure for displaying the test menu screen and the setting key window screen

Procedure for TC monitor basic operation	2-48
[Q] Quick test operation of monitor devices	2-30
[S] Specifications	2-28
TC Monitor (Monitoring Timers and Counters) Test Operation	2-53

Procedure for entry monitor basic operation 2-38

LADDER MONITOR FUNCTION

[A] Access range	3-12
[C] Coil search Contact point search	
[D]	
Defect search	
Devices and range that can be monitored	
Device search	
Displaying 32 characters of comments	
Displaying notes	
Displaying statements	
Displaying the test menu screen	3-70
Display switching of 16-bit (one-word)/32-bit	0.40
(two-word) modules Display switching of decimal numbers/	3-46
hexadecimal numbers	3-47
Tiexadosimai namboro	0 47
[E]	
Error Messages and Corrective Action	3-74
[H]	
Hard copy output	3-45
[1]	
	
Information and key functions displayed on the screen	3-38
	0 00
[L]	
Ladder end search	3-63
[0]	
Operation Procedure Common	
Outline until the start	3-16
[P]	
Precautions	3-12
1 1000010110	0 12
[S]	
Searching from the monitor screen	3-32
Search Operation	
Setting and deleting media for saving	
ladder data	
Specifications	
Step search	
Switching comment/no-comment display	
Switching the Display Format	3-46
System configuration	3-4

[T]

Test Operation	3-70
Touch search	3-68

MELSEC-A LIST EDITOR

[A]
Access range
Adding (inserting) commands 4-23
[B] Basic Operation
[C]
Changing (Overwriting) commands
[D]
Deleting commands
Display format of the display area 4-12
[E]
Error Messages and Corrective Actions
CPU connection4-33
Error using list editor function on the link system 4-37
ru1
[H] Hard copy output4-19
[K]
Key arrangement and a list of key functions 4-10
[L]
List of functions
[0]
Operation Methods4-10
Operation of keyword input
[P]
PLC CPU error messages and troubleshooting 4-36
PLC memory all clear 4-27 Precautions 4-5
[R]
Reading sequence programs 4-21
[5]
Selection and operation of modes
T 0

Switching valid keys (upper/lower functions)	4-15
System configuration	4-3
•	
[U]	
Using the help function	4-25

MELSEC-FX LIST EDITOR

INTELLIGENT MODULE MONITOR

[A]	[A]
Action for an incorrect key input 5-32	Access range6-6
[C]	[C]
Changing operands, set values 5-20	Composition of PC Information monitor
ro:	screen and key functions (only when using QCPU (Q mode))6-18
[D]	Composition of the intelligent module monitor
Deleting commands	screen and key 6-23
Display 5-6	Composition of the system configuration
[E]	screen and key functions6-15
	Composition of the unit detail info
Error Messages and Corrective Actions 5-33	screen and key functions (only when using QCPU (Q mode))6-22
[Н]	(Q 11100 <i>e</i>))0-22
Hard copy output5-32	[D]
Tidia dopy datpat	Display 6-11
[K]	
Key arrangement and a list of key functions 5-9	[E]
Keywords 5-28	Error Messages and Corrective Action 6-115
[L]	[1]
List monitor5-30	Intelligent Module Monitor Screens 6-27
[0]	[M]
Operation Procedures 5-9	Monitor screen configuration and
•	key functions 6-114
[P]	
Parameter setting 5-25	[0]
PLC diagnostics 5-23	Operating I/O Module Monitor Screen6-113
	Operation of Each Intelligent Module
[S]	Monitor Screen 6-15
Searching commands and devices 5-15	נחו
Selection and operation of modes	[P]
Sequence program all clear	Precautions6-8
Specifications	161
System configuration	
,	Setting method for other station monitoring 6-17
[W]	Specifications 6-3 Specifying a module to monitor and
Writing commands 5-17	selecting monitor menu
-	Specifying the module to be monitored 6-113
	System configuration 6-3
	[T]
	Testing of the intelligent function module 6-25

[A]	[A]	
Access range 7-7	Access range	8-5
[D]	[D]	
Detailed monitor	Display	8-6
	[E]	
[E]	Error List Designated-Axis screen	8-15
Error Message and Corrective Action 7-30	Error List screen Error Messages and Corrective Action	
[L]		
Line monitor 7-12	[H]	
	Hard copy output	8-25
[N]		
Network information that can be monitored 7-5	[M]	
	Monitor Menu screen	8-10
[0]		
Operation Procedures 7-12	[0]	
Other station communication status monitor 7-24 Other station CPU operation status monitor 7-27	Operation Procedures	8-9
Other station CPU RUN status monitor	[P]	
Other station data link status monitor		0.00
Other station loop status monitor 7-29	Parameter setting screen Positioning Monitor screen	
Other station monitor	Precautions	
Other station parameter status monitor 7-26	Present Value History Monitor screen	
	Present Value Monitor screen	
[P]		
Precautions 7-7	[S]	
	Servo Monitor screen	8-19
[8]	SFC Error History screen	
Specifications	Specifications	
System configuration	System configuration	
	System configuration screen layout	8-9

Q MOTION MONITOR

NETWORK MONITOR

SERVO AMPLIFIER MONITOR

[A] Access range
[D] Diagnostics function 9-22 Display 9-12
[E] Error Messages and Corrective Action 9-44
[H] Hard copy output9-43
[M] Monitor functions9-17
[O] Operations of Servo Amplifier Monitor Screens 9-15
[P]9-29Precautions9-11
[S] Servo amplifier monitor 9-15 Setup 9-16 Specifications 9-3 System configuration 9-3
[T] Test operations

CNC MONITOR FUNCTIONS

Access range10-	5
[D] Display10-	6
[E] Error Messages and Corrective Action10-1	0
[O] Operation Procedures	8
[P] Precautions	-5
[S] Specifications	2

[A]	[A]
Access range	Access range
[C]	[C]
Changing screens	Changing screens.
[D]	
Data list (restoration)	[D]
Data to be backed up and restored 11-4	Display
Display operation	, ,
	[E]
[M]	Error Messages and
Main menu 11-27	J
	[P]
[0]	Precautions
Operation procedures 11-27	
Outline before starting 11-12	[S]
[P]	Specifications
Precautions	System configuration
Progress screen (backup)	
Progress screen (restoration)	
, , , , , , , , , , , , , , , , , , , ,	
[S]	
Security and password	
Setting storage location for backup data 11-14	
Specifications	
System configuration	
[T]	

Trigger backup 11-20

BACKUP/RESTORE

[A] Access range12-3	
[C] Changing screens12-6	
[D] Display12-5	
[E] Error Messages and Corrective Actions 12-12	
[P] Precautions12-3	
[S] Specifications	

CNC DATA I/O

SFC MONITOR [A] Active block list window...... 13-36 Active step list window 13-35 [C] Changing screens 13-11 Communication setting window...... 13-21 [D] Device/contact/coil search window 13-30 Devices and range that can be monitored 13-7 [E] Error Messages and Corrective Action 13-41 [H] How to Operate Block List Screen 13-23 How to Operate device test window...... 13-38 How to Operate PLC Read Screen 13-17 How to Operate SFC Diagram Monitor Screen... 13-25 [M] Monitoring Mode menu 13-37 [0] [P] Program list window 13-22 [R] Reading comment files from CF card...... 13-13 [S] Setting automatic scroll mode 13-16 Setting display mode of SFC programs 13-15 Setting SFC data storage location 13-12 Setting zoom comment display mode 13-15

Switching display formats between decimal and hexadecimal numbers
ш
Test Operation
Zoom window

Step No./transition condition

LADDER EDITOR	
[A]	
Access range 14	I-6

-	
[C]	
Change open/close contact window	14-42
Comment file list window	14-44
Communication setting window	14-20
Copy program memory data into ROM window	14-48

[D]

נסן	
Devices and range that can be monitored	14-5
Device search window	14-40
Display menu	14-24
Display Operation	14-8

[E]

Edit menu	14-37
Enter ladder program window	14-28
Error Messages and Corrective Action	14-51

[F]

Find menu	14-24
Find/Replace menu	14-38

[H]

How to Operate Ladder Editor Screen	14-27
How to Operate Ladder Monitor Screen	14-22
How to Operate PLC Read Screen	14-16

[1]

Inputting or deleting ladders 14-3	Inputting or deleting	ladders	14-30
------------------------------------	-----------------------	---------	-------

[J]

Jump window	. 14-39
•	

[L]

Ladder registration monitor window 14-25	
--	--

[M]

Monitoring Mode menu	14-26
----------------------	-------

[0]

Online menu	14-45
Outline before starting	. 14-8

[P]

Password input window	14-18
Precautions	14-6
Drogram liet window	1/1 21

[R]

Remote operation window	
·	
[S]	
Setting Display Format	14-15
Setting ladder data storage location	14-12
Specifications	. 14-3
Switching display formats between decimal	and
hexadecimal numbers	14-15
Switching languages of sequence programs	14-15
System configuration	. 14-3
ш	
Test Operation	14-49
[V]	

Verify result window 14-46

Reading comment files from CF card...... 14-13

MEMO

WARRANTY

Please confirm the following product warranty details before using this product.

1. Gratis Warranty Term and Gratis Warranty Range

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the sales representative or Mitsubishi Service Company. However, if repairs are required onsite at domestic or overseas location, expenses to send an engineer will be solely at the customer's discretion. Mitsubishi shall not be held responsible for any re-commissioning, maintenance, or testing on-site that involves replacement of the failed module.

[Gratis Warranty Term]

The gratis warranty term of the product shall be for thirty-six (36) months after the date of purchase or delivery to a designated place

Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be forty-two (42) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

[Gratis Warranty Range]

- (1) The customer shall be responsible for the primary failure diagnosis unless otherwise specified.
 - If requested by the customer, Mitsubishi Electric Corporation or its representative firm may carry out the primary failure diagnosis at the customer's expence.
 - The primary failure diagnosis will, however, be free of charge should the cause of failure be attributable to Mitsubishi Electric Corporation.
- (2) The range shall be limited to normal use within the usage state, usage methods and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (3) Even within the gratis warranty term, repairs shall be charged for in the following cases.
 - 1. Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
 - 2. Failure caused by unapproved modifications, etc., to the product by the user.
 - 3. When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
 - Failure that could have been avoided if consumable parts designated in the instruction manual had been correctly serviced or replaced.
 - 5. Replacing consumable parts such as the battery, backlight and fuses.
 - 6. Failure caused by external irresistible forces such as fires or abnormal voltages, and Failure caused by force majeure such as earthquakes, lightning, wind and water damage.
 - 7. Failure caused by reasons unpredictable by scientific technology standards at time of shipment from Mitsubishi.
 - 8. Any other failure found not to be the responsibility of Mitsubishi or that admitted not to be so by the user.

2. Onerous repair term after discontinuation of production

- (1) Mitsubishi shall accept onerous product repairs for seven (7) years after production of the product is discontinued. Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.
- (2) Product supply (including repair parts) is not available after production is discontinued.

3. Overseas service

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center. Note that the repair conditions at each FA Center may differ.

4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to damages caused by any cause found not to be the responsibility of Mitsubishi, loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products, special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products, replacement by the user, maintenance of on-site equipment, start-up test run and other tasks

5. Changes in product specifications

The specifications given in the catalogs, manuals or technical documents are subject to change without prior notice.

6. Product application

- (1) In using the Mitsubishi graphic operation terminal, the usage conditions shall be that the application will not lead to a major accident even if any problem or fault should occur in the graphic operation terminal device, and that backup and fail-safe functions are systematically provided outside of the device for any problem or fault.
- (2) The Mitsubishi graphic operation terminal has been designed and manufactured for applications in general industries, etc. Thus, applications in which the public could be affected such as in nuclear power plants and other power plants operated by respective power companies, and applications in which a special quality assurance system is required, such as for Railway companies or Public service purposes shall be excluded from the graphic operation terminal applications.
 - In addition, applications in which human life or property that could be greatly affected, such as in aircraft, medical applications, incineration and fuel devices, manned transportation equipment for recreation and amusement, and safety devices, shall also be excluded from the graphic operation terminal range of applications.
 - However, in certain cases, some applications may be possible, providing the user consults the local Mitsubishi representative outlining the special requirements of the project, and providing that all parties concerned agree to the special circumstances, solely at our discretion.
 - In some of three cases, however, Mitsubishi Electric Corporation may consider the possibility of an application, provided that the customer notifies Mitsubishi Electric Corporation of the intention, the application is clearly defined and any special quality is not required.

Microsoft, Windows, Windows NT, Windows Vista are registered trademarks of Microsoft Corporation in the United States and other countries.

Adobe and Adobe Reader are registered trademarks of Adobe Systems Incorporated.

Pentium and Celeron are a registered trademarks of Intel Corporation in the United States and other countries.

Ethernet is a trademark of Xerox Co., Ltd. in the United States.

MODBUS is a trademark of Schneider Electric SA.

Other company and product names herein are either trademarks or registered trademarks of their respective owners.



GOT1000 Series Extended/Option Functions Manual

MODEL	GT1000-O(SYS)-E	
MODEL CODE	1D7M32	
SH(NA)-080544ENG-O(1209)MEE		



HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN NAGOYA WORKS : 1-14 , YADA-MINAMI 5-CHOME , HIGASHI-KU, NAGOYA , JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.