



INVERTER

Plug-in option

FR-A7NL E kit

INSTRUCTION MANUAL

LONWORKS[®] communication function

PRE-OPERATION INSTRUCTIONS

1

INSTALLATION

2

WIRING

3

INVERTER SETTING

4

FUNCTION OVERVIEW

5

NETWORK VARIABLES

6

TROUBLESHOOTING

7

Thank you for choosing this Mitsubishi Inverter plug-in option. This instruction manual gives handling information and precautions for use of this equipment. Incorrect handling might cause an unexpected fault. Before using the equipment, please read this manual carefully to use the equipment to its optimum. Please forward this manual to the end user.

This section is specifically about safety matters

Do not attempt to install, operate, maintain or inspect this product until you have read through this instruction manual and appended documents carefully and can use the equipment correctly. Do not use this product until you have a full knowledge of the equipment, safety information and instructions.

In this instruction manual, the safety instruction levels are classified into "WARNING" and "CAUTION".



Assumes that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



Assumes that incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause physical damage only.

Note that even the  **CAUTION** level may lead to a serious consequence according to conditions. Please follow the instructions of both levels because they are important to personnel safety.

SAFETY INSTRUCTIONS

1. Electric Shock Prevention

WARNING

- While power is on or when the inverter is running, do not open the front cover. You may get an electric shock.
- Do not run the inverter with the front cover or wiring cover removed. Otherwise, you may access the exposed high-voltage terminals and charging part and get an electric shock.
- If power is off, do not remove the front cover except for wiring or periodic inspection. You may access the charged inverter circuits and get an electric shock.
- Before starting wiring or inspection, check to make sure that the indication of the inverter operation panel is off, wait for at least 10 minutes after the power supply has been switched off, and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power off and it is dangerous.
- Any person who is involved in the wiring or inspection of this equipment should be fully competent to do the work.
- Always install the plug-in option before wiring. Otherwise, you may get an electric shock or be injured.
- Do not touch the plug-in option with wet hands. Otherwise you may get an electric shock.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Otherwise you may get an electric shock.

2. Injury Prevention

CAUTION

- Apply only the voltage specified in the instruction manual to each terminal. Otherwise, burst, damage, etc. may occur.
- Ensure that the cables are connected to the correct terminals. Otherwise, burst, damage, etc. may occur.
- Always make sure that polarity is correct to prevent damage, etc. Otherwise, burst, damage may occur.
- While power is on or for some time after power-off, do not touch the inverter as it is hot and you may get burnt.

3. Additional Instructions

Also note the following points to prevent an accidental failure, injury, electric shock, etc.

1) Transportation and mounting

CAUTION

- Do not install or operate the plug-in option if it is damaged or has parts missing.
- Do not stand or rest heavy objects on the product.
- Check that the mounting orientation is correct.
- Prevent other conductive bodies such as screws and metal fragments or other flammable substance such as oil from entering the inverter.

2) Trial run

CAUTION

- Before starting operation, confirm and adjust the parameters. A failure to do so may cause some machines to make unexpected motions.

3) Usage

WARNING

- Do not modify the equipment.
- Do not perform parts removal which is not instructed in this manual. Doing so may lead to fault or damage of the inverter.

CAUTION

- When parameter clear or all parameter clear is performed, reset the required parameters before starting operations. Each parameter returns to the initial value.
- For prevention of damage due to static electricity, touch nearby metal before touching this product to eliminate static electricity from your body.

4) Maintenance, inspection and parts replacement

CAUTION

- Do not test the equipment with a megger (measure insulation resistance).

5) Disposal

CAUTION

- Treat as industrial waste.

6) General instruction

All illustrations given in this manual may have been drawn with covers or safety guards removed to provide in-depth description. Before starting operation of the product, always return the covers and guards into original positions as specified and operate the equipment in accordance with the manual.

— CONTENTS —

1	PRE-OPERATION INSTRUCTIONS	1
1.1	Unpacking and Product Confirmation	1
1.1.1	SERIAL number	1
1.1.2	Packing confirmation	2
1.2	Parts	3
1.3	Operation Status Indication LED	4
1.4	Specifications	6
1.4.1	Inverter option specifications	6
1.4.2	Communication specification	6
2	INSTALLATION	7
2.1	Pre-Installation Instructions	7
2.2	Installation Procedure	7
3	WIRING	13
3.1	System Configuration Example	13
3.2	Wiring	14
4	INVERTER SETTING	19
4.1	Parameter List	19
4.2	Operation Mode Setting	20
4.2.1	Operation mode indication	20
4.2.2	Operation mode switching and communication startup mode (Pr. 79, Pr. 340)	21

4.3	Operation and Speed Command Source (Pr. 338, Pr. 339, Pr. 550)	24
4.3.1	Communication EEPROM write selection (Pr. 342)	28
4.4	Operation at Communication Error Occurrence	29
4.4.1	Operation selection at communication error occurrence (Pr. 500 to Pr. 502)	29
4.4.2	Alarm and measures	33
4.5	Inverter Reset	34
5	FUNCTION OVERVIEW	36
<hr/>		
5.1	XIF File	36
5.2	Output from the Inverter to the Network	37
5.3	Input from the Network to the Inverter	38
6	NETWORK VARIABLES	40
<hr/>		
6.1	Object Map	40
6.2	Network Variable List	41
6.3	LONWORKS Object	45
6.3.1	Setting range of object ID	45
6.3.2	Object request (network input SNVT_obj_request nviRequest)	46
6.3.3	Object status (network output SNVT_obj_status nvoStatus)	47
6.4	Variable Speed Motor Drive Object	48
6.4.1	Start/stop and simple speed setting (network input SNVT_switch nviDrvSpeedStpt)	48
6.4.2	Speed adjustment (0.005% increments) (network input SNVT_lev_percent nviDrvSpeedScale)	49
6.4.3	Speed monitor (0.005% increments) (network output SNVT_lev_percent nvoDrvSpeed)	50
6.5	Inverter Basic Functions	51
6.5.1	Inverter input signal (network input SNVT_state nviInVInputSig)	51
6.5.2	Inverter output signal (network output SNVT_state nvoInVOutputSig)	53

6.5.3	Set frequency write destination selection (network input SNVT_switch nviInvSetFreqSw).....	55
6.5.4	Set frequency (0.1Hz increments) (network input SNVT_freq_hz nviInvSetFreq)	56
6.5.5	Set frequency (0.005% increments) (network input SNVT_lev_percent nviInvSetFreqP).....	56
6.5.6	Output frequency monitor (0.1Hz increments) (network output SNVT_freq_hz nvoInvOutFreq)	57
6.5.7	Output frequency monitor (0.005% increments) (network output SNVT_lev_percent nvoInvOutFreqP)	58
6.5.8	Output current monitor (0.1A increments) (network output SNVT_amp nvoDrvCurrt)	59
6.5.9	Output voltage monitor (0.1V increments) (network output SNVT_volt nvoDrvVolt).....	59
6.5.10	Actual operation time monitor (1h increments) (network output SNVT_time_hour nvoDrvRunHours).....	59
6.5.11	Cumulative power monitor (1kWh increments) (network output SNVT_elec_kwh nvoDrvRunPower).....	60
6.5.12	Cumulative power monitor 2 (0.1kWh increments) (network output SNVT_elec_kwh_I nvoDrvRunPower_I)	61
6.5.13	Alarm reset (network input SNVT_switch nviInvAlarmReset).....	61
6.5.14	Alarm occurrence definition (network output SNVT_str_asc nvoInvAlarmStr)	62
6.5.15	Product information (maker name, type) (network output SNVT_str_asc nvoInvTypeInfo)	64
6.5.16	Emergency stop command (network input SNVT_hvac_emerg nviEmergOverride).....	65
6.5.17	Emergency stop status (network output SNVT_hvac_emerg nvoEmergStatus).....	66
6.5.18	Alarm status (network output SNVT_switch nvoDrvAlarm)	67
6.6	Inverter PID Control Functions	68
6.6.1	PID set point (network input SNVT_lev_percent nviInvPIDTarget)	69
6.6.2	PID measured value (network input SNVT_lev_percent nviInvPIDValue)	70
6.6.3	PID deviation (network input SNVT_lev_percent nviInvPIDDev)	71
6.7	Inverter Extended Functions	72
6.7.1	Monitor code (network input SNVT_count nviInvMonCode).....	72
6.7.2	Monitor data (network output SNVT_count nvoInvMonData).....	75
6.7.3	Set frequency (0.01Hz increments) (network input SNVT_count nviInvSetFreq2).....	76
6.7.4	Output frequency monitor (0.01Hz increments) (network output SNVT_count nvoInvOutFreq2)	76
6.7.5	Command request (network input SNVT_str_asc nviInvCmdReq)	77
6.7.6	Command reply (network output SNVT_str_asc nvoInvCmdReply).....	82
6.8	Configuration Properties.....	83
6.8.1	Initial communication delay time (network input config SNVT_time_sec nciPwUpOutTm).....	83

6.8.2	Forward/reverse rotation prevention (network input config SNVT_count nciInvFwdRevLock).....	84
6.8.3	% set reference frequency (network input config SNVT_freq_hz nciInvSetFreqBas)	85
6.8.4	Maximum frequency (0.1Hz increments) (network input config SNVT_freq_hz nciInvMaxFreq)	86
6.8.5	Minimum frequency (0.1Hz increments) (network input config SNVT_freq_hz nciInvMinFreq)	86
6.8.6	Heartbeat send time interval (network input config SNVT_time_sec nciSndHrtBt)	87
6.8.7	Minimum heartbeat send time (network input config SNVT_time_sec nciMinOutTm)	87
6.8.8	Acceleration time (network input config SNVT_time_sec nciRampUpTm).....	90
6.8.9	Deceleration time (network input config SNVT_time_sec nciRampDownTm).....	91
6.8.10	PID action selection (network input config SNVT_count nciInvPIDSwitch)	92
6.8.11	PID proportional band (network input config SNVT_count nciInvPIDPro).....	94
6.8.12	PID integral time (network input config SNVT_time_sec nciInvPIDIntTm).....	94
6.8.13	PID differential time (network input config SNVT_time_sec nciInvPIDDiffTm).....	95
6.8.14	PID manipulated variable bias (0.1Hz increments) (network input config SNVT_freq_hz nciInvPIDOpeBias)	95
6.8.15	PID manipulated variable gain (0.1Hz increments) (network input config SNVT_freq_hz nciInvPIDOpeGain).....	96
6.8.16	Heartbeat receive time interval (network input config SNVT_time_sec nciRcvHrtBt)	97
6.8.17	Maximum speed (0.005% increments) (network input config SNVT_lev_percent nciMaxSpeed).....	99
6.8.18	Minimum speed (0.005% increments) (network input config SNVT_lev_percent nciMinSpeed).....	99
6.8.19	Reference speed setting (network input config SNVT_rpm nciNmlSpeed)	100
6.8.20	Reference frequency setting (network input config SNVT_freq_hz nciNmlFreq)	101
6.8.21	Speed adjustment default value (network input config SNVT_lev_percent nciDrvSpeedScale)	101
6.8.22	Event driven detection width (network input config SNVT_lev_percent nciInvEvtDuty).....	102

7 TROUBLESHOOTING 104

APPENDIX 105

Setup Example 105

Example of Inverter Parameter Clear 106

1 PRE-OPERATION INSTRUCTIONS

1.1 Unpacking and Product Confirmation

Take the plug-in option out of the package, check the product name, and confirm that the product is as you ordered and intact.

This product is a plug-in option for the FR-E700 series inverter.

1.1.1 SERIAL number

Check the SERIAL number indicated on the inverter rating plate or package.

For the 200V class of FR-E700, this option can be used with the inverter having the following SERIAL number or later. (For the 400V class of FR-E700, this option can be used with all inverters regardless of SERIAL number.)

Type	SERIAL number
FR-E720-0.1K to 0.75K	J7Y○○○○○○
FR-E720-1.5K to 5.5K	K7Y○○○○○○
FR-E720-7.5K	L7Y○○○○○○
FR-E720-11K, 15K	G7Y○○○○○○

● SERIAL number check

Refer to the inverter manual for the location of the rating plate.

Rating plate example




<u>□</u>	<u>7</u>	<u>Y</u>	<u>○○○○○○</u>
Symbol	Year	Month	Control number
SERIAL number			

The SERIAL consists of 1 version symbol, 2 numeric characters or 1 numeric character and 1 alphabet letter indicating year and month, and 6 numeric characters indicating control number.

Month is indicated as 1 to 9, X (October), Y (November), and Z (December).

1.1.2 Packing confirmation

Check the enclosed items.

<p>Plug-in option 1</p> 	<p>Mounting screw (M3 × 6mm) 2 (Refer to page 9, 11.)</p> 	<p>Terminal block 1 (Refer to page 9, 11.)</p> 	<p>Front cover for plug-in option 1</p> 
<p>Option protective cover 1 *</p> 	<p>Option small cover (Not used) 1</p> 	<p>Neuron® ID bar code sticker 1 (Since one bar code sticker is for maker duplicate, three stickers are provided.)</p>	

* Used with the FR-E720-3.7K (FR-E720-175) or less and FR-E740-7.5K (FR-E740-170) or less.


CAUTION

- In place of the inverter front cover, install a provided front cover for plug-in option.

REMARKS

- Echelon®, LONWORKS®, LonMaker®, LONMARK® and Neuron® are registered trademarks of Echelon Corporation in the U.S.A. and other countries.
Company and product names herein are the trademarks and registered trademarks of their respective owners.

1.2 Parts




1

1.3 Operation Status Indication LED

Operation status indication LED indicates the operating status of the option unit according to the indication status.

Refer to the figure below for LED location.



Name	Function	LED Status	Status
L.RUN	Display the handshaking status with the inverter.	ON	Normal operation
		OFF	Alarm detection
RUN	Display the unit operation status.	ON	Normal operation
		OFF	Alarm (watchdog timer expiration etc.) detection
TX *	Display the transmission status of packet to the network.	ON (for about 50ms)	Transmitting
		OFF	Stop transmission
RX	Display the receiving status of packet from the network.	ON (for about 50ms)	Receiving
		OFF	Stop receiving
SERVICE	Display the status of node and service switch.	ON	Service switch pressed status
		Flicker	Unconfigured status
		OFF	Configured status
WINK	Display the receiving status of WINK message from the network.	Flicker three times	Receiving WINK message
		OFF	Stop



* TX LED turns on when the inverter autonomously sends data due to heartbeat and event driven function even when the communication cable is not wired.

1.4 Specifications

1.4.1 Inverter option specifications

Type		Inverter plug-in option type (can be mounted/dismounted to/from the inverter front face)
Number of nodes occupied		One inverter occupies one node.
Connection cable	Free topology	Twisted pair cable equivalent to EBT0.65mm × 1p
	Bus topology	Twisted pair cable equivalent to EBT1.3mm × 1p

1.4.2 Communication specification

Number of units connected		64 units maximum including the inverter in the same segment.	
Communication speed		78kbps	
Maximum cable length		<p>Free topology (connect a terminating resistor at any one point) Maximum: 500m</p> <p><Example></p> 	<p>Bus topology (connect a terminating resistor at both ends) Maximum: 2700m (The total length of each node stub should be 3m maximum.)</p> <p><Example></p> 
		<p>Event reception</p> <p>Number of events receivable at a time : 20 Reception time per event : 100ms maximum (when not conflicting with event transmission)</p>	<p>Event transmission</p> <p>Transmission time per event</p> <ul style="list-style-type: none"> · Without bind : 200ms · With bind : [retry interval time] × [number of retries]

2 INSTALLATION

2.1 Pre-Installation Instructions

Make sure that the input power of the inverter is off.

CAUTION

-  With input power on, do not install or remove the plug-in option. Otherwise, the inverter and plug-in option may be damaged.
-  For prevention of damage due to static electricity, touch nearby metal before touching this product to eliminate static electricity from your body.

2.2 Installation Procedure


The FR-E700 series has one connection connector for the plug-in option.

CAUTION

- Always perform wiring to the main circuit terminals and control circuit terminals before installing the option. Wiring cannot be performed after installing the option.
- When the inverter can not recognize that the option unit is mounted due to improper installation, etc., "E. /" (option alarm) is displayed.
- Take care not to drop a mounting screw during mounting and removal.
- Pull out the option straight to remove. Otherwise, the connector may be damaged.

7 INSTALLATION

- For FR-E720-3.7K (FR-E720-175) or less and FR-E740-7.5K (FR-E740-170) or less
- (1) Remove the front cover from the inverter. (For removing the front cover, refer to the FR-E700 instruction manual.)
 - (2) Remove the PU cover from the front cover. Open the PU cover with a driver, etc. and remove it in the direction of arrow as shown below.




REMARKS

- Because the voltage class, model name and serial (only voltage class is labeled for FR-E740-5.5K (FR-E740-120) or more) are stated on the PU cover, replace a PU cover of a plug-in option front cover with the removed PU cover from the inverter.



- (3) Install the option protective cover.
- (4) Securely fit the connector of the plug-in option to the inverter connector along the guides.
- (5) Securely fix the both top and bottom of the plug-in option to the inverter with the accessory mounting screws. (tightening torque 0.45N•m to 0.55N•m) If the screw holes do not line-up, the connector may not have been plugged snugly. Check for loose plugging.
- (6) Remove the PU cover provided on the front cover for plug-in option and install the other PU cover, which was removed in (2).
- (7) Mount the already wired terminal block to the plug-in option. (Refer to *the chapter 3* for wiring.)
- (8) Install the front cover for plug-in option to the inverter.




REMARKS

- When the option protective cover is not installed, the protective structure (JEM1030) changes to open type (IP00).

7 INSTALLATION

- For FR-E720-5.5K (FR-E720-240) or more and FR-E740-11K (FR-E740-230) or more
- (1) Remove the front cover 1 and 2 from the inverter. (For removing the front cover, refer to the FR-E700 instruction manual.)
 - (2) Remove the PU cover from the front cover 2. For removing the PU cover, refer to *page 8*.




REMARKS

- Because the voltage class is stated on the PU cover, replace a PU cover of a plug-in option front cover with the removed PU cover from the inverter.



- (3) Install the front cover 1 to the inverter.
- (4) Securely fit the connector of the plug-in option to the inverter connector along the guides.
- (5) Securely fix the both top and bottom of the plug-in option to the inverter with the accessory mounting screws. (tightening torque 0.45N•m to 0.55N•m) If the screw holes do not line-up, the connector may not have been plugged snugly. Check for loose plugging.
- (6) Remove the PU cover provided on the front cover for plug-in option and install the other PU cover, which was removed in (2).
- (7) Mount the already wired terminal block to the plug-in option. (Refer to *the chapter 3* for wiring.)
- (8) Install the front cover for plug-in option to the inverter.



3 WIRING

3.1 System Configuration Example


- (1) Mount the communication option (FR-A7NL) on the inverter. (*Refer to page 7.*)
- (2) Connect the LONWORKS node, option unit, network management computer, and terminating resistor with the cable for LONWORKS communication.

Select a terminating resistor so that resistance values of R of the RC network are the same as shown below.

- Free topology (*Refer to page 6*) R = $52.3\Omega \pm 1\%$ 1/8W
- Bus topology (*Refer to page 6*) R = $105\Omega \pm 1\%$ 1/8W

- (3) Install the network management tool on the network management computer to assign the network address and bind (association function) the network variable, etc. to the LONWORKS node.

(Example) Bus topology (without stub)




REMARKS

- The network management tool is not included with this product. Please purchase it separately. For the network management tool, LonMaker by Echelon Co. is recommended.
- When the option unit has been replaced because of a fault or others, perform "Commission" or "Replace" from the network management tool after switching on the inverter. After performing "Commission" or "Replace", reset the inverter (switch power off once, then on again or turn the RES signal on).
- Use the network management computer in the earthed status. Use the isolated power supply if the computer can not be earthed.

3.2 Wiring

- (1) Strip off the sheath of the cable for LONWORKS communication. If the length of the sheath peeled is too long, a short circuit may occur among neighboring wires. If the length is too short, wires might come off.



**Wire the stripped cable after twisting it to prevent it from becoming loose.
(Do not solder it.)
Use a bar type terminal as required.**

REMARKS

- Information on bar terminals
Commercially available product examples (as of September, 2006)

Terminal Screw Size	Wire Size (mm ²)	Bar Terminal Model		Maker
		With insulation sleeve	Without insulation sleeve	
M3	0.3 to 0.5	AI 0,5-6WH	A 0,5-6	Phoenix Contact Co.,Ltd.
	0.5 to 0.75	AI 0,75-6GY	A 0,75-6	

Bar terminal crimping tool: CRIMPFOX ZA3 (Phoenix Contact Co., Ltd.)

When using the bar terminal (without insulation sleeve), use care so that the twisted wires do not come out.




- (2) Loosen the terminal screw and insert the cable into the terminal.
Tighten the fastening screws to the recommended tightening torques. Leave the other end of the cable unconnected.

Screw Size	Tightening Torque	Cable Size	Screwdriver
M3	0.5N·m to 0.6N·m	0.3mm ² to 0.75mm ²	Small ⊖ flat-blade screwdriver (Tip thickness: 0.4mm /tip width: 2.5mm)

CAUTION


- **Undertightening can cause cable disconnection or malfunction. Overtightening can cause a short circuit or malfunction due to damage to the screw or unit.**

<When using one twisted pair cable>



Twisted pair cable
To be connected
to other node

<When using two twisted pair cables>




Twisted pair cable
To be connected to
other node


REMARKS

- Change the number of twisted pair cables to insert in NET_A and NET_B according to the system used.

- (3) Connect the terminal block to the connector for communication of the communication option.




- (4) When wiring, if a hook of the front cover of the plug-in option impedes wiring, cut off the hook and perform wiring.

**REMARKS**

- When the option protective cover is not fitted or wire is not passed through even if the hook of the front cover of the plug-in option has been cut off, the protective structure (JEM1030) changes to open type (IP00).

- (5) For wiring of FR-E720-5.5K (FR-E720-240) or more and FR-E740-11K (FR-E740-230) or more, pass a cable on the inverter front cover as shown below. If a cable for LONWORKS communication is passed through inside the inverter front cover, the bending radius of the cable becomes small, stressing the cable.



CAUTION

-  **When wiring, take care not to subject the cable to stress.**
-  **After wiring, wire offcuts must not be left in the inverter. They may cause a fault, failure or malfunction.**

4 INVERTER SETTING

4.1 Parameter List

The following parameters are used for the communication option (FR-A7NL)
Perform setting as required.

Parameter Number	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page
79	Operation mode selection	0 to 4, 6, 7	1	0	21
338	Communication operation command source	0, 1	1	0	24
339	Communication speed command source	0, 1, 2	1	0	24
340	Communication startup mode selection	0, 1, 10	1	0	21
342	Communication EEPROM write selection	0, 1	1	0	28
349 *1	Communication reset selection	0, 1	1	0	35
387 *1	Initial communication delay time	0 to 120s	0.1s	0s	83
388 *1	Send time interval at heart beat	0 to 999.8s	0.1s	0s	87
389 *1	Minimum sending time at heart beat	0 to 999.8s	0.1s	0.5s	87
390 *1	% setting reference frequency	1 to 400Hz	0.01Hz	60Hz/50Hz *2	85
391 *1	Receive time interval at heart beat	0 to 999.8s	0.1s	0s	97
392 *1	Event driven detection width	0.00 to 163.83%	0.01%	0%	102
500 *1	Communication error execution waiting time	0 to 999.8s	0.1s	0	29
501 *1	Communication error occurrence count display	0	1	0	30
502 *3	Stop mode selection at communication error	0, 1, 2, 3	1	0	31
550 *3	NET mode operation command source selection	0, 2, 9999	1	9999	24

*1 Parameters which can be displayed when the plug-in option (FR-A7NL) is mounted.

*2 60Hz for the Japanese and NA version and 50Hz for the EC and CH version.

*3 The setting is reflected after inverter reset or at the next power-on.

4.2 Operation Mode Setting

The inverter mounted with a communication option has three operation modes.

- (1) PU operation [PU]..... Controls the inverter from the key of the operation panel on the inverter or parameter unit (FR-PU07/FR-PA07).
- (2) External operation [EXT] ... Controls the inverter by switching on/off external signals connected to the control circuit terminals of the inverter.
(The inverter is factory-set to this mode.)
- (3) Network operation [NET] ... Controls the inverter with instructions from the network via the communication option.
(The operation signal and running frequency can be entered from the control circuit terminals depending on the *Pr. 338 Communication operation command source* and *Pr. 339 Communication speed command source* setting.
Refer to page 25.)

4.2.1 Operation mode indication

Operation panel



Operation mode indication
(The inverter operates according to the LED lit mode.)
PU: PU operation mode
EXT: External operation mode
NET: Network operation mode

4.2.2 Operation mode switching and communication startup mode (Pr. 79, Pr. 340)

(1) Operation mode switching conditions

Before switching the operation mode, check that:

- 1) The inverter is at a stop;
- 2) Both the STF and STR signals are off; and
- 3) The *Pr. 79 Operation mode selection* setting is correct.

(Set using the operation panel of the inverter or parameter unit (FR-PU07/FR-PA07).)

Refer to *the inverter manual* for details of *Pr. 79*.

(2) Operation mode selection at power on and at restoration from instantaneous power failure

The operation mode at power on and at restoration from instantaneous power failure can be selected.

Set a value other than "0" in *Pr. 340* to select the network operation mode.

After started in network operation mode, parameter write from the network is enabled.

REMARKS

- Change of the *Pr. 340* setting is made valid when powering on or resetting the inverter.
- *Pr. 340* can be changed with the operation panel independently of the operation mode.

7 INVERTER SETTING



Pr. 340 Setting	Pr. 79 Setting	Operation Mode at Power on or Power Restoration	Operation Mode Switchover
0 (initial value)	0 (initial value)	External operation mode	Switching among the external, PU, and NET operation mode is enabled *1
	1	PU operation mode	PU operation mode fixed
	2	External operation mode	Switching between the external and Net operation mode is enabled Switching to the PU operation mode is disallowed
	3, 4	External/PU combined operation mode	Operation mode switching is disallowed
	6	External operation mode	Switching among the external, PU, and NET operation mode is enabled while running.
	7	X12 (MRS) signal ON external operation mode	Switching among the external, PU, and NET operation mode is enabled *1
X12 (MRS) signal OFF ... external operation mode		External operation mode fixed (Forcibly switched to external operation mode.)	
1	0	NET operation mode	Same as when Pr. 340 = "0"
	1	PU operation mode	
	2	NET operation mode	
	3, 4	External/PU combined operation mode	
	6 *3	NET operation mode	
	7	X12 (MRS) signal ON NET operation mode	
X12 (MRS) signal OFF ... external operation mode			
10	0	NET operation mode	Switching between the PU and NET operation mode is enabled *2
	1	PU operation mode	Same as when Pr. 340 = "0"
	2	NET operation mode	NET operation mode fixed
	3, 4	External/PU combined operation mode	Same as when Pr. 340 = "0"
	6 *3	NET operation mode	Switching between the PU and NET operation mode is enabled while running *2
	7	External operation mode	Same as when Pr. 340 = "0"

*1 Operation mode can not be directly changed between the PU operation mode and network operation mode.

*2 Operation mode can be changed between the PU operation mode and network operation mode with  of the operation panel and X65 signal.

*3 Pr. 79 = "6" and Pr. 128 to Pr. 134 (PID control) are not activated simultaneously. Switchover mode and PID control are made invalid, and the inverter performs the same operation as when "0" is set in Pr. 79.

(3) Operation mode switching method



For the switching method from the external terminal, refer to *the inverter manual*.
 Refer to page 46 and 78 for a switching method from the network.

CAUTION

- When starting the inverter in network operation mode at powering on or an inverter reset, set a value other than 0 in Pr. 340. (Refer to page 21)
- When setting a value other than 0 in Pr. 340, make sure that the initial settings of the inverter are correct.

4.3 Operation and Speed Command Source (Pr. 338, Pr. 339, Pr. 550)

(1) Select control source for the network operation mode (Pr. 550)

A control location for the network operation mode can be selected from either the RS-485 communication with the PU connector or communication option.

When using a communication option, set "0 or 9999 (initial value)" in Pr. 550.

Parameter Number	Name	Initial Value	Setting Range	Description
550	NET mode operation command source selection	9999	0	Selects the communication option as NET operation mode command source.
			2	Selects the PU connector as the NET operation mode command source.
			9999	Automatic communication option recognition Normally, PU connector is the command source. When a communication option is mounted, the communication option is the command source.

Refer to the inverter manual for details.

(2) Selection of control source for the network operation mode (Pr. 338, Pr. 339)

- As control sources, there are the operation command source that controls the signals related to the inverter start command and function selection and the speed command source that controls the signals related to frequency setting.
- In network operation mode, the commands from the external terminals and communication (PU connector or communication option) are as listed below.

Operation Location Selection		Pr. 338 Communication operation command source		0: NET			1: External			Remarks	
				0: NET	1: External	2: External	0: NET	1: External	2: External		
Fixed function (terminal-equivalent function)	Running frequency from communication		NET	—	NET	NET	—	NET			
	Terminal 2		—	External	—	—	External	—			
	Terminal 4		—	External		—	External				
Selective function	Pr. 178 to Pr. 184 setting	0	RL	Low speed operation command/remote setting clear/stop-on contact selection 0	NET	External		NET	External	Pr. 59 = "0" (multi-speed) Pr. 59 = "1, 2" (remote) Pr. 270 = "1" (stop-on-contact)	
		1	RM	Middle speed operation command/remote setting function	NET	External		NET	External		
		2	RH	High speed operation command/remote setting function	NET	External		NET	External		
		3	RT	Second function selection/stop-on contact selection 1	NET		External				Pr. 270 = "1" (stop-on-contact)
		4	AU	Current input selection	—	Combined		—	Combined		
		5	JOG	Jog operation selection	—		External				

7 INVERTER SETTING

Operation Location Selection	Pr. 338 Communication operation command source		0: NET			1: External			Remarks		
	Pr. 339 Communication speed command source		0: NET	1: External	2: External	0: NET	1: External	2: External			
Selective function Pr. 178 to Pr. 184 setting	7	OH	External thermal relay input		External						
	8	REX	Fifteen speed selection	NET	External		NET	External		Pr. 59 = "0" (multi-speed)	
	10	X10	Inverter operation enable signal		External						
	12	X12	PU operation external interlock		External						
	14	X14	PID control valid terminal		NET	External		NET	External		
	15	BRI	Brake opening completion signal		NET			External			
	16	X16	PU-external operation switchover		External						
	18	X18	V/F switching		NET			External			
	24	MRS	Output stop		Combined			External			Pr. 79 ≠ "7"
			PU operation interlock		External					Pr. 79 = "7" When the X12 signal is not assigned	
25	STOP	Start self-holding selection		—			External				
60	STF	Forward rotation command		NET			External				

Operation Location Selection		<i>Pr. 338 Communication operation command source</i>		0: NET			1: External			Remarks	
				0: NET	1: External	2: External	0: NET	1: External	2: External		
Selective function	<i>Pr. 178 to Pr. 184 setting</i>	61	STR	Reverse rotation command	NET			External			
		62	RES	Reset				External			
		65	X65	PU/NET operation switchover				External			
		66	X66	NET-external operation switching				External			
		67	X67	Command source switchover				External			

[Explanation of table]

External : Command is valid only from control terminal.

NET : Command only from communication is valid

Combined : Command from both control terminal and communication is valid.

— : Command from either of control terminal and communication is invalid.

REMARKS

- The command source of communication is as set in *Pr. 550* and *Pr. 551*.
- The *Pr. 338* and *Pr. 339* settings can be changed while the inverter is running when *Pr. 77* = "2". Note that the setting change is reflected after the inverter has stopped. Until the inverter has stopped, communication operation command source and communication speed command source before the setting change are valid.

4.3.1 Communication EEPROM write selection (Pr. 342)

When parameter write is performed from the communication option, write to RAM is enabled. Set when frequent parameter changes are necessary.

Parameter Number	Name	Initial Value	Setting Range	Description
342	Communication EEPROM write selection	0	0	Parameter values written by communication are written to the EEPROM and RAM.
			1	Parameter values written by communication are written to the RAM.

- When changing the parameter values frequently, set "1" in *Pr. 342* to write them to the RAM. Performing frequent parameter write with "0 (initial value)" (EEPROM write) set will shorten the life of the EEPROM.

REMARKS

- When "1" (write to RAM only) is set in *Pr. 342*, powering off the inverter will erase the changed parameter values. Therefore, the parameter values available when power is switched on again are the values stored in EEPROM previously.

4.4 Operation at Communication Error Occurrence


4.4.1 Operation selection at communication error occurrence (Pr. 500 to Pr. 502)

You can select operations at communication error occurrences by setting *Pr. 500 to Pr. 502* under network operation.

(1) The set time from when a communication line error occurrence until communication error output

You can set the waiting time from when a communication line error occurs until it is recognized as a communication error.

Parameter Number	Name	Setting Range	Minimum Setting Increments	Initial Value
500	Communication error execution waiting time	0 to 999.8s	0.1s	0



If the communication line error still persists after the time set in *Pr. 500* has elapsed, it is recognized as a communication error.

When the error is restored to normal communication within the set time, it is not regarded as a communication error and operation continues.

REMARKS


- For detection of communication error, set *Pr. 391 Receive time interval at heart beat* and set the send time interval from the other node shorter than the heartbeat receive time interval.
 When data is not received for more than the heartbeat receive time interval after the first reception, it is considered as a communication line error, then "communication line alarm (E.OP1)" is displayed and the inverter stops. (Refer to page 97.)

(2) Display and erasure of communication error occurrence count

The cumulative number of communication error occurrences can be indicated.

Write "0" to erase this cumulative count.

Parameter Number	Name	Setting Range	Minimum Setting Increments	Initial Value
501	Communication error occurrence count display	0	1	0



At the point of communication line error occurrence, *Pr. 501 Communication error occurrence count display* is incremented by 1.

CAUTION

- The communication error count occurrence is stored into RAM temporarily. Since this data is stored in EEPROM at one-hour intervals, performing power-on reset or inverter may cause the *Pr. 501* data to be the value stored in EEPROM the last time depending on the reset timing.

(3) Inverter operation selection at communication error occurrence

You can select the inverter operation if a communication line error or an error of the option unit itself occurs.

Parameter Number	Name	Setting Range	Minimum Setting Increments	Initial Value
502	Stop mode selection at communication error	0, 1, 2, 3	1	0

About setting

● **Operation at error occurrence**

Alarm Definition	Pr. 502 Setting	Operation	Indication	Alarm Output
Communication line	0	Continued *	Normal indication *	Not provided *
	1			
	2			
	3			
Communication option itself	0, 3	Coast to stop	E. 1 lit	Provided
	1, 2	Decelerated to stop	E. 1 lit after stop	Provided after stop

* When the error returns to normal communication within the time set in Pr. 500, it is not regarded as a communication line error (E.OP1).

● **Operation at error recognition after elapse of Pr. 500 time**

Alarm Definition	Pr. 502 Setting	Operation	Indication	Alarm Output
Communication line	0	Coast to stop	E.OP1 lit	Provided
	1	Decelerated to stop	E.OP1 lit after stop	Provided after stop
	2			Not provided
	3	Continued	Normal indication	
Communication option itself	0, 3	Coast to stop	E. 1 lit	Provided
	1, 2	Decelerated to stop	E. 1 lit after stop	Provided after stop

● Operation at error removal

Alarm Definition	Pr. 502 Setting	Operation	Indication	Alarm Output
Communication line	0	Kept stopped	E.OP1 kept lit	Kept provided
	1			
	2	Restart	Normal indication	Not provided
	3	Continued		
Communication option itself	0, 3	Kept stopped	E. 1 kept lit	Kept provided
	1, 2			

CAUTION

- A communication line error [E.OP1 (alarm data: HA1)] is an error that occurs on the communication line, and an error of the communication option unit itself [E. 1 (alarm data: HF1)] is a communication circuit error in the option.
- The alarm output indicates alarm output signal (ALM signal) or alarm bit output.
- When the setting was made to provide an alarm output, the error definition is stored into the alarm history. (The error definition is written to the alarm history when an alarm output is provided.)
When no alarm output is provided, the error definition overwrites the alarm indication of the alarm history temporarily, but is not stored.
After the error is removed, the alarm indication is reset and returns to the ordinary monitor, and the alarm history returns to the preceding alarm indication.
- When the Pr. 502 setting is "1" or "2", the deceleration time is the ordinary deceleration time setting (e.g. Pr. 8, Pr. 44, Pr. 45).
- The acceleration time at a restart is the ordinary acceleration time setting (e.g. Pr. 7, Pr. 44).
- When the Pr. 502 setting is "2", the operation/speed command at a restart is the one given before the error occurrence.
- When a communication line error occurs at the Pr. 502 setting of "2", removing the error during deceleration causes acceleration to restart at that point. (Acceleration is not restarted if the error is that of the option unit itself.)

4.4.2 Alarm and measures

(1) The inverter operates as follows at alarm occurrences.

Alarm Location	Status		Operation Mode		
			Network Operation	External Operation	PU Operation
Inverter	Inverter operation		Inverter trip	Inverter trip	Inverter trip
	Data communication		Continued	Continued	Continued
Communication line	Inverter operation		Inverter trip *	Continued	Continued
	Data communication		Stop	Stop	Stop
Communication option	Communication option connection error	Inverter operation	Inverter trip *	Inverter trip *	Inverter trip *
		Data communication	Continued	Continued	Continued
	Error of communication option itself	Inverter operation	Inverter trip *	Continued	Continued
		Data communication	Stop	Stop	Stop

* Depends on the *Pr: 502* setting.

(2) Measures at alarm occurrences

Alarm Indication	Alarm Definition	Measures
E.OP1	Communication line error	Check the LED status of the option unit and remove the cause of the alarm. (Refer to <i>page 4</i> for LED indication status) Check the other nodes on the network. Inspect the master.
E.1	Option alarm	Check the connection between the inverter and option unit for poor contact, etc. and remove the cause of the error.

When alarms other than the above are displayed, refer to the inverter manual and remove the cause of the alarm.

4.5 Inverter Reset

(1) Operation conditions of inverter reset

Which resetting method is allowed or not allowed in each operation mode is described below.

Resetting Method		Operation Mode		
		Network Operation	External Operation	PU Operation
Reset from the network	Inverter reset (Command request network variable) (Refer to page 77) *1	Enabled	Disabled	Disabled
	Error reset at inverter fault (Inverter input signal network variable) (Refer to page 61) *2	Pr.349 = 0 Pr.349 = 1	Enabled Disabled	Enabled Disabled
Turn on the inverter terminal RES (RES signal)		Enabled	Enabled	Enabled
Switch off inverter power		Enabled	Enabled	Enabled
Reset from the PU/operation panel	Inverter reset	Enabled	Enabled	Enabled
	Reset at inverter fault	Enabled	Enabled	Enabled

*1 Inverter reset can be made any time.

*2 Reset can be made only when the protective function of the inverter is activated.

CAUTION

- When a communication line error has occurred, reset cannot be made from the network.
- The inverter is set to the external operation mode if it has been reset in network operation mode in the initial status.
To resume the network operation, the inverter must be switched to the network operation mode again.
Set a value other than "0" in Pr. 340 to start in network operation mode. (Refer to page 21.)
- The inverter can not be controlled for about 1s after release of a reset command .

(2) Error reset operation selection at inverter fault

When used with the communication option, an error reset command* from network can be made invalid in the external operation mode or PU operation mode.

Parameter Number	Name	Initial Value	Setting Range	Function
349	Communication reset selection	0	0	Error reset* is enabled independently of operation mode
			1	Error reset* is enabled only in the network operation mode

* nvInvAlarmReset (Refer to page 61.)

5 FUNCTION OVERVIEW

5.1 XIF File

Using the configuration software, network setting is easily done.

To use the configuration software, an XIF file is necessary. XIF file is used to recognize device features and functions. For details of installation and XIF file usage, refer to the configuration software manual.

XIF file can be downloaded from

Mitsubishi Electric FA Network Service MELFANS web

<http://www.MitsubishiElectric.co.jp/melfansweb> or obtained from your sales representative.

CAUTION

- **Since memory for write enable application is not installed in the inverter, Mitsubishi does not provide application files (file extensions such as .nxe, .apb).**
-
-

5.2 Output from the Inverter to the Network

Main items to be output from the inverter (FR-A7NL) to the network and their descriptions are explained below.

Item	Description	Refer to Page
Object status	You can check the condition of the node.	47
Speed monitor	You can monitor the output frequency in 0.005% increments.	50
Inverter output signal	You can monitor the output terminal status of the inverter.	53
Output frequency monitor	You can monitor the output frequency in 0.1/0.01Hz or 0.005% increments.	57, 58, 76
Output current monitor	You can monitor the output current in 0.1A increments.	59
Output voltage monitor	You can monitor the output voltage in 0.1V increments.	59
Actual operation time monitor	You can monitor the actual operation time of the inverter.	59
Cumulative power monitor	You can monitor the cumulative power of the inverter.	60
Alarm occurrence definition	At inverter alarm occurrence, you can confirm the alarm definition.	62
Product information	You can output the maker name and type as a character string.	64
Emergency stop status	You can confirm the emergency stop status of the inverter.	66
Alarm status	You can check whether the inverter is in the alarm status or not.	67
Monitor data	You can check the monitor value corresponding to the monitor code set.	75
Command response	You can check the reply to command requests, e.g. operation mode selection, parameter write, inverter reset, from the inverter.	82

REMARKS

- Refer to *the inverter manual* for functions controllable from the network in each operation mode.

5.3 Input from the Network to the Inverter

Main items which can be commanded from the network to the inverter and their descriptions are explained below.

Item	Description	Refer to Page
Object request	You can make a request to know the object status.	46
Start and stop/simple speed setting	You can perform start/stop and simple frequency setting.	48
Speed adjustment	You can perform frequency setting in 0.005% increments.	49
Inverter input signal	You can execute functions assigned to the inverter input terminals.	51
Set frequency write destination selection	You can select either of RAM or EEPROM as the write destination of set frequencies.	55
Set frequency	You can set the set frequency in 0.1/0.01Hz or 0.005% increments.	56, 76
Alarm reset	You can reset the inverter at an inverter alarm occurrence.	61
Emergency stop command	You can make an emergency stop of the inverter.	65
PID set point	You can input the set point for PID control.	69
PID measured value	You can input the current measured value for PID control.	70
PID deviation	You can input the current deviation for PID control.	71
Monitor code	You can input a code to select a monitor type.	72
Command request	You can make command requests, e.g. operation mode selection, parameter write, inverter reset, to the inverter.	77
Initial communication delay time	You can set the time from when the inverter starts until when data is sent to the network.	83
Forward/reverse rotation prevention	You can prevent rotation in the wrong direction.	84
% setting reference frequency	You can set the reference frequency of set frequency (nvInVSetFreqP) and output frequency (nvInVOutFreqP).	85
Maximum frequency	You can set the maximum frequency of the inverter.	86
Minimum frequency	You can set the minimum frequency of the inverter.	86

Item	Description	Refer to Page
Heartbeat send time interval	You can set the heartbeat send time interval of output network variables.	87
Minimum heartbeat send time	You can set the minimum heartbeat send time of output network variables.	87
Acceleration time	You can set the motor acceleration time.	90
Deceleration time	You can set the motor deceleration time.	91
PID action selection	You can choose the operation of PID control.	92
PID proportional band	You can set the proportional band for PID control.	94
PID integral time	You can set the integral time for PID control.	94
PID differential time	You can set the differential time for PID control.	95
PID manipulated bias	You can set the manipulated variable at 0%.	95
PID manipulated gain	You can set the manipulated variable at 100%.	96
Heartbeat receive time interval	You can set the heartbeat receive time interval of input network variables.	97
Maximum speed	You can set the maximum speed of the inverter.	99
Minimum speed	You can set the minimum speed of the inverter.	99
Reference speed setting	You can set the reference speed of maximum speed, minimum speed, speed adjustment, speed monitor.	100
Reference frequency setting	You can set the reference frequency of maximum speed, minimum speed, speed adjustment, speed monitor.	101
Default value of speed adjustment	You can set the default value of speed adjustment.	101
Event driven detection width	You can set the event driven detection width of the monitor-related output network variables.	102


REMARKS

- Refer to *the inverter manual* for functions controllable from the network in each operation mode.

6 NETWORK VARIABLES

6.1 Object Map

This chapter describes detailed object definitions for use of LONWORKS system.



6.2 Network Variable List

No.	Type *4	Function	Network Variables		In/ Out	Setting Value Storage Location	Size (byte)	Initial Value	Refer to Page
			Variables	Name					
1	SN	Object request	SNVT_obj_request	nviRequest	In	—	3	H0	46
2	SN	Object status	SNVT_obj_status	nvoStatus	Out		6	H0	47
3	SN	Start/stop and simple speed setting	SNVT_switch	nviDrvSpeedStpt	In		2	state=HFF value=0	48
4	SN	Speed adjustment	SNVT_lev_percent	nviDrvSpeedScale	In		2	100.00%	49
5	SN	Speed monitor	SNVT_lev_percent	nvoDrvSpeed	Out		2	0.000%	50
6	SN	Inverter input signal	SNVT_state	nviInvInputSig	In		2	0	51
7	SN	Inverter output signal	SNVT_state	nvoInvOutputSig	Out		2	H8000	53
8	SN	Set frequency write destination selection	SNVT_switch	nviInvSetFreqSw	In		2	state=H0 value=0	55
9	SN	Set frequency (0.1Hz/bit) *1	SNVT_freq_hz	nviInvSetFreq	In	RAM/ EEPROM of the inverter	2	H7FFF	56
10	SN	Set frequency (0.005%/bit)	SNVT_lev_percent	nviInvSetFreqP	In		2	100.00%	56
11	SN	Output frequency monitor (0.1Hz/bit) *1	SNVT_freq_hz	nvoInvOutFreq	Out	—	2	0.0Hz	57
12	SN	Output frequency monitor (0.005%/bit)	SNVT_lev_percent	nvoInvOutFreqP	Out		2	0.000%	58
13	SN	Output current monitor (0.1A/bit) *1	SNVT_amp	nvoDrvCurnt	Out		2	0.0A	59
14	SN	Output voltage monitor (0.1V/bit) *1	SNVT_volt	nvoDrvVolt	Out		2	0.0V	59
15	SN	Actual operation time monitor (1 h/bit)	SNVT_time_hour	nvoDrvRunHours	Out	EEPROM of the inverter	2	0h	59
16	SN	Cumulative power monitor(1kWh/bit)	SNVT_elec_kwh	nvoDrvRunPower	Out		2	0kWh	60

No.	Type *4	Function	Network Variables		In/ Out	Setting Value Storage Location	Size (byte)	Initial Value	Refer to Page	
			Variables	Name						
17	SN	Alarm reset	SNVT_switch	nvilnvAlarmReset	In	—	2	state=H0 value=H0	61	
18	SN	Alarm occurrence definition	SNVT_str_asc	nvolnvAlarmStr	Out		31	0	62	
19	SN	Product information (maker name, type)	SNVT_str_asc	nvolnvTypeInfo	Out		31	MITSUBISHI FR-A7NL	64	
20	SN	Emergency stop command	SNVT_hvac_emerg	nviEmergOverride	In		1	H0	65	
21	SN	Emergency stop status	SNVT_hvac_emerg	nvoEmergStatus	Out		1	H0	66	
22	SN	Alarm status	SNVT_switch	nvoDrvAlarm	Out		2	state=H0 value=H0	67	
23	SN	PID set point (0.005%/bit)	SNVT_lev_percent	nvilnvPIDTarget	In		2	0.000%	69	
24	SN	PID measured value (0.005%/bit)	SNVT_lev_percent	nvilnvPIDValue	In		2	0.000%	70	
25	SN	PID deviation (0.005%/bit)	SNVT_lev_percent	nvilnvPIDDev	In		2	0.000%	71	
26	SN	Monitor code	SNVT_count	nvilnvMonCode	In		2	0	72	
27	SN	Monitor data	SNVT_count	nvolnvMonData	Out		2	0	75	
28	SN	Set frequency (0.01Hz/bit)	SNVT_count	nvilnvSetFreq2	In		RAM/ EEPROM of the inverter	2	0.00Hz	76
29	SN	Output frequency monitor (0.01Hz/bit)	SNVT_count	nvolnvOutFreq2	Out		—	2	0.00Hz	76
30	SN	Command request	SNVT_str_asc	nvilnvCmdReq	In	31		0	77	
31	SN	Command reply	SNVT_str_asc	nvolnvCmdReply	Out	31		0	82	
32	SC	Initial communication delay time (0.1s/bit)	SNVT_time_sec	nciPwUpOutTm	In	Pr. 387	2	0s	83	
33	SC	Forward/reverse rotation prevention	SNVT_count	ncilnvFwdRevLock	In	Pr. 78	2	*2	84	

No.	Type *4	Function	Network Variables		In/ Out	Setting Value Storage Location	Size (byte)	Initial Value	Refer to Page
			Variables	Name					
34	SC	% set reference frequency (0.1Hz/bit) *1	SNVT_freq_hz	nciInvSetFreqBas	In	<i>Pr. 390</i>	2	60Hz <50Hz> *3	85
35	SC	Maximum frequency (0.1Hz/bit) *1	SNVT_freq_hz	nciInvMaxFreq	In	<i>Pr. 1</i>	2	*2	86
36	SC	Minimum frequency (0.1Hz/bit) *1	SNVT_freq_hz	nciInvMinFreq	In	<i>Pr. 2</i>	2	*2	86
37	SC	Heartbeat send time interval (0.1s/bit)	SNVT_time_sec	nciSndHrtBt	In	<i>Pr. 388</i>	2	0	87
38	SC	Minimum heartbeat send time (0.1s/bit)	SNVT_time_sec	nciMinOutTm	In	<i>Pr. 389</i>	2	0.5s	87
39	SC	Acceleration time (0.1s/bit)	SNVT_time_sec	nciRampUpTm	In	<i>Pr. 7</i>	2	*2	90
40	SC	Deceleration time (0.1s/bit)	SNVT_time_sec	nciRampDownTm	In	<i>Pr. 8</i>	2	*2	91
41	SC	PID action selection	SNVT_count	nciInvPIDSwitch	In	<i>Pr. 128</i>	2	*2	92
42	SC	PID proportional band (0.1%/bit)	SNVT_count	nciInvPIDPro	In	<i>Pr. 129</i>	2	*2	94
43	SC	PID integral time (0.1s/bit)	SNVT_time_sec	nciInvPIDIntTm	In	<i>Pr. 130</i>	2	*2	94
44	SC	PID differential time (0.1s/bit) *1	SNVT_time_sec	nciInvPIDDiffTm	In	<i>Pr. 134</i>	2	*2	95
45	SC	PID manipulated variable bias (0.1Hz/bit) *1	SNVT_freq_hz	nciInvPIDOpeBias	In	<i>C2 (Pr. 902)</i>	2	*2	95
46	SC	PID manipulated variable gain (0.1Hz/bit) *1	SNVT_freq_hz	nciInvPIDOpeGain	In	<i>Pr.125 (Pr. 903)</i>	2	*2	96
47	SC	Heartbeat receive time interval (0.1s/bit)	SNVT_time_sec	nciRcvHrtBt	In	<i>Pr. 391</i>	2	0s	97
48	SC	Maximum speed (0.005%/bit)	SNVT_lev_percent	nciMaxSpeed	In	<i>Pr. 1</i>	2	*2	99
49	SC	Minimum speed (0.005%/bit)	SNVT_lev_percent	nciMinSpeed	In	<i>Pr. 2</i>	2	*2	99
50	SC	Reference speed setting (1r/min/bit)	SNVT_rpm	nciNm1Speed	In	<i>Pr. 390</i>	2	1800r/min <1500r/min> *3	100

No.	Type *4	Function	Network Variables		In/ Out	Setting Value Storage Location	Size (byte)	Initial Value	Refer to Page
			Variables	Name					
51	SC	Reference frequency setting (0.1Hz/bit) *1	SNVT_freq_hz	nciNmIFreq	In	<i>Pr. 390</i>	2	60Hz <50Hz> *3	101
52	SC	Speed adjustment default value	SNVT_lev_percent	nciDrvSpeedScale	In	—	2	100.00%	101
53	SC	Event driven detection width (0.005%/bit)	SNVT_lev_percent	nciInvEvtDuty	In	<i>Pr. 392</i>	2	0%	102
54	SN	Cumulative power monitor 2 (0.1kWh/bit)	SNVT_elec_kwh_l	nvoDrvRunPower_l	Out	EEPROM of the inverter	4	0kWh	61
55 to 62	System reserved								

*1 Displayed in 0.01 increments on the operation panel.

*2 Refer to the inverter manual for the corresponding parameter initial values.

*3 Values within parenthesis are initial values for EC and CH versions.

*4 SN represents "SNVT" (Standard network variables) and SC represents "SCPT" (configuration property).

REMARKS

- Write conditions of configuration property is same as those of the inverter parameter. Write conditions are restricted by *Pr. 77 Parameter write selection*. When writing to configuration property during inverter operation, set "2" in *Pr. 77*. Refer to *the inverter manual* for details of *Pr. 77*.

6.3 LONWORKS Object

6.3.1 Setting range of object ID

The setting values of object ID are 0 to 4 and are as listed below.

When any values 5 to 65535 are set for object ID, invalid_id bit of object status (nvoStatus) becomes 1 and a command set for object request is made invalid. (*Refer to page 47*)

Object ID	Description
0	Node object
1	Variable Speed Motor Drive object [LONMARK object]
2	Inverter basic function
3	Inverter PID control function
4	Inverter extended function

6.3.2 Object request (network input SNVT_obj_request nviRequest)

You can make a request to get the object status.

Member Name		Description		Initial Value
object_id		Stores the object ID.		
object_request	H0	RQ_NORMAL	In external operation mode *3, it shifts to the network operation mode.	H0
	H1	RQ_DISABLED	Makes the inverter object invalid.	
	H2	RQ_UPDATE_STATUS	Update object status (nvoStatus).	
	H3	RQ_SELF_TEST	Not supported.*1	
	H4	RQ_UPDATE_ALARM	Updates in_alarm bit of the object status (nvoStatus).	
	H5	RQ_REPORT_MASK	Changes bit (invalid_id, invalid_request, disabled, manual_control, in_alarm, in_override, report_mask) supported by object status (nvoStatus) to "1".	
	H6	RQ_OVERRIDE	Not supported.*1	
	H7	RQ_ENABLE	Makes the inverter object valid.	
	H8	RQ_RMV_OVERRIDE	Not supported.*1	
	H9	RQ_CLEAR_STATUS	Clears all bits of the object status (nvoStatus) to "0".	
	HA	RQ_CLEAR_ALARM	Clears in_alarm bit of object status (nvoStatus) to "0".*2	
	HB	RQ_ALARM_NOTIFY_ENABLED	Not supported.*1	
	HC	RQ_ALARM_NOTIFY_DISABLED		
	HD	RQ_MANUAL_CTRL	Shifts the inverter to the external operation mode.	
	HE	RQ_REMOTE_CTRL	Shifts the inverter to the network operation mode.	
	HF	RQ_PROGRAM	Not supported.*1	
HFF	RQ_NUL	Nothing is done.		
—	Other than the above	Not supported.*1		

*1 Changes the invalid_request of the object status (nvoStatus) to "1" when data is set. (Refer to page 47)

*2 Use alarm reset (nviInvAlarmReset) to reset the alarm status of the inverter. (Refer to page 61)

*3 Can also be switched from switchover mode. (For details of switchover mode, refer to *the inverter manual*.)

6.3.3 Object status (network output SNVT_obj_status nvoStatus)

You can indicate the condition of the node.

Member Name	Description	Initial Value
object_id	The setting value of object request (nviRequest) written to object_id is displayed.	H0
invalid_id	Changes to "1" if an illegal object ID is specified in object_id of the object request (nviRequest).	
invalid_request	Changes to "1" if object_request not supported by the object request (nviRequest) is set.	
disabled	Changes to "1" if the object of the inverter is invalid.	
out_of_limits	Not supported.*	
open_circuit		
out_of_service		
Mechanical_fault		
feedback_failure		
over_range		
under_range		
electrical_fault		
unable_to_measure		
comm_failure		
fail_self_test		
self_test_in_progress		
locked_out		
manual_control	Changes to "1" if the operation mode of the inverter is other than the network operation mode.	
in_alarm	Changes to "1" during the inverter is in the alarm status.	
in_override	Changes to "1" if the operation mode of the inverter is network operation mode and run command and speed command are not given via the network.	
report_mask	Not supported.*	
programming_mode		
programming_fail		
alarm_notify_disabled		

* "0" is always set in the unsupported functions bit position.

6.4 Variable Speed Motor Drive Object

6.4.1 Start/stop and simple speed setting (network input SNVT_switch nviDrvSpeedStpt)

You can set "start/stop" and "simple setting of set frequency".

- Set start/stop in state.

The rotation direction (forward/reverse rotation) is determined by whether "speed adjustment (nviDrvSpeedScale)" (Refer to page 49) is positive or negative.

- Set simple speed setting in value.

As the set frequency, set its ratio to "speed adjustment (nviDrvSpeedScale)" (0.5% increments).

nviDrvSpeedStpt		Operation *	
State	Value	nviInvSetFreq = "H7FFF"	nviInvSetFreq = "0Hz to 400Hz"
H0	NA	Stop	
H1	0 (initial value)	Run at a 0% frequency.	
	0.5 to 100%	Run at a 0.5 to 100% frequency. (nciNmIFreq × nviDrvSpeedStpt × nviDrvSpeedScale)	Run at an nviInvSetFreq frequency.
H2 to HFF (initial value: HFF)	NA	No operation	

* Operation of nviDrvSpeedStpt differs according to nviInvSetFreq. (Refer to page 56)

REMARKS

- The variable is initialized to "HFF" at power-on or if it is not updated at the "heartbeat receive time interval (nciRcvHrtBt)" (Refer to page 97).
- The inverter operates at value = 100% frequency even if "the value exceeding 100%" is set when state = "H1".
- Updating nviDrvSpeedScale resets the start command depending on the state of nviDrvSpeedStpt.

6.4.2 Speed adjustment (0.005% increments) (network input SNVT_lev_percent nviDrvSpeedScale)

You can set the set frequency in 0.005% increments on the assumption that the frequency set in "reference frequency setting (nciNmiFreq)" (Refer to page 101) is 100%.

- When the state of nviDrvSpeedStpt is H1, the motor is placed in forward rotation status if nviDrvSpeed Scale value is positive and placed in reverse rotation status if the value is negative.
- When state of nviDrvSpeedStpt is H0, the motor is at a stop status.

Data Name	Initial Value	Range	Increments
nviDrvSpeedScale	100.00% (NciDrvSpeedScale value) <i>(Refer to page 101)</i>	-163.840% to 163.830%	0.005%/bit

- Data acceptance timing At network variable receive (nv_update_occurs event)

The frequency to be written to the inverter actually is as shown in the following formula.

$$\text{Set frequency} = | (\text{reference frequency setting} \times \text{speed adjustment} \times \text{simple speed setting}) |$$

For example, when "Reference frequency setting (nciNmiFreq)" = 60.0Hz, "Speed adjustment (nviDrvSpeedScale)" = -150%, and "Simple speed setting (nviDrvSpeed Stpt.value)" = 50%, output frequency is $(60.00\text{Hz} \times (-150\%) \times 50\%) = -45\text{Hz}$.

Therefore, a reverse command of 45Hz is given.

REMARKS

- The variable is initialized to "100.00%" at power-on or if it is not updated within the set "heartbeat receive time interval (nciRcvHrtBt)" (Refer to page 97).
- Control can not be exercised at less than the minimum frequency resolution (0.01Hz) of the inverter.
- To make the change of "reference frequency setting (nciNmiFreq)" reflected to the operation speed, a value is need to be written to speed adjustment (nviDrvSpeedScale)

6.4.3 Speed monitor (0.005% increments) (network output SNVT_lev_percent nvoDrvSpeed)

You can set the frequency command in 0.005% increments on the assumption that the frequency set in "reference frequency setting (nciNmiFreq)" (Refer to page 101) is 100%.

- A positive value indicates the motor is in the forward rotation status and a negative value indicates that the motor is in the reverse rotation status.

Data Name	Initial Value	Range	Increments
nvoDrvSpeed	0.000%	-163.840% to 163.830%	0.005%/bit

- Data send event When data changes in 0.005% increments
- Data send timing As set in Pr. 388 Send time interval at heart beat and Pr. 389 Minimum sending time at heart beat. (Refer to page 87)

Output frequency is as shown in the following formula.

$\text{Output frequency} = (\text{reference frequency setting} \times \text{speed monitor} \times \text{simple speed setting}) \times $
--

* Refer to page 101 for reference frequency setting and page 48 for simple speed setting.

For example, when "reference frequency setting(nciNmiFreq)" = 60.0Hz, "speed setting monitor(nvoDrvSpeed)" = -150%, and "simple speed setting(nviDrvSpeedStpt.value)" = 50%, output frequency is $(60.0\text{Hz} \times (-150\%) \times 50\%) = -45\text{Hz}$.

Therefore, a reverse rotation of 45Hz is given.

REMARKS

- Monitoring is disabled at less than the minimum frequency resolution (0.01Hz) of the inverter.

6.5 Inverter Basic Functions

6.5.1 Inverter input signal (network input SNVT_state nvInvInputSig)

A 16-bit-wide input signal to the inverter.

- The initial value of all bits are "0".
- Data acceptance timing At network variable receive (nv_update_occurs event)

Bit	Signal Name	Description	
0	Forward rotation command *2	0: Stop command 1: Forward rotation start	A starting command is input to the inverter when the signal turns to 1. A stop command is given when both signals turn to 1 simultaneously.
1	Reverse rotation command *2	0: Stop command 1: Reverse rotation start	
2	High-speed operation command (terminal RH function) *1	Functions assigned to terminals RH, RM and RL are activated.	
3	Middle-speed operation command (terminal RM function) *1		
4	Low-speed operation command (terminal RL function) *1		
5	Not used	Always 0	
6	Second function selection (RT signal) *3	1: Second function is selected	
7	Terminal 4 input selection (AU signal) *3	1: Terminal 4 input is the main speed setting	
8	Not used	Always 0	
9	Output stop (terminal MRS function) *1	Functions assigned to terminal MRS is activated.	
10	Not used	Always 0	
11	Inverter reset (terminal RES function) *1	Functions assigned to terminal RES is activated.*4	
12 to 15	Not used	System reserved	

- *1 Signal names are initial values. Using *Pr. 180 to Pr. 184*, you can change input signal functions. Note that some of signals do not accept a command from the network according to the *Pr. 338 and Pr. 339* settings. (*Refer to page 25*) Refer to *the inverter manual* for details of *Pr. 180 to Pr.184*.
- *2 Signals of the Bit0 and Bit1 can not be changed. Even when changed using *Pr.178 and Pr.179* the settings are invalid.
Refer to *the inverter manual* for details of *Pr. 178 and Pr.179*.
- *3 Signals of the Bit6 and Bit7 can not be changed.
- *4 Inverter reset function is invalid.

6.5.2 Inverter output signal (network output SNVT_state nvolnvOutputSig)

A 16-bit-wide output signal to the inverter.

- Data send timing As set in *Pr. 388 Send time interval at heart beat* and *Pr. 389 Minimum sending time at heart beat*. (Refer to page 87)

Bit	Signal Name	Description
0	During forward running	0: Other than during forward running (during stop, during reverse running) 1: During forward running
1	During reverse running	0: Other than during reverse running (during stop, during forward running) 1: During reverse running
2	Inverter running (terminal RUN function) *1	Functions assigned to terminals RUN are activated. Refer to the <i>page 54</i> for signals which can be assigned.
3	Up to frequency (SU signal) *2	1: Output frequency has reached the set frequency
4	Overload alarm (OL signal) *2	1: Overload alarm occurrence
5	Not used	Always 0
6	Frequency detection (terminal FU function) *1	Functions assigned to terminals FU and ABC activate. Refer to the <i>page 54</i> for signals which can be assigned.
7	Alarm (terminal ABC function) *1	
8	Not used	Always 0
9 to 13	Not used	System reserved
14	Error status flag	Turns to 1 when output stops due to the inverter fault occurrence. *3
15	Ready signal	Turns to 1 when the inverter is ready to operate after powering on. Turns to 0 when the inverter fault occurs (when the protective function is activated).

- *1 Signal names are initial values. Using *Pr. 190 to Pr.192*, you can change output signal functions. Refer to *the inverter manual* for details of *Pr. 190 to Pr.192*.
- *2 Signals of the Bit3 and Bit4 can not be changed.
- *3 When the retry function is used, the signal turns on according to the retry setting. Refer to the inverter manual for the retry function.

<Output Signal List>

The following signals can be assigned to Bit2, Bit6 and Bit7 using *Pr.190 to Pr.192* respectively.

For details of signal definitions, refer to *Pr. 190 to Pr. 192 Output terminal function selection of the inverter manual*.

Setting		Signal Name	Function
Positive Logic	Negative Logic		
0	100	RUN	Inverter running
1	101	SU	Up to frequency
3	103	OL	Overload alarm
4	104	FU	Output frequency detection
7	107	RBP	Regenerative brake pre-alarm
8	108	THP	Electronic thermal O/L relay function pre-alarm
11	111	RY	Inverter operation ready
12	112	Y12	Output current detection
13	113	Y13	Zero current detection
14	114	FDN	PID lower limit
15	115	FUP	PID upper limit
16	116	RL	PID forward/reverse rotation output
20	120	BOF	Brake opening request

Setting		Signal Name	Function
Positive Logic	Negative Logic		
25	125	FAN	Fan fault output
26	126	FIN	Heatsink overheat pre-alarm
46	146	Y46	During deceleration at occurrence of power failure
47	147	PID	During PID control activated
64	164	Y64	During retry
90	190	Y90	Life alarm
91	191	Y91	Fault output 3 (power-off signal)
93	193	Y93	Current average value monitor signal
95	195	Y95	Maintenance timer signal
96	196	REM	Remote output
98	198	LF	Alarm output
99	199	ALM	Fault output
9999		—	No function

REMARKS

- When an option error (E, !) occurs, all outputs are tuned off.

6.5.3 Set frequency write destination selection (network input SNVT_switch nvilnvSetFreqSw)

When writing the set frequency of any of the following network variable, you can select either of the internal memories of the inverter, RAM and EEPROM, as the write destination.

Network Variables Supported	Increments	Refer to page
nvilnvSetFreq	0.1Hz	56
nvilnvSetFreqP	0.005%	56
nvilnvSetFreq2	0.01Hz	76

State	Value	Write Destination	Operation
H0 (initial value)	Don't care (not used/ initial value: 0)	RAM	Switching power off erases the written value. You can prevent the write life of the EEPROM from becoming shorter.
H1		RAM, EEPROM	Switching power off does not erase the written value.
H2 to HFF		—	Invalid

- Data acceptance timing At network variable receive (nv_update_occurs event)

CAUTION

- When changing the set frequency frequently, set "RAM write."
With "write to EEPROM" being selected, frequent setting of the set frequency will shorten the life of the EEPROM.

6.5.4 Set frequency (0.1Hz increments) (network input SNVT_freq_hz nvInvSetFreq)

The set frequency can be set in 0.1Hz increments.

Data Name	Initial Value	Range	Increments
nvInvSetFreq	H7FFF	0.0Hz to 400.0Hz, H7FFF	0.1Hz/bit

· Data acceptance timing At network variable receive (nv_update_occurs event)

REMARKS

- When H7FFF is set, the set frequency is as set in "start/stop/simple speed setting (nviDrvSpeedStpt)" (Refer to page 48).
- H7FFF is not reflected as the actual set frequency value.
- Always set frequency (Hz) regardless of the Pr. 37 setting.

6.5.5 Set frequency (0.005% increments) (network input SNVT_lev_percent nvInvSetFreqP)

You can monitor the output frequency of the inverter in 0.005% increments on the assumption that the frequency set in "% set reference frequency (ncInvSetFreqBas)" (Refer to page 85) is 100%.

Data Name	Initial Value	Range	Increments
nvInvSetFreqP	100.000%	0.000% to 163.830%	0.005%/bit

· Data acceptance timing At network variable receive (nv_update_occurs event)

For example, when "% set reference frequency (ncInvSetFreqBas)" = 60.0Hz and "set frequency (nvInvSetFreqP)" = 50.000%, set frequency = $60 \times 0.5 = 30\text{Hz}$

REMARKS

- Control can not be exercised at less than the minimum frequency resolution (0.01Hz) of the inverter.

6.5.6 Output frequency monitor (0.1Hz increments) (network output SNVT_freq_hz nvolnvOutFreq)

You can monitor the output frequency of the inverter in 0.1Hz increments.

Data Name	Initial Value	Range	Increments
nvolnvOutFreq	0.0Hz	0.0Hz to 400.0Hz	0.1Hz/bit

- Data send event When data changes in 0.1Hz increments
- Data send timing As set in *Pr. 388 Send time interval at heart beat* and *Pr. 389 Minimum sending time at heart beat*. (Refer to page 87)

REMARKS

- This variable is similar to "output frequency monitor (0.005% increments)" (Refer to page 58) but may sometimes differ from it in data send timing since they are different in mutual resolution.
- It is always displayed as frequency (Hz) regardless of the *Pr.37* setting.

6.5.7 Output frequency monitor (0.005% increments) (network output SNVT_lev_percent nvolnvOutFreqP)

You can monitor the output frequency of the inverter in 0.005% increments on the assumption that the frequency set in "% set reference frequency (ncilnvSetFreqBas)" (Refer to page 85) is 100%.

Data Name	Initial Value	Range	Increments
nvolnvOutFreqP	0.000%	0.000% to 163.830%	0.005%/bit

- Data send event When data changes in 0.005% increments
- Data send timing As set in Pr. 388 Send time interval at heart beat and Pr. 389 Minimum sending time at heart beat. (Refer to page 87)

For example, when inverter output frequency = 90.0Hz and % set reference frequency = 60.0Hz,

$$\frac{90.0\text{Hz}}{60.0\text{Hz}} = 1.5 \quad \text{Therefore, the monitoring value is 150.000\%.$$

REMARKS

- Monitoring is disabled at less than the minimum frequency resolution (0.01Hz) of the inverter.
- This variable is similar to "output frequency monitor (0.1Hz increments)" (Refer to page 57) but may sometimes differ from it in data send timing since they are different in mutual resolution.

6.5.8 Output current monitor (0.1A increments) (network output SNVT_amp nvoDrvCurnt)

You can monitor the output current of the inverter in 0.1A increments.

Data Name	Initial Value	Range	Increments
nvoDrvCurnt	0.0A	0.0A to 3276.7A	0.1A/bit

- Data send event When data changes in 0.1A increments
- Data send timing As set in *Pr. 388 Send time interval at heart beat* and *Pr. 389 Minimum sending time at heart beat*. (Refer to page 87)

6.5.9 Output voltage monitor (0.1V increments) (network output SNVT_volt nvoDrvVolt)

You can monitor the output voltage of the inverter in 0.1V increments.

Data Name	Initial Value	Range	Increments
nvoDrvVolt	0.0V	0.0V to 3276.7V	0.1V/bit

- Data send event When data changes in 0.1V increments
- Data send timing As set in *Pr. 388 Send time interval at heart beat* and *Pr. 389 Minimum sending time at heart beat*. (Refer to page 87)

6.5.10 Actual operation time monitor (1h increments) (network output SNVT_time_hour nvoDrvRunHours)

You can monitor the actual operation time (cumulative inverter output time) of the inverter in 1h increments.

Data Name	Initial Value	Range	Increments
nvoDrvRunHours	0h	0 to 65534h	1h/bit

- Data send event When data changes in 1h increments
- Data send timing As set in *Pr. 388 Send time interval at heart beat* and *Pr. 389 Minimum sending time at heart beat*. (Refer to page 87)

6.5.11 Cumulative power monitor (1kWh increments) (network output SNVT_elec_kwh nvoDrvRunPower)

You can monitor the cumulative power of the inverter in 1kWh increments.

You can select monitoring data from either BCD code data or binary data according to *Pr. 170 Watt-hour meter clear*. The initial value is binary data. (For details of *Pr. 170*, refer to *the inverter manual*.)

Data Name	Initial Value	Pr. 170	Range	Increments
nvoDrvRunPower	0kWh	10	0 to 9999kWh (BCD code data)	1kWh/bit
		9999 (initial value)	0 to 65535kWh (binary data)	

REMARKS

- When the numerical value exceeds the maximum value in the monitoring range, the value returns to 0 and is recounted from 0.
- Data send event When data changes in 1kWh increments.
- Data send timing As set in *Pr. 388 Send time interval at heart beat* and *Pr. 389 Minimum sending time at heart beat*. (Refer to page 87)

6.5.12 Cumulative power monitor 2 (0.1kWh increments) (network output *SNVT_elec_kwh_I nvoDrvRunPower_I*)

You can monitor cumulative power of the inverter in 32 bit data and 0.1kWh increments.

Data Name	Initial Value	Range	Increments
NvoDrvRunPower_I	0kWh	0 to 42949672.9kWh	0.1kWh/bit

REMARKS

- If the value exceeds the maximum value of the monitor range, the value returns to 0 and is recounted from 0.
- Data send event At data change in 0.1kWh increments
- Data send timing Depends on the settings of *Pr. 388 Send time interval at heart beat* and *Pr. 389 Minimum sending time at heart beat.* (Refer to page 87)

6.5.13 Alarm reset (network input *SNVT_switch nvilnvAlarmReset*)

You can reset the inverter at inverter alarm occurrence.

Data Name	Initial Value	Range		Operation
		state	value	
nvilnvAlarmReset	H0	H0	Don't care (not used)	Without alarm reset
		H1		Execute an alarm reset.
		H2 to HFF		Invalid

- Data acceptance timing..... When network variables are being received and state = 1 (nv_update_occurs event)
- Setting "1" in *Pr.349* disables the alarm reset command in operations other than network operation.

REMARKS

- You can reset the inverter at inverter alarm occurrence. When the inverter is not during an alarm, performing this operation does not reset the inverter.

6.5.14 Alarm occurrence definition (network output SNVT_str_asc nvolnvAlarmStr)

At inverter alarm occurrence, you can confirm the alarm definition of the inverter with a character string.

- If an inverter alarm occurs at power-on/inverter reset, data is not sent before the *Pr.387 Initial communication delay time* (nciPwUpOutTm) (Refer to page 83).
- The initial setting of +0 to +30 is 0.
- Data send timingAt inverter alarm occurrence

Storage position	Definition (ASCII code)
+0	(Alarm code)H
+1	E (H45)
+2	.(H2E)
+3	Character 1 (Character 1)
+4	Character 2 (Character 2)
+5	Character 3 (Character 3)
+6 to +30	(H00)L

Alarm Code Correspondence Table

Definition	+0	+1	+2	+3	+4	+5	+6 to +30
	Alarm Code	E	.	Character 1	Character 2	Character 3	
OC1	H10	E(H45)	.(H2E)	O(H4F)	C(H43)	1(H31)	
OC2	H11			O(H4F)	C(H43)	2(H32)	
OC3	H12			O(H4F)	C(H43)	3(H33)	
OV1	H20			O(H4F)	V(H56)	1(H31)	
OV2	H21			O(H4F)	V(H56)	2(H32)	
OV3	H22			O(H4F)	V(H56)	3(H33)	
THT	H30			T(H54)	H(H48)	T(H54)	
THM	H31			T(H54)	H(H48)	M(H4D)	
FIN	H40			F(H46)	I(H49)	N(H4E)	
ILF	H52			I(H49)	L(H4C)	F(H46)	
OLT	H60			O(H4F)	L(H4C)	T(H54)	

Definition	+0	+1	+2	+3	+4	+5	+6 to +30
	Alarm Code	E	.	Character 1	Character 2	Character 3	
BE	H70	E(H45)	.(H2E)	B(H42)	E(H45)	Space(H20)	
GF	H80			G(H47)	F(H46)	Space(H20)	
LF	H81			L(H4C)	F(H46)	Space(H20)	
OHT	H90			O(H4F)	H(H48)	T(H54)	
OP1	HA1			O(H4F)	P(H50)	1(H31)	
PE	HB0			P(H50)	E(H45)	Space(H20)	
PUE	HB1			P(H50)	U(H55)	E(H45)	
RET	HB2			R(H52)	E(H45)	T(H54)	
PE2	HB3			P(H50)	E(H45)	2(H32)	
CPU	HC0			C(H43)	P(H50)	U(H55)	
IOH	HC5			I(H49)	O(H4F)	H(H48)	
AIE	HC7			A(H41)	I(H49)	E(H45)	
USB *2	HC8			A(H41)	L(H4C)	Space(H20)	
MB4	HD8			M(H4D)	B(H42)	4(H34)	
MB5	HD9			M(H4D)	B(H42)	5(H35)	
MB6	HDA			M(H4D)	B(H42)	6(H36)	
MB7	HDB			M(H4D)	B(H42)	7(H37)	
E1	HF1			E(H45)	1(H31)	Space(H20)	
E6	HF6			E(H45)	6(H36)	Space(H20)	
E7	HF7			E(H45)	7(H37)	Space(H20)	
E13	HFD	E(H45)	1(H31)	3(H33)			

*1 Value in parenthesis is ASCII code.

*2 Although "E.AL" is sent in ASCII code character string, the alarm definition is "E.USB".

6.5.15 Product information (maker name, type) (network output SNVT_str_asc nvolnvTypeInfo)

When an alarm has occurred in the inverter, you can send the "maker name (MITSUBISHI)" and "type (FR-A7NL)" data as a character string (ASCII).

At power-on/inverter reset, data is not sent before the *Pr.387 Initial communication delay time (nciPwUpOutTm)* (Refer to page 83).

- Data send timing At power-on/inverter reset/inverter alarm occurrence

Storage position	Data (ASCII code)
+0	M H
+1	I
+2	T
+3	S
+4	U
+5	B
+6	I
+7	S
+8	H
+9	I
+10	(20H)
+11	F
+12	R
+13	-
+14	A
+15	7
+16	N
+17	L
+18 to +30	(00H) L

6.5.16 Emergency stop command (network input SNVT_hvac_emerg nviEmergOverride)

You can give an emergency stop command during inverter operation.

If "EMERG_SHUTDOWN" is requested during inverter operation, the inverter decelerates to a stop independently of the operation mode.

Data Name	Initial Value	Range	Description
nviEmergOverride	H0	H0	EMERG_NORMAL Emergency stop cancel
		H4	EMERG_SHUTDOWN Emergency stop
		HFF	EMERG_NUL Invalid (no operation)

· Data acceptance timing At network variable receive (nv_update_occurs event)

(1) Emergency Stop	(2) Emergency Stop Cancel
<ul style="list-style-type: none"> · The deceleration time depends on the Pr. 8, Pr. 44 and other settings. · When the inverter starts decelerating under the emergency stop command, " P5 " appears in the display section of the operation panel and the inverter is put in an emergency stop status. · An emergency stop status cannot be canceled unless emergency stop cancel operation is performed. · During occurrence of a communication line error, an emergency stop command is not accepted. · During an inverter stop, an emergency stop command is invalid. 	<ul style="list-style-type: none"> · During an inverter stop, turn OFF all start commands (forward rotation command, reverse rotation command) and request "EMERG_NORMAL". When the inverter recognizes this status, it cancels the emergency stop and also " P5 " shown in the display section disappears. · During deceleration made under an emergency stop command, performing emergency stop cancel operation will not cancel an emergency stop immediately. Perform emergency stop cancel operation during an inverter stop.


6.5.17 Emergency stop status (network output SNVT_hvac_emerg nvoEmergStatus)

You can indicate the emergency stop status of the inverter.

Data Name	Initial Value	Range	Description
nvoEmergStatus	H0	H0	EMERG_NORMAL During normal or emergency stop cancel
		H4	EMERG_SHUTDOWN During emergency stop

- Data send event When the value data changes at emergency stop command receive
- Data send timing As set in Pr. 388 Send time interval at heart beat and Pr. 389 Minimum sending time at heart beat. (Refer to page 87)

Emergency Stop Operation Timing Chart



6.5.18 Alarm status (network output SNVT_switch nvoDrvAlarm)


You can indicate the alarm status of the inverter.

Data Name	Range		Operation
	state	value	
nvoDrvAlarm	H0 (initial value)	Don't care (not used)	Inverter normal
	H1	(initial value: 0)	During inverter alarm

- Data send timing As set in Pr. 388 Send time interval at heart beat and Pr. 389 Minimum sending time at heart beat. (Refer to page 87)

6.6 Inverter PID Control Functions

System configuration example



6.6.1 PID set point (network input SNVT_lev_percent nvInvPIDTarget)

Enter the target value of air volume, temperature, etc. in 0.005% increments.

Data Name	Initial Value	Range	Increments
nvInvPIDTarget	0.000%	0.00% to 100.00%	0.005%/bit

· Data acceptance timingAt network variable receive (nv_update_occurs event)

For example, when setting 30°C as the set point using a 10°C/0% and 50°C/100% detector,

$$\frac{(30 - 10)}{(50 - 10)} \times 100 = 50\%. \quad \text{As the PID set point, input 50.00\%.$$

REMARKS

- Control can not be exercised at less than the minimum resolution (0.01%) of the inverter.
- When the value outside of the range is input, the input value is made invalid and the inverter operates with the value set last time.

6.6.2 PID measured value (network input SNVT_lev_percent nvilnvPIDValue)

Enter the measured value of air volume, temperature, etc. in 0.005% increments.

Data Name	Initial Value	Range	Increments
nvilnvPIDValue	0.000%	0.00% to 100.00%	0.005%/bit

· Data acceptance timingAt network variable receive (nv_update_occurs event)

For example, when the measured value is 25°C on a 10°C/0% and 50°C/100% detector,

$$\frac{(25 - 10)}{(50 - 10)} \times 100 = 37.5\%. \quad \text{As the PID measured value, input 37.50\%.$$

REMARKS

- Control cannot be exercised at less than the minimum resolution (0.01%) of the inverter.
- When the value outside of the range is input, the input value is made invalid and the inverter operates with the value set last time.

6.6.3 PID deviation (network input SNVT_lev_percent nvInvPIDDev)

Input the set value of air volume, temperature, etc. in 0.005% increments.

Data Name	Initial Value	Range	Increments
nvInvPIDDev	0.000%	-100.00% to +100.00%	0.005%/bit

· Data acceptance timingAt network variable receive (nv_update_occurs event)

For example, when the set point is 25°C and the current temperature is 30°C on a 10°C/0% and 50°C/100% detector (deviation: +5°C),

$$\frac{(30 - 25)}{(50 - 10)} \times 100 = 12.5\%. \quad \text{As the PID deviation, input 12.50\%.$$

REMARKS

- Control cannot be exercised at less than the minimum resolution (0.01%) of the inverter.
- When the value outside of the range is input, the input value is made invalid and the inverter operates with the value set last time.

6.7 Inverter Extended Functions

6.7.1 Monitor code (network input SNVT_count nvInvMonCode)

Set the monitor data you want to monitor.

The monitor value enters "monitor data (nvInvMonData)" (Refer to page 75).

Data Name	Initial Value	Range	Increments
nvInvMonCode	H0	H0 to H0036	—

· Data acceptance timing At network variable receive (nv_update_occurs event)

<Monitor Code Table>

When a monitor code other than the below is set, monitor data (nvInvMonData) becomes arbitrary value.

Code Number	Description	Increments	100% Value of Event Driven Detection Width (Refer to page 102)
H0000	No monitoring *1	—	—
H0001	Output frequency	0.01Hz	Pr. 55 Frequency monitoring reference setting
H0002	Output current	0.01A	Pr. 56 Current monitoring reference setting
H0003	Output voltage	0.1V	200V class: 400V, 400V class: 800V
H0004	No monitoring *1	—	—
H0005	Frequency setting	0.01Hz	Pr. 55 Frequency monitoring reference setting
H0006	No monitoring *1	—	—
H0007	Motor torque	0.1%	Rated torque of the applied motor × 2
H0008	Converter output voltage	0.1V	200V class: 400V, 400V class: 800V
H0009	Regenerative brake duty	0.1%	Pr.70 Special regenerative brake duty setting
H000A	Electronic thermal relay function load factor	0.1%	100%

Code Number	Description	Increments	100% Value of Event Driven Detection Width (Refer to page 102)
H000B	Output current peak value	0.01A	<i>Pr. 56 Current monitoring reference</i>
H000C	Converter output voltage peak value	0.1V	200V class: 400V, 400V class: 800V
H000D	No monitoring *1	—	—
H000E	Output power	0.01kW	Rated inverter power × 2
H000F	Input terminal status *2	—	—
H0010	Output terminal status *3	—	—
H0011 to H0013	No monitoring *1	—	—
H0014	Cumulative energization time	1h	—
H0015	No monitoring *1	—	—
H0016			
H0017	Actual operation time	1h	—
H0018	Motor load factor	0.1%	200% (rated inverter current × 2)
H0019	Cumulative power	1kWh	—
H0020 to H0033	No monitoring *1	—	—
H0034	PID set point	0.1%	100%
H0035	PID measured value	0.1%	100%
H0036	PID deviation	0.1%	100%

*1 The value of the first monitor is "0", and the value is the value previously monitored when switched from other monitor.

*2 Input terminal monitor details

b15

b0

—	—	—	—	—	RES	—	MRS	—	RH	RM	RL	—	—	STR	STF
---	---	---	---	---	-----	---	-----	---	----	----	----	---	---	-----	-----

Functions of each terminal are assigned using Pr.178 to Pr.184.

(Refer to *the inverter manual* for details of Pr. 178 to Pr.184.)

*3 Output terminal monitor details

b15

b0

—	—	—	—	—	—	—	—	—	—	ABC	FU	—	—	—	RUN
---	---	---	---	---	---	---	---	---	---	-----	----	---	---	---	-----

Functions of each terminal are assigned using Pr.190 to Pr.192.

(Refer to *the inverter manual* for details of Pr. 190 to Pr.192.)

6.7.2 Monitor data (network output SNVT_count nvInvMonData)

You can monitor the monitor description set in "monitor code (nvInvMonCode)" (Refer to page 72).

Data Name	Initial Value	Range	Increments
nvInvMonData	0	0 to 65535	Refer to the monitor code table. (Refer to page 72)

- Data send event When the monitor value data changes
- Data send timing As set in Pr. 388 Send time interval at heart beat and Pr. 389 Minimum sending time at heart beat. (Refer to page 87)

For example, if the monitor value is 60.00Hz, "6000" is displayed.

6.7.3 Set frequency (0.01Hz increments) (network input SNVT_count nvInvSetFreq2)

You can set the set frequency in 0.01Hz increments.

Data Name	Initial Value	Range	Increments
nvInvSetFreq2	0.00Hz	0.00Hz to 400.00Hz	0.01Hz/bit

- Data acceptance timing At network variable receive (nv_update_occurs event)

For example, if you want to set 120.00Hz, set "12000", the value 100 times greater than the desired frequency.

REMARKS

- Always set frequency (Hz) regardless of the *Pr.37* setting.

6.7.4 Output frequency monitor (0.01Hz increments) (network output SNVT_count nvInvOutFreq2)

You can monitor the output frequency of the inverter in 0.01Hz increments.

Data Name	Initial Value	Range	Increments
nvInvOutFreq2	0.00Hz	0.00Hz to 400.00Hz	0.01Hz/bit

- Data send event When the data changes in 0.01Hz increments
- Data send timing As set in *Pr. 388 Send time interval at heart beat* and *Pr. 389 Minimum sending time at heart beat*. (Refer to page 87)

For example, if the monitor value is 120.00Hz, "12000", the value 100 times greater, is displayed.

REMARKS

- It is always displayed as frequency (Hz) regardless of the *Pr.37* setting.


6.7.5 Command request (network input SNVT_str_asc nvInvCmdReq)

Instruction code and write data, such as operation mode rewrite, parameter reading, writing, alarm history reference, parameter clear, etc., which can not be operated with network variables can be set.

The format is as shown below. The data to be set are in ASCII code. The initial setting of +0 to +30 is 0.


Request flag	H01	Command request is made
	Other than H01	Command request is not made
Request code	Refer to the command list on the next page to set the instruction code.	
Request data	Set the data at writing. (Set H0000 at reading.)	

- Data acceptance timing.....At network variable receive (nv_update_occurs event) and when request flag = 1




Setting example

1. When writing "Pr: 7
Acceleration time = 10.0s"



2. When resetting the inverter



● Command List

Item	Read/Write	Instruction Code	Data Description							
Operation mode	Read	H007B	H0000: Network operation H0001: External operation H0002: PU operation							
	Write	H00FB	H0000: Network operation H0001: External operation H0002: PU operation (When Pr. 79 = "6")							
Alarm definition	Read	H0074 to H0077	H0000 to HFFFF: Last two alarm definitions							
			H0074	<table border="1"> <tr> <td style="text-align: center;">b15</td> <td style="text-align: center;">b8 b7</td> <td style="text-align: center;">b0</td> </tr> <tr> <td>Second alarm in past</td> <td>Latest alarm</td> <td></td> </tr> </table>	b15	b8 b7	b0	Second alarm in past	Latest alarm	
			b15	b8 b7	b0					
			Second alarm in past	Latest alarm						
			H0075	<table border="1"> <tr> <td>Fourth alarm in past</td> <td>Third alarm in past</td> </tr> </table>	Fourth alarm in past	Third alarm in past				
Fourth alarm in past	Third alarm in past									
H0076	<table border="1"> <tr> <td>Sixth alarm in past</td> <td>Fifth alarm in past</td> </tr> </table>	Sixth alarm in past	Fifth alarm in past							
Sixth alarm in past	Fifth alarm in past									
H0077	<table border="1"> <tr> <td>Eighth alarm in past</td> <td>Seventh alarm in past</td> </tr> </table>	Eighth alarm in past	Seventh alarm in past							
Eighth alarm in past	Seventh alarm in past									
			Refer to the alarm code correspondence table (page 62).							
Set frequency (RAM)	Read	H006D	Read set frequency from RAM or EEPROM. · H0000 to HFFFF: Set frequency.....Increments 0.01Hz (It is always displayed as frequency (Hz) regardless of the Pr.37 setting.)							
Set frequency (EEPROM)		H006E								

Item	Read/Write	Instruction Code	Data Description
Set frequency (RAM)	Write	H00ED	Write set frequency to RAM or EEPROM. · H0000 to H9C40 (0 to 400.00Hz): Frequency Increments 0.01Hz
Set frequency write (RAM and EEPROM)	Write	H00EE	(Always set frequency (Hz) regardless of the <i>Pr.37</i> setting.) · To change the set frequency consecutively, write data to the inverter RAM. (Code number: H00ED)
Parameter	Read	H0000 to H0063	· Refer to the instruction code in the parameter list in <i>the inverter manual</i> to read and write as required. Write to <i>Pr. 77</i> and <i>Pr. 79</i> is disabled. When setting <i>Pr.100</i> and later, link parameter expansion setting must be set.
	Write	H0080 to H00E3	· Set 65520 (HFFF0) as a parameter value "8888" and 65535 (HFFFF) as "9999". · When changing the parameter values frequently, set "1" in <i>Pr. 342</i> to write them to the RAM. (<i>Refer to page 28</i>)
Alarm definition all clear	Write	H00F4	H9696: Batch-clears the alarm description

Item	Read/Write	Instruction Code	Data Description				
All parameter clear	Write	H00FC	All parameters return to the initial values. Any of four different all clear operations are performed according to the data. All clear types (O...Clear, x...not clear)				
			Data	Communication Parameters	Calibration Parameters	Other Parameters	HEC, HF3, HFF
			H9696	○ *1	×	○	○
			H9966	○ *1	○	○	○
			H5A5A	×	×	○	○
			H55AA	×	○	○	○
Inverter reset	Write	H00FD	H9696: Reset the inverter.				
Link parameter expansion setting	Read	H007F	Parameter description is changed according to the H00 to H09 setting. Refer to the instruction code of <i>the inverter manual</i> for details of the values.				
	Write	H00FF					
Second parameter changing *2	Read	H006C	When setting the bias / gain (C2 to C7, C22 to C25 *3) parameters H00: Frequency *4				
	Write	H00EC	H01: Analog value set in parameters H02: Analog value input from the terminal				


*1 Communication parameters (*Pr. 117 to Pr. 124, Pr. 338 to Pr.340, Pr.343, Pr.349, Pr.549 to Pr.551*) are also cleared.

*2 Setting can be made when the link parameter expansion setting = "1, 9".

*3 C22 to C25 are available with the Japanese version only. Refer to the parameter list of the inverter for instruction code.

*4 Gain frequencies can be written using *Pr. 125* (instruction code H99) and *Pr. 126* (instruction code H9A) also.

Command processing is performed in the following procedure.



6.7.6 Command reply (network output SNVT_str_asc nvolnvCmdReply)

Gives a reply to the command requested in "command request (nvilnvCmdReq)" (Refer to page 77). The data entered are the reply code and read data as the command processing results.

The format is as shown below. The data to be set are in ASCII code. The initial setting of +0 to +30 is 0.

Reply flag	H01	Reply to command request
Reply code (Results in response to the command request enter)	H0000	Normal completion of command
	Other than H0000	Command execution error
		H0001: Mode error (different operation mode)
		H0002: Instruction code error (specified instruction code does not exist)
H0003: Data range error (data written is outside the range)		
Reply data	The data is set at reading. (A given value is set at writing.)	

· Data send event At command processing completion

Storage position	Data (ASCII code)	
+0	Request flag	H
		L
+2	Reply code	H
		L
+6	Reply data	H
		L
+10 to +30	0	

Setting example

1. When Pr. 8 Deceleration time with "5.0s" set in is read

2. When the latest alarm (OP1) and second alarm in past (OC1) are read

Storage position	Data (ASCII code)	
+0	0 (H30)	H
	1 (H31)	L
+2	0 (H30)	H
	0 (H30)	
	0 (H30)	L
+6	0 (H30)	H
	0 (H30)	
	3 (H33)	L
	2 (H32)	
+10 to +30	0	

Storage position	Data (ASCII code)	
+0	0 (H30)	H
	1 (H31)	L
+2	0 (H30)	H
	0 (H30)	
	0 (H30)	L
+6	0 (H30)	H
	1 (H31)	
	0 (H30)	L
	A (H41)	
	1 (H31)	L
+10 to +30	0	

Refer to page 81 for the command processing procedure.

6.8 Configuration Properties

6.8.1 Initial communication delay time (network input config SNVT_time_sec nciPwUpOutTm)

You can set the time from when the inverter starts until when data is sent to LONWORKS at power-on or inverter reset.

REMARKS

- The parameter setting is made valid at power-on or inverter reset.
- The delay time at power-on and inverter reset is set and this setting does not affect normal data transmission.

Data Name		Initial Value	Range	Increments
nciPwUpOutTm		0s	0.0s to 120.0s	0.1s/bit
Parameter	Name			
387	Initial communication delay time			

- Data acceptance timing At network variable receive (nv_update_occurs event)

6.8.2 Forward/reverse rotation prevention (network input config SNVT_count nciInvFwdRevLock)

You can limit the rotation direction of the inverter. (Used to disable rotation in the wrong direction in a system where an air conditioning fan, etc. is fixed in rotation direction.)

Data Name	Initial Value	Range		Operation	Setting Value Storage Location
		state	value		
nciInvFwdRevLock	Initial value of Pr. 78	H0	Not used	Both forward rotation and reverse rotation enabled	Pr.78
		H1		Reverse rotation disabled	
		H2		Forward rotation disabled	

· Data acceptance timingAt network variable receive (nv_update_occurs event)


REMARKS

- Refer to *the inverter manual* for details of Pr. 78.

6.8.3 % set reference frequency (network input config SNVT_freq_hz nciInvSetFreqBas)

You can set the reference frequency of "set frequency (nvilnvSetFreqP)" (Refer to page 56) and "output frequency monitor (nvlnvOutFreqP)" (Refer to page 58).

The % set reference frequency can not be set at less than the minimum frequency resolution of the inverter.



Data Name		Initial Value	Range	Increments
nciInvSetFreqBas		60Hz / 50Hz *	1.0Hz to 400.0Hz	0.1Hz/bit
Parameter	Name		1.00Hz to 400.00Hz	0.01Hz
390	% setting reference frequency			

* 60Hz for the Japanese and NA version and 50Hz for the EC and CH version.

- Data acceptance timing At network variable receive (nv_update_occurs event)

6.8.4 Maximum frequency (0.1Hz increments) (network input config SNVT_freq_hz ncilnvMaxFreq)

You can set the maximum frequency to be output by the motor to the inverter in 0.1Hz increments.

Data Name	Initial Value	Range	Increments	Setting Value Storage Location
ncilnvMaxFreq	Initial value of Pr. 1	0.0Hz to 400.0Hz	0.1Hz/bit	Pr.1/Pr.18

• Data acceptance timing At network variable receive (nv_update_occurs event))

REMARKS

- Refer to *the inverter manual* for details of Pr. 1, Pr.18.

6.8.5 Minimum frequency (0.1Hz increments) (network input config SNVT_freq_hz ncilnvMinFreq)

You can set the minimum frequency to be output by the motor to the inverter in 0.1Hz increments.

Data Name	Initial Value	Range	Increments	Setting Value Storage Location
ncilnvMinFreq	Initial value of Pr.2	0.0Hz to 120.0Hz	0.1Hz/bit	Pr.2

• Data acceptance timing At network variable receive (nv_update_occurs event)

REMARKS

- Refer to *the inverter manual* for details of Pr. 2.

6.8.6 Heartbeat send time interval (network input config SNVT_time_sec nciSndHrtBt)

You can set the time interval at which data is sent to network in output network variable send.

Data Name		Initial Value	Range	Increments
nciSndHrtBt		0s	0.0s to 999.8s	0.1s/bit
Parameter	Name			
388	Send time interval at heart beat			

- Data acceptance timing At network variable receive (nv_update_occurs event)

6.8.7 Minimum heartbeat send time (network input config SNVT_time_sec nciMinOutTm)

You can set the minimum time at which data is sent to network in output network variable send.

Data Name		Initial Value	Range	Increments
nciMinOutTm		0.5s	0.0s to 999.8s	0.1s/bit
Parameter	Name			
389	Minimum sending time at heart beat			

- Data acceptance timing At network variable receive (nv_update_occurs event)

●Heartbeat send time (*Pr.388, Pr.389*)

<i>Pr. 388</i> Setting	<i>Pr. 389</i> Setting	Operation
0	0	Sends data when data send event occurs. * Network variables outputting data frequently (frequent changes) causes network congestion. In such cases, adjust by setting <i>Pr. 392 Event driven detection width</i> , <i>Pr. 388</i> and <i>Pr. 389</i> .
Other than 0	0	Checks presence or absence of data send event and sends data when an event occurs. Sends data after the heartbeat send time interval (<i>Pr. 388</i> setting) has elapsed if there is no event.
0	Other than 0	Checks for presence or absence of data send event at interval of minimum heartbeat send time (<i>Pr. 389</i> setting). Sends data if an event presents.
<i>Pr. 388 > Pr. 389</i> (Other than 0)		Checks for presence or absence of data send event at an interval of minimum heartbeat send time (<i>Pr. 389</i> setting). Sends data if an event presents. Sends data after the heartbeat send time interval (<i>Pr. 388</i> setting) has elapsed if there is no event.
<i>Pr. 388 ≤ Pr. 389</i> (Other than 0)		Sends data at an interval of minimum heartbeat send time (<i>Pr. 389</i> setting) independently of presence and absence of data send event.

REMARKS


- At power-on and inverter reset, data is not sent before the *Pr. 387 Initial communication delay time (nciPwUpOutTm)*.
(Refer to page 83)

The network variables subject to the heartbeat send time

Function (Increments)	Network Variables		In/Out	Refer to Page
	Variable	Name		
Speed monitor (0.005%/bit)	SNVT_lev_percent	nvoDrvSpeed	Out	50
Inverter output signal	SNVT_state	nvoInvOutputSig	Out	53
Output frequency monitor (0.1Hz/bit)	SNVT_freq_hz	nvoInvOutFreq	Out	57
Output frequency monitor (0.005%/bit)	SNVT_lev_percent	nvoInvOutFreqP	Out	58
Output current monitor (0.1A/bit)	SNVT_amp	nvoDrvCurnt	Out	59
Output voltage monitor (0.1V/bit)	SNVT_volt	nvoDrvVolt	Out	59
Actual operation time monitor (1h/bit)	SNVT_time_hour	nvoDrvRunHours	Out	59
Cumulative power monitor (1kWh/bit)	SNVT_elec_kwh	nvoDrvRunPower	Out	60
Cumulative power monitor 2 (0.1kWh/bit)	SNVT_elec_kwh_l	nvoDrvRunPower_l	Out	61
Emergency stop status	SNVT_hvac_emerg	nvoEmergStatus	Out	66
Alarm status	SNVT_switch	nvoDrvAlarm	Out	67
Monitor data	SNVT_count	nvoInvMonData	Out	75
Output frequency monitor (0.01Hz/bit)	SNVT_count	nvoInvOutFreq2	Out	76

REMARKS

- The send time interval of one network variable is time set in *Pr. 388 (Pr. 389)* independently of the number of monitors bound by network management packages such as LonMaker.
 For example, when the speed monitor and output current monitor are bound, the send time interval of the speed monitor is *Pr. 388 (Pr. 389)*s and the send time interval of the output current monitor is also *Pr. 388 (Pr. 389)*s.
 In addition, the actual send time interval is 1.1s due to constraints of each data send time even when *Pr. 388 Send time interval at heart beat* is set to 1.0s or less. (It takes 1.2s when monitor data is set.)



6.8.8 Acceleration time (network input config SNVT_time_sec nciRampUpTm)

You can set the acceleration time taken for the motor to reach the set frequency (1 to 400Hz) of Pr. 20 Acceleration/deceleration reference frequency from 0Hz.

Data Name	Initial Value	Pr.21 Setting	Range *	Increments	Setting Value Storage Location
		nciRampUpTm	Initial value of Pr. 7	0 (Initial value)	0.0s to 3600.0s
		1	0.00s to 360.00s	0.01s/bit	

* The setting range changes according to the Pr. 21 Acceleration/deceleration time increments setting. The value 0.1 times greater than the setting value is written to the inverter when Pr. 21 = 1. When the Pr. 21 setting has been changed, set the acceleration time again. (Example)

When Pr. 21 = "0", setting "5.0s" for acceleration time and "1" in Pr. 21 automatically changes the acceleration time setting to "0.5s".

- Data acceptance timing At network variable receive (nv_update_occurs event)

REMARKS

- Refer to *the inverter manual* for details of Pr. 7, Pr. 20, Pr. 21.

6.8.9 Deceleration time (network input config SNVT_time_sec nciRampDownTm)

You can set the deceleration time taken for the motor to reach 0Hz from the set frequency (1 to 400Hz) of Pr. 20 Acceleration/deceleration reference frequency.

Data Name	Initial Value	Pr.21 Setting	Range *	Increments	Setting Value Storage Location
		nciRampDownTm	Initial value of Pr. 8	0 (Initial value)	
		1	0.00s to 360.00s	0.01s/bit	

- * The setting range changes according to the Pr. 21 Acceleration/deceleration time increments setting. The value 0.1 times greater than the setting value is written to the inverter when Pr. 21 = 1. When the Pr. 21 setting has been changed, set the deceleration time again. (Example)
 When Pr. 21 = "0", setting "5.0s" for deceleration time and "1" in Pr. 21 automatically changes the deceleration time setting to "0.5s".
- Data acceptance timing At network variable receive (nv_update_occurs event)

REMARKS

- Refer to *the inverter manual* for details of Pr. 8, Pr. 20, Pr. 21.

6.8.10 PID action selection (network input config SNVT_count nciInvPIDSwitch)

You can set whether the PID control of the inverter will be exercised or not.

Data Name	Initial Value	Range	Increments	Setting Value Storage Location
nciInvPIDSwitch	Initial value of Pr. 128	0, 20, 21, 40 to 43, 50, 51, 60, 61	—	Pr. 128

nciInvPIDSwitch Setting		Action		Set Point Input	Deviation Value/ Measured Value Input		
state	value						
0	Don't care (not used)	PID action is not performed		—	—		
20		PID reverse action		Set point signal input (terminal 2)	Measured value signal input (terminal 4)		
21		PID forward action					
40 *1		PID reverse action	Addition method: fixed	For dancer control set point (Pr. 133)	For dancer control measured value (terminal 4)		
41 *1		PID forward action					
42 *1		PID reverse action	Addition method: ratio				
43 *1		PID forward action					
50 *2		PID reverse action				Set point communication input (Network)	Deviation value communication input (Network)
51 *2		PID forward action					Measured value communication input (Network)
60 *2		PID reverse action					
61 *2		PID forward action					

- *1 The main speed command is the speed command of each operation mode (external, PU, communication).
- *2 Precautions for 50, 51, 60, 61 settings
 - PID control is made valid independently of ON/OFF of the X14 terminal.
 - Input the set point and setting value (deviation input) in % increments. At this time, the set frequency of C2 (*Pr. 902 Terminal 2 frequency setting bias frequency*) is equivalent to 0 % and the set frequency of Pr. 125 (*Pr. 903 Terminal 2 frequency setting gain frequency*) is equivalent to 100%.
 - The settings of Pr. 338 *Communication operation command source* and Pr. 339 *Communication speed command source* are made valid. (*Refer to page 25*)
 - When Pr. 79 = "6" (switchover mode), both PID function and switchover mode are made invalid.
- Data acceptance timing....At network variable receive when the inverter is at a stop (nv_update_occurs event)

REMARKS

- Refer to *the inverter manual* for use of PID control function.

6.8.11 PID proportional band (network input config SNVT_count nciInvPIDPro)

You can set the proportional band of the PID control of the inverter.

To disable integral control, set "0.0%" or "6553.5".

Data Name	Initial Value	Range	Increments	Setting Value Storage Location
nciInvPIDPro	Initial value of Pr: 129	0.0% to 1000.0%, 6553.5	0.1%/bit	Pr:129

· Data acceptance timing.... At network variable receive when the inverter is at a stop (nv_update_occurs event)

Set the value 10 times greater than the desired value in nciInvPIDPro.

For example, if you want to set 50.0%, set "500", the value 10 times greater than 50.0.

REMARKS

- Refer to *the inverter manual* for use of PID control function.

6.8.12 PID integral time (network input config SNVT_time_sec nciInvPIDIntTm)

You can set the integral time of the PID control of the inverter.

To disable integral control, set "0.0s" or "6553.5".

Data Name	Initial Value	Range	Increments	Setting Value Storage Location
nciInvPIDIntTm	Initial value of Pr: 130	0.0s to 3600.0s, 6553.5	0.1s/bit	Pr:130

· Data acceptance timing.... At network variable receive when the inverter is at a stop (nv_update_occurs event)

REMARKS

- Refer to *the inverter manual* for use of PID control function.

6.8.13 PID differential time (network input config SNVT_time_sec nciInvPIDDiffTm)

You can set the differential time of the PID control of the inverter.

To disable differential control, set "0.0s" or "6553.5".

Data Name	Initial Value	Range	Increments	Setting Value Storage Location
nciInvPIDDiffTm	Initial value of Pr: 134	0.0s to 10.0s, 6553.5	0.1s/bit	Pr: 134

· Data acceptance timing.....At network variable receive when the inverter is at a stop (nv_update_occurs event)

REMARKS

- Refer to *the inverter manual* for use of PID control.

6.8.14 PID manipulated variable bias (0.1Hz increments) (network input config SNVT_freq_hz nciInvPIDOpeBias)

You can set the manipulated variable of the inverter in 0.1Hz increments when the deviation (difference between set point and measured value) under PID control is 0%.

Data Name	Initial Value	Range	Increments	Setting Value Storage Location
nciInvPIDOpeBias	Initial value of C2 (Pr: 902)	0.0Hz to 400.0Hz	0.1Hz/bit	C2 (Pr: 902)

· Data acceptance timing..... At network variable receive (nv_update_occurs event)

REMARKS

- Refer to *the inverter manual* for use of PID control and details of C2 (Pr: 902).

6.8.15 PID manipulated variable gain (0.1Hz increments) (network input config SNVT_freq_hz nciInvPIDOpeGain)

You can set the manipulated variable of the inverter in 0.1Hz increments when the deviation (difference between set point and process variable) under PID control is 100%.

Data Name	Initial Value	Range	Increments	Setting Value Storage Location
nciInvPIDOpeGain	Initial value of Pr. 125 (Pr. 903)	0.0Hz to 400.0Hz	0.1Hz/bit	Pr.125(Pr.903)

- Data acceptance timing..... At network variable receive (nv_update_occurs event)

REMARKS

- Refer to *the inverter manual* for use of PID control and details of Pr. 125 (Pr.903).

6.8.16 Heartbeat receive time interval (network input config *SNVT_time_sec nciRcvHrtBt*)


You can set the time interval at which input network variables data is received from the network. When the receive interval time from the network has risen above the setting, it is considered as a communication line error, then "communication alarm (E.OP1)" is displayed and the inverter stops.

Data Name		Initial Value	Range	Increments
nciRcvHrtBt		0s	0.0s to 999.8s	0.1s/bit
Parameter	Name			
391	Receive time interval at heart beat			

- Data acceptance timing....At network variable receive (nv_update_occurs event)

REMARKS

- For the data send to other nodes, the counters of heartbeat receive time interval are not cleared.



● Network variables supported

The following network variables are subject to the receive interval time.

Function	Network Variables		In/Out	Refer to Page
	Variable	Name		
Start and stop/simple speed setting	SNVT_switch	nviDrvSpeedStpt	In	48
Speed adjustment	SNVT_lev_percent	nviDrvSpeedScale	In	49
Inverter input signal	SNVT_state	nviInvInputSig	In	51
Set frequency (0.1Hz/bit)	SNVT_freq_hz	nviInvSetFreq	In	56
Set frequency (0.005%/bit)	SNVT_lev_percent	nviInvSetFreqP	In	56
PID set point (0.005%/bit)	SNVT_lev_percent	nviInvPIDTarget	In	69
PID measured value (0.005%/bit)	SNVT_lev_percent	nviInvPIDValue	In	70
PID deviation (0.005%/bit)	SNVT_lev_percent	nviInvPIDDev	In	71
Set frequency (0.01Hz/bit)	SNVT_count	nviInvSetFreq2	In	76

REMARKS

- The communication line error detection is invalid when *Pr. 502 Stop mode selection at communication error* = "3".

6.8.17 Maximum speed (0.005% increments) (network input config SNVT_lev_percent nciMaxSpeed)

You can set the maximum speed to be output by the inverter to the motor.

Set the speed in 0.005% increments using the setting value of "reference speed setting (nciNmlSpeed)" (Refer to page 100) or "reference frequency setting (nciNmlFreq)" (Refer to page 101) as reference.

Data Name	Initial Value	Range	Increments	Setting Value Storage Location
nciMaxSpeed	Initial value of Pr. 1	0.000% to 163.830%	0.005%/bit	Pr. 1/Pr. 18

· Data acceptance timing At network variable receive (nv_update_occurs event)

REMARKS

- Refer to *the inverter manual* for details of Pr. 1 or Pr. 18.
- The setting value exceeding 163.830% is made invalid.
- Control can not be exercised at less than the minimum frequency resolution (0.01Hz) of the inverter.

6.8.18 Minimum speed (0.005% increments) (network input config SNVT_lev_percent nciMinSpeed)

You can set the minimum speed to be output by the inverter to the motor.

Set the speed in 0.005% increments using the setting value of "reference speed setting (nciNmlSpeed)" (Refer to page 100) or "reference frequency setting (nciNmlFreq)" (Refer to page 101) as reference.

Data Name	Initial Value	Range	Increments	Setting Value Storage Location
nciMinSpeed	Initial value of Pr. 2	0.000% to 163.830%	0.005%/bit	Pr. 2

· Data acceptance timing At network variable receive (nv_update_occurs event)

REMARKS

- Refer to *the inverter manual* for details of Pr. 2.
- The setting value exceeding 163.830% is made invalid.
- Control can not be exercised at less than the minimum frequency resolution (0.01Hz) of the inverter.

6.8.19 Reference speed setting (network input config SNVT_rpm nciNmISpeed)

Set the speed used as the reference of "speed adjustment (nviDrvSpeedScale)" (Refer to page 49), "speed monitor (nvoDrvSpeed)" (Refer to page 50), "maximum speed (nciMaxSpeed)" (Refer to page 99) and "minimum speed (nciMinSpeed)" (Refer to page 99).

Data Name	Initial Value	Range	Increments	Setting Value Storage Location
nciNmISpeed	1800r/min / 1500r/min *	30r/min to 12000r/min	1r/min/bit	Pr. 390

* 1800r/min for the Japanese and NA version and 1500r/min for the EC and CH version.

- Data acceptance timing At network variable receive (nv_update_occurs event)

The setting of reference speed setting (nciNmISpeed) is changed from speed increments to frequency increments, then written to Pr. 390.

<p>Frequency = $\frac{\text{Number of motor poles (4*)} \times \text{speed}}{120}$ (the calculation result is rounded down.)</p> <p>* The number of motor poles is always four.</p>
--

REMARKS

- Refer to page 85 for details of Pr. 390.

6.8.20 Reference frequency setting (network input config SNVT_freq_hz nciNmlFreq)

Set the frequency used as the reference of "speed adjustment (nviDrvSpeedScale)" (Refer to page 49), "speed monitor (nvoDrvSpeed)" (Refer to page 50), "maximum speed (nciMaxSpeed)" (Refer to page 99) and "minimum speed (nciMinSpeed)" (Refer to page 99).

Data Name	Initial Value	Range	Increments	Setting Value Storage Location
nciNmlFreq	60Hz / 50Hz *	1.0Hz to 400.0Hz	0.1Hz/bit	Pr. 390

* 60Hz for the Japanese and NA version and 50Hz for the EC and CH version.

- Data acceptance timing At network variable receive (nv_update_occurs event)

REMARKS

- Refer to page 85 for details of Pr. 390.
- To make the change of "reference frequency setting (nciNmlFreq)" be reflected to the operation speed, a value is need to be written to "speed adjustment (nviDrvSpeedScale)".

6.8.21 Speed adjustment default value (network input config SNVT_lev_percent nciDrvSpeedScale)

You can set the default value of "speed adjustment (nviDrvSpeedScale)" (Refer to page 49).

Data Name	Initial Value	Range	Increments	Setting Value Storage Location
nciDrvSpeedScale	100.00%	-163.840% to 163.830%	0.005%/bit	—

- Data acceptance timing At network variable receive (nv_update_occurs event)

REMARKS

- Write and read the setting value from the network. You can not read and write from the inverter.
- The value stored in the inverter is rounded up. For example, 1.005% is rounded up to 1.010%.

6.8.22 Event driven detection width (network input config SNVT_lev_percent nciInvEvtDuty)

You can set the event driven detection width (varying width) of the monitor-related output network variables.

A 100% value that will be the basis of the detection width varies with the network variables.

This setting can reduce traffic jams caused by occurrence of many send events due to consecutive value changes.

Data Name		Initial Value	Range	Increments
nciInvEvtDuty		0%	0.000% to 163.830%	0.005%/bit
Parameter	Name		0.00 to 163.83%	0.01%
392	Event driven detection width			

· Data acceptance timingAt network variable receive (nv_update_occurs event)

REMARKS

- Control can not be exercised at less than the minimum frequency resolution (0.01Hz) of the inverter.
- The value stored in the inverter is rounded up. For example, 1.005% is rounded up to 1.010%.
- When the inverter operation status has changed, e.g. from a stop to startup or from running to a stop, the monitor value is output even when the value is within the event driven detection width.

**(Example) when the output frequency monitor and Pr. 392 Event driven detection width = "100%",
Pr. 390 % setting reference frequency = "60Hz" (set frequency)**

As the monitor is output once at starting from the stop status, the starting monitor output is 0.5Hz when the starting frequency is set to 0.5Hz. Therefore, the second monitor output is equal to or more than "0.5Hz+60Hz (Pr. 390 setting × Pr. 392 setting)" = "60.5Hz". (This is not the monitor output when the frequency reaches 60Hz. Use the SU signal to detect output frequency, etc.)

- Network variables that allow setting of event driven detection width

Name of Network Variables	In/Out	100% Value	Formula of Detection Width (0.005% increments)	Refer to Page
Speed monitor (0.005%/bit) SNVT_lev_percent nvoDrvSpeed	Out	—	As network variables supported and SNVT of detection width are the same type, set the value directly.	50
Output frequency monitor (0.1Hz/bit) SNVT_freq_hz nvolnvOutFreq	Out	% set reference frequency	$\frac{\text{Varying width of frequency monitor value}}{\% \text{ setting reference frequency}} \times 100\%$	57
Output frequency monitor (0.005%/bit) SNVT_lev_percent nvolnvOutFreqP	Out	—	As network variables supported and SNVT of detection width are the same type, set the value directly.	58
Output current monitor (0.1A/bit) SNVT_amp nvoDrvCurmt	Out	Rated inverter current	$\frac{\text{Varying width of current monitor value}}{\text{Rated inverter current}} \times 100\%$	59
Output voltage monitor (0.1V/bit) SNVT_volt nvoDrvVolt	Out	Rated inverter voltage (200V class: 200VAC, 400V class: 400VAC)	$\frac{\text{Varying width of voltage monitor value}}{\text{Rated inverter voltage}} \times 100\%$	59
Cumulative power monitor 2 (0.1kWh/bit) SNVT_elec_kwh_l nvoDrvRunPower_l	Out	Rated inverter power × 2	$\frac{\text{Varying width of cumulative power monitor value}}{\text{Rated inverter power} \times 2} \times 100\%$	61
Monitor data SNVT_count nvolnvMonData	Out	The reference value of 100% differs according to the monitor description. (Refer to page 72)	$\frac{\text{Varying width of monitor data value}}{\text{Reference value of each monitor}} \times 100\%$	75
Output frequency monitor (0.01Hz/bit) SNVT_count nvolnvOutFreq2	Out	% set reference frequency	$\frac{\text{Varying width of frequency monitor value}}{\% \text{ setting reference frequency}} \times 100\%$	76

Method for event driven detection... | Previous value - present value | ≥ event driven detection width

7 TROUBLESHOOTING

Operation mode does not switch to network operation mode.

- Check that the communication option (FR-A7NL) and LONWORKS dedicated cables are fitted properly. (Check for contact fault, break in the cable, etc.)
- Check that the node addresses are set to the correct positions.
- Check that operation mode switchover conditions are satisfied. (*Refer to page 21*)
- Check that the operation mode switching network variable is running.
- Check that the operation mode switching network variable has been written correctly.

The inverter does not start in network operation mode.

- Check that the inverter starting network variable has been written correctly.
- Check that the inverter starting network variable is running.

When "E.OP1" or "E.1" is displayed

- Refer to *page 33*.

Setup Example

The following is an example of procedure to perform LONWORKS communication with the FR-A7NL.

(1) Confirmation of installation and connection

- 1) Check that the FR-A7NL is mounted on the option connector of the inverter. (*Refer to page 7*)
- 2) Check that the twisted pair cable is connected to NET_A and NET_B of the terminal block supplied securely. (*Refer to page 15*)
- 3) Check that the terminating resistor is connected with a LONWOKRS cable. (Please fabricate a terminating resistor.) (*Refer to page 13*)

(2) Parameter setting of the inverter (when the network operation mode is always set)

- 1) Set "0" (simple mode+extended parameters display) in *Pr. 160 User group read selection*.
- 2) Set a value other than "0" in *Pr. 340 Communication startup mode selection*. (*Refer to page 21*)
- 3) Set "0 or 2" in *Pr. 79 Operation mode selection*. (*Refer to page 21*)

REMARKS

- By making parameter setting of 2) and 3) above, the inverter operates in network operation mode when the inverter power is switched on. (It is not necessary to change the operation mode with network variables.)

(3) Switch on the inverter power from off

Power on the inverter (inverter reset) again to change the mode to network operation mode.

(4) Perform LONWORKS communication setting

Perform LONWORKS communication setting with software necessary for LONWORKS communication such as "LonMaker for Windows, Visio 2000". (For a setting method, refer to the manual of software used.) Communication setting is complete if "SERVICE" LED of the FR-A7NL is not flickering.

(5) Check the status of the network variables

- 1) Power on the inverter (inverter reset) again and reflect the current network variables of the inverter to LonMaker Browser.
- 2) Set LonMaker Browser to "Monitor All On" to turn on monitoring of the inverter network variables. (When "Monitor All Off" is set, only the initial value of network variables the inverter sent to LonMaker Browser can be referred. To always check network variables, set "Monitor All On".)

(6) Setup is completed

Example of Inverter Parameter Clear

The following shows procedure to make LONWORKS communication again when inverter parameter clear is performed from LONWORKS communication.

(1) Perform parameter clear

Perform parameter clear via network or with the operation panel or parameter unit.

When performing with the operation panel or parameter unit, the procedure is the same as that of the inverter.

When performing via the network (LONWORKS), use the command request "SNVT_str_asc nviInvCmdReq" (*Refer to page 77*) of network variables.

Data set by command request:
Request flag = H01
Request code = H00FC
Request data = H5A5A, H55AA

- Parameter for communication is also cleared when H9696 and H9966 are set as request data.
(*Refer to page 77*)
- When Pr. 79 = "2", resetting is necessary as the set value is cleared.

(2) Check the status of the network variables

Set LonMaker Browser to "Monitor All On" to turn on monitoring of the inverter network variables.

(When "Monitor All Off" is set, only the initial value of network variables the inverter sent to LonMaker Browser can be referred. To always check network variables, set "Monitor All On".)

(3) LONWORKS communication resetting is complete

MEMO

REVISIONS

*The manual number is given on the bottom left of the back cover.

Print Date	*Manual Number	Revision
Mar., 2008	IB(NA)-0600344ENG-A	First edition

FR-A7NL Instruction Manual Supplement

The FR-A7NL manufactured in July 2011 or later is compatible with binary command requests and replies.


- (1) How to check if the product is compatible with binary command requests and replies
- (2) XIF file

The compatible FR-A7NL has the SERIAL of "□17○○" or later on its body or on its packaging box. Refer to the figure below for the SERIAL printed position on FR-A7NL.

●SERIAL number check

□ 1 7 ○○○] SERIAL
Symbol Year Month Control number

The SERIAL consists of one symbol, two characters indicating the production year and month, and three characters indicating the control number. The last digit of the production year is indicated as the Year, and the Month is indicated by 1 to 9, X (October), Y (November), or Z (December).



The XIF file, which supports binary command requests and replies, is available for download.

The download is free at "MELFANS Web," the Mitsubishi Electric FA network service on the world wide web.

URL:
<http://www.MitsubishiElectric.co.jp/melfansweb>

Contact your sales representative for the detail.

CAUTION

- Check the manufactured date of your FR-A7NL, and use the appropriate XIF file. An incorrect XIF file will disrupt normal operation. Refer to MELFANS web for more details.

(3) Command request (binary) (network input SNVT_preset nvInvcmdBinReq)

The actions that were unavailable with network variables can be set with binary data. Examples include the setting of instruction codes for operation mode change, parameter reading/writing, fault history reference, and parameter clear, and the setting of writing data. The format is as shown below. Data to be set are in binary code. A command request in binary code requires less communication data amount than a command request in ASCII code does. The initial setting of +0 to +13 is 0.

Function code	H02: LN_LEARN_VALUE	Command request is made.
	H02: Other than LN_LEARN_VALUE	Command request is not made.
Request code	Refer to the command list on <i>Subsection 6.7.5 in the Instruction Manual</i> to set the instruction code.	
Writing data	Set the data at writing. (Set value is ignored during reading.)	

- Data accepting timing.....At the network variable reception (nv_update_occurs event) while the function code = 2.

Storage position	Member	Content (binary data)	
+0	learn	Function code	
+1	selector	Invalid (Set value is ignored.)	H
		Request code	L
+3	value[0]	Invalid (Set value is ignored.)	H
	value[1]	Invalid (Set value is ignored.)	
	value[2]	Upper bytes of writing data	
	value[3]	Lower bytes of writing data	L
+7	day	Invalid (Set value is ignored.)	H
		Invalid (Set value is ignored.)	L
+9	hour	Invalid (Set value is ignored.)	
+10	minute	Invalid (Set value is ignored.)	
+11	second	Invalid (Set value is ignored.)	
+12	millisecond	Invalid (Set value is ignored.)	H
		Invalid (Set value is ignored.)	L

Setting example 1				Setting example 2			
When writing Pr.7 Acceleration time = 10.0s				When resetting the inverter			
Storage position	Content (binary data)			Storage position	Content (binary data)		
+0	H02			+0	H02		
+1	H00	H		+1	H00	H	
	H87	L			HFD	L	
+3	H00	H		+3	H00	H	
	H00				H00		
	H00				H96		
	H64	L			H96	L	
+7	H00	H		+7	H00	H	
	H00	L			H00	L	
+9	H00			+9	H00		
+10	H00			+10	H00		
+11	H00			+11	H00		
+12	H00	H		+12	H00	H	
	H00	L			H00	L	

* Refer to *Subsection 6.7.5 in the Instruction Manual* for the command processing procedure.

(4) Command reply (binary) (network output SNVT_preset nvInvCmdBinRply)

A reply to the command requested in "command request (binary) (nvInvCmdBinReq)" (on page 2/4) is given. The reply code and read data are included in the command processing results.

The format is as shown below. The data to be set are in binary code. A command reply in binary code requires less communication data amount than a command reply in ASCII code does. The initial values of +0 to +13 is 0.

Function code	H02: LN_LEARN_VALUE	Normal completion of command
	HFF: LN_NUL	Command execution error
Reply data	The data is set at reading. (A given value is set at writing.)	

●Relationship between function codes and reply data

Command execution results (function code)	Request code type set in nvInvCmdBinReq	Reply data content
H02 (Normal completion of command)	Read command	Read data
	Write command	Written data (echo back)
HFF (Command execution error)	Write command	H01: Mode error (The operation mode is different.)
	Read/write command	H02: Instruction code error (An non-existent instruction code is specified.)
	Write command	H03: Data range error (Out-of-range data is written.)

- Data transmission event..... At the completion of command processing

Storage position	Member	Content (binary data)	
+0	learn	Function code	
+1	selector	H00 (fixed)	H
		Echo back of the request code	L
+3	value[0] value[1] value[2] value[3]	H00 (fixed)	H
		H00 (fixed)	
		Upper bytes of reply data	
		Lower bytes of reply data	L
+7	day	H00 (fixed)	H
		H00 (fixed)	L
+9	hour	H00 (fixed)	
+10	minute	H00 (fixed)	
+11	second	H00 (fixed)	
+12	millisecond	H00 (fixed)	H
		H00 (fixed)	L

Setting example 1

When Pr.1 Maximum frequency setting of "60.00Hz" is read

Storage position	Content (binary data)	
+0	H02	
+1	H00	H
	H01	L
+3	H00	H
	H00	
	H17	
	H70	L
+7	H00	H
	H00	L
+9	H00	
+10	H00	
+11	H00	
+12	H00	H
	H00	L

Setting example 2

When out-of-range data, "0x7FFF," is written to Pr.2 Minimum frequency

Storage position	Content (binary data)	
+0	HFF	
+1	H00	H
	H82	L
+3	H00	H
	H00	
	H00	
	H03	L
+7	H00	H
	H00	L
+9	H00	
+10	H00	
+11	H00	
+12	H00	H
	H00	L

* Refer to *Subsection 6.7.5 in the Instruction Manual* for the command processing procedure.