

E860



Thank you for choosing Mitsubishi Electric inverter. This Inverter Safety Guideline provides handling information and precautions for use of this product. Do not use this product until you have full knowledge of the product mechanism, safety information and instructions.

Please forward this Safety Guideline to the end user

INVERTER SAFETY GUIDELINE FR-E860-0017(0.75K) to 0120(7.5K)



IB-0600862ENG-F(2312)MEE Specifications subject to change without notice

MITSUBISHI ELECTRIC CORPORATION

Usage

◆ Stay away from the equipment after using the retry function in this product as the equipment will restart suddenly after the output shutoff of this product.

◆ Access to the motor is allowed only after it is fully confirmed that the motor does

Access to the motor is allowed only after it is fully confirmed that the motor does not start numning.

Depending on the function settings of this product, the product does not stop is output even when the STOP/RESET key on the operation panel is pressed. To prepare for it, provide a separate circuit and switch (to turn OFF the power of this product, or apply a mechanical brake, etc.) for an emergency stop. The product of the sum of the fault as this product will restart the motor suddenly after a fault is cleared. Do not use a PM motor for an application that the motor may be driven by the load and run at a speed higher than the maximum motor speed. Use only a three-phase squirrel cage motor or PM motor as a load on this product. Connection of any other electrical equipment to the output of this product may damage the equipment. X signal and X13 signal under torque control may start the motor running at a low speed even when the start signal (STF or STR) is not input. This product with the start command ON may also rotate the motor at a low speed when the speed limit value is set to zero. Confirm that the motor running does not cause any safety problems before performing pre-excitation.

Do not modify this product.

en installing the MC on the output side of the inverter, turn it ON/OFF while in the inverter and motor are at a stop.

I electronic thermal O/L relay function may not be enough for protection of a or from overheading. It is recommended to install an external thermal relay or TC thermistor for overhead protection.

To thermistor for overhead protection. To the product of the pro

To drive a 600V class molor with this product, use an insulation-enhanced motor, or take measures to suppress surge voltage, which is attributed to the length and thickness of wire, may occur at the motor ferminals, causing the motor insulation to deteriorate.
 When a motor is driven by the inverter, axial voltage is generated on the motor shaft, which may cause electrical corrosion of the bearing. Take measures such shaft, which may cause electrical corrosion of the bearing. Take measures such shaft, which may cause electrical corrosion of the bearing. Take measures such a parameter clear or All parameter clear is performed, the parameters must be set again as required before the operation is started.
 As all parameters return to their initial values after Parameter clear or All parameter clear is performed, the parameters must be set again as required before the operation is started.
 This product can be easily set for high-speed operation. Therefore, consider all things related to the operation such as the performance of a motor and equipment in a system before the setting change.
 If the machine must not be restarted we not power is restored after a power failure, which will not switch OM the start signal.
 When performing an inverter operation with frequent starts/stops, rise/fall in the temperature of the transistor element of the inverter will repeat due to a repeated flow of large current, shortening the life.
 Perform an inspection and test operation of this product if it has been stored for a long period of time.
 In o avoid damage to this product due to static electricity, static electricity in your to avoid admand the support which this product.

Perform an inspection and test operation of this product if it has been stored for a long period of time.

To avoid damage to this product due to static electricity, static electricity in your body must be discharged before you touch this product.
Only one PM motor can be connected to a single unit of this product. A PM motor must be used under PM sensorless vector control. Do not use a synchronous motor, induction motor, or synchronous induction motor. Do not connect a PM motor to this product with it set to the induction motor control setting (initial setting). Do not connect an induction motor to this product with it set to the induction motor control setting (in the PM sensorless vector control setting). Doing so will cause failure with it set to the PM sensorless vector control setting. Doing so will cause failure the lose the contactor on the output side of this product.

To maintain the security (confidentiality, integrity and availability) of the inverter and the system against unauthorized access. DoS*1 attacks, computer viruses, and other cyberattacks from external devices via network, take appropriate measures such as firewalls, virtual private networks (VPNs), and antivirus solutions. We shall have no responsibility or liability for any problems involving inverter trouble and system trouble by DoS attacks, unauthorized access, computer viruses, and other cyberattacks.

When the emergency drive function is enabled, the operation is continued or the retry operation (automatic reset and restart) is repeated even if a fault occurs, which may damage or burn this product and the motor. Before restarting the sure that this product and the motor have no fault.

mergency stop

A safety backus such as an emercency brake must be provided for devices or

Emergency stop

A safety backup such as an emergency brake must be provided for devices or equipment in a system to prevent hazardous conditions in case of failure of this

For clarity, illustrations in this Safety Guideline may be drawn with covers or safety guards removed. Ensure all covers and safety guards are properly instal as described in the Instruction Manual (Connection) prior to starting operation

♦ Application of caution labels Caution labels are used to ensure safety during use of Mitsubishi Electric

inverters.
Make copies of the following labels and apply them to the inverter if the "retry function" and/or "automatic restart after instantaneous power failure" have been enabled.

CAUTION (Retry Function Has) Been Selected

Stay away from the motor and machine

CAUTION

Failure Has Been Selected

Stay away from the motor and machine They will start suddenly (after reset time has elapsed) when instantaneous power failure occurs.

Automatic Restart after Instantaneous Power

They will start suddenly (after given time has elapsed) when alarm occurs.

For automatic restart after instantaneous power failure

product. Doing so will cause failure.

Disposal

This product must be treated as industrial waste.

For the retry function

eth till a system to preven nazarucco consultation and the seaker installed on the input side of this product trips, check for wiring faults is short circuits) and damage to internal parts of this product. Identify and it the cause of the trip before resetting the tripped breaker and applying the to the product again. It is activated, take an appropriate corrective action are setting this product to resume the operation.

Ince, inspection and parts replacement carry out a megger (insulation resistance) test on the control circuit of this

Related manuals

Manual name	Manual number	Details
FR-E860 Instruction Manual (Connection)	IB-0600906ENG	Manuals describing installation, wiring, specifications, outline dimensions, standards, and how to connect options.
FR-E800 Instruction Manual (Function)	IB-0600868ENG	Manual describing details of the functions.
FR-E800 Instruction Manual (Communication)	IB-0600871ENG	Manual describing details of the communications.
FR-E800 Instruction Manual (Maintenance)	IB-0600874ENG	Manual describing how to identify causes of faults and warnings.
FR-E800 Instruction Manual (Functional Safety)	BCN-A23488-000	Manual describing the functional safety.
FR Configurator2 Instruction Manual	IB-0600516ENG	Manual describing details of the software used to set inverter parameters using a personal computer.
PLC Function Programming Manual	IB-0600492ENG	Manual describing details of the PLC function.

CAUTION

onot attempt to install, operate, maintain or inspect this product un u have read through this Safety Guideline and supplementary cuments carefully to use the equipment correctly. Do not use the

accuments caretully to use the equipment correctly. Do not use the product until you have full knowledge of the product mechanism, safety information and instructions. Installation, operation, maintenance and inspection must be performed by qualified personnel. Here, qualified personnel means a person who meets all the following conditions:

A person who possesses a certification in regard with electric appliance handling, or person took a proper peningering training.

• A person wno possesses a certification in regard with electric appliance handling, or person took a proper engineering training. Such training may be available at your local Mitsubishi Electric office Contact your local sales office for schedules and locations.
• A person who can access operating manuals for the protective devices (for example, light curtain) connected to the safety control system, or a person who has read these manuals thoroughly and familiarized themselves with the protective devices.

In this Safety Guideline, the safety instruction levels are classified int "WARNING" and "CAUTION".

↑ CAUTION

lote that even the <u>CAUTION</u> level may lead to a serious ensequence depending on conditions. Be sure to follow structions of both levels as they are critical to person ons. Be sure to follow the

♦ Electric shock prevention

Do not remove the front cover or the wiring cover while the power of this product is ON, and do not run this product with the front cover or the wiring cover removed, as the exposed high voltage terminals or the charging part of the circuitry can be touched. Doing so may cause an electric shock. Even if power is OFF, do not remove the front cover except for wiring or period inspection as the inside of this product is charged. Doing so may cause an electric shock.

electric shook.

Before wiring or inspection, check that the display of the operation panel is OFF. Any person who is involved in wiring or inspection shall wait for 10 minutes or longer after power OFF and check that there are no residual voltage using a digital multimeter or the like. The capacitor is charged with high voltage for some time after power OFF, and it is dangerous.

This must be earthed (grounded). Earthing (grounding) must conform to the requirements of national and local safety regulations and electrical code (NEC section 250, 61140 class 1 and other applicable standards).

Any person who is involved in wiring or inspection of this product shall be fully competent to do the work.

Use crimp terminals with insulation sleeves to wire the power supply and the motor.

This product body must be installed before wiring. Otherwise you may get an

product body must be installed before wiring. Otherwise you may get an electric shock or be injured.

Do not touch the setting dial or keys with wet hands. Doing so may cause an electric shock.

Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Poing on may cause an electric shock.

Doing so may cause an electric shock. Do not change the cooling fan while power is ON as it is dangerous to change the cooling fan while power is ON. Do not fouch the printed circuit board or handle the cables with wet hands. Doing

Do not touch the printed circuit board or handle the capies with we manus. During so may cause an electric shock. Never touch the motor terminals, etc. right after powering OFF as the DC voltage is applied to the motor for 1 second at powering OFF if the main circuit capacitor capacity is measured. Doing so may cause an electric shock.

This product must be installed on a nonflammable wall without holes in it so that its components cannot be touched from behind. Installing it on or near flammable

its components cannot be touched from behind. Installing it on or near flammable material may cause a fire. If this product becomes faulty, the product power must be switched OFF. A continuous flow of large current may cause a fire. Do not connect a resistor directly to the DC terminals P/+ and N/-. Doing so could cause a fire.

Do not connect a resistor directly to the DC terminals P/+ and N/-. Doing so could cause a fire.

De some to perform daily and periodic inspections as specified in the instruction Manual (Maintenance). There is a possibility of explosion, damage, or fire if this product is used without inspection.

Injury prevention

↑ CAUTION

⚠ CAUTION

The cables must be connected to the correct terminals. Otherwise an explosion of demage may occur. The polarity (* and -) must be correct. Otherwise an explosion or damage may While power is ON or for some time after power OFF, do not touch the inverter as it will be extremely hot. Doing so may cause hums

Additional instructions The following instructions must be also followed. If the product is handled ncorrectly, it may cause unexpected fault, an injury, or an electric shock.

↑ CAUTION

Transportation and installation

Use proper lifting techniques or a trolley when carrying products. Failure to do so may lead to injuries.

Do not stack the boxes containing inverters higher than the number

may lead to injuries.

Do not stack the boxes containing inverters higher than the number recommended.

The product miding to the information in the Instruction Manual.

Do not install or operate this product if it is damaged or has parts missing.

When carrying this product, do not hold it by the front cover. It may fall or break.

Do not stand or place heavy objects on the product.

Ensure the mounting orientation of this product is correct.

Prevent conductive objects such as screws, metal fragments, and wire offcuts, or flammable substances such as oil from entering the inverter.

As this product is a precision instrument, do not drop or subject it to impact.

The surrounding air temperature must be between -10°C and +60°C (nonfreezing). The rated current must be reduced at a surrounding air temperature above 50°C. Otherwise this product may be damaged.

The surrounding humidity must be 90% RH or less (non-condensing) for models with circuit board coating, and 95% RH or less (non-condensing) for models with circuit board coating. Otherwise this product may be damaged.

The temporary storage temperature (applicable to a short limited time such as a may be damaged.)

The temporary storage temperature (applicable to a short limited time such as a may be damaged.)

The temporary storage temperature (applicable to a short limited time such as a may be damaged.)

This product must be used indoors (without corresive as flammable ass. oil

transportation time) must be between "40°C and +70°C. Otherwise this product may be damaged.

This product must be used indoors (without corrosive gas, flammable gas, oil mist dust and dirt). Otherwise the product may be damaged.

Do not use this product at an altitude above 2000 m. Vibration should not exceet 5.9 m/s² at 10 to 55 Hz in X, Y, and Z directions. Otherwise the product may be damaged.

damaged. If halogens (including fluorine, chlorine, bromine, and iodine) contained in furnigants for wood packages enter this product, the product may be damaged. Prevent the entry of furnigant residuals or use an alternative method such as heat disinfection. Note that sterilization or disinfection of wood packages should be performed before packing the product.

performed before packing the product.

Wing

Do not install a power factor correction capacitor, surge absorber, or radio noise
filter on the output side of this product. These devices may overheat or burn out.

The output terminals (terminals U, V, and W) must be connected to a motor

Even with the power OFF, high voltage is still applied to the terminals U, V and W
wille the PM motor is running. Ensure the PM motor has stopped before carrying
out any wiring. Otherwise you may get an electric shock.

Never connect a PM motor to a commercial power supply. Connecting a
commercial power supply to the input terminals (U, V, W) of a PM motor will burn
it out. The PM motor must be connected with the output terminals (U, V, W) of fish
product.


Avoid places where the inverter is subjected to direct sunlight, high temperature and high

wiring cover to fix the inverter.

INVERTER INSTALLATION AND PRECAUTIONS

Install the inverter on a nonflammable wall surface.


 Install the inverter on a strong surface securely with screws. Leave enough clearances and take cooling measures.



or more

INSTALLATION AND WIRING

Removal and reinstallation of covers



(a) Loosen the mounting screws of the cover. (These screws cannot be

(b) Pull out the cover using its lower side as a support With the cover removed, the control circuit terminals can be wired and the plug-in option can be installed.

(a) Check the position of the hooks on the rear of the cover

(b) Insert the hooks of the cover into the sockets of the wiring cover, and reinstall the cover to the inverter.

(c) Tighten the mounting screws of the front cover. (Tightening torque: 0.6 to 0.8 $_{\hbox{N\cdot m})}$




(a) Insert a tool such as a flathead screwdriver into the half-hole above the "PUSH" mark on the wiring cover to push the stopper behind the wiring cover approx. 3 mm.

(b) Pull out the cover along the guides in the direction shown by the arrow in the figure above.


FR-E860-0061(3.7K) or higher Removal of the wiring cover

◆ FR-E860-0040(2.2K) or lower

Removal of the wiring cover








(a) Insert a tool such as a flathead screwdriver into the half-hole above the "PUSH" mark on the wiring cover to push the stopper behind the wiring cover approx. 3 mm.

(b) Pull out the cover along the guides in the direction shown by the arrow in the figure above.

Main circuit terminal layout and wiring to power supply and motor ◆ Three-phase 575 V class



Connect the motor to terminals U, V, and W. The motor rotates counterclockwise when viewed from the motor load side when the forward rotation switch (signal) turns ON

Applicable cables and wiring length

Select cables of recommended gauge size to ensure that the voltage drop will be 2% or less. If the wiring distance is long between the inverter and motor, the voltage drop in the main circuit will cause the motor torque to decrease especially at a low speed

The following table shows a selection example for the wiring length of 20 m at the ND rating. When using the inverter with the LD rating, refer to the FR-E860 Instruction

		01			Cable	gauge		
Terminal		Crimp	erminai	HIV cables, etc. (mm ²) *		AWG (mm ²) *2		
screw size *3	N·m	R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	
M4	1	2-4	2-4	2	2	14	14	
M4	1	2-4	2-4	2	2	14	14	
M4	1	2-4	2-4	2	2	14	14	
M4	1	2-4	2-4	2	2	14	14	
M4	1	2-4	2-4	2	2	14	14	
M4	1	5.5-4	2-4	3.5	2	12	14	
	screw size *3 M4 M4 M4 M4 M4	Screw Size *3 Storque N·m	Terminal screw Screw N·m R/L1, S/L2, T/L3 M4 1 2-4 M5 M6 1 2-4 M6 M6 1 2-4 M7 M8 M8 M8 M8 M8 M8 M8	screw size *3 torque N·m R/L1, S/L2, T/L3 U, V, W M4 1 2-4 2-4 M4 1 2-4 2-4	Terminal Screw N-m Fig. Filt Filt	Terminal Screw Tightening screw R/L1, R/L1, S/L2, T/L3 U, V, W T/L3 U, V	Terminal Screw Size *3 Tightening R/L1, S/L2, U, V, W R/L1, S/L2, T/L3 U, V, W R/L1, T/L3 U, V, W T/L3 U, V, W T/L3 U, V, W R/L1, T/L3 U, V, W T/L3 U, V, W	

HIV cable (DUU V grade feath-resistant PVV installation wine) with a Continuous immension permission of the property of the pr The line voltage drop can be cal

Line voltage drop [V] = $\sqrt{3}$ × wire resistance [mΩ/m] × wiring distance [m] × current [A] / 1000

Use a larger diameter cable when the wiring distance is long or when it is desired to decrease the voltage drop (torque reduction) in the low speed range. Total wiring length

Connect one or more motors within the total wiring length (sum of the wiring lengths of the motor and the inverter) shown in the following table


Cable type	Pr.72 setting (carrier frequency)	Voltage class	0.75K	1.5K	2.2K	3.7K	5.5K	7.5K
Unshielded	1 (1 kHz) or lower	575 V	100m	100m	100m	200m	400m	500m
Orioniciaca	2 (2 kHz) or higher	3/3 4	100m	100m	100m	200m	300m	400m

Use a "600 V class inverter-driven insulation-enhanced motor" and set Pr.72 PWM frequency selection according to the wiring length: "14.5 kHz or less" when the wiring length is 50 m or shorter, "8 kHz or less" when the wiring length is from 50 m to 100 m, or "2 kHz or less" when the wiring length is longer than 100 m.

Terminal connection diagram

Terminal symbol

Common



Details on the main circuit terminals and the control circuit terminals

Terminal function description

Terminal name

		T/L3	-	AC power input	Connected to the commercial power supply.						
		U, V, W	_	Inverter output	Connected to a three-phase squirrel cage motor or a PM motor.						
	Main circuit	P/+, PR	-	Brake resistor connection	Connect a brake resistor across terminals P/+	and PR.					
	0	P/+, N/-	_	Brake unit connection	Connect the brake unit.						
	Mai	P/+, P1	_	DC reactor connection	Remove the jumper across terminals P/+ and P1, and connect a DC reactor. When a DC reactornected, the jumper across terminals P/+ and P1 should not be removed.						
			_	Earth (ground)	For earthing (grounding) the inverter chassis.	he inverter.					
		STF *1		Forward rotation start	Turn ON the STF signal to start forward rotation and turn it OFF to stop.	When the STF and STR signals are turned ON					
		STR*1	SD (sink	Reverse rotation start	Turn ON the STR signal to start reverse rotation and turn it OFF to stop.	simultaneously, the stop command is given.	Input resistance: 4.7 kΩ				
	input	RH, RM, RL *1	(negative common))	Multi-speed selection	Multi-speed can be selected according to the and RL signals.	combination of RH, RM	Voltage when contacts are open: 21 to 26 VDC				
	Contact input	MRS *1	PC (source (positive	Output stop		the MRS signal (5 ms or more) to stop the inverter output. signal to shut off the inverter output when stopping the motor ectromagnetic brake.					
		RES*1	common))	Reset	Use this signal to reset a fault output provided function is activated. Turn ON the RES signal then turn it OFF. In the initial setting, reset is always enabled. B be enabled only at an inverter fault occurrence about 1 second after reset.	4 to 6 mADC					
Input signal		10	5	Power supply for a frequency setting potentiometer	Used as the power supply for an external freq setting) potentiometer.	uency setting (speed	5 ±0.5 VDC, Permissible load current: 10 mA				
Ē	/ setting	2	5	Frequency setting (voltage)	Inputting 0 to 5 VDC (or 0 to 10 VDC) provide frequency at 5 V (or 10 V) and makes input ar Use Pr.73 to switch among input 0 to 5 VDC (VDC, and 0 to 20 mA. * The initial setting vari specification. Set the voltage/current input switch to the "I" prinput (0 to 20 mA).	nd output proportional. initial setting), 0 to 10 es depending on the	For voltage input, Input resistance: 10 to 11 kO				
	Frequency setting	4	5	Frequency setting (current)	Inputting 4 to 20 mADC (or 0 to 5 VDC, 0 to 1 maximum output frequency at 20 mA and map rroportional. This input signal is valid only who (terminal 2 input is invalid). To use the terminal 4 (current input at initial se parameter from Pr.178 to Pr.184 (Input terminal 6 to 1 to	Maximum permissible voltage: 20 VDC For current input, Input resistance: 245 ±5 Ω Permissible maximum current: 30 mA					



Terminal function description

(power factor = 0.4) or 30 VDC 1 A

hangeover contact output indicates that the inverter protective

Fault: discontinuity across B and C (continuity across A and C), Normal

ction has activated and the outputs are stopped


tinuity across B and C (discontinuity across A and C)

Control circuit terminal layout

Common

Terminal name

Relay output (fault





BASIC OPERATION

Components of the operation panel The operation panel cannot be removed from the inverte

Description
Switches between the PU operation mode, the PUJOG operation mode, and the PU/EXT kev Switches the operation panel to a different mode Jsed to confirm each selection. ches the monitor screen in the monitor mode. RUN kev PU MODE SET Used to stop operation commands.
Used to reset the inverter when the protective function is activated. RUN STOP RESET he setting dial of the Mitsubishi Electric inverters. Turn the setting dial to change ne setting of frequency or parameter.

◆Starting/stopping the inverter on the operation pane





4 PARAMETERS

For details, refer to the FR-E800 Instruction Manual (Function). The PDF manual can also be downloaded from the Mitsubishi Electric FA Global

The PDF manual can also be downloaded from the Mitsubishi Electric FA Global Website.

5 LIST OF FAULT DISPLAYS For details, refer to the FR-E800 Instruction Manual (Maintenance) Website.





SPECIFICATIONS

6.1 Inverter rating

◆ Three-phase 575 V power supply

	Model FR-	E060 II		0017	0027	0040	0061	0090	0120		
	Model FR-	-E860-[]		0.75K	1.5K	2.2K	3.7K	5.5K	7.5K		
Applicable motor capacity (kW) *1					2.2	3.7	5.5	7.5	11.0		
ND				0.75	1.5	2.2	3.7	5.5	7.5		
	Rated capac	in. /L\/A\ *2	LD	2.5	3.6	5.6	8.2	11.0	15.9		
	Rated Capac	ity (KVA) "2	ND	1.7	2.7	4.0	6.1	9.0	12.0		
	Rated current (A) *7		LD	2.5	3.6	5.6	8.2	11.0	16.0		
				(2.1)	(3.0)	(4.8)	(7.0)	(9.0)	(13.6)		
			ND	1.7	2.7	4.0	6.1	9.0	12.0		
			LD				-time chara	acteristics)	at		
Output	tput Overload current rating *3				ing air tem						
			ND				-time chara	acteristics)	stics) at		
		oltage *4		surrounding air temperature of 50°C Three-phase 525 to 600 V							
	V	alatar	Built-in								
	Regenerative braking	Brake tran		Built-in							
		Maximum brake torque (ND		100%	50%	20%					
	Diaking	e) *5	100%	50%							
	Pated input A	C voltage/fred	, .	Three-phase 575 V 60 Hz							
		C voltage fluc		490 to 632 V. 60 Hz							
		requency fluct		1490 to 632 V, 60 HZ							
	r eminasible i	Without DC	LD	4.3	5.9	8.9	12.4	15.9	22.4		
	Rated input	reactor	ND	3.0	4.6	6.6	9.5	13.3	17.4		
Power	current (A) *8	With DC	LD	2.5	3.6	5.6	8.2	11.0	16.0		
supply	Carronic (71)	reactor	ND	1.7	2.7	4.0	6.1	9.0	12.0		
		Without DC	LD	4.3	5.9	8.9	12.3	16.0	23.0		
	Power supply	reactor	ND	3.0	4.6	6.6	9.5	14.0	18.0		
	capacity	With DC	LD	2.5	3.6	5.6	8.2	11.0	16.0		
	(kVA) *6	reactor	ND	1.7	2.7	4.0	6.1	9.0	12.0		
						4.0	0.1	9.0	12.0		
Р	rotective structu)	Open typ	, ,						
	Cooling	•		Natural	Forced a		1		1		
	Approx. m	ass (kg)		1.9	1.9	1.9	2.4	2.4	2.4		

- The motor capturing management of the output voltage is 575 V. The percentage of the overload current rating is the ratio of the overload current to the inverter's rated output current. For repeated outry, allow united to the output voltage is 575 V. The percentage of the overload current rating is the ratio of the overload current to the inverter's rated output current. For repeated outry, allow united to the output voltage and output voltage output current. For repeated outry, allow united to the output voltage waveform at the temperatures under 100% load. The maximum output voltage does not exceed the power supply voltage. The maximum output voltage does not exceed the power supply voltage. The maximum output voltage does not exceed the power supply voltage multiplied by √2. maximum capacity of a 4-pole standard motor driven by all of the inverters in parallel connection.
 es that the output voltage is 575 V.
 urrent rating is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the
- output side of the invertor is approximately the power supply voltage multiplied by x². The amount of braking broque is the average short-term foruce (which varies depending on motor loss) that is generated when a motor decelerates in the shortest time by itself from 60 Hz. It is not continuous regenerative lorque. The average deceleration torque becomes lower when a motor decelerates from a frequency higher than the base frequency. The inverter is not equipped with a built-in brake resistor. Use a brake resistor for an operation with large regenerative power. A brake unit can be also used.

 The power supply capacity varies with the value of the power supply side impedance (including those of the input reactor and cables).

 The power supply capacity varies with the value of the power supply side impedance (including those of the input reactor and cables).

 The power supply capacity varies with the value of the power supply side impedance (including those of the input reactor and cables).

 The power supply capacity varies with the value of the power supply side impedance (including those of the input reactor and cables).
- y selection.

 s the value when at the rated output current. The impedance at the power supply side (including those of the input reactor and cables) affects the rated input current.

Inverter installation environment

Item	Description	
Surrounding air temperature *1	-10°C to +60°C (The rated current must be reduced at a temperature above 50°C. For details, refer to the FR-E860 Instruction Manual (Connection). To meet the UL/EN standards, use the product at temperatures from -10°C to 50°C.)	Enclosure Inverter Measurement
Ambient humidity	95% RH or less (non-condensing) (With circuit board coating (IEC 60721-3-3:1994 3C2 compatible)) 90% RH or less (non-condensing) (Without circuit board coating)	position 5 cm 5 cm
Storage temperature	-40°C to +70°C	Measurement +5 cm
Atmosphere	Indoors (free from corrosive gas, flammable gas, oil mist, dust and dirt)	
Altitude/vibration	Maximum 2000 m, $5.9~\text{m/s}^2$ or less (For installation at an altitude above 1000 m, consider a 3% reduction altitude.)	in the rated current per 500 m increase in

7 APPENDIX

7.1 Instructions for compliance with the EU Directives

- The authorized representative in the EU
 The authorized representative in the EU is shown below Name: Mitsubishi Electric Europe B.V.
- Address: Mitsubishi-Electric-Platz 1, 40882 Ratingen, Germany
- We declare that this inverter conforms with the EMC Directive and affix the CE marking on the inverter.
- EMC Directive: 2014/30/EU
- Standard: IEC 61800-3 (Category "C3" / Second environment) This inverter is not intended to be used on a low-voltage public network which supplies domestic premises. When using the inverter in a residential area, take appropriate measures
- and ensure the conformity of the inverter used in the residential area Radio frequency interference is expected if used on such a network.

Set the EMC Directive compliant EMC filter to the inverter. Insert line noise filters and ferrite cores to the power and control cables as required.

- Set the EMC Directive compilant EMC filter to the inverter. Insert line holse filters and refrite cores to the power and control capies as required.

 Connect the inverter to an earthed power supply.

 Install the motor and controller cable found in the EMC Installation Guidelines (BCN-A21041-204) and Technical News (MF-S-177) according to the instructions. (Contact your sales representative for the manual.)

 To make full use of the EMC Directive compliant noise filter, motor cable lengths should not exceed 20 m.

 Ensure that the finalized system which includes an inverter complies with the EMC Directive.

- ♦ Low Voltage Directive

 We have self-confirmed our inverters as products compliant to the Low Voltage Directive and affix the CE marking on the inverters.
- Standard: EN 61800-5-1
 - · Do not use an earth leakage circuit breaker as an electric shock protector without connecting the equipment to the earth. Connect the equipment to the earth (ground)

 - Wire the earth terminal independently. (Do not connect two or more cables to one terminal.)
 Select appropriate wire according to EN 60204-1 or IEC 60364-5-52. (Refer to the selection examples of cable sizes in 2.3 Applicable cables and wiring length.) Use a tinned (plating should not include zinc) crimping terminal to connect the earth (ground) cable. When tightening the screw, be careful not to damage the threads. For use as a product compliant with the Low Voltage Directive, use PVC cables.

 - Use PVC cables for I/O wiring. Use the molded case circuit breaker and magnetic contactor which conform to the EN or IEC Standard
- If an earth leakage circuit breaker is required, use a type-B earth leakage circuit breaker (AC/DC detection compatible).

 Use the inverter under the conditions of overvoitage category III specified in IEC 60664.

 To use the inverter under the conditions of pollution degree 3, install it in the enclosure of IP54 or higher for protection against electric shock and fire.
- · Attach the fan cover to the fan with the fan cover fixing screw enclosed with the inverter



Fuse selection for branch circuit protection Use the following semiconductor fuses for branch circuit protection

Inverter model	Cat. No	Manufacturer	Rating	1	Inverter model	Cat. No	Manufacturer	Rating
FR-E860-0017(0.75K)	170M1409, 170M1309 or 170M1359	Bussmann	700 V, 16 A		FR-E860-0061(3.7K)	170M1413, 170M1313 or 170M1363	Bussmann	700 V, 40 A
FR-E860-0027(1.5K)	170M1410, 170M1310 or 170M1360	Bussmann	700 V, 20 A		FR-E860-0090(5.5K)	170M1414, 170M1314 or 170M1364	Bussmann	700 V, 50 A
FR-E860-0040(2.2K)	170M1312, 170M1362 or 170M1412	Bussmann	700 V, 32 A		FR-E860-0120(7.5K)	170M1415, 170M1315 or 170M1365	Bussmann	700 V, 63 A

♦ Motor overload protection For details, refer to 7.2 Instructions for UL and cUL: Motor overload protection

For other information, refer to the FR-E860 Instruction Manual (Connection).

♦ EU RoHS Directive

We have declared that our inverters are compliant to the EU RoHS Directive and affix the CE marking on the inverters.

7.2 Instructions for UL and cUL

(Standard to comply with: UL 61800-5-1, CSA C22.2 No. 274)

♦ Product handling information / Informations sur la manipulation du produit
-WARNING- Operation of this product requires detailed installation and operation instructions provided in this Safety Guideline and the Instruction Manual (Connection) intended for use with this product. Please forward relevant manuals to the end user. The manuals can also be downloaded in PDF form from the Mitsubishi Electric FA Global Website. To order manuals, please contact your sales representative.

-AVERTISSEMENT-

L'utilisation de ce produit nécessite des instructions détaillées d'installation et d'utilisation fournies dans le présent document de la Directive de sécurité et le Manuel d'instructions (Connexion) destiné à être utilisé avec ce produit. Veuillez transmettre les manuels correspondants à l'utilisateur final. Les manuels peuvent éga être téléchargés au format PDF sur Mitsubishi Electric FA Global Website. Pour commander des manuels, veuillez contacter votre représentant commercial.

For installation in the United States, use the branch circuit protection equipment specified in Technical News MF-S-187, in accordance with the National Electrical Code and any applicable local codes For installation in Canada, use the branch circuit protection equipment specified in Technical News MF-S-187, in accordance with the Canadian Electrical Code and

any applicable local codes. Short circuit protection of the inverter cannot be used as branch circuit protection. Integral solid state short circuit protection does not provide branch circuit protection Branch circuit protection must be provided in accordance with the National Electrical Code and any additional local codes.

The installation/operation manual is available via the internet at https://www.mitsubishielectric.com/fa/products/drv/inv/support/e800/e800.html. A hard copy of this information may be ordered at +1 (847) 478-2100 (Mitsubishi Electric Automation, Inc. in USA).

Precautions for opening the branch-circuit protective device / Précautions pour ouvrir le dispositif de protection du circuit de dérivation -WARNING- If the fuse melts down or the breaker trips on the input side of this product, check for wiring faults (such as short circuits). Identify and remove the cause of melting down or the trip before replacing the fuse or resetting the tripped breaker (or before applying the power to the inverter again).

-AVENTIOSEMENT:
Si le fusible fond ou si le disjoncteur se déclenche du côté entrée de ce produit, vérifier les défauts de câblage (tels que les courts-circuits). Identifier et éliminer la cause de la fonte ou du déclenchement avant de remplacer le fusible ou de réinitialiser le disjoncteur déclenché (ou avant de remettre sous tension l'onduleur).

♦ Capacitor discharge time / Temps de décharge du condensateur CAUTION - Risk of Electric Shock -

Before wiring or inspection, check that the LED display of the operation panel is OFF. Any person who is involved in wiring or inspection shall wait for 10 minutes or longer after power OFF, and check that there are no residual voltage using a digital multimeter or the like. The capacitor is charged with high voltage for some time after

ATTENTION - Risque de choc électrique - Avant le câblage ou l'inspection, vérifier que le témoin LED s'éteint. Toute personne impliquée dans le câblage ou l'inspection doit attendre 10 minutes ou plus après la mise hors tension et vérifier l'absence de tension résiduelle à l'aide d'un multimètre numérique ou similaire. Le condensateur est chargé avec une haute tension pendant un certain temps après la mise hors tension, ce qui est dangereux. Précautions pour ouvrir le dispositif de protection du circuit de dérivation

Wiring to the power supply and the motor

Refer to the National Electrical Code (Article 310) regarding the allowable current of the cable. Select the cable size for 125% of the rated current according to the National Electrical Code (Article 430). For wiring the input (R/L1, S/L2, T/L3) and output (U, V, W) terminals of the inverter, use the UL listed copper, stranded wires (rated at 75°C) and round crimp terminals. Crimp the terminals with the crimping tool recommended by the terminal manufacturer


The following table shows examples when the inverter rating is the LD rating, when the cable is the THHW cable with continuous maximum permissible temperature of 75°C, when the surrounding air temperature is 30°C or less, and the wiring length is 20 m or shorter.

			Crimp termi	nal	Cable gauge		
Applicable inverter model	Terminal screw size	Tightening torque (N·m)	Crimp termi	IIdi	AWG		
	·	(,	R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	
FR-E860-0017(0.75K) to 0040(2.2K)	M4	1.5	2-4	2-4	14	14	
FR-E860-0061(3.7K), 0090(5.5K)	M4	1.5	3.5-4	2-4	12	14	
FR-E860-0120(7.5K)	M4	1.5	5.5-4	3.5-4	10	12	

- *1 The screw size for terminals R/L1, S/L2, T/L3, U, V, W, PR, P/+, N/-, and P1, and the earthing (grounding) terminal is shown
- Short circuit ratings
 600 V class: Suitable for use in a circuit capable of delivering not more than 100 kA rms symmetrical amperes, 575 V maximum.

♦ Motor overload protection The following explains the details of the motor overload protection.

When using the electronic thermal relay function as motor overload protection, set the rated motor current in Pr.9 Electronic thermal O/L relay Pr.9 = 50% setting of



This function detects the overload (overheat) of the motor and shut off the inverter output by stopping the operation of the transistor at the inverter output side. (The operation characteristic is shown on the left.)

- When using the constant-torque motor

 1) Set one of "10, 13, 15, 16" in **Pr.71**. (This setting enables the 100% constant-torque characteristic in the low-speed
- Set the rated motor current in Pr.9.

- When setting Pr.9 to a value (current value) of 50% of the inverter rated output current. The % value denotes the percentage to the inverter rated output current. It is not the percentage to the rated motor current. When the electronic thermal relay function dedicated to the constant-torque motor is set, this characteristic curve applies to operation at 6 Hz or higher.

. The internal accumulated heat value of the electronic thermal O/L relay is reset to the initial value by the inverter's power reset or reset signal input. Avoid unnecessary reset and


- The cooling effect of the motor drops during low-speed operation. Use a motor with built-in thermal protector
- The electronic thermal memory retention function is not provided by the drive. The electronic thermal relay function is not a speed sensing function

power-OFF. Install an external thermal relay (OCR) between the inverter and motors to operate several motors, a multi-pole motor or a dedicated motor with one inverter. When configuring an

- external thermal relay, note that the current indicated on the motor rating plate is affected by the line-to-line leakage current. (Refer to the Instruction Manual (Function).) The cooling effect of the motor drops during low-speed operation. Use a motor with built-in thermal protector. When the difference between the inverter and motor capacities is large and the set value is small, the protective characteristics of the electronic thermal relay function will be deteriorated. Use an external thermal relay in such cases.
- A dedicated motor cannot be protected by the electronic thermal relay. Use an external thermal relay. Motor over temperature sensing is not provided by the drive.

7.3 SERIAL number check

The SERIAL number can be checked on the inverter rating plate or package



Symbol Year Month Control number

SERIAL The SERIAL consists of two symbol, three characters indicating the production year

and month, and six characters indicating the control number. The last two digits of the production year are indicated as the Year, and the Month is indicated by 1 to 9, X (October), Y (November), or Z (December)

7.4 Instructions for EAC

The product certified in compliance with the Eurasian Conformity has the EAC marking

Note: EAC marking In 2010, three countries (Russia, Belarus, and Kazakhstan) established a Customs Union for the purposes of revitalizing the economy by forming a large economic bloc by abolishing or reducing tariffs and unifying regulatory procedures for the handling of articles Products to be distributed over these three countries of the Customs Union must comply with the Customs Union Technical



For information on the country of origin, manufacture year and month, and authorized sales representative (importer) in the CU area of this product, refer to the

- · Country of origin indication

Phone: +90-216-969-25-00

- Check the SERIAL number indicated on the rating plate of the product

Regulations (CU-TR), and the EAC marking must be affixed to the products.

Authorized sales representative (importer) in the CU area The authorized sales representative (importer) in the CU area is shown below. Name: Mitsubishi Electric Turkey A.S. Head Office Address: Serifali Mahallesi Kale Sokak. No:41 34775 Umraniye, Istanbul, Turkey

7.5 Compliance with the UK certification scheme

We declare that this product conforms with the related technical requirements under UK legislation, and affix the UKCA (UK Conformity Assessed) marking on the product. Approval conditions are the same as those for the EU Directives. Refer to the "7.1 Instructions for compliance with the EU Directives" in



the Instruction Manual.

The UKCA marking is used for products sold in the markets of Great Britain (England, Wales, and Scotland) from January 1, 2021 after the departure of the UK from the

7.6 EU ErP Directive (Ecodesign Directive)

The following table shows the power loss data according to Ecodesign Directive. The regulation covers 3-phase variable speed drives from 0.12 kW \leq Pn \leq 1 000 kW. (LD rated / ND rated)

Model name	Rated Apparent power	Stand by loss	load point 1 (90;100) (%)	load point 2 (50;100) (%)	load point 3 (0;100) (%)	load point 4 (90;50) (%)	load point 5 (50;50) (%)	load point 6 (0;50) (%)	load point 7 (50;25) (%)	load point 8 (0;25) (%)	IE class
R-E860-0017(0.75K)	2.5 / 1.7	5.7 / 5.7	1.7 / 1.7	1.7 / 2	1.7 / 2	1.2 / 1.4	1.2 / 1.4	1.2 / 1.4	1.0 / 1.2	1.0 / 1.2	IE2
R-E860-0027(1.5K)	3.6 / 2.7	9.8 / 9.8	1.4 / 1.5	1.4 / 1.5	1.4 / 1.5	1.1 / 1.2	1.1 / 1.2	1.1 / 1.2	0.9 / 1.1	0.9 / 1.1	IE2
R-E860-0040(2.2K)	5.6 / 4	9.8 / 9.8	1.3 / 1.4	1.3 / 1.4	1.3 / 1.4	1.0 / 1.0	1.0 / 1.0	1.0 / 1.0	0.8 / 0.9	0.8 / 0.9	IE2
R-E860-0061(3.7K)	8.2 / 6.1	14.5 / 14.5	1.3 / 1.3	1.3 / 1.3	1.3 / 1.3	0.9 / 1.0	0.9 / 1.0	0.9 / 1.0	0.8 / 0.9	0.8 / 0.9	IE2
R-E860-0090(5.5K)	11 / 9	14.5 / 14.5	1.2 / 1.2	1.2 / 1.2	1.2 / 1.2	0.7 / 0.8	0.7 / 0.7	0.7 / 0.7	0.6 / 0.6	0.6 / 0.6	IE2
R-E860-0120(7.5K)	16 / 12	14.5 / 14.5	1.2 / 1.1	1.1 / 1.1	1.1 / 1.1	0.7 / 0.7	0.7 / 0.7	0.7 / 0.7	0.5 / 0.5	0.5 / 0.5	IE2

7.7 Restricted Use of Hazardous Substances in Electronic and Electrical **Products**

The mark of restricted use of hazardous substances in electronic and electrical products is applied to the product as follows based on the "Management Methods for the Restriction of the Use of Hazardous Substances in Electrical and Electronic Products" of the People's Republic of China. 电器电子产品有害物质限制使用标识要求



本产品中所含有的有害物质的名称、含量、含有部件如下表所示。

• 产品中所含有害物质的名称及含量

	有害物质 *1									
部件名称 *2	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)				
电路板组件 (包括印刷电路板及其构成的零部件, 如电阻、电容、集成电路、连接器等)、电子部件	×	0	×	0	0	0				
金属壳体、金属部件	X	0	0	0	0	0				
树脂壳体、树脂部件	0	0	0	0	0	0				
螺丝、电线	0	0	0	0	0	0				

〇:表示该有害物质在该部件所有均质材料中的含量均在 GB/T26572 规定的限量要求以下。

×:表示该有害物质在该部件的至少一种均质材料中的含量超出 GB/T26572 规定的限量要求。 *1 即使表中记载为 × ,根据产品型号,也可能会有有害物 *2 根据产品型号,一部分部件可能不包含在产品中。

7.8 Referenced Standard (Requirement of Chinese standardized law)

This Product is designed and manufactured accordance with following Chinese standards Machinery safety: GB/T 16855.1

GB/T 12668.502 GB 28526 GB/T 12668.3 Electrical safety: GB/T 12668.501

8 WARRANTY

EMC: GB/T 12668.3

Exclusion of loss in opportunity and secondary loss from warranty liability Regardless of the gratis warranty term, Mitsubishi Electric shall not be liable for compensation to

(1) Damages caused by any cause found not to be the responsibility of Mitsubishi Electric

(2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi Electric products (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than

Mitsubishi Electric products. (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks