

E860-E



Thank you for choosing Mitsubishi Electric inverter. This Inverter Safety Guideline provides handling information and precautions for use of this product. Do not use this product until you have full knowledge of the product mechanism, safety information and

Please forward this Safety Guideline to the end user.

**INVERTER SAFETY GUIDELINE** FR-E860-0017(0.75K) to 0120(7.5K)E



### IB-0600863ENG-F(2312)MEE

Specifications subject to change without notice.

### Related manuals

Manual name	Manual number	Details
FR-E860 Instruction Manual (Connection)	IB-0600906ENG	Manuals describing installation, wiring, specifications, outline dimensions, standards, and how to connect options.
FR-E800 Instruction Manual (Function)	IB-0600868ENG	Manual describing details of the functions.
FR-E800 Instruction Manual (Communication)	IB-0600871ENG	Manual describing details of the communications.
FR-E800 Instruction Manual (Maintenance)	IB-0600874ENG	Manual describing how to identify causes of faults and warnings.
FR-E800 Instruction Manual (Functional Safety)	BCN-A23488-000	Manual describing the functional safety.
FR Configurator2 Instruction Manual	IB-0600516ENG	Manual describing details of the software used to set inverter parameters using a personal computer.
PLC Function Programming Manual	IB-0600492ENG	Manual describing details of the PLC function.

**↑** CAUTION

### not attempt to install, operate, maintain or inspect this product until u have read through this Safety Guideline and supplementary

Do not attempt to install, operate, maintain or inspect this product until you have read through this Safety Guideline and supplementary documents carefully to use the equipment correctly. Do not use the product until you have full knowledge of the product mechanism, safety information and instructions.

Installation, operation, maintenance and inspection must be performed by qualified personnel. Here, qualified personnel means a person who meets all the following conditions:

A person who possesses a certification in regard with electric appliance handling, or person took a proper engineering training. Such training may be available at your local Mitsubishi Electric office Contact your local sales office for schedules and locations.

A person who can access operating manuals for the protective devices (for example, light curtain) connected to the safety control system, or a person who has read these manuals thoroughly and familiarized themselves with the protective devices.

In this Safety Guideline, the safety instruction levels are classified int "WARNING" and "CAUTION".

**↑** CAUTION

lote that even the <u>CAUTION</u> level may lead to a serious sequence depending on conditions. Be sure to follow the ructions of both levels as they are critical to personnel safety

### Electric shock prevention

Do not remove the front cover or the wiring cover while the power of this product is ON, and do not run this product with the front cover or the wiring cover removed, as the exposed high voltage terminals or the charging part of the circuitry can be touched. Doing so may cause an electric shook. Even if power is OFF, do not remove the front cover except for wiring or periodi inspection as the inside of this product is charged. Doing so may cause an alertric school.

respection as the sinuser of this product is unargue. Doing so may cause an electric shock.

Any person who is involved in wiring or inspection shall wait for 10 minutes or longer after power OFF and check that there are no residual voltage using a digital multimeter or the like. The capacitor is charged with high voltage for some time after power OFF, and it is dangerous.

This must be earthed (grounded). Earthing (grounding) must conform to the requirements of national and local safety regulations and electrical code (NEC section 250, 61140 class 1 and other applicable standards).

Any person who is involved in wiring or inspection of this product shall be fully competent to do the work.

Any person who is involved in wiring or inspection of this product shall be fully competent to do the work. Jse crimp terminals with insulation sleeves to wire the power supply and the

roduct body must be installed before wiring. Otherwise you may get an

This product body must be installed before wiring. Otherwise you may get an electric shock or be injured. 
Do not touch the keys with wet hands. Doing so may cause an electric shock. 
Do not subject the eables to scratches, excessive stress, heavy loads or prinching. 
Doing so may cause an electric shock. 
Do not change the cooling fan while power is ON as it is dangerous to change the 
cooling fan while power is ON. 
Do not touch the printed circuit board or handle the cables with wet hands. Doing 
Do not touch the printed circuit board or handle the cables with wet hands. Doing 
Never touch the motor terminals, etc. right after powering OFF as the DC voltage is applied to the motor for 1 second at powering OFF if the main circuit capacitor 
capacity is measured. Doing so may cause an electric shock.

**↑** CAUTION This product must be installed on a nonflammable wall without holes in it so that its components cannot be touched from behind. Installing it on or near flammable

its components cannot be usuated from the components cannot be used to the components cannot be used to the components cannot cannot be switched OFF. A continuous flow of large current may cause a fire. Do not connect a resistor directly to the DC terminals P/+ and N/-. Doing so could cause a tire,

Across terminals P/+ and PR, connect only an external brake resistor.

Be sure to perform daily and periodic inspections as specified in the Instruction Manual (Maintenance). There is a possibility of explosion, damage, or fire if this product is used without inspection.

- The voltage applied to each terminal must be as specified in the Instruction Manual (Connection). Otherwise an explosion or damage may occur. The cables must be connected to the correct terminals. Otherwise an explosior

## ♦ Additional instructions The following instructions must be also followed. If the product is handled

Transportation and installation

■ Use proper lifting techniques or a trolley when carrying products. Failure to do so may lead to injuries.

■ Do not stack the boxes containing inverters higher than the number

damaged.

If halogens (including fluorine, chlorine, bromine, and iodine) contained in fumigants for wood packages enter this product, the product may be damaged. Prevent the entry of fumigant residuals or use an alternative method such as heat disinfection. Note that sterilization or disinfection of wood packages should be performed before packing the product.

Iflinia

Viring
Do not install a power factor correction capacitor, surge absorber, or radio noise filter on the output side of this product. These devices may overheat or burn out. The output terminals (turninals U, v, and W) must be connected to a motor correctly. Otherwise the motor will rotate inversely.


Even with the power OFF, high voltage is still applied to the terminals U, V and W while the PM motor is running. Ensure the PM motor has stopped before carrying out any wiring. Otherwise you may get an electric shock.

Never connect a PM motor to a commercial power supply. Connecting a commercial power supply to the input terminals (U, V, W) of a PM motor will burn it out. The PM motor must be connected with the output terminals (U, V, W) of this product.

### INVERTER INSTALLATION AND PRECAUTIONS

When installing the inverter on the enclosure surface, remove the front cover and wiring cover to fix the inverter.

Install the inverter on a strong surface securely with screws.



# Allow clearance


10 cm


or more When using the inverters at the surrounding air temperature of 40°C or less, the inverters can be installed closely attached (0 cm clearance).

### **INSTALLATION AND WIRING**

### Removal and reinstallation of covers

# Removal of the front cover





(b) Insert the hooks of the cover into the sockets of the wiring cover, and reinstall the

(c) Tighten the mounting screws of the front cover. (Tightening torque: 0.6 to 0.8

Fit the cover to the inverter along the guides, and push the hook into the socket

Guides

(a) Check the position of the hooks on the rear of the cover

♦ FR-E860-0040(2.2K) or lower

◆ FR-E860-0061(3.7K) or higher

Fit the cover to the inverter along the guides

tallation of the wiring cove


Hook -

(a) Loosen the mounting screws of the cover. (These screws cannot be

(b) Pull out the cover using its lower side as a support. With the cover removed, the control circuit terminals can be wired and the plug-in option can be installed.


♦ FR-E860-0040(2.2K) or lower Removal of the wiring cov







(a) Insert a tool such as a flathead screwdriver into the half-hole above the "PUSH" mark on the wiring cover to push the stopper behind the wiring (b) Pull out the cover along the guides in the direction shown by the arrow in

the figure above.








"PUSH" mark on the wiring cover to push the stopper behind the wiring

(b) Pull out the cover along the guides in the direction shown by the arrow in the figure above.

### 2.2 Main circuit terminal layout and wiring to power supply and motor ◆ Three-phase 575 V class



Make sure the power cables are connected to terminals R/L1, S/L2, and T/L3 (the phases need not be matched). Never connect the power cable to terminals U, V, or W of the inverter. Doing so will

### Applicable cables and wiring length

Select cables of recommended gauge size to ensure that the voltage drop will be 2% or less. If the wiring distance is long between the inverter and motor, the voltage drop in the main circuit will cause the motor torque to decrease especially at a low speed The following table shows a selection example for the wiring length of 20 m at the ND rating. When using the inverter with the LD rating, refer to the FR-E860 Instruction

			0-1			Cable g		
Applicable Inverter	Terminal	Tightening	Crimp terminal		HIV cables,	etc. (mm²) *1	AWG *2	
model	screw size *3	torque N·m	R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W
FR-E860-0017(0.75K)	M4	1	2-4	2-4	2	2	14	14
FR-E860-0027(1.5K)	M4	1	2-4	2-4	2	2	14	14
FR-E860-0040(2.2K)	M4	1	2-4	2-4	2	2	14	14
FR-E860-0061(3.7K)	M4	1	2-4	2-4	2	2	14	14
FR-E860-0090(5.5K)	M4	1	2-4	2-4	2	2	14	14
FR-F860-0120(7.5K)	M4	1	5 5-4	2-4	3.5	2	12	14

\*I HIV cable (600 V grade heat-resistant PVC insulated wire) with a continuous maximum permissible temperature of 75°C. It is assumed that the cables will be used in a surrounding air temperature of 50°C or less and the wiring distance of 20 m or shorter.

2 The summer of the cables will be used in a surrounding air temperature of 40°C or less and the wiring distance of 20 m or shorter. (For use in the United States or Canada, refer to the section 7.2 "Instructions for UL and cUL".)

The line voltage drop can be calculated by the following formula:

Line voltage drop [V] =  $\sqrt{3}$  × wire resistance [m $\Omega$ /m] × wiring distance [m] × current [A] / 1000


Use a larger diameter cable when the wiring distance is long or when it is desired to decrease the voltage drop (torque reduction) in the low speed range

♦ Total wiring length
Connect one or more motors within the total wiring length (sum of the wiring lengths of the motor and the inverter) shown in the following table.

Cable type	(carrier frequency)	voltage class	0.75K	1.5K	2.2K	3.7K	5.5K	7.5K
Unshielded	1 (1 kHz) or lower	575 V	100m	100m	100m	200m	400m	500m
Orioniciaca	2 (2 kHz) or higher	0,01	100m	100m	100m	200m	300m	400m


Use a "600 V class inverter-driven insulation-enhanced motor" and set Pr.72 PWM frequency selection according to the wiring length: "14.5 kHz or less" when the wiring length is 50 m or shorter, "8 kHz or less" when the wiring length is from 50 m to 100 m, or "2 kHz or less" when the wiring length is longer than 100 m.

### Terminal connection diagram




### Details on the main circuit terminals and the control circuit terminals

		R/L1, S/L2, T/L3	_	AC power input	Connected to the commercial power supply.						
1		U, V, W	_	Inverter output	Connected to a three-phase squirrel cage motor or a PM motor.						
	Main circuit	P/+, PR	_	Brake resistor connection	Connect an optional brake resistor across terminals P/+ and PR.						
	<u> </u>	P/+, N/-	-	Brake unit connection	Connect the brake unit.						
:	Ma	P/+, P1	_	DC reactor connection	Remove the jumper across terminals P/ connected, the jumper across terminals						
			_	Earth (ground)	For earthing (grounding) the inverter ch	assis. Be sure to earth (ground) the	ne inverter.				
	nput	DI0 *1	SD (sink (negative common))	Forward rotation start	Turn ON the STF signal to start forward rotation and turn it OFF to stop.	When the STF and STR	Input resistance: 4.7 kΩ Voltage when contacts are open:				
	Contact input	DI1 *1	PC (source (positive common))	Reverse rotation start	Turn ON the STR signal to start reverse rotation and turn it OFF to stop.	signals are turned ON simultaneously, the stop command is given	21 to 26 VDC Current when contacts are short-circuited: 4 to 6 mADC				
		10	5	Power supply for a frequency setting potentiometer	Used as the power supply for an extern setting) potentiometer.	5 ±0.5 VDC, Permissible load current: 10 mA					
Input signal	/ setting	2	5	Frequency setting (voltage)	Inputting 0 to 5 VDC (or 0 to 10 VDC) p frequency at 5 V (or 10 V) and makes in Use Pr.73 to switch among input 0 to 5 VDC, and 0 to 20 mA. * The initial settir specification. Set the voltage/current input switch to the input (0 to 20 mA).	For voltage input, Input resistance: 10 to 11 kO					
	Frequency setting	4	5	Frequency setting (current)	Inputting 4 to 20 mADC (or 0 to 5 VDC, maximum output frequency at 20 mA ar proportional. This input signal is valid or (terminal 2 input is invalid). To use the terminal 4 (current input at in Pr.178 or Pr.179 (input terminal funct ON the AU signal. *The initial setting vs specification. Use Pr.267 to switch among input 4 to 2 VDC, and 0 to 10 VDC. Set the voltage voice in the setting via the voice of the voice of the voltage of voltage input (0 to 5 VDC).	Maximum permissible voltage: 20 VDC For current input, Input resistance: 245 ±5 Ω Permissible maximum current: 30 mA					
Output signal	Relay	A, B, C	_	Relay output (fault output)	1 changeover contact output indicates t function has activated and the outputs a Fault: discontinuity across B and C (con continuity across B and C (discontinuity	Contact capacity: 240 VAC 2 A (power factor = 0.4) or 30 VDC 1 A					



### Control circuit terminal layout



crimp terminals and stripped wire for the control circuit wiring. If only a single wire is used, the wire can be stripped and used without a ferrule.
Connect the end of wires (crimp terminal or stranded wire) to the terminal block.

Crimp terminals commercially available (as of April 2023.)


Crimping too model No. With insulation sleeve insulation sleev AI 1,5-10BK A 1.5-10

### **BASIC OPERATION**

### 3.1 Components of the operation panel The operation panel cannot be removed from the inverter.

	Name	Description
PU MON RUN	PU/EXT key	Switches between the PU operation mode, the PUJOG operation mode, and the External operation mode.
Hz EXT = PRM = PM	MODE key	Switches the operation panel to a different mode.
	SET key	Used to confirm each selection. Switches the monitor screen in the monitor mode.
PU MODE SET NS MS	RUN key	Start command The direction of motor rotation depends on the <b>Pr.40</b> setting.
RUN STOP LINK1 LINK2	STOP/RESET key	Used to stop operation commands. Used to reset the inverter when the protective function is activated.
RESET V = LINK2	UP/DOWN key (↑↓)	Press this key to change the setting of frequency or parameter.

### ◆Starting/stopping the inverter on the operation panel



### 4 PARAMETERS

For details, refer to the FR-E800 Instruction Manual (Function). The PDF manual can also be downloaded from the Mitsubishi Electric FA Global The PDF manual can also be downloaded from the Mitsubishi Electric FA Global

# For details, refer to the FR-E800 Instruction Manual (Maintenance).

Change the setting.





5 LIST OF FAULT DISPLAYS



# **↑** CAUTION

Do not stack the boxes containing inverters higher than the number recommended.
The product must be installed in a position where it withstands the weight of the product according to the information in the Instruction Manual.
Do not install or operate this product if it is damaged or has parts missing.
When carrying this product, do not hold it by the front cover. It may fall or break.
When carrying this product, do not hold it by the front cover. It may fall or break.
Do not install or operate this product is correct.
Prevent conductive objects such as screws, metal fragments, and wire offcuts, or flammable substances such as oil from entering the inverter.
As this product is a precision instrument, do not drop or subject it to impact.
The surrounding air temperature must be between -10°C and +60°C (nonferezing). The rated current must be reduced at a surrounding air temperature for the control of the product is a precision instrument, do not decided in the product is a precision instrument, or other control of the control

transportation time) must be between -40°C and +70°C. Otherwise this product may be damaged. This product must be used indoors (without corrosive gas, flammable gas, oil mist, dust and dirt). Otherwise the product may be damaged. Do not use this product at an altitude above 2000 m. Vibration should not exceen

5.9 m/s<sup>2</sup> at 10 to 55 Hz in X, Y, and Z directions. Otherwise the product may be

Usage

Stay away from the equipment after using the retry function in this product as the equipment will restart suddenly after the output shutoff of this product.

Access to the motor is allowed only after it is fully confirmed that the motor does

Access to the motor is allowed only after it is fully confirmed that the motor does not start nunning.

Depending on the function settings of this product, the product does not stop its output even when the STOP/RESET key on the operation panel is pressed. To prepare for it, provide a separate circuit and switch (to turn OFF the power of this product, or apply a mechanical brake, etc.) for an emergency stop, product, or apply a mechanical brake, etc.) for an emergency stop, and the following the follo

en installing the MC on the output side of the inverter, turn it ON/OFF while he the inverter and motor are at a stop.

It is electronic thermal O/L relay function may not be enough for protection of a tor from overheading. It is recommended to install an external thermal relay or TC thermistor for overhead protection.

To the mistor for overhead protection. To the product of th

shaft, which may cause electrical corrosion of the bearing. Take measures such as decreasing the carrier frequency. As all parameters return to their initial values after Parameter clear or All parameter clear is performed, the parameters must be set again as required before the operation is started. This product can be easily set for high-speed operation. Therefore, consider all things related to the operation such as the performance of a motor and equipment in a system before the setting change. If the machine must not be restarted when power is restored after a power failure, provide an MC on the input side of the inverter and also make up a sequence which will not switch ON the start signal. When performing an inverter operation with frequent starts/stops, rise/fall in the temperature of the transistor element of the inverter will repeat due to a repeated flow of large current, shortening the life. Perform an inspection and test operation of this product if it has been stored for a long period of time.

Perform an inspection and test operation of this product if it has been stored for a long period of time.

To avoid damage to this product due to static electricity, static electricity in your body must be discharged before you touch this product.
Only one PM motor can be connected to a single unit of this product. A PM motor must be used under PM sensorless vector control. Do not use a synchronous motor induction motor, or synchronous induction motor. Do not connect a PM motor to this product with it set to the induction motor borned to the product of PM motor to the product with it set to the induction motor with the product of PM motor to the product with it set to the induction motor with it set to the PM sensorless vector control setting. Doing so will cause failure. As a process of starting a PM motor, turn ON the power of this product first, and then close the contactor on the output side of this product.

To maintain the security (confidentiality, integrity, and availability) of the inverter and the system against unauthorized access, DoS\*1 attacks, computer viruses, and other cyberatlacks from external devices via network, take appropriate measures such as firewalls, virtual private networks (VPNs), and antiviving solutions. We shall have measures such as firewalls, virtual private networks (VPNs), and antiviving solutions. We shall have measures such as firewalls, virtual private networks (VPNs), and antiviving solutions. We shall have the expectation of the product and the motor selection is continued or the retry operation (automatic reset and restart) is repeated even if a fault occurs, which may damage or burn this product and the motor. Before restarting the entry operation after the operation using the emergency drive function, make mergency and the product and the motor. Before restarting the more dependent and the motor have no fault.

\*\*Mergency Stop\*\*

\*\*A safety backup such as an am emergency brake must be provided for devices or and the provided for devices or an emergency brake must be pr

Emergency stop

A safety backup such as an emergency brake must be provided for devices or equipment in a system to prevent hazardous conditions in case of failure of this

oduct must be treated as industrial waste

CAUTION (Retry Function Has) Been Selected

Stay away from the motor and machine They will start suddenly (after given

CAUTION

/ Automatic Restart after Instantaneous Power Failure Has Been Selected They will start suddenly (after reset time has elapsed) when

instantaneous power failure occurs.

time has elapsed) when alarm occurs.

For automatic restart after instantaneous power failure

Application of caution labels

For the retry function

The district of the control of the c

For clarity, illustrations in this Safety Guideline may be drawn with covers or safety guards removed. Ensure all covers and safety guards are properly installe as described in the Instruction Manual (Connection) prior to starting operation.
 For details on the PM motor, refer to the Instruction Manual of the PM motor.

inverters.

Make copies of the following labels and apply them to the inverter if the 
"retry function" and/or "automatic restart after instantaneous power 
failure" have been enabled.

n labels are used to ensure safety during use of Mitsubishi Electric

DoS: A denial-of-service (DoS) attack disrupts services by overloading systems or exploiting vulnerabilities, resulting in a denial-of-service (DoS) state.

### **SPECIFICATIONS**

### 6.1 Inverter rating

### ◆ Three-phase 575 V power supply

				0017	0027	0040	0061	0090	0120			
	Model FR-	·E860-[]	0.75K	1.5K	2.2K	3.7K	5.5K	7.5K				
			LD	1.5	2.2	3.7	5.5	7.5	11.0			
Applica	able motor capa	city (kW) *1	ND	0.75	1.5	2.2	3.7	5.5	7.5			
			LD	2.5	3.6	5.6	8.2	11.0	15.9			
	Rated capac	ity (KVA) ^2	ND	1.7	2.7	4.0	6.1	9.0	12.0			
		LD		2.5	3.6	5.6	8.2	11.0	16.0			
	Rated curr	ent (A) *7		(2.1)	(3.0)	(4.8)	(7.0)	(9.0)	(13.6)			
			ND	1.7	2.7	4.0	6.1	9.0	12.0			
	Output Overload current rating *3				s, 150% 3 ing air tem			acteristics)	at			
Output	·		ND		s, 200% 3 ing air tem			acteristics)	at			
	V	oltage *4		Three-phase 525 to 600 V								
		Brake tran	sistor	Built-in								
	Regenerative braking	Maximum torque ( reference	ND	100%	50%	20%						
	Rated input A	C voltage/free	quency	Three-ph	ase 575 V	60 Hz						
	Permissible A	C voltage fluc	tuation	490 to 632 V, 60 Hz								
	Permissible f	requency fluc	tuation	±5%								
		Without DC	LD	4.3	5.9	8.9	12.4	15.9	22.4			
Power	Rated input	reactor	ND	3.0	4.6	6.6	9.5	13.3	17.4			
supply	current (A) *8	With DC	LD	2.5	3.6	5.6	8.2	11.0	16.0			
		reactor	ND	1.7	2.7	4.0	6.1	9.0	12.0			
	Power supply	Without DC	LD	4.3	5.9	8.9	12.3	16.0	23.0			
	capacity	reactor	ND	3.0	4.6	6.6	9.5	14.0	18.0			
	(kVA) *6	With DC	LD	2.5	3.6	5.6	8.2	11.0	16.0			
		reactor	ND	1.7	2.7	4.0	6.1	9.0	12.0			
P	rotective structu	•	)	Open typ	, ,							
	Cooling	•		Natural	Forced a							
	Approx. m	ass (kg)		1.9	1.9	1.9	2.4	2.4	2.4			

- maximum capacity of a 4-pole standard motor driven by all of the inverters in parallel connection. is that the output voltage is 575 V. urrent rating is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the
- red output capacity assumes that the output votage is o.r.o.v.
  rocentage of the overload current tailing is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the ratures under 100% load.

  aximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range. The maximum point of the voltage waveform at the
- output side of the invertor is approximately the power supply voltage multiplied by \(\tilde{c}\). The amount of briating forque is the average short-term broque (which varies depending on motor loss) that is generated when a motor decolerates in the shortest time by itself from 60 Hz. It is not continuous regenerately torque. The average decoleration torque becomes lower when a motor decolerates from a frequency higher than the base frequency. The inverter is not equipped with a built-in brake resistor. Use a brake resistor for an operation with large regenerative power. A brake unit can be also used.

  The power supply capacity varies with the value of the power supply side impedance (including those of the input reactor and cables). The power supply capacity varies with the value of the power supply side impedance (including those of the input reactor and cables). The power supply capacity varies with the value of the power supply side impedance (including those of the input reactor and cables). The power supply capacity varies with the value of the power supply side impedance (including those of the input reactor and cables). The power supply capacity varies with the value of the power supply side impedance (including those of the input reactor and cables). The power supply capacity varies with the value of the power supply side impedance (including those of the input reactor and cables). The power supply capacity varies with the value of the power supply side impedance (including those of the input reactor and cables). The power supply capacity varies with the value of the power supply side impedance (including the power supply capacity varies with the value of the power supply side impedance (including the power supply capacity varies with the value of the power supply capacity varies with the varies of the power supply capacity varies with the varies of the power supply capacity varies with the varies of the power supply capacity varies with the varies of the power supply capacity varies with the varies o A selection.
  It is a contract the rated output current. The impedance at the power supply side (including those of the input reactor and cables) affects the rated input current.

### Inverter installation environment

Item	Description						
Surrounding air temperature *1	-10°C to +60°C (The rated current must be reduced at a temperature above 50°C. For details, refer to the FR-E860 Instruction Manual (Connection). To meet the UL/EN standards, use the product at temperatures from -10°C to 50°C.)	Enclosure  Inverter Measurement					
Ambient humidity	95% RH or less (non-condensing) (With circuit board coating (IEC 60721-3-3:1994 3C2 compatible)) 90% RH or less (non-condensing) (Without circuit board coating)	position 5 cm 5 cm					
Storage temperature	-40°C to +70°C	Measurement 5 cm position					
Atmosphere	Indoors (free from corrosive gas, flammable gas, oil mist, dust and dirt)	•					
Altitude/vibration Maximum 2000 m, 5.9 m/s <sup>2</sup> or less (For installation at an altitude above 1000 m, consider a 3% reduction in the rated current per 500 m increase in altitude.)							

### 7 APPENDIX

### Instructions for compliance with the EU Directives

- · The authorized representative in the EU
- The authorized representative in the EU is shown below Name: Mitsubishi Electric Europe B.V.
- Address: Mitsubishi-Electric-Platz 1, 40882 Ratingen, Germany

### EMC Directive

- We declare that this inverter conforms with the EMC Directive and affix the CE marking on the inverter. EMC Directive: 2014/30/EU
- Standard: IEC 61800-3 (Category "C3" / Second environment)
- This inverter is not intended to be used on a low-voltage public network which supplies domestic premises. When using the inverter in a residential area, take appropriate mea and ensure the conformity of the inverter used in the residential area.
- Radio frequency interference is expected if used on such a network.

- Set the EMC Directive compliant EMC filter to the inverter. Insert line noise filters and ferrite cores to the power and control cables as required.
- Set the EMC Directive compliant EMC niter to the inverter. Insert line noise internal and territe cores to the power and control values as required.
   Install the motor and controller cable found in the EMC Installation Guidelines (BCN-A21041-204) and Technical News (MF-S-177) according to the instructions. (Contact your sales representative for the manual.)
   To make full use of the EMC Directive compliant noise filter, motor cable lengths should not exceed 20 m.
   Ensure that the finalized system which includes an inverter complies with the EMC Directive.

# ♦ Low Voltage Directive We have self-confirmed our inverters as products compliant to the Low Voltage Directive and affix the CE marking on the inverters. Low Voltage Directive: 2014/35/EU

### Standard: EN 61800-5-1

### Outline of instructions

- Do not use an earth leakage circuit breaker as an electric shock protector without connecting the equipment to the earth. Connect the equipment to the earth (ground)
- Wire the earth terminal independently. (Do not connect two or more cables to one terminal.)
- Select appropriate wire according to EN 60204-1 or IEC 60364-5-52. (Refer to the selection examples of cable sizes in 2.3 Applicable cables and wiring length.)

  Use a tinned (plating should not include zinc) crimping terminal to connect the earth (ground) cable. When tightening the screw, be careful not to damage the threads.

  For use as a product compliant with the Low Voltage Directive, use PVC cables.

- For use as a product compliant with the Low Voltage Directive, use PVC cables.

  Use PVC cables for I/O wiring.

  Use the molded case circuit breaker and magnetic contactor which conform to the EN or IEC Standard.

  If an earth leakage circuit breaker is required, use a type-B earth leakage circuit breaker (AC/DC detection compatible).

  Use the inverter under the conditions of overvoltage category III specified in IEC 60664.

  To use the inverter under the conditions of pollution degree 3, install it in the enclosure of IP54 or higher for protection against electric shock and fire.

  Attach the fan cover to the fan with the fan cover fixing screw enclosed with the inverter.

FR-E860-0017(0.75K) or higher Fan cover fixing screw



If the cover is not fixed, the inverter protective structure is regarded as IP00. Fuse selection for branch circuit protection

### Use the following semiconductor fuses for branch circuit protection

· ·		· ·				
Inverter model	Cat. No	Manufacturer	Rating	Inverter model	Cat. No	Manufacturer
FR-E860-0017(0.75K)	170M1409, 170M1309 or 170M1359	Bussmann	700 V, 16 A	FR-E860-0061(3.7K)	170M1413, 170M1313 or 170M1363	Bussmann
FR-E860-0027(1.5K)	170M1410, 170M1310 or 170M1360	Bussmann	700 V, 20 A	FR-E860-0090(5.5K)	170M1414, 170M1314 or 170M1364	Bussmann
FR-E860-0040(2.2K)	170M1312, 170M1362 or 170M1412	Bussmann	700 V, 32 A	FR-E860-0120(7.5K)	170M1415, 170M1315 or 170M1365	Bussmann

### Motor overload protection For details, refer to 7.2 Instructions for UL and cUL: Motor overload protection

We have declared that our inverters are compliant to the EU RoHS Directive and affix the CE marking on the inverters.

For other information, refer to the FR-E860 Instruction Manual (Connection).

### 7.2 Instructions for UL and cUL

(Standard to comply with: UL 61800-5-1, CSA C22.2 No. 274)

♦ Product handling information / Informations sur la manipulation du produit
-WARNING- Operation of this product requires detailed installation and operation instructions provided in this Safety Guideline and the Instruction Manual (Connection) intended for use with this product. Please forward relevant manuals to the end user. The manuals can also be downloaded in PDF form from the Mitsubishi Electric FA Global Website. To order manuals, please contact your sales representative

L'utilisation de ce produit nécessite des instructions détaillées d'installation et d'utilisation fournies dans le présent document de la Directive de sécurité et le Manuel d'instructions (Connexion) destiné à être utilisé avec ce produit. Veuillez transmettre les manuels correspondants à l'utilisateur final. Les manuels peuvent égale être téléchargés au format PDF sur Mitsubishi Electric FA Global Website. Pour commander des manuels, veuillez contacter votre représentant commercial.

• Branch circuit protection
For installation in the United States, use the branch circuit protection equipment specified in Technical News MF-S-187, in accordance with the National Electrical Code For installation in Canada, use the branch circuit protection equipment specified in Technical News MF-S-187, in accordance with the Canadian Electrical Code and

Short circuit protection of the inverter cannot be used as branch circuit protection. Integral solid state short circuit protection does not provide branch circuit protection

Branch circuit protection must be provided in accordance with the National Electrical Code and any additional local codes. The installation/operation manual is available via the internet at https://www.mitsubishielectric.com/fa/products/dry/inv/support/e800/e800e.html. A hard copy of this information may be ordered at +1 (847) 478-2100 (Mitsubishi Electric Automation, Inc. in USA).

Precautions for opening the branch-circuit protective device /
 Précautions pour ouvrir le dispositif de protection du circuit de dérivation
-WARNING-I fit he fuse melts down or the breaker tips on the input side of this product, check for wiring faults (such as short circuits). Identify and remove the cause of melting down or the trip before replacing the fuse or resetting the tripped breaker (or before applying the power to the inverter again).

Si le fusible fond ou si le disjoncteur se déclenche du côté entrée de ce produit, vérifier les défauts de câblage (tels que les courts-circuits). Identifier et éliminer la cause de la fonte ou du déclenchement avant de remplacer le fusible ou de réinitialiser le disjoncteur déclenché (ou avant de remettre sous tension l'onduleur).

### ♦ Capacitor discharge time / Temps de décharge du condensateur CAUTION - Risk of Electric Shock -

Before wiring or inspection, check that the LED display of the operation panel is OFF. Any person who is involved in wiring or inspection shall wait for 10 minutes or longer after power OFF, and check that there are no residual voltage using a digital multimeter or the like. The capacitor is charged with high voltage for some time after power OFF, and it is dangerous.

ATTENTION - Risque de choc électrique Avant le câblage ou l'inspection, vérifier que le témoin LED s'éteint. Toute personne impliquée dans le câblage ou l'inspection doit attendre 10 minutes ou plus après la mise hors tension et vérifier l'absence de tension résiduelle à l'aide d'un multimètre numérique ou similaire. Le condensateur est chargé avec une haute tension

pendant un certain temps après la mise hors tension, ce qui est dangereux. Précautions pour ouvrir le dispositif de protection du circuit de dérivation


Refer to the National Electrical Code (Article 310) regarding the allowable current of the cable. Select the cable size for 125% of the rated current according to the National Electrical Code (Article 430). For wiring the input (R/L1, S/L2, T/L3) and output (U, V, W) terminals of the inverter, use the UL listed copper, stranded wires (rated at 75°C) and round

The following table shows examples when the inverter rating is the LD rating, when the cable is the THHW cable with continuous maximum permissible temperature of 75°C, when the surrounding air temperature is 30°C or less, and the wiring length is 20 m or shorter.

			Crimp termi	nal	Cable gauge		
Applicable inverter model	Terminal screw size	inal screw size Tightening torque (N·m)		IIai	AWG		
	·	(14)	R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	
FR-E860-0017(0.75K) to 0040(2.2K)	M4	1.5	2-4	2-4	14	14	
FR-E860-0061(3.7K), 0090(5.5K)	M4	1.5	3.5-4	2-4	12	14	
FR-E860-0120(7.5K)	M4	1.5	5.5-4	3.5-4	10	12	

### \*1 The screw size for terminals R/L1, S/L2, T/L3, U, V, W, PR, P/+, N/-, and P1, and the earthing (grounding) terminal is shown. Short circuit ratings 600 V class: Suitable for use in a circuit capable of delivering not more than 100 kA rms symmetrical amperes, 575 V maximum.

♦ Motor overload protection
The following explains the details of the motor overload protection.
When using the electronic thermal relay function as motor overload protection, set the rated motor current in Pr.9 Electronic thermal O/L relay.



the inverter output by stopping the operation of the transistor at the

- 100% constant-torque characteristic in the low-speed range.) Set the rated motor current in Pr.9.

# This function detects the overload (overheat) of the motor and shut off

### inverter output side. (The operation characteristic is shown on the left.) When using the constant-torque motor Set one of "10, 13, 15, 16" in **Pr.71**. (This setting enables the

- When setting Pr.9 to a value (current value) of 50% of the inverter rated output current. The % value denotes the percentage to the inverter rated output current. It is not the percentage to the rated motor current. When the electronic thermal relay function declicated to the constant-torque motor is set, this characteristic curve applies to operation at 6 bit or higher.


### The internal accumulated heat value of the electronic thermal O/L relay is reset to the initial value by the inverter's power reset or reset signal input. Avoid unnecessary reset and


- Install an external thermal relay (OCR) between the inverter and motors to operate several motors, a multi-pole motor or a dedicated motor with one inverter. When configuring a external thermal relay, note that the current indicated on the motor rating plate is affected by the line-to-line leakage current. (Refer to the Instruction Manual (Function).) The cooling effect of the motor drops during low-speed operation. Use a motor with built-in thermal protector. When the difference between the inverter and motor capacities is large and
- the set value is small, the protective characteristics of the electronic thermal relay function will be deteriorated. Use an external thermal relay in such cases. The cooling effect of the motor drops during low-speed operation. Use a motor with built-in thermal protector.

  A dedicated motor cannot be protected by the electronic thermal relay. Use an external thermal relay.
- Motor over temperature sensing is not provided by the drive.
  The electronic thermal memory retention function is not provided by the drive.
  The electronic thermal relay function is not a speed sensing function.

### 7.3 SERIAL number check

The SERIAL number can be checked on the inverter rating plate or package





The last two digits of the production year is indicated as the Year, and the Month is

indicated by 1 to 9, X (October), Y (November), or Z (Decembe

### 7.4 Instructions for EAC

The product certified in compliance with the Eurasian Conformity has the EAC marking.

### Note: EAC marking

In 2010, three countries (Russia, Belarus, and Kazakhstan) established a Customs Union for the purposes of revitalizing the economy by forming a large economic bloc by abolishing or reducing tariffs and unifying regulatory procedures for the handling of articles. Products to be distributed over these three countries of the Customs Union must comply with the Customs Union Technical Regulations (CU-TR), and the EAC marking must be affixed to the products.

For information on the country of origin, manufacture year and month, and authorized sales representative (importer) in the CU area of this product, refer to the

- · Country of origin indication Check the rating plate of the product. Example: MADE IN JAPAN

- Check the SERIAL number indicated on the rating plate of the product
- Authorized sales representative (importer) in the CU area
  - The authorized sales representative (importer) in the CU area is shown below. Name: Mitsubishi Electric Turkey A.S. Head Office Address: Serifali Mahallesi Kale Sokak. No:41 34775 Umraniye, Istanbul, Turkey
  - Fax: +90-216-661-44-47

### Compliance with the UK certification scheme

We declare that this product conforms with the related technical requirements under UK legislation, and affix the UKCA (UK Conformity Assessed) marking on the product.

Approval conditions are the same as those for the EU Directives. Refer to the "7.1 Instructions for compliance with the EU Directives" in the Instruction Manual



UKCA marking:
The UKCA marking is used for products sold in the markets of Great Britain (England, Wales, and Scotland) from January 1, 2021 after the departure of the UK from the

### 7.6 EU ErP Directive (Ecodesign Directive)

The following table shows the power loss data according to Ecodesign Directive. The regulation covers 3-phase variable speed drives from 0.12 kW ≤ Pn ≤ 1 000 kW. (LD rated / ND rated)

odel name	Rated Apparent power	Stand by loss	load point 1 (90;100) (%)	load point 2 (50;100) (%)	load point 3 (0;100) (%)	load point 4 (90;50) (%)	load point 5 (50;50) (%)	load point 6 (0;50) (%)	load point 7 (50;25) (%)	load point 8 (0;25) (%)	IE class
60-0017(0.75K)	2.5 / 1.7	5.7 / 5.7	1.7 / 1.7	1.7 / 2	1.7 / 2	1.2 / 1.4	1.2 / 1.4	1.2 / 1.4	1.0 / 1.2	1.0 / 1.2	IE2
60-0027(1.5K)	3.6 / 2.7	9.8 / 9.8	1.4 / 1.5	1.4 / 1.5	1.4 / 1.5	1.1 / 1.2	1.1 / 1.2	1.1 / 1.2	0.9 / 1.1	0.9 / 1.1	IE2
60-0040(2.2K)	5.6 / 4	9.8 / 9.8	1.3 / 1.4	1.3 / 1.4	1.3 / 1.4	1.0 / 1.0	1.0 / 1.0	1.0 / 1.0	0.8 / 0.9	0.8 / 0.9	IE2
60-0061(3.7K)	8.2 / 6.1	14.5 / 14.5	1.3 / 1.3	1.3 / 1.3	1.3 / 1.3	0.9 / 1.0	0.9 / 1.0	0.9 / 1.0	0.8 / 0.9	0.8 / 0.9	IE2
60-0090(5.5K)	11 / 9	14.5 / 14.5	1.2 / 1.2	1.2 / 1.2	1.2 / 1.2	0.7 / 0.8	0.7 / 0.7	0.7 / 0.7	0.6 / 0.6	0.6 / 0.6	IE2
60-0120(7.5K)	16 / 12	14.5 / 14.5	1.2 / 1.1	1.1 / 1.1	1.1 / 1.1	0.7 / 0.7	0.7 / 0.7	0.7 / 0.7	0.5 / 0.5	0.5 / 0.5	IE2

### Restricted Use of Hazardous Substances in Electronic and Electrical 7.7 Products

The mark of restricted use of hazardous substances in electronic and electrical products is applied to the product as follows based on the "Management Methods fo the Restriction of the Use of Hazardous Substances in Electrical and Electronic Products" of the People's Republic of China. 电器电子产品有害物质限制使用标识要求



本产品中所含有的有害物质的名称、含量、含有部件如下表所示。

### 产品中所含有害物质的名称及含量

	有害物质 *1								
部件名称 *2	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr (VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)			
电路板组件 (包括印刷电路板及其构成的零部件, 如电阻、电容、集成电路、连接器等)、电子部件	×	0	×	0	0	0			
金属壳体、金属部件	X	0	0	0	0	0			
树脂壳体、树脂部件	0	0	0	0	0	0			
螺丝、电线	0	0	0	0	0	0			

- 〇:表示该有害物质在该部件所有均质材料中的含量均在GB/T26572规定的限量要求以下。
- \*: 表示该有害物质在该部件的至少一种均质材料中的含量超出GB/T26572规定的限量要求。
   申 即使表中证数为水、根据产品型外、也可能会有存著物质的含量为限制值以下的情况。
   电报产品型号,一部分部件可能不包含在产品中。
  - Referenced Standard (Requirement of Chinese standardized law)

### This Product is designed and manufactured accordance with following Chinese standards Machinery safety: GB/T 16855.1 GB/T 12668.502

GB 28526 GB/T 12668.3 Electrical safety: GB/T 12668.501

### EMC: GB/T 12668.3 8 WARRANTY

Regardless of the gratis warranty term, Mitsubishi Electric shall not be liable for compensation to: (1) Damages caused by any cause found not to be the responsibility of Mitsubishi Electric

(2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi Electric products (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than

Mitsubishi Electric products. (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.