


# **Motion Controller**



# Q173D(S)CPU/Q172D(S)CPU Motion Controller (SV22) Programming Manual (VIRTUAL MODE)

- -Q172DCPU
- -Q173DCPU
- -Q172DCPU-S1
- -Q173DCPU-S1
- -Q172DSCPU
- -Q173DSCPU





(Please read these instructions before using this equipment.)

Before using this product, please read this manual and the relevant manuals introduced in this manual carefully and pay full attention to safety to handle the product correctly.

These precautions apply only to this product. Refer to the Q173D(S)CPU/Q172D(S)CPU Users manual for a description of the Motion controller safety precautions.

In this manual, the safety instructions are ranked as "DANGER" and "CAUTION".



Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.

Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Depending on circumstances, procedures indicated by CAUTION may also be linked to serious results.

In any case, it is important to follow the directions for usage.

Please save this manual to make it accessible when required and always forward it to the end user.

# For Safe Operations

# 1. Prevention of electric shocks

## **⚠DANGER**

- Never open the front case or terminal covers while the power is ON or the unit is running, as this may lead to electric shocks.
- Never run the unit with the front case or terminal cover removed. The high voltage terminal and charged sections will be exposed and may lead to electric shocks.
- Never open the front case or terminal cover at times other than wiring work or periodic inspections even if the power is OFF. The insides of the Motion controller and servo amplifier are charged and may lead to electric shocks.
- Completely turn off the externally supplied power used in the system before mounting or removing the module, performing wiring work, or inspections. Failing to do so may lead to electric shocks.
- When performing wiring work or inspections, turn the power OFF, wait at least ten minutes, and then check the voltage with a tester, etc. Failing to do so may lead to electric shocks.
- Be sure to ground the Motion controller, servo amplifier and servo motor. (Ground resistance:
   100 Ω or less) Do not ground commonly with other devices.
- The wiring work and inspections must be done by a qualified technician.
- Wire the units after installing the Motion controller, servo amplifier and servo motor. Failing to do so may lead to electric shocks or damage.
- Never operate the switches with wet hands, as this may lead to electric shocks.
- Do not damage, apply excessive stress, place heavy things on or sandwich the cables, as this may lead to electric shocks.
- Do not touch the Motion controller, servo amplifier or servo motor terminal blocks while the power is ON, as this may lead to electric shocks.
- Do not touch the built-in power supply, built-in grounding or signal wires of the Motion controller and servo amplifier, as this may lead to electric shocks.

## 2. For fire prevention

# **∆** CAUTION

- Install the Motion controller, servo amplifier, servo motor and regenerative resistor on incombustible. Installing them directly or close to combustibles will lead to fire.
- If a fault occurs in the Motion controller or servo amplifier, shut the power OFF at the servo amplifier's power source. If a large current continues to flow, fire may occur.
- When using a regenerative resistor, shut the power OFF with an error signal. The regenerative resistor may abnormally overheat due to a fault in the regenerative transistor, etc., and may lead to fire
- Always take heat measures such as flame proofing for the inside of the control panel where the servo amplifier or regenerative resistor is installed and for the wires used. Failing to do so may lead to fire.
- Do not damage, apply excessive stress, place heavy things on or sandwich the cables, as this
  may lead to fire.

## 3. For injury prevention

# **∆** CAUTION

- Do not apply a voltage other than that specified in the instruction manual on any terminal.
   Doing so may lead to destruction or damage.
- Do not mistake the terminal connections, as this may lead to destruction or damage.
- Do not mistake the polarity ( + / ), as this may lead to destruction or damage.
- Do not touch the heat radiating fins of controller or servo amplifier, regenerative resistor and servo motor, etc., while the power is ON and for a short time after the power is turned OFF. In this timing, these parts become very hot and may lead to burns.
- Always turn the power OFF before touching the servo motor shaft or coupled machines, as these parts may lead to injuries.
- Do not go near the machine during test operations or during operations such as teaching.
   Doing so may lead to injuries.

## 4. Various precautions

Strictly observe the following precautions.

Mistaken handling of the unit may lead to faults, injuries or electric shocks.

#### (1) System structure

# **∆**CAUTION

- Always install a leakage breaker on the Motion controller and servo amplifier power source.
- If installation of an electromagnetic contactor for power shut off during an error, etc., is specified in the instruction manual for the servo amplifier, etc., always install the electromagnetic contactor.
- Install the emergency stop circuit externally so that the operation can be stopped immediately and the power shut off.
- Use the Motion controller, servo amplifier, servo motor and regenerative resistor with the correct combinations listed in the instruction manual. Other combinations may lead to fire or faults.
- Use the Motion controller, base unit and motion module with the correct combinations listed in the instruction manual. Other combinations may lead to faults.
- If safety standards (ex., robot safety rules, etc.,) apply to the system using the Motion controller, servo amplifier and servo motor, make sure that the safety standards are satisfied.
- Construct a safety circuit externally of the Motion controller or servo amplifier if the abnormal operation of the Motion controller or servo amplifier differ from the safety directive operation in the system.
- In systems where coasting of the servo motor will be a problem during the forced stop, emergency stop, servo OFF or power supply OFF, use dynamic brakes.
- Make sure that the system considers the coasting amount even when using dynamic brakes.
- In systems where perpendicular shaft dropping may be a problem during the forced stop, emergency stop, servo OFF or power supply OFF, use both dynamic brakes and electromagnetic brakes.

# **∆** CAUTION

- ◆ The dynamic brakes must be used only on errors that cause the forced stop, emergency stop, or servo OFF. These brakes must not be used for normal braking.
- The brakes (electromagnetic brakes) assembled into the servo motor are for holding applications, and must not be used for normal braking.
- The system must have a mechanical allowance so that the machine itself can stop even if the stroke limits switch is passed through at the max. speed.
- Use wires and cables that have a wire diameter, heat resistance and bending resistance compatible with the system.
- Use wires and cables within the length of the range described in the instruction manual.
- The ratings and characteristics of the parts (other than Motion controller, servo amplifier and servo motor) used in a system must be compatible with the Motion controller, servo amplifier and servo motor.
- Install a cover on the shaft so that the rotary parts of the servo motor are not touched during operation.
- There may be some cases where holding by the electromagnetic brakes is not possible due to the life or mechanical structure (when the ball screw and servo motor are connected with a timing belt, etc.). Install a stopping device to ensure safety on the machine side.

#### (2) Security

# **^**CAUTION

■ To maintain the security (confidentiality, integrity, and availability) of the programmable controller and the system against unauthorized access, denial-of-service (DoS) attacks, computer viruses, and other cyberattacks from external devices via the network, take appropriate measures such as firewalls, virtual private networks (VPNs), and antivirus solutions.

#### (3) Parameter settings and programming

# **∆**CAUTION

- Set the parameter values to those that are compatible with the Motion controller, servo amplifier, servo motor and regenerative resistor model and the system application. The protective functions may not function if the settings are incorrect.
- The regenerative resistor model and capacity parameters must be set to values that conform to the operation mode, servo amplifier and servo power supply module. The protective functions may not function if the settings are incorrect.
- Set the mechanical brake output and dynamic brake output validity parameters to values that are compatible with the system application. The protective functions may not function if the settings are incorrect.
- Set the stroke limit input validity parameter to a value that is compatible with the system application. The protective functions may not function if the setting is incorrect.

# **∆** CAUTION

- Set the servo motor encoder type (increment, absolute position type, etc.) parameter to a value that is compatible with the system application. The protective functions may not function if the setting is incorrect.
- Set the servo motor capacity and type (standard, low-inertia, flat, etc.) parameter to values that are compatible with the system application. The protective functions may not function if the settings are incorrect.
- Set the servo amplifier capacity and type parameters to values that are compatible with the system application. The protective functions may not function if the settings are incorrect.
- Use the program commands for the program with the conditions specified in the instruction manual.
- Set the sequence function program capacity setting, device capacity, latch validity range, I/O assignment setting, and validity of continuous operation during error detection to values that are compatible with the system application. The protective functions may not function if the settings are incorrect.
- Some devices used in the program have fixed applications, so use these with the conditions specified in the instruction manual.
- The input devices and data registers assigned to the link will hold the data previous to when communication is terminated by an error, etc. Thus, an error correspondence interlock program specified in the instruction manual must be used.
- Use the interlock program specified in the intelligent function module's instruction manual for the program corresponding to the intelligent function module.

#### (4) Transportation and installation

# **∆** CAUTION

- Transport the product with the correct method according to the mass.
- Use the servo motor suspension bolts only for the transportation of the servo motor. Do not transport the servo motor with machine installed on it.
- Do not stack products past the limit.
- When transporting the Motion controller or servo amplifier, never hold the connected wires or cables.
- When transporting the servo motor, never hold the cables, shaft or detector.
- When transporting the Motion controller or servo amplifier, never hold the front case as it may fall off.
- When transporting, installing or removing the Motion controller or servo amplifier, never hold the edges.
- Install the unit according to the instruction manual in a place where the mass can be withstood.
- Do not get on or place heavy objects on the product.
- Always observe the installation direction.
- Keep the designated clearance between the Motion controller or servo amplifier and control panel inner surface or the Motion controller and servo amplifier, Motion controller or servo amplifier and other devices.

## **⚠** CAUTION

- Do not install or operate Motion controller, servo amplifiers or servo motors that are damaged or that have missing parts.
- Do not block the intake/outtake ports of the Motion controller, servo amplifier and servo motor with cooling fan.
- Do not allow conductive matter such as screw or cutting chips or combustible matter such as oil enter the Motion controller, servo amplifier or servo motor.
- The Motion controller, servo amplifier and servo motor are precision machines, so do not drop or apply strong impacts on them.
- Securely fix the Motion controller, servo amplifier and servo motor to the machine according to the instruction manual. If the fixing is insufficient, these may come off during operation.
- Always install the servo motor with reduction gears in the designated direction. Failing to do so may lead to oil leaks.


Store and use the unit in the following environmental conditions.

- · · ·	Conditions	
Environment	Motion controller/Servo amplifier	Servo motor
Ambient temperature	According to each instruction manual.	0°C to +40°C (With no freezing) (32°F to +104°F)
Ambient humidity	According to each instruction manual.	80% RH or less (With no dew condensation)
Storage temperature	According to each instruction manual.	-20°C to +65°C (-4°F to +149°F)
Atmosphere	Indoors (where not subject to direct sunlight).  No corrosive gases, flammable gases, oil mist or dust must exist	
Altitude	According to each instruction manual	
Vibration	According to each instruction manual	

- When coupling with the synchronous encoder or servo motor shaft end, do not apply impact such as by hitting with a hammer. Doing so may lead to detector damage.
- Do not apply a load larger than the tolerable load onto the synchronous encoder and servo motor shaft. Doing so may lead to shaft breakage.
- When not using the module for a long time, disconnect the power line from the Motion controller or servo amplifier.
- Place the Motion controller and servo amplifier in static electricity preventing vinyl bags and store.
- When storing for a long time, please contact with our sales representative. Also, execute a trial operation.
- When fumigants that contain halogen materials such as fluorine, chlorine, bromine, and iodine are used for disinfecting and protecting wooden packaging from insects, they cause malfunction when entering our products.
  - Please take necessary precautions to ensure that remaining materials from fumigant do not enter our products, or treat packaging with methods other than fumigation (heat method). Additionally, disinfect and protect wood from insects before packing products.

## **⚠** CAUTION

- Correctly and securely wire the wires. Reconfirm the connections for mistakes and the terminal screws for tightness after wiring. Failing to do so may lead to run away of the servo motor.
- After wiring, install the protective covers such as the terminal covers to the original positions.
- Do not install a phase advancing capacitor, surge absorber or radio noise filter (option FR-BIF) on the output side of the servo amplifier.
- Correctly connect the output side (terminal U, V, W) and ground. Incorrect connections will lead the servo motor to operate abnormally.
- Do not connect a commercial power supply to the servo motor, as this may lead to trouble.
- Do not mistake the direction of the surge absorbing diode installed on the DC relay for the control signal output of brake signals, etc. Incorrect installation may lead to signals not being output when trouble occurs or the protective functions not functioning.



For the sink output interface

For the source output interface

- Do not connect or disconnect the connection cables between each unit, the encoder cable or PLC expansion cable while the power is ON.
- Securely tighten the cable connector fixing screws and fixing mechanisms. Insufficient fixing may lead to the cables coming off during operation.
- Do not bundle the power line or cables.

#### (6) Trial operation and adjustment

# **∆**CAUTION

- Confirm and adjust the program and each parameter before operation. Unpredictable movements may occur depending on the machine.
- Extreme adjustments and changes may lead to unstable operation, so never make them.
- When using the absolute position system function, on starting up, and when the Motion controller or absolute position motor has been replaced, always perform a home position return.
- Before starting test operation, set the parameter speed limit value to the slowest value, and make sure that operation can be stopped immediately by the forced stop, etc. if a hazardous state occurs.

#### (7) Usage methods

## **∆** CAUTION


- Immediately turn OFF the power if smoke, abnormal sounds or odors are emitted from the Motion controller, servo amplifier or servo motor.
- Always execute a test operation before starting actual operations after the program or parameters have been changed or after maintenance and inspection.
- Do not attempt to disassemble and repair the units excluding a qualified technician whom our company recognized.
- Do not make any modifications to the unit.
- Keep the effect or electromagnetic obstacles to a minimum by installing a noise filter or by using wire shields, etc. Electromagnetic obstacles may affect the electronic devices used near the Motion controller or servo amplifier.
- When using the CE Mark-compliant equipment, refer to the User's manual for the Motion controllers and refer to the corresponding EMC guideline information for the servo amplifiers, inverters and other equipment.
- Use the units with the following conditions.

Item	Conditions
Input power	According to each instruction manual.
Input frequency	According to each instruction manual.
Tolerable momentary power failure	According to each instruction manual.

#### (8) Corrective actions for errors

# **∆**CAUTION

- If an error occurs in the self diagnosis of the Motion controller or servo amplifier, confirm the check details according to the instruction manual, and restore the operation.
- If a dangerous state is predicted in case of a power failure or product failure, use a servo motor with electromagnetic brakes or install a brake mechanism externally.
- Use a double circuit construction so that the electromagnetic brake operation circuit can be operated by emergency stop signals set externally.



- If an error occurs, remove the cause, secure the safety and then resume operation after alarm release.
- The unit may suddenly resume operation after a power failure is restored, so do not go near the machine. (Design the machine so that personal safety can be ensured even if the machine restarts suddenly.)

## **⚠** CAUTION

- Perform the daily and periodic inspections according to the instruction manual.
- Perform maintenance and inspection after backing up the program and parameters for the Motion controller and servo amplifier.
- Do not place fingers or hands in the clearance when opening or closing any opening.
- Periodically replace consumable parts such as batteries according to the instruction manual.
- Do not touch the lead sections such as ICs or the connector contacts.
- Before touching the module, always touch grounded metal, etc. to discharge static electricity from human body. Failure to do so may cause the module to fail or malfunction.
- Do not directly touch the module's conductive parts and electronic components. Touching them could cause an operation failure or give damage to the module.
- Do not place the Motion controller or servo amplifier on metal that may cause a power leakage or wood, plastic or vinyl that may cause static electricity buildup.
- Do not perform a megger test (insulation resistance measurement) during inspection.
- When replacing the Motion controller or servo amplifier, always set the new module settings correctly.
- When the Motion controller or absolute value motor has been replaced, carry out a home position return operation using one of the following methods, otherwise position displacement could occur.
  - 1) After writing the servo data to the Motion controller using programming software, switch on the power again, then perform a home position return operation.
  - 2) Using the backup function of the programming software, load the data backed up before replacement.
- After maintenance and inspections are completed, confirm that the position detection of the absolute position detector function is correct.
- Do not drop or impact the battery installed to the module.
   Doing so may damage the battery, causing battery liquid to leak in the battery. Do not use the dropped or impacted battery, but dispose of it.
- Do not short circuit, charge, overheat, incinerate or disassemble the batteries.
- The electrolytic capacitor will generate gas during a fault, so do not place your face near the Motion controller or servo amplifier.
- The electrolytic capacitor and fan will deteriorate. Periodically replace these to prevent secondary damage from faults. Replacements can be made by our sales representative.
- Lock the control panel and prevent access to those who are not certified to handle or install electric equipment.
- Do not burn or break a module and servo amplifier. Doing so may cause a toxic gas.

#### (10) About processing of waste

When you discard Motion controller, servo amplifier, a battery (primary battery) and other option articles, please follow the law of each country (area).

## **⚠**CAUTION

- This product is not designed or manufactured to be used in equipment or systems in situations that can affect or endanger human life.
- When considering this product for operation in special applications such as machinery or systems used in passenger transportation, medical, aerospace, atomic power, electric power, or submarine repeating applications, please contact your nearest Mitsubishi Electric sales representative.
- Although this product was manufactured under conditions of strict quality control, you are strongly advised to install safety devices to forestall serious accidents when it is used in facilities where a breakdown in the product is likely to cause a serious accident.

#### (11) General cautions

• All drawings provided in the instruction manual show the state with the covers and safety partitions removed to explain detailed sections. When operating the product, always return the covers and partitions to the designated positions, and operate according to the instruction manual.

#### **REVISIONS**

\* The manual number is given on the bottom left of the back cover.

	<u> </u>	* The manual number is given on the bottom left of the back cover.
Print Date	* Manual Number	Revision
Sep., 2007	IB(NA)-0300137-A	First edition
Nov., 2009	IB(NA)-0300137-B	[Additional model]  MR-J3W-□B, MR-J3-□B-RJ080W, MR-J3-□BS  [Additional correction/partial correction]
		Safety precautions, About Manuals, Restrictions by the software's version or serial number, Servo amplifier display servo error code (#8008+20), Amplifier-less operation status flag (SM508), SSCNET control (Status_SD508), SSCNET control (Command_SD803), Advanced S-curve acceleration/deceleration, Error code list, Warranty
Sep., 2011	IB(NA)-0300137-C	[Additional model] Q173DCPU-S1, Q172DCPU-S1, GX Works2, MR Configurator2 [Additional correction/partial correction] Safety precautions, About Manuals, Restrictions by the software's version, Error code list
Mar., 2012	IB(NA)-0300137-D	[Additional model] Q173DSCPU, Q172DSCPU, Q171ENC-W8, MR-J4-□B, MR-J4W-□B [Additional function] Speed-torque control [Additional correction/partial correction] About Manuals, Manual page organization, Restrictions by the software's version, Programming software version, PI-PID switching command (M3217+20n), Parameter error number (#8009+20n), Servo status 1 (#8010+20n), Servo status 2 (#8011+20n), Servo status 3 (#8012+20n), Maximum motion operation cycle (SD524), System setting error information (SD550, SD551), Error code list, Processing time of the Motion CPU
Sep., 2012	IB(NA)-0300137-E	[Additional correction/partial correction] About Manuals, Restrictions by the software's version, Programming software version, External forced stop input ON latch flag (SM506), Operation method (SD560), Error code list, Processing time of the Motion CPU
Apr., 2013	IB(NA)-0300137-F	[Additional correction/partial correction] About Manuals, Restrictions by the software's version, Error code list
Nov., 2013	IB(NA)-0300137-G	[Additional correction/partial correction] Safety precautions, Restrictions by the software's version, Error code list
Dec., 2015	IB(NA)-0300137-H	[Additional correction/partial correction] Restrictions by the software's version, Servo status7 (#8018+20n), Error codes stored using the Motion CPU, Warranty
Mar., 2017	IB(NA)-0300137-J	[Additional correction/partial correction] Safety precautions, Restrictions by the software's version, Error code list, Warranty
Dec., 2019	IB(NA)-0300137-K	[Additional correction/partial correction] Servo status1 (#8010+20n)
Apr., 2022	IB(NA)-0300137-L	[Additional model] MR-J5-□B, MR-J5W-□B [Additional correction/partial correction] Safety precautions, About Manuals, Restrictions by the software's version, Gain changing 2 command (M3206+20n), Servo status5 (#8014+20n), Error code list, Warranty

Print Date	* Manual Number	Revision
Dec., 2023	IB(NA)-0300137-M	

Japanese Manual Number IB(NA)-0300129

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

#### INTRODUCTION

Thank you for choosing the Mitsubishi Electric Motion controller Q173D(S)CPU/Q172D(S)CPU. Before using the equipment, please read this manual carefully to develop full familiarity with the functions and performance of the Motion controller you have purchased, so as to ensure correct use.

#### CONTENTS

Safety Precautions	A- 1
Revisions	A-11
Contents	A-13
About Manuals	A-16
Manual Page Organization	A-19
1. OVERVIEW	1- 1 to 1-12
1.1 Overview	1- 1
1.2 Motion Control in SV13/SV22 Real Mode	1- 4
1.3 Motion Control in SV22 Virtual Mode	1- 5
1.4 Restrictions by the Software's Version	1- 6
1.5 Programming Software Version	1-12
2. STARTING UP THE SYSTEM	2- 1 to 2- 8
2.1 Starting Up the Virtual Mode System	2- 1
2.2 Starting Up the Incremental System and Absolute System	2- 3
2.2.1 Operation for incremental system	2- 3
2.2.2 Operation for absolute (absolute position) system	2- 4
2.3 Differences Between Real Mode and Virtual Mode	
2.3.1 Positioning data	2- 5
2.3.2 Positioning devices	2- 5
2.3.3 Servo programs	2- 6
2.3.4 Control change (Current value change/speed change/target position change)	2- 7
2.3.5 Switching of control mode (Speed-torque control)	2- 8
3. PERFORMANCE SPECIFICATIONS	3- 1 to 3- 2
4. POSITIONING DEDICATED SIGNALS	4- 1 to 4-92
4.1 Internal Relays	4- 3
4.1.1 Axis statuses	
4.1.2 Axis command signals	4-23
4.1.3 Virtual servo motor axis statuses	
4.1.4 Virtual servo motor axis command signals	4-32
4.1.5 Synchronous encoder axis statuses	4-37
4.1.6 Synchronous encoder axis command signals	4-38
4.1.7 Common devices	4-39
4.2 Data Registers	4-54

4.2.1 Axis monitor devices	4-62
4.2.2 Control change registers	4-64
4.2.3 Virtual servo motor axis monitor devices	4-65
4.2.4 Current value after virtual servo motor axis main shaft's differential gear	4-67
4.2.5 Synchronous encoder axis monitor devices	
4.2.6 Current value after synchronous encoder axis main shaft's differential gear	
4.2.7 Cam axis monitor devices	
4.2.8 Common devices	
4.3 Motion Registers (#)	4-76
4.4 Special Relays (SM)	
4.5 Special Registers (SD)	
5. MECHANICAL SYSTEM PROGRAM	5- 1 to 5-10
5.1 Mechanical Module Connection Diagram	5- 2
5.2 Mechanical Module List	5- 6
6. DRIVE MODULE	6- 1 to 6-22
6.1 Virtual Servo motor	6- 2
6.1.1 Operation description	6- 2
6.1.2 Parameter list	6- 8
6.1.3 Virtual servo motor axis devices (Internal relays, data registers)	6-13
6.2 Synchronous Encoder	6-14
6.2.1 Operation description	6-14
6.2.2 Parameter list	6-18
6.2.3 Synchronous encoder axis devices (Internal relays, data registers)	6-19
6.3 Virtual Servo motor/Synchronous Encoder Control Change	6-20
6.3.1 Virtual servo motor control change	6-20
6.3.2 Synchronous encoder control change	6-22
7. TRANSMISSION MODULE	7- 1 to 7-38
7.4 Coor	7.0
7.1 Gear	
7.1.1 Operation	
7.1.2 Parameters	
7.2 Clutch	
7.2.1 Operation	
7.2.2 Parameters	
7.3 Speed Change Gear	
7.3.1 Operation	
7.3.2 Parameters	
7.4 1 Operation	
7.4.1 Operation	
7.4.2 Parameters	1-31
8. OUTPUT MODULE	8- 1 to 8-42
8.1 Rollers	8- 5
8.1.1 Operation	8 5

8.1.2 Parameter list	8- 6
8.2 Ball Screw	8- 9
8.2.1 Operation	8- 9
8.2.2 Parameter list	8-10
8.3 Rotary Tables	8-13
8.3.1 Operation	8-13
8.3.2 Parameter list	8-14
8.4 Cam	8-21
8.4.1 Operation	8-22
8.4.2 Settings items at cam data creating	8-26
8.4.3 Parameter list	
8.4.4 Cam curve list	
8.5 Phase Compensation Function	
•	
9. REAL MODE/VIRTUAL MODE SWITCHING AND STOP/RE-START	9- 1 to 9-12
9.1 Switching from the Real Mode to Virtual Mode	
9.2 Switching from the Virtual Mode to Real Mode	9- 5
9.2.1 Switching by user	9- 5
9.2.2 Switching by the operating system software	9- 5
9.2.3 Continuous operation on servo error in virtual mode	9- 6
9.3 Precautions at Real Mode/Virtual Mode Switching	9- 7
9.4 Stop and Re-start	9- 9
9.4.1 Stop operation/stop causes during operation and re-starting operation list	9-10
10. AUXILIARY AND APPLIED FUNCTIONS	10- 1 to 10-10
10.1 Mixed Function of Virtual Mode/Real Mode	
10.2 Speed-Torque Control	10- 7
ADDENDICEC	ADD 44- ADD 400
APPENDICES	APP- 1 to APP-103
APPENDIX 1 Error Codes Stored Using the Motion CPU	APP- 1
APPENDIX 1.1 Expression method for word data axis No	
APPENDIX 1.2 Related systems and error processing	
APPENDIX 1.3 Servo program setting errors (Stored in SD517)	
APPENDIX 1.4 Drive module errors	
APPENDIX 1.4 Drive module enois	
APPENDIX 1.5 Servo errors	
APPENDIX 1.7 Errors at real mode/virtual mode switching	
APPENDIX 2 Setting Range for Indirect Setting Devices	
APPENDIX 3 Processing Times of the Motion CPU	
APPENDIX 4 Device List	APP-85

## **About Manuals**

The following manuals are also related to this product.

When necessary, order them by quoting the details in the tables below.

## Related Manuals

## (1) Motion controller

Manual Name	Manual Number (Model Code)
Q173D(S)CPU/Q172D(S)CPU Motion controller User's Manual	
This manual explains specifications of the Motion CPU modules, Q172DLX Servo external signal interface	IB-0300133
module, Q172DEX Synchronous encoder interface module, Q173DPX Manual pulse generator interface	(1XB927)
module, Power supply modules, Servo amplifiers, SSCNETⅢ cables and Synchronous encoder, and the	
maintenance/inspection for the system, trouble shooting and others.	
Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)	ID 0200424
This manual explains the Multiple CPU system configuration, performance specifications, common	IB-0300134 (1XB928)
parameters, auxiliary/applied functions, error lists and others.	(.7.2020)
Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (Motion SFC)	IB-0300135 (1XB929)
This manual explains the functions, programming, debugging, error lists for Motion SFC and others.	(17,0020)
Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)	IB-0300136 (1XB930)
This manual explains the servo parameters, positioning instructions, device lists, error lists and others.	(17.2000)
Q173D(S)CPU/Q172D(S)CPU Motion controller (SV22) Programming Manual (VIRTUAL MODE)	
This manual explains the dedicated instructions to use the synchronous control by virtual main shaft,	IB-0300137 (1XB931)
mechanical system program create mechanical module, servo parameters, positioning instructions, device	(170931)
lists, error lists and others.	
Q173DSCPU/Q172DSCPU Motion controller (SV22) Programming Manual (Advanced Synchronous Control)	IB-0300198
This manual explains the dedicated instructions to use the synchronous control by synchronous control	(1XB953)
parameters, device lists, error lists and others.	
Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (Safety Observation)	
This manual explains the details, safety parameters, safety sequence program instructions, device lists	IB-0300183 (1XB945)
and error lists and others for safety observation function by Motion controller.	(1/10040)
Motion controller Setup Guidance (MT Developer2 Version1)	
This manual explains the items related to the setup of the Motion controller programming software MT Developer2.	IB-0300142 ( — )

## (2) PLC

Manual Name	Manual Number (Model Code)
QCPU User's Manual (Hardware Design, Maintenance and Inspection)  This manual explains the specifications of the QCPU modules, power supply modules, base units, extension cables, memory card battery, and the maintenance/inspection for the system, trouble shooting, error codes and others.	SH-080483ENG (13JR73)
QnUCPU User's Manual (Function Explanation, Program Fundamentals)  This manual explains the functions, programming methods and devices and others to create programs with the QCPU.	SH-080807ENG (13JZ27)
QCPU User's Manual (Multiple CPU System)  This manual explains the Multiple CPU system overview, system configuration, I/O modules, communication between CPU modules and communication with the I/O modules or intelligent function modules.	SH-080485ENG (13JR75)
QnUCPU User's Manual (Communication via Built-in Ethernet Port)  This manual explains functions for the communication via built-in Ethernet port of the CPU module.	SH-080811ENG (13JZ29)
MELSEC-Q/L Programming Manual (Common Instruction)  This manual explains how to use the sequence instructions, basic instructions, application instructions and micro computer program.	SH-080809ENG (13JW10)
MELSEC-Q/L/QnA Programming Manual (PID Control Instructions)  This manual explains the dedicated instructions used to exercise PID control.	SH-080040 (13JF59)
MELSEC-Q/L/QnA Programming Manual (SFC)  This manual explains the system configuration, performance specifications, functions, programming, debugging, error codes and others of MELSAP3.	SH-080041 (13JF60)
I/O Module Type Building Block User's Manual  This manual explains the specifications of the I/O modules, connector, connector/terminal block conversion modules and others.	SH-080042 (13JL99)
MELSEC-L SSCNETII/H Head Module User's Manual  This manual explains specifications of the head module, procedures before operation, system configuration, installation, wiring, settings, and troubleshooting.	SH-081152ENG (13JZ78)

## (3) Servo amplifier

Manual Name	Manual Number (Model Code)
MR-J5-B/MR-J5W-B User's Manual (Introduction)  This manual explains the specifications, functions, start-up procedure and others for AC Servo MR-J5-B/MR-J5W-B Servo amplifier.	IB-0300578ENG ( — )
MR-J5 User's Manual (Hardware)  This manual explains the installation, wiring, use option and others for AC Servo MR-J5-B/MR-J5W-B Servo amplifier.	SH-030298ENG ( — )
MR-J5 User's Manual (Function)  This manual explains how to use each function required to operate the AC Servo MR-J5-B/MR-J5W-B Servo amplifier.	SH-030300ENG ( — )
MR-J5 User's Manual (Adjustment)  This manual explains the operation status adjustment procedure, adjustment method and others for AC Servo MR-J5-B/MR-J5W-B Servo amplifier.	SH-030306ENG ( — )
MR-J5 User's Manual (Troubleshooting)  This manual explains the causes of alarms, and warnings, etc. for AC Servo MR-J5-B/MR-J5W-B Servo amplifier.	SH-030312ENG ( — )
MR-J5-B/MR-J5W-B User's Manual (Parameters)  This manual explains the parameters for AC Servo MR-J5-B/MR-J5W-B Servo amplifier.	IB-0300581ENG ( — )
SSCNETII/H Interface AC Servo MR-J4B_(-RJ) Servo amplifier Instruction Manual This manual explains the I/O signals, parts names, parameters, start-up procedure and others for AC Servo MR-J4B_(-RJ) Servo amplifier.	SH-030106 (1CW805)
SSCNETII/H Interface Multi-axis AC Servo MR-J4W2B/MR-J4W3B/MR-J4W2-0303B6 Servo amplifier Instruction Manual This manual explains the I/O signals, parts names, parameters, start-up procedure and others for Multi-axis AC Servo MR-J4W2B/MR-J4W3B/MR-J4W2-0303B6 Servo amplifier.	SH-030105 (1CW806)
SSCNETII interface MR-J3-□B Servo amplifier Instruction Manual  This manual explains the I/O signals, parts names, parameters, start-up procedure and others for MR-J3-□B Servo amplifier.	SH-030051 (1CW202)
SSCNETII interface 2-axis AC Servo Amplifier MR-J3W-0303BN6/MR-J3W-\B Servo amplifier Instruction Manual  This manual explains the I/O signals, parts names, parameters, start-up procedure and others for 2-axis AC Servo Amplifier MR-J3W-0303BN6/MR-J3W-\B Servo amplifier.	SH-030073 (1CW604)
SSCNETII Compatible Linear Servo MR-J3-□B-RJ004U□ Instruction Manual  This manual explains the I/O signals, parts names, parameters, start-up procedure and others for Linear Servo MR-J3-□B-RJ004U□ Servo amplifier.	SH-030054 (1CW943)
SSCNETII Compatible Fully Closed Loop Control MR-J3-□B-RJ006 Servo amplifier Instruction Manual  This manual explains the I/O signals, parts names, parameters, start-up procedure and others for Fully Closed Loop Control MR-J3-□B-RJ006 Servo amplifier.	SH-030056 (1CW304)
SSCNETII Interface Direct Drive Servo MR-J3-□B-RJ080W Instruction Manual  This manual explains the I/O signals, parts names, parameters, start-up procedure and others for Direct  Drive Servo MR-J3-□B-RJ080W Servo amplifier.	SH-030079 (1CW601)

Manual Name	Manual Number (Model Code)
SSCNETⅢ interface Drive Safety integrated MR-J3-□B Safety Servo amplifier Instruction Manual	SH-030084
This manual explains the I/O signals, parts names, parameters, start-up procedure and others for safety integrated MR-J3-□B Safety Servo amplifier.	(1CW205)
SSCNETII/H interface AC Servo MR-JEB Servo amplifier Instruction Manual  This manual explains the I/O signals, parts names, parameters, start-up procedure and others for MR-JE-□B Servo amplifier.	SH-030152ENG ( — )
SSCNETII/H interface AC Servo With functional safety MR-JEBF Servo amplifier Instruction Manual  This manual explains the I/O signals, parts names, parameters, start-up procedure and others for MR-JE-□BF Servo amplifier.	SH-030258ENG ( — )

## Manual Page Organization

The symbols used in this manual are shown below.

Symbol	Description
QDS(	Symbol that indicates correspondence to only Q173DSCPU/Q172DSCPU.
QD	Symbol that indicates correspondence to only Q173DCPU(-S1)/Q172DCPU(-S1).

MEMO			

## 1. OVERVIEW

#### 1.1 Overview

This programming manual describes the dedicated instructions, positioning control parameters and positioning dedicated devices for mechanical system program comprised of a virtual main shaft or mechanical module required to execute the synchronous control in the Motion controller (SV22 virtual mode).

The following positioning control is possible in the Motion controller (SV22 virtual mode).

Applicable CPU	Number of positioning control axes
Q173DSCPU	
Q173DCPU (-S1)	Up to 32 axes
Q172DSCPU	Up to 16 axes
Q172DCPU (-S1)	Up to 8 axes

#### In this manual, the following abbreviations are used.

in this mandal, the following appreviations are used.				
Generic term/Abbreviation	Description			
Q173D(S)CPU/Q172D(S)CPU or	Q173DSCPU/Q172DSCPU/Q173DCPU/Q172DCPU/Q173DCPU-S1/			
Motion CPU (module)	Q172DCPU-S1 Motion CPU module			
	Q172DLX Servo external signals interface module/			
Q172DLX/Q172DEX/Q173DPX/	Q172DEX Synchronous encoder interface module <sup>(Note-1)</sup> /			
Q173DSXY or Motion module	Q173DPX Manual pulse generator interface module/			
	Q173DSXY Safety signal module			
MR-J5(W)-□B	Servo amplifier model MR-J5-□B/MR-J5W-□B			
MR-J4(W)-□B	Servo amplifier model MR-J4-□B/MR-J4W-□B			
MR-J3(W)-□B	Servo amplifier model MR-J3-□B/MR-J3W-□B			
MR-JE-□B	Servo amplifier model MR-JE-□B/MR-JE-□BF			
AMD - Common constitution	General name for "Servo amplifier model MR-J5-□B/MR-J5W-□B/MR-J4-□B/			
AMP or Servo amplifier	MR-J4W-□B/MR-J3-□B/MR-J3W-□B/MR-JE-□B/MR-JE-□BF"			
QCPU, PLC CPU or PLC CPU module	QnUD(E)(H)CPU/QnUDVCPU			
Multiple CPU system or Motion system	Abbreviation for "Multiple PLC system of the Q series"			
OBU	Abbreviation for "CPU No.n (n= 1 to 4) of the CPU module for the Multiple CPU			
CPUn	system"			
Operating system software	General name for "SW7DNC-SV□Q□/SW8DNC-SV□Q□"			
CV42	Operating system software for conveyor assembly use (Motion SFC) :			
SV13	SW8DNC-SV13Q□			
SV22	Operating system software for automatic machinery use (Motion SFC):			
5V22	SW8DNC-SV22Q□			
Programming software package	General name for MT Developer2/GX Works2/GX Developer/MR Configurator□			
NAT Marks O	Abbreviation for "Motion controller engineering environment MELSOFT			
MT Works2	MT Works2"			
MT Developer2 <sup>(Note-2)</sup>	Abbreviation for "Motion controller programming software MT Developer2			
ivi i Developeiz.	(Version 1.00A or later)"			
CV Morko?	Abbreviation for "Programmable controller engineering software			
GX Works2	MELSOFT GX Works2 (Version 1.15R or later)"			
CV Davidanas	Abbreviation for "MELSEC PLC programming software package			
GX Developer	GX Developer (Version 8.48A or later)"			

## 1 OVERVIEW

Generic term/Abbreviation	Description		
MR Configurator□ <sup>(Note-2)</sup>	General name for "MR Configurator/MR Configurator2"		
MP Configurator	Abbreviation for "Servo setup software package		
MR Configurator	MR Configurator (Version C0 or later)"		
MR Configurator2	Abbreviation for "Servo setup software package		
WIN Cornigulator2	MR Configurator2 (Version 1.01B or later)"		
Manual pulse generator or MR-HDP01	Abbreviation for "Manual pulse generator (MR-HDP01)"		
Serial absolute synchronous encoder	Abbreviation for "Serial absolute synchronous encoder (Q171ENC-W8/		
or Q171ENC-W8/Q170ENC	Q170ENC)"		
SSCNETII/H(Note-3)	High annual armshuanarra mahrrayli hatira an Matian anntuallar and a mra ansulifian		
SSCNETⅢ <sup>(Note-3)</sup>	High speed synchronous network between Motion controller and servo amplifier		
SSCNETII(/H)(Note-3)	General name for SSCNETⅢ/H, SSCNETⅢ		
Abacluta position quatem	General name for "system using the servo motor and servo amplifier for absolute		
Absolute position system	position"		
Battery holder unit	Battery holder unit (Q170DBATC)		
Intelligent function module	General name for module that has a function other than input or output such as		
Intelligent function module	A/D converter module and D/A converter module.		
SSCNETⅢ/H head module	Abbreviation for "MELSEC-L series SSCNETII/H head module (LJ72MS15)"		
Optical hub unit or MR-MV200	Abbreviation for "SSCNETIII/H compatible optical hub unit (MR-MV200)"		

(Note-1): Q172DEX can be used in SV22.

(Note-2): This software is included in Motion controller engineering environment "MELSOFT MT Works2".

(Note-3): SSCNET:  $\underline{S}$ ervo  $\underline{S}$ ystem  $\underline{C}$ ontroller  $\underline{NET}$ work

## REMARK

For information about each module, design method for program and parameter, refer to the following manuals relevant to each module.

	Item	Reference Manual
Motion CPU mo	dule/Motion unit	Q173D(S)CPU/Q172D(S)CPU Motion controller User's Manual
	heral devices for sequence program design, d intelligent function module	Manual relevant to each module
Operation meth	od for MT Developer2	Help of each software
	<ul> <li>Multiple CPU system configuration</li> <li>Performance specification</li> <li>Design method for common parameter</li> <li>Auxiliary and applied functions (common)</li> </ul>	Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)
	<ul> <li>Design method for Motion SFC program</li> <li>Design method for Motion SFC parameter</li> <li>Motion dedicated PLC instruction</li> </ul>	Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (Motion SFC)
SV13/SV22	<ul> <li>Design method for positioning control program in the real mode</li> <li>Design method for positioning control parameter</li> </ul>	Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)
	<ul> <li>Design method for safety observation parameter</li> <li>Design method for user made safety sequence program</li> </ul>	Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (Safety Observation)
SV22		
(Advanced	Design method for synchronous control	Q173DSCPU/Q172DSCPU Motion controller (SV22)
synchronous control)	parameter	Programming Manual (Advanced Synchronous Control)


# **∆**CAUTION

- When designing the system, provide external protective and safety circuits to ensure safety in the event of trouble with the Motion controller.
- There are electronic components which are susceptible to the effects of static electricity mounted on the printed circuit board. When handling printed circuit boards with bare hands you must ground your body or the work bench.
  - Do not touch current-carrying or electric parts of the equipment with bare hands.
- Make parameter settings within the ranges stated in this manual.
- Use the program instructions that are used in programs in accordance with the conditions stipulated in this manual.
- Some devices for use in programs have fixed applications: they must be used in accordance with the conditions stipulated in this manual.

#### 1.2 Motion Control in SV13/SV22 Real Mode

- (1) System with servo motor is controlled directly using the servo program in (SV13/SV22) real mode.
- (2) Setting of the positioning parameter and creation of the servo program/Motion SFC program are required.
- (3) The procedure of positioning control is shown below:
  - Motion SFC program is requested to start using the D(P). SFCS instruction of the sequence program.
     (Motion SFC program can also be started automatically by parameter setting.)
  - Execute the positioning control using the specified Motion SFC program.
     (Output to the servo amplifier)
  - 3) The servo motor is controlled.


#### Program structure in SV13/SV22 real mode



#### 1.3 Motion Control in SV22 Virtual Mode

- (1) Synchronous control with software is performed using the mechanical system program comprised by virtual main shaft and mechanical module in (SV22) virtual mode.
- (2) Mechanical system programs is required in addition to the positioning parameter, servo program/Motion SFC program used in real mode.
- (3) The procedure of positioning control in virtual mode is shown below:
  - Motion SFC program for virtual mode is requested to start using the D(P). SFCS instruction of the sequence program.
     (Motion SFC program can also be started automatically by parameter setting.)
  - 2) The virtual servo motor of the mechanical system program is started.
  - 3) Output the operation result obtained through the transmission module to the servo amplifier set as the output module.
  - 4) The servo motor is controlled.

Program structure in SV22 virtual mode



## 1.4 Restrictions by the Software's Version

There are restrictions in the function that can be used by the version of the operating system software and programming software.

The combination of each version and a function is shown in Table1.1.

Table 1.1 Restrictions by the Software's Version

	•		
	Operating system softw		
Function	Q173DSCPU/Q172DSCPU	Q173DCPU(-S1)/Q172DCPU(-S1)	
Checking Motion controller's serial number and operating		00D	
system software version in GX Developer	_	OOD	
Advanced S-curve acceleration/deceleration			
(Except constant-speed control (CPSTART) of servo	_	00H	
program.)			
Direct drive servo		00H	
MR-J3-□B-RJ080W	_	ООН	
Servo amplifier display servo error code (#8008+20n)	_	00H	
0.44ms fixed-cycle event task		00H	
444µs coasting timer (SD720, SD721)	_	00H	
Synchronous encoder current value monitor in real mode	_	00Н	
Display of the past ten times history in current value history monitor	_	00H	
Amplifier-less operation	_	00H	
Servo instruction (Home position return (ZERO), high speed			
oscillation (OSC)) and manual pulse generator operation in	_	00H	
mixed function of virtual mode/real mode			
Advanced S-curve acceleration/deceleration in constant-	_	00K	
speed control (CPSTART) of servo program.			
External input signal (DOG) of servo amplifier in home		200	
position return of count method and speed-position switching	_	00G	
control		00H	
Communication via PERIPHERAL I/F	<del>-</del>	00H	
Motion SFC operation control instruction	_	00L	
Type conversion (DFLT, SFLT)			
Vision system dedicated function (MVOPEN, MVLOAD,	_	00L	
MVTRG, MVPST, MVIN, MVFIN, MVCLOSE, MVCOM)			
Home position return of scale home position signal detection method	<del>-</del>	00L	
Real time display function in digital oscilloscope function	_	00N	
Rapid stop deceleration time setting error invalid function	_	00\$	

—: There is no restriction by the version.

(Note-4)

(Note-1): SV13/SV22 is the completely same version.

1.39R

(Note-2): The operating system software version can be confirmed in the operating system software (CD-ROM), MT Developer2 or GX Works2/GX Developer. (Refer to "Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON) Section 1.3, 1.4".)

(Note-3): Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (Motion SFC)

1.17T

(Note-4): Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)

(Note-5): Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)

(Note-6): Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (Safety Observation)

(Note-7): Q173DSCPU/Q172DSCPU Motion controller (SV22) Programming Manual (Advanced Synchronous Control)

Table 1.1 Restrictions by the Software's Version (continued)

			•	
		Operating system software version (Note-1), (Note-2)		
Function		Q173DSCPU/Q172DSCPU	Q173DCPU(-S1)/Q172DCPU(-S1)	
Vision system dedicated function (MVOU	T)	_	008	
Motion SFC operation control instruction				
Program control (IF - ELSE - IEND, SELE	ECT -CASE - SEND,	_	00R	
FOR -NEXT, BREAK)				
Display format depending on the error se	tting data		008	
information of motion error history device	(#8640 to #8735)		003	
Product information list device (#8736 to	#8751)	<u> </u>	00S	
Safety observation function		<u> </u>	00S	
Feed current value update command (M3	3212+20n) valid in	00B	Not support	
speed control (I)		005	Not support	
External forced stop input ON latch (SM5	06)	00B	00S	
Operation method (SD560)		00B	Not support	
Advanced synchronous control		00B	Not support	
Limit switch output function expansion		00B	Not support	
Driver communication function (SSCNET	Ⅲ)	00C	Not support	
Intelligent function module support		00C	Not support	
SSCNETⅢ/H head module connection		00C	Not support	
Cam auto-generation (CAMMK) easy stro	oke ratio cam	00C	Not support	
Acceleration/deceleration time change fu	nction	00C	Not support	
Home position return of dogless home po	sition signal	200	Netsonnet	
reference method		00C	Not support	
Setting range expansion of backlash comp	pensation amount	00C	Not support	
Multiple CPU synchronous control		00C	Not support	
Cam axis length per cycle change during	synchronous control	00C	Not support	
Servo driver VCI series manufactured	SSCNETII	_	00L	
by CKD Nikki Denso Co., Ltd.	SSCNETII/H	00D	Not support	
Inverter FR-A700 series		_		
Synchronous encoder via servo amplifier		00D	Not support	
Driver communication function (SSCNET		00D	Not support	
Optical hub unit connection		00F	Not support	
Home position return of driver home position return method		00H	Not support	
Stepping motor module AlphaStep/5-phase manufactured by ORIENTAL MOTOR Co., Ltd.		00H	Not support	
Servo driver VPH series manufactured by Co., Ltd.	/ CKD Nikki Denso	00H	Not support	
IAI electric actuator controller manufacture	d by IAI Corporation	00H	Not support	
Inverter FR-A800 series	·	00J	Not support	

MELCOET ME WA	Programming software version	<u> </u>		Ocation of reference
Q173DSCPU/Q172DSCPU	rks2 (MT Developer2) Q173DCPU(-S1)/Q172DCPU(-S1)	MR Configurator2	MR Configurator	Section of reference
1.39R	1.39R	_	_	(Note-3)
				(11010-0)
1.39R	1.39R	_	_	(Note-3)
_	_	_	_	(Note-3)
_	_	_	_	Section 4.3
1.39R	1.39R	_	_	(Note-6)
_	Not support	_	_	(Note-4)
_	_	_		(Note-5)
_	Not support	_	_	(Note-5)
1.47Z	Not support	_	_	(Note-7)
1.47Z	Not support	_	_	(Note-5)
_	Not support	_	_	(Note-5)
1.56J	Not support	_	_	(Note-5)
1.56J	Not support	_	_	(Note-5)
1.56J	Not support	_	_	(Note-3)
1.56J	Not support	_		(Note-4)
1.56J	Not support	_	-	(Note-4)
1.56J	Not support	_	_	(Note-4)
1.56J	Not support	_	_	(Note-7)
1.56J	Not support	_	_	(Note-7)
1.34L	1.15R	_	_	(Note-4)
1.56J	Not support	_	_	(Note-4)
1.34L	1.15R	_	_	(Note-4)
1.68W	Not support	1.23Z	Not support	(Note-7)
1.68W	Not support	1.23Z	Not support	(Note-5)
_	Not support	_		(Note-4)
1.118Y	Not support	_	_	(Note-4)
1.118Y	Not support	_	_	(Note-4)
1.118Y	Not support	_	_	(Note-4)
1.118Y	Not support	_	_	(Note-4)
1.120A	Not support	_	_	(Note-4)

—: There is no restriction by the version.

(Note-1): SV13/SV22 is the completely same version.

(Note-2): The operating system software version can be confirmed in the operating system software (CD-ROM), MT Developer2 or GX Works2/GX Developer. (Refer to "Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON) Section 1.3, 1.4".)

(Note-3): Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (Motion SFC)

(Note-4): Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)

(Note-5): Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)

(Note-6): Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (Safety Observation)

(Note-7): Q173DSCPU/Q172DSCPU Motion controller (SV22) Programming Manual (Advanced Synchronous Control)

Table 1.1 Restrictions by the Software's Version (continued)

	Operating system softw		
Function	Q173DSCPU/Q172DSCPU	Q173DCPU(-S1)/Q172DCPU(-S1)	
Improvement of absolute positioning operation for servo driver VCI/VPH series manufactured by CKD Nikki Denso Co., Ltd., and stepping motor module AlphaStep/5-phase manufactured by ORIENTAL MOTOR Co., Ltd.	00L	Not support	
Servo amplifier MR-J5(W)-□B support	00Y	Not support	
DOG/CHANGE signal input method support	00Y	Not support	
Servo amplifier MR-JE-□B support	0AA	Not support	

MELSOFT MT Work	ks2 (MT Developer2)	MD O f	MD 0 5 1	Section of reference	
Q173DSCPU/Q172DSCPU	Q173DCPU(-S1)/Q172DCPU(-S1)	MR Configurator2	MR Configurator		
-	Not support	I	_	(Note-4)	
1.170C	Not support	1.130L	Not support		
1.170C	Not support	_	_	(Note-5)	
1.187V	Not support	1.150G	Not support		

—: There is no restriction by the version.

(Note-1): SV13/SV22 is the completely same version.

(Note-2): The operating system software version can be confirmed in the operating system software (CD-ROM), MT Developer2 or GX Works2/GX Developer. (Refer to "Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON) Section 1.3, 1.4".)

(Note-3): Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (Motion SFC)

(Note-4): Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)

(Note-5): Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)

(Note-6): Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (Safety Observation)

(Note-7): Q173DSCPU/Q172DSCPU Motion controller (SV22) Programming Manual (Advanced Synchronous Control)

## 1.5 Programming Software Version

The programming software versions that support Motion CPU are shown below.

M. C. OPU	MELSOFT MT Wor	MELSOFT MT Works2 (MT Developer2)		MD O C	
Motion CPU	SV13/SV22	SV43	MR Configurator2	MR Configurator	
Q173DSCPU	1.39R <sup>(Note-1)</sup>		1.10L	Not support	
Q172DSCPU	1.39R (Note-1)		1.10L	Not support	
Q173DCPU-S1	1.00A (Note-2)	1.03D (Note-3)	1.00A	C0 (Note-4)	
Q172DCPU-S1	1.00A (Note-2)	1.03D (Note-3)	1.00A	C0 (Note-4)	
Q173DCPU	1.00A	1.03D	1.00A	C0 (Note-4)	
Q172DCPU	1.00A	1.03D	1.00A	C0 (Note-4)	

(Note-1): Use version 1.47Z or later to use advanced synchronous control method.

(Note-2): Use version 1.12N or later to communicate via PERIPHERAL I/F.

(Note-3): Use version 1.23Z or later to communicate via PERIPHERAL I/F.


(Note-4): Use version C1 or later to use MR Configurator combination with MT Developer2.


## 2. STARTING UP THE SYSTEM

The procedure for virtual mode positioning control is shown below.

## 2.1 Starting Up the Virtual Mode System

The procedure to start up for virtual mode system is shown below.






## 2.2 Starting Up the Incremental System and Absolute System

When incremental system or absolute system is used, the procedure for virtual mode operation is shown below.


#### 2.2.1 Operation for incremental system

The operation procedure for incremental system is shown below.



# 2.2.2 Operation for absolute (absolute position) system

The operation procedure for absolute system is shown below.



#### 2.3 Differences Between Real Mode and Virtual Mode

Specifications of the positioning data, positioning devices and servo programs, etc. used in the real mode differ in part in the virtual mode.

When using them in the virtual mode, refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)" after checking about a different point in the real mode.

### 2.3.1 Positioning data

Positioning data used in the virtual mode are shown in Table 2.1 below.

Table 2.1 Positioning Data List

ltem	Real mode	Virtual mode	Remark		
System settings	0	0			
Fixed parameters	0	Δ	Usable units differ according to the output module.		
Servo parameters	0	0			
Parameter blocks	0	$\triangle$	Only [pulse] usable.		
Home position return data	0	_			
JOG operation data	0	_			
Limit switch output data	0	Δ			

O: Used

 $\triangle$  : Used (Restrictions in part)

- : Not used

(Note): Refer to Section 10.1 for the real mode axis at virtual mode.

### 2.3.2 Positioning devices

The operating ranges of positioning devices used in virtual mode are shown in Table 2.2 below.

Table 2.2 Operating Range of Positioning Devices

Device name	Real mode	Virtual mode		
	M2000 to M3839			
Internal relays	M4640 to M4687	M2000 to M5487		
	M5440 to M5487			
Special relays	SM0 to SM2255			
Data registera	D0 to D799	D0 to D1559		
Data registers	D1120 to D1239	D0 t0 D 1959		
Motion registers	#8000 to #8751			
Special registers	SD0 to SD2255			

# 2.3.3 Servo programs

- (1) Servo program area
  - (a) The same servo program (Kn) No. cannot be used in both the real mode and virtual modes. The range of servo program (Kn) used in the virtual mode must be set using MT Developer2 in advance.

### (2) Servo instructions

- (a) The home position return, speed control (II), speed-position switching control, high-speed oscillation control and speed control with fixed position stop among the controls which can be used in the real mode cannot be used in the virtual mode.
- (b) Control units of the parameter block and the torque limit value among the positioning data which can be set using the servo program are not used.
- (3) Differences of the servo instruction between real mode and virtual mode are shown in Table 2.3 below.

Table 2.3 Differences of Servo Instruction List

	Item		Real mode	Virtual mode	Remark
	Speed-position switching control	VPF VPR VPSTART	0	×	
	Speed control (II)	VVF VVR	0	×	
Servo instruction	Home position return	ZERO	0	×	Switch to virtual mode after home position return in the real mode.
	High-speed oscillation	OSC	0	×	
	Speed control with fixed position stop	PVF PVR	0	×	
Desitioning		Control units	0	Fixed as [pulse]	
Positioning data	Parameter block	Torque limit value	0	_	The torque limit value is set with the "output module parameter".

 $<sup>\</sup>bigcirc$ : Used,  $\times$ : Unusable, -: Not used

(Note-2): Refer to Section 10.1 for the real mode axis at virtual mode.

<sup>(</sup>Note-1): Instruction not listed in the table above are common instructions in real mode and virtual mode.

## 2.3.4 Control change (Current value change/speed change/target position change)

When a control change is executed in the virtual mode, the feed current value/speed of the drive module is changed.

Control changes are not possible for the output module (except for cam).

Differences between control changes in the real mode and virtual modes are shown in Table 2.4 below.

Table 2.4 Differences List of Control Change

	Real	mode	Virtual mode						
lt a ma		0 1	Drive r	module	Output module				
Item	Servo motor	Synchronous encoder	Virtual servo motor	Synchronous encoder	Roller	Ball screw	Rotary table	Cam	
Current value change	0	○ Ver.l	0	0	×	×	×	0	
Speed change	0	×	0	×	× (Note-1)				
Target position change	O ×		O ×		×				

 $\bigcirc$ : Used,  $\times$ : Unusable

(Note-1): If the output module is a roller which uses a speed change gear, a speed change can be executed by changing the speed change gear ratio.

# REMARK

Refer to the following Chapters for details of the drive and output modules.

Drive module : Chapter 5 and 6Output module : Chapter 5 and 8

Ver.!): Refer to Section 1.4 for the software version that supports this function.

# 2.3.5 Switching of control mode (Speed-torque control)

When a speed-torque control is executed in the virtual mode, the control mode of the output module (except for cam) and real mode axis is switched.

Differences between speed-torque control in the real mode and virtual modes are shown in Table 2.5 below.

Table 2.5 Differences List of Control Mode Switching

	Real mode		Virtual mode						
Itam			Drive module		Output module				Б
Item	Servo motor	Synchronous encoder	Virtual servo	Synchronous	Roller	Ball	Rotary	Cam	Real mode axis
			motor	encoder		screw	table	Calli	mode axis
Speed-torque	0	×	×	×	0	$\supset$	$\supset$	×	$\bigcirc$
control	)	, ,	, ,	, ,	)	)	)	, ,	O

 $\bigcirc$  : Used,  $\times$  : Unusable

# REMARK

Refer to the Section 10.2 for details of the speed-torque control in virtual mode.

# 3. PERFORMANCE SPECIFICATIONS

Performance specifications of the Motion CPU are shown in Table 3.1 below.

Table 3.1 Motion CPU Performance Specifications (Virtual Mode)

Up to 32 axes   Up to 16 axes   Simultaneous: 2 to 4/ (Simultaneous: 2 to 4/ (Simultaneous: 2 to 4/ (Simultaneous: 2 to 4/ (Simultaneous: 2 to 4/ (Independent: 13 axes)   Independent: 13 axes   Independ			Item		Q173E	SCPU	Q172E	SCPU	Q173DC	PU(-S1)	Q172DC	PU(-S1)
Number of control axes   (Simultaneous: 2 to 4/   (Simultaneous: 2 to												
Independent: 32 axes    Independent: 16 axes    Independent: 32 axes    Independent: 8 axes    Synchronous control, profit of points to Points operation control, position follow-up control speed-outcal position follow-up control speed-outcal position follow-up control speed-outcal fixed position follow-up a	Nui	mbe	er of control axe	s			•				1	
Synchronous control, PTP (Point to Point) control, fixed-pitch feed, constant-speed control, position follow-up control, speed-switching control speed-switching control position follow-up control speed-switching control sp	]				,		•		`		,	
PTP (Point to Point) control, speed control, fixed-pitch feed, constant-speed control, speed-switching control speed-switching control speed-switching control speed-switching control speed-switc					· ·						,	
Control method    Virtual servo module   Drive modu					PTP (Poi	•	-	d control.	1			d control.
Position follow-up control, speed-switching control, speed-switching control, speed-switching control, speed-switching control, speed-switching control, speed-switching control speed-speed speed speed-switching control s	Coi	Control method			-	-						
Drive module   Driv					-				-			
Drive module   Synchronous   Solution   Synchronous   Solution   Synchronous   Solution   Solutio										speed-switch	ching control	
Module   Synchronous   Anniest   Synchronous   Synchrono				Virtual servo			•			•		
			Drive	motor								
Roller			module	Synchronous				pu	Ise			
Output module   Ball screw   Rotary table   Cam	Coi	ntro	ı	encoder								
Output   Module   Rotary table   Fixed as "degree"	uni	ts		Roller								
Module   Rotary table   Cam			Output	Ball screw				mm,	inch			
Cam				Rotary table				Fixed as	"degree"			
Program   Inguage						mm, inch, de	egree, pulse		_	mm, inc	ch, pulse	
Capacity   Number of positioning points   Total of 3200 points (It changes with programs, indirect specification is possible.)	Pro	gra	m language	-			-	(Servo prog	ram + mecha			
Number of positioning points   Total of 3200 points (It changes with programs, indirect specification is possible.)				Capacity								
Positioning positioning points   Total of 3200 points   Total of 3	_			Number of		1 / 1 /						
Drive module	Ser	٧o	program	positioning	Tot	tal of 3200 po	oints (It chan	ges with pro	grams, indire	ct specificat	tion is possib	le.)
Drive module   Driv		points					•		•	·		,
Drive module   Drive module   Drive module   Drive module   Drive module   Synchronous encoder   12 axes   12 axes   12 axes   12 axes   8 axes				Virtual servo	00.		40		00 -		0	
Synchronous   12 axes   12 axes   12 axes   12 axes   8 axes		D	<b>.</b>	motor	32 8	axes	16 8	axes	32 a	ixes	8 a	xes
Virtual axis   Virtual axis   Virtual axis   Virtual axis   Safet   Virtual axis   Virtual axi			Drive module	Synchronous	40		40		40 -		0 -	
Virtual axis   Virt		PU		encoder	12 8	12 dxes		axes	12 a	ixes	o axes	
Virtual axis   Virt		S. C.		Virtual main	22			0	22		0	
Stroke resolution   Stro	ے	it De		shaft	3	32		10		32		3
Stroke resolution   Stro	grar	ese	virtuai axis	Virtual auxiliary			16		20		0	
Stroke resolution   Stro	pro	ď⊓		input axis	3	02	1	U	3.		,	)
Stroke resolution   Stro	em	h cs			6	34	3	2	6	4	1	6
Stroke resolution   Stro	syst	hic		Clutch (Note-1)	6	34	3	2	6	4	1	6
Stroke resolution   Stro	g	N Sé	Transmissis	Speed change	_	.,	,	2	_	4		6
Stroke resolution   Stro	iani	ğ		gear	б	14	3		6	4	1	υ
Stroke resolution   Stro	1ect	E.	module	Differential gear	3	2	1	6	3:	2	8	3
Output module         Ball screw Rotary table         32 Rotary table         Total 32         Total 32         Total 16         32 Rotary table         32 Rotary table         Total 32         Total 32         8 Rotary table         32 Rota	2	۶. of		Differential gear	2	2	4	6	3	2		2
Output module         Ball screw Rotary table         32 Rotary table         Total 32         Total 32         Total 16         32 Rotary table         32 Rotary table         Total 32         Total 32         8 Rotary table         32 Rota		mbe		to main shaft	3	)∠	1	U	3.		,	)
Module   Rotary table   32		N		Roller	32		16		32		8	
Module   Rotary table   32   16   32   8			Output	Ball screw	32	Total 22	16	Total 16	32	Total 22	8	Total 0
Types Up to 256 (Note-3) Resolution per cycle 256 • 512 • 1024 • 2048 (Note-3)  Memory capacity 132k bytes  Storage memory for cam data CPU internal RAM memory  Stroke resolution 32767			module	Rotary table	32	10tal 32	16	10(8) 16	32	10tal 32	8	างเลา ช
Resolution per cycle  Memory capacity  Storage memory for cam data  Stroke resolution  256 • 512 • 1024 • 2048 (Note-3)  132k bytes  CPU internal RAM memory  32767		Cam		32		16				8		
Memory capacity  Storage memory for cam data  Stroke resolution  132k bytes  CPU internal RAM memory  32767		Resolution per cycle  Memory capacity						Up to 25	6 (Note-3)			
Storage memory for cam data  CPU internal RAM memory  Stroke resolution  32767							256	6 • 512 • 1 <mark>0</mark> 2	24 • 2048 <sup>(Not</sup>	e-3)		
Stroke resolution 32767	ے							132k	bytes			
Stroke resolution 32767	Cai							PU internal	RAM memor	у		
Control mode			ntrol mode									

Table 3.1 Motion CPU Performance Specifications (Virtual Mode) (Continued)

		tem	Q173DSCPU	Q172DSCPU	Q173DCPU(-S1)	Q172DCPU(-S1)				
	Interpolation fu	ınctions	Linear	interpolation (2 to 4 axe	s), circular interpolation (2	2 axes)				
	Control metho	ds	PTP (Point to Point) control, speed control, fixed-pitch feed, constant-speed control, position follow-up control							
	Positioning	Method	· ·	: Incremental data	d incremental data method					
		Position command	Addre	Address setting range : -2147483648 to 2147483647 [pulse]						
		Speed command		Speed setting range : 1	to 2147483647 [pulse/s]					
l servo motor	Acceleration/	Trapezoidal acceleration/ deceleration	Acceleration time	celeration/deceleration a: 1 to 65535 [ms] e: 1 to 65535 [ms]	Time-fixed acceleration Acceleration/deceleration (Only constant-speed co	n time: 1 to 5000 [ms]				
;_	deceleration control	S-curve acceleration/ deceleration	S-curve ratio: 0 to 100[%]  Acceleration section ratio: 0.0 to 100.0[%]  Deceleration section ratio: 0.0 to 100.0[%]							
		Advanced S-curve acceleration/ deceleration								
	JOG operation	function		Pro	vided					
	M-code function	on	M-code outp	out function provided, M-	-code complete wait funct	ion provided				
	Manual pulse g function (Test mode on	generator operation	Up to 3 units can be connected. Up to 3 axes can be operated simultaneously. Setting of magnification: 1 to 10000 Setting of smoothing magnification provided.							

(Note-1): When the TREN input signal is used as "external input mode clutch", the high speed reading function cannot be used.

<sup>(</sup>Note-3): Relation between a resolution per cycle of cam and type are shown below.

Resolution per cycle	256	512	1024	2048
Туре	256	128	64	32

<sup>(</sup>Note-2): Capacity matching the servo program for real mode.

# 4. POSITIONING DEDICATED SIGNALS

The internal signals of the Motion CPU and the external signals to the Motion CPU are used as positioning signals.

## (1) Internal signals

The following five devices of the Motion CPU are used as the internal signals of the Motion CPU.

- Internal relay (M) ...... M2000 to M5487 (3488 points)
- Special relay (SM) ...... SM0 to SM2255 (2256 points)
- Motion register (#) ...... #8000 to #8751 (752 points)
- Special register (SD) ...... SD0 to SD2255 (2256 points)

## (2) External signals

The external input signals to the Motion CPU are shown below.

- Upper/lower limit switch input ......... The upper/lower limit of the positioning range is controlled.
- Stop signal ...... This signal makes the starting axis stop.
- Proximity dog signal ...... ON/OFF signal from the proximity dog.
- Speed/position switching signal ...... Signal for switching from speed to position.
- Manual pulse generator input ......... Signal from the manual pulse generator.




Fig.4.1 Flow of the internal signals/external signals

The positioning dedicated devices are shown below.

It indicates the device refresh cycle of the Motion CPU for status signal with the positioning control, and the device fetch cycle of the Motion CPU for command signal with the positioning control.

The operation cycle and main cycle of the Motion CPU are shown below.

(a) Operation cycle

Item		Q173DSCPU	Q172DSCPU	Q173DCPU(-S1)	Q172DCPU(-S1)	
Number of control axes		Up to 32 axes	Up to 16 axes	Up to 32 axes	Up to 8 axes	
Operation cycle (Default)	SV22	0.44ms/ 1 to 6 axes 0.88ms/ 7 to 16 axes 1.77ms/ 17 to 32 axes	0.44ms/ 1 to 6 axes 0.88ms/ 7 to 16 axes	0.44ms/ 1 to 4 axes 0.88ms/ 5 to 12 axes 1.77ms/ 13 to 28 axes 3.55ms/ 29 to 32 axes	0.44ms/ 1 to 4 axes 0.88ms/ 5 to 8 axes	

(b) Main cycle is not fixed-cycle as operation cycle. The cycle is dozens[ms] to hundreds[ms].

# REMARK

(1) In the positioning dedicated signals, "n" in "M3200+20n", etc. indicates a value corresponding to axis No. such as the following tables.

Axis No.	n	Axis No.	n	Axis No.	n	Axis No.	n
1	0	9	8	17	16	25	24
2	1	10	9	18	17	26	25
3	2	11	10	19	18	27	26
4	3	12	11	20	19	28	27
5	4	13	12	21	20	29	28
6	5	14	13	22	21	30	29
7	6	15	14	23	22	31	30
8	7	16	15	24	23	32	31

• Calculate as follows for the device No. corresponding to each axis.

(Example) For axis 32 M3200+20n (Stop command)=M3200+20×31=M3820 M3215+20n (Servo OFF command)=M3215+20×31=M3835

• The following range is valid.

• Q172DSCPU : Axis No.1 to 16 (n=0 to 16)

• Q172DCPU(-S1): Axis No.1 to 8 (n=0 to 7)

(2) In the positioning dedicated signals, "n" in "M4640+4n", etc. of the "Synchronous encoder axis status", "Synchronous encoder axis command signal" and "Synchronous encoder axis monitor device" indicates a value corresponding to synchronous encoder No. such as the following tables.

Synchronous encoder No.	n	Synchronous encoder No.	n	Synchronous encoder No.	n
P1	0	P5	4	P9	8
P2	1	P6	5	P10	9
P3	2	P7	6	P11	10
P4	3	P8	7	P12	11

Calculate as follows for the device No. corresponding to each synchronous encoder.
 (Example) For synchronous encoder No.12

M4640+4n (Error detection)= M4640+4×11=M4684

D1122+10n (Minor error code)= D1122+10×11= D1232

• The range (n=0 to 7) of synchronous encoder No. P1 to P8 is valid in the Q172DCPU(-S1).

# 4.1 Internal Relays

# (1) Internal relay list

	SV22			
Device No.	Application	Real	Virtual	
МО	User device			
to	(2000 points)			
M2000	Common device			)
to	(320 points)	0	0	
M2320	Unusable			
to	(80 points)	=	_	
M2400	Axis status			
	(20 points × 32 axes)	_	_	
to	Real mode : Each axis	0	0	
	Virtual mode : Output module			
M3040	Unusable			
to	(32 points)	_	_	
M3072	Common device			Real/virtual
1110072	(Command signal)	0	0	community
to	(64 points)			
M3136	Unusable			
to	(64 points)	_	_	
M3200	Axis command signal			
W0200	(20 points × 32 axes)			
to	Real mode : Each axis	0	0	
10	Virtual mode : Output module			
M3840	Unusable			
to	(160 points)	=	_	J
M4000 (Note-1)	(100 points)			5
	Virtual servo motor axis status			
to	(20 points $\times$ 32 axes) (Note-2)	Backup	0	
10	(20 points × 02 axes)			
M4640 (Note-1)	Synchronous encoder axis			
1010	status	0	0	
to	(4 points × 12 axes)			
M4688 (Note-1)	Unusable			
to	(112 points)	_	-	├ Virtual
M4800 <sup>(Note-1)</sup>	( · · = pointo)			
W-1000 ( )	Virtual servo motor axis			
to	command signal	×	0	
to	(20 points × 32 axes) (Note-2)			
M5440 <sup>(Note-1)</sup>				
1013440 (********)	Synchronous encoder axis			
to	command signal	(Note-4)	0	
to	(4 points × 12 axes)	(		
M5400				J
M5488	User device (Note-3)			
to	(2704 points)			
M8191				
	C	: Valid,	imes : Invalid	

It can be used as a user device.

#### **POINT**

- (1) Total number of user device points 4704 points
- (2) (Note-1): Do not set M4000 to M5487 as the latch range in virtual mode.
- (3) (Note-2): This signal occupies only the area of the axis set in the mechanical system program. The unused axis areas in the mechanical system program can be used as a user device.
- (4) (Note-3): The cam axis command signal and smoothing clutch complete signal can be set as the optional device at the parameter.
- (5) (Note-4): It is valid for the version (Refer to Section 1.4) that supports "synchronous encoder current value monitor in real mode".
- (6) This manual describes only details for internal relays used in the virtual mode. If it is required, refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)".

### (2) Axis status list

Axis No.	Device No.		Signal name											
1	M2400 to M2419													
2	M2420 to M2439	Γ							Virtual					
3	M2440 to M2459	ľ	\	0.							Real	Refresh	Fetch	Signal
4	M2460 to M2479		\	Sig	gnal name	Real	Roller	Ball	Rotary	Cam	Mode	cycle	cycle	direction
5	M2480 to M2499		\					screw	table		axis			
6	M2500 to M2519	Ī	0	Positionin	ng start complete			0						
7	M2520 to M2539	ı	1		ng complete			O	FF					
8	M2540 to M2559	Г						,						
9	M2560 to M2579		2	In-positio	n			(	)					
10	M2580 to M2599	Г	3	Comman	d in-position							Operation		
11	M2600 to M2619	I	4	Speed co								cycle		
12	M2620 to M2639		_	Speed / p	osition switching			O	FF					
13	M2640 to M2659	L	5	latch										
14	M2660 to M2679		6	Zero pass	8									
15	M2680 to M2699	L	7	Error dete	ection							Immediately		
16	M2700 to M2719		0	C		0						Operation		Status
17	M2720 to M2739	L	8	Servo em	or detection							cycle		signal
18	M2740 to M2759		9	Home pos	sition return							Main cycle		
19	M2760 to M2779	L	9	request								Main cycle		
20	M2780 to M2799	I.	10	Home pos	sition return				)			Operation		
21	M2800 to M2819	L	10	complete					_			cycle		
22	M2820 to M2839	Ŀ	11		FLS									
23	M2840 to M2859	Ŀ	12	External	RLS							Main cycle	Н	
24	M2860 to M2879			signals	STOP							Iviairi Gyole	П	
25	M2880 to M2899		14		DOG/CHANGE									
26	M2900 to M2919	Ŀ	15	Servo rea	ady							Operation		
27	M2920 to M2939	ŀ	16	Torque lir	miting							cycle		
28	M2940 to M2959	Ŀ	17	Unusable		_		_	_		_	_	<u> </u>	
29	M2960 to M2979			Virtual mo	ode continuation							At virtual	/	
30	M2980 to M2999	1	18		disable warning			(	)			mode	/	Status
31	M3000 to M3019	ļ		(Note-1)		0					0	transition	/	signal
32	M3020 to M3039	Į.	19	M-code o	utputtina			Ο	FF			Operation	/	Signal
ĺ		L	٠,	5546 0								cycle	/	
														○ : Valid

(Note-1): It is unusable in the SV22 real mode.

# POINT

(1) The following range is valid.

Q172DSCPU : Axis No.1 to 16Q172DCPU(-S1): Axis No.1 to 8

(2) The following device area can be used as a user device.

• Q172DSCPU : 17 axes or more • Q172DCPU(-S1): 9 axes or more

However, when the project of Q172DSCPU/Q172DCPU(-S1) is replaced with Q173DSCPU/Q173DCPU(-S1), this area cannot be used as a user device.

# (3) Axis command signal list

Axis No.	Device No.					Sign	al name					
1	M3200 to M3219											
2	M3220 to M3239	\					Virtual					
3	M3240 to M3259	$  \rangle$							Real	Refresh	Fetch	Signal
4	M3260 to M3279		Signal name	Real	Roller	Ball	Rotary	Cam	mode	cycle	cycle	direction
5	M3280 to M3299	Ι'	V			screw	table		axis			
6	M3300 to M3319	0	Stop command								Operation	
7	M3320 to M3339	1	Rapid stop command							/	cycle	
8	M3340 to M3359		Forward rotation JOG							l /		
9	M3360 to M3379	2	start command									
10	M3380 to M3399		Reverse rotation JOG							/	Main	
11	M3400 to M3419	3	start command			,	×				cycle	
12	M3420 to M3439	4	Complete signal OFF									
13	M3440 to M3459	4	command									
14	M3460 to M3479	5	Speed/position switching	0					0		Operation	Command
15	M3480 to M3499	э	enable command								cycle	signal
16	M3500 to M3519		Gain changing 2								Operation	
17	M3520 to M3539	6	command (Note-1)								cycle	
18	M3540 to M3559		QDS( Ver.)			(	Э				(Note-2)	
19	M3560 to M3579	7	Error reset command				)				Main	
20	M3580 to M3599	8	Servo error reset								Main cycle	
21	M3600 to M3619	L	command							1/	Сусіе	
22	M3620 to M3639	a	External stop input disable				×			V/	At start	
23	M3640 to M3659	Ľ	at start command								At Start	
24	M3660 to M3679	10	Unusable	_		_	_		_		_	_
25	M3680 to M3699	11	Chacasic									
26	M3700 to M3719	12	Feed current value update	0		,	×		0	l /	At start	
27	M3720 to M3739	Ľ.	command	_			` I			/	7 tt Start	
28	M3740 to M3759	13	Address clutch reference			×				/	At virtual	
29	M3760 to M3779		setting command (Note-3)	×				1	×	/	mode	
30	M3780 to M3799	14	Cam reference position			×		0		/	transition	
31	M3800 to M3819		setting command (Note-3)							/		
32	M3820 to M3839	15	Servo OFF command							/	Operation	Command
		-								/	cycle	signal
		16	Gain changing command								Operation	
		17	PI-PID switching	0		(	)		0		cycle (Note-2)	
		-	command ODS								(11010 2)	
		18	Control loop changing								Operation	
		10	command FIN signal				~		-	/	cycle	
		18	TELLA SIGNAL		<u> </u>		×		<u> </u>	<u>V</u>	O . M-#-	
											∪ : valid	d, ≍: Invalid

(Note-1): Servo amplifier (MR-J5(W)-□B) only.

(Note-2): It is unusable in the SV22 real mode.

(Note-3): Operation cycle 7.1[ms] or more: Every 3.5[ms]

Ver.!: Refer to Section 1.4 for the software version that supports this function.

# POINT

(1) The following range is valid.

Q172DSCPU : Axis No.1 to 16Q172DCPU(-S1): Axis No.1 to 8

(2) The following device area can be used as a user device.

• Q172DSCPU : 17 axes or more • Q172DCPU(-S1): 9 axes or more

However, when the project of Q172DSCPU/Q172DCPU(-S1) is replaced with Q173DSCPU/Q173DCPU(-S1), this area cannot be used as a user device.

# (4) Virtual servo motor axis status list

Axis No.	Device No.		Signal name										
1	M4000 to M4019												_
2	M4020 to M4039	Γ						Virtual					
3	M4040 to M4059	- 1		0				,		Real	Refresh	Fetch	Signal
4	M4060 to M4079		$\setminus \mid$	Signal name	Real	Roller	Ball	Rotary table	Cam	mode	cycle	cycle	direction
5	M4080 to M4099		$\setminus$				screw	table		axis			
6	M4100 to M4119		)	Positioning start complete				0			Operation		Status
7	M4120 to M4139	-	1	Positioning complete	Backup		(	0		×	cycle		signal
8	M4140 to M4159	2	2	Unusable	_		-	_		_	_	_	_
9	M4160 to M4179	3	3	Command in-position	D I		,	0			Operation		Status
10	M4180 to M4199	4	4	Speed controlling	Backup		,	0		×	cycle		signal
11	M4200 to M4219	į	5	Unusable									
12	M4220 to M4239	6	3	Unusable						_	_		_
13	M4240 to M4259	١.	,	Error detection	Doolsun			0		×	Immedi-		Status
14	M4260 to M4279	Ľ	′	Error detection	Backup					^	ately		signal
15	M4280 to M4299	8	3										
16	M4300 to M4319	9	9										
17	M4320 to M4339	1	0										
18	M4340 to M4359		1										
19	M4360 to M4379	1	2										
20	M4380 to M4399	1	3	Unusable	_		-	_		_	_	_	_
21	M4400 to M4419		4										
22	M4420 to M4439	1	5										
23	M4440 to M4459		6										
24	M4460 to M4479	1	7										
25	M4480 to M4499	1	8									ļ ,	
26	M4500 to M4519	1	9	M-code outputting	Backup		(	0		×	Operation	/	Status
27	M4520 to M4539	Ľ	<u>ٽ</u>	saas sarpatiing	Saskap						cycle	/	signal
28	M4540 to M4559										0:	Valid,	< : Invalid
29	M4560 to M4579												
30	M4580 to M4599												
31	M4600 to M4619												
32	M4620 to M4639												

# POINT

(1) The following range is valid.

• Q172DSCPU : Axis No.1 to 16 • Q172DCPU(-S1): Axis No.1 to 8

(2) The unused axis areas in the mechanical system program can be used as a user device.

# (5) Virtual servo motor axis command signal list

Axis No.	Device No.		Signal name									
1	M4800 to M4819											
2	M4820 to M4839						Virtual					
3	M4840 to M4859	$    \rangle$							Real	Refresh	Fetch	Signal
4	M4860 to M4879	$    \rangle$	Signal name	Real	Roller	Ball	Rotary	Cam	mode	cycle	cycle	direction
5	M4880 to M4899		V			screw	table		axis			
6	M4900 to M4919	0	Stop command							/	Operation	
7	M4920 to M4939	1	Rapid stop command							/	cycle	
8	M4940 to M4959		Forward rotation JOG							/		
9	M4960 to M4979	2	start command			,				/		Command
10	M4980 to M4999		Reverse rotation JOG	×		(	Э		×	/	Main	signal
11	M5000 to M5019	3	start command							/	cycle	
12	M5020 to M5039		Complete signal OFF							/		
13	M5040 to M5059	4	command							/		
14	M5060 to M5079	5	I leave a let a									
15	M5080 to M5099	6	Unusable	_		_						
16	M5100 to M5119	_					)				Main	Command
17	M5120 to M5139	7	Error reset command	×		(	J		×		cycle	signal
18	M5140 to M5159	8	Unusable	_		_	_		_	_	_	_
19	M5160 to M5179		External stop input									0
20	M5180 to M5199	9	disable at start	×		(	С		×		At start	Command signal
21	M5200 to M5219		command									Signal
22	M5220 to M5239	10	)									
23	M5240 to M5259	11										
24	M5260 to M5279	12	2									
25	M5280 to M5299	13	3									
26	M5300 to M5319	14	Unusable	-		-	_		_	_	_	_
27	M5320 to M5339	15	5									
28	M5340 to M5359	16	3									
29	M5360 to M5379	17	_									
30	M5380 to M5399	18	3							ļ,		
31	M5400 to M5419	10	FIN signal	×		(	Э		×		Operation	Command
32	M5420 to M5439	١	, ii ii sigilal			`			^		cycle	signal
											○ : Valid	l, ×: Invalid

# POINT

(1) The following range is valid.

• Q172DSCPU : Axis No.1 to 16 • Q172DCPU(-S1): Axis No.1 to 8

(2) The unused axis areas in the mechanical system program can be used as a user device.

### (6) Synchronous encoder axis status list

Axis No.	Device No.				Sigr	nal name			
1	M4640 to M4643	_							
2	M4644 to M4647		$\overline{}$	Cirrent Income	D	\ Code I	Deficely and	E-t-ll-	Signal
3	M4648 to M4651	L		Signal name	Real	Virtual	Refresh cycle	Fetch cycle	direction
4	M4652 to M4655		0	Error detection			Immediately		
5	M4656 to M4659		1	External signal TREN					Status
6	M4660 to M4663		2	Virtual mode continuation operation			Main cycle		signal
7	M4664 to M4667		2	disable warning					
8	M4668 to M4671	L	3	Unusable	_	_	_	_	_
9	M4672 to M4675								○ : Valid
10	M4676 to M4679								
11	M4680 to M4683								
12	M4684 to M4687								

#### **POINT**

- (1) The range of axis No.1 to 8 is valid in the Q172DCPU(-S1).
- (2) The device area of 9 axes or more can be used as a user device in the Q172DCPU (-S1).

However, when the project of Q172DCPU(-S1) is replaced with Q173DSCPU/Q172DSCPU/Q173DCPU(-S1), this area cannot be used.

# (7) Synchronous encoder axis command signal list

Axis No.	Device No.			Sigr	nal name			
1	M5440 to M5443							
2	M5444 to M5447		Signal name	Real	Virtual	Refresh cycle	Fetch cycle	Signal
3	M5448 to M5451		Olgriai Harric	rtcai	VIItuai	Tellesii eyele	1 Ctorr Cycle	direction
4	M5452 to M5455		Error reset	×	0		Main cycle	Status
5	M5456 to M5459		Lifor reset	(Note-1)	Ŭ		Iviairi cycle	signal
6	M5460 to M5463	1						
7	M5464 to M5467	2	Unusable	-	_	_	_	_
8	M5468 to M5471	3						
9	M5472 to M5475						○ : Valid	, ×: Invalid
10	M5476 to M5479	(N	ote-1): It is valid for the version (Refer to	Section	1.4) tha	t supports "synch	nronous encoder c	urrent
11	M5480 to M5483		value monitor in real mode".					
12	M5484 to M5487							

#### **POINT**

- (1) The range of axis No.1 to 8 is valid in the Q172DCPU(-S1).
- (2) The device area of 9 axes or more can be used as a user device in the Q172DCPU (-S1).

However, when the project of Q172DCPU(-S1) is replaced with Q173DSCPU/Q172DSCPU/Q173DCPU(-S1), this area cannot be used.

# (8) Common device list

Device No.	Signal name	Refresh cycle	Fetch cycle	Signal direction	Remark (Note-6)	Device No.	Signal name	Refresh cycle	Fetch cycle	Signal direction	Remark (Note-6)
M2000	PLC ready flag		Main cycle	Command signal	M3072	M2055					
M2001 M2002 M2003 M2004 M2005	Axis 1 Axis 2 Axis 3 Axis 4 Axis 5			Signal		M2056 M2057 M2058 M2059 M2060	Unusable (6 points)	-	_	=	=
M2006 M2007 M2008 M2010 M2010 M2011 M2011 M2012 M2013 M2014 M2015 M2016 M2019 M2020 M2021 M2021 M2022 M2021 M2022 M2023 M2023 M2023 M2023 M2033 M2030	Axis 6 Axis 7 Axis 8 Axis 9 Axis 10 Axis 11 Axis 12 Axis 13 Axis 14 Axis 15 Axis 16 Axis 17 Axis 18 Axis 19 Axis 20 Axis 20 Axis 21 Axis 22 Axis 23 Axis 24 Axis 25 Axis 26 Axis 27 Axis 28 Axis 27 Axis 28 Axis 30 Axis 31 Axis 31 Axis 30	Operation cycle		Status signal (Note-1), (Note-2), (Note-3), (Note-4)		M2061 M2062 M2063 M2064 M2065 M2066 M2067 M2068 M2070 M2071 M2073 M2074 M2075 M2076 M2076 M2077 M2078 M2078 M2078 M2080 M2080 M2081	Axis 1 Axis 2 Axis 3 Axis 4 Axis 5 Axis 6 Axis 7 Axis 8 Axis 9 Axis 10 Axis 11 Axis 12 Axis 13 Axis 14 Axis 15 Axis 16 Axis 17 Axis 18 Axis 19 Axis 20 Axis 21 Axis 22 Axis 22 Axis 23 Axis 24 Axis 25 Axis 26 Axis 27	Operation cycle		Status signal (Note-1), (Note-2), (Note-3), (Note-4)	
M2033 M2034	Unusable (2 points)	_	-	-	_	M2088 M2089	Axis 28 Axis 29				
M2035 M2036	Motion error history clear request flag Unusable		Main cycle	Command signal	M3080	M2090 M2091	Axis 30 Axis 31		/		
M2037	(2 points)	—		-	_	M2092	Axis 32		/		
M2038 M2039	Motion SFC debugging flag  Motion error detection flag	At debugging mode transition		Status signal		M2093 M2094					
M2040	Speed switching point specified flag	Illimediate	At start	Command signal	M3073	M2095					
M2041	System setting error flag	Operation cycle		Status signal		M2096					
M2042	All axes servo ON command		Operation cycle	Command	M3074	M2097	Unusable (8 points)	-	_	-	_
M2043	Real mode/virtual mode switching request (SV22)		At virtual mode transition	signal	M3075	M2098					
M2044	Real mode/virtual mode switching status (SV22) Real mode/virtual mode	At virtual mode		Status		M2099					
M2045	switching error detection signal (SV22)	transition		signal		M2100			,		
M2046 M2047	Out-of-sync warning (SV22) Motion slot fault detection flag	Operation cycle				M2101 M2102	Axis 1 Axis 2		/		
M2048	JOG operation simultaneous start command	,	Main cycle	Command signal	M3076	M2103			/		
M2049	All axes servo ON accept flag	Operation cycle		Status signal		M2104			/		
M2050	Unusable	_	-	_	_	M2105	Axis 5 Synchronous encoder current	Operation	/	Status signal	
M2051	Manual pulse generator 1 enable flag				M3077	M2106	Axis 6 value changing flag (Note-5)	Operation cycle	/	(Note-2), (Note-4)	
M2052	Manual pulse generator 2 enable flag		Main cycle	Command signal	M3078	M2107	Axis 7		/		
M2053	Manual pulse generator 3 enable flag				M3079	M2108	Axis 8		/		
M2054	Operation cycle over flag	Operation cycle		Status signal		M2109	Axis 9		<u>/</u>		

# Common device list (Continued)

Device No.	Signal name	Refresh cycle	Fetch cycle	Signal direction	Remark (Note-6)	Device No.	Signal name	Refresh cycle	Fetch cycle	Signal direction	Remark (Note-6)
M2110 M2111 M2112	Axis 11 encoder current value changing flag	Operation cycle		Status signal (Note-2), (Note-4)		M2179 M2180 M2181					
M2113 M2114 M2115 M2116 M2117 M2118 M2119 M2120 M2121 M2122 M2123 M2124 M2125 M2126 M2127	Unusable (15 points)	-	-	-	_	M2182 M2183 M2184 M2185 M2186 M2187 M2188 M2189 M2190 M2191 M2192 M2193 M2194 M2195 M2196					
M2128 M2129 M2130 M2131 M2132 M2133 M2134 M2135 M2136 M2137 M2141 M2142 M2143 M2144 M2144 M2145 M2146 M2146 M2147 M2145 M2150 M2151 M2155 M2155 M2155	Axis 2 Axis 3 Axis 4 Axis 5 Axis 6 Axis 7 Axis 8 Axis 9 Axis 10 Axis 11 Axis 12 Axis 13 Axis 14 Axis 15 Axis 16 Axis 17 decelerating flag Axis 18 Axis 20 Axis 21 Axis 22 Axis 22 Axis 23 Axis 24 Axis 24 Axis 26 Axis 27 Axis 28	Operation cycle		Status signal (Note-1), (Note-2), (Note-3), (Note-4)		M2197 M2198 M2199 M2200 M2201 M2203 M2204 M2205 M2206 M2207 M2208 M2201 M2211 M2212 M2213 M2214 M2215 M2215 M2216 M2217 M2218 M2219 M2221 M2221 M2222 M2223 M2222 M2223	Unusable (45 points) (Note-7)	_	_	_	_
M2157 M2158 M2159	Axis 30 Axis 31 Axis 32					M2226 M2227 M2228					
M2160 M2161 M2162 M2163 M2164 M2165 M2166 M2167 M2170 M2171 M2172 M2173 M2174 M2175 M2177 M2177 M2177	Unusable (19 points) (Note-7)	_	_	_	_	M2233 M2234 M2235 M2236 M2237 M2238 M2239 M2240 M2241 M2242 M2243 M2244 M2244	Axis 1 Axis 2 Axis 3 Axis 4 Speed change "0" Axis 5 Axis 6 Axis 7	Operation cycle	_	Status signal (Note-1), (Note-2), (Note-3), (Note-4)	_

# Common device list (Continued)

Device					Signal	Remark	Device				Signal	Remark
No.		Signal name	Refresh cycle	Fetch cycle	direction	(Note-6)	No.	Signal name	Refresh cycle	Fetch cycle	direction	(Note-6)
M2248	Axis 9						M2284	Axis 13		/		
M2249	Axis 10			1			M2285	Axis 14		l /		
M2250	Axis 11			- 1			M2286	Axis 15		l /		
M2251	Axis 12			1			M2287	Axis 16		/		
M2252	Axis 13			1			M2288	Axis 17		l /		
M2253	Axis 14			1			M2289	Axis 18		l /		
M2254	Axis 15			1			M2290	Axis 19		/		
M2255	Axis 16			1			M2291	Axis 20		l /	Status	
M2256	Axis 17			1			M2292	Axis 21		/	signal	
M2257	Axis 18			1			M2293	Axis 22 Control loop monitor		/	(Note-1),	
M2258	Axis 19			1			M2294	Axis 23 status	Operation cycle	/	(Note-2),	
M2259	Axis 20	Speed change "0"		1			M2295	Axis 24		/	(Note-3),	
M2260	Axis 21	accepting flag		- 1			M2296	Axis 25		/	(Note-4)	
M2261	Axis 22			1			M2297	Axis 26		/		
M2262	Axis 23			1			M2298	Axis 27		/		
M2263	Axis 24			1	Status		M2299	Axis 28		/		
M2264	Axis 25			1	signal		M2300	Axis 29		/		
M2265	Axis 26			1	(Note-1),		M2301	Axis 30		/		
M2266	Axis 27		Operation cycle	1	(Note-2),		M2302	Axis 31		1/		
M2267	Axis 28			1	(Note-3),		M2303	Axis 32		<b>V</b>		
M2268	Axis 29			1	(Note-4)		M2304					
M2269	Axis 30			1			M2305					
M2270	Axis 31			1			M2306					
M2271	Axis 32			1			M2307					
M2272	Axis 1			1			M2308					
M2273	Axis 2			1			M2309					
M2274	Axis 3			1			M2310					
M2275	Axis 4			1			M2311	Unusable				
M2276	Axis 5			[			M2312	(16 points)	_	_	_	-
M2277	Axis 6	Control loop		/			M2313					1 1
M2278	Axis 7	monitor status		1			M2314					1 1
M2279	Axis 8						M2315					
M2280	Axis 9			1			M2316					
M2281	Axis 10			1			M2317					<b>i</b> I
M2282	Axis 11			/			M2318					<b> </b>
M2283	Axis 12						M2319					<u> </u>

(Note-1): The range of axis No.1 to 16 is valid in the Q172DSCPU.

(Note-2): The range of axis No.1 to 8 is valid in the Q172DCPU(-S1).

(Note-3): Device area of 17 axes or more is unusable in the Q172DSCPU.

(Note-4): Device area of 9 axes or more is unusable in the Q172DCPU(-S1).

(Note-5): It is unusable in the real mode.

(It can be used in the real mode for the version (Refer to Section 1.4) that supports "synchronous encoder current value monitor in real mode".)

(Note-6): It can also be ordered the device of a remark column.

(Note-7): These devices can be used as the clutch statuses.

The clutch status can also be set as the optional device at the clutch parameter.

Refer to Section 7.2.2.

## (9) Common device list (Command signal)

Device No.	Signal name	Refresh cycle	Fetch cycle	Signal direction	Remark (Note-1), (Note-2)
M3072	PLC ready flag	/	Main cycle		M2000
M3073	Speed switching point specified flag	/	At start		M2040
M3074	All axes servo ON command		Operation cycle		M2042
M3075	Real mode/virtual mode switching request (SV22)		At virtual mode transition		M2043
M3076	JOG operation simultaneous start command			Command signal	M2048
M3077	Manual pulse generator 1 enable flag				M2051
M3078	Manual pulse generator 2 enable flag		Main cycle		M2052
M3079	Manual pulse generator 3 enable flag	/			M2053
M3080	Motion error history clear request flag	/			M2035
M3081 to M3135	Unusable <sup>(Note-3)</sup> (55 points)	_	_	_	_

- (Note-1): The state of a device is not in agreement when the device of a remark column is turned ON/OFF directly. In addition, when the request from a data register and the request from the above device are performed simultaneously, the request from the above device becomes effective.
- (Note-2): It can also be ordered the device of a remark column.
- (Note-3): Do not use it as a user device. It can be used as a device that performs automatic refresh because of area for the reserve of command signal.

### **POINT**


The device of a remark column turns ON by OFF to ON of the above device, and turns OFF by ON to OFF of the above device.

The command signal cannot be turned ON/OFF by the PLC CPU in the automatic refresh because the statuses and commands are mixed together in M2000 to M2053. Use the above devices in the case.

And, it can also be turned ON/OFF by the data register. (Refer to Section 4.2.8)

#### 4.1.1 Axis statuses

- (1) In-position signal (M2402+20n) ...... Status signal
  - (a) This signal turns on when the number of droop pulses in the deviation counter becomes below the "in-position range" set in the servo parameters. It turns off at positioning start.



(b) While the control circuit power supply of the servo amplifier is ON, the status of the in-position signal of the servo amplifier (Servo status1 (#8010+20n): b12 ( is reflected.

However, the state of the signal is always OFF for the following.

- Servo error
- From positioning start until deceleration start (Note-1)
- · Current value change
- Home position return (Note-2)


(Note-1): Except during position follow-up control, high-speed oscillation control, manual pulse generator operation, and synchronous control. (The in-position signal is constantly updated during such controls.)

(Note-2): The in-position signal may be updated after a proximity dog is turned ON during home position return.

Once the zero point has been passed, it remains on state until the Multiple CPU system has been reset.

However, in the home position return method of proximity dog method, count method, dog cradle method, limit switch combined method, scale home position signal detection method, or dogless home position signal reference method, this signal turns off once at the home position return in real mode start and turns on again at the next zero point passage.


- (3) Error detection signal (M2407+20n) ...... Status signal
  - (a) This signal turns on with detection of a minor error or major error, and it is used as judgement of the error available/not available. The applicable error code (Note-1) is stored in the minor error code storage register (D6+20n) with detection of a minor error.
    - The applicable error code (Note-1) is stored in the major error code storage register (D7+20n) with detection of a major error.
  - (b) This signal turns off when the error reset command (M3207+20n) turns on.



# REMARK

(Note-1): Refer to APPENDIX 1 for the error codes with detection of major/minor errors.

- (4) Servo error detection signal (M2408+20n) ...... Status signal
  - (a) This signal turns on when an error occurs at the servo amplifier side (except for errors cause of alarms and emergency stops) (Note-1) and it is used as judgement of the servo error available/not available. When an error is detected at the servo amplifier side, the applicable error code (Note-1) is stored in the servo error code storage register (D8+20n).
  - (b) This signal turns off when the servo error reset command (M3208+20n) turns on or the servo power supply turns on again. (Servo error reset is valid in the real mode only.)



# REMARK

(Note-1): Refer to APPENDIX 1.5 for the error codes on errors detected at the servo amplifier side.

(5) Home position return request signal (M2409+20n) ...... Status signal

This signal turns on when it is necessary to confirm the home position address.

- (a) When not using an absolute position system
  - 1) This signal turns on in the following cases:
    - Multiple CPU system power supply on or reset
    - · Servo amplifier power supply on
    - Home position return start in the real mode (Unless a home position return is completed normally, the home position return request signal does not turn off.)
  - 2) This signal turns off by the completion of home position return.
- (b) When using an absolute position system
  - 1) This signal turns on in the following cases:
    - When not executing a home position return once after system start.
    - Home position return start in the real mode (Unless a home position return is completed normally, the home position return request signal does not turn off.)
    - Erase of an absolute data in Motion CPU according to causes, such as battery error
    - · Servo error [2025] (absolute position erase) occurrence
    - Servo error [2143] (absolute position counter warning) occurrence
    - Servo error [2913] (encoder counter error) occurrence
    - Major error [1201], [1202], [1203] or [1204] occurrence
    - When the "rotation direction selection" of servo parameter is changed.
  - 2) This signal turns off by the completion of the home position return.


# **∆** CAUTION


• When using the absolute position system function, on starting up, and when the Motion controller or absolute value motor has been replaced, always perform a home position return in real mode. In the case of the absolute position system, use the sequence program to check the home position return request before performing the positioning control.
Failure to observe this could lead to an accident such as a collision.

6)	Home position return complete signal (M2410+20n)	
		Status signa


- (a) This signal turns on when the home position return operation using the servo program has been completed normally.
- (b) This signal turns off at the positioning start, JOG operation start and manual pulse generator operation start.
- (c) If the home position return of proximity dog, dog cradle or stopper method using the servo program is executed during this signal on, a minor error (error code: 115) occurs and it cannot be start the home position return.


- (7) FLS signal (M2411+20n) (Note-1) ...... Status signal
  - (a) This signal is controlled by the ON/OFF state for the upper stroke limit switch input (FLS) of the Q172DLX/servo amplifier and bit device ...
    - Upper stroke limit switch input OFF ...... FLS signal: ON
    - Upper stroke limit switch input ON ...... FLS signal: OFF
  - (b) The state for the upper stroke limit switch input (FLS) when the FLS signal is ON/OFF is shown below.
    - 1) Q172DLX use (Note-2)







2) Servo amplifier input use (Note-3)







- 3) Bit device use (Note-1) QDS(
  The set bit device is the FLS signal.
- (Note-1): Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)" for an external signal and bit device.
- (Note-2): Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller User's Manual" for a pin configuration.
- (Note-3): Refer to the "Servo Amplifier Instruction Manual" for a pin configuration.
- (c) "Normally open contact input" and "Normally closed contact input" of the servo data setting can be selected.
- - (a) This signal is controlled by the ON/OFF state for the lower stroke limit switch input (RLS) of the Q172DLX/servo amplifier and bit device.
    - · Lower stroke limit switch input OFF ..... RLS signal: ON
    - · Lower stroke limit switch input ON ...... RLS signal: OFF
  - (b) The state of the lower stroke limit switch input (RLS) when the RLS signal is ON/OFF is shown below.
    - 1) Q172DLX use (Note-2)






2) Servo amplifier input use (Note-3)






3) Bit device use (Note-1) QDS(
The set bit device is the RLS signal.

- (Note-1): Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)" for an external signal and bit device.
- (Note-2): Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller User's Manual" for a pin configuration.
- (Note-3): Refer to the "Servo Amplifier Instruction Manual" for a pin configuration.
- (c) "Normally open contact input" and "Normally closed contact input" of the servo data setting can be selected.
- (9) STOP signal (M2413+20n) (Note-1)...... Status signal
  - (a) This signal is controlled by the ON/OFF state for the stop signal input (STOP) of the Q172DLX and bit device (25%).
    - Stop signal input of the Q172DLX OFF ..... STOP signal: OFF
    - Stop signal input of the Q172DLX ON ...... STOP signal: ON
  - (b) The state of the stop signal input (STOP) when the STOP signal input is ON/OFF is shown below.
    - 1) Q172DLX use (Note-2)





2) Bit device use (Note-1) (DDS)


The set bit device is the STOP signal.


- (Note-1): Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)" for an external signal and bit device.
- (Note-2): Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller User's Manual" for a pin configuration.
- (c) "Normally open contact input" and "Normally closed contact input" of the servo data setting can be selected.

- (10) DOG/CHANGE signal (M2414+20n) (Note-1)...... Status signal
  - (a) This signal turns on/off by the proximity dog input (DOG) of the Q172DLX/ servo amplifier/input (DI) of built-in interface in Motion CPU (bit device (bit devi


(There is no CHANGE signal in the servo amplifier.)


- (b) The state of the speed/position switching input (CHANGE) when the CHANGE signal is ON/OFF is shown below.
  - 1) Q172DLX use (Note-3)







2) Servo amplifier input use (Note-4)





3) Built-in interface in Motion CPU use (Note-3)





4) Bit device use (Note-1) QDS(

The set bit device is the DOG/CHANGE signal.


- (Note-1): Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)" for an external signal and bit device.
- (Note-2): When using the Q173DCPU(-S1)/Q172DCPU(-S1), the external input signal (DOG) of servo amplifier can also be used in the speed-position switching control. (Refer to Section 1.4 for the software version that supports this function.)
- (Note-3): Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller User's Manual" for a pin configuration.
- (Note-4): Refer to the "Servo Amplifier Instruction Manual" for a pin configuration.

(c) When using the Q172DLX/built-in interface in Motion CPU, "Normally open contact input" and "Normally closed contact input" of the system setting can be selected.

When using the proximity dog input (DOG) of servo amplifier/bit device, "Normally open contact input" and "Normally closed contact input" of the servo data setting can be selected.

- (11) Servo ready signal (M2415+20n) ...... Status signal
  - (a) This signal turns on when the servo amplifiers connected to each axis are in the READY state (READY ON and Servo ON).
  - (b) This signal turns off in the following cases.
    - · All axes servo ON command (M2042) is off
    - · Servo amplifier is not mounted
    - · Servo parameter is not set
    - It is received the forced stop input from an external source
    - Servo OFF by the servo OFF command (M3215+20n) ON of each axis
    - Servo error occurs

Refer to "APPENDIX 1.5 Servo errors" for details.



#### **POINT**

When the part of multiple servo amplifiers connected to the SSCNETII(/H) becomes a servo error, only an applicable axis becomes the servo OFF state.

It checks for the following cases.

No.	Check	Remark
1	Servo amplifier power supply ON for absolute axis.	A minor error (error code: 901 (power supply on in real mode)/9010 (power supply on in virtual mode)) are also set.
2	Anytime during real mode operation.	It also turns on at the following cases.  Home position return  Current value change  Fixed-pitch feed, speed control (I), (II) or speed-position switching control.

Reset the "Virtual mode continuation operation disable warning signal device" using the Motion SFC program.

## 4.1.2 Axis command signals

(1) Gain changing 2 command (M3206+20n) QDS( VEI)

...... Command signal


This signal is used to change the gain of servo amplifier (MR-J5(W)-□B) in the Motion controller by the gain changing 2 command ON/OFF.

- ON ...... Gain changing 2 command ON
- OFF ...... Gain changing 2 command OFF


When gain changing command (M3216+20n) and gain changing 2 command (M3206+20n) are both ON, the setting details of gain changing 2 command (M3206+20n) are prioritized.

Refer to the "Servo amplifier Instruction Manual" for details of gain changing function.

(2) Error reset command (M3207+20n) ...... Command signal This command is used to clear the minor error code storage register (D6+20n), and major error code storage register (D7+20n) of an axis for which the error detection signal has turn on (M2407+20n: ON), and reset the error detection signal (M2407+20n).



(3) Servo error reset command (M3208+20n) ............ Command signal This command is used to clear the servo error code storage register (D8+20) of an axis for which the servo error detection signal has turn on (M2408+20n: ON), and reset the servo error detection signal (M2408+20n).



Ver.!): Refer to Section 1.4 for the software version that supports this function.

## 

This signal is only effective when the output module is a cam connected an address mode clutch or a rotary table, and it is used to specify the "0" reference position for the current value within 1 virtual axis revolution.

The following processes are executed based on the ON/OFF state of the address clutch reference setting command at the real mode/virtual mode switching request.

#### (a) M3213+20n: ON

Virtual mode operation starts as "0" for the current value within 1 virtual axis revolution of the main shaft and auxiliary input axis.

#### (b) M3213+20n: OFF

- If the drive module is a virtual servo motor or an incremental synchronous encoder, operation will be continued from the current value within 1 virtual axis revolution for the main shaft and auxiliary input axis in the previous virtual mode.
- If the drive module is an absolute synchronous encoder, operation will be continued from the current value within 1 virtual axis revolution for the main shaft and auxiliary input axis calculated from the current value of synchronous encoder.

# (5) Cam reference position setting command (M3214+20n)


..... Command signal

This signal is only effective when the output module is a cam, and it is used to specify the cam reference position.

The following processes are executed based on the ON/OFF state of the cam reference position setting command at the real mode/virtual mode switching request.

#### (a) M3214+20n: ON

- The current value is cam reference position.
- The current feed current value is lower stroke limit value (bottom dead point). Moreover, a cam table search is conducted from the beginning of a cycle, and the bottom dead point (0) is specified as the current value within 1 cam shaft revolution.



 After the bottom dead point alignment of cam is completed at the system start-up, it must be turned on at the first real mode to virtual mode switching.

Once the bottom dead point setting is set, operation will be continued with M3214+20n ON by switching from real mode to virtual mode. (The bottom dead point position is stored in the backup memory.)

#### (b) M3214+20n: OFF

(Final servo command value in previous virtual mode operation)

- (Current servo current value) ≤ (In-position) .........
- For formula 1)

Operation will be continued by making the lower stroke limit value and current value within 1 cam shaft revolution into the lower stroke limit value and current value within 1 cam shaft revolution at the previous virtual mode operation.

(Final servo command value in previous virtual mode operation)

- (Current servo current value) > (In-position) ......2)
- For formula 2)


Current value within 1 cam shaft revolution for current feed current value is calculated and operation will be continued by making the lower stroke limit value into the lower stroke limit value at the previous virtual mode operation.

[Calculation of current value within 1 cam shaft revolution]

(Feed current value) = (Stroke amount) × (Stroke ratio) + (Lower stroke limit value)

The stroke ratio(y) used as above formula is calculated, the cam table of the setting cam No. is searched from the beginning of a cycle, and the current value within 1 cam shaft revolution for applicable point is calculated. Because the current value within 1 cam shaft revolution is searched always from the beginning of a cycle, beware of cases where the same stroke ratio appears more than once in the cycle.

(Make the necessary position adjustment at the real mode/virtual mode switching.)



(6)	Servo OFF command (M3215+20n)	Command signa
	This command is used to execute the servo C	OFF state (free run state) when all
	axes servo ON command (M2042) is ON.	

- OFF ..... Servo ON
- ON ..... Servo OFF (free run state)

Execute this command after positioning completion because it becomes invalid during positioning.

When the servo OFF command is executed in virtual mode, the clutch will be disengaged first. If it is executed while a "clutch ON" state, a minor error occurs and the servo OFF command becomes invalid.

# **∆** CAUTION

 Turn the power supply of the servo amplifier side off before touching a servo motor, such as machine adjustment.

- (7) Gain changing command (M3216+20n) ....... Command signal This signal is used to change the gain of servo amplifier in the Motion controller by the gain changing command ON/OFF.
  - ON ..... Gain changing command ON
  - OFF ...... Gain changing command OFF

When gain changing command (M3216+20n) and gain changing 2 command (M3206+20n) are both ON, the setting details of gain changing 2 command (M3206+20n) are prioritized.

Refer to the "Servo amplifier Instruction Manual" for details of gain changing function.

(8) PI-PID switching command (M3217+20n) QDS(

...... Command signal

This signal is used to change the PI-PID switching of servo amplifier in the Motion controller by the PI-PID switching command ON/OFF.

- ON ......PI-PID switching command ON(PID control)
- OFF ......PI-PID switching command OFF(PI control)


Refer to the "Servo amplifier Instruction Manual" for details of PI-PID switching function.

#### (9) Control loop changing command (M3218+20n)

...... Command signal

When using the fully closed loop control servo amplifier, this signal is used to change the fully closed loop control/semi closed loop control of servo amplifier in the Motion controller by the control loop changing command ON/OFF.

- ON ...... During fully closed loop control
- OFF ...... During semi closed loop control




Refer to the "Servo amplifier Instruction Manual" for details of control loop changing function.

#### **POINTS**

- (1) When the servo amplifier is not started (LED: "AA", "Ab", "AC", "Ad" or "AE"), if the control loop changing command is turned ON/OFF, the command becomes invalid.
- (2) When the following are operated during the fully closed loop, it returns to the semi closed loop control.
  - (a) Power supply OFF or reset of the Multiple CPU system
  - (b) Wire breakage of the SSCNET**I** cable between the servo amplifier and Motion controller
  - (c) Control circuit power supply OFF of the servo amplifier

#### 4.1.3 Virtual servo motor axis statuses

- (1) Positioning start complete signal (M4000+20n)
  - ..... Status signal
  - (a) This signal turns on with the start completion for the positioning control of the axis specified with the servo program. It does not turn on at JOG operation. It can be used to read an M-code (Note-1) at the positioning start.
  - (b) This signal turns off at leading edge of complete signal OFF command (M4804+20n) or positioning completion.



# REMARK

(Note-1): Refer to Chapter 7 of the "Q173D(S)CPU/ Q172D(S)CPU Motion controller (SV13/SV22) Programming manual (REAL MODE)".

- (2) Positioning complete signal (M4001+20n) ...... Status signal
  - (a) This signal turns on with the completion for the positioning control of the axis specified with the servo program.


It does not turn on at the start or stop on the way using JOG operation or speed control.

It does not turn on at the stop on the way during positioning.

It can be used to read an M-code at the positioning completion.

(Refer to Chapter 7 of the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV/13/SV22) Programming Manual (REAL MODE)".)


(b) This signal turns off at leading edge of complete signal OFF command (M4804+20n) or positioning start.




- (3) Command in-positioning signal (M4003+20n) ...... Status signal
  - (a) This signal turns on when the absolute value of the difference between the command position and the feed current value becomes below the "command in-position range" set in the parameters of virtual servo motor (Refer to Section 6.1.2).

This signal turns off in the following cases.

- · Positioning control start
- Speed control
- JOG operation
- (b) Command in-position check is continually executed during position control. This check is not executed during speed control.



- (4) Speed controlling signal (M4004+20n) ...... Status signal
  - (a) This signal turns on during speed control, and it is used as judgement of during the speed control or position control.
     The speed controlling signal that turned on with speed control turns off at the positioning control start of following figure.
  - (b) This signal turns off at the power supply on and during position control.



- (5) Error detection signal (M4007+20n) ...... Status signal
  - (a) This signal turns on when a minor error or major error is detected in a virtual servo motor or output module connected to a virtual servo motor.
     It is used as judgement of the error available/not available by turning the error detection signal on/off.
  - (b) When the error detection signal turns on, the applicable error code is stored in the error code storage register.
    - Minor error code (Note-1) ... Stored in the minor error code storage register (D802+20n) (Note-2).
    - Major error code (Note-1) ... Stored in the major error code storage register (D803+20n) (Note-2).

The judgement of the virtual servo motor/output module for detected error can be confirmed by the error code details or turning the error detection signal of output module on/off.

(c) When the error reset command (M4807+20n) turns on in the state where the virtual servo motor or output module connected to the virtual servo motor turns on is normal, the error detection signal turns off.


## REMARK

(Note-1): Refer to APPENDIX 1.4 for details of the virtual servo motor minor/major error codes.

Refer to APPENDIX 1.6 for details of the output module minor/major error codes.

(Note-2): Refer to Section 4.2.3 for details of the minor error storage code register (D802+20n) and major error code storage register (D803+20n).

- (6) M-code outputting signal (M4019+20n) ...... Status signal
  - (a) This signal turns during M-code is outputting.
  - (b) This signal turns off when the stop command, cancel signal, skip signal or FIN signal are inputted.




#### **POINT**

- (1) The FIN signal (M4819+20n) and M-code outputting signal (M4019+20n) are both signal for the FIN signal wait function.
- (2) The FIN signal (M4819+20n) and M-code outputting signal (M4019+20n) are effective only when FIN acceleration/deceleration is designated in the servo program. Otherwise, the FIN signal wait function is disabled, and the M-code outputting signal (M4019+20n) does not turn on.

### 4.1.4 Virtual servo motor axis command signals

- (1) Stop command (M4800+20n) ...... Command signal
  - (a) This command stops a starting axis from an external source and becomes effective at leading edge of signal. (An axis for which the stop command is turning on cannot be started.)



- (b) It can also be used as the stop command during the speed control. (Refer to Section "6.13 Speed Control (I)" of the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)" for details of the speed control.
- (c) Stop processing details when the stop command turned on is shown in Table 4.1.

Control details

during execution

During control

During deceleration stop processing

During deceleration stop processing

During deceleration stop processing

The axis decelerates to a stop in
Speed control

JOG operation


Processing at the turning stop command on

During deceleration stop processing in deceleration stop processing is continued.

Table 4.1 Stop Processing at Stop command ON

(d) The stop command in a dwell time is invalid. (After a dwell time, the start accept flag (M2001+n) turns OFF, and the positioning complete signal (M4001+20n) turns ON.)

- (2) Rapid stop command (M4801+20n) ...... Command signal
  - (a) This command stops a starting axis rapidly from an external source and becomes effective at leading edge of signal. (An axis for which the rapid stop command is turning on cannot be started.)



(b) The details of stop processing when the rapid stop command turns on are shown in Table 4.2.

Table 4.2 Details of stop processing when the rapid stop command turns on

Control details	Processing at the turn	ing rapid stop command on
during execution	During control	During deceleration stop processing
Positioning control	Rapid stop processing is executed.	Deceleration processing is stopped and rapid stop processing is executed.
Speed control	Parameter (Speed limit value) Stop cause	Setting speed—
JOG operation	Operation speed  Stop  Real deceleration time  Rapid stop deceleration time of the parameter block	Rapid stop cause Rapid stop deceleration processing Stop

(c) The rapid stop command in a dwell time is invalid. (After a dwell time, the start accept flag (M2001+n) turns OFF, and the positioning complete signal (M4001+20n) turns ON.)

# **REMARK**

(Note-1): Rapid stop processing is deceleration stop with deceleration time set in the parameter block or servo program.

- (3) Forward rotation JOG start command (M4802+20n)/Reverse rotation JOG start command (M4803+20n) .......... Command signal
  - (a) JOG operation to the address increase direction is executed while forward rotation JOG start command (M4802+20n) is turning on.
     When M4802+20n is turned off, a deceleration stop is executed in the deceleration time set in the parameter block.
  - (b) JOG operation to the address decrease direction is executed while reverse rotation JOG start command (M4803+20n) is turning on. When M4803+20n is turned off, a deceleration stop is executed in the deceleration time set in the parameter block.


#### **POINT**

Take an interlock so that the forward rotation JOG start command (M4802+20n) and reverse rotation JOG start command (M4803+20n) may not turn on simultaneously.

(4) Complete signal OFF command (M4804+20n)

...... Command signal

(a) This command is used to turn off the positioning start complete signal (M4000+20n) and positioning complete signal (M4001+20n).



#### **POINT**

Do not turn the complete signal OFF command on with a PLS instruction. If it is turned on with a PLS instruction, it cannot be turned off the positioning start complete signal (M4000+20n) and the positioning complete signal (M4001+20n).


- (5) Error reset command (M4807+20n) ...... Command signal
  - (a) This command is used to clear the minor error code storage register (D802+20n) and major error code storage register (D803+20n) of an axis for which the error detection signal has turn on (M4007+20n: ON), and reset the error detection signal (M4007+20n).
  - (b) The following processing is executed when the error reset command turns on
    - If the virtual servo motor and output module are normal, the minor error code storage register (D802+20n) and major error code storage register (D803+20n) are cleared and the error detection signal (M4007+20n) is reset
    - If the virtual servo motor and output module error has not been canceled, the error code is again stored in the minor error code storage register (D802+20n) and major error code storage register (D803+20n).
       In this case, the error detection signal (M4007+20n) remains on.
       Reset the output module error by error reset of each axis command signal to the output module.
- (6) External stop input disable at start command (M4809+20n) ...... Command signal

This command is used to set the external stop signal input valid or invalid.

- ON....... External stop input is set as invalid, and even axes which stop input is turning on can be started.
- OFF ......External stop input is set as valid, and axes which stop input is turning on cannot be started.

#### **POINT**

When it stops an axis with the external stop input after it starts by turning on the external stop input disable at start command (M4809+20n), switch the external stop input from OFF  $\rightarrow$  ON (If the external stop input is turning on at the starting, switch it from ON  $\rightarrow$  OFF  $\rightarrow$  ON).



#### **POINT**

- (1) The FIN signal (M4819+20n) and M-code outputting signal (M4019+20n) are both signal for the FIN signal wait function.
- (2) The FIN signal (M4819+20n) and M-code outputting signal (M4019+20n) are valid only when FIN acceleration/deceleration is designated in the servo program. Otherwise, the FIN signal wait function is disabled, and the M-code outputting signal does not turn on.

#### 4.1.5 Synchronous encoder axis statuses

- (1) Error detection signal (M4640+4n) ...... Status signal
  - (a) This signal turns on when a minor error or major error is detected in a synchronous encoder or output module connected to the synchronous encoder.
    - It is used as judgement of the error available/not available by turning the error detection signal on/off.
  - (b) When the error detection signal turns on, the applicable error code is stored in the error code storage register.
    - Minor error code (Note-1) ... Stored in the minor error code storage register (D1122+10n) (Note-2)
    - Major error code <sup>(Note-1)</sup>... Stored in the major error code storage register (D1123+10n) <sup>(Note-2)</sup>

The judgement of the synchronous encoder/output module for detected error can be confirmed by the error code details or turning the error detection signal of output module on/off.

- (c) When the error reset command (M5440+4n) turns on in the state where the synchronous encoder or output module connected to the synchronous encoder is normal, the error detection signal turns off.
- (2) External signal TREN (M4641+4n) ...... Status signal
  - (a) This signal is used for clutch control in the external input mode. It turns on by turning on the Q173DPX "TREN" input terminal, and indicates the input ON/OFF state of the "TREN" terminal.
    - Q172DEX does not turn ON regardless of the input status of TREN terminal.
- (3) Virtual mode continuation operation disabled warning signal (M4642+4n) ...... Status signal
  - (a) When the inputted current value at the power supply on of the Multiple CPU system differs from the memorized current value (Final current value in virtual mode operation) at the power supply off of the Multiple CPU system, like the absolute synchronous encoder is moved during the power supply off of the Multiple CPU system, this signal turns on.
    - The validity of continuation operation in virtual mode can be confirmed at the power supply on or resetting of the Multiple CPU system.

## REMARK

- (Note-1): Refer to APPENDIX 1.4 for details of the minor/major error code for the synchronous encoder.
  - Refer to APPENDIX 1.6 for details of the minor/major error code for the output module.
- (Note-2): Refer to Section 4.2.5 for details of the minor error code storage register (D1122+10n) and major error code storage register (D1123+10n).

## 4.1.6 Synchronous encoder axis command signals

- (1) Error reset command (M5440+4n) ...... Command signal
  - (a) This command is used to clear the minor error code storage register (D1122+10n) and major error code storage register (D1123+10n) of synchronous encoder of an axis for which the error detection signal has turn on (M4640+4n: ON), and reset the error detection signal (M4640+4n).
  - (b) The following processing is executed when the error reset command turns on.
    - If the synchronous encoder and output module are normal, the minor error code storage register (D1122+10n) and major error code storage register (D1123+10n) are cleared and the error detection signal (M4640+4n) is reset.
    - If the synchronous encoder and output module error has not been canceled, the error code is again stored in the minor error code storage register (D1122+10n) and major error code storage register (D1123+10n). In this case, the error detection signal (M4640+4n) remains on. Reset the output module error by error reset of each axis command signal to the output module.


#### 4.1.7 Common devices

#### **POINT**

- (1) Internal relays for positioning control are not latched even within the latch range.
- (2) The range devices allocated as internal relays for positioning control cannot be used by the user even if their applications have not been set.
- (1) PLC ready flag (M2000) ....... Command signal
  - (a) This signal informs the Motion CPU that the PLC CPU is normal.
    - The positioning control, home position return or JOG operation using the servo program which performs the Motion SFC program when the M2000 is ON.
    - The above 1) control is not performed even if the M2000 is turned on during the test mode [TEST mode ON flag (SM501): ON] using MT Developer2.
  - (b) The setting data such as the fixed parameters, servo parameters and limit switch output data can be changed using MT Developer2 when the M2000 is OFF only.

The above data using MT Developer2 cannot be written when the M2000 is ON.

- (c) The following processing are performed when the M2000 turns OFF to ON.
  - 1) Processing details
    - Clear the M-code storage area of all axes.
    - Turn the PCPU READY complete flag (SM500) on. (Motion SFC program can be executed.)
    - Start to execute the Motion SFC program of the automatic starting from the first.
  - 2) If there is a starting axis, an error occurs, and the processing in above (c) 1) is not executed.
  - 3) The processing in above (c) 1) is not executed during the test mode. It is executed when the test mode is cancelled and M2000 is ON.



- (d) The following processes are performed when the M2000 turns ON to OFF.
  - 1) Processing details
    - Turn the PCPU READY complete flag (SM500) off.
    - Deceleration stop of the starting axis.
    - Stop to execute the Motion SFC program.
    - Turn all points of the real output PY off.
- (e) Operation at STOP to RUN

Set the condition in which the PLC ready flag (M2000) turns ON. Select the following either.

- 1) M2000 turns ON by switching from STOP to RUN. (Default) Condition in which the M2000 turns from OFF to ON.
  - Move the RUN/STOP switch from STOP to RUN.
  - Turn ON the Multiple CPU system's power supply with the RUN/STOP switch set to RUN.

Condition in which the M2000 turns from ON to OFF

- Move the RUN/STOP switch from RUN to STOP.
- 2) M2000 turns ON by switching from STOP to RUN and by setting "1" in the setting register.

Condition in which the M2000 turns from OFF to ON


 Set "1" in the setting register (D704) of the PLC ready flag or turn ON the PLC ready flag (M3072) with the RUN/STOP switch set to RUN. (The Motion CPU detects the change from "0" to "1" in the lowest bit of D704).

Condition in which the M2000 turns from ON to OFF


- Set "0" in the setting register (D704) of the PLC ready flag or turn OFF the PLC ready flag (M3072) with the RUN/STOP switch set to RUN.
   (The Motion CPU detects the change from "1" to "0" in the lowest bit of D704).
- Move the RUN/STOP switch from RUN to STOP.

- (2) Virtual servo start accept flag (M2001 to M2032)
  - .....Status signal
  - (a) This flag turns on when the servo program is started. The start accept flag corresponding to an axis specified with the servo program turns on.
  - (b) The ON/OFF processing of the start accept flag is shown below.
    - 1) When the servo program is started using the Motion SFC program or Motion dedicated PLC instruction (D(P).SVST), the start accept flag corresponding to an axis specified with the servo program turns on and it turns off at the positioning completion. This flag also turns off when it is made to stopping on the way.

(When it is made to stop on the way by the speed change to speed "0", this flag remains on.)



- 2) This flag turns on at the positioning control by turning on the JOG start command (M4802+20n or M4803+20n), and turns off at the positioning stop by turning off the JOG start command.
- This flag turns on during the manual pulse generator enable (M2051 to M2053: ON), and turns off at the manual pulse generator disable (M2051 to M2053: OFF).
- 4) This flag turns on during a current value change by the CHGA instruction of servo program or Motion dedicated PLC instruction (D(P).CHGA), and turns off at the completion of the current value change.



The start accept flag list is shown below.

Axis No.	Device No.						
1	M2001	9	M2009	17	M2017	25	M2025
2	M2002	10	M2010	18	M2018	26	M2026
3	M2003	11	M2011	19	M2019	27	M2027
4	M2004	12	M2012	20	M2020	28	M2028
5	M2005	13	M2013	21	M2021	29	M2029
6	M2006	14	M2014	22	M2022	30	M2030
7	M2007	15	M2015	23	M2023	31	M2031
8	M2008	16	M2016	24	M2024	32	M2032

(Note): The following range is valid.


- Q172DSCPU : Axis No.1 to 16
- Q172DCPU(-S1): Axis No.1 to 8

# **Λ**CAUTION

- Do not turn the start accept flags ON/OFF in the user side.
  - If the start accept flag is turned off using the Motion SFC program or MT Developer2 while this flag is on, no error will occur but the positioning operation will not be reliable. Depending on the type of machine, it might operate in an unanticipated operation.
  - If the start accept flag is turned on using the Motion SFC program or MT Developer2 while this flag is off, no error will occur but the "start accept on error" will occur at the next starting and cannot be started.

(3)	Motion error history clear request flag (M2035)
. ,	
	This flag is used to clear the backed-up Motion error history (#8640 to #8735).
	The Motion error history is cleared at leading edge of M2035.
	After detection of the leading edge of M2035, the Motion error history is cleared, and then the M2035 is automatically turned OFF.
(4)	Motion SFC debugging flag (M2038) Status signal This flag turns on when it switches to the debug mode of the Motion SFC program using MT Developer2.
	It turns off with release of the debug mode.
(5)	Motion error detection flag (M2039)
	Turn off this flag by the user side, after checking the error contents and removing the error cause.
	The self-diagnosis error information except stop error is cleared at the turning M2039 ON to OFF.

- (6) Speed switching point specified flag (M2040) ...... Command signal This flag is used when the speed change is specified at the pass point of the constant speed control.
  - (a) By turning M2040 on before the starting of the constant speed control (before the servo program is started), control with the change speed can be executed from the first of pass point.
    - OFF ......... Speed is changed to the specified speed from the pass point of the constant speed control.
    - ON ......... Speed has been changed to the specified speed at the pass point of the constant speed control.



- - ON ..... Error
  - OFF ...... Normal
  - (a) When an error occurs, the 7-segment LED at the front side of Motion CPU shows the system setting error.

The error contents can be confirmed using the monitor of MT Developer2.


(b) When M2041 is ON, positioning cannot be started. Remove an error factor, and turn the Multiple CPU system's power supply on again or reset.

# REMARK

Even if the module which is not set as the system setting of MT Developer2 is installed in the slot, it is not set as the object of an adjustment check. And the module which is not set as the system setting cannot be used in the Motion CPU.

- (8) All axes servo ON command (M2042) ...... Command signal This command is used to enable servo operation.
  - (a) Servo operation enabled..... M2042 turns on while the servo OFF command (M3215+20n) is off and there is no servo error.
  - (b) Servo operation disable ...... M2042 is off
    - The servo OFF command (M3215+20n) is on
    - · Servo error state
    - Forced stop

Execute this command after positioning completion because it becomes invalid in positioning.



(Note): Refer to servo ready signal (M2415+20n) in Section 4.1.1 for details.

#### POINT

When M2042 turns ON, it is not turned off even if the Motion CPU is set in the STOP state.

M2042 turns OFF by the forced stop of Motion CPU.

(9) Real mode/virtual mode switching request flag (M2043)

..... Command signal

This flag is used for switching between the real mode and virtual modes.

- (a) Turn the M2043 on after the PCPU READY complete flag (SM500) has turn on for switching from the real mode to virtual mode.
  - An error check is executed when the M2043 is switched from off to on.
     If no error is detected, switch to the virtual mode, and the real mode/virtual mode status switching status flag (M2044) turns on.
  - If an error is detected, not switch to the virtual mode. In this case, the real mode/virtual mode switching error detection flag (M2045) turns on, and the error code is stored in the real mode/virtual mode switching error code storage register (SD504).
- (b) Turn the M2043 off for switching from the virtual mode to real mode.
  - If all axes of the virtual servo motors stopped, switch to the real mode, and the real mode/virtual mode status switching status flag (M2044) turns off.
  - If the virtual servo motor is operating also with 1 axis, not switch to the real mode. In this case, the real mode/virtual mode switching error detection flag (M2045) turns on, and the error code is stored in the real mode/virtual mode switching error code storage register (SD504).
- (c) Refer to Chapter 9 for switching between the real mode and virtual modes.

(10)	Real mode/virtual mode switching status flag (M2044)Status signal
	This flag checks the switching completion between the real mode and virtual modes, and the current mode.  • This flag turns off with during the real mode or switching completion from the virtual mode to real mode.  • This flag turns on with switching completion from the real mode to virtual mode.
	It can be used as an interlock for the servo program start or control change (speed change, current value change).
(11)	Real mode/virtual mode switching error detection flag (M2045)Status signal
	This flag is used as judgement of the error available/not available at the mode switching (between the real mode and virtual modes).  • This flag remains off if no error was detected at mode switching.  • This flag turns on if an error was detected at mode switching.
	In this case, the error code is stored in the real mode/virtual mode switching error code storage register (SD504).
(12)	Out-of-sync warning flag (M2046)
	<ul><li>(b) This out-of-sync warning flag (M2046) turns on the following cases.</li><li>• Stop by the forced stop.</li><li>• The servo error in the output module.</li></ul>
	<ul> <li>(c) When the out-of-sync warning flag (M2046) turns on, resume operation by the following procedure.</li> <li>1) Return to the real mode and eliminate the error cause.</li> <li>2) Synchronize the axes.</li> <li>3) Turn the out-of-sync warning flag (M2046) off.</li> <li>4) Switch to the virtual mode.</li> </ul>
	5) Resume operation.

- - ON ........ Installed module is abnormal
  - OFF ...... Installed module is normal


The module information at the power supply on and after the power supply on are always checked, and errors are detected.

- (a) When M2047 turns OFF in operation, the operating axis decelerates to a stop.
- (b) When an error occurs, the 7-segment LED at the front side of Motion CPU shows the system setting error.
  - The error contents can be confirmed using the monitor of MT Developer2.
- (c) When M2047 is ON, positioning cannot be started. Remove an error factor, and turn the Multiple CPU system's power supply on again or reset.
- (14) JOG operation simultaneous start command (M2048)

..... Command signal

- (a) When M2048 turns on, JOG operation simultaneous start based on the JOG operation execution axis set in the JOG operation simultaneous start axis setting register (D710 to D713).
- (b) When M2048 turns OFF, the operating axis decelerates to a stop.
- (15) All axes servo ON accept flag (M2049) ...... Status signal This flag turns on when the Motion CPU accepts the all axes servo ON command (M2042).

Since the servo ready state of each axis is not checked, confirm it in the servo ready signal (M2415+20n).



(Note): Refer to servo ready signal (M2415+20n) in Section 4.1.1 for details.

This flag set the enabled or disabled state for positioning with the pulse input from the manual pulse generators connected to P1 to P3 (Note) of the Q173DPX.

- ON ....... Positioning control is executed by the input from the manual pulse generators.
- OFF ..... Positioning control cannot be executed by the manual pulse generators because of the input from the manual pulse generators is ignored.

Default value is invalid (OFF).

## REMARK

(Note): Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller User's Manual" for P1 to P3 connector of the Q173DPX.

- - Turn the power supply of the Multiple CPU system on to off
  - Reset the Multiple CPU system
  - Reset using the user program

[Operation cycle over measures]


- 1) Change the operation cycle into a large value in the system setting.
- 2) The number of instruction completions of an event task or NMI task in the Motion SFC program.

## (18) Speed change accepting flag (M2061 to M2092)

.....Status signal

This flag turns on at start of speed change by the control change (CHGV) instruction of the Motion SFC program.

The flag does not turn on when Motion dedicated PLC instruction (D(P).CHGV) is used.



The speed change accepting flag list is shown below.


Axis No.	Device No.						
1	M2061	9	M2069	17	M2077	25	M2085
2	M2062	10	M2070	18	M2078	26	M2086
3	M2063	11	M2071	19	M2079	27	M2087
4	M2064	12	M2072	20	M2080	28	M2088
5	M2065	13	M2073	21	M2081	29	M2089
6	M2066	14	M2074	22	M2082	30	M2090
7	M2067	15	M2075	23	M2083	31	M2091
8	M2068	16	M2076	24	M2084	32	M2092


(Note): The following range is valid.

• Q172DSCPU : Axis No.1 to 16

• Q172DCPU(-S1): Axis No.1 to 8

- (19) Automatic decelerating flag (M2128 to M2159) ........ Status signal This signal turns on while automatic deceleration processing is performed during the positioning control or position follow-up control.
  - (a) This flag turns on while automatic deceleration to the command address at the position follow-up control, but it turns off if the command address is changed.
  - (b) This signal turns on while automatic deceleration processing is performed during execution of positioning to final point while in constant speed control.






#### **POINT**

Set a travel value in which automatic deceleration processing can be started at the final positioning point, therefore the automatic decelerating flag turns on at the start point of automatic deceleration processing after this final point.

- (c) The signal turns off when all normal start complete commands became achieve.
- (d) The automatic decelerating flag (M2128+n) might be turned ON even during acceleration at advanced S-curve acceleration/deceleration.

- (e) In any of the following cases, the automatic decelerating flag (M2128+20n) does not turn off.
  - · During deceleration due to JOG signal off
  - During manual pulse generator operation
  - During deceleration due to stop command or stop cause occurrence
  - · When travel value is 0



The automatic decelerating flag list is shown below.

Axis No.	Device No.	Axis No.	Device No.	Axis No.	Device No.	Axis No.	Device No.
1	M2128	9	9 M2136		17 M2144		M2152
2	M2129	M2129 10 M2137 18		M2145	26	M2153	
3	M2130	11	M2138	19	M2146	27	M2154
4	M2131	12	M2139	20	M2147	28	M2155
5	M2132	13 M21		21	M2148	29	M2156
6	M2133	14	M2141	22	M2149	30	M2157
7	M2134	15	M2142	23	M2150	31	M2158
8	M2135	16	M2143	24	M2151	32	M2159

(Note): The following range is valid.

• Q172DSCPU : Axis No.1 to 16


• Q172DCPU(-S1): Axis No.1 to 8

### (20) Speed change "0" accepting flag (M2240 to M2271)

.....Status signal

This flag turns on while a speed change request to speed "0" or negative speed change request is being accepted.

It turns on when the speed change request to speed "0" or negative speed change request is accepted during a start. After that, this signal turns off when a speed change is accepted or on completion of a stop due to a stop cause.



The speed change "0" accepting flag list is shown below.


Axis No.	Device No.						
1	M2240	9	M2248	17	M2256	25	M2264
2	M2241	10	M2249	18	M2257	26	M2265
3	M2242	11	M2250	19	M2258	27	M2266
4	M2243	12	M2251	20	M2259	28	M2267
5	M2244	13	M2252	21	M2260	29	M2268
6	M2245	14	M2253	22	22 M2261		M2269
7	M2246	15	M2254	23	M2262	31	M2270
8	M2247	16	M2255	24	M2263	32	M2271

(Note): The following range is valid.

- Q172DSCPU : Axis No.1 to 16
- Q172DCPU(-S1): Axis No.1 to 8

## REMARK

- (1) Even if it has stopped, when the start accept flag (M2001+n) is ON state, the state where the request of speed change "0" is accepted is indicated. Confirm by this speed change "0" accepting flag (M2240+n).
- (2) During interpolation, the flags corresponding to the interpolation axes are set.
- (3) In any of the following cases, the speed change "0" request is invalid.
  - · After deceleration by the JOG signal off
  - · After positioning automatic deceleration start
  - After deceleration due to stop cause
  - (a) The flag turns off if a speed change request occurs during deceleration to a stop due to speed change "0".



Speed change "0" accepting flag

(M2240+n)

OFF

Start accept flag (M2001+n)


OFF

ON


ON

(b) The flag turns off if a stop cause occurs after speed change "0" accept.

(c) The speed change "0" accepting flag (M2240+n) does not turn on if a speed change "0" occurs after an automatic deceleration start.



(d) Even if it is speed change "0" after the automatic deceleration start to the "command address", speed change "0" accepting flag (M2240+n) turns on.



# REMARK

It does not start, even if the "command address" is changed during speed change "0" accepting.


### (21) Control loop monitor status (M2272 to M2303)

..... Command signal

When using the fully closed loop control servo amplifier, this signal is used to check the fully closed loop control/semi closed loop control of servo amplifier.

- ON ....... During fully closed loop control
- OFF ...... During semi closed loop control

It can be changed the fully closed loop control/semi closed loop control of servo amplifier in the Motion controller by the control loop changing command ON/OFF.



The Control loop monitor status list is shown below.

Axis No.	Device No.						
1	M2272	9	9 M2280		M2288	25	M2296
2	M2273	10	M2281	18	M2289	26	M2297
3	M2274	11	M2282	19	M2290	27	M2298
4	M2275	12	M2283	20	M2291	28	M2299
5	M2276	13 M2284		21	M2292	29	M2300
6	M2277	14	M2285	22	M2293	30	M2301
7	M2278	15	M2286	23	M2294	31	M2302
8	M2279	16	M2287	24	M2295	32	M2303

(Note): The following range is valid.

• Q172DSCPU : Axis No.1 to 16

• Q172DCPU(-S1): Axis No.1 to 8

# 4.2 Data Registers

# (1) Data register list

	SV22			]
Device No.	Application	Real	Virtual	
D0 to	Axis monitor device (20 points × 32 axes) Real mode : Each axis Virtual mode : Output module	0	0	
D640 to	Control change register (2 points × 32 axes)	0	0	Real/virtual community
D704 to	Common device (Command signal) (54 points)	0	0	
D758 to	Unusable (42 points)	_	_	
D800	Virtual servo motor axis monitor device (6 points × 32 axes) (Note-1)  Current value after virtual servo motor axis main shaft's differential gear (4 points × 32 axes) (Note-1)	Backup		
D1120	Synchronous encoder axis monitor device (6 points × 12 axes)	Backup (Note-2)	0	→ Virtual
to	Current value after synchronous encoder axis main shaft's differential gear (4 points × 12 axes)	Backup		
D1240	Cam axis monitor device (10 points × 32 axes) (Note-1)			
D1560 to D8191	User device (6632 points)			

It can be used as a user device.

#### **POINT**

- (1) Total number of points for the user devices 6632 points
- (2) (Note-1): This device occupies only the areas of the axes set in the mechanical system program. The unused axis areas in the mechanical system program can be used as a user side.
- (3) (Note-2): It is valid for the version (Refer to Section 1.4) that supports "synchronous encoder current value monitor in real mode".
- (4) This manual describes only details for data registers used in the virtual mode. If it is required, refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)".

## (2) Axis monitor device list

Axis No.	Device No.					S	ignal na	me				
1	D0 to D19											
2	D20 to D39				Virtual							
3	D40 to D59		O: .						Real	Refresh	Fetch	Signal
4	D60 to D79	1\	Signal name	Real	Roller	Ball screw	Rotary	Cam	mode	cycle	cycle	direction
5	D80 to D99						table		axis			
6	D100 to D119	0	Feed current									
7	D120 to D139	1	value/roller cycle speed								/	
8	D140 to D159	2	D1							Operation	/	
9	D160 to D179	3	Real current value							cycle		
10	D180 to D199	4	Deviation counter value			(	С		0			
11	D200 to D219	5	Deviation counter value									
12	D220 to D239	6	Minor error code							Immodiately.		Monitor
13	D240 to D259	7	Major error code							Immediately		
14	D260 to D279	8	Servo error code	0						Main cycle		
15	D280 to D299	9	Home position return		Backup			Backup			device	
16	D300 to D319	9	re-travel value					Баскир	Operation			
17	D320 to D339	10	Travel value after			Баскир				cycle		
18	D340 to D359	11	proximity dog ON									
19	D360 to D379	12	Execute program No.			×				At start	. /	
20	D380 to D399	13	M-code						0	Operation	1/	
21	D400 to D419	14	Torque limit value			(	)			cycle	/	
22	D420 to D439	15	Data set pointer for				×			At start/	/	
23	D440 to D459	13	constant-speed control							during start		
24	D460 to D479	16	Unusable <sup>(Note-1)</sup>	_		_	_		_	_	_	_
25	D480 to D499	17	- Indubio						_	_		
26	D500 to D519	18	Real current value at	0		Ba	ckup		0	Operation		Monitor
27	D520 to D539	19	stop input	Ŭ		Dat	жир		Ŭ	cycle		device
28	D540 to D559										○ : Valid	×: Invalid
29	D560 to D579											
30	D580 to D599											
31	D600 to D619											
32	D620 to D639											

(Note-1): It can be used as the travel value change register. The travel value change register can be set to the device optionally in the servo program.

Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)" for details.

### **POINT**

(1) The following range is valid.

Q172DSCPU : Axis No.1 to 16Q172DCPU(-S1): Axis No.1 to 8

(2) The following device area can be used as a user device.

• Q172DSCPU : 17 axes or more • Q172DCPU(-S1): 9 axes or more

However, when the project of Q172DSCPU/Q172DCPU(-S1) is replaced with Q173DSCPU/Q173DCPU(-S1), this area cannot be used as a user device.

## (3) Control change register list

Axis No.	Device No.			Signal	name			
1	D640, D641							
2	D642, D643 D644, D645		Signal name	Real	Virtual	Refresh cycle	Fetch cycle	Signal direction
4	D644, D645 D646, D647	0	JOG speed setting	0	0	cycle	At start	Command
5	D648, D649	1	1000 speed setting		Ŭ		At Start	device
6	D650, D651							○ : Valid
7	D652, D653							
8	D654, D655							
9	D656, D657							
10	D658, D659							
11	D660, D661							
12	D662, D663							
13	D664, D665							
14	D666, D667							
15	D668, D669							
16	D670, D671							
17	D672, D673							
18	D674, D675							
19	D676, D677							
20	D678, D679							
21	D680, D681							
22	D682, D683							
23	D684, D685							
24	D686, D687							
25	D688, D689							
26	D690, D691							
27	D692, D693							
28	D694, D695							
29	D696, D697							
30	D698, D699							
31	D700, D701							
32	D702, D703							

### **POINT**

(1) The following range is valid.

• Q172DSCPU : Axis No.1 to 16 • Q172DCPU(-S1): Axis No.1 to 8

(2) The following device area can be used as a user device.

Q172DSCPU : 17 axes or moreQ172DCPU(-S1): 9 axes or more

However, when the project of Q172DSCPU/Q172DCPU(-S1) is replaced with Q173DSCPU/Q173DCPU(-S1), this area cannot be used as a user device.

## (4) Virtual servo motor axis monitor device list

Axis No.	Device No.					S	ignal na	ame					
1	D800 to D809												_
2	D810 to D819	$\setminus$						Virtual					
3	D820 to D829	1	ιl	0: 1			,			Real	Refresh	Fetch	Signal
4	D830 to D839		$\setminus \mid$	Signal name	Real	Roller	Ball	Rotary	Cam	mode	cycle	cycle	direction
5	D840 to D849		$\setminus$				screw	table		axis			
6	D850 to D859	(	)	F d							Operation		
7	D860 to D869	Ľ	1	Feed current value							cycle	] /	
8	D870 to D879	2	2	Minor error code							luarua a ali ada lu		
9	D880 to D889	3	3	Major error code							Immediately		
10	D890 to D899	4	4	Execute program No.							At start		
11	D900 to D909	ţ	5	M-code	Daaloo	0				\ \ \			Monitor
12	D910 to D919	6	ŝ	Current value after virtual	Backup			)		×			device
13	D920 to D929	I.	7	servo motor axis main							Operation	1 /	
14	D930 to D939		′	shaft's differential gear							Operation cycle	1/	
15	D940 to D949	8	3	Error search output axis No.						Cycle	1/		
16	D950 to D959	Ι,	9	Data set pointer for								/	
17	D960 to D969	Ľ	9	constant-speed control									
18	D970 to D979										0:	Valid,	×: Invalid
19	D980 to D989												
20	D990 to D999												
21	D1000 to D1009												
22	D1010 to D1019												
23	D1020 to D1029												
24	D1030 to D1039												
25	D1040 to D1049												
26	D1050 to D1059												
27	D1060 to D1069												
28	D1070 to D1079												
29	D1080 to D1089												
30	D1090 to D1099												
31	D1100 to D1109												
32	D1100 to D1119												

## POINT

(1) The following range is valid.

Q172DSCPU : Axis No.1 to 16Q172DCPU(-S1): Axis No.1 to 8

(2) The unused axis areas in the mechanical system program can be used as a user device.

## (5) Synchronous encoder axis monitor device list

Axis No.	Device No.	Signal name						
1	D1120 to D1129							_
2	D1130 to D1139		Cianal mana	Deel	\ /: who is all	Refresh	Catala avala	Signal
3	D1140 to D1149		Signal name	Real	Virtual	cycle	Fetch cycle	direction
4	D1150 to D1159	0	Command walks	Backup		Operation		
5	D1160 to D1169	1	Current value	(Note-1)		cycle		Monitor
6	D1170 to D1179	2			O	Immediately		device
7	D1180 to D1189	3						
8	D1190 to D1199	4	Unusable					
9	D1200 to D1209	5	Offusable			_	_	_
10	D1210 to D1219	6	6 Current value after synchronous encoder 7 axis main shaft's differential gear			Operation cycle		Monitor device
11	D1220 to D1229	7						
12	D1230 to D1239	8 Error search output axis No.						
		9	Unusable	_	_	_	_	_
								○ : Valid
		(No	ote-1): It is valid for the version (Refer to Se value monitor in real mode".	ection 1.4	) that sup	ports "synchr	onous encode	r current

## POINT

- (1) It is unusable in the SV22 real mode.
- (2) The range of axis No.1 to 8 is valid in the Q172DCPU(-S1).
- (3) The device area of 9 axes or more can be used as a user device. However, when the project of Q172DCPU(-S1) is replaced with Q173DSCPU/Q172DSCPU/Q173DCPU(-S1), this area cannot be used.

## (6) Cam axis monitor device list

Axis No.	Device No.			Signal name				
1	D1240 to D1249							
2	D1250 to D1259	$\setminus$	<u> </u>			Refresh		Signal
3	D1260 to D1269	L	Signal name	Real	Virtual	cycle	Fetch cycle	direction
4	D1270 to D1279	0	Unusable	_	_		_	_
5	D1280 to D1289	1	Execute cam No.					
6	D1290 to D1299	2	Furnita atraka arasunt			O		N.4 i4
7	D1300 to D1309	3	Execute stroke amount	Backup	0	Operation cycle		Monitor device
8	D1310 to D1319	4	Current value within 1 cam shaft			cycle		device
9	D1320 to D1329	5	revolution					
10	D1330 to D1339	6						
11	D1340 to D1349	7	I become letter			_	_	_
12	D1350 to D1359	8	Unusable	_				
13	D1360 to D1369	9						
14	D1370 to D1379							○ : Valid
15	D1380 to D1389							
16	D1390 to D1399							
17	D1400 to D1409							
18	D1410 to D1419							
19	D1420 to D1429							
20	D1430 to D1439							
21	D1440 to D1449							
22	D1450 to D1459							
23	D1460 to D1469							
24	D1470 to D1479							
25	D1480 to D1489							
26	D1490 to D1499							
27	D1500 to D1509							
28	D1510 to D1519							
29	D1520 to D1529							
30	D1530 to D1539							
31	D1540 to D1549							
32	D1550 to D1559							

## POINT

(1) The following range is valid.

• Q172DSCPU : Axis No.1 to 16 • Q172DCPU(-S1) : Axis No.1 to 8

(2) The unused axis areas in the mechanical system program can be used as a user device.

# (7) Common device list

Device			illion devic	Signal	Device				Signal
No.	Signal name	Refresh cycle	Fetch cycle	direction	No.	Signal name	Refresh cycle	Fetch cycle	direction
D704	PLC ready flag request				D752	Manual pulse generator 1 smoothing magnification setting register			
D705	Speed switching point specified flag request			Command	D753	Manual pulse generator 2 smoothing magnification setting register		At the manual pulse generator enable flag OFF to ON	
D706	All axes servo ON command request		Main cycle	device	D754	Manual pulse generator 3 smoothing magnification setting register			Command device
D707	Real mode/virtual mode switching request (SV22)				D755	Manual pulse generator 1 enable flag request			
D708	JOG operation simultaneous start command request	/			D756	Manual pulse generator 2 enable flag request		Main cycle	
D709	Unusable	_	_	_	D757	Manual pulse generator 3 enable flag request	ual pulse generator 3  le flag request		
D710 D711	JOG operation simultaneous				D758 D759				
D712	start axis setting register	1	At start		D760				
D713					D761				
D714 D715	Manual pulse generator axis 1 No. setting register	1			D762 D763				
D716	Manual pulse generator axis	1			D764				
D717	2 No. setting register				D765				
D718	Manual pulse generator axis	1			D766				
D719 D720	3 No. setting register Axis 1				D767 D768				
D721	Axis 2	1			D769				
D722	Axis 3	1			D770				
D723	Axis 4	1			D771				
D724	Axis 5	1			D772				
D725 D726	Axis 6 Axis 7	1			D773 D774				
D727	Axis 8	1			D775				
D728	Axis 9				D776				
D729	Axis 10	1			D777				
D730	Axis 11			Command	D778	Unusable	_	_	_
D731 D732	Axis 12 Axis 13	1	At the manual pulse	device	D779 D780	(42 points)			
D733	Axis 14		generator enable flag		D781				
D734	Axis 15 Manual pulse	1	OFF to ON		D782				
D735	Axis 16 generators 1 pulse input magnification				D783				
D736	Axis 17 setting register	1 /			D784				
D737 D738	Axis 18 (Note-1), (Note-2)  Axis 19	1 /			D785 D786				
D739	Axis 20				D787				
D740	Axis 21				D788				
	Axis 22	1 /			D789				
D742	Axis 23	1 /			D790				
D743 D744	Axis 24 Axis 25	1 /			D791 D792				
D744 D745	Axis 26	1 /			D792 D793				
D746	Axis 27	1 /			D794				
D747	Axis 28	17			D795				
D748	Axis 29	1/			D796				
D749	Axis 30	/			D797				
D750 D751	Axis 31 Axis 32	V			D798 D799				
ונוט	TAID JZ			I	פפוט		l Note-1): The followi		I

(Note-1): The following range is valid.

• Q172DSCPU : Axis No.1 to 16

• Q172DCPU(-S1) : Axis No.1 to 8

(Note-2): The following device area is unusable.

• Q172DSCPU : 17 axes or more

• Q172DCPU(-S1) : 9 axes or more

#### 4.2.1 Axis monitor devices

The monitoring data area is used by the Motion CPU to store data such as the feed current value during positioning control, the real current value and the deviation counter value.

It can be used to check the positioning control state using the Motion SFC program. The user cannot write data to the monitoring data area.

Refer to "APPENDIX 3 Processing Times of the Motion CPU" for the delay time between a positioning device (input, internal relay and special relay) turning on/off and storage of data in the monitor data area.

- - (a) The target address which is output to the servo amplifier is stored in this register. The target address is based on the command address calculated from the mechanical system program settings.
  - (b) The stroke range check is performed on this feed current value data.
  - (c) Roller cycle speed is stored. The storage range for cycle speed the roller cycle speed storage register is shown below.

Setting Units	Storage Range	Real Roller Cycle Speed			
mm		0.01 to 6000000.00 [mm/min]			
inch	1 to 600000000	0.001 to 600000.000 [inch/min]			

- - (b) The "feed current value" is equal to the "real current value" in the stopped

feedback position of the motor encoder (in pulse unit).

state.

- (4) Minor error code storage register (D6+20n) ...... Monitor device
  - (a) This register stores the corresponding error code (Refer to APPENDIX 1.4 and 1.6) at the minor error occurrence. If another minor error occurs after error code storing, the previous error code is overwritten by the new error code.
  - (b) Minor error codes can be cleared by an error reset command (M3207+20n).

- (5) Major error code storage register (D7+20n) ...... Monitor device
  - (a) This register stores the corresponding error code (Refer to APPENDIX 1.4 and 1.6) at the major error occurrence. If another major error occurs after error code storing, the previous error code is overwritten by the new error code.
  - (b) Major error codes can be cleared by an error reset command (M3207+20n).
- (6) Servo error code storage register (D8+20n) ...... Monitor device
  - (a) This register stores the corresponding error code (Refer to APPENDIX 1.5) at the servo error occurrence. If another servo error occurs after error code storing, the previous error code is overwritten by the new error code.
  - (b) It returns to the real mode by the servo error.
  - (c) For MR-J5(W)- B, the register stores error codes (2000 or 2100) (Refer to APPENDIX 1.5) at the servo error occurrence.

    Error codes read by the servo amplifier are stored in the servo amplifier display servo error code (#8008+20n).
- (7) Torque limit value storage register (D14+20n) ......... Monitor device
  - (a) This register stores the positive direction torque limit value to command the servo amplifier (unit: [%]). The default value "300[%]" is stored at the power supply of servo amplifier ON.
  - (b) To monitor the positive/negative direction torque limit value, set "Positive Direction Torque Limit Value Monitor Device" and "Negative Direction Torque Limit Value Monitor Device" with the expansion parameter. (Refer to "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)" for details of expansion parameter.)

### 4.2.2 Control change registers

This area stores the JOG operation speed data of the virtual servo motor axis.

Table 4.3 Data storage area for control change list

Name	Axis 1	Axis 2	Axis 3	Axis 4	Axis 5	Axis 6	Axis 7	Axis 8
	D641, D640	D643, D642	D645, D644	D647, D646	D649, D648	D651, D650	D653, D652	D655, D654
	Axis 9	Axis 10	Axis 11	Axis 12	Axis 13	Axis 14	Axis 15	Axis 16
JOG speed	D657, D656	D659, D658	D661, D660	D663, D662	D665, D664	D667, D666	D669, D668	D671, D670
setting	Axis 17	Axis 18	Axis 19	Axis 20	Axis 21	Axis 22	Axis 23	Axis 24
register	D673, D672	D675, D674	D677, D676	D679, D678	D681, D680	D683, D682	D685, D684	D687, D686
	Axis 25	Axis 26	Axis 27	Axis 28	Axis 29	Axis 30	Axis 31	Axis 32
	D689, D688	D691, D690	D693, D692	D695, D694	D697, D696	D699, D698	D701, D700	D703, D702

(Note): The following range is valid.

• Q172DSCPU : Axis No.1 to 16 • Q172DCPU(-S1) : Axis No.1 to 8

(1) JOG speed setting registers (D640+2n, D641+2n)

...... Command device


- (a) This register stores the JOG speed at the JOG operation.
- (b) Setting range of the JOG speed is shown below.

Unit	pulse				
Item	Setting Range	Unit			
JOG speed	1 to 2147483647	[pulse/s]			

- (c) The JOG speed is the value stored in the JOG speed setting registers (D640+2n, D641+2n) at leading edge of the JOG start signal. Even if data is changed during JOG operation, JOG speed cannot be changed.
- (d) Refer to Section 6.21 of the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)" for details of the JOG operation.

#### 4.2.3 Virtual servo motor axis monitor devices

- (1) Feed current value storage register (D800+10n, D801+10n)
  - ...... Monitor device
  - (a) This register stores the target address output to the servo amplifier based on the positioning address/travel value specified with the servo program.
  - (b) The stroke range check is performed on this feed current value data.
  - (c) Ring address is -2147483648 ( $-2^{31}$ ) [pulse] to 2147483647 ( $2^{31}$ -1) [pulse] in the infinite operation.



- (d) The data of feed current value storage register is also stored in a backup memory at the power supply off or resetting of the Multiple CPU system.
- (2) Minor error code storage register (D802+10n)

command (Note-2) of the output module.

- ...... Monitor device
- (a) This register stores the corresponding error code (refer to APPENDIX 1.4 and 1.6) at the minor error occurrence in the virtual servo motor or output module. If another minor error occurs after error code storing, the previous error code is overwritten by the new error code.
- (b) Minor error codes in the virtual servo motor can be cleared by an error reset command (Note-1) of the drive module.
  Minor error codes in the output module can be cleared by an error reset

# REMARK

- (Note-1): Refer to Section 4.1.4 for details of the error reset command for the virtual servo motor axis.
- (Note-2): Refer to Section 4.1.2 for details of the error reset command for the output module.

- - (a) This register stores the corresponding error code (refer to APPENDIX 1.4 and 1.6) at the major error occurrence in the virtual servo motor or output module. If another major error occurs after error code storing, the previous error code is overwritten by the new error code.
  - (b) Major error codes in the virtual servo motor can be cleared by an error reset command (Note-1) of the drive module.
     Major error codes in the output module can be cleared by an error reset command (Note-2) of the output module.


# REMARK

- (Note-1): Refer to Section 4.1.4 for details of the error reset command for the virtual servo motor axis.
- (Note-2): Refer to Section 4.1.2 for details of the error reset command for the output module.


### 4.2.4 Current value after virtual servo motor axis main shaft's differential gear

(1) Current value after virtual servo motor axis main shaft's differential gear storage register (D806+10n, D807+10n)

..... Monitor device



- (a) The current value will be the same as the drive module current value of the main shaft side at the virtual mode switching.
- (b) When the current value change is executed toward the drive module current value of the main shaft side, the current value after main shaft's differential gear is also simultaneous changed to the specified current value.
- (c) If the differential gear is not connected with the main shaft, drive module feed current value of the main shaft side is always stored in the current value storage register after main shaft's differential gear.
- (d) In the case of following figure, use "current value after virtual servo motor axis main shaft's differential gear" of axis 1 as "current value after virtual servo motor axis main shaft's differential gear".
  (The drive module feed current value of the auxiliary input axis side is stored as "current value after virtual servo motor axis main shaft's differential gear" of axis 2.)



- - (a) This register stores the axis No. of the output module in error by the error search function in the virtual mode.
  - (b) If there are no errors at the virtual servo motor axes of the main shaft and auxiliary input axis, the error occurrence output axis No. is stored into the error search output axis No. storage register of the corresponding drive module No. when a minor or major error occurs at the connected output axis.
  - (c) Error search and error reset
    - 1) Searching the main shaft for error The output axes connected to the main shaft are searched for an error in order of lower to higher numbers. If either a minor or major error has occurred, the corresponding output axis No. is stored into the error search output axis No. storage register. Resetting the error of the corresponding output axis stores the other error occurrence output axis No. connected to the same main shaft.
    - 2) Searching the auxiliary input axis for error If either a minor or major error has occurred at the output axis connected to the auxiliary input axis, the corresponding output axis No. is stored into the error search output axis No. storage register. However, when the differential gear (for virtual main shaft connection) is used to provide auxiliary input to the main shaft, the output axis connected to the auxiliary input axis is not searched for an error. Use the main shaft side error search output axis No. storage register to confirm the error occurrence output axis No.
  - (d) When error occurs at the drive module axis

    When an error occurs at the main shaft/auxiliary input axis to which the output axis is connected, "0" (no error) is stored into the error search output axis No. storage device if an error occurred at the output axis.

### 4.2.5 Synchronous encoder axis monitor devices

- - (a) This register stores the synchronous encoder current value.
  - (b) Ring address is "-2147483648 ( -2<sup>31</sup>) to 2147483647 (2<sup>31</sup>-1)" [pulse].
  - (c) The current value storage register data is also stored in a backup memory at the power supply off or resetting of the Multiple CPU system.
- (2) Minor error code storage register (D1122+10n) ....... Monitor device
  - (a) This register stores the corresponding error code (refer to APPENDIX 1.4 and 1.6) at the minor error occurrence in the synchronous encoder or output module. If another minor error occurs after error code storing, the previous error code is overwritten by the new error code.
  - (b) Minor error codes in the synchronous encoder can be cleared by an error reset command (Note-1) of the synchronous encoder axis.
     Minor error codes in the output module can be cleared by an error reset command (Note-2) of the output module.

# REMARK

- (Note-1): Refer to Section 4.1.6 for details of the error reset command for the synchronous encoder axis.
- (Note-2): Refer to Section 4.1.2 for details of the error reset command for the output module.
- (3) Major error code storage register (D1123+10n) ....... Monitor device
  - (a) This register stores the corresponding error code (refer to APPENDIX 1.4 and 1.6) at the major error occurrence in the synchronous encoder or output module. If another major error occurs after error code storing, the previous error code is overwritten by the new error code.
  - (b) Major error codes in the synchronous encoder axis can be cleared by an error reset command (Note-1) of the synchronous encoder.
     Major error codes in the output module can be cleared by an error reset command (Note-2) of the output module.


# REMARK

- (Note-1): Refer to Section 4.1.6 for details of the error reset command for the synchronous encoder axis.
- (Note-2): Refer to Section 4.1.2 for details of the error reset command for the output module.


### 4.2.6 Current value after synchronous encoder axis main shaft's differential gear

(1) Current value after synchronous encoder axis main shaft's differential gear storage registers (D1126+10n, D1127+10n)

...... Monitor device



- (a) The current value will be the same as the drive module current value of the main shaft side at the virtual mode switching.
- (b) When the current value change is executed toward the drive module current value of the main shaft side, the current value after main shaft's differential gear is also simultaneous changed to the specified current value.
- (c) If the differential gear is not connected with the main shaft, drive module current value of the main shaft side is always stored in the current value storage register after main shaft's differential gear.
- (d) In the case of following figure, use "current value after synchronous encoder axis main shaft's differential gear" of axis 1 as "current value after synchronous encoder axis main shaft's differential gear". (The drive module feed current value of the auxiliary input axis side is stored as "current value after synchronous encoder axis main shaft's differential gear" of axis 2.)



- - (a) This register stores the axis No. of the output module in error by the error search function in the virtual mode.
  - (b) If there are no errors at the synchronous encoder axes of the main shaft and auxiliary input axis, the error occurrence output axis No. is stored into the error search output axis No. storage register of the corresponding drive module No. when a minor or major error occurs at the connected output axis.
  - (c) Error search and error reset
    - 1) Searching the main shaft for error The output axes connected to the main shaft are searched for an error in order of lower to higher numbers. If either a minor or major error has occurred, the corresponding output axis No. is stored into the error search output axis No. storage register. Resetting the error of the corresponding output axis stores the other error occurrence output axis No. connected to the same main shaft.
    - 2) Searching the auxiliary input axis for error If either a minor or major error has occurred at the output axis connected to the auxiliary input axis, the corresponding output axis No. is stored into the error search output axis No. storage register. However, when the differential gear (for virtual main shaft connection) is used to provide auxiliary input to the main shaft, the output axis connected to the auxiliary input axis is not searched for an error. Use the main shaft side error search output axis No. storage register to confirm the error occurrence output axis No.
  - (d) When error occurs at the drive module axis When an error occurs at the main shaft/auxiliary input axis to which the output axis is connected, "0" (no error) is stored into the error search output axis No. storage device if an error occurred at the output axis.

#### 4.2.7 Cam axis monitor devices

- (1) Execute cam No. storage register (D1241+10n) ...... Monitor device
  - (a) This register stores the cam No. currently being controlled.
  - (b) Cam No. of the execute cam No. storage register is held until next cam is executed. (Cam No. is not cleared, even if cam control is completed.)
- - (a) This register stores the stroke amount currently being controlled.
- - (a) This register stores the current value within 1 cam shaft revolution set in the parameter.

The current value is a ring address of "0 to [Number of pulses per cam shaft revolution (Nc)-1]".



#### 4.2.8 Common devices

Because cannot be turn on/off in every bit from the PLC CPU, the bit device is assigned to data register (D), and each bit device turns on with the lowest rank bit 0 to 1 and each bit device becomes off with 1 to 0.

The details of request register are shown below.


(Refer to Section "4.1.7 Common devices" for the bit device M2000 to M2053.)

#### Details of the request register

No.	Function	Request register	Bit device	Remark <sup>(Note-1)</sup>
1	PLC ready flag	D704	M2000	M3072
2	Speed switching point specified flag	D705	M2040	M3073
3	All axes servo ON command	D706	M2042	M3074
4	Real mode/virtual mode switching request (SV22)	D707	M2043	M3075
5	JOG operation simultaneous start command	D708	M2048	M3076
6	Manual pulse generator 1 enable flag	D755	M2051	M3077
7	Manual pulse generator 2 enable flag	D756	M2052	M3078
8	Manual pulse generator 3 enable flag	D757	M2053	M3079


(Note-1): It can also be ordered the device of a remark column.

- - (a) These registers set the virtual servo motor axis No. and direction which start simultaneously the JOG operation.



(b) Refer to Section 6.21.3 of the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)" for details of the JOG operation simultaneous start.

- (3) Manual pulse generator axis No. setting registers (D714 to D719) ...... Command signal
  - (a) These registers store the virtual servo motor axis No. controlled with the manual pulse generator.



- (b) Refer to Section 6.22 of the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)" for details of the manual pulse generator operation.
- - (a) These registers set the magnification (1 to 10000) per pulse of number of the input pulses from manual pulse generator at the pulse generator operation.

1-pulse input magnification setting register	Axis No.	Setting range	1-pulse input magnification setting register	Axis No.	Setting range
D720	Axis 1		D736	Axis 17	
D721	Axis 2		D737	Axis 18	
D722	Axis 3		D738	Axis 19	
D723	Axis 4		D739	Axis 20	
D724	Axis 5		D740	Axis 21	
D725	Axis 6		D741	Axis 22	
D726	Axis 7		D742	Axis 23	
D727	Axis 8	4 += 40000	D743	Axis 24	4 += 40000
D728	Axis 9	1 to 10000	D744	Axis 25	1 to 10000
D729	Axis 10		D745	Axis 26	
D730	Axis 11		D746	Axis 27	
D731	Axis 12		D747	Axis 28	
D732	Axis 13		D748	Axis 29	
D733	Axis 14		D749	Axis 30	
D734	Axis 15		D750	Axis 31	
D735	Axis 16		D751	Axis 32	

(Note): The following range is valid.


• Q172DSCPU : Axis No.1 to 16

• Q172DCPU(-S1): Axis No.1 to 8

- (b) Refer to Section 6.22 of the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)" for details of the manual pulse generator operation.
- - (a) These registers set the smoothing time constants of manual pulse generators.

Manual pulse generator smoothing magnification setting register	Setting range
Manual pulse generator 1 (P1): D752	
Manual pulse generator 2 (P2): D753	0 to 59
Manual pulse generator 3 (P3): D754	

- (b) When the smoothing magnification is set, the smoothing time constant is as indicated by the following expression.Smoothing time constant (t) = (Smoothing magnification + 1) × 56.8 [ms]
- (c) Operation



Output speed  $(V_1)$  [pulse/s] = (Number of input pulses/s) × (Manual pulse generator 1-pulse input magnification setting)

Travel value (L) = (Number of input pulses) × (Manual pulse generator 1-pulse input magnification setting)

(d) The manual pulse operation in the virtual mode is effective at the only test mode.

# REMARK

(1) The smoothing time constant is 56.8[ms] to 3408[ms].

#### 4.3 Motion Registers (#)

There are motion registers (#0 to #12287) in the Motion CPU. #8000 to #8639 are used as the monitor device, #8640 to #8735 are used as the Motion error history device and #8736 to #8751 are used as the product information list device. Refer to the "Q173D(S)CPU/Q172D(S)Motion Controller (SV13/SV22) Programming Manual (Motion SFC)" for details of the motion registers and Motion error history device.

### (1) Monitor devices (#8000 to #8639)

Information for each axis is stored in the monitor devices. The details of the storage data are shown below.

Axis No.	Device No.			Signal name	
1	#8000 to #8019				
2	#8020 to #8039		Cimmal manage	Defined avala	Cinnal dinastian
3	#8040 to #8059		Signal name	Refresh cycle	Signal direction
4	#8060 to #8079	C	Servo amplifier type	When the servo amplifier power-on	
5	#8080 to #8099	1	Motor current value	On anti-manuals 4.75 and a second constitution and	
6	#8100 to #8119	2	. Matanana d	Operation cycle 1.7[ms] or less : Operation cycle Operation cycle 3.5[ms] or more : 3.5[ms]	
7	#8120 to #8139	3	Motor speed	Operation cycle 3.5[ms] or more . 3.5[ms]	
8	#8140 to #8159	4	Command speed	Operation evals	
9	#8160 to #8179	5	Command speed	Operation cycle	
10	#8180 to #8199	6	Home position return re-	At home position return re-travel	Monitor device
11	#8200 to #8219	7	travel value	At home position return re-travel	ivionitor device
12	#8220 to #8239	8	Servo amplifier display servo		
13	#8240 to #8259		error code	Main cycle	
14	#8260 to #8279	ç	Parameter error No. QDS		
15	#8280 to #8299	1	Servo status1 QDS(	On anation avale 4 7[read and are a Consention avale	
16	#8300 to #8319	1	1 Servo status2 QDS	Operation cycle 1.7[ms] or less : Operation cycle	
17	#8320 to #8339	1:	2 Servo status3 QDS	Operation cycle 3.5[ms] or more : 3.5[ms]	
18	#8340 to #8359	1	3 Unusable	_	_
19	#8360 to #8379	4	4 Servo status5 QDS( Ver.)	Operation cycle 1.7[ms] or less : Operation cycle	Maniton device
20	#8380 to #8399	1.	4 Servo statuso (ass)	Operation cycle 3.5[ms] or more : 3.5[ms]	Monitor device
21	#8400 to #8419	1	5		
22	#8420 to #8439	1	0 Unusable	_	_
23	#8440 to #8459	1	7		
24	#8460 to #8479	1	8 Servo status7 QDS( Ver.)	Operation cycle 1.7[ms] or less : Operation cycle	Monitor device
25	#8480 to #8499		Servo status/	Operation cycle 3.5[ms] or more : 3.5[ms]	ivioriilor device
26	#8500 to #8519	1	9 Unusable		_
27	#8520 to #8539				
28	#8540 to #8559				
29	#8560 to #8579				
30	#8580 to #8599				
31	#8600 to #8619				
32	#8620 to #8639				

(a)	Servo ampli	fier type (#8000+20n)	. Monitor device
	•	r stores the servo amplifier type for each axis at th	ne servo
		wer supply ON.	
	• 0		
	• 256		
		MR-J3W-□B (For 2-axis type)	
	• 257	MR-J3-□B-RJ006 (For fully closed loop control)	
		MR-J3-□B Safety (For drive safety servo)	
		MR-J3-□B-RJ004 (For Linear servo motor)	
		MR-J3-□B-RJ080W (For direct drive motor) Ver	Ð
	• 4096	MR-J4-□B <b>QDS</b> (	,,
		MR-J4W-□B (For 2-axis type, 3-axis type) QDS	
	• 4352	VCII series (Note-1) (CKD Nikki Denso Co., Ltd. r	nake) <b>QDS</b> (
		(Ver.)	
	• 4354	VC <b>I</b> series (For Linear stage) <sup>(Note-2)</sup>	
		(CKD Nikki Denso Co., Ltd. make)	
	• 4359	VCII series (For direct drive motor) (Note-2)	
		(CKD Nikki Denso Co., Ltd. make) Ver.	
	• 4608	MR-JE-□B QDS( Ver.)	
		MR-JE-□BF QDS( Ver.)	
	• 4864	VPH series (Note-1) (CKD Nikki Denso Co., Ltd. r	make) <b>@DS</b> 《
		Ver.)	
	• 4866	VPH series (For Linear stage) (Note-2)	
		(CKD Nikki Denso Co., Ltd. make) QDS( Ver.)	
	• 4871	VPH series (For direct drive motor) (Note-2)	
		(CKD Nikki Denso Co., Ltd. make) QDS( Ver.)	
	• 5210	MR-J5-□B <b>QDS</b> ( Ver.)	
		MR-J5W-□B (For 2-axis type, 3-axis type) QDS	Ver.I
		FR-A800-1 (Inverter) QDS (Ver.)	
		FR-A800-2 (Inverter) QDS (Ver.)	
	• 8193	IAI electric actuator controller	
		(IAI Corporation make) QDS( Ver.)	
	• 8233	5-phase stepping motor driver	
		(ORIENTAL MOTOR Co., Ltd. make) QDS( Ver.	
	• 8234	Stepping motor driver AlphaStep (AZ series)	
		(ORIENTAL MOTOR Co., Ltd. make) QDS( Ver.	
	• 16640	FR-A700 series (Inverter) Ver.	
		(Note-1): When connecting SSCNETⅢ/H	
		(Note-2): When connecting SSCNETⅢ	
	It is not clea	red even if the servo amplifier power supply turns	OFF.
(b)		nt value (#8001+20n)	
	This register	r stores the motor current value ( $ imes$ 0.1[%]) (signed	d) read from the
	servo amplif	îer.	

The motor speed ( $\times 0.1$ [mm/s]) (signed) is stored at linear servo use.

(e) Home position return re-travel value (#8006+20n, #8007+20n)

.....Monitor device

If the position stopped in the position specified with the travel value after proximity dog ON using MT Developer2 is not zero point, it made to travel to zero point by re-travel in the Motion CPU. The travel value (signed ([pulse] units)) of making it travel to zero point by re-travel at this time is stored. (Data does not change with the last value in the data setting type.)

(f) Servo amplifier display servo error code (#8008+20n) Ver.

20n) Veru
...... Monitor device


This register stores the servo error code read from the servo amplifier.

The hexadecimal display is the same as the LED of servo amplifier.


Refer to the "Servo amplifier Instruction Manual" for details of the servo error codes.

Servo amplifier type	Servo amplifier LED display
MR-J5(W)-□B ODS( Ver.)	Displays 4 digits <sup>(Note-1)</sup> on the LED display
MR-J4(W)-□B QDS(	Displays 3 digits on the LED display
MR-J3-□B	Displays 2 digits on the LED display
MR-J3W-□B	Displays the first 2 digits on the LED display
MR-JE-□B QDS( Ver.)	Displays 3 digits on the LED display

(Note-1): Alarm No. (3 digits) + Alarm detail No. (1 digit)



This register stores the servo status read from the servo amplifier.



(Note): The 0/1 is stored in the servo status 1. • 0: OFF

- READY ON (b0)......Indicates the ready ON/OFF.
- Servo ON (b1)......Indicates the servo ON/OFF.
- Control mode (b2, b3)......Indicates the control mode of the servo


amplifier.


b3	b2	Control mode
0	0	Position control mode
0	1	Speed control mode
1	0	Torque control mode

- Gain changing (b4) ......Turns ON when the servo amplifier is gain changing.
- Fully closed control
  - changing (b5) ......Turns ON when the servo amplifier is using fully closed loop control.
- Servo alarm (b7) ......Turn ON during the servo alarm.
- In-position (b12) ...... The dwell pulse turns ON within the servo parameter "in-position".
- Torque limit (b13).....Turns ON when the servo amplifier is having the torque restricted.
- Absolute position lost (b14) ....... Turns ON when the servo amplifier has lost the absolute position.
- Servo warning (b15) ......Turn ON during the servo warning.

#### **POINT**

Servo warning (b15) turns ON during Motion controller forced stop or servo forced stop.





Ver.!): Refer to Section 1.4 for the software version that supports this function.

occurs.

(2) Product information list devices (#8736 to #8751) Ver The operating system software version and serial number of Motion CPU is

stored in ASCII code.

The product information list devices are shown below.

Device No.	Signal name	Refresh cycle	Fetch cycle	Signal direction
#8736				
to	Operating system software version			
#8743				
#8744		At power on		Monitor device
to	Motion CPU module serial number			
#8751				

(a) Operating system software version (#8736 to #8743) ...... Monitor device The operating system software version of Motion CPU displayed on the system monitor (product information list) of GX Works2/GX Developer is stored in ASCII code.

(Example) Operating system software version: "SV22j VER300A"

								Devic	e No.							
	#87	736	#87	737	#87	738	#87	739	#87	740	#87	741	#87	742	#87	743
	Low	High	Low	High	Low	High	Low	High	Low	High	Low	High	Low	High	Low	High
ASCII code	20H	53H	56H	32H	32H	6AH	20H	20H	56H	45H	52H	33H	30H	30H	41H	20H
Character	J	S	V	2	2	j	П	J	V	Е	R	3	0	0	Α	

 ☐ : Space.

(b) Motion CPU module serial number (#8744 to #8751) ...... Monitor device The serial number of Motion CPU displayed on the system monitor (product information list) of GX Works2/GX Developer is stored in ASCII code. (Example) Serial number: "A7Z123015"

								Devic	e No.							
	#87	744	#87	745	#87	746	#87	747	#87	748	#87	749	#87	750	#87	751
	Low	High	Low	High	Low	High	Low	High	Low	High	Low	High	Low	High	Low	High
ASCII code	41H	37H	5AH	31H	32H	33H	30H	31H	35H	20H	20H	20H	20H	20H	20H	20H
Character	Α	7	Z	1	2	3	0	1	5					Г		Г

 ☐ : Space.

#### **POINT**

Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion Controller User's Manual" or "Q173D(S)CPU/Q172D(S)CPU Motion Controller Programming Manual (COMMON)" for checking of the operating system software version and serial number.


## 4.4 Special Relays (SM)

There are 2256 special relay points of SM0 to SM2255 in the Motion CPU. Of these, devices in a Table 4.4 are used for the positioning control. The special relay list used for the positioning control is shown below. (Refer to "Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)" for the application of special relays except below.)

Table 4.4 Special relay list

Device No.	Signal name	Refresh cycle	Fetch cycle	Signal type
SM500	PCPU READY complete flag		/	
SM501	TEST mode ON flag	Main cycle	/	
SM502	External forced stop input flag	Operation cycle		
SM503	Digital oscilloscope executing flag	Main cycle		
SM506	External forced stop input ON latch flag	Operation cycle		
SM508	Amplifier-less operation status flag			Status signal
SM510	TEST mode request error flag		/	
SM512	Motion CPU WDT error flag	Main cycle	/	
SM513	Manual pulse generator axis setting error flag		/	
SM516	Servo program setting error flag		/	

- (1) PCPU READY complete flag (SM500) ...... Status signal This flag is used as judgement of the normal or abnormal in the Motion CPU side using the sequence program.
  - (a) At leading edge of PLC ready flag (M2000), the fixed parameters, servo parameters and limit switch output data are checked, and if error is not detected, this flag turns on. The servo parameters are written to the servo amplifiers and the M-codes
  - (b) This flag turns off when the PLC ready flag (M2000) turns off.



are cleared.

(2)	TEST mode ON flag (SM501)
	<ul><li>(b) If the test mode is not executed in the test mode request from MT Developer2, the TEST mode request error flag (SM510) turns on.</li></ul>
(3)	External forced stop input flag (SM502)
F	POINT
(2)	If the forced stop signal is input during positioning, the operation is as follows.  • When using Q173DSCPU/Q172DSCPU  The feed current value becomes the same value as the real current value.  • When using Q173DCPU(-S1)/Q172DCPU(-S1)  The feed current value is advanced within the rapid stop deceleration time set in the parameter block.  At the same time, the servo OFF state is established because the all axes servo ON command (M2042) turns off.  When the rapid stop deceleration time has elapsed after input of the forced stop signal, the feed current value returns to the value at the point when the emergency stop was initiated.  If the forced stop is cancelled while the rapid stop deceleration time isn't progressing, an overspeed error or error excessive error may occur.
(4)	Digital oscilloscope executing flag (SM503)
(5)	External forced stop input ON latch flag (SM506) Fig. Status signal
	This flag turns on when an external forced stop input is detected.  After that, it remains ON even if the external forced stop input is cancelled.  Reset the external forced stop input ON latch flag using the Motion SFC program.  • OFF External forced stop input is not detected.  • ON External forced stop input is detected.


(6)	This	nplifier-less operation status flag (SM508)Status signal is flag is used to check the state of amplifier-less operation.  FFDuring normal operation  NDuring amplifier-less operation
(7)		ST mode request error flag (SM510)
	(b)	When SM510 turns on, the error contents are stored in the test mode request error information (SD510, SD511).
(8)	This Mot Who with If the The	status signal status on when a WDT error (watchdog timer error) is detected of the tion CPU self-diagnosis function.  en the Motion CPU detects a WDT error, it executes an immediate stop nout deceleration of the operating axes.  e Motion CPU WDT error flag has turn on, reset the Multiple CPU system.  M512 remains on after resetting, there is a fault at the Motion CPU side.  e error cause is stored in the "Motion CPU WDT error cause (SD512)".  fer to Section 4.5(7)).
(9)	Ма	nual pulse generator axis setting error flag (SM513)
	(a)	This flag is use as judgement of normal or abnormal setting of the manual pulse generator axis No. setting registers (D714 to D719).  • OFFD714 to D719 is normal  • OND714 to D719 is abnormal
	(b)	This flag turns ON by turning ON the manual pulse generator enable flag (M2051 to M2053) with the manual pulse generator axis P1 to P3 unused after setting the manual pulse generator interface module (Q173DPX) in the system setting.
	(c)	When SM513 turns on, the error contents are stored in the manual pulse
		generator axis setting error information (SD513 to SD515).

#### 4.5 Special Registers (SD)

There are 2256 special register points of SD0 to SD2255 in the Motion CPU. Of these, devices in a Table 4.5 are used for the positioning control. The special register list used for the positioning control is shown below. (Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)" for the applications of special registers except below.)

Table 4.5 Special register list

Device No.	Signal name	Refresh cycle	Fetch cycle	Signal direction
SD200	State of switch		/	
SD500	Deal med a suis information remister (CV/22)	Main cycle	/	
SD501	Real mode axis information register (SV22)			
SD502	Can a amplifier leading information	At power supply on/	/	
SD503	Servo amplifier loading information	operation cycle		
SD504	Deal med de himbrel med de arribblica a anno a		/	
SD505	Real mode/virtual mode switching error information (SV22)	At virtual mode transition	/	
SD506	Information (3V22)		/	
SD508	SSCNET control (status)	Main cycle		
SD510	Test mode request error information	At test mode request	/	
SD511	Test mode request error information	At test mode request	] /	
SD512	Motion CPU WDT error cause	At Motion CPU WDT error occurrence		Monitor device
SD513			] /	
SD514	Manual pulse generator axis setting error information	At the manual pulse generator	/	
SD515	information	enable flag OFF to ON	] /	
SD516	Error program No.	A4 s4set	/	
SD517	Error item information	At start		
SD522	Motion operation cycle	Operation cycle	] /	
SD523	Operation cycle of the Motion CPU setting	At power supply on	] /	
SD524	Maximum Motion operation cycle QDS	Operation cycle	] /	
SD550	Country and the second in forms of the CODE	At System setting error	/	
SD551	System setting error information	occurrence	]/	
SD560	Operation method QDS( Ver)	At power supply on	V	
SD803	SSCNET control (command)		Main cycle	Command device



# (2) Real mode axis information register (SD500, SD501)

..... Monitor device

This signal is used to store the information used as a real mode axis at the time of switching from real mode to virtual mode.

The real mode axis information does not change at the time of switching from virtual mode to real mode.

	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0	
SD500	Axis 16	Axis 15	Axis 14	Axis 13	Axis 12	Axis 11	Axis 10	Axis 9	Axis 8	Axis 7	Axis 6	Axis 5	Axis 4	Axis 3	Axis 2	Axis 1	
SD501	Axis 32	Axis 31	Axis 30	Axis 29	Axis 28	Axis 27	Axis 26	Axis 25	Axis 24	Axis 23	Axis 22	Axis 21	Axis 20	Axis 19	Axis 18	Axis 17	
	•	•Q •Q -2): Re	172DS 172DC fer to /	SCPU CPU(-S APPEN	inge is : Ax (31): Ax NDIX 1 ord dat	is No.′ is No.′ .1 for t	1 to 8		n meth	od of a	axis No	o. corre	espond	ing		• 0 : E	node axis informatior ixcept real mode axis leal mode axis

## (3) Servo amplifier loading information (SD502, SD503)

..... Monitor device

The mounting status of the servo amplifier is checked at the power supply on or reset of the Multiple CPU system and its results are stored in this device. If communication with servo amplifier stops, it is reset.

The mounting status of changed axis after the power supply on is stored.

SD502	b15 Axis 16	b14 Axis 15		b12 Axis 13			b9 Axis 10	b8 Axis 9	b7 Axis 8	b6 Axis 7	b5 Axis 6	b4 Axis 5	b3 Axis 4	b2 Axis 3	b1	b0 Axis 1	1
SD503																	
,		•Q1	72DS 72DC	ring rar CPU PU(-S1	: Axi: 1): Axi:	s No.1 s No.1	to 8	ression	n meth	od of a	axis No	o corre	espond	ina	<b></b>	• 0: No	amplifier mounting statu lot mounted lounted

#### (a) Servo amplifier mounting status


- 1) Mounting status
  - Mounted ........ The servo amplifier is normal. (Communication with the servo amplifier is normal.)
  - Not mounted .... The servo amplifier is not mounted.
     The servo amplifier control circuit power is off.
     Normal communication with the servo amplifier is not possible due to a connecting cable fault, etc.
- 2) The system settings and servo amplifier mounting status are shown below.

0 1 0 111	Servo a	amplifier
System Settings	Mounted	Not mounted
Used (axis No. setting)	1 is stored	0 is stored
Unused	0 is s	tored

When a mode switching error occurs in real-to-virtual or virtual-to-real mode switching, or a mode continuation error occurs in the virtual mode, its error information is stored.

Refer to APPENDIX 1.7 for details of the stored error code.

The axis error code among the error codes stored in SD504 to SD506 is shown below.



- - 0 ...... Command accept waiting
  - -1 ..... Execute waiting
  - -2 ..... Executing

Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller programming Manual (COMMON)" for details of the SSCNET control function.

(6) Test mode request error information (SD510, SD511)

..... Monitor device


If there are operating axis at a test mode request using MT Developer2, a test mode request error occurs, the test mode request error flag (SM510) turns on, and the during operation/stop data of each axis are stored.

	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0	
D510	Axis 16	Axis 15	Axis 14	Axis 13	Axis 12	Axis 11	Axis 10	Axis 9	Axis 8	Axis 7	Axis 6	Axis 5	Axis 4	Axis 3	Axis 2	Axis 1	
D511	Axis 32	Axis 31	Axis 30	Axis 29	Axis 28	Axis 27	Axis 26	Axis 25	Axis 24	Axis 23	Axis 22	Axis 21	Axis 20	Axis 19	Axis 18	Axis 17	
		•Q	172DS 172DS	SCPU CPU(-S	ange is : Ax S1): Ax NDIX 1	is No.′ is No.′	1 to 8		on meti	hod of	axis N	o. corr	espono	ding		• 0 : D	f each axis Juring stop Juring operation

Error code	Error cause	Operation when error occurs	Action to take
1	S/W fault 1		Reset the Multiple CPU system.
2	Operation cycle time over	All axes stop immediately, after which operation cannot be started.	• If the an operation cycle time over reoccurs after resetting, or a main cycle is lengthened (more than 1.0[s]),  1) Change the operation cycle into a large value in the system setting.  2) Reduce the number of command execution of the event task or NMI task in the system setting.
4	WDT error		Reset the Multiple CPU system.
300	S/W fault 3		If the error reoccurs after resetting, explain the error symptom
303	S/W fault 4		and get advice from our sales representative.
304	RIO WDT error		

The setting information is checked at leading edge of manual pulse generator enable signal, if an error is found, the following error information is stored into SD513 to SD515 and the manual pulse generator axis setting error flag (SM513) turns on.

If there is an unused setting error for the manual pulse generator axis, a correspondence bit of SD513 turns ON.



	Error program No. (SD516)
	b) If an error occurs in another servo program when error program No. has been stored, the program No. of the new error is stored.
(10)	Error item information (SD517)
(11)	Motion operation cycle (SD522)
(12)	Operation cycle of the Motion CPU setting (SD523)
(13)	Maximum Motion operation cycle (SD524)
(14)	System setting error information (SD550,SD551)

When the operating system software is SV22, the operation method information is stored. • 0 ...... Virtual mode switching method • 1 ..... Advanced synchronous control method (16) SSCNET control (command) (SD803) ...... Command device SSCNET control (command) (SD803) is required for connect/disconnect of SSCNET communication and start/release of amplifier-less operation. • 0 ..... No command • 1 to 32 ..... Disconnect command of SSCNET communication • -10 ...... Re-connect command of SSCNET communication • -20 ...... Start command 1 of amplifier-less operation (EMI invalid) • -21 .......... Start command 2 of amplifier-less operation (EMI valid) • -25 ...... Release command of amplifier-less operation • -2 ..... Execute command

Refer to the "Q173DCPU/Q172DCPU Motion controller Programming Manual (COMMON)" for details of the SSCNET control function.

MEMO			

## 5. MECHANICAL SYSTEM PROGRAM

This section describes the mechanical system program in the virtual mode.

In the mechanical system program (Mechanical support language), what was performing synchronous control by hardware using the gear, shaft, belt, pulley, cam or infinitely variable speed changer, etc. is transposed to software, and same operation control is performed.

The mechanical system program is composed with the mechanical module connection diagram and mechanical module parameter.

- The mechanical module connection diagram shows the virtual mechanical system which connected the virtual mechanical modules.
- The mechanical module parameters are used to control of the mechanical modules used at the mechanical module connection diagram.

Refer to the mechanical module parameter lists shown in Chapters 6 to 8 for the mechanical module parameters.

## 5.1 Mechanical Module Connection Diagram

The mechanical module connection diagram shows a virtual system diagram which arranged the mechanical modules and was composed.

Configuration of the mechanical module connection is shown in Fig. 5.1 below.




Fig. 5.1 Configuration of the Mechanical Module Connection

#### **POINT**

- (1) Either a virtual servo motor or a synchronous encoder can be connected in the drive module.
- (2) One of the cam, roller, ball screw or rotary table can be connected in the output module.

# (1) Block

The term "block" is one relation from the virtual transmission module (gear) connected to the virtual main shaft to the output module.

Refer to Section 5.2 for the number of mechanical modules which can be connected in one block.

#### (2) System


The term "system" is a generic term of multiple blocks connected to one virtual main shaft.

The number of blocks connectable with one system is up to 32 blocks.


#### (3) Transmission module connections

There are 3 transmission module connection patterns:

- Pattern 1...... Without a differential gear.
- Pattern 2...... Without a speed change gear at the output side of the differential gear.
- Pattern 3...... With a speed change gear at the output side of the differential gear.



- (a) Transmission modules which can be connected at "A" and "B" above
  - 1) A clutch, speed change gear, and "clutch + speed change gear" can be connected at "A" and "B".
  - 2) If a "clutch + speed change gear" are used, connection constraints have not restrictions.



(b) Transmission module which can be connected at "C" (pattern 3) Only a clutch can be connected at "C".

MEMO		

## 5.2 Mechanical Module List

An overview of the mechanical modules used at the mechanical module connection diagrams in the virtual mode is shown in Tables 5.1.

Refer to Chapter 6 to 8 for details of each mechanical module.

Table 5.1 Mechanical Module List

	Mechanica	al Module				0172		aximum Nur	nber o	of Usab	е	0470	DECENIA DE CENTRA DE		
						Q1/3L	OSCPU	or Plast	N.I			Q1/2L	SCPU Number D	or Plast	1
Classification	Name	Appearance	Per	imber Motion CPU odule	F	mber Per stem	Number F Connection Shaft Side	Auxiliary Input Axis Side	Per	mber Motion CPU odule	ı	mber Per stem	Number P Connection Axis Side	Auxiliary Input Axis Side	
Drive we did	Virtual servo motor		32	Total	32	Total	_	_	16	Total	16	Total	_	_	
Drive module	Synchronous encoder		12 44		12	34	_	_	12	28	18		_	_	
	Virtual main shaft —		32	Total		32	_	_	16			16	_	_	
Virtual axis	Virtual auxiliary input axis	_	32	Total 64			_	_	16	Total 32	16		_		
	Gear			64		64	1	1		32		32	1	1	
	Direct clutch														
Transmission module	Smoothing clutch		- 64			64	1	1		32		32	1	1	
	Speed change gear			64		64	1	1		32		32	1	1	
	Differential gear	1 gear 32 32		1			16		16	1					
	Differential gear to main shaft			32		1	_	_		16		1	_	_	

Maximum Number of Usable														
	1	1	Q173DC	PU(-S1)				(	Q172DC	PU(-S1)				
	nber	N	umber	Number P			mber	Nu	ımber	Number P		Function Description	Section	
С	Motion PU dule		Per ystem	Connection Shaft Side	Auxiliary Input Axis Side	С	Motion :PU odule		Per ⁄stem	Connection Axis Side	Auxiliary Input Axis Side			
32	Total	32	Total	_	_	8	Total	8	Total	_	_	It is used to drive the virtual axis of mechanical system program by the servo program or JOG operation.	Section 6.1	
12	44	12	34	_		8	16	8	10			It is used to drive the virtual axis by the input pulses from the external synchronous encoder.	Section 6.2	
32			32	_	ı	8			8	I	l	This is a virtual "link shaft". Drive module rotation is transferred to the transmission module.	ı	
32	Total 64		32	_		8	Total 16 8		I	-	This is the auxiliary input axis for input to the differential gear of transmission module. It is automatically displayed when a differential gear and gear are connected.	ı		
64		64 64		64 1		1	16			16	1	1	The drive module rotation is transmitted to the output axis. A setting gear ratio is applied to the travel value (pulse) input from the drive module, and then transmits to the output axis that it becomes in the setting rotation direction.	Section 7.1
64			64	1	1		16		16	1	1	Transmit or separate the drive module rotation to the output module. There are a direct clutch transmitted directly and the smoothing clutch which performs the acceleration/deceleration and transmission by the smoothing time constant setting at the switching ON/OFF of the clutch. It can be selected the ON/OFF mode, address mode or the external input mode depending on the application. Time constant system or slippage system can be selected as a smoothing method.	Section 7.2	
(	64		64	1	1		16		16	1	1	<ul> <li>It is used to change the speed of output module (roller).</li> <li>The setting speed change ratio is applied to input axis speed, and transmits to the output axis.</li> </ul>	Section 7.3	
;	32		32	1			8		8	1		Auxiliary input axis rotation is subtracted from virtual main shaft rotation and the result is transmitted to the output axis.	Section	
;	32		1	_			8		1	_	_	Auxiliary input axis rotation is subtracted from virtual main shaft rotation, and the result is transmitted to the output axis. (Connected to the virtual main shaft)	7.4	

Table 5.1 Mechanical Module List (Continued)

								`								
Classification	Mechanical Module			Maximum Number of Usable												
				Q173DSCPU							Q172DSCPU					
			Number Per Motion CPU module		Number Per System		Number P	Number		Numahar		Number P				
	Name	Appearance					Connection Shaft Side	Auxiliary Input Axis Side	Per Motion CPU module		Number Per System		Connection Axis Side	Auxiliary Input Axis Side		
Output module	Roller		32		32		1	1	16		16	16 Total	1	1		
	Ball screw		32	Total		Total			16	Total 16	16					
	Rotary table		32	32		32			16		16	16				
	Cam		32		32				16		16					

	Maximum Number of Usable																
	Q173DCPU(-S1)						Q172DCPU(-S1)										
	Number Per Motion CPU module Number Per System			Number Per Block			Number		mber	Number Per Block		Function Description	Section				
					Connection Shaft Side	I Input		Per Motion CPU module		Per stem	Connection Axis Side	Auxiliary Input Axis Side	Tunidan Besanpton	CCCHOIT			
	32	32				32				8		8				It is used to perform the speed control at the final output.	Section 8.1
	32	Total	32	Total 32	1	1	8	Total 8	8	Total 8	1	1	It is used to perform the linear positioning control at the final output.	Section 8.2			
	32	32	32						8				It is used to perform the angle control at the final output.	Section 8.3			
	32		32				8		8				It is used to perform the position control based on the cam pattern setting data.     There are 2 cam control modes: the two-way cam and feed cam.	Section 8.4			

MEMO		

# 6. DRIVE MODULE

The drive module is the source of drive for the virtual axis (virtual main shaft, virtual auxiliary input axis).

There are following 2 types drive module.

- Virtual servo motor ...... Refer to Section 6.1
- Synchronous encoder ...... Refer to Section 6.2

# POINT

Set the travel value of drive module so large as possible to prevent the speed fluctuation of output module in the mechanical system program. If the travel value of drive module is small, the speed fluctuation of output module may occur depending on the setting for transmission module.

#### 6.1 Virtual Servo motor

The virtual servo motor is used to operate the virtual axis (virtual main shaft, virtual auxiliary input axis) using the servo program or JOG operation.

Virtual servo motor operation and parameters are shown below.

### 6.1.1 Operation description

# (1) Operation

When the virtual servo motor is started, the pulses are transmitted to the virtual axis (virtual main shaft, virtual auxiliary input axis) by the start conditions (command speed, travel value).

The transmitted pulses are transmitted to the output module connected via the transmission module (gear, differential gear, clutch, speed change gear).


## (2) Starting method

The virtual servo motor is started using the servo program or JOG operation.

(a) Start using the servo program

The servo program of Motion SFC program (motion control step) is executed. At this time, the start accept flag <sup>(Note-1)</sup> (M2001 to M2032) of the starting axis turns on.

Example of the Motion SFC program is shown below.



(Note): Example of the above Motion SFC program is started using the automatic start or sequence program.

# REMARK

(Note-1): Refer to Section 4.1.7 (2) for details of the start accept flag.


## (b) Start using the JOG operation

An individual start and simultaneous start can be executed in the JOG operation (Note-1).

### 1) Individual start

......It is started by turning on the forward/reverse JOG command (Note-2) of each axis.


Motion SFC program for which executes the JOG operation is shown below.



(Note): Example of the above Motion SFC program is started using the automatic start or sequence program.

#### 2) Simultaneous start

......The simultaneous start axis No. and directions (forward/reverse) are set by the JOG operation simultaneous start axis setting register (D710 to D713) (Note-3), and it is started by turning on the JOG operation simultaneous start command flag (M2048) (Note-3).



(Note): Example of the above Motion SFC program is started using the automatic start or sequence program.

# REMARK

- (Note-1): Refer to Section "6.21 JOG Operation" of the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)" for details of the JOG operation.
- (Note-2): Refer to Section 4.1.4 (3) for details of the forward/reverse rotation JOG start commands.
- (Note-3): Refer to Section 4.2.8 (2) for details of the JOG operation simultaneous start axis setting registers, and Section 4.1.7 (14) for details of the JOG operation simultaneous start command.

## (3) Stopping method during operation

When the virtual servo motor is stopped during operation after the start, turn the stop command (M4800+20n)/rapid stop command (M4801+20n) on using the Motion SFC program.

(There are no external stop causes (STOP, FLS, RLS) for the virtual servo motor.)

#### (4) Control items

- (a) It is controlled as the virtual servo motor backlash compensation amount "0" at the positioning control.
- (b) The deviation counter value and the real current value are not stored, so that the virtual servo motor has no feedback pulse.
- (c) The feed current value of virtual servo motor is recorded in a backup memory, and it is restored at the switching from real mode to virtual mode after the power supply of the Multiple CPU system turned on.
  - 1) When the output module is using the absolute position system, continuation operation is possible. However, if the servo motor of the output module connected to the virtual servo motor is operated while the power supply of the Multiple CPU system turns off, continuation operation is impossible even if the absolute position system is being used.

At this time, the virtual mode continuation operation disabled warning signal (Note-1) turns on.

- Set the virtual servo motor or servo motor of output module to the position which synchronous operation is possible.
- 2) When the output module is not using the absolute position system, correct the feed current value of virtual servo motor by the current value change switching from real mode to virtual mode.

#### (5) Control change

The following control changes are possible for the virtual servo motor.

- · Current value change
- Speed change
- Target position change QDS(

Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (Motion SFC)" for details of the current value change, speed change or target position change.

# REMARK

(Note-1): Refer to Section 4.1.5 (3) for details of the virtual mode continuation operation disabled warning signal.

## (6) Error-time operation mode

The processing shown below applies when major errors occur with the output modules per 1 system.

The following control is executed based on the parameter settings (Refer to Section 6.1.2) of the virtual servo motor connected to the virtual main shaft.

#### (a) Continuation

Even if a major error occurs with the output module, the output module continues operation. At this time, the error detection signal (M2407+20n) turns on, and the applicable error code is stored in the major error code storage register.

Use the Motion SFC program for continue/stop of the system and the output module operation at the major error occurrence.

#### (b) Clutch OFF

If a major error occurs with the output module, the clutch within 1 system turns off and stops connected output modules. (The smoothing processing is executed by the clutch setting.)


At this time, the clutch ON/OFF command device does not turn off.

However, the clutch status storage device turns off regardless of the clutch ON/OFF command device's ON/OFF status.

Operation continues at axes where no clutch is connected.

Use the Motion SFC program to stop the drive module.

Eliminate the error cause, then turn the clutch ON/OFF command device off to on to resume the operation.



## (7) Virtual servo motor axis infinite operation

By setting the upper stroke limit value and lower stroke limit value of the virtual servo motor parameters such that the "upper stroke limit value = lower stroke limit value", the stroke limit becomes invalid and infinite operation becomes possible.

When the stroke limit is invalid, it is also possible for the start of the feed current value to take place in a direction that exceeds 32 bits. In this case, the feed current value is converted to a 32 bits ring address.

→ -2147483648.....2147483647 **←** 

The following operations are possible by the control mode.

Control mode	Control contents
Positioning (Linear)	When the ABS command is used for the start, it starts in a
Speed-switching	direction within the 32 bits range. It does not start in a
Constant-speed (Linear)	<ul> <li>direction that exceeds the 32 bits range.</li> <li>When the INC command is used for the start, it starts in the specified direction, so it also can be start in a direction that exceeds 32 bits.</li> </ul>
Fixed-pitch feed	It starts in the specified direction, it also can be start in a direction that exceeds 32 bits.
Position follow-up	The command address is controlled by the absolute method so it does not start in a direction that exceeds the 32 bits range.
Speed	
JOG	Stroke is invalid. (It is ignored.) Moves in the specified
Manual pulse generator (Test mode)	direction.
Positioning (Circular, Helical)	• A start error (107, 108, 109) accompanies the ABS, ABH,
Constant-speed (Circular, Helical)	INC or INH command and start is not possible.

### (8) Reverse return during positioning

By specifying a negative speed and making a speed change request by the CHGV instruction during the start, allow the axis start deceleration at that point and return in the opposite direction upon completion of deceleration. Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (Motion SFC)" for details.

# (9) Target position change QDS(

Making a target position change request by the CHGP instruction during the start. Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (Motion SFC)" for details.

#### 6.1.2 Parameter list

The virtual servo motor parameters are shown in Table 6.1 and the parameters shown in this table are explained in items (1) to (4) below.

Refer to the help of MT Developer2 for the parameter setting method of virtual servo motor

A parameter is requested except for the above for program operation of the virtual servo motor. Refer to the item (5) for precautions of the parameter blocks.

No. Default value Setting item Setting range Q173DSCPU/Q173DCPU(-S1): 1 to 32 1 Virtual axis No. Q172DSCPU : 1 to 16 Q172DCPU(-S1) 2 2147483647 Upper stroke limit value -2147483648 to 2147483647 pulse pulse 3 Lower stroke limit value pulse -2147483648 to 2147483647 pulse 0 Q173DSCPU/Q172DSCPU : 1 to 2147483647 4 Command in-position range 100 pulse pulse Q173DCPU(-S1)/Q172DCPU(-S1): 1 to 32767 5 JOG operation-time JOG speed restriction 20000 1 to 2147483647 pulse/s pulse/s 6 parameter Parameter block No. 1 to 64 Continuation Continuation/Clutch OFF Operation mode at error occurrence

Table 6.1 Virtual Servo motor Parameter List

# (1) Virtual axis No. setting

The virtual axis No. is set in the servo program at the virtual mode operation. The axis No. of the virtual servo motor connected to the virtual main shaft or virtual auxiliary input axis.

## (2) Upper/lower stroke limit value settings

The stroke limit range of the virtual servo motor axis is set.

(a) When the stroke limit value is made valid:

Set the stroke range of the "Lower stroke limit value < upper stroke limit value".

The stroke limit check and control details at the start/during start are shown below.

Control mode			Error ch	eck (Note)		
		At start	art During start			Remarks
		106	207	208	220	
<b></b> .	Linear	0		_	_	
Positioning	Circular	0	0	0	_	
Fixed-pitch feed Speed-switching Constant-speed/Helical		0	_	_	_	Start in the return direction in a
		0	0	0	_	stroke limit range from outside the stroke limit range is possible.
		0	0	0	_	enone iiiiii rango le pecolole.
Position follow-	up	0	0	_	0	
Speed	•	_	_	_	_	Stroke limit is invalid.
JOG		_	0	_	_	Start in the return direction in a
Manual pulse g	enerator	_	0	0	_	stroke limit range from outside the stroke limit range is possible.

(Note):  $\bigcirc$  Code detected at the error check.

#### <Error check at start>

Error code	Contents	Operation
106	Command position is outside the stroke limit range at	Operation does not
100	start.	start.

## <Error check during start>

Error code	Contents	Operation
207	Feed current value is outside the stroke limit range during start.	
208	Feed current value of another axis is outside the stroke limit range at the circular interpolation start.	Deceleration stop.
220	Command address is outside the stroke limit range during position follow-up control.	

## (b) When the stroke limit value is invalid.

Set the stroke range of the "Lower stroke limit value = upper stroke limit

When the stroke limit is invalid, feed current value startup in a direction that exceeds 32 bits is possible.

In such a case the feed current value is converted to a 32 bit ring address.

The following operations are possible by the control mode.

Control mode	Control contents
Positioning (Linear)	When the ABS command is used at the start, it starts in a
Speed-switching	direction within the 32 bits range. It does not start in a
	direction that exceeds the 32 bits range.
Constant around (Linear)	When the INC command is used at the start, it starts in
Constant-speed (Linear)	the specified direction, so it also can be start in a direction
	that exceeds 32 bits.
Fixed-pitch feed	It starts in the specified direction, it also can be start in a
Fixed-pitch leed	direction that exceeds 32 bits.
	The command address is controlled by the absolute
Position follow-up	method so it does not start in a direction that exceeds the
	32 bits range.
Speed	Charles in invalid //h in impound \ Travel in the appoint
JOG	Stroke is invalid. (It is ignored.) Travel in the specified
Manual pulse generator	direction.
Positioning (Circular, Helical)	A start error (107, 108, 109) occurs in the ABS, ABH, INC
Constant-speed (Circular, Helical)	or INH command and start is not possible.

# (3) Command in-position range

The command in-position is the difference between the positioning address (command position) and feed current value.

Once the value for the command in-position has been set, the command in-position signal (M2403 + 20n) turns on when the difference between the command position and the feed current value enters the set range [(command position - feed current value)  $\leq$  (command in-position range)].

The command in-position check is executed, continuously during position control. (The command in-position range is not checked during the speed control and JOG operation.)




Fig. 6.1 Command in-position range

# (4) Setting of the JOG speed restriction and parameter block No.

The JOG speed restriction and parameter block No. used in the JOG operation are shown below.

(a) JOG speed restriction

This is the maximum speed setting at the JOG operation for virtual axis. If the JOG speed exceeds the JOG speed restriction, the JOG speed is controlled with the JOG speed restriction.

(b) Parameter block No. setting

This is the parameter block No. setting at the JOG operation.

The following parameter block data items are valid in the JOG operation.

- Acceleration time
- Deceleration time
- · Rapid stop deceleration time





Fig. 6.2 Relationships between the JOG speed restriction, acceleration time, deceleration time and rapid stop time

### **POINT**

- (1) Unit is fixed at [pulse] regardless of the interpolation control unit setting of parameter block in the JOG operation.
- (2) Even if the JOG speed of virtual servo motor is within the JOG speed restriction, when the JOG speed has not satisfied the condition "(Command speed [pulse/s]) × (Operation cycle [ms]) × (Number of input side gear teeth) < 2147483647 × 10<sup>3</sup>", the speed of output module becomes abnormal. Be sure to use within the range of above conditional expression.



(Example) Relation between an operation cycle, number of input side gear teeth and maximum speed

Speed	[Unit:	pulse/s]
Ороса	O i iic.	Paicoro

Operation cycle	Number of input side gear teeth		
[ms]	1	10000	65535
0.22 <b>QDS</b> (		900000000	137331200
0.44		450000000	68665600
0.88	2147483647	225000000	34332800
1.77		112500000	17166400
3.55		56250000	8583200
7.11		28125000	4291600
14.2 QD		14062500	2145800

# **REMARK**

Regardless of the speed limit value of parameter block for also program start of virtual servo motor, when the command speed has not satisfied the condition "(Command speed [pulse/s]) × (Operation cycle [ms]) × (Number of input side gear teeth)  $< 2147483647 \times 10^{3}$ ", the speed of output module becomes abnormal. Be sure to use within the range of above conditional expression.

(5) The parameter block No. for the program operation of virtual servo motor is set in the servo program for virtual mode. (If the parameter block No. setting is omitted, it is controlled with the contents of parameter block No.1.)

The valid parameter block data are shown below.

	Item	Control unit
Interpolation control	unit	[pulse] only (Note-1)
Speed limit value		[pulse/s] only (Note-1)
Acceleration time		0
Deceleration time		0
Rapid stop decelera	tion time	0
S-curve ratio		0
	Acceleration/deceleration system	0
Advanced S-curve	Acceleration section 1 ratio	0
acceleration/	Acceleration section 2 ratio	0
deceleration	Deceleration section 1 ratio	0
	Deceleration section 2 ratio	0
Torque limit value		× (Note-2)
STOP input-time de	celeration processing	×
Circular interpolation error permissible range		[pulse] only (Note-1)

 $\bigcirc$ : Valid,  $\times$ : Invalid

(Note-1): If it is set except for the [pulse] or [pulse/s], the program operation is executed as [pulse] automatically. (Note-2): It is set for every output module with a parameter of output module.

### <Example>

	Item	Specified parameter block setting value	Value used for the program operation
Interpolation control	unit	[mm]	[pulse]
Speed limit value		2000.00[mm/min]	200000[pulse/s]
Acceleration time		1000[ms]	1000[ms]
Deceleration time		1000[ms]	1000[ms]
Rapid stop decelera	tion time	1000[ms]	1000[ms]
S-curve ratio		0[%]	0[%]
	Acceleration/deceleration system	Trapezoid/S-curve	Trapezoid/S-curve
Advanced S-curve	Acceleration section 1 ratio	20.0[%]	20.0[%]
acceleration/	Acceleration section 2 ratio	20.0[%]	20.0[%]
deceleration	Deceleration section 1 ratio	20.0[%]	20.0[%]
Deceleration section 2 ratio		20.0[%]	20.0[%]
Torque limit value		300[%]	_
STOP input-time de	celeration processing	Deceleration stop	_
Circular interpolation	n error permissible range	0.0100[mm]	100[pulse]

# 6.1.3 Virtual servo motor axis devices (Internal relays, data registers)

- (1) Virtual servo motor axis status

  Refer to Section 4.1.3 for details of the virtual servo motor axis statuses.
- (2) Virtual servo motor axis command signal Refer to Section 4.1.4 for details of the virtual servo motor axis command signals.
- (3) Virtual servo motor axis monitor device
  Refer to Section 4.2.3 for details of the virtual servo motor axis monitor devices.
- (4) Current value after virtual servo motor axis main shaft's differential gear

Refer to Section 4.2.4 for details of the current value after virtual servo motor axis main shaft's differential gear.

## 6.2 Synchronous Encoder

The synchronous encoder is used to operate the virtual axis (virtual main shaft, virtual auxiliary input axis) with the external input pulse.

Synchronous encoder operation and parameters are shown below.

### 6.2.1 Operation description


# (1) Operations

Although a synchronous encoder does not need to start using the servo program etc. in order to operate it by external devices, it needs cautions for the timing which begins to input the input pulse from a synchronous encoder.

(a) Operation start

The input timing of input pulse (Note-4) from an external synchronous encoder is shown below.


- At the switching from real mode to virtual mode
- At the external signal (Note-2) (TREN: Synchronous encoder input start signal) input
- 1) When the input pulse is started to input at the switching from real mode to virtual mode. (Note-4)
  - a) The input pulse is input from the external synchronous encoder at the switching from real mode to virtual mode.



- b) The control mode (Note-3) of a clutch is operation in the case of ON/OFF mode and address mode. It can be used with the synchronous encoder for the incremental/absolute data method.
- c) Operating of the synchronous encoder axis starts when switched to the virtual mode by executing the switching request from real mode to virtual mode (M2043 OFF to ON). It depends on the state of connected clutch whether synchronous encoder operation in virtual mode is transmitted or not to the output module.
  - Clutch ON ...... Transmit to the output module.
  - Clutch OFF ..... Not transmit to the output module.

# **⚠** CAUTION

- If the mode is switched from real mode to virtual mode in the state of clutch ON, use the smoothing clutch. If the direct clutch is used and the mode is switched from real mode to virtual mode in the state of clutch ON, the rapid acceleration occurs at the output module axis, causing a servo error, and the machine will be subjected to a jolt.
  - When the input pulse is inputted from an external synchronous encoder.
     (Note-4)
    - a) The input pulse is started to input from the external synchronous encoder, when the clutch is switched on in virtual mode.



- b) The control mode (Note-3) of a clutch is operation in the case of external input mode.
  - Operation of the synchronous encoder and clutch corresponds. It can be used with the synchronous encoder for the incremental data method connected to Q173DPX only.
- (b) Operation end
  - Operation of the synchronous encoder axis is executed the real mode/virtual mode switching request (M2043 : ON → OFF) and ends at the switching to real mode. (Note-4)
  - 2) The procedure for ending operation of the synchronous encoder axis is shown below.
    - a) Stop the output module
      - Stop the external synchronous encoder.
      - Switch the connected clutch OFF.
    - b) Switch from the virtual mode to real mode.

# **∆** CAUTION

• If the mode is switched from virtual mode to real mode while the synchronous encoder axis and connected output module are operating, the rapid stop occurs at the output module axis, causing a servo error, and the machine will be subjected to a jolt.

#### (c) Stopping method

Stop the external synchronous encoder for stopping the external synchronous encoder.

There are no external inputs (FLS, RLS, STOP) or stop command/rapid stop command from the Motion SFC program for the synchronous encoder.

#### (d) Control items

- 1) The deviation counter value and the real current value are not stored, so that the synchronous encoder has no feedback pulse.
- 2) The current value of synchronous encoder is recorded in a backup memory, and it is restored at the switching from real mode to virtual mode after the power supply of the Multiple CPU system turned on. (Note-4)
  - a) When the output module is using the absolute position system, continuation operation is possible. However, if the servo motor of the output module connected to the synchronous encoder or synchronous encoder for the absolute data method is operated by 180° or more while the power supply of the Multiple CPU system turns off, continuation operation is impossible even if the absolute position system is being used.

At this time, the virtual mode continuation operation disabled warning signal turns on.

- Set the servo motor of output module to the position which synchronous operation is possible.
- b) When the output module is not using the absolute position system, correct the feed current value by the current value change switching from real mode to virtual mode.

### (e) Control change

The following current value change is possible for the synchronous encoder. Refer to Section 7.3 of the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (Motion SFC)" for details of the current value change.

# REMARK

- (Note-1): Refer to Section 4.1.7 (9) (10) for details of the real mode/virtual mode switching request flag and real mode/virtual mode switching status flag. Refer to Chapter 9 for switching from real mode to virtual mode.
- (Note-2): The synchronous encoder input start signal is inputted to the Q173DPX "TREN" terminal.

Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller User's Manual" for details of the Q173DPX "TREN" terminal.

- (Note-3): Refer to Section 7.2.1 for details of the clutch control mode.
- (Note-4): The input pulse is always input after Multiple CPU system's power supply ON in the real mode for the version (Refer to Section 1.4) that supports "synchronous encoder current value monitor in real mode".

  Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)" for details.

#### (f) Error-time operation mode

The processings are shown below when major errors occurred with the output modules per 1 system.

The following control is executed based on the parameter settings (Refer to Table 6.2) of the synchronous encoder connected to the virtual main shaft.

#### 1) Continuation

Even if a major error occurs with the output module, the output module continues operation. At this time, the error detection signal (M2407+20n) turns on, and the applicable error code is stored in the major error code storage register.

Use the Motion SFC program for continue/stop of the system and the output module operation at the major error occurrence.

#### 2) Clutch OFF

If a major error occurs with the output module, the clutch within 1 system turns off and stops connected output modules.

At this time, the clutch ON/OFF command device does not turn off. However, the clutch status storage device turns off regardless of the clutch ON/OFF command device's ON/OFF status.

Operation continues at axes where no clutch is connected.

Use the Motion SFC program to stop the drive module.

Eliminate the error cause, then turn the clutch ON/OFF command device off to on to resume the operation.

# [During operation] [Operation at major error occurrence] Synchronous encoder Clutch ON Clutch OF Major error occurrence 1 Operation continuation Clutch ON Clutch OFF Clutch ON Clutch OFF Major error occurrence Stop

## 6.2.2 Parameter list

The synchronous encoder parameters are shown in Table 6.2 and the parameters shown in this table are explained in items (1) below.

Refer to the help of MT Developer2 for the parameter setting method of synchronous encoder.

Table 6.2 Synchronous Encoder Parameter List

No.	Setting item	Default value	Setting range
1	Synchronous encoder No.		Q173DSCPU/Q172DSCPU/Q173DCPU(-S1) : 1 to 12 Q172DCPU(-S1) : 1 to 8
2	Error-time operation mode	Continuation	Continuation/ Clutch OFF

# (1) Synchronous encoder No.

The synchronous encoder No. is set connected to the Q172DEX/Q173DPX/built-in interface in Motion CPU (DI) .

Connecting position	Synchronous encoder No.
P1	1
P2	2
P3	3
P4	4
P5	5
P6	6
P7	7
P8	8
P9	9
P10	10
P11	11
P12	12

# REMARK

(Note-1): The absolute and incremental synchronous encoders can be used (set) together.

# 6.2.3 Synchronous encoder axis devices (Internal relays, data registers)

- (1) Synchronous encoder axis status
  Refer to Section 4.1.5 for details of the synchronous encoder axis statuses.
- (2) Synchronous encoder axis command signal Refer to Section 4.1.6 for details of the synchronous encoder axis command signals.
- (3) Synchronous encoder axis monitor device
  Refer to Section 4.2.5 for details of the synchronous encoder axis monitor devices
- (4) Current value after synchronous encoder axis main shaft's differential gear

Refer to Section 4.2.6 for details of the current value after synchronous encoder axis main shaft's differential gear.

# 6.3 Virtual Servo motor/Synchronous Encoder Control Change

The current value change and JOG speed change of the virtual servo motor and the current value of synchronous encoder.

Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (Motion SFC)" for details of the current value change/speed change/target position change

# 6.3.1 Virtual servo motor control change

# (1) Control change registers

Axis No.	Device No.			Signal	name			
1	D640, D641							
2	D642, D643		Signal name	Real	Virtual	Refresh	Fetch cycle	Signal
3	D644, D645					cycle		direction
4	D646, D647	0	JOG speed setting	0	0		At start	Command
5	D648, D649	1						device
6	D650, D651							○ : Valid
7	D652, D653							
8	D654, D655							
9	D656, D657							
10	D658, D659							
11	D660, D661							
12	D662, D663							
13	D664, D665							
14	D666, D667							
15	D668, D669							
16	D670, D671							
17	D672, D673							
18	D674, D675							
19	D676, D677							
20	D678, D679							
21	D680, D681							
22	D682, D683							
23	D684, D685							
24	D686, D687							
25	D688, D689							
26	D690, D691							
27	D692, D693							
28	D694, D695							
29	D696, D697							
30	D698, D699							
31	D700, D701							
32	D702, D703							

#### **POINT**

(1) The following range is valid.

Q172DSCPU : Axis No.1 to 16
 Q172DCPU(-S1): Axis No.1 to 8

(2) The following device area can be used as a user device.

Q172DSCPU : 17 axes or moreQ172DCPU(-S1): 9 axes or more

However, when the project of Q172DSCPU/Q172DCPU(-S1) is replaced with Q173DSCPU/Q173DCPU(-S1), this area cannot be used as a user device.


- (a) JOG speed setting registers (D640+2n, D641+2n) ......Command device
  - 1) This register stores the JOG speed at the JOG operation.
  - 2) Setting range of the JOG speed is 1 to 2147483647 [pulse/s].
  - The JOG speed is the value stored in the JOG speed setting registers at leading edge of JOG start signal.

Even if data is changed during JOG operation, JOG speed cannot be changed.

(Note): Refer to Section 6.21 of the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)" for details of the JOG operation.

# (2) Current value change


(a) Current value change by the CHGA instruction Motion SFC program for which executes the servo program is shown below. Current value change program of the virtual servo motor (When 1 axis feed current value of the virtual servo motor is changed to 1000 pulse.)



(Note): Example of the above Motion SFC program is started using the automatic start or sequence program.


## 6.3.2 Synchronous encoder control change

Current value change by the CHGA-E instruction
 Example of Motion SFC program for which executes the servo program is shown below.



(Note): Example of the above Motion SFC program is started using the automatic start or sequence program.

(a) The current value to change uses the following devices.



#### (b) Precautions

- When the synchronous encoder current value is changed in the real mode, an error occurs and the current value change is not executed. (Note-1)
- The synchronous encoder current value change can be executed even during operation in the virtual mode operation (during pulse input from the synchronous encoder). (Note-1)

When the current value is changed, the synchronous encoder current value will be continued from the changed value.

• Even if a synchronous encoder current value is changed, it will have no effect on the output module current value.

(Note-1): The current value change can be executed in real mode for the version (Refer to Section 1.4) that supports "synchronous encoder current value monitor in real mode".

## 7. TRANSMISSION MODULE

The transmission module transmits the pulse outputted from the drive module to output module.

The following 4 types of transmission modules are available.

The device range and setting procedure for indirect setting in the parameter setting of the transmission module are show below.

## (1) Device range

The number of device words and device range at the indirect setting are shown below.

Module	ltem	Number of device words		Devid	Remark	
	Clutch ON/OFF command device  Smoothing clutch complete signal	Bit		Device X Y M B	Range 0000 to 1FFF (Note-1) 0000 to 1FFF 0 to 8191 0000 to 1FFF 0 to 2047	
Clutch	Clutch status			r U□\G	10000.0 to (10000+p-1).F (Note-2)	
	Mode setting device	1				
	Clutch ON address setting device	2		Device	Range	
	Clutch OFF address setting device	2		D	0 to 8191	
	Slippage setting device	2		W	0000 to 1FFF	
	Slippage in-position range setting device	2		#	0 to 7999	
			1	U□\G	10000 to	
Gear	Input axis side tooth count	1		ULIG	(10000+p-1) (Note-2)	
Geal	Output axis side tooth count	1				
Speed change gear	Speed change ratio setting device	1				

(Note-1): The range of "PXn+4 to PXn+F" cannot be used (fixed at 0) for the input device (PXn+0 to PXn+F) allocated to the built-in interface in Motion CPU (DI). (n: First input No.)

(Note-2): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

#### **POINT**

- (1) Be sure to set even-numbered devices of the items set as 2-word.
  Be sure to set as 32-bit integer type when the data is set in these devices using the Motion SFC programs.
- (2) When a 2-word monitor device is read in the Motion SFC program, read it as 32-bit integer type.
- (3) Refer to Chapter 2 of the "Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)" for the user setting area points of the Multiple CPU high speed transmission area.

## (2) Device data input

The all device data set indirectly is inputted as "initial value" at the switching from real mode to virtual mode, thereafter the input control for module is executed during the virtual mode operation.

The input timing of each setting device and refresh cycle of setting device are shown below.

			Refresh device			
Module	ltem	Input device		Real mode/ Virtual mode switching	During the virtual mode operation	Refresh cycle
	Clutch ON/OFF command device	0	_	0	Input for every operation cycle. (Note)	_
	Smoothing clutch complete signal	-	0	_	_	Operation cycle
	Clutch status	_	0	_	_	(Note)
	Mode setting device	0	_	0		
Clutch	Clutch ON address setting device	0	_	0	Input for every operation cycle. (Note)	
	Clutch OFF address setting device	0	_	0		
	Slippage setting device	0	_	0	Input when switching mode setting device.	
	Slippage in-position range setting device	0	_	0	Input for every operation cycle. (Note)	_
	Input axis side tooth count	0	_	0	Input when the current value change of the connection source	
Gear	Output axis side tooth count	0	_	0	drive module (virtual servo motor axis/synchronous encoder axis) is executed and the gear ratio is changed.	
Speed change gear	Speed change ratio setting device	0	_	0	Input for every operation cycle. (Note)	

# REMARK

(Note): The operation cycle is set in the "operation cycle setting" of system basic setting.

Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)" for details of setting contents.

#### 7.1 Gear


This section describes the gear operation and the parameters required to use a gear.

## 7.1.1 Operation


Relation between the number of pulses outputted from the synchronous encoder or virtual servo motor and the output module is adjusted by parameter setting of the encoder resolution of servo motor, the gear ratio in consideration of the deceleration ratio for machine system etc. and rotation direction.

The gear operation is shown below.

(1) The gear transmits the number of pulses which applied the gear ratio set in the gear parameter to the travel value (number of pulses) of drive module (virtual servo motor, synchronous encoder) to the output axis.



(2) The rotation direction of output axis is set in the gear parameters.



# REMARK

Refer to Section 7.1.2 for details of the gear parameters.

#### 7.1.2 Parameters

The gear parameters are shown in Table 7.1 and the parameters shown in this table are explained in items (1) to (2) below.

Refer to the help of MT Developer2 for the gear parameter setting method.

Setting range Setting Item Default No. Direct setting Indirect setting D0 to D8191 (Note-1) Input axis side tooth count (GI) W0 to W1FFF Gear 1 1 to 65535 1 ratio Output axis side #0 to #7999 <u>U</u>□\G10000 to <u>U</u>□\G(10000+p-1)<sup>(Note-2)</sup> tooth count (GO) Rotation direction of Forward rotation Forward rotation output axis Reverse rotation

Table 7.1 Gear Parameter List

(Note-2): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

<sup>(</sup>Note-1): D800 to D1559 are dedicated devices of the virtual servo motor axis, synchronous encoder axis and output module "Cam" in the virtual mode. Unused areas of virtual servo motor axis and cam axis can be used as a user device.

## (1) Gear ratio


- (a) The number of pulses transmitted to the output axis through 1 pulse outputted from the drive module by the gear module is set in the gear ratio.
- (b) The gear ratio is based on the settings for the input axis side tooth count (GI) and output axis side tooth count (GO).

## (2) Rotation direction of output axis

- (a) The rotation direction of the output axis forward the rotation direction of the input axis is set.
- (b) There are two types for rotation directions of the output axis: forward and reverse.


#### 1) Forward

When the input axis rotates to the address increase direction, the output axis also rotates to the address increase direction.



## 2) Reverse

When the input axis rotates to the address increase direction, the output axis rotates to the address decrease direction.



#### **POINT**

If the gear ratio is set indirectly, the timing that the gear ratio set in Motion SFC program becomes valid is shown below.

- (1) When the real mode is switched to virtual mode.
- (2) When the current value of the drive module is changed in the virtual mode.

#### 7.2 Clutch

The clutch is used to transmit/disengage the command pulse from drive module side to output module side, and to control the operation/stop of servo motor.

There are two types for clutch: smoothing clutch and direct clutch.

These two clutches operate in the same way, but these have the difference in whether the acceleration/deceleration processing by the smoothing processing is executed or not at the switching of the clutch on/off.

# (1) Smoothing clutch and direct clutch

### (a) Smoothing clutch

When the clutch is switched on/off, output to the output axis with the acceleration/deceleration processing (smoothing processing) set in the clutch parameters.

There are following three systems for smoothing clutch.

- 1) Time constant system
- 2) Slippage system
  - Exponential function system Linear acceleration/deceleration system

#### (b) Direct clutch

When the clutch is switched on/off, output to the output axis without the acceleration/deceleration processing.





Fig. 7.1 Output to the Output axis by the Smoothing and Direct Clutch

# REMARK


(1) Clutch ON/OFF state is shown below.




- Clutch ON state......The state in which pulses inputted to the clutch are output to the output axis.
- Clutch OFF state......The state in which pulses inputted to the clutch are not output to the output axis.

# (2) Smoothing processing

- (a) Time constant system
  - 1) Since the time constant is fixed, the slippage of clutch changes according to the speed of drive module.



2) If input to clutch (travel value after the main shaft's differential gear) changes after smoothing completion, the smoothing processing is executed at that point.




\*t : Smoothing time constant


#### (b) Slippage system

There are following two systems for slippage system.


- Exponential function system
- Linear acceleration/deceleration system
- 1) Exponential function system
  - a) Set the slippage indicated by the shaded area in the diagram below. Slippage is recommended to be set greater than input to clutch (travel value after the main shaft's differential gear).



b) Since the slippage remains constant even if the drive module speed changes, the clutch ON/OFF position can be controlled without any influence from speed changes.




c) If input to clutch (travel value after the main shaft's differential gear) changes after smoothing completion, the smoothing processing is not executed at that point and output directly.




- d) The smoothing clutch complete signal turns ON after completion of smoothing processing.
  - ON ...."(Remainder slippage) < (Slippage in-position range)"
  - OFF... Smoothing processing start (Clutch ON/OFF)

The smoothing clutch complete signal is used to check the completion of smoothing processing, etc.


- 2) Linear acceleration/deceleration system
  - a) Set the slippage indicated by the shaded area in the diagram below. Slippage is recommended to be set greater than input to clutch (travel value after the main shaft's differential gear).



- b) Execute the smoothing processing so that the slippage may become the shaded area by the linear acceleration/deceleration system at clutch ON/OFF.
- c) Since the slippage remains constant even if the drive module speed changes, the clutch ON/OFF position can be controlled without any influence from speed changes.



d) If input to clutch (travel value after the main shaft's differential gear) changes after smoothing completion, the smoothing processing is not executed and output directly.



- e) The smoothing clutch complete signal turns ON after completion of smoothing processing.
  - ON ...."(Remainder slippage) < (Slippage in-position range)"
  - OFF... Smoothing processing start (Clutch ON/OFF)

The smoothing clutch complete signal is used to check the completion of smoothing processing, etc.

## 7.2.1 Operation

There are following five clutch operation modes.

Operation mode	Description				
ON/OFF mode	Clutch ON/OFF control is executed by turning the clutch ON/OFF command device on/off.				
Address mode	Clutch ON/OFF control is executed by turning the clutch ON/OFF command device on/off and an address of clutch ON/OFF address setting device.				
Address mode 2	After clutch ON/OFF command device turns on, Clutch ON/OFF control by an address of clutch ON/OFF address setting device.				
One-shot mode	Clutch ON/OFF control is executed based on the drive module current value, setting travel value before clutch ON and setting travel value after clutch ON after the clutch ON/OFF command device from off to on.				
External input mode	Only axis that the incremental synchronous encoder (manual pulse generator) is set as drive module can be set.  Clutch ON/OFF control is executed by turning the clutch ON/OFF command device on/off and an external input (TREN signal: Synchronous encoder start signal).				

Operations for every clutch mode are shown below.

## (1) ON/OFF mode


(a) The clutch ON/OFF control is executed by turning the clutch ON/OFF command device on/off.

Conditions	Clutch operation		
Clutch ON/OFF command device: ON	ON		
Clutch ON/OFF command device: OFF	OFF		

(b) It takes a time for maximum operation cycle until a clutch will be in the ON/OFF state after turning the clutch ON/OFF command device on/off. If greater accuracy is required, use the "address mode".

# POINT

- (1) The mode setting device of except "0 to 4" is regarded as an error, and it controls continuously at the previous setting value.
- (2) Clutch operation mode can be changed at any time.
  - (c) The clutch ON/OFF state can be checked by the clutch status signal.



(d) The refresh cycle of clutch status signal is an operation cycle.

Fig. 7.2 Operation Timing for ON/OFF Mode

## (2) Address mode

- (a) When the current value of virtual axis reaches an address of clutch ON/OFF address setting device, the clutch ON/OFF is executed. (Mode setting device is "1".)
  - 1) When the clutch ON/OFF command device is ON and the current value of virtual axis reaches an address set in the clutch ON address setting device, the clutch is set to the ON state.
  - 2) When the clutch ON/OFF command device is OFF and the current value of virtual axis reaches an address set in the clutch OFF address setting device, the clutch is set to the OFF state.
- (b) The clutch ON/OFF control differs according to the output module connected as follows.
  - 1) For a ball screw or roller The ON/OFF control is executed by the current value of virtual axis. When a differential gear is connected to the main shaft, the ON/OFF control is executed by the current value after the main shaft's differential gear.
  - 2) For a rotary table or cam The ON/OFF control can be executed by setting the current value of virtual axis or current value within 1 virtual axis revolution. (Refer to a rotary table or cam of output module for details.)

- (c) Turn the clutch ON/OFF command device on/off after setting an address of clutch ON/OFF address setting device.
  - 1) When the clutch ON/OFF command device is OFF, even if the current value of virtual axis reaches an address of clutch ON address setting device, the clutch is not set to the ON state.
  - 2) When the clutch ON/OFF command device is ON, even if the current value of virtual axis reaches an address of clutch OFF address setting device, the clutch is not set to the OFF state.
- (d) The clutch ON/OFF state can be checked by clutch status signal.
- (e) The refresh cycle of clutch status signal is an operation cycle.




Fig. 7.3 Operation Timing for Address Mode

### **POINT**

- (1) The mode setting device of except for "0 to 4" is regarded as an error, and control is continued at the previous setting value.
- (2) Clutch operation mode changes are valid at any time.
- (3) Clutch ON/OFF address setting device changes are valid at any time. Since they have 2-word data, set it as 32-bit integer type data.

#### (3) Address mode 2

- (a) When the current value of virtual axis reaches an address of clutch ON/OFF address setting device, the clutch ON/OFF is executed. (Mode setting device is "2".)
- (b) When the clutch ON/OFF command device is ON, the following controls are executed according to the current clutch status.
  - When the current clutch status is OFF.
     When the current value of virtual axis reaches an address set in the clutch ON address setting device, the clutch is set to the ON state.
     After that, it is set the state in 2).
  - 2) When the current clutch status is ON. When the current value of virtual axis reaches an address set in the clutch OFF address setting device, the clutch is set to the OFF state. After that, it is set the state in 1).
- (c) When the clutch ON/OFF command device is OFF, the clutch is turned off and the above control (b) is not executed. Therefore, the above control is resumed by turning the clutch ON/OFF command device on.





Fig. 7.4 Operation Timing for Address Mode 2


# **POINT**

- (1) The mode setting device of except for "0 to 4" is regarded as an error, and control is continued at the previous setting value.
- (2) Clutch control mode changes are valid at any time.
- (3) Clutch ON/OFF address setting device changes are valid at any time. Since they have 2-word data, set it as 32-bit integer type data.

- (d) The clutch ON/OFF control is executed for every operation cycle. When the current value passes through an address set in the clutch ON/OFF address setting device for 1 operation cycle, the internal control is executed correctly but the clutch status signal does not change.
  - 1) When the clutch status signal is OFF and the current value passes through an address set in the clutch ON/OFF address setting device.



2) When the clutch status signal is ON and the current value passes through an address set in the clutch ON/OFF address setting device.



(e) When the "Clutch OFF" is set in the parameter "Error-time operation mode" of drive module and a major error occurs in the output module, the operating system software turns off the clutch.

The procedure to resume an operation after an error occurrence is shown below.

- 1) Remove a major error factor.
- 2) Turn the clutch ON/OFF command device off.
  - $\rightarrow$  It returns to normal state.
- 3) Turn the clutch ON/OFF command device on.
  - → The clutch ON address is monitored and control is resumed.

- (f) The procedure to execute the axis servo OFF or power supply OFF of servo amplifier during operation is shown below.
  - 1) Turn the clutch ON/OFF command device off.
    - → The clutch status is set to the OFF state. After that, the axis servo OFF command becomes valid.
  - 2) Execute the axis servo OFF command or the power supply OFF of servo amplifier.
- (g) The procedure to resume an operation after the axis servo OFF or power supply OFF of servo amplifier during operation is shown below.
  - 1) Turn the power supply of servo amplifier on.
  - 2) Execute the axis servo ON command.
  - 3) Turn the clutch ON/OFF command device on.
    - → The clutch ON address is monitored and control is resumed.

# (4) One-shot mode

- (a) When the mode setting device is "3: One-shot mode clutch ON command is valid" or "4: One-shot mode clutch ON command is invalid", it switches to one-shot mode control.
- (b) When the mode setting device is "3", the clutch ON/OFF command device becomes valid, and the following controls are executed based on the clutch ON address setting device (setting travel value after clutch ON)/clutch OFF address setting device (setting travel value before clutch ON) by the clutch ON/OFF command device.
  - 1) When the clutch ON/OFF command device switches from OFF to ON. The clutch is set to the ON state after moving the travel value set in the setting travel value before clutch ON, and it is set to the OFF state after moving the travel value set in the setting travel value after clutch ON.
  - 2) When the clutch ON/OFF command device switches from ON to OFF. It has no influence on the clutch processing. The clutch state is held.





Fig. 7.5 Operation Timing for One-shot Mode

(c) When the mode setting device is "4", the clutch ON/OFF command device becomes invalid, and the clutch remains OFF. However, when the mode setting device is changed from "3" to "4" during execution of clutch ON/OFF processing by turning the clutch ON/OFF command device on, the clutch ON/OFF processing in execution is executed till the end and the next clutch ON/OFF command or later becomes invalid.

The clutch ON/OFF command device becomes valid by changing the mode setting device value to "3" again.




(d) The details for setting items are shown below.

Setting items	Description
Clutch ON/OFF command device	The clutch ON/OFF processing of one-shot mode starts at leading edge of this device.
Clutch ON address setting device	The transmitted travel value (setting travel value after clutch ON) of connected drive module from turning on clutch to turning off is set. A positive travel value is stored to indicate a positive direction travel value from the point of clutch ON, and a negative value to indicate a negative travel direction travel value.  (Setting range: -2147483648 (-2 <sup>31</sup> ) to 2147483647 (2 <sup>31</sup> -1) [pulse])
Clutch OFF address setting device	The travel value (setting travel value before clutch ON) of connected drive module from turning on clutch ON/OFF command device to turning on the clutch actually is set. A positive travel value is stored to indicate a positive direction travel value from the point of clutch ON, and a negative value to indicate a negative travel direction travel value.  (Setting range: -2147483648 (-2 <sup>31</sup> ) to 2147483647 (2 <sup>31</sup> -1) [pulse])


(Note): When the setting travel value before clutch ON is "0", the clutch also becomes ON state simultaneously by turning the clutch ON/OFF command device off to on.

#### **POINT**


- (1) The mode setting device of except for "0 to 4" is regarded as an error, and control is continued at the previous setting value.
- (2) Clutch control mode changes are valid at any time.
- (3) Clutch ON/OFF address setting device changes are valid at any time. Since they have 2-word data, set it as 32-bit integer type data.
  - (e) The clutch ON/OFF control is executed for every operation cycle. The internal control is executed correctly but the clutch status signal does not change for the setting travel value that the clutch status turns from off to on to off for 1 operation cycle.



(f) When the mode setting device becomes "3", the clutch ON/OFF control starts based on the setting data while the clutch ON/OFF command device is ON.




(g) When the mode setting device becomes "3", the clutch status turns OFF, while the clutch ON/OFF command device is OFF and the clutch status is ON



- (h) When the mode setting device is changed from "except 3" to "4", the clutch status turns off regardless of the clutch ON/OFF command device.
- (i) When the clutch ON/OFF address setting device data is changed during the clutch processing of one-shot mode, it becomes valid by turning the next clutch ON/OFF command device off to on.
- (j) When the drive module stops during the clutch ON/OFF processing by turning the clutch ON/OFF command device on, or if the clutch ON/OFF command device is turned on though the drive module stops, the one-shot mode clutch does not end until the travel value condition set to the setting travel value before clutch ON or setting travel value after clutch ON is satisfied.
- (k) When the current value change is made to the drive module during the clutch ON/OFF processing by turning the clutch ON/OFF command device on, the clutch turns off at the position where the setting travel value before clutch ON or setting travel value after clutch ON from the clutch ON position is satisfied.

(I) When the travel direction of drive module changes during the clutch ON/OFF processing by turning the clutch ON/OFF command device on, the clutch ON/OFF control is executed at the position in which not the travel value of drive module but the setting travel value before clutch ON/ setting travel value after clutch ON to the position where the clutch ON command is given was added.



- (m) The setting travel value before clutch ON/setting travel value after clutch ON differs according to the output module connected as follows.
  - 1) For a ball screw or roller

The clutch ON/OFF control is executed by the current travel value of virtual axis connected.

When a differential gear is connected to the main shaft, the clutch ON/OFF control is executed by the current travel value after the main shaft's differential gear.

- 2) For a rotary table or cam The clutch ON/OFF control is executed by the travel value of current value within 1 virtual axis revolution. The setting travel value can be set outside the range of current value within 1 virtual axis revolution.
- (n) When the travel direction set in the setting travel value before clutch ON/ setting travel value after clutch ON does not match the virtual axis or current value within 1 virtual axis revolution, note that the clutch will turn on/off even if the condition is not satisfied when the data found by subtracting the travel value from the specified travel value comes out of the range -2147483648 to 2147483647 [pulse] and changes from "+" to "-" or from "-" to "+".

(o) When the "Clutch OFF" is set in the parameter "Error-time operation mode" of drive module and a major error occurs in the output module, the operating system software turns off the clutch.

The procedure to resume an operation after an error occurrence is shown below.

- 1) Remove a major error factor.
- 2) Turn the clutch ON/OFF command device off.
  - → It returns to normal state.
- 3) Turn the clutch ON/OFF command device on.
  - → The clutch control of one-shot mode is resumed.
- (p) The procedure to execute the axis servo ON/OFF or power supply OFF of servo amplifier during operation is shown below.
  - 1) Turn the clutch revolution OFF command device off, when the clutch status is ON state, wait until the clutch status becomes OFF.
    - → After the clutch status to be set to OFF state, the axis servo OFF command becomes valid.
  - 2) Execute the axis servo OFF command or the power supply OFF of servo amplifier off.
- (q) The procedure to resume an operation after the axis servo OFF or the power supply OFF of servo amplifier during operation is shown below.
  - 1) Turn the power supply of servo amplifier on.
  - 2) Execute the axis servo ON command.
  - 3) Turn the clutch ON/OFF command device on.
    - → The clutch control of one-shot mode is resumed.

#### (5) External input mode

(a) The clutch ON/OFF control is executed by turning the clutch ON/OFF command device on/off and external input (TREN signal: Synchronous encoder start signal).

Since the input pulses from synchronous encoder are counted at leading edge of external input, a high-speed response and high accuracy clutch control is possible.

- The clutch is set to the ON state at leading edge of external input (OFF
   → ON) after the clutch ON/OFF command device turns on.
- 2) When the clutch ON/OFF command device turns off, the clutch is set to the OFF state after maximum 2 operation cycles.
- (b) Turn the external input (TREN signal) on after turning the clutch ON/OFF command device on.

In this mode, a time for maximum 2 operation cycles is required to turn the external input on after the clutch ON/OFF command device turns on.

- 1) If the external input turns from off to on when the clutch ON/OFF command device is OFF, the clutch is not set to the ON state.
- 2) If the clutch ON/OFF device turns on when the external input is ON, the clutch is not set to the ON state.
- 3) If the external input turns off after the clutch is set to the ON state, the clutch state remain ON.

- (c) The clutch status signal ON/OFF is refreshed by the operation cycle.
- (d) The current value of input axis (synchronous encoder) changes at the clutch ON state only.




Fig. 7.6 Operation Timing for External Input Mode


- (e) Only axis that the incremental synchronous encoder (manual pulse generator) is set as drive module can be used in this mode. When an absolute synchronous encoder is set as the drive module, it cannot be used.
- (f) A synchronous encoder, external input and external input mode clutch can be set in only 1:1 ratio.

The relationship between the synchronous encoder and external input is shown in the table below.

Synchronous encoder No.	External input (TREN signal)	Synchronous encoder No.	External input (TREN signal)
P1	TREN 1	P7	TREN 7
P2	TREN 2	P8	TREN 8
P3	TREN 3	P9	TREN 9
P4	TREN 4	P10	TREN 10
P5	TREN 5	P11	TREN 11
P6	TREN 6	P12	TREN 12


(Note): The range of synchronous encoder No. P1 to P8 is valid in the Q172DCPU(-S1).

- (g) Set all clutches connected to the same encoder No. to the external input mode to use the clutch connected to an encoder in the external input mode. However, it is permissible to use a combination of direct clutches and smoothing clutches.
  - < Example 1 > Synchronous encoder is connected to a drive axis
    When an external input mode clutch is used, set all clutches connected to the synchronous encoder to the external input mode. (Also set clutch ON/OFF devices to the same setting.)



# < Example 2 > Same synchronous encoder is connected to auxiliary input axis


Set all the clutches connected to the same synchronous encoder set to the external input mode. (Also set clutch ON/OFF devices to the same setting.)



# < Example 3 > Same synchronous encoder is connected to a drive axis and auxiliary input axis

Set all the connected clutches to the external input mode. (Refer to examples 1 and 2)

#### Synchronous encoder No.1



Synchronous encoder No.1

# 7.2.2 Parameters

The clutch parameters are shown in Table 7.2 and the parameters shown in this table are explained in items (1) to (11) below.

Refer to the help of MT Developer2 for the clutch parameter setting method.

Table 7.2 Clutch Parameter List

No.	Setting item	Default value		Setting ra	ange		Settin	ıg possible
1	Operation mode	ON/OFF mode	ON/OFF mode	ON/OFF mode Address mode Address mode 2 One-shot mode	combined use	External input mode	Direct clutch	Smoothing clutch
2	Mode setting device (1 word)	_	_	Word de	evice	_	0	0
3	Clutch ON/OFF command device	1		Bit devi	ice		0	0
4	Clutch status			/Bit device	(Note-1)		0	0
5	Clutch ON address setting device (2 words)	-		Word de	evice	_	0	0
6	Clutch OFF address setting device (2 words)							
7	Smoothing method	Time constant system	Time constant system/slippage system (Exponential function system/Linear acceleration deceleration system)		_	0		
8	Smoothing time constant	_		1 to 65535		-	_	0
9	Slippage setting device (2 words)	1		Word de	vice		_	0
10	Slippage in-position range setting device (2 words)	_	Word device		_	0		
11	Address mode clutch control system	Current value within 1 virtual axis revolution	Cui	rrent value within 1 vi Current value of		on/	cam/ro	Od when a stary table is the output adule.
12	Smoothing clutch complete signal			—/Bit device	e (Note-1)		_	0

(Note-1): The devices set in other clutch parameter cannot be used.

# (1) Operation mode

- (a) This device is used to set the mode to switch clutch ON/OFF.
  - The following three modes can be set.
  - ON/OFF mode
  - ON/OFF mode, address mode 2 and one-shot mode combined use
  - External input mode

Refer to Section "7.2.1 Operation" for each operation modes.

(b) If a synchronous encoder is used as the drive module, the operation modes that can be set differ depending on the encoder interface connected to the Q173DPX/Q172DEX.

	Clutch operation mode			
Encoder interface	ON/OFF mode	Address mode, Address mode 2, One-Shot mode	External input mode	
Manual pulse generator input (Q173DPX)	0	0	0	
Serial encoder input (Q172DEX)	0	0	×	

○ : Enable, × : Disable

- (2) Mode setting device (only ON/OFF mode, address mode, address mode 2 and one-shot mode combined use, 1 word)
  - (a) This device is used to switch the ON/OFF mode and address mode. The mode by mode setting device value are as follows:

Mode setting device No.	Name
0	ON/OFF mode
1	Address mode
2	Address mode 2
3, 4	One-shot mode

The mode setting device of except for "0 to 4" is regarded as an error, and an operation is continued at the previous setting value.

(b) The following devices can be used as the mode setting device.

Name	Setting range
Data register	D0 to D8191 <sup>(Note-1)</sup>
Link register	W0 to W1FFF
Motion register	#0 to #7999
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) <sup>(Note-2)</sup>

(Note-1): D800 to D1559 are dedicated devices of virtual servo motor axis, synchronous encoder axis and output module "cam" in the virtual mode. Unused areas of virtual servo motor axis and cam axis can be used as a user device.

(Note-2): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

#### (3) Clutch ON/OFF command device

- (a) This device is used to execute the clutch ON/OFF command.
- (b) The following devices can be used as the clutch ON/OFF command device.

Name	Setting range
Input	X0 to X1FFF <sup>(Note-1)</sup>
Output	Y0 to Y1FFF
Internal relay	M0 to M8191 <sup>(Note-2)</sup>
Link relay	B0 to B1FFF
Annunciator	F0 to F2047
Multiple CPU area device	U□\G10000.0 to U□\G(10000+p-1).F (Note-3)

- (Note-1): The range of "PXn+4 to PXn+F" cannot be used (fixed at 0) for the input device (PXn+0 to PXn+F) allocated to the built-in interface in Motion CPU (DI). (n: First input No.)
- (Note-2): "M4000 to M4639 and M4800 to M5439" are the dedicated devices of virtual servo motor axis in the virtual mode.
  - Unused area of virtual servo motor axis can be used as a user side.
- (Note-3): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

#### (4) Clutch status

- (a) This device is used to indicate the clutch ON/OFF state.
- (b) The following devices can be used as the clutch status.

Name	Setting range
Input	X0 to X1FFF (Note-1)
Output	Y0 to Y1FFF
Internal relay	M0 to M8191 (Note-2), (Note-3)
Link relay	B0 to B1FFF
Annunciator	F0 to F2047
Multiple CPU area device	U□\G10000.0 to U□\G(10000+p-1).F (Note-4), (Note-5)

- (Note-1): The range of "PXn+4 to PXn+F" cannot be used (fixed at 0) for the input device (PXn+0 to PXn+F) allocated to the built-in interface in Motion CPU (DI). (n: First input No.)
- (Note-2): "M4000 to M4639 and M4800 to M5439" are the dedicated devices of virtual servo motor axis in the virtual mode. Unused area of virtual servo motor axis can be used as a user side.
- (Note-3): Use these parameters to use the device (M2160 to M2223) allocated to Q17 $\Box$ CPUN/Q17 $\Box$ HCPU.
- (Note-4): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.
- (Note-5): Only device of the self CPU can be used.

- (5) Clutch ON/OFF address setting device (only ON/OFF mode, address mode, address mode 2 and one-shot mode combined use, 2 words)
  - (a) This device is used to set an address to turn the clutch on/off in the address mode.
  - (b) The following devices can be used as the clutch ON/OFF address setting devices.

Name	Setting range (Note-1)
Data register	D0 to D8191 (Note-2)
Link register	W0 to W1FFF
Motion register	#0 to #7999
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) (Note-3)

(Note-1): Set an even numbered the first device.


(Note-2): D800 to D1559 are dedicated devices of virtual servo motor axis, synchronous encoder axis and output module "cam" in the virtual mode. Unused areas of virtual servo motor axis and cam axis can be used as a user device.

(Note-3): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

- (c) The clutch ON/OFF address settings range is as follows.
  - The output module is a ball screw/roller, or output module is a cam/rotary table and the address mode clutch control system is current value of virtual axis.
    - -2147483648 (-2<sup>31</sup>) to 2147483647 (2<sup>31</sup>-1) [pulse]
  - 2) The output module is a cam/rotary table, and the address mode clutch control system is current value within virtual axis revolution.0 to number of pulses within 1 output axis revolution -1 [pulse]

(d) The clutch ON/OFF address setting device value according to the output module is as follows.

Refer to Section 7.2.1 (1) to (5) for details of each mode operation.



- (6) Smoothing method
  - (a) The method for smoothing processing of the clutch is set.

    The following three methods can be set:
    - Time constant system
    - Slippage system Exponential function system Linear acceleration/deceleration system
  - (b) Refer to Section 7.2 for each system operation.
- (7) Smoothing time constant

This is the time taken to reach 63[%] of the output axis speed.

- (8) Slippage setting device (2 words)
  - (a) This device is used to set the slippage of clutch.
  - (b) The following devices can be used as the slippage setting device.


Name	Setting range <sup>(Note-1)</sup>
Data register	D0 to D8191 <sup>(Note-2)</sup>
Link register	W0 to W1FFF
Motion register	#0 to #7999
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) (Note-3)


- (Note-1): Set an even numbered the first device.
- (Note-2): D800 to D1559 are dedicated devices of virtual servo motor axis, synchronous encoder axis and output module "cam" in the virtual mode. Unused areas of virtual servo motor axis and cam axis can be used as a user device.
- (Note-3): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.
- (c) The setting range for slippage is 0 to 2147483647 [pulse].
- (9) Slippage in-position range setting device (2 words)
  - (a) This device is used to set the remainder slippage range for judge as smoothing completion.
  - (b) The following devices can be used as the slippage in-position range setting device.

Name	Setting range <sup>(Note-1)</sup>
Data register	D0 to D8191 <sup>(Note-2)</sup>
Link register	W0 to W1FFF
Motion register	#0 to #7999
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) <sup>(Note-3)</sup>

- (Note-1): Set an even numbered the first device.
- (Note-2): D800 to D1559 are dedicated devices of virtual servo motor axis, synchronous encoder axis and output module "cam" in the virtual mode. Unused areas of virtual servo motor axis and cam axis can be used as a user device.
- (Note-3): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.
- (c) The setting range for remainder slippage is 0 to 2147483647 [pulse].

- (d) When "(Remainder slippage) < (Slippage in-position range)" is set, the smoothing clutch complete signal turns on.
  - The smoothing clutch complete signal ON/OFF is refreshed by the operation cycle.
  - 1) ON/OFF state of smoothing clutch is indicated. (Only exponential function system and linear acceleration/deceleration system are valid.)
    - ON ....."(Remainder slippage) < (Slippage in-position range)"
    - OFF.... Smoothing processing start (Clutch ON/OFF)
  - 2) Set the slippage in-position range setting device to use the smoothing clutch complete signal.
  - 3) Operation for smoothing clutch
    - a) Exponential function system





#### b) Linear acceleration/deceleration system

- (e) When "0" is set in the slippage in-position range setting device, when a clutch is connected/disconnected completely (Remainder slippage=0), the smoothing clutch complete signal turns on.
- (f) Slippage in-position range can be changed at any time.
- (g) When the slippage in-position range setting device is not set, the smoothing clutch complete signal does not turns on.
- (h) When the setting value for slippage in-position range setting device is outside the range, a minor error [5430] of output module will occur at the time of switching from real mode to virtual mode. In this case, it controls as a setting value "0".
  - Besides, the setting value for slippage in-position range is set outside the range during virtual mode operation, a minor error [6170] of output module will occur, and it controls as a setting value "0".

- (10) Address mode clutch control system
  - (a) When a clutch is turned on by the setting value of ON/OFF address setting device in the address mode/address mode 2, the current value (current value within 1 virtual axis revolution/current value of virtual axis) of virtual axis to be used is selected.
    - 1) Current value within 1 virtual axis revolution
      - ..... The ON/OFF control is executed by the current value within 1 virtual axis revolution system.
    - 2) Current value of virtual axis
      - ..... The ON/OFF control is executed by the current value of virtual axis. When a differential gear is connected to the main shaft, the ON/OFF control is executed by the current value after the main shaft's differential gear.
  - (b) The output module connected to clutch is valid for cam/rotary table
- (11) Smoothing clutch complete signal
  - (a) This device is used to confirm the completion of smoothing processing.
  - (b) The following devices can be used as the smoothing clutch complete signal.

Name	Setting range
Input	X0 to X1FFF (Note-1)
Output	Y0 to Y1FFF
Internal relay	M0 to M8191 (Note-2), (Note-3)
Link relay	B0 to B1FFF
Annunciator	F0 to F2047
Multiple CPU area device	U□\G10000.0 to U□\G(10000+p-1).F (Note-4), (Note-5)

- (Note-1): The range of "PXn+4 to PXn+F" cannot be used (fixed at 0) for the input device (PXn+0 to PXn+F) allocated to the built-in interface in Motion CPU (DI). (n: First input No.)
- (Note-2): "M4000 to M4639 and M4800 to M5439" are the dedicated devices of virtual servo motor axis in the virtual mode.
  - Unused area of virtual servo motor axis can be used as a user side.
- (Note-3): Use these parameters to use the device (M5520 to M5583) allocated to Q17 $\square$ CPUN/Q17 $\square$ HCPU.
- (Note-4): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.
- (Note-5): Only device of the self CPU can be used.

# 7.3 Speed Change Gear


Speed change gear is used to change the rotation speed to output module and travel value during operation.


The operation of speed change gear and parameters required to use it are shown below.

## 7.3.1 Operation


This section describes the operation of speed change gear.

(1) The speed that the input axis speed multiplied by a speed change ratio set in the speed change ratio setting device is transmitted to output axis.





(2) When a speed change ratio changes, the acceleration/deceleration processing is executed by the smoothing time constant (t) set in the speed change gear parameters.



#### 7.3.2 Parameters

The speed change gear parameters are shown in Table 7.3 and the parameters shown in this table are explained in items (1) to (3) below.


Refer to the help of MT Developer2 for the speed change gear parameter setting method.

No. Setting Item Default Setting range Speed change ratio 1 10000 0 to 65535 upper limit value Speed change ratio 2 0 to 65535 1 lower limit value D0 to D8191 Speed change ratio W0 to W1FFF setting device #0 to #7999 (1 word) U□\G10000 to U□\G(10000+p-1) (Note-1) Smoothing time 0 0 to 65535 [ms] 4 constant

Table 7.3 Speed Change Gear Parameter List

(Note-1): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

- (1) Speed change ratio upper/lower limit value
  - (a) The validate range (0.00 to 655.35[%]) of speed change ratio set in the speed change ratio setting device is set.
  - (b) When the setting value of speed change ratio setting device is greater than the speed change ratio upper limit value, an operation is executed by a speed change ratio clamped at the upper limit value. When the setting value of speed change ratio setting device is smaller than the speed change ratio lower limit value, an operation is executed by a speed change ratio clamped at the lower limit value.



- (c) The speed change ratio upper/lower limit value is set in the range of 0 to 65535, i.e. 100 times the settings actually made: 0.00 to 655.35%.
- (d) Set the speed change ratio upper/lower limit value as formula below.

0 ≤ (Speed change ratio lower limit value) ≤ (Speed change ratio upper limit value) ≤ 65535

- (2) Speed change ratio setting device
  - (a) The device to set a speed change ratio of speed change gear.
  - (b) The following devices can be used as the speed change ratio setting devices.

Name	Setting range		
Data register	D0 to D8191 <sup>(Note-1)</sup>		
Link register	W0 to W1FFF		
Motion register	#0 to #7999		
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) <sup>(Note-2)</sup>		

(Note-1): D800 to D1559 are dedicated devices of virtual servo motor axis, synchronous encoder axis and output module "cam" in the virtual mode. Unused areas of virtual servo motor axis and cam axis can be used as a user device.

(Note-2): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

- (c) The setting range is "Speed change ratio lower limit value" to "Speed change ratio upper limit value".
- (3) Smoothing time constant

This is the time taken to reach 63[%] of the output axis speed.


#### 7.4 Differential Gear

The differential gear is used for the following purposes;


- Output module phase is shifted or alignment of operation start position is executed.
- Individual operation separated from the virtual main shaft is executed.

## 7.4.1 Operation

- (1) When the output module phase is shifted or alignment of the operation start position is executed.
  - (a) When the input axis clutch is ON.
    The differential gear subtracts the auxiliary input shaft travel value from the input shaft travel value and transmits this to the output axis.



- (b) When the input axis clutch is OFF. Individual operation is possible using the auxiliary input axis since the differential gear transmits only the travel value from the auxiliary input axis to the output axis.
- (2) When the differential gear is used to connect to the virtual main shaft. This is used for operation in which the main shaft is switched or when the same drive module is used as auxiliary input to control all blocks.



Set the different drive modules for virtual main shaft side and auxiliary input axis side.

#### 7.4.2 Parameters

No parameters need to be set for the differential gear.

MEMO	

# 8. OUTPUT MODULE

The command pulse output from drive module is input to output module via the transmission module.

The travel value of servo motor is controlled by the command pulse from output module.

There are following four output modules.

The parameters in accordance with that mechanism is set if necessary.

# (1) Output module types

Output module types are shown below.

Module	Details	Applications		
Roller	The speed control is executed with the final output (axis).	Roller		
Ball screw	The linear position control is executed with the final output (axis).	Ball screw		
Rotary table	The angle control is executed with the final output (axis).	Rotary table		
Cam	The electronic cam operation is executed with the final output (axis).	Cam (Electronic cam)		

- (2) Device range of output module parameters and device data input The device range and setting method of items set in the indirect setting by devices among the output module parameters are shown below.
  - (a) Device range The number of device words and device range in the indirect setting are shown below.

Module	Item	Number of device words		Remark	
Roller	Torque limit value setting device	1			
Ball screw	Torque limit value setting device	1			
	Torque limit value setting device	1			
Rotary table	Current value within 1 virtual axis revolution storage device (Main shaft side)	2			
	Current value within 1 virtual axis revolution storage device (Auxiliary input axis side)	2	Device	Range	
	Number of pulses per cam shaft revolution (Nc)	2	D W	0 to 8191 0 to 1FFF	
	Cam No. setting device	1	#	0 to 7999	
	Stroke amount setting device	2	U□\G	10000 to (10000+p-1) (Note-1)	
	Torque limit value setting device	1			
	Lower stroke limit value storage device	2			
	Current value within 1 virtual axis revolution storage device (Main shaft side)	2			
Cam	Current value within 1 virtual axis revolution storage device (Auxiliary input axis side)	2			
	Cam/ball screw switching command device		Device	Range	
			Х	0 to 1FFF (Note-2)	
			Y	0 to 1FFF	
		Bit	М	0 to 8191	
			В	0 to 1FFF	
			F	0 to 2047	
			U□\G	10000.0 to (10000+p-1).F (Note-1)	

<sup>(</sup>Note-1): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

<sup>(</sup>Note-2): The range of "PXn+4 to PXn+F" cannot be used (fixed at 0) for the input device (PXn+0 to PXn+F) allocated to the built-in interface in Motion CPU (DI). (n: First input No.)

#### **POINT**

- (1) Be sure to set even-numbered device of the items set as 2-word. Be sure to set as 32-bit integer type when the data is set in these devices using the Motion SFC programs.
- (2) When a 2-word monitor device is read in the Motion SFC program, read it as 32-bit integer type.
- (3) Refer to Chapter 2 of the "Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)" for the user setting area points of the Multiple CPU high speed transmission area.

### (b) Device data input

All indirect setting device data are input as "initial value" at the switching real mode/virtual mode, thereafter the input control for module is executed during the virtual mode operation.

The input timing and refresh cycle of setting device are shown below.

				Devic		
Module	ltem	Input device	Refresh device	Real mode /Virtual mode switching	During the Virtual mode operation	Refresh cycle
Roller	Torque limit value setting device	0	_	0	lance for occur.	_
Ball screw	Torque limit value setting device	0	_	0	Input for every operation cycle. (Note)	
	Torque limit value setting device	0	_	0	operation cycle.	
Rotary table	Current value within 1 virtual axis revolution storage device (Main shaft side)	l	0	-		Operation cycle <sup>(Note)</sup>
	Current value within 1 virtual axis revolution storage device (Auxiliary input axis side)	-	0	_	_	
	Number of pulses per cam shaft revolution (Nc)	0	_	0	_	_
	Cam No. setting device	0	_	0	Input for every operation cycle. (Note) However, the cam No.	
	Stroke amount setting device	0	_	0	and stroke amount switching position pass point are valid.	
	Torque limit value setting device	0	_	0	Input for every operation cycle. (Note)	
Cam	Lower stroke limit value storage device	_	0	_		Operation cycle (Note)
	Current value within 1 virtual axis revolution storage device (Main shaft side)	_	0		_	
	Current value within 1 virtual axis revolution storage device (Auxiliary input axis side)	_	0	_		
	Cam/ball screw switching command device	0	_	0	Input for every operation cycle. (Note)	_

# REMARK

(Note): The operation cycle is set in the "operation cycle setting" of system basic setting.

Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)" for details.

#### 8.1 Rollers

The rollers are used in the following cases.

- The machine connected to the servo motor is operated continuously.
- The system which does not need position control.
   (It is used when the speed control (cycle speed/number of rotations) mainly is controlled without the current value and position data.)

This section describes the roller operation and parameters required to use a roller.

# 8.1.1 Operation


# (1) Operation

(a) The roller is controlled with the speed that the speed/travel value of drive module multiplied by a gear ratio/speed change ratio of transmission module, and it rotates for the travel value.

```
Roller speed = (Drive module speed [pulse/s]) \times (Gear ratio) \times (Speed change ratio) [pulse/s]

Number of roller revolution = (Drive module travel value [pulse]) \times (Gear ratio) \times (Speed change ratio) [pulse]
```

The speed/travel value of drive module transmitted to the roller is commanded to the servo amplifier.




(b) When a clutch is used, the roller is controlled at clutch ON.

# (2) Control details

(a) The roller has no current value.

However, when it switches from the virtual mode to real mode, it reaches the current value corresponding to the position moved in the virtual mode.

• The current value is a ring address within the range of -2147483648 ( $-2^{31}$ ) to 2147483647 ( $2^{31}$ -1) [pulse].



- (b) Backlash compensation processing is continued with the settings value of fixed parameters even if it switches the real mode/virtual mode.
- (c) The roller cycle speed can be monitored using MT Developer2 and the roller cycle speed storage register.

Refer to Section 8.1.2 for the calculation formula of roller cycle speed, and refer to Section 4.2.1 for details of the roller cycle speed storage register.

#### 8.1.2 Parameter list

The roller parameters are shown in Table 8.1 and the parameters shown in this table are explained in items (1) to (6) below.

Refer to the help of MT Developer2 for the roller parameter setting method.

No. Setting item Default Setting range Q173DSCPU/Q173DCPU(-S1): 1 to 32 Output axis No. 0 Q172DSCPU : 1 to 16 Q172DCPU(-S1) :1 to 8 Output unit mm mm inch 0.1 to 214748364.7 0.00001 to Roller diameter (L) 0 [µm] 21474.83647 [inch] Number of pulses per roller 0 1 to 2147483647 [pulse] revolution (NL) Permissible droop pulse value 6553500 5 1 to 1073741824 [pulse] 0.001 to 600000.000 0.01 to 6000000.00 0 Speed limit value (VL) 6 [mm/min] [inch/min] Torque limit value setting -(300[%]) / word device (D, W, #, U□\G) device (1 word) 8 Comment None 32 characters


Table 8.1 Roller Parameter List

#### (1) Output unit

- (a) This device is used to set the unit ([mm]/[inch]) of roller.
- (b) The unit (unit in the fixed parameter) for the axis which execute the roller setting in the real mode is permissible to use the any of [mm], [inch], [degree] and [pulse].

# (2) Roller diameter (L)/Number of pulses per roller revolution (NL)

(a) The roller diameter connected to servo motor and the number of pulses per roller revolution are displayed.



(b) The roller cycle speed is calculated by the roller diameter and number of pulses per roller revolution as the formula below.

1) Unit: [mm]

[Roller cycle speed] = 
$$\begin{pmatrix} \text{Number of input} \\ \text{pulses per minute} \end{pmatrix} \times \frac{\pi \times L}{\text{NL}} [\text{mm/min}] \quad L : [\text{mm}]$$

2) Unit: [inch]

[Roller cycle speed] = 
$$\begin{pmatrix} \text{Number of input} \\ \text{pulses per minute} \end{pmatrix} \times \frac{\pi \times L}{\text{NL}}$$
 [inch/min] L : [inch]

The value calculated by calculations 1) and 2) is stored with an integer value in the roller cycle speed storage register.

Output unit	Roller cycle speed storage register				
mm	Calculated value $ imes$ 100				
inch	Calculated value $ imes$ 1000				

# (3) Permissible droop pulse value

- (a) This device is used to set the permissible droop pulse value of deviation counter.
- (b) The deviation counter value is continually checked, and if it becomes larger than the permissible droop pulse value, the error detection signal (M2407+20n) turns on.

However, since the roller axis operation continues, execute the error processing by user side.


#### (4) Speed control limit (VL)

- (a) This device is used to set the maximum speed of roller axis.
- (b) Set the speed limit value within the following range.

$$1 \le \frac{\text{VL} \times \text{NL}}{60 \times \pi \times \text{L}} \le 2147483647 \text{[pulse/s]}$$
 VL: [mm/min] or [inch/min] L: [mm] or [inch]

(c) When the roller axis speed exceeds the speed limit value, the error detection signal (M2407+20n) turns on.

However, the roller axis speed is not clamped.



# (5) Torque limit value setting device (1 word)

(a) This device is used to set the torque limit value of roller axis.

When the device is set, the torque control is executed with the preset device value.

In the virtual mode, the torque limit setting is always valid. If the device is not set, the torque limit is set at 300[%].

(b) The following devices can be set as the torque limit setting device.

Name	Setting range		
Data register	D0 to D8191 <sup>(Note-1)</sup>		
Link register	W0 to W1FFF		
Motion register	#0 to #7999		
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) <sup>(Note-2)</sup>		

(Note-1): D800 to D1559 are dedicated devices of virtual servo motor axis, synchronous encoder axis and output module "cam" in the virtual mode. Unused areas of virtual servo motor axis and cam axis can be used as a user device.

(Note-2): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

(c) The setting range for torque limit value is 1 to 1000[%].

#### (6) Comment

- (a) This device is used to create a comment such as purpose of roller axis. Made comment can be displayed at monitoring using MT Developer2.
- (b) Comments up to 32 characters long can be created.

#### **POINT**

- (1) "Roller diameter" or "number of pulses per roller revolution" set in the roller parameter is used for only the cycle speed monitor of servo motor, and it is not related to the rotation speed/travel value of servo motor.
- (2) The roller cycle speed monitor device is the same for the "feed current value" in the real mode. Therefore, the position address (current value) of roller axis cannot be monitored in the virtual mode.

When it switches from the virtual mode to real mode, the certain value is stored in the position address (current value). The value at this time is an unfixed value.

#### 8.2 Ball Screw

The ball screw is used to make a machine connected to servo motor operate linearly. This section describes the ball screw operation and parameters required to use ball screws.


# 8.2.1 Operation

# (1) Operation

(a) The ball screw is controlled with the speed that the speed/travel value of drive module multiplied by a gear ratio of transmission module, and the travel value is output.

```
(Ball screw speed) = (Drive module speed [pulse/s]) × (Gear ratio) [pulse/s]
(Ball screw travel value) = (Drive module travel value [pulse]) × (Gear ratio) [pulse]
```

The speed/travel value of drive module transmitted to the ball screw is commanded to the servo amplifier.



(b) When a clutch is used, the ball screw is controlled at clutch ON.

#### (2) Control details

- (a) Feed current value is continued, even if it switches from the real mode to virtual mode/from the virtual mode to real mode.
- (b) Backlash compensation processing is continued with the settings value of fixed parameters, even if it switches the real/virtual mode.

# 8.2.2 Parameter list

The ball screw parameters are shown in Table 8.2 and the parameters shown in this table are explained in items (1) to (7) below.

Refer to the help of MT Developer2 for the ball screw parameter setting method.

Table 8.2 Ball Screw Parameter List

No.	Setting Item	Default	Setting range		
			Q173DSCPU/Q173DCPU(-S1): 1 to 32		
1	Output axis No.	0	Q172DSCPU	: 1 to 16	
			Q172DCPU(-S1)	:1 to 8	
2	Output unit	mm	mm	inch	
3	Ball screw pith (P)	Must be not set.			
١,	Number of pulses per ball	14:			
4	screw revolution (NP)	It is controlled with the fixed parameter.			
5	Permissible droop pulse value	6553500 1 to 1073741824 [pulse]			
6	Upper stroke limit value	214748364.7	-214748364.8 to	-21474.83648 to	
7	Lower stroke limit value	0	214748364.7 [µm]	21474.83647 [inch]	
	Speed limit value (VL)	0	0.01 to 6000000.00	0.001 to 600000.000	
8			[mm/min]	[inch/min]	
9	Torque limit value setting device (1 word)	_	-(300[%]) / word device (D, W, #, U□\G)		
10	Comment	None	32 characters		


# (1) Output unit

- (a) This device is used to set the unit ([mm]/[inch]) of ball screw.
- (b) Set the same unit as used in the real mode (unit in the fixed parameters) for the ball screw unit.

If the ball screw unit differs unit in the real mode, a mode switching error will occur at the switching from real mode to virtual mode.

# (2) Ball screw pitch(P)/Number of pulses per ball screw revolution(NP)

(a) The ball screw pitch connected to the servo motor and number of pulses per ball screw revolution are displayed.



(b) The travel value per pulse is calculated by the ball screw pitch and number of pulses per ball screw revolution as the formula below.

[Travel value per pulse] = 
$$\frac{P}{NP}$$

## **POINT**

"Ball screw pitch" or "number of pulses per ball screw revolution" is used for only the cycle speed monitor of servo motor, and it is not related to the rotation speed/travel value of servo motor.

# (3) Permissible droop pulse value

- (a) This device is used to set the permissible droop pulse value of deviation counter.
- (b) The deviation counter value is continually checked, and if it becomes larger than the permissible droop pulse value, the error detection signal (M2407+20n) turns on.

However, since the ball screw axis operation continues, execute the error processing by user side.

#### (4) Upper/lower stroke limit value

- (a) This device is used to set the stroke range in the virtual mode.
- (b) When it exceeds the stroke range during operation, the error detection signal (M2407+20n) turns on.

However, a stop processing of ball screw axis is not executed.

#### (5) Speed limit value (VL)

- (a) This device is used to set the maximum speed of ball screw axis.
- (b) Set the speed limit value within the following range.
  - 1) Unit: [mm]


$$1 \le \frac{V_L \times 10^4 \times N_P}{60 \times P} \le 2147483647$$
 [pulse/s]

2) Unit: [inch]

$$1 \le \frac{V_L \times 10^5 \times N_P}{60 \times P} \le 2147483647$$
 [pulse/s]

(c) When the ball screw axis speed exceeds the speed limit value, the error detection signal (M2407+20n) turns on.

However, the ball screw axis speed is not clamped.



# (6) Torque limit value setting device (1 word)

(a) This device is used to set the torque limit value of ball screw axis.

When the device is set, the torque control is executed with the preset device value.

In the virtual mode, the torque limit setting is always valid.

If the device is not set, the torque limit is set at 300[%].

(b) The following devices can be set as the torque limit value setting device.

Name	Setting range
Data register	D0 to D8191 <sup>(Note-1)</sup>
Link register	W0 to W1FFF
Motion register	#0 to #7999
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) <sup>(Note-2)</sup>

(Note-1): D800 to D1559 are dedicated devices of virtual servo motor axis, synchronous encoder axis and output module "Cam" in the virtual mode. Unused areas of virtual servo motor axis and cam axis can be used as a user device.

(Note-2): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

(c) The setting range for the torque limit value is 1 to 1000[%].

#### (7) Comment

- (a) This device is used to create a comment such as purpose of ball screw axis. Made comment can be displayed at monitoring using MT Developer2.
- (b) Comments up to 32 characters long can be created.

## 8.3 Rotary Tables

The rotary table is used to make a machine connected to the servo motor gyrate. This section describes the rotary table operation and parameters required to use rotary table.


### 8.3.1 Operation

# (1) Operation

(a) The rotary table is controlled with the speed that the speed/travel value of drive module multiplied by a gear ratio of transmission module, and the travel value is output.

```
(Rotary table speed) = (Drive module speed) [pulse/s] × (Gear ratio) [pulse/s]
(Rotary table travel value) = (Drive module travel value) [pulse] × (Gear ratio) [pulse]
```

The speed/travel value of drive module transmitted to the rotary table is commanded to the servo amplifier.



(b) When a clutch is used, the rotary table is controlled at clutch ON.

### (2) Control details

- (a) Feed current value is continued, even if it switches from the real mode to virtual mode/from the virtual mode to real mode.
- (b) Backlash compensation processing is continued with the settings value of fixed parameters, even if it switches the real mode/virtual mode.

### 8.3.2 Parameter list

The rotary table parameters are shown in Table 8.3 and the parameters shown in this table are explained in items (1) to (8) below.

Refer to the help of MT Developer2 for the rotary table parameter setting method.


Table 8.3 Rotary Table Parameter List

No.	Setting Item	Default	Setting range
1	Output axis No.	0	Q173DSCPU/Q173DCPU(-S1): 1 to 32 Q172DSCPU : 1 to 16 Q172DCPU(-S1) : 1 to 8
2	Number of pulses per rotary table revolution (ND)	It	Must be not set. is controlled with the fixed parameter.
3	Permissible droop pulse value	6553500	1 to 1073741824 [pulse]
4	Upper stroke limit value	0	0 to 359.99999 [degree]
5	Lower stroke limit value	0 0 to 359.99999 [degree]	
6	Speed limit value (VL) 0 0.001 to 2		0.001 to 2147483.647 [degree/min] (Note-1)
7	Torque limit value setting device (1 word)	_	-(300[%]) / word device (D, W, #, U□\G)
8	Comment	None	32 characters
9	Current value within 1 virtual axis revolution storage device (Main shaft side) (2 words)	_	- / word device (D, W, #, U□\G)
10	Current value within 1 virtual axis revolution storage device (Auxiliary input axis side) (2 words)	_	- / word device (D, W, #, U□\G)

(Note-1): When the "speed control  $10 \times$  multiplied speed setting for degree axis" is set to "valid", the setting range is 0.01 to 21474836.47[degree/min].

# (1) Number of pulses per rotary table revolution (ND)

(a) The number of pulses per rotary table connected to the servo motor revolution is displayed.



Displayed items	Displayed range
	Must be not set.
Nonelean of modern man	It is controlled with the fixed parameter.
Number of pulses per	No - As[pulse] 360[degree]
	ND = AP[pulse] × 360[degree] AL [degree]
	AP : Number of pulsesI value per revolution of fixed parameter
	AL : Travel value per revolution of fixed parameter

(b) The travel value per pulse is calculated from the number of pulses per rotary table revolution in accordance with the following formula:

[Travel value per pulse] = 
$$\frac{360}{ND}$$
 [degree]

#### **POINT**

"Number of pulses per rotary table revolution" is used for only the cycle speed monitor of servo motor, and it is not related to the rotation speed/travel value of servo motor.

# (2) Permissible droop pulse value

- (a) This device is used to set the permissible droop pulse value of deviation counter.
- (b) The deviation counter value is continually checked, and if it becomes larger than the permissible droop pulse value, the error detection signal (M2407+20n) turns on.

However, since the rotary table axis operation continues, execute the error processing by user side.

# (3) Upper/lower stroke limit value

- (a) This device is used to set the stroke range in the virtual mode. The upper/lower stroke limit setting determines whether the stroke limit is valid or not. If the upper stroke limit value is equal to the lower stroke limit value, the stroke limit is invalid.
- (b) When it exceeds the stroke range during operation, the error detection signal (M2407+20n) turns on.

However, a stop processing of rotary table axis is not executed.


### (4) Speed limit value (VL)

- (a) This device is used to set the maximum speed of rotary table axis.
- (b) Set the speed limit value within the following range.

$$1 \le \frac{V_L \times 10^5 \times N_D}{60 \times 360 \times 10^5} \le 2147483647[pulse/s]$$

(c) When the rotary table axis speed exceeds the speed limit value, the error detection signal (M2407+20n) turns on.

However, the rotary table axis speed is not clamped.



# (5) Torque limit value setting device (1 word)

(a) This device is used to set the torque limit value of rotary table axis.

When the device is set, the torque control is executed with the preset device value.

In the virtual mode, the torque limit setting is always valid.

If the device is not set, the torque limit is set at 300[%].

(b) The following devices can be set as the torque limit value setting device.

Name	Setting range
Data register	D0 to D8191 <sup>(Note-1)</sup>
Link register	W0 to W1FFF
Motion register	#0 to #7999
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) (Note-2)

(Note-1): D800 to D1559 are dedicated devices of virtual servo motor axis, synchronous encoder axis and output module "Cam" in the virtual mode. Unused areas of virtual servo motor axis and cam axis can be used as a user device.

(Note-2): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

(c) The setting range for torque limit value is 1 to 1000[%].


#### (6) Comment

(a) This device is used to create a comment such as purpose of rotary table axis


Made comment can be displayed at monitoring using MT Developer2.

- (b) Comments up to 32 characters long can be created.
- (7) Current value within 1 virtual axis revolution storage device (Main shaft side) (2 words)

This parameter is set when the address mode clutch is set at the rotary table main shaft side.



Current value within 1 virtual axis revolution = (Drive module travel value  $\times$  gear) %ND



The reference position (0) for the current value within 1 virtual axis revolution is set with the address clutch reference setting command (M3213+20n).

(a) The current value within 1 virtual axis revolution of rotary table main shaft side is stored in the preset device.

(b) The following devices can be set as the current value within 1 virtual axis revolution storage device.

Name	Setting range <sup>(Note-1)</sup>
Data register	D0 to D8191 <sup>(Note-2)</sup>
Link register	W0 to W1FFF
Motion register	#0 to #7999
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) (Note-3), (Note-4)

(Note-1): Set an even number at the first device.

(Note-2): D800 to D1559 are dedicated devices of virtual servo motor axis, synchronous encoder axis and output module "Cam" in the virtual mode. Unused areas of virtual servo motor axis and cam axis can be used as a user device.

(Note-3): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

(Note-4): Only device of the self-CPU can be used.

(c) The current value within 1 virtual axis revolution is the range of 0 to (ND-1) [pulse].

(ND: Number of pulses per rotary table revolution)

- (d) The address mode clutch is turned on/off with the specified address of the current value within 1 virtual axis revolution range of 0 to (ND-1) [pulse]. Therefore, set the address value within the range of 0 to (ND-1) [pulse] in the clutch ON/OFF address setting device.
- (e) The current value within 1 virtual axis revolution reference position "0" is set by turning the address clutch reference setting command (M3213+20n) on and switching to the virtual mode.

The current values within 1 virtual axis revolution for both the main shaft and the auxiliary input axis is set to "0" at this time.


If the address clutch reference setting command (M3213+20n) is turned off and it switches to the virtual mode, the following processing is executed depending on the drive module.

- If the drive module is a virtual servo motor or an incremental synchronous encoder, operation will be continued from the current value within 1 virtual axis revolution for the main shaft and auxiliary input axis in the previous virtual mode.
- If the drive module is an absolute synchronous encoder, operation will be continued from the current value within 1 virtual axis revolution for the main shaft and auxiliary input axis calculated from the current value of synchronous encoder.

(f) An example of an address mode clutch operation is shown below.

(8) Current value within 1 virtual axis revolution storage device (Auxiliary input axis side) (2 words)

This parameter is set when the address mode clutch is set at the rotary table auxiliary input axis side.



(a) By setting the current value within 1 virtual axis revolution of rotary table auxiliary input axis side for the current value within 1 virtual axis revolution is stored in the preset device.

Current value within 1		Drive module travel		Gear ratio
virtual axis revolution of	=	value of auxiliary input	×	Number of pulses per rotary table revolution
auxiliary input axis side		axis side		rame or parece per retary table reversalies.

(Note): Current value within 1 virtual axis revolution of auxiliary input axis side is updated regardless of clutch ON/OFF.

(b) The following devices can be set as the current value within 1 virtual axis revolution storage device.

Name	Setting range <sup>(Note-1)</sup>
Data register	D0 to D8191 <sup>(Note-2)</sup>
Link register	W0 to W1FFF
Motion register	#0 to #7999
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) (Note-3), (Note-4)

(Note-1): Set an even number at the first device.

(Note-2): D800 to D1559 are dedicated devices of virtual servo motor axis, synchronous encoder axis and output module "Cam" in the virtual mode. Unused areas of virtual servo motor axis and cam axis can be used as a user device.

(Note-3): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

(Note-4): Only device of the self CPU can be used.

(c) The current value within 1 virtual axis revolution is the range of 0 to (ND-1) [pulse].


(ND: Number of pulses per rotary table revolution)

- (d) The address mode clutch is turned on/off with the specified address of the current value within 1 virtual axis revolution range of 0 to (ND-1) [pulse]. Therefore, set the address value within the range of 0 to (ND-1) [pulse] in the clutch ON/OFF address setting device.
- (e) The current value within 1 virtual axis revolution reference position "0" is set by turning the address clutch reference setting command (M3213+20n) on and switching to the virtual mode.

The current values within 1 virtual axis revolution for both the main shaft and the auxiliary input axis is set to "0" at this time.

If the address clutch reference setting command (M3213+20n) is turned off and it switches to the virtual mode, the following processing is executed depending on the drive module.

- If the drive module is a virtual servo motor or an incremental synchronous encoder, operation will be continued from the current value within 1 virtual axis revolution for the main shaft and auxiliary input axis in the previous virtual mode.
- If the drive module is an absolute synchronous encoder, operation will be continued from the current value within 1 virtual axis revolution for the main shaft and auxiliary input axis calculated from the current value of synchronous encoder.



(f) An example of an address mode clutch operation is shown below.


# POINT

When the number of pulses per virtual axis revolution is not an integer value, a virtual axis revolution may not become a rotary table revolution.

### 8.4 Cam

Cam is used to make a machine connected to the servo motor operate according to the preset cam pattern.

(1) For axes at which the cam is set as the output module, the same operation as a cam is executed using a ball screw as shown in the example below.



- (2) The following two types data required to use a cam.
  - Settings item at cam data creation.
     It is set at cam data (cam curve) creation using the MT Developer2.
     (Refer to Section 8.4.2)
  - Cam parameters

These are the parameters used to set to cam in the output module at mechanical system program creation.

(Refer to Section 8.4.3)

### 8.4.1 Operation

This section describes the cam operation.

- (1) Procedure for switching from the real mode to virtual mode Set the devices by the following procedure using the Motion SFC program at the switching from real mode to virtual mode.
  - (a) Set the following details.
    - Set the cam No. and stroke amount in the "cam No. setting device" and "stroke amount setting device" set in each cam shaft parameters.
    - Turn the cam reference position setting command (M3214+20n) on/off as required.

(Refer to Section 4.1.2 (4))

.1.

(b) Execute the real mode/virtual mode switching request.(M2043: OFF → ON)

J.

- (c) Start operation based on the cam pattern, stroke amount and cam reference setting command set in each cam shaft.
- (2) Processing at the switching from the real mode to virtual mode

  The current value within 1 cam shaft revolution is indexed based on the cam
  reference position setting command (M3214+20n), feed current value, lower
  stroke limit value, stroke amount and cam No. (cam pattern) at the switching from
  real mode to virtual mode.


# (3) Operation

A value calculated by the stroke ratio of cam data table based on the current value within 1 cam shaft revolution is output.

[Feed current value] = [Lower stroke limit value] + [Stroke amount] × [Stroke ratio]

The current value within 1 cam shaft revolution is set by the travel value that the travel value of drive module multiplied by a gear ratio of transmission module. Number of pulses per stroke amount is controlled based on the travel value per pulse set in the fixed parameter in the real mode.

- (4) Switching the stroke amount and cam No. during operation
  - (a) The cam stroke amount and execute cam No. can be changed using the Motion SFC program during cam operation.
  - (b) The stroke amount and cam No. are changed by the address set in the "stroke amount, cam No. change point" at the creating cam data. When the "stroke amount, cam No. change point" is passed, the stroke amount/cam No. is changed based on the value of the stroke amount setting device and cam No. setting device set in the cam parameters.



- (c) Error causes at the changing stroke amount/cam No. during operation
  - 1) The cam No. and stroke amount are always input at the switching from real mode to virtual mode and in the virtual mode.

A relative check is executed at the time of input. An error occurs in the following cases, the error detection signal (M2407+20n) turns on and the error code is stored in the minor error code storage register.

- The stroke amount is outside the range of 1 to 2147483647 (2<sup>31</sup>-1).
   "Lower stroke limit value + Stroke amount" ≤ "2147483647 (2<sup>31</sup>-1)" is not satisfied in the two-way cam mode.
- The control mode of cam No. is not same.
- 2) Processing for the cam No./stroke amount error
  - If the error occurs at switching from the real mode to virtual mode, it does not switch to the virtual mode.
  - If the error occurs at reaching the preset "stroke amount, cam No. change point" (during cam operation), operation continues without switching to the preset stroke amount/cam No.
    - Reset the error detection signal and minor error code storage register by the error reset command (M3207+20n).
- 3) Processing for the error
  - a) If the error occurs at switching from the real mode to virtual mode, correct by the following procedure.
    - Turn the real mode/virtual mode switching request flag (M2043) off.
    - Correct the cam No. and stroke amount.
    - Turn the real mode/virtual mode switching request flag on, and switch to virtual mode.
  - b) If the error occurs during cam operation, correct the cam No. and stroke amount.

### (5) Control details

- (a) The cam feed current value is continued at switching from the real mode to virtual mode/from the virtual mode to real mode.
- (b) Backlash compensation processing is continued with the settings value of fixed parameters, even if switches the real mode/virtual mode.
- (c) Upper/lower stroke limit value and speed limit value are not checked.


### (6) Control change

The current value within 1 cam shaft revolution can be changed to optional value for the cam as the control change during the virtual mode operation.

Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22)


Programming Manual (Motion SFC)" for details of current value change.

Motion SFC program for which executes the current value change (CHGA-C) is shown below.



(Note): Example of the above Motion SFC program is started using the automatic start or sequence program.


#### [Operation]



## (7) Program example

[Switching real mode/virtual mode]


Motion SFC program for switching real mode/virtual mode is shown below.



(Note): Example of the above Motion SFC program is started using the automatic start or sequence program.

[Switching cam No./stroke amount during operation]

Motion SFC program for switching cam No. or stroke amount is shown below.



(Note): Example of the above Motion SFC program is started using the automatic start or sequence program.

## 8.4.2 Settings items at cam data creating

This section describes the setting items at cam data creating using MT Developer2.

Table 8.4 Table of Settings Items at cam Data Creating

No.	Setting item	Default	Setting range
1	Cam No.		Refer to (1)
2	Resolution	256	256, 512, 1024, 2048
3	Stroke amount/ Cam No. change point	0	0 to (resolution-1)
4	Operation mode	Two-way cam mode	Two-way cam mode Feed cam mode
5	Cam data table	0	0 to 32767

# (1) Cam No.

This device is used to set the number allocated in created cam data.

The number of cam data is set "1 to 64" for each machine.

A cam No. is used with the number which offset value attached by the machine name sequence registered on mechanical system editing screen in the mechanical system program.

Machine name sequence	Setting cam No.
1	1 to 64
2	101 to 164
3	201 to 264
4	301 to 364

### (2) Resolution


- (a) This device is used to set the number of index divisions in one cam cycle.
- (b) The following conditions need to be satisfied in order to output the all point data of resolution correctly.
  - Number of pulses per cam revolution (Nc) ≥ Resolution
  - Time required per cam revolution ≥ Operation cycle × Resolution


### (3) Stroke amount/cam No. change point

- (a) This device is used to set a position at which the stroke amount/cam No. is switched during operation.
- (b) When the set switching position [range: 0 to (resolution -1)] is reached, if the stroke amount/cam No. is normal, it is switched to the setting stroke amount and cam No.


# (4) Operation mode


- (a) This device is used to set the two-way cam mode/feed cam mode.
  - Two-way cam mode ...... A two-way operation is repeated between the lower stroke limit value (lower dead point) and the range set in the stroke amount.






2) Feed cam mode ......With the lower stroke limit value (lower dead point) as the operation start position, positioning is executed by feeding one stroke amount per cycle in a fixed direction.





# (5) Cam data table

(a) This device is used to set each point stroke ratio (when the stroke amount is divided into 32767 divisions) in the set resolution.



(b) The cam data table is automatically created by creating the cam curve using MT Developer2.

The cam curves which can be used in the Motion CPU are shown in Section 8.4.4.

#### 8.4.3 Parameter list

The cam parameters are shown in Table 8.5 and the parameters No.2 to No.12 shown in this table are explained in items (1) to (11) below.

Refer to the help of MT Developer2 for the cam parameter setting method.


Table 8.5 Cam Parameter List

No.	Setting item	Default value	Setting range		
1	Output axis No.	0	Q173DSCPU/Q173DCPU(-S1): 1 to 32 Q172DSCPU : 1 to 16 Q172DCPU(-S1) : 1 to 8		
2	Number of pulses per cam shaft revolution (Nc) (2 words)	0	1 to 1073741824 [pulse]/ Word device (D, W, #, U□\G)		
3	Cam No. setting device (1 word)	_	Word device (D, W, #, U□\G)		
4	Permissible droop pulse value	6553500	1 to 1073741824 [pulse]		
5	Output unit	mm	mm inch degree 🚥 pulse		
6	Stroke amount setting device (2 words)	_	Word device (D, W, #, U□\G)		
7	Torque limit value setting device (1 word)	_	-(300[%]) / word device (D, W, #, U□\G)		
8	Comment	None	32 characters		
9	Lower stroke limit value storage device (2 words)	_	- / word device (D, W, #, U□\G)		
10	Current value within 1 virtual axis revolution storage device (Main shaft side, 2 words)	_	- / word device (D, W, #, U□\G)		
11	Current value within 1 virtual axis revolution storage device (Auxiliary input axis side, 2 words)	_	- / word device (D, W, #, U□\G)		
12	Cam/ball screw switching command device	_	- / bit device (Note-1)		

(Note-1): The devices set in other parameter cannot be used.

### (1) Number of pulses per cam shaft revolution (Nc) (2 word)

(a) The number of pulses required to rotate the cam one cycle is set.



- (b) The setting for the number of pulses per cam shaft revolution is not related to the travel value per pulse (fixed parameter setting).
- (c) Set cam reference position after setting the number of pulses per cam shaft revolution. If not setting, the positioning is executed at the position before change.

(d) The following devices can be set as the number of pulses per cam shaft revolution. QDS

Name	Setting range <sup>(Note1)</sup>
Data register	D0 to D8191 <sup>(Note2)</sup>
Link register	W0 to W1FFF
Motion register	#0 to #7999
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) (Note-3)

(Note-1): Set an even number at the first device.

(Note-2): D800 to D1559 are dedicated devices of virtual servo motor axis, synchronous encoder axis and output module "Cam" in the virtual mode. Unused areas of virtual servo motor axis and cam axis can be used as a user device.

(Note-3): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

### (2) Cam No. setting device (1 word)

- (a) This device is used to set the device that sets in the Motion SFC program by which the cam No. to control.
- (b) The following devices can be set as the cam No. setting device.

Name	Setting range
Data register	D0 to D8191 <sup>(Note-1)</sup>
Link register	W0 to W1FFF
Motion register	#0 to #7999
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) (Note-2)

(Note-1): D800 to D1559 are dedicated devices of virtual servo motor axis, synchronous encoder axis and output module "Cam" in the virtual mode. Unused areas of virtual servo motor axis and cam axis can be used as a user device.

(Note-2): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

(c) When the cam No. setting device value is changed during operation, it changes to the cam No. changed in the "stroke amount/cam No. switching position" set at the cam creating.

### (3) Permissible droop pulse value

- (a) This device is used to set the permissible droop pulse value of deviation counter.
- (b) The deviation counter value is continually checked, and if it becomes larger than the permissible droop pulse value, the error detection signal (M2407+20n) turns on.

However, since the cam shaft operation continues, execute the error processing by user side.

### (4) Output unit

- (a) This device is used to set the unit ([mm]/[inch]/[degree] [msk/[pulse]) of cam.
- (b) Set the same unit as used in the real mode (unit in the fixed parameters) for the cam shaft.

# (5) Stroke amount setting device (2 words)

- (a) This device is used to set the cam stroke amount.
- (b) The following devices can be set as the stroke amount setting device.

Name	Setting range <sup>(Note1)</sup>				
Data register	D0 to D8191 <sup>(Note2)</sup>				
Link register	W0 to W1FFF				
Motion register	#0 to #7999				
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) (Note-3)				

(Note-1): Set an even number at the first device.

(Note-2): D800 to D1559 are dedicated devices of virtual servo motor axis, synchronous encoder axis and output module "Cam" in the virtual mode. Unused areas of virtual servo motor axis and cam axis can be used as a user device.

(Note-3): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

- (c) Set the stroke amount within the following range.
  - · Setting range in the two-way cam mode

Unit	Setting range
mm	Lower stroke limit value + Stroke amount ≤ 2147483647×10 <sup>-1</sup> [µm]
inch	Lower stroke limit value + Stroke amount ≤ 2147483647×10 <sup>-5</sup> [inch]
degree @ps(	Lower stroke limit value + Stroke amount ≤ 2147483647×10 <sup>-5</sup> [degree]
pulse	Lower stroke limit value + Stroke amount ≤ 2147483647 [pulse]

#### · Setting range in the feed cam mode

Unit	Setting range
mm	0 < Stroke amount ≤ 2147483647 × 10 <sup>-1</sup> [μm]
inch	0 < Stroke amount ≤ 2147483647×10 <sup>-5</sup> [inch]
degree @DSK	0 < Stroke amount ≤ 2147483647 × 10 <sup>-5</sup> [degree]
pulse	0 < Stroke amount ≤ 2147483647 [pulse]

#### **POINT**

When the cam reference position setting command (M3214+20n) is OFF, a position of cam axis is restored in the range of 0 to 359.99999[degree]. If the cam stroke amount is larger than 360.00000[degree], the current value within 1 cam shaft revolution different from the previous virtual mode might be restored. (Example) When cam position is restored by switching to virtual mode in the

following conditions, the current value within 1 cam shaft revolution corresponding to "current feed value: 80[degree]" is restored.

Stroke amount : 720[degree]Lower stroke limit value: 0[degree]

• Current value : Lower stroke limit value + 440[degree]

(Current feed value: 80[degree])

# (6) Torque limit value setting device (1 word)

(a) This device is used to set the torque limit value for cam shaft.

When the device is set, the torque control is executed with the preset device value.

In the virtual mode, the torque limit setting is always valid.

If the device is not set, the torque limit is set at 300[%].

(b) The following devices can be set as the torque limit value setting device.

Name	Setting range			
Data register	D0 to D8191 <sup>(Note-1)</sup>			
Link register	W0 to W1FFF			
Motion register	#0 to #7999			
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) (Note-2)			

(Note-1): D800 to D1559 are dedicated devices of virtual servo motor axis, synchronous encoder axis and output module "Cam" in the virtual mode. Unused areas of virtual servo motor axis and cam axis can be used as a user device.

(Note-2): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

(c) The setting range for torque limit value is 1 to 1000[%].

### (7) Comment

- (a) This device is used to create a comment such as purpose of cam shaft. Made comment can be displayed at monitoring using MT Developer2.
- (b) Comments up to 32 characters long can be created.

### (8) Lower stroke limit value storage device (2 words)

- (a) This device is used to store the cam lower stroke limit value. The current lower stroke limit value is stored.
- (b) The following devices can be set as the lower stroke limit value storage device.

Name	Setting range (Note-1)				
Data register	D0 to D8191 <sup>(Note-2)</sup>				
Link register	W0 to W1FFF				
Motion register	#0 to #7999				
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) (Note-3), (Note-4)				

(Note-1): Set an even number at the first device.

(Note-2): D800 to D1559 are dedicated devices of the virtual servo motor axis, synchronous encoder axis and output module "Cam" in the virtual mode. The unused areas of the virtual servo motor axis and cam axis can be used as a user device.

(Note-3): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.


(Note-4): Only device of the self CPU can be used.

- (c) The lower stroke limit value is range of -2147483648 (- $2^{31}$ ) to 2147483647 ( $2^{31}$ -1).
  - The lower stroke limit value is determined as follows for each unit setting.


Unit	Setting range			
mm	Lower stroke limit value×10 <sup>-1</sup> [µm]			
inch	Lower stroke limit value×10 <sup>-5</sup> [inch]			
degree @DSK	Lower stroke limit value×10 <sup>-5</sup> [degree]			
pulse	Lower stroke limit value ×1 [pulse]			

(9) Current value within 1 virtual axis revolution storage device (Main shaft side) (2 words)

This parameter is set when the address mode clutch is set at the cam main shaft side.



Current value within 1 virtual axis revolution = (Drive module travel value × gear) %Nc (% : Remainder operator)




- (a) The current value within 1 virtual axis revolution of cam main shaft side is stored in the preset device.
- (b) The following devices can be set as the current value within 1 virtual axis revolution storage device.

Name	Setting range (Note-1)				
Data register	D0 to D8191 <sup>(Note-2)</sup>				
Link register	W0 to W1FFF				
Motion register	#0 to #7999				
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) (Note-3), (Note-4)				


- (Note-1): Set an even number at the first device.
- (Note-2): D800 to D1559 are dedicated devices of the virtual servo motor axis, synchronous encoder axis and output module "Cam" in the virtual mode. The unused areas of the virtual servo motor axis and cam axis can be used as a user device.
- (Note-3): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.
- (Note-4): Only device of the self CPU can be used.
- (c) The current value within 1 virtual axis revolution is the range of 0 to (Nc-1) [pulse].
  - (Nc: Number of pulses per cam shaft revolution)
- (d) The address mode clutch is turned on/off with the specified address of the current value within 1 virtual axis revolution range of 0 to (Nc-1) [pulse]. Therefore, set the address value within the range of 0 to (Nc-1) [pulse] in the clutch ON/OFF address setting device.

- (e) The current value within 1 virtual axis revolution reference position "0" is set by turning the address clutch reference setting command (M3213+20n) on and switching to the virtual mode.
  - The current values within 1 virtual axis revolution for both the main shaft and the auxiliary input axis is set to "0" at this time.
  - If the address clutch reference setting command (M3213+20n) is turned off and it switches to the virtual mode, the following processing is executed depending on the drive module.
  - If the drive module is a virtual servo motor or an incremental synchronous encoder, operation will be continued from the current value within 1 virtual axis revolution for the main shaft and auxiliary input axis in the previous virtual mode.
  - If the drive module is an absolute synchronous encoder, operation will be continued from the current value within 1 virtual axis revolution for the main shaft and auxiliary input axis calculated from the current value of synchronous encoder.
- (f) An example of an address mode clutch operation is shown below.



(10) Current value within 1 virtual axis revolution storage device (Auxiliary input axis side) (2 words)

This parameter is set when the address mode clutch is set at the cam auxiliary input axis side.



(a) By setting the current value within 1 virtual axis revolution of auxiliary input axis side, for the current value within 1 virtual axis revolution is stored in the preset device.

Current value within 1 virtual	Drive module travel value	Gear ratio
axis revolution of auxiliary input =	of auxiliary input axis side	× Number of pulses per cam revolution
axis side	or auxiliary imput axis side	ramile er pailee per cam reverance.


(Note): Current value within 1 virtual axis revolution of auxiliary input axis side is updated regardless of clutch ON/OFF.

(b) The following devices can be set as the current value within 1 virtual axis revolution storage device.

Name	Setting range <sup>(Note-1)</sup>				
Data register	D0 to D8191 <sup>(Note-2)</sup>				
Link register	W0 to W1FFF				
Motion register	#0 to #7999				
Multiple CPU area device	U□\G10000 to U□\G(10000+p-1) (Note-3), (Note-4)				

- (Note-1): Set an even number at the first device.
- (Note-2): D800 to D1559 are dedicated devices of the virtual servo motor axis, synchronous encoder axis and output module "Cam" in the virtual mode. The unused areas of the virtual servo motor axis and cam axis can be used as a user device.
- (Note-3): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.
- (Note-4): Only device of the self CPU can be used.
- (c) The current value within 1 virtual axis revolution is the range of 0 to (Nc-1) [pulse].
- (d) The address mode clutch is turned on/off with the specified address of the current value within 1 virtual axis revolution range of 0 to (NC-1) [pulse]. Therefore, set the address value within the range of 0 to (NC-1) [pulse] in the clutch ON/OFF address setting device.

- (e) The current value within 1 virtual axis revolution reference position "0" is set by turning the address clutch reference setting command (M3213+20n) on and switching to the virtual mode.
  - The current values within 1 virtual axis revolution for both the main shaft and the auxiliary input axis is set to "0" at this time.
  - If the address clutch reference setting command (M3213+20n) is turned off and it switches to the virtual mode, the following processing is executed depending on the drive module.
  - If the drive module is a virtual servo motor or an incremental synchronous encoder, operation will be continued from the current value within 1 virtual axis revolution for the main shaft and auxiliary input axis in the previous virtual mode.
  - If the drive module is an absolute synchronous encoder, operation will be continued from the current value within 1 virtual axis revolution for the main shaft and auxiliary input axis calculated from the current value of synchronous encoder.
- (f) An example of an address mode clutch operation is shown below.



- (11) Cam/ball screw switching command device
  - (a) This parameter is used to set cam operation.
  - (b) The following devices can be used as the cam/ball screw switching command device.

Name	Setting range				
Input	X0 to X1FFF (Note-1)				
Output	Y0 to Y1FFF				
Internal relay	M0 to M8191 (Note-2), (Note-3)				
Link relay	B0 to B1FFF				
Annunciator	F0 to F2047				
Multiple CPU area device	U□\G10000.0 to U□\G(10000+p-1).F (Note-4)				

- (Note-1): The range of "PXn+4 to PXn+F" cannot be used (fixed at 0) for the input device (PXn+0 to PXn+F) allocated to the built-in interface in Motion CPU (DI). (n: First input No.)
- (Note-2): "M4000 to M4639 and M4800 to M5439" are the dedicated devices of virtual servo motor axis in the virtual mode.

Unused area of virtual servo motor axis can be used as a user side.

- (Note-3): Use these parameters to use the device (M5488 to M5519) allocated to Q17 $\square$ CPUN/Q17 $\square$ HCPU.
- (Note-4): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.
- (c) The following operation is executed depending on the setting unit by turning the cam/ball screw switching command on corresponding to each output axis No.

mm : Same operation as ball screw. inch : Same operation as ball screw.

degree : Same operation as rotary table.

pulse : Same operation as ball screw.

(d) Operation of output axis by cam/ball screw switching command is shown below.

Items	Operation details		
Cam/ball screw switching command : OFF	Specified cam pattern operation		
Cam/ball screw switching command : ON	Unit: mm, inch, pulse     Same operation as ball screw.     Unit: degree		

- (e) The current value within 1 cam shaft revolution is calculated based on the feed current value, lower stroke limit value, stroke amount and cam No. (cam pattern) by turning off the cam/ball screw switching command. If the cam/ball screw switching command is turned off outside the range of "lower stroke limit value to stroke amount" for cam, a minor error (error code: 5000) will occur.
- (f) "Continue Virtual Mode" is set for operation on servo error, if the feed current value of output axis is outside the range of cam operation ("Lower stroke limit value to Stroke amount") by servo error for two-way cam, return the output axis to within cam operation range.
  - 1) Remove servo error cause.

1

2) Turn the cam/ball screw switching command ON.

3) Execute the servo error reset (M3208+20n).

4) Return the output axis position within cam operation range to within stroke range by JOG operation, etc.

5) Turn the cam/ball screw switching command OFF.

6) Re-start virtual mode.

### 8.4.4 Cam curve list

This section describes the cam curves which can be used in the virtual mode.

(1) Cam curve characteristics comparison

The cam curve characteristics comparison is shown below.

Table 8.6 Cam Curve Characteristics Comparison Table

	Class	Cam curve name	Acceleration curve shape	Vm	Am	(A • V)m	(V • V)m	(S • V)m	Remark
Discontinuity curves		Constant - speed	<b>*</b>	1.00			1.00	1.00	
		Constant- acceleration		2.00	± 4.00	± 8.00	4.00	1.09	
	Symmetrical curves	5 <sup>th</sup> curve	$\sim$	1.88	± 5.77	± 6.69	3.52	1.19	
		Cycloid	$\sim$	2.00	± 6.28	± 8.16	4.00	1.26	
		Distorted trapezoid		2.00	± 4.89	± 8.09	4.00	1.20	Ta = 1 / 8
Two-		Distorted sine	$\sim$	1.76	± 5.53	± 5.46	3.10	1.13	Ta = 1 / 8
dwelling curve		Distorted constant-speed	Δ	1.28	± 8.01	± 5.73	1.63	1.07	Ta = 1 / 16 Ta = 1 / 4
	Asymmetrical curves	Trapecloid		2.18	± 6.17	± 10.84	4.76	1.28	m = 1
		Reverse trapecloid	$\sim$	2.18	± 6.17	± 10.84	4.76	1.28	m = 1
One-dwelling curve		Double hypotenuse		2.04	+ 5.55 - 9.87	+ 7.75 - 9.89	4.16	1.39	
Non-dwelling curve		Single hypotenuse		1.57	± 4.93	± 3.88	2.47	1.02	

### (2) Free-form curve

The spline interpolation function can be used to create free-form cam curves.

## 8.5 Phase Compensation Function

When carrying out a position follow-up control (synchronous operation) by synchronous encoder, delays in the progresses, etc. cause the phase to deviate at servo motor shaft end in respect to the synchronous encoder. The phase compensation function compensates in this case so that the phase does not deviate.

### (1) Parameter list

Set the following devices for axes to execute the phase compensation function. (Set in the output module parameter.)

Table 8.7 Phase Compensation Function Parameter List

No.	Item	Number of device words	Device setting range	Setting range
1	Phase advance time	2	D0 to D8191 <sup>(Note-1), (Note-2)</sup> W0 to W1FFF <sup>(Note-2)</sup> U□\G10000 to U□\G(10000+p-1) <sup>(Note-2), (Note-3)</sup>	-2147483648 to 2147483647[µs]
2	Phase compensation time constant	1	D0 to D8191 <sup>(Note-1)</sup> W0 to W1FFF  U□\G10000 to U□\G(10000+p-1) <sup>(Note-3)</sup>	0 to 32767[times]
3	Phase compensation processing valid flag	Bit	X0 to X1FFF <sup>(Note-4)</sup> Y0 to Y1FFF M0 to M8191 <sup>(Note-5)</sup> F0 to F2047 B0 to B1FFF U□\G10000.0 to U□\G(10000+p-1).F <sup>(Note-3)</sup>	_
4	Compensation amount monitor device	2	D0 to D8191 <sup>(Note-1), (Note-2)</sup> W0 to W1FFF <sup>(Note-2)</sup> U□\G10000 to U□\G(10000+p-1) <sup>(Note-2), (Note-3), (Note-6)</sup>	_

(Note-1): D800 to D1559 are dedicated devices of virtual servo motor axis, synchronous encoder axis and output module "Cam" in the virtual mode.

Unused areas of virtual servo motor axis and cam axis can be used as a user device.

- (Note-2): Set an even number at the first device.
- (Note-3): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.
- (Note-4): The range of "PXn+4 to PXn+F" cannot be used (fixed at 0) for the input device (PXn+0 to PXn+F) allocated to the built-in interface in Motion CPU (DI). (n: First input No.)
- (Note-5): "M4000 to M4639 and M4800 to M5439" are the dedicated devices of virtual servo motor axis in the virtual mode.
  - Unused area of virtual servo motor axis can be used as a user side.
- (Note-6): Only device of the self CPU can be used.

#### (a) Phase advance time

It is used to set whether a phase is advanced/delayed.

Phase advance time is calculated in the formula below.

Phase advance time = Delay time peculiar to system [s] + 1/PG1 [rad/s]

Delay time peculiar to system [t] : Refer to Table 8.8

: Model control gain

"Command speed[pulse/s] × Phase advance time[s]" is added to the servo command value as an amount of compensation.

Table 8.8 Delay time peculiar to system

Operation cycle	Incremental synchronous encoder use	Q171ENC-W8/Q170ENC use
[ms]	[µs]	[µs]
0.22 <b>QDS</b> (	681	612
0.44	1088	1271
0.88	2376	2611
1.77	4165	4388
3.55	7715	7943
7.11	18378	18608
14.2 QD	32613	32829

#### (b) Phase compensation time constant

It is used to set to execute leading edge/trailing edge smoothly so that a servo motor does not make rapid acceleration/deceleration at phase compensation.

Set the number of operation cycles as setting unit.

<Example>

For operation cycle is 0.88[ms] and phase compensation time constant is 50[times].

The phase compensation time constant becomes " $0.88 \times 50 = 44 [ms]$ "

Phase compensation time constant is input at the phase compensation processing valid flag ON.

#### (c) Phase compensation processing valid flag

It is used to set whether the phase compensation function is "Valid/Invalid".

- ON......Phase compensation function "Valid"
- OFF.... Phase compensation function "Invalid"

#### (d) Compensation amount monitor

The compensation amount under compensating is stored to the preset register.

- Except cam axis...Compensation amount of servo motor shaft [pulse]
- Cam axis......Compensation amount of current value within 1 virtual axis revolution [pulse]

### (2) Operating method

Operating method for phase compensation function is shown below.

(a) Set a phase advance time.

 $\downarrow$ 

- (b) Set a suitable time constant as a phase compensation time constant.
- (c) Turn the phase compensation processing valid flag on for every axis before the servo motor start.

(d) For cam axis, make a gain adjustment in the servo amplifier side to improve the flattery for cam pattern. In this case, advance to the phase of cam axis compared with axis of other roller or rotary table, etc.

Therefore, if the phase of cam axis is delayed in the phase advance time setting, a phase with the axis of a roller or rotation table, etc. can be set.

### (3) Errors at phase compensation

(a) When the phase compensation time constant is outside the setting range, a minor error [6300] will occur for applicable axis, a phase compensation is executed without soothing processing.

#### **POINT**

- (1) It must be reduced a phase compensation time constant to use for delay compensation of synchronous encoder.
- (2) When driving 2 axes synchronizing with virtual servo motor, even if the position control gains 1 of each axis differ, it can be compensated to eliminate a phase discrepancy by the following setting.
  - <Example>

For Axis 1: PG1= 50[rad/s] and Axis 2: PG1=100[rad/s],

Phase advance time = 1/50 - 1/100

 $= 0.01[s] (=10000[\mu s])$ 

Therefore,  $-10000[\mu s]$  is set as a phase advance time of axis 2, a phase of axis 2 can be set with a phase of axis 1.

(3) For cam axis, if it switches from the virtual mode to real mode in compensation amount except "0", it switches to the real mode with a phase shifted to other axes for compensation amount of remainder. In this case, switch to the real mode after setting "0" as a compensation amount.

## 9. REAL MODE/VIRTUAL MODE SWITCHING AND STOP/RE-START

This section describes the check details and switching method for the real mode/virtual mode switching.

- (1) Real mode/virtual mode switching
  - Real mode/virtual mode switching is executed by turning the real mode/virtual mode switching request flag (M2043) ON/OFF.
  - Real mode ....... Switching request to the real mode by turning the M2043 OFF.
  - Virtual mode ...... Switching request to the virtual mode by turning the M2043 ON.
- (2) Real mode/virtual mode confirmation

The current control mode state (real or virtual) can be confirmed by turning the real mode/virtual mode switching status flag (M2044) ON/OFF.

- M2044 : OFF ...... Real mode state
- M2044 : ON ...... Virtual mode state

# 9.1 Switching from the Real Mode to Virtual Mode

When the real mode to virtual mode switching is requested (M2043 OFF→ON), the following check is executed. (Confirm the check items in Table 9.1 to 9.3 for switching from real mode to virtual mode, and execute with all normal state.)

- Check to determine if switching to the virtual mode is possible.... Refer to Table 9.1

- (1) Check to determine if switching to the virtual mode is possible
  - (a) The items in Table 9.1 are checked to determine if switching to the virtual mode is possible.
    - When all check items of Table 9.1 are normal, switching to the virtual mode is executed.
  - (b) If an error of at least one item of Table 9.1, the real mode/virtual mode switching error detection flag (M2045) turns on, and the error code is stored in the real mode/virtual mode switching error information storage register (SD504 to SD506).

Refer to APPENDIX 1.7 for the error codes which are stored in the SD504 to SD506.

Table 9.1 Check Items List for Real Mode to Virtual Mode Switching

			Applicat					
Check sequence	Check item	Roller	Ball screw	Rotary table	Cam	Real mode axis (Note-1)	Normal condition	Abnor- mal condition
1	Are PLC ready flag (M2000) and PCPU READY complete flag (SM500) ON?	0	0	0	0	0	ON	OFF
2	Have all axes stopped ?     (M2001 to M2032 : OFF)	0	0	0	0	0	YES	NO
3	Has cam data using the Motion SFC program changed?	ı		_	0	l	NO	YES
	Has the mechanical system program been registered ?	0	0	0	0	0	YES	NO
4	Does the axis No. set in the system settings match the output axis set in the mechanical system program?	0	0	0	0	0	YES	NO
5	Is the all axes servo ON command (M2042) ON ?	0	0	0	0	0	ON	OFF
6	Does not the servo start processing by the servo error reset executed at the servo amplifier (axis used)?	0	0	0	0	0	Comple- tion	During proc- essing
7	• Is the external encoder normal ?	0	0	0	0	0	YES	NO
8	Is the external forced stop inputted ?	0	0	0	0	0	NO	YES
9	Are the all axes servo error detection signal (M2408+20n) ON ?	0	0	0	0	0	OFF	ON even if 1 axis
10	• Are the home position return request flag (M2409+20n) OFF ? (Excluding roller axis)	1	0	0	0	1	OFF	ON even if 1 axis
11	• Does the units set in the fixed parameters match that set in the output module ?	-	0	0	0	-	YES	NO
12	Has the cam data been registered?	_	_	_	0	_	YES	NO
13	• Has the cam No. been set at the "cam No. setting device" set in the cam parameter?	_	_	_	0	_	YES	NO
14	Has the stroke amount (1 to 2147483647)     been set at the "stroke amount setting device" set in the cam parameter?	_	_	_	0	_	YES	NO
15	Is the cam "stroke amount setting device"     an even number ?	_	_	_	0	_	YES	NO

(Note-1): It is not check target for the operating system software version "00H or later".

### (2) Output module check

- (a) The items in Table 9.2 below are checked to determine the output module state.
  - If an error is detected, it switches to the virtual mode, but the applicable system cannot be started. Correct the error cause in the real mode, and switch to virtual mode again.
- (b) When an error is detected, the error detection signal (M2407+20n) of applicable output module turns on, and the error code is stored in the minor/major error code storage register.

Table 9.2 Check Items List for Output Module

01 1		Applicable output module					
Check sequence	Check item	Roller	Ball screw	Rotary table	Cam	Normal condition	Abnormal condition
	• Is the feed current value within the stroke limit range ?	1	0	0	1		
1	<ul> <li>Is the feed current value within the range of "[lower stroke limit value] to [stroke amount]" ?</li> </ul>	_	_		0	YES	NO
2	• Does not "[lower stroke limit value] + [stroke amount]" exceed 2147483647 (2 <sup>31</sup> -1) in the two-way cam mode?	_	_	_	0	YES	NO
3	When the clutch connected to between the drive module and synchronous encoder is "external input mode", are the clutch ON/OFF device the same device?	0	0	0	0	YES	NO
3	When the clutch connected to between the drive module and synchronous encoder is "external input mode", are the encoder I/F the manual pulse generator input?	0	0	0	0	YES	NO (Serial encoder (ABS) input)
4	• Is the output module where either a "no clutch" or "clutch ON command" in effect for the virtual main shaft or the virtual auxiliary input axis the servo ready (M2415+20n : ON)?	0	0	0	0	ON	OFF
	• Is the external input signal "STOP" of output module where either a "no clutch" or "clutch ON command" in effect for the main shaft or the auxiliary input axis OFF?	0	0	0	0	OFF	ON
5	Can the current value within 1 cam revolution be calculated in the two-way cam mode?	_	_	_	0	YES	NO
6	<ul> <li>Is the clutch ON/ OFF address setting device for address mode clutch an even number?</li> </ul>	0	0	0	0	YES	NO

- (3) Synchronous encoder axis check
  - (a) The items in Table 9.3 below are checked to determine the synchronous encoder state.
    - If an error is detected, it switches to the virtual mode, but the applicable system cannot be started. Correct the error cause in the real mode, and switch to virtual mode again.
  - (b) When an error is detected, the error detection signal (M2407+20n) of the applicable output module turns on, and the error code is stored in the minor/major error code storage register.

Table 9.3 Check Items List for Synchronous Encoder Axis

		Applicable sy enco		Normal condition	Abnormal condition
Check sequence	Check item	External synchronous encoder	Output module		
1	• Is the synchronous encoder connected	0		Connected	Not connected
I	to the Q172DEX ?				Cable break

## 9.2 Switching from the Virtual Mode to Real Mode

There are following methods for switching from the virtual mode to real mode.

- · Switching by user
- · Switching automatically by the operating system software

### 9.2.1 Switching by user

- (1) When the virtual mode to real mode switching is requested (M2043 ON → OFF), the item in Table 9.4 is checked. If normal, it switches to the real mode. (Confirm the check items in Table 9.4 for the switching from virtual mode to real mode, and execute with all normal state.)
- (2) The real mode/virtual mode switching error detection flag (M2045) turns on at the error detection, and the error code is stored in the real mode/virtual mode switching error information (SD504 to SD506). (Refer to APPENDIX 1.7)

Table 9.4 Check Items for VIRTUAL Mode to REAL Mode Switching

Check item	Normal condition	Abnormal condition	
• Is the virtual axis stopped? (M2001 to M2032 of	Virtual axis	Virtual axis	
virtual axis: OFF)	OFF	ON even if 1 axis	
Virtual axis and real mode axis stopped? (M2001 to			
M2032 : OFF)	OFF	ON even if 1 axis	
(Operating system software version "00G" or before	OFF		
in the Q17□DCPU(-S1))			

### 9.2.2 Switching by the operating system software

- (1) If the following items are detected in the virtual mode operation, the operating system software automatically switches back to the real mode.
  - The forced stop is input.
  - PLC ready flag (M2000) turns off.
  - When "Return to Real Mode" is set as an operation on servo error, the servo error detection signal (M2408+20n) turns on even if 1 axis.
- (2) The error code is stored in the real mode/virtual mode switching error information (SD504 to SD506) at the switching back from virtual mode to real mode. However, the real mode/virtual mode switching error detection flag (M2045) does not turn on.

## 9.2.3 Continuous operation on servo error in virtual mode


Set the processing on servo error in virtual mode on the mechanical system screen of MT Developer2.

(Default: "Return to real mode")

Refer to the help of MT Developer2 for the setting method.

· Mechanical system screen





· Operation on servo error setting screen



Operation conditions for continuous operation on servo error in virtual mode are shown below.

Operation mode	Details	Operation on servo error	Operation for other axes	Return condition to virtual mode
Return to real mode	Motion CPU switches to real mode.	Only axis on servo error is servo OFF,	Rapid stop	After error release in real mode
Continue virtual mode	Virtual mode continues.	and servo motor coasts.	Operation continues	After error release in virtual mode

#### **POINT**

When "Continue virtual mode" is selected, be sure to use a clutch in the mechanical system program.


In addition, the drive module connected to output axis on servo error is also continuing operation. Be sure to release a servo error after clutch OFF.

## 9.3 Precautions at Real Mode/Virtual Mode Switching

This section describes the precautions at real mode/virtual mode switching.

(1) The motion control step and the torque limit value change instruction/speed change instruction during mode switching processing execution impossible. The motion control step and the torque limit value change instruction/speed change instruction during the from real mode to virtual mode/from virtual mode to real mode switching processing (part of timing chart (Note-1)) cannot execute. The real mode/virtual mode switching request flag (M2043) and real mode/virtual mode switching status flag (M2044) should be used as an interlock.


#### [Timing Chart]



Motion SFC program for which executes the motion control step of real mode and virtual mode is shown below.

#### [Program Example]

(a) Motion control step in the virtual mode Example of Motion SFC program is shown below.



(Note): Example of the above Motion SFC program is started using the automatic start or sequence program.

Real mode example Real mode G10 PX000 turn on, real mode/virtual mode PX000\*!M2043\*!M2044\*!M2001 switching request and switching status turn off, and axis 1 start accept flag turn off. K10 ABS-1 1 axis linear control 20000pulse ( • Axis used..... Axis 1 1, Axis े End address...... 20000[pulse] Speed 2000pulse/s Positioning speed....... 2000[pulse/s] G20 Wait until PX000 and axis 1 start accept flag !PX000\*!M2001 turn off.

(b) Motion control step in the real mode Example of Motion SFC program is shown below.

(Note): Example of the above Motion SFC program is started using the automatic start or sequence program.

(2) M2043 processing during the TEST mode using MT Developer2 M2043 ON/OFF (Real mode/virtual mode switching request) is ignored during the test mode using MT Developer2.

Real mode/virtual mode switching can be executed using MT Developer2, during TEST mode operation using MT Developer2.

The real mode/virtual mode switching status flag (M2044) is turned off/on with the real mode/virtual mode.

# REMARK

The same check as the "M2043 (OFF  $\rightarrow$  ON/ON  $\rightarrow$  OFF)" is also executed at the real mode/virtual mode switching using MT Developer2. (Refer to Sections 9.1 and 9.2)

#### 9.4 Stop and Re-start

The basic method for stopping the system (output module) in the virtual mode operation is to stop the main shaft. If an auxiliary input axis is used, also stop the auxiliary input axis.

#### (1) Virtual axis stop

The stop operation or causes of virtual axis, the stop processing and re-start after stop are shown below. The following three methods for the virtual servo motor axis stop processing. This processing is also valid for interpolation axes during the interpolation operation.

- Deceleration stop ..... Deceleration stop based on the "stop deceleration time" of parameter block.
- Rapid stop ...... Deceleration stop based on the "rapid stop deceleration time" of parameter block.
- Immediate stop ...... Immediate stop without deceleration.

Because the synchronous encoder axis becomes the input immediate stop, operation should be executed after the synchronous encoder axis has been stopped from the external input, except for abnormal stops such as the forced stop or a servo error occurrence, etc.

(Example: M2000 is OFF, All axes servo OFF command, etc.)

(The servo error occurs by the immediate stop of output module connected to the synchronous encoder axis, and the synchronization discrepancy may occurs.)

When the synchronization discrepancy occurs by the stop cause, the synchronization discrepancy warning (M2046) turns on. In this case, re-align the axes in the real mode, turn M2046 off, then continue the virtual mode operation.

The stop operation/stop causes during operation and re-starting operation after stop are shown in the next page.

# 9.4.1 Stop operation/stop causes during operation and re-starting operation list

Table 9.5 Stop Operation/stop Causes during Operation and Re-starting Operation List

	Table ele elep (	1			1			1	
No.	Stop operation or stop causes during operation	Virtual servo motor axis	Synchronous encoder axis	All axes batch	Stop prod Virtual servo motor axis	Synchronous encoder axis	Return to Real mode by operating system software after all virtual axes stop completion	Synchronization discrepancy warning (M2046) set	
1	Stop command ON	(Applicable axis)	_	_	Deceleration stop	_	_	_	
2	Rapid stop command ON	(Applicable axis)	_	_	Rapid stop	_	_	_	
3	All-axes servo OFF command (M2042 OFF, Command using MT Developer2 in the TEST mode)	_	_	0	Deceleration stop	Immediate input stop (Note-1)	_	_	
4	PLC ready flag (M2000) OFF	_	_	0	Deceleration stop	Immediate input stop (Note-1)	0		
5	Motion CPU stop	_	_	0	Deceleration stop	Immediate input stop (Note-1)	0	_	
6	All-axes rapid stop from MT Developer2	_	_	0	Rapid stop	Immediate input stop (Note-1)	_		
7	Stop from MT Developer2 in the TEST mode	(All axes)	_	_	Deceleration stop	_	-	_	
8	Forced stop	_	_	0	Rapid stop	Immediate input stop (Note-1)	0	0	
9	Servo error at output module even if 1 axis	_	_	0	Rapid stop	Immediate input stop (Note-1)	0	0	
10	Motion CPU WDT error	_	_	0	Immediate stop	Immediate input stop	_		
11	Multiple CPU system reset	_	_	0	Immediate stop	Immediate input stop	_	_	
12	Multiple CPU system power OFF	_	_	0	Immediate stop	Immediate input stop	_	_	
13	Other errors during virtual axis operation	0	_	_	Deceleration stop	_	_	_	
14	Error detection at absolute synchronous encoder axis		0	_	_	Immediate input stop	_	_	

Error set	Output module operation	Operation continuation enabled ( ○ )/ disabled ( × )	Re-start operation after stop
_	Deceleration stop based on the smoothing time constant.	0	Continuous operation is possible by turning the stop command off (not necessary when on) and starting.
_	Deceleration stop based on the smoothing time constant.	0	Continuous operation is possible by turning the stop command off (not necessary when on) and starting.
_	Servo OFF state after deceleration stop based on the smoothing time constant.	0	Continuous operation is possible by turning the all clutch off → all axes servo on → clutch on.  (However, when the servo motor does not operate during the servo OFF. Also, the clutch OFF/ON is switched as required by the user side.)      For synchronous encoder axes, switch to the real mode, then back to the virtual mode to resume inputs. (Note-1)
Minor error (200) set (virtual axis)	Deceleration stop based on the smoothing time constant.	0	Operation is possible by executing the real mode to virtual mode switching request (M2043 ON), after turning the PLC ready flag (M2000) on.
Minor error (200) set (virtual axis)	Deceleration stop based on the smoothing time constant.	0	Operation is possible by executing the real mode to virtual mode switching request (M2043 ON), after starting the Motion CPU.
_	Deceleration stop based on the smoothing time constant.	0	Continuous operation is possible by starting after stop. For synchronous encoder axes, switch to the real mode, then back to the virtual mode to resume inputs. (Note-1)
	Deceleration stop based on the smoothing time constant.	0	Continuous operation is possible by starting after stop.
_	Servo OFF state after immediate stop.	×	Continuous operation is not possible due to a synchronization discrepancy between the virtual axis and output module, and stop. After release the forced stop, re-align the output module in the real mode, switch the synchronization discrepancy warning (M2046) OFF, then switch back to the virtual mode to resume operation.
Applicable output module (Servo error, Servo error code set)	Servo OFF state after immediate stop for error axis only. Operation is different according to the setting at error occurrence.	×	After executing a servo error reset in the real mode, re-align the axes, switch the synchronization discrepancy warning (M2046) OFF, then switch back to the virtual mode to resume operation.
SM512 (Motion CPU WDT error flag) ON	Servo OFF state after immediate stop.	×	Continuous operation is not possible due to a synchronization discrepancy between the virtual axis and output module, and stop. After resetting the Multiple CPU system, re-align the output module, then switch to the virtual mode to resume operation.
_	Servo OFF state after immediate stop.	×	Continuous operation is not possible due to a synchronization discrepancy between the virtual axis and output module, and stop. After resetting the Multiple CPU system, re-align the output module, then switch to the virtual mode to resume operation.
_	Servo OFF state after immediate stop.	×	Continuous operation is not possible due to a synchronization discrepancy between the virtual axis and output module, and stop.     After resetting the Multiple CPU system, re-align the output module, then switch to the virtual mode to resume operation.
Applicable error set	Deceleration stop based on the smoothing time constant.	0	Operation is possible by release the error cause.
Applicable error set	Deceleration stop based on the smoothing time constant.	×	Return to the real mode, re-align the axes, then switch to the virtual mode to resume operation.

(Note-1): It is input continuously for the version (Refer to Section 1.4) that supports "synchronous encoder current value monitor in real mode".

MEMO			
_			

## 10. AUXILIARY AND APPLIED FUNCTIONS


This section describes the auxiliary and applied functions for positioning control in the Multiple CPU system.

Items	Details	Applications
	Positioning control for preset axis is	It is used in the system for which
Mixed function of virtual	executed during synchronous	conveys while executing synchronous
mode/real mode	control/cam control in the	control.
	mechanical system program.	

#### 10.1 Mixed Function of Virtual Mode/Real Mode

When the output axis No. to execute positioning control directly is selected in the mixed function of virtual mode/real mode, a positioning control of axis which is not used in the mechanical system program can be executed simultaneously during the mechanical system program.


Example of program is shown below.




Set the axis to control as real mode axis on the mechanical system screen of MT Developer2.

Refer to the help of MT Developer2 for the setting method.

· Mechanical system screen



· Real mode axis setting screen



#### **POINT**

- (1) Execute "Mechanical System Program Conversion" after setting "Real mode axis setting" in the mechanical system program editor.
- (2) When a fixed parameter of each axis is changed, be sure to execute "Mechanical System Program Conversion".
- (3) Axis No. set in the "Real mode axis setting" cannot be set as virtual servo motor axis No. And, the output axis No. set in the mechanical system program cannot be also set as real mode axis No.
- (4) Operation cycle over may occur for default operation cycle depending on the number of axes for real mode axis. In this case, change an operation cycle to a large value in the system setting.

# (1) Usable instructions and controls

	Items	Usable/unusable	Remarks	
	Linear positioning control			
	Linear interpolation control			
	Circular interpolation control			
	Helical interpolation control			
	Fixed-pitch feed control			
	Speed control (I)		Positioning control with the	
Servo	Speed control (II)	O	torque limit value set in the	
instructions	Speed-position switching control		servo program (parameter	
	Position follow-up control		block)	
	Constant-speed control		,	
	Simultaneous start			
	Speed control with fixed position			
	stop			
	Home position return (ZERO)	○ Ver.!		
	High-speed oscillation (OSC)			
JOG operation	on		Control with JOG operation	
		0	data	
Speed-torque	e control <b>QDS</b> (		Control with speed-torque control data	
Manual nulse	e generator operation	○ Ver.!	Control data	
Current value change (D(P).CHGA Jn <sup>(Note)</sup> , CHGA)				
Speed change (D(P).CHGV, CHGV)				
Torque limit value change (D(P).CHGT, CHGT)		0		
Torque limit	Torque limit value individual change			
	2, CHGT2) ODS			
Target position	on change (CHGP)			

 $\bigcirc$  : Usable  $\times$  : Unusable

(Note): "n" shows the numerical value (axis No. 1 to 32) correspond to axis No.

Ver.!: Refer to Section 1.4 for the software version that supports this function.

## (2) Control methods

Items	Control method	Remarks
Servo program start	Use a Motion SFC program start or D(P).SVST instruction Set a real mode axis No. as axis No.	<ul> <li>When the real mode axis is set to the virtual servo program and it starts, "Servo program setting error" (error code: 906) occurs.</li> <li>When the real mode axis and virtual axis are set together to the interpolation axis if it starts, "Servo program setting error" (error code: 906) occurs.</li> </ul>
Stop	<ul> <li>Turn the stop command (M3200+20n) or rapid stop command (M3201+20n) ON in real mode.</li> <li>Turn the external signal (STOP) ON.</li> <li>Use the deceleration stop or all axes rapid stop (Test mode ON) from MT Developer2.</li> <li>Change speed to "0".</li> </ul>	Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)" for details.
JOG operation	Use the forward rotation JOG start command (M3202+20n) or reverse rotation JOG start command (M3203+20n).	Control with parameter JOG operation data.
Speed-torque control	<ul> <li>Set the parameter required at Motion SFC program to switch the mode.</li> <li>Set a real mode axis No. as axis No. for parameter setting.</li> </ul>	Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)" for details.
Current value change	Use D(P).CHGA Jn (Note), CHGA instruction.  Set a real mode axis No. as axis No.	<ul> <li>When the D(P).CHGA Cn (Note) instruction is executed, the instruction is ignored.</li> <li>When the CHGA-C instruction is executed to real mode axis, the instruction is ignored.</li> </ul>
Speed change	Use D(P).CHGV, CHGV instruction.     Set a real mode axis No. as axis No.	
Torque limit value	Use D(P).CHGT, CHGT instruction.	Torque limit value of real mode axis at switching
change  Torque limit value  individual change	<ul> <li>Set a real mode axis No. as axis No.</li> <li>Use D(P).CHGT2, CHGT2 instruction.</li> <li>Set a real mode axis No. as axis No.</li> </ul>	from real mode to virtual mode continues the state in real mode.
Target position change	Use CHGP instruction.     Set a real mode axis No. as axis No.	

(Note): "n" shows the numerical value (axis No. 1 to 32) correspond to axis No.  $\,$ 

#### (3) Error codes in real mode axis

Error codes at positioning control in the mixed function of virtual mode with real mode are shown below.

- (a) Minor error (1 to 999)
- (b) Major error (1000 to 1299)

Minor error (4000 to 9990)/major error (10000 to 12990) code of output module in virtual mode are not set in minor/major error code storage register (D6+20n/D7+20n).

# (4) Difference for operation between the output axis of mechanical system program and real mode axis

Operation details for "output axis of mechanical system program" and "real mode axis" on error are shown below.

Items	Operation for output axis of mechanical system program	Operation for real mode axis
Feed current value exceeds the stroke limit range at switching from real mode to virtual mode.	Minor error (error code: 5000) occurs.     Related system cannot be started.	Minor error (error code: 105) occurs at servo program start, and operation does not start.
Feed current value exceeds the stroke limit range during operation.	Minor error (error code: 6030) occurs.     Operation continues.	Minor error (error code: 207) occurs, and deceleration stop is executed.
Output speed exceeds the speed limit value.	<ul> <li>Minor error (error code: 6010) occurs.</li> <li>Speed cramp does not process by speed limit value.</li> </ul>	Servo program setting error or minor error occurs. Speed is controlled by speed limit value.
Stop signal (STOP) is ON.	<ul> <li>Major error (error code: 11020) occurs.</li> <li>Operation continues for axis without clutch.</li> <li>Operation is controlled based on the operation mode on error for axis with clutch.</li> </ul>	<ul> <li>Major error (error code: 1000) occurs by turning the stop signal (STOP) on at start, and operation does not start.</li> <li>Operation stops based on "deceleration processing at stop" of parameter block by turning the stop signal (STOP) on during operation.</li> </ul>
External upper LS signal (FLS) turns off during travel to forward direction (address increase direction).	<ul> <li>Major error (error code: 11030) occurs.</li> <li>Operation continues for axis without clutch.</li> <li>Operation is controlled based on the operation mode on error for axis with clutch.</li> </ul>	<ul> <li>Major error (error code: 1001) occurs by turning the external upper LS signal (FLS) off at start to forward direction, and operation does not start.</li> <li>Major error (error code: 1101) occurs by turning the external upper LS signal (FLS) off during start to forward direction, operation stops based on "deceleration processing at stop" of parameter block.</li> </ul>
External lower LS signal (RLS) turns off during travel to reverse direction (address decrease direction).	<ul> <li>Major error (error code: 11040) occurs.</li> <li>Operation continues for axis without clutch.</li> <li>Operation is controlled based on the operation mode on error for axis with clutch.</li> </ul>	<ul> <li>Major error (error code: 1002) occurs by turning the external lower LS signal (RLS) off at start to reverse direction, and operation does not start.</li> <li>Major error (error code: 1102) occurs by turning the external lower LS signal (RLS) off during start to reverse direction, operation stops based on "deceleration processing at stop" of parameter block.</li> </ul>
Change the torque limit value.	<ul> <li>Any time valid by setting the torque limit value setting device of output axis and changing preset value.</li> <li>Torque limit value individual change request instructions (D(P).CHGT2, CHGT2) are valid.</li> </ul>	Torque limit value change request instructions (D(P).CHGT, CHGT) and torque limit value individual change request instructions (D(P).CHGT2, CHGT2) are valid.

(5) Difference for operation between the real mode axis in virtual mode and real mode

When the servo OFF command (M3215+20n) turns on at using the mixed function of virtual mode with real mode in virtual mode, positioning control stops.

Items	Operation for real mode axis in virtual mode	Operation for axis in real mode
	Invalid during positioning control.	
Servo OFF command	Any time valid.	Invalid during positioning control.
(M3215+20n)	(Operating system software version	invalid during positioning control.
	"00G" or before in the Q17□DCPU(-S1))	

## (6) Cautions

- (a) For the operating system software version "00G or before" in the Q17□DCPU(-S1), axis operation, current value, speed and torque limit value cannot be changed for all axes during mode switching.
- (b) When the feed current value of real mode axis is outside the stroke limit range at virtual mode switching, an error will occur at start of real mode axis. Use the JOG operation to reverse within the stroke limit range.

#### **POINT**

For the operating system software version "00G or before" in the Q17 DCPU(-S1), switching from virtual mode to real mode cannot be executed during positioning control of real mode axis. Switch a mode after stop the real mode axis.

## 10.2 Speed-Torque Control QDS

Control mode can be switched for output axis of mechanical system and real mode axis during virtual mode.

#### (1) Speed-torque control in output axis of mechanical system

- (a) The speed-torque control can be executed for output axis of roller, ball screw and rotary table as output module. When the control mode switching is executed for output axis of cam, a minor error (error code: 6240) will occur, and the control mode is not switched. When switching the mode to speed control mode or torque control mode, the control mode switching is possible during motor stop. When the motor is operating at control mode switching request, a minor error (error code: 6200) will occur, and the control mode is not switched. The mode can be switched to continuous operation to torque control mode even when the motor is operating.
- (b) In the speed-torque control in output axis of mechanical system, the setting value of "Speed command device" is not referred, and the command speed to output axis is the value of command speed. Command speed acceleration time, command speed deceleration time and initial speed selection at control mode switching are also invalid. (For speed limit value, the value set in each output axis module is valid.)
- (c) Control the command torque by setting torque command value in the torque command device set in speed-torque control data same as real mode. Torque limit value change request (D(P).CHGT, CHGT) is invalid (no operation), and the torque limit value to servo amplifier can be changed within the range of torque limit value at speed-torque control by the value of torque limit value setting device. (If the value is outside the range, a minor error (error code: 6250) will occur.)
  Only when the torque limit value setting device of output module is not set, the torque limit value to servo amplifier can be changed within the range of torque limit value at speed-torque control by the torque limit value individual change request (D(P).CHGT2, CHGT2). If the value exceeds the torque limit value at speed-torque control is set in positive direction torque limit value or negative direction torque limit value, a minor error (error code: 6250) will occur, and the torque limit value is not changed.

#### (2) Cautions at control mode switching

(a) When using continuous operation to torque control mode, use servo amplifiers that support continuous operation to torque control. When using servo amplifiers that do not support continuous operation to torque control, a major error (error code: 11050) will occur at switching to continuous operation to torque control mode request, and the operation continues based on the parameter settings at major error occurrence, or the clutch is OFF. (b) When the mode is switched from virtual mode to real mode, return all output axes to position control mode. If output axis except position control mode exists when the mode is switched from virtual mode to real mode, an error at real mode/virtual mode switching (error code: 256) will occur, and the mode is not switched to real mode.

## (3) Stop causes during virtual mode

Operations of stop causes during "speed-torque control" in the output module during virtual mode are shown below.

Item	Operation during speed-torque control mode		
The stop command (M3200+20n) turned ON.			
The rapid stop command (M3201+20n) turned ON.	Command is ignored, and operation continues.		
The external stop input turned ON.	<ul> <li>A major error (error code: 10030) will occur, and related system cannot be started at virtual servo motor start</li> <li>A major error (error code: 11020) will occur, and operation continues for axis without clutch during command. Operation is controlled based on the operation mode on error for axis with clutch.</li> </ul>		
The all axes servo ON command (M2042) turned OFF.	During virtual mode, OFF of the all axes servo ON command is not accepted, and the command is ignored.  When the mode is returned to position control mode and switched to real mode, command status at the time is valid.		
Servo OFF command (M3215+20n) turned ON.	<ul> <li>During no-clutch/clutch ON/clutch status ON, a minor error (error code: 6000) will occur.</li> <li>When the control mode is speed control, torque control or continuous operation to torque control during clutch OFF, servo OFF is not executed. When the mode is switched to position control mode, command status at the time is valid.</li> </ul>		
The current value reached to software stroke limit.	A minor error (error code: 6030) will occur.		
The position of motor reached to hardware stroke limit	A major error (error code: 11030, 11040) will occur, and operation continues for axis without clutch. Operation is controlled based on the operation mode on error for axis with clutch.		
The PLC ready flag (M2000) turned OFF.	An error at real mode/virtual mode switching (error code: -4094(F002)) will occur, and the mode is returned to real mode.  After that, the control mode is switched to position control mode, and the operation immediately stops.		
The forced stop input to Motion CPU.	An error at real mode/virtual mode switching (error code: -4096(F000)) will occur, and the mode is returned to real mode.  The control mode switches to position control mode at servo OFF.		
The forced stop input to servo amplifier.	<ul> <li>During no-clutch/clutch ON/clutch status ON, a major error (error code: 11010) will occur, and operation continues for axis without clutch. Operation is controlled based on the operation mode on error for axis with clutch.</li> <li>When the control mode is speed control, torque control or continuous operation to torque control during clutch OFF, the mode is switched to position control mode at servo OFF.</li> </ul>		
The servo error occurred.	An error at real mode/virtual mode switching (error code: -4095(F001)) will occur, and the mode is returned to real mode.  The control mode switches to position control mode at servo OFF.		
The servo amplifier's power supply turned OFF.	<ul> <li>During no-clutch/clutch ON/clutch status ON, a major error (error code: 11010) will occur, and operation continues for axis without clutch. Operation is controlled based on the operation mode on error for axis with clutch.</li> <li>When the control mode is speed control, torque control, or continuous operation to torque control during clutch OFF, the mode switches to position control mode at the servo amplifier's power supply ON again.</li> </ul>		

## (4) Speed-torque control in the real mode axis

The speed-torque control can be executed in the real mode axis.

In this case, the control follows the control during real mode.

The real mode axis can be switched from virtual to real mode during speed-torque control.

Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22)

Programming Manual (REAL MODE)" for details of operation during real mode.

MEMO			
_			

# APP.

#### **APPENDICES**

## APPENDIX 1 Error Codes Stored Using the Motion CPU

The following errors are detected in the Motion CPU.

- · Servo program setting error
- · Positioning error
- · Control mode switching error
- Motion SFC error (Note-1)
- Motion SFC parameter error (Note-1)
- Multiple CPU related error (Note-2)

(Note-1): Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (Motion SFC)" for details.

(Note-2): Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)" for details.

#### (1) Servo program setting errors

These are positioning data errors set in the servo program, and it checks at the start of each servo program.

They are errors that occur when the positioning data is set indirectly.

The operations at the error occurrence are shown below.

- The servo program setting error flag (SM516) turns on.
- The erroneous servo program is stored in the error program No. storage register (SD516).
- The error code is stored in the error item information register (SD517).

#### (2) Positioning error

- (a) Positioning errors occurs at the positioning start or during positioning control. There are minor errors, major errors and servo errors.
  - Minor errors ....... These errors occur in the Motion SFC program or servo program, and the error codes (drive module : 1 to 999, output module : 4000 to 9990) are used.

    Check the error code, and remove the error cause by correcting the Motion SFC program or servo program.
  - 2) Major errors ...... These errors occur in the external input signals or control commands from the Motion SFC program, and the error codes (drive module : 1 to 1999, output module : 10000 to 11990) are used. Check the error code, and remove the error cause of
  - the external input signal state or Motion SFC program.

    3) Servo errors ...... These errors detected in the servo amplifier, and the error codes 2000 to 2999 are used.

Check the error code, and remove the error cause of the servo amplifier side. The error applicable range for each error class are shown below.

Error class Erroneous category		Error module		
Error class	Erroneous category	Drive module	Output module	
	Setting data	1 to 99	4000 to 4990	
Minor error	At start	100 to 199	5000 to 5990	
Willior error	During operation	200 to 299	6000 to 6990	
	At control change	300 to 399	_	
	At start	1000 to 1099	10000 to 10990	
Major error	During operation	1100 to 1199	11000 to 11990	
	System		15000 to 15990	
	Servo amplifier		2000 to 2799 (2100 to 2499 : warning)	
Servo error	Servo amplifier power supply module		2800 to 2999 (2900 or later : warning)	

(b) The error detection signal of the erroneous axis turns on at the error occurrence, and the error codes are stored in the minor error code, major error code or servo error code storage register.

	Device					Error	code st	orage re	gister				
Error class		Axis 1	Axis 2	Axis 3	Axis 4	Axis 5	Axis 6	Axis 7	Axis 8	Axis 9	Axis10	Axis11	Axis12
Virtual servo	Minor error code	D802	D812	D822	D832	D842	D852	D862	D872	D882	D892	D902	D912
motor	Major error code	D803	D813	D823	D833	D843	D853	D863	D873	D883	D893	D903	D913
Synchronous	Minor error code	D1122	D1132	D1142	D1152	D1162	D1172	D1182	D1192	D1202	D1212	D1222	D1232
encoder	Major error code	D1123	D1133	D1143	D1153	D1163	D1173	D1183	D1193	D1203	D1213	D1223	D1233
	Minor error code	D6	D26	D46	D66	D86	D106	D126	D146	D166	D186	D206	D226
Output module	Major error code	D7	D27	D47	D67	D87	D107	D127	D147	D167	D187	D207	D227
	Servo error code	D8	D28	D48	D68	D88	D108	D128	D148	D168	D188	D208	D228

	Device					Error	code sto	orage re	gister					
Error class		Axis13	Axis14	Axis15	Axis16	Axis17	Axis18	Axis19	Axis20	Axis21	Axis22	Axis23	Axis24	
Virtual servo	Minor error code	D922	D932	D942	D952	D962	D972	D982	D992	D1002	D1012	D1022	D1032	
motor	Major error code	D923	D933	D943	D953	D963	D973	D983	D993	D1003	D1013	D1023	D1033	
Synchronous	Minor error code													
encoder	Major error code													
	Minor error code	D246	D266	D286	D306	D326	D346	D366	D386	D406	D426	D446	D466	
Output module	Major error code	D247	D267	D287	D307	D327	D347	D367	D387	D407	D427	D447	D467	
	Servo error code	D248	D268	D288	D308	D328	D348	D368	D388	D408	D428	D448	D468	

	Device			Error	code st	orage reç	gister			Error detection	Error reset
Error class		Axis25	Axis26	Axis27	Axis28	Axis29	Axis30	Axis31	Axis32	signal	command
Virtual servo	Minor error code	D1042	D1052	D1062	D1072	D1082	D1092	D1102	D1112	144007.00	144007.00
motor	Major error code	<del>                                      </del>					M4007+20n	M4807+20n			
Synchronous	Minor error code						N4040 - 4	ME 440 : 4:-			
encoder	Major error code									M4640+4n	M5440+4n
	Minor error code	D486	D506	D526	D546	D566	D586	D606	D626	M0.407 : 00:-	M0007 - 00-
Output module	Major error code	D487	D507	D527	D547	D567	D587	D607	D627	M2407+20n	M3207+20n
	Servo error code	D488	D508	D528	D548	D568	D588	D608	D628	M2408+20n	M3208+20n

- (c) If another error occurs after an error code has been stored, the existing error code is overwritten, deleting it. However, the error history can be checked using MT Developer2.
- (d) Error detection signals and error codes are held until the error reset command (M3207+20n) or servo error reset command (M3208+20n) turns on.

#### **POINT**


- (1) Even if the servo error reset (M3208+20n) turns on at the servo error occurrence, the same error code might be stored again.
- (2) Reset the servo error after removing the error cause of the servo amplifier side at the servo error occurrence.

## (3) Error at the real mode/virtual mode switching

These errors are checked when the real mode/virtual mode switching request flag (M2043) turns off to on/on to off.

When the check shown in Section 9.1 and 9.2 is executed, and if error is detected, it is as follows.


- It remains the current mode without the real mode/virtual mode switching.
- The real mode/virtual mode switching error detection flag (M2045) turns on.
- The error codes are stored in the real mode/virtual mode switching error information (SD504 to SD506).



## APPENDIX 1.1 Expression method for word data axis No.

The axis No. may be expressed to correspond to each bit of word data for the positioning dedicated signal.

Example of the TEST mode request error information (SD510, SD511) is shown below.



## (1) Axis 8: Test mode request error

	Th	ne co	ntrol	ling s	signa	l "1"	is sto	ored	in S[	D510	"b7	(axis	8)".						
_	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0	D	ecimal	Hexadecimal
SD510	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	SD510	128	0080H
SD511	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	SD511	0	0000H
																	•		

## (2) Axis 12, 20: Test mode request error

	Th	ne co	ntrol	ling s	signa	l "1"	is sto	ored	in S[	D510	"b1′	l (ax	is 12	)" an	d SE	511	"b3 (ax	is 20)	)".
	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0		ecimal	Hexadecimal
SD510	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	SD510	2048	H0080
SD511	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	SD511	8	H8000

#### (3) Axis 4, 10: Test mode request error

	The controlling signal "1" is stored in SD510 "b3 (axis 4)" and SD511 "b9 (axis 10)".																		
	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0		ecimal	Hexadecimal
SD510	0	0	0	0	0	0	1	0	0	0	0	0	1	0	0	0	SD510	520	0208H
SD511	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	SD511	0	0000H


#### APPENDIX 1.2 Related systems and error processing

There are following 2 types for the related systems of virtual mode.

- System consisting of a drive module and output module.
- Multiple systems used the same drive module.

The following processing occurs, when the error is detected at an output module.

- If an error is detected at least one output module, a drive module cannot start and that system cannot be operate.
  - The auxiliary input axis operation for the erroneous output module also cannot operate.
- Other systems which use the drive module which could not start by the output module error also cannot operate.



# APPENDIX 1.3 Servo program setting errors (Stored in SD517)

The error codes, error contents and corrective actions for servo program setting errors are shown in Table 1.1.

In the error codes marked with "Note" indicates the axis No. (1 to 32).

Table 1.1 Servo program setting error list

	I					
Error code stored in SD517	Error name	Error contents	Error processing	Corrective action		
1	Parameter block No. setting error	The parameter block No. is outside the range of 1 to 64.	Execute the servo program with the default value "1" of parameter block.	Set the parameter block No. within the range of 1 to 64.		
n03 <sup>(Note)</sup>	Address (travel value) setting error (Except the speed control and speed/position control.) (Setting error for linear axis at the helical-interpolation.)	(1) The address is outside the setting range at the positioning start for absolute data method.  Unit Address setting range degree 0 to × 10 <sup>-5</sup> (degree)  (2) The travel value is set to -2147483648 (H80000000) at the positioning start for incremental data method.	<ol> <li>(1) Positioning control does not start. (All interpolation control at the interpolation control.)</li> <li>(2) If the error is detected during the speedswitching control or constant-speed control, a deceleration stop is made.</li> <li>(3) If an error occurs in one servo program, all servo programs do not execute during the simultaneous start.</li> </ol>	<ul> <li>(1) If the control unit is [degree], set the address within the range of 0 to 35999999.</li> <li>(2) Set the travel value within the range of "0 to ± (2<sup>31</sup>-1)".</li> </ul>		
4	Command speed error	(1) The command speed is outside the range of 1 to the speed limit value.  (2) The command speed is outside the setting range.  Unit Speed setting range  1 to ×10-2 600000000 [mm/min] inch 1 to ×10-3 600000000 [inch/min]  4 to 10-3 600000000 [inch/min] 6000000000 [inch/min] 7 to 2147483647 [visit of commander in the setting range in the settin	(1) Positioning control does not start if the command speed is "0" or less.      (2) If the command speed exceeds the speed limit value, control with the speed limit value.	Set the command speed within the range of 1 to the speed limit value.		
5	Dwell time setting error	The dwell time is outside the range of 0 to 5000.	Control with the default value "0".	Set the dwell time within the range of 0 to 5000.		
6	M-code setting error	The M-code is outside the range of 0 to 32767.		Set the M-code within the range of 0 to 32767.		
7	Torque limit value setting error	The torque limit value is outside the range of 1 to 1000.	Control with the torque limit value of the specified parameter block.			

(Note-1): When the "speed control  $10 \times$  multiplier setting for degree axis" is set to "valid", the setting range is 0.01 to 21474836.47 [degree/min].

Table 1.1 Servo program setting error list (Continued)

Error code	Table	r. i Servo program settir		T
stored in SD517	Error name	Error contents	Error processing	Corrective action
n08 <sup>(Note)</sup>	Auxiliary point setting error (At the auxiliary point-specified circular interpolation.) (At the auxiliary point-specified	(1) The auxiliary point address is outside the setting range at the positioning start for absolute data method.  Unit Address setting range degree 0 to × 10-5 35999999 [degree]	Positioning control does not start.	(1) If the control unit is [degree], set the auxiliary point address within the range of 0 to 35999999.
	helical interpolation.)	(2) The auxiliary point address is set to -2147483648 (H80000000) at the positioning start for incremental data method.		(2) Set the auxiliary point address within the range of 0 to ± (2 <sup>31</sup> -1).
n09 <sup>(Note)</sup>	Radius setting error (At the radius- specified circular interpolation.) (At the radius- specified helical interpolation.)	(1) The radius is outside the setting range at the positioning control for absolute data method.  Unit Address setting range  0 to ×10 <sup>-5</sup> degree 35999999 [degree]		(1) If the control unit is [degree], set the radius within the range of 0 to 35999999.
		(2) The radius is set to "0" or negative setting at the positioning start for incremental data method.		(2) Set the radius within the range of 1 to (2 <sup>31</sup> -1).
n10 <sup>(Note)</sup>	Central point setting error (At the central point-specified circular interpolation.) (At the central point-specified helical interpolation.)	(1) The central point address is outside the setting range at the positioning start for absolute data method.  Unit Address setting range 0 to × 10 <sup>-5</sup> degree 35999999 [degree]		(1) If the control unit is [degree], set the central point address within the range of 0 to 35999999.
		(2) The central point is set to -2147483648 (H80000000) at the positioning start for incremental data method.		(2) Set the central point address within the range of 0 to ± (2 <sup>31</sup> -1).
11	Interpolation control unit setting error	The interpolation control unit is set outside the range of 0 to 3.	Control with the default value "3".	Set the interpolation control unit within the range of 0 to 3.
12	Speed limit value setting error	The speed limit value is set outside the setting range.	Control with the default value 200000[pulse/s].	Set the speed limit value within the setting range. [For pulse] 1 to 2147483647[pulse/s]
13	Acceleration time setting error FIN acceleration/ deceleration setting error Fixed position stop acceleration/ deceleration time setting error	The acceleration time is set to "0".  The FIN acceleration/deceleration time is set except 1 to 5000.  The fixed position stop acceleration/deceleration time is set to "0".	Control with the default value "1000".	Set the acceleration time within the range of 1 to 65535. The FIN acceleration/ deceleration time within the range of 1 to 5000.  Set the fixed position stop acceleration/deceleration time within the range of 1 to 65535.
14	Deceleration time setting error	The deceleration time is set to "0".		Set the deceleration time within the range of 1 to 65535.

Table 1.1 Servo program setting error list (Continued)

	I	1.1 Servo program settii	.9	· /
Error code stored in SD517	Error name	Error contents	Error processing	Corrective action
15	Rapid stop deceleration time setting error	The rapid stop deceleration time is set to "0".	Control with the default value "1000".	Set the rapid stop deceleration time within the range of 1 to 65535.
16	Torque limit value setting error	The torque limit value is outside the range of 1 to 1000.	Control with the default value "300[%]".	Set the torque limit value within the range of 1 to 1000.
17	Allowable error range for circular interpolation setting error	The allowable error range for circular interpolation is outside the setting range.   Unit Address setting range		Set the allowable error range for circular interpolation within the setting range.
18	Repeat count error	The repeat count is outside the range of 1 to 32767.	Control the repeat count with "1".	Set the repeat count within the range of 1 to 32767.
19	START instruction setting error	<ul> <li>(1) The servo program specified with the START instruction does not exist.</li> <li>(2) There is a START instruction in the specified servo program.</li> <li>(3) The starting axis of the specified servo program overlap.</li> <li>(4) The real mode program and virtual mode program are mixed.</li> <li>(5) The real axis program and command generation axis program are mixed.</li> </ul>	Positioning control does not start.	<ol> <li>(1) Create the servo program specified with the START instruction.</li> <li>(2) Delete the servo program specified with the START instruction.</li> <li>(3) Do not overlap the starting axis.</li> <li>(4) Do not allow mixture of the real mode program and virtual mode program.</li> <li>(5) Do not allow mixture of the real axis program and command generation axis program.</li> </ol>
20	Point setting error	Point is not specified in the instruction at the constant-speed control.		Set a point between CPSTART and CPEND.
21	Reference axis speed setting error	The axis except interpolation axis is set as the reference axis at the linear interpolation of the reference axis speed-specified method.		Set one of the interpolation axes as the reference axis.
22	S-curve ratio setting error	S-curve ratio is set outside the range of 0 to 100[%] at the S-curve acceleration/deceleration.	Control the S-curve ratio with 0[%] (Trapezoidal acceleration/deceleration).	Set the S-curve ratio within the range of 0 to 100[%].
23	VSTART setting error	Not even one speed-switching point has been set between a VSTART and VEND instruction, or between FOR and NEXT instruction.	Positioning control does not start.	Set the speed switching point between the VSTART and VEND instructions or the FOR and NEXT instructions.
24	Cancel function start program No. error	The start program No. for the cancel function is set outside the range 0 to 4095.		Start after set the start program No. within the range of 0 to 4095.

Table 1.1 Servo program setting error list (Continued)

Error code stored in SD517	Error name	Error contents	Error processing	Corrective action
25	High-Speed oscillation command amplitude error	Operation cannot be started because the amplitude specified with the high-speed oscillation function is outside the range 1 to 2147483647.	Positioning control does not start.	Start after set the command amplitude within the range of 1 to 214783647.
26	High-Speed oscillation command starting angle error	Operation cannot be started because the starting angle specified with the high-speed oscillation function is outside the range of 0 to 3599 (×0.1[degree]).		Start after set the starting angle within the range of 0 to 3599 (× 0.1 [degree]).
27	High-Speed oscillation command frequency error	Operation cannot be started because the frequency specified with the high-speed oscillation function is outside the range of 1 to 5000[CPM].		Start after set the frequency within the range of 1 to 5000[CPM].
28	Number of helical interpolation pitches error	The specified number of pitches of helical interpolation is outside the range of 0 to 999.		Set the specified number of pitches within the range of 0 to 999.
41		Any unauthorized devices are set in the home position return data for indirect setting.	Positioning control does not start.	Review the devices of home position return data for indirect setting.
45	Advanced S-curve acceleration/ deceleration setting	The acceleration section 1 ratio is outside the range of 0.0 to 100.0[%].	Control with acceleration section 1 ratio = 0.0	Set the each ratio within the range of 0.0 to 100.0[%].
46	error	The acceleration section 2 ratio is outside the range of 0.0 to 100.0[%].	acceleration section 2 ratio = 0.0 deceleration section 1 ratio =	
47		The deceleration section 1 ratio is outside the range of 0.0 to 100.0[%].	0.0 deceleration section 2 ratio = 0.0	
48		The deceleration section 2 ratio is outside the range of 0.0 to 100.0[%].		
49		(Acceleration section 1 + Acceleration section 2) > 100.0[%]		
50		(Deceleration section 1 + Deceleration section 2) > 100.0[%]		
51	Rapid stop deceleration time setting error	The rapid stop deceleration time is bigger than the setting value of deceleration time.	Control the rapid stop deceleration time with the setting value of deceleration time.	Set the rapid stop deceleration time within the range of 1 to deceleration time setting value.
900	START instruction setting error	The servo program specified with the servo program start does not exist.	Positioning control does not start.	Set the correct servo program No.
901	START instruction setting error	The axis No. set in the servo program start is different from the axis No. set in the servo program.		Set the correct axis No.
902	Servo program instruction code error	The instruction code cannot be decoded. (A non-existent instruction code has been specified.)		Set the correct instruction code

Table 1.1 Servo program setting error list (Continued)

Error code stored in SD517	Error name	Error contents	Error processing	Corrective action
903	Start error	A virtual mode program was started in the real mode.	Positioning control does not start.	Check the program mode allocation.
	Start error	(1) Operation disable instructions (VPF, VPR, VPSTART, PVF, PVR, ZERO, VVF, VVR, OSC) was started in virtual mode.		Correct the servo program.
		(2) Operation disable instructions (ZERO, OSC, CHGA-C) was started in real mode axis.		
905		(3) Operation disable instructions (VPF, VPR, VPSTART, VSTART, ZERO, VVF, VVR, OSC) was started in command		
		generation axis.  (4) Operation disable instructions (CHGA-C, CHGA-E) from the D(P).SVST instruction of Motion dedicated instruction was started.		Use the D(P).CHGA instruction of Motion dedicated instruction.
	Axis No. setting error	(1) Unused axis of the system setting is set in the servo program start.  (2) It was started by setting the		Set the axis No. set in the system setting or mechanical system program.
906		real mode axis in the virtual servo program.  (3) It was started in the condition that the real mode axis had been mixed with virtual axis in the interpolation axis.  (4) It was started by setting the virtual axis in the real mode		
907	Start error	program in virtual mode.  It was started during processing for switching from real mode to virtual mode.		Use M2043 (real mode/virtual mode switching request), M2044 (real mode/virtual
908	Start error	It was stated during processing for switching from virtual mode to real mode.		mode switching status) as interlocks for start.

# APPENDIX 1.4 Drive module errors

Table 1.2 Drive module error (100 to 1199) list

		C	ontro	ol ma	ode (	of vii					Tro modulo error (100 to	,	
Error class	Error code	Positioning	feed	Speed	switching			ial pulse generator	Synchronous encoder		Error cause	Error processing	Corrective action
	100	0	0	0	0	0	0	0		0	The PLC ready flag (M2000) or PCPU READY complete flag (SM500) is OFF.		<ul> <li>Set the Motion CPU to RUN.</li> <li>Turn the PLC ready flag (M2000) on.</li> </ul>
	101	0	0	0	0	0	0	0		0	The start accept flag (M2001 to M2032) for applicable axis is ON.		Take an interlock in the program not to start the starting axis. (Use the start accept flag OFF of the applicable axis as the starting condition).
	103	0	0	0	0	0	0	0		0	• The stop command (M4800+20n) for applicable axis is ON.		Turn the stop command (M4800+20n) off and start.
	104	0	0	0	0	0	0	0		0	• The rapid stop command (M4801 +20n) for applicable axis is ON.		Turn the rapid stop command (M4801+20n) off and start.
	105 (Note)	0			0	0				0	The feed current value is outside the range of stroke limit at the start.		<ul> <li>Set within the stroke limit range by the JOG operation.</li> <li>Set within the stroke limit range by the home position return or current value change.</li> </ul>
Minor error	106 (Note)	0	0		0	0				0	<ul> <li>Positioning is outside the range of stroke limit.</li> <li>When absolute position system is enabled for stepping driver, and software stroke limit is valid with control units as degree, the following instructions were started.</li> <li>(1) Absolute system instructions in constant-speed control</li> <li>(2) Position follow-up control</li> <li>(3) Absolute system instructions in speed-switching control</li> </ul>	Positioning control does not start.	<ul> <li>Perform the positioning within the range of stroke limit.</li> <li>When absolute position system is enabled for stepping driver, if software stroke limit is valid and control units are degree, do not use the following instructions.</li> <li>(1) Absolute system instructions in constant-speed control</li> <li>(2) Position follow-up control</li> <li>(3) Absolute system instructions in speed-switching control</li> </ul>
	107 (Note)	0				0					The address that does not generate an arc is set at auxiliary point-specified circular interpolation or auxiliary point-specified helical interpolation.  (Relationship between the start point, auxiliary point and end point.)  The auxiliary point-specified circular interpolation or auxiliary point-specified helical interpolation was started in the control unit degree axis which is "stroke limit invalid".  The auxiliary point-specified circular interpolation or auxiliary point-specified helical interpolation was started in the axis which is "stroke limit invalid".		Correct the addresses of the servo program.      Make the stroke limit valid for the control unit degree axis starts the auxiliary point-specified circular interpolation or auxiliary point-specified helical interpolation.      Make the stroke limit valid for the axis starts the auxiliary point-specified circular interpolation or auxiliary point-specified helical interpolation.

(Note): This error code is stored at all relevant interpolation axis storage areas at the interpolation operation.

Table 1.2 Drive module error (100 to 1199) list (Continued)

		C	ntro			of vir					oddie enoi (100 to 1199)	(	1
Error class	Error code	Positioning	feed	Speed	switching			ial pulse generator	Synchronous encoder	Position follow-up	Error cause	Error processing	Corrective action
	108 (Note)	0				0					The address that does not generate an arc is set at R(radius) specified circular interpolation or R(radius) specified helical interpolation.  (Relationship between the start point, radius and end point.)  The radius-specified circular interpolation or radius-specified helical interpolation was started in the control unit degree axis which is "stroke limit invalid".  The radius-specified circular interpolation or radius-specified helical interpolation was started in the radius-specified helical interpolation was started in the axis which is "stroke limit invalid".		Correct the addresses of the servo program.      Make the stroke limit valid for the control unit degree axis starts the radius-specified circular interpolation or radius-specified helical interpolation.      Make the stroke limit valid for the axis starts the radius-specified circular interpolation or radius-specified circular interpolation or radius-specified helical interpolation.
Minor error	109 (Note)	0				0					The address that does not generate an arc is set at central point-specified circular interpolation or central point-specified helical interpolation.  (Relationship between the start point, central point-specified circular interpolation or central point-specified circular interpolation or central point-specified helical interpolation was started in the control unit degree axis which is "stroke limit invalid".  The central point-specified circular interpolation or central point-specified helical interpolation was started in the axis which is "stroke	Positioning control does not start.	Correct the addresses of the servo program.      Make the stroke limit valid for the control unit degree axis starts the central point-specified circular interpolation or central point-specified helical interpolation.      Make the stroke limit valid for the axis starts the central point-specified circular interpolation or central point-specified circular interpolation or central point-specified helical
	110 (Note)	0				0					limit invalid".  The difference between the end point address and ideal end point is outside the allowable error range for circular interpolation.		interpolation.  Correct the addresses of the servo program.
	116						0				<ul> <li>The setting JOG speed is "0".</li> <li>The setting JOG speed exceeded the JOG speed limit value.</li> <li>The setting JOG speed limit value exceeded the setting range.</li> </ul>	Control with the JOG speed limit value. Control with the maximum setting range of each control unit.	<ul> <li>Set the correct speed (within the setting range).</li> <li>Set the correct JOG speed limit value (within the setting range).</li> </ul>

(Note): This error code is stored at all relevant interpolation axis storage areas at the interpolation operation.

Table 1.2 Drive module error (100 to 1199) list (Continued)

	1	_	1								odule error (100 to 1199)	1100 (00110	i
Error class	Error code	Positioning	feed	Speed Speed	switching	Constant-speed	fual	lal pulse generator	Synchronous encoder		Error cause	Error processing	Corrective action
	117						0				Both of forward and reverse rotation were set at the simultaneous start for the JOG operation.	Only the applicable axis set to the forward direction starts.	Set a correct data.
	119				0						<ul> <li>In the real mode or at the real mode axis, the instruction to specify the end point address by absolute data method in speed switching control was executed for the axis with unit [pulse/mm/inch] where the stroke limit is disabled.</li> </ul>		When specifying the end point address by absolute data method in speed switching control, make the stroke limit valid.
	136			0							<ul> <li>An unusable instruction (VVF/VVR) was started in an axis that does not support VVF/VVR instruction.</li> </ul>		Cannot start VVF/VVR     instruction in an axis that does     not support VVF/VVR     instruction.
	140	0									<ul> <li>The travel value of the reference axis is set at "0" in the linear interpolation for reference axis specification.</li> </ul>	Positioning control does not start.	Do not set axis of travel value "0" as the reference axis.
	141									0	<ul> <li>The position command device of position follow-up control is set the odd number.</li> </ul>	not start.	<ul> <li>Set the even number for the position command device of position follow-up control.</li> </ul>
Minor error	151	0	0	0	0	0	0	0		0	<ul> <li>Not allowed axis started in the virtual mode. (It cannot be started with error at real mode/virtual mode switching.)</li> </ul>		<ul> <li>Start in the virtual mode again after correct the error cause in the real mode.</li> </ul>
	152	0	0	0	0	0	0	0		0	<ul> <li>It started at the virtual mode and during deceleration by all axes servo OFF (M2042 OFF).</li> </ul>		
	153	0	0	0	0	0	0	0		0	<ul> <li>It started at the virtual mode and during deceleration by occurrence of the output module servo error.</li> </ul>		
	200	0	0	0	0	0	0	0		0	<ul> <li>The PLC ready flag (M2000) turned off during the control by the servo program.</li> </ul>	Deceleration stop	<ul> <li>Turn the PLC ready flag (M2000) on after all axes have stopped.</li> </ul>
	204	0	0	0	0	0	0	0		0	<ul> <li>The PLC ready flag (M2000) turned off to on again during deceleration by turning off the PLC ready flag (M2000).</li> </ul>	No operation	<ul> <li>Turn the PLC ready flag (M2000) off to on after all axes have stopped.</li> <li>(Turn the PLC ready flag (M2000) off to on during deceleration is "no operation".)</li> </ul>
	207	0			0	0	0			0	The feed current value exceeded the stroke limit range during positioning control. Only the axis exceed the stroke limit range is stored at the circular/helical interpolation.  All interpolation axes are stored in the linear interpolation.	Deceleration stop	Correct the stroke limit range or travel value setting so that positioning control is within the range of the stroke limit.

Table 1.2 Drive module error (100 to 1199) list (Continued)

		Cc	ontro					/o a>		oddie enoi (100 to 1199)	(	<u>-</u>
Error class	Error	Positioning	Fixed-pitch feed	switching		DOC	Manual pulse generator	Synchronous encoder	Position follow-up	Error cause	Error processing	Corrective action
	208	0		0	0		0			<ul> <li>The feed current value of another axis exceeded the stroke limit value during the circular/helical interpolation control or simultaneous manual pulse generator operation.</li> <li>(For detection of other axis errors).</li> </ul>	Deceleration	Correct the stroke limit range or travel value setting so that positioning control is within the range of the stroke limit.
	211				0					During positioning control, an overrun occurred because the deceleration distance for the output speed is not attained at the point where the final positioning address was detected.	stop	Set the speed setting so that overrun does not occur.     Set the travel value so that overrun does not occur.
	214						0			The manual pulse generator was enabled during the start of the applicable axis, the manual pulse generator operation was executed.	Manual pulse generator input is ignored until the axis stops.	Execute the manual pulse generator operation after the applicable axis stopped.
	215			0						<ul> <li>The speed switching point address exceed the end point address.</li> <li>The positioning address in the reverse direction was set during the speed switching control.</li> </ul>	Rapid stop	<ul> <li>Set the speed-switching point between the previous speed switching point address and the end point address.</li> </ul>
Minor										The same servo program was executed again.		Correct the Motion SFC program.
error	220								0	When the control unit is "degree" during the position follow-up control, the command address exceeded the range of 0 to 35999999.  The command address for the position follow-up control exceeded	Deceleration stop	When the control unit is "degree", set the command address within the range of 0 to 359999999. Set the address within the stroke limit range.
	225				0					the stroke limit range.  The speed at the pass point exceeded the speed limit value during constant-speed control.  The speed at the pass point is 0 or less.	the speed limit value. Control with the speed of last pass	Set the speed command value within the range of 1 to speed limit value.
	230				0					When the skip is executed in the constant-speed control, the next interpolation instruction is an absolute circular interpolation or absolute helical interpolation.  After the skip is executed in the constant-speed control, an absolute circular interpolation or absolute helical interpolation is executed while passing through only the positioning point for incremental method.	point  Immediate stop  Deceleration stop	If absolute circular interpolation or absolute helical interpolation is designated at a point after the skip designation point, set an absolute linear interpolation in the interval.

Table 1.2 Drive module error (100 to 1199) list (Continued)

		Co	ontro			of vir					oddie enor (100 to 1199)		, 
Error class	Error code	Positioning	feed		switching		9Of	Manual pulse generator	Synchronous encoder	Position follow-up	Error cause	Error processing	Corrective action
	260	0	0			0					• The target position change request (CHGP) specifying the address where the target position is outside the range of 0 to 35999999 is executed to the axis whose unit is [degree].		When executing the target position change request specifying the address to the axis whose unit is [degree], set the target position within the range of 0 to 35999999.
	261	0	0			0					• At the target position change request (CHGP), since the travel to the target position after the change was shorter than the deceleration distance, an overrun occurred.		<ul> <li>Set the speed so that an overrun will not occur.</li> <li>Set the target position so that an overrun will not occur.</li> </ul>
	262	0	0			0					At the target position change request (CHGP), the target position after the change exceeds the range of the stroke limit.		<ul> <li>Set the stroke limit range or the target position after the change so that the positioning control is performed within the stroke limit range.</li> </ul>
Minor error	263	0	0			0					The target position change request (CHGP) is executed to the program where the following acceleration/deceleration system is set.  The set of the program where the following acceleration/deceleration system is set.  The set of the program where the program where the following acceleration system is set.  Advanced S-curve acceleration/deceleration/deceleration	Deceleration stop	Do not execute the target position change to the program where the FIN acceleration/deceleration or the advanced S-curve acceleration/deceleration is set.     Set the acceleration/deceleration system of the parameter block or the servo program to the trapezoid/S-curve acceleration/deceleration.
	264	0									<ul> <li>In reference axis-specified linear interpolation or the long axis- specified linear interpolation, the travel of the reference axis or the long axis after the target position change request (CHGP) is 0.</li> </ul>		Set a target position so that the travel of the reference axis or the long axis after the target position change is not 0.
	300	0	0	0	0	0	0	0		0	<ul> <li>The current value was changed during positioning control of the applicable axis.</li> <li>The current value was changed for the axis that had not been started.</li> <li>The current value was changed for the servo OFF axis.</li> </ul>	Current value is not changed.	Use the following devices as interlocks not to change the current value for the applicable axis.  The start accept flag (M2001 to M2032) OFF for applicable axis.  The servo READY signal (M2415+20n) ON.
	305	0	0	0	0	0	0			0	<ul> <li>The speed after speed change is set outside the range of 0 to speed limit value.</li> <li>The absolute value of speed after speed change is set outside the</li> </ul>	Control with the speed limit value.	<ul> <li>Set the speed after speed change within the range of 0 to speed limit value.</li> <li>Set the absolute value of speed after speed change within the</li> </ul>
											range of 0 to speed limit value.		range of 0 to speed limit value.

Table 1.2 Drive module error (100 to 1199) list (Continued)

		Co	ontro	ol mo	ode (	of vi	rtual	ser	o ax	(is			
Error class	Error code	Positioning	Fixed-pitch feed	Speed	Speed switching	Constant-speed	106	Manual pulse generator	Synchronous encoder	Position follow-up	Error cause	Error processing	Corrective action
	310	0	0	0	0	0	0			0	Change speed to negative speed in the invalid axis of stroke limit.	Speed is not changed.	Do not change speed to negative speed in the invalid axis of stroke limit.
Minor error	330			0	0		0	0			The target position change request (CHGP) was executed for the axis which was executing a servo instruction which was not compatible with target position change.	Target position is not changed.	Change the target position for the axes operated by the following servo instructions.     (1) Linear interpolation control     (2) Fixed-pitch feed operation     (3) Constant-speed control
											Q172DEX or encoder hardware error.      Disconnected encoder cable	Immediate input stop	Check (replace) the Q172DEX or encoder.     Check the encoder cable
Major	1151								0		<ul> <li>A synchronous encoder set in the system setting differs from a synchronous encoder actually connected.</li> </ul>	Input from synchronous encoder does not accept.	Set a synchronous encoder actually connected in the system setting.
error											No battery or disconnected battery at Q172DEX.	Immediate input stop	<ul> <li>Replace the battery and turn ON the Multiple CPU system power supply a few minutes later.</li> </ul>
	1152 1153								0		<ul> <li>Low voltage at Q172DEX.</li> <li>No battery or disconnected battery at Q172DEX.</li> </ul>	Operation is continued.	Replace the battery.      Replace the battery or check (replace) the Q172DEX.

#### APPENDIX 1.5 Servo errors

## (1) Servo errors (2000 to 2999)

These errors are detected by the servo amplifier, and the error codes are [2000] to [2999].

The servo error detection signal (M2408+20n) turns on at the servo error occurrence. Eliminate the error cause, reset the servo amplifier error by turning on the servo error reset command (M3208+20n) and perform re-start. (The servo error detection signal does not turn on because the codes [2100] to [2599] are for warnings.)

(Note-1): As for the regenerative alarm (error code [2030]) or overload 1 or 2 (error codes [2050], [2051]), the state at the operation is held also for after the protection circuit operation in the servo amplifier. The memory contents are cleared with the external power supply off, but are not cleared by the reset signal.

(Note-2): If resetting by turning off the external power supply is repeated at the occurrence of error code [2030], [2050] or [2051], it may cause devices to be destroyed by overheating. Re-start operation after eliminating the cause of the error certainly.

The hexadecimal display of servo amplifier display servo error code (#8008+20n) is the same as the LED of servo amplifier.  $\sqrt{er.}$ 

# **⚠** CAUTION

• If a controller, servo amplifier self-diagnosis error occurs, check the points stated in this manual and clear the error.

> List of servo errors are shown in next page or later. Refer to the "Servo amplifier Instruction Manual" for details.

Servo amplifier type	Instruction manual name
MR-J5-□B	ND IT II I M I IT II I I I I I I I I I I I
MR-J5W-□B	MR-J5 User's Manual (Troubleshooting) (SH-030312ENG)
MR-J4-□B	SSCNETII/H Interface AC Servo MR-J4B_(-RJ) Servo amplifier Instruction Manual (SH-030106)
MR-J4W-□B	SSCNETII/H Interface Multi-axis AC Servo MR-J4W2B/MR-J4W3B/MR-J4W2-0303B6 Servo amplifier Instruction Manual (SH-030105)
MR-J3-□B	SSCNETⅢ interface MR-J3-□B Servo amplifier Instruction Manual (SH-030051)
MR-J3W-□B	SSCNETⅢ interface 2-axis AC Servo Amplifier MR-J3W-0303BN6/MR-J3W-□B Servo amplifier Instruction Manual (SH-030073)
MR-J3-□B-RJ004	SSCNETⅢ Compatible Linear Servo MR-J3-□B-RJ004U□ Instruction Manual (SH-030054)
MR-J3-□B-RJ006	SSCNETⅢ Compatible Fully Closed Loop Control MR-J3-□B-RJ006 Servo amplifier Instruction Manual (SH-030056)
MR-J3-□B-RJ080	SSCNETⅢ Interface Direct Drive Servo MR-J3-□B-RJ080W Instruction Manual (SH-030079)
MR-J3-□B Safety	SSCNETⅢ interface Drive Safety integrated MR-J3-□B Safety Servo amplifier Instruction Manual (SH-030084)
MR-JE-□B	MELSERVO-JE Servo amplifier Instruction Manual (Trouble Shooting) (SH-030166ENG)
MR-JE-□BF	SSCNETII/H interface AC Servo With functional safety MR-JEBF Servo amplifier Instruction Manual (SH-030258ENG)

Ver.!: Refer to Section 1.3 for the software version that supports this function.

## (a) MR-J5(W)-□B

The servo errors below are all displayed with the same error codes (2000 or 2100).

Check servo amplifier display servo error code (#8008+20n) for the details of servo errors read by the servo amplifier.

Table 1.3 Servo error (2000 and 2100) list (MR-J5(W)-□B)

Error code	Servo amplifier LED display	Name	Details name	Remarks
	010.1	Lindonvoltago	Voltage drop in the control circuit power	
	010.2	Undervoltage	Voltage drop in the main circuit power	
	011.1	Cuitab acting arrar	Rotary switch setting error	
	011.2	Switch setting error	Disabled axis setting error	
	012.1		RAM error 1	
	012.2		RAM error 2	
	012.4		RAM error 4	
	012.5	Memory error 1 (RAM)	RAM error 5	
	012.6	iviemory error i (RAW)	RAM error 6	
	012.7		RAM error 7	
	012.8		RAM error 8	
	012.9		RAM error 9	
	013.1		CPU error 1	
	013.2	0.001	CPU error 2	
	013.4	CPU error	CPU error 4	
	013.5		CPU error 5	
	014.1		Control process error 1	
	014.2		Control process error 2	
	014.3		Control process error 3	
2000	014.4		Control process error 4	
	014.5	Control process error	Control process error 5	
	014.8		Control process error 8	
	014.9		Control process error 9	
	014.C		Control process error 12	
	016.1		Encoder initial communication – Receive data error 1	
	016.2		Encoder initial communication – Receive data error 2	
	016.3		Encoder initial communication – Receive data error 3	
	016.5		Encoder initial communication – Transmission data error 1	
	016.6		Encoder initial communication – Transmission data error 2	
		Encoder initial	Encoder initial communication – Transmission data	
	016.7	communication error 1	error 3	
	016.A	_	Encoder initial communication – Process error 1	
	016.B	_	Encoder initial communication – Process error 2	
	016.C		Encoder initial communication – Process error 3	
	016.D	]	Encoder initial communication – Process error 4	
	016.E		Encoder initial communication – Process error 5	
	016.F		Encoder initial communication – Process error 6	

Table 1.3 Servo error (2000 and 2100) list (MR-J5(W)-□B) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
	017.1	_	Board error 1	
	017.3	_	Board error 2	
	017.4	_	Board error 3	
	017.5	Board error	Board error 4	
	017.6		Board error 5	
	017.7		Board error 7	
	017.9		Board error 8	
	019.1		Flash-ROM error 1	
	019.2	Memory error 3	Flash-ROM error 2	
	019.3	Welliory ellor 3	Flash-ROM error 3	
	019.6		Flash-ROM error 6	
	01A.1	_	Servo motor combination error 1	
	01A.2	_	Servo motor control mode combination error	
	01A.3	Servo motor	Control mode/load-side encoder combination error	
	01A.4	combination error	Servo motor combination error 2	
	01A.5		Servo motor combination error 3	
	01A.6		Servo motor combination error 4	
	01E.1	Encoder initial	Encoder malfunction	
	01E.2	communication error 2	Load-side encoder malfunction	
	01F.1	Encoder initial	Incompatible encoder	
	01F.2	communication error 3	Incompatible load-side encoder	
	020.1		Encoder normal communication – Receive data error 1	
	020.2		Encoder normal communication – Receive data error 2	
2000	020.3		Encoder normal communication – Receive data error 3	
2000	020.5	Encoder normal	Encoder normal communication – Transmission data error 1	
	020.6	communication error 1	Encoder normal communication – Transmission data error 2	
	020.7		Encoder normal communication – Transmission data error 3	
	021.1		Encoder data error 1	
	021.2	1	Encoder data update error	
	021.3	Encoder normal	Encoder data waveform error	
	021.4	communication error 2	No encoder signal	
	021.5	1	Encoder hardware error 1	
	021.6	1	Encoder hardware error 2	
	024.1		Ground fault detected via hardware detection circuit	
	024.2	Main circuit error	Ground fault detected via software detection processing	
	025.1		Servo motor encoder absolute position erased	
	025.2	Absolute position erased	Scale measurement encoder – Absolute position	
	007.4		erased	
	027.1	-	Initial magnetic pole detection – Abnormal termination	
	027.2	1	Initial magnetic pole detection – Time out error	
	027.3	Initial magnetic pole	Initial magnetic pole detection – Limit switch error	
	027.4	detection error	Initial magnetic pole detection – Estimation error	
	027.5	-	Initial magnetic pole detection – Speed deviation error	
	027.6 027.7		Initial magnetic pole detection – Position deviation error Initial magnetic pole detection – Current error	

Table 1.3 Servo error (2000 and 2100) list (MR-J5(W)-□B) (Continued)

Display   Linear encoder error 2	Error code	Servo amplifier LED display	Name	Details name	Remarks
028.2   Load-side linear encoder error 1-1   Linear encoder error 1-1   Linear encoder error 1-2   Linear encoder error 1-2   Linear encoder error 1-2   Linear encoder error 1-3   Linear encoder error 1-3   Linear encoder error 1-3   Linear encoder error 1-3   Linear encoder error 1-5   Linear encoder error 1-5   Linear encoder error 1-5   Linear encoder error 1-5   Linear encoder error 1-6   Linear encoder error 1-7   Linear encoder error 1-8   Linear encoder error 1-7   Linear encoder error 1-8   Linear encoder error 1-9   Linear encoder error 1-9   Linear encoder error 1-9   Linear encoder error 1-9   Linear encoder error 2   Regenerative leads error   Linear encoder error 2   Linear encoder error 2   Linear encoder error 2   Linear encoder error 2   Linear encoder error 1-9   Linear encode		028.1	Lineau anne den amen O	Linear encoder environmental error	
Dinear encoder error 1-2   Linear encoder error 1-3   Linear encoder error 1-3   Linear encoder error 1-3   Linear encoder error 1-3   Linear encoder error 1-4   Linear encoder error 1-5   Linear encoder error 1-5   Linear encoder error 1-5   Linear encoder error 1-6   Linear encoder error 1-7   Linear encoder error 1-7   Linear encoder error 1-7   Linear encoder error 1-8   Linear encoder error 1-8   Linear encoder error 1-8   Linear encoder error 1-8   Linear encoder error 1-7   Linear encoder error 1-8   Linear encoder error 1-9   Linear encoder error 1-5   Linear encoder error 1-8   Linear encoder erro		028.2	Linear encoder error 2	Load-side linear encoder environmental error	
Display		02A.1		Linear encoder error 1-1	
Dinear encoder error 1		02A.2		Linear encoder error 1-2	
Linear encoder error 1		02A.3		Linear encoder error 1-3	
D2A.6   D2A.6   Canal		02A.4	1:	Linear encoder error 1-4	
Direct communication   Direct combination error   Direct combination error   Direct communication   Direct commu		02A.5	Linear encoder error 1	Linear encoder error 1-5	
Display   Command frequency   Command freque		02A.6		Linear encoder error 1-6	
D2B.1		02A.7		Linear encoder error 1-7	
2000  2002 2003 2003 2003 2003 2003 200		02A.8		Linear encoder error 1-8	
038.2   Encoder counter error 2		02B.1		Encoder counter error 1	
Regenerative error   Regenerative signal error   Regenerative feedback signal error   Regenerative feedback signal error		02B.2	Encoder counter error	Encoder counter error 2	
2000  201.1 Overspeed Servo motor speed error Overcurrent detected via hardware detection circuit (during operation)  202.2 Overcurrent detected via software detection processing (during a stop)  2000  202.4 Overcurrent detected via software detection processing (during a stop)  2000  203.3 Overcurrent detected via software detection circuit (during a stop)  2000  203.4 Overcurrent detected via software detection processing (during a stop)  203.1 Overcurrent detected via software detection processing (during a stop)  203.1 Overcurrent detected via software detection processing (during a stop)  203.1 Overcurrent detected via software detection processing (during a stop)  203.1 Overcurrent detected via software detection processing (during a stop)  203.1 Overcurrent detected via software detection processing (during a stop)  203.1 Overcurrent detected via software detection processing (during a stop)  203.1 Overcurrent detected via software detection processing (during a stop)  203.1 Overcurrent detected via software detection processing (during a stop)  203.1 Overcurrent detected via software detection processing (during a stop)  203.1 Overcurrent detected via software detection processing (during a stop)  204.1 Overcurrent detected via software detection processing (during a stop)  205.1 Overcurrent detected via software detection processing (during a stop)  206.1 SSCNET receive data error  206.1 SSCNET communication data error  207.1 Parameter error (Note-1) Overcurent signal detection processing (during a stop)  208.1 Intermittent communication data error  208.1 Inter		030.1		Regenerative heat error	
030.3   Regenerative feedback signal error		030.2	Regenerative error	Regenerative signal error	
Overcurrent detected via hardware detection circuit (during operation) Overcurrent detected via software detection processing (during a peration) Overcurrent detected via software detection processing (during a stop) Overcurrent detected via hardware detection circuit (during a stop) Overcurrent detected via hardware detection circuit (during a stop) Overcurrent detected via software detection processing (during a stop) Main circuit voltage error SSCNET receive data error SSCNET connector connection error SSCNET communication data error Hardware error signal detection SSCNET communication data error 2 Command frequency error error  O36.1 SSCNET receive error 2 O37.1 Parameter error (Note-1) O37.2 Parameter error (Note-1) Parameter setting range error Parameter combination error  O3D.1 Driver communication Driver communication parameter setting error Master-side driver communication parameter combination error Master-side driver communication parameter combination error		030.3		Regenerative feedback signal error	
Overcurrent detected via hardware detection circuit (during operation) Overcurrent detected via software detection processing (during a peration) Overcurrent detected via software detection processing (during a stop) Overcurrent detected via hardware detection circuit (during a stop) Overcurrent detected via hardware detection circuit (during a stop) Overcurrent detected via software detection processing (during a stop) Main circuit voltage error SSCNET receive data error SSCNET connector connection error SSCNET communication data error Hardware error signal detection SSCNET communication data error 2 Command frequency error error  O36.1 SSCNET receive error 2 O37.1 Parameter error (Note-1) O37.2 Parameter error (Note-1) Parameter setting range error Parameter combination error  O3D.1 Driver communication Driver communication parameter setting error Master-side driver communication parameter combination error Master-side driver communication parameter combination error		031.1	Overspeed	Servo motor speed error	
2000  Overcurrent Overcurrent detected via software detection processing (during operation) Overcurrent detected via hardware detection circuit (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via software detection processing (during a stop) Overcurrent detected via software detection processing (during a stop) Overcurrent detected via software detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection processing (during a stop) SCNET connection processing (during a stop) SCNET connection processing value and stop of the processing value and stop of value and stop of value and sto				•	
Overcurrent detected via software detection processing (during operation) Overcurrent detected via hardware detection circuit (during a stop) Overcurrent detected via software detection circuit (during a stop) Overcurrent detected via software detection circuit (during a stop) Overcurrent detected via software detection processing (during a stop) Overcurrent detected via software detection circuit (during a stop) Overcurrent detected via hardware detection processing (during a stop) Overcurrent detected via hardware detection circuit (during a stop) Overcurrent detected via hardware detection circuit (during a stop) Overcurrent detected via hardware detection circuit (during a stop) Overcurrent detected via hardware detection circuit detection Overcurrent detected via hardware detection circuit detection processing (during a stop) Overcurrent detected via hardware detection circuit detror  SSCNET consumication data error SSCNET receive data error SSCNET communication data error SSCNET communication data error 2 Command frequency error Intermittent communication data error Parameter setting range error Parameter setting range error Parameter mismatch error Inrush current suppression circuit error Inrush current suppression circuit error SSCNET communication parameter Combination error Master-side driver communication parameter combination error		032.1		(during operation)	
Overcurrent  Overcurrent (during a stop)  Overcurrent detected via hardware detection circuit (during a stop)  Overcurrent detected via software detection processing (during a stop)  O33.1 Overvoltage Main circuit voltage error  SSCNET receive error  O34.1 O34.2 SSCNET receive error  O34.4 O34.7 SSCNET receive error  O35.1 Command frequency error  O35.1 Command frequency error  O36.1 SSCNET receive error  O37.1 Parameter error (Note-1)  O37.2 (Note-1)  O37.6 Parameter error  O3A.1 suppression circuit error  O3D.1 Driver communication  O3D.2 Slave-side driver communication parameter combination error  Master-side driver communication parameter combination parameter combination error  Master-side driver communication parameter combination error					
2000  032.4  032.4  032.4  032.4  032.4  033.1  0 Overvoltage 034.1  034.2  034.3  034.4  034.7  035.1  036.1  037.1  037.2  037.6  038.1  038.1  038.1  038.2  038.2  038.3  038.4  038.4  038.4  038.4  038.5  038.4  038.7  038.6  038.6  038.7  038		032.2		(during operation)	
2000  032.4  032.4  033.1  Overvoltage  Main circuit voltage error  034.1  034.2  034.3  034.4  035.1  Command frequency error  036.1  037.1  037.2  037.2  Inrush current  03A.1  Driver communication  parameter setting error  Master-side driver communication parameter combination error			Overcurrent	Overcurrent detected via hardware detection circuit	
032.4 (during a stop)  033.1 Overvoltage Main circuit voltage error  034.1 SSCNET receive error  034.3 O34.4 SSCNET receive error  035.1 Command frequency error  036.1 SSCNET receive error  2 Command frequency error  037.1 Parameter error (Note-1) Parameter setting range error  03A.1 suppression circuit error  03D.1 Driver communication  03D.2 Size of diver communication parameter combination error  03D.2 Main circuit voltage error SSCNET receive data error  SSCNET connector connection error  SSCNET connector connection error  SSCNET communication data error  Command frequency error  Intermittent communication data error  Parameter setting range error Parameter combination error  Parameter ismatch error  Size of data error  SSCNET connector connection error  SSCNET connector connection error  Excent connection error  SSCNET communication data error  Intermittent communication data error  Parameter setting range error Parameter combination error  Parameter ismatch error  Inrush current suppression circuit error error  Size of data error  SSCNET connector connection error  Excent communication data error  Intermittent communication data error  Parameter setting error  Parameter setting error  Parameter setting error  Master-side driver communication parameter combination error  Master-side driver communication parameter combination error		032.3		(during a stop)	
033.1 Overvoltage Main circuit voltage error  034.1 SSCNET receive error  034.2 O34.3 O34.4 O34.4 O34.7 O35.1 Command frequency error  035.1 Command frequency error  036.1 SSCNET receive error  037.1 Parameter error  037.2 (Note-1) Parameter error  03A.1 Suppression circuit error  03D.1 Driver communication  03D.2 SCNET receive data error  SSCNET connector connection error  SSCNET communication data error  Command frequency error  Intermittent communication data error  Parameter setting range error  Parameter setting range error  Parameter mismatch error  Inrush current suppression circuit error  Elave-side driver communication parameter  combination error  Master-side driver communication parameter  combination error	2000	200.4		Overcurrent detected via software detection processing	
034.1   034.2   SSCNET receive error   SSCNET connector connection error   SSCNET communication data error   SSCNET communication data error   Hardware error signal detection   SSCNET communication data error   Hardware error signal detection   SSCNET communication data error   Command frequency error   Command frequency error   Intermittent communication data error   Parameter setting range error   Parameter combination error   Parameter mismatch error   Parameter mismatch error   Inrush current   Suppression circuit error   SSCNET receive error   Parameter setting range error   Parameter mismatch error   Parameter mismatch error   SSCNET communication error   Parameter setting range error   Parameter mismatch error   SSCNET connector connection error   Parameter setting error   Parameter setting range error   Parameter mismatch error   SIave-side driver communication parameter   SIave-side driver communication parameter   Combination error   Master-side driver communication parameter   Combination error   C		032.4		(during a stop)	
SSCNET receive error   SSCNET connector connection error   SSCNET communication data error   Hardware error signal detection   SSCNET communication data error 2		033.1	Overvoltage	Main circuit voltage error	
SSCNET receive error   1		034.1		SSCNET receive data error	
034.4   034.7   SSCNET communication data error   Hardware error signal detection   SSCNET communication data error 2		034.2		SSCNET connector connection error	
O34.7   Hardware error signal detection   SSCNET communication data error 2		034.3		SSCNET communication data error	
Command frequency error  O35.1		034.4	] 1	Hardware error signal detection	
O35.1   error   Command frequency error		034.7		SSCNET communication data error 2	
037.1		035.1	• •	Command frequency error	
O37.2 Parameter error (Note-1) Parameter combination error  O37.6 Parameter combination error  Parameter mismatch error  Inrush current suppression circuit error  O3D.1 Driver communication parameter setting error  Master-side driver communication parameter combination error  Master-side driver communication parameter combination error		036.1		Intermittent communication data error	
037.2 (Note-1) Parameter combination error Parameter mismatch error  Inrush current suppression circuit error  03D.1 Driver communication parameter setting error  Master-side driver communication parameter combination error  Master-side driver communication parameter combination error		037.1	Danis at	Parameter setting range error	
037.6 Parameter mismatch error  Inrush current suppression circuit error  03D.1 Driver communication parameter setting error  03D.2 Parameter mismatch error  Inrush current suppression circuit error  Slave-side driver communication parameter combination error  Master-side driver communication parameter combination error		037.2		Parameter combination error	
Inrush current suppression circuit error  O3D.1  Driver communication parameter setting error  D3D.2  Inrush current suppression circuit error  Slave-side driver communication parameter combination error  Master-side driver communication parameter combination error		037.6	(1.5.0 1)	Parameter mismatch error	
Driver communication combination error  parameter setting error Master-side driver communication parameter combination error		03A.1	suppression circuit	Inrush current suppression circuit error	
03D.2 parameter setting error Master-side driver communication parameter combination error		03D.1	Driver communication		
		03D.2		Master-side driver communication parameter	
		035.0	Operation made array		

Table 1.3 Servo error (2000 and 2100) list (MR-J5(W)-□B) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
	042.1		Servo control error based on position deviation	
	042.2		Servo control error based on speed deviation	
	042.3		Servo control error based on torque/thrust deviation	
	040.0	Comic control orror	Fully closed loop control error based on position	
	042.8	Servo control error	deviation	
	042.9		Fully closed loop control error based on speed deviation	
	042.A		Fully closed loop control error based on position	
	042.A		deviation during command stop	
	045.1	Main circuit device	Main circuit device overheat error 1	
	045.2	overheat	Main circuit device overheat error 2	
	046.1		Servo motor temperature error 1	
	046.2		Servo motor temperature error 2	
	046.3		Thermistor disconnected error	
	046.4	Servo motor overheat	Thermistor circuit error	
	046.5		Servo motor temperature error 3	
	046.6	_	Servo motor temperature error 4	
	046.7		Servo motor temperature error 5	
	047.1	Cooling fan error	Cooling fan stop error	
	047.2		Decreased cooling fan speed error	
2000	050.1	Overload 1	Thermal overload error 1 during operation	
	050.2		Thermal overload error 2 during operation	
	050.3		Thermal overload error 4 during operation	
	050.4		Thermal overload error 1 during a stop	
	050.5		Thermal overload error 2 during a stop	
	050.6		Thermal overload error 4 during a stop	
	051.1	Overland 2	Thermal overload error 3 during operation	
	051.2	Overload 2	Thermal overload error 3 during a stop	
	052.1		Excessive droop pulse 1	
	052.3		Excessive droop pulse 2	
	052.4	Excessive error	Excessive error during 0 torque limit	
	052.5		Excessive droop pulse 3	
	052.6		Excessive droop pulse at servo-off	
	054.1	Oscillation detection	Oscillation detection error	
	056.2		Speed exceeded during forced stop	
	056.3	Forced stop error	Estimated distance exceeded during forced stop	
	056.5		Travel distance exceeded during forced stop 2	
	063.1	STO timing array	STO1 off	
	063.2	STO timing error	STO2 off	
	068.1	STO diagnosis error	STO signal mismatch error	

Table 1.3 Servo error (2000 and 2100) list (MR-J5(W)-□B) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
	070.1		Load-side encoder initial communication – Receive	
	070.1		data error 1	
	070.2		Load-side encoder initial communication – Receive	
	070.2		data error 2	
	070.3		Load-side encoder initial communication – Receive	
	070.0		data error 3	
	070.5		Load-side encoder initial communication –	
			Transmission data error 1	
	070.6		Load-side encoder initial communication –	
			Transmission data error 2	
	070.7	Load-side encoder	Load-side encoder initial communication –	
		initial communication	Transmission data error 3	
	070.A	error 1	Load-side encoder initial communication – Process	
			error 1	
	070.B		Load-side encoder initial communication – Process	
			error 2	
	070.C		Load-side encoder initial communication – Process	
			error 3	
	070.D		Load-side encoder initial communication – Process	
			error 4	
	070.E		Load-side encoder initial communication – Process	
			error 5	
	070.F		Load-side encoder initial communication – Process	
2000			error 6	
	071.1		Load-side encoder normal communication – Receive	
			data error 1	
	071.2	Load-side encoder normal communication error 1	Load-side encoder normal communication – Receive	
			data error 2  Load-side encoder normal communication – Receive	
	071.3		data error 3	
			Load-side encoder normal communication –	
	071.5		Transmission data error 1	
			Load-side encoder normal communication –	
	071.6		Transmission data error 2	
			Load-side encoder normal communication –	
	071.7		Transmission data error 3	
	072.1		Load-side encoder data error 1	
	072.2	1	Load-side encoder data update error	
	072.3	Load-side encoder	Load-side encoder data waveform error	
	072.4	normal communication	No load-side encoder signal	
	072.5	error 2	Load-side encoder hardware error 1	
	072.6	1	Load-side encoder hardware error 2	
	082.1	Master-slave operation error 1	Master-slave operation error 1	
	088.1	GITOT 1	Watchdog 1-1	
	088.2	1	Watchdog 1-2	
	088.4	Watchdog	Watchdog 1-4	
		1		
	088.8		Watchdog 1-8	

Table 1.3 Servo error (2000 and 2100) list (MR-J5(W)-□B) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
	08E.1		Serial communication receive error	
	08E.2	Carial communication	Serial communication checksum error	
	08E.3	Serial communication	Serial communication character error	
	08E.4	error	Serial communication command error	
	08E.5		Serial communication data number error	
	118.1	Encoder diagnosis	Encoder communication circuit diagnosis in progress	
	119.1		Memory error 4-1	
	119.2		Memory error 4-2	
	119.3		Memory error 4-3	
	119.4		Memory error 4-4	
	119.5	Memory error 4	Memory error 4-5	
	119.6		Memory error 4-6	
	119.7		Memory free space error 4-1	
	119.8		Memory free space error 4-2	
	11A.1		Servo motor constant file error	
2000	11A.2	Servo motor constant	Servo motor constant file extension error	
	11A.3	error	Servo motor constant file amount error	
	130.1	Regenerative error 2	Regenerative heat error	
	139.1	J	Input open-phase error	
	139.2	Open-phase error	Output open-phase error	
	139.3		Motor wiring error	
	17A.1		Load-side linear encoder error 1-1	
	17A.2		Load-side linear encoder error 1-2	
	17A.3		Load-side linear encoder error 1-3	
	17A.4	Load-side linear	Load-side linear encoder error 1-4	
	17A.5	encoder error 1	Load-side linear encoder error 1-5	
	17A.6	onocaci circi i	Load-side linear encoder error 1-6	
	17A.7	-	Load-side linear encoder error 1-7	
	17A.7		Load-side linear encoder error 1-8	
	188.1	Watchdog 2	Watchdog 2-1	
	091.1	Servo amplifier overheat warning	Main circuit device overheat warning	
	092.1	<b>5</b>	Encoder battery cable disconnection warning	
	092.2	Battery cable	Load-side encoder battery cable disconnection warning	
	092.3	disconnection warning	Battery degradation	
	095.1		STO1 off detection	
	095.2	STO warning	STO2 off detection	
	096.1	Home position setting	In-position warning at homing	
2100	096.2	warning	Command input warning at homing	
	09B.1		Excessive droop pulse 1 warning	
	09B.3	Excessive error	Excessive droop pulse 2 warning	
	09B.4	warning	Excessive error warning during 0 torque limit	
	09F.1		Low battery	
	09F.2	Battery warning	Battery degradation warning	
	0E0.1	Excessive regeneration warning	Excessive regeneration warning	

Table 1.3 Servo error (2000 and 2100) list (MR-J5(W)-□B) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
	0E1.1		Thermal overload warning 1 during operation	
	0E1.2		Thermal overload warning 2 during operation	
	0E1.3		Thermal overload warning 3 during operation	
	0E1.4		Thermal overload warning 4 during operation	
	0E1.5	Overload warning 1	Thermal overload warning 1 during a stop	
	0E1.6		Thermal overload warning 2 during a stop	
	0E1.7		Thermal overload warning 3 during a stop	
	0E1.8	1	Thermal overload warning 4 during a stop	
	0E2.1	Servo motor overheat	Servo motor temperature warning	
	0E2.2	warning	Servo motor temperature warning 2	
	0E3.2		Absolute position counter warning	
	0E3.5	1 F	Encoder absolute position counter warning	
	0E3.3	counter warning	Scale measurement encoder absolute position counter	
	0E3.6	counter warning	warning	
	0E4.1	Parameter warning (Note-1)	Parameter setting range error warning	
	0E6.1	Servo forced stop warning	Forced stop warning	
	0E7.1	Controller forced stop warning	Controller forced stop input warning	
	0E8.1	Decreased cooling fan	Decreased cooling fan speed	
	0E8.2	speed warning	Cooling fan stop	
	0E9.1	Main circuit off	Servo-on signal on during main circuit off	
2100	0E9.2		Bus voltage drop during low speed operation	
	0E9.3	warning	Ready-on signal on during main circuit off	
	0EB.1	The other axis error warning	The other axis error warning	
	0EC.1	Overload warning 2	Overload warning 2	
	0ED.1	Output watt excess warning	Output watt excess warning	
	0F0.1		Instantaneous power failure tough drive warning	
	0F0.3	Tough drive warning	Vibration tough drive warning	
	0F2.1		Drive recorder warning 1	
	0F2.2	1	Drive recorder warning 2	
	0F2.3	1	Drive recorder warning 3	
	0F2.4	Drive recorder warning	Drive recorder warning 4	
	0F2.5	1	Drive recorder warning 5	
	0F2.6	1	Drive recorder warning 6	
	0F3.1	Oscillation detection warning	Oscillation detection warning	
	0F7.1	g	Vibration failure prediction warning	
	0F7.2	1	Friction failure prediction warning	
	0F7.3	Machine diagnosis	Failure prediction warning based on servo motor total travel distance	
	0F7.4	warning	Gear failure prediction warning	
		-		
	0F7.5 0F7.6	1	Static friction failure prediction warning  Belt failure prediction warning	

Table 1.3 Servo error (2000 and 2100) list (MR-J5(W)-□B) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
	19E.4	Network warning 2	SSCNET communication error warning	
0400	1E9.1	Open-phase warning	Input open-phase warning	
2100	1F8.1		Memory writing frequency warning	
	1F8.2	Memory warning 1	Memory free space warning	

## (b) MR-J4(W)-□B

Table 1.4 Servo error (2000 to 2999) list (MR-J4(W)-□B)

Error code	Servo amplifier LED display	Name	Details name	Remarks
2040	10.1	l la deminita no	Voltage drop in the control power	
2010	10.2	Undervoltage	Voltage drop in the main circuit power	
2044	11.1	Considerate and this are a summary	Axis number setting error/Station number setting error	
2011	11.2	Switch setting error	Disabling control axis setting error	
	12.1		RAM error 1	
	12.2		RAM error 2	
2042	12.3	Manager ( DAM)	RAM error 3	
2012	12.4	Memory error 1 (RAM)	RAM error 4	
	12.5		RAM error 5	
	12.6		RAM error 6	
0040	13.1	Ole ele esses	Clock error 1	
2013	13.2	Clock error	Clock error 2	
	14.1		Control process error 1	
	14.2		Control process error 2	
	14.3		Control process error 3	
	14.4		Control process error 4	
	14.5		Control process error 5	
2014	14.6	Control process error	Control process error 6	
	14.7		Control process error 7	
	14.8		Control process error 8	
	14.9		Control process error 9	
	14.A		Control process error 10	
	14.B		Control process error 11	
	15.1		EEP-ROM error at power on	
2015	15.2	Memory error 2	EEP-ROM error during operation	
	15.4	(EEP-ROM)	Home position information read error	
	16.1		Encoder initial communication - Receive data error 1	
	16.2		Encoder initial communication - Receive data error 2	
	16.3		Encoder initial communication - Receive data error 3	
	16.4		Encoder initial communication - Encoder malfunction	
	16.5		Encoder initial communication - Transmission data error	
	16.6		Encoder initial communication - Transmission data error 2	
2016	16.7	Encoder initial communication error 1	Encoder initial communication - Transmission data error 3	
	16.8		Encoder initial communication - Incompatible encoder	
	16.A		Encoder initial communication - Process error 1	
	16.B		Encoder initial communication - Process error 2	
	16.C		Encoder initial communication - Process error 3	
	16.D		Encoder initial communication - Process error 4	
	16.E		Encoder initial communication - Process error 5	
	16.F		Encoder initial communication - Process error 6	

Table 1.4 Servo error (2000 to 2999) list (MR-J4(W)-□B) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
	17.1		Board error 1	
	17.3		Board error 2	
	17.4	-	Board error 3	
	17.5	Ī	Board error 4	
2017	17.6	Board error	Board error 5	
	17.7	1	Board error 7	
	17.8		Board error 6	
	17.9	1	Board error 8	
	19.1		Flash-ROM error 1	
2019	19.2	Memory error 3	Flash-ROM error 2	
2010	19.3	(Flash-ROM)	Flash-ROM error 3	
	20.1		Encoder normal communication - Receive data error 1	
	20.2	_	Encoder normal communication - Receive data error 2	
	20.3	-	Encoder normal communication - Receive data error 3	
	20.3	-	Encoder normal communication - Transmission data	
	20.5		error 1	
2020		Encoder normal	Encoder normal communication - Transmission data	
2020	20.6	communication error 1	error 2	
			Encoder normal communication - Transmission data	
	20.7		error 3	
	20.9		Encoder normal communication - Receive data error 4	
	20.A			
	21.1		Encoder normal communication - Receive data error 5 Encoder error 1	
	21.2	-	Encoder data update error	
2021		Encoder normal	Encoder data waveform error	
2021	21.4	communication error 2	Encoder non-signal error	
	21.5		Encoder hardware error 1	
	21.6	-	Encoder hardware error 2	
	21.9		Encoder error 2	
2024	24.1	Main circuit error	Ground fault detected at hardware detection circuit	
	24.2		Ground fault detected at software detection function	
2025	25.1	Absolute position	Servo motor encoder - Absolute position erased	
	25.2	erased	Scale measurement encoder - Absolute position erased	
	27.1	-	Initial magnetic pole detection - Abnormal termination	
	27.2	4	Initial magnetic pole detection - Time out error	
	27.3	Initial magnetic pole	Initial magnetic pole detection - Limit switch error	
2027	27.4	detection error	Initial magnetic pole detection - Estimated error	
_	27.5		Initial magnetic pole detection - Speed deviation error	
	27.6	_	Initial magnetic pole detection - Position deviation error	
	27.7		Initial magnetic pole detection - Current error	
2028	28.1	Linear encoder error 2	Linear encoder - Environment error	
	30.1		Regeneration heat error	
2030	30.2	Regenerative error	Regeneration signal error	
	30.3		Regeneration feedback signal error	
2031	31.1	Overspeed	Abnormal motor speed	

Table 1.4 Servo error (2000 to 2999) list (MR-J4(W)-□B) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
	32.1	_	Overcurrent detected at hardware detection circuit (during operation)	
			Overcurrent detected at software detection function	
	32.2		(during operation)	
2032		Overcurrent	Overcurrent detected at hardware detection circuit	
	32.3		(during a stop)	
			Overcurrent detected at software detection function	
	32.4		(during a stop)	
2033	33.1	Overvoltage	Main circuit voltage error	
	34.1		SSCNET receive data error	
	34.2		SSCNET connector connection error	
	34.3		SSCNET communication data error	
0004	34.4	SSCNET receive error	Hardware error signal detection	
2034		1	SSCNET receive data error (safety observation	
	34.5		function)	
	24.2		SSCNET communication data error (safety observation	
	34.6		function)	
2035	35.1	Command frequency error	Command frequency error	
	36.1	SSCNET receive error 2	Continuous communication data error	
2036			Continuous communication data error (safety	
	36.2		observation function)	
	37.1		Parameter setting range error	
2037 (Note-1)	37.2	Parameter error	Parameter combination error	
	37.3		Point table setting error	
	42.1		Servo control error by position deviation	
	42.2	Servo control error	Servo control error by speed deviation	
	42.3		Servo control error by torque/thrust deviation	
2042	42.8		Fully closed loop control error by position deviation	
	42.9	Fully closed loop control error	Fully closed loop control error by speed deviation	
			Fully closed loop control error by position deviation	
	42.A		(during command stop)	
	45.1	Main circuit device	Main circuit device overheat error 1	
2045	45.2	overheat	Main circuit device overheat error 2	
	46.1		Abnormal temperature of servo motor 1	
	46.2		Abnormal temperature of servo motor 2	
00:-	46.3	]	Thermistor disconnected error	
2046	46.4	Servo motor overheat	Thermistor circuit error	
	46.5		Abnormal temperature of servo motor 3	
	46.6	1	Abnormal temperature of servo motor 4	
	47.1		Cooling fan stop error	
2047	47.2	Cooling fan error	Cooling fan speed reduction error	
	50.1		Thermal overload error 1 during operation	
	50.2	1	Thermal overload error 2 during operation	
	50.3	1	Thermal overload error 4 during operation	
2050	50.4	Overload 1	Thermal overload error 1 during a stop	
	50.5	1	Thermal overload error 2 during a stop	
	50.6	1	Thermal overload error 4 during a stop	

Table 1.4 Servo error (2000 to 2999) list (MR-J4(W)-□B) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
2051	51.1	Overload 2	Thermal overload error 3 during operation	
2051	51.2	Overload 2	Thermal overload error 3 during a stop	
	52.1	_	Excess droop pulse 1	
	52.3		Excess droop pulse 2	
2052	52.4	Error excessive	Error excessive during 0 torque limit	
	52.5		Excess droop pulse 3	
	52.6		Excessive droop pulse at servo-off	
2054	54.1	Oscillation detection	Oscillation detection error	
	56.2		Over speed during forced stop	
2056	56.3	Forced stop error	Estimated distance over during forced stop	
	1A.1		Servo motor combination error	
2060	1A.2	Servo motor	Servo motor control mode combination error	
2000	1A.4	combination error	Servo motor combination error 2	
	2A.1		Linear encoder error 1-1	
	2A.2	+	Linear encoder error 1-2	
	2A.3		Linear encoder error 1-3	
2061	2A.4	Linear encoder error 1	Linear encoder error 1-4	
	2A.5		Linear encoder error 1-5	
	2A.6		Linear encoder error 1-6	
	2A.7		Linear encoder error 1-7	
	2A.8		Linear encoder error 1-8	
	63.1	STO timing error	STO1 off	
	63.2		STO2 off	
2063	63.5		STO by functional safety unit	
	1E.1	Encoder initial	Encoder malfunction	
	1E.2	communication error 2	Load-side encoder malfunction	
	64.1		STO input error	
	64.2	Functional safety unit	Compatibility mode setting error	
2064	64.3	setting error	Operation mode setting error	
	1F.1	Encoder initial	Incompatible encoder	
	1F.2	communication error 3	Incompatible load-side encoder	
	65.1		Functional safety unit communication error 1	
	65.2		Functional safety unit communication error 2	
	65.3	1	Functional safety unit communication error 3	
	65.4	1	Functional safety unit communication error 4	
2065	65.5	Functional safety unit	Functional safety unit communication error 5	
2000	65.6	connection error	-	
		-	Functional safety unit communication error 6	
	65.7	1	Functional safety unit communication error 7	
	65.8		Functional safety unit shut-off signal error 1	
	65.9		Functional safety unit shut-off signal error 2	
	66.1		Encoder initial communication - Receive data error 1	
2066			(safety observation function)	
	66.2		Encoder initial communication - Receive data error 2	
		Encoder initial	(safety observation function)	
	66.3	communication error	Encoder initial communication - Receive data error 3	
		(safety observation	(safety observation function)	
	66.7	function)	Encoder initial communication - Transmission data error 1 (safety observation function)	
		1	Encoder initial communication - Process error 1 (safety	
	66.9		observation function)	

Table 1.4 Servo error (2000 to 2999) list (MR-J4(W)-□B) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
	67.1	Encoder normal	Encoder normal communication - Receive data error 1 (safety observation function)	
	67.2	communication error 1 (safety observation	Encoder normal communication - Receive data error 2 (safety observation function)	
2067	67.3	function)	Encoder normal communication - Receive data error 3 (safety observation function)	
	67.4	Encoder normal communication error 1	Encoder normal communication - Receive data error 4 (safety observation function)	
	67.7	(safety observation function)	Encoder normal communication - Transmission data error 1 (safety observation function)	
2068	68.1	STO diagnosis error	Mismatched STO signal error	
	70.1		Load-side encoder initial communication - Receive data error 1	
	70.2		Load-side encoder initial communication - Receive data error 2	
	70.3		Load-side encoder initial communication - Receive data error 3	
	70.4		Load-side encoder initial communication - Encoder malfunction	
	70.5		Load-side encoder initial communication - Transmission data error 1	
	70.6		Load-side encoder initial communication - Transmission data error 2	
	70.7	Load-side encoder	Load-side encoder initial communication - Transmission data error 3	
2070	70.8	initial communication error 1	Load-side encoder initial communication - Incompatible encoder	
	70.A		Load-side encoder initial communication - Process error 1	
	70.B		Load-side encoder initial communication - Process error 2	
	70.C		Load-side encoder initial communication - Process error 3	
	70.D		Load-side encoder initial communication - Process error 4	
	70.E		Load-side encoder initial communication - Process error 5	
	70.F		Load-side encoder initial communication - Process error 6	

Table 1.4 Servo error (2000 to 2999) list (MR-J4(W)-□B) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
	71.1		Load-side encoder communication - Receive data error 1	
	71.2		Load-side encoder communication - Receive data error 2	
	71.3		Load-side encoder communication - Receive data error 3	
	71.5	Load-side encoder	Load-side encoder communication - Transmission data error 1	
2071	71.6	normal communication error 1	Load-side encoder communication - Transmission data error 2	
	71.7		Load-side encoder communication - Transmission data error 3	
	71.9		Load-side encoder communication - Transmission data error 4	
	71.A		Load-side encoder communication - Transmission data error 5	
72.1	72.1		Load-side encoder data error 1	
72	72.2		Load-side encoder data update error	
	72.3	Load-side encoder	Load-side encoder data waveform error	
2072	72.4	normal communication	Load-side encoder non-signal error	
	72.5	error 2	Load-side encoder hardware error 1	
	72.6		Load-side encoder hardware error 2	
	72.9		Load-side encoder data error 2	
	79.1	Functional safety unit	Functional safety unit power voltage error	
	79.2		Functional safety unit internal error	
	79.3		Abnormal temperature of functional safety unit	
	79.4		Servo amplifier error	
2079	79.5		Input device error	
	79.6		Output device error	
	79.7		Mismatched input signal error	
	79.8		Position feedback fixing error	
2082	82.1	Master-slave operation error 1	Master-slave operation error 1	
2088	888	Watchdog	Watchdog	
2091	91.1	Servo amplifier overheat warning	Main circuit device overheat warning	
	95.1		STO1 off detection	
	95.2		STO2 off detection	
2095	95.3	STO warning	STO warning 1 (safety observation function)	
	95.4	]	STO warning 2 (safety observation function)	
	95.5		STO warning 3 (safety observation function)	
0.100	92.1	Battery cable	Encoder battery cable disconnection warning	
2102	92.3	disconnection warning	Battery degradation	
	96.1		In-position warning at home positioning	
	96.2	11	Command input warning at home positioning	
2106	96.3	Home position setting	Servo off warning at home positioning	
	96.4	warning	Home positioning warning during magnetic pole detection	
	9F.1		Low battery	
2116	9F.2	Battery warning	Battery degradation warning	

Table 1.4 Servo error (2000 to 2999) list (MR-J4(W)-□B) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
2140	E0.1	Excessive regeneration warning	Excessive regeneration warning	
	E1.1		Thermal overload warning 1 during operation	
	E1.2		Thermal overload warning 2 during operation	
0444	E1.3		Thermal overload warning 3 during operation	
	E1.4		Thermal overload warning 4 during operation	
2141	E1.5	Overload warning 1	Thermal overload error 1 during a stop	
	E1.6		Thermal overload error 2 during a stop	
	E1.7		Thermal overload error 3 during a stop	
	E1.8		Thermal overload error 4 during a stop	
2142	E2.1	Servo motor overheat warning	Servo motor temperature warning	
	E3.1		Multi-revolution counter travel distance excess warning	
	E3.2	1	Absolute position counter warning	
2143		Absolute position	Absolute positioning counter EEP-ROM writing	
	E3.4	counter warning	frequency warning	
	E3.5		Encoder absolute positioning counter warning	
2144 <sup>(Note-1)</sup>	E4.1	Parameter warning	Parameter setting range error warning	
	E6.1		Forced stop warning	
2146	E6.2	Servo forced stop	SS1 forced stop warning 1 (safety observation function)	
	E6.3	warning	SS1 forced stop warning 2 (safety observation function)	
2147	Controller forced		Controller forced stop warning	
	E8.1	Cooling fan speed	Decreased cooling fan speed warning	
2148	E8.2	reduction warning	Cooling fan stop	
	E9.1	J	Servo-on signal on during main circuit off	
	E9.2	Main circuit off	Bus voltage drop during low speed operation	
2149	E9.3	warning	Ready-on signal on during main circuit off	
	E9.4		Converter unit forced stop	
2151	EB.1	The other axis error warning	The other axis error warning	
2152	EC.1	Overload warning 2	Overload warning 2	
2153	ED.1	Output watt excess warning	Output watt excess warning	
0.1	F0.1	<u> </u>	Instantaneous power failure tough drive warning	
2160	F0.3	Tough drive warning	Vibration tough drive warning	
	F2.1	Drive recorder -	Drive recorder - Area writing time-out warning	
2162	F2.2	Miswriting warning	Drive recorder - Data miswriting warning	
2163	F3.1	Oscillation detection warning	Oscillation detection warning	
	F7.1		Vibration failure prediction warning	
2167	F7.2	Machine diagnosis	Friction failure prediction warning	
	F7.3	warning	Total travel distance failure prediction warning	
2907	1B.1	Converter error	Converter unit error	
2001	2B.1	2311701101 01101	Encoder counter error 1	
2913	2B.2	Encoder counter error	Encoder counter error 2	

Table 1.4 Servo error (2000 to 2999) list (MR-J4(W)-□B) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
2918 3A.1		Inrush current suppression circuit error	Inrush current suppression circuit error	
	3D.1	Parameter setting	Parameter combination error for driver communication on slave	
2921	3D.2	error for driver communication	Parameter combination error for driver communication on master	
0000	3E.1		Operation mode error	
2922	3E.6	Operation mode error	Operation mode switch error	
	7A.1		Parameter verification error (safety observation function)	
00.40	7A.2	Parameter setting	Parameter setting range error (safety observation function)	
2942	7A.3	error (safety observation function)	Parameter combination error (safety observation function)	
	7A.4		Functional safety unit combination error (safety observation function)	
	7B.1		Encoder diagnosis error 1 (safety observation function)	
	7B.2	Encoder diagnosis	Encoder diagnosis error 2 (safety observation function)	
2943	7B.3	error (safety	Encoder diagnosis error 3 (safety observation function)	
	7B.4	observation function)	Encoder diagnosis error 4 (safety observation function)	
2944	7C.1	Functional safety unit communication	Functional safety unit communication cycle error (safety observation function)	
	7C.2	diagnosis error (safety observation function)	Functional safety unit communication data error (safety observation function)	
	7D.1	Safety observation	Stop observation error	
2945	7D.2	error	Speed observation error	
	8A.1	USB communication time-out error/serial	USB communication time-out error/serial communication time-out error	
2948	8A.2	communication time- out error/Modbus-RTU communication time- out error	Modbus-RTU communication time-out error	
	8E.1		USB communication receive error/serial communication receive error	
	8E.2		USB communication checksum error/serial communication checksum error	
	8E.3	USB communication error/serial	USB communication character error/serial communication character error	
2952	8E.4	communication error/Modbus-RTU	USB communication command error/serial communication command error	
	8E.5	communication error	USB communication data number error/serial communication data number error	
	8E.6		Modbus-RTU communication receive error	
	8E.7	1	Modbus-RTU communication message frame error	
	8E.8	1	Modbus-RTU communication CRC error	
	9B.1		Excess droop pulse 1 warning	
2955	9B.3	Error excessive	Excess droop pulse 2 warning	
2000	9B.4	warning	Error excessive warning during 0 torque limit	
2956	9C.1	Converter error	Converter unit error	

#### (c) MR-J3-□B

Table 1.5 Servo error (2000 to 2999) list (MR-J3-□B)

Error code	Servo amplifier LED display <sup>(Note-1)</sup>	Name	Remarks
2010	10	Undervoltage	
2012 12		Memory error 1 (RAM)	
2013	13	Clock error	
2015	15	Memory error 2 (EEP-ROM)	
2016	16	Encoder error 1 (At power on)	
2017	17	Board error	
2019	19	Memory error 3 (Flash ROM)	
2020	20	Encoder error 2 (During runtime)	
2021	21	Encoder error 3 (During runtime)	
2024	24	Main circuit error	
2025	25	Absolute position erase	
2030	30	Regenerative error	
2031	31	Overspeed	
2032	32	Overcurrent	
2033	33	Overvoltage	
2034	34	Receive error 1	
2035	35	Command frequency error	
2036	36	Receive error 2	
2045	45	Main circuit device overheat	
2046	46	Servo motor overheat	
2047	47	Cooling fan error	
2050	50	Overload 1	
2051	51	Overload 2	
2052	52	Error excessive	
2060	1A	Motor combination error	
2082	82	Master/slave operation error 1	
2088	888	Watchdog	
2102	92	Battery cable disconnection warning	
2106	96	Home position setting warning	
2116	9F	Battery warning	
2140	E0	Excessive regeneration warning	
2141	E1	Overload warning 1	
2143	E3	Absolute position counter warning	
2146	E6	Servo forced stop warning	
2147	E7	Controller forced stop warning	
2148	E8	Cooling fan speed reduction warning	
2149	E9	Main circuit off warning	
2152	EC	Overload warning 2	
2153	ED	Output watt excess warning	
2301 to 2599	E4	Parameter warning (Refer to the table 1.6)	
2601 to 2899	37	Parameter error (Refer to the table 1.6)	

(Note-1): The LED display is different when using the servo amplifiers with a large capacity. Refer to the "Servo amplifier Instruction Manual" for details.

Table 1.5 Servo error (2000 to 2999) list (MR-J3-□B) (Continued)

Error code	Servo amplifier LED display <sup>(Note-1)</sup>	Name	Remarks
2907 <sup>(Note-2)</sup>	1B	Converter alarm	
2921 <sup>(Note-2)</sup>	3D	Driver communication parameter setting error	
2948 <sup>(Note-2)</sup>	8A	USB communication time-out error	
2952 <sup>(Note-2)</sup>	8E	USB communication error	
2956 (Note-2)	9C	Converter warning	

(Note-1): The LED display is different when using the servo amplifiers with a large capacity. Refer to the "Servo amplifier Instruction Manual" for details.

(Note-2): Error codes will differ depending on the operating system software version.

	<u> </u>			
Error	code	Servo amplifier		
Operating system	Operating system software version "00F" or earlier "00G" or later		Name	
"00F" or earlier				
2021	2907	1B	Converter alarm	
2043	2921	3D	Driver communication parameter setting error	
2090	2948	8A	USB communication time-out error	
2094	2952	8E	USB communication error	
2102	2956	9C	Converter warning	

Table 1.6 Parameter warning (2301 to 2599)/Parameter error (2601 to 2899) error detail

<del></del>			6 Farameter warning (2501 to 259	
Error code		Parameter No.	Name	
2301	2601	PA01	Control mode	
2302	2602	PA02	Regenerative option	
2303	2603	PA03	Absolute position detection system	
2304	2604	PA04	Function selection A-1	
2305	2605	PA05		
2306	2606	PA06	For manufacturer setting	
2307	2607	PA07		
2308	2608	PA08	Auto tuning mode	
2309	2609	PA09	Auto tuning response	
2310	2610	PA10	In-position range	
2311	2611	PA11		
2312	2612	PA12	For manufacturar action	
2313	2613	PA13	For manufacturer setting	
2314	2614	PA14	Rotation direction selection	
2315	2615	PA15	Encoder output pulse	
2316	2616	PA16		
2317	2617	PA17	For manufacturer setting	
2318	2618	PA18		
2319	2619	PA19	Parameter write inhibit	
2320	2620	PB01	Adaptive tuning mode (adaptive filter II)	
2321	2621	PB02	Vibration suppression control tuning mode (advanced vibration suppression control)	
2322	2622	PB03	For manufacturer setting	
2323	2623	PB04	Feed forward gain	
2324	2624	PB05	For manufacturer setting	
2325	2625	PB06	Ratio of load inertia moment to servo motor inertia moment	
2326	2626	PB07	Model loop gain	
2327	2627	PB08	Position loop gain	
2328	2628	PB09	Speed loop gain	
2329	2629	PB10	Speed integral compensation	
2330	2630	PB11	Speed differential compensation	
2331	2631	PB12	Overshoot amount compensation	
2332	2632	PB13	Machine resonance suppression filter 1	
2333	2633	PB14	Notch shape selection 1	
2334	2634	PB15	Machine resonance suppression filter 2	
2335	2635	PB16	Notch shape selection 2	
2336	2636	PB17	Automatic setting parameter	
2337	2637	PB18	Low-pass filter setting	
2338	2638	PB19	Vibration suppression control vibration frequency setting	

Error	code	Parameter No.	Name
2339	2639	PB20	Vibration suppression control resonance frequency setting
2340	2640	PB21	For manufacturer setting
2341	2641	PB22	, and the second
2342	2642	PB23	Low-pass filter selection
2343	2643	PB24	Slight vibration suppression control selection
2344	2644	PB25	For manufacturer setting
2345	2645	PB26	Gain changing selection
2346	2646	PB27	Gain changing condition
2347	2647	PB28	Gain changing time constant
2348	2648	PB29	Gain changing ratio of load inertia moment to servo motor inertia moment
2349	2649	PB30	Gain changing position loop gain
2350	2650	PB31	Gain changing speed loop gain
			Gain changing speed integral
2351	2651	PB32	compensation
			Gain changing vibration suppression
2352	2652	PB33	control vibration frequency setting
2252	2652	DD24	Gain changing vibration suppression
2353	2653	PB34	control resonance frequency setting
2354	2654	PB35	
2355	2655	PB36	
2356	2656	PB37	
2357	2657	PB38	
2358	2658	PB39	
2359	2659	PB40	For manufacturer setting
2360	2660	PB41	
2361	2661	PB42	
2362	2662	PB43	
2363	2663	PB44	
2364	2664	PB45	Vibration suppression control filter 2
2365	2665	PC01	Error excessive alarm level
2366	2666	PC02	Electromagnetic brake sequence output
2367	2667	PC03	Encoder output pulse selection
2368	2668	PC04	Function selection C-1
2369	2669	PC05	Function selection C-2
2370	2670	PC06	Function selection C-3
2371	2671	PC07	Zero speed
2372	2672	PC08	For manufacturer setting
2373	2673	PC09	Analog monitor 1 output
2374	2674	PC10	Analog monitor 2 output
2375	2675	PC11	Analog monitor 1 offset
2376	2676	PC12	Analog monitor 2 offset

(Note): The details are different when using the servo amplifiers with a large capacity. Refer to the "Servo amplifier Instruction Manual" for details.

Table 1.6 Parameter warning (2301 to 2599)/Parameter error (2601 to 2899) error detail (Continued)

	1		ameter warning (2501 to 2599)/Para	1.0.01		<u>`</u>	
Error	code	Parameter No.	Name	Error	code	Parameter No.	Name
2377	2677	PC13	Analog monitor feedback position output	2416	2716	PD20	Driver communication setting
			standard data Low				Master axis No. selection1 for slave
2378	2678	PC14	Analog monitor feedback position output standard data High	2417	2717	PD21	
2379	2679	PC15	For manufacturer setting	2418	2718	PD22	
2380	2680	PC16	Function selection C-3A	2419	2719	PD23	
2381	2681	PC17	Function selection C-4	2420	2720	PD24	For manufacturar acting
2382	2682	PC18	For manufacturar actting	2421	2721	PD25	For manufacturer setting
2383	2683	PC19	For manufacturer setting	2422	2722	PD26	
2384	2684	PC20	Function selection C-7	2423	2723	PD27	
2385	2685	PC21	Alarm history clear	2424	2724	PD28	
2386	2686	PC22		2425	2725	PD29	
2387	2687	PC23		2426	2726	PD30	Master-slave operation - Torque command coefficient on slave
2388	2688	PC24		2427	2727	PD31	Master-slave operation - Speed limit coefficient on slave
2389	2689	PC25		2428	2728	PD32	Master-slave operation - Speed limit adjustment value on slave
2390	2690	PC26		2429	2729	PE01	
2391	2691	PC27		2430	2730	PE02	
2392	2692	PC28		2431	2731	PE03	
2393	2693	PC29	For manufacturer setting	2432	2732	PE04	
2394	2694	PC30		2433	2733	PE05	
2395	2695	PC31		2434	2734	PE06	
2396	2696	PC32		2435	2735	PE07	
2397	2697	PD01		2436	2736	PE08	
2398	2698	PD02		2437	2737	PE09	
2399	2699	PD03		2438	2738	PE10	
2400	2700	PD04		2439	2739	PE11	
2401	2701	PD05		2440	2740	PE12	
2402	2702	PD06		2441	2741	PE13	
2403	2703	PD07	Output signal device selection 1 (CN3-13)	2442	2742	PE14	For manufacturer setting
2404	2704	PD08	Output signal device selection 2 (CN3-9)	2443	2743	PE15	
2405	2705	PD09	Output signal device selection 3 (CN3-15)	2444	2744	PE16	
2406		PD10	For manufacturer setting		2745	PE17	
2407	2707	PD11	Input filter setting		2746	PE18	
2408		PD12			2747	PE19	
2409		PD13	For manufacturer setting	2448	2748	PE20	
2410		PD14	Function selection D-3		2749	PE21	
2411		PD15	Driver communication setting		2750	PE22	
2412		PD16	Driver communication setting Master transmit data selection1		2751	PE23	
2413	2713	PD17	Driver communication setting Master transmit data selection2	2452	2752	PE24	
2414	2714	PD18	For manufacturar acting	2453	2753	PE25	
2415	2715	PD19	For manufacturer setting	2454	2754	PE26	Filter coefficient 2-1

(Note): The details are different when using the servo amplifiers with a large capacity. Refer to the "Servo amplifier Instruction Manual" for details.

Table 1.6 Parameter warning (2301 to 2599)/Parameter error (2601 to 2899) error detail (Continued)

Error code		Parameter No.	Name
2455	2755	PE27	Filter coefficient 2-2
2456	2756	PE28	Filter coefficient 2-3
2457	2757	PE29	Filter coefficient 2-4
2458	2758	PE30	Filter coefficient 2-5
2459	2759	PE31	Filter coefficient 2-6
2460	2760	PE32	Filter coefficient 2-7
2461	2761	PE33	Filter coefficient 2-8

Error	Error code Parameter		Name	
		NO.		
2462	2762	PE34		
2463	2763	PE35		
2464	2764	PE36		
2465	2765	PE37	For manufacturer setting	
2466	2766	PE38		
2467	2767	PE39		
2468	2768	PE40		

(Note): The details are different when using the servo amplifiers with a large capacity. Refer to the "Servo amplifier Instruction Manual" for details.

#### (d) MR-J3W-□B

Table 1.7 Servo error (2000 to 2999) list (MR-J3W-□B)

Error code	Servo amplifier LED display	Name	Details name	Remarks
2010	10.1	Lindonioltogo	Voltage drop in the control circuit power supply	
2010	10.2	Undervoltage	Voltage drop in the main circuit power	
	11.1		Rotary switch setting error	
0044	11.2	O it also a string or a summer	DIP switch setting error	
2011	11.3	Switch setting error	Servo motor selection switch setting error	
	11.4		Servo motor selection switch setting error 2	
	12.1		CPU built-in RAM error	
2012	12.2	Memory error 1 (RAM)	CPU data RAM error	
	12.3		Custom IC RAM error	
2013	13.1	Clock error	Clock error	
	15.1	Memory error 2 (EEP-	EEP-ROM error at power on	
2015	15.2	ROM)	EEP-ROM error during operation	
	16.1		Encoder receive data error 1	
	16.2	<del>-</del>	Encoder receive data error 2	
	16.3	Encoder initial	Encoder receive data error 3	
2016	16.5	communication error 1	Encoder transmission data error 1	
	16.6		Encoder transmission data error 2	
	16.7	1	Encoder transmission data error 3	
	17.1		AD converter error	
	17.1	Board error	Current feedback data error	
			Custom IC error	
2017	17.3			
	17.4		Amplifier detection signal error	
	17.5	-	Rotary switch error	
	17.6		DIP switch error	
2019	19.1	Memory error 3 (Flash	Flash-ROM error 1	
	19.2	ROM)	Flash-ROM error 2	
	20.1	=	Encoder receive data error 1	
	20.2	-	Encoder receive data error 2	
2020	20.3	Encoder normal	Encoder receive data error 3	
	20.5	communication error 1	Encoder transmission data error 1	
	20.6	-	Encoder transmission data error 2	
	20.7		Encoder transmission data error 3	
	21.1	Encoder normal	Encoder data error	
2021	21.2	communication error 2	Encoder data update error	
	21.3	COMMUNICATION CITOR 2	Encoder waveform error	Direct drive motor use
2024	24.1	Main circuit error	Ground fault detected at hardware detection circuit	
2024	24.2	Main Circuit error	Ground fault detected at software detection function	
2025	25.1	Absolute position erase	Absolute position data erase	
	27.1		Magnetic pole detection abnormal termination	
	27.2		Magnetic pole detection time out error	
	27.3	1	Magnetic pole detection limit switch error	
2027	27.4	Initial magnetic pole	Magnetic pole detection estimated error	Linear servo motor/
	27.5	detection error	Magnetic pole detection position deviation error	direct drive motor use
	27.6	1	Magnetic pole detection speed deviation error	1
	27.7	1	Magnetic pole detection current error	1
2028	28.1	Linear encoder error 2	Linear encoder environment error	Linear servo motor use

Table 1.7 Servo error (2000 to 2999) list (MR-J3W-□B) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks		
	30.1		Regeneration heat error			
2030	30.2	Regenerative error	Regenerative transistor error			
	30.3		Regenerative transistor feedback data error			
2031	31.1	Overspeed	Abnormal motor speed (Note-1), (Note-2)			
	32.1		Overcurrent detected at hardware detection circuit (during operation).			
	32.2		Overcurrent detected at software detection function (during operation).			
2032	32.3	Overcurrent	Overcurrent detected at hardware detection circuit (during a stop).			
	32.4		Overcurrent detected at software detection function (during a stop).			
2033	33.1	Overvoltage	Main circuit voltage error			
	34.1	•	SSCNET receive data error			
2034	34.2	SSCNET receive error	SSCNET communication connector connection error			
2001	34.3	1	Communication data error			
	34.4	-	Hardware error signal detection			
2035	35.1	Command frequency error	Command frequency error			
2036	36.1	SSCNET receive error	Continuous communication data error			
	42.1	Linear servo control error	Linear servo control error on the positioning detection	Linear servo motor use		
	42.2			Servo control error	Servo control error due to position deviation	Direct drive motor use
2042		Linear servo control error	Linear servo control error on the speed detection	Linear servo motor use		
		Servo control error	Servo control error due to speed deviation	Direct drive motor use		
		Linear servo control error	Linear servo control error on the thrust detection	Linear servo motor use		
		Servo control error	Servo control error due to torque detection	Direct drive motor use		
2045	45.1	Main circuit device	Main circuit abnormal temperature			
2045	45.2	overheat	Board temperature error			
	46.1		Abnormal temperature of servo motor			
	46.2	Servo motor overheat	Linear servo motor thermal sensor error	Linear servo motor use		
2046	40.2	(Note-2)	Direct drive motor thermal sensor error	Direct drive motor use		
	46.3		Thermistor wires are not connected error	Linear servo motor/direct drive motor use		
0047	47.1	0 " (	Cooling fan stop error			
2047	47.2	Cooling fan error	Decreased cooling fan speed error			
	50.1		Thermal overload error 1 during operation			
	50.2		Thermal overload error 2 during operation			
2050	50.3	Overdeed 4	Thermal overload error 4 during operation			
2050	50.4	Overload 1	Thermal overload error 1 during a stop			
	50.5		Thermal overload error 2 during a stop			
	50.6		Thermal overload error 4 during a stop			

(Note-1): The name is different when using the linear servo motors. Refer to the "Servo amplifier Instruction Manual" for details. (Note-2): The name is different when using the direct drive motors. Refer to the "Servo amplifier Instruction Manual" for details.

Table 1.7 Servo error (2000 to 2999) list (MR-J3W-□B) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
2054	51.1	0,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	Thermal overload error 3 during operation	
2051	51.2	Overload 2	Thermal overload error 3 during a stop	
0050	52.3	F	Excess droop pulse (Note-1), (Note-2)	
2052	52.4	Error excessive	Maximum deviation at 0 torque limit (Note-1), (Note-2)	
2060	1A.1	Motor combination error	Motor combination Motor combination error	
	2A.1		Linear encoder side error 1	
	2A.2		Linear encoder side error 2	
	2A.3		Linear encoder side error 3	
0004	2A.4	]	Linear encoder side error 4	]
2061	2A.5	Linear encoder error 1	Linear encoder side error 5	Linear servo motor use
	2A.6	-	Linear encoder side error 6	1
	2A.7		Linear encoder side error 7	
	2A.8		Linear encoder side error 8	
2063 <sup>(Note-3)</sup>	1E.1	Encoder initial communication error 2	Encoder failure	
2064 <sup>(Note-3)</sup>	1F.1	Encoder initial communication error 3		
2088	888	Watchdog	_	
2101 <sup>(Note-3)</sup>	91.1	Main circuit device	Main circuit device overheat warning	
2101 (1000 0)	91.2	overheat warning	Board temperature warning	
2102	92.1	Battery cable disconnection warning	Encoder battery disconnection warning signal detection	
	96.1	Home position setting	In-position error at home positioning	
2106	96.2	warning	Command input error at home positioning	
2116	9F.1	Battery warning	Low battery	
2140	E0.1	Excessive regeneration warning	Excessive regeneration warning	
	E1.1		Thermal overload warning 1 during operation	
	E1.2		Thermal overload warning 2 during operation	
	E1.3		Thermal overload warning 3 during operation	
	E1.4	1	Thermal overload warning 4 during operation	
2141	E1.5	Overload warning 1	Thermal overload warning 1 during a stop	
	E1.6	1	Thermal overload warning 2 during a stop	
	E1.7	1	Thermal overload warning 3 during a stop	
	E1.8		Thermal overload warning 4 during a stop	
2442		Linear servo motor overheat warning	Linear servo motor overheat warning	Linear servo motor use
2142	E2.1	Direct drive motor overheat warning	Direct drive motor overheat warning	Direct drive motor use

(Note-1): The name is different when using the linear servo motors. Refer to the "Servo amplifier Instruction Manual" for details. (Note-2): The name is different when using the direct drive motors. Refer to the "Servo amplifier Instruction Manual" for details. (Note-3): Error codes will differ depending on the operating system software version.

	code n software version	Servo amplifier	Name	
"00F" or earlier "00G" or later		LED display		
2024	2063	1E	Encoder initial communication error 2	
2025	2064	1F	Encoder initial communication error 3	
2091	2101	91	Main circuit device overheat warning	

Table 1.7 Servo error (2000 to 2999) list (MR-J3W-□B) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
2143	E3.1	Absolute position	The multi-revolution counter travel distance excess warning	
	E3.2	counter warning	Absolute positioning counter error	
2146	E6.1	Servo forced stop warning	Servo forced stop warning	
2147	E7.1	Controller forced stop warning	Controller forced stop warning	
2148	E8.1	Cooling fan speed reduction warning	Decreased cooling fan speed warning	
	E9.1		Ready-on signal on at main circuit off	
2149	E9.2	Main circuit off warning	Bus voltage drop during low speed operation (Note-1)	
	E9.3		Servo-on signal on at main circuit off	
2151	EB.1	The other axis fault warning	The other axis fault warning	
2152	EC.1	Overload warning 2	Overload warning 2	
2153	ED.1	Output watt excess warning	Output watt excess	
2301 to 2599	E4.1	Parameter warning (Refer to the table 1.8)	Parameter setting range error warning	
0004 to 0000	37.1	Parameter error	Parameter setting range error	
2601 to 2899	37.2	(Refer to the table 1.8)	Parameter combination error	
2913 <sup>(Note-3)</sup>	2B.1		Encoder counter error 1	Dina at duis a ma atau sa a
2913 (**** */	2B.2	Encoder counter error	Encoder counter error 2	Direct drive motor use
2948 <sup>(Note-3)</sup>	8A.1	USB communication time-out error	USB communication time-out error	
	8E.1		USB communication receive error	
	8E.2		USB communication checksum error	
2952 <sup>(Note-3)</sup>	8E.3	USB communication	USB communication character error	
	8E.4	error	USB communication command error	
	8E.5		USB communication data No. error	

(Note-1): The name is different when using the linear servo motors. Refer to the "Servo amplifier Instruction Manual" for details. (Note-2): The name is different when using the direct drive motors. Refer to the "Servo amplifier Instruction Manual" for details. (Note-3): Error codes will differ depending on the operating system software version.

	code n software version	Servo amplifier LED display	Name	
"00F" or earlier	"00F" or earlier "00G" or later			
2031	2913	2B	Encoder counter error	
2090	2948	8A	USB communication time-out error	
2094	2958	8E	USB communication error	

Table 1.8 Parameter warning (2301 to 2599)/Parameter error (2601 to 2899) error detail

Error code		Parameter No.	Name	
2301	2601	PA01	Control mode	
2302	2602	PA02	Regenerative option	
2303	2603	PA03	Absolute position detection system	
2304	2604	PA04	Function selection A-1	
2305	2605	PA05		
2306	2606	PA06	For manufacturer setting	
2307	2607	PA07		
2308	2608	PA08	Auto tuning mode	
2309	2609	PA09	Auto tuning response	
2310	2610	PA10	In-position range	
2311	2611	PA11		
2312	2612	PA12	For manufacturer setting	
2313	2613	PA13		
2314	2614	PA14	Rotation direction selection	
2315	2615	PA15	Encoder output pulse	
2316	2616	PA16	Encoder output pulse 2	
2317	2617	PA17	For manufacturer actting	
2318	2618	PA18	For manufacturer setting	
2319	2619	PA19	Parameter write inhibit	
2320	2620	PB01	Adaptive tuning mode (adaptive filter II)	
2321	2621	PB02	Vibration suppression control tuning mode (advanced vibration suppression control)	
2322	2622	PB03	For manufacturer setting	
2323	2623	PB04	Feed forward gain	
2324	2624	PB05	For manufacturer setting	
2325	2625	PB06	Ratio of load inertia moment to servo motor inertia moment	
2326	2626	PB07	Model loop gain	
2327	2627	PB08	Position loop gain	
2328	2628	PB09	Speed loop gain	
2329	2629	PB10	Speed integral compensation	
2330	2630	PB11	Speed differential compensation	
2331	2631	PB12	For manufacturer setting	
2332	2632	PB13	Machine resonance suppression filter 1	
2333	2633	PB14	Notch shape selection 1	
2334	2634	PB15	Machine resonance suppression filter 2	
2335	2635	PB16	Notch shape selection 2	
2336	2636	PB17	Automatic setting parameter	
2337	2637	PB18	Low-pass filter setting	
2338	2638	PB19	Vibration suppression control vibration frequency setting	
2339	2639	PB20	Vibration suppression control resonance frequency setting	

Error	code	Parameter No.	Name		
2340	2640	PB21	F		
2341	2641	PB22	For manufacturer setting		
2342	2642	PB23	Low-pass filter selection		
2343	2643	PB24	Slight vibration suppression control selection		
2344	2644	PB25	For manufacturer setting		
2345	2645	PB26	Gain changing selection		
2346	2646	PB27	Gain changing condition		
2347	2647	PB28	Gain changing time constant		
2348	2648	PB29	Gain changing ratio of load inertia moment to servo motor inertia moment		
2240	0040	DD20			
2349	2649	PB30	Gain changing position loop gain		
2350	2650	PB31	Gain changing speed loop gain		
2351	2651	PB32	Gain changing speed integral		
			compensation		
2352	2652	PB33	Gain changing vibration suppression		
			control vibration frequency setting Gain changing vibration suppression		
2353	2653	PB34	control resonance frequency setting		
2354	2654	PB35	control resonance frequency setting		
2355	2655	PB36			
2356	2656	PB37			
2357	2657	PB38			
2358	2658	PB39			
2359	2659	PB40			
2360	2660	PB41	For manufacturer setting		
2361	2661	PB42			
2362	2662	PB43			
2363	2663	PB44			
2364	2664	PB45			
2365	2665	PC01	Error excessive alarm level		
2366	2666	PC02	Electromagnetic brake sequence output		
2367	2667	PC03	Encoder output pulse selection		
2368	2668	PC04	Function selection C-1		
2369	2669	PC05	Function selection C-2		
2370	2670	PC06	Function selection C-3		
2371	2671	PC07	Zero speed		
2372	2672	PC08	For manufacturer setting		
2373	2673	PC09	Analog monitor 1 output		
2374	2674	PC10	Analog monitor 2 output		
2375	2675	PC11	Analog monitor 1 offset		
2376	2676	PC12	Analog monitor 2 offset		
2377	2677	PC13			
2378	2678	PC14	For manufacturer setting		

Table 1.8 Parameter warning (2301 to 2599)/Parameter error (2601 to 2899) error detail (Continued)

Error	code	Parameter No.	Name
2379	2679	PC15	Station number selection
2380	2680	PC16	For manufacturer setting
2381	2681	PC17	Function selection C-4
2382	2682	PC18	
2383	2683	PC19	For manufacturer setting
2384	2684	PC20	
2385	2685	PC21	Alarm history clear
2386	2686	PC22	
2387	2687	PC23	
2388	2688	PC24	
2389	2689	PC25	
2390	2690	PC26	
2391	2691	PC27	
2392	2692	PC28	
2393	2693	PC29	
2394	2694	PC30	
2395	2695	PC31	For manufacturer setting
2396	2696	PC32	
2397	2697	PD01	
2398	2698	PD02	
2399	2699	PD03	
2400	2700	PD04	
2401	2701	PD05	
2402	2702	PD06	
2403	2703	PD07	Output signal device selection 1 (CN3-12 for A-axis and CN3-25 for B-axis)
2404	2704	PD08	For manufacturer setting
2405	2705	PD09	Output signal device selection 3 (CN3-11 for A-axis and CN3-24 for B-axis)
2406	2706	PD10	For manufacturer setting
2407	2707	PD11	Input filter setting
2408	2708	PD12	For manufacturar acting
2409	2709	PD13	For manufacturer setting
2410	2710	PD14	Function selection D-3
2411	2711	PD15	For manufacturer setting

Error	code	Parameter	Name				
LIIOI	code	No.	ivanie				
2412	2712	PD16					
2413	2713	PD17					
2414	2714	PD18					
2415	2715	PD19					
2416	2716	PD20					
2417	2717	PD21					
2418	2718	PD22					
2419	2719	PD23					
2420	2720	PD24	For manufacturer setting				
2421	2721	PD25					
2422	2722	PD26					
2423	2723	PD27					
2424	2724	PD28					
2425	2725	PD29					
2426	2726	PD30					
2427	2727	PD31					
2428	2728	PD32					
2485	2785	Po01	Function selection O-1				
0.400	0700		Axis selection for graphing analog data				
2486	2786	Po02	(MR Configurator)				
2487	2797	2787	2787	2707	2707	Po03	Axis selection for graphing digital data
2407	2/0/	F003	(MR Configurator)				
2488	2788	Po04	Function selection O-2				
2489	2789	Po05					
2490	2790	Po06					
2491	2791	Po07					
2492	2792	Po08					
2493	2793	Po09					
2494	2794	Po10	For manufacturer setting				
2495	2795	Po11					
	2796	Po12					
	2797	Po13					
	2798	Po14					
2499		Po15					
2500		Po16					

## (e) MR-J3-□B-RJ004 (For linear servo)

# Table 1.9 Servo error (2000 to 2999) list (MR-J3-□B-RJ004)

Error code	Servo amplifier LED display	Name	Remarks
2010	10	Undervoltage	
2012	12	Memory error 1 (RAM)	
2013	13	Clock error	
2015	15	Memory error 2 (EEP-ROM)	
2016	16	Encoder error 1 (At power on)	
2017	17	Board error	
2019	19	Memory error 3 (Flash ROM)	
2020	20	Encoder error 2	
2021	21	Encoder error 3	
2024	24	Main circuit error	
2027	27	Initial magnetic pole detection error	
2028	28	Linear encoder error 2	
2030	30	Regenerative error	
2031	31	Overspeed	
2032	32	Overcurrent	
2033	33	Overvoltage	
2034	34	Receive error 1	
2035	35	Command frequency alarm	
2036	36	Receive error 2	
2042	42	Linear servo control error	
2045	45	Main circuit device overheat	
2046	46	Linear servo motor overheat	
2047	47	Cooling fan alarm	
2050	50	Overload 1	
2051	51	Overload 2	
2052	52	Error excessive	
2061	2A	Linear encoder error 1	
2088	888	Watchdog	
2106	96	Home position setting error	
2140	E0	Excessive regeneration warning	
2141	E1	Overload warning 1	
2142	E2	Linear servo motor overheat warning	
2146	E6	Servo forced stop warning	
2147	E7	Controller emergency stop warning	
2148	E8	Cooling fan speed reduction warning	
2149	E9	Main circuit off warning	
2152	EC	Overload warning 2	
2153	ED	Output watt excess warning	
2301 to 2599	E4	Parameter warning (Refer to the table 1.10)	
2601 to 2899	37	Parameter error (Refer to the table 1.10)	

Table 1.9 Servo error (2000 to 2999) list (MR-J3-□B-RJ004) (Continued)

Error code	Servo amplifier LED display	Name	Remarks
2948 <sup>(Note-1)</sup>	8A	USB communication time-out error	
2952 <sup>(Note-1)</sup>	8E	USB communication error	

(Note-1): Error codes will differ depending on the operating system software version.

Operating system software version  "00F" or earlier "00G" or later		Servo amplifier LED display	Name
2090	2948	8A	USB communication time-out error
2094	2952	8E	USB communication error

Table 1.10 Parameter warning (2301 to 2599)/Parameter error (2601 to 2899) error detail

Error	code	Parameter No.	Name	
2301	2601	PA01	For manufacturer setting	
	2602	PA02	Regenerative option	
2303	2603	PA03	Absolute position detection system	
2304	2604	PA04	Function selection A-1	
2305	2605	PA05		
2306	2606	PA06	For manufacturer setting	
2307	2607	PA07		
2308	2608	PA08	Auto tuning mode	
2309	2609	PA09	Auto tuning response	
2310	2610	PA10	In-position range	
2311	2611	PA11		
2312	2612	PA12	For manufacturer setting	
2313	2613	PA13		
2314	2614	PA14	Moving direction selection	
2315	2615	PA15	Encoder output pulse	
2316	2616	PA16	Encoder output pulse 2	
2317	2617	PA17	Far manufactum action	
2318	2618	PA18	For manufacturer setting	
2319	2619	PA19	Parameter write inhibit	
2320	2620	PB01	Adaptive tuning mode (adaptive filter II)	
2321	2621	PB02	Vibration suppression control tuning mode	
2321	2021	1 002	(advanced vibration suppression control)	
2322	2622	PB03	For manufacturer setting	
2323	2623	PB04	Feed forward gain	
2324	2624	PB05	For manufacturer setting	
2325	2625	PB06	Load mass ratio to the linear servo motor primary side (coil)	
2326	2626	PB07	Model loop gain	
2327	2627	PB08	Position loop gain	
2328	2628	PB09	Speed loop gain	
2329	2629	PB10	Speed integral compensation	
2330	2630	PB11	Speed differential compensation	
2331	2631	PB12	For manufacturer setting	
2332	2632	PB13	Machine resonance suppression filter 1	
2333	2633	PB14	Notch form selection 1	
2334	2634	PB15	Machine resonance suppression filter 2	
2335	2635	PB16	Notch form selection 2	
2336	2636	PB17	Automatic setting parameter	
2337	2637	PB18	Low-pass filter setting	
2338	2638	PB19	Vibration suppression control vibration frequency setting	
2339	2639	PB20	Vibration suppression control resonance frequency setting	
2340	2640	PB21	For manufacturer setting	

Error code		Parameter No.	Name
2341	2641	PB22	For manufacturer setting
2342	2642	PB23	Low-pass filter selection
2343	2643	PB24	Slight vibration suppression control selection
2344	2644	PB25	For manufacturer setting
2345	2645	PB26	Gain changing selection
2346	2646	PB27	Gain changing condition
2347	2647	PB28	Gain changing time constant
2348	2648	PB29	Gain load mass ratio to the linear servo motor primary side (coil)
2349	2649	PB30	Gain changing position loop gain
2350	2650	PB31	Gain changing speed loop gain
2351	2651	PB32	Gain changing speed integral compensation
2352	2652	PB33	Gain changing vibration suppression control vibration frequency setting
2353	2653	PB34	Gain changing vibration suppression control resonance frequency setting
2354	2654	PB35	
2355	2655	PB36	
2356	2656	PB37	
2357	2657	PB38	
2358	2658	PB39	
2359	2659	PB40	For manufacturer setting
2360	2660	PB41	
2361	2661	PB42	
2362	2662	PB43	
2363	2663	PB44	
2364	2664	PB45	Vibration suppression control filter 2
2365	2665	PC01	Error excessive alarm level
2366	2666	PC02	Electromagnetic brake sequence output
2367	2667	PC03	Encoder output pulse selection
2368		PC04	
2369		PC05	For manufacturer setting
	2670	PC06	•
2371	2671	PC07	Zero speed
2372	2672	PC08	For manufacturer setting
2373	2673	PC09	Analog monitor 1 output
	2674	PC10	Analog monitor 2 output
2375		PC11	Analog monitor 1 offset
2376	2676	PC12	Analog monitor 2 offset
2377	2677	PC13	
2378	2678	PC14	
2379	2679	PC15	For manufacturer setting
2380	2680	PC16	

Table 1.10 Parameter warning (2301 to 2599)/Parameter error (2601 to 2899) error detail (Continued)

Error	code	Parameter No.	Name	
2381	2681	PC17	Function selection C-4	
2382	2682	PC18		
	2683	PC19	For manufacturer setting	
2384	2684	PC20	j	
2385		PC21	Alarm history clear	
	2686	PC22		
	2687	PC23		
	2688	PC24	For manufacturer setting	
	2689	PC25		
2390		PC26	Function selection C-8	
2391		PC27	Function selection C-9	
	2692	PC28		
	2693	PC29		
2394		PC30		
2395		PC31	For manufacturer setting	
2396		PC32		
2397		PD01		
2398		PD02	Input signal automatic ON selection	
2399		PD03	input signal automatic Cit sciosion	
	2700	PD04		
2401		PD05	For manufacturer setting	
2402		PD06		
2403		PD07	Output signal device selection 1 (CN3-13)	
2404		PD08	Output signal device selection 2 (CN3-9)	
2405		PD09	Output signal device selection 3 (CN3-15)	
2406		PD10	For manufacturer setting	
2407		PD11	Input filter setting	
	2708	PD12		
2409		PD13	For manufacturer setting	
2410		PD14	Function selection D-3	
2411		PD15		
	2712	PD16		
	2713	PD17		
2414		PD18		
2415		PD19		
2416		PD20		
2417	2717	PD21		
	2718	PD22		
2419	2719	PD23		
2420	2720	PD24	For manufacturer setting	
2421	2721	PD25		
2422	2722	PD26		
2423	2723	PD27		
2424	2724	PD28		
2425	2725	PD29		
2426	2726	PD30		

Error	code	Parameter No.	Name
2427	2727	PD31	
2428	2728	PD32	
2429	2729	PE01	
	2730	PE02	
2431	2731	PE03	
2432	2732	PE04	
2433	2733	PE05	
2434	2734	PE06	
2435	2735	PE07	
2436	2736	PE08	
2437	2737	PE09	
2438	2738	PE10	
2439	2739	PE11	
2440	2740	PE12	For manufacturer setting
2441	2741	PE13	
2442	2742	PE14	
2443	2743	PE15	
2444	2744	PE16	
2445	2745	PE17	
2446	2746	PE18	
2447	2747	PE19	
2448	2748	PE20	
2449	2749	PE21	
2450	2750	PE22	
2451	2751	PE23	
2452	2752	PE24	
2453	2753	PE25	
2454	2754	PE26	Filter coefficient 2-1
2455	2755	PE27	Filter coefficient 2-2
2456	2756	PE28	Filter coefficient 2-3
2457	2757	PE29	Filter coefficient 2-4
2458	2758	PE30	Filter coefficient 2-5
2459	2759	PE31	Filter coefficient 2-6
2460	2760	PE32	Filter coefficient 2-7
2461	2761	PE33	Filter coefficient 2-8
2462	2762	PE34	
2463	2763	PE35	
2464	2764	PE36	
2465	2765	PE37	For manufacturer setting
2466	2766	PE38	
2467	2767	PE39	
2468	2768	PE40	
2501	2801	PS01	Linear function selection 1
2502	2802	PS02	Linear encoder resolution setting Numerator
2503	2803	PS03	Linear encoder resolution setting Denominator
2504	2804	PS04	Linear function selection 2

Table 1.10 Parameter warning (2301 to 2599)/Parameter error (2601 to 2899) error detail (Continued)

Error	code	Parameter No.	Name
2505	2805	PS05	Linear servo motor control position deviation error detection level
2506	2806	PS06	Linear servo motor control speed deviation error detection level
2507	2807	PS07	Linear servo motor control thrust deviation error detection level
2508	2808	PS08	Linear function selection 3
2509	2809	PS09	Magnetic pole detection voltage level
2510	2810	PS10	At magnetic pole detection current detection method Identification signal frequency
2511	2811	PS11	At magnetic pole detection current detection method Identification signal amplitude
2512	2812	PS12	-
2513	2813	PS13	
2514	2814	PS14	
2515	2815	PS15	For manufacturer setting
2516	2816	PS16	
2517	2817	PS17	
2518	2818	PS18	

Error code		Parameter No.	Name
2519	2819	PS19	
2520	2820	PS20	
2521	2821	PS21	
2522	2822	PS22	
2523	2823	PS23	
2524	2824	PS24	For manufacturer setting
2525	2825	PS25	
2526	2826	PS26	
2527	2827	PS27	
2528	2828	PS28	
2529	2829	PS29	
2530	2830	PS30	
2531	2831	PS31	
2532	2832	PS32	

## (f) MR-J3-□B-RJ006 (For fully closed control)

Table 1.11 Servo error (2000 to 2999) list (MR-J3-□B-RJ006)

Error code	Servo amplifier LED display	Name	Remarks
2010	10	Undervoltage	
2012	12	Memory error 1 (RAM)	
2013	13	Clock error	
2015	15	Memory error 2 (EEP-ROM)	
2016	16	Encoder error 1 (At power on)	
2017	17	Board error	
2019	19	Memory error 3 (Flash ROM)	
2020	20	Encoder error 2 (During runtime)	
2021	21	Encoder error 3 (During runtime)	
2024	24	Main circuit error	
2028	28	Linear encoder error 2	
2030	30	Regenerative error	
2031	31	Overspeed	
2032	32	Overcurrent	
2033	33	Overvoltage	
2034	34	Receive error 1	
2035	35	Command frequency alarm	
2036	36	Receive error 2	
2042	42	Fully closed control error detection	
2045	45	Main circuit device overheat	
2046	46	Servo motor overheat	
2047	47	Cooling fan alarm	
2050	50	Overload 1	
2051	51	Overload 2	
2052	52	Error excessive	
2060	1A	Motor combination error	
2061	2A	Linear encoder error 1	
2070	70	Load side encoder error 1	
2071	71	Load side encoder error 2	
2088	888	Watchdog	
2106	96	Home position setting error	
2140	E0	Excessive regeneration warning	
2141	E1	Overload warning 1	
2146	E6	Servo forced stop warning	
2147	E7	Controller emergency stop warning	
2148	E8	Cooling fan speed reduction warning	
2149	E9	Main circuit off warning	
2152	EC	Overload warning 2	
2153	ED	Output watt excess warning	
2301 to 2599	E4	Parameter warning (Refer to the table 1.12)	
2601 to 2899	37	Parameter error (Refer to the table 1.12)	

Table 1.11 Servo error (2000 to 2999) list (MR-J3-□B-RJ006) (Continued)

Error code	Servo amplifier LED display	Name	Remarks
2948 <sup>(Note-1)</sup>	8A	USB communication time-out error	
2952 <sup>(Note-1)</sup>	8E	USB communication error	

(Note-1): Error codes will differ depending on the operating system software version.

	Error code  Operating system software version  "00F" or earlier "00G" or later		Name
2090	2948	8A	USB communication time-out error
2094	2952	8E	USB communication error

Table 1.12 Parameter warning (2301 to 2599)/Parameter error (2601 to 2899) error detail

Error	code	Parameter No.	Name	
2301	2601	PA01	Control mode	
2302	2602	PA02	Regenerative option	
2303	2603	PA03	Absolute position detection system	
2304	2604	PA04	Function selection A-1	
2305	2605	PA05		
2306	2606	PA06	For manufacturer setting	
2307	2607	PA07		
2308	2608	PA08	Auto tuning mode	
2309	2609	PA09	Auto tuning response	
2310	2610	PA10	In-position range	
2311	2611	PA11		
2312	2612	PA12	For manufacturer setting	
2313	2613	PA13		
2314	2614	PA14	Rotation direction selection	
2315	2615	PA15	Encoder output pulse	
2316	2616	PA16	Encoder output pulse 2	
2317	2617	PA17	For manufacturar acting	
2318	2618	PA18	For manufacturer setting	
2319	2619	PA19	Parameter write inhibit	
2320	2620	PB01	Adaptive tuning mode (adaptive filter II)	
2321	2621	PB02	Vibration suppression control tuning mode	
2021	2021	1 002	(advanced vibration suppression control)	
2322	2622	PB03	For manufacturer setting	
2323	2623	PB04	Feed forward gain	
2324	2624	PB05	For manufacturer setting	
2325	2625	PB06	Ratio of load inertia moment to servo motor inertia moment	
2326	2626	PB07	Model loop gain	
2327	2627	PB08	Position loop gain	
2328	2628	PB09	Speed loop gain	
2329	2629	PB10	Speed integral compensation	
2330	2630	PB11	Speed differential compensation	
2331	2631	PB12	Overshoot amount compensation	
2332	2632	PB13	Machine resonance suppression filter 1	
2333	2633	PB14	Notch shape selection 1	
2334	2634	PB15	Machine resonance suppression filter 2	
2335	2635	PB16	Notch shape selection 2	
2336	2636	PB17	Automatic setting parameter	
2337	2637	PB18	Low-pass filter setting	
2338	2638	PB19	Vibration suppression control vibration frequency setting	
2339	2639	PB20	Vibration suppression control resonance frequency setting	
2340	2640	PB21	For manufacturer setting	

Error code		Parameter No.	Name
2341	2641	PB22	For manufacturer setting
2342	2642	PB23	Low-pass filter selection
2343	2643	PB24	Slight vibration suppression control selection
2344	2644	PB25	For manufacturer setting
2345	2645	PB26	Gain changing selection
2346	2646	PB27	Gain changing condition
2347	2647	PB28	Gain changing time constant
2348	2648	PB29	Gain changing ratio of load inertia moment to servo motor inertia moment
2349	2649	PB30	Gain changing position loop gain
2350	2650	PB31	Gain changing speed loop gain
2351	2651	PB32	Gain changing speed integral compensation
2352	2652	PB33	Gain changing vibration suppression control vibration frequency setting
2353	2653	PB34	Gain changing vibration suppression control resonance frequency setting
2354	2654	PB35	
2355	2655	PB36	
2356	2656	PB37	
2357	2657	PB38	
2358	2658	PB39	
2359		PB40	For manufacturer setting
2360	2660	PB41	ű
2361	2661	PB42	
2362	2662	PB43	
2363	2663	PB44	
2364	2664	PB45	Vibration suppression control filter 2
2365	2665	PC01	Error excessive alarm level
2366	2666	PC02	Electromagnetic brake sequence output
2367	2667	PC03	Encoder output pulse selection
2368		PC04	Function selection C-1
2369	2669	PC05	Function selection C-2
2370	2670	PC06	Function selection C-3
2371	2671	PC07	Zero speed
2372	2672	PC08	For manufacturer setting
2373	2673	PC09	Analog monitor 1 output
2374	2674	PC10	Analog monitor 2 output
2375	2675	PC11	Analog monitor 1 offset
2376	2676	PC12	Analog monitor 2 offset
2377	2677	PC13	
2378	2678	PC14	For manufacturer setting
2379	2679	PC15	S. Coung
2380	2680	PC16	Function selection C-3A

Table 1.12 Parameter warning (2301 to 2599)/Parameter error (2601 to 2899) error detail (Continued)

Error	code	Parameter No.	Name
2381	2681	PC17	Function selection C-4
2382	2682	PC18	
2383	2683	PC19	For manufacturer setting
2384	2684	PC20	Function selection C-7
2385	2685	PC21	Alarm history clear
2386	2686	PC22	
2387	2687	PC23	
2388	2688	PC24	For manufacturer setting
2389	2689	PC25	
2390	2690	PC26	Function selection C-8
2391	2691	PC27	Function selection C-9
2392	2692	PC28	
2393	2693	PC29	
2394	2694	PC30	
2395	2695	PC31	
2396	2696	PC32	
2397	2697	PD01	For manufacturer setting
2398	2698	PD02	
2399	2699	PD03	
2400	2700	PD04	
2401	2701	PD05	
2402	2702	PD06	
2403	2703	PD07	Output signal device selection 1 (CN3-13)
2404	2704	PD08	Output signal device selection 2 (CN3-9)
2405	2705	PD09	Output signal device selection 3 (CN3-15)
2406	2706	PD10	For manufacturer setting
2407	2707	PD11	Input filter setting
2408	2708	PD12	For manufacturer setting
2409	2709	PD13	To mandadura soung
2410	2710	PD14	Function selection D-3
2411	2711	PD15	
2412	2712	PD16	
2413	2713	PD17	
2414	2714	PD18	
2415	2715	PD19	
2416	2716	PD20	
2417	2717	PD21	
2418	2718	PD22	For manufacturer setting
2419	2719	PD23	
2420	2720	PD24	
2421	2721	PD25	
2422	2722	PD26	
2423	2723	PD27	
2424	2724	PD28	

Error	code	Parameter No.	Name
2425	2725	PD29	
	2726	PD30	
	2727	PD31	For manufacturer setting
2428		PD31	
	2729	PE01	Fully closed loop solection 1
			Fully closed loop selection 1
	2730	PE02	For manufacturer setting
2431	2731	PE03	Fully closed loop selection 2 Fully closed loop feedback pulse
2432	2732	PE04	electronic 1 gear numerator
			Fully closed loop feedback pulse
2433	2733	PE05	electronic gear 1 denominator
			Fully closed loop control speed deviation
2434	2734	PE06	error detection level
			Fully closed loop control position deviation
2435	2735	PE07	error detection level
2436	2736	PE08	Fully closed loop dual feedback filter
2437		PE09	For manufacturer setting
	2738	PE10	Fully closed loop selection 3
	2739	PE11	Tally closed loop collection o
	2740	PE12	
	2741	PE13	
	2742	PE14	
2443		PE15	
2444		PE16	
2445		PE17	
	2746		For manufacturar actting
	2747	PE18	For manufacturer setting
	2748	PE19 PE20	
2449		PE21	
	2750	PE22	
2451		PE23	
2452		PE24	
2453		PE25	Filter coefficient 2.1
	2754	PE26	Filter coefficient 2-1 Filter coefficient 2-2
2455		PE27	Filter coefficient 2-3
	2756	PE28	
2457		PE29	Filter coefficient 2-4
2458		PE30	Filter coefficient 2-5
2459		PE31	Filter coefficient 2-6
2460	2760	PE32	Filter coefficient 2-7
2461	2761	PE33	Filter coefficient 2-8
2462	2762	PE34	Fully closed loop feedback pulse
			electronic gear 2 numerator
2463	2763	PE35	Fully closed loop feedback pulse electronic gear 2 denominator
2464	2764	PE36	
2465		PE37	
2466		PE38	For manufacturer setting
2467	2767	PE39	
2468	2768	PE40	
2-700	2,00	1 1 1 1 1	

#### (g) MR-J3-DB-RJ080W (For direct drive motor)

Table 1.13 Servo error (2000 to 2999) list (MR-J3-□B-RJ080W)

Error code	Servo amplifier LED display	Name	Remarks
2010	10	Undervoltage	
2012	12	Memory error 1 (RAM)	
2013	13	Clock error	
2015	15	Memory error 2 (EEP-ROM)	
2016	16	Encoder error 1	
2017	17	Board error	
2019	19	Memory error 3 (Flash ROM)	
2020	20	Encoder error 2	
2021	21	Encoder error 3	
2024	24	Main circuit error	
2025	25	Absolute position erase	
2027	27	Initial magnetic pole detection error	
2030	30	Regenerative error	
2031	31	Overspeed	
2032	32	Overcurrent	
2033	33	Overvoltage	
2034	34	Receive error 1	
2035	35	Command frequency alarm	
2036	36	Receive error 2	
2042	42	Servo control error	
2045	45	Main circuit device overheat	
2046	46	Direct drive motor overheat	
2047	47	Cooling fan alarm	
2050	50	Overload 1	
2051	51	Overload 2	
2052	52	Error excessive	
2060	1A	Motor combination error	
2064 <sup>(Note-1)</sup>	1F	Encoder combination error	
2088	888	Watchdog	
2102	92	Battery cable disconnection warning	
2106	96	Home position setting error	
2116	9F	Battery warning	
2140	E0	Excessive regeneration warning	
2141	E1	Overload warning 1	
2142	E2	Direct drive motor overheat warning	
2143	E3	Absolute position counter warning	
2146	E6	Servo forced stop warning	
2147	E7	Controller emergency stop warning	
2148	E8	Cooling fan speed reduction warning	
2149	E9	Main circuit off warning	
2152	EC	Overload warning 2	
2153	ED	Output watt excess warning	

(Note-1): Error codes will differ depending on the operating system software version.

Error Operating system "00F" or earlier	code software version "00G" or later	Servo amplifier LED display	Name
2025	2064	1F	Encoder combination error

Table 1.13 Servo error (2000 to 2999) list (MR-J3-□B-RJ080W) (Continued)

Error code	Servo amplifier LED display	Name	Remarks
2301 to 2599	E4	Parameter warning (Refer to the table 1.14)	
2601 to 2899	37	Parameter error (Refer to the table 1.14)	
2913 <sup>(Note-1)</sup>	2B	Encoder counter error	
2948 <sup>(Note-1)</sup>	8A	USB communication time-out error	
2952 <sup>(Note-1)</sup>	8E	USB communication error	

(Note-1): Error codes will differ depending on the operating system software version.

Error code Operating system software version		Servo amplifier	Name	
"00F" or earlier	"00G" or later	LED display		
2031	2913	2B	Encoder counter error	
2090	2948	8A	USB communication time-out error	
2094	2952	8E	USB communication error	

Table 1.14 Parameter warning (2301 to 2599)/Parameter error (2601 to 2899) error detail

Error	code	Parameter No.	Name	
2301	2601	PA01	For manufacturer setting	
2302	2602	PA02	Regenerative option	
2303	2603	PA03	Absolute position detection system	
2304	2604	PA04	Function selection A-1	
2305	2605	PA05		
2306	2606	PA06	For manufacturer setting	
2307	2607	PA07		
2308	2608	PA08	Auto tuning mode	
2309	2609	PA09	Auto tuning response	
2310	2610	PA10	In-position range	
2311	2611	PA11		
2312	2612	PA12	For manufacturer setting	
2313	2613	PA13		
2314	2614	PA14	Rotation direction selection	
2315	2615	PA15	Encoder output pulse	
2316	2616	PA16		
2317	2617	PA17	For manufacturer setting	
2318	2618	PA18		
2319	2619	PA19	Parameter write inhibit	
2320	2620	PB01	Adaptive tuning mode (adaptive filter II)	
2321	2621	PB02	Vibration suppression control tuning mode (advanced vibration suppression control)	
2322	2622	PB03	For manufacturer setting	
2323	2623	PB04	Feed forward gain	
2324	2624	PB05	For manufacturer setting	
2325	2625	PB06	Ratio of load inertia moment to direct drive motor inertia moment	
2326	2626	PB07	Model loop gain	
2327	2627	PB08	Position loop gain	
2328	2628	PB09	Speed loop gain	
2329	2629	PB10	Speed integral compensation	
2330	2630	PB11	Speed differential compensation	
2331	2631	PB12	For manufacturer setting	
2332	2632	PB13	Machine resonance suppression filter 1	
2333	2633	PB14	Notch shape selection 1	
2334	2634	PB15	Machine resonance suppression filter 2	
2335	2635	PB16	Notch shape selection 2	
2336	2636	PB17	Automatic setting parameter	
2337	2637	PB18	Low-pass filter setting	
2338	2638	PB19	Vibration suppression control vibration frequency setting	
2339	2639	PB20	Vibration suppression control resonance frequency setting	

Error	code	Parameter No.	Name
2340	2640	PB21	
2341	2641	PB22	For manufacturer setting
2342	2642	PB23	Low-pass filter selection
2342	2042	FDZ3	Slight vibration suppression control
2343	2643	PB24	selection
2344	2644	PB25	For manufacturer setting
2345	2645	PB26	Gain changing selection
2346	2646	PB27	Gain changing condition
2347	2647	PB28	Gain changing time constant
2348	2648	PB29	Gain changing ratio of load inertia moment to direct drive motor inertia moment
2349	2649	PB30	Gain changing position loop gain
2350	2650	PB31	Gain changing speed loop gain
2000	2000	1 201	Gain changing speed loop gain  Gain changing speed integral
2351	2651	PB32	compensation
			Gain changing vibration suppression
2352	2652	PB33	control vibration frequency setting
			Gain changing vibration suppression
2353	2653	PB34	control resonance frequency setting
2354	2654	PB35	control resonance responsy seaming
		PB36	
		PB37	
2357		PB38	
2358	2658	PB39	
2359	2659	PB40	For manufacturer setting
2360	2660	PB41	Tormanulacturer setting
2361	2661	PB42	
2362	2662	PB43	
2363	2663	PB44	
2364	2664	PB45	Vibration suppression control filter 2
2365	2665	PC01	Error excessive alarm level
2366	2666	PC02	Electromagnetic brake sequence output
2367	2667	PC03	Encoder output pulse selection
2368	2668	PC04	Function selection C-1
2369	2669	PC05	For manufacturer setting
2370	2670	PC06	Function selection C-3
2371	2671	PC07	Zero speed
2372	2672	PC08	For manufacturer setting
2373	2673	PC09	Analog monitor 1 output
2374	2674	PC10	Analog monitor 2 output
2375	2675	PC11	Analog monitor 1 offset
2376	2676	PC12	Analog monitor 2 offset
2377	2677	PC13	Analog monitor feedback position output standard data Low
2378	2678	PC14	Analog monitor feedback position output standard data High

Table 1.14 Parameter warning (2301 to 2599)/Parameter error (2601 to 2899) error detail (Continued)

_			3 (	_		`	/
Error	code	Parameter No.	Name	Err	or code	Parameter No.	Name
2379	2679	PC15		242	6 2726	PD30	
2380	2680	PC16		242	7 2727	PD31	
2381	2681	PC17	For manufacturer setting	242	8 2728	PD32	
2382	2682	PC18		242	9 2729	PE01	
2383	2683	PC19		243	0 2730	PE02	
2384	2684	PC20	Function selection C-7	243	1 2731	PE03	
2385	2685	PC21	Alarm history clear	243	2 2732	PE04	
	2686	PC22			3 2733		
2387	2687	PC23		243	4 2734	PE06	
2388	2688	PC24		243	5 2735	PE07	
2389	2689	PC25			6 2736		
2390	2690	PC26		243	7 2737	PE09	
2391	2691	PC27		243	8 2738	PE10	
2392	2692	PC28			9 2739		
2393	2693	PC29		244	0 2740	PE12	For manufacturer setting
	2694	PC30	For manufacturer setting	244	1 2741	PE13	
	2695	PC31	ğ		2 2742		
2396	2696	PC32		244	3 2743	PE15	
2397	2697	PD01			4 2744		
	2698	PD02			5 2745	1	
2399	2699	PD03			6 2746		
2400	2700	PD04		244	7 2747	PE19	
	2701	PD05		244	8 2748	PE20	
	2702	PD06			9 2749	1	
2403	2703	PD07	Output signal device selection 1 (CN3-13)	245	0 2750	PE22	
	2704	PD08	Output signal device selection 2 (CN3-9)		1 2751		
	2705	PD09	Output signal device selection 3 (CN3-15)		2 2752		
2406	2706	PD10	For manufacturer setting	245	3 2753	PE25	
2407	2707	PD11	Input filter setting	245	4 2754	PE26	Filter coefficient 2-1
2408	2708	PD12		245	5 2755	PE27	Filter coefficient 2-2
2409	2709	PD13	For manufacturer setting	245	6 2756	PE28	Filter coefficient 2-3
2410	2710	PD14	Function selection D-3	245	7 2757	PE29	Filter coefficient 2-4
2411	2711	PD15		245	8 2758	PE30	Filter coefficient 2-5
	2712			245	9 2759	PE31	Filter coefficient 2-6
2413	2713	PD17		246	0 2760	PE32	Filter coefficient 2-7
2414	2714	PD18		246	1 2761	PE33	Filter coefficient 2-8
2415	2715	PD19		246	2 2762	PE34	
2416	2716	PD20		246	3 2763	PE35	
2417	2717	PD21		246	4 2764	PE36	
	2718	PD22	For manufacturer setting	246	5 2765		For manufacturer setting
	2719	PD23		246	6 2766	PE38	
	2720	PD24			7 2767		
	2721	PD25			8 2768		
	2722	PD26			1 2801		Special function selection 1
	2723	PD27			2 2802		
	2724				3 2803		For manufacturer setting
	2725				4 2804		Special function selection 2
					_		

Table 1.14 Parameter warning (2301 to 2599)/Parameter error (2601 to 2899) error detail (Continued)

Error code		Parameter No.	Name
2505	2805	PS05	Servo control position deviation error detection level
2506	2806	PS06	Servo control speed deviation error detection level
2507	2807	PS07	Servo control torque deviation error detection level
2508	2808	PS08	Special function selection 3
2509	2809	PS09	Magnetic pole detection voltage level
2510	2810	PS10	
2511	2811	PS11	
2512	2812	PS12	
2513	2813	PS13	For manufacturer setting
2514	2814	PS14	
2515	2815	PS15	
2516	2816	PS16	
2517	2817	PS17	Minimal position detection method function selection
2518	2818	PS18	Minimal position detection method identification signal amplitude

Error	code	Parameter No.	Name
2519	2819	PS19	
2520	2820	PS20	
2521	2821	PS21	
2522	2822	PS22	
2523	2823	PS23	
2524	2824	PS24	
2525	2825	PS25	For manufacturer setting
2526	2826	PS26	
2527	2827	PS27	
2528	2828	PS28	
2529	2829	PS29	
2530	2830	PS30	
2531	2831	PS31	
2532	2832	PS32	

# (h) MR-J3-□B Safety (For safety servo)

Table 1.15 Servo error (2000 to 2999) list (MR-J3-□B Safety)

Error code	Servo amplifier LED display	Name	Remarks
2010	10	Undervoltage	
2012	12	Memory error 1 (RAM)	
2013	13	Clock error	
2015	15	Memory error 2 (EEP-ROM)	
2016	16	Encoder error 1 (At power on)	
2017	17	Board error	
2019	19	Memory error 3 (Flash ROM)	
2020	20	Encoder error 2 (during runtime)	
2021	21	Encoder error 3 (during runtime)	
2024	24	Main circuit error	
2025	25	Absolute position erase	
2028	28	Linear encoder error 2	
2030	30	Regenerative error	
2031	31	Overspeed	
2032	32	Overcurrent	
2033	33	Overvoltage	
2034	34	Receive error 1	
2035	35	Command frequency error	
2036	36	Receive error 2	
2042	42	Fully closed control error detection	
2045	45	Main circuit device overheat	
2046	46	Servo motor overheat	
2047	47	Cooling fan error	
2050	50	Overload 1	
2051	51	Overload 2	
2052	52	Error excessive	
2056	56	Forced stop error	
2070	70	Load side encoder error 1	
2071	71	Load side encoder error 2	
2060	1A	Motor combination error	
2061	2A	Linear encoder error 1	
2063	63	STO timing error	
2088	888	Watchdog	
2095	95	STO warning	
2102	92	Battery cable disconnection warning	
2106	96	Home position setting warning	
2116	9F	Battery warning	
2140	E0	Excessive regeneration warning	
2141	E1	Overload warning 1	
2143	E3	Absolute position counter warning	
2146	E6	Servo forced stop warning	
2147	E7	Controller forced stop warning	
2148	E8	Cooling fan speed reduction warning	
2149	E9	Main circuit off warning	
2152	EC	Overload warning 2	
2153	ED	Output watt excess warning	

Table 1.15 Servo error (2000 to 2999) list (MR-J3-□B Safety) (Continued)

Error code	Servo amplifier LED display	Name	Remarks
2301 to 2599	E4	Parameter warning (Refer to the table 1.16)	
2601 to 2899	37	Parameter error (Refer to the table 1.16)	
2948 <sup>(Note-1)</sup>	8A	USB communication time-out error	
2952 <sup>(Note-1)</sup>	8E	USB communication error	

(Note-1): Error codes will differ depending on the operating system software version.

	code n software version	Servo amplifier	Name	
"00F" or earlier	"00G" or later	LED display		
2090	2948	8A	USB communication time-out error	
2094	2952	8E	USB communication error	

Table 1.16 Parameter warning (2301 to 2599)/Parameter error (2601 to 2899) error detail

		Parameter	To Parameter warning (2501 to 25s	
Error	code	No.	Name	
2301	2601	PA01	Control mode	
2302	2602	PA02	Regenerative option	
2303	2603	PA03	Absolute position detection system	
2304	2604	PA04	Function selection A-1	
2305	2605	PA05		
2306	2606	PA06	For manufacturer setting	
2307	2607	PA07		
2308	2608	PA08	Auto tuning mode	
2309	2609	PA09	Auto tuning response	
2310	2610	PA10	In-position range	
2311	2611	PA11		
2312	2612	PA12	For manufacturer setting	
2313	2613	PA13		
2314	2614	PA14	Rotation direction selection	
2315	2615	PA15	Encoder output pulse	
2316	2616	PA16	Encoder output pulse 2	
2317	2617	PA17		
2318	2618	PA18	For manufacturer setting	
2319	2619	PA19	Parameter write inhibit	
2320	2620	PB01	Adaptive tuning mode (adaptive filter II)	
2321	2621	PB02	Vibration suppression control tuning mode (advanced vibration suppression control)	
2322	2622	PB03	For manufacturer setting	
2323	2623	PB04	Feed forward gain	
2324	2624	PB05	For manufacturer setting	
2325	2625	PB06	Ratio of load inertia moment to servo motor inertia moment	
2326	2626	PB07	Model loop gain	
2327	2627	PB08	Position loop gain	
2328	2628	PB09	Speed loop gain	
2329	2629	PB10	Speed integral compensation	
2330	2630	PB11	Speed differential compensation	
2331	2631	PB12	Overshoot amount compensation	
2332	2632	PB13	Machine resonance suppression filter 1	
2333	2633	PB14	Notch shape selection 1	
2334	2634	PB15	Machine resonance suppression filter 2	
2335	2635	PB16	Notch shape selection 2	
2336	2636	PB17	Automatic setting parameter	
2337	2637	PB18	Low-pass filter setting	
2338	2638	PB19	Vibration suppression control vibration frequency setting	
2339	2639	PB20	Vibration suppression control resonance frequency setting	

Error	code	Parameter No.	Name
2340	2640	PB21	
2341	2641	PB22	For manufacturer setting
2342	2642	PB23	Low-pass filter selection
			Slight vibration suppression control
2343	2643	PB24	selection
2344	2644	PB25	For manufacturer setting
2345	2645	PB26	Gain changing selection
2346	2646	PB27	Gain changing condition
2347	2647	PB28	Gain changing time constant
2348	2648	PB29	Gain changing ratio of load inertia moment
2040	2040	1 029	to servo motor inertia moment
2349	2649	PB30	Gain changing position loop gain
2350	2650	PB31	Gain changing speed loop gain
2351	2651	PB32	Gain changing speed integral
2001	2001	1 032	compensation
2352	2652	PB33	Gain changing vibration suppression
_552	2002	. 500	control vibration frequency setting
2353	2653	PB34	Gain changing vibration suppression
2000	2000		control resonance frequency setting
2354	2654	PB35	
2355	2655	PB36	
2356	2656	PB37	
2357	2657	PB38	
2358	2658	PB39	
2359	2659	PB40	For manufacturer setting
2360	2660	PB41	
2361	2661	PB42	
2362	2662	PB43	
2363	2663	PB44	
2364	2664	PB45	Vibration suppression control filter 2
2365	2665	PC01	Error excessive alarm level
2366	2666	PC02	Electromagnetic brake sequence output
2367	2667	PC03	Encoder output pulse selection
2368	2668	PC04	Function selection C-1
2369	2669	PC05	Function selection C-2
2370	2670	PC06	Function selection C-3
2371	2671	PC07	Zero speed
2372	2672	PC08	For manufacturer setting
2373	2673	PC09	Analog monitor 1 output
2374	2674	PC10	Analog monitor 2 output
2375	2675	PC11	Analog monitor 1 offset
2376	2676	PC12	Analog monitor 2 offset
2377	2677	PC13	Analog monitor feedback position output standard data Low
2378	2678	PC14	Analog monitor feedback position output standard data High

Table 1.16 Parameter warning (2301 to 2599)/Parameter error (2601 to 2899) error detail (Continued)

Error	code	Parameter No.	Name	
2379	2679	PC15	For manufacturer setting	
2380	2680	PC16	Function selection C-3A	
2381	2681	PC17	Function selection C-4	
2382	2682	PC18		
2383	2683	PC19	For manufacturer setting	
2384	2684	PC20	Function selection C-7	
2385	2685	PC21	Alarm history clear	
2386	2686	PC22	For manufacturer actting	
2387	2687	PC23	For manufacturer setting	
2388	2688	PC24	Forced stop deceleration time constant	
2389	2689	PC25	For manufacturer setting	
2390	2690	PC26	Function selection C-8	
2391	2691	PC27	Function selection C-9	
2392	2692	PC28		
2393	2693	PC29	For manufacturer setting	
2394	2694	PC30		
2395	2695	PC31	Vertical axis freefall prevention compensation amount	
2396	2696	PC32	,	
2397	2697	PD01		
2398	2698	PD02		
2399	2699	PD03	For manufacturer setting	
2400	2700	PD04	-	
2401	2701	PD05		
2402	2702	PD06		
2403	2703	PD07	Output signal device selection 1 (CN3-13)	
2404	2704	PD08	Output signal device selection 2 (CN3-9)	
2405	2705	PD09	Output signal device selection 3 (CN3-15)	
2406	2706	PD10	For manufacturer setting	
2407	2707	PD11	Input filter setting	
2408	2708	PD12	For monufacture	
2409	2709	PD13	For manufacturer setting	
2410	2710	PD14	Function selection D-3	
2411	2711	PD15		
2412	2712	PD16		
2413	2713	PD17		
2414	2714	PD18		
2415	2715	PD19		
2416	2716	PD20	For manufacturer setting	
2417	2717	PD21	_	
2418	2718	PD22		
2419	2719	PD23		
2420	2720	PD24		

Error	code	Parameter No.	Name
2421	2721	PD25	
2422	2722	PD26	
2423	2723	PD27	
2424	2724	PD28	
	2725	PD29	For manufacturer setting
2426	2726	PD30	
2427	2727	PD31	
2428	2728	PD32	
2429	2729	PE01	Fully closed loop selection 1
2430	2730	PE02	For manufacturer setting
2431	2731	PE03	Fully closed loop selection 2
0400	0700	DE04	Fully closed loop feedback pulse
2432	2732	PE04	electronic gear 1 numerator
2422	2722	DEOS	Fully closed loop feedback pulse
2433	2733	PE05	electronic gear 1 denominator
2434	2734	PE06	Fully closed loop speed deviation error
2434	2134	PEUU	detection level
2435	2735	PE07	Fully closed loop position deviation error
2400	2100	1 L07	detection level
2436	2736	PE08	Fully closed loop dual feedback filter
2437	2737	PE09	For manufacturer setting
2438	2738	PE10	Fully closed loop selection 3
2439	2739	PE11	
2440	2740	PE12	
2441	2741	PE13	
2442	2742	PE14	
2443	2743	PE15	
2444	2744	PE16	
2445	2745	PE17	
2446	2746	PE18	For manufacturer setting
2447	2747	PE19	
2448	2748	PE20	
2449	2749	PE21	
2450	2750	PE22	
2451	2751	PE23	
2452	2752	PE24	
2453	2753	PE25	
2454	2754	PE26	Filter coefficient 2-1
2455	2755	PE27	Filter coefficient 2-2
2456	2756	PE28	Filter coefficient 2-3
2457	2757	PE29	Filter coefficient 2-4
2458	2758	PE30	Filter coefficient 2-5
2459	2759	PE31	Filter coefficient 2-6
2460	2760	PE32	Filter coefficient 2-7
2461	2761	PE33	Filter coefficient 2-8
2460	2762	DE34	Fully closed loop feedback pulse
2462	2762	PE34	electronic gear 2 numerator

Table 1.16 Parameter warning (2301 to 2599)/Parameter error (2601 to 2899) error detail (Continued)

Error	code	Parameter No.	Name			
2463	2763	PE35	Fully closed loop feedback pulse electronic gear 2 denominator			
2464	2764	PE36				
2465	2765	PE37	For manufacturer setting			

Error code		Parameter No.	Name
2466	2766	PE38	
2467	2767	PE39	For manufacturer setting
2468	2768	PE40	

# (i) MR-JE-□B(F)

Table 1.17 Servo error (2000 to 2999) list (MR-JE-□B(F))

Error code	Servo amplifier LED display	Name	Details name	Remarks
0040	10.1		Voltage drop in the power	
2010	10.2	Undervoltage	Bus voltage drop	
	12.1		RAM error 1	
	12.2		RAM error 2	
	12.3	]	RAM error 3	
2012	12.4	Memory error 1 (RAM)	RAM error 4	
	12.5		RAM error 5	
	12.6		RAM error 6	
	13.1	<del>-</del>	Clock error 1	
2013	13.2		Clock error 2	
	13.3		Clock error 3	
	14.1		Control process error 1	
	14.2		Control process error 2	
	14.3		Control process error 3	
	14.4		Control process error 4	
	14.5		Control process error 5	
	14.6	1	Control process error 6	
2014	14.7	Control process error	Control process error 7	
	14.8		Control process error 8	
	14.9		Control process error 9	
	14.A		Control process error 10	
	14.C		Control process error 12	
	14.D		Control process error 13	
	15.1		EEP-ROM error at power on	
2015	15.2	Memory error 2	EEP-ROM error during operation	
	15.4	(EEP-ROM)	Home position information read error	
	16.1		Encoder initial communication - Receive data error 1	
	16.2		Encoder initial communication - Receive data error 2	
	16.3		Encoder initial communication - Receive data error 3	
			Encoder initial communication - Transmission data error	
	16.5		1	
	16.6		Encoder initial communication - Transmission data error 2	
2016	16.7	Encoder initial communication error 1	Encoder initial communication - Transmission data error 3	
	16.A		Encoder initial communication - Process error 1	
	16.B		Encoder initial communication - Process error 2	
	16.C		Encoder initial communication - Process error 3	
	16.D		Encoder initial communication - Process error 4	
	16.E		Encoder initial communication - Process error 5	
	16.F		Encoder initial communication - Process error 6	
	17.1		Board error 1	
	17.3		Board error 2	
	17.4	1	Board error 3	
2017	17.5	Board error	Board error 4	
	17.6	1	Board error 5	
	17.7	1	Board error 7	

Table 1.17 Servo error (2000 to 2999) list (MR-JE-□B(F)) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
	19.1		Flash-ROM error 1	
0040	19.2	Memory error 3	Flash-ROM error 2	
2019	19.4	(Flash-ROM)	Flash-ROM error 4	
	19.5		Flash-ROM error 5	
	20.1		Encoder normal communication - Receive data error 1	
	20.2		Encoder normal communication - Receive data error 2	
	20.3		Encoder normal communication - Receive data error 3	
	20.5		Encoder normal communication - Transmission data error 1	
2020	20.6	Encoder normal communication error 1	Encoder normal communication - Transmission data error 2	
	20.7		Encoder normal communication - Transmission data error 3	
	20.9		Encoder normal communication - Receive data error 4	
	20.A		Encoder normal communication - Receive data error 5	
	21.1		Encoder data error 1	
	21.2		Encoder data update error	
	21.3	Encoder normal	Encoder data waveform error	
2021	21.5	communication error 2	Encoder hardware error 1	
	21.6	1	Encoder hardware error 2	
	21.9	1	Encoder data error 2	
	24.1		Ground fault detected at hardware detection circuit	
2024	24.2	Main circuit error	Ground fault detected at software detection function	
2025	25.1	Absolute position erased	Servo motor encoder - Absolute position erased	
	30.1		Regeneration heat error	
2030	30.2	Regenerative error	Regeneration signal error	
	30.3		Regeneration feedback signal error	
2031	31.1	Overspeed	Abnormal motor speed	
	32.1		Overcurrent detected at hardware detection circuit (during operation)	
	32.2		Overcurrent detected at software detection function (during operation)	
2032	32.3	Overcurrent	Overcurrent detected at hardware detection circuit (during a stop)	
	32.4		Overcurrent detected at software detection function (during a stop)	
2033	33.1	Overvoltage	Main circuit voltage error	
	34.1		SSCNET receive data error	
	34.2	SSCNET receive error	SSCNET connector connection error	
2034	34.3	1	SSCNET communication data error	
	34.4	1	Hardware error signal detection	
2035	35.1	Command frequency error	Command frequency error	
2036	36.1	SSCNET receive error	Continuous communication data error	
	37.1		Parameter setting range error	
2037 <sup>(Note-1)</sup>	37.2	Parameter error	Parameter combination error	
2031 ( ')	37.3	1	Point table setting error	

(Note-1): Refer to the parameter No. stored in parameter error No. (#8009+20n) for details of the parameter for which the error occurred.

Table 1.17 Servo error (2000 to 2999) list (MR-JE-□B(F)) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
	39.1		Program error	
	39.2	]_	Instruction argument external error	
2039	39.3	Program error	Register No. error	
	39.4		Non-correspondence command error	
2045	45.1	Main circuit device overheat	Main circuit device overheat error 1	
	46.1		Abnormal temperature of servo motor 1	
2046	46.5	Servo motor overheat	Abnormal temperature of servo motor 3	
	46.6		Abnormal temperature of servo motor 4	
2047	47.2	Cooling fan error	Cooling fan speed reduction error	
	50.1		Thermal overload error 1 during operation	
	50.2		Thermal overload error 2 during operation	
	50.3		Thermal overload error 4 during operation	
2050	50.4	Overload 1	Thermal overload error 1 during a stop	
	50.5	-		
ŀ	50.5	†	Thermal overload error 2 during a stop	
			Thermal overload error 4 during a stop	
2051	51.1	Overload 2	Thermal overload error 3 during operation	
	51.2		Thermal overload error 3 during a stop	
	52.1		Excess droop pulse 1	
2052	52.3	Error excessive	Excess droop pulse 2	
	52.4	- Chief Gradesive	Error excessive during 0 torque limit	
	52.5		Excess droop pulse 3	
2054	54.1	Oscillation detection	Oscillation detection error	
2050	56.2		Over speed during forced stop	
2056	56.3	Forced stop error	Estimated distance over during forced stop	
0000	1A.1	Servo motor	Servo motor combination error 1	
2060	1A.4	combination error	Servo motor combination error 2	
2061	61.1	Operation error	Point table setting range error	
	63.1	•	STO1 off	
	63.2	STO timing error	STO2 off	
2063	63.5	]	STO by functional safety unit	
2000	1E.1	Encoder initial communication error 2	Encoder malfunction	
2064	1F.1	Encoder initial communication error 3	Incompatible encoder	
	69.1		Forward rotation-side software limit detection - Command excess error	
	69.2		Reverse rotation-side software limit detection - Command excess error	
2069	69.3	Command error	Forward rotation stroke end detection - Command excess error	
	69.4	-	Reverse rotation stroke end detection - Command	
	86.1		Network communication error 1	
2086	86.4	Network	Network communication error 4	
2000		communication error		
2000	86.5	Mataba = =	Network communication error 5	
2088	888	Watchdog	Watchdog	
0000	90.1	Home position return	Home position return incomplete	
2090	90.2	incomplete warning	Home position return abnormal termination	

Table 1.17 Servo error (2000 to 2999) list (MR-JE-□B(F)) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
2005	95.1	CTO	STO1 off detection	
2095	95.2	STO warning	STO2 off detection	
2097	97.1	Positioning specification warning	Program operation disabled warning	
0000	98.1		Forward rotation-side software stroke limit reached	
2098	98.2	Software limit warning	Reverse rotation-side software stroke limit reached	
	99.1		Forward rotation stroke end off	
2099	99.2	Stroke limit warning	Reverse rotation stroke end off	
2101	91.1	Servo amplifier overheat warning	Main circuit device overheat warning	
0400	92.1	Battery cable	Encoder battery cable disconnection warning	
2102	92.3	disconnection warning	Battery degradation	
	96.1		In-position warning at home positioning	
2106	96.2	Home position setting	Command input warning at home positioning	
	96.3	warning	Servo off warning at home positioning	
2116	9F.1	Battery warning	Low battery	
2140	E0.1	Excessive regeneration warning	Excessive regeneration warning	
	E1.1	_	Thermal overload warning 1 during operation	
	E1.2	<u></u>	Thermal overload warning 2 during operation	
	E1.3	_	Thermal overload warning 3 during operation	
2444	E1.4	Occarda a di compilia a d	Thermal overload warning 4 during operation	
2141	E1.5	Overload warning 1	Thermal overload warning 1 during a stop	
	E1.6		Thermal overload warning 2 during a stop	
	E1.7		Thermal overload warning 3 during a stop	
	E1.8		Thermal overload warning 4 during a stop	
	E3.1		Multi-revolution counter travel distance excess warning	
	E3.2	],,	Absolute position counter warning	
2143	E3.4	Absolute position counter warning	Absolute positioning counter EEPROM writing frequency warning	
	E3.5		Encoder absolute positioning counter warning	
2144 <sup>(Note-1)</sup>	E4.1	Parameter warning	Parameter setting range error warning	
2146	E6.1	Servo forced stop warning	Forced stop warning	
2147	E7.1	Controller forced stop warning	Controller forced stop input warning	
2148	E8.1	Cooling fan speed reduction warning	Decreased cooling fan speed warning	
	E9.1		Servo-on signal on during main circuit off	
2149	E9.2	Main circuit off	Bus voltage drop during low speed operation	
	E9.3	warning	Ready-on signal on during main circuit off	
2152	EC.1	Overload warning 2	Overload warning 2	
2153	ED.1	Output watt excess warning	Output watt excess warning	
	F0.1	_	Instantaneous power failure tough drive warning	
2160	F0.3	Tough drive warning	Vibration tough drive warning	
	F2.1	Drive recorder -	Drive recorder - Area writing timeout warning	
2162	F2.2	Miswriting warning	Drive recorder - Data miswriting warning	

(Note-1): Refer to the parameter No. stored in parameter error No. (#8009+20n) for details of the parameter for which the error occurred.

Table 1.17 Servo error (2000 to 2999) list (MR-JE-□B(F)) (Continued)

Error code	Servo amplifier LED display	Name	Details name	Remarks
2163	F3.1	Oscillation detection warning	Oscillation detection warning	
	F4.4		Target position setting range error warning	
0404	F4.6	D 141 1	Acceleration time constant setting range error warning	
2164	F4.7	Positioning warning	Deceleration time constant setting range error warning	
	F4.8		Control command input error warning	
	F5.1	Simple cam function	Cam data - Area writing time-out warning	
2165	F5.2	Cam data miswriting	Cam data - Area miswriting warning	
	F5.3	warning	Cam data checksum error	
	F6.1		Cam axis one cycle current value restoration failed	
	F6.2		Cam axis feed current value restoration failed	
0.400	F6.3	Simple cam function -	Cam unregistered error	
2166	F6.4	Cam control warning	Cam control data setting range error	
	F6.5	]	Cam No. external error	
	F6.6		Cam control inactive	
2918	3A.1	Inrush current suppression circuit error	Inrush current suppression circuit error	
2222	3E.1		Operation mode error	
2922	3E.6	Operation mode error	Operation mode switch error	
	8A.1	USB communication time-out error/serial	USB communication time-out error/serial communication timeout error	
2948	8A.2	communication timeout error/Modbus RTU communication timeout error	Modbus RTU communication timeout error	
	8C.1		Network module communication error 1	
	8C.2		Network module communication error 2	
	8C.3	]	Network module communication error 3	
2950	8C.4	Network module	Network module communication error 4	
	8C.5	communication error	Network module communication error 5	
	8C.6		Network module communication error 6	
	8C.7		Network module communication error 7	
			USB communication receive error/serial communication	
	8E.1		receive error	
	05.0		USB communication checksum error/serial	
	8E.2		communication checksum error	
	05.0	USB communication	USB communication character error/serial	
	8E.3	error/serial	communication character error	
2952	05.4	communication	USB communication command error/serial	
	8E.4	error/Modbus RTU	communication command error	
	8E.5	communication error	USB communication data number error/serial communication data number error	
	8E.6	1	Modbus RTU communication receive error	
	8E.7	1	Modbus RTU communication message frame error	
	8E.8	1	Modbus RTU communication CRC error	
	9B.1		Excess droop pulse 1 warning	
2955	9B.3	Error excessive	Excess droop pulse 1 warning  Excess droop pulse 2 warning	
2000	9B.3 9B.4	warning	Error excessive warning during 0 torque limit	

# APPENDIX 1.6 Output module errors

# (1) Output module errors at real mode/virtual mode switching (4000 to 5990)

Table 1.18 Output Module Error List (4000 to 5990)

			Output	module				
Error	Error		Ball	Rotary	Cc	Error cause	Processing	Corrective action
class	code	Roller	screw	table	Cam			
	4050				0	The "lower stroke limit setting device value + stroke amount setting device value" exceeded "2147483647 (setting unit)".  (At the two-way cam mode.)		Since the current value within 1 cam shaft revolution cannot be calculated, return to the real mode and set the correct No. in the device.
	4060	0	0	0	0	When the drive module is the synchronous encoder connected to the manual pulse generator inputs, and the connected clutch is the "external input mode", multiple ON/OFF command bit devices are set. Or, the external input mode clutch setting is fault.		Set a one-to-one setting for the external input mode clutch and synchronous encoder.     Return to the real mode, turn the PLC ready flag off, then correct and write the clutch setting.
	4070	0	0	0	0	The clutch of the external input mode is set at the Q173DPX or Q172DEX set for high-speed reading.		Do not use the clutch of the external input mode at the Q173DPX or Q172DEX set for high-speed reading.
Minor error	5000		0	0	0	The "feed current value" is outside the stroke limit range. For cam, the feed current value is outside the range of "lower stroke limit value to stroke amount", when the cam/ball screw switching command device is turned ON to OFF at real/virtual mode switching or in virtual mode. (The current value within 1 cam shaft revolution cannot be calculated at the two-way cam mode.) For cam, the feed current value is outside the range of "lower stroke limit value to stroke amount" at the servo amplifier's power supply ON. (In this case, the servo amplifier does not change into servo ON status.)	Related system cannot be started.	Return to the real mode and position within the stroke limit range.
	5060				0	The "feed current value" is within the stroke limit range, but the current value within 1 cam shaft revolution cannot be calculated. (Cam table fault)		Correct the cam table.  Set the cam table by the stroke ratio "0 to 7FFFH" of lower stroke value and stroke amount.
	5080	0	0	0	0	Torque limit value setting outside range error.	Control with the default value "300[%]".	Set the torque limit value within the setting range.
	5200				0	The first lower stroke limit value storage device is an odd number.	Operation is possible, but monitoring is impossible.	Set an even numbered the first device.
	5210	0	0	0	0	The first clutch ON address setting device is an odd number.	Related system cannot be started.	

Table 1.18 Output Module Error List (4000 to 5990) (Continued)

			Output	module		<u> </u>	, ,	,
Error	Error		Ball	Rotary		Error cause	Processing	Corrective action
class	code	Roller	screw	table	Cam	Lifoi cause	1 Tocessing	Corrective action
	5220	0	O	O	0	The first clutch OFF address setting device is an odd number.	Related system cannot be started.	Set an even numbered the first device.
	5230			0	0	The first current value within 1 virtual axis revolution storage device (main shaft side) is an odd number.  The first current value within 1 virtual.	Operation is possible, but	
	5240			0	0	The first current value within 1 virtual axis revolution storage device (auxiliary input shaft side) is an odd number.	monitoring is impossible.	
	5250	0	0	0	0	When the amount of slip is set as the clutch smoothing method, the amount of slip setting device value is outside the range (0 to 2147483647).	Amount of slip = 0 (control as the direct clutch).	• Set a value within the range of 0 to 2147483647.
	5260				0	The device set to "Stroke amount		Correct the device set to
	5270				0	setting device" is outside the range.     The device set to "Cam No. setting device" is outside the range.		"Stroke amount setting device".  • Correct the device set to Cam  No.
	5280	0	0	0	0	The device set to "Clutch mode setting device" is outside the range.		Correct the device set to clutch mode.
	5290	0	0	0	0		Related system cannot be	Correct the device set to clutch     ON address.
	5300	0	0	0	0	The device set to "Clutch OFF address setting device" is outside the range.	started.	Correct the device set to clutch     OFF address.
Minor	5310	0	0	0	0	The device set to "Clutch ON/OFF command setting device" is outside the range.		Correct the device set to clutch ON/OFF command.
error	5320	0	0	0	0	The device set to "Speed change ratio setting device" is outside the range.		Correct the device set to speed change ratio.
	5330	0	0	0	0	The device set to "Amount of slip setting device" is outside the range.	Amount of slip = 0 (control as the direct clutch).	Correct the device set to amount of slip.
	5340	0	0	0	0	The device set to "Torque limit value setting device" is outside the range.	Related system cannot be started	Correct the device set to torque limit value.
	5350			0	0		Current value within 1 virtual axis revolution (main shaft side) cannot be monitored.	Correct the device set to current value within 1 virtual axis revolution (main shaft side).
	5360			0	0	The device set to "Current value within 1 virtual axis revolution storage device (auxiliary input axis side) storage device" is outside the range.	Current value within 1 virtual axis revolution (auxiliary input axis side) cannot be monitored.	Correct the device set to current value within 1 virtual axis revolution (auxiliary input axis side).
	5370				0	The device set to "Lower stroke limit value storage device" is outside the range.	Lower stroke limit value cannot be monitored.	Correct the device set to lower stroke limit value.
	5380	0	0	0	0	The device set to "Number of input axis side gear tooth count setting device" is outside the range.	Related system cannot be started.	Correct the device set to number of input axis side gear tooth count.

Table 1.18 Output Module Error List (4000 to 5990) (Continued)

			Output	module				
Error	Error	- ·	Ball	Rotary	_	Error cause	Processing	Corrective action
class	code	Roller	screw	table	Cam			
						The device set to "Number of output		Correct the device set to
	5390	0	0	0	0	axis side gear tooth count setting		number of output axis side gear
						device" is outside the range.		tooth count.
	5400	0	0	0	0	Number of input axis side gear tooth	Related system	Correct the number of input axis
	0.00					count setting device is set to "0".	cannot be	side gear tooth count.
	5410	0	0	0	0	<ul> <li>Number of output axis side gear tooth count setting device is set to "0".</li> </ul>	started.	Correct the number of output axis side gear tooth count.
						The device set to "Slippage in-position		Correct the device set to
	5420	0	0	0	0	range setting device" is outside the		slippage in-position range
						range.		setting device.
						Slippage in-position range setting	Control with the	
	5430	0	0	0	0	device is outside the range (0 to	setting value "0".	
						2147483647).	county range or	
						• Either of "phase advance time" of	Control as the	Correct the phase advance
						"phase compensation processing valid flag" or "phase compensation time	phase	time. • Correct the phase
	5440	0	0	0	0	constant" of the phase compensation	compensation	compensation processing valid
	0110					setting devices is outside the setting	processing	flag.
						range.	invalid.	Correct the phase
								compensation time constant.
						The device set to "Smoothing clutch		Correct the device set to
	5450	0	0	0	0	complete signal device" is outside the		"Smoothing clutch complete
Minor						range.  • The device set to "Clutch status		signal device".  • Correct the device set to "Clutch
error	5460	0	0	0	0	device" is outside the range.		status device".
on or						The device set to "Cam/ball screw		Correct the device set to
	5480				0	switching command device" is outside		"Cam/ball screw switching
						the range.		command device".
						When the address mode clutch control		Correct the setting value set to
						system is the current value within 1		"Clutch ON address setting
	5490			0	0	virtual axis revolution, the setting value set to "Clutch ON address setting		device" with in the range of "0 to
	5490			0		device" is outside the range of "0 to		number of pulses within 1
						number of pulses within 1 output axis	Related system	output axis revolution –
						revolution –1[pulse]".	cannot be started.	1[pulse]".
						When the address mode clutch control	Starteu.	Correct the setting value set to
						system is the current value within 1		"Clutch OFF address setting
						virtual axis revolution, the setting value		device" with in the range of "0 to
	5500			0	0	set to "Clutch OFF address setting		number of pulses within 1
						device" is outside the range of "0 to number of pulses within 1 output axis		output axis revolution –
						revolution –1[pulse]".		1[pulse]".
						The device set to "Number of pulses	1	Correct the device set to
	5510				0	per cam shaft revolution" is outside the		"Number of pulses per cam
						range.		shaft revolution".
	-					The value of "Number of pulses per		Correct the setting of "Number
	5520				0	cam shaft revolution" is outside the		of pulses per cam shaft
						range.		revolution".

# (2) Output module errors (6000 to 6990)

Table 1.19 Output Module Error List (6000 to 6990)

	_		Output	module				
Error class	Error code	Roller	Ball screw	Rotary table	Cam	Error cause	Processing	Corrective action
	6000	0	0	0	0	<ul> <li>The servo OFF command (M3215+20n) turned ON during operation.</li> <li>The servo amplifier's power supply is turned ON during operation.</li> </ul>		Execute the servo OFF after clutch OFF command.
	6010	0	0	0		The output speed exceeded the speed limit value during operation. (Speed clamp processing by the speed limit value is not executed.)		Correct the speed, gear ratio and speed change ratio of drive module within the speed limit value.
	6020	0	0	0	0	The deviation counter value exceeded the permissible droop pulse value during operation.	Operation continues.	<ul> <li>Correct the speed, gear ratio and speed change ratio of drive module within the permissible droop pulse value after stopping the drive module.</li> </ul>
	6030		0	0		The feed current value exceeded the stroke limit range during operation.		Control within the stroke limit value.
	6040				0	The cam No. setting device value is outside the "used cam No." range.  (Operation continues with the current cam No.)		Correct the cam No. setting.
Minor error	6050				0	The stroke amount setting device value is outside the range of "1 to 2147483647".  "Lower stroke limit value + stroke amount ≤ 2147483647" is outside the range. (Operation continues with the current stroke amount.)	Operation continues with the current cam No. and stroke amount.	Correct the stroke amount setting.
	6060				0	A control mode (feed/two-way) does not match at cam No. switching.	Operation continues.	Correct the control mode after stopping the drive module.
	6080	0	0	0	0	The torque limit value setting device is outside the range.	Control with the default value "300[%]".	Set the torque limit value within the setting range.
	6090	0	0	0	0	<ul> <li>The servo OFF command (M3215+20n) turned on at servo OFF in operation.</li> <li>The servo ON is executed by turning ON the servo amplifier's power supply in operation.</li> </ul>	Servo ON is not executed.	Execute the servo ON after clutch OFF command.
	6120				0	The current value within 1 cam axis revolution was changed to the outside the range.	The current value is not changed.	<ul> <li>Set a value within the range of 1 to "number of pulses 1 cam shaft revolution – 1".</li> </ul>
	6130	0	0	0	0	Number of input axis side gear tooth count is set by indirect device setting, and the current value for the drive module was changed to the device value "0".	The gear ratio of applicable gear	• Set the value within the range of 1 to 65535.
	6140	0	0	0	0	Number of output axis side gear tooth count is set by indirect device setting, and the current value for the drive module was changed to the device value "0".	is not changed.	

Table 1.19 Output Module Error List (6000 to 6990) (Continued)

_	_			module	<u> </u>	The module Life List (0000	, ,	,
Error	Error code	Roller	Ball screw	Rotary table	Cam	Error cause	Processing	Corrective action
	6160				0	Current value was changed for the axis that had not been started. Or, the current value within 1 cam shaft revolution was changed for the servo OFF axis. The current value within 1 cam shaft revolution was changed during cam/ball screw switching processing.	Do not change the current value within 1 cam shaft revolution.	Use the following device as interlock not to change the current value within 1 cam shaft revolution for applicable axis. (Servo READY signal (M2415+20) ON) Do not change the current value within 1 cam shaft revolution during cam/ball screw switching or cam/ball screw switching command ON.
	6170	0	0	0	0	Slippage in-position range setting device value is outside the range (0 to 2147483647).	Control with the setting value "0".	Set the device value within the range of 0 to 2147483647.
	6180	0	0	0		One of the devices set in the speed- torque control operation data is outside the range.		Correct the speed-torque control operation data device.
	6190	0	0	The control mode switching was executed with an invalid value specified in the control mode setting device.  Operation continues:	Operation continues without switching	Correct the value of the control mode setting device.     When switching the mode from the continuous operation to torque control mode to another, return the mode to the previous one.		
Minor error	6200	0	0	0		The control mode switching request was executed during the zero speed was OFF.	the control mode.	Switch the control mode while the output axis is stopped and the zero speed is turned on.     Make "Invalid selection during zero speed at control mode switching" valid when not waiting for the stop of the servo motor.
	6210	0	0	0		At the control mode switching, a value set to the torque limit value at speed- torque control is outside the range.	Control with the default value "300[%]".	• Set the torque limit value to 0.1 to 1000.0[%].
	6220	0	0	0		During torque control or continuous operation to torque control, the absolute value of the command torque is outside the range of 0 to the torque limit value at speed-torque control.	Control with the torque limit value at speed-torque control.	Set the torque after torque change within the range of 0 to the torque limit value at speed- torque control.
	6230	0	0	0		The control mode switching request of speed/torque control was executed for the axis that connects to the stepping driver which do not support the control mode switching.	The control mode is not switched.	<ul> <li>Do not switch the control mode switching request of speed/torque control for the axis that connects to the stepping driver which does not support the control mode switching.</li> </ul>
	6240				0	The control mode switching request of speed-torque control was executed to the cam axis.		Do not execute the speed- torque control mode switching request to the cam axis.

Table 1.19 Output Module Error List (6000 to 6990) (Continued)

_	_			module			, ,	,
Error class	Error code	Roller	Ball screw	Rotary table	Cam	Error cause	Processing	Corrective action
	6250	0	0	0		<ul> <li>During the speed-torque control, the change value by the torque limit value setting device exceeds the torque limit value at speed-torque control.</li> <li>During the speed-torque control, the change value by the torque limit value individual change request (D(P).CHGT2, CHGT2) exceeds the torque limit value at speed-torque control.</li> </ul>	Control with the torque limit value at speed-torque control. The torque limit value by the torque limit value individual change request (D(P).CHGT2, CHGT2) is not changed.	
	6260	0	0	0	0	<ul> <li>The torque limit value individual change request (D(P).CHGT2, CHGT2) was executed with the setting of the torque limit value setting device of the mechanical system output module.</li> </ul>		<ul> <li>When executing the torque limit value individual change request (D(P).CHGT2, CHGT2), do not set the torque limit value setting device of the mechanical system output module.</li> </ul>
Minor	6270	0	0	0	0	The positive direction torque limit value or the negative direction torque limit value outside the range of 0.1 to 1000.0[%] was set in the torque limit value individual change request (CHGT2).	The torque limit value is not changed.	Set the change request within the range of 0.1 to 1000.0[%] for the positive direction torque limit value or the negative direction torque limit value.
error	6280	0	0	0	0	The torque limit value individual change request (D(P).CHGT2, CHGT2) was made for the axis that had not been started.		Request the torque limit value individual change for the starting axis.
	6300	0	0	0	0	Phase compensation time constant is outside the range.	Control with the phase compensation time constant "0".	Set the phase compensation time constant within the range of 0 to 32767 (times).
	6500	0	0	0	0	A servo OFF state at a clutch ON command.	Clutch remains	<ul> <li>Return to the clutch OFF command, and repeat the clutch ON command after executing a servo ON command.</li> </ul>
	6530		0	0	0	The home position return request signal (M2409+20n) is turning on at a clutch ON command. (Incremental axis servo amplifier power from off to ON.)	OFF.	Return to the real mode, back to the virtual mode after home position return.
	6540				0	Although the feed current value is within the stroke limit value, the current value within 1 cam shaft revolution cannot be calculated. (Cam table error)	Servo remains ON.	<ul> <li>Return to the real mode, correct the cam data settings.</li> <li>Set the cam table by the stroke ratio "0 to 7FFFH" of lower stroke value and stroke amount.</li> </ul>

# (3) System errors (9000 to 9990)

Table 1.20 Output Module Error List (9000 to 9990)

Error	Error		Output	module				
class		Roller	Ball Rotary cam		Cam	Error cause	Processing	Corrective action
Minor error	9010	0	0	0	0	setting mode-allowable travel value during power off" set in the system		Check the position.     Check the battery of encoder.

# (4) Output module errors at virtual servo motor axis start (10000 to 10990)

Table 1.21 Output Module Error List (10000 to 10990)

Error	Error		Output	module					
class		Roller	Ball screw	Rotary table	Cam	Error cause	Processing	Corrective action	
	10000		0	0	0	The home position return request signal (M2409+20n) is ON.		<ul> <li>Return to the real mode and execute a home position return.</li> <li>If position is not established after executing a home position return at all axes, the virtual mode operation cannot be executed.</li> </ul>	
Maian	10010	0	0	0	0	The servo error detection signal (M2408+20n) is ON.	Deleted evetem	Execute a servo error reset in the real mode.	
Major error	10020	0	0	0	0	<ul> <li>A servo OFF (M2415+20n OFF) status exists at an output module where a "clutch ON" or "no clutch" setting is set at either the main shaft or auxiliary input axis.</li> </ul>	cannot be start.	Turn the servo on after clutch OFF command.	
	10030	0	0	0	0	An external input signal (STOP) is turning on at an output module where a "clutch ON" or "no clutch" setting is set at either the main shaft or auxiliary input axis.		Turn the stop signal (STOP) off.	

# (5) "No-clutch/clutch ON/clutch status ON" output module errors (11000 to 11990)

Table 1.22 Output Module Error List (11000 to 11990)

Error	Error		Output	module					
class	code	Roller	Ball screw	Rotary table	Cam	Error cause Processing		Corrective action	
	11000	0	0	0	0	The servo error detection signal (M2408+20n) turned on during operation.	After an immediate stop at the applicable output module, and the servo OFF state.	Release the servo error causes. (Refer to APPENDIX 1.5).	
	11010	0	0	0	0	OFF) during operation	<ul> <li>When the "operation continuation" setting is set, execute the stop processing using the user's Motion</li> </ul>		
	11020	0	0	0	0	The stop signal (STOP) turned on.		SFC program.	
Major error	11030	0	0	0	0	The upper limit switch signal (FLS) turned off during forward (address increase direction) travel.	At axes with clutches, control is executed based on the operation mode at the		
	11040	0	0	0	0	The lower limit switch signal (RLS) turned off during reverse (address decrease direction) travel.	time of the error.  • Operation continues.  • All clutches turns off		
	11050	0	0	0		At the switching request to the continuous operation to torque control, the servo amplifier is not compatible with the continuous operation to torque control.	at the applicable systems.		

# (6) Errors when using an absolute position system (12000 to 12990)

Table 1.23 Output Module Error List (12000 to 12990)

	Гтог		Output	module					
Error class	Error code	Roller	Ball screw	Rotary table	Cam	Error cause	Processing	Corrective action	
	12010	0	0	0	0	The error causes why the home position return is required in the absolute position system are as follows:  The home position return has never been executed after the system start.  The home position return is started, but not completed correctly.  Absolute data in the Motion CPU is erased due to causes such as a battery error.  Servo error [2025], [2143], or [2913] occurred.  Major error [1202], [1203], [1204], [12020], [12030] or [12040] occurred.  Rotation direction selection" of the servo parameter is changed.	Home position return signal turns ON.	Execute the home position return in real mode after checking the batteries of the Motion CPU module and servo amplifier.	
Major error	12020	0	0	0	0	A communication error between the servo amplifier and encoder occurred at the servo amplifier power supply on.	Depending on the version of operating system and servo amplifier, home position return signal turns ON.	<ul> <li>Check the motor and encoder cables.</li> <li>If the home position return request signal is turning ON, execute a home position return in the real mode.</li> </ul>	
	12030	0	0	0	0	The amount of change in encoder current value during operation holds the following expression:  "Amount of change in encoder current value / 3.5[ms] >180° of motor revolution"  It is always checked after the servo amplifier power supply on (in both servo ON and OFF states).  (Q17□DCPU(-S1) use)	Home position	Check the motor and encoder cables.	
	12040	0	0	0	0	During operation, the following expression holds:     "Encoder current value [pulse] ≠ feedback current value [pulse] (number of bits in encoder enable range)".     It is always checked after the servo amplifier power supply on (in both servo ON and OFF states).     (Q17□DCPU(-S1) use)	return signal turns ON.		

# Table 1.23 Output Module Error List (12000 to 12990) (Continued)

Error	Error		Output	module				
class		Roller	Ball screw	Rotary table	Cam	Error cause	Processing	Corrective action
Major error	12050	0	0	0	0	<ul> <li>During operation, the following expression holds:         "Encoder current value [pulse] ≠ feedback current value [pulse]         (number of bits in encoder enable range)".         It is always checked after the servo amplifier power supply on (in both servo ON and OFF states).</li> </ul>	Operation continues. (Home position return signal does not turn ON.)	Check the motor and encoder cables.

# APPENDIX 1.7 Errors at real mode/virtual mode switching

Table 1.24 Real Mode/Virtual Mode Switching Error Code List

Error codes st	ored in SD504		
Decimal	Hexadecimal	Error description	Corrective action
display	display		
		<ul> <li>Real mode/virtual mode switching request flag (M2043) turned OFF → ON in the state which all axes have not stopped.</li> <li>(Operation system software version "00G" or before)</li> <li>Real mode/virtual mode switching request flag (M2043)</li> </ul>	<ul> <li>Turn real mode/virtual mode switching request flag (M2043) OFF → ON when start accept flag (M2001 to M2032) are all OFF.</li> <li>(Operation system software version "00G" or before)</li> <li>Turn real mode/virtual mode switching request</li> </ul>
1	0001	turned OFF → ON in the state which output axis set in the mechanical system program has not stopped.  (Operation system software version "00H" or later)	flag (M2043) OFF → ON when start accept flag (M2001 to M2032) of output axis set in the mechanical system program are all OFF. (The real mode axis can be switched in even operation.) (Operation system software version "00H" or later)
		<ul> <li>Real mode/virtual mode switching request flag (M2043) turned ON → OFF in the state which all axes have not stopped.</li> <li>(Operation system software version "00G" or before)</li> </ul>	<ul> <li>Turn real mode/virtual mode switching request flag (M2043) ON → OFF when start accept flag (M2001 to M2032) are all OFF.</li> <li>(Operation system software version "00G" or before)</li> </ul>
256	0100	<ul> <li>Real mode/virtual mode switching request flag (M2043) turned ON → OFF in the state which virtual axis has not stopped.</li> <li>(Operation system software version "00H" or later)</li> </ul>	<ul> <li>Turn real mode/virtual mode switching request flag (M2043) ON → OFF when start accept flag (M2001 to M2032) of virtual axis are all OFF. (The real mode axis can be switched in even operation.)</li> <li>(Operation system software version "00H" or later)</li> </ul>
		<ul> <li>Real mode/virtual mode switching request flag (M2043) turned ON → OFF in the state which virtual axis has not stopped.</li> <li>Real mode/virtual mode switching request flag (M2043) turned ON → OFF in the state which output module is speed-torque control".</li> </ul>	<ul> <li>Turn real mode/virtual mode switching request flag (M2043) ON → OFF when start accept flag (M2001 to M2032) of output axis set in the mechanical system program are all OFF. (The real mode axis can be switched in even operation.)</li> <li>Turn real/virtual mode switching request flag (M2043) ON → OFF when all output modules are in the position control.</li> </ul>
512	0200	<ul> <li>Real mode/virtual mode switching request flag (M2043) turned OFF → ON in the state which mechanical system program has not registered.</li> <li>Real mode/virtual mode switching request flag (M2043)</li> </ul>	Write the mechanical system program to the Motion CPU.      Set the same axis No. at both the system
		turned OFF → ON in the state which the axis No. set in the system setting does not match the output axis No. set in the mechanical system program.	settings and mechanical system program, then write the data to the Motion CPU.
513 <sup>(Note)</sup>	0201	<ul> <li>Real mode/virtual mode switching request flag (M2043) turned OFF → ON in the state which the PLC ready flag (M2000) or PCPU READY complete flag (SM500) is OFF.</li> </ul>	• After turning the PLC ready flag and PCPU READY flags on, turn real mode/virtual mode switching request flag (M2043) OFF $\rightarrow$ ON.
514 <sup>(Note)</sup>	0202	<ul> <li>Real mode/virtual mode switching request flag (M2043) turned OFF → ON in the state which the all-axes servo ON command (M2042) is OFF.</li> </ul>	<ul> <li>Turn all axes servo ON command (M2042) on, turn the all-axes servo ON accept flag on, then turn real mode/virtual mode switching request flag (M2043) OFF → ON.</li> </ul>

(Note): Error axis No. information is not set to SD505, SD506 in this error.

Table 1.24 Real Mode/Virtual Mode Switching Error Code List (Continued)

Error codes st	ored in SD504		
Decimal	Hexadecimal	Error description	Corrective action
display	display	· ·	
. ,	, ,	Real mode/virtual mode switching request flag (M2043)	Turn the external forced stop signal off, then
515 <sup>(Note)</sup>	0203	turned OFF → ON in the state which the external forced	turn real mode/virtual mode switching request
		stop input signal (EMG) is ON.	flag (M2043) OFF → ON switching.
		Real mode/virtual mode switching request flag (M2043)	When the servo error reset is executed by
		turned OFF → ON during the servo start processing by	turning servo error reset command
516 <sup>(Note)</sup>	0004	the servo error reset command (M3208+20n).	(M3208+20n) on, turn the servo error detection
516 (1919)	0204		signal (M2408+20n) off, then turn real
			mode/virtual mode switching request flag
			(M2043) OFF $\rightarrow$ ON.
		Real mode/virtual mode switching request flag (M2043)	Execute the home position return (execute
		turned OFF $ ightarrow$ ON in the state which the home position	ZERO in the servo program), and turn real
768	0300	return signal is turning on for the output module is other	mode/virtual mode switching request flag
		than the roller.	(M2043) OFF → ON after home position return
		Produced children I will to a constant	request signal (M2409+20n) has turned OFF.
1004	0400	• Real mode/virtual mode switching request flag (M2043)	Check the servo amplifier, servo motor and
1024	0400	turned OFF → ON in the state (M2408+20n ON) of the	wiring, etc.
		servo error.     Real mode/virtual mode switching request flag (M2043)	Correct the setting unit of the fixed parameter or
		turned OFF → ON in the state which the units set in the	output module, and write to the Motion CPU.
1280	0500	fixed parameter and output module are different for the	Carpar module, and write to the Motion OFU.
		output module is other than the roller.	
		Real mode/virtual mode switching request flag (M2043)	Write the cam data to the Motion CPU.
1536	0600	turned OFF → ON in the state which cam data has not	2 2.2 2.2 2.3 10 1.10 1.10 1.10 1.10 1.10
		registered although the cam is set to the output module.	
		Real mode/virtual mode switching request flag (M2043)	Turn real mode/virtual mode switching request
2048	0800	turned OFF $\rightarrow$ ON without the cam No. setting to the	flag (M2043) OFF → ON after writing the cam
2040	0000	cam No. setting device.	No. set in the cam No. used of cam parameter
		(Cam No. setting device is "0").	to the cam No. setting device.
		The setting value of cam stroke amount setting device is	
2304	0900	outside the range of 1 to (2 <sup>31</sup> -1).	flag (M2043) OFF → ON after setting the value
			within the range of 1 to (2 <sup>31</sup> -1) to the cam
		The compatible and the second	stroke amount setting device.
2816	0B00	The cam stroke amount setting device is not an even	Set an even number to the cam stroke amount
		number.	setting device.
3072	0C00	Setting for real mode axis is not correct.	<ul> <li>Execute "conversion and save" after setting real mode axis setting in the mechanical system</li> </ul>
3072	0000		program editor.
		The number of pulses per revolution of the rotary table	Correct the number of pulses per revolution and
		is outside the range of 1 to 1073741824.	the travel value per revolution in the fixed
3328	0D00		parameter within the range of 1 to 1073741824
			to the number of pulses per revolution of the
			rotary table.
		The PLC ready flag (M2000) turned off, and the system	• Turn PLC ready flag (M2000) on.
-4094 <sup>(Note)</sup>	F002	returned to the real mode during virtual mode operation.	Set the Motion CPU "RUN" state.
		The Motion CPU stopped during virtual mode operation.	
		The servo error detection signal (M2408+20n) turned	Check the servo error code register to
-4095 <sup>(Note)</sup>	F001	off, and the system returned to the real mode during	determine the error cause at the axis in
1000	. 501	virtual mode operation.	question, then release the error cause
			(Refer to APPENDIX 1.5).
-4096 <sup>(Note)</sup>	F000	The forced stop signal (EMG) turned on, and the	Turn the forced stop signal off.
. , .		system returned to the real mode.	

(Note): Error axis No. information is not set to SD505, SD506 in this error.

### APPENDIX 2 Setting Range for Indirect Setting Devices

Positioning address, command speed or M-code, etc. (excluding the axis No.) set in the servo program can be set indirectly by the word.

#### (1) Device range

The number of device words and device range at indirect setting are shown below.

		Item	Number of device words		Device setting range	Remarks
	Parameter bloc	k No.	1			
_ ا	Address (trave	value)	2			
Sommon	Command spe	•	2	Device	Range	
E E	Dwell time		1	D	0 to 8191 <sup>(Note-1)</sup>	
0	M-code		1	W	0000 to 1FFF	
	Torque limit va	lue	1	#	0 to 7999	
	Auxiliary point		2	U□\G	10000 to (10000+p-1) (Note-2)	
Arc	Radius		2		•	
₹	Central point		2			
	Pitch		1			
	Control unit		1			
	Speed limit val	ue	2			
	Acceleration tir	ne	1			
	Deceleration til	ne	1			
	Rapid stop dec	eleration time	1			
첫	S-curve ratio		1			
Parameter block		Acceleration/deceleration	1			
Tete	Advanced	system	'			
Iran	S-curve	Acceleration section 1 ratio	1			
<u>a</u>	acceleration/	Acceleration section 2 ratio	1			
	deceleration	Deceleration section 1 ratio	1			
		Deceleration section 2 ratio	1			
	Torque limit va	lue	1			
		rocessing on STOP input	1			
		range for circular interpolation	2			
	Command spee	ed (Constant speed)	2			
	FIN acceleration	n/deceleration	1			
	Fixed position stime	stop acceleration/deceleration	1			
	Repetition cond	dition (Number of repetitions)	1			
		dition (ON/OFF)				]
SI-S	Cancel Skip WAIT ON/OFF			Device	Range	
T #				X	0000 to 1FFF <sup>(Note-3)</sup>	
1				Y	0000 to 1FFF	
1	Fixed position :		Bit	М	0 to 8191 <sup>(Note-1)</sup>	
1	•	·		В	0000 to 1FFF	
1				F	0 to 2047	
				U□\G	10000.0 to (10000+p-1).F (Note-2)	
				E-		

<sup>(</sup>Note-1): Synchronous encoder axis area cannot be set.

<sup>(</sup>Note-2): "p" indicates the user setting area points of the Multiple CPU high speed transmission area for each CPU.

<sup>(</sup>Note-3): The range of "PXn+4 to PXn+F" cannot be used (fixed at 0) for the input device (PXn+0 to PXn+F) allocated to the built-in interface in Motion CPU (DI). (n: First input No.)

#### POINT

- (1) Be sure to set even-numbered devices of the items set as 2-word.

  Be sure to set as 32-bit integer type when the data is set in these devices using the Motion SFC programs. (Example : #0L, D0L)
- (2) Refer to Chapter 2 of the "Q173D(S)CPU/Q172D(S)CPU Motion controller Programming Manual (COMMON)" for the user setting area points of the Multiple CPU high speed transmission area.

#### (2) Inputting device data

Indirect setting device data is inputted by the Motion CPU at the servo program start.

Do not change the applicable device before setting to device and start completion.

The procedures by start method for setting data to devices and cautions are shown below.

Start method	Setting method	Notes
Start by the servo program	Set data in indirect setting devices.  ↓ Start the servo program.	Do not change the indirect setting device before the "positioning start complete signal" of the starting axis turns on.
Set the loop (FOR - NEXT) point data for CPSTART instruction indirectly	Set initial command data in the indirect setting device.  \$\text{J}  Start using the servo program (or turn the cancel command device on).  \$\text{J}  Read the value of "data set pointer for constant-speed control" of the start axis, and update the data input by Motion CPU.	Refer to the positioning signal data register "Monitoring data area" for details.

#### APPENDIX 3 Processing Times of the Motion CPU

The processing time of each signal and each instruction for positioning control in the Multiple CPU system is shown below.

#### (1) Motion operation cycle [ms] (Default)

#### (a) Q173DSCPU/Q172DSCPU

		Q173DSCPL	J	Q172E	SCPU
Number of setting axes (SV22)	1 to 6	7 to 16	17 to 32	1 to 6	7 to 16
Operation cycle [ms]	0.44	0.88	1.77	0.44	0.88

#### (b) Q173DCPU(-S1)/Q172DCPU(-S1)

		Q173D0	Q172DCPU(-S1)			
Number of setting axes (SV22)	1 to 4	5 to 12	13 to 28	29 to 32	1 to 4	5 to 8
Operation cycle [ms]	0.44	0.88	1.77	3.55	0.44	0.88

#### (2) CPU processing time [ms]

The instruction processing time means the time until the content is reflected to servo amplifier side after each instruction is executed.

(Including the transmission time between Motion controller and servo amplifier.)

#### (a) Q173DSCPU/Q172DSCPU

				Q173DSCPU	/Q172DSCPU		
Ор	eration cycle [ms]	0.22	0.44	0.88	1.77	3.55	7.11
Servo program	"WAIT ON/OFF" + Motion control step	0.44	0.88	1.77	2.66	4.44	7.99
start processing	Only Motion control step	0.6 to 0.9	1.0 to 1.4	1.9 to 2.8	2.8 to 4.6	4.6 to 8.2	8.1 to 15.2
time (Note-1)	Dedicated instruction (D(P).SVST) from the PLC CPU	1.4 to 2.3	2.2 to 3.1	3.5 to 4.4	5.3 to 6.2	8.8 to 9.7 16.0 to 16 4.4 to 8.0 8.0 to 15 4.4 5.3 to 6.2 8.9 to 9. 4.4 4.4 to 8.0 4.4 to 11 4.4 5.3 to 6.2 5.3 to 9.	16.0 to 16.9
Speed change	Instruction (CHGV) from the Motion SFC	0.4 to 0.9	0.8 to 1.3	1.7 to 2.6	2.6 to 4.4	4.4 to 8.0	8.0 to 15.1
response time	Dedicated instruction (D(P).CHGV) from the PLC CPU	1.4 to 2.3	1.7 to 2.6	2.6 to 3.5	3.5 to 4.4	5.3 to 6.2	8.9 to 9.8
Torque limit value change response	Instruction (CHGT) from the Motion SFC	0.4 to 0.9	0.8 to 1.3	1.7 to 2.6	2.6 to 4.4	4.4 to 8.0	4.4 to 11.5
time	Dedicated instruction (D(P).CHGT) from the PLC CPU	1.4 to 2.3	1.7 to 2.6	2.6 to 3.5	3.5 to 4.4	5.3 to 6.2	5.3 to 9.7
Torque limit value	Instruction (CHGT2) from the Motion SFC	0.4 to 0.9	0.8 to 1.3	1.7 to 2.6	2.6 to 4.4	4.4 to 8.0	4.4 to 11.5
individual change response time	Dedicated instruction (D(P).CHGT2) from the PLC CPU	1.4 to 2.3	1.7 to 2.6	2.6 to 3.5	3.5 to 4.4	5.3 to 6.2	5.3 to 9.7
Target position change response time	Instruction (CHGP) from the Motion SFC	0.4 to 0.9	0.8 to 1.3	1.7 to 2.6	2.6 to 4.4	4.4 to 8.0	8.0 to 15.1
	ly flag (M2000) ON to plete flag (SM500) ON			44 to	o 60		

(Note-1): FEED instruction varies greatly depending on the condition (whether other axes are operating).

#### (b) Q173DCPU(-S1)/Q172DCPU(-S1)

			Q1	73DCPU(-S1)	/Q172DCPU(-	S1)			
Ор	eration cycle [ms]	0.44	0.88	1.77	3.55	7.11	14.2		
Servo program	"WAIT ON/OFF" + Motion control step	0.88	1.77	2.66	4.44	7.99	15.11		
start processing	Only Motion control step	1.0 to 1.4	1.9 to 2.8	2.8 to 4.6	4.6 to 8.2	8.1 to 15.2	15.2 to 29.4		
time <sup>(Note-1)</sup>	Dedicated instruction (D(P).SVST) from the PLC CPU	2.2 to 3.1	3.5 to 4.4	5.3 to 6.2	8.8 to 9.7	16.0 to 16.9	30.2 to 31.1		
Speed change	Instruction (CHGV) from the Motion SFC	0.8 to 1.3	1.7 to 2.6	2.6 to 4.4	4.4 to 8.0	8.0 to 15.1	15.1 to 29.3		
response time	Dedicated instruction (D(P).CHGV) from the PLC CPU	1.7 to 2.6	2.6 to 3.5	3.5 to 4.4	5.3 to 6.2	8.9 to 9.8	16.0 to 16.9		
Torque limit value	Instruction (CHGT) from the Motion SFC	0.8 to 1.3	1.7 to 2.6	2.6 to 4.4	4.4 to 8.0	4.4 to 11.5	4.4 to 18.6		
change response time	Dedicated instruction (D(P).CHGT) from the PLC CPU	1.7 to 2.6	2.6 to 3.5	3.5 to 4.4	5.3 to 6.2	5.3 to 9.7	5.3 to 16.0		
	ly flag (M2000) ON to olete flag (SM500) ON	22 to 28							

(Note-1): FEED instruction varies greatly depending on the condition (whether other axes are operating).

# (3) Virtual servo motor axis/synchronous encoder axis operation cycle [ms] (Default)

#### (a) Q173DSCPU/Q172DSCPU

	(	Q173DSCPL	Q172DSCPU		
Number of setting axes (SV22)	1 to 6	7 to 16	17 to 32	1 to 6	7 to 16
Virtual servo motor [ms]	0.44	0.88	1.77	0.44	0.88
Synchronous encoder [ms]	0.44	0.88	1.77	0.44	0.88

# (b) Q173DCPU(-S1)/Q172DCPU(-S1)

		Q173D0		Q172DCPU(-S1)		
Number of setting axes (SV22)	1 to 4	5 to 12	13 to 28	29 to 32	1 to 4	5 to 8
Virtual servo motor [ms]	0.44	0.88	1.77	3.55	0.44	0.88
Synchronous encoder [ms]	0.44	0.88	1.77	3.55	0.44	0.88

#### **APPENDIX 4 Device List**

#### (1) Axis status list

Axis No.	Device No.	` '					Signa	l name					
1	M2400 to M2419						Gigina	Hallic					
2	M2420 to M2419	$\overline{}$						Virtual					
3	M2440 to M2459	$    \rangle$						Viituai		Real	Refresh	Fetch	Signal
4	M2460 to M2479	$I \setminus$	Sig	gnal name	Real	Roller	Ball	Rotary	Cam	Mode	cycle		direction
5	M2480 to M2499	\				1 tolloi	screw	table	Ouiii	axis	oyo.c		un ootion
6	M2500 to M2519		Positionin	ng start complete						GI, II G			
7	M2520 to M2539	1		ng complete		OFF							
8	M2540 to M2559												
9	M2560 to M2579	2	In-positio	n		0							
10	M2580 to M2599	3	Comman	d in-position							Operation		
11	M2600 to M2619		Speed co								cycle		
12	M2620 to M2639			position switching	OFF								
13	M2640 to M2659	5	latch	· ·									
14	M2660 to M2679	6	Zero pas	s									
15	M2680 to M2699	7	Error dete	ection							Immediately		
16	M2700 to M2719		C	0				0	Operation		Status		
17	M2720 to M2739	8	Servo err	Servo error detection							cycle		signal
18	M2740 to M2759	9	Home po	sition return					Main cycle				
19	M2760 to M2779	9	request							iviairi cycle	_		
20	M2780 to M2799	10	Home po	sition return		0				Operation			
21	M2800 to M2819	10	complete				`	_			cycle	П	
22	M2820 to M2839	11		FLS									
23	M2840 to M2859	12	External	RLS							Main cycle	H	
24	M2860 to M2879		signals	STOP							.nan oyoto		
25	M2880 to M2899	14	1	DOG/CHANGE									
26	M2900 to M2919		Servo rea								Operation		
27	M2920 to M2939		Torque lir								cycle		
28	M2940 to M2959	17	Unusable				_	_		_	_	<u> </u>	
29	M2960 to M2979			ode continuation				_			At virtual	/	
30	M2980 to M2999	18	operation (Note-1)	disable warning						mode	/	Status	
31	M3000 to M3019	-	(14010-1)						0	Operation	/	signal	
32	M3020 to M3039	19	M-code o	outputting	OFF				/				
				-						]	cycle	V	~ \/ ":
													○ : Valid

(Note-1): It is unusable in the SV22 real mode.

#### **POINT**

(1) The following range is valid.

• Q172DSCPU : Axis No.1 to 16 • Q172DCPU(-S1): Axis No.1 to 8

(2) The following device area can be used as a user device.

• Q172DSCPU : 17 axes or more • Q172DCPU(-S1): 9 axes or more

However, when the project of Q172DSCPU/Q172DCPU(-S1) is replaced with Q173DSCPU/Q173DCPU(-S1), this area cannot be used as a user device.

# (2) Axis command signal list

Axis No.	Device No.					Signa	al name					
1	M3200 to M3219											
2	M3220 to M3239						Virtual					
3	M3240 to M3259	$\mathbb{I}\setminus$							Real	Refresh	Fetch	Signal
4	M3260 to M3279		Signal name	Real	Roller	Ball	Rotary	Cam	mode	cycle	cycle	direction
5	M3280 to M3299	1	V			screw	table		axis			
6	M3300 to M3319	0	Stop command			•	•	•			Operation	
7	M3320 to M3339	1	Rapid stop command							/	cycle	
8	M3340 to M3359		Forward rotation JOG							/		
9	M3360 to M3379	2	start command							/		
10	M3380 to M3399		Reverse rotation JOG			,					Main	
11	M3400 to M3419	3	start command			,	×				cycle	
12	M3420 to M3439	_	Complete signal OFF									
13	M3440 to M3459	4	command									
14	M3460 to M3479	5	Speed/position switching	0					0		Operation	Command
15	M3480 to M3499	٥	enable command								cycle	signal
16	M3500 to M3519		Gain changing 2								Operation	
17	M3520 to M3539	6	command (Note-1)								cycle	
18	M3540 to M3559		QDS (Ver.)			(	<u> </u>				(Note-2)	
19	M3560 to M3579	7	Error reset command		0						Main	
20	M3580 to M3599	8	Servo error reset								Main cycle	
21	M3600 to M3619	°	command								Сусіе	
22	M3620 to M3639	9	External stop input disable			,	×				At start	
23	M3640 to M3659		at start command								At Start	
24	M3660 to M3679	10	Unusable									_
25	M3680 to M3699	11	Oliusabic									
26	M3700 to M3719	12	Feed current value update	0		`	×		0	l /	At start	
27	M3720 to M3739	Ľ	command				· ·			/	7 tt otart	
28	M3740 to M3759	13	Address clutch reference			<				/	At virtual	
29	M3760 to M3779	L	setting command (Note-3)	×				1	×	/	mode	
30	M3780 to M3799	14	Cam reference position			×		0		/	transition	
31	M3800 to M3819	-	setting command (Note-3)							/		
32	M3820 to M3839	15	Servo OFF command							/	Operation	Command
										/	cycle	signal
		16	Gain changing command								Operation	
		17	PI-PID switching	0		0		cycle (Note-2)				
		-	command CDS								(11010-2)	
		18	Control loop changing								Operation	
		10	command				<u> </u>			/	cycle	
		15	FIN signal			,	×		<u> </u>	<u> </u>	○ - M-P	ادالت تسلماني
											○ : valid	$ ext{d},  imes:$ Invalid

(Note-1): Servo amplifier (MR-J5(W)- $\square$ B) only.

(Note-2): It is unusable in the SV22 real mode.

(Note-3): Operation cycle 7.1[ms] or more: Every 3.5[ms]

Ver.!: Refer to Section 1.4 for the software version that supports this function.

#### POINT

(1) The following range is valid.

Q172DSCPU : Axis No.1 to 16Q172DCPU(-S1): Axis No.1 to 8

(2) The following device area can be used as a user device.

• Q172DSCPU : 17 axes or more • Q172DCPU(-S1): 9 axes or more

However, when the project of Q172DSCPU/Q172DCPU(-S1) is replaced with Q173DSCPU/Q173DCPU(-S1), this area cannot be used as a user device.

# (3) Virtual servo motor axis status list

Axis No.	Device No.				5	Signal n	ame					
1	M4000 to M4019											
2	M4020 to M4039	$\setminus$					Virtual					
3	M4040 to M4059	$  1 \rangle$	0: 1						Real	Refresh	Fetch	Signal
4	M4060 to M4079		Signal name	Real	Roller	Ball	Rotary	Cam	mode	cycle	cycle	direction
5	M4080 to M4099					screw	table		axis			
6	M4100 to M4119	0	Positioning start complete							Operation		Status
7	M4120 to M4139	1	Positioning complete	Backup		(	)		×	cycle		signal
8	M4140 to M4159	2	Unusable	_		-			_	_	_	_
9	M4160 to M4179	3	Command in-position	D I		,	$\sim$			Operation		Status
10	M4180 to M4199	4	Speed controlling	Backup	ckup				×	cycle		signal
11	M4200 to M4219	5	Unusable				·					
12	M4220 to M4239	6	Unusable	_		_			_	_	_	_
13	M4240 to M4259	7	Error detection	Backup		(	)		×	Immedi-		Status
14	M4260 to M4279	Ľ	Error detection	Баскир					^	ately		signal
15	M4280 to M4299	8										
16	M4300 to M4319	9										
17	M4320 to M4339	10	)									
18	M4340 to M4359	1										
19	M4360 to M4379	12	2									
20	M4380 to M4399	13	Unusable	-		-	_		_	_	_	_
21	M4400 to M4419	14	1									
22	M4420 to M4439	15	5									
23	M4440 to M4459	16	3									
24	M4460 to M4479	17										
25	M4480 to M4499	18	3								ļ,	
26	M4500 to M4519	10	M-code outputting	Backup		(	0		×	Operation		Status
27	M4520 to M4539	Ľ	, in code odipating	Васкар			-		, `	cycle		signal
28	M4540 to M4559									0:	Valid,	×: Invalid
29	M4560 to M4579											
30	M4580 to M4599											
31	M4600 to M4619											
32	M4620 to M4639											

#### **POINT**

- (1) The following range is valid.
  - Q172DSCPU : Axis No.1 to 16 • Q172DCPU(-S1): Axis No.1 to 8
- (2) The unused axis areas in the mechanical system program can be used as a user device.

# (4) Virtual servo motor axis command signal list

Axis No.	Device No.					Sign	al name	)				
1	M4800 to M4819											
2	M4820 to M4839	$\setminus$					Virtual					
3	M4840 to M4859	$    \rangle$		<u> </u>					Real	Refresh	Fetch	Signal
4	M4860 to M4879	'	Signal name	Real	Roller	Ball	Rotary	Cam	mode	cycle	cycle	direction
5	M4880 to M4899		\			screw	table		axis			
6	M4900 to M4919	0	Stop command							/	Operation	
7	M4920 to M4939	1	Rapid stop command							/	cycle	
8	M4940 to M4959		Forward rotation IOG							/		
9	M4960 to M4979	2	start command							/		Command
10	M4980 to M4999		Reverse rotation JOG	×					×	/	Main	signal
11	M5000 to M5019	3	start command							/	cycle	
12	M5020 to M5039		Complete signal OFF							/		
13	M5040 to M5059	4	command							/		
14	M5060 to M5079	5	I lavorable									
15	M5080 to M5099	6	Unusable	musable — — —								
16	M5100 to M5119	Ι,	F			,					Main	Command
17	M5120 to M5139	7	Error reset command	×				X		cycle	signal	
18	M5140 to M5159	8	Unusable	_		-	_		_	_	_	_
19	M5160 to M5179		External stop input									C = 112 112 112 11
20	M5180 to M5199	9	disable at start	×		(	О		×		At start	Command
21	M5200 to M5219		command									signal
22	M5220 to M5239	10	)									
23	M5240 to M5259	1	1									
24	M5260 to M5279	12	2									
25	M5280 to M5299	13	3									
26	M5300 to M5319	14	Unusable Unusable	-		-	_		_		_	_
27	M5320 to M5339	1	5									
28	M5340 to M5359	16	3									
29	M5360 to M5379	1	7									
30	M5380 to M5399	18	3									
31	M5400 to M5419	10	FIN signal	×		(	0		×		Operation	Command
32	M5420 to M5439	Ľ	7 I II Signal	^		,					cycle	signal
											○ : Valid	l, $ imes$ : Invalid

#### POINT

(1) The following range is valid.

Q172DSCPU : Axis No.1 to 16Q172DCPU(-S1): Axis No.1 to 8

(2) The unused axis areas in the mechanical system program can be used as a user device.

#### (5) Synchronous encoder axis status list

Axis No.	Device No.				Sigr	nal name			
1	M4640 to M4643								
2	M4644 to M4647	ľ	$\overline{\ }$	Signal name	Real	Virtual	Defreeb evels	Fetch cycle	Signal
3	M4648 to M4651		$\overline{}$	Signal Harne	Real	Virtual	Refresh cycle	Fetch cycle	direction
4	M4652 to M4655		0	Error detection			Immediately		
5	M4656 to M4659		1	External signal TREN					Status
6	M4660 to M4663		2	Virtual mode continuation operation			Main cycle		signal
7	M4664 to M4667			disable warning					
8	M4668 to M4671		3	Unusable	_	_	_	_	_
9	M4672 to M4675	_							○ : Valid
10	M4676 to M4679								
11	M4680 to M4683								
12	M4684 to M4687								

#### **POINT**

- (1) The range of axis No.1 to 8 is valid in the Q172DCPU(-S1).
- (2) The device area of 9 axes or more can be used as a user device in the Q172DCPU(-S1).

However, when the project of Q172DCPU(-S1) is replaced with Q173DSCPU/Q172DSCPU/Q173DCPU(-S1), this area cannot be used.

#### (6) Synchronous encoder axis command signal list

Axis No.	Device No.			Sigr	nal name	)		
1	M5440 to M5443							
2	M5444 to M5447		Signal name	Dool	Virtual	Defreeb evels	Catab avala	Signal
3	M5448 to M5451		Signal name	Real	virtuai	Refresh cycle	Fetch cycle	direction
4	M5452 to M5455		Error reset	×	0		Main avala	Status
5	M5456 to M5459	U	Enorreset	(Note-1)			Main cycle	signal
6	M5460 to M5463	1						
7	M5464 to M5467	2	Unusable	_	_	_	_	_
8	M5468 to M5471	3						
9	M5472 to M5475						○ : Valid	, ×: Invalid
10	M5476 to M5479	(N	ote-1): It is valid for the version (Refer to	Section	1.4) tha	it supports "synch	nronous encoder c	urrent
11	M5480 to M5483		value monitor in real mode".					
12	M5484 to M5487							

#### **POINT**

- (1) The range of axis No.1 to 8 is valid in the Q172DCPU(-S1).
- (2) The device area of 9 axes or more can be used as a user device in the Q172DCPU(-S1).

However, when the project of Q172DCPU(-S1) is replaced with Q173DSCPU/Q172DSCPU/Q173DCPU(-S1), this area cannot be used.

# (7) Common device list

_	1	(1)	ommon d	1		_					1	
Device No.	Signal name	Refresh cycle	Fetch cycle	Signal direction	Remark (Note-6)	Device No.		Signal name	Refresh cycle	Fetch cycle	Signal direction	Remark (Note-6)
M2000	PLC ready flag		Main cycle	Command	M3072	M2055						
M2001 M2002 M2003 M2004	Axis 1 Axis 2 Axis 3 Axis 4 Axis 5		Wallington	signal	WOOTZ	M2056 M2057 M2058 M2059 M2060	Unusab (6 points		_	_	-	_
M2006 M2007 M2008 M2009 M2010 M2011 M2012 M2013 M2014 M2015 M2016 M2016 M2017 M2018 M2020 M2021 M2022 M2023 M2022 M2023 M2024 M2026 M2026 M2027 M2028	Axis 6 Axis 7 Axis 8 Axis 9 Axis 10 Axis 11 Axis 12 Axis 13 Axis 14 Axis 15 Axis 16 Axis 17 Axis 18 Axis 19 Axis 20 Axis 20 Axis 21 Axis 22 Axis 23 Axis 24 Axis 25 Axis 26 Axis 27 Axis 28 Axis 29 Axis 29 Axis 20 Axis 21 Axis 22 Axis 23 Axis 24 Axis 25 Axis 26 Axis 27 Axis 28 Axis 29 Axis 30 Axis 31 Axis 31 Axis 32	Operation cycle		Status signal (Note-1), (Note-2), (Note-3), (Note-4)		M2061 M2062 M2063 M2064 M2065 M2066 M2067 M2068 M2069 M2071 M2072 M2073 M2074 M2074 M2075	Axis 1 Axis 2 Axis 3 Axis 4 Axis 5 Axis 6 Axis 6 Axis 7 Axis 8 Axis 7 Axis 8 Axis 10 Axis 11 Axis 12 Axis 15 Axis 16 Axis 17 Axis 18 Axis 19 Axis 20 Axis 21 Axis 22 Axis 23 Axis 24 Axis 23 Axis 24 Axis 27	Speed change accepting flag	Operation cycle		Status signal (Note-1), (Note-2), (Note-3), (Note-4)	
M2033 M2034	Unusable (2 points)	_	-	_	_	M2088 M2089	Axis 28 Axis 29					
M2035	Motion error history clear request flag		Main cycle	Command signal	M3080	M2090	Axis 30			1		
M2036 M2037	Unusable (2 points)	_	_		_	M2091 M2092	Axis 31 Axis 32					
	Motion SFC debugging flag	At debugging mode transition		Status signal		M2093						
M2039 M2040	Motion error detection flag  Speed switching point specified	Immediate	At start	Command	M3073	M2094 M2095						
	flag			signal Status								
M2041	System setting error flag	Operation cycle	Operation avala	signal	M3074	M2096	Unusabl	le	_	_	_	
	All axes servo ON command Real mode/virtual mode		Operation cycle At virtual mode	Command	M3074	M2097	(8 points	s)	_	_	_	
M2043	switching request (SV22)		transition	signal	M3075	M2098						
M2044	Real mode/virtual mode switching status (SV22) Real mode/virtual mode	At virtual mode		Status		M2099						
	switching error detection signal (SV22)	transition		Status signal		M2100				,		
M2046 M2047	Out-of-sync warning (SV22)  Motion slot fault detection flag	Operation cycle				M2101 M2102				/		
M2048	JOG operation simultaneous start command	2,2	Main cycle	Command signal	M3076	M2103				/		
M2049	All axes servo ON accept flag	Operation cycle		Status signal		M2104	Axis 4			/		
M2050	Unusable	_		—	_	M2105	Axis 5	Synchronous encoder current		/	Status signal	
M2051	Manual pulse generator 1 enable flag	$\overline{}$			M3077	M2106	Axis 6	value changing flag (Note-5)	Operation cycle	/	(Note-2), (Note-4)	
M2052	Manual pulse generator 2 enable flag		Main cycle	Command signal	M3078	M2107	Axis 7	-,		/	"	
M2053	Manual pulse generator 3 enable flag				M3079	M2108	Axis 8			/		
M2054	Operation cycle over flag	Operation cycle		Status signal		M2109	Axis 9			/		

# Common device list (Continued)

Device No.		Signal name	Refresh cycle	Fetch cycle	Signal direction	Remark (Note-6)	Device No.	Signal name	Refresh cycle	Fetch cycle	Signal direction	Remark (Note-6)
	Axis 11	Synchronous encoder current value changing flag	Operation cycle		Status signal (Note-2),		M2179 M2180 M2181					
M2113 M2114 M2115 M2116 M2117 M2118 M2119 M2120 M2121 M2122 M2123 M2124 M2125 M2126 M2126 M2127	Unusabl (15 point		-	-	(Note-4)	_	M2182 M2183 M2184 M2185 M2186 M2187 M2189 M2190 M2191 M2192 M2193 M2194 M2195 M2196					
M2129 M2130 M2131 M2132 M2133 M2134 M2135 M2136 M2137 M2138 M2141 M2142 M2141 M2142 M2144 M2145 M2146 M2141 M2145 M2146 M2147 M2148 M2149 M2150 M2151 M2152 M2153 M2155 M2156 M2157	Axis 2 Axis 3 Axis 4 Axis 5 Axis 6 Axis 7 Axis 8 Axis 9 Axis 10 Axis 11 Axis 12 Axis 13 Axis 14 Axis 12 Axis 14 Axis 15 Axis 16 Axis 17 Axis 18 Axis 19 Axis 20 Axis 20 Axis 22 Axis 23 Axis 24 Axis 25 Axis 24 Axis 27 Axis 28 Axis 27 Axis 28 Axis 29 Axis 20	Automatic decelerating flag	Operation cycle		Status signal (Note-1), (Note-2), (Note-4)		M2197 M2198 M2199 M2200 M2201 M2203 M2204 M2205 M2206 M2207 M2208 M2210 M2211 M2212 M2211 M2212 M2213 M2214 M2215 M2216 M2217 M2218 M2217 M2218 M2212 M2221 M2222 M2223 M2224 M2222	Unusable (45 points) (Note-7)	_	_	-	_
M2159 M2160 M2161 M2162 M2163 M2164 M2165 M2166 M2167 M2168 M2170 M2171 M2172 M2173 M2174 M2175 M2176 M2177	Axis 32 Unusabli (19 point (Note-7)		_	_	_	_	M2228 M2229 M2230 M2231 M2232 M2233 M2234 M2235 M2236 M2236 M2239 M2240 M2241 M2242 M2242 M2243	Axis 2 Axis 3 Axis 4 Speed change "0" accepting flag Axis 6 Axis 7	— Operation cycle	-	Status signal (Note-1), (Note-2), (Note-3), (Note-4)	_

## Common device list (Continued)

Device		Signal name	Refresh cycle	Fetch cycle	Signal direction	Remark (Note-6)	Device No.	Signal name	Refresh cycle	Fetch cycle	Signal direction	Remark (Note-6)
No. M2248 M2249 M2250 M2251 M2252 M2253 M2254 M2255 M2256 M2257 M2256 M2260 M2261 M2262 M2263 M2264 M2266 M2266 M2267	Axis 10 Axis 11 Axis 12 Axis 13 Axis 14 Axis 15 Axis 16 Axis 17 Axis 18 Axis 19 Axis 20 Axis 21 Axis 22 Axis 23 Axis 24 Axis 25 Axis 26	Speed change "0" accepting flag	Operation cycle		Status signal (Note-1), (Note-2), (Note-3),		M2284 Axi M2285 Axi M2286 Axi M2287 Axi M2288 Axi M2289 Axi M2291 Axi M2291 Axi M2292 Axi M2293 Axi M2294 Axi M2295 Axi M2296 Axi M2297 Axi M2298 Axi M2298 Axi M2299 Axi M2299 Axi M2290 Axi M2291 Axi M2291 Axi M2291 Axi M2292 Axi M2293 Axi M2293 Axi M2293 Axi M2293 Axi M2300 Axi M2301 Axi M2302 Axi	is 13 is 14 is 15 is 16 is 16 is 17 is 18 is 19 is 20 is 21 is 22 Control loop monitor is 23 is 24 is 25 is 26 is 27 is 28 is 29 is 30 is 31 is	Operation cycle		Status signal (Note-1), (Note-3), (Note-4)	
M2268 M2269 M2270 M2271 M2272 M2273 M2274 M2275 M2276 M2277 M2278 M2279 M2280 M2281 M2282 M2283	Axis 30 Axis 31 Axis 32 Axis 1 Axis 2 Axis 3 Axis 4 Axis 5 Axis 6 Axis 7 Axis 8 Axis 9 Axis 10 Axis 11	Control loop monitor status			(Note-4)		M2304 M2305 M2306 M2307 M2308 M2309 M2310 M2311 M2312 M2313 M2314 M2315 M2316 M2317 M2318 M2319	usable 6 points)	-			_

(Note-1): The range of axis No.1 to 16 is valid in the Q172DSCPU.

(Note-2): The range of axis No.1 to 8 is valid in the Q172DCPU(-S1).

(Note-3): Device area of 17 axes or more is unusable in the Q172DSCPU.

(Note-4): Device area of 9 axes or more is unusable in the Q172DCPU(-S1).

(Note-5): It is unusable in the real mode.

(It can be used in the real mode for the version (Refer to Section 1.4) that supports "synchronous encoder current value monitor in real mode".)

(Note-6): It can also be ordered the device of a remark column.

(Note-7): These devices can be used as the clutch statuses.

The clutch status can also be set as the optional device at the clutch parameter.

Refer to Section 7.2.2.

### (8) Common device list (Command signal)

	T				
Device No.	Signal name	Refresh cycle	Fetch cycle	Signal direction	Remark (Note-1), (Note-2)
M3072	PLC ready flag	/	Main cycle		M2000
M3073	Speed switching point specified flag	/	At start		M2040
M3074	All axes servo ON command		Operation cycle		M2042
M3075	Real mode/virtual mode switching request (SV22)		At virtual mode transition		M2043
M3076	JOG operation simultaneous start command			Command signal	M2048
M3077	Manual pulse generator 1 enable flag		NA - in access		M2051
M3078	Manual pulse generator 2 enable flag		Main cycle		M2052
M3079	Manual pulse generator 3 enable flag	/			M2053
M3080	Motion error history clear request flag	/			M2035
M3081 to M3135	Unusable <sup>(Note-3)</sup> (55 points)	_	_	_	

- (Note-1): The state of a device is not in agreement when the device of a remark column is turned ON/OFF directly. In addition, when the request from a data register and the request from the above device are performed simultaneously, the request from the above device becomes effective.
- (Note-2): It can also be ordered the device of a remark column.
- (Note-3): Do not use it as a user device. It can be used as a device that performs automatic refresh because of area for the reserve of command signal.

### **POINT**

The device of a remark column turns ON by OFF to ON of the above device, and turns OFF by ON to OFF of the above device.

The command signal cannot be turned ON/OFF by the PLC CPU in the automatic refresh because the statuses and commands are mixed together in M2000 to M2053. Use the above devices in the case.

And, it can also be turned ON/OFF by the data register. (Refer to Section 4.2.8)

### (9) Axis monitor device list

Axis No.	Device No.		Signal name									
1	D0 to D19											
2	D20 to D39						Virtua	l				
3	D40 to D59	$    \rangle$	<b>O</b>						Real	Refresh	Fetch	Signal
4	D60 to D79		Signal name	Real	Roller	Ball	Rotary	Cam	mode	cycle	cycle	direction
5	D80 to D99	\				screw	table		axis			
6	D100 to D119	0	Feed current									
7	D120 to D139	1	value/roller cycle speed								/	
8	D140 to D159	2	D1							Operation	/	
9	D160 to D179	3	Real current value							cycle	/	
10	D180 to D199	4	Deviation counter value			(	)		0			
11	D200 to D219	5	Deviation counter value									
12	D220 to D239	6	Minor error code							Immediately		
13	D240 to D259	7	Major error code							immediately	] /	
14	D260 to D279	8	Servo error code	0						Main cycle		Monitor
15	D280 to D299	9	Home position return						Backup			device
16	D300 to D319	9	re-travel value			Bar	ckup		Баскир	Operation		
17	D320 to D339	10	Travel value after			Dat	жир			cycle	/	
18	D340 to D359	11	proximity dog ON								/	
19	D360 to D379		Execute program No.				×			At start	/	
20	D380 to D399	13	M-code						0	Operation	1/	
21	D400 to D419	14	Torque limit value			(	)			cycle		
22	D420 to D439	15	Data set pointer for			,	×			At start/	V	
23	D440 to D459		constant-speed control				•			during start	<b>/</b>	
24	D460 to D479	16	Unusable <sup>(Note-1)</sup>	_		_	_		_	_	_	_
25	D480 to D499	17									ļ	
26	D500 to D519		Real current value at	0		Bad	ckup		0	Operation		Monitor
27	D520 to D539	19	stop input				-			cycle		device
28	D540 to D559										○ : Valid	×: Invalid
29	D560 to D579											
30	D580 to D599											
31	D600 to D619											
32	D620 to D639											

(Note-1): It can be used as the travel value change register. The travel value change register can be set to the device optionally in the servo program.

Refer to the "Q173D(S)CPU/Q172D(S)CPU Motion controller (SV13/SV22) Programming Manual (REAL MODE)" for details.

### **POINT**

(1) The following range is valid.

• Q172DSCPU : Axis No.1 to 16 • Q172DCPU(-S1): Axis No.1 to 8

(2) The following device area can be used as a user device.

Q172DSCPU : 17 axes or moreQ172DCPU(-S1): 9 axes or more

However, when the project of Q172DSCPU/Q172DCPU(-S1) is replaced with Q173DSCPU/Q173DCPU(-S1), this area cannot be used as a user device.

## (10) Control change register list

Axis No.	Device No.			Signal	name			
1	D640, D641							
2	D642, D643 D644, D645		Signal name	Real	Virtual	Refresh cycle	Fetch cycle	Signal direction
						Cycle		
4	D646, D647	0	JOG speed setting	0	0		At start	Command
5	D648, D649	1						device
6	D650, D651							○ : Valid
7	D652, D653							
8	D654, D655							
9	D656, D657							
10	D658, D659							
11	D660, D661							
12	D662, D663							
13	D664, D665							
14	D666, D667							
15	D668, D669							
16	D670, D671							
17	D672, D673							
18	D674, D675							
19	D676, D677							
20	D678, D679							
21	D680, D681							
22	D682, D683							
23	D684, D685							
24	D686, D687							
25	D688, D689							
26	D690, D691							
27	D692, D693							
28	D694, D695							
29	D696, D697							
30	D698, D699							
31	D700, D701							
32	D702, D703							

### POINT

(1) The following range is valid.

• Q172DSCPU : Axis No.1 to 16 • Q172DCPU(-S1): Axis No.1 to 8

(2) The following device area can be used as a user device.

Q172DSCPU : 17 axes or moreQ172DCPU(-S1): 9 axes or more

However, when the project of Q172DSCPU/Q172DCPU(-S1) is replaced with Q173DSCPU/Q173DCPU(-S1), this area cannot be used as a user device.

## (11) Virtual servo motor axis monitor device list

Axis No.	Device No.			Signal name									
1	D800 to D809												
2	D810 to D819	١	\			Virtual							
3	D820 to D829			Ciamal mana	Daal		2	D - 4		Real	Refresh	Fetch	Signal
4	D830 to D839		\	Signal name	Real	Roller	Roller Ball Rotary screw table	Cam mo	mode	cycle	cycle	direction	
5	D840 to D849	L	\				screw	lable		axis			
6	D850 to D859		0								Operation		
7	D860 to D869	L	1	Feed current value							cycle		
8	D870 to D879	L	2	Minor error code							Immodiately	/	
9	D880 to D889	L	3	Major error code							Immediately		
10	D890 to D899	L	4	Execute program No.							At start	/	
11	D900 to D909	L	5	M-code	Backup			)		×			Monitor
12	D910 to D919	L	6	Current value after virtual	Баскир					^			device
13	D920 to D929		7	servo motor axis main							Operation		
14	D930 to D939	L	1	shaft's differential gear							cycle		
15	D940 to D949	L	8	Error search output axis No.							Сусіє		
16	D950 to D959		9	Data set pointer for								//	
17	D960 to D969	L	ð	constant-speed control									
18	D970 to D979										0:	Valid,	x: Invalid
19	D980 to D989												
20	D990 to D999												
21	D1000 to D1009												
22	D1010 to D1019												
23	D1020 to D1029												
24	D1030 to D1039												
25	D1040 to D1049												
26	D1050 to D1059												
27	D1060 to D1069												
28	D1070 to D1079												
29	D1080 to D1089												
30	D1090 to D1099												
31	D1100 to D1109												
32	D1100 to D1119												

### POINT

(1) The following range is valid.

Q172DSCPU : Axis No.1 to 16Q172DCPU(-S1): Axis No.1 to 8

(2) The unused axis areas in the mechanical system program can be used as a user device.

## (12) Synchronous encoder axis monitor device list

Axis No.	Device No.			Signal n	ame			
1	D1120 to D1129							
2	D1130 to D1139		Circulation of	Deel	\ /:tul	Refresh	Catab avala	Signal
3	D1140 to D1149		Signal name	Real	Virtual	cycle	Fetch cycle	direction
4	D1150 to D1159	0	Q.,	Backup		Operation		
5	D1160 to D1169	1	Current value	(Note-1)	0	cycle		Monitor
6	D1170 to D1179		Minor error code	Backup		 		device
7	D1180 to D1189	3	3 Major error code			Immediately		
8	D1190 to D1199	4	l leve elele					
9	D1200 to D1209	5	Unusable		_	_	_	_
10	D1210 to D1219	6	Current value after synchronous encoder					
11	D1220 to D1229	7	axis main shaft's differential gear	Backup	0	Operation		Monitor
12	D1230 to D1239	8	Error search output axis No.			cycle		device
		9	Unusable	_	_	_		_
		- <del></del>		•	•	•		○ : Valid
		(No	ote-1): It is valid for the version (Refer to Se value monitor in real mode".	ection 1.4	) that sup	ports "synchr	onous encode	r current

### **POINT**

- (1) It is unusable in the SV22 real mode.
- (2) The range of axis No.1 to 8 is valid in the Q172DCPU(-S1).
- (3) The device area of 9 axes or more can be used as a user device.

  However, when the project of Q172DCPU(-S1) is replaced with Q173DSCPU/Q172DSCPU/Q173DCPU(-S1), this area cannot be used.

## (13) Cam axis monitor device list

Axis No.	Device No.			Signal n	ame			
1	D1240 to D1249							
2	D1250 to D1259		Q: 1	Б.		Refresh		Signal
3	D1260 to D1269		Signal name	Real	Virtual	cycle	Fetch cycle	direction
4	D1270 to D1279	(	Unusable	_	_	_	_	_
5	D1280 to D1289	1	Execute cam No.					
6	D1290 to D1299	2				o "		
7	D1300 to D1309	3	Execute stroke amount	Backup	0	Operation		Monitor device
8	D1310 to D1319	4	Current value within 1 cam shaft			cycle		device
9	D1320 to D1329	5	revolution					
10	D1330 to D1339	6						
11	D1340 to D1349	7	Havaakla					
12	D1350 to D1359	8	Unusable	_	_	_	_	_
13	D1360 to D1369	9						
14	D1370 to D1379							○ : Valid
15	D1380 to D1389							
16	D1390 to D1399							
17	D1400 to D1409							
18	D1410 to D1419							
19	D1420 to D1429							
20	D1430 to D1439							
21	D1440 to D1449							
22	D1450 to D1459							
23	D1460 to D1469							
24	D1470 to D1479							
25	D1480 to D1489							
26	D1490 to D1499							
27	D1500 to D1509							
28	D1510 to D1519							
29	D1520 to D1529							
30	D1530 to D1539							
31	D1540 to D1549							
32	D1550 to D1559							

### POINT

(1) The following range is valid.

Q172DSCPU : Axis No.1 to 16Q172DCPU(-S1): Axis No.1 to 8

(2) The unused axis areas in the mechanical system program can be used as a user device.

## (14) Common device list

Device No.	Signal name	Refresh cycle	Fetch cycle	Signal direction	Device No.	Signal name	Refresh cycle	Fetch cycle	Signal direction
D704	PLC ready flag request				D752	Manual pulse generator 1 smoothing magnification setting register	/		
D705	Speed switching point specified flag request				D753	Manual pulse generator 2 smoothing magnification setting register		At the manual pulse generator enable flag OFF to ON	
D706	All axes servo ON command request		Main cycle	Command device	D754	Manual pulse generator 3 smoothing magnification setting register			Command device
D707	Real mode/virtual mode switching request (SV22) JOG operation simultaneous				D755	Manual pulse generator 1 enable flag request Manual pulse generator 2			
D708 D709	start command request Unusable	_	_	_	D756 D757	enable flag request Manual pulse generator 3		Main cycle	
D710					D758	enable flag request	/		
D711	JOG operation simultaneous				D759				
D712	start axis setting register		At start		D760				
D713		] //			D761				
D714	Manual pulse generator axis	] / /			D762				
D715	1 No. setting register	/			D763				
D716	Manual pulse generator axis	1			D764				
D717	2 No. setting register	/			D765				
D718 D719	Manual pulse generator axis 3 No. setting register	1			D766				
D719	Axis 1	/			D767 D768				
D721	Axis 2				D769				
D722	Axis 3	1			D770				
D723	Axis 4	1			D771				
D724	Axis 5				D772				
D725	Axis 6				D773				
D726 D727	Axis 7 Axis 8				D774 D775				
D728	Axis 9				D776				
D729	Axis 10				D777				
D730	Axis 11			Command	D778	Unusable			
D731	Axis 12			device	D779	(42 points)	_	_	_
D732	Axis 13	1	At the manual pulse generator enable flag		D780				
D733	Axis 14		OFF to ON		D781				
D734	Axis 15 Manual pulse  Axis 16 generators 1 pulse				D782				
D735 D736	Axis 16 input magnification				D783 D784				
D737	Axis 17 setting register (Note-1), (Note-2)				D785				
D738	Axis 19				D786				
D739	Axis 20				D787				
D740	Axis 21				D788				
	Axis 22				D789				
	Axis 23				D790				
D743 D744	Axis 24 Axis 25				D791 D792				
	Axis 26				D792				
	Axis 27				D794				
D747	Axis 28	] [			D795				
D748	Axis 29				D796				
D749	Axis 30	/			D797				
	Axis 31	/			D798				
D751	Axis 32	I .			D799		Note 1): The followi		

(Note-1): The following range is valid.

• Q172DSCPU : Axis No.1 to 16

• Q172DCPU(-S1) : Axis No.1 to 8

(Note-2): The following device area is unusable.

• Q172DSCPU : 17 axes or more

• Q172DCPU(-S1) : 9 axes or more

## (15) Motion register list (#)

Axis No.	Device No.	Signal name									
1	#8000 to #8019										
2	#8020 to #8039	$\overline{}$									
3	#8040 to #8059	\	Signal name	Refresh cycle	Signal direction						
4	#8060 to #8079		Servo amplifier type	When the servo amplifier power-on							
5	#8080 to #8099										
6	#8100 to #8119	2		Operation cycle 1.7[ms] or less : Operation cycle							
7	#8120 to #8139	3	Motor speed	Operation cycle 3.5[ms] or more : 3.5[ms]							
8	#8140 to #8159										
9	#8160 to #8179		Command speed	Operation cycle							
10	#8180 to #8199	6			1						
11	#8200 to #8219	7	· ·	At home position return re-travel	Monitor device						
12	#8220 to #8239		Servo amplifier display servo								
13	#8240 to #8259	3	error code	Main cycle							
14	#8260 to #8279	9	Parameter error No. QDS								
15	#8280 to #8299	1									
16	#8300 to #8319	1	1 Servo status2 QDS	Operation cycle 1.7[ms] or less : Operation cycle							
17	#8320 to #8339	1	2 Servo status3 QDS	Operation cycle 3.5[ms] or more : 3.5[ms]							
18	#8340 to #8359	1	3 Unusable	_							
19	#8360 to #8379	4	4 Comparatotus F (ODS/ Ver)	Operation cycle 1.7[ms] or less : Operation cycle	Manitan dayina						
20	#8380 to #8399	1	4 Servo status5 QDS( Ver.)	Operation cycle 3.5[ms] or more : 3.5[ms]	Monitor device						
21	#8400 to #8419	1	5								
22	#8420 to #8439	1	6 Unusable	_	_						
23	#8440 to #8459	1	7								
24	#8460 to #8479	1	8 Servo status7 QDS( Ver.)	Operation cycle 1.7[ms] or less : Operation cycle	Monitor device						
25	#8480 to #8499	Ľ	Servo Status/	Operation cycle 3.5[ms] or more : 3.5[ms]	ivioriilor device						
26	#8500 to #8519	1	9 Unusable	_	_						
27	#8520 to #8539										
28	#8540 to #8559										
29	#8560 to #8579										
30	#8580 to #8599										
31	#8600 to #8619										
32	#8620 to #8639										

# (16) Product information list devices (#8736 to #8751)

Device No.	Signal name	Refresh cycle	Fetch cycle	Signal direction
#8736				
to	Operating system software version			
#8743		At power supply		Manifest desires
#8744		ON		Monitor device
to	Motion CPU module serial number			
#8751				

Ver.!: Refer to Section 1.4 for the software version that supports this function.

## (17) Special relay list

Device No.	Signal name	Refresh cycle	Fetch cycle	Signal type
SM500	PCPU READY complete flag		/	
SM501	TEST mode ON flag	Main cycle		
SM502	External forced stop input flag	Operation cycle	] /	
SM503	Digital oscilloscope executing flag	Main cycle		
SM506	External forced stop input ON latch flag	Operation cycle	] /	0
SM508	Amplifier-less operation status flag		/	Status signal
SM510	TEST mode request error flag		/	
SM512	Motion CPU WDT error flag	Main cycle	/	
SM513	Manual pulse generator axis setting error flag		/	
SM516	Servo program setting error flag		/	

## (18) Special register list

Device No.	Signal name	Refresh cycle	Fetch cycle	Signal direction
SD200	State of switch		/	
SD500	Real mode axis information register (SV22)	Main cycle		Monitor device
SD501				
SD502	Servo amplifier loading information	At power supply on/		
SD503		operation cycle		
SD504	Real mode/virtual mode switching error information (SV22)	At virtual mode transition		
SD505				
SD506				
SD508	SSCNET control (status)	Main cycle		
SD510	Test mode request error information	At test mode request		
SD511				
SD512	Motion CPU WDT error cause	At Motion CPU		
00012		WDT error occurrence		
SD513	Manual pulse generator axis setting error information	At the manual pulse generator enable flag OFF to ON		
SD514				
SD515				
SD516	Error program No.	At start		
SD517	Error item information	At start		
SD522	Motion operation cycle	Operation cycle	/	
SD523	Operation cycle of the Motion CPU setting	At power supply on		
SD524	Maximum Motion operation cycle QDS	Operation cycle		
SD550	System setting error information	At System setting error		
SD551		occurrence		
SD560	Operation method ODS( Ver)	At power supply on		
SD803	SSCNET control (command)		Main cycle	Command device

Ver.!: Refer to Section 1.4 for the software version that supports this function.

MEMO		

### **WARRANTY**

Please confirm the following product warranty details before using this product.

### 1. Gratis Warranty Term and Gratis Warranty Range

We will repair any failure or defect hereinafter referred to as "failure" in our FA equipment hereinafter referred to as the "Product" arisen during warranty period at no charge due to causes for which we are responsible through the distributor from which you purchased the Product or our service provider. However, we will charge the actual cost of dispatching our engineer for an on-site repair work on request by customer in Japan or overseas countries. We are not responsible for any on-site readjustment and/or trial run that may be required after a defective unit is repaired or replaced.

### [Gratis Warranty Term]

The term of warranty for Product is thirty six (36) months after your purchase or delivery of the Product to a place designated by you or forty two (42) months from the date of manufacture whichever comes first "Warranty Period". Warranty period for repaired Product cannot exceed beyond the original warranty period before any repair work.

### [Gratis Warranty Range]

- (1) You are requested to conduct an initial failure diagnosis by yourself, as a general rule. It can also be carried out by us or our service company upon your request and the actual cost will be charged. However, it will not be charged if we are responsible for the cause of the failure.
- (2) This limited warranty applies only when the condition, method, environment, etc. of use are in compliance with the terms and conditions and instructions that are set forth in the instruction manual and user manual for the Product and the caution label affixed to the Product.
- (3) Even during the term of warranty, the repair cost will be charged on you in the following cases;
  - 1) A failure caused by your improper storing or handling, carelessness or negligence, etc., and a failure caused by your hardware or software problem
  - 2) A failure caused by any alteration, etc. to the Product made on your side without our approval
  - 3) A failure which may be regarded as avoidable, if your equipment in which the Product is incorporated is equipped with a safety device required by applicable laws and has any function or structure considered to be indispensable according to a common sense in the industry
  - 4) A failure which may be regarded as avoidable if consumable parts designated in the instruction manual, etc. are duly maintained and replaced
  - 5) Any replacement of consumable parts (battery, fan, etc.)
  - 6) A failure caused by external factors such as inevitable accidents, including without limitation fire and abnormal fluctuation of voltage, and acts of God, including without limitation earthquake, lightning and natural disasters
  - 7) A failure generated by an unforeseeable cause with a scientific technology that was not available at the time of the shipment of the Product from our company
  - 8) Any other failures which we are not responsible for or which you acknowledge we are not responsible for

### 2. Onerous Repair Term after Discontinuation of Production

(1) We may accept the repair at charge for another seven (7) years after the production of the product is

The announcement of the stop of production for each model can be seen in our Sales and Service, etc.

(2) Please note that the Product (including its spare parts) cannot be ordered after its stop of production.

### 3. Service in overseas countries

Our regional FA Center in overseas countries will accept the repair work of the Product; However, the terms and conditions of the repair work may differ depending on each FA Center. Please ask your local FA center for details.

#### 4. Exclusion of Loss in Opportunity and Secondary Loss from Warranty Liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

#### 5. Change of Product specifications

Specifications listed in our catalogs, manuals or technical documents may be changed without notice.

### 6. Precautions for Choosing the Products

- (1) For the use of our Motion controller, its applications should be those that may not result in a serious damage even if any failure or malfunction occurs in Motion controller, and a backup or fail-safe function should operate on an external system to Motion controller when any failure or malfunction occurs.
- (2) Our Motion controller is designed and manufactured as a general purpose product for use at general industries. Therefore, applications substantially influential on the public interest for such as atomic power plants and other power plants of electric power companies, and also which require a special quality assurance system, including applications for railway companies and government or public offices are not recommended, and we assume no responsibility for any failure caused by these applications when used.
  - In addition, applications which may be substantially influential to human lives or properties for such as airlines, medical treatments, railway service, incineration and fuel systems, man-operated material handling equipment, entertainment machines, safety machines, etc. are not recommended, and we assume no responsibility for any failure caused by these applications when used.
  - We will review the acceptability of the abovementioned applications, if you agree not to require a specific quality for a specific application. Please contact us for consultation.
- (3) Mitsubishi Electric shall have no responsibility or liability for any problems involving programmable controller trouble and system trouble caused by DoS attacks, unauthorized access, computer viruses, and other cyberattacks.

# **INFORMATION AND SERVICES**

For further information and services, please contact your local Mitsubishi Electric sales office or representative. Visit our website to find our locations worldwide.

MITSUBISHI ELECTRIC Factory Automation Global Website Locations Worldwide www.MitsubishiElectric.com/fa/about-us/overseas/

# **TRADEMARKS**

Microsoft and Windows are trademarks of the Microsoft group of companies.

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as '™, or '®, are not specified in this manual.

IB(NA)-0300137-M(2312)MEE

MODEL: Q173D-P-SV22-KASO-E

MODEL CODE: 1XB931

# MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN NAGOYA WORKS: 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA 461-8670, JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.