

Numerical Control (CNC)

PLC Interface Manual

M800V/M80V Series

Introduction

This manual describes the various signal interfaces and functions required to create sequence programs (built-in PLC) of Mitsubishi Electric CNC.

Read this manual thoroughly and understand the product's functions and performance before use.

Supported models of this manual are as follows:

Supported models	Abbreviations in this manual
M800VW Series	M850VW, M830VW
M800VS Series	M850VS, M830VS
M80VW Series	M80VW
M80V Series	M80V TypeA, M80V TypeB

Abbreviations for model names used in this manual are as follows:

Abbreviations	Supported models
M800V, M800V Series	M800VW Series/M800VS Series
M80V, M80V Series	M80VW Series/M80V Series
M800V/M80V, M800V/M80V Series	M800VW Series/M800VS Series/M80VW Series/M80V Series
M8V, M8V Series	M800VW Series/M800VS Series/M80VW Series/M80V Series

To safely use this CNC unit, thoroughly study the "Precautions for Safety" before use.

Be sure to keep this manual on hand so that users can refer to it at any time.

Also refer to the manuals on "Manual List" as necessary.

■ Details described in this manual

(1) "Sequencer" is referred to as "PLC" in some parts of this manual.

Manual List

Manuals related to M800V/M80V Series are listed as follows.

These manuals are written on the assumption that all optional functions are added to the targeted model.

Some functions or screens may not be available depending on the machine or specifications set by MTB. (Confirm the specifications before use.)

The manuals issued by MTB take precedence over these manuals.

Manual	IB No.	Purpose and Contents
M800V/M80V Series Instruction Manual	IB-1501618	<ul style="list-style-type: none">♦ Operation guide for NC♦ Explanation for screen operation, etc.
M800V/M80V Series Programming Manual (Lathe System) (1/2)	IB-1501619	<ul style="list-style-type: none">♦ G code programming for lathe system♦ Basic functions, etc.
M800V/M80V Series Programming Manual (Lathe System) (2/2)	IB-1501620	<ul style="list-style-type: none">♦ G code programming for lathe system♦ Functions for multi-part system, high-accuracy function, etc.
M800V/M80V Series Programming Manual (Machining Center System) (1/2)	IB-1501621	<ul style="list-style-type: none">♦ G code programming for machining center system♦ Basic functions, etc.
M800V/M80V Series Programming Manual (Machining Center System) (2/2)	IB-1501622	<ul style="list-style-type: none">♦ G code programming for machining center system♦ Functions for multi-part system, high-accuracy function, etc.
M800V/M80V Series Alarm/Parameter Manual	IB-1501623	<ul style="list-style-type: none">♦ Alarms♦ Parameters

Manuals for MTBs (NC)

Manual	IB No.	Purpose and Contents
M800V/M80V Series Specifications Manual (Function)	IB-1501610	<ul style="list-style-type: none"> ♦ Model selection ♦ Outline of various functions
M800V/M80V Series Specifications Manual (Hardware)	IB-1501611	<ul style="list-style-type: none"> ♦ Model selection ♦ Specifications of hardware unit
M800VW/M80VW Series Connection and Setup Manual	IB-1501612	<ul style="list-style-type: none"> ♦ Detailed specifications of hardware unit ♦ Installation, connection, wiring, setup (startup/adjustment)
M800VS/M80V Series Connection and Setup Manual	IB-1501613	<ul style="list-style-type: none"> ♦ Detailed specifications of hardware unit ♦ Installation, connection, wiring, setup (startup/adjustment)
M800V/M80V Series PLC Development Manual	IB-1501614	<ul style="list-style-type: none"> ♦ Electrical design ♦ I/O relation (assignment, setting, connection), field network ♦ Development environment (PLC on-board, peripheral development environment), etc.
M800V/M80V Series PLC Programming Manual (1/2)	IB-1501667	<ul style="list-style-type: none"> ♦ Electrical design ♦ Sequence programming ♦ Explanation for instructions, functions, and parameters
M800V/M80V Series PLC Programming Manual (2/2)	IB-1501668	<ul style="list-style-type: none"> ♦ Electrical design ♦ Sequence programming ♦ Usage examples of instructions
M800V/M80V Series PLC Interface Manual	IB-1501616	<ul style="list-style-type: none"> ♦ Electrical design ♦ Interface signals between NC and PLC
M800V/M80V Series Maintenance Manual	IB-1501617	<ul style="list-style-type: none"> ♦ Cleaning and replacement for each unit ♦ Other items related to maintenance

Manuals for MTBs (drive section)

Manual	IB No.	Contents
MDS-E/EH Series Specifications Manual	IB-1501226	<ul style="list-style-type: none"> ♦ Specifications for power supply regeneration type
MDS-E/EH Series Instruction Manual	IB-1501229	<ul style="list-style-type: none"> ♦ Instruction for power supply regeneration type
MDS-EJ/EJH Series Specifications Manual	IB-1501232	<ul style="list-style-type: none"> ♦ Specifications for regenerative resistor type
MDS-EJ/EJH Series Instruction Manual	IB-1501235	<ul style="list-style-type: none"> ♦ Instruction for regenerative resistor type
MDS-EM/EMH Series Specifications Manual	IB-1501238	<ul style="list-style-type: none"> ♦ Specifications for multi-hybrid, power supply regeneration type
MDS-EM/EMH Series Instruction Manual	IB-1501241	<ul style="list-style-type: none"> ♦ Instruction for multi-hybrid, power supply regeneration type
DATA BOOK	IB-1501252	<ul style="list-style-type: none"> ♦ Specifications of servo drive unit, spindle drive unit, motor, etc.
MDS-EX-CVP Series Specifications and Instruction Manual	IB-1501587	<ul style="list-style-type: none"> ♦ Specifications and instruction for the power supply unit with large capacity

Manuals for MTBs (Others)

Manual	No.	Purpose and Contents
GOT2000 Series User's Manual (Hardware)	SH-081194ENG	• Outline of hardware such as part names, external dimensions, installation, wiring, maintenance, etc. of GOTs
GOT2000 Series User's Manual (Utility)	SH-081195ENG	• Outline of utilities such as screen display setting, operation method, etc. of GOTs
GOT2000 Series User's Manual (Monitor)	SH-081196ENG	• Outline of each monitor function of GOTs
GOT2000 Series Connection Manual (Mitsubishi Electric Products)	SH-081197ENG	• Outline of connection types and connection method between GOT and Mitsubishi Electric connection devices
GT Designer3 (GOT2000) Screen Design Manual	SH-081220ENG	• Outline of screen design method using screen creation software GT Designer3
GOT2000/GOT1000 Series CC-Link Communication Unit User's Manual	IB-0800351	• Explanation for handling CC-Link communication unit (for GOT2000 series/GOT1000 series)
GX Developer Version 8 Operating Manual (Startup)	SH-080372E	• Explanation for system configuration, installation, etc. of PLC development tool GX Developer
GX Developer Version 8 Operating Manual	SH-080373E	• Explanation for operations using PLC development tool GX Developer
GX Converter Version 1 Operating Manual	IB-0800004	• Explanation for operations using data conversion tool GX Converter
GX Works2 Installation Instructions	BCN-P5999-0944	• Explanation for the operating environment and installation method of GX Works2
GX Works2 Version 1 Operating Manual (Common)	SH-080779ENG	• Explanation for the system configuration of GX Works2 and the functions common to Simple project and Structured project such as parameter setting, operation method for the online function
GX Works2 Version 1 Operating Manual (Simple Project)	SH-080780ENG	• Explanation for methods for such as creating and monitoring programs in Simple project of GX Works2
MELSEC-Q/L/F Structured Programming Manual (Fundamentals)	SH-080782ENG	• Explanation for programming methods, types of programming languages, etc. required to create structured programs
MELSEC-Q/L Structured Programming Manual (Application Functions)	SH-080784ENG	• Explanation for specifications and functions related to application functions which can be used in structured programs
GX Works2 Version 1 Operating Manual (Simple Project, Function Block)	SH-080984ENG	• Explanation for methods for such as creating function blocks, pasting function blocks to sequence programs, and operating FB library in Simple project of GX Works2
GX Works2 Version 1 Operating Manual (Structured Project)	SH-080781ENG	• Explanation for methods for such as creating and monitoring programs in Structured project of GX Works2
GX Works3 Installation Instructions	BCN-P5999-0391	• Explanation for the operating environment and installation method of GX Works3
MELSEC-Q CC-Link System Master/Local Module User's Manual	SH-080394E	• Explanation for system configuration, installation, wiring, etc. of master/local modules for CC-Link system
GOT2000 Series Connection Manual (Non-Mitsubishi Electric Products 1)	SH-081198ENG	• Explanation for connection types and connection method between GOT and other company's devices
GOT2000 Series Connection Manual (Non-Mitsubishi Electric Products 2)	SH-081199ENG	
GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals)	SH-081200ENG	• Explanation for connection types and connection method between GOT and microcomputers, MODBUS/fieldbus products, peripherals
GT SoftGOT2000 Version1 Operating Manual	SH-081201ENG	• Explanation for system configuration, screen configuration and operation method of monitoring software GT SoftGOT2000
MELSEC iQ-R Programming Manual (CPU Module Instructions, Standard Functions/Function Blocks)	SH-081266ENG	• Explanation for instructions, general-purpose functions, and general-purpose function blocks required for programming the sequencer MELSEC iQ-R series




Reference Manual for MTBs


Manual	No.	Purpose and Contents
M800/M80 Series Smart safety observation Specification manual	BNP-C3072-022	• Explanation for smart safety observation function
M800/M80 Series CC-Link (Master/Local) Specification manual	BNP-C3072-089	• Explanation for CC-Link
M800/M80 Series PROFIBUS-DP Specification manual	BNP-C3072-118	• Explanation for PROFIBUS-DP communication function
M800/M80 Series Interactive cycle insertion (Customization) Specification manual	BNP-C3072-121-0003	• Explanation for interactive cycle insertion
M800/M80 Series EtherNet/IP Specifications manual	BNP-C3072-263	• Explanation for EtherNet/IP
M800/M80 Series CC-Link IE Field (Master/local) Specifications manual	BNP-C3072-283	• Explanation for CC-Link IE Field
M800/M80 Series GOT Connection Specifications manual	BNP-C3072-314	• Explanation for GOT connection
M800/M80 Series CC-Link IE Field Basic Specifications manual	BNP-C3072-337	• Explanation for CC-Link IE Field Basic
M800/M80 Series FL-net Specifications manual	BNP-C3072-368	• Explanation for FL-net
M800/M80 Series Synchronous Control Specifications manual	BNP-C3072-074	• Explanation for synchronous control
M800/M80 Series Multiple-Axis Synchronization Control Specifications manual	BNP-C3072-339	• Explanation for multiple-axis synchronization control

Precautions for Safety



Always read the specifications issued by the machine tool builder, this manual, related manuals and attached documents before installation, operation, programming, maintenance or inspection to ensure correct use. Understand this numerical controller, safety items and cautions before using the unit.



This manual ranks the safety precautions into "DANGER", "WARNING" and "CAUTION".

<div>  DANGER </div> <p>When the user may be subject to imminent fatalities or major injuries if handling is mistaken.</p>
<div>  WARNING </div> <p>When the user may be subject to fatalities or major injuries if handling is mistaken.</p>
<div>  CAUTION </div> <p>When the user may be subject to medium or minor injuries or when only property damage may occur, if handling is mistaken.</p>











Note that even items ranked as "  CAUTION", may lead to serious consequences depending on the situation. All the items are important and must always be observed.

The following signs indicate prohibition and compulsory.

<div>  </div>	<p>This sign indicates prohibited behavior (must not do).</p> <p>For example,  indicates "Keep fire away".</p>
--------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<div>  </div>	<p>This sign indicates a thing that is compulsory (must do).</p> <p>For example,  indicates "it must be grounded".</p>
--------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

The following signs indicate prohibition and compulsory.

<div>  </div> <p>CAUTION</p>	<div>  </div> <p>CAUTION rotated object</p>	<div>  </div> <p>CAUTION HOT</p>	<div>  </div> <p>Danger Electric shock risk</p>	<div>  </div> <p>Danger explosive</p>
<div>  </div> <p>Prohibited</p>	<div>  </div> <p>Disassembly is prohibited</p>	<div>  </div> <p>KEEP FIRE AWAY</p>	<div>  </div> <p>General instruction</p>	<div>  </div> <p>Earth ground</p>

For Safe Use

Mitsubishi Electric CNC is designed and manufactured solely for applications to machine tools to be used for industrial purposes.



Do not use this product in any applications other than those specified above, especially those which are substantially influential on the public interest or which are expected to have significant influence on human lives or properties.

DANGER

Not applicable in this manual.







WARNING

■ Items related to prevention of electric shocks




-  Do not operate the switches with wet hands. Failure to observe this caution could result in electric shocks.
-  Do not damage, apply excessive stress, place heavy things on or sandwich the cables. Failure to observe this caution could result in electric shocks.

CAUTION


■ Items related to product and manual

-  For items described as "Restrictions" or "Usable State" in this manual, the instruction manual issued by the machine tool builder takes precedence over this manual.
 -  Items not described in this manual must be interpreted as "not possible".
 -  This manual is written on the assumption that all the applicable functions are included. Some of them, however, may not be available for your NC system. Refer to the specifications issued by the machine tool builder before use.
 -  Some screens and functions may differ depending on each NC system (or version), and some functions may not be possible. Please confirm the specifications before starting to use.
 -  To protect the availability, integrity and confidentiality of the NC system against cyber-attacks including unauthorized access, denial-of-service (DoS) (*1) attack, and computer virus from external sources via a network, take security measures such as firewall, VPN, and anti-virus software.
- (*1) Denial-of-service (DoS) refers to a type of cyber-attack that disrupts services by overloading the system or by exploiting a vulnerability of the system.
-  Mitsubishi Electric assumes no responsibility for any problems caused to the NC system by any type of cyber-attacks including DoS attack, unauthorized access and computer virus.

■ Items related to connection

-  When using an inductive load such as relays, always connect a diode in parallel to the load as a noise measure.
-  When using a capacitive load such as a lamp, always connect a protective resistor serially to the load to suppress rush currents.
-  Since the analog output R registers are allocated in ascending order of channels and station numbers, the analog output destination may change depending on added option.

■ Items related to design

-  Always turn the spindle phase synchronization completion signal ON before chucking both ends of the workpiece to the reference spindle and synchronized spindle. If the spindle phase synchronization signal is turned ON when both ends of the workpiece are chucked to the reference spindle and synchronized spindle, the chuck or workpiece could be damaged by the torsion that occurs during phase alignment.

! If the temperature rise detection function is invalidated with the parameters, the control could be disabled when the temperature is excessive. This could result in machine damage or personal injuries due to runaway axis, and could damage the device. Enable the detection function for normal use.

Disposal



(Note) This symbol mark is for EU countries only.
This symbol mark is according to the directive 2006/66/EC Article 20 Information for end-users and Annex II.

Your MITSUBISHI ELECTRIC product is designed and manufactured with high quality materials and components which can be recycled and/or reused.

This symbol means that batteries and accumulators, at their end-of-life, should be disposed of separately from your household waste.

If a chemical symbol is printed beneath the symbol shown above, this chemical symbol means that the battery or accumulator contains a heavy metal at a certain concentration. This will be indicated as follows:

Hg: mercury (0,0005%), Cd: cadmium (0,002%), Pb: lead (0,004%)

In the European Union there are separate collection systems for used batteries and accumulators.

Please, dispose of batteries and accumulators correctly at your local community waste collection/recycling centre.

Please, help us to conserve the environment we live in!

Trademarks

MELDAS, MELSEC, EZSocket, EZMotion, iQ Platform, MELSEC iQ-R, MELSOFT, GOT, CC-Link, CC-Link/LT, CC-Link IE, CC-Link IE/field, EcoMonitorLight and SLMP are either trademarks or registered trademarks of Mitsubishi Electric Corporation in Japan and/or other countries.

Ethernet is a registered trademark of Xerox Corporation in the United States and/or other countries.

Microsoft®, Windows®, SQL Server® and Access® are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.

SD logo and SDHC logo are either registered trademarks or trademarks of LLC.

UNIX is a registered trademark of The Open Group in the United States and/or other countries.

Intel® and Pentium® are either trademarks or registered trademarks of Intel Corporation in the United States and/or other countries.

MODBUS® is either a trademark or a registered trademark of Schneider Electric USA, Inc. or the affiliated companies in Japan and/or other countries.

EtherNet/IP is a trademark of Open DeviceNet Vendor Association, Inc.

PROFIBUS-DP is either a trademark or a registered trademark of PROFIBUS User Organization.

Oracle® is a registered trademark of Oracle Corporation, the subsidiaries, or the affiliated companies in the United States and /or other countries.

VNC is a registered trademark of RealVNC Ltd. in the United States and other countries.

QR Code is a registered trademark of DENSO WAVE INCORPORATED.

McAfee is a registered trademark or a trademark of McAfee, LLC or its subsidiaries in the United States and other countries.

Punchtap is licensed by EMUGE.

The term HDMI and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

Wi-Fi is either a trademark or a registered trademark of Wi-Fi Alliance.

BiSS is a registered trademark of iC-Haus GmbH.

Other company and product names that appear in this manual are trademarks or registered trademarks of the respective companies.

本製品の取扱いについて

(日本語 /Japanese)

本製品は工業用 (クラス A) 電磁環境適合機器です。販売者あるいは使用者はこの点に注意し、住商業環境以外での使用をお願いいたします。

Handling of our product

(English)

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

본 제품의 취급에 대해서

(한국어 /Korean)

이 기기는 업무용 (A 급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며 가정외의 지역에 서 사용하는 것을 목적으로 합니다 .

Contents

1 List of Devices	1
1.1 List of Devices	2
1.1.1 Device Range Setting at Multi-project	3
1.2 File Register General Map	5
2 Input/Output Signals with Controller	7
2.1 PLC Input Signals (Bit Type: X***)	10
2.2 PLC Input Signals (Data Type: R***)	36
2.3 PLC Output Signals (Bit Type: Y***)	74
2.4 PLC Output Signals (Data Type: R***)	101
2.5 Special Relay/Special Register	149
2.6 ZR Devices	151
2.7 Classified for Each Application	161
3 Other Devices	169
4 Explanation of Interface Signals	173
4.1 PLC Input Signals (Bit Type: X***)	175
4.2 PLC Input Signals (Data Type: R***)	288
4.3 PLC Output Signals (Bit Type: Y***)	366
4.4 PLC Output Signals (Data Type: R***)	534
4.5 Explanation of Special Relays (SM***)	634
4.6 Explanation of ZR Device	635
4.6.1 Smart Safety Observation	635
4.6.1.1 PLC -> CNC	635
4.6.1.2 CNC -> PLC	653
4.6.2 Memory Switch (PLC Switch)	678
4.6.3 MES Interface Library	679
4.6.4 Diagnosis Data Output	693
4.6.5 Spindle Protection	696
4.6.6 External Encoder Position Output I/F	697
4.6.7 Machine Contact Input/Output I/F	698
4.6.8 BiSS Encoder I/F	701
5 Appx.1: PLC window	703
5.1 Details	704
5.1.1 Read/Write Operation	706
5.2 PLC Window Interface	708
5.2.1 Parameter Interface	708
5.2.2 Read Window Interface	710
5.2.3 Write Window Interface	711
5.2.4 Read Window Expanded Interface	712
5.2.5 Write Window Expanded Interface	713
5.2.6 Interface for Consecutive Writes Detection Log	714
5.3 Data Type	715
5.4 Read/Write PLC Axis Data	716
5.5 Precautions	717
5.6 Usage Example	718
6 Appx.2: List of PLC Window Data	721
6.1 Section No. List	722
6.2 Sub-section No. List	724
7 Appx.3: List of Option Status Exported to PLC	757



List of Devices

1 List of Devices

1.1 List of Devices

1.1 List of Devices

The device range in the following table is the default number of device points set in the project 1 when the multi-project setting or the setting of the number of device points is not performed.

Device	Device No.	Unit	Details
X (*1)	X0 to X1FFF (8192 points)	1 bit	Input signal to PLC: Machine input, etc.
Y (*1)	Y0 to Y1FFF (8192 points)	1 bit	Output signal from PLC: Machine output, etc.
M	M0 to M61439 (61440 points)	1 bit	Temporary memory
F	F0 to F2047 (2048 points)	1 bit	Temporary memory, alarm message interface
L	L0 to L1023 (1024 points)	1 bit	Latch relay (back up memory)
SM	SM0 to SM2047 (2048 points)	1 bit	Special relay
V	V0 to V511 (512 points)	1 bit	Edge relay
SB	SB0 to SB3FF (1024 points)	1 bit	Special relay
B	B0 to BDFFF (57344 points)	1 bit	Link relay
SW	SW0 to SW3FF (1024 points)	16 bits	Special register
SD	SD0 to SD2047 (2048 points)	16 bits	Special register
T	T0 to T2047 (2048 points)	1 bit/16 bits	Timer (The variable/fixed boundary is set with a parameter.) (*2)
ST	ST0 to ST127 (128 points)	1 bit/16 bits	Integrated timer (100 ms unit)
C	C0 to C511 (512 points)	1 bit/16 bits	Counter (The variable/fixed boundary is set with a parameter.)
D	D0 to D4095 (4096 points)	16 bits/32 bits	Data register (Register for calculation)
R (*1)	R0 to R32767 (32768 points)	16 bits/32 bits	File register, CNC word interface
ZR (*1)	ZR0 to ZR13311 (13312 points)	16 bits/32 bits	File register (Input/output signals with the PLC, machine input/output, etc.)
W	W0 to W2FFF (12288 points)	16 bits/32 bits	Link register
Z (*3)	Z0 to Z13/Z0 to Z9 (14 points/10 points)	16 bits	Address index
N	N0 to N7 (8 points)		Master controller nesting level
P (*1)	P0 to P4095 (4096 points)		Label for conditional jump, subroutine call command (*4)
K	K-32768 to K32767		Decimal constant for 16-bit command
	K-2147483648 to K2147483647		Decimal constant for 32-bit command
H	H0 to HFFFF		Hexadecimal constant for 16-bit command
	H0 to HFFFFFFFF		Hexadecimal constant for 32-bit command
E	E±1.17549435-38 to E±3.40282347+38		Real number constant for 16-bit command
	E±2.2250738585072014 - 308 to E±1.7976931348623157+308		Real number constant for 32-bit command
\$	0 to 32 characters		String constant

(*1) These devices have designated applications. Do not use devices other than those corresponding to the input/output signals with the machine side (input/output signals of the remote I/O unit), even if it is an undefined vacant device.

(*2) Distinction of 10 ms timer and 100 ms timer is performed by command.

(10 ms timer is performed by OUTH command, 100 ms timer is performed by OUT command.)

(*3) For the Z device, the number of device points depends on the parameter setting.

(*4) The P device has two types of pointers (local and common), and the above points are the total points.

1 List of Devices**1.1 List of Devices****1.1.1 Device Range Setting at Multi-project**

Each device will be categorized to either the common device among projects (common device among projects) or the independent device for each projects (independent device among projects) when the multi-project function is used.

■ Common device among projects

Device is influenced by the access from the multiple projects.

The number of device points is fixed without being affected by the number of projects.

For example, the X/Y/R devices are common devices among projects.

■ Independent device among projects

Device can be used independently in the multiple projects.

In addition, independent device among projects are categorized into variable points or fixed points device.

[Independent device among projects (Fixed points)]

The number of device points is fixed without being affected by the number of projects.

For example, the SM/SD/Z devices are independent devices among projects (fixed points).

[Independent device among projects (Variable points)]

The maximum number of project is allocated to each project and used.

For example, the M/L/SB devices are independent devices among projects (variable points).

1 List of Devices**1.1 List of Devices**

The list of device categories is as follows.

[Category explanation]

Category	Details
Common	Common device among projects
Independent (fixed)	Independent device among projects (Fixed points)
Independent (variable)	Independent device among projects (Variable points)
Common/independent	Independent device among projects (Variable points) However, it is possible to set as the common device among projects from the top.

[List of categories]

Device	Category	Number of device points (Maximum number of projects)
X	Common	8192 points
Y	Common	8192 points
M	Common/independent	61440 points (122880 points)
L	Independent (variable)	1024 points (2048 points)
F	Common	2048 points
SB	Independent (variable)	1024 points (2048 points)
B	Independent (variable)	57344 points (114688 points)
SM	Independent (fixed)	2048 points
V	Independent (variable)	256 points (1024 points)
SW	Independent (variable)	1024 points (2048 points)
SD	Independent (fixed)	2048 points
T	Independent (variable)	2048 points (4096 points)
ST	Independent (variable)	128 points (256 points)
C	Independent (variable)	512 points (1024 points)
D	Common/independent	4096 points (8192 points)
R	Common	32768 points
ZR	Common	13312 points
W	Independent (variable)	12288 points (24576 points)
Z	Independent (fixed)	14 points
N	Independent (fixed)	15 points
P	Independent (fixed)	4096 points

When the additional specification of "Number of PLC projects: 6" is valid, the number of device points in "()" (parentheses) becomes valid.

Refer to "PLC Programming Manual" for details on the independent device among projects and the common device among projects.

1 List of Devices

1.2 File Register General Map

1.2 File Register General Map

Device	Details
R00000 to R00199	System common data (NC -> PLC)
R00200 to R00499	System common data (PLC -> NC)
R00500 to R00699	1st part system data (NC -> PLC)
R00700 to R00899	2nd part system data (NC -> PLC)
R00900 to R01099	3rd part system data (NC -> PLC)
R01100 to R01299	4th part system data (NC -> PLC)
R01300 to R01499	5th part system data (NC -> PLC)
R01500 to R01699	6th part system data (NC -> PLC)
R01700 to R01899	7th part system data (NC -> PLC)
R01900 to R02099	8th part system data (NC -> PLC)
R02100 to R02397	Pallet program data (Drive unit -> PLC)
R02398 to R02499	System reserve
R02500 to R02699	1st part system data (PLC -> NC)
R02700 to R02899	2nd part system data (PLC -> NC)
R02900 to R03099	3rd part system data (PLC -> NC)
R03100 to R03299	4th part system data (PLC -> NC)
R03300 to R03499	5th part system data (PLC -> NC)
R03500 to R03699	6th part system data (PLC -> NC)
R03700 to R03899	7th part system data (PLC -> NC)
R03900 to R04099	8th part system data (PLC -> NC)
R04100 to R04103	Pallet program data (PLC -> Drive unit)
R04104 to R04499	System reserve
R04500 to R05683	Axis data (NC -> PLC)
R05684 to R05699	System reserve
R05700 to R06371	Axis data (PLC -> NC)
R06372 to R06499	User macro (NC -> PLC: 64 point, PLC -> NC: 64 point)
R06500 to R06549	1st spindle data (NC -> PLC)
R06550 to R06599	2nd spindle data (NC -> PLC)
R06600 to R06649	3rd spindle data (NC -> PLC)
R06650 to R06699	4th spindle data (NC -> PLC)
R06700 to R06749	5th spindle data (NC -> PLC)
R06750 to R06799	6th spindle data (NC -> PLC)
R06800 to R06849	7th spindle data (NC -> PLC)
R06850 to R06899	8th spindle data (NC -> PLC)
R06900 to R06999	System reserve
R07000 to R07049	1st spindle data (PLC -> NC)
R07050 to R07099	2nd spindle data (PLC -> NC)
R07100 to R07149	3rd spindle data (PLC -> NC)
R07150 to R07199	4th spindle data (PLC -> NC)
R07200 to R07249	5th spindle data (PLC -> NC)
R07250 to R07299	6th spindle data (PLC -> NC)
R07300 to R07349	7th spindle data (PLC -> NC)
R07350 to R07399	8th spindle data (PLC -> NC)
R07400 to R07499	System reserve
R07500 to R07949	PLC constants
R07950 to R07999	System reserve
R08000 to R08099	PLC axis indexing
R08100 to R08259	System reserve
R08260 to R08289	Option status export to PLC
R08290 to R08299	Optimum acceleration/deceleration (Spindle)
R08300 to R09799	User backed up area
R09800 to R09899	User work area

1 List of Devices

1.2 File Register General Map

Device	Details
R10000 to R10099	Remote I/O communication error information
R10181 to R10187	System reserve
R10188 to R10189	Base PLC mounting check
R10600 to R12759	ATC data, tool life management for M system/Tool life management I, II for L system
R12760 to R13999	System reserve
R14000 to R14499	EcoMonitorLight data (NC -> PLC)
R14500 to R14699	MES Interface (System common data)
R14700 to R14949	MES Interface (1st part system data) (PLC -> NC)
R14950 to R15199	MES Interface (2nd part system data) (PLC -> NC)
R15200 to R15449	MES Interface (3rd part system data) (PLC -> NC)
R15450 to R15699	MES Interface (4th part system data) (PLC -> NC)
R15700 to R15949	MES Interface (5th part system data) (PLC -> NC)
R15950 to R16199	MES Interface (6th part system data) (PLC -> NC)
R16200 to R16449	MES Interface (7th part system data) (PLC -> NC)
R16450 to R16699	MES Interface (8th part system data) (PLC -> NC)
R16700 to R17299	System reserve
R17300 to R18299	Modbus input/output device
R18300 to R19799	User backed up area
R19800 to R19899	User work area
R19900 to R19999	System reserve
R20000 to R20199	System common data (NC -> PLC)
R20200 to R20499	System common data (PLC -> NC)
R20500 to R20699	1st part system data (NC -> PLC)
R20700 to R20899	2nd part system data (NC -> PLC)
R20900 to R21099	3rd part system data (NC -> PLC)
R21100 to R21299	4th part system data (NC -> PLC)
R21300 to R21499	5th part system data (NC -> PLC)
R21500 to R21699	6th part system data (NC -> PLC)
R21700 to R21899	7th part system data (NC -> PLC)
R21900 to R22099	8th part system data (NC -> PLC)
R22100 to R22499	System reserve
R22500 to R22699	1st part system data (PLC -> NC)
R22700 to R22899	2nd part system data (PLC -> NC)
R22900 to R23099	3rd part system data (PLC -> NC)
R23100 to R23299	4th part system data (PLC -> NC)
R23300 to R23499	5th part system data (PLC -> NC)
R23500 to R23699	6th part system data (PLC -> NC)
R23700 to R23899	7th part system data (PLC -> NC)
R23900 to R24099	8th part system data (PLC -> NC)
R24100 to R24499	System reserve
R24500 to R25683	Axis data (NC -> PLC)
R25684 to R26371	Axis data (PLC -> NC)
R26372 to R27499	System reserve
R27500 to R28299	PLC constants (prepared for specific machine tool builders)
R28300 to R29799	User backed up area
R29800 to R29899	User work area
R29900 to R32767	System reserve

Note

(1) Do not use the system reserve as it is used by Mitsubishi Electric for function expansion.

Input/Output Signals with Controller

Types of Input/Output Signals Tables

The followings are the types of input/output signals tables to be used.

[For devices used commonly by part systems (Sample)]

Device	Abbrev.	Signal name	Device	Abbrev.	Signal name
X720			X728		
X721			X729		
X722		Diagnosis data output completic	X72A		
X723		Collecting diagnosis data	X72B		
X724		In remote program input ▲	X72C		
X725		Remote program input completion▲	X72D		
X726		Remote program input error ▲	X72E		
X727		In tool ID communication ▲	X72F		Power OFF required after parameter change

[For devices used in each part system (Sample)]

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y7A0	Y7A8	Y7B0	Y7B8	*SVF1	Servo OFF 1st axis
Y7A1	Y7A9	Y7B1	Y7B9	*SVF2	2nd axis
Y7A2	Y7AA	Y7B2	Y7BA	*SVF3	3rd axis
Y7A3	Y7AB	Y7B3	Y7BB	*SVF4	4th axis
Y7A4	Y7AC	Y7B4	Y7BC	*SVF5	5th axis
Y7A5	Y7AD	Y7B5	Y7BD	*SVF6	6th axis
Y7A6	Y7AE	Y7B6	Y7BE	*SVF7	7th axis
Y7A7	Y7AF	Y7B7	Y7BF	*SVF8	8th axis

[For devices used in each spindle (Sample)]

Device No.							
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	Abbrev.	Signal name
R6500	R6550	R6600	R6650	R6700	R6750		Spindle command rotation speed input (L)
R6501	R6551	R6601	R6651	R6701	R6751		(H)
R6502	R6552	R6602	R6652	R6702	R6752		Spindle command final data (rotation speed) (L)
R6503	R6553	R6603	R6653	R6703	R6753		(H)
R6504	R6554	R6604	R6654	R6704	R6754		Spindle command final data (12-bit binary) (L)
R6505	R6555	R6605	R6655	R6705	R6755		(H)
R6506	R6556	R6606	R6656	R6706	R6756		Spindle actual speed (L)
R6507	R6557	R6607	R6657	R6707	R6757		(H)

Note

- (1) Signals marked with "*" in the "Abbrev." column are handled as B contacts.
- (2) Signals with "▲" are prepared for a specific machine tool builder.
- (3) Unit is changed by "#1040 M_inch" for the signals marked with [M].
- (4) 2-bit signals are shown with (L)/(H), which indicates Low/High order. Data structure and the descriptions are as follows.

Rn	—	—	Low-order (L)
Rn+1	—	—	High-order (H)

Classification of Input/Output Signals with Controller

There are 1-bit unit, and 16-bit or 32-bit unit controller input/output signals, which are classified as shown below.

When designing, refer to the section indicated below and make allocations according to the table in the respective section.

	Signal type	Explanation	Reference
Input	DI	<ul style="list-style-type: none"> Allocated to device X. Data calculated in bit units are allocated as a principle. Signals with only \$1 or 1stSP section filled are common for all part systems or all spindles. 	2.1 PLC Input Signals (Bit Type: X***)
	Data	<ul style="list-style-type: none"> Allocated to device R. Data handled in 16-bit or 32-bit units is allocated as a principle. 	2.2 PLC Input Signals (Data Type: R***)
Output	DO	<ul style="list-style-type: none"> Allocated to device Y. Data calculated in bit units are allocated as a principle. Signals with only \$1 or 1stSP section filled are common for all part systems or all spindles. 	2.3 PLC Output Signals (Bit Type: Y***)
	Data	<ul style="list-style-type: none"> Allocated to device R. Data handled in 16-bit or 32-bit units is allocated as a principle. 	2.4 PLC Output Signals (Data Type: R***)
Others	Special relay/register	<ul style="list-style-type: none"> Allocated to device SM, SB and SW. The sequence instruction calculation state, results and the signals with special operations are allocated. 	2.5 Special Relay/Special Register
	ZR	<ul style="list-style-type: none"> Allocated to device ZR. Use in the smart safety observation function. 	2.6 ZR Devices
	Classified under purpose	<ul style="list-style-type: none"> Devices are classified under the usage purpose. 	2.7 Classified for Each Application

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

2.1 PLC Input Signals (Bit Type: X***)

Note

(1) Signals with "▲" are prepared for a specific machine tool builder.

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
X2F0	BRST	Board reset			
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
X700	IPCEI1	Power consumption computation: Consumption accumulation ON 1	X708	IPCCC1	Power consumption computation: Clearing consumption accumulation 1 complete
X701	IPCEI2	Power consumption computation: Consumption accumulation ON 2	X709	IPCCC2	Power consumption computation: Clearing consumption accumulation 2 complete
X702	IPCEI3	Power consumption computation: Consumption accumulation ON 3	X70A	IPCCC3	Power consumption computation: Clearing consumption accumulation 3 complete
X703	IPCEI4	Power consumption computation: Consumption accumulation ON 4	X70B	IPCCC4	Power consumption computation: Clearing consumption accumulation 4 complete
X704			X70C		
X705			X70D		
X706			X70E	BATWR	Battery warning
X707		Power OFF processing	X70F	BATAL	Battery alarm
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
X710			X718		
X711	ESTSPF	Optimum acceleration/deceleration parameter switch completion [spindle] ▲	X719		
X712	SMLKO	High-speed simple program check mode ON	X71A		
X713	SPSCO	High-speed simple program check: Coordinate position check ON	X71B		
X714	PNCM-DO	Manual arbitrary reverse run: Actual cutting mode ON	X71C		
X715	PCHKO	Manual arbitrary reverse run mode ON	X71D		
X716	MOREV	Manual arbitrary reverse run: Reverse run ON	X71E		
X717			X71F		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
X720		In sampling trace ▲	X728	MDBUSIF	Modbus/TCP communicating ▲
X721		Sampling trace complete ▲	X729	MDBUSER1	Modbus time-out 1 ▲
X722		Diagnosis data output completion	X72A	MDBUSER2	Modbus time-out 2 ▲
X723		Collecting diagnosis data	X72B	FLNETO	FL-net: Online ▲
X724		In remote program input ▲	X72C		
X725		Remote program input completion ▲	X72D		
X726		Remote program input error ▲	X72E		
X727		In tool ID communication ▲	X72F		Power OFF required after parameter change
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
X730			X738		
X731			X739		
X732			X73A		
X733			X73B		
X734			X73C		
X735			X73D		
X736			X73E		
X737			X73F		

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
X740			X748		
X741			X749		
X742			X74A		
X743			X74B		
X744			X74C		
X745			X74D	MBSTP	Thread, tap block stopping in manual arbitrary reverse run
X746			X74E	MRVNG	Thread, tap reverse run prohibition alarm in manual arbitrary reverse run
X747			X74F		MES interface library: Operation trigger status
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
X750			X758		Pallet program registration Ext. workpiece co-ordinate transfer completion
X751			X759		Graphic check (check method II) in progress
X752	CNOP	24 hours continuous operation	X75A		
X753	MSOE	In multi-step speed monitor	X75B		
X754			X75C		
X755			X75D		
X756			X75E		
X757			X75F		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
X760		\$1 Display	X768		
X761		\$2 Display	X769		
X762		\$3 Display	X76A		
X763		\$4 Display	X76B		
X764		\$5 Display	X76C		
X765		\$6 Display	X76D		
X766		\$7 Display	X76E		
X767		\$8 Display	X76F		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
X770			X778	GBMOD	G/B spindle synchronizing mode
X771	ITF3DTF	Interference check III: Interfering object selection data setting completed	X779	GBSYN	G/B spindle synchronization: Position control synchronizing
X772	ITF3MD	Interference check III: In interference check III mode	X77A	GBPHF	G/B spindle synchronization: Phase alignment complete
X773		Interference check between part systems: Mode is active	X77B	GBPCM	G/B spindle synchronization: Position error compensating
X774			X77C		
X775			X77D		
X776			X77E		
X777			X77F		

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X780	X788	X790	X798	RDY1	Servo ready 1st axis
X781	X789	X791	X799	RDY2	Servo ready 2nd axis
X782	X78A	X792	X79A	RDY3	Servo ready 3rd axis
X783	X78B	X793	X79B	RDY4	Servo ready 4th axis
X784	X78C	X794	X79C	RDY5	Servo ready 5th axis
X785	X78D	X795	X79D	RDY6	Servo ready 6th axis
X786	X78E	X796	X79E	RDY7	Servo ready 7th axis
X787	X78F	X797	X79F	RDY8	Servo ready 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X7A0	X7A8	X7B0	X7B8	AX1	Axis selection 1st axis
X7A1	X7A9	X7B1	X7B9	AX2	Axis selection 2nd axis
X7A2	X7AA	X7B2	X7BA	AX3	Axis selection 3rd axis
X7A3	X7AB	X7B3	X7BB	AX4	Axis selection 4th axis
X7A4	X7AC	X7B4	X7BC	AX5	Axis selection 5th axis
X7A5	X7AD	X7B5	X7BD	AX6	Axis selection 6th axis
X7A6	X7AE	X7B6	X7BE	AX7	Axis selection 7th axis
X7A7	X7AF	X7B7	X7BF	AX8	Axis selection 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X7C0	X7C8	X7D0	X7D8	MVP1	In axis plus motion 1st axis
X7C1	X7C9	X7D1	X7D9	MVP2	In axis plus motion 2nd axis
X7C2	X7CA	X7D2	X7DA	MVP3	In axis plus motion 3rd axis
X7C3	X7CB	X7D3	X7DB	MVP4	In axis plus motion 4th axis
X7C4	X7CC	X7D4	X7DC	MVP5	In axis plus motion 5th axis
X7C5	X7CD	X7D5	X7DD	MVP6	In axis plus motion 6th axis
X7C6	X7CE	X7D6	X7DE	MVP7	In axis plus motion 7th axis
X7C7	X7CF	X7D7	X7DF	MVP8	In axis plus motion 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X7E0	X7E8	X7F0	X7F8	MVM1	In axis minus motion 1st axis
X7E1	X7E9	X7F1	X7F9	MVM2	In axis minus motion 2nd axis
X7E2	X7EA	X7F2	X7FA	MVM3	In axis minus motion 3rd axis
X7E3	X7EB	X7F3	X7FB	MVM4	In axis minus motion 4th axis
X7E4	X7EC	X7F4	X7FC	MVM5	In axis minus motion 5th axis
X7E5	X7ED	X7F5	X7FD	MVM6	In axis minus motion 6th axis
X7E6	X7EE	X7F6	X7FE	MVM7	In axis minus motion 7th axis
X7E7	X7EF	X7F7	X7FF	MVM8	In axis minus motion 8th axis

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.
For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X800	X808	X810	X818	ZP11	1st reference position reached 1st axis
X801	X809	X811	X819	ZP12	1st reference position reached 2nd axis
X802	X80A	X812	X81A	ZP13	1st reference position reached 3rd axis
X803	X80B	X813	X81B	ZP14	1st reference position reached 4th axis
X804	X80C	X814	X81C	ZP15	1st reference position reached 5th axis
X805	X80D	X815	X81D	ZP16	1st reference position reached 6th axis
X806	X80E	X816	X81E	ZP17	1st reference position reached 7th axis
X807	X80F	X817	X81F	ZP18	1st reference position reached 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X820	X828	X830	X838	ZP21	2nd reference position reached 1st axis
X821	X829	X831	X839	ZP22	2nd reference position reached 2nd axis
X822	X82A	X832	X83A	ZP23	2nd reference position reached 3rd axis
X823	X82B	X833	X83B	ZP24	2nd reference position reached 4th axis
X824	X82C	X834	X83C	ZP25	2nd reference position reached 5th axis
X825	X82D	X835	X83D	ZP26	2nd reference position reached 6th axis
X826	X82E	X836	X83E	ZP27	2nd reference position reached 7th axis
X827	X82F	X837	X83F	ZP28	2nd reference position reached 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X840	X848	X850	X858	ZP31	3rd reference position reached 1st axis
X841	X849	X851	X859	ZP32	3rd reference position reached 2nd axis
X842	X84A	X852	X85A	ZP33	3rd reference position reached 3rd axis
X843	X84B	X853	X85B	ZP34	3rd reference position reached 4th axis
X844	X84C	X854	X85C	ZP35	3rd reference position reached 5th axis
X845	X84D	X855	X85D	ZP36	3rd reference position reached 6th axis
X846	X84E	X856	X85E	ZP37	3rd reference position reached 7th axis
X847	X84F	X857	X85F	ZP38	3rd reference position reached 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X860	X868	X870	X878	ZP41	4th reference position reached 1st axis
X861	X869	X871	X879	ZP42	4th reference position reached 2nd axis
X862	X86A	X872	X87A	ZP43	4th reference position reached 3rd axis
X863	X86B	X873	X87B	ZP44	4th reference position reached 4th axis
X864	X86C	X874	X87C	ZP45	4th reference position reached 5th axis
X865	X86D	X875	X87D	ZP46	4th reference position reached 6th axis
X866	X86E	X876	X87E	ZP47	4th reference position reached 7th axis
X867	X86F	X877	X87F	ZP48	4th reference position reached 8th axis

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.
For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X880	X888	X890	X898	NRF1	Near reference position 1st axis
X881	X889	X891	X899	NRF2	Near reference position 2nd axis
X882	X88A	X892	X89A	NRF3	Near reference position 3rd axis
X883	X88B	X893	X89B	NRF4	Near reference position 4th axis
X884	X88C	X894	X89C	NRF5	Near reference position 5th axis
X885	X88D	X895	X89D	NRF6	Near reference position 6th axis
X886	X88E	X896	X89E	NRF7	Near reference position 7th axis
X887	X88F	X897	X89F	NRF8	Near reference position 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X8A0	X8A8	X8B0	X8B8	PLFN1	Arbitrary axis superimposition complete 1st axis
X8A1	X8A9	X8B1	X8B9	PLFN2	Arbitrary axis superimposition complete 2nd axis
X8A2	X8AA	X8B2	X8BA	PLFN3	Arbitrary axis superimposition complete 3rd axis
X8A3	X8AB	X8B3	X8BB	PLFN4	Arbitrary axis superimposition complete 4th axis
X8A4	X8AC	X8B4	X8BC	PLFN5	Arbitrary axis superimposition complete 5th axis
X8A5	X8AD	X8B5	X8BD	PLFN6	Arbitrary axis superimposition complete 6th axis
X8A6	X8AE	X8B6	X8BE	PLFN7	Arbitrary axis superimposition complete 7th axis
X8A7	X8AF	X8B7	X8BF	PLFN8	Arbitrary axis superimposition complete 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X8C0	X8C8	X8D0	X8D8	ZSF1	Zero point initialization set completed 1st axis
X8C1	X8C9	X8D1	X8D9	ZSF2	Zero point initialization set completed 2nd axis
X8C2	X8CA	X8D2	X8DA	ZSF3	Zero point initialization set completed 3rd axis
X8C3	X8CB	X8D3	X8DB	ZSF4	Zero point initialization set completed 4th axis
X8C4	X8CC	X8D4	X8DC	ZSF5	Zero point initialization set completed 5th axis
X8C5	X8CD	X8D5	X8DD	ZSF6	Zero point initialization set completed 6th axis
X8C6	X8CE	X8D6	X8DE	ZSF7	Zero point initialization set completed 7th axis
X8C7	X8CF	X8D7	X8DF	ZSF8	Zero point initialization set completed 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X8E0	X8E8	X8F0	X8F8	ZSE1	Zero point initialization set error completed 1st axis
X8E1	X8E9	X8F1	X8F9	ZSE2	Zero point initialization set error completed 2nd axis
X8E2	X8EA	X8F2	X8FA	ZSE3	Zero point initialization set error completed 3rd axis
X8E3	X8EB	X8F3	X8FB	ZSE4	Zero point initialization set error completed 4th axis
X8E4	X8EC	X8F4	X8FC	ZSE5	Zero point initialization set error completed 5th axis
X8E5	X8ED	X8F5	X8FD	ZSE6	Zero point initialization set error completed 6th axis
X8E6	X8EE	X8F6	X8FE	ZSE7	Zero point initialization set error completed 7th axis
X8E7	X8EF	X8F7	X8FF	ZSE8	Zero point initialization set error completed 8th axis

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.

For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X900	X908	X910	X918	ILI1	In current limit 1st axis
X901	X909	X911	X919	ILI2	In current limit 2nd axis
X902	X90A	X912	X91A	ILI3	In current limit 3rd axis
X903	X90B	X913	X91B	ILI4	In current limit 4th axis
X904	X90C	X914	X91C	ILI5	In current limit 5th axis
X905	X90D	X915	X91D	ILI6	In current limit 6th axis
X906	X90E	X916	X91E	ILI7	In current limit 7th axis
X907	X90F	X917	X91F	ILI8	In current limit 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X920	X928	X930	X938	ILA1	Current limit reached 1st axis
X921	X929	X931	X939	ILA2	Current limit reached 2nd axis
X922	X92A	X932	X93A	ILA3	Current limit reached 3rd axis
X923	X92B	X933	X93B	ILA4	Current limit reached 4th axis
X924	X92C	X934	X93C	ILA5	Current limit reached 5th axis
X925	X92D	X935	X93D	ILA6	Current limit reached 6th axis
X926	X92E	X936	X93E	ILA7	Current limit reached 7th axis
X927	X92F	X937	X93F	ILA8	Current limit reached 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X940	X948	X950	X958	ARRF1	NC axis up-to-speed 1st axis
X941	X949	X951	X959	ARRF2	NC axis up-to-speed 2nd axis
X942	X94A	X952	X95A	ARRF3	NC axis up-to-speed 3rd axis
X943	X94B	X953	X95B	ARRF4	NC axis up-to-speed 4th axis
X944	X94C	X954	X95C	ARRF5	NC axis up-to-speed 5th axis
X945	X94D	X955	X95D	ARRF6	NC axis up-to-speed 6th axis
X946	X94E	X956	X95E	ARRF7	NC axis up-to-speed 7th axis
X947	X94F	X957	X95F	ARRF8	NC axis up-to-speed 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X960	X968	X970	X978	UCLP1	Unclamp command 1st axis
X961	X969	X971	X979	UCLP2	Unclamp command 2nd axis
X962	X96A	X972	X97A	UCLP3	Unclamp command 3rd axis
X963	X96B	X973	X97B	UCLP4	Unclamp command 4th axis
X964	X96C	X974	X97C	UCLP5	Unclamp command 5th axis
X965	X96D	X975	X97D	UCLP6	Unclamp command 6th axis
X966	X96E	X976	X97E	UCLP7	Unclamp command 7th axis
X967	X96F	X977	X97F	UCLP8	Unclamp command 8th axis

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.
For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X980	X988	X990	X998		In mixed control (cross axis control) 1st axis
X981	X989	X991	X999		In mixed control (cross axis control) 2nd axis
X982	X98A	X992	X99A		In mixed control (cross axis control) 3rd axis
X983	X98B	X993	X99B		In mixed control (cross axis control) 4th axis
X984	X98C	X994	X99C		In mixed control (cross axis control) 5th axis
X985	X98D	X995	X99D		In mixed control (cross axis control) 6th axis
X986	X98E	X996	X99E		In mixed control (cross axis control) 7th axis
X987	X98F	X997	X99F		In mixed control (cross axis control) 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X9A0	X9A8	X9B0	X9B8		In synchronous/superimposition control 1st axis
X9A1	X9A9	X9B1	X9B9		In synchronous/superimposition control 2nd axis
X9A2	X9AA	X9B2	X9BA		In synchronous/superimposition control 3rd axis
X9A3	X9AB	X9B3	X9BB		In synchronous/superimposition control 4th axis
X9A4	X9AC	X9B4	X9BC		In synchronous/superimposition control 5th axis
X9A5	X9AD	X9B5	X9BD		In synchronous/superimposition control 6th axis
X9A6	X9AE	X9B6	X9BE		In synchronous/superimposition control 7th axis
X9A7	X9AF	X9B7	X9BF		In synchronous/superimposition control 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X9C0	X9C8	X9D0	X9D8	MIR1	In mirror image 1st axis
X9C1	X9C9	X9D1	X9D9	MIR2	In mirror image 2nd axis
X9C2	X9CA	X9D2	X9DA	MIR3	In mirror image 3rd axis
X9C3	X9CB	X9D3	X9DB	MIR4	In mirror image 4th axis
X9C4	X9CC	X9D4	X9DC	MIR5	In mirror image 5th axis
X9C5	X9CD	X9D5	X9DD	MIR6	In mirror image 6th axis
X9C6	X9CE	X9D6	X9DE	MIR7	In mirror image 7th axis
X9C7	X9CF	X9D7	X9DF	MIR8	In mirror image 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
X9E0	X9E8	X9F0	X9F8		Reference position establishment 1st axis
X9E1	X9E9	X9F1	X9F9		Reference position establishment 2nd axis
X9E2	X9EA	X9F2	X9FA		Reference position establishment 3rd axis
X9E3	X9EB	X9F3	X9FB		Reference position establishment 4th axis
X9E4	X9EC	X9F4	X9FC		Reference position establishment 5th axis
X9E5	X9ED	X9F5	X9FD		Reference position establishment 6th axis
X9E6	X9EE	X9F6	X9FE		Reference position establishment 7th axis
X9E7	X9EF	X9F7	X9FF		Reference position establishment 8th axis

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.

For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
XA00	XA08	XA10	XA18		Reference position return direction 1st axis
XA01	XA09	XA11	XA19		Reference position return direction 2nd axis
XA02	XA0A	XA12	XA1A		Reference position return direction 3rd axis
XA03	XA0B	XA13	XA1B		Reference position return direction 4th axis
XA04	XA0C	XA14	XA1C		Reference position return direction 5th axis
XA05	XA0D	XA15	XA1D		Reference position return direction 6th axis
XA06	XA0E	XA16	XA1E		Reference position return direction 7th axis
XA07	XA0F	XA17	XA1F		Reference position return direction 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
XA20	XA28	XA30	XA38		In NC axis control 1st axis
XA21	XA29	XA31	XA39		In NC axis control 2nd axis
XA22	XA2A	XA32	XA3A		In NC axis control 3rd axis
XA23	XA2B	XA33	XA3B		In NC axis control 4th axis
XA24	XA2C	XA34	XA3C		In NC axis control 5th axis
XA25	XA2D	XA35	XA3D		In NC axis control 6th axis
XA26	XA2E	XA36	XA3E		In NC axis control 7th axis
XA27	XA2F	XA37	XA3F		In NC axis control 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
XA40	XA48	XA50	XA58	ECIL1	Ext. machine coordinate system offset data illegal 1st axis
XA41	XA49	XA51	XA59	ECIL2	Ext. machine coordinate system offset data illegal 2nd axis
XA42	XA4A	XA52	XA5A	ECIL3	Ext. machine coordinate system offset data illegal 3rd axis
XA43	XA4B	XA53	XA5B	ECIL4	Ext. machine coordinate system offset data illegal 4th axis
XA44	XA4C	XA54	XA5C	ECIL5	Ext. machine coordinate system offset data illegal 5th axis
XA45	XA4D	XA55	XA5D	ECIL6	Ext. machine coordinate system offset data illegal 6th axis
XA46	XA4E	XA56	XA5E	ECIL7	Ext. machine coordinate system offset data illegal 7th axis
XA47	XA4F	XA57	XA5F	ECIL8	Ext. machine coordinate system offset data illegal 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
XA60	XA68	XA70	XA78		Vertical axis pull-up prevented 1st axis
XA61	XA69	XA71	XA79		Vertical axis pull-up prevented 2nd axis
XA62	XA6A	XA72	XA7A		Vertical axis pull-up prevented 3rd axis
XA63	XA6B	XA73	XA7B		Vertical axis pull-up prevented 4th axis
XA64	XA6C	XA74	XA7C		Vertical axis pull-up prevented 5th axis
XA65	XA6D	XA75	XA7D		Vertical axis pull-up prevented 6th axis
XA66	XA6E	XA76	XA7E		Vertical axis pull-up prevented 7th axis
XA67	XA6F	XA77	XA7F		Vertical axis pull-up prevented 8th axis

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.

For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
XA80	XA88	XA90	XA98		Mirror image status 1st axis ▲
XA81	XA89	XA91	XA99		Mirror image status 2nd axis ▲
XA82	XA8A	XA92	XA9A		Mirror image status 3rd axis ▲
XA83	XA8B	XA93	XA9B		Mirror image status 4th axis ▲
XA84	XA8C	XA94	XA9C		Mirror image status 5th axis ▲
XA85	XA8D	XA95	XA9D		Mirror image status 6th axis ▲
XA86	XA8E	XA96	XA9E		Mirror image status 7th axis ▲
XA87	XA8F	XA97	XA9F		Mirror image status 8th axis ▲
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
XAC0	XAC8	XAD0	XAD8	CRSWT1	Mixed control (cross axis control): Waiting for target axis travel completion (1st axis) ▲
XAC1	XAC9	XAD1	XAD9	CRSWT2	Mixed control (cross axis control): Waiting for target axis travel completion (2nd axis) ▲
XAC2	XACA	XAD2	XADA	CRSWT3	Mixed control (cross axis control): Waiting for target axis travel completion (3rd axis) ▲
XAC3	XACB	XAD3	XADB	CRSWT4	Mixed control (cross axis control): Waiting for target axis travel completion (4th axis) ▲
XAC4	XACC	XAD4	XADC	CRSWT5	Mixed control (cross axis control): Waiting for target axis travel completion (5th axis) ▲
XAC5	XACD	XAD5	XADD	CRSWT6	Mixed control (cross axis control): Waiting for target axis travel completion (6th axis) ▲
XAC6	XACE	XAD6	XADE	CRSWT7	Mixed control (cross axis control): Waiting for target axis travel completion (7th axis) ▲
XAC7	XACF	XAD7	XADF	CRSWT8	Mixed control (cross axis control): Waiting for target axis travel completion (8th axis) ▲
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
XAE0	XAE8	XAF0	XAF8	CRSAL1	Mixed control (cross axis control): Alarm complete (1st axis) ▲
XAE1	XAE9	XAF1	XAF9	CRSAL2	Mixed control (cross axis control): Alarm complete (2nd axis) ▲
XAE2	XAEA	XAF2	XAFA	CRSAL3	Mixed control (cross axis control): Alarm complete (3rd axis) ▲
XAE3	XAEB	XAF3	XAFB	CRSAL4	Mixed control (cross axis control): Alarm complete (4th axis) ▲
XAE4	XAEC	XAF4	XAFC	CRSAL5	Mixed control (cross axis control): Alarm complete (5th axis) ▲
XAE5	XAED	XAF5	XAFD	CRSAL6	Mixed control (cross axis control): Alarm complete (6th axis) ▲
XAE6	XAEE	XAF6	XAFE	CRSAL7	Mixed control (cross axis control): Alarm complete (7th axis) ▲
XAE7	XAEF	XAF7	XAFF	CRSAL8	Mixed control (cross axis control): Alarm complete (8th axis) ▲

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.
For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
XB00	XB08	XB10	XB18	CLP1	Clamp command 1st axis
XB01	XB09	XB11	XB19	CLP2	Clamp command 2nd axis
XB02	XB0A	XB12	XB1A	CLP3	Clamp command 3rd axis
XB03	XB0B	XB13	XB1B	CLP4	Clamp command 4th axis
XB04	XB0C	XB14	XB1C	CLP5	Clamp command 5th axis
XB05	XB0D	XB15	XB1D	CLP6	Clamp command 6th axis
XB06	XB0E	XB16	XB1E	CLP7	Clamp command 7th axis
XB07	XB0F	XB17	XB1F	CLP8	Clamp command 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
XB40	XB48	XB50	XB58	ROTSPM1	Spindle-mode rotary axis control mode 1st axis
XB41	XB49	XB51	XB59	ROTSPM2	Spindle-mode rotary axis control mode 2nd axis
XB42	XB4A	XB52	XB5A	ROTSPM3	Spindle-mode rotary axis control mode 3rd axis
XB43	XB4B	XB53	XB5B	ROTSPM4	Spindle-mode rotary axis control mode 4th axis
XB44	XB4C	XB54	XB5C	ROTSPM5	Spindle-mode rotary axis control mode 5th axis
XB45	XB4D	XB55	XB5D	ROTSPM6	Spindle-mode rotary axis control mode 6th axis
XB46	XB4E	XB56	XB5E	ROTSPM7	Spindle-mode rotary axis control mode 7th axis
XB47	XB4F	XB57	XB5F	ROTSPM8	Spindle-mode rotary axis control mode 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
XB60	XB68	XB70	XB78	AXINP1	Each axis in-position 1st axis
XB61	XB69	XB71	XB79	AXINP2	Each axis in-position 2nd axis
XB62	XB6A	XB72	XB7A	AXINP3	Each axis in-position 3rd axis
XB63	XB6B	XB73	XB7B	AXINP4	Each axis in-position 4th axis
XB64	XB6C	XB74	XB7C	AXINP5	Each axis in-position 5th axis
XB65	XB6D	XB75	XB7D	AXINP6	Each axis in-position 6th axis
XB66	XB6E	XB76	XB7E	AXINP7	Each axis in-position 7th axis
XB67	XB6F	XB77	XB7F	AXINP8	Each axis in-position 8th axis

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.

For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
XB80	XB88	XB90	XB98	VGHLD1	Real-time tuning 1: Speed control gain changeover hold-down ON 1st axis
XB81	XB89	XB91	XB99	VGHLD2	Real-time tuning 1: Speed control gain changeover hold-down ON 2nd axis
XB82	XB8A	XB92	XB9A	VGHLD3	Real-time tuning 1: Speed control gain changeover hold-down ON 3rd axis
XB83	XB8B	XB93	XB9B	VGHLD4	Real-time tuning 1: Speed control gain changeover hold-down ON 4th axis
XB84	XB8C	XB94	XB9C	VGHLD5	Real-time tuning 1: Speed control gain changeover hold-down ON 5th axis
XB85	XB8D	XB95	XB9D	VGHLD6	Real-time tuning 1: Speed control gain changeover hold-down ON 6th axis
XB86	XB8E	XB96	XB9E	VGHLD7	Real-time tuning 1: Speed control gain changeover hold-down ON 7th axis
XB87	XB8F	XB97	XB9F	VGHLD8	Real-time tuning 1: Speed control gain changeover hold-down ON 8th axis

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
XBA0	XBA8	XBB0	XBB8	NPCHGIS1	NC axis/PLC axis switchover invalid status 1st axis
XBA1	XBA9	XBB1	XBB9	NPCHGIS2	NC axis/PLC axis switchover invalid status 2nd axis
XBA2	XBA A	XBB2	XBB A	NPCHGIS3	NC axis/PLC axis switchover invalid status 3rd axis
XBA3	XBA B	XBB3	XBB B	NPCHGIS4	NC axis/PLC axis switchover invalid status 4th axis
XBA4	XBA C	XBB4	XBB C	NPCHGIS5	NC axis/PLC axis switchover invalid status 5th axis
XBA5	XBA D	XBB5	XBB D	NPCHGIS6	NC axis/PLC axis switchover invalid status 6th axis
XBA6	XBA E	XBB6	XBB E	NPCHGIS7	NC axis/PLC axis switchover invalid status 7th axis
XBA7	XBA F	XBB7	XBB F	NPCHGIS8	NC axis/PLC axis switchover invalid status 8th axis

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
XBC0	XBC8	XBD0	XBD8	NPCHGMOD1	NC axis/PLC axis switchover 1st axis in process
XBC1	XBC9	XBD1	XBD9	NPCHGMOD2	NC axis/PLC axis switchover 2nd axis in process
XBC2	XBC A	XBD2	XBD A	NPCHGMOD3	NC axis/PLC axis switchover 3rd axis in process
XBC3	XBC B	XBD3	XBD B	NPCHGMOD4	NC axis/PLC axis switchover 4th axis in process
XBC4	XBC C	XBD4	XBD C	NPCHGMOD5	NC axis/PLC axis switchover 5th axis in process
XBC5	XBC D	XBD5	XBD D	NPCHGMOD6	NC axis/PLC axis switchover 6th axis in process
XBC6	XBC E	XBD6	XBD E	NPCHGMOD7	NC axis/PLC axis switchover 7th axis in process
XBC7	XBC F	XBD7	XBD F	NPCHGMOD8	NC axis/PLC axis switchover 8th axis in process

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
XBE0	XBE8	XBF0	XBF8	GQEMGO1	Machine group-based alarm stop: Machine group-based PLC interlock ON 1st axis
XBE1	XBE9	XBF1	XBF9	GQEMGO2	Machine group-based alarm stop: Machine group-based PLC interlock ON 2nd axis
XBE2	XBE A	XBF2	XBF A	GQEMGO3	Machine group-based alarm stop: Machine group-based PLC interlock ON 3rd axis
XBE3	XBE B	XBF3	XBF B	GQEMGO4	Machine group-based alarm stop: Machine group-based PLC interlock ON 4th axis
XBE4	XBE C	XBF4	XBF C	GQEMGO5	Machine group-based alarm stop: Machine group-based PLC interlock ON 5th axis
XBE5	XBE D	XBF5	XBF D	GQEMGO6	Machine group-based alarm stop: Machine group-based PLC interlock ON 6th axis
XBE6	XBE E	XBF6	XBF E	GQEMGO7	Machine group-based alarm stop: Machine group-based PLC interlock ON 7th axis
XBE7	XBE F	XBF7	XBF F	GQEMGO8	Machine group-based alarm stop: Machine group-based PLC interlock ON 8th axis

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.

For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC00	XD40	XE80	XFC0	X1100	X1240	X1380	X14C0	JO	In jog mode
XC01	XD41	XE81	XFC1	X1101	X1241	X1381	X14C1	HO	In handle mode
XC02	XD42	XE82	XFC2	X1102	X1242	X1382	X14C2	SO	In incremental mode
XC03	XD43	XE83	XFC3	X1103	X1243	X1383	X14C3	PTPO	In manual arbitrary feed mode
XC04	XD44	XE84	XFC4	X1104	X1244	X1384	X14C4	ZRNO	In reference position return mode
XC05	XD45	XE85	XFC5	X1105	X1245	X1385	X14C5	ASTO	In automatic initial set mode
XC06	XD46	XE86	XFC6	X1106	X1246	X1386	X14C6		In JOG-handle simultaneous mode
XC07	XD47	XE87	XFC7	X1107	X1247	X1387	X14C7		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC08	XD48	XE88	XFC8	X1108	X1248	X1388	X14C8	MEMO	In memory mode
XC09	XD49	XE89	XFC9	X1109	X1249	X1389	X14C9	TO	In tape mode
XC0A	XD4A	XE8A	XFCA	X110A	X124A	X138A	X14CA		In online operation mode
XC0B	XD4B	XE8B	XFCB	X110B	X124B	X138B	X14CB	DO	In MDI mode
XC0C	XD4C	XE8C	XFCC	X110C	X124C	X138C	X14CC		
XC0D	XD4D	XE8D	XFCD	X110D	X124D	X138D	X14CD		
XC0E	XD4E	XE8E	XFCE	X110E	X124E	X138E	X14CE	SBSMO	Sub part system control: Sub part system control I mode ON
XC0F	XD4F	XE8F	XFCF	X110F	X124F	X138F	X14CF		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC10	XD50	XE90	XFD0	X1110	X1250	X1390	X14D0	MA	Controller ready completion
XC11	XD51	XE91	XFD1	X1111	X1251	X1391	X14D1	SA	Servo ready completion
XC12	XD52	XE92	XFD2	X1112	X1252	X1392	X14D2	OP	In automatic operation "run"
XC13	XD53	XE93	XFD3	X1113	X1253	X1393	X14D3	STL	In automatic operation "start"
XC14	XD54	XE94	XFD4	X1114	X1254	X1394	X14D4	SPL	In automatic operation "pause"
XC15	XD55	XE95	XFD5	X1115	X1255	X1395	X14D5	RST	In "reset"
XC16	XD56	XE96	XFD6	X1116	X1256	X1396	X14D6	CXN	In manual arbitrary feed
XC17	XD57	XE97	XFD7	X1117	X1257	X1397	X14D7	RWD	In rewind
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC18	XD58	XE98	XFD8	X1118	X1258	X1398	X14D8	DEN	Motion command completion
XC19	XD59	XE99	XFD9	X1119	X1259	X1399	X14D9	TIMP	All axes in-position
XC1A	XD5A	XE9A	XFDA	X111A	X125A	X139A	X14DA	TSMZ	All axes smoothing zero
XC1B	XD5B	XE9B	XFDB	X111B	X125B	X139B	X14DB		
XC1C	XD5C	XE9C	XFDC	X111C	X125C	X139C	X14DC	CXFIN	Manual arbitrary feed completion
XC1D	XD5D	XE9D	XFDD	X111D	X125D	X139D	X14DD		External search finished
XC1E	XD5E	XE9E	XFDE	X111E	X125E	X139E	X14DE		
XC1F	XD5F	XE9F	XPDF	X111F	X125F	X139F	X14DF		In high-speed machining mode (G05)

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC20	XD60	XEA0	XFE0	X1120	X1260	X13A0	X14E0	RPN	In rapid traverse
XC21	XD61	XEA1	XFE1	X1121	X1261	X13A1	X14E1	CUT	In cutting feed
XC22	XD62	XEA2	XFE2	X1122	X1262	X13A2	X14E2	TAP	In tapping
XC23	XD63	XEA3	XFE3	X1123	X1263	X13A3	X14E3	THRD	In thread cutting
XC24	XD64	XEA4	XFE4	X1124	X1264	X13A4	X14E4	SYN	In synchronous feed
XC25	XD65	XEA5	XFE5	X1125	X1265	X13A5	X14E5	CSS	In constant surface speed
XC26	XD66	XEA6	XFE6	X1126	X1266	X13A6	X14E6	SKIP	In skip
XC27	XD67	XEA7	XFE7	X1127	X1267	X13A7	X14E7	ZRNN	In reference position return
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC28	XD68	XEA8	XFE8	X1128	X1268	X13A8	X14E8	INCH	In inch unit selection
XC29	XD69	XEA9	XFE9	X1129	X1269	X13A9	X14E9	DLKN	In display lock
XC2A	XD6A	XEA	XFE	X112A	X126A	X13AA	X14EA	F1DN	F 1-digit commanded
XC2B	XD6B	XEAB	XFEB	X112B	X126B	X13AB	X14EB	TLFO	In tool life management
XC2C	XD6C	XEAC	XFEC	X112C	X126C	X13AC	X14EC		Tool life management: Temporary cancel of tool life expiration ON
XC2D	XD6D	XEAD	XFED	X112D	X126D	X13AD	X14ED		Tool life management: Temporary cancel of tool group life expiration ON
XC2E	XD6E	XEAE	XFEE	X112E	X126E	X13AE	X14EE	TLOV	Tool life over
XC2F	XD6F	XEAF	XFEE	X112F	X126F	X13AF	X14EF		Tool group life over
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC30	XD70	XEB0	XFF0	X1130	X1270	X13B0	X14F0	F11	F1-digit No. code 1
XC31	XD71	XEB1	XFF1	X1131	X1271	X13B1	X14F1	F12	F1-digit No. code 2
XC32	XD72	XEB2	XFF2	X1132	X1272	X13B2	X14F2	F14	F1-digit No. code 4
XC33	XD73	XEB3	XFF3	X1133	X1273	X13B3	X14F3	F18	F1-digit No. code 8
XC34	XD74	XEB4	XFF4	X1134	X1274	X13B4	X14F4		Timing synchronization between part systems
XC35	XD75	XEB5	XFF5	X1135	X1275	X13B5	X14F5	PCINO	In PLC interrupt
XC36	XD76	XEB6	XFF6	X1136	X1276	X13B6	X14F6		
XC37	XD77	XEB7	XFF7	X1137	X1277	X13B7	X14F7	ASLE	Illegal axis selected
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC38	XD78	XEB8	XFF8	X1138	X1278	X13B8	X14F8		
XC39	XD79	XEB9	XFF9	X1139	X1279	X13B9	X14F9		
XC3A	XD7A	XEBA	XFFA	X113A	X127A	X13BA	X14FA		
XC3B	XD7B	XEBB	XFFB	X113B	X127B	X13BB	X14FB		
XC3C	XD7C	XEBC	XFFC	X113C	X127C	X13BC	X14FC		
XC3D	XD7D	XEBD	XFFD	X113D	X127D	X13BD	X14FD		
XC3E	XD7E	XEBE	XFFE	X113E	X127E	X13BE	X14FE		
XC3F	XD7F	XEBF	XFFF	X113F	X127F	X13BF	X14FF		

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC40	XD80	XEC0	X1000	X1140	X1280	X13C0	X1500	DM00	M code independent output M00
XC41	XD81	XEC1	X1001	X1141	X1281	X13C1	X1501	DM01	M code independent output M01
XC42	XD82	XEC2	X1002	X1142	X1282	X13C2	X1502	DM02	M code independent output M02
XC43	XD83	XEC3	X1003	X1143	X1283	X13C3	X1503	DM30	M code independent output M30
XC44	XD84	XEC4	X1004	X1144	X1284	X13C4	X1504		
XC45	XD85	XEC5	X1005	X1145	X1285	X13C5	X1505		
XC46	XD86	XEC6	X1006	X1146	X1286	X13C6	X1506		
XC47	XD87	XEC7	X1007	X1147	X1287	X13C7	X1507		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC48	XD88	XEC8	X1008	X1148	X1288	X13C8	X1508		In manual speed command valid
XC49	XD89	XEC9	X1009	X1149	X1289	X13C9	X1509	MMS	Manual numerical command
XC4A	XD8A	XECA	X100A	X114A	X128A	X13CA	X150A		In tool escape and return mode
XC4B	XD8B	XECB	X100B	X114B	X128B	X13CB	X150B		
XC4C	XD8C	XECC	X100C	X114C	X128C	X13CC	X150C		
XC4D	XD8D	XECD	X100D	X114D	X128D	X13CD	X150D		
XC4E	XD8E	XECE	X100E	X114E	X128E	X13CE	X150E	SBS	Sub part system control: Sub part system processing
XC4F	XD8F	XECF	X100F	X114F	X128F	X13CF	X150F		In circular feed in manual mode
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC50	XD90	XED0	X1010	X1150	X1290	X13D0	X1510		
XC51	XD91	XED1	X1011	X1151	X1291	X13D1	X1511		
XC52	XD92	XED2	X1012	X1152	X1292	X13D2	X1512		
XC53	XD93	XED3	X1013	X1153	X1293	X13D3	X1513	TRTN2	In tool retract and return 2 mode ▲
XC54	XD94	XED4	X1014	X1154	X1294	X13D4	X1514		
XC55	XD95	XED5	X1015	X1155	X1295	X13D5	X1515		
XC56	XD96	XED6	X1016	X1156	X1296	X13D6	X1516		
XC57	XD97	XED7	X1017	X1157	X1297	X13D7	X1517		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC58	XD98	XED8	X1018	X1158	X1298	X13D8	X1518		
XC59	XD99	XED9	X1019	X1159	X1299	X13D9	X1519		
XC5A	XD9A	XEDA	X101A	X115A	X129A	X13DA	X151A		
XC5B	XD9B	XEDB	X101B	X115B	X129B	X13DB	X151B		
XC5C	XD9C	XEDC	X101C	X115C	X129C	X13DC	X151C		
XC5D	XD9D	XEDD	X101D	X115D	X129D	X13DD	X151D		
XC5E	XD9E	XEDE	X101E	X115E	X129E	X13DE	X151E		
XC5F	XD9F	XEDF	X101F	X115F	X129F	X13DF	X151F		Coordinate rotation by parameter: Manual feed coordinate system

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC60	XDA0	XEE0	X1020	X1160	X12A0	X13E0	X1520	MF1	M function strobe 1
XC61	XDA1	XEE1	X1021	X1161	X12A1	X13E1	X1521	MF2	M function strobe 2
XC62	XDA2	XEE2	X1022	X1162	X12A2	X13E2	X1522	MF3	M function strobe 3
XC63	XDA3	XEE3	X1023	X1163	X12A3	X13E3	X1523	MF4	M function strobe 4
XC64	XDA4	XEE4	X1024	X1164	X12A4	X13E4	X1524	SF1	S function strobe 1
XC65	XDA5	XEE5	X1025	X1165	X12A5	X13E5	X1525	SF2	S function strobe 2
XC66	XDA6	XEE6	X1026	X1166	X12A6	X13E6	X1526	SF3	S function strobe 3
XC67	XDA7	XEE7	X1027	X1167	X12A7	X13E7	X1527	SF4	S function strobe 4
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC68	XDA8	XEE8	X1028	X1168	X12A8	X13E8	X1528	TF1	T function strobe 1
XC69	XDA9	XEE9	X1029	X1169	X12A9	X13E9	X1529	TF2	T function strobe 2
XC6A	XDAA	XEEA	X102A	X116A	X12AA	X13EA	X152A	TF3	T function strobe 3
XC6B	XDAB	XEEB	X102B	X116B	X12AB	X13EB	X152B	TF4	T function strobe 4
XC6C	XDAC	XEEC	X102C	X116C	X12AC	X13EC	X152C	BF1	2nd M function strobe 1
XC6D	XDAD	XEED	X102D	X116D	X12AD	X13ED	X152D	BF2	2nd M function strobe 2
XC6E	XDAE	XEEE	X102E	X116E	X12AE	X13EE	X152E	BF3	2nd M function strobe 3
XC6F	XDAF	XEEF	X102F	X116F	X12AF	X13EF	X152F	BF4	2nd M function strobe 4
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC70	XDB0	XEF0	X1030	X1170	X12B0	X13F0	X1530	SF5	S function strobe 5
XC71	XDB1	XEF1	X1031	X1171	X12B1	X13F1	X1531	SF6	S function strobe 6
XC72	XDB2	XEF2	X1032	X1172	X12B2	X13F2	X1532	SF7	S function strobe 7
XC73	XDB3	XEF3	X1033	X1173	X12B3	X13F3	X1533	SF8	S function strobe 8
XC74	XDB4	XEF4	X1034	X1174	X12B4	X13F4	X1534		
XC75	XDB5	XEF5	X1035	X1175	X12B5	X13F5	X1535		
XC76	XDB6	XEF6	X1036	X1176	X12B6	X13F6	X1536		
XC77	XDB7	XEF7	X1037	X1177	X12B7	X13F7	X1537		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC78	XDB8	XEF8	X1038	X1178	X12B8	X13F8	X1538		
XC79	XDB9	XEF9	X1039	X1179	X12B9	X13F9	X1539		
XC7A	XDBA	XEFA	X103A	X117A	X12BA	X13FA	X153A		
XC7B	XDBB	XEFB	X103B	X117B	X12BB	X13FB	X153B		
XC7C	XDBC	XEFC	X103C	X117C	X12BC	X13FC	X153C		
XC7D	XDBD	XEFD	X103D	X117D	X12BD	X13FD	X153D		
XC7E	XDBE	XEFE	X103E	X117E	X12BE	X13FE	X153E		
XC7F	XDBF	XEFF	X103F	X117F	X12BF	X13FF	X153F	CHPRCC	Chopping compensation update prevented

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC80	XDC0	XF00	X1040	X1180	X12C0	X1400	X1540	CHOP	In chopping start
XC81	XDC1	XF01	X1041	X1181	X12C1	X1401	X1541	CHP1	Basic position -> upper dead point path flag
XC82	XDC2	XF02	X1042	X1182	X12C2	X1402	X1542	CHP2	Upper dead point -> bottom dead point path flag
XC83	XDC3	XF03	X1043	X1183	X12C3	X1403	X1543	CHP3	Bottom dead point -> upper dead point path flag
XC84	XDC4	XF04	X1044	X1184	X12C4	X1404	X1544	CHP4	Upper dead point -> basic position path flag
XC85	XDC5	XF05	X1045	X1185	X12C5	X1405	X1545	CHPMD	In chopping mode
XC86	XDC6	XF06	X1046	X1186	X12C6	X1406	X1546		Stroke compensation completion
XC87	XDC7	XF07	X1047	X1187	X12C7	X1407	X1547		Tool escape and return transit point recognition completed
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC88	XDC8	XF08	X1048	X1188	X12C8	X1408	X1548		
XC89	XDC9	XF09	X1049	X1189	X12C9	X1409	X1549		
XC8A	XDCA	XF0A	X104A	X118A	X12CA	X140A	X154A	SSE	Search & start Error
XC8B	XDCB	XF0B	X104B	X118B	X12CB	X140B	X154B	SSG	Search & start Search
XC8C	XDCC	XF0C	X104C	X118C	X12CC	X140C	X154C		
XC8D	XDCD	XF0D	X104D	X118D	X12CD	X140D	X154D		
XC8E	XDCE	XF0E	X104E	X118E	X12CE	X140E	X154E	PTAPn	Punchtap cycle in progress
XC8F	XDCF	XF0F	X104F	X118F	X12CF	X140F	X154F		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC90	XDD0	XF10	X1050	X1190	X12D0	X1410	X1550		
XC91	XDD1	XF11	X1051	X1191	X12D1	X1411	X1551		
XC92	XDD2	XF12	X1052	X1192	X12D2	X1412	X1552		
XC93	XDD3	XF13	X1053	X1193	X12D3	X1413	X1553	TCP	Tool change position return completion
XC94	XDD4	XF14	X1054	X1194	X12D4	X1414	X1554	TCRQ	New tool change
XC95	XDD5	XF15	X1055	X1195	X12D5	X1415	X1555		All spindles simultaneous control (G47.1)
XC96	XDD6	XF16	X1056	X1196	X12D6	X1416	X1556		Tool life prediction
XC97	XDD7	XF17	X1057	X1197	X12D7	X1417	X1557		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XC98	XDD8	XF18	X1058	X1198	X12D8	X1418	X1558	AL1	NC alarm 1
XC99	XDD9	XF19	X1059	X1199	X12D9	X1419	X1559	AL2	NC alarm 2 (Servo alarm)
XC9A	XDDA	XF1A	X105A	X119A	X12DA	X141A	X155A	AL3	NC alarm 3 (Program error)
XC9B	Xddb	XF1B	X105B	X119B	X12DB	X141B	X155B	AL4	NC alarm 4 (Operation error)
XC9C	XDDC	XF1C	X105C	X119C	X12DC	X141C	X155C	WR1	NC warning (Servo warning)
XC9D	XDDD	XF1D	X105D	X119D	X12DD	X141D	X155D		
XC9E	XDDE	XF1E	X105E	X119E	X12DE	X141E	X155E		
XC9F	XDDF	XF1F	X105F	X119F	X12DF	X141F	X155F		

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XCA0	XDE0	XF20	X1060	X11A0	X12E0	X1420	X1560		Load monitor I: Teaching/Monitor mode in execution ▲
XCA1	XDE1	XF21	X1061	X11A1	X12E1	X1421	X1561		Load monitor I: Teaching mode valid ▲
XCA2	XDE2	XF22	X1062	X11A2	X12E2	X1422	X1562		Load monitor I: Monitor mode valid ▲
XCA3	XDE3	XF23	X1063	X11A3	X12E3	X1423	X1563		Load monitor I: Adaptive control in execution ▲
XCA4	XDE4	XF24	X1064	X11A4	X12E4	X1424	X1564	FFCO	Thread cutting: Feed-forward control ON
XCA5	XDE5	XF25	X1065	X11A5	X12E5	X1425	X1565	TRVE	Tap retract possible
XCA6	XDE6	XF26	X1066	X11A6	X12E6	X1426	X1566	PCNT	No. of work machining over
XCA7	XDE7	XF27	X1067	X11A7	X12E7	X1427	X1567	ABSW	Absolute position warning
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XCA8	XDE8	XF28	X1068	X11A8	X12E8	X1428	X1568		
XCA9	XDE9	XF29	X1069	X11A9	X12E9	X1429	X1569		In axis name switch
XCAA	XDEA	XF2A	X106A	X11AA	X12EA	X142A	X156A	ESTSVF	Optimum acceleration/deceleration parameter switch completion [axis] ▲
XCAB	XDEB	XF2B	X106B	X11AB	X12EB	X142B	X156B	ESTSVIN	Optimum acceleration/deceleration selection: NC axis inertia estimation in progress ▲
XCAC	XDEC	XF2C	X106C	X11AC	X12EC	X142C	X156C	GETAFLT	Optimum acceleration/deceleration selection: Estimated resonance frequency acquisition in progress ▲
XCAD	XDED	XF2D	X106D	X11AD	X12ED	X142D	X156D	VFTCIS	Variable feed thread cutting invalid state ▲
XCAE	XDEE	XF2E	X106E	X11AE	X12EE	X142E	X156E	HOBRTM	Hob machining: Retracting
XCAF	XDEF	XF2F	X106F	X11AF	X12EF	X142F	X156F	HOBRTF	Hob machining: Retract complete
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XCB0	XDF0	XF30	X1070	X11B0	X12F0	X1430	X1570		In spindle-NC axis polygon mode
XCB1	XDF1	XF31	X1071	X11B1	X12F1	X1431	X1571	AL5	NC alarm 5
XCB2	XDF2	XF32	X1072	X11B2	X12F2	X1432	X1572		In spindle-spindle polygon mode
XCB3	XDF3	XF33	X1073	X11B3	X12F3	X1433	X1573		Spindle-spindle polygon synchronization completion
XCB4	XDF4	XF34	X1074	X11B4	X12F4	X1434	X1574		
XCB5	XDF5	XF35	X1075	X11B5	X12F5	X1435	X1575	PSNCP	Phase alignment incomplete (polygon) ▲
XCB6	XDF6	XF36	X1076	X11B6	X12F6	X1436	X1576	TFF	Thread cutting: Feed-forwarding ▲
XCB7	XDF7	XF37	X1077	X11B7	X12F7	X1437	X1577		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XCB8	XDF8	XF38	X1078	X11B8	X12F8	X1438	X1578		
XCB9	XDF9	XF39	X1079	X11B9	X12F9	X1439	X1579		In 3-dimensional coordinate conversion
XCBA	XDFA	XF3A	X107A	X11BA	X12FA	X143A	X157A		
XCBB	XDFB	XF3B	X107B	X11BB	X12FB	X143B	X157B		
XCBC	XDFC	XF3C	X107C	X11BC	X12FC	X143C	X157C		
XCBD	XDFD	XF3D	X107D	X11BD	X12FD	X143D	X157D		
XCBE	XDFE	XF3E	X107E	X11BE	X12FE	X143E	X157E		
XCBF	XDFE	XF3F	X107F	X11BF	X12FF	X143F	X157F		

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XCC0	XE00	XF40	X1080	X11C0	X1300	X1440	X1580	RTAP	In synchronized tapping selection (M command)
XCC1	XE01	XF41	X1081	X11C1	X1301	X1441	X1581		In small diameter deep hole cycle
XCC2	XE02	XF42	X1082	X11C2	X1302	X1442	X1582		High-speed retract function valid state ▲
XCC3	XE03	XF43	X1083	X11C3	X1303	X1443	X1583		In high-speed retract function operation ▲
XCC4	XE04	XF44	X1084	X11C4	X1304	X1444	X1584		
XCC5	XE05	XF45	X1085	X11C5	X1305	X1445	X1585		
XCC6	XE06	XF46	X1086	X11C6	X1306	X1446	X1586		
XCC7	XE07	XF47	X1087	X11C7	X1307	X1447	X1587		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XCC8	XE08	XF48	X1088	X11C8	X1308	X1448	X1588		In barrier valid (left)
XCC9	XE09	XF49	X1089	X11C9	X1309	X1449	X1589		In barrier valid (right)
XCCA	XE0A	XF4A	X108A	X11CA	X130A	X144A	X158A	TLMSFIN	Tool length measurement completion ▲
XCCB	XE0B	XF4B	X108B	X11CB	X130B	X144B	X158B	TLMSERR	Tool length measurement error ▲
XCCC	XE0C	XF4C	X108C	X11CC	X130C	X144C	X158C		
XCCD	XE0D	XF4D	X108D	X11CD	X130D	X144D	X158D		
XCCE	XE0E	XF4E	X108E	X11CE	X130E	X144E	X158E	TLMSSE-LO	Tool length measurement sub-side selected ▲
XCCF	XE0F	XF4F	X108F	X11CF	X130F	X144F	X158F		Tool retract position reached ▲
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XCD0	XE10	XF50	X1090	X11D0	X1310	X1450	X1590	TRME	With tool retract amount command ▲
XCD1	XE11	XF51	X1091	X11D1	X1311	X1451	X1591	TRRP	In tool repositioning ▲
XCD2	XE12	XF52	X1092	X11D2	X1312	X1452	X1592		
XCD3	XE13	XF53	X1093	X11D3	X1313	X1453	X1593		
XCD4	XE14	XF54	X1094	X11D4	X1314	X1454	X1594		
XCD5	XE15	XF55	X1095	X11D5	X1315	X1455	X1595		
XCD6	XE16	XF56	X1096	X11D6	X1316	X1456	X1596		
XCD7	XE17	XF57	X1097	X11D7	X1317	X1457	X1597		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XCD8	XE18	XF58	X1098	X11D8	X1318	X1458	X1598		Door open enable
XCD9	XE19	XF59	X1099	X11D9	X1319	X1459	X1599		
XCDA	XE1A	XF5A	X109A	X11DA	X131A	X145A	X159A		
XCDB	XE1B	XF5B	X109B	X11DB	X131B	X145B	X159B		
XCDC	XE1C	XF5C	X109C	X11DC	X131C	X145C	X159C		
XCDD	XE1D	XF5D	X109D	X11DD	X131D	X145D	X159D		
XCDE	XE1E	XF5E	X109E	X11DE	X131E	X145E	X159E		
XCDF	XE1F	XF5F	X109F	X11DF	X131F	X145F	X159F		

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XCE0	XE20	XF60	X10A0	X11E0	X1320	X1460	X15A0		
XCE1	XE21	XF61	X10A1	X11E1	X1321	X1461	X15A1		
XCE2	XE22	XF62	X10A2	X11E2	X1322	X1462	X15A2		
XCE3	XE23	XF63	X10A3	X11E3	X1323	X1463	X15A3		
XCE4	XE24	XF64	X10A4	X11E4	X1324	X1464	X15A4		
XCE5	XE25	XF65	X10A5	X11E5	X1325	X1465	X15A5		
XCE6	XE26	XF66	X10A6	X11E6	X1326	X1466	X15A6		
XCE7	XE27	XF67	X10A7	X11E7	X1327	X1467	X15A7		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XCE8	XE28	XF68	X10A8	X11E8	X1328	X1468	X15A8		Door open enable (2 channels per 1 part system)
XCE9	XE29	XF69	X10A9	X11E9	X1329	X1469	X15A9		
XCEA	XE2A	XF6A	X10AA	X11EA	X132A	X146A	X15AA		External search: Program return completed
XCEB	XE2B	XF6B	X10AB	X11EB	X132B	X146B	X15AB		
XCEC	XE2C	XF6C	X10AC	X11EC	X132C	X146C	X15AC		
XCED	XE2D	XF6D	X10AD	X11ED	X132D	X146D	X15AD		Optimum machining diagnosis in progress ▲
XCEE	XE2E	XF6E	X10AE	X11EE	X132E	X146E	X15AE		Load monitor I: Cutting torque estimation in progress ▲
XCEF	XE2F	XF6F	X10AF	X11EF	X132F	X146F	X15AF		Load monitor I: Cutting torque estimation completed ▲
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XCF0	XE30	XF70	X10B0	X11F0	X1330	X1470	X15B0	PFCHS	Program format switch in progress
XCF1	XE31	XF71	X10B1	X11F1	X1331	X1471	X15B1		
XCF2	XE32	XF72	X10B2	X11F2	X1332	X1472	X15B2		
XCF3	XE33	XF73	X10B3	X11F3	X1333	X1473	X15B3		
XCF4	XE34	XF74	X10B4	X11F4	X1334	X1474	X15B4		
XCF5	XE35	XF75	X10B5	X11F5	X1335	X1475	X15B5		
XCF6	XE36	XF76	X10B6	X11F6	X1336	X1476	X15B6		
XCF7	XE37	XF77	X10B7	X11F7	X1337	X1477	X15B7		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XCF8	XE38	XF78	X10B8	X11F8	X1338	X1478	X15B8		
XCF9	XE39	XF79	X10B9	X11F9	X1339	X1479	X15B9	GLMT	Torque limitation skip: G160 torque limit ON
XCFA	XE3A	XF7A	X10BA	X11FA	X133A	X147A	X15BA		
XCFB	XE3B	XF7B	X10BB	X11FB	X133B	X147B	X15BB		
XCFC	XE3C	XF7C	X10BC	X11FC	X133C	X147C	X15BC		
XCFD	XE3D	XF7D	X10BD	X11FD	X133D	X147D	X15BD		
XCFE	XE3E	XF7E	X10BE	X11FE	X133E	X147E	X15BE		
XCFF	XE3F	XF7F	X10BF	X11FF	X133F	X147F	X15BF		

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XD00	XE40	XF80	X10C0	X1200	X1340	X1480	X15C0		
XD01	XE41	XF81	X10C1	X1201	X1341	X1481	X15C1		
XD02	XE42	XF82	X10C2	X1202	X1342	X1482	X15C2		
XD03	XE43	XF83	X10C3	X1203	X1343	X1483	X15C3		
XD04	XE44	XF84	X10C4	X1204	X1344	X1484	X15C4		
XD05	XE45	XF85	X10C5	X1205	X1345	X1485	X15C5		
XD06	XE46	XF86	X10C6	X1206	X1346	X1486	X15C6		
XD07	XE47	XF87	X10C7	X1207	X1347	X1487	X15C7		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XD08	XE48	XF88	X10C8	X1208	X1348	X1488	X15C8		
XD09	XE49	XF89	X10C9	X1209	X1349	X1489	X15C9		
XD0A	XE4A	XF8A	X10CA	X120A	X134A	X148A	X15CA		
XD0B	XE4B	XF8B	X10CB	X120B	X134B	X148B	X15CB	G0AC	Rapid traverse time constant: In switchover
XD0C	XE4C	XF8C	X10CC	X120C	X134C	X148C	X15CC	RT2CHG	Real-time tuning 2: Acceleration/deceleration time constant in switchover
XD0D	XE4D	XF8D	X10CD	X120D	X134D	X148D	X15CD		
XD0E	XE4E	XF8E	X10CE	X120E	X134E	X148E	X15CE	TWNIN	Reserved tool wear compensation not reflected
XD0F	XE4F	XF8F	X10CF	X120F	X134F	X148F	X15CF	TWOUT	Reflection of reserved tool wear compensation is complete
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XD10	XE50	XF90	X10D0	X1210	X1350	X1490	X15D0		
XD11	XE51	XF91	X10D1	X1211	X1351	X1491	X15D1		
XD12	XE52	XF92	X10D2	X1212	X1352	X1492	X15D2		
XD13	XE53	XF93	X10D3	X1213	X1353	X1493	X15D3		
XD14	XE54	XF94	X10D4	X1214	X1354	X1494	X15D4		3D coordinate conversion: Manual feed valid
XD15	XE55	XF95	X10D5	X1215	X1355	X1495	X15D5	RCEI	Rotation center error compensation in progress
XD16	XE56	XF96	X10D6	X1216	X1356	X1496	X15D6	SECA	Spatial error compensation invalid ▲
XD17	XE57	XF97	X10D7	X1217	X1357	X1497	X15D7	SECI	Spatial error compensation in progress
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XD18	XE58	XF98	X10D8	X1218	X1358	X1498	X15D8	MJST	3D manual feed (JOG, INC): Tool axis coordinate system selected
XD19	XE59	XF99	X10D9	X1219	X1359	X1499	X15D9	MJSB	3D manual feed (JOG, INC): Table coordinate system selected
XD1A	XE5A	XF9A	X10DA	X121A	X135A	X149A	X15DA	MJSF	3D manual feed (JOG, INC): Feature coordinate system selected
XD1B	XE5B	XF9B	X10DB	X121B	X135B	X149B	X15DB	MH1ST	3D manual feed (1st handle): Tool axis coordinate system selected
XD1C	XE5C	XF9C	X10DC	X121C	X135C	X149C	X15DC	MH1SB	3D manual feed (1st handle): Table coordinate system selected
XD1D	XE5D	XF9D	X10DD	X121D	X135D	X149D	X15DD	MH1SF	3D manual feed (1st handle): Feature coordinate system selected
XD1E	XE5E	XF9E	X10DE	X121E	X135E	X149E	X15DE	MH2ST	3D manual feed (2nd handle): Tool axis coordinate system selected
XD1F	XE5F	XF9F	X10DF	X121F	X135F	X149F	X15DF	MH2SB	3D manual feed (2nd handle): Table coordinate system selected

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XD20	XE60	XFA0	X10E0	X1220	X1360	X14A0	X15E0	MH2SF	3D manual feed (2nd handle): Feature coordinate system selected
XD21	XE61	XFA1	X10E1	X1221	X1361	X14A1	X15E1	MH3ST	3D manual feed (3rd handle): Tool axis coordinate system selected
XD22	XE62	XFA2	X10E2	X1222	X1362	X14A2	X15E2	MH3SB	3D manual feed (3rd handle): Table coordinate system selected
XD23	XE63	XFA3	X10E3	X1223	X1363	X14A3	X15E3	MH3SF	3D manual feed (3rd handle): Feature coordinate system selected
XD24	XE64	XFA4	X10E4	X1224	X1364	X14A4	X15E4		
XD25	XE65	XFA5	X10E5	X1225	X1365	X14A5	X15E5		
XD26	XE66	XFA6	X10E6	X1226	X1366	X14A6	X15E6		
XD27	XE67	XFA7	X10E7	X1227	X1367	X14A7	X15E7	TCPRS	In tool center point rotation

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XD28	XE68	XFA8	X10E8	X1228	X1368	X14A8	X15E8	RSSCT	R-Navi: Machining surface being selected
XD29	XE69	XFA9	X10E9	X1229	X1369	X14A9	X15E9	RSIND	R-Navi: Machining surface being indexed
XD2A	XE6A	XFAA	X10EA	X122A	X136A	X14AA	X15EA	RSIDF	R-Navi: Machine surface index complete
XD2B	XE6B	XFAB	X10EB	X122B	X136B	X14AB	X15EB		
XD2C	XE6C	XFAC	X10EC	X122C	X136C	X14AC	X15EC		
XD2D	XE6D	XFAD	X10ED	X122D	X136D	X14AD	X15ED		
XD2E	XE6E	XFAE	X10EE	X122E	X136E	X14AE	X15EE		
XD2F	XE6F	XFAF	X10EF	X122F	X136F	X14AF	X15EF	SLOP	Simple inclined surface machining/Inclined surface control command ON

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
XD30	XE70	XFB0	X10F0	X1230	X1370	X14B0	X15F0		MES interface library: Sending user arbitrary information
XD31	XE71	XFB1	X10F1	X1231	X1371	X14B1	X15F1		Manual arbitrary reverse run: Reverse run invalid status
XD32	XE72	XFB2	X10F2	X1232	X1372	X14B2	X15F2		
XD33	XE73	XFB3	X10F3	X1233	X1373	X14B3	X15F3		
XD34	XE74	XFB4	X10F4	X1234	X1374	X14B4	X15F4		
XD35	XE75	XFB5	X10F5	X1235	X1375	X14B5	X15F5		
XD36	XE76	XFB6	X10F6	X1236	X1376	X14B6	X15F6		
XD37	XE77	XFB7	X10F7	X1237	X1377	X14B7	X15F7		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
X1810	X1811	X1812	X1813	X1814	X1815	X1816	X1817	VCC	VCC: Mode in execution

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
X1870			X1878		Edit/search window displayed
X1871			X1879		
X1872			X187A		
X1873			X187B		
X1874			X187C		
X1875			X187D		
X1876			X187E		
X1877			X187F		

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
X1880	X18E0	X1940	X19A0	X1A00	X1A60	X1AC0	X1B20		
X1881	X18E1	X1941	X19A1	X1A01	X1A61	X1AC1	X1B21		
X1882	X18E2	X1942	X19A2	X1A02	X1A62	X1AC2	X1B22	SIGE	S command gear No. illegal
X1883	X18E3	X1943	X19A3	X1A03	X1A63	X1AC3	X1B23	SOVE	S command max./min. command value over
X1884	X18E4	X1944	X19A4	X1A04	X1A64	X1AC4	X1B24	SNGE	S command no gear selected
X1885	X18E5	X1945	X19A5	X1A05	X1A65	X1AC5	X1B25	GR1	Spindle gear shift command 1
X1886	X18E6	X1946	X19A6	X1A06	X1A66	X1AC6	X1B26	GR2	Spindle gear shift command 2
X1887	X18E7	X1947	X19A7	X1A07	X1A67	X1AC7	X1B27	-	(Always "0")
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
X1888	X18E8	X1948	X19A8	X1A08	X1A68	X1AC8	X1B28	ORAO2	Spindle 2nd in-position
X1889	X18E9	X1949	X19A9	X1A09	X1A69	X1AC9	X1B29	CDO	Current detection
X188A	X18EA	X194A	X19AA	X1A0A	X1A6A	X1ACA	X1B2A	VRO	Speed detection
X188B	X18EB	X194B	X19AB	X1A0B	X1A6B	X1ACB	X1B2B	FLO	In spindle alarm
X188C	X18EC	X194C	X19AC	X1A0C	X1A6C	X1ACC	X1B2C	ZSO	Zero speed
X188D	X18ED	X194D	X19AD	X1A0D	X1A6D	X1ACD	X1B2D	USO	Spindle up-to-speed
X188E	X18EE	X194E	X19AE	X1A0E	X1A6E	X1ACE	X1B2E	ORAO	Spindle in-position
X188F	X18EF	X194F	X19AF	X1A0F	X1A6F	X1ACF	X1B2F	LCSA	In L coil selection
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
X1890	X18F0	X1950	X19B0	X1A10	X1A70	X1AD0	X1B30	SMA	Spindle ready-ON
X1891	X18F1	X1951	X19B1	X1A11	X1A71	X1AD1	X1B31	SSA	Spindle servo-ON
X1892	X18F2	X1952	X19B2	X1A12	X1A72	X1AD2	X1B32	SEMG	In spindle emergency stop
X1893	X18F3	X1953	X19B3	X1A13	X1A73	X1AD3	X1B33	SSRN	In spindle forward run
X1894	X18F4	X1954	X19B4	X1A14	X1A74	X1AD4	X1B34	SSRI	In spindle reverse run
X1895	X18F5	X1955	X19B5	X1A15	X1A75	X1AD5	X1B35		Z phase passed
X1896	X18F6	X1956	X19B6	X1A16	X1A76	X1AD6	X1B36	SIMP	Position loop in-position
X1897	X18F7	X1957	X19B7	X1A17	X1A77	X1AD7	X1B37	STLQ	In spindle torque limit
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
X1898	X18F8	X1958	X19B8	X1A18	X1A78	X1AD8	X1B38		
X1899	X18F9	X1959	X19B9	X1A19	X1A79	X1AD9	X1B39		
X189A	X18FA	X195A	X19BA	X1A1A	X1A7A	X1ADA	X1B3A		Spindle torque limit reached
X189B	X18FB	X195B	X19BB	X1A1B	X1A7B	X1ADB	X1B3B		
X189C	X18FC	X195C	X19BC	X1A1C	X1A7C	X1ADC	X1B3C		
X189D	X18FD	X195D	X19BD	X1A1D	X1A7D	X1ADD	X1B3D	SD2	Speed detection 2
X189E	X18FE	X195E	X19BE	X1A1E	X1A7E	X1ADE	X1B3E	MCSA	In M coil selection
X189F	X18FF	X195F	X19BF	X1A1F	X1A7F	X1ADF	X1B3F		Index positioning completion

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
X18A0	X1900	X1960	X19C0	X1A20	X1A80	X1AE0	X1B40	ENB	Spindle enable
X18A1	X1901	X1961	X19C1	X1A21	X1A81	X1AE1	X1B41		
X18A2	X1902	X1962	X19C2	X1A22	X1A82	X1AE2	X1B42		
X18A3	X1903	X1963	X19C3	X1A23	X1A83	X1AE3	X1B43		
X18A4	X1904	X1964	X19C4	X1A24	X1A84	X1AE4	X1B44		
X18A5	X1905	X1965	X19C5	X1A25	X1A85	X1AE5	X1B45		
X18A6	X1906	X1966	X19C6	X1A26	X1A86	X1AE6	X1B46	PSNCS	Phase alignment incomplete (spindle synchronization control II) ▲
X18A7	X1907	X1967	X19C7	X1A27	X1A87	X1AE7	X1B47		Spindle synchronization speed detect ▲
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
X18A8	X1908	X1968	X19C8	X1A28	X1A88	X1AE8	X1B48	SPSYN 1	In spindle synchronization
X18A9	X1909	X1969	X19C9	X1A29	X1A89	X1AE9	X1B49	FSPRV	Spindle rotation speed synchronization completion
X18AA	X190A	X196A	X19CA	X1A2A	X1A8A	X1AEA	X1B4A	FSPPH	Spindle phase synchronization completion
X18AB	X190B	X196B	X19CB	X1A2B	X1A8B	X1AEB	X1B4B	SPSYN 2	In spindle synchronization 2
X18AC	X190C	X196C	X19CC	X1A2C	X1A8C	X1AEC	X1B4C	SPCMP	Chuck close confirmation
X18AD	X190D	X196D	X19CD	X1A2D	X1A8D	X1AED	X1B4D	TSS1	In tool spindle synchronization I (Polygon)
X18AE	X190E	X196E	X19CE	X1A2E	X1A8E	X1AEE	X1B4E	SPSYN 3	In tool spindle synchronization II
X18AF	X190F	X196F	X19CF	X1A2F	X1A8F	X1AEF	X1B4F	SPNCH	Spindle superimposition control: Speed change disabled
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
X18B0	X1910	X1970	X19D0	X1A30	X1A90	X1AF0	X1B50	SP- PHOV	Spindle synchronization phase error over
X18B1	X1911	X1971	X19D1	X1A31	X1A91	X1AF1	X1B51	SPILE	Spindle superimposition control ON
X18B2	X1912	X1972	X19D2	X1A32	X1A92	X1AF2	X1B52	SPLCR	Spindle superimposition control: Spindle superimposition clamped
X18B3	X1913	X1973	X19D3	X1A33	X1A93	X1AF3	X1B53	PHOVR	Hob axis delay excess
X18B4	X1914	X1974	X19D4	X1A34	X1A94	X1AF4	X1B54		
X18B5	X1915	X1975	X19D5	X1A35	X1A95	X1AF5	X1B55	EXOFN	Holding power of spindle increased
X18B6	X1916	X1976	X19D6	X1A36	X1A96	X1AF6	X1B56	SPOF- FA	In spindle off
X18B7	X1917	X1977	X19D7	X1A37	X1A97	X1AF7	X1B57	SSRD	Spindle speed fluctuation detection: Spindle speed out of setting range
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
X18B8	X1918	X1978	X19D8	X1A38	X1A98	X1AF8	X1B58		
X18B9	X1919	X1979	X19D9	X1A39	X1A99	X1AF9	X1B59		
X18BA	X191A	X197A	X19DA	X1A3A	X1A9A	X1AFA	X1B5A		
X18BB	X191B	X197B	X19DB	X1A3B	X1A9B	X1AFB	X1B5B		
X18BC	X191C	X197C	X19DC	X1A3C	X1A9C	X1AFC	X1B5C		
X18BD	X191D	X197D	X19DD	X1A3D	X1A9D	X1AFD	X1B5D		
X18BE	X191E	X197E	X19DE	X1A3E	X1A9E	X1AFE	X1B5E		
X18BF	X191F	X197F	X19DF	X1A3F	X1A9F	X1AFF	X1B5F		

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
X18C0	X1920	X1980	X19E0	X1A40	X1AA0	X1B00	X1B60		
X18C1	X1921	X1981	X19E1	X1A41	X1AA1	X1B01	X1B61	SVMD	Spindle position control (Spindle/C axis control): C axis mode ON
X18C2	X1922	X1982	X19E2	X1A42	X1AA2	X1B02	X1B62	GO1	Spindle gear selection output 1
X18C3	X1923	X1983	X19E3	X1A43	X1AA3	X1B03	X1B63	GO2	Spindle gear selection output 2
X18C4	X1924	X1984	X19E4	X1A44	X1AA4	X1B04	X1B64		
X18C5	X1925	X1985	X19E5	X1A45	X1AA5	X1B05	X1B65		
X18C6	X1926	X1986	X19E6	X1A46	X1AA6	X1B06	X1B66		
X18C7	X1927	X1987	X19E7	X1A47	X1AA7	X1B07	X1B67		
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
X18C8	X1928	X1988	X19E8	X1A48	X1AA8	X1B08	X1B68		Spindle oscillation in progress
X18C9	X1929	X1989	X19E9	X1A49	X1AA9	X1B09	X1B69	SPRTC T	Spindle protection: Mode in progress
X18CA	X192A	X198A	X19EA	X1A4A	X1AAA	X1B0A	X1B6A	VGHL	Real-time tuning 1: Speed control gain changeover hold-down ON
X18CB	X192B	X198B	X19EB	X1A4B	X1AAB	X1B0B	X1B6B	SP- FLST	SPFL: Control in execution ▲
X18CC	X192C	X198C	X19EC	X1A4C	X1AAC	X1B0C	X1B6C		
X18CD	X192D	X198D	X19ED	X1A4D	X1AAD	X1B0D	X1B6D		
X18CE	X192E	X198E	X19EE	X1A4E	X1AAE	X1B0E	X1B6E		
X18CF	X192F	X198F	X19EF	X1A4F	X1AAF	X1B0F	X1B6F		

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
X1CA0		Laser: Height control in progress	X1CA8		
X1CA1		Laser: Approach in height control completed	X1CA9		
X1CA2		Laser: Height being retained in height control	X1CAA		
X1CA3			X1CAB		
X1CA4			X1CAC		
X1CA5			X1CAD		
X1CA6		Laser: Laser condition change strobe	X1CAE		
X1CA7		Laser: Laser beam irradiating	X1CAF		

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
X1CD0		Handy terminal key 1	X1CD8		Handy terminal key 9
X1CD1		Handy terminal key 2	X1CD9		Handy terminal key 10
X1CD2		Handy terminal key 3	X1CDA		Handy terminal key 11
X1CD3		Handy terminal key 4	X1CDB		Handy terminal key 12
X1CD4		Handy terminal key 5	X1CDC		Handy terminal key 13
X1CD5		Handy terminal key 6	X1CDD		Handy terminal key 14
X1CD6		Handy terminal key 7	X1CDE		Handy terminal key 15
X1CD7		Handy terminal key 8	X1CDF		Handy terminal key 16

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
X1CE0		Handy terminal key 17	X1CE8		Handy terminal key 25
X1CE1		Handy terminal key 18	X1CE9		Handy terminal key 26
X1CE2		Handy terminal key 19	X1CEA		Handy terminal key 27
X1CE3		Handy terminal key 20	X1CEB		Handy terminal key 28
X1CE4		Handy terminal key 21	X1CEC		Handy terminal key 29
X1CE5		Handy terminal key 22	X1CED		Handy terminal key 30
X1CE6		Handy terminal key 23	X1CEE		Handy terminal key 31
X1CE7		Handy terminal key 24	X1CEF		Handy terminal key 32

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
X1CF0		Handy terminal key 33	X1CF8		Handy terminal key 41
X1CF1		Handy terminal key 34	X1CF9		Handy terminal key 42
X1CF2		Handy terminal key 35	X1CFA		Handy terminal key 43
X1CF3		Handy terminal key 36	X1CFB		Handy terminal key 44
X1CF4		Handy terminal key 37	X1CFC		Handy terminal key 45
X1CF5		Handy terminal key 38	X1CFD		
X1CF6		Handy terminal key 39	X1CFE		
X1CF7		Handy terminal key 40	X1CFF		

2 Input/Output Signals with Controller

2.1 PLC Input Signals (Bit Type: X***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
X1D00	X1D20	X1D40	X1D60	X1D80	X1DA0	X1DC0	X1DE0	PSW1	Position switch 1
X1D01	X1D21	X1D41	X1D61	X1D81	X1DA1	X1DC1	X1DE1	PSW2	Position switch 2
X1D02	X1D22	X1D42	X1D62	X1D82	X1DA2	X1DC2	X1DE2	PSW3	Position switch 3
X1D03	X1D23	X1D43	X1D63	X1D83	X1DA3	X1DC3	X1DE3	PSW4	Position switch 4
X1D04	X1D24	X1D44	X1D64	X1D84	X1DA4	X1DC4	X1DE4	PSW5	Position switch 5
X1D05	X1D25	X1D45	X1D65	X1D85	X1DA5	X1DC5	X1DE5	PSW6	Position switch 6
X1D06	X1D26	X1D46	X1D66	X1D86	X1DA6	X1DC6	X1DE6	PSW7	Position switch 7
X1D07	X1D27	X1D47	X1D67	X1D87	X1DA7	X1DC7	X1DE7	PSW8	Position switch 8
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
X1D08	X1D28	X1D48	X1D68	X1D88	X1DA8	X1DC8	X1DE8	PSW9	Position switch 9
X1D09	X1D29	X1D49	X1D69	X1D89	X1DA9	X1DC9	X1DE9	PSW10	Position switch 10
X1D0A	X1D2A	X1D4A	X1D6A	X1D8A	X1DAA	X1DCA	X1DEA	PSW11	Position switch 11
X1D0B	X1D2B	X1D4B	X1D6B	X1D8B	X1DAB	X1DCB	X1DEB	PSW12	Position switch 12
X1D0C	X1D2C	X1D4C	X1D6C	X1D8C	X1DAC	X1DCC	X1DEC	PSW13	Position switch 13
X1D0D	X1D2D	X1D4D	X1D6D	X1D8D	X1DAD	X1DCD	X1DED	PSW14	Position switch 14
X1D0E	X1D2E	X1D4E	X1D6E	X1D8E	X1DAE	X1DCE	X1DEE	PSW15	Position switch 15
X1D0F	X1D2F	X1D4F	X1D6F	X1D8F	X1DAF	X1DCF	X1DEF	PSW16	Position switch 16
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
X1D10	X1D30	X1D50	X1D70	X1D90	X1DB0	X1DD0	X1DF0	PSW17	Position switch 17
X1D11	X1D31	X1D51	X1D71	X1D91	X1DB1	X1DD1	X1DF1	PSW18	Position switch 18
X1D12	X1D32	X1D52	X1D72	X1D92	X1DB2	X1DD2	X1DF2	PSW19	Position switch 19
X1D13	X1D33	X1D53	X1D73	X1D93	X1DB3	X1DD3	X1DF3	PSW20	Position switch 20
X1D14	X1D34	X1D54	X1D74	X1D94	X1DB4	X1DD4	X1DF4	PSW21	Position switch 21
X1D15	X1D35	X1D55	X1D75	X1D95	X1DB5	X1DD5	X1DF5	PSW22	Position switch 22
X1D16	X1D36	X1D56	X1D76	X1D96	X1DB6	X1DD6	X1DF6	PSW23	Position switch 23
X1D17	X1D37	X1D57	X1D77	X1D97	X1DB7	X1DD7	X1DF7	PSW24	Position switch 24
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
X1D18	X1D38	X1D58	X1D78	X1D98	X1DB8	X1DD8	X1DF8	PSW25	Position switch 25 ▲
X1D19	X1D39	X1D59	X1D79	X1D99	X1DB9	X1DD9	X1DF9	PSW26	Position switch 26 ▲
X1D1A	X1D3A	X1D5A	X1D7A	X1D9A	X1DBA	X1DDA	X1DFA	PSW27	Position switch 27 ▲
X1D1B	X1D3B	X1D5B	X1D7B	X1D9B	X1DBB	X1ddb	X1DFB	PSW28	Position switch 28 ▲
X1D1C	X1D3C	X1D5C	X1D7C	X1D9C	X1DBC	X1DDC	X1DFC	PSW29	Position switch 29 ▲
X1D1D	X1D3D	X1D5D	X1D7D	X1D9D	X1DBD	X1DDD	X1DFD	PSW30	Position switch 30 ▲
X1D1E	X1D3E	X1D5E	X1D7E	X1D9E	X1DBE	X1DDE	X1DFE	PSW31	Position switch 31 ▲
X1D1F	X1D3F	X1D5F	X1D7F	X1D9F	X1DBF	X1DDF	X1DFE	PSW32	Position switch 32 ▲

2.2 PLC Input Signals (Data Type: R***)

Note

(1) Signals with " ▲ " are prepared for a specific machine tool builder.

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R0	AI1	Analog input 1	R8		KEY IN 1
R1	AI2	Analog input 2	R9		
R2	AI3	Analog input 3	R10		
R3	AI4	Analog input 4	R11		Clock data Year/Month
R4	AI5	Analog input 5	R12		Clock data Date/Hour
R5	AI6	Analog input 6	R13		Clock data Minute/Second
R6	AI7	Analog input 7	R14		
R7	AI8	Analog input 8	R15		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R16		CNC software version code A	R24		
R17		CNC software version code B	R25		PC high-speed process time
R18		CNC software version code C1	R26		Turret interference check status
R19		CNC software version code C2	R27		Interference object alarm information
R20			R28		
R21			R29		
R22			R30		Remote program input error information ▲
R23			R31		Diagnosis data output
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R32			R40		ASync error: Exceptional occurrence R register number ▲
R33			R41		
R34			R42		
R35			R43		
R36			R44		
R37		PLC window parameter error status	R45		
R38		ASync error: Exceptional occurrence	R46		
R39		step number ▲	R47		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R48			R56		Battery drop cause
R49			R57		Temperature warning cause
R50			R58		5V/24V error cause
R51			R59		
R52			R60		Control unit temperature
R53			R61		
R54			R62		Tool ID communication error informa- tion ▲
R55			R63		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R64			R72		Ball screw thermal displacement compensation: Compensation amount 1st axis [M]
R65			R73		Ball screw thermal displacement compensation: Compensation amount 2nd axis [M]
R66			R74		Ball screw thermal displacement compensation: Compensation amount 3rd axis [M]
R67			R75		Ball screw thermal displacement compensation: Compensation amount 4th axis [M]
R68		PLC main scan time	R76		
R69		Emergency stop cause	R77		
R70		DIO card information	R78		
R71			R79		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R80			R88		
R81			R89		
R82			R90		Modbus/TCP connection request monitor ▲
R83		Modbus/RTU received packet monitor ▲	R91		Modbus/TCP number of connections monitor ▲
R84		Modbus/RTU communication error monitor ▲	R92		Modbus/TCP received packet monitor ▲
R85		Modal task data update cycle	R93		Modbus/TCP communication error monitor ▲
R86			R94		Modbus protocol error packet monitor ▲
R87			R95		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R96	SM-DOEN	Speed monitor door open possible	R104		
R97			R105		
R98	SOPFN	Multi-step speed monitor selected speed output	R106		
R99			R107		
R100	SODIO2	Safety observation I/O signal state 2 ▲	R108		
R101		Interference check between part systems: Setting error alarm information	R109		
R102		Interference check between part systems: Alarm information	R110		
R103			R111		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R112			R120	DTPPC	Power consumption computation: Present consumption of entire drive system (L)
R113	SMPSTS	NC data sampling: Sampling state ▲	R121		Power consumption computation: Present consumption of entire drive system (H)
R114		PLC axis position switch 1 to 16 ▲	R122	DTIPC1	Power consumption computation: Accumulated consumption of entire drive system 1 (L)
R115		PLC axis position switch 17 to 32 ▲	R123		Power consumption computation: Accumulated consumption of entire drive system 1 (H)
R116	HS1PCNT	Handle feed: 1st handle pulse counter	R124	DTIPC2	Power consumption computation: Accumulated consumption of entire drive system 2 (L)
R117	HS2PCNT	Handle feed: 2nd handle pulse counter	R125		Power consumption computation: Accumulated consumption of entire drive system 2 (H)
R118	HS3PCNT	Handle feed: 3rd handle pulse counter	R126	DTIPC3	Power consumption computation: Accumulated consumption of entire drive system 3 (L)
R119			R127		Power consumption computation: Accumulated consumption of entire drive system 3 (H)
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R128	DTIPC4	Power consumption computation: Accumulated consumption of entire drive system 4 (L)	R136	NDIPC4	Power consumption computation: Accumulated consumption of devices other than drive system 4 (L)
R129		Power consumption computation: Accumulated consumption of entire drive system 4 (H)	R137		Power consumption computation: Accumulated consumption of devices other than drive system 4 (H)
R130	NDIPC1	Power consumption computation: Accumulated consumption of devices other than drive system 1 (L)	R138	ITF3CHWGOBJ	Interference check III: Entry in interference warning area interfering object information
R131		Power consumption computation: Accumulated consumption of devices other than drive system 1 (H)	R139	ITF3CHALOBJ	Interference check III: Interference detection interfering object information
R132	NDIPC2	Power consumption computation: Accumulated consumption of devices other than drive system 2 (L)	R140	ITF3-TRAL-OBJ	Interference check III: Entry in interference alarm area interfering object information
R133		Power consumption computation: Accumulated consumption of devices other than drive system 2 (H)	R141	ITF3DTE R1	Interference check III: Data setting error information 1
R134	NDIPC3	Power consumption computation: Accumulated consumption of devices other than drive system 3 (L)	R142	ITF3DTE R2	Interference check III: Data setting error information 2
R135		Power consumption computation: Accumulated consumption of devices other than drive system 3 (H)	R143		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R144	ITF3DTE R2	Interference check III: Data setting error information 2	R152		
R145			R153		
R146			R154		
R147			R155		
R148			R156		
R149			R157		
R150			R158	HYPSP	Hypothetical spindle configured ▲
R151			R159	HYPSP	Hypothetical spindle command invalid ▲

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R160			R168		PLC axis alarm/warning No. 1st axis
R161			R169		PLC axis alarm/warning No. 2nd axis
R162			R170		PLC axis alarm/warning No. 3rd axis
R163			R171		PLC axis alarm/warning No. 4th axis
R164			R172		PLC axis alarm/warning No. 5th axis
R165			R173		PLC axis alarm/warning No. 6th axis
R166			R174		PLC axis alarm/warning No. 7th axis
R167			R175		PLC axis alarm/warning No. 8th axis
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R176			R184		
R177			R185		
R178			R186		
R179			R187		
R180			R188		
R181			R189		
R182			R190		
R183			R191		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R192					
R193					
R194					
R195					
R196					
R197					
R198					
R199					

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R500	R700	R900	R1100	R1300	R1500	R1700	R1900		External search status
R501	R701	R901	R1101	R1301	R1501	R1701	R1901		External search: Program return complete status
R502	R702	R902	R1102	R1302	R1502	R1702	R1902		
R503	R703	R903	R1103	R1303	R1503	R1703	R1903		
R504	R704	R904	R1104	R1304	R1504	R1704	R1904		M code data 1 (L)
R505	R705	R905	R1105	R1305	R1505	R1705	R1905		M code data 1 (H)
R506	R706	R906	R1106	R1306	R1506	R1706	R1906		M code data 2 (L)
R507	R707	R907	R1107	R1307	R1507	R1707	R1907		M code data 2 (H)
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R508	R708	R908	R1108	R1308	R1508	R1708	R1908		M code data 3 (L)
R509	R709	R909	R1109	R1309	R1509	R1709	R1909		M code data 3 (H)
R510	R710	R910	R1110	R1310	R1510	R1710	R1910		M code data 4 (L)
R511	R711	R911	R1111	R1311	R1511	R1711	R1911		M code data 4 (H)
R512	R712	R912	R1112	R1312	R1512	R1712	R1912		S code data 1 (L)
R513	R713	R913	R1113	R1313	R1513	R1713	R1913		S code data 1 (H)
R514	R714	R914	R1114	R1314	R1514	R1714	R1914		S code data 2 (L)
R515	R715	R915	R1115	R1315	R1515	R1715	R1915		S code data 2 (H)

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R^{***})

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R516	R716	R916	R1116	R1316	R1516	R1716	R1916		S code data 3 (L)
R517	R717	R917	R1117	R1317	R1517	R1717	R1917		S code data 3 (H)
R518	R718	R918	R1118	R1318	R1518	R1718	R1918		S code data 4 (L)
R519	R719	R919	R1119	R1319	R1519	R1719	R1919		S code data 4 (H)
R520	R720	R920	R1120	R1320	R1520	R1720	R1920		S code data 5 (L)
R521	R721	R921	R1121	R1321	R1521	R1721	R1921		S code data 5 (H)
R522	R722	R922	R1122	R1322	R1522	R1722	R1922		S code data 6 (L)
R523	R723	R923	R1123	R1323	R1523	R1723	R1923		S code data 6 (H)
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R524	R724	R924	R1124	R1324	R1524	R1724	R1924		S code data 7 (L)
R525	R725	R925	R1125	R1325	R1525	R1725	R1925		S code data 7 (H)
R526	R726	R926	R1126	R1326	R1526	R1726	R1926		S code data 8 (L)
R527	R727	R927	R1127	R1327	R1527	R1727	R1927		S code data 8 (H)
R528	R728	R928	R1128	R1328	R1528	R1728	R1928		
R529	R729	R929	R1129	R1329	R1529	R1729	R1929		
R530	R730	R930	R1130	R1330	R1530	R1730	R1930		
R531	R731	R931	R1131	R1331	R1531	R1731	R1931		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R532	R732	R932	R1132	R1332	R1532	R1732	R1932		
R533	R733	R933	R1133	R1333	R1533	R1733	R1933		
R534	R734	R934	R1134	R1334	R1534	R1734	R1934		
R535	R735	R935	R1135	R1335	R1535	R1735	R1935		
R536	R736	R936	R1136	R1336	R1536	R1736	R1936		T code data 1 (L)
R537	R737	R937	R1137	R1337	R1537	R1737	R1937		T code data 1 (H)
R538	R738	R938	R1138	R1338	R1538	R1738	R1938		T code data 2 (L)
R539	R739	R939	R1139	R1339	R1539	R1739	R1939		T code data 2 (H)
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R540	R740	R940	R1140	R1340	R1540	R1740	R1940		T code data 3 (L)
R541	R741	R941	R1141	R1341	R1541	R1741	R1941		T code data 3 (H)
R542	R742	R942	R1142	R1342	R1542	R1742	R1942		T code data 4 (L)
R543	R743	R943	R1143	R1343	R1543	R1743	R1943		T code data 4 (H)
R544	R744	R944	R1144	R1344	R1544	R1744	R1944		2nd M function data 1 (L)
R545	R745	R945	R1145	R1345	R1545	R1745	R1945		2nd M function data 1 (H)
R546	R746	R946	R1146	R1346	R1546	R1746	R1946		2nd M function data 2 (L)
R547	R747	R947	R1147	R1347	R1547	R1747	R1947		2nd M function data 2 (H)

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R548	R748	R948	R1148	R1348	R1548	R1748	R1948		2nd M function data 3 (L)
R549	R749	R949	R1149	R1349	R1549	R1749	R1949		2nd M function data 3 (H)
R550	R750	R950	R1150	R1350	R1550	R1750	R1950		2nd M function data 4 (L)
R551	R751	R951	R1151	R1351	R1551	R1751	R1951		2nd M function data 4 (H)
R552	R752	R952	R1152	R1352	R1552	R1752	R1952		
R553	R753	R953	R1153	R1353	R1553	R1753	R1953		
R554	R754	R954	R1154	R1354	R1554	R1754	R1954		Chopping error No.
R555	R755	R955	R1155	R1355	R1555	R1755	R1955		Manual measurement status
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R556	R756	R956	R1156	R1356	R1556	R1756	R1956		
R557	R757	R957	R1157	R1357	R1557	R1757	R1957		
R558	R758	R958	R1158	R1358	R1558	R1758	R1958		
R559	R759	R959	R1159	R1359	R1559	R1759	R1959		
R560	R760	R960	R1160	R1360	R1560	R1760	R1960		
R561	R761	R961	R1161	R1361	R1561	R1761	R1961		
R562	R762	R962	R1162	R1362	R1562	R1762	R1962		
R563	R763	R963	R1163	R1363	R1563	R1763	R1963		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R564	R764	R964	R1164	R1364	R1564	R1764	R1964		Load monitor I: Warning axis ▲
R565	R765	R965	R1165	R1365	R1565	R1765	R1965		Load monitor I: Alarm axis ▲
R566	R766	R966	R1166	R1366	R1566	R1766	R1966		Load monitor I: Data error information ▲
R567	R767	R967	R1167	R1367	R1567	R1767	R1967		Group in tool life management
R568	R768	R968	R1168	R1368	R1568	R1768	R1968		
R569	R769	R969	R1169	R1369	R1569	R1769	R1969		
R570	R770	R970	R1170	R1370	R1570	R1770	R1970		
R571	R771	R971	R1171	R1371	R1571	R1771	R1971		Load monitor I: Adaptive control override ▲
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R572	R772	R972	R1172	R1372	R1572	R1772	R1972		CNC completion standby status
R573	R773	R973	R1173	R1373	R1573	R1773	R1973		
R574	R774	R974	R1174	R1374	R1574	R1774	R1974		In initialization
R575	R775	R975	R1175	R1375	R1575	R1775	R1975		Initialization incompleteness
R576	R776	R976	R1176	R1376	R1576	R1776	R1976		Reference position adjustment value parameter setting completed
R577	R777	R977	R1177	R1377	R1577	R1777	R1977	APIER	User macro section and sub-section designated execution result
R578	R778	R978	R1178	R1378	R1578	R1778	R1978		Measurement tool tip point No. ▲
R579	R779	R979	R1179	R1379	R1579	R1779	R1979		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R580	R780	R980	R1180	R1380	R1580	R1780	R1980		Near reference position (per reference position) 1 to 4 axes
R581	R781	R981	R1181	R1381	R1581	R1781	R1981		Near reference position (per reference position) 5 to 8 axes
R582	R782	R982	R1182	R1382	R1582	R1782	R1982		Presetter contact
R583	R783	R983	R1183	R1383	R1583	R1783	R1983		Presetter interlock
R584	R784	R984	R1184	R1384	R1584	R1784	R1984		Area signal X axis ON/OFF ▲
R585	R785	R985	R1185	R1385	R1585	R1785	R1985		Area signal Z axis ON/OFF ▲
R586	R786	R986	R1186	R1386	R1586	R1786	R1986		Area signal X axis (-) ON/OFF ▲
R587	R787	R987	R1187	R1387	R1587	R1787	R1987		Area signal Z axis (-) ON/OFF ▲
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R588	R788	R988	R1188	R1388	R1588	R1788	R1988		Takt time (ms) (L)
R589	R789	R989	R1189	R1389	R1589	R1789	R1989		Takt time (ms) (H)
R590	R790	R990	R1190	R1390	R1590	R1790	R1990		Takt time (min) (L)
R591	R791	R991	R1191	R1391	R1591	R1791	R1991		Takt time (min) (H)
R592	R792	R992	R1192	R1392	R1592	R1792	R1992		
R593	R793	R993	R1193	R1393	R1593	R1793	R1993		
R594	R794	R994	R1194	R1394	R1594	R1794	R1994		
R595	R795	R995	R1195	R1395	R1595	R1795	R1995		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R596	R796	R996	R1196	R1396	R1596	R1796	R1996		Load monitor I: Status output (1) ▲
R597	R797	R997	R1197	R1397	R1597	R1797	R1997		Load monitor I: Status output (2) ▲
R598	R798	R998	R1198	R1398	R1598	R1798	R1998		Load monitor I: Status output (3) ▲
R599	R799	R999	R1199	R1399	R1599	R1799	R1999		Load monitor I: Status output (4) ▲
R600	R800	R1000	R1200	R1400	R1600	R1800	R2000		Load monitor I: Status output (5) ▲
R601	R801	R1001	R1201	R1401	R1601	R1801	R2001		Load monitor I: Status output (6) ▲
R602	R802	R1002	R1202	R1402	R1602	R1802	R2002		Load monitor I: Status output (7) ▲
R603	R803	R1003	R1203	R1403	R1603	R1803	R2003		Load monitor I: Status output (8) ▲
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R604	R804	R1004	R1204	R1404	R1604	R1804	R2004		Load monitor I: Status output (9) ▲
R605	R805	R1005	R1205	R1405	R1605	R1805	R2005		Load monitor I: Status output (10) ▲
R606	R806	R1006	R1206	R1406	R1606	R1806	R2006		No. of work machining (current value) (L)
R607	R807	R1007	R1207	R1407	R1607	R1807	R2007		No. of work machining (current value) (H)
R608	R808	R1008	R1208	R1408	R1608	R1808	R2008		No. of work machining (maximum value) (L)
R609	R809	R1009	R1209	R1409	R1609	R1809	R2009		No. of work machining (maximum value) (H)
R610	R810	R1010	R1210	R1410	R1610	R1810	R2010		
R611	R811	R1011	R1211	R1411	R1611	R1811	R2011		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R612	R812	R1012	R1212	R1412	R1612	R1812	R2012		
R613	R813	R1013	R1213	R1413	R1613	R1813	R2013		
R614	R814	R1014	R1214	R1414	R1614	R1814	R2014		
R615	R815	R1015	R1215	R1415	R1615	R1815	R2015		
R616	R816	R1016	R1216	R1416	R1616	R1816	R2016	SBSID	Sub part system control: Sub part system control II identification No.
R617	R817	R1017	R1217	R1417	R1617	R1817	R2017	SBSCL	Sub part system control: Calling sub part system
R618	R818	R1018	R1218	R1418	R1618	R1818	R2018	SBSWT	Sub part system control: Waiting for sub part system completion
R619	R819	R1019	R1219	R1419	R1619	R1819	R2019	SBSSY	Sub part system control: Caller of sub part system
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R620	R820	R1020	R1220	R1420	R1620	R1820	R2020		
R621	R821	R1021	R1221	R1421	R1621	R1821	R2021		
R622	R822	R1022	R1222	R1422	R1622	R1822	R2022		
R623	R823	R1023	R1223	R1423	R1623	R1823	R2023		
R624	R824	R1024	R1224	R1424	R1624	R1824	R2024		Constant torque control: Axis under constant torque/proportional torque stopper control
R625	R825	R1025	R1225	R1425	R1625	R1825	R2025		Constant torque control: Constant torque droop cancel axis status
R626	R826	R1026	R1226	R1426	R1626	R1826	R2026		
R627	R827	R1027	R1227	R1427	R1627	R1827	R2027		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R628	R828	R1028	R1228	R1428	R1628	R1828	R2028		Tool life usage data (L)
R629	R829	R1029	R1229	R1429	R1629	R1829	R2029		Tool life usage data (H)
R630	R830	R1030	R1230	R1430	R1630	R1830	R2030		Number of registered tool life control tools
R631	R831	R1031	R1231	R1431	R1631	R1831	R2031		
R632	R832	R1032	R1232	R1432	R1632	R1832	R2032		
R633	R833	R1033	R1233	R1433	R1633	R1833	R2033		
R634	R834	R1034	R1234	R1434	R1634	R1834	R2034		
R635	R835	R1035	R1235	R1435	R1635	R1835	R2035		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R636	R836	R1036	R1236	R1436	R1636	R1836	R2036		Circular feed in manual mode Current position H (L) [M]
R637	R837	R1037	R1237	R1437	R1637	R1837	R2037		Circular feed in manual mode Current position H (H) [M]
R638	R838	R1038	R1238	R1438	R1638	R1838	R2038		
R639	R839	R1039	R1239	R1439	R1639	R1839	R2039		
R640	R840	R1040	R1240	R1440	R1640	R1840	R2040		Circular feed in manual mode Current position V (L) [M]
R641	R841	R1041	R1241	R1441	R1641	R1841	R2041		Circular feed in manual mode Current position V (H) [M]
R642	R842	R1042	R1242	R1442	R1642	R1842	R2042		
R643	R843	R1043	R1243	R1443	R1643	R1843	R2043		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R^{***})

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R644	R844	R1044	R1244	R1444	R1644	R1844	R2044		
R645	R845	R1045	R1245	R1445	R1645	R1845	R2045		
R646	R846	R1046	R1246	R1446	R1646	R1846	R2046		Machining mode state ▲
R647	R847	R1047	R1247	R1447	R1647	R1847	R2047		
R648	R848	R1048	R1248	R1448	R1648	R1848	R2048		Thread recutting status
R649	R849	R1049	R1249	R1449	R1649	R1849	R2049		Thread recutting execution status
R650	R850	R1050	R1250	R1450	R1650	R1850	R2050		Thread recutting spindle No.
R651	R851	R1051	R1251	R1451	R1651	R1851	R2051		Thread recutting lead axis No.
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R652	R852	R1052	R1252	R1452	R1652	R1852	R2052	TLMSL-NO1	Sensor ON Tool length compensation No. (BCD output) ▲
R653	R853	R1053	R1253	R1453	R1653	R1853	R2053	TLMSWN O1	Sensor ON Tool wear compensation No. (BCD output) ▲
R654	R854	R1054	R1254	R1454	R1654	R1854	R2054	TLMSL-NO2	Compensation data update Tool length compensation No. (BCD output) ▲
R655	R855	R1055	R1255	R1455	R1655	R1855	R2055	TLMSWN O2	Compensation data update Tool wear compensation No. (BCD output) ▲
R656	R856	R1056	R1256	R1456	R1656	R1856	R2056	RPAROUT	Rotary axis configuration parameter output
R657	R857	R1057	R1257	R1457	R1657	R1857	R2057		
R658	R858	R1058	R1258	R1458	R1658	R1858	R2058		
R659	R859	R1059	R1259	R1459	R1659	R1859	R2059		Ext. machine coordinate: Number input compensation offset valid axis ▲
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R660	R860	R1060	R1260	R1460	R1660	R1860	R2060	RSWRK	R-Navi: Selected workpiece No.
R661	R861	R1061	R1261	R1461	R1661	R1861	R2061	RSSRF	R-Navi: Selecting machine surface number
R662	R862	R1062	R1262	R1462	R1662	R1862	R2062	CAXSVFO	Spindle position control (spindle/C axis control): Servo OFF state during Spindle/C axis mode n-th axis ▲
R663	R863	R1063	R1263	R1463	R1663	R1863	R2063	SPGNCI	Spindle position control (spindle/C axis control): Position loop gain switch at C axis mode in progress ▲
R664	R864	R1064	R1264	R1464	R1664	R1864	R2064		
R665	R865	R1065	R1265	R1465	R1665	R1865	R2065		
R666	R866	R1066	R1266	R1466	R1666	R1866	R2066		
R667	R867	R1067	R1267	R1467	R1667	R1867	R2067		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R668	R868	R1068	R1268	R1468	R1668	R1868	R2068	SVESTAF	Optimum acceleration/deceleration selection: NC axis estimated resonance frequency (in estimating inertia) ▲
R669	R869	R1069	R1269	R1469	R1669	R1869	R2069	SVESTST	Optimum acceleration/deceleration selection: NC axis estimated inertia state ▲
R670	R870	R1070	R1270	R1470	R1670	R1870	R2070	ITF3CHW	Interference check III: Entry in interference warn area solid information
R671	R871	R1071	R1271	R1471	R1671	R1871	R2071	GSLD	
R672	R872	R1072	R1272	R1472	R1672	R1872	R2072	ITF3CHAL	Interference check III: Interference detection solid information
R673	R873	R1073	R1273	R1473	R1673	R1873	R2073	SLD	
R674	R874	R1074	R1274	R1474	R1674	R1874	R2074	ITF3-	Interference check III: Entry in interference alarm area solid information
R675	R875	R1075	R1275	R1475	R1675	R1875	R2075	TRALSLD	

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R684	R884	R1084	R1284	R1484	R1684	R1884	R2084		Specific user NC status 1 ▲
R685	R885	R1085	R1285	R1485	R1685	R1885	R2085		
R686	R886	R1086	R1286	R1486	R1686	R1886	R2086		
R687	R887	R1087	R1287	R1487	R1687	R1887	R2087		
R688	R888	R1088	R1288	R1488	R1688	R1888	R2088		Specific user Manual skip: Axis in skip motion ▲
R689	R889	R1089	R1289	R1489	R1689	R1889	R2089		Specific user Manual skip: Skip motion direction ▲
R690	R890	R1090	R1290	R1490	R1690	R1890	R2090		Specific user Error/Warning detail ▲
R691	R891	R1091	R1291	R1491	R1691	R1891	R2091		

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R2400		3D Machine Interference Check: Requested shape group No.1	R2408		
R2401		3D Machine Interference Check: Requested shape group No.2	R2409		
R2402		3D Machine Interference Check: Requested shape group No.3	R2410		
R2403		3D Machine Interference Check: Requested shape group No.4	R2411		
R2404			R2412		
R2405			R2413		
R2406			R2414		
R2407			R2415		

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4500	R4532	R4564	R4596		Machine position 1st axis (L) [M]
R4501	R4533	R4565	R4597		Machine position 1st axis (H) [M]
R4502	R4534	R4566	R4598		
R4503	R4535	R4567	R4599		
R4504	R4536	R4568	R4600		Machine position 2nd axis (L) [M]
R4505	R4537	R4569	R4601		Machine position 2nd axis (H) [M]
R4506	R4538	R4570	R4602		
R4507	R4539	R4571	R4603		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4508	R4540	R4572	R4604		Machine position 3rd axis (L) [M]
R4509	R4541	R4573	R4605		Machine position 3rd axis (H) [M]
R4510	R4542	R4574	R4606		
R4511	R4543	R4575	R4607		
R4512	R4544	R4576	R4608		Machine position 4th axis (L) [M]
R4513	R4545	R4577	R4609		Machine position 4th axis (H) [M]
R4514	R4546	R4578	R4610		
R4515	R4547	R4579	R4611		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R^{***})

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4516	R4548	R4580	R4612		Machine position 5th axis (L) [M]
R4517	R4549	R4581	R4613		Machine position 5th axis (H) [M]
R4518	R4550	R4582	R4614		
R4519	R4551	R4583	R4615		
R4520	R4552	R4584	R4616		Machine position 6th axis (L) [M]
R4521	R4553	R4585	R4617		Machine position 6th axis (H) [M]
R4522	R4554	R4586	R4618		
R4523	R4555	R4587	R4619		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4524	R4556	R4588	R4620		Machine position 7th axis (L) [M]
R4525	R4557	R4589	R4621		Machine position 7th axis (H) [M]
R4526	R4558	R4590	R4622		
R4527	R4559	R4591	R4623		
R4528	R4560	R4592	R4624		Machine position 8th axis (L) [M]
R4529	R4561	R4593	R4625		Machine position 8th axis (H) [M]
R4530	R4562	R4594	R4626		
R4531	R4563	R4595	R4627		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4628	R4660	R4692	R4724		Feedback machine position 1st axis (L) [M]
R4629	R4661	R4693	R4725		Feedback machine position 1st axis (H) [M]
R4630	R4662	R4694	R4726		
R4631	R4663	R4695	R4727		
R4632	R4664	R4696	R4728		Feedback machine position 2nd axis (L) [M]
R4633	R4665	R4697	R4729		Feedback machine position 2nd axis (H) [M]
R4634	R4666	R4698	R4730		
R4635	R4667	R4699	R4731		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4636	R4668	R4700	R4732		Feedback machine position 3rd axis (L) [M]
R4637	R4669	R4701	R4733		Feedback machine position 3rd axis (H) [M]
R4638	R4670	R4702	R4734		
R4639	R4671	R4703	R4735		
R4640	R4672	R4704	R4736		Feedback machine position 4th axis (L) [M]
R4641	R4673	R4705	R4737		Feedback machine position 4th axis (H) [M]
R4642	R4674	R4706	R4738		
R4643	R4675	R4707	R4739		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4644	R4676	R4708	R4740		Feedback machine position 5th axis (L) [M]
R4645	R4677	R4709	R4741		Feedback machine position 5th axis (H) [M]
R4646	R4678	R4710	R4742		
R4647	R4679	R4711	R4743		
R4648	R4680	R4712	R4744		Feedback machine position 6th axis (L) [M]
R4649	R4681	R4713	R4745		Feedback machine position 6th axis (H) [M]
R4650	R4682	R4714	R4746		
R4651	R4683	R4715	R4747		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4652	R4684	R4716	R4748		Feedback machine position 7th axis (L) [M]
R4653	R4685	R4717	R4749		Feedback machine position 7th axis (H) [M]
R4654	R4686	R4718	R4750		
R4655	R4687	R4719	R4751		
R4656	R4688	R4720	R4752		Feedback machine position 8th axis (L) [M]
R4657	R4689	R4721	R4753		Feedback machine position 8th axis (H) [M]
R4658	R4690	R4722	R4754		
R4659	R4691	R4723	R4755		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4756	R4772	R4788	R4804		Servo deflection amount 1st axis (L) [M]
R4757	R4773	R4789	R4805		Servo deflection amount 1st axis (H) [M]
R4758	R4774	R4790	R4806		Servo deflection amount 2nd axis (L) [M]
R4759	R4775	R4791	R4807		Servo deflection amount 2nd axis (H) [M]
R4760	R4776	R4792	R4808		Servo deflection amount 3rd axis (L) [M]
R4761	R4777	R4793	R4809		Servo deflection amount 3rd axis (H) [M]
R4762	R4778	R4794	R4810		Servo deflection amount 4th axis (L) [M]
R4763	R4779	R4795	R4811		Servo deflection amount 4th axis (H) [M]
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4764	R4780	R4796	R4812		Servo deflection amount 5th axis (L) [M]
R4765	R4781	R4797	R4813		Servo deflection amount 5th axis (H) [M]
R4766	R4782	R4798	R4814		Servo deflection amount 6th axis (L) [M]
R4767	R4783	R4799	R4815		Servo deflection amount 6th axis (H) [M]
R4768	R4784	R4800	R4816		Servo deflection amount 7th axis (L) [M]
R4769	R4785	R4801	R4817		Servo deflection amount 7th axis (H) [M]
R4770	R4786	R4802	R4818		Servo deflection amount 8th axis (L) [M]
R4771	R4787	R4803	R4819		Servo deflection amount 8th axis (H) [M]

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4820	R4836	R4852	R4868		Motor rotation speed 1st axis (L)
R4821	R4837	R4853	R4869		Motor rotation speed 1st axis (H)
R4822	R4838	R4854	R4870		Motor rotation speed 2nd axis (L)
R4823	R4839	R4855	R4871		Motor rotation speed 2nd axis (H)
R4824	R4840	R4856	R4872		Motor rotation speed 3rd axis (L)
R4825	R4841	R4857	R4873		Motor rotation speed 3rd axis (H)
R4826	R4842	R4858	R4874		Motor rotation speed 4th axis (L)
R4827	R4843	R4859	R4875		Motor rotation speed 4th axis (H)
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4828	R4844	R4860	R4876		Motor rotation speed 5th axis (L)
R4829	R4845	R4861	R4877		Motor rotation speed 5th axis (H)
R4830	R4846	R4862	R4878		Motor rotation speed 6th axis (L)
R4831	R4847	R4863	R4879		Motor rotation speed 6th axis (H)
R4832	R4848	R4864	R4880		Motor rotation speed 7th axis (L)
R4833	R4849	R4865	R4881		Motor rotation speed 7th axis (H)
R4834	R4850	R4866	R4882		Motor rotation speed 8th axis (L)
R4835	R4851	R4867	R4883		Motor rotation speed 8th axis (H)
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4884	R4900	R4916	R4932		Motor load current 1st axis (L)
R4885	R4901	R4917	R4933		Motor load current 1st axis (H)
R4886	R4902	R4918	R4934		Motor load current 2nd axis (L)
R4887	R4903	R4919	R4935		Motor load current 2nd axis (H)
R4888	R4904	R4920	R4936		Motor load current 3rd axis (L)
R4889	R4905	R4921	R4937		Motor load current 3rd axis (H)
R4890	R4906	R4922	R4938		Motor load current 4th axis (L)
R4891	R4907	R4923	R4939		Motor load current 4th axis (H)
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4892	R4908	R4924	R4940		Motor load current 5th axis (L)
R4893	R4909	R4925	R4941		Motor load current 5th axis (H)
R4894	R4910	R4926	R4942		Motor load current 6th axis (L)
R4895	R4911	R4927	R4943		Motor load current 6th axis (H)
R4896	R4912	R4928	R4944		Motor load current 7th axis (L)
R4897	R4913	R4929	R4945		Motor load current 7th axis (H)
R4898	R4914	R4930	R4946		Motor load current 8th axis (L)
R4899	R4915	R4931	R4947		Motor load current 8th axis (H)

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4948	R4980	R5012	R5044		Skip coordinate position 1st axis (L) [M]
R4949	R4981	R5013	R5045		Skip coordinate position 1st axis (H) [M]
R4950	R4982	R5014	R5046		
R4951	R4983	R5015	R5047		
R4952	R4984	R5016	R5048		Skip coordinate position 2nd axis (L) [M]
R4953	R4985	R5017	R5049		Skip coordinate position 2nd axis (H) [M]
R4954	R4986	R5018	R5050		
R4955	R4987	R5019	R5051		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4956	R4988	R5020	R5052		Skip coordinate position 3rd axis (L) [M]
R4957	R4989	R5021	R5053		Skip coordinate position 3rd axis (H) [M]
R4958	R4990	R5022	R5054		
R4959	R4991	R5023	R5055		
R4960	R4992	R5024	R5056		Skip coordinate position 4th axis (L) [M]
R4961	R4993	R5025	R5057		Skip coordinate position 4th axis (H) [M]
R4962	R4994	R5026	R5058		
R4963	R4995	R5027	R5059		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4964	R4996	R5028	R5060		Skip coordinate position 5th axis (L) [M]
R4965	R4997	R5029	R5061		Skip coordinate position 5th axis (H) [M]
R4966	R4998	R5030	R5062		
R4967	R4999	R5031	R5063		
R4968	R5000	R5032	R5064		Skip coordinate position 6th axis (L) [M]
R4969	R5001	R5033	R5065		Skip coordinate position 6th axis (H) [M]
R4970	R5002	R5034	R5066		
R4971	R5003	R5035	R5067		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R4972	R5004	R5036	R5068		Skip coordinate position 7th axis (L) [M]
R4973	R5005	R5037	R5069		Skip coordinate position 7th axis (H) [M]
R4974	R5006	R5038	R5070		
R4975	R5007	R5039	R5071		
R4976	R5008	R5040	R5072		Skip coordinate position 8th axis (L) [M]
R4977	R5009	R5041	R5073		Skip coordinate position 8th axis (H) [M]
R4978	R5010	R5042	R5074		
R4979	R5011	R5043	R5075		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R^{***})

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5076	R5092	R5108	R5124		Synchronous error amount 1st, 9th, 17th, 25th axis (L) [M]
R5077	R5093	R5109	R5125		Synchronous error amount 1st, 9th, 17th, 25th axis (H) [M]
R5078	R5094	R5110	R5126		Synchronous error amount 2nd, 10th, 18th, 26th axis (L) [M]
R5079	R5095	R5111	R5127		Synchronous error amount 2nd, 10th, 18th, 26th axis (H) [M]
R5080	R5096	R5112	R5128		Synchronous error amount 3rd, 11th, 19th, 27th axis (L) [M]
R5081	R5097	R5113	R5129		Synchronous error amount 3rd, 11th, 19th, 27th axis (H) [M]
R5082	R5098	R5114	R5130		Synchronous error amount 4th, 12th, 20th, 28th axis (L) [M]
R5083	R5099	R5115	R5131		Synchronous error amount 4th, 12th, 20th, 28th axis (H) [M]
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5084	R5100	R5116	R5132		Synchronous error amount 5th, 13th, 21st, 29th axis (L) [M]
R5085	R5101	R5117	R5133		Synchronous error amount 5th, 13th, 21st, 29th axis (H) [M]
R5086	R5102	R5118	R5134		Synchronous error amount 6th, 14th, 22nd, 30th axis (L) [M]
R5087	R5103	R5119	R5135		Synchronous error amount 6th, 14th, 22nd, 30th axis (H) [M]
R5088	R5104	R5120	R5136		Synchronous error amount 7th, 15th, 23rd, 31st axis (L) [M]
R5089	R5105	R5121	R5137		Synchronous error amount 7th, 15th, 23rd, 31st axis (H) [M]
R5090	R5106	R5122	R5138		Synchronous error amount 8th, 16th, 24th, 32nd axis (L) [M]
R5091	R5107	R5123	R5139		Synchronous error amount 8th, 16th, 24th, 32nd axis (H) [M]
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5140	R5148	R5156	R5164		Optimum acceleration/deceleration parameter group currently selected (axis) 1st axis ▲
R5141	R5149	R5157	R5165		Optimum acceleration/deceleration parameter group currently selected (axis) 2nd axis ▲
R5142	R5150	R5158	R5166		Optimum acceleration/deceleration parameter group currently selected (axis) 3rd axis ▲
R5143	R5151	R5159	R5167		Optimum acceleration/deceleration parameter group currently selected (axis) 4th axis ▲
R5144	R5152	R5160	R5168		Optimum acceleration/deceleration parameter group currently selected (axis) 5th axis ▲
R5145	R5153	R5161	R5169		Optimum acceleration/deceleration parameter group currently selected (axis) 6th axis ▲
R5146	R5154	R5162	R5170		Optimum acceleration/deceleration parameter group currently selected (axis) 7th axis ▲
R5147	R5155	R5163	R5171		Optimum acceleration/deceleration parameter group currently selected (axis) 8th axis ▲

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5172	R5204	R5236	R5268		Cutting feed movement amount 1st axis (L) [M]
R5173	R5205	R5237	R5269		Cutting feed movement amount 1st axis (H) [M]
R5174	R5206	R5238	R5270		
R5175	R5207	R5239	R5271		
R5176	R5208	R5240	R5272		Cutting feed movement amount 2nd axis (L) [M]
R5177	R5209	R5241	R5273		Cutting feed movement amount 2nd axis (H) [M]
R5178	R5210	R5242	R5274		
R5179	R5211	R5243	R5275		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5180	R5212	R5244	R5276		Cutting feed movement amount 3rd axis (L) [M]
R5181	R5213	R5245	R5277		Cutting feed movement amount 3rd axis (H) [M]
R5182	R5214	R5246	R5278		
R5183	R5215	R5247	R5279		
R5184	R5216	R5248	R5280		Cutting feed movement amount 4th axis (L) [M]
R5185	R5217	R5249	R5281		Cutting feed movement amount 4th axis (H) [M]
R5186	R5218	R5250	R5282		
R5187	R5219	R5251	R5283		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5188	R5220	R5252	R5284		Cutting feed movement amount 5th axis (L) [M]
R5189	R5221	R5253	R5285		Cutting feed movement amount 5th axis (H) [M]
R5190	R5222	R5254	R5286		
R5191	R5223	R5255	R5287		
R5192	R5224	R5256	R5288		Cutting feed movement amount 6th axis (L) [M]
R5193	R5225	R5257	R5289		Cutting feed movement amount 6th axis (H) [M]
R5194	R5226	R5258	R5290		
R5195	R5227	R5259	R5291		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5196	R5228	R5260	R5292		Cutting feed movement amount 7th axis (L) [M]
R5197	R5229	R5261	R5293		Cutting feed movement amount 7th axis (H) [M]
R5198	R5230	R5262	R5294		
R5199	R5231	R5263	R5295		
R5200	R5232	R5264	R5296		Cutting feed movement amount 8th axis (L) [M]
R5201	R5233	R5265	R5297		Cutting feed movement amount 8th axis (H) [M]
R5202	R5234	R5266	R5298		
R5203	R5235	R5267	R5299		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5300	R5308	R5316	R5324		
R5301	R5309	R5317	R5325		
R5302	R5310	R5318	R5326		
R5303	R5311	R5319	R5327		
R5304	R5312	R5320	R5328		
R5305	R5313	R5321	R5329		
R5306	R5314	R5322	R5330		
R5307	R5315	R5323	R5331		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R^{***})

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5332	R5340	R5348	R5356		Servo alarm/warning No. 1st axis
R5333	R5341	R5349	R5357		Servo alarm/warning No. 2nd axis
R5334	R5342	R5350	R5358		Servo alarm/warning No. 3rd axis
R5335	R5343	R5351	R5359		Servo alarm/warning No. 4th axis
R5336	R5344	R5352	R5360		Servo alarm/warning No. 5th axis
R5337	R5345	R5353	R5361		Servo alarm/warning No. 6th axis
R5338	R5346	R5354	R5362		Servo alarm/warning No. 7th axis
R5339	R5347	R5355	R5363		Servo alarm/warning No. 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5364	R5396	R5428	R5460		Skip coordinate position 1st axis feature coordinate (L) [M]
R5365	R5397	R5429	R5461		Skip coordinate position 1st axis feature coordinate (H) [M]
R5366	R5398	R5430	R5462		
R5367	R5399	R5431	R5463		
R5368	R5400	R5432	R5464		Skip coordinate position 2nd axis feature coordinate (L) [M]
R5369	R5401	R5433	R5465		Skip coordinate position 2nd axis feature coordinate (H) [M]
R5370	R5402	R5434	R5466		
R5371	R5403	R5435	R5467		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5372	R5404	R5436	R5468		Skip coordinate position 3rd axis feature coordinate (L) [M]
R5373	R5405	R5437	R5469		Skip coordinate position 3rd axis feature coordinate (H) [M]
R5374	R5406	R5438	R5470		
R5375	R5407	R5439	R5471		
R5376	R5408	R5440	R5472		Skip coordinate position 4th axis feature coordinate (L) [M]
R5377	R5409	R5441	R5473		Skip coordinate position 4th axis feature coordinate (H) [M]
R5378	R5410	R5442	R5474		
R5379	R5411	R5443	R5475		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5380	R5412	R5444	R5476		Skip coordinate position 5th axis feature coordinate (L) [M]
R5381	R5413	R5445	R5477		Skip coordinate position 5th axis feature coordinate (H) [M]
R5382	R5414	R5446	R5478		
R5383	R5415	R5447	R5479		
R5384	R5416	R5448	R5480		Skip coordinate position 6th axis feature coordinate (L) [M]
R5385	R5417	R5449	R5481		Skip coordinate position 6th axis feature coordinate (H) [M]
R5386	R5418	R5450	R5482		
R5387	R5419	R5451	R5483		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5388	R5420	R5452	R5484		Skip coordinate position 7th axis feature coordinate (L) [M]
R5389	R5421	R5453	R5485		Skip coordinate position 7th axis feature coordinate (H) [M]
R5390	R5422	R5454	R5486		
R5391	R5423	R5455	R5487		
R5392	R5424	R5456	R5488		Skip coordinate position 8th axis feature coordinate (L) [M]
R5393	R5425	R5457	R5489		Skip coordinate position 8th axis feature coordinate (H) [M]
R5394	R5426	R5458	R5490		
R5395	R5427	R5459	R5491		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5492	R5500	R5508	R5516		Load monitor I: Cutting torque output value 1st axis ▲
R5493	R5501	R5509	R5517		Load monitor I: Cutting torque output value 2nd axis ▲
R5494	R5502	R5510	R5518		Load monitor I: Cutting torque output value 3rd axis ▲
R5495	R5503	R5511	R5519		Load monitor I: Cutting torque output value 4th axis ▲
R5496	R5504	R5512	R5520		Load monitor I: Cutting torque output value 5th axis ▲
R5497	R5505	R5513	R5521		Load monitor I: Cutting torque output value 6th axis ▲
R5498	R5506	R5514	R5522		Load monitor I: Cutting torque output value 7th axis ▲
R5499	R5507	R5515	R5523		Load monitor I: Cutting torque output value 8th axis ▲
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5524	R5532	R5540	R5548		Actual machining time 1st axis ▲
R5525	R5533	R5541	R5549		Actual machining time 2nd axis ▲
R5526	R5534	R5542	R5550		Actual machining time 3rd axis ▲
R5527	R5535	R5543	R5551		Actual machining time 4th axis ▲
R5528	R5536	R5544	R5552		Actual machining time 5th axis ▲
R5529	R5537	R5545	R5553		Actual machining time 6th axis ▲
R5530	R5538	R5546	R5554		Actual machining time 7th axis ▲
R5531	R5539	R5547	R5555		Actual machining time 8th axis ▲
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5556	R5564	R5572	R5580	SVINER1	Optimum acceleration/deceleration selection: NC axis estimated inertia ratio 1st axis ▲
R5557	R5565	R5573	R5581	SVINER2	Optimum acceleration/deceleration selection: NC axis estimated inertia ratio 2nd axis ▲
R5558	R5566	R5574	R5582	SVINER3	Optimum acceleration/deceleration selection: NC axis estimated inertia ratio 3rd axis ▲
R5559	R5567	R5575	R5583	SVINER4	Optimum acceleration/deceleration selection: NC axis estimated inertia ratio 4th axis ▲
R5560	R5568	R5576	R5584	SVINER5	Optimum acceleration/deceleration selection: NC axis estimated inertia ratio 5th axis ▲
R5561	R5569	R5577	R5585	SVINER6	Optimum acceleration/deceleration selection: NC axis estimated inertia ratio 6th axis ▲
R5562	R5570	R5578	R5586	SVINER7	Optimum acceleration/deceleration selection: NC axis estimated inertia ratio 7th axis ▲
R5563	R5571	R5579	R5587	SVINER8	Optimum acceleration/deceleration selection: NC axis estimated inertia ratio 8th axis ▲

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5588	R5596	R5604	R5612	SVAFLT1	Optimum acceleration/deceleration selection: NC axis estimated resonance frequency 1st axis ▲
R5589	R5597	R5605	R5613	SVAFLT2	Optimum acceleration/deceleration selection: NC axis estimated resonance frequency 2nd axis ▲
R5590	R5598	R5606	R5614	SVAFLT3	Optimum acceleration/deceleration selection: NC axis estimated resonance frequency 3rd axis ▲
R5591	R5599	R5607	R5615	SVAFLT4	Optimum acceleration/deceleration selection: NC axis estimated resonance frequency 4th axis ▲
R5592	R5600	R5608	R5616	SVAFLT5	Optimum acceleration/deceleration selection: NC axis estimated resonance frequency 5th axis ▲
R5593	R5601	R5609	R5617	SVAFLT6	Optimum acceleration/deceleration selection: NC axis estimated resonance frequency 6th axis ▲
R5594	R5602	R5610	R5618	SVAFLT7	Optimum acceleration/deceleration selection: NC axis estimated resonance frequency 7th axis ▲
R5595	R5603	R5611	R5619	SVAFLT8	Optimum acceleration/deceleration selection: NC axis estimated resonance frequency 8th axis ▲
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5620	R5628	R5636	R5644		Load monitoring I: Effective torque output 1st axis
R5621	R5629	R5637	R5645		Load monitoring I: Effective torque output 2nd axis
R5622	R5630	R5638	R5646		Load monitoring I: Effective torque output 3rd axis
R5623	R5631	R5639	R5647		Load monitoring I: Effective torque output 4th axis
R5624	R5632	R5640	R5648		Load monitoring I: Effective torque output 5th axis
R5625	R5633	R5641	R5649		Load monitoring I: Effective torque output 6th axis
R5626	R5634	R5642	R5650		Load monitoring I: Effective torque output 7th axis
R5627	R5635	R5643	R5651		Load monitoring I: Effective torque output 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5652	R5660	R5668	R5676		
R5653	R5661	R5669	R5677		
R5654	R5662	R5670	R5678		
R5655	R5663	R5671	R5679		
R5656	R5664	R5672	R5680		
R5657	R5665	R5673	R5681		
R5658	R5666	R5674	R5682		
R5659	R5667	R5675	R5683		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R6372	R6380	R6388	R6396	R6404	R6412	R6420	R6428		User macro output #1132 (NC -> PLC) (L)
R6373	R6381	R6389	R6397	R6405	R6413	R6421	R6429		User macro output #1132 (NC -> PLC) (H)
R6374	R6382	R6390	R6398	R6406	R6414	R6422	R6430		User macro output #1133 (NC -> PLC) (L)
R6375	R6383	R6391	R6399	R6407	R6415	R6423	R6431		User macro output #1133 (NC -> PLC) (H)
R6376	R6384	R6392	R6400	R6408	R6416	R6424	R6432		User macro output #1134 (NC -> PLC) (L)
R6377	R6385	R6393	R6401	R6409	R6417	R6425	R6433		User macro output #1134 (NC -> PLC) (H)
R6378	R6386	R6394	R6402	R6410	R6418	R6426	R6434		User macro output #1135 (NC -> PLC) (L)
R6379	R6387	R6395	R6403	R6411	R6419	R6427	R6435		User macro output #1135 (NC -> PLC) (H)

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
R6500	R6550	R6600	R6650	R6700	R6750	R6800	R6850		Spindle command rotation speed input (L)
R6501	R6551	R6601	R6651	R6701	R6751	R6801	R6851		Spindle command rotation speed input (H)
R6502	R6552	R6602	R6652	R6702	R6752	R6802	R6852		Spindle command final data (rotation speed) (L)
R6503	R6553	R6603	R6653	R6703	R6753	R6803	R6853		Spindle command final data (rotation speed) (H)
R6504	R6554	R6604	R6654	R6704	R6754	R6804	R6854		Spindle command final data (12-bit binary) (L)
R6505	R6555	R6605	R6655	R6705	R6755	R6805	R6855		Spindle command final data (12-bit binary) (H)
R6506	R6556	R6606	R6656	R6706	R6756	R6806	R6856		Spindle actual speed (L)
R6507	R6557	R6607	R6657	R6707	R6757	R6807	R6857		Spindle actual speed (H)
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
R6508	R6558	R6608	R6658	R6708	R6758	R6808	R6858		
R6509	R6559	R6609	R6659	R6709	R6759	R6809	R6859		
R6510	R6560	R6610	R6660	R6710	R6760	R6810	R6860		
R6511	R6561	R6611	R6661	R6711	R6761	R6811	R6861		
R6512	R6562	R6612	R6662	R6712	R6762	R6812	R6862		
R6513	R6563	R6613	R6663	R6713	R6763	R6813	R6863		
R6514	R6564	R6614	R6664	R6714	R6764	R6814	R6864		Optimum acceleration/deceleration: Estimated inertia ratio (spindle) ▲
R6515	R6565	R6615	R6665	R6715	R6765	R6815	R6865		Optimum acceleration/deceleration parameter group currently selected (spindle) ▲
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
R6516	R6566	R6616	R6666	R6716	R6766	R6816	R6866		Spindle synchronization: Phase error/Hob axis delay angle
R6517	R6567	R6617	R6667	R6717	R6767	R6817	R6867		Spindle synchronization: Maximum phase error/Maximum hob axis delay angle
R6518	R6568	R6618	R6668	R6718	R6768	R6818	R6868		Spindle synchronization: Phase offset data
R6519	R6569	R6619	R6669	R6719	R6769	R6819	R6869		Spindle synchronization: Phase error monitor
R6520	R6570	R6620	R6670	R6720	R6770	R6820	R6870		Spindle synchronization: Phase error monitor (lower limit)
R6521	R6571	R6621	R6671	R6721	R6771	R6821	R6871		Spindle synchronization: Phase error monitor (upper limit)
R6522	R6572	R6622	R6672	R6722	R6772	R6822	R6872		Spindle synchronization: Phase error 1
R6523	R6573	R6623	R6673	R6723	R6773	R6823	R6873		Spindle synchronization: Phase error 2
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
R6524	R6574	R6624	R6674	R6724	R6774	R6824	R6874		
R6525	R6575	R6625	R6675	R6725	R6775	R6825	R6875		Spindle motor load ratio
R6526	R6576	R6626	R6676	R6726	R6776	R6826	R6876	SP-TEMP	Spindle temperature output
R6527	R6577	R6627	R6677	R6727	R6777	R6827	R6877		Spindle actual machining time ▲
R6528	R6578	R6628	R6678	R6728	R6778	R6828	R6878		Load monitor I: Spindle cutting torque output value ▲
R6529	R6579	R6629	R6679	R6729	R6779	R6829	R6879		Spindle alarm/warning No.
R6530	R6580	R6630	R6680	R6730	R6780	R6830	R6880		
R6531	R6581	R6631	R6681	R6731	R6781	R6831	R6881		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R^{***})

Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
R6532	R6582	R6632	R6682	R6732	R6782	R6832	R6882		Synchronous tapping Current error width (L)
R6533	R6583	R6633	R6683	R6733	R6783	R6833	R6883		Synchronous tapping Current error width (H)
R6534	R6584	R6634	R6684	R6734	R6784	R6834	R6884		Synchronous tapping Maximum error width (L)
R6535	R6585	R6635	R6685	R6735	R6785	R6835	R6885		Synchronous tapping Maximum error width (H)
R6536	R6586	R6636	R6686	R6736	R6786	R6836	R6886		Synchronous tapping Current error angle (L)
R6537	R6587	R6637	R6687	R6737	R6787	R6837	R6887		Synchronous tapping Current error angle (H)
R6538	R6588	R6638	R6688	R6738	R6788	R6838	R6888		Synchronous tapping Maximum error angle (L)
R6539	R6589	R6639	R6689	R6739	R6789	R6839	R6889		Synchronous tapping Maximum error angle (H)

Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
R6540	R6590	R6640	R6690	R6740	R6790	R6840	R6890		
R6541	R6591	R6641	R6691	R6741	R6791	R6841	R6891		Load monitoring I: Estimated spindle disturbance torque output
R6542	R6592	R6642	R6692	R6742	R6792	R6842	R6892		Load monitoring I: Effective spindle torque output
R6543	R6593	R6643	R6693	R6743	R6793	R6843	R6893		
R6544	R6594	R6644	R6694	R6744	R6794	R6844	R6894		
R6545	R6595	R6645	R6695	R6745	R6795	R6845	R6895		
R6546	R6596	R6646	R6696	R6746	R6796	R6846	R6896		
R6547	R6597	R6647	R6697	R6747	R6797	R6847	R6897		

Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
R7024	R7074	R7124	R7174	R7224	R7274	R7324	R7374	VC-C_SPR EV	VCC: Spindle rotation speed
R7025	R7075	R7125	R7175	R7225	R7275	R7325	R7375		
R7026	R7076	R7126	R7176	R7226	R7276	R7326	R7376		
R7027	R7077	R7127	R7177	R7227	R7277	R7327	R7377		
R7028	R7078	R7128	R7178	R7228	R7278	R7328	R7378		
R7029	R7079	R7129	R7179	R7229	R7279	R7329	R7379		
R7030	R7080	R7130	R7180	R7230	R7280	R7330	R7380		
R7031	R7081	R7131	R7181	R7231	R7281	R7331	R7381		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10000		RIO1 No. of error occurrences 1st ch	R10008		RIO2 No. of error occurrences 1st ch
R10001		RIO1 No. of error occurrences 2nd ch	R10009		RIO2 No. of error occurrences 2nd ch
R10002		RIO1 No. of error occurrences 3rd ch	R10010		RIO2 No. of error occurrences 3rd ch
R10003		RIO1 No. of error occurrences 4th ch	R10011		RIO2 No. of error occurrences 4th ch
R10004		RIO1 No. of error occurrences 5th ch	R10012		RIO2 No. of error occurrences 5th ch
R10005		RIO1 No. of error occurrences 6th ch	R10013		RIO2 No. of error occurrences 6th ch
R10006		RIO1 No. of error occurrences 7th ch	R10014		RIO2 No. of error occurrences 7th ch
R10007		RIO1 No. of error occurrences 8th ch	R10015		RIO2 No. of error occurrences 8th ch
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10016		RIO3 No. of error occurrences 1st ch	R10024		
R10017		RIO3 No. of error occurrences 2nd ch	R10025		
R10018		RIO3 No. of error occurrences 3rd ch	R10026		
R10019		RIO3 No. of error occurrences 4th ch	R10027		
R10020		RIO3 No. of error occurrences 5th ch	R10028		
R10021		RIO3 No. of error occurrences 6th ch	R10029		
R10022		RIO3 No. of error occurrences 7th ch	R10030		
R10023		RIO3 No. of error occurrences 8th ch	R10031		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10064		Connection status of each channel RIO1,2	R10072		
R10065		Connection status of each channel RIO3	R10073		
R10066			R10074		
R10067			R10075		
R10068		CRC warning channel RIO1,2	R10076		
R10069		CRC warning channel RIO3	R10077		
R10070			R10078		
R10071			R10079		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10176			R10184		
R10177			R10185		
R10178			R10186		
R10179			R10187		
R10180			R10188		Base PLC mounting check (L)
R10181			R10189		Base PLC mounting check (H)
R10182			R10190		
R10183			R10191		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R^{***})

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R11800	R11850	R11900	R11950	R12000	R12050	R12100	R12150		Tool life management (M system) Spare tool: Group No. (L)
R11801	R11851	R11901	R11951	R12001	R12051	R12101	R12151		Spare tool: Group No. (H)
R11802	R11852	R11902	R11952	R12002	R12052	R12102	R12152		Spare tool: Tool No. (L)
R11803	R11853	R11903	R11953	R12003	R12053	R12103	R12153		Spare tool: Tool No. (H)
R11804	R11854	R11904	R11954	R12004	R12054	R12104	R12154		Spare tool: Tool data flag/Status
R11805	R11855	R11905	R11955	R12005	R12055	R12105	R12155		Spare tool: Auxiliary data
R11806	R11856	R11906	R11956	R12006	R12056	R12106	R12156		Spare tool: Cumulative usage time (L)
R11807	R11857	R11907	R11957	R12007	R12057	R12107	R12157		Spare tool: Cumulative usage time (H)
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R11808	R11858	R11908	R11958	R12008	R12058	R12108	R12158		Spare tool: Service lifetime (L)
R11809	R11859	R11909	R11959	R12009	R12059	R12109	R12159		Spare tool: Service lifetime (H)
R11810	R11860	R11910	R11960	R12010	R12060	R12110	R12160		Spare tool: Cumulative usage count
R11811	R11861	R11911	R11961	R12011	R12061	R12111	R12161		Spare tool: Service life count
R11812	R11862	R11912	R11962	R12012	R12062	R12112	R12162		Spare tool: Cumulative usage wear amount (L)
R11813	R11863	R11913	R11963	R12013	R12063	R12113	R12163		Spare tool: Cumulative usage wear amount (H)
R11814	R11864	R11914	R11964	R12014	R12064	R12114	R12164		Spare tool: Service life wear amount (L)
R11815	R11865	R11915	R11965	R12015	R12065	R12115	R12165		Spare tool: Service life wear amount (H)
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R11816	R11866	R11916	R11966	R12016	R12066	R12116	R12166		Spare tool: Length compensation amount (L)
R11817	R11867	R11917	R11967	R12017	R12067	R12117	R12167		Spare tool: Length compensation amount (H)
R11818	R11868	R11918	R11968	R12018	R12068	R12118	R12168		Spare tool: Radius compensation amount (L)
R11819	R11869	R11919	R11969	R12019	R12069	R12119	R12169		Spare tool: Radius compensation amount (H)
R11820	R11870	R11920	R11970	R12020	R12070	R12120	R12170		Spare tool: Length wear amount (L)
R11821	R11871	R11921	R11971	R12021	R12071	R12121	R12171		Spare tool: Length wear amount (H)
R11822	R11872	R11922	R11972	R12022	R12072	R12122	R12172		Spare tool: Radius wear amount (L)
R11823	R11873	R11923	R11973	R12023	R12073	R12123	R12173		Spare tool: Radius wear amount (H)

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R11824	R11874	R11924	R11974	R12024	R12074	R12124	R12174		Tool life management (M system) Active tool: Group No. (L)
R11825	R11875	R11925	R11975	R12025	R12075	R12125	R12175		Active tool: Group No. (H)
R11826	R11876	R11926	R11976	R12026	R12076	R12126	R12176		Active tool: Tool No. (L)
R11827	R11877	R11927	R11977	R12027	R12077	R12127	R12177		Active tool: Tool No. (H)
R11828	R11878	R11928	R11978	R12028	R12078	R12128	R12178		Active tool: Tool data flag/Status
R11829	R11879	R11929	R11979	R12029	R12079	R12129	R12179		Active tool: Auxiliary data
R11830	R11880	R11930	R11980	R12030	R12080	R12130	R12180		Active tool: Cumulative usage time (L)
R11831	R11881	R11931	R11981	R12031	R12081	R12131	R12181		Active tool: Cumulative usage time (H)
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R11832	R11882	R11932	R11982	R12032	R12082	R12132	R12182		Active tool: Service lifetime (L)
R11833	R11883	R11933	R11983	R12033	R12083	R12133	R12183		Active tool: Service lifetime (H)
R11834	R11884	R11934	R11984	R12034	R12084	R12134	R12184		Active tool: Cumulative usage count
R11835	R11885	R11935	R11985	R12035	R12085	R12135	R12185		Active tool: Service life count
R11836	R11886	R11936	R11986	R12036	R12086	R12136	R12186		Active tool: Cumulative usage wear amount (L)
R11837	R11887	R11937	R11987	R12037	R12087	R12137	R12187		Active tool: Cumulative usage wear amount (H)
R11838	R11888	R11938	R11988	R12038	R12088	R12138	R12188		Active tool: Service life wear amount (L)
R11839	R11889	R11939	R11989	R12039	R12089	R12139	R12189		Active tool: Service life wear amount (H)
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R11840	R11890	R11940	R11990	R12040	R12090	R12140	R12190		Active tool: Length compensation amount (L)
R11841	R11891	R11941	R11991	R12041	R12091	R12141	R12191		Active tool: Length compensation amount (H)
R11842	R11892	R11942	R11992	R12042	R12092	R12142	R12192		Active tool: Radius compensation amount (L)
R11843	R11893	R11943	R11993	R12043	R12093	R12143	R12193		Active tool: Radius compensation amount (H)
R11844	R11894	R11944	R11994	R12044	R12094	R12144	R12194		Active tool: Length wear amount (L)
R11845	R11895	R11945	R11995	R12045	R12095	R12145	R12195		Active tool: Length wear amount (H)
R11846	R11896	R11946	R11996	R12046	R12096	R12146	R12196		Active tool: Radius wear amount (L)
R11847	R11897	R11947	R11997	R12047	R12097	R12147	R12197		Active tool: Radius wear amount (H)

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14000		EcoMonitorLight connection: Station #1 consumed power	R14008		
R14001			R14009		
R14002		EcoMonitorLight connection: Station #1 regenerated power	R14010		EcoMonitorLight connection: Station #2 consumed power
R14003			R14011		
R14004			R14012		EcoMonitorLight connection: Station #2 regenerated power
R14005			R14013		
R14006			R14014		
R14007			R14015		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14016			R14024		
R14017			R14025		
R14018			R14026		
R14019			R14027		
R14020		EcoMonitorLight connection: Station #3 consumed power	R14028		
R14021			R14029		
R14022		EcoMonitorLight connection: Station #3 regenerated power	R14030		EcoMonitorLight connection: Station #4 consumed power
R14023			R14031		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14032		EcoMonitorLight connection: Station #4 regenerated power	R14040		EcoMonitorLight connection: Station #5 consumed power
R14033			R14041		
R14034			R14042		EcoMonitorLight connection: Station #5 regenerated power
R14035			R14043		
R14036			R14044		
R14037			R14045		
R14038			R14046		
R14039			R14047		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14048			R14056		
R14049			R14057		
R14050		EcoMonitorLight connection: Station #6 consumed power	R14058		
R14051			R14059		
R14052		EcoMonitorLight connection: Station #6 regenerated power	R14060		EcoMonitorLight connection: Station #7 consumed power
R14053			R14061		
R14054			R14062		EcoMonitorLight connection: Station #7 regenerated power
R14055			R14063		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14064			R14072		EcoMonitorLight connection: Station #8 regenerated power
R14065			R14073		
R14066			R14074		
R14067			R14075		
R14068			R14076		
R14069			R14077		
R14070		EcoMonitorLight connection: Station #8 consumed power	R14078		
R14071			R14079		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14080		EcoMonitorLight connection: Station #9 consumed power	R14088		
R14081			R14089		
R14082		EcoMonitorLight connection: Station #9 regenerated power	R14090		EcoMonitorLight connection: Station #10 consumed power
R14083			R14091		
R14084			R14092		EcoMonitorLight connection: Station #10 regenerated power
R14085			R14093		
R14086			R14094		
R14087			R14095		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14096			R14104		
R14097			R14105		
R14098			R14106		
R14099			R14107		
R14100		EcoMonitorLight connection: Station #11 consumed power	R14108		
R14101			R14109		
R14102		EcoMonitorLight connection: Station #11 regenerated power	R14110		EcoMonitorLight connection: Station #12 consumed power
R14103			R14111		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14112		EcoMonitorLight connection: Station #12 regenerated power	R14120		EcoMonitorLight connection: Station #13 consumed power
R14113			R14121		
R14114			R14122		EcoMonitorLight connection: Station #13 regenerated power
R14115			R14123		
R14116			R14124		
R14117			R14125		
R14118			R14126		
R14119			R14127		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14128			R14136		
R14129			R14137		
R14130		EcoMonitorLight connection: Station #14 consumed power	R14138		
R14131			R14139		
R14132		EcoMonitorLight connection: Station #14 regenerated power	R14140		EcoMonitorLight connection: Station #15 consumed power
R14133			R14141		
R14134			R14142		EcoMonitorLight connection: Station #15 regenerated power
R14135			R14143		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14144			R14152		EcoMonitorLight connection: Station #16 re-generated power
R14145			R14153		
R14146			R14154		
R14147			R14155		
R14148			R14156		
R14149			R14157		
R14150		EcoMonitorLight connection: Station #16 consumed power	R14158		
R14151			R14159		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14192			R14200		EcoMonitorLight connection: Station #1 number of reception errors
R14193			R14201		EcoMonitorLight connection: Station #1 maximum number of successive reception errors
R14194			R14202		EcoMonitorLight connection: Station #1 number of transmission errors
R14195			R14203		EcoMonitorLight connection: Station #1 maximum number of successive transmission errors
R14196			R14204		
R14197			R14205		
R14198			R14206		
R14199			R14207		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14208			R14216		
R14209			R14217		
R14210		EcoMonitorLight connection: Station #2 number of reception errors	R14218		
R14211		EcoMonitorLight connection: Station #2 maximum number of successive reception errors	R14219		
R14212		EcoMonitorLight connection: Station #2 number of transmission errors	R14220		EcoMonitorLight connection: Station #3 number of reception errors
R14213		EcoMonitorLight connection: Station #2 maximum number of successive transmission errors	R14221		EcoMonitorLight connection: Station #3 maximum number of successive reception errors
R14214			R14222		EcoMonitorLight connection: Station #3 number of transmission errors
R14215			R14223		EcoMonitorLight connection: Station #3 maximum number of successive transmission errors
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14224			R14232		EcoMonitorLight connection: Station #4 number of transmission errors
R14225			R14233		EcoMonitorLight connection: Station #4 maximum number of successive transmission errors
R14226			R14234		
R14227			R14235		
R14228			R14236		
R14229			R14237		
R14230		EcoMonitorLight connection: Station #4 number of reception errors	R14238		
R14231		EcoMonitorLight connection: Station #4 maximum number of successive reception errors	R14239		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14240		EcoMonitorLight connection: Station #5 number of reception errors	R14248		
R14241		EcoMonitorLight connection: Station #5 maximum number of successive reception errors	R14249		
R14242		EcoMonitorLight connection: Station #5 number of transmission errors	R14250		EcoMonitorLight connection: Station #6 number of reception errors
R14243		EcoMonitorLight connection: Station #5 maximum number of successive transmission errors	R14251		EcoMonitorLight connection: Station #6 maximum number of successive reception errors
R14244			R14252		EcoMonitorLight connection: Station #6 number of transmission errors
R14245			R14253		EcoMonitorLight connection: Station #6 maximum number of successive transmission errors
R14246			R14254		
R14247			R14255		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14256			R14264		
R14257			R14265		
R14258			R14266		
R14259			R14267		
R14260		EcoMonitorLight connection: Station #7 number of reception errors	R14268		
R14261		EcoMonitorLight connection: Station #7 maximum number of successive reception errors	R14269		
R14262		EcoMonitorLight connection: Station #7 number of transmission errors	R14270		EcoMonitorLight connection: Station #8 number of reception errors
R14263		EcoMonitorLight connection: Station #7 maximum number of successive transmission errors	R14271		EcoMonitorLight connection: Station #8 maximum number of successive reception errors
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14272		EcoMonitorLight connection: Station #8 number of transmission errors	R14280		EcoMonitorLight connection: Station #9 number of reception errors
R14273		EcoMonitorLight connection: Station #8 maximum number of successive transmission errors	R14281		EcoMonitorLight connection: Station #9 maximum number of successive reception errors
R14274			R14282		EcoMonitorLight connection: Station #9 number of transmission errors
R14275			R14283		EcoMonitorLight connection: Station #9 maximum number of successive transmission errors
R14276			R14284		
R14277			R14285		
R14278			R14286		
R14279			R14287		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14288			R14296		
R14289			R14297		
R14290		EcoMonitorLight connection: Station #10 number of reception errors	R14298		
R14291		EcoMonitorLight connection: Station #10 maximum number of successive reception errors	R14299		
R14292		EcoMonitorLight connection: Station #10 number of transmission errors	R14300		EcoMonitorLight connection: Station #11 number of reception errors
R14293		EcoMonitorLight connection: Station #10 maximum number of successive transmission errors	R14301		EcoMonitorLight connection: Station #11 maximum number of successive reception errors
R14294			R14302		EcoMonitorLight connection: Station #11 number of transmission errors
R14295			R14303		EcoMonitorLight connection: Station #11 maximum number of successive transmission errors
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14304			R14312		EcoMonitorLight connection: Station #12 number of transmission errors
R14305			R14313		EcoMonitorLight connection: Station #12 maximum number of successive transmission errors
R14306			R14314		
R14307			R14315		
R14308			R14316		
R14309			R14317		
R14310		EcoMonitorLight connection: Station #12 number of reception errors	R14318		
R14311		EcoMonitorLight connection: Station #12 maximum number of successive reception errors	R14319		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14320		EcoMonitorLight connection: Station #13 number of reception errors	R14328		
R14321		EcoMonitorLight connection: Station #13 maximum number of successive reception errors	R14329		
R14322		EcoMonitorLight connection: Station #13 number of transmission errors	R14330		EcoMonitorLight connection: Station #14 number of reception errors
R14323		EcoMonitorLight connection: Station #13 maximum number of successive transmission errors	R14331		EcoMonitorLight connection: Station #14 maximum number of successive reception errors
R14324			R14332		EcoMonitorLight connection: Station #14 number of transmission errors
R14325			R14333		EcoMonitorLight connection: Station #14 maximum number of successive transmission errors
R14326			R14334		
R14327			R14335		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14336			R14344		
R14337			R14345		
R14338			R14346		
R14339			R14347		
R14340		EcoMonitorLight connection: Station #15 number of reception errors	R14348		
R14341		EcoMonitorLight connection: Station #15 maximum number of successive reception errors	R14349		
R14342		EcoMonitorLight connection: Station #15 number of transmission errors	R14350		EcoMonitorLight connection: Station #16 number of reception errors
R14343		EcoMonitorLight connection: Station #15 maximum number of successive transmission errors	R14351		EcoMonitorLight connection: Station #16 maximum number of successive reception errors
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14352		EcoMonitorLight connection: Station #16 number of transmission errors	R14360		
R14353		EcoMonitorLight connection: Station #16 maximum number of successive transmission errors	R14361		
R14354			R14362		
R14355			R14363		
R14356			R14364		
R14357			R14365		
R14358			R14366		
R14359			R14367		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14400		EcoMonitorLight connection: Completion bit			
R14401		EcoMonitorLight connection: Completion status			
R14402		EcoMonitorLight connection: Acquired data			
R14403					
R14404					
R14405					
R14406					
R14407					

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14500		MES interface library: Serial number	R14508		MES interface library: Serial number
R14501			R14509		
R14502			R14510		
R14503			R14511		
R14504			R14512		
R14505			R14513		
R14506			R14514		
R14507			R14515		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14516		MES interface library: Serial number	R14524		MES interface library: Serial number
R14517			R14525		
R14518			R14526		
R14519			R14527		
R14520			R14528		
R14521			R14529		
R14522			R14530		
R14523			R14531		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14532		MES interface library: Operator ID	R14540		MES interface library: Operator ID
R14533			R14541		
R14534			R14542		
R14535			R14543		
R14536			R14544		
R14537			R14545		
R14538			R14546		
R14539			R14547		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14548		MES interface library: Operator ID	R14556		MES interface library: Operator ID
R14549			R14557		
R14550			R14558		
R14551			R14559		
R14552			R14560		
R14553			R14561		
R14554			R14562		
R14555			R14563		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14564		MES interface library: NC unit number	R14572		MES interface library: Line number
R14565			R14573		
R14566			R14574		
R14567			R14575		
R14568			R14576		
R14569			R14577		
R14570			R14578		
R14571			R14579		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14580		MES interface library: Line number	R14588		MES interface library: Machine type
R14581			R14589		MES interface library: Database connection status
R14582			R14590		MES interface library: Database operation request register
R14583			R14591		MES interface library: Database operation reception register
R14584			R14592		MES interface library: Database operation result register
R14585			R14593		
R14586			R14594		
R14587			R14595		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R14596		MES interface library: Database operation result register	R14604		MES interface library: G code modal registration selection
R14597			R14605		
R14598		MES interface library: DB operation selection	R14606		
R14599		MES interface library: Operation table selection	R14607		
R14600		MES interface library: Function selection at machining end	R14608		
R14601		MES interface library: Function selection at alarm	R14609		
R14602		MES interface library: Function selection at user's option	R14610		
R14603			R14611		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20000	FLSYSM	FL-net: System monitor ▲	R20008	RULS	FL-net: Upper layer status of reference node ▲
R20001	LNA	FL-net: Local node address ▲	R20009	RCAD1	FL-net: Common memory area 1 data top address of reference node ▲
R20002	LULS	FL-net: Upper layer status of local node ▲	R20010	RCSZ1	FL-net: Common memory area 1 data size of reference node ▲
R20003	LLKS	FL-net: Link status of local node ▲	R20011	RCAD2	FL-net: Common memory area 2 data top address of reference node ▲
R20004	LSTS	FL-net: Status of local node ▲	R20012	RCSZ2	FL-net: Common memory area 2 data size of reference node ▲
R20005	PNADSP	FL-net: Participating node top address on display ▲	R20013	RLKS	FL-net: Link status of reference node ▲
R20006	PNALST	FL-net: List of participating nodes ▲	R20014	RMFT	FL-net: Allowable minimum frame interval time of reference node ▲
R20007	RNAD-SP	FL-net: Reference node address on display ▲	R20015	RCT-NOW	FL-net: Present value of refresh cycle measurement time ▲

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20016	RVCYR	FL-net: API return value of cyclic transmission read ▲	R20024		NC warning display: Alarm 3D accumulation counter ▲
R20017	RVCYW	FL-net: API return value of cyclic transmission write ▲	R20025		
R20018			R20026		
R20019			R20027		
R20020			R20028		
R20021			R20029		
R20022			R20030		
R20023			R20031		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20032		NC warning display: Alarm 3D frequency counter ▲	R20040		NC warning display: "Z48 Power supply voltage error warning at acceleration/deceleration" state ▲
R20033			R20041		
R20034			R20042		
R20035			R20043	SVIDDD	Diagnosis data output: Servomotor insulation degradation detection in progress (PLC axis)
R20036			R20044		
R20037			R20045		
R20038			R20046		
R20039			R20047		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20048	SPIDDD	Diagnosis data output: Spindle motor insulation degradation detection in progress	R20056		
R20049			R20057		
R20050			R20058		PLC window: number of continuous writes detected
R20051			R20059		PLC window: continuous write window No.
R20052			R20060		
R20053			R20061		
R20054			R20062		Laser: Laser output feedback value (W)
R20055			R20063		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R20064	R20080	R20096	R20112		Motor load current PLC axis (1st axis) (L) ▲
R20065	R20081	R20097	R20113		Motor load current PLC axis (1st axis) (H) ▲
R20066	R20082	R20098	R20114		Motor load current PLC axis (2nd axis) (L) ▲
R20067	R20083	R20099	R20115		Motor load current PLC axis (2nd axis) (H) ▲
R20068	R20084	R20100	R20116		Motor load current PLC axis (3rd axis) (L) ▲
R20069	R20085	R20101	R20117		Motor load current PLC axis (3rd axis) (H) ▲
R20070	R20086	R20102	R20118		Motor load current PLC axis (4th axis) (L) ▲
R20071	R20087	R20103	R20119		Motor load current PLC axis (4th axis) (H) ▲
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R20072	R20088	R20104	R20120		Motor load current PLC axis (5th axis) (L) ▲
R20073	R20089	R20105	R20121		Motor load current PLC axis (5th axis) (H) ▲
R20074	R20090	R20106	R20122		Motor load current PLC axis (6th axis) (L) ▲
R20075	R20091	R20107	R20123		Motor load current PLC axis (6th axis) (H) ▲
R20076	R20092	R20108	R20124		Motor load current PLC axis (7th axis) (L) ▲
R20077	R20093	R20109	R20125		Motor load current PLC axis (7th axis) (H) ▲
R20078	R20094	R20110	R20126		Motor load current PLC axis (8th axis) (L) ▲
R20079	R20095	R20111	R20127		Motor load current PLC axis (8th axis) (H) ▲

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20080	PSWSY Sn	Arbitrary-assigned PSW for each part system 1 to 16 ▲			
R20081	PSWSY Sn	Arbitrary-assigned PSW for each part system 17 to 32 ▲			
R20082	PSWSY Sn	Arbitrary-assigned PSW for each part system 33 to 48 ▲			
R20083	PSWSY Sn	Arbitrary-assigned PSW for each part system 49 to 64 ▲			
R20084					
R20085					
R20086					
R20087					

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R^{***})

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R20500	R20700	R20900	R21100	R21300	R21500	R21700	R21900		Current spatial error compensation value (orthogonal coordinate horizontal axis)
R20501	R20701	R20901	R21101	R21301	R21501	R21701	R21901		
R20502	R20702	R20902	R21102	R21302	R21502	R21702	R21902		Current spatial error compensation value (orthogonal coordinate vertical axis)
R20503	R20703	R20903	R21103	R21303	R21503	R21703	R21903		
R20504	R20704	R20904	R21104	R21304	R21504	R21704	R21904		Current spatial error compensation value (orthogonal coordinate height axis)
R20505	R20705	R20905	R21105	R21305	R21505	R21705	R21905		
R20506	R20706	R20906	R21106	R21306	R21506	R21706	R21906		Current spatial error compensation value (1st rotary axis)
R20507	R20707	R20907	R21107	R21307	R21507	R21707	R21907		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R20508	R20708	R20908	R21108	R21308	R21508	R21708	R21908		Current spatial error compensation value (2nd rotary axis)
R20509	R20709	R20909	R21109	R21309	R21509	R21709	R21909		
R20510	R20710	R20910	R21110	R21310	R21510	R21710	R21910		
R20511	R20711	R20911	R21111	R21311	R21511	R21711	R21911		
R20512	R20712	R20912	R21112	R21312	R21512	R21712	R21912		
R20513	R20713	R20913	R21113	R21313	R21513	R21713	R21913		
R20514	R20714	R20914	R21114	R21314	R21514	R21714	R21914		
R20515	R20715	R20915	R21115	R21315	R21515	R21715	R21915		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R20516	R20716	R20916	R21116	R21316	R21516	R21716	R21916		Appropriate machining diagnosis error axis ▲
R20517	R20717	R20917	R21117	R21317	R21517	R21717	R21917	TRTNCNT	Tool retract and return 2: Number of transit points stored ▲
R20518	R20718	R20918	R21118	R21318	R21518	R21718	R21918		
R20519	R20719	R20919	R21119	R21319	R21519	R21719	R21919		NC warning display: "Z48 Power supply voltage error warning at acceleration/deceleration" state ▲
R20520	R20720	R20920	R21120	R21320	R21520	R21720	R21920		
R20521	R20721	R20921	R21121	R21321	R21521	R21721	R21921		
R20522	R20722	R20922	R21122	R21322	R21522	R21722	R21922	SVIDDD	Diagnosis data output: Servomotor insulation degradation detection in progress
R20523	R20723	R20923	R21123	R21323	R21523	R21723	R21923		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R20524	R20724	R20924	R21124	R21324	R21524	R21724	R21924		
R20525	R20725	R20925	R21125	R21325	R21525	R21725	R21925		
R20526	R20726	R20926	R21126	R21326	R21526	R21726	R21926		
R20527	R20727	R20927	R21127	R21327	R21527	R21727	R21927		
R20528	R20728	R20928	R21128	R21328	R21528	R21728	R21928		
R20529	R20729	R20929	R21129	R21329	R21529	R21729	R21929		
R20530	R20730	R20930	R21130	R21330	R21530	R21730	R21930		
R20531	R20731	R20931	R21131	R21331	R21531	R21731	R21931		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R20532	R20732	R20932	R21132	R21332	R21532	R21732	R21932		
R20533	R20733	R20933	R21133	R21333	R21533	R21733	R21933		
R20534	R20734	R20934	R21134	R21334	R21534	R21734	R21934		
R20535	R20735	R20935	R21135	R21335	R21535	R21735	R21935		
R20536	R20736	R20936	R21136	R21336	R21536	R21736	R21936	L system T code data	
R20537	R20737	R20937	R21137	R21337	R21537	R21737	R21937		
R20538	R20738	R20938	R21138	R21338	R21538	R21738	R21938		
R20539	R20739	R20939	R21139	R21339	R21539	R21739	R21939		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R20540	R20740	R20940	R21140	R21340	R21540	R21740	R21940		
R20541	R20741	R20941	R21141	R21341	R21541	R21741	R21941		
R20542	R20742	R20942	R21142	R21342	R21542	R21742	R21942		
R20543	R20743	R20943	R21143	R21343	R21543	R21743	R21943		
R20544	R20744	R20944	R21144	R21344	R21544	R21744	R21944		
R20545	R20745	R20945	R21145	R21345	R21545	R21745	R21945		
R20546	R20746	R20946	R21146	R21346	R21546	R21746	R21946		
R20547	R20747	R20947	R21147	R21347	R21547	R21747	R21947		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R20556	R20756	R20956	R21156	R21356	R21556	R21756	R21956	VCC_VIB	VCC: Number of vibrations
R20557	R20757	R20957	R21157	R21357	R21557	R21757	R21957	VCC_FRQ	VCC: Frequency
R20558	R20758	R20958	R21158	R21358	R21558	R21758	R21958	VC-C_VIBAX	VCC: Vibrating axis
R20559	R20759	R20959	R21159	R21359	R21559	R21759	R21959	VCC-FACT	VCC: Cause of non-vibration
R20560	R20760	R20960	R21160	R21360	R21560	R21760	R21960		
R20561	R20761	R20961	R21161	R21361	R21561	R21761	R21961		
R20562	R20762	R20962	R21162	R21362	R21562	R21762	R21962		
R20563	R20763	R20963	R21163	R21363	R21563	R21763	R21963		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R20564	R20764	R20964	R21164	R21364	R21564	R21764	R21964		CLC: Maximum load
R20565	R20765	R20965	R21165	R21365	R21565	R21765	R21965		CLC: Minimum load
R20566	R20766	R20966	R21166	R21366	R21566	R21766	R21966		
R20567	R20767	R20967	R21167	R21367	R21567	R21767	R21967		
R20568	R20768	R20968	R21168	R21368	R21568	R21768	R21968		
R20569	R20769	R20969	R21169	R21369	R21569	R21769	R21969		
R20570	R20770	R20970	R21170	R21370	R21570	R21770	R21970		
R20571	R20771	R20971	R21171	R21371	R21571	R21771	R21971		

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R^{***})

Device No.				Abbrev.	Signal name
\$1	\$2	\$3	\$4		
R24500	R24532	R24564	R24596		NC warning display: Alarm 3D accumulation counter 1st axis ▲
R24501	R24533	R24565	R24597		NC warning display: Alarm 3D accumulation counter 2nd axis ▲
R24502	R24534	R24566	R24598		NC warning display: Alarm 3D accumulation counter 3rd axis ▲
R24503	R24535	R24567	R24599		NC warning display: Alarm 3D accumulation counter 4th axis ▲
R24504	R24536	R24568	R24600		NC warning display: Alarm 3D accumulation counter 5th axis ▲
R24505	R24537	R24569	R24601		NC warning display: Alarm 3D accumulation counter 6th axis ▲
R24506	R24538	R24570	R24602		NC warning display: Alarm 3D accumulation counter 7th axis ▲
R24507	R24539	R24571	R24603		NC warning display: Alarm 3D accumulation counter 8th axis ▲

Device No.				Abbrev.	Signal name
\$1	\$2	\$3	\$4		
R24508	R24540	R24572	R24604		NC warning display: Alarm 3D frequency counter 1st axis ▲
R24509	R24541	R24573	R24605		NC warning display: Alarm 3D frequency counter 2nd axis ▲
R24510	R24542	R24574	R24606		NC warning display: Alarm 3D frequency counter 3rd axis ▲
R24511	R24543	R24575	R24607		NC warning display: Alarm 3D frequency counter 4th axis ▲
R24512	R24544	R24576	R24608		NC warning display: Alarm 3D frequency counter 5th axis ▲
R24513	R24545	R24577	R24609		NC warning display: Alarm 3D frequency counter 6th axis ▲
R24514	R24546	R24578	R24610		NC warning display: Alarm 3D frequency counter 7th axis ▲
R24515	R24547	R24579	R24611		NC warning display: Alarm 3D frequency counter 8th axis ▲

Device No.				Abbrev.	Signal name
\$1	\$2	\$3	\$4		
R24756	R24788	R24820	R24852	CRSAXO1	Mixed control (cross axis control): Swapped axis (1st axis) ▲
R24757	R24789	R24821	R24853	CRSAXO2	Mixed control (cross axis control): Swapped axis (2nd axis) ▲
R24758	R24790	R24822	R24854	CRSAXO3	Mixed control (cross axis control): Swapped axis (3rd axis) ▲
R24759	R24791	R24823	R24855	CRSAXO4	Mixed control (cross axis control): Swapped axis (4th axis) ▲
R24760	R24792	R24824	R24856	CRSAXO5	Mixed control (cross axis control): Swapped axis (5th axis) ▲
R24761	R24793	R24825	R24857	CRSAXO6	Mixed control (cross axis control): Swapped axis (6th axis) ▲
R24762	R24794	R24826	R24858	CRSAXO7	Mixed control (cross axis control): Swapped axis (7th axis) ▲
R24763	R24795	R24827	R24859	CRSAXO8	Mixed control (cross axis control): Swapped axis (8th axis) ▲

2 Input/Output Signals with Controller

2.2 PLC Input Signals (Data Type: R***)

Device No.				Abbrev.	Signal name
\$1	\$2	\$3	\$4		
R24884	R24916	R24948	R24980		Total distance traveled by 1st axis during automatic operation [M]
R24885	R24917	R24949	R24981		
R24886	R24918	R24950	R24982		
R24887	R24919	R24951	R24983		
R24888	R24920	R24952	R24984		Total distance traveled by 2nd axis during automatic operation [M]
R24889	R24921	R24953	R24985		
R24890	R24922	R24954	R24986		
R24891	R24923	R24955	R24987		
R24892	R24924	R24956	R24988		Total distance traveled by 3rd axis during automatic operation [M]
R24893	R24925	R24957	R24989		
R24894	R24926	R24958	R24990		
R24895	R24927	R24959	R24991		
R24896	R24928	R24960	R24992		Total distance traveled by 4th axis during automatic operation [M]
R24897	R24929	R24961	R24993		
R24898	R24930	R24962	R24994		
R24899	R24931	R24963	R24995		
R24900	R24932	R24964	R24996		Total distance traveled by 5th axis during automatic operation [M]
R24901	R24933	R24965	R24997		
R24902	R24934	R24966	R24998		
R24903	R24935	R24967	R24999		
R24904	R24936	R24968	R25000		Total distance traveled by 6th axis during automatic operation [M]
R24905	R24937	R24969	R25001		
R24906	R24938	R24970	R25002		
R24907	R24939	R24971	R25003		
R24908	R24940	R24972	R25004		Total distance traveled by 7th axis during automatic operation [M]
R24909	R24941	R24973	R25005		
R24910	R24942	R24974	R25006		
R24911	R24943	R24975	R25007		
R24912	R24944	R24976	R25008		Total distance traveled by 8th axis during automatic operation [M]
R24913	R24945	R24977	R25009		
R24914	R24946	R24978	R25010		
R24915	R24947	R24979	R25011		

2.3 PLC Output Signals (Bit Type: Y***)

Note

(1) Signals with "▲" are prepared for a specific machine tool builder.

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
Y700	IPCC1	Power consumption computation: Clear consumption accumulation 1	Y708	*KEY1	Data protect key 1
Y701	IPCC2	Power consumption computation: Clear consumption accumulation 2	Y709	*KEY2	Data protect key 2
Y702	IPCC3	Power consumption computation: Clear consumption accumulation 3	Y70A	*KEY3	Data protect key 3
Y703	IPCC4	Power consumption computation: Clear consumption accumulation 4	Y70B		
Y704	RHD1	Integration time input 1	Y70C	PDISP	Program display during operation ▲
Y705	RHD2	Integration time input 2	Y70D		Handle pulse encoder communication connector priority
Y706	MD-BUSRST1	Modbus Time-out 1 cancel ▲	Y70E		
Y707	MD-BUSRST2	Modbus Time-out 2 cancel ▲	Y70F		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
Y710			Y718	*PCD1	PLC axis near point detection 1st axis
Y711		Optimum acceleration/deceleration parameter switch request [spindle] ▲	Y719	*PCD2	PLC axis near point detection 2nd axis
Y712			Y71A	*PCD3	PLC axis near point detection 3rd axis
Y713			Y71B	*PCD4	PLC axis near point detection 4th axis
Y714			Y71C	*PCD5	PLC axis near point detection 5th axis
Y715			Y71D	*PCD6	PLC axis near point detection 6th axis
Y716			Y71E	*PCD7	PLC axis near point detection 7th axis
Y717			Y71F	*PCD8	PLC axis near point detection 8th axis
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
Y720	HS1P	PLC axis 1st handle valid	Y728	CRTFN	CRT changeover completion
Y721	HS2P	PLC axis 2nd handle valid	Y729	SCRON	Screen display request
Y722	HS3P	PLC axis 3rd handle valid	Y72A		
Y723		PLC axis control buffering mode valid	Y72B		Collecting diagnosis data stop
Y724	IPCE1	Power consumption computation: Enable consumption accumulation 1	Y72C	SMPTRG	Sampling start/stop
Y725	IPCE2	Power consumption computation: Enable consumption accumulation 2	Y72D		
Y726	IPCE3	Power consumption computation: Enable consumption accumulation 3	Y72E		Pallet program registration In APC execution
Y727	IPCE4	Power consumption computation: Enable consumption accumulation 4	Y72F		Pallet program registration Ext. workpiece coordinate transfer ready
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
Y730	DISP1	Display changeover \$1	Y738		
Y731	DISP2	Display changeover \$2	Y739		
Y732	DISP3	Display changeover \$3	Y73A	MSBK	Single block between part systems
Y733	DISP4	Display changeover \$4	Y73B		
Y734	DISP5	Display changeover \$5	Y73C	MORR	Manual arbitrary reverse run mode
Y735	DISP6	Display changeover \$6	Y73D	MORSP	Manual arbitrary reverse run speed selection
Y736	DISP7	Display changeover \$7	Y73E	SMLK	High-speed simple program check mode
Y737	DISP8	Display changeover \$8	Y73F	CCHK	Interference check between part systems: Interference check enabled

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
Y740		Tool IC new read ▲	Y748		PLC skip 1
Y741		Tool IC exchange read ▲	Y749		PLC skip 2
Y742	MCT	Contactor shutoff test	Y74A		PLC skip 3
Y743			Y74B		PLC skip 4
Y744			Y74C		PLC skip 5
Y745			Y74D		PLC skip 6
Y746			Y74E		PLC skip 7
Y747		Turret interference check valid	Y74F		PLC skip 8
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
Y750			Y758		
Y751			Y759		
Y752			Y75A		
Y753			Y75B		
Y754			Y75C		
Y755			Y75D		Automatic power OFF request
Y756			Y75E		
Y757			Y75F		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
Y760			Y768		Door open I
Y761	MRCMD	Actual cutting mode (thread, tap) in manual arbitrary reverse run	Y769	ITF3VLD T	Interference check III: Enable interfering object selection data
Y762			Y76A	ITF3CMD	Interference check III: Interference check III mode
Y763			Y76B	SPSC	High-speed simple program check: Enable coordinate position check
Y764		Encoder 1 arbitrary pulse selection	Y76C		Remote program input start ▲
Y765		Encoder 2 arbitrary pulse selection	Y76D		Tool ID data read ▲
Y766		Encoder 1 arbitrary pulse valid	Y76E		Tool ID data write ▲
Y767		Encoder 2 arbitrary pulse valid	Y76F		Tool ID data erase ▲
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
Y770		PLC axis control valid 1st axis	Y778	GBON	G/B spindle synchronization valid
Y771		PLC axis control valid 2nd axis	Y779		
Y772		PLC axis control valid 3rd axis	Y77A	GBPHS	G/B spindle synchronization: Phase alignment
Y773		PLC axis control valid 4th axis	Y77B	GBPHM	G/B spindle synchronization: Phase memory
Y774		PLC axis control valid 5th axis	Y77C	GBC-MON	G/B spindle synchronization: Position error compensation
Y775		PLC axis control valid 6th axis	Y77D	GBOFF	G/B spindle synchronization: Temporary cancel
Y776		PLC axis control valid 7th axis	Y77E	GBCMKP	G/B spindle synchronization: Keep position error compensation amount signal
Y777		PLC axis control valid 8th axis	Y77F		

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y780	Y788	Y790	Y798	DTCH1	Control axis detachment 1st axis
Y781	Y789	Y791	Y799	DTCH2	Control axis detachment 2nd axis
Y782	Y78A	Y792	Y79A	DTCH3	Control axis detachment 3rd axis
Y783	Y78B	Y793	Y79B	DTCH4	Control axis detachment 4th axis
Y784	Y78C	Y794	Y79C	DTCH5	Control axis detachment 5th axis
Y785	Y78D	Y795	Y79D	DTCH6	Control axis detachment 6th axis
Y786	Y78E	Y796	Y79E	DTCH7	Control axis detachment 7th axis
Y787	Y78F	Y797	Y79F	DTCH8	Control axis detachment 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y7A0	Y7A8	Y7B0	Y7B8	*SVF1	Servo OFF 1st axis
Y7A1	Y7A9	Y7B1	Y7B9	*SVF2	Servo OFF 2nd axis
Y7A2	Y7AA	Y7B2	Y7BA	*SVF3	Servo OFF 3rd axis
Y7A3	Y7AB	Y7B3	Y7BB	*SVF4	Servo OFF 4th axis
Y7A4	Y7AC	Y7B4	Y7BC	*SVF5	Servo OFF 5th axis
Y7A5	Y7AD	Y7B5	Y7BD	*SVF6	Servo OFF 6th axis
Y7A6	Y7AE	Y7B6	Y7BE	*SVF7	Servo OFF 7th axis
Y7A7	Y7AF	Y7B7	Y7BF	*SVF8	Servo OFF 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y7C0	Y7C8	Y7D0	Y7D8	MI1	Mirror image 1st axis
Y7C1	Y7C9	Y7D1	Y7D9	MI2	Mirror image 2nd axis
Y7C2	Y7CA	Y7D2	Y7DA	MI3	Mirror image 3rd axis
Y7C3	Y7CB	Y7D3	Y7DB	MI4	Mirror image 4th axis
Y7C4	Y7CC	Y7D4	Y7DC	MI5	Mirror image 5th axis
Y7C5	Y7CD	Y7D5	Y7DD	MI6	Mirror image 6th axis
Y7C6	Y7CE	Y7D6	Y7DE	MI7	Mirror image 7th axis
Y7C7	Y7CF	Y7D7	Y7DF	MI8	Mirror image 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y7E0	Y7E8	Y7F0	Y7F8	*+EDT1	External deceleration+ 1st axis
Y7E1	Y7E9	Y7F1	Y7F9	*+EDT2	External deceleration+ 2nd axis
Y7E2	Y7EA	Y7F2	Y7FA	*+EDT3	External deceleration+ 3rd axis
Y7E3	Y7EB	Y7F3	Y7FB	*+EDT4	External deceleration+ 4th axis
Y7E4	Y7EC	Y7F4	Y7FC	*+EDT5	External deceleration+ 5th axis
Y7E5	Y7ED	Y7F5	Y7FD	*+EDT6	External deceleration+ 6th axis
Y7E6	Y7EE	Y7F6	Y7FE	*+EDT7	External deceleration+ 7th axis
Y7E7	Y7EF	Y7F7	Y7FF	*+EDT8	External deceleration+ 8th axis

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.
For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y800	Y808	Y810	Y818	*-EDT1	External deceleration- 1st axis
Y801	Y809	Y811	Y819	*-EDT2	External deceleration- 2nd axis
Y802	Y80A	Y812	Y81A	*-EDT3	External deceleration- 3rd axis
Y803	Y80B	Y813	Y81B	*-EDT4	External deceleration- 4th axis
Y804	Y80C	Y814	Y81C	*-EDT5	External deceleration- 5th axis
Y805	Y80D	Y815	Y81D	*-EDT6	External deceleration- 6th axis
Y806	Y80E	Y816	Y81E	*-EDT7	External deceleration- 7th axis
Y807	Y80F	Y817	Y81F	*-EDT8	External deceleration- 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y820	Y828	Y830	Y838	*+AIT1	Automatic interlock+ 1st axis
Y821	Y829	Y831	Y839	*+AIT2	Automatic interlock+ 2nd axis
Y822	Y82A	Y832	Y83A	*+AIT3	Automatic interlock+ 3rd axis
Y823	Y82B	Y833	Y83B	*+AIT4	Automatic interlock+ 4th axis
Y824	Y82C	Y834	Y83C	*+AIT5	Automatic interlock+ 5th axis
Y825	Y82D	Y835	Y83D	*+AIT6	Automatic interlock+ 6th axis
Y826	Y82E	Y836	Y83E	*+AIT7	Automatic interlock+ 7th axis
Y827	Y82F	Y837	Y83F	*+AIT8	Automatic interlock+ 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y840	Y848	Y850	Y858	*-AIT1	Automatic interlock- 1st axis
Y841	Y849	Y851	Y859	*-AIT2	Automatic interlock- 2nd axis
Y842	Y84A	Y852	Y85A	*-AIT3	Automatic interlock- 3rd axis
Y843	Y84B	Y853	Y85B	*-AIT4	Automatic interlock- 4th axis
Y844	Y84C	Y854	Y85C	*-AIT5	Automatic interlock- 5th axis
Y845	Y84D	Y855	Y85D	*-AIT6	Automatic interlock- 6th axis
Y846	Y84E	Y856	Y85E	*-AIT7	Automatic interlock- 7th axis
Y847	Y84F	Y857	Y85F	*-AIT8	Automatic interlock- 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y860	Y868	Y870	Y878	*+MIT1	Manual interlock+ 1st axis
Y861	Y869	Y871	Y879	*+MIT2	Manual interlock+ 2nd axis
Y862	Y86A	Y872	Y87A	*+MIT3	Manual interlock+ 3rd axis
Y863	Y86B	Y873	Y87B	*+MIT4	Manual interlock+ 4th axis
Y864	Y86C	Y874	Y87C	*+MIT5	Manual interlock+ 5th axis
Y865	Y86D	Y875	Y87D	*+MIT6	Manual interlock+ 6th axis
Y866	Y86E	Y876	Y87E	*+MIT7	Manual interlock+ 7th axis
Y867	Y86F	Y877	Y87F	*+MIT8	Manual interlock+ 8th axis

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.
For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y880	Y888	Y890	Y898	*-MIT1	Manual interlock- 1st axis
Y881	Y889	Y891	Y899	*-MIT2	Manual interlock- 2nd axis
Y882	Y88A	Y892	Y89A	*-MIT3	Manual interlock- 3rd axis
Y883	Y88B	Y893	Y89B	*-MIT4	Manual interlock- 4th axis
Y884	Y88C	Y894	Y89C	*-MIT5	Manual interlock- 5th axis
Y885	Y88D	Y895	Y89D	*-MIT6	Manual interlock- 6th axis
Y886	Y88E	Y896	Y89E	*-MIT7	Manual interlock- 7th axis
Y887	Y88F	Y897	Y89F	*-MIT8	Manual interlock- 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y8A0	Y8A8	Y8B0	Y8B8	AMLK1	Automatic machine lock 1st axis
Y8A1	Y8A9	Y8B1	Y8B9	AMLK2	Automatic machine lock 2nd axis
Y8A2	Y8AA	Y8B2	Y8BA	AMLK3	Automatic machine lock 3rd axis
Y8A3	Y8AB	Y8B3	Y8BB	AMLK4	Automatic machine lock 4th axis
Y8A4	Y8AC	Y8B4	Y8BC	AMLK5	Automatic machine lock 5th axis
Y8A5	Y8AD	Y8B5	Y8BD	AMLK6	Automatic machine lock 6th axis
Y8A6	Y8AE	Y8B6	Y8BE	AMLK7	Automatic machine lock 7th axis
Y8A7	Y8AF	Y8B7	Y8BF	AMLK8	Automatic machine lock 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y8C0	Y8C8	Y8D0	Y8D8	MMLK1	Manual machine lock 1st axis
Y8C1	Y8C9	Y8D1	Y8D9	MMLK2	Manual machine lock 2nd axis
Y8C2	Y8CA	Y8D2	Y8DA	MMLK3	Manual machine lock 3rd axis
Y8C3	Y8CB	Y8D3	Y8DB	MMLK4	Manual machine lock 4th axis
Y8C4	Y8CC	Y8D4	Y8DC	MMLK5	Manual machine lock 5th axis
Y8C5	Y8CD	Y8D5	Y8DD	MMLK6	Manual machine lock 6th axis
Y8C6	Y8CE	Y8D6	Y8DE	MMLK7	Manual machine lock 7th axis
Y8C7	Y8CF	Y8D7	Y8DF	MMLK8	Manual machine lock 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y8E0	Y8E8	Y8F0	Y8F8	+J1	Feed axis selection+ 1st axis
Y8E1	Y8E9	Y8F1	Y8F9	+J2	Feed axis selection+ 2nd axis
Y8E2	Y8EA	Y8F2	Y8FA	+J3	Feed axis selection+ 3rd axis
Y8E3	Y8EB	Y8F3	Y8FB	+J4	Feed axis selection+ 4th axis
Y8E4	Y8EC	Y8F4	Y8FC	+J5	Feed axis selection+ 5th axis
Y8E5	Y8ED	Y8F5	Y8FD	+J6	Feed axis selection+ 6th axis
Y8E6	Y8EE	Y8F6	Y8FE	+J7	Feed axis selection+ 7th axis
Y8E7	Y8EF	Y8F7	Y8FF	+J8	Feed axis selection+ 8th axis

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.
For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y900	Y908	Y910	Y918	-J1	Feed axis selection- 1st axis
Y901	Y909	Y911	Y919	-J2	Feed axis selection- 2nd axis
Y902	Y90A	Y912	Y91A	-J3	Feed axis selection- 3rd axis
Y903	Y90B	Y913	Y91B	-J4	Feed axis selection- 4th axis
Y904	Y90C	Y914	Y91C	-J5	Feed axis selection- 5th axis
Y905	Y90D	Y915	Y91D	-J6	Feed axis selection- 6th axis
Y906	Y90E	Y916	Y91E	-J7	Feed axis selection- 7th axis
Y907	Y90F	Y917	Y91F	-J8	Feed axis selection- 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y920	Y928	Y930	Y938	MAE1	Manual/Automatic simultaneous valid 1st axis
Y921	Y929	Y931	Y939	MAE2	Manual/Automatic simultaneous valid 2nd axis
Y922	Y92A	Y932	Y93A	MAE3	Manual/Automatic simultaneous valid 3rd axis
Y923	Y92B	Y933	Y93B	MAE4	Manual/Automatic simultaneous valid 4th axis
Y924	Y92C	Y934	Y93C	MAE5	Manual/Automatic simultaneous valid 5th axis
Y925	Y92D	Y935	Y93D	MAE6	Manual/Automatic simultaneous valid 6th axis
Y926	Y92E	Y936	Y93E	MAE7	Manual/Automatic simultaneous valid 7th axis
Y927	Y92F	Y937	Y93F	MAE8	Manual/Automatic simultaneous valid 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y940	Y948	Y950	Y958	FBE1	Manual feedrate B valid 1st axis
Y941	Y949	Y951	Y959	FBE2	Manual feedrate B valid 2nd axis
Y942	Y94A	Y952	Y95A	FBE3	Manual feedrate B valid 3rd axis
Y943	Y94B	Y953	Y95B	FBE4	Manual feedrate B valid 4th axis
Y944	Y94C	Y954	Y95C	FBE5	Manual feedrate B valid 5th axis
Y945	Y94D	Y955	Y95D	FBE6	Manual feedrate B valid 6th axis
Y946	Y94E	Y956	Y95E	FBE7	Manual feedrate B valid 7th axis
Y947	Y94F	Y957	Y95F	FBE8	Manual feedrate B valid 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y960	Y968	Y970	Y978	AZS1	Zero point initialization set mode 1st axis
Y961	Y969	Y971	Y979	AZS2	Zero point initialization set mode 2nd axis
Y962	Y96A	Y972	Y97A	AZS3	Zero point initialization set mode 3rd axis
Y963	Y96B	Y973	Y97B	AZS4	Zero point initialization set mode 4th axis
Y964	Y96C	Y974	Y97C	AZS5	Zero point initialization set mode 5th axis
Y965	Y96D	Y975	Y97D	AZS6	Zero point initialization set mode 6th axis
Y966	Y96E	Y976	Y97E	AZS7	Zero point initialization set mode 7th axis
Y967	Y96F	Y977	Y97F	AZS8	Zero point initialization set mode 8th axis

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.
For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y980	Y988	Y990	Y998	ZST1	Zero point initialization set start 1st axis
Y981	Y989	Y991	Y999	ZST2	Zero point initialization set start 2nd axis
Y982	Y98A	Y992	Y99A	ZST3	Zero point initialization set start 3rd axis
Y983	Y98B	Y993	Y99B	ZST4	Zero point initialization set start 4th axis
Y984	Y98C	Y994	Y99C	ZST5	Zero point initialization set start 5th axis
Y985	Y98D	Y995	Y99D	ZST6	Zero point initialization set start 6th axis
Y986	Y98E	Y996	Y99E	ZST7	Zero point initialization set start 7th axis
Y987	Y98F	Y997	Y99F	ZST8	Zero point initialization set start 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y9A0	Y9A8	Y9B0	Y9B8	ILC1	Current limit changeover 1st axis
Y9A1	Y9A9	Y9B1	Y9B9	ILC2	Current limit changeover 2nd axis
Y9A2	Y9AA	Y9B2	Y9BA	ILC3	Current limit changeover 3rd axis
Y9A3	Y9AB	Y9B3	Y9BB	ILC4	Current limit changeover 4th axis
Y9A4	Y9AC	Y9B4	Y9BC	ILC5	Current limit changeover 5th axis
Y9A5	Y9AD	Y9B5	Y9BD	ILC6	Current limit changeover 6th axis
Y9A6	Y9AE	Y9B6	Y9BE	ILC7	Current limit changeover 7th axis
Y9A7	Y9AF	Y9B7	Y9BF	ILC8	Current limit changeover 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y9C0	Y9C8	Y9D0	Y9D8	DOR1	Droop cancel request 1st axis
Y9C1	Y9C9	Y9D1	Y9D9	DOR2	Droop cancel request 2nd axis
Y9C2	Y9CA	Y9D2	Y9DA	DOR3	Droop cancel request 3rd axis
Y9C3	Y9CB	Y9D3	Y9DB	DOR4	Droop cancel request 4th axis
Y9C4	Y9CC	Y9D4	Y9DC	DOR5	Droop cancel request 5th axis
Y9C5	Y9CD	Y9D5	Y9DD	DOR6	Droop cancel request 6th axis
Y9C6	Y9CE	Y9D6	Y9DE	DOR7	Droop cancel request 7th axis
Y9C7	Y9CF	Y9D7	Y9DF	DOR8	Droop cancel request 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
Y9E0	Y9E8	Y9F0	Y9F8		Workpiece coordinate Measurement 1st axis (Spare)
Y9E1	Y9E9	Y9F1	Y9F9		Workpiece coordinate Measurement 2nd axis
Y9E2	Y9EA	Y9F2	Y9FA		Workpiece coordinate Measurement 3rd axis (Spare)
Y9E3	Y9EB	Y9F3	Y9FB		Workpiece coordinate Measurement 4th axis (Spare)
Y9E4	Y9EC	Y9F4	Y9FC		Workpiece coordinate Measurement 5th axis (Spare)
Y9E5	Y9ED	Y9F5	Y9FD		Workpiece coordinate Measurement 6th axis (Spare)
Y9E6	Y9EE	Y9F6	Y9FE		Workpiece coordinate Measurement 7th axis (Spare)
Y9E7	Y9EF	Y9F7	Y9FF		Workpiece coordinate Measurement 8th axis (Spare)

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.
For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YA00	YA08	YA10	YA18	DTCH21	Control axis detachment 2 1st axis
YA01	YA09	YA11	YA19	DTCH22	Control axis detachment 2 2nd axis
YA02	YA0A	YA12	YA1A	DTCH23	Control axis detachment 2 3rd axis
YA03	YA0B	YA13	YA1B	DTCH24	Control axis detachment 2 4th axis
YA04	YA0C	YA14	YA1C	DTCH25	Control axis detachment 2 5th axis
YA05	YA0D	YA15	YA1D	DTCH26	Control axis detachment 2 6th axis
YA06	YA0E	YA16	YA1E	DTCH27	Control axis detachment 2 7th axis
YA07	YA0F	YA17	YA1F	DTCH28	Control axis detachment 2 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YA20	YA28	YA30	YA38	UCLPF1	Unclamp completion 1st axis
YA21	YA29	YA31	YA39	UCLPF2	Unclamp completion 2nd axis
YA22	YA2A	YA32	YA3A	UCLPF3	Unclamp completion 3rd axis
YA23	YA2B	YA33	YA3B	UCLPF4	Unclamp completion 4th axis
YA24	YA2C	YA34	YA3C	UCLPF5	Unclamp completion 5th axis
YA25	YA2D	YA35	YA3D	UCLPF6	Unclamp completion 6th axis
YA26	YA2E	YA36	YA3E	UCLPF7	Unclamp completion 7th axis
YA27	YA2F	YA37	YA3F	UCLPF8	Unclamp completion 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YA40	YA48	YA50	YA58		Each axis reference position return 1st axis
YA41	YA49	YA51	YA59		Each axis reference position return 2nd axis
YA42	YA4A	YA52	YA5A		Each axis reference position return 3rd axis
YA43	YA4B	YA53	YA5B		Each axis reference position return 4th axis
YA44	YA4C	YA54	YA5C		Each axis reference position return 5th axis
YA45	YA4D	YA55	YA5D		Each axis reference position return 6th axis
YA46	YA4E	YA56	YA5E		Each axis reference position return 7th axis
YA47	YA4F	YA57	YA5F		Each axis reference position return 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YA60	YA68	YA70	YA78		Mixed control (cross axis control) request 1st axis
YA61	YA69	YA71	YA79		Mixed control (cross axis control) request 2nd axis
YA62	YA6A	YA72	YA7A		Mixed control (cross axis control) request 3rd axis
YA63	YA6B	YA73	YA7B		Mixed control (cross axis control) request 4th axis
YA64	YA6C	YA74	YA7C		Mixed control (cross axis control) request 5th axis
YA65	YA6D	YA75	YA7D		Mixed control (cross axis control) request 6th axis
YA66	YA6E	YA76	YA7E		Mixed control (cross axis control) request 7th axis
YA67	YA6F	YA77	YA7F		Mixed control (cross axis control) request 8th axis

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.
For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YA80	YA88	YA90	YA98	SYNC1	Synchronous control request 1st axis
YA81	YA89	YA91	YA99	SYNC2	Synchronous control request 2nd axis
YA82	YA8A	YA92	YA9A	SYNC3	Synchronous control request 3rd axis
YA83	YA8B	YA93	YA9B	SYNC4	Synchronous control request 4th axis
YA84	YA8C	YA94	YA9C	SYNC5	Synchronous control request 5th axis
YA85	YA8D	YA95	YA9D	SYNC6	Synchronous control request 6th axis
YA86	YA8E	YA96	YA9E	SYNC7	Synchronous control request 7th axis
YA87	YA8F	YA97	YA9F	SYNC8	Synchronous control request 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YAA0	YAA8	YAB0	YAB8	PILE1	Superimposition control request 1st axis
YAA1	YAA9	YAB1	YAB9	PILE2	Superimposition control request 2nd axis
YAA2	YAAA	YAB2	YABA	PILE3	Superimposition control request 3rd axis
YAA3	YAAB	YAB3	YABB	PILE4	Superimposition control request 4th axis
YAA4	YAAC	YAB4	YABC	PILE5	Superimposition control request 5th axis
YAA5	YAAD	YAB5	YABD	PILE6	Superimposition control request 6th axis
YAA6	YAAE	YAB6	YABE	PILE7	Superimposition control request 7th axis
YAA7	YAAF	YAB7	YABF	PILE8	Superimposition control request 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YAC0	YAC8	YAD0	YAD8		NC axis control selection 1st axis
YAC1	YAC9	YAD1	YAD9		NC axis control selection 2nd axis
YAC2	YACA	YAD2	YADA		NC axis control selection 3rd axis
YAC3	YACB	YAD3	YADB		NC axis control selection 4th axis
YAC4	YACC	YAD4	YADC		NC axis control selection 5th axis
YAC5	YACD	YAD5	YADD		NC axis control selection 6th axis
YAC6	YACE	YAD6	YADE		NC axis control selection 7th axis
YAC7	YACF	YAD7	YADF		NC axis control selection 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YAE0	YAE8	YAF0	YAF8		Vertical axis pull-up prevention request 1st axis
YAE1	YAE9	YAF1	YAF9		Vertical axis pull-up prevention request 2nd axis
YAE2	YAEA	YAF2	YAFA		Vertical axis pull-up prevention request 3rd axis
YAE3	YAEB	YAF3	YAFB		Vertical axis pull-up prevention request 4th axis
YAE4	YAEC	YAF4	YAFD		Vertical axis pull-up prevention request 5th axis
YAE5	YAED	YAF5	YAFD		Vertical axis pull-up prevention request 6th axis
YAE6	YAEF	YAF6	YAFE		Vertical axis pull-up prevention request 7th axis
YAE7	YAEF	YAF7	YAFF		Vertical axis pull-up prevention request 8th axis

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.

For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YB00	YB08	YB10	YB18	CLPF1	Clamp completion 1st axis
YB01	YB09	YB11	YB19	CLPF2	Clamp completion 2nd axis
YB02	YB0A	YB12	YB1A	CLPF3	Clamp completion 3rd axis
YB03	YB0B	YB13	YB1B	CLPF4	Clamp completion 4th axis
YB04	YB0C	YB14	YB1C	CLPF5	Clamp completion 5th axis
YB05	YB0D	YB15	YB1D	CLPF6	Clamp completion 6th axis
YB06	YB0E	YB16	YB1E	CLPF7	Clamp completion 7th axis
YB07	YB0F	YB17	YB1F	CLPF8	Clamp completion 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YB20	YB28	YB30	YB38	HOBRTV1	Hob machining: Retract amount selection 1st axis
YB21	YB29	YB31	YB39	HOBRTV2	Hob machining: Retract amount selection 2nd axis
YB22	YB2A	YB32	YB3A	HOBRTV3	Hob machining: Retract amount selection 3rd axis
YB23	YB2B	YB33	YB3B	HOBRTV4	Hob machining: Retract amount selection 4th axis
YB24	YB2C	YB34	YB3C	HOBRTV5	Hob machining: Retract amount selection 5th axis
YB25	YB2D	YB35	YB3D	HOBRTV6	Hob machining: Retract amount selection 6th axis
YB26	YB2E	YB36	YB3E	HOBRTV7	Hob machining: Retract amount selection 7th axis
YB27	YB2F	YB37	YB3F	HOBRTV8	Hob machining: Retract amount selection 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YB40	YB48	YB50	YB58	ROTSPC1	Spindle-mode rotary axis control command 1st axis
YB41	YB49	YB51	YB59	ROTSPC2	Spindle-mode rotary axis control command 2nd axis
YB42	YB4A	YB52	YB5A	ROTSPC3	Spindle-mode rotary axis control command 3rd axis
YB43	YB4B	YB53	YB5B	ROTSPC4	Spindle-mode rotary axis control command 4th axis
YB44	YB4C	YB54	YB5C	ROTSPC5	Spindle-mode rotary axis control command 5th axis
YB45	YB4D	YB55	YB5D	ROTSPC6	Spindle-mode rotary axis control command 6th axis
YB46	YB4E	YB56	YB5E	ROTSPC7	Spindle-mode rotary axis control command 7th axis
YB47	YB4F	YB57	YB5F	ROTSPC8	Spindle-mode rotary axis control command 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YB60	YB68	YB70	YB78	SLMC1	Stored stroke limit I:Change request 1st axis
YB61	YB69	YB71	YB79	SLMC2	Stored stroke limit I:Change request 2nd axis
YB62	YB6A	YB72	YB7A	SLMC3	Stored stroke limit I:Change request 3rd axis
YB63	YB6B	YB73	YB7B	SLMC4	Stored stroke limit I:Change request 4th axis
YB64	YB6C	YB74	YB7C	SLMC5	Stored stroke limit I:Change request 5th axis
YB65	YB6D	YB75	YB7D	SLMC6	Stored stroke limit I:Change request 6th axis
YB66	YB6E	YB76	YB7E	SLMC7	Stored stroke limit I:Change request 7th axis
YB67	YB6F	YB77	YB7F	SLMC8	Stored stroke limit I:Change request 8th axis

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.

For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YB80	YB88	YB90	YB98	VGHLC1	Real-time tuning 1: Speed control gain changeover hold-down command 1st axis
YB81	YB89	YB91	YB99	VGHLC2	Real-time tuning 1: Speed control gain changeover hold-down command 2nd axis
YB82	YB8A	YB92	YB9A	VGHLC3	Real-time tuning 1: Speed control gain changeover hold-down command 3rd axis
YB83	YB8B	YB93	YB9B	VGHLC4	Real-time tuning 1: Speed control gain changeover hold-down command 4th axis
YB84	YB8C	YB94	YB9C	VGHLC5	Real-time tuning 1: Speed control gain changeover hold-down command 5th axis
YB85	YB8D	YB95	YB9D	VGHLC6	Real-time tuning 1: Speed control gain changeover hold-down command 6th axis
YB86	YB8E	YB96	YB9E	VGHLC7	Real-time tuning 1: Speed control gain changeover hold-down command 7th axis
YB87	YB8F	YB97	YB9F	VGHLC8	Real-time tuning 1: Speed control gain changeover hold-down command 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YBA0	YBA8	YBB0	YBB8		
YBA1	YBA9	YBB1	YBB9		
YBA2	YBAA	YBB2	YBBA		
YBA3	YBAB	YBB3	YBBB		
YBA4	YBAC	YBB4	YBBC		
YBA5	YBAD	YBB5	YBBD		
YBA6	YBAE	YBB6	YBBE		
YBA7	YBAF	YBB7	YBBF		
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YBC0	YBC8	YBD0	YBD8	NPCH-GREQ1	NC axis/PLC axis switchover request 1st axis
YBC1	YBC9	YBD1	YBD9	NPCH-GREQ2	NC axis/PLC axis switchover request 2nd axis
YBC2	YBCA	YBD2	YBDA	NPCH-GREQ3	NC axis/PLC axis switchover request 3rd axis
YBC3	YBCB	YBD3	YBDB	NPCH-GREQ4	NC axis/PLC axis switchover request 4th axis
YBC4	YBCC	YBD4	YBDC	NPCH-GREQ5	NC axis/PLC axis switchover request 5th axis
YBC5	YBCD	YBD5	YBDD	NPCH-GREQ6	NC axis/PLC axis switchover request 6th axis
YBC6	YBCE	YBD6	YBDE	NPCH-GREQ7	NC axis/PLC axis switchover request 7th axis
YBC7	YBCF	YBD7	YBDF	NPCH-GREQ8	NC axis/PLC axis switchover request 8th axis
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YBE0	YBE8	YBF0	YBF8	GQEMG1	Machine group-based alarm stop: Machine group-based PLC interlock 1st axis
YBE1	YBE9	YBF1	YBF9	GQEMG2	Machine group-based alarm stop: Machine group-based PLC interlock 2nd axis
YBE2	YBEA	YBF2	YBFA	GQEMG3	Machine group-based alarm stop: Machine group-based PLC interlock 3rd axis
YBE3	YBEB	YBF3	YBFB	GQEMG4	Machine group-based alarm stop: Machine group-based PLC interlock 4th axis
YBE4	YBEC	YBF4	YBFC	GQEMG5	Machine group-based alarm stop: Machine group-based PLC interlock 5th axis
YBE5	YBED	YBF5	YBFD	GQEMG6	Machine group-based alarm stop: Machine group-based PLC interlock 6th axis
YBE6	YBEE	YBF6	YBFE	GQEMG7	Machine group-based alarm stop: Machine group-based PLC interlock 7th axis
YBE7	YBEF	YBF7	YBFF	GQEMG8	Machine group-based alarm stop: Machine group-based PLC interlock 8th axis

Note

- (1) The CNC control and CNC status signals are arbitrarily assigned to the device and axis numbers by the parameter "#1603 PLCdev_no" for each axis.

For details of setting, refer to the "PLC I/F axis random device assignment" in the "PLC Programming Manual".

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YC00	YD40	YE80	YFC0	Y1100	Y1240	Y1380	Y14C0	J	Jog mode
YC01	YD41	YE81	YFC1	Y1101	Y1241	Y1381	Y14C1	H	Handle mode
YC02	YD42	YE82	YFC2	Y1102	Y1242	Y1382	Y14C2	S	Incremental mode
YC03	YD43	YE83	YFC3	Y1103	Y1243	Y1383	Y14C3	PTP	Manual arbitrary feed mode
YC04	YD44	YE84	YFC4	Y1104	Y1244	Y1384	Y14C4	ZRN	Reference position return mode
YC05	YD45	YE85	YFC5	Y1105	Y1245	Y1385	Y14C5	AST	Automatic initialization mode
YC06	YD46	YE86	YFC6	Y1106	Y1246	Y1386	Y14C6		
YC07	YD47	YE87	YFC7	Y1107	Y1247	Y1387	Y14C7		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YC08	YD48	YE88	YFC8	Y1108	Y1248	Y1388	Y14C8	MEM	Memory mode
YC09	YD49	YE89	YFC9	Y1109	Y1249	Y1389	Y14C9	T	Tape mode
YC0A	YD4A	YE8A	YFCA	Y110A	Y124A	Y138A	Y14CA		Online operation mode (Computer link B)
YC0B	YD4B	YE8B	YFCB	Y110B	Y124B	Y138B	Y14CB	D	MDI mode
YC0C	YD4C	YE8C	YFCC	Y110C	Y124C	Y138C	Y14CC		
YC0D	YD4D	YE8D	YFCD	Y110D	Y124D	Y138D	Y14CD		
YC0E	YD4E	YE8E	YFCE	Y110E	Y124E	Y138E	Y14CE	SBSM	Sub part system control: Sub part system control I mode
YC0F	YD4F	YE8F	YFCF	Y110F	Y124F	Y138F	Y14CF		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YC10	YD50	YE90	YFD0	Y1110	Y1250	Y1390	Y14D0	ST	Automatic operation "start" command (Cycle start)
YC11	YD51	YE91	YFD1	Y1111	Y1251	Y1391	Y14D1	*SP	Automatic operation "pause" command (Feed hold)
YC12	YD52	YE92	YFD2	Y1112	Y1252	Y1392	Y14D2	SBK	Single block
YC13	YD53	YE93	YFD3	Y1113	Y1253	Y1393	Y14D3	*BSL	Block start interlock
YC14	YD54	YE94	YFD4	Y1114	Y1254	Y1394	Y14D4	*CSL	Cutting block start interlock
YC15	YD55	YE95	YFD5	Y1115	Y1255	Y1395	Y14D5	DRN	Dry run
YC16	YD56	YE96	YFD6	Y1116	Y1256	Y1396	Y14D6		
YC17	YD57	YE97	YFD7	Y1117	Y1257	Y1397	Y14D7	ERD	Error detection
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YC18	YD58	YE98	YFD8	Y1118	Y1258	Y1398	Y14D8	NRST1	NC reset 1
YC19	YD59	YE99	YFD9	Y1119	Y1259	Y1399	Y14D9	NRST2	NC reset 2
YC1A	YD5A	YE9A	YFDA	Y111A	Y125A	Y139A	Y14DA	RRW	Reset & rewind
YC1B	YD5B	YE9B	YFDB	Y111B	Y125B	Y139B	Y14DB	*CDZ	Chamfering
YC1C	YD5C	YE9C	YFDC	Y111C	Y125C	Y139C	Y14DC	ARST	Automatic restart
YC1D	YD5D	YE9D	YFDD	Y111D	Y125D	Y139D	Y14DD		External search strobe
YC1E	YD5E	YE9E	YFDE	Y111E	Y125E	Y139E	Y14DE	FIN1	M function finish 1
YC1F	YD5F	YE9F	YFDF	Y111F	Y125F	Y139F	Y14DF	FIN2	M function finish 2

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.										
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name	
YC20	YD60	YEA0	YFE0	Y1120	Y1260	Y13A0	Y14E0	TLM	Tool length measurement 1	
YC21	YD61	YEA1	YFE1	Y1121	Y1261	Y13A1	Y14E1	TLMS	Tool length measurement 2	
YC22	YD62	YEA2	YFE2	Y1122	Y1262	Y13A2	Y14E2		Synchronization correction mode	
YC23	YD63	YEA3	YFE3	Y1123	Y1263	Y13A3	Y14E3	PRST	Program restart	
YC24	YD64	YEA4	YFE4	Y1124	Y1264	Y13A4	Y14E4			
YC25	YD65	YEA5	YFE5	Y1125	Y1265	Y13A5	Y14E5	UIT	Macro interrupt	
YC26	YD66	YEA6	YFE6	Y1126	Y1266	Y13A6	Y14E6	RT	Rapid traverse	
YC27	YD67	YEA7	YFE7	Y1127	Y1267	Y13A7	Y14E7	VRV	Reverse run	
Device No.										
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name	
YC28	YD68	YEA8	YFE8	Y1128	Y1268	Y13A8	Y14E8	ABS	Manual absolute	
YC29	YD69	YEA9	YFE9	Y1129	Y1269	Y13A9	Y14E9	DLK	Display lock	
YC2A	YD6A	YEA	YFEA	Y112A	Y126A	Y13AA	Y14EA	F1D	F1-digit speed change valid	
YC2B	YD6B	YEA	YFEB	Y112B	Y126B	Y13AB	Y14EB	CRQ	Recalculation request	
Common (\$)	Abbrev.	Signal name						Common (\$)	Abbrev.	Signal name
YC2C	QEMG	PLC emergency stop								
Device No.										
YC2D	YD6D	YEAD	YFED	Y112D	Y126D	Y13AD	Y14ED	RTN	Reference position retract	
YC2E	YD6E	YEA	YFEE	Y112E	Y126E	Y13AE	Y14EE	PIT	PLC interrupt	
YC2F	YD6F	YEA	YFEF	Y112F	Y126F	Y13AF	Y14EF			
Device No.										
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name	
YC30	YD70	YEB0	YFF0	Y1130	Y1270	Y13B0	Y14F0	CHPS	Chopping	
YC31	YD71	YEB1	YFF1	Y1131	Y1271	Y13B1	Y14F1	RSST	Search & start	
YC32	YD72	YEB2	YFF2	Y1132	Y1272	Y13B2	Y14F2			
YC33	YD73	YEB3	YFF3	Y1133	Y1273	Y13B3	Y14F3			
YC34	YD74	YEB4	YFF4	Y1134	Y1274	Y13B4	Y14F4		Chopping parameter valid	
YC35	YD75	YEB5	YFF5	Y1135	Y1275	Y13B5	Y14F5		Inclined axis control valid	
YC36	YD76	YEB6	YFF6	Y1136	Y1276	Y13B6	Y14F6		Inclined axis control: No Z axis compensation	
YC37	YD77	YEB7	YFF7	Y1137	Y1277	Y13B7	Y14F7	BDT1	Optional block skip 1	
Device No.										
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name	
YC38	YD78	YEB8	YFF8	Y1138	Y1278	Y13B8	Y14F8	BDT2	Optional block skip 2	
YC39	YD79	YEB9	YFF9	Y1139	Y1279	Y13B9	Y14F9	BDT3	Optional block skip 3	
YC3A	YD7A	YEB	YFFA	Y113A	Y127A	Y13BA	Y14FA	BDT4	Optional block skip 4	
YC3B	YD7B	YEB	YFFB	Y113B	Y127B	Y13BB	Y14FB	BDT5	Optional block skip 5	
YC3C	YD7C	YEB	YFFC	Y113C	Y127C	Y13BC	Y14FC	BDT6	Optional block skip 6	
YC3D	YD7D	YEB	YFFD	Y113D	Y127D	Y13BD	Y14FD	BDT7	Optional block skip 7	
YC3E	YD7E	YEB	YFFE	Y113E	Y127E	Y13BE	Y14FE	BDT8	Optional block skip 8	
YC3F	YD7F	YEB	YFFF	Y113F	Y127F	Y13BF	Y14FF	BDT9	Optional block skip 9	

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YC40	YD80	YEC0	Y1000	Y1140	Y1280	Y13C0	Y1500	HS11	1st handle axis selection code 1
YC41	YD81	YEC1	Y1001	Y1141	Y1281	Y13C1	Y1501	HS12	1st handle axis selection code 2
YC42	YD82	YEC2	Y1002	Y1142	Y1282	Y13C2	Y1502	HS14	1st handle axis selection code 4
YC43	YD83	YEC3	Y1003	Y1143	Y1283	Y13C3	Y1503	HS18	1st handle axis selection code 8
YC44	YD84	YEC4	Y1004	Y1144	Y1284	Y13C4	Y1504	HS116	1st handle axis selection code 16
YC45	YD85	YEC5	Y1005	Y1145	Y1285	Y13C5	Y1505		
YC46	YD86	YEC6	Y1006	Y1146	Y1286	Y13C6	Y1506		
YC47	YD87	YEC7	Y1007	Y1147	Y1287	Y13C7	Y1507	HS1S	1st handle valid
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YC48	YD88	YEC8	Y1008	Y1148	Y1288	Y13C8	Y1508	HS21	2nd handle axis selection code 1
YC49	YD89	YEC9	Y1009	Y1149	Y1289	Y13C9	Y1509	HS22	2nd handle axis selection code 2
YC4A	YD8A	YEC A	Y100A	Y114A	Y128A	Y13CA	Y150A	HS24	2nd handle axis selection code 4
YC4B	YD8B	YECB	Y100B	Y114B	Y128B	Y13CB	Y150B	HS28	2nd handle axis selection code 8
YC4C	YD8C	YECC	Y100C	Y114C	Y128C	Y13CC	Y150C	HS216	2nd handle axis selection code 16
YC4D	YD8D	YECD	Y100D	Y114D	Y128D	Y13CD	Y150D		
YC4E	YD8E	YECE	Y100E	Y114E	Y128E	Y13CE	Y150E		
YC4F	YD8F	YECF	Y100F	Y114F	Y128F	Y13CF	Y150F	HS2S	2nd handle valid
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YC50	YD90	YED0	Y1010	Y1150	Y1290	Y13D0	Y1510	HS31	3rd handle axis selection code 1
YC51	YD91	YED1	Y1011	Y1151	Y1291	Y13D1	Y1511	HS32	3rd handle axis selection code 2
YC52	YD92	YED2	Y1012	Y1152	Y1292	Y13D2	Y1512	HS34	3rd handle axis selection code 4
YC53	YD93	YED3	Y1013	Y1153	Y1293	Y13D3	Y1513	HS38	3rd handle axis selection code 8
YC54	YD94	YED4	Y1014	Y1154	Y1294	Y13D4	Y1514	HS316	3rd handle axis selection code 16
YC55	YD95	YED5	Y1015	Y1155	Y1295	Y13D5	Y1515		
YC56	YD96	YED6	Y1016	Y1156	Y1296	Y13D6	Y1516		
YC57	YD97	YED7	Y1017	Y1157	Y1297	Y13D7	Y1517	HS3S	3rd handle valid
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YC58	YD98	YED8	Y1018	Y1158	Y1298	Y13D8	Y1518	OVC	Override cancel
YC59	YD99	YED9	Y1019	Y1159	Y1299	Y13D9	Y1519	OVSL	Manual override method selection
YC5A	YD9A	YEDA	Y101A	Y115A	Y129A	Y13DA	Y151A	AFL	Miscellaneous function lock
YC5B	YD9B	YEDB	Y101B	Y115B	Y129B	Y13DB	Y151B		
YC5C	YD9C	YEDC	Y101C	Y115C	Y129C	Y13DC	Y151C	TRV	Tap retract
YC5D	YD9D	YEDD	Y101D	Y115D	Y129D	Y13DD	Y151D		
YC5E	YD9E	YEDE	Y101E	Y115E	Y129E	Y13DE	Y151E		Tool handle feed mode
YC5F	YD9F	YEDF	Y101F	Y115F	Y129F	Y13DF	Y151F		

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YC60	YDA0	YEE0	Y1020	Y1160	Y12A0	Y13E0	Y1520	*FV1	Cutting feedrate override code 1
YC61	YDA1	YEE1	Y1021	Y1161	Y12A1	Y13E1	Y1521	*FV2	Cutting feedrate override code 2
YC62	YDA2	YEE2	Y1022	Y1162	Y12A2	Y13E2	Y1522	*FV4	Cutting feedrate override code 4
YC63	YDA3	YEE3	Y1023	Y1163	Y12A3	Y13E3	Y1523	*FV8	Cutting feedrate override code 8
YC64	YDA4	YEE4	Y1024	Y1164	Y12A4	Y13E4	Y1524	*FV16	Cutting feedrate override code 16
YC65	YDA5	YEE5	Y1025	Y1165	Y12A5	Y13E5	Y1525		
YC66	YDA6	YEE6	Y1026	Y1166	Y12A6	Y13E6	Y1526	FV2E	2nd cutting feedrate override valid
YC67	YDA7	YEE7	Y1027	Y1167	Y12A7	Y13E7	Y1527	FVS	Cutting feedrate override method selection
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YC68	YDA8	YEE8	Y1028	Y1168	Y12A8	Y13E8	Y1528	ROV1	Rapid traverse override code 1
YC69	YDA9	YEE9	Y1029	Y1169	Y12A9	Y13E9	Y1529	ROV2	Rapid traverse override code 2
YC6A	YDAA	YEEA	Y102A	Y116A	Y12AA	Y13EA	Y152A		
YC6B	YDAB	YEEB	Y102B	Y116B	Y12AB	Y13EB	Y152B		
YC6C	YDAC	YEEC	Y102C	Y116C	Y12AC	Y13EC	Y152C		
YC6D	YDAD	YEE D	Y102D	Y116D	Y12AD	Y13ED	Y152D		
YC6E	YDAE	YEEE	Y102E	Y116E	Y12AE	Y13EE	Y152E		
YC6F	YDAF	YEEF	Y102F	Y116F	Y12AF	Y13EF	Y152F	ROVS	Rapid traverse override method selection
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YC70	YDB0	YEF0	Y1030	Y1170	Y12B0	Y13F0	Y1530	*JV1	Manual feedrate code 1
YC71	YDB1	YEF1	Y1031	Y1171	Y12B1	Y13F1	Y1531	*JV2	Manual feedrate code 2
YC72	YDB2	YEF2	Y1032	Y1172	Y12B2	Y13F2	Y1532	*JV4	Manual feedrate code 4
YC73	YDB3	YEF3	Y1033	Y1173	Y12B3	Y13F3	Y1533	*JV8	Manual feedrate code 8
YC74	YDB4	YEF4	Y1034	Y1174	Y12B4	Y13F4	Y1534	*JV16	Manual feedrate code 16
YC75	YDB5	YEF5	Y1035	Y1175	Y12B5	Y13F5	Y1535		
YC76	YDB6	YEF6	Y1036	Y1176	Y12B6	Y13F6	Y1536	MCLMP	Manual speed clamp ON
YC77	YDB7	YEF7	Y1037	Y1177	Y12B7	Y13F7	Y1537	JVS	Manual feedrate method selection
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YC78	YDB8	YEF8	Y1038	Y1178	Y12B8	Y13F8	Y1538	PCF1	Feedrate least increment code 1
YC79	YDB9	YEF9	Y1039	Y1179	Y12B9	Y13F9	Y1539	PCF2	Feedrate least increment code 2
YC7A	YDBA	YEF A	Y103A	Y117A	Y12BA	Y13FA	Y153A		
YC7B	YDBB	YEF B	Y103B	Y117B	Y12BB	Y13FB	Y153B	JHAN	Jog handle synchronous
YC7C	YDBC	YEF C	Y103C	Y117C	Y12BC	Y13FC	Y153C		Each axis manual feedrate B valid
YC7D	YDBD	YEF D	Y103D	Y117D	Y12BD	Y13FD	Y153D		Manual feedrate B surface speed control valid
YC7E	YDBE	YEF E	Y103E	Y117E	Y12BE	Y13FE	Y153E		Circular feed in manual mode valid
YC7F	YDBF	YEF F	Y103F	Y117F	Y12BF	Y13FF	Y153F		Coordinate rotation by parameter: Coordinate switch for manual feed

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YC80	YDC0	YF00	Y1040	Y1180	Y12C0	Y1400	Y1540	MP1	Handle/incremental feed magnification code 1
YC81	YDC1	YF01	Y1041	Y1181	Y12C1	Y1401	Y1541	MP2	Handle/incremental feed magnification code 2
YC82	YDC2	YF02	Y1042	Y1182	Y12C2	Y1402	Y1542	MP4	Handle/incremental feed magnification code 4
YC83	YDC3	YF03	Y1043	Y1183	Y12C3	Y1403	Y1543		
YC84	YDC4	YF04	Y1044	Y1184	Y12C4	Y1404	Y1544		
YC85	YDC5	YF05	Y1045	Y1185	Y12C5	Y1405	Y1545	CXS9	Manual arbitrary feed: Feedrate selection ▲
YC86	YDC6	YF06	Y1046	Y1186	Y12C6	Y1406	Y1546		Magnification valid for each handle
YC87	YDC7	YF07	Y1047	Y1187	Y12C7	Y1407	Y1547	MPS	Handle/incremental feed magnification method selection
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YC88	YDC8	YF08	Y1048	Y1188	Y12C8	Y1408	Y1548	TAL1	Tool alarm 1/Tool-skip
YC89	YDC9	YF09	Y1049	Y1189	Y12C9	Y1409	Y1549	TAL2	Tool alarm 2
YC8A	YDCA	YF0A	Y104A	Y118A	Y12CA	Y140A	Y154A	TCEF	Usage data count valid
YC8B	YDCB	YF0B	Y104B	Y118B	Y12CB	Y140B	Y154B	TLF1	Tool life management input
YC8C	YDCC	YF0C	Y104C	Y118C	Y12CC	Y140C	Y154C	TRST	Tool change reset
YC8D	YDCD	YF0D	Y104D	Y118D	Y12CD	Y140D	Y154D		Tool escape and return Transit point designation
YC8E	YDCE	YF0E	Y104E	Y118E	Y12CE	Y140E	Y154E		Manual tool length measurement interlock temporarily canceled ▲
YC8F	YDCF	YF0F	Y104F	Y118F	Y12CF	Y140F	Y154F		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YC90	YDD0	YF10	Y1050	Y1190	Y12D0	Y1410	Y1550	ZSL1	Reference position selection code 1
YC91	YDD1	YF11	Y1051	Y1191	Y12D1	Y1411	Y1551	ZSL2	Reference position selection code 2
YC92	YDD2	YF12	Y1052	Y1192	Y12D2	Y1412	Y1552		Tool length compensation along the tool axis Compensation amount change mode
YC93	YDD3	YF13	Y1053	Y1193	Y12D3	Y1413	Y1553	RTNST	Tool retract and return 2: Tool return start ▲
YC94	YDD4	YF14	Y1054	Y1194	Y12D4	Y1414	Y1554	FFC	Thread cutting: Feed-forward control request
YC95	YDD5	YF15	Y1055	Y1195	Y12D5	Y1415	Y1555		In balance cut timing synchronization invalid ▲
YC96	YDD6	YF16	Y1056	Y1196	Y12D6	Y1416	Y1556		
YC97	YDD7	YF17	Y1057	Y1197	Y12D7	Y1417	Y1557		Reference position selection method
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YC98	YDD8	YF18	Y1058	Y1198	Y12D8	Y1418	Y1558		Tool life management: Temporary cancel of tool life expiration
YC99	YDD9	YF19	Y1059	Y1199	Y12D9	Y1419	Y1559		Tool life management: Temporary cancel of tool group life expiration
YC9A	YDDA	YF1A	Y105A	Y119A	Y12DA	Y141A	Y155A	PRTN	External search: Program return
YC9B	Yddb	YF1B	Y105B	Y119B	Y12DB	Y141B	Y155B		MES interface library: User arbitrary information send request
YC9C	YDDC	YF1C	Y105C	Y119C	Y12DC	Y141C	Y155C	TFFC	Thread cutting: Feed-forward cancel ▲
YC9D	YDDD	YF1D	Y105D	Y119D	Y12DD	Y141D	Y155D		Manual speed command valid
YC9E	YDDE	YF1E	Y105E	Y119E	Y12DE	Y141E	Y155E		Manual speed command sign reversed
YC9F	YDDF	YF1F	Y105F	Y119F	Y12DF	Y141F	Y155F		Manual speed command reverse run valid

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YCA0	YDE0	YF20	Y1060	Y11A0	Y12E0	Y1420	Y1560	CX11	Manual arbitrary feed 1st axis selection code 1
YCA1	YDE1	YF21	Y1061	Y11A1	Y12E1	Y1421	Y1561	CX12	Manual arbitrary feed 1st axis selection code 2
YCA2	YDE2	YF22	Y1062	Y11A2	Y12E2	Y1422	Y1562	CX14	Manual arbitrary feed 1st axis selection code 4
YCA3	YDE3	YF23	Y1063	Y11A3	Y12E3	Y1423	Y1563	CX18	Manual arbitrary feed 1st axis selection code 8
YCA4	YDE4	YF24	Y1064	Y11A4	Y12E4	Y1424	Y1564	CX116	Manual arbitrary feed 1st axis selection code 16
YCA5	YDE5	YF25	Y1065	Y11A5	Y12E5	Y1425	Y1565		
YCA6	YDE6	YF26	Y1066	Y11A6	Y12E6	Y1426	Y1566		
YCA7	YDE7	YF27	Y1067	Y11A7	Y12E7	Y1427	Y1567	CX1S	Manual arbitrary feed 1st axis valid
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YCA8	YDE8	YF28	Y1068	Y11A8	Y12E8	Y1428	Y1568	CX21	Manual arbitrary feed 2nd axis selection code 1
YCA9	YDE9	YF29	Y1069	Y11A9	Y12E9	Y1429	Y1569	CX22	Manual arbitrary feed 2nd axis selection code 2
YCAA	YDEA	YF2A	Y106A	Y11AA	Y12EA	Y142A	Y156A	CX24	Manual arbitrary feed 2nd axis selection code 4
YCAB	YDEB	YF2B	Y106B	Y11AB	Y12EB	Y142B	Y156B	CX28	Manual arbitrary feed 2nd axis selection code 8
YCAC	YDEC	YF2C	Y106C	Y11AC	Y12EC	Y142C	Y156C	CX216	Manual arbitrary feed 2nd axis selection code 16
YCAD	YDED	YF2D	Y106D	Y11AD	Y12ED	Y142D	Y156D		
YCAE	YDEE	YF2E	Y106E	Y11AE	Y12EE	Y142E	Y156E		
YCAF	YDEF	YF2F	Y106F	Y11AF	Y12EF	Y142F	Y156F	CX2S	Manual arbitrary feed 2nd axis valid
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YCB0	YDF0	YF30	Y1070	Y11B0	Y12F0	Y1430	Y1570	CX31	Manual arbitrary feed 3rd axis selection code 1
YCB1	YDF1	YF31	Y1071	Y11B1	Y12F1	Y1431	Y1571	CX32	Manual arbitrary feed 3rd axis selection code 2
YCB2	YDF2	YF32	Y1072	Y11B2	Y12F2	Y1432	Y1572	CX34	Manual arbitrary feed 3rd axis selection code 4
YCB3	YDF3	YF33	Y1073	Y11B3	Y12F3	Y1433	Y1573	CX38	Manual arbitrary feed 3rd axis selection code 8
YCB4	YDF4	YF34	Y1074	Y11B4	Y12F4	Y1434	Y1574	CX316	Manual arbitrary feed 3rd axis selection code 16
YCB5	YDF5	YF35	Y1075	Y11B5	Y12F5	Y1435	Y1575		
YCB6	YDF6	YF36	Y1076	Y11B6	Y12F6	Y1436	Y1576		
YCB7	YDF7	YF37	Y1077	Y11B7	Y12F7	Y1437	Y1577	CX3S	Manual arbitrary feed 3rd axis valid
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YCB8	YDF8	YF38	Y1078	Y11B8	Y12F8	Y1438	Y1578	CXS1	Manual arbitrary feed Smoothing off
YCB9	YDF9	YF39	Y1079	Y11B9	Y12F9	Y1439	Y1579	CXS2	Manual arbitrary feed Axis independent
YCBA	YDFA	YF3A	Y107A	Y11BA	Y12FA	Y143A	Y157A	CXS3	Manual arbitrary feed EX.F/MODAL.F
YCBB	YDFB	YF3B	Y107B	Y11BB	Y12FB	Y143B	Y157B	CXS4	Manual arbitrary feed G0/G1
YCBC	YDFC	YF3C	Y107C	Y11BC	Y12FC	Y143C	Y157C	CXS5	Manual arbitrary feed MC/WK
YCBD	YDFD	YF3D	Y107D	Y11BD	Y12FD	Y143D	Y157D	CXS6	Manual arbitrary feed ABS/INC
YCBE	YDFE	YF3E	Y107E	Y11BE	Y12FE	Y143E	Y157E	*CXS7	Manual arbitrary feed Stop
YCBF	YDFF	YF3F	Y107F	Y11BF	Y12FF	Y143F	Y157F	CXS8	Manual arbitrary feed Strobe

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YCC0	YE00	YF40	Y1080	Y11C0	Y1300	Y1440	Y1580	ILM1	Current limit mode 1
YCC1	YE01	YF41	Y1081	Y11C1	Y1301	Y1441	Y1581	ILM2	Current limit mode 2
YCC2	YE02	YF42	Y1082	Y11C2	Y1302	Y1442	Y1582		
YCC3	YE03	YF43	Y1083	Y11C3	Y1303	Y1443	Y1583	LDWT	Load monitor I: Teaching/Monitor execution ▲
YCC4	YE04	YF44	Y1084	Y11C4	Y1304	Y1444	Y1584		Load monitor I: Teaching mode ▲
YCC5	YE05	YF45	Y1085	Y11C5	Y1305	Y1445	Y1585		Load monitor I: Monitor mode ▲
YCC6	YE06	YF46	Y1086	Y11C6	Y1306	Y1446	Y1586		Load monitor I: Alarm reset ▲
YCC7	YE07	YF47	Y1087	Y11C7	Y1307	Y1447	Y1587		Load monitor I: Warning reset ▲
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YCC8	YE08	YF48	Y1088	Y11C8	Y1308	Y1448	Y1588	*ZRIT	2nd reference position return interlock
YCC9	YE09	YF49	Y1089	Y11C9	Y1309	Y1449	Y1589		Load monitor I: Adaptive control execution ▲
YCCA	YE0A	YF4A	Y108A	Y11CA	Y130A	Y144A	Y158A		Small diameter deep hole drilling cycle
YCCB	YE0B	YF4B	Y108B	Y11CB	Y130B	Y144B	Y158B		Chuck barrier ON
YCCC	YE0C	YF4C	Y108C	Y11CC	Y130C	Y144C	Y158C		High-speed retract function valid ▲
YCCD	YE0D	YF4D	Y108D	Y11CD	Y130D	Y144D	Y158D		
YCCE	YE0E	YF4E	Y108E	Y11CE	Y130E	Y144E	Y158E		
YCCF	YE0F	YF4F	Y108F	Y11CF	Y130F	Y144F	Y158F		Tool retract start ▲
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YCD0	YE10	YF50	Y1090	Y11D0	Y1310	Y1450	Y1590		Waiting ignore
YCD1	YE11	YF51	Y1091	Y11D1	Y1311	Y1451	Y1591		Spindle-spindle polygon cancel
YCD2	YE12	YF52	Y1092	Y11D2	Y1312	Y1452	Y1592		Synchronous tapping command polarity reversal
YCD3	YE13	YF53	Y1093	Y11D3	Y1313	Y1453	Y1593		Spindle OFF mode
YCD4	YE14	YF54	Y1094	Y11D4	Y1314	Y1454	Y1594		Longitudinal hole drilling axis selection
YCD5	YE15	YF55	Y1095	Y11D5	Y1315	Y1455	Y1595		Optimum acceleration/deceleration parameter switching request [axis] ▲
YCD6	YE16	YF56	Y1096	Y11D6	Y1316	Y1456	Y1596	TRVEC	Tap retract possible state cancel
YCD7	YE17	YF57	Y1097	Y11D7	Y1317	Y1457	Y1597	CHPRCR	Chopping compensation update prevention request
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YCD8	YE18	YF58	Y1098	Y11D8	Y1318	Y1458	Y1598		Barrier valid (left)
YCD9	YE19	YF59	Y1099	Y11D9	Y1319	Y1459	Y1599		Barrier valid (right)
YCDA	YE1A	YF5A	Y109A	Y11DA	Y131A	Y145A	Y159A		Tool pre-setter sub-side valid ▲
YCDB	YE1B	YF5B	Y109B	Y11DB	Y131B	Y145B	Y159B		
YCDC	YE1C	YF5C	Y109C	Y11DC	Y131C	Y145C	Y159C		
YCDD	YE1D	YF5D	Y109D	Y11DD	Y131D	Y145D	Y159D		
YCDE	YE1E	YF5E	Y109E	Y11DE	Y131E	Y145E	Y159E	HOBTR	Hob machining: Retract request
YCDE	YE1F	YF5F	Y109F	Y11DF	Y131F	Y145F	Y159F	HOBARTC	Hob machining: Alarm retract control

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YCE0	YE20	YF60	Y10A0	Y11E0	Y1320	Y1460	Y15A0		T command in tool life management prohibited ▲
YCE1	YE21	YF61	Y10A1	Y11E1	Y1321	Y1461	Y15A1		Door open II
YCE2	YE22	YF62	Y10A2	Y11E2	Y1322	Y1462	Y15A2		Door open signal input (spindle speed monitor)
YCE3	YE23	YF63	Y10A3	Y11E3	Y1323	Y1463	Y15A3		Door interlock spindle speed clamp
YCE4	YE24	YF64	Y10A4	Y11E4	Y1324	Y1464	Y15A4		
YCE5	YE25	YF65	Y10A5	Y11E5	Y1325	Y1465	Y15A5		
YCE6	YE26	YF66	Y10A6	Y11E6	Y1326	Y1466	Y15A6		
YCE7	YE27	YF67	Y10A7	Y11E7	Y1327	Y1467	Y15A7		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YCE8	YE28	YF68	Y10A8	Y11E8	Y1328	Y1468	Y15A8		Door open II (2 channels per 1 part system)
YCE9	YE29	YF69	Y10A9	Y11E9	Y1329	Y1469	Y15A9		
YCEA	YE2A	YF6A	Y10AA	Y11EA	Y132A	Y146A	Y15AA		
YCEB	YE2B	YF6B	Y10AB	Y11EB	Y132B	Y146B	Y15AB		
YCEC	YE2C	YF6C	Y10AC	Y11EC	Y132C	Y146C	Y15AC		
YCED	YE2D	YF6D	Y10AD	Y11ED	Y132D	Y146D	Y15AD		
YCEE	YE2E	YF6E	Y10AE	Y11EE	Y132E	Y146E	Y15AE		
YCEF	YE2F	YF6F	Y10AF	Y11EF	Y132F	Y146F	Y15AF		Load monitor I: Cutting torque estimation execution ▲
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YCF0	YE30	YF70	Y10B0	Y11F0	Y1330	Y1470	Y15B0		
YCF1	YE31	YF71	Y10B1	Y11F1	Y1331	Y1471	Y15B1	VFTCI	Variable feed thread cutting invalid ▲
YCF2	YE32	YF72	Y10B2	Y11F2	Y1332	Y1472	Y15B2		
YCF3	YE33	YF73	Y10B3	Y11F3	Y1333	Y1473	Y15B3		
YCF4	YE34	YF74	Y10B4	Y11F4	Y1334	Y1474	Y15B4	BCHK	Barrier check invalid
YCF5	YE35	YF75	Y10B5	Y11F5	Y1335	Y1475	Y15B5		
YCF6	YE36	YF76	Y10B6	Y11F6	Y1336	Y1476	Y15B6		
YCF7	YE37	YF77	Y10B7	Y11F7	Y1337	Y1477	Y15B7		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YCF8	YE38	YF78	Y10B8	Y11F8	Y1338	Y1478	Y15B8	MSYNC	Synchronization between part systems OFF
YCF9	YE39	YF79	Y10B9	Y11F9	Y1339	Y1479	Y15B9		
YCFA	YE3A	YF7A	Y10BA	Y11FA	Y133A	Y147A	Y15BA	DRNC	Dry run invalid
YCFB	YE3B	YF7B	Y10BB	Y11FB	Y133B	Y147B	Y15BB	AUTED	Automatic error detection
YCFC	YE3C	YF7C	Y10BC	Y11FC	Y133C	Y147C	Y15BC	MRPSG	Manual arbitrary reverse run: MSTB reverse run prohibited
YCFD	YE3D	YF7D	Y10BD	Y11FD	Y133D	Y147D	Y15BD		G71 Shape judgement disable ▲
YCFE	YE3E	YF7E	Y10BE	Y11FE	Y133E	Y147E	Y15BE		Appropriate machining diagnosis in progress ▲
YCFE	YE3E	YF7E	Y10BE	Y11FE	Y133E	Y147E	Y15BE		Appropriate machining diagnosis in progress ▲
YCFE	YE3E	YF7E	Y10BE	Y11FE	Y133E	Y147E	Y15BE		Appropriate machining diagnosis error reset ▲

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YD00	YE40	YF80	Y10C0	Y1200	Y1340	Y1480	Y15C0	PFCHR	Program format switch request
YD01	YE41	YF81	Y10C1	Y1201	Y1341	Y1481	Y15C1	RBSSY	Manual arbitrary reverse run: Reverse run block stop designated part system
YD02	YE42	YF82	Y10C2	Y1202	Y1342	Y1482	Y15C2		
YD03	YE43	YF83	Y10C3	Y1203	Y1343	Y1483	Y15C3		
YD04	YE44	YF84	Y10C4	Y1204	Y1344	Y1484	Y15C4		
YD05	YE45	YF85	Y10C5	Y1205	Y1345	Y1485	Y15C5		
YD06	YE46	YF86	Y10C6	Y1206	Y1346	Y1486	Y15C6		
YD07	YE47	YF87	Y10C7	Y1207	Y1347	Y1487	Y15C7		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YD08	YE48	YF88	Y10C8	Y1208	Y1348	Y1488	Y15C8	RVSP	Reverse run from block start
YD09	YE49	YF89	Y10C9	Y1209	Y1349	Y1489	Y15C9	RVIT	Macro interrupt priority
YD0A	YE4A	YF8A	Y10CA	Y120A	Y134A	Y148A	Y15CA	RVMD	Reverse run control mode
YD0B	YE4B	YF8B	Y10CB	Y120B	Y134B	Y148B	Y15CB	ACCG	Rapid traverse time constant: Switchover request
YD0C	YE4C	YF8C	Y10CC	Y120C	Y134C	Y148C	Y15CC	RT2CHGA	Real-time tuning 2: Acceleration/deceleration time constant in automatic switchover
YD0D	YE4D	YF8D	Y10CD	Y120D	Y134D	Y148D	Y15CD	RT2CHGM	Real-time tuning 2: Acceleration/deceleration time constant in manual switchover
YD0E	YE4E	YF8E	Y10CE	Y120E	Y134E	Y148E	Y15CE	RT2RST	Real-time tuning 2: Acceleration/deceleration time constant reset
YD0F	YE4F	YF8F	Y10CF	Y120F	Y134F	Y148F	Y15CF	TWIN	Request for reflecting reserved tool wear compensation
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YD10	YE50	YF90	Y10D0	Y1210	Y1350	Y1490	Y15D0		
YD11	YE51	YF91	Y10D1	Y1211	Y1351	Y1491	Y15D1		
YD12	YE52	YF92	Y10D2	Y1212	Y1352	Y1492	Y15D2		
YD13	YE53	YF93	Y10D3	Y1213	Y1353	Y1493	Y15D3		
YD14	YE54	YF94	Y10D4	Y1214	Y1354	Y1494	Y15D4		3D coordinate conversion: Manual feed coordinates conversion
YD15	YE55	YF95	Y10D5	Y1215	Y1355	Y1495	Y15D5	RCEE	Rotation center error compensation enabled
YD16	YE56	YF96	Y10D6	Y1216	Y1356	Y1496	Y15D6		
YD17	YE57	YF97	Y10D7	Y1217	Y1357	Y1497	Y15D7	SECE	Spatial error compensation enabled
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YD18	YE58	YF98	Y10D8	Y1218	Y1358	Y1498	Y15D8	MJCT	3D manual feed (JOG, INC): Tool axis coordinate system selection
YD19	YE59	YF99	Y10D9	Y1219	Y1359	Y1499	Y15D9	MJCB	3D manual feed (JOG, INC): Table coordinate system selection
YD1A	YE5A	YF9A	Y10DA	Y121A	Y135A	Y149A	Y15DA	MJCF	3D manual feed (JOG, INC): Feature coordinate system selection
YD1B	YE5B	YF9B	Y10DB	Y121B	Y135B	Y149B	Y15DB	MH1CT	3D manual feed (1st handle): Tool axis coordinate system selection
YD1C	YE5C	YF9C	Y10DC	Y121C	Y135C	Y149C	Y15DC	MH1CB	3D manual feed (1st handle): Table coordinate system selection
YD1D	YE5D	YF9D	Y10DD	Y121D	Y135D	Y149D	Y15DD	MH1CF	3D manual feed (1st handle): Feature coordinate system selection
YD1E	YE5E	YF9E	Y10DE	Y121E	Y135E	Y149E	Y15DE	MH2CT	3D manual feed (2nd handle): Tool axis coordinate system selection
YD1F	YE5F	YF9F	Y10DF	Y121F	Y135F	Y149F	Y15DF	MH2CB	3D manual feed (2nd handle): Table coordinate system selection

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YD20	YE60	YFA0	Y10E0	Y1220	Y1360	Y14A0	Y15E0	MH2CF	3D manual feed (2nd handle): Feature coordinate system selection
YD21	YE61	YFA1	Y10E1	Y1221	Y1361	Y14A1	Y15E1	MH3CT	3D manual feed (3rd handle): Tool axis coordinate system selection
YD22	YE62	YFA2	Y10E2	Y1222	Y1362	Y14A2	Y15E2	MH3CB	3D manual feed (3rd handle): Table coordinate system selection
YD23	YE63	YFA3	Y10E3	Y1223	Y1363	Y14A3	Y15E3	MH3CF	3D manual feed (3rd handle): Feature coordinate system selection
YD24	YE64	YFA4	Y10E4	Y1224	Y1364	Y14A4	Y15E4		
YD25	YE65	YFA5	Y10E5	Y1225	Y1365	Y14A5	Y15E5		
YD26	YE66	YFA6	Y10E6	Y1226	Y1366	Y14A6	Y15E6		
YD27	YE67	YFA7	Y10E7	Y1227	Y1367	Y14A7	Y15E7	TCPRC	Tool center point rotation
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YD28	YE68	YFA8	Y10E8	Y1228	Y1368	Y14A8	Y15E8	MFIN1	Miscellaneous function command high-speed output: M function finish 1
YD29	YE69	YFA9	Y10E9	Y1229	Y1369	Y14A9	Y15E9	MFIN2	Miscellaneous function command high-speed output: M function finish 2
YD2A	YE6A	YFAA	Y10EA	Y122A	Y136A	Y14AA	Y15EA	MFIN3	Miscellaneous function command high-speed output: M function finish 3
YD2B	YE6B	YFAB	Y10EB	Y122B	Y136B	Y14AB	Y15EB	MFIN4	Miscellaneous function command high-speed output: M function finish 4
YD2C	YE6C	YFAC	Y10EC	Y122C	Y136C	Y14AC	Y15EC	SFIN1	Miscellaneous function command high-speed output: S function finish 1
YD2D	YE6D	YFAD	Y10ED	Y122D	Y136D	Y14AD	Y15ED	SFIN2	Miscellaneous function command high-speed output: S function finish 2
YD2E	YE6E	YFAE	Y10EE	Y122E	Y136E	Y14AE	Y15EE	SFIN3	Miscellaneous function command high-speed output: S function finish 3
YD2F	YE6F	YFAF	Y10EF	Y122F	Y136F	Y14AF	Y15EF	SFIN4	Miscellaneous function command high-speed output: S function finish 4
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YD30	YE70	YFB0	Y10F0	Y1230	Y1370	Y14B0	Y15F0	TFIN1	Miscellaneous function command high-speed output: T function finish 1
YD31	YE71	YFB1	Y10F1	Y1231	Y1371	Y14B1	Y15F1	TFIN2	Miscellaneous function command high-speed output: T function finish 2
YD32	YE72	YFB2	Y10F2	Y1232	Y1372	Y14B2	Y15F2	TFIN3	Miscellaneous function command high-speed output: T function finish 3
YD33	YE73	YFB3	Y10F3	Y1233	Y1373	Y14B3	Y15F3	TFIN4	Miscellaneous function command high-speed output: T function finish 4
YD34	YE74	YFB4	Y10F4	Y1234	Y1374	Y14B4	Y15F4	BFIN1	Miscellaneous function command high-speed output: 2nd M function finish 1
YD35	YE75	YFB5	Y10F5	Y1235	Y1375	Y14B5	Y15F5	BFIN2	Miscellaneous function command high-speed output: 2nd M function finish 2
YD36	YE76	YFB6	Y10F6	Y1236	Y1376	Y14B6	Y15F6	BFIN3	Miscellaneous function command high-speed output: 2nd M function finish 3
YD37	YE77	YFB7	Y10F7	Y1237	Y1377	Y14B7	Y15F7	BFIN4	Miscellaneous function command high-speed output: 2nd M function finish 4

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
YD38	YE78	YFB8	Y10F8	Y1238	Y1378	Y14B8	Y15F8	SFIN5	Miscellaneous function command high-speed output: S function finish 5
YD39	YE79	YFB9	Y10F9	Y1239	Y1379	Y14B9	Y15F9	SFIN6	Miscellaneous function command high-speed output: S function finish 6
YD3A	YE7A	YFBA	Y10FA	Y123A	Y137A	Y14BA	Y15FA	SFIN7	Miscellaneous function command high-speed output: S function finish 7
YD3B	YE7B	YFBB	Y10FB	Y123B	Y137B	Y14BB	Y15FB	SFIN8	Miscellaneous function command high-speed output: S function finish 8
YD3C	YE7C	YFBC	Y10FC	Y123C	Y137C	Y14BC	Y15FC		
YD3D	YE7D	YFBD	Y10FD	Y123D	Y137D	Y14BD	Y15FD		
YD3E	YE7E	YFBE	Y10FE	Y123E	Y137E	Y14BE	Y15FE		
YD3F	YE7F	YFBF	Y10FF	Y123F	Y137F	Y14BF	Y15FF		

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
Y1870			Y1878		Edit/search
Y1871			Y1879		
Y1872			Y187A		
Y1873			Y187B		
Y1874			Y187C		
Y1875			Y187D		
Y1876			Y187E		
Y1877			Y187F		

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
Y1880	Y18E0	Y1940	Y19A0	Y1A00	Y1A60	Y1AC0	Y1B20		
Y1881	Y18E1	Y1941	Y19A1	Y1A01	Y1A61	Y1AC1	Y1B21		
Y1882	Y18E2	Y1942	Y19A2	Y1A02	Y1A62	Y1AC2	Y1B22		
Y1883	Y18E3	Y1943	Y19A3	Y1A03	Y1A63	Y1AC3	Y1B23		
Y1884	Y18E4	Y1944	Y19A4	Y1A04	Y1A64	Y1AC4	Y1B24		
Y1885	Y18E5	Y1945	Y19A5	Y1A05	Y1A65	Y1AC5	Y1B25	GFIN	Gear shift completion
Y1886	Y18E6	Y1946	Y19A6	Y1A06	Y1A66	Y1AC6	Y1B26		
Y1887	Y18E7	Y1947	Y19A7	Y1A07	Y1A67	Y1AC7	Y1B27		
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
Y1888	Y18E8	Y1948	Y19A8	Y1A08	Y1A68	Y1AC8	Y1B28	SP1	Spindle speed override code 1
Y1889	Y18E9	Y1949	Y19A9	Y1A09	Y1A69	Y1AC9	Y1B29	SP2	Spindle speed override code 2
Y188A	Y18EA	Y194A	Y19AA	Y1A0A	Y1A6A	Y1ACA	Y1B2A	SP4	Spindle speed override code 4
Y188B	Y18EB	Y194B	Y19AB	Y1A0B	Y1A6B	Y1ACB	Y1B2B		
Y188C	Y18EC	Y194C	Y19AC	Y1A0C	Y1A6C	Y1ACC	Y1B2C		
Y188D	Y18ED	Y194D	Y19AD	Y1A0D	Y1A6D	Y1ACD	Y1B2D		
Y188E	Y18EE	Y194E	Y19AE	Y1A0E	Y1A6E	Y1ACE	Y1B2E		
Y188F	Y18EF	Y194F	Y19AF	Y1A0F	Y1A6F	Y1ACF	Y1B2F	SPS	Spindle override method selection
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
Y1890	Y18F0	Y1950	Y19B0	Y1A10	Y1A70	Y1AD0	Y1B30	GI1	Spindle gear selection code 1
Y1891	Y18F1	Y1951	Y19B1	Y1A11	Y1A71	Y1AD1	Y1B31	GI2	Spindle gear selection code 2
Y1892	Y18F2	Y1952	Y19B2	Y1A12	Y1A72	Y1AD2	Y1B32		
Y1893	Y18F3	Y1953	Y19B3	Y1A13	Y1A73	Y1AD3	Y1B33	EXOBS	Increase holding power of spindle
Y1894	Y18F4	Y1954	Y19B4	Y1A14	Y1A74	Y1AD4	Y1B34	SSTP	Spindle stop
Y1895	Y18F5	Y1955	Y19B5	Y1A15	Y1A75	Y1AD5	Y1B35	SSFT	Spindle gear shift
Y1896	Y18F6	Y1956	Y19B6	Y1A16	Y1A76	Y1AD6	Y1B36	SORC	Spindle orientation
Y1897	Y18F7	Y1957	Y19B7	Y1A17	Y1A77	Y1AD7	Y1B37		Spindle command invalid
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
Y1898	Y18F8	Y1958	Y19B8	Y1A18	Y1A78	Y1AD8	Y1B38	SRN	Spindle forward run start
Y1899	Y18F9	Y1959	Y19B9	Y1A19	Y1A79	Y1AD9	Y1B39	SRI	Spindle reverse run start
Y189A	Y18FA	Y195A	Y19BA	Y1A1A	Y1A7A	Y1ADA	Y1B3A	TL1	Spindle torque limit 1
Y189B	Y18FB	Y195B	Y19BB	Y1A1B	Y1A7B	Y1ADB	Y1B3B	TL2	Spindle torque limit 2
Y189C	Y18FC	Y195C	Y19BC	Y1A1C	Y1A7C	Y1ADC	Y1B3C	WRN	Spindle forward run index
Y189D	Y18FD	Y195D	Y19BD	Y1A1D	Y1A7D	Y1ADD	Y1B3D	WRI	Spindle reverse run index
Y189E	Y18FE	Y195E	Y19BE	Y1A1E	Y1A7E	Y1ADE	Y1B3E	ORC	Spindle orientation command
Y189F	Y18FF	Y195F	Y19BF	Y1A1F	Y1A7F	Y1ADF	Y1B3F	LRSL	L coil selection

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
Y18A0	Y1900	Y1960	Y19C0	Y1A20	Y1A80	Y1AE0	Y1B40		
Y18A1	Y1901	Y1961	Y19C1	Y1A21	Y1A81	Y1AE1	Y1B41		
Y18A2	Y1902	Y1962	Y19C2	Y1A22	Y1A82	Y1AE2	Y1B42		
Y18A3	Y1903	Y1963	Y19C3	Y1A23	Y1A83	Y1AE3	Y1B43		
Y18A4	Y1904	Y1964	Y19C4	Y1A24	Y1A84	Y1AE4	Y1B44		
Y18A5	Y1905	Y1965	Y19C5	Y1A25	Y1A85	Y1AE5	Y1B45	CMOD	Spindle position control (Spindle/C axis control): C axis selection
Y18A6	Y1906	Y1966	Y19C6	Y1A26	Y1A86	Y1AE6	Y1B46	LRSM	M coil selection
Y18A7	Y1907	Y1967	Y19C7	Y1A27	Y1A87	Y1AE7	Y1B47		
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
Y18A8	Y1908	Y1968	Y19C8	Y1A28	Y1A88	Y1AE8	Y1B48	SWS	Spindle selection
Y18A9	Y1909	Y1969	Y19C9	Y1A29	Y1A89	Y1AE9	Y1B49		
Y18AA	Y190A	Y196A	Y19CA	Y1A2A	Y1A8A	Y1AEA	Y1B4A	SPRR	Spindle rotation reversal
Y18AB	Y190B	Y196B	Y19CB	Y1A2B	Y1A8B	Y1AEB	Y1B4B	SPRS	Spindle rotation direction switch method selection
Y18AC	Y190C	Y196C	Y19CC	Y1A2C	Y1A8C	Y1AEC	Y1B4C		
Y18AD	Y190D	Y196D	Y19CD	Y1A2D	Y1A8D	Y1AED	Y1B4D		
Y18AE	Y190E	Y196E	Y19CE	Y1A2E	Y1A8E	Y1AEE	Y1B4E		
Y18AF	Y190F	Y196F	Y19CF	Y1A2F	Y1A8F	Y1AEF	Y1B4F	MPCSL	PLC coil changeover
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
Y18B0	Y1910	Y1970	Y19D0	Y1A30	Y1A90	Y1AF0	Y1B50	SPSY	Spindle synchronization
Y18B1	Y1911	Y1971	Y19D1	Y1A31	Y1A91	Y1AF1	Y1B51	SPPHS	Spindle phase synchronization
Y18B2	Y1912	Y1972	Y19D2	Y1A32	Y1A92	Y1AF2	Y1B52	SPSDR	Spindle synchronous rotation direction
Y18B3	Y1913	Y1973	Y19D3	Y1A33	Y1A93	Y1AF3	Y1B53	SSPHM	Phase shift calculation request
Y18B4	Y1914	Y1974	Y19D4	Y1A34	Y1A94	Y1AF4	Y1B54	SSPHF	Phase offset request
Y18B5	Y1915	Y1975	Y19D5	Y1A35	Y1A95	Y1AF5	Y1B55	SPDRPO	Error temporary cancel
Y18B6	Y1916	Y1976	Y19D6	Y1A36	Y1A96	Y1AF6	Y1B56		
Y18B7	Y1917	Y1977	Y19D7	Y1A37	Y1A97	Y1AF7	Y1B57		
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
Y18B8	Y1918	Y1978	Y19D8	Y1A38	Y1A98	Y1AF8	Y1B58	SPSYC	Spindle synchronization/superimposition cancel
Y18B9	Y1919	Y1979	Y19D9	Y1A39	Y1A99	Y1AF9	Y1B59	SPCMPC	Chuck close
Y18BA	Y191A	Y197A	Y19DA	Y1A3A	Y1A9A	Y1AFA	Y1B5A		
Y18BB	Y191B	Y197B	Y19DB	Y1A3B	Y1A9B	Y1AFB	Y1B5B		
Y18BC	Y191C	Y197C	Y19DC	Y1A3C	Y1A9C	Y1AFC	Y1B5C		
Y18BD	Y191D	Y197D	Y19DD	Y1A3D	Y1A9D	Y1AFD	Y1B5D		
Y18BE	Y191E	Y197E	Y19DE	Y1A3E	Y1A9E	Y1AFE	Y1B5E		
Y18BF	Y191F	Y197F	Y19DF	Y1A3F	Y1A9F	Y1AFF	Y1B5F	SPOFF	Exclude spindle

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
Y18C0	Y1920	Y1980	Y19E0	Y1A40	Y1AA0	Y1B00	Y1B60		
Y18C1	Y1921	Y1981	Y19E1	Y1A41	Y1AA1	Y1B01	Y1B61		
Y18C2	Y1922	Y1982	Y19E2	Y1A42	Y1AA2	Y1B02	Y1B62		
Y18C3	Y1923	Y1983	Y19E3	Y1A43	Y1AA3	Y1B03	Y1B63		
Y18C4	Y1924	Y1984	Y19E4	Y1A44	Y1AA4	Y1B04	Y1B64		
Y18C5	Y1925	Y1985	Y19E5	Y1A45	Y1AA5	Y1B05	Y1B65		
Y18C6	Y1926	Y1986	Y19E6	Y1A46	Y1AA6	Y1B06	Y1B66		
Y18C7	Y1927	Y1987	Y19E7	Y1A47	Y1AA7	Y1B07	Y1B67		
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
Y18C8	Y1928	Y1988	Y19E8	Y1A48	Y1AA8	Y1B08	Y1B68		Spindle oscillation command
Y18C9	Y1929	Y1989	Y19E9	Y1A49	Y1AA9	Y1B09	Y1B69		
Y18CA	Y192A	Y198A	Y19EA	Y1A4A	Y1AAA	Y1B0A	Y1B6A	VGHLDC	Real-time tuning 1: Speed control gain changeover hold-down command
Y18CB	Y192B	Y198B	Y19EB	Y1A4B	Y1AAB	Y1B0B	Y1B6B	SPFLRQ	SPFL: Control request ▲
Y18CC	Y192C	Y198C	Y19EC	Y1A4C	Y1AAC	Y1B0C	Y1B6C		
Y18CD	Y192D	Y198D	Y19ED	Y1A4D	Y1AAD	Y1B0D	Y1B6D		
Y18CE	Y192E	Y198E	Y19EE	Y1A4E	Y1AAE	Y1B0E	Y1B6E		
Y18CF	Y192F	Y198F	Y19EF	Y1A4F	Y1AAF	Y1B0F	Y1B6F		
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
Y18D0	Y1930	Y1990	Y19F0	Y1A50	Y1AB0	Y1B10	Y1B70		
Y18D1	Y1931	Y1991	Y19F1	Y1A51	Y1AB1	Y1B11	Y1B71		
Y18D2	Y1932	Y1992	Y19F2	Y1A52	Y1AB2	Y1B12	Y1B72		
Y18D3	Y1933	Y1993	Y19F3	Y1A53	Y1AB3	Y1B13	Y1B73		
Y18D4	Y1934	Y1994	Y19F4	Y1A54	Y1AB4	Y1B14	Y1B74		
Y18D5	Y1935	Y1995	Y19F5	Y1A55	Y1AB5	Y1B15	Y1B75		
Y18D6	Y1936	Y1996	Y19F6	Y1A56	Y1AB6	Y1B16	Y1B76		
Y18D7	Y1937	Y1997	Y19F7	Y1A57	Y1AB7	Y1B17	Y1B77		
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
Y18D8	Y1938	Y1998	Y19F8	Y1A58	Y1AB8	Y1B18	Y1B78		
Y18D9	Y1939	Y1999	Y19F9	Y1A59	Y1AB9	Y1B19	Y1B79		
Y18DA	Y193A	Y199A	Y19FA	Y1A5A	Y1ABA	Y1B1A	Y1B7A		
Y18DB	Y193B	Y199B	Y19FB	Y1A5B	Y1ABB	Y1B1B	Y1B7B		
Y18DC	Y193C	Y199C	Y19FC	Y1A5C	Y1ABC	Y1B1C	Y1B7C		
Y18DD	Y193D	Y199D	Y19FD	Y1A5D	Y1ABD	Y1B1D	Y1B7D		
Y18DE	Y193E	Y199E	Y19FE	Y1A5E	Y1ABE	Y1B1E	Y1B7E		
Y18DF	Y193F	Y199F	Y19FF	Y1A5F	Y1ABF	Y1B1F	Y1B7F		

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
Y1C80		MES interface library: Operation trigger	Y1C88	ENC1PC LR	External encoder 1: Position output clear request
Y1C81	*KEY_Me mC	Data protect key (memory card)	Y1C89		
Y1C82	*KEY_DS	Data protect key (DS)	Y1C8A		
Y1C83	BZR	Buzzer sound control: Buzzer ON	Y1C8B		
Y1C84	EQLDWR	Spindle protection: Resetting alarm of equivalent load factor over limit	Y1C8C		
Y1C85	DSPCRD	Image input I/F: Screen selection	Y1C8D	DSP-FLPV	Image input I/F: IPC screen vertical inversion
Y1C86			Y1C8E	DSP-FLPH	Image input I/F: IPC screen horizontal inversion
Y1C87			Y1C8F		

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
Y1CA0			Y1CA8		
Y1CA1			Y1CA9		
Y1CA2			Y1CAA		
Y1CA3			Y1CAB		
Y1CA4			Y1CAC		
Y1CA5			Y1CAD		
Y1CA6		Laser: Laser condition change complete	Y1CAE		
Y1CA7		Laser: Laser beam irradiating	Y1CAF		

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
Y1CB0			Y1CB8	TWR	Reservation of tool wear compensation
Y1CB1			Y1CB9		
Y1CB2			Y1CBA		
Y1CB3			Y1CBB		
Y1CB4			Y1CBC		
Y1CB5			Y1CBD		
Y1CB6			Y1CBE		
Y1CB7			Y1CBF		

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
Y1CD0			Y1CD8		Laser: Height control
Y1CD1			Y1CD9		Laser: Enable height retention in height control
Y1CD2			Y1CDA		
Y1CD3			Y1CDB		
Y1CD4			Y1CDC		
Y1CD5			Y1CDD		
Y1CD6			Y1CDE		
Y1CD7			Y1CDF		

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
Y1CE0		Laser: Laser beam irradiation ready	Y1CE8		
Y1CE1		Laser: Axis stop time with beam ON monitoring OFF	Y1CE9		
Y1CE2			Y1CEA		
Y1CE3			Y1CEB		
Y1CE4			Y1CEC		
Y1CE5			Y1CED		
Y1CE6			Y1CEE		
Y1CE7			Y1CEF		

2 Input/Output Signals with Controller

2.3 PLC Output Signals (Bit Type: Y***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
Y1D00	Y1D20	Y1D40	Y1D60	Y1D80	Y1DA0	Y1DC0	Y1DE0		Position switch 1 interlock
Y1D01	Y1D21	Y1D41	Y1D61	Y1D81	Y1DA1	Y1DC1	Y1DE1		Position switch 2 interlock
Y1D02	Y1D22	Y1D42	Y1D62	Y1D82	Y1DA2	Y1DC2	Y1DE2		Position switch 3 interlock
Y1D03	Y1D23	Y1D43	Y1D63	Y1D83	Y1DA3	Y1DC3	Y1DE3		Position switch 4 interlock
Y1D04	Y1D24	Y1D44	Y1D64	Y1D84	Y1DA4	Y1DC4	Y1DE4		Position switch 5 interlock
Y1D05	Y1D25	Y1D45	Y1D65	Y1D85	Y1DA5	Y1DC5	Y1DE5		Position switch 6 interlock
Y1D06	Y1D26	Y1D46	Y1D66	Y1D86	Y1DA6	Y1DC6	Y1DE6		Position switch 7 interlock
Y1D07	Y1D27	Y1D47	Y1D67	Y1D87	Y1DA7	Y1DC7	Y1DE7		Position switch 8 interlock
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
Y1D08	Y1D28	Y1D48	Y1D68	Y1D88	Y1DA8	Y1DC8	Y1DE8		Position switch 9 interlock
Y1D09	Y1D29	Y1D49	Y1D69	Y1D89	Y1DA9	Y1DC9	Y1DE9		Position switch 10 interlock
Y1D0A	Y1D2A	Y1D4A	Y1D6A	Y1D8A	Y1DAA	Y1DCA	Y1DEA		Position switch 11 interlock
Y1D0B	Y1D2B	Y1D4B	Y1D6B	Y1D8B	Y1DAB	Y1DCB	Y1DEB		Position switch 12 interlock
Y1D0C	Y1D2C	Y1D4C	Y1D6C	Y1D8C	Y1DAC	Y1DCC	Y1DEC		Position switch 13 interlock
Y1D0D	Y1D2D	Y1D4D	Y1D6D	Y1D8D	Y1DAD	Y1DCD	Y1DED		Position switch 14 interlock
Y1D0E	Y1D2E	Y1D4E	Y1D6E	Y1D8E	Y1DAE	Y1DCE	Y1DEE		Position switch 15 interlock
Y1D0F	Y1D2F	Y1D4F	Y1D6F	Y1D8F	Y1DAF	Y1DCF	Y1DEF		Position switch 16 interlock
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
Y1D10	Y1D30	Y1D50	Y1D70	Y1D90	Y1DB0	Y1DD0	Y1DF0		Position switch 17 interlock
Y1D11	Y1D31	Y1D51	Y1D71	Y1D91	Y1DB1	Y1DD1	Y1DF1		Position switch 18 interlock
Y1D12	Y1D32	Y1D52	Y1D72	Y1D92	Y1DB2	Y1DD2	Y1DF2		Position switch 19 interlock
Y1D13	Y1D33	Y1D53	Y1D73	Y1D93	Y1DB3	Y1DD3	Y1DF3		Position switch 20 interlock
Y1D14	Y1D34	Y1D54	Y1D74	Y1D94	Y1DB4	Y1DD4	Y1DF4		Position switch 21 interlock
Y1D15	Y1D35	Y1D55	Y1D75	Y1D95	Y1DB5	Y1DD5	Y1DF5		Position switch 22 interlock
Y1D16	Y1D36	Y1D56	Y1D76	Y1D96	Y1DB6	Y1DD6	Y1DF6		Position switch 23 interlock
Y1D17	Y1D37	Y1D57	Y1D77	Y1D97	Y1DB7	Y1DD7	Y1DF7		Position switch 24 interlock
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
Y1D18	Y1D38	Y1D58	Y1D78	Y1D98	Y1DB8	Y1DD8	Y1DF8		Position switch 25 interlock ▲
Y1D19	Y1D39	Y1D59	Y1D79	Y1D99	Y1DB9	Y1DD9	Y1DF9		Position switch 26 interlock ▲
Y1D1A	Y1D3A	Y1D5A	Y1D7A	Y1D9A	Y1DBA	Y1DDA	Y1DFA		Position switch 27 interlock ▲
Y1D1B	Y1D3B	Y1D5B	Y1D7B	Y1D9B	Y1DBB	Y1ddb	Y1DFB		Position switch 28 interlock ▲
Y1D1C	Y1D3C	Y1D5C	Y1D7C	Y1D9C	Y1DBC	Y1DDC	Y1DFC		Position switch 29 interlock ▲
Y1D1D	Y1D3D	Y1D5D	Y1D7D	Y1D9D	Y1DBD	Y1DDD	Y1DFD		Position switch 30 interlock ▲
Y1D1E	Y1D3E	Y1D5E	Y1D7E	Y1D9E	Y1DBE	Y1DDE	Y1DFE		Position switch 31 interlock ▲
Y1D1F	Y1D3F	Y1D5F	Y1D7F	Y1D9F	Y1DBF	Y1DDF	Y1DFF		Position switch 32 interlock ▲

2.4 PLC Output Signals (Data Type: R***)

Note

(1) Signals with " ▲ " are prepared for a specific machine tool builder.

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R200	AO1	Analog output 1	R208		
R201	AO2	Analog output 2	R209		
R202	AO3	Analog output 3	R210		Displayed screen No.
R203	AO4	Analog output 4	R211		
R204			R212		KEY OUT 1
R205			R213		
R206			R214		
R207			R215		Power OFF indication Y device No.
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R216		Detailed screen No.	R224		User sequence program version code A
R217			R225		User sequence program version code B
R218			R226		User sequence program version code C
R219			R227		User sequence program version code D
R220			R228		
R221			R229		
R222			R230		
R223			R231		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R232		User sequence program version code 2 A	R240		APLC version A
R233		User sequence program version code 2 B	R241		APLC version B
R234		User sequence program version code 2 C	R242		APLC version C
R235		User sequence program version code 2 D	R243		APLC version D
R236		User sequence program version code 2 E	R244		
R237		User sequence program version code 2 F	R245		
R238		User sequence program version code 2 G	R246		
R239		User sequence program version code 2 H	R247		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R248		OT ignored (Axis 1 to 8 for part system 1,2)	R256		
R249		OT ignored (Axis 1 to 8 for part system 3,4)	R257		
R250			R258		
R251			R259		
R252			R260		
R253			R261		
R254			R262		
R255		PLC axis OT ignored	R263		

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R264			R272		Near-point dog ignored (Axis 1 to 8 for part system 1,2)
R265			R273		Near-point dog ignored (Axis 1 to 8 for part system 3,4)
R266			R274		
R267			R275		
R268			R276		
R269			R277		
R270			R278		
R271			R279		PLC axis near-point dog ignored
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R280			R288		
R281			R289		
R282			R290		
R283			R291		
R284			R292		
R285			R293		
R286			R294		
R287			R295		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R296	SOMD	Speed monitor mode	R304	NDPC	Power consumption computation: Consumption of devices other than drive system(L)
R297		Handy terminal Data area top address	R305		Power consumption computation: Consumption of devices other than drive system(H)
R298		Handy terminal Data valid number of registers	R306	DFPCC	Power consumption computation: Drive system's fixed consumption correction(L)
R299		Handy terminal Cause of communication error	R307		Power consumption computation: Drive system's fixed consumption correction(H)
R300			R308		Operator message I/F 1
R301			R309		Operator message I/F 2
R302			R310		Operator message I/F 3
R303			R311		Operator message I/F 4
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R312			R320	DSP-POSH	Image input I/F: Image display position (H)
R313			R321	DSP-POSV	Image input I/F: Image display position (V)
R314		PLC axis position switch interlock 1 to 16 ▲	R322	DSPSZH	Image input I/F: Display range (width)
R315		PLC axis position switch interlock 17 to 32 ▲	R323	DSPSZV	Image input I/F: Display range (height)
R316			R324	IP-CPOSH	Image input I/F: IPC screen transfer start position (H)
R317			R325	IP-CPOSV	Image input I/F: IPC screen transfer start position (V)
R318			R326	IPCSZH	Image input I/F: IPC screen transfer range (width)
R319			R327	IPCSZV	Image input I/F: IPC screen transfer range (height)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R328	DSPACT	Image input I/F: Behavior at operation	R336		Tool I/D R/W pot No. designation ▲
R329			R337		Large diameter tool information ▲
R330			R338		Tool weight (spindle tool) ▲
R331			R339		Tool weight (standby tool) ▲
R332			R340		Unset tool information ▲
R333			R341		
R334			R342		Specified shape interference Shape No. designation
R335			R343		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R344			R352		Remote program input No. (L) ▲
R345			R353		Remote program input No. (H) ▲
R346			R354		Machine manufacturer macro password No. (L)
R347		Skip retract valid	R355		Machine manufacturer macro password No. (H)
R348		Skip retract amount (L) [M]	R356		Direct screen selection A
R349		Skip retract amount (H) [M]	R357		Direct screen selection B
R350		Skip retract speed (L) [M]	R358		Direct screen selection C
R351		Skip retract speed (H) [M]	R359		Direct screen selection D
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R360			R368		
R361		User level-based data protection: Operation level	R369		
R362			R370		
R363			R371		
R364		Machine parameter lock I/F	R372		High-speed simple program check: Time measurement output (L)
R365		Measures against tool setter chattering Movement amount	R373		High-speed simple program check: Time measurement output (H)
R366			R374		
R367			R375		Manual arbitrary reverse run handle selection
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R376			R384		
R377			R385		
R378		High-speed simple program check: Time reduction coefficient	R386		
R379		Manual arbitrary reverse run speed multiplier	R387		
R380			R388		
R381			R389		
R382			R390		G/B spindle synchronization: Position error compensation scale, and the number of times of compensations
R383			R391		Optimum acceleration/deceleration parameter switching axis (spindle and bit selection) ▲

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R392			R400		Ball screw thermal displacement compensation: Offset amount 1st axis [M]
R393			R401		Ball screw thermal displacement compensation: Max. compensation amount 1st axis [M]
R394			R402		Ball screw thermal displacement compensation: Part system, axis No. 1st axis
R395			R403		Ball screw thermal displacement compensation: Offset amount 2nd axis [M]
R396		User PLC info program format info	R404		Ball screw thermal displacement compensation: Max. compensation amount 2nd axis [M]
R397			R405		Ball screw thermal displacement compensation: Part system, axis No. 2nd axis
R398			R406		Ball screw thermal displacement compensation: Offset amount 3rd axis [M]
R399			R407		Ball screw thermal displacement compensation: Max. compensation amount 3rd axis [M]
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R408		Ball screw thermal displacement compensation: Part system, axis No. 3rd axis	R416		
R409		Ball screw thermal displacement compensation: Offset amount 4th axis [M]	R417		
R410		Ball screw thermal displacement compensation: Max. compensation amount 4th axis [M]	R418		
R411		Ball screw thermal displacement compensation: Part system, axis No. 4th axis	R419		
R412			R420		
R413			R421		
R414			R422		
R415			R423		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R424		PLC window Reading start R register 1	R432		PLC window Reading start R register 3
R425		PLC window Number of read windows 1	R433		PLC window Number of read windows 3
R426		PLC window Writing start R register 1	R434		PLC window Writing start R register 3
R427		PLC window Number of write windows 1	R435		PLC window Number of write windows 3
R428		PLC window Reading start R register 2	R436		
R429		PLC window Number of read windows 2	R437		
R430		PLC window Writing start R register 2	R438		
R431		PLC window Number of write windows 2	R439		

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R440		PLC axis control information address 1st axis	R448		PLC axis control buffering mode information address
R441		PLC axis control information address 2nd axis	R449		
R442		PLC axis control information address 3rd axis	R450		
R443		PLC axis control information address 4th axis	R451		
R444		PLC axis control information address 5th axis	R452		
R445		PLC axis control information address 6th axis	R453		
R446		PLC axis control information address 7th axis	R454		
R447		PLC axis control information address 8th axis	R455		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R456		Encoder 1 arbitrary pulse 1	R464		G/B spindle synchronization: Maximum value of the relative position error during the steady state
R457		Encoder 1 arbitrary pulse 2	R465		G/B spindle synchronization: Position error compensation amount
R458		Encoder 2 arbitrary pulse 1	R466		G/B spindle synchronization: Phase shift amount
R459		Encoder 2 arbitrary pulse 2	R467		
R460		G/B spindle synchronization: Maximum range of the relative position error	R468		Interference check between part systems: Data address
R461		G/B spindle synchronization: Maximum value of the relative position error	R469	SKIPGN	Skip signal ignore ▲
R462		G/B spindle synchronization: Average value of the relative position error during the steady state	R470		Modbus block 1 transfer position ▲
R463		G/B spindle synchronization: Maximum range of the relative position error during the steady state	R471		Modbus block 1 number of transfer ▲
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R472		Modbus block 2 transfer position ▲	R480		
R473		Modbus block 2 number of transfer ▲	R481		
R474		Modbus block 3 transfer position ▲	R482		
R475		Modbus block 3 number of transfer ▲	R483		
R476		Modbus block 4 transfer position ▲	R484		
R477		Modbus block 4 number of transfer ▲	R485		
R478		Modbus transfer cycle ▲	R486		
R479		Modbus time-out period ▲	R487		
Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R488			R496		
R489			R497		
R490			R498		
R491			R499		
R492					
R493					
R494					
R495					

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2500	R2700	R2900	R3100	R3300	R3500	R3700	R3900		1st cutting feedrate override
R2501	R2701	R2901	R3101	R3301	R3501	R3701	R3901		2nd cutting feedrate override
R2502	R2702	R2902	R3102	R3302	R3502	R3702	R3902		Rapid traverse override
R2503	R2703	R2903	R3103	R3303	R3503	R3703	R3903	CHPOV	Chopping override
R2504	R2704	R2904	R3104	R3304	R3504	R3704	R3904		Manual feedrate (L) [M]
R2505	R2705	R2905	R3105	R3305	R3505	R3705	R3905		Manual feedrate (H) [M]
R2506	R2706	R2906	R3106	R3306	R3506	R3706	R3906		Manual feedrate B (L) [M]
R2507	R2707	R2907	R3107	R3307	R3507	R3707	R3907		Manual feedrate B (H) [M]
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2508	R2708	R2908	R3108	R3308	R3508	R3708	R3908		1st handle/incremental feed magnification (L)
R2509	R2709	R2909	R3109	R3309	R3509	R3709	R3909		1st handle/incremental feed magnification (H)
R2510	R2710	R2910	R3110	R3310	R3510	R3710	R3910		2nd handle feed magnification (L)
R2511	R2711	R2911	R3111	R3311	R3511	R3711	R3911		2nd handle feed magnification (H)
R2512	R2712	R2912	R3112	R3312	R3512	R3712	R3912		3rd handle feed magnification (L)
R2513	R2713	R2913	R3113	R3313	R3513	R3713	R3913		3rd handle feed magnification (H)
R2514	R2714	R2914	R3114	R3314	R3514	R3714	R3914		
R2515	R2715	R2915	R3115	R3315	R3515	R3715	R3915		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2516	R2716	R2916	R3116	R3316	R3516	R3716	R3916		
R2517	R2717	R2917	R3117	R3317	R3517	R3717	R3917		
R2518	R2718	R2918	R3118	R3318	R3518	R3718	R3918		PLC interrupt program number (L)
R2519	R2719	R2919	R3119	R3319	R3519	R3719	R3919		PLC interrupt program number (H)
R2520	R2720	R2920	R3120	R3320	R3520	R3720	R3920		
R2521	R2721	R2921	R3121	R3321	R3521	R3721	R3921		
R2522	R2722	R2922	R3122	R3322	R3522	R3722	R3922		
R2523	R2723	R2923	R3123	R3323	R3523	R3723	R3923		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2524	R2724	R2924	R3124	R3324	R3524	R3724	R3924		Manual feedrate B override
R2525	R2725	R2925	R3125	R3325	R3525	R3725	R3925		External search device No.
R2526	R2726	R2926	R3126	R3326	R3526	R3726	R3926		External search program No. (L)
R2527	R2727	R2927	R3127	R3327	R3527	R3727	R3927		External search program No. (H)
R2528	R2728	R2928	R3128	R3328	R3528	R3728	R3928		External search sequence No. (L)
R2529	R2729	R2929	R3129	R3329	R3529	R3729	R3929		External search sequence No. (H)
R2530	R2730	R2930	R3130	R3330	R3530	R3730	R3930		External search block No. (L)
R2531	R2731	R2931	R3131	R3331	R3531	R3731	R3931		External search block No. (H)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2532	R2732	R2932	R3132	R3332	R3532	R3732	R3932		
R2533	R2733	R2933	R3133	R3333	R3533	R3733	R3933		
R2534	R2734	R2934	R3134	R3334	R3534	R3734	R3934		
R2535	R2735	R2935	R3135	R3335	R3535	R3735	R3935		
R2536	R2736	R2936	R3136	R3336	R3536	R3736	R3936		
R2537	R2737	R2937	R3137	R3337	R3537	R3737	R3937		
R2538	R2738	R2938	R3138	R3338	R3538	R3738	R3938		
R2539	R2739	R2939	R3139	R3339	R3539	R3739	R3939		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2540	R2740	R2940	R3140	R3340	R3540	R3740	R3940		Handle polarity
R2541	R2741	R2941	R3141	R3341	R3541	R3741	R3941		
R2542	R2742	R2942	R3142	R3342	R3542	R3742	R3942		
R2543	R2743	R2943	R3143	R3343	R3543	R3743	R3943		
R2544	R2744	R2944	R3144	R3344	R3544	R3744	R3944		Manual arbitrary feed 1st axis travel amount (L) [M]
R2545	R2745	R2945	R3145	R3345	R3545	R3745	R3945		Manual arbitrary feed 1st axis travel amount (H) [M]
R2546	R2746	R2946	R3146	R3346	R3546	R3746	R3946		
R2547	R2747	R2947	R3147	R3347	R3547	R3747	R3947		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2548	R2748	R2948	R3148	R3348	R3548	R3748	R3948		Manual arbitrary feed 2nd axis travel amount (L) [M]
R2549	R2749	R2949	R3149	R3349	R3549	R3749	R3949		Manual arbitrary feed 2nd axis travel amount (H) [M]
R2550	R2750	R2950	R3150	R3350	R3550	R3750	R3950		
R2551	R2751	R2951	R3151	R3351	R3551	R3751	R3951		
R2552	R2752	R2952	R3152	R3352	R3552	R3752	R3952		Manual arbitrary feed 3rd axis travel amount (L) [M]
R2553	R2753	R2953	R3153	R3353	R3553	R3753	R3953		Manual arbitrary feed 3rd axis travel amount (H) [M]
R2554	R2754	R2954	R3154	R3354	R3554	R3754	R3954		
R2555	R2755	R2955	R3155	R3355	R3555	R3755	R3955		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2556	R2756	R2956	R3156	R3356	R3556	R3756	R3956		Alarm message I/F 1
R2557	R2757	R2957	R3157	R3357	R3557	R3757	R3957		Alarm message I/F 2
R2558	R2758	R2958	R3158	R3358	R3558	R3758	R3958		Alarm message I/F 3
R2559	R2759	R2959	R3159	R3359	R3559	R3759	R3959		Alarm message I/F 4
R2560	R2760	R2960	R3160	R3360	R3560	R3760	R3960		Operator message I/F
R2561	R2761	R2961	R3161	R3361	R3561	R3761	R3961		
R2562	R2762	R2962	R3162	R3362	R3562	R3762	R3962		Search & start program No. (L)
R2563	R2763	R2963	R3163	R3363	R3563	R3763	R3963		Search & start program No. (H)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2564	R2764	R2964	R3164	R3364	R3564	R3764	R3964		Manual skip I/F 1 (Manual skip control) ▲
R2565	R2765	R2965	R3165	R3365	R3565	R3765	R3965		Manual skip I/F 2 (Manual skip axis stop/read request) ▲
R2566	R2766	R2966	R3166	R3366	R3566	R3766	R3966		Manual skip I/F 3 (Manual skip axis stop mode) ▲
R2567	R2767	R2967	R3167	R3367	R3567	R3767	R3967		Encoder selection
R2568	R2768	R2968	R3168	R3368	R3568	R3768	R3968		C axis selection
R2569	R2769	R2969	R3169	R3369	R3569	R3769	R3969		
R2570	R2770	R2970	R3170	R3370	R3570	R3770	R3970		
R2571	R2771	R2971	R3171	R3371	R3571	R3771	R3971		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2572	R2772	R2972	R3172	R3372	R3572	R3772	R3972		
R2573	R2773	R2973	R3173	R3373	R3573	R3773	R3973		
R2574	R2774	R2974	R3174	R3374	R3574	R3774	R3974		
R2575	R2775	R2975	R3175	R3375	R3575	R3775	R3975		
R2576	R2776	R2976	R3176	R3376	R3576	R3776	R3976		
R2577	R2777	R2977	R3177	R3377	R3577	R3777	R3977		
R2578	R2778	R2978	R3178	R3378	R3578	R3778	R3978		
R2579	R2779	R2979	R3179	R3379	R3579	R3779	R3979		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2580	R2780	R2980	R3180	R3380	R3580	R3780	R3980		Load monitoring I: Axis selection
R2581	R2781	R2981	R3181	R3381	R3581	R3781	R3981		Load monitoring I: Load change rate detection axis ▲
R2582	R2782	R2982	R3182	R3382	R3582	R3782	R3982		Load monitoring I: Teaching data sub-No. ▲
R2583	R2783	R2983	R3183	R3383	R3583	R3783	R3983		Load monitoring I: Adaptive control reference axis selection ▲
R2584	R2784	R2984	R3184	R3384	R3584	R3784	R3984		Each axis reference position selection
R2585	R2785	R2985	R3185	R3385	R3585	R3785	R3985		
R2586	R2786	R2986	R3186	R3386	R3586	R3786	R3986		
R2587	R2787	R2987	R3187	R3387	R3587	R3787	R3987		Chopping control data address
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2588	R2788	R2988	R3188	R3388	R3588	R3788	R3988		Tool life management data sort
R2589	R2789	R2989	R3189	R3389	R3589	R3789	R3989		Synchronous control operation method
R2590	R2790	R2990	R3190	R3390	R3590	R3790	R3990		Tool group No. designation (L)
R2591	R2791	R2991	R3191	R3391	R3591	R3791	R3991		Tool group No. designation (H)
R2592	R2792	R2992	R3192	R3392	R3592	R3792	R3992		Reference position adjustment completion
R2593	R2793	R2993	R3193	R3393	R3593	R3793	R3993		Current limit changeover
R2594	R2794	R2994	R3194	R3394	R3594	R3794	R3994		Wear compensation No. (tool presetter)
R2595	R2795	R2995	R3195	R3395	R3595	R3795	R3995		

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2596	R2796	R2996	R3196	R3396	R3596	R3796	R3996		Turret interference object tool No. designation
R2597	R2797	R2997	R3197	R3397	R3597	R3797	R3997		
R2598	R2798	R2998	R3198	R3398	R3598	R3798	R3998		
R2599	R2799	R2999	R3199	R3399	R3599	R3799	R3999		Workpiece coordinate selection ▲
R2600	R2800	R3000	R3200	R3400	R3600	R3800	R4000		Workpiece coordinate offset measurement: Tool compensation No./Selected tool compensation No. (main) (L) (*1)
R2601	R2801	R3001	R3201	R3401	R3601	R3801	R4001		Workpiece coordinate offset measurement: Tool compensation No./Selected tool compensation No. (main) (H)
R2602	R2802	R3002	R3202	R3402	R3602	R3802	R4002		Workpiece coordinate offset measurement: Tool No./Selected tool No. (main) (L) (*1)
R2603	R2803	R3003	R3203	R3403	R3603	R3803	R4003		Workpiece coordinate offset measurement: Tool No./Selected tool No. (main) (H)
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2604	R2804	R3004	R3204	R3404	R3604	R3804	R4004		Selected tool compensation No. (sub) (L)
R2605	R2805	R3005	R3205	R3405	R3605	R3805	R4005		Selected tool compensation No. (sub) (H)
R2606	R2806	R3006	R3206	R3406	R3606	R3806	R4006		Selected tool wear No. (sub) (L)
R2607	R2807	R3007	R3207	R3407	R3607	R3807	R4007		Selected tool wear No. (sub) (H)
R2608	R2808	R3008	R3208	R3408	R3608	R3808	R4008		Tool mounting information 1-16
R2609	R2809	R3009	R3209	R3409	R3609	R3809	R4009		Tool mounting information 17-32
R2610	R2810	R3010	R3210	R3410	R3610	R3810	R4010		Tool mounting information 33-48
R2611	R2811	R3011	R3211	R3411	R3611	R3811	R4011		Tool mounting information 49-64
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2612	R2812	R3012	R3212	R3412	R3612	R3812	R4012		Tool mounting information 65-80
R2613	R2813	R3013	R3213	R3413	R3613	R3813	R4013		
R2614	R2814	R3014	R3214	R3414	R3614	R3814	R4014	SLSPNO	Multiple-spindle control I: Selected spindle No.
R2615	R2815	R3015	R3215	R3415	R3615	R3815	R4015	RPARCH G	Rotary axis configuration parameter switch
R2616	R2816	R3016	R3216	R3416	R3616	R3816	R4016		Ext. machine coordinate: Compensation No. ▲
R2617	R2817	R3017	R3217	R3417	R3617	R3817	R4017		Optimum acceleration/deceleration: Parameter switching axis (axis and bit selection) ▲
R2618	R2818	R3018	R3218	R3418	R3618	R3818	R4018		Tool length measurement 2 Tool No. (L)
R2619	R2819	R3019	R3219	R3419	R3619	R3819	R4019		Tool length measurement 2 Tool No. (H)
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2620	R2820	R3020	R3220	R3420	R3620	R3820	R4020		Constant torque control: Constant torque/proportional torque stopper control request axis
R2621	R2821	R3021	R3221	R3421	R3621	R3821	R4021		Constant torque control: Constant torque droop cancel request axis
R2622	R2822	R3022	R3222	R3422	R3622	R3822	R4022		
R2623	R2823	R3023	R3223	R3423	R3623	R3823	R4023		
R2624	R2824	R3024	R3224	R3424	R3624	R3824	R4024		
R2625	R2825	R3025	R3225	R3425	R3625	R3825	R4025		Servo ready completion output designation
R2626	R2826	R3026	R3226	R3426	R3626	R3826	R4026		Thread recutting command
R2627	R2827	R3027	R3227	R3427	R3627	R3827	R4027		Thread recutting execution operation

(*1) When the chuck barrier is checked, "Selected tool compensation No.(main): R2600, R2601" and "Selected tool No.(main): R2602, R2603" are applied.

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2628	R2828	R3028	R3228	R3428	R3628	R3828	R4028		Mechanical axis specifications 1st rotary axis angle (L)
R2629	R2829	R3029	R3229	R3429	R3629	R3829	R4029		Mechanical axis specifications 1st rotary axis angle (H)
R2630	R2830	R3030	R3230	R3430	R3630	R3830	R4030		Mechanical axis specifications 2nd rotary axis angle (L)
R2631	R2831	R3031	R3231	R3431	R3631	R3831	R4031		Mechanical axis specifications 2nd rotary axis angle (H)
R2632	R2832	R3032	R3232	R3432	R3632	R3832	R4032		
R2633	R2833	R3033	R3233	R3433	R3633	R3833	R4033		
R2634	R2834	R3034	R3234	R3434	R3634	R3834	R4034	TAN- GOFS	Simple inclined surface machining command: Tool axis rotation angle compensation amount
R2635	R2835	R3035	R3235	R3435	R3635	R3835	R4035		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2636	R2836	R3036	R3236	R3436	R3636	R3836	R4036		Circular feed in manual mode Operation mode data (L)
R2637	R2837	R3037	R3237	R3437	R3637	R3837	R4037		Circular feed in manual mode Operation mode data (H)
R2638	R2838	R3038	R3238	R3438	R3638	R3838	R4038		Circular feed in manual mode Part system designation
R2639	R2839	R3039	R3239	R3439	R3639	R3839	R4039		
R2640	R2840	R3040	R3240	R3440	R3640	R3840	R4040		Circular feed in manual mode Horizontal axis designation
R2641	R2841	R3041	R3241	R3441	R3641	R3841	R4041		Circular feed in manual mode Vertical axis designation
R2642	R2842	R3042	R3242	R3442	R3642	R3842	R4042		
R2643	R2843	R3043	R3243	R3443	R3643	R3843	R4043		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2644	R2844	R3044	R3244	R3444	R3644	R3844	R4044		Circular feed in manual mode Reference point H data (L)
R2645	R2845	R3045	R3245	R3445	R3645	R3845	R4045		Circular feed in manual mode Reference point H data (H)
R2646	R2846	R3046	R3246	R3446	R3646	R3846	R4046		
R2647	R2847	R3047	R3247	R3447	R3647	R3847	R4047		
R2648	R2848	R3048	R3248	R3448	R3648	R3848	R4048		Circular feed in manual mode Reference point V data (L)
R2649	R2849	R3049	R3249	R3449	R3649	R3849	R4049		Circular feed in manual mode Reference point V data (H)
R2650	R2850	R3050	R3250	R3450	R3650	R3850	R4050		
R2651	R2851	R3051	R3251	R3451	R3651	R3851	R4051		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2652	R2852	R3052	R3252	R3452	R3652	R3852	R4052		Circular feed in manual mode Travel range H (+) data (L)
R2653	R2853	R3053	R3253	R3453	R3653	R3853	R4053		Circular feed in manual mode Travel range H (+) data (H)
R2654	R2854	R3054	R3254	R3454	R3654	R3854	R4054		
R2655	R2855	R3055	R3255	R3455	R3655	R3855	R4055		
R2656	R2856	R3056	R3256	R3456	R3656	R3856	R4056		Circular feed in manual mode Travel range H (-) data (L)
R2657	R2857	R3057	R3257	R3457	R3657	R3857	R4057		Circular feed in manual mode Travel range H (-) data (H)
R2658	R2858	R3058	R3258	R3458	R3658	R3858	R4058		
R2659	R2859	R3059	R3259	R3459	R3659	R3859	R4059		

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2660	R2860	R3060	R3260	R3460	R3660	R3860	R4060		Circular feed in manual mode Travel range V (+) data (L)
R2661	R2861	R3061	R3261	R3461	R3661	R3861	R4061		Circular feed in manual mode Travel range V (+) data (H)
R2662	R2862	R3062	R3262	R3462	R3662	R3862	R4062		
R2663	R2863	R3063	R3263	R3463	R3663	R3863	R4063		
R2664	R2864	R3064	R3264	R3464	R3664	R3864	R4064		Circular feed in manual mode Travel range V (-) data (L)
R2665	R2865	R3065	R3265	R3465	R3665	R3865	R4065		Circular feed in manual mode Travel range V (-) data (H)
R2666	R2866	R3066	R3266	R3466	R3666	R3866	R4066		
R2667	R2867	R3067	R3267	R3467	R3667	R3867	R4067		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2668	R2868	R3068	R3268	R3468	R3668	R3868	R4068		Circular feed in manual mode Gradient/arc center H data (L)
R2669	R2869	R3069	R3269	R3469	R3669	R3869	R4069		Circular feed in manual mode Gradient/arc center H data (H)
R2670	R2870	R3070	R3270	R3470	R3670	R3870	R4070		
R2671	R2871	R3071	R3271	R3471	R3671	R3871	R4071		
R2672	R2872	R3072	R3272	R3472	R3672	R3872	R4072		Circular feed in manual mode Gradient/arc center V data (L)
R2673	R2873	R3073	R3273	R3473	R3673	R3873	R4073		Circular feed in manual mode Gradient/arc center V data (H)
R2674	R2874	R3074	R3274	R3474	R3674	R3874	R4074		
R2675	R2875	R3075	R3275	R3475	R3675	R3875	R4075		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2676	R2876	R3076	R3276	R3476	R3676	R3876	R4076		
R2677	R2877	R3077	R3277	R3477	R3677	R3877	R4077		
R2678	R2878	R3078	R3278	R3478	R3678	R3878	R4078		
R2679	R2879	R3079	R3279	R3479	R3679	R3879	R4079		
R2680	R2880	R3080	R3280	R3480	R3680	R3880	R4080	CAXSVF	Spindle position control (spindle/C axis control): Servo OFF request during Spindle/C axis mode ▲
R2681	R2881	R3081	R3281	R3481	R3681	R3881	R4081	SPGNCO	Spindle position control (spindle/C axis control): Position loop gain switch at C axis mode ▲
R2682	R2882	R3082	R3282	R3482	R3682	R3882	R4082	UAC	U-axis tool control: U-axis tool zero point reaching request ▲
R2683	R2883	R3083	R3283	R3483	R3683	R3883	R4083		
Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R2684	R2884	R3084	R3284	R3484	R3684	R3884	R4084		For specific users NC control signal 1 ▲
R2685	R2885	R3085	R3285	R3485	R3685	R3885	R4085		
R2686	R2886	R3086	R3286	R3486	R3686	R3886	R4086		
R2687	R2887	R3087	R3287	R3487	R3687	R3887	R4087		
R2688	R2888	R3088	R3288	R3488	R3688	R3888	R4088		Specific users Manual skip motion direction (-) ▲
R2689	R2889	R3089	R3289	R3489	R3689	R3889	R4089		Specific users Manual skip motion direction (+) ▲
R2690	R2890	R3090	R3290	R3490	R3690	R3890	R4090		
R2691	R2891	R3091	R3291	R3491	R3691	R3891	R4091		

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R4400		3D Machine Interference Check: Enabled shape group No.1			
R4401		3D Machine Interference Check: Enabled shape group No.2			
R4402		3D Machine Interference Check: Enabled shape group No.3			
R4403		3D Machine Interference Check: Enabled shape group No.4			
R4404					
R4405					
R4406					
R4407					

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5700	R5716	R5732	R5748		Ext. machine coordinate system offset data 1st axis (L) [M]
R5701	R5717	R5733	R5749		Ext. machine coordinate system offset data 1st axis (H) [M]
R5702	R5718	R5734	R5750		Ext. machine coordinate system offset data 2nd axis (L) [M]
R5703	R5719	R5735	R5751		Ext. machine coordinate system offset data 2nd axis (H) [M]
R5704	R5720	R5736	R5752		Ext. machine coordinate system offset data 3rd axis (L) [M]
R5705	R5721	R5737	R5753		Ext. machine coordinate system offset data 3rd axis (H) [M]
R5706	R5722	R5738	R5754		Ext. machine coordinate system offset data 4th axis (L) [M]
R5707	R5723	R5739	R5755		Ext. machine coordinate system offset data 4th axis (H) [M]
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5708	R5724	R5740	R5756		Ext. machine coordinate system offset data 5th axis (L) [M]
R5709	R5725	R5741	R5757		Ext. machine coordinate system offset data 5th axis (H) [M]
R5710	R5726	R5742	R5758		Ext. machine coordinate system offset data 6th axis (L) [M]
R5711	R5727	R5743	R5759		Ext. machine coordinate system offset data 6th axis (H) [M]
R5712	R5728	R5744	R5760		Ext. machine coordinate system offset data 7th axis (L) [M]
R5713	R5729	R5745	R5761		Ext. machine coordinate system offset data 7th axis (H) [M]
R5714	R5730	R5746	R5762		Ext. machine coordinate system offset data 8th axis (L) [M]
R5715	R5731	R5747	R5763		Ext. machine coordinate system offset data 8th axis (H) [M]
Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5764	R5780	R5796	R5812		Each axis manual feedrate B 1st axis (L) [M]
R5765	R5781	R5797	R5813		Each axis manual feedrate B 1st axis (H) [M]
R5766	R5782	R5798	R5814		Each axis manual feedrate B 2nd axis (L) [M]
R5767	R5783	R5799	R5815		Each axis manual feedrate B 2nd axis (H) [M]
R5768	R5784	R5800	R5816		Each axis manual feedrate B 3rd axis (L) [M]
R5769	R5785	R5801	R5817		Each axis manual feedrate B 3rd axis (H) [M]
R5770	R5786	R5802	R5818		Each axis manual feedrate B 4th axis (L) [M]
R5771	R5787	R5803	R5819		Each axis manual feedrate B 4th axis (H) [M]

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5772	R5788	R5804	R5820		Each axis manual feedrate B 5th axis (L) [M]
R5773	R5789	R5805	R5821		Each axis manual feedrate B 5th axis (H) [M]
R5774	R5790	R5806	R5822		Each axis manual feedrate B 6th axis (L) [M]
R5775	R5791	R5807	R5823		Each axis manual feedrate B 6th axis (H) [M]
R5776	R5792	R5808	R5824		Each axis manual feedrate B 7th axis (L) [M]
R5777	R5793	R5809	R5825		Each axis manual feedrate B 7th axis (H) [M]
R5778	R5794	R5810	R5826		Each axis manual feedrate B 8th axis (L) [M]
R5779	R5795	R5811	R5827		Each axis manual feedrate B 8th axis (H) [M]

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5828	R5836	R5844	R5852		
R5829	R5837	R5845	R5853		
R5830	R5838	R5846	R5854		
R5831	R5839	R5847	R5855		
R5832	R5840	R5848	R5856		
R5833	R5841	R5849	R5857		
R5834	R5842	R5850	R5858		
R5835	R5843	R5851	R5859		

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5860	R5868	R5876	R5884		
R5861	R5869	R5877	R5885		
R5862	R5870	R5878	R5886		
R5863	R5871	R5879	R5887		
R5864	R5872	R5880	R5888		
R5865	R5873	R5881	R5889		
R5866	R5874	R5882	R5890		
R5867	R5875	R5883	R5891		

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5892	R5900	R5908	R5916		
R5893	R5901	R5909	R5917		
R5894	R5902	R5910	R5918		
R5895	R5903	R5911	R5919		
R5896	R5904	R5912	R5920		
R5897	R5905	R5913	R5921		
R5898	R5906	R5914	R5922		
R5899	R5907	R5915	R5923		

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R5924	R5940	R5956	R5972	CRSAX1	Mixed control (cross axis control): Target axis (1st axis) ▲
R5925	R5941	R5957	R5973	CRSAX2	Mixed control (cross axis control): Target axis (2nd axis) ▲
R5926	R5942	R5958	R5974	CRSAX3	Mixed control (cross axis control): Target axis (3rd axis) ▲
R5927	R5943	R5959	R5975	CRSAX4	Mixed control (cross axis control): Target axis (4th axis) ▲
R5928	R5944	R5960	R5976	CRSAX5	Mixed control (cross axis control): Target axis (5th axis) ▲
R5929	R5945	R5961	R5977	CRSAX6	Mixed control (cross axis control): Target axis (6th axis) ▲
R5930	R5946	R5962	R5978	CRSAX7	Mixed control (cross axis control): Target axis (7th axis) ▲
R5931	R5947	R5963	R5979	CRSAX8	Mixed control (cross axis control): Target axis (8th axis) ▲

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R6052	R6060	R6068	R6076		
R6053	R6061	R6069	R6077		
R6054	R6062	R6070	R6078		
R6055	R6063	R6071	R6079		
R6056	R6064	R6072	R6080		
R6057	R6065	R6073	R6081		
R6058	R6066	R6074	R6082		
R6059	R6067	R6075	R6083		

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R6084	R6092	R6100	R6108		Optimum acceleration/deceleration: Parameter group selection 1st axis ▲
R6085	R6093	R6101	R6109		Optimum acceleration/deceleration: Parameter group selection 2nd axis ▲
R6086	R6094	R6102	R6110		Optimum acceleration/deceleration: Parameter group selection 3rd axis ▲
R6087	R6095	R6103	R6111		Optimum acceleration/deceleration: Parameter group selection 4th axis ▲
R6088	R6096	R6104	R6112		Optimum acceleration/deceleration: Parameter group selection 5th axis ▲
R6089	R6097	R6105	R6113		Optimum acceleration/deceleration: Parameter group selection 6th axis ▲
R6090	R6098	R6106	R6114		Optimum acceleration/deceleration: Parameter group selection 7th axis ▲
R6091	R6099	R6107	R6115		Optimum acceleration/deceleration: Parameter group selection 8th axis ▲

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R6116	R6124	R6132	R6140		Target machining time 1st axis ▲
R6117	R6125	R6133	R6141		Target machining time 2nd axis ▲
R6118	R6126	R6134	R6142		Target machining time 3rd axis ▲
R6119	R6127	R6135	R6143		Target machining time 4th axis ▲
R6120	R6128	R6136	R6144		Target machining time 5th axis ▲
R6121	R6129	R6137	R6145		Target machining time 6th axis ▲
R6122	R6130	R6138	R6146		Target machining time 7th axis ▲
R6123	R6131	R6139	R6147		Target machining time 8th axis ▲

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R6436	R6444	R6452	R6460	R6468	R6476	R6484	R6492		User macro input #1032 (PLC -> NC) (L)
R6437	R6445	R6453	R6461	R6469	R6477	R6485	R6493		User macro input #1032 (PLC -> NC) (H)
R6438	R6446	R6454	R6462	R6470	R6478	R6486	R6494		User macro input #1033 (PLC -> NC) (L)
R6439	R6447	R6455	R6463	R6471	R6479	R6487	R6495		User macro input #1033 (PLC -> NC) (H)
R6440	R6448	R6456	R6464	R6472	R6480	R6488	R6496		User macro input #1034 (PLC -> NC) (L)
R6441	R6449	R6457	R6465	R6473	R6481	R6489	R6497		User macro input #1034 (PLC -> NC) (H)
R6442	R6450	R6458	R6466	R6474	R6482	R6490	R6498		User macro input #1035 (PLC -> NC) (L)
R6443	R6451	R6459	R6467	R6475	R6483	R6491	R6499		User macro input #1035 (PLC -> NC) (H)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
R7000	R7050	R7100	R7150	R7200	R7250	R7300	R7350		Spindle command rotation speed output (L)
R7001	R7051	R7101	R7151	R7201	R7251	R7301	R7351		Spindle command rotation speed output (H)
R7002	R7052	R7102	R7152	R7202	R7252	R7302	R7352	SLSP	Spindle command selection
R7003	R7053	R7103	R7153	R7203	R7253	R7303	R7353		Optimum acceleration/deceleration parameter group selection [spindle] ▲
R7004	R7054	R7104	R7154	R7204	R7254	R7304	R7354		Spindle target machining time ▲
R7005	R7055	R7105	R7155	R7205	R7255	R7305	R7355		
R7006	R7056	R7106	R7156	R7206	R7256	R7306	R7356		
R7007	R7057	R7107	R7157	R7207	R7257	R7307	R7357		
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
R7008	R7058	R7108	R7158	R7208	R7258	R7308	R7358		S command override
R7009	R7059	R7109	R7159	R7209	R7259	R7309	R7359		Multi-point orientation position data
R7010	R7060	R7110	R7160	R7210	R7260	R7310	R7360	ORDIR	Orientation rotation direction ▲
R7011	R7061	R7111	R7161	R7211	R7261	R7311	R7361		
R7012	R7062	R7112	R7162	R7212	R7262	R7312	R7362	ANSLD	Interface of load meter for analog I/F spindle
R7013	R7063	R7113	R7163	R7213	R7263	R7313	R7363		
R7014	R7064	R7114	R7164	R7214	R7264	R7314	R7364		
R7015	R7065	R7115	R7165	R7215	R7265	R7315	R7365		
Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
R7016	R7066	R7116	R7166	R7216	R7266	R7316	R7366		Spindle synchronization: Reference spindle selection
R7017	R7067	R7117	R7167	R7217	R7267	R7317	R7367		Spindle synchronization: Synchronized spindle selection
R7018	R7068	R7118	R7168	R7218	R7268	R7318	R7368		Spindle synchronization: Phase shift amount
R7019	R7069	R7119	R7169	R7219	R7269	R7319	R7369		Spindle synchronization: Phase error tolerance
R7020	R7070	R7120	R7170	R7220	R7270	R7320	R7370		Spindle oscillation amplitude
R7021	R7071	R7121	R7171	R7221	R7271	R7321	R7371		Spindle oscillation frequency
R7022	R7072	R7122	R7172	R7222	R7272	R7322	R7372	SPFLAMP	SPFL: Amplitude ▲
R7023	R7073	R7123	R7173	R7223	R7273	R7323	R7373	SPFLCYC	SPFL: Cycle ▲

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10600		ATC control parameter	R10608		
R10601			R10609		
R10602			R10610		No.1 magazine number of magazines designation
R10603		Display tool selection parameter	R10611		No.2 magazine number of magazines designation
R10604		AUX data	R10612		No.3 magazine number of magazines designation
R10605			R10613		No.4 magazine number of magazines designation
R10606			R10614		No.5 magazine number of magazines designation
R10607			R10615		No.1 magazine pointer designation

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10616		No.2 magazine pointer designation	R10624		No.1 magazine standby 4 tool (T4-digit)/No.1 magazine standby 2 tool (T8-digit)
R10617		No.3 magazine pointer designation	R10625		No.1 magazine standby 2 tool (T8-digit)
R10618		No.4 magazine pointer designation	R10626		No.1 magazine standby 3 tool (T8-digit)
R10619		No.5 magazine pointer designation	R10627		No.1 magazine standby 3 tool (T8-digit)
R10620		No.1 magazine spindle tool	R10628		No.1 magazine standby 4 tool (T8-digit)
R10621		No.1 magazine standby 1 tool (T4-digit)/No.1 magazine spindle tool (T8-digit)	R10629		No.1 magazine standby 4 tool (T8-digit)
R10622		No.1 magazine standby 2 tool (T4-digit)/No.1 magazine standby 1 tool (T8-digit)	R10630		No.2 magazine spindle tool
R10623		No.1 magazine standby 3 tool (T4-digit)/No.1 magazine standby 1 tool (T8-digit)	R10631		No.2 magazine standby 1 tool (T4-digit)/No.2 magazine spindle tool (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10632		No.2 magazine standby 2 tool (T4-digit)/No.2 magazine standby 1 tool (T8-digit)	R10640		No.3 magazine spindle tool
R10633		No.2 magazine standby 3 tool (T4-digit)/No.2 magazine standby 1 tool (T8-digit)	R10641		No.3 magazine standby 1 tool (T4-digit)/No.3 magazine spindle tool (T8-digit)
R10634		No.2 magazine standby 4 tool (T4-digit)/No.2 magazine standby 2 tool (T8-digit)	R10642		No.3 magazine standby 2 tool (T4-digit)/No.3 magazine standby 1 tool (T8-digit)
R10635		No.2 magazine standby 2 tool (T8-digit)	R10643		No.3 magazine standby 3 tool (T4-digit)/No.3 magazine standby 1 tool (T8-digit)
R10636		No.2 magazine standby 3 tool (T8-digit)	R10644		No.3 magazine standby 4 tool (T4-digit)/No.3 magazine standby 2 tool (T8-digit)
R10637		No.2 magazine standby 3 tool (T8-digit)	R10645		No.3 magazine standby 2 tool (T8-digit)
R10638		No.2 magazine standby 4 tool (T8-digit)	R10646		No.3 magazine standby 3 tool (T8-digit)
R10639		No.2 magazine standby 4 tool (T8-digit)	R10647		No.3 magazine standby 3 tool (T8-digit)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10648		No.3 magazine standby 4 tool (T8-digit)	R10656		No.4 magazine standby 3 tool (T8-digit)
R10649		No.3 magazine standby 4 tool (T8-digit)	R10657		No.4 magazine standby 3 tool (T8-digit)
R10650		No.4 magazine spindle tool	R10658		No.4 magazine standby 4 tool (T8-digit)
R10651		No.4 magazine standby 1 tool (T4-digit)/No.4 magazine spindle tool (T8-digit)	R10659		No.4 magazine standby 4 tool (T8-digit)
R10652		No.4 magazine standby 2 tool (T4-digit)/No.4 magazine standby 1 tool (T8-digit)	R10660		No.5 magazine spindle tool
R10653		No.4 magazine standby 3 tool (T4-digit)/No.4 magazine standby 1 tool (T8-digit)	R10661		No.5 magazine standby 1 tool (T4-digit)/No.5 magazine spindle tool (T8-digit)
R10654		No.4 magazine standby 4 tool (T4-digit)/No.4 magazine standby 2 tool (T8-digit)	R10662		No.5 magazine standby 2 tool (T4-digit)/No.5 magazine standby 1 tool (T8-digit)
R10655		No.4 magazine standby 2 tool (T8-digit)	R10663		No.5 magazine standby 3 tool (T4-digit)/No.5 magazine standby 1 tool (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10664		No.5 magazine standby 4 tool (T4-digit)/No.5 magazine standby 2 tool (T8-digit)	R10672		No.1 magazine standby 2 tool D
R10665		No.5 magazine standby 2 tool (T8-digit)	R10673		No.1 magazine standby 3 tool D
R10666		No.5 magazine standby 3 tool (T8-digit)	R10674		No.1 magazine standby 4 tool D
R10667		No.5 magazine standby 3 tool (T8-digit)	R10675		No.2 magazine spindle tool D
R10668		No.5 magazine standby 4 tool (T8-digit)	R10676		No.2 magazine standby 1 tool D
R10669		No.5 magazine standby 4 tool (T8-digit)	R10677		No.2 magazine standby 2 tool D
R10670		No.1 magazine spindle tool D	R10678		No.2 magazine standby 3 tool D
R10671		No.1 magazine standby 1 tool D	R10679		No.2 magazine standby 4 tool D

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10680		No.3 magazine spindle tool D	R10688		No.4 magazine standby 3 tool D
R10681		No.3 magazine standby 1 tool D	R10689		No.4 magazine standby 4 tool D
R10682		No.3 magazine standby 2 tool D	R10690		No.5 magazine spindle tool D
R10683		No.3 magazine standby 3 tool D	R10691		No.5 magazine standby 1 tool D
R10684		No.3 magazine standby 4 tool D	R10692		No.5 magazine standby 2 tool D
R10685		No.4 magazine spindle tool D	R10693		No.5 magazine standby 3 tool D
R10686		No.4 magazine standby 1 tool D	R10694		No.5 magazine standby 4 tool D
R10687		No.4 magazine standby 2 tool D	R10695		No.1 magazine pot head No.

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10696		No.2 magazine pot head No.	R10704		No.1 magazine tool data pot 5 (T4-digit)/pot 3 (T8-digit)
R10697		No.3 magazine pot head No.	R10705		No.1 magazine tool data pot 6 (T4-digit)/pot 3 (T8-digit)
R10698		No.4 magazine pot head No.	R10706		No.1 magazine tool data pot 7 (T4-digit)/pot 4 (T8-digit)
R10699		No.5 magazine pot head No.	R10707		No.1 magazine tool data pot 8 (T4-digit)/pot 4 (T8-digit)
R10700		No.1 magazine tool data pot 1	R10708		No.1 magazine tool data pot 9 (T4-digit)/pot 5 (T8-digit)
R10701		No.1 magazine tool data pot 2 (T4-digit)/pot 1 (T8-digit)	R10709		No.1 magazine tool data pot 10 (T4-digit)/pot 5 (T8-digit)
R10702		No.1 magazine tool data pot 3 (T4-digit)/pot 2 (T8-digit)	R10710		No.1 magazine tool data pot 11 (T4-digit)/pot 6 (T8-digit)
R10703		No.1 magazine tool data pot 4 (T4-digit)/pot 2 (T8-digit)	R10711		No.1 magazine tool data pot 12 (T4-digit)/pot 6 (T8-digit)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10712		No.1 magazine tool data pot 13 (T4-digit)/pot 7 (T8-digit)	R10720		No.1 magazine tool data pot 21 (T4-digit)/pot 11 (T8-digit)
R10713		No.1 magazine tool data pot 14 (T4-digit)/pot 7 (T8-digit)	R10721		No.1 magazine tool data pot 22 (T4-digit)/pot 11 (T8-digit)
R10714		No.1 magazine tool data pot 15 (T4-digit)/pot 8 (T8-digit)	R10722		No.1 magazine tool data pot 23 (T4-digit)/pot 12 (T8-digit)
R10715		No.1 magazine tool data pot 16 (T4-digit)/pot 8 (T8-digit)	R10723		No.1 magazine tool data pot 24 (T4-digit)/pot 12 (T8-digit)
R10716		No.1 magazine tool data pot 17 (T4-digit)/pot 9 (T8-digit)	R10724		No.1 magazine tool data pot 25 (T4-digit)/pot 13 (T8-digit)
R10717		No.1 magazine tool data pot 18 (T4-digit)/pot 9 (T8-digit)	R10725		No.1 magazine tool data pot 26 (T4-digit)/pot 13 (T8-digit)
R10718		No.1 magazine tool data pot 19 (T4-digit)/pot 10 (T8-digit)	R10726		No.1 magazine tool data pot 27 (T4-digit)/pot 14 (T8-digit)
R10719		No.1 magazine tool data pot 20 (T4-digit)/pot 10 (T8-digit)	R10727		No.1 magazine tool data pot 28 (T4-digit)/pot 14 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10728		No.1 magazine tool data pot 29 (T4-digit)/pot 15 (T8-digit)	R10736		No.1 magazine tool data pot 37 (T4-digit)/pot 19 (T8-digit)
R10729		No.1 magazine tool data pot 30 (T4-digit)/pot 15 (T8-digit)	R10737		No.1 magazine tool data pot 38 (T4-digit)/pot 19 (T8-digit)
R10730		No.1 magazine tool data pot 31 (T4-digit)/pot 16 (T8-digit)	R10738		No.1 magazine tool data pot 39 (T4-digit)/pot 20 (T8-digit)
R10731		No.1 magazine tool data pot 32 (T4-digit)/pot 16 (T8-digit)	R10739		No.1 magazine tool data pot 40 (T4-digit)/pot 20 (T8-digit)
R10732		No.1 magazine tool data pot 33 (T4-digit)/pot 17 (T8-digit)	R10740		No.1 magazine tool data pot 41 (T4-digit)/pot 21 (T8-digit)
R10733		No.1 magazine tool data pot 34 (T4-digit)/pot 17 (T8-digit)	R10741		No.1 magazine tool data pot 42 (T4-digit)/pot 21 (T8-digit)
R10734		No.1 magazine tool data pot 35 (T4-digit)/pot 18 (T8-digit)	R10742		No.1 magazine tool data pot 43 (T4-digit)/pot 22 (T8-digit)
R10735		No.1 magazine tool data pot 36 (T4-digit)/pot 18 (T8-digit)	R10743		No.1 magazine tool data pot 44 (T4-digit)/pot 22 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10744		No.1 magazine tool data pot 45 (T4-digit)/pot 23 (T8-digit)	R10752		No.1 magazine tool data pot 53 (T4-digit)/pot 27 (T8-digit)
R10745		No.1 magazine tool data pot 46 (T4-digit)/pot 23 (T8-digit)	R10753		No.1 magazine tool data pot 54 (T4-digit)/pot 27 (T8-digit)
R10746		No.1 magazine tool data pot 47 (T4-digit)/pot 24 (T8-digit)	R10754		No.1 magazine tool data pot 55 (T4-digit)/pot 28 (T8-digit)
R10747		No.1 magazine tool data pot 48 (T4-digit)/pot 24 (T8-digit)	R10755		No.1 magazine tool data pot 56 (T4-digit)/pot 28 (T8-digit)
R10748		No.1 magazine tool data pot 49 (T4-digit)/pot 25 (T8-digit)	R10756		No.1 magazine tool data pot 57 (T4-digit)/pot 29 (T8-digit)
R10749		No.1 magazine tool data pot 50 (T4-digit)/pot 25 (T8-digit)	R10757		No.1 magazine tool data pot 58 (T4-digit)/pot 29 (T8-digit)
R10750		No.1 magazine tool data pot 51 (T4-digit)/pot 26 (T8-digit)	R10758		No.1 magazine tool data pot 59 (T4-digit)/pot 30 (T8-digit)
R10751		No.1 magazine tool data pot 52 (T4-digit)/pot 26 (T8-digit)	R10759		No.1 magazine tool data pot 60 (T4-digit)/pot 30 (T8-digit)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10760		No.1 magazine tool data pot 61 (T4-digit)/pot 31 (T8-digit)	R10768		No.1 magazine tool data pot 69 (T4-digit)/pot 35 (T8-digit)
R10761		No.1 magazine tool data pot 62 (T4-digit)/pot 31 (T8-digit)	R10769		No.1 magazine tool data pot 70 (T4-digit)/pot 35 (T8-digit)
R10762		No.1 magazine tool data pot 63 (T4-digit)/pot 32 (T8-digit)	R10770		No.1 magazine tool data pot 71 (T4-digit)/pot 36 (T8-digit)
R10763		No.1 magazine tool data pot 64 (T4-digit)/pot 32 (T8-digit)	R10771		No.1 magazine tool data pot 72 (T4-digit)/pot 36 (T8-digit)
R10764		No.1 magazine tool data pot 65 (T4-digit)/pot 33 (T8-digit)	R10772		No.1 magazine tool data pot 73 (T4-digit)/pot 37 (T8-digit)
R10765		No.1 magazine tool data pot 66 (T4-digit)/pot 33 (T8-digit)	R10773		No.1 magazine tool data pot 74 (T4-digit)/pot 37 (T8-digit)
R10766		No.1 magazine tool data pot 67 (T4-digit)/pot 34 (T8-digit)	R10774		No.1 magazine tool data pot 75 (T4-digit)/pot 38 (T8-digit)
R10767		No.1 magazine tool data pot 68 (T4-digit)/pot 34 (T8-digit)	R10775		No.1 magazine tool data pot 76 (T4-digit)/pot 38 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10776		No.1 magazine tool data pot 77 (T4-digit)/pot 39 (T8-digit)	R10784		No.1 magazine tool data pot 85 (T4-digit)/pot 43 (T8-digit)
R10777		No.1 magazine tool data pot 78 (T4-digit)/pot 39 (T8-digit)	R10785		No.1 magazine tool data pot 86 (T4-digit)/pot 43 (T8-digit)
R10778		No.1 magazine tool data pot 79 (T4-digit)/pot 40 (T8-digit)	R10786		No.1 magazine tool data pot 87 (T4-digit)/pot 44 (T8-digit)
R10779		No.1 magazine tool data pot 80 (T4-digit)/pot 40 (T8-digit)	R10787		No.1 magazine tool data pot 88 (T4-digit)/pot 44 (T8-digit)
R10780		No.1 magazine tool data pot 81 (T4-digit)/pot 41 (T8-digit)	R10788		No.1 magazine tool data pot 89 (T4-digit)/pot 45 (T8-digit)
R10781		No.1 magazine tool data pot 82 (T4-digit)/pot 41 (T8-digit)	R10789		No.1 magazine tool data pot 90 (T4-digit)/pot 45 (T8-digit)
R10782		No.1 magazine tool data pot 83 (T4-digit)/pot 42 (T8-digit)	R10790		No.1 magazine tool data pot 91 (T4-digit)/pot 46 (T8-digit)
R10783		No.1 magazine tool data pot 84 (T4-digit)/pot 42 (T8-digit)	R10791		No.1 magazine tool data pot 92 (T4-digit)/pot 46 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10792		No.1 magazine tool data pot 93 (T4-digit)/pot 47 (T8-digit)	R10800		No.1 magazine tool data pot 101 (T4-digit)/pot 51 (T8-digit)
R10793		No.1 magazine tool data pot 94 (T4-digit)/pot 47 (T8-digit)	R10801		No.1 magazine tool data pot 102 (T4-digit)/pot 51 (T8-digit)
R10794		No.1 magazine tool data pot 95 (T4-digit)/pot 48 (T8-digit)	R10802		No.1 magazine tool data pot 103 (T4-digit)/pot 52 (T8-digit)
R10795		No.1 magazine tool data pot 96 (T4-digit)/pot 48 (T8-digit)	R10803		No.1 magazine tool data pot 104 (T4-digit)/pot 52 (T8-digit)
R10796		No.1 magazine tool data pot 97 (T4-digit)/pot 49 (T8-digit)	R10804		No.1 magazine tool data pot 105 (T4-digit)/pot 53 (T8-digit)
R10797		No.1 magazine tool data pot 98 (T4-digit)/pot 49 (T8-digit)	R10805		No.1 magazine tool data pot 106 (T4-digit)/pot 53 (T8-digit)
R10798		No.1 magazine tool data pot 99 (T4-digit)/pot 50 (T8-digit)	R10806		No.1 magazine tool data pot 107 (T4-digit)/pot 54 (T8-digit)
R10799		No.1 magazine tool data pot 100 (T4-digit)/pot 50 (T8-digit)	R10807		No.1 magazine tool data pot 108 (T4-digit)/pot 54 (T8-digit)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10808		No.1 magazine tool data pot 109 (T4-digit)/pot 55 (T8-digit)	R10816		No.1 magazine tool data pot 117 (T4-digit)/pot 59 (T8-digit)
R10809		No.1 magazine tool data pot 110 (T4-digit)/pot 55 (T8-digit)	R10817		No.1 magazine tool data pot 118 (T4-digit)/pot 59 (T8-digit)
R10810		No.1 magazine tool data pot 111 (T4-digit)/pot 56 (T8-digit)	R10818		No.1 magazine tool data pot 119 (T4-digit)/pot 60 (T8-digit)
R10811		No.1 magazine tool data pot 112 (T4-digit)/pot 56 (T8-digit)	R10819		No.1 magazine tool data pot 120 (T4-digit)/pot 60 (T8-digit)
R10812		No.1 magazine tool data pot 113 (T4-digit)/pot 57 (T8-digit)	R10820		No.1 magazine tool data pot 61 (T8-digit)
R10813		No.1 magazine tool data pot 114 (T4-digit)/pot 57 (T8-digit)	R10821		No.1 magazine tool data pot 61 (T8-digit)
R10814		No.1 magazine tool data pot 115 (T4-digit)/pot 58 (T8-digit)	R10822		No.1 magazine tool data pot 62 (T8-digit)
R10815		No.1 magazine tool data pot 116 (T4-digit)/pot 58 (T8-digit)	R10823		No.1 magazine tool data pot 62 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10824		No.1 magazine tool data pot 63 (T8-digit)	R10832		No.1 magazine tool data pot 67 (T8-digit)
R10825		No.1 magazine tool data pot 63 (T8-digit)	R10833		No.1 magazine tool data pot 67 (T8-digit)
R10826		No.1 magazine tool data pot 64 (T8-digit)	R10834		No.1 magazine tool data pot 68 (T8-digit)
R10827		No.1 magazine tool data pot 64 (T8-digit)	R10835		No.1 magazine tool data pot 68 (T8-digit)
R10828		No.1 magazine tool data pot 65 (T8-digit)	R10836		No.1 magazine tool data pot 69 (T8-digit)
R10829		No.1 magazine tool data pot 65 (T8-digit)	R10837		No.1 magazine tool data pot 69 (T8-digit)
R10830		No.1 magazine tool data pot 66 (T8-digit)	R10838		No.1 magazine tool data pot 70 (T8-digit)
R10831		No.1 magazine tool data pot 66 (T8-digit)	R10839		No.1 magazine tool data pot 70 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10840		No.1 magazine tool data pot 71 (T8-digit)	R10848		No.1 magazine tool data pot 75 (T8-digit)
R10841		No.1 magazine tool data pot 71 (T8-digit)	R10849		No.1 magazine tool data pot 75 (T8-digit)
R10842		No.1 magazine tool data pot 72 (T8-digit)	R10850		No.1 magazine tool data pot 76 (T8-digit)
R10843		No.1 magazine tool data pot 72 (T8-digit)	R10851		No.1 magazine tool data pot 76 (T8-digit)
R10844		No.1 magazine tool data pot 73 (T8-digit)	R10852		No.1 magazine tool data pot 77 (T8-digit)
R10845		No.1 magazine tool data pot 73 (T8-digit)	R10853		No.1 magazine tool data pot 77 (T8-digit)
R10846		No.1 magazine tool data pot 74 (T8-digit)	R10854		No.1 magazine tool data pot 78 (T8-digit)
R10847		No.1 magazine tool data pot 74 (T8-digit)	R10855		No.1 magazine tool data pot 78 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10856		No.1 magazine tool data pot 79 (T8-digit)	R10864		No.1 magazine tool data pot 83 (T8-digit)
R10857		No.1 magazine tool data pot 79 (T8-digit)	R10865		No.1 magazine tool data pot 83 (T8-digit)
R10858		No.1 magazine tool data pot 80 (T8-digit)	R10866		No.1 magazine tool data pot 84 (T8-digit)
R10859		No.1 magazine tool data pot 80 (T8-digit)	R10867		No.1 magazine tool data pot 84 (T8-digit)
R10860		No.1 magazine tool data pot 81 (T8-digit)	R10868		No.1 magazine tool data pot 85 (T8-digit)
R10861		No.1 magazine tool data pot 81 (T8-digit)	R10869		No.1 magazine tool data pot 85 (T8-digit)
R10862		No.1 magazine tool data pot 82 (T8-digit)	R10870		No.1 magazine tool data pot 86 (T8-digit)
R10863		No.1 magazine tool data pot 82 (T8-digit)	R10871		No.1 magazine tool data pot 86 (T8-digit)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10872		No.1 magazine tool data pot 87 (T8-digit)	R10880		No.1 magazine tool data pot 91 (T8-digit)
R10873		No.1 magazine tool data pot 87 (T8-digit)	R10881		No.1 magazine tool data pot 91 (T8-digit)
R10874		No.1 magazine tool data pot 88 (T8-digit)	R10882		No.1 magazine tool data pot 92 (T8-digit)
R10875		No.1 magazine tool data pot 88 (T8-digit)	R10883		No.1 magazine tool data pot 92 (T8-digit)
R10876		No.1 magazine tool data pot 89 (T8-digit)	R10884		No.1 magazine tool data pot 93 (T8-digit)
R10877		No.1 magazine tool data pot 89 (T8-digit)	R10885		No.1 magazine tool data pot 93 (T8-digit)
R10878		No.1 magazine tool data pot 90 (T8-digit)	R10886		No.1 magazine tool data pot 94 (T8-digit)
R10879		No.1 magazine tool data pot 90 (T8-digit)	R10887		No.1 magazine tool data pot 94 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10888		No.1 magazine tool data pot 95 (T8-digit)	R10896		No.1 magazine tool data pot 99 (T8-digit)
R10889		No.1 magazine tool data pot 95 (T8-digit)	R10897		No.1 magazine tool data pot 99 (T8-digit)
R10890		No.1 magazine tool data pot 96 (T8-digit)	R10898		No.1 magazine tool data pot 100 (T8-digit)
R10891		No.1 magazine tool data pot 96 (T8-digit)	R10899		No.1 magazine tool data pot 100 (T8-digit)
R10892		No.1 magazine tool data pot 97 (T8-digit)	R10900		No.1 magazine tool data pot 101 (T8-digit)
R10893		No.1 magazine tool data pot 97 (T8-digit)	R10901		No.1 magazine tool data pot 101 (T8-digit)
R10894		No.1 magazine tool data pot 98 (T8-digit)	R10902		No.1 magazine tool data pot 102 (T8-digit)
R10895		No.1 magazine tool data pot 98 (T8-digit)	R10903		No.1 magazine tool data pot 102 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10904		No.1 magazine tool data pot 103 (T8-digit)	R10912		No.1 magazine tool data pot 107 (T8-digit)
R10905		No.1 magazine tool data pot 103 (T8-digit)	R10913		No.1 magazine tool data pot 107 (T8-digit)
R10906		No.1 magazine tool data pot 104 (T8-digit)	R10914		No.1 magazine tool data pot 108 (T8-digit)
R10907		No.1 magazine tool data pot 104 (T8-digit)	R10915		No.1 magazine tool data pot 108 (T8-digit)
R10908		No.1 magazine tool data pot 105 (T8-digit)	R10916		No.1 magazine tool data pot 109 (T8-digit)
R10909		No.1 magazine tool data pot 105 (T8-digit)	R10917		No.1 magazine tool data pot 109 (T8-digit)
R10910		No.1 magazine tool data pot 106 (T8-digit)	R10918		No.1 magazine tool data pot 110 (T8-digit)
R10911		No.1 magazine tool data pot 106 (T8-digit)	R10919		No.1 magazine tool data pot 110 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10920		No.1 magazine tool data pot 111 (T8-digit)	R10928		No.1 magazine tool data pot 115 (T8-digit)
R10921		No.1 magazine tool data pot 111 (T8-digit)	R10929		No.1 magazine tool data pot 115 (T8-digit)
R10922		No.1 magazine tool data pot 112 (T8-digit)	R10930		No.1 magazine tool data pot 116 (T8-digit)
R10923		No.1 magazine tool data pot 112 (T8-digit)	R10931		No.1 magazine tool data pot 116 (T8-digit)
R10924		No.1 magazine tool data pot 113 (T8-digit)	R10932		No.1 magazine tool data pot 117 (T8-digit)
R10925		No.1 magazine tool data pot 113 (T8-digit)	R10933		No.1 magazine tool data pot 117 (T8-digit)
R10926		No.1 magazine tool data pot 114 (T8-digit)	R10934		No.1 magazine tool data pot 118 (T8-digit)
R10927		No.1 magazine tool data pot 114 (T8-digit)	R10935		No.1 magazine tool data pot 118 (T8-digit)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10936		No.1 magazine tool data pot 119 (T8-digit)	R10944		No.1 magazine tool data (Aux.D) pot 5
R10937		No.1 magazine tool data pot 119 (T8-digit)	R10945		No.1 magazine tool data (Aux.D) pot 6
R10938		No.1 magazine tool data pot 120 (T8-digit)	R10946		No.1 magazine tool data (Aux.D) pot 7
R10939		No.1 magazine tool data pot 120 (T8-digit)	R10947		No.1 magazine tool data (Aux.D) pot 8
R10940		No.1 magazine tool data (Aux.D) pot 1	R10948		No.1 magazine tool data (Aux.D) pot 9
R10941		No.1 magazine tool data (Aux.D) pot 2	R10949		No.1 magazine tool data (Aux.D) pot 10
R10942		No.1 magazine tool data (Aux.D) pot 3	R10950		No.1 magazine tool data (Aux.D) pot 11
R10943		No.1 magazine tool data (Aux.D) pot 4	R10951		No.1 magazine tool data (Aux.D) pot 12

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10952		No.1 magazine tool data (Aux.D) pot 13	R10960		No.1 magazine tool data (Aux.D) pot 21
R10953		No.1 magazine tool data (Aux.D) pot 14	R10961		No.1 magazine tool data (Aux.D) pot 22
R10954		No.1 magazine tool data (Aux.D) pot 15	R10962		No.1 magazine tool data (Aux.D) pot 23
R10955		No.1 magazine tool data (Aux.D) pot 16	R10963		No.1 magazine tool data (Aux.D) pot 24
R10956		No.1 magazine tool data (Aux.D) pot 17	R10964		No.1 magazine tool data (Aux.D) pot 25
R10957		No.1 magazine tool data (Aux.D) pot 18	R10965		No.1 magazine tool data (Aux.D) pot 26
R10958		No.1 magazine tool data (Aux.D) pot 19	R10966		No.1 magazine tool data (Aux.D) pot 27
R10959		No.1 magazine tool data (Aux.D) pot 20	R10967		No.1 magazine tool data (Aux.D) pot 28

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10968		No.1 magazine tool data (Aux.D) pot 29	R10976		No.1 magazine tool data (Aux.D) pot 37
R10969		No.1 magazine tool data (Aux.D) pot 30	R10977		No.1 magazine tool data (Aux.D) pot 38
R10970		No.1 magazine tool data (Aux.D) pot 31	R10978		No.1 magazine tool data (Aux.D) pot 39
R10971		No.1 magazine tool data (Aux.D) pot 32	R10979		No.1 magazine tool data (Aux.D) pot 40
R10972		No.1 magazine tool data (Aux.D) pot 33	R10980		No.1 magazine tool data (Aux.D) pot 41
R10973		No.1 magazine tool data (Aux.D) pot 34	R10981		No.1 magazine tool data (Aux.D) pot 42
R10974		No.1 magazine tool data (Aux.D) pot 35	R10982		No.1 magazine tool data (Aux.D) pot 43
R10975		No.1 magazine tool data (Aux.D) pot 36	R10983		No.1 magazine tool data (Aux.D) pot 44

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R10984		No.1 magazine tool data (Aux.D) pot 45	R10992		No.1 magazine tool data (Aux.D) pot 53
R10985		No.1 magazine tool data (Aux.D) pot 46	R10993		No.1 magazine tool data (Aux.D) pot 54
R10986		No.1 magazine tool data (Aux.D) pot 47	R10994		No.1 magazine tool data (Aux.D) pot 55
R10987		No.1 magazine tool data (Aux.D) pot 48	R10995		No.1 magazine tool data (Aux.D) pot 56
R10988		No.1 magazine tool data (Aux.D) pot 49	R10996		No.1 magazine tool data (Aux.D) pot 57
R10989		No.1 magazine tool data (Aux.D) pot 50	R10997		No.1 magazine tool data (Aux.D) pot 58
R10990		No.1 magazine tool data (Aux.D) pot 51	R10998		No.1 magazine tool data (Aux.D) pot 59
R10991		No.1 magazine tool data (Aux.D) pot 52	R10999		No.1 magazine tool data (Aux.D) pot 60

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11000		No.1 magazine tool data (Aux.D) pot 61	R11008		No.1 magazine tool data (Aux.D) pot 69
R11001		No.1 magazine tool data (Aux.D) pot 62	R11009		No.1 magazine tool data (Aux.D) pot 70
R11002		No.1 magazine tool data (Aux.D) pot 63	R11010		No.1 magazine tool data (Aux.D) pot 71
R11003		No.1 magazine tool data (Aux.D) pot 64	R11011		No.1 magazine tool data (Aux.D) pot 72
R11004		No.1 magazine tool data (Aux.D) pot 65	R11012		No.1 magazine tool data (Aux.D) pot 73
R11005		No.1 magazine tool data (Aux.D) pot 66	R11013		No.1 magazine tool data (Aux.D) pot 74
R11006		No.1 magazine tool data (Aux.D) pot 67	R11014		No.1 magazine tool data (Aux.D) pot 75
R11007		No.1 magazine tool data (Aux.D) pot 68	R11015		No.1 magazine tool data (Aux.D) pot 76

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11016		No.1 magazine tool data (Aux.D) pot 77	R11024		No.1 magazine tool data (Aux.D) pot 85
R11017		No.1 magazine tool data (Aux.D) pot 78	R11025		No.1 magazine tool data (Aux.D) pot 86
R11018		No.1 magazine tool data (Aux.D) pot 79	R11026		No.1 magazine tool data (Aux.D) pot 87
R11019		No.1 magazine tool data (Aux.D) pot 80	R11027		No.1 magazine tool data (Aux.D) pot 88
R11020		No.1 magazine tool data (Aux.D) pot 81	R11028		No.1 magazine tool data (Aux.D) pot 89
R11021		No.1 magazine tool data (Aux.D) pot 82	R11029		No.1 magazine tool data (Aux.D) pot 90
R11022		No.1 magazine tool data (Aux.D) pot 83	R11030		No.1 magazine tool data (Aux.D) pot 91
R11023		No.1 magazine tool data (Aux.D) pot 84	R11031		No.1 magazine tool data (Aux.D) pot 92

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11032		No.1 magazine tool data (Aux.D) pot 93	R11040		No.1 magazine tool data (Aux.D) pot 101
R11033		No.1 magazine tool data (Aux.D) pot 94	R11041		No.1 magazine tool data (Aux.D) pot 102
R11034		No.1 magazine tool data (Aux.D) pot 95	R11042		No.1 magazine tool data (Aux.D) pot 103
R11035		No.1 magazine tool data (Aux.D) pot 96	R11043		No.1 magazine tool data (Aux.D) pot 104
R11036		No.1 magazine tool data (Aux.D) pot 97	R11044		No.1 magazine tool data (Aux.D) pot 105
R11037		No.1 magazine tool data (Aux.D) pot 98	R11045		No.1 magazine tool data (Aux.D) pot 106
R11038		No.1 magazine tool data (Aux.D) pot 99	R11046		No.1 magazine tool data (Aux.D) pot 107
R11039		No.1 magazine tool data (Aux.D) pot 100	R11047		No.1 magazine tool data (Aux.D) pot 108

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11048		No.1 magazine tool data (Aux.D) pot 109	R11056		No.1 magazine tool data (Aux.D) pot 117
R11049		No.1 magazine tool data (Aux.D) pot 110	R11057		No.1 magazine tool data (Aux.D) pot 118
R11050		No.1 magazine tool data (Aux.D) pot 111	R11058		No.1 magazine tool data (Aux.D) pot 119
R11051		No.1 magazine tool data (Aux.D) pot 112	R11059		No.1 magazine tool data (Aux.D) pot 120
R11052		No.1 magazine tool data (Aux.D) pot 113	R11060		No.2 magazine tool data pot 1
R11053		No.1 magazine tool data (Aux.D) pot 114	R11061		No.2 magazine tool data pot 2 (T4-digit)/pot 1 (T8-digit)
R11054		No.1 magazine tool data (Aux.D) pot 115	R11062		No.2 magazine tool data pot 3 (T4-digit)/pot 2 (T8-digit)
R11055		No.1 magazine tool data (Aux.D) pot 116	R11063		No.2 magazine tool data pot 4 (T4-digit)/pot 2 (T8-digit)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11064		No.2 magazine tool data pot 5 (T4-digit)/pot 3 (T8-digit)	R11072		No.2 magazine tool data pot 13 (T4-digit)/pot 7 (T8-digit)
R11065		No.2 magazine tool data pot 6 (T4-digit)/pot 3 (T8-digit)	R11073		No.2 magazine tool data pot 14 (T4-digit)/pot 7 (T8-digit)
R11066		No.2 magazine tool data pot 7 (T4-digit)/pot 4 (T8-digit)	R11074		No.2 magazine tool data pot 15 (T4-digit)/pot 8 (T8-digit)
R11067		No.2 magazine tool data pot 8 (T4-digit)/pot 4 (T8-digit)	R11075		No.2 magazine tool data pot 16 (T4-digit)/pot 8 (T8-digit)
R11068		No.2 magazine tool data pot 9 (T4-digit)/pot 5 (T8-digit)	R11076		No.2 magazine tool data pot 17 (T4-digit)/pot 9 (T8-digit)
R11069		No.2 magazine tool data pot 10 (T4-digit)/pot 5 (T8-digit)	R11077		No.2 magazine tool data pot 18 (T4-digit)/pot 9 (T8-digit)
R11070		No.2 magazine tool data pot 11 (T4-digit)/pot 6 (T8-digit)	R11078		No.2 magazine tool data pot 19 (T4-digit)/pot 10 (T8-digit)
R11071		No.2 magazine tool data pot 12 (T4-digit)/pot 6 (T8-digit)	R11079		No.2 magazine tool data pot 20 (T4-digit)/pot 10 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11080		No.2 magazine tool data pot 21 (T4-digit)/pot 11 (T8-digit)	R11088		No.2 magazine tool data pot 29 (T4-digit)/pot 15 (T8-digit)
R11081		No.2 magazine tool data pot 22 (T4-digit)/pot 11 (T8-digit)	R11089		No.2 magazine tool data pot 30 (T4-digit)/pot 15 (T8-digit)
R11082		No.2 magazine tool data pot 23 (T4-digit)/pot 12 (T8-digit)	R11090		No.2 magazine tool data pot 31 (T4-digit)/pot 16 (T8-digit)
R11083		No.2 magazine tool data pot 24 (T4-digit)/pot 12 (T8-digit)	R11091		No.2 magazine tool data pot 32 (T4-digit)/pot 16 (T8-digit)
R11084		No.2 magazine tool data pot 25 (T4-digit)/pot 13 (T8-digit)	R11092		No.2 magazine tool data pot 33 (T4-digit)/pot 17 (T8-digit)
R11085		No.2 magazine tool data pot 26 (T4-digit)/pot 13 (T8-digit)	R11093		No.2 magazine tool data pot 34 (T4-digit)/pot 17 (T8-digit)
R11086		No.2 magazine tool data pot 27 (T4-digit)/pot 14 (T8-digit)	R11094		No.2 magazine tool data pot 35 (T4-digit)/pot 18 (T8-digit)
R11087		No.2 magazine tool data pot 28 (T4-digit)/pot 14 (T8-digit)	R11095		No.2 magazine tool data pot 36 (T4-digit)/pot 18 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11096		No.2 magazine tool data pot 37 (T4-digit)/pot 19 (T8-digit)	R11104		No.2 magazine tool data pot 45 (T4-digit)/pot 23 (T8-digit)
R11097		No.2 magazine tool data pot 38 (T4-digit)/pot 19 (T8-digit)	R11105		No.2 magazine tool data pot 46 (T4-digit)/pot 23 (T8-digit)
R11098		No.2 magazine tool data pot 39 (T4-digit)/pot 20 (T8-digit)	R11106		No.2 magazine tool data pot 47 (T4-digit)/pot 24 (T8-digit)
R11099		No.2 magazine tool data pot 40 (T4-digit)/pot 20 (T8-digit)	R11107		No.2 magazine tool data pot 48 (T4-digit)/pot 24 (T8-digit)
R11100		No.2 magazine tool data pot 41 (T4-digit)/pot 21 (T8-digit)	R11108		No.2 magazine tool data pot 49 (T4-digit)/pot 25 (T8-digit)
R11101		No.2 magazine tool data pot 42 (T4-digit)/pot 21 (T8-digit)	R11109		No.2 magazine tool data pot 50 (T4-digit)/pot 25 (T8-digit)
R11102		No.2 magazine tool data pot 43 (T4-digit)/pot 22 (T8-digit)	R11110		No.2 magazine tool data pot 51 (T4-digit)/pot 26 (T8-digit)
R11103		No.2 magazine tool data pot 44 (T4-digit)/pot 22 (T8-digit)	R11111		No.2 magazine tool data pot 52 (T4-digit)/pot 26 (T8-digit)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11112		No.2 magazine tool data pot 53 (T4-digit)/pot 27 (T8-digit)	R11120		No.2 magazine tool data pot 61 (T4-digit)/pot 31 (T8-digit)
R11113		No.2 magazine tool data pot 54 (T4-digit)/pot 27 (T8-digit)	R11121		No.2 magazine tool data pot 62 (T4-digit)/pot 31 (T8-digit)
R11114		No.2 magazine tool data pot 55 (T4-digit)/pot 28 (T8-digit)	R11122		No.2 magazine tool data pot 63 (T4-digit)/pot 32 (T8-digit)
R11115		No.2 magazine tool data pot 56 (T4-digit)/pot 28 (T8-digit)	R11123		No.2 magazine tool data pot 64 (T4-digit)/pot 32 (T8-digit)
R11116		No.2 magazine tool data pot 57 (T4-digit)/pot 29 (T8-digit)	R11124		No.2 magazine tool data pot 65 (T4-digit)/pot 33 (T8-digit)
R11117		No.2 magazine tool data pot 58 (T4-digit)/pot 29 (T8-digit)	R11125		No.2 magazine tool data pot 66 (T4-digit)/pot 33 (T8-digit)
R11118		No.2 magazine tool data pot 59 (T4-digit)/pot 30 (T8-digit)	R11126		No.2 magazine tool data pot 67 (T4-digit)/pot 34 (T8-digit)
R11119		No.2 magazine tool data pot 60 (T4-digit)/pot 30 (T8-digit)	R11127		No.2 magazine tool data pot 68 (T4-digit)/pot 34 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11128		No.2 magazine tool data pot 69 (T4-digit)/pot 35 (T8-digit)	R11136		No.2 magazine tool data pot 77 (T4-digit)/pot 39 (T8-digit)
R11129		No.2 magazine tool data pot 70 (T4-digit)/pot 35 (T8-digit)	R11137		No.2 magazine tool data pot 78 (T4-digit)/pot 39 (T8-digit)
R11130		No.2 magazine tool data pot 71 (T4-digit)/pot 36 (T8-digit)	R11138		No.2 magazine tool data pot 79 (T4-digit)/pot 40 (T8-digit)
R11131		No.2 magazine tool data pot 72 (T4-digit)/pot 36 (T8-digit)	R11139		No.2 magazine tool data pot 80 (T4-digit)/pot 40 (T8-digit)
R11132		No.2 magazine tool data pot 73 (T4-digit)/pot 37 (T8-digit)	R11140		No.2 magazine tool data pot 81 (T4-digit)/pot 41 (T8-digit)
R11133		No.2 magazine tool data pot 74 (T4-digit)/pot 37 (T8-digit)	R11141		No.2 magazine tool data pot 82 (T4-digit)/pot 41 (T8-digit)
R11134		No.2 magazine tool data pot 75 (T4-digit)/pot 38 (T8-digit)	R11142		No.2 magazine tool data pot 83 (T4-digit)/pot 42 (T8-digit)
R11135		No.2 magazine tool data pot 76 (T4-digit)/pot 38 (T8-digit)	R11143		No.2 magazine tool data pot 84 (T4-digit)/pot 42 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11144		No.2 magazine tool data pot 85 (T4-digit)/pot 43 (T8-digit)	R11152		No.2 magazine tool data pot 93 (T4-digit)/pot 47 (T8-digit)
R11145		No.2 magazine tool data pot 86 (T4-digit)/pot 43 (T8-digit)	R11153		No.2 magazine tool data pot 94 (T4-digit)/pot 47 (T8-digit)
R11146		No.2 magazine tool data pot 87 (T4-digit)/pot 44 (T8-digit)	R11154		No.2 magazine tool data pot 95 (T4-digit)/pot 48 (T8-digit)
R11147		No.2 magazine tool data pot 88 (T4-digit)/pot 44 (T8-digit)	R11155		No.2 magazine tool data pot 96 (T4-digit)/pot 48 (T8-digit)
R11148		No.2 magazine tool data pot 89 (T4-digit)/pot 45 (T8-digit)	R11156		No.2 magazine tool data pot 97 (T4-digit)/pot 49 (T8-digit)
R11149		No.2 magazine tool data pot 90 (T4-digit)/pot 45 (T8-digit)	R11157		No.2 magazine tool data pot 98 (T4-digit)/pot 49 (T8-digit)
R11150		No.2 magazine tool data pot 91 (T4-digit)/pot 46 (T8-digit)	R11158		No.2 magazine tool data pot 99 (T4-digit)/pot 50 (T8-digit)
R11151		No.2 magazine tool data pot 92 (T4-digit)/pot 46 (T8-digit)	R11159		No.2 magazine tool data pot 100 (T4-digit)/pot 50 (T8-digit)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11160		No.2 magazine tool data pot 101 (T4-digit)/pot 51 (T8-digit)	R11168		No.2 magazine tool data pot 109 (T4-digit)/pot 55 (T8-digit)
R11161		No.2 magazine tool data pot 102 (T4-digit)/pot 51 (T8-digit)	R11169		No.2 magazine tool data pot 110 (T4-digit)/pot 55 (T8-digit)
R11162		No.2 magazine tool data pot 103 (T4-digit)/pot 52 (T8-digit)	R11170		No.2 magazine tool data pot 111 (T4-digit)/pot 56 (T8-digit)
R11163		No.2 magazine tool data pot 104 (T4-digit)/pot 52 (T8-digit)	R11171		No.2 magazine tool data pot 112 (T4-digit)/pot 56 (T8-digit)
R11164		No.2 magazine tool data pot 105 (T4-digit)/pot 53 (T8-digit)	R11172		No.2 magazine tool data pot 113 (T4-digit)/pot 57 (T8-digit)
R11165		No.2 magazine tool data pot 106 (T4-digit)/pot 53 (T8-digit)	R11173		No.2 magazine tool data pot 114 (T4-digit)/pot 57 (T8-digit)
R11166		No.2 magazine tool data pot 107 (T4-digit)/pot 54 (T8-digit)	R11174		No.2 magazine tool data pot 115 (T4-digit)/pot 58 (T8-digit)
R11167		No.2 magazine tool data pot 108 (T4-digit)/pot 54 (T8-digit)	R11175		No.2 magazine tool data pot 116 (T4-digit)/pot 58 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11176		No.2 magazine tool data pot 117 (T4-digit)/pot 59 (T8-digit)	R11184		No.2 magazine tool data pot 63 (T8-digit)
R11177		No.2 magazine tool data pot 118 (T4-digit)/pot 59 (T8-digit)	R11185		No.2 magazine tool data pot 63 (T8-digit)
R11178		No.2 magazine tool data pot 119 (T4-digit)/pot 60 (T8-digit)	R11186		No.2 magazine tool data pot 64 (T8-digit)
R11179		No.2 magazine tool data pot 120 (T4-digit)/pot 60 (T8-digit)	R11187		No.2 magazine tool data pot 64 (T8-digit)
R11180		No.2 magazine tool data pot 61 (T8-digit)	R11188		No.2 magazine tool data pot 65 (T8-digit)
R11181		No.2 magazine tool data pot 61 (T8-digit)	R11189		No.2 magazine tool data pot 65 (T8-digit)
R11182		No.2 magazine tool data pot 62 (T8-digit)	R11190		No.2 magazine tool data pot 66 (T8-digit)
R11183		No.2 magazine tool data pot 62 (T8-digit)	R11191		No.2 magazine tool data pot 66 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11192		No.2 magazine tool data pot 67 (T8-digit)	R11200		No.2 magazine tool data pot 71 (T8-digit)
R11193		No.2 magazine tool data pot 67 (T8-digit)	R11201		No.2 magazine tool data pot 71 (T8-digit)
R11194		No.2 magazine tool data pot 68 (T8-digit)	R11202		No.2 magazine tool data pot 72 (T8-digit)
R11195		No.2 magazine tool data pot 68 (T8-digit)	R11203		No.2 magazine tool data pot 72 (T8-digit)
R11196		No.2 magazine tool data pot 69 (T8-digit)	R11204		No.2 magazine tool data pot 73 (T8-digit)
R11197		No.2 magazine tool data pot 69 (T8-digit)	R11205		No.2 magazine tool data pot 73 (T8-digit)
R11198		No.2 magazine tool data pot 70 (T8-digit)	R11206		No.2 magazine tool data pot 74 (T8-digit)
R11199		No.2 magazine tool data pot 70 (T8-digit)	R11207		No.2 magazine tool data pot 74 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11208		No.2 magazine tool data pot 75 (T8-digit)	R11216		No.2 magazine tool data pot 79 (T8-digit)
R11209		No.2 magazine tool data pot 75 (T8-digit)	R11217		No.2 magazine tool data pot 79 (T8-digit)
R11210		No.2 magazine tool data pot 76 (T8-digit)	R11218		No.2 magazine tool data pot 80 (T8-digit)
R11211		No.2 magazine tool data pot 76 (T8-digit)	R11219		No.2 magazine tool data pot 80 (T8-digit)
R11212		No.2 magazine tool data pot 77 (T8-digit)	R11220		No.2 magazine tool data pot 81 (T8-digit)
R11213		No.2 magazine tool data pot 77 (T8-digit)	R11221		No.2 magazine tool data pot 81 (T8-digit)
R11214		No.2 magazine tool data pot 78 (T8-digit)	R11222		No.2 magazine tool data pot 82 (T8-digit)
R11215		No.2 magazine tool data pot 78 (T8-digit)	R11223		No.2 magazine tool data pot 82 (T8-digit)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11224		No.2 magazine tool data pot 83 (T8-digit)	R11232		No.2 magazine tool data pot 87 (T8-digit)
R11225		No.2 magazine tool data pot 83 (T8-digit)	R11233		No.2 magazine tool data pot 87 (T8-digit)
R11226		No.2 magazine tool data pot 84 (T8-digit)	R11234		No.2 magazine tool data pot 88 (T8-digit)
R11227		No.2 magazine tool data pot 84 (T8-digit)	R11235		No.2 magazine tool data pot 88 (T8-digit)
R11228		No.2 magazine tool data pot 85 (T8-digit)	R11236		No.2 magazine tool data pot 89 (T8-digit)
R11229		No.2 magazine tool data pot 85 (T8-digit)	R11237		No.2 magazine tool data pot 89 (T8-digit)
R11230		No.2 magazine tool data pot 86 (T8-digit)	R11238		No.2 magazine tool data pot 90 (T8-digit)
R11231		No.2 magazine tool data pot 86 (T8-digit)	R11239		No.2 magazine tool data pot 90 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11240		No.2 magazine tool data pot 91 (T8-digit)	R11248		No.2 magazine tool data pot 95 (T8-digit)
R11241		No.2 magazine tool data pot 91 (T8-digit)	R11249		No.2 magazine tool data pot 95 (T8-digit)
R11242		No.2 magazine tool data pot 92 (T8-digit)	R11250		No.2 magazine tool data pot 96 (T8-digit)
R11243		No.2 magazine tool data pot 92 (T8-digit)	R11251		No.2 magazine tool data pot 96 (T8-digit)
R11244		No.2 magazine tool data pot 93 (T8-digit)	R11252		No.2 magazine tool data pot 97 (T8-digit)
R11245		No.2 magazine tool data pot 93 (T8-digit)	R11253		No.2 magazine tool data pot 97 (T8-digit)
R11246		No.2 magazine tool data pot 94 (T8-digit)	R11254		No.2 magazine tool data pot 98 (T8-digit)
R11247		No.2 magazine tool data pot 94 (T8-digit)	R11255		No.2 magazine tool data pot 98 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11256		No.2 magazine tool data pot 99 (T8-digit)	R11264		No.2 magazine tool data pot 103 (T8-digit)
R11257		No.2 magazine tool data pot 99 (T8-digit)	R11265		No.2 magazine tool data pot 103 (T8-digit)
R11258		No.2 magazine tool data pot 100 (T8-digit)	R11266		No.2 magazine tool data pot 104 (T8-digit)
R11259		No.2 magazine tool data pot 100 (T8-digit)	R11267		No.2 magazine tool data pot 104 (T8-digit)
R11260		No.2 magazine tool data pot 101 (T8-digit)	R11268		No.2 magazine tool data pot 105 (T8-digit)
R11261		No.2 magazine tool data pot 101 (T8-digit)	R11269		No.2 magazine tool data pot 105 (T8-digit)
R11262		No.2 magazine tool data pot 102 (T8-digit)	R11270		No.2 magazine tool data pot 106 (T8-digit)
R11263		No.2 magazine tool data pot 102 (T8-digit)	R11271		No.2 magazine tool data pot 106 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11272		No.2 magazine tool data pot 107 (T8-digit)	R11280		No.2 magazine tool data pot 111 (T8-digit)
R11273		No.2 magazine tool data pot 107 (T8-digit)	R11281		No.2 magazine tool data pot 111 (T8-digit)
R11274		No.2 magazine tool data pot 108 (T8-digit)	R11282		No.2 magazine tool data pot 112 (T8-digit)
R11275		No.2 magazine tool data pot 108 (T8-digit)	R11283		No.2 magazine tool data pot 112 (T8-digit)
R11276		No.2 magazine tool data pot 109 (T8-digit)	R11284		No.2 magazine tool data pot 113 (T8-digit)
R11277		No.2 magazine tool data pot 109 (T8-digit)	R11285		No.2 magazine tool data pot 113 (T8-digit)
R11278		No.2 magazine tool data pot 110 (T8-digit)	R11286		No.2 magazine tool data pot 114 (T8-digit)
R11279		No.2 magazine tool data pot 110 (T8-digit)	R11287		No.2 magazine tool data pot 114 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11288		No.2 magazine tool data pot 115 (T8-digit)	R11296		No.2 magazine tool data pot 119 (T8-digit)
R11289		No.2 magazine tool data pot 115 (T8-digit)	R11297		No.2 magazine tool data pot 119 (T8-digit)
R11290		No.2 magazine tool data pot 116 (T8-digit)	R11298		No.2 magazine tool data pot 120 (T8-digit)
R11291		No.2 magazine tool data pot 116 (T8-digit)	R11299		No.2 magazine tool data pot 120 (T8-digit)
R11292		No.2 magazine tool data pot 117 (T8-digit)	R11300		No.2 magazine tool data (Aux.D) pot 1
R11293		No.2 magazine tool data pot 117 (T8-digit)	R11301		No.2 magazine tool data (Aux.D) pot 2
R11294		No.2 magazine tool data pot 118 (T8-digit)	R11302		No.2 magazine tool data (Aux.D) pot 3
R11295		No.2 magazine tool data pot 118 (T8-digit)	R11303		No.2 magazine tool data (Aux.D) pot 4

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11304		No.2 magazine tool data (Aux.D) pot 5	R11312		No.2 magazine tool data (Aux.D) pot 13
R11305		No.2 magazine tool data (Aux.D) pot 6	R11313		No.2 magazine tool data (Aux.D) pot 14
R11306		No.2 magazine tool data (Aux.D) pot 7	R11314		No.2 magazine tool data (Aux.D) pot 15
R11307		No.2 magazine tool data (Aux.D) pot 8	R11315		No.2 magazine tool data (Aux.D) pot 16
R11308		No.2 magazine tool data (Aux.D) pot 9	R11316		No.2 magazine tool data (Aux.D) pot 17
R11309		No.2 magazine tool data (Aux.D) pot 10	R11317		No.2 magazine tool data (Aux.D) pot 18
R11310		No.2 magazine tool data (Aux.D) pot 11	R11318		No.2 magazine tool data (Aux.D) pot 19
R11311		No.2 magazine tool data (Aux.D) pot 12	R11319		No.2 magazine tool data (Aux.D) pot 20

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11320		No.2 magazine tool data (Aux.D) pot 21	R11328		No.2 magazine tool data (Aux.D) pot 29
R11321		No.2 magazine tool data (Aux.D) pot 22	R11329		No.2 magazine tool data (Aux.D) pot 30
R11322		No.2 magazine tool data (Aux.D) pot 23	R11330		No.2 magazine tool data (Aux.D) pot 31
R11323		No.2 magazine tool data (Aux.D) pot 24	R11331		No.2 magazine tool data (Aux.D) pot 32
R11324		No.2 magazine tool data (Aux.D) pot 25	R11332		No.2 magazine tool data (Aux.D) pot 33
R11325		No.2 magazine tool data (Aux.D) pot 26	R11333		No.2 magazine tool data (Aux.D) pot 34
R11326		No.2 magazine tool data (Aux.D) pot 27	R11334		No.2 magazine tool data (Aux.D) pot 35
R11327		No.2 magazine tool data (Aux.D) pot 28	R11335		No.2 magazine tool data (Aux.D) pot 36

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11336		No.2 magazine tool data (Aux.D) pot 37	R11344		No.2 magazine tool data (Aux.D) pot 45
R11337		No.2 magazine tool data (Aux.D) pot 38	R11345		No.2 magazine tool data (Aux.D) pot 46
R11338		No.2 magazine tool data (Aux.D) pot 39	R11346		No.2 magazine tool data (Aux.D) pot 47
R11339		No.2 magazine tool data (Aux.D) pot 40	R11347		No.2 magazine tool data (Aux.D) pot 48
R11340		No.2 magazine tool data (Aux.D) pot 41	R11348		No.2 magazine tool data (Aux.D) pot 49
R11341		No.2 magazine tool data (Aux.D) pot 42	R11349		No.2 magazine tool data (Aux.D) pot 50
R11342		No.2 magazine tool data (Aux.D) pot 43	R11350		No.2 magazine tool data (Aux.D) pot 51
R11343		No.2 magazine tool data (Aux.D) pot 44	R11351		No.2 magazine tool data (Aux.D) pot 52

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11352		No.2 magazine tool data (Aux.D) pot 53	R11360		No.2 magazine tool data (Aux.D) pot 61
R11353		No.2 magazine tool data (Aux.D) pot 54	R11361		No.2 magazine tool data (Aux.D) pot 62
R11354		No.2 magazine tool data (Aux.D) pot 55	R11362		No.2 magazine tool data (Aux.D) pot 63
R11355		No.2 magazine tool data (Aux.D) pot 56	R11363		No.2 magazine tool data (Aux.D) pot 64
R11356		No.2 magazine tool data (Aux.D) pot 57	R11364		No.2 magazine tool data (Aux.D) pot 65
R11357		No.2 magazine tool data (Aux.D) pot 58	R11365		No.2 magazine tool data (Aux.D) pot 66
R11358		No.2 magazine tool data (Aux.D) pot 59	R11366		No.2 magazine tool data (Aux.D) pot 67
R11359		No.2 magazine tool data (Aux.D) pot 60	R11367		No.2 magazine tool data (Aux.D) pot 68

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11368		No.2 magazine tool data (Aux.D) pot 69	R11376		No.2 magazine tool data (Aux.D) pot 77
R11369		No.2 magazine tool data (Aux.D) pot 70	R11377		No.2 magazine tool data (Aux.D) pot 78
R11370		No.2 magazine tool data (Aux.D) pot 71	R11378		No.2 magazine tool data (Aux.D) pot 79
R11371		No.2 magazine tool data (Aux.D) pot 72	R11379		No.2 magazine tool data (Aux.D) pot 80
R11372		No.2 magazine tool data (Aux.D) pot 73	R11380		No.2 magazine tool data (Aux.D) pot 81
R11373		No.2 magazine tool data (Aux.D) pot 74	R11381		No.2 magazine tool data (Aux.D) pot 82
R11374		No.2 magazine tool data (Aux.D) pot 75	R11382		No.2 magazine tool data (Aux.D) pot 83
R11375		No.2 magazine tool data (Aux.D) pot 76	R11383		No.2 magazine tool data (Aux.D) pot 84

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11384		No.2 magazine tool data (Aux.D) pot 85	R11392		No.2 magazine tool data (Aux.D) pot 93
R11385		No.2 magazine tool data (Aux.D) pot 86	R11393		No.2 magazine tool data (Aux.D) pot 94
R11386		No.2 magazine tool data (Aux.D) pot 87	R11394		No.2 magazine tool data (Aux.D) pot 95
R11387		No.2 magazine tool data (Aux.D) pot 88	R11395		No.2 magazine tool data (Aux.D) pot 96
R11388		No.2 magazine tool data (Aux.D) pot 89	R11396		No.2 magazine tool data (Aux.D) pot 97
R11389		No.2 magazine tool data (Aux.D) pot 90	R11397		No.2 magazine tool data (Aux.D) pot 98
R11390		No.2 magazine tool data (Aux.D) pot 91	R11398		No.2 magazine tool data (Aux.D) pot 99
R11391		No.2 magazine tool data (Aux.D) pot 92	R11399		No.2 magazine tool data (Aux.D) pot 100

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11400		No.2 magazine tool data (Aux.D) pot 101	R11408		No.2 magazine tool data (Aux.D) pot 109
R11401		No.2 magazine tool data (Aux.D) pot 102	R11409		No.2 magazine tool data (Aux.D) pot 110
R11402		No.2 magazine tool data (Aux.D) pot 103	R11410		No.2 magazine tool data (Aux.D) pot 111
R11403		No.2 magazine tool data (Aux.D) pot 104	R11411		No.2 magazine tool data (Aux.D) pot 112
R11404		No.2 magazine tool data (Aux.D) pot 105	R11412		No.2 magazine tool data (Aux.D) pot 113
R11405		No.2 magazine tool data (Aux.D) pot 106	R11413		No.2 magazine tool data (Aux.D) pot 114
R11406		No.2 magazine tool data (Aux.D) pot 107	R11414		No.2 magazine tool data (Aux.D) pot 115
R11407		No.2 magazine tool data (Aux.D) pot 108	R11415		No.2 magazine tool data (Aux.D) pot 116

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11416		No.2 magazine tool data (Aux.D) pot 117	R11424		No.3 magazine tool data pot 5 (T4-digit)/pot 3 (T8-digit)
R11417		No.2 magazine tool data (Aux.D) pot 118	R11425		No.3 magazine tool data pot 6 (T4-digit)/pot 3 (T8-digit)
R11418		No.2 magazine tool data (Aux.D) pot 119	R11426		No.3 magazine tool data pot 7 (T4-digit)/pot 4 (T8-digit)
R11419		No.2 magazine tool data (Aux.D) pot 120	R11427		No.3 magazine tool data pot 8 (T4-digit)/pot 4 (T8-digit)
R11420		No.3 magazine tool data pot 1	R11428		No.3 magazine tool data pot 9 (T4-digit)/pot 5 (T8-digit)
R11421		No.3 magazine tool data pot 2 (T4-digit)/pot 1 (T8-digit)	R11429		No.3 magazine tool data pot 10 (T4-digit)/pot 5 (T8-digit)
R11422		No.3 magazine tool data pot 3 (T4-digit)/pot 2 (T8-digit)	R11430		No.3 magazine tool data pot 11 (T4-digit)/pot 6 (T8-digit)
R11423		No.3 magazine tool data pot 4 (T4-digit)/pot 2 (T8-digit)	R11431		No.3 magazine tool data pot 12 (T4-digit)/pot 6 (T8-digit)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11432		No.3 magazine tool data pot 13 (T4-digit)/pot 7 (T8-digit)	R11440		No.3 magazine tool data pot 21 (T4-digit)/pot 11 (T8-digit)
R11433		No.3 magazine tool data pot 14 (T4-digit)/pot 7 (T8-digit)	R11441		No.3 magazine tool data pot 22 (T4-digit)/pot 11 (T8-digit)
R11434		No.3 magazine tool data pot 15 (T4-digit)/pot 8 (T8-digit)	R11442		No.3 magazine tool data pot 23 (T4-digit)/pot 12 (T8-digit)
R11435		No.3 magazine tool data pot 16 (T4-digit)/pot 8 (T8-digit)	R11443		No.3 magazine tool data pot 24 (T4-digit)/pot 12 (T8-digit)
R11436		No.3 magazine tool data pot 17 (T4-digit)/pot 9 (T8-digit)	R11444		No.3 magazine tool data pot 25 (T4-digit)/pot 13 (T8-digit)
R11437		No.3 magazine tool data pot 18 (T4-digit)/pot 9 (T8-digit)	R11445		No.3 magazine tool data pot 26 (T4-digit)/pot 13 (T8-digit)
R11438		No.3 magazine tool data pot 19 (T4-digit)/pot 10 (T8-digit)	R11446		No.3 magazine tool data pot 27 (T4-digit)/pot 14 (T8-digit)
R11439		No.3 magazine tool data pot 20 (T4-digit)/pot 10 (T8-digit)	R11447		No.3 magazine tool data pot 28 (T4-digit)/pot 14 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11448		No.3 magazine tool data pot 29 (T4-digit)/pot 15 (T8-digit)	R11456		No.3 magazine tool data pot 37 (T4-digit)/pot 19 (T8-digit)
R11449		No.3 magazine tool data pot 30 (T4-digit)/pot 15 (T8-digit)	R11457		No.3 magazine tool data pot 38 (T4-digit)/pot 19 (T8-digit)
R11450		No.3 magazine tool data pot 31 (T4-digit)/pot 16 (T8-digit)	R11458		No.3 magazine tool data pot 39 (T4-digit)/pot 20 (T8-digit)
R11451		No.3 magazine tool data pot 32 (T4-digit)/pot 16 (T8-digit)	R11459		No.3 magazine tool data pot 40 (T4-digit)/pot 20 (T8-digit)
R11452		No.3 magazine tool data pot 33 (T4-digit)/pot 17 (T8-digit)	R11460		No.3 magazine tool data pot 41 (T4-digit)/pot 21 (T8-digit)
R11453		No.3 magazine tool data pot 34 (T4-digit)/pot 17 (T8-digit)	R11461		No.3 magazine tool data pot 42 (T4-digit)/pot 21 (T8-digit)
R11454		No.3 magazine tool data pot 35 (T4-digit)/pot 18 (T8-digit)	R11462		No.3 magazine tool data pot 43 (T4-digit)/pot 22 (T8-digit)
R11455		No.3 magazine tool data pot 36 (T4-digit)/pot 18 (T8-digit)	R11463		No.3 magazine tool data pot 44 (T4-digit)/pot 22 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11464		No.3 magazine tool data pot 45 (T4-digit)/pot 23 (T8-digit)	R11472		No.3 magazine tool data pot 53 (T4-digit)/pot 27 (T8-digit)
R11465		No.3 magazine tool data pot 46 (T4-digit)/pot 23 (T8-digit)	R11473		No.3 magazine tool data pot 54 (T4-digit)/pot 27 (T8-digit)
R11466		No.3 magazine tool data pot 47 (T4-digit)/pot 24 (T8-digit)	R11474		No.3 magazine tool data pot 55 (T4-digit)/pot 28 (T8-digit)
R11467		No.3 magazine tool data pot 48 (T4-digit)/pot 24 (T8-digit)	R11475		No.3 magazine tool data pot 56 (T4-digit)/pot 28 (T8-digit)
R11468		No.3 magazine tool data pot 49 (T4-digit)/pot 25 (T8-digit)	R11476		No.3 magazine tool data pot 57 (T4-digit)/pot 29 (T8-digit)
R11469		No.3 magazine tool data pot 50 (T4-digit)/pot 25 (T8-digit)	R11477		No.3 magazine tool data pot 58 (T4-digit)/pot 29 (T8-digit)
R11470		No.3 magazine tool data pot 51 (T4-digit)/pot 26 (T8-digit)	R11478		No.3 magazine tool data pot 59 (T4-digit)/pot 30 (T8-digit)
R11471		No.3 magazine tool data pot 52 (T4-digit)/pot 26 (T8-digit)	R11479		No.3 magazine tool data pot 60 (T4-digit)/pot 30 (T8-digit)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11480		No.3 magazine tool data pot 61 (T4-digit)/pot 31 (T8-digit)	R11488		No.3 magazine tool data pot 69 (T4-digit)/pot 35 (T8-digit)
R11481		No.3 magazine tool data pot 62 (T4-digit)/pot 31 (T8-digit)	R11489		No.3 magazine tool data pot 70 (T4-digit)/pot 35 (T8-digit)
R11482		No.3 magazine tool data pot 63 (T4-digit)/pot 32 (T8-digit)	R11490		No.3 magazine tool data pot 71 (T4-digit)/pot 36 (T8-digit)
R11483		No.3 magazine tool data pot 64 (T4-digit)/pot 32 (T8-digit)	R11491		No.3 magazine tool data pot 72 (T4-digit)/pot 36 (T8-digit)
R11484		No.3 magazine tool data pot 65 (T4-digit)/pot 33 (T8-digit)	R11492		No.3 magazine tool data pot 73 (T4-digit)/pot 37 (T8-digit)
R11485		No.3 magazine tool data pot 66 (T4-digit)/pot 33 (T8-digit)	R11493		No.3 magazine tool data pot 74 (T4-digit)/pot 37 (T8-digit)
R11486		No.3 magazine tool data pot 67 (T4-digit)/pot 34 (T8-digit)	R11494		No.3 magazine tool data pot 75 (T4-digit)/pot 38 (T8-digit)
R11487		No.3 magazine tool data pot 68 (T4-digit)/pot 34 (T8-digit)	R11495		No.3 magazine tool data pot 76 (T4-digit)/pot 38 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11496		No.3 magazine tool data pot 77 (T4-digit)/pot 39 (T8-digit)	R11504		No.3 magazine tool data pot 85 (T4-digit)/pot 43 (T8-digit)
R11497		No.3 magazine tool data pot 78 (T4-digit)/pot 39 (T8-digit)	R11505		No.3 magazine tool data pot 86 (T4-digit)/pot 43 (T8-digit)
R11498		No.3 magazine tool data pot 79 (T4-digit)/pot 40 (T8-digit)	R11506		No.3 magazine tool data pot 87 (T4-digit)/pot 44 (T8-digit)
R11499		No.3 magazine tool data pot 80 (T4-digit)/pot 40 (T8-digit)	R11507		No.3 magazine tool data pot 88 (T4-digit)/pot 44 (T8-digit)
R11500		No.3 magazine tool data pot 81 (T4-digit)/pot 41 (T8-digit)	R11508		No.3 magazine tool data pot 89 (T4-digit)/pot 45 (T8-digit)
R11501		No.3 magazine tool data pot 82 (T4-digit)/pot 41 (T8-digit)	R11509		No.3 magazine tool data pot 90 (T4-digit)/pot 45 (T8-digit)
R11502		No.3 magazine tool data pot 83 (T4-digit)/pot 42 (T8-digit)	R11510		No.3 magazine tool data pot 91 (T4-digit)/pot 46 (T8-digit)
R11503		No.3 magazine tool data pot 84 (T4-digit)/pot 42 (T8-digit)	R11511		No.3 magazine tool data pot 92 (T4-digit)/pot 46 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11512		No.3 magazine tool data pot 93 (T4-digit)/pot 47 (T8-digit)	R11520		No.3 magazine tool data pot 101 (T4-digit)/pot 51 (T8-digit)
R11513		No.3 magazine tool data pot 94 (T4-digit)/pot 47 (T8-digit)	R11521		No.3 magazine tool data pot 102 (T4-digit)/pot 51 (T8-digit)
R11514		No.3 magazine tool data pot 95 (T4-digit)/pot 48 (T8-digit)	R11522		No.3 magazine tool data pot 103 (T4-digit)/pot 52 (T8-digit)
R11515		No.3 magazine tool data pot 96 (T4-digit)/pot 48 (T8-digit)	R11523		No.3 magazine tool data pot 104 (T4-digit)/pot 52 (T8-digit)
R11516		No.3 magazine tool data pot 97 (T4-digit)/pot 49 (T8-digit)	R11524		No.3 magazine tool data pot 105 (T4-digit)/pot 53 (T8-digit)
R11517		No.3 magazine tool data pot 98 (T4-digit)/pot 49 (T8-digit)	R11525		No.3 magazine tool data pot 106 (T4-digit)/pot 53 (T8-digit)
R11518		No.3 magazine tool data pot 99 (T4-digit)/pot 50 (T8-digit)	R11526		No.3 magazine tool data pot 107 (T4-digit)/pot 54 (T8-digit)
R11519		No.3 magazine tool data pot 100 (T4-digit)/pot 50 (T8-digit)	R11527		No.3 magazine tool data pot 108 (T4-digit)/pot 54 (T8-digit)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11528		No.3 magazine tool data pot 109 (T4-digit)/pot 55 (T8-digit)	R11536		No.3 magazine tool data pot 117 (T4-digit)/pot 59 (T8-digit)
R11529		No.3 magazine tool data pot 110 (T4-digit)/pot 55 (T8-digit)	R11537		No.3 magazine tool data pot 118 (T4-digit)/pot 59 (T8-digit)
R11530		No.3 magazine tool data pot 111 (T4-digit)/pot 56 (T8-digit)	R11538		No.3 magazine tool data pot 119 (T4-digit)/pot 60 (T8-digit)
R11531		No.3 magazine tool data pot 112 (T4-digit)/pot 56 (T8-digit)	R11539		No.3 magazine tool data pot 120 (T4-digit)/pot 60 (T8-digit)
R11532		No.3 magazine tool data pot 113 (T4-digit)/pot 57 (T8-digit)	R11540		No.3 magazine tool data pot 61 (T8-digit)
R11533		No.3 magazine tool data pot 114 (T4-digit)/pot 57 (T8-digit)	R11541		No.3 magazine tool data pot 61 (T8-digit)
R11534		No.3 magazine tool data pot 115 (T4-digit)/pot 58 (T8-digit)	R11542		No.3 magazine tool data pot 62 (T8-digit)
R11535		No.3 magazine tool data pot 116 (T4-digit)/pot 58 (T8-digit)	R11543		No.3 magazine tool data pot 62 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11544		No.3 magazine tool data pot 63 (T8-digit)	R11552		No.3 magazine tool data pot 67 (T8-digit)
R11545		No.3 magazine tool data pot 63 (T8-digit)	R11553		No.3 magazine tool data pot 67 (T8-digit)
R11546		No.3 magazine tool data pot 64 (T8-digit)	R11554		No.3 magazine tool data pot 68 (T8-digit)
R11547		No.3 magazine tool data pot 64 (T8-digit)	R11555		No.3 magazine tool data pot 68 (T8-digit)
R11548		No.3 magazine tool data pot 65 (T8-digit)	R11556		No.3 magazine tool data pot 69 (T8-digit)
R11549		No.3 magazine tool data pot 65 (T8-digit)	R11557		No.3 magazine tool data pot 69 (T8-digit)
R11550		No.3 magazine tool data pot 66 (T8-digit)	R11558		No.3 magazine tool data pot 70 (T8-digit)
R11551		No.3 magazine tool data pot 66 (T8-digit)	R11559		No.3 magazine tool data pot 70 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11560		No.3 magazine tool data pot 71 (T8-digit)	R11568		No.3 magazine tool data pot 75 (T8-digit)
R11561		No.3 magazine tool data pot 71 (T8-digit)	R11569		No.3 magazine tool data pot 75 (T8-digit)
R11562		No.3 magazine tool data pot 72 (T8-digit)	R11570		No.3 magazine tool data pot 76 (T8-digit)
R11563		No.3 magazine tool data pot 72 (T8-digit)	R11571		No.3 magazine tool data pot 76 (T8-digit)
R11564		No.3 magazine tool data pot 73 (T8-digit)	R11572		No.3 magazine tool data pot 77 (T8-digit)
R11565		No.3 magazine tool data pot 73 (T8-digit)	R11573		No.3 magazine tool data pot 77 (T8-digit)
R11566		No.3 magazine tool data pot 74 (T8-digit)	R11574		No.3 magazine tool data pot 78 (T8-digit)
R11567		No.3 magazine tool data pot 74 (T8-digit)	R11575		No.3 magazine tool data pot 78 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11576		No.3 magazine tool data pot 79 (T8-digit)	R11584		No.3 magazine tool data pot 83 (T8-digit)
R11577		No.3 magazine tool data pot 79 (T8-digit)	R11585		No.3 magazine tool data pot 83 (T8-digit)
R11578		No.3 magazine tool data pot 80 (T8-digit)	R11586		No.3 magazine tool data pot 84 (T8-digit)
R11579		No.3 magazine tool data pot 80 (T8-digit)	R11587		No.3 magazine tool data pot 84 (T8-digit)
R11580		No.3 magazine tool data pot 81 (T8-digit)	R11588		No.3 magazine tool data pot 85 (T8-digit)
R11581		No.3 magazine tool data pot 81 (T8-digit)	R11589		No.3 magazine tool data pot 85 (T8-digit)
R11582		No.3 magazine tool data pot 82 (T8-digit)	R11590		No.3 magazine tool data pot 86 (T8-digit)
R11583		No.3 magazine tool data pot 82 (T8-digit)	R11591		No.3 magazine tool data pot 86 (T8-digit)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11592		No.3 magazine tool data pot 87 (T8-digit)	R11600		No.3 magazine tool data pot 91 (T8-digit)
R11593		No.3 magazine tool data pot 87 (T8-digit)	R11601		No.3 magazine tool data pot 91 (T8-digit)
R11594		No.3 magazine tool data pot 88 (T8-digit)	R11602		No.3 magazine tool data pot 92 (T8-digit)
R11595		No.3 magazine tool data pot 88 (T8-digit)	R11603		No.3 magazine tool data pot 92 (T8-digit)
R11596		No.3 magazine tool data pot 89 (T8-digit)	R11604		No.3 magazine tool data pot 93 (T8-digit)
R11597		No.3 magazine tool data pot 89 (T8-digit)	R11605		No.3 magazine tool data pot 93 (T8-digit)
R11598		No.3 magazine tool data pot 90 (T8-digit)	R11606		No.3 magazine tool data pot 94 (T8-digit)
R11599		No.3 magazine tool data pot 90 (T8-digit)	R11607		No.3 magazine tool data pot 94 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11608		No.3 magazine tool data pot 95 (T8-digit)	R11616		No.3 magazine tool data pot 99 (T8-digit)
R11609		No.3 magazine tool data pot 95 (T8-digit)	R11617		No.3 magazine tool data pot 99 (T8-digit)
R11610		No.3 magazine tool data pot 96 (T8-digit)	R11618		No.3 magazine tool data pot 100 (T8-digit)
R11611		No.3 magazine tool data pot 96 (T8-digit)	R11619		No.3 magazine tool data pot 100 (T8-digit)
R11612		No.3 magazine tool data pot 97 (T8-digit)	R11620		No.3 magazine tool data pot 101 (T8-digit)
R11613		No.3 magazine tool data pot 97 (T8-digit)	R11621		No.3 magazine tool data pot 101 (T8-digit)
R11614		No.3 magazine tool data pot 98 (T8-digit)	R11622		No.3 magazine tool data pot 102 (T8-digit)
R11615		No.3 magazine tool data pot 98 (T8-digit)	R11623		No.3 magazine tool data pot 102 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11624		No.3 magazine tool data pot 103 (T8-digit)	R11632		No.3 magazine tool data pot 107 (T8-digit)
R11625		No.3 magazine tool data pot 103 (T8-digit)	R11633		No.3 magazine tool data pot 107 (T8-digit)
R11626		No.3 magazine tool data pot 104 (T8-digit)	R11634		No.3 magazine tool data pot 108 (T8-digit)
R11627		No.3 magazine tool data pot 104 (T8-digit)	R11635		No.3 magazine tool data pot 108 (T8-digit)
R11628		No.3 magazine tool data pot 105 (T8-digit)	R11636		No.3 magazine tool data pot 109 (T8-digit)
R11629		No.3 magazine tool data pot 105 (T8-digit)	R11637		No.3 magazine tool data pot 109 (T8-digit)
R11630		No.3 magazine tool data pot 106 (T8-digit)	R11638		No.3 magazine tool data pot 110 (T8-digit)
R11631		No.3 magazine tool data pot 106 (T8-digit)	R11639		No.3 magazine tool data pot 110 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11640		No.3 magazine tool data pot 111 (T8-digit)	R11648		No.3 magazine tool data pot 115 (T8-digit)
R11641		No.3 magazine tool data pot 111 (T8-digit)	R11649		No.3 magazine tool data pot 115 (T8-digit)
R11642		No.3 magazine tool data pot 112 (T8-digit)	R11650		No.3 magazine tool data pot 116 (T8-digit)
R11643		No.3 magazine tool data pot 112 (T8-digit)	R11651		No.3 magazine tool data pot 116 (T8-digit)
R11644		No.3 magazine tool data pot 113 (T8-digit)	R11652		No.3 magazine tool data pot 117 (T8-digit)
R11645		No.3 magazine tool data pot 113 (T8-digit)	R11653		No.3 magazine tool data pot 117 (T8-digit)
R11646		No.3 magazine tool data pot 114 (T8-digit)	R11654		No.3 magazine tool data pot 118 (T8-digit)
R11647		No.3 magazine tool data pot 114 (T8-digit)	R11655		No.3 magazine tool data pot 118 (T8-digit)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11656		No.3 magazine tool data pot 119 (T8-digit)	R11664		No.3 magazine tool data (Aux.D) pot 5
R11657		No.3 magazine tool data pot 119 (T8-digit)	R11665		No.3 magazine tool data (Aux.D) pot 6
R11658		No.3 magazine tool data pot 120 (T8-digit)	R11666		No.3 magazine tool data (Aux.D) pot 7
R11659		No.3 magazine tool data pot 120 (T8-digit)	R11667		No.3 magazine tool data (Aux.D) pot 8
R11660		No.3 magazine tool data (Aux.D) pot 1	R11668		No.3 magazine tool data (Aux.D) pot 9
R11661		No.3 magazine tool data (Aux.D) pot 2	R11669		No.3 magazine tool data (Aux.D) pot 10
R11662		No.3 magazine tool data (Aux.D) pot 3	R11670		No.3 magazine tool data (Aux.D) pot 11
R11663		No.3 magazine tool data (Aux.D) pot 4	R11671		No.3 magazine tool data (Aux.D) pot 12

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11672		No.3 magazine tool data (Aux.D) pot 13	R11680		No.3 magazine tool data (Aux.D) pot 21
R11673		No.3 magazine tool data (Aux.D) pot 14	R11681		No.3 magazine tool data (Aux.D) pot 22
R11674		No.3 magazine tool data (Aux.D) pot 15	R11682		No.3 magazine tool data (Aux.D) pot 23
R11675		No.3 magazine tool data (Aux.D) pot 16	R11683		No.3 magazine tool data (Aux.D) pot 24
R11676		No.3 magazine tool data (Aux.D) pot 17	R11684		No.3 magazine tool data (Aux.D) pot 25
R11677		No.3 magazine tool data (Aux.D) pot 18	R11685		No.3 magazine tool data (Aux.D) pot 26
R11678		No.3 magazine tool data (Aux.D) pot 19	R11686		No.3 magazine tool data (Aux.D) pot 27
R11679		No.3 magazine tool data (Aux.D) pot 20	R11687		No.3 magazine tool data (Aux.D) pot 28

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11688		No.3 magazine tool data (Aux.D) pot 29	R11696		No.3 magazine tool data (Aux.D) pot 37
R11689		No.3 magazine tool data (Aux.D) pot 30	R11697		No.3 magazine tool data (Aux.D) pot 38
R11690		No.3 magazine tool data (Aux.D) pot 31	R11698		No.3 magazine tool data (Aux.D) pot 39
R11691		No.3 magazine tool data (Aux.D) pot 32	R11699		No.3 magazine tool data (Aux.D) pot 40
R11692		No.3 magazine tool data (Aux.D) pot 33	R11700		No.3 magazine tool data (Aux.D) pot 41
R11693		No.3 magazine tool data (Aux.D) pot 34	R11701		No.3 magazine tool data (Aux.D) pot 42
R11694		No.3 magazine tool data (Aux.D) pot 35	R11702		No.3 magazine tool data (Aux.D) pot 43
R11695		No.3 magazine tool data (Aux.D) pot 36	R11703		No.3 magazine tool data (Aux.D) pot 44

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11704		No.3 magazine tool data (Aux.D) pot 45	R11712		No.3 magazine tool data (Aux.D) pot 53
R11705		No.3 magazine tool data (Aux.D) pot 46	R11713		No.3 magazine tool data (Aux.D) pot 54
R11706		No.3 magazine tool data (Aux.D) pot 47	R11714		No.3 magazine tool data (Aux.D) pot 55
R11707		No.3 magazine tool data (Aux.D) pot 48	R11715		No.3 magazine tool data (Aux.D) pot 56
R11708		No.3 magazine tool data (Aux.D) pot 49	R11716		No.3 magazine tool data (Aux.D) pot 57
R11709		No.3 magazine tool data (Aux.D) pot 50	R11717		No.3 magazine tool data (Aux.D) pot 58
R11710		No.3 magazine tool data (Aux.D) pot 51	R11718		No.3 magazine tool data (Aux.D) pot 59
R11711		No.3 magazine tool data (Aux.D) pot 52	R11719		No.3 magazine tool data (Aux.D) pot 60

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11720		No.3 magazine tool data (Aux.D) pot 61	R11728		No.3 magazine tool data (Aux.D) pot 69
R11721		No.3 magazine tool data (Aux.D) pot 62	R11729		No.3 magazine tool data (Aux.D) pot 70
R11722		No.3 magazine tool data (Aux.D) pot 63	R11730		No.3 magazine tool data (Aux.D) pot 71
R11723		No.3 magazine tool data (Aux.D) pot 64	R11731		No.3 magazine tool data (Aux.D) pot 72
R11724		No.3 magazine tool data (Aux.D) pot 65	R11732		No.3 magazine tool data (Aux.D) pot 73
R11725		No.3 magazine tool data (Aux.D) pot 66	R11733		No.3 magazine tool data (Aux.D) pot 74
R11726		No.3 magazine tool data (Aux.D) pot 67	R11734		No.3 magazine tool data (Aux.D) pot 75
R11727		No.3 magazine tool data (Aux.D) pot 68	R11735		No.3 magazine tool data (Aux.D) pot 76

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11736		No.3 magazine tool data (Aux.D) pot 77	R11744		No.3 magazine tool data (Aux.D) pot 85
R11737		No.3 magazine tool data (Aux.D) pot 78	R11745		No.3 magazine tool data (Aux.D) pot 86
R11738		No.3 magazine tool data (Aux.D) pot 79	R11746		No.3 magazine tool data (Aux.D) pot 87
R11739		No.3 magazine tool data (Aux.D) pot 80	R11747		No.3 magazine tool data (Aux.D) pot 88
R11740		No.3 magazine tool data (Aux.D) pot 81	R11748		No.3 magazine tool data (Aux.D) pot 89
R11741		No.3 magazine tool data (Aux.D) pot 82	R11749		No.3 magazine tool data (Aux.D) pot 90
R11742		No.3 magazine tool data (Aux.D) pot 83	R11750		No.3 magazine tool data (Aux.D) pot 91
R11743		No.3 magazine tool data (Aux.D) pot 84	R11751		No.3 magazine tool data (Aux.D) pot 92

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11752		No.3 magazine tool data (Aux.D) pot 93	R11760		No.3 magazine tool data (Aux.D) pot 101
R11753		No.3 magazine tool data (Aux.D) pot 94	R11761		No.3 magazine tool data (Aux.D) pot 102
R11754		No.3 magazine tool data (Aux.D) pot 95	R11762		No.3 magazine tool data (Aux.D) pot 103
R11755		No.3 magazine tool data (Aux.D) pot 96	R11763		No.3 magazine tool data (Aux.D) pot 104
R11756		No.3 magazine tool data (Aux.D) pot 97	R11764		No.3 magazine tool data (Aux.D) pot 105
R11757		No.3 magazine tool data (Aux.D) pot 98	R11765		No.3 magazine tool data (Aux.D) pot 106
R11758		No.3 magazine tool data (Aux.D) pot 99	R11766		No.3 magazine tool data (Aux.D) pot 107
R11759		No.3 magazine tool data (Aux.D) pot 100	R11767		No.3 magazine tool data (Aux.D) pot 108

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R11768		No.3 magazine tool data (Aux.D) pot 109	R11776		No.3 magazine tool data (Aux.D) pot 117
R11769		No.3 magazine tool data (Aux.D) pot 110	R11777		No.3 magazine tool data (Aux.D) pot 118
R11770		No.3 magazine tool data (Aux.D) pot 111	R11778		No.3 magazine tool data (Aux.D) pot 119
R11771		No.3 magazine tool data (Aux.D) pot 112	R11779		No.3 magazine tool data (Aux.D) pot 120
R11772		No.3 magazine tool data (Aux.D) pot 113	R11780		
R11773		No.3 magazine tool data (Aux.D) pot 114	R11781		
R11774		No.3 magazine tool data (Aux.D) pot 115	R11782		
R11775		No.3 magazine tool data (Aux.D) pot 116	R11783		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R12200	R12210	R12220	R12230	R12240	R12250	R12260	R12270		Spindle tool No. (L)
R12201	R12211	R12221	R12231	R12241	R12251	R12261	R12271		Spindle tool No. (H)
R12202	R12212	R12222	R12232	R12242	R12252	R12262	R12272		Standby tool No. (L)
R12203	R12213	R12223	R12233	R12243	R12253	R12263	R12273		Standby tool No. (H)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.								Abbrev.	Signal name
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8		
R14700	R14950	R15200	R15450	R15700	R15950	R16200	R16450		MES interface library: Machining start time
R14701	R14951	R15201	R15451	R15701	R15951	R16201	R16451		
R14702	R14952	R15202	R15452	R15702	R15952	R16202	R16452		
R14703	R14953	R15203	R15453	R15703	R15953	R16203	R16453		MES interface library: Machining end time
R14704	R14954	R15204	R15454	R15704	R15954	R16204	R16454		MES interface library: Cycle time
R14705	R14955	R15205	R15455	R15705	R15955	R16205	R16455		
R14706	R14956	R15206	R15456	R15706	R15956	R16206	R16456		MES interface library: Program number at machining start
R14707	R14957	R15207	R15457	R15707	R15957	R16207	R16457		

Device No.								Abbrev.	Signal name
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8		
R14708	R14958	R15208	R15458	R15708	R15958	R16208	R16458		MES interface library: Program number at machining start
R14709	R14959	R15209	R15459	R15709	R15959	R16209	R16459		
R14710	R14960	R15210	R15460	R15710	R15960	R16210	R16460		
R14711	R14961	R15211	R15461	R15711	R15961	R16211	R16461		
R14712	R14962	R15212	R15462	R15712	R15962	R16212	R16462		
R14713	R14963	R15213	R15463	R15713	R15963	R16213	R16463		
R14714	R14964	R15214	R15464	R15714	R15964	R16214	R16464		
R14715	R14965	R15215	R15465	R15715	R15965	R16215	R16465		

Device No.								Abbrev.	Signal name
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8		
R14716	R14966	R15216	R15466	R15716	R15966	R16216	R16466		MES interface library: Program number at machining start
R14717	R14967	R15217	R15467	R15717	R15967	R16217	R16467		
R14718	R14968	R15218	R15468	R15718	R15968	R16218	R16468		
R14719	R14969	R15219	R15469	R15719	R15969	R16219	R16469		
R14720	R14970	R15220	R15470	R15720	R15970	R16220	R16470		
R14721	R14971	R15221	R15471	R15721	R15971	R16221	R16471		
R14722	R14972	R15222	R15472	R15722	R15972	R16222	R16472		MES interface library: N number at machining start
R14723	R14973	R15223	R15473	R15723	R15973	R16223	R16473		

Device No.								Abbrev.	Signal name
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8		
R14724	R14974	R15224	R15474	R15724	R15974	R16224	R16474		MES interface library: B number at machining start
R14725	R14975	R15225	R15475	R15725	R15975	R16225	R16475		
R14726	R14976	R15226	R15476	R15726	R15976	R16226	R16476		MES interface library: Spindle 1 maximum load
R14727	R14977	R15227	R15477	R15727	R15977	R16227	R16477		MES interface library: Spindle 2 maximum load
R14728	R14978	R15228	R15478	R15728	R15978	R16228	R16478		MES interface library: Power consumption amount
R14729	R14979	R15229	R15479	R15729	R15979	R16229	R16479		
R14730	R14980	R15230	R15480	R15730	R15980	R16230	R16480		MES interface library: Power regeneration amount
R14731	R14981	R15231	R15481	R15731	R15981	R16231	R16481		

Device No.								Abbrev.	Signal name
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8		
R14732	R14982	R15232	R15482	R15732	R15982	R16232	R16482		MES interface library: Tool number 1
R14733	R14983	R15233	R15483	R15733	R15983	R16233	R16483		
R14734	R14984	R15234	R15484	R15734	R15984	R16234	R16484		MES interface library: Tool number 2
R14735	R14985	R15235	R15485	R15735	R15985	R16235	R16485		
R14736	R14986	R15236	R15486	R15736	R15986	R16236	R16486		MES interface library: Tool number 3
R14737	R14987	R15237	R15487	R15737	R15987	R16237	R16487		
R14738	R14988	R15238	R15488	R15738	R15988	R16238	R16488		MES interface library: Tool number 4
R14739	R14989	R15239	R15489	R15739	R15989	R16239	R16489		

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14740	R14990	R15240	R15490	R15740	R15990	R16240	R16490		MES interface library: Tool number 5
R14741	R14991	R15241	R15491	R15741	R15991	R16241	R16491		
R14742	R14992	R15242	R15492	R15742	R15992	R16242	R16492		MES interface library: Tool offset number 1
R14743	R14993	R15243	R15493	R15743	R15993	R16243	R16493		MES interface library: Tool offset number 2
R14744	R14994	R15244	R15494	R15744	R15994	R16244	R16494		MES interface library: Tool offset number 3
R14745	R14995	R15245	R15495	R15745	R15995	R16245	R16495		MES interface library: Tool offset number 4
R14746	R14996	R15246	R15496	R15746	R15996	R16246	R16496		MES interface library: Tool offset number 5
R14747	R14997	R15247	R15497	R15747	R15997	R16247	R16497		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14748	R14998	R15248	R15498	R15748	R15998	R16248	R16498		MES interface library: Tool length offset 1
R14749	R14999	R15249	R15499	R15749	R15999	R16249	R16499		
R14750	R15000	R15250	R15500	R15750	R16000	R16250	R16500		MES interface library: Tool length offset 2
R14751	R15001	R15251	R15501	R15751	R16001	R16251	R16501		
R14752	R15002	R15252	R15502	R15752	R16002	R16252	R16502		MES interface library: Tool length offset 3
R14753	R15003	R15253	R15503	R15753	R16003	R16253	R16503		
R14754	R15004	R15254	R15504	R15754	R16004	R16254	R16504		MES interface library: Tool length offset 4
R14755	R15005	R15255	R15505	R15755	R16005	R16255	R16505		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14756	R15006	R15256	R15506	R15756	R16006	R16256	R16506		MES interface library: Tool length offset 5
R14757	R15007	R15257	R15507	R15757	R16007	R16257	R16507		
R14758	R15008	R15258	R15508	R15758	R16008	R16258	R16508		MES interface library: Tool radius offset 1
R14759	R15009	R15259	R15509	R15759	R16009	R16259	R16509		
R14760	R15010	R15260	R15510	R15760	R16010	R16260	R16510		MES interface library: Tool radius offset 2
R14761	R15011	R15261	R15511	R15761	R16011	R16261	R16511		
R14762	R15012	R15262	R15512	R15762	R16012	R16262	R16512		MES interface library: Tool radius offset 3
R14763	R15013	R15263	R15513	R15763	R16013	R16263	R16513		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14764	R15014	R15264	R15514	R15764	R16014	R16264	R16514		MES interface library: Tool radius offset 4
R14765	R15015	R15265	R15515	R15765	R16015	R16265	R16515		
R14766	R15016	R15266	R15516	R15766	R16016	R16266	R16516		MES interface library: Tool radius offset 5
R14767	R15017	R15267	R15517	R15767	R16017	R16267	R16517		
R14768	R15018	R15268	R15518	R15768	R16018	R16268	R16518		MES interface library: Tool length wear amount 1
R14769	R15019	R15269	R15519	R15769	R16019	R16269	R16519		
R14770	R15020	R15270	R15520	R15770	R16020	R16270	R16520		MES interface library: Tool length wear amount 2
R14771	R15021	R15271	R15521	R15771	R16021	R16271	R16521		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14772	R15022	R15272	R15522	R15772	R16022	R16272	R16522		MES interface library: Tool length wear amount 3
R14773	R15023	R15273	R15523	R15773	R16023	R16273	R16523		
R14774	R15024	R15274	R15524	R15774	R16024	R16274	R16524		MES interface library: Tool length wear amount 4
R14775	R15025	R15275	R15525	R15775	R16025	R16275	R16525		
R14776	R15026	R15276	R15526	R15776	R16026	R16276	R16526		MES interface library: Tool length wear amount 5
R14777	R15027	R15277	R15527	R15777	R16027	R16277	R16527		
R14778	R15028	R15278	R15528	R15778	R16028	R16278	R16528		MES interface library: Tool radius wear amount 1
R14779	R15029	R15279	R15529	R15779	R16029	R16279	R16529		

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.								Abbrev.	Signal name
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8		
R14780	R15030	R15280	R15530	R15780	R16030	R16280	R16530		MES interface library: Tool radius wear amount 2
R14781	R15031	R15281	R15531	R15781	R16031	R16281	R16531		
R14782	R15032	R15282	R15532	R15782	R16032	R16282	R16532		MES interface library: Tool radius wear amount 3
R14783	R15033	R15283	R15533	R15783	R16033	R16283	R16533		
R14784	R15034	R15284	R15534	R15784	R16034	R16284	R16534		MES interface library: Tool radius wear amount 4
R14785	R15035	R15285	R15535	R15785	R16035	R16285	R16535		
R14786	R15036	R15286	R15536	R15786	R16036	R16286	R16536		MES interface library: Tool radius wear amount 5
R14787	R15037	R15287	R15537	R15787	R16037	R16287	R16537		

Device No.								Abbrev.	Signal name
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8		
R14788	R15038	R15288	R15538	R15788	R16038	R16288	R16538		MES interface library: Tool life 1
R14789	R15039	R15289	R15539	R15789	R16039	R16289	R16539		
R14790	R15040	R15290	R15540	R15790	R16040	R16290	R16540		MES interface library: Tool life 2
R14791	R15041	R15291	R15541	R15791	R16041	R16291	R16541		
R14792	R15042	R15292	R15542	R15792	R16042	R16292	R16542		MES interface library: Tool life 3
R14793	R15043	R15293	R15543	R15793	R16043	R16293	R16543		
R14794	R15044	R15294	R15544	R15794	R16044	R16294	R16544		MES interface library: Tool life 4
R14795	R15045	R15295	R15545	R15795	R16045	R16295	R16545		

Device No.								Abbrev.	Signal name
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8		
R14796	R15046	R15296	R15546	R15796	R16046	R16296	R16546		MES interface library: Tool life 5
R14797	R15047	R15297	R15547	R15797	R16047	R16297	R16547		
R14798	R15048	R15298	R15548	R15798	R16048	R16298	R16548		MES interface library: Time of alarm occurrence
R14799	R15049	R15299	R15549	R15799	R16049	R16299	R16549		
R14800	R15050	R15300	R15550	R15800	R16050	R16300	R16550		MES interface library: Alarm number 1
R14801	R15051	R15301	R15551	R15801	R16051	R16301	R16551		
R14802	R15052	R15302	R15552	R15802	R16052	R16302	R16552		
R14803	R15053	R15303	R15553	R15803	R16053	R16303	R16553		

Device No.								Abbrev.	Signal name
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8		
R14804	R15054	R15304	R15554	R15804	R16054	R16304	R16554		MES interface library: Alarm number 1
R14805	R15055	R15305	R15555	R15805	R16055	R16305	R16555		
R14806	R15056	R15306	R15556	R15806	R16056	R16306	R16556		
R14807	R15057	R15307	R15557	R15807	R16057	R16307	R16557		
R14808	R15058	R15308	R15558	R15808	R16058	R16308	R16558		
R14809	R15059	R15309	R15559	R15809	R16059	R16309	R16559		
R14810	R15060	R15310	R15560	R15810	R16060	R16310	R16560		
R14811	R15061	R15311	R15561	R15811	R16061	R16311	R16561		

Device No.								Abbrev.	Signal name
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8		
R14812	R15062	R15312	R15562	R15812	R16062	R16312	R16562		MES interface library: Alarm number 1
R14813	R15063	R15313	R15563	R15813	R16063	R16313	R16563		
R14814	R15064	R15314	R15564	R15814	R16064	R16314	R16564		
R14815	R15065	R15315	R15565	R15815	R16065	R16315	R16565		
R14816	R15066	R15316	R15566	R15816	R16066	R16316	R16566		MES interface library: Alarm number 2
R14817	R15067	R15317	R15567	R15817	R16067	R16317	R16567		
R14818	R15068	R15318	R15568	R15818	R16068	R16318	R16568		
R14819	R15069	R15319	R15569	R15819	R16069	R16319	R16569		

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14820	R15070	R15320	R15570	R15820	R16070	R16320	R16570		MES interface library: Alarm number 2
R14821	R15071	R15321	R15571	R15821	R16071	R16321	R16571		
R14822	R15072	R15322	R15572	R15822	R16072	R16322	R16572		
R14823	R15073	R15323	R15573	R15823	R16073	R16323	R16573		
R14824	R15074	R15324	R15574	R15824	R16074	R16324	R16574		
R14825	R15075	R15325	R15575	R15825	R16075	R16325	R16575		
R14826	R15076	R15326	R15576	R15826	R16076	R16326	R16576		
R14827	R15077	R15327	R15577	R15827	R16077	R16327	R16577		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14828	R15078	R15328	R15578	R15828	R16078	R16328	R16578		MES interface library: Alarm number 2
R14829	R15079	R15329	R15579	R15829	R16079	R16329	R16579		
R14830	R15080	R15330	R15580	R15830	R16080	R16330	R16580		
R14831	R15081	R15331	R15581	R15831	R16081	R16331	R16581		
R14832	R15082	R15332	R15582	R15832	R16082	R16332	R16582		MES interface library: Alarm number 3
R14833	R15083	R15333	R15583	R15833	R16083	R16333	R16583		
R14834	R15084	R15334	R15584	R15834	R16084	R16334	R16584		
R14835	R15085	R15335	R15585	R15835	R16085	R16335	R16585		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14836	R15086	R15336	R15586	R15836	R16086	R16336	R16586		MES interface library: Alarm number 3
R14837	R15087	R15337	R15587	R15837	R16087	R16337	R16587		
R14838	R15088	R15338	R15588	R15838	R16088	R16338	R16588		
R14839	R15089	R15339	R15589	R15839	R16089	R16339	R16589		
R14840	R15090	R15340	R15590	R15840	R16090	R16340	R16590		
R14841	R15091	R15341	R15591	R15841	R16091	R16341	R16591		
R14842	R15092	R15342	R15592	R15842	R16092	R16342	R16592		
R14843	R15093	R15343	R15593	R15843	R16093	R16343	R16593		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14844	R15094	R15344	R15594	R15844	R16094	R16344	R16594		MES interface library: Alarm number 3
R14845	R15095	R15345	R15595	R15845	R16095	R16345	R16595		
R14846	R15096	R15346	R15596	R15846	R16096	R16346	R16596		
R14847	R15097	R15347	R15597	R15847	R16097	R16347	R16597		
R14848	R15098	R15348	R15598	R15848	R16098	R16348	R16598		MES interface library: Alarm number 4
R14849	R15099	R15349	R15599	R15849	R16099	R16349	R16599		
R14850	R15100	R15350	R15600	R15850	R16100	R16350	R16600		
R14851	R15101	R15351	R15601	R15851	R16101	R16351	R16601		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14852	R15102	R15352	R15602	R15852	R16102	R16352	R16602		MES interface library: Alarm number 4
R14853	R15103	R15353	R15603	R15853	R16103	R16353	R16603		
R14854	R15104	R15354	R15604	R15854	R16104	R16354	R16604		
R14855	R15105	R15355	R15605	R15855	R16105	R16355	R16605		
R14856	R15106	R15356	R15606	R15856	R16106	R16356	R16606		
R14857	R15107	R15357	R15607	R15857	R16107	R16357	R16607		
R14858	R15108	R15358	R15608	R15858	R16108	R16358	R16608		
R14859	R15109	R15359	R15609	R15859	R16109	R16359	R16609		

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14860	R15110	R15360	R15610	R15860	R16110	R16360	R16610		MES interface library: Alarm number 4
R14861	R15111	R15361	R15611	R15861	R16111	R16361	R16611		
R14862	R15112	R15362	R15612	R15862	R16112	R16362	R16612		
R14863	R15113	R15363	R15613	R15863	R16113	R16363	R16613		
R14864	R15114	R15364	R15614	R15864	R16114	R16364	R16614		MES interface library: Power ON time
R14865	R15115	R15365	R15615	R15865	R16115	R16365	R16615		
R14866	R15116	R15366	R15616	R15866	R16116	R16366	R16616		MES interface library: Program number at alarm
R14867	R15117	R15367	R15617	R15867	R16117	R16367	R16617		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14868	R15118	R15368	R15618	R15868	R16118	R16368	R16618		MES interface library: Program number at alarm
R14869	R15119	R15369	R15619	R15869	R16119	R16369	R16619		
R14870	R15120	R15370	R15620	R15870	R16120	R16370	R16620		
R14871	R15121	R15371	R15621	R15871	R16121	R16371	R16621		
R14872	R15122	R15372	R15622	R15872	R16122	R16372	R16622		
R14873	R15123	R15373	R15623	R15873	R16123	R16373	R16623		
R14874	R15124	R15374	R15624	R15874	R16124	R16374	R16624		
R14875	R15125	R15375	R15625	R15875	R16125	R16375	R16625		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14876	R15126	R15376	R15626	R15876	R16126	R16376	R16626		MES interface library: Program number at alarm
R14877	R15127	R15377	R15627	R15877	R16127	R16377	R16627		
R14878	R15128	R15378	R15628	R15878	R16128	R16378	R16628		
R14879	R15129	R15379	R15629	R15879	R16129	R16379	R16629		
R14880	R15130	R15380	R15630	R15880	R16130	R16380	R16630		
R14881	R15131	R15381	R15631	R15881	R16131	R16381	R16631		
R14882	R15132	R15382	R15632	R15882	R16132	R16382	R16632		MES interface library: Subprogram number at alarm
R14883	R15133	R15383	R15633	R15883	R16133	R16383	R16633		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14884	R15134	R15384	R15634	R15884	R16134	R16384	R16634		MES interface library: Subprogram number at alarm
R14885	R15135	R15385	R15635	R15885	R16135	R16385	R16635		
R14886	R15136	R15386	R15636	R15886	R16136	R16386	R16636		
R14887	R15137	R15387	R15637	R15887	R16137	R16387	R16637		
R14888	R15138	R15388	R15638	R15888	R16138	R16388	R16638		
R14889	R15139	R15389	R15639	R15889	R16139	R16389	R16639		
R14890	R15140	R15390	R15640	R15890	R16140	R16390	R16640		
R14891	R15141	R15391	R15641	R15891	R16141	R16391	R16641		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14892	R15142	R15392	R15642	R15892	R16142	R16392	R16642		MES interface library: Subprogram number at alarm
R14893	R15143	R15393	R15643	R15893	R16143	R16393	R16643		
R14894	R15144	R15394	R15644	R15894	R16144	R16394	R16644		
R14895	R15145	R15395	R15645	R15895	R16145	R16395	R16645		
R14896	R15146	R15396	R15646	R15896	R16146	R16396	R16646		
R14897	R15147	R15397	R15647	R15897	R16147	R16397	R16647		
R14898	R15148	R15398	R15648	R15898	R16148	R16398	R16648		MES interface library: N number at alarm
R14899	R15149	R15399	R15649	R15899	R16149	R16399	R16649		

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14900	R15150	R15400	R15650	R15900	R16150	R16400	R16650		MES interface library: B number at alarm
R14901	R15151	R15401	R15651	R15901	R16151	R16401	R16651		
R14902	R15152	R15402	R15652	R15902	R16152	R16402	R16652		
R14903	R15153	R15403	R15653	R15903	R16153	R16403	R16653		MES interface library: G code modal status
R14904	R15154	R15404	R15654	R15904	R16154	R16404	R16654		
R14905	R15155	R15405	R15655	R15905	R16155	R16405	R16655		
R14906	R15156	R15406	R15656	R15906	R16156	R16406	R16656		
R14907	R15157	R15407	R15657	R15907	R16157	R16407	R16657		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14908	R15158	R15408	R15658	R15908	R16158	R16408	R16658		MES interface library: G code modal status
R14909	R15159	R15409	R15659	R15909	R16159	R16409	R16659		
R14910	R15160	R15410	R15660	R15910	R16160	R16410	R16660		
R14911	R15161	R15411	R15661	R15911	R16161	R16411	R16661		
R14912	R15162	R15412	R15662	R15912	R16162	R16412	R16662		
R14913	R15163	R15413	R15663	R15913	R16163	R16413	R16663		
R14914	R15164	R15414	R15664	R15914	R16164	R16414	R16664		
R14915	R15165	R15415	R15665	R15915	R16165	R16415	R16665		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14916	R15166	R15416	R15666	R15916	R16166	R16416	R16666		MES interface library: G code modal status
R14917	R15167	R15417	R15667	R15917	R16167	R16417	R16667		
R14918	R15168	R15418	R15668	R15918	R16168	R16418	R16668		
R14919	R15169	R15419	R15669	R15919	R16169	R16419	R16669		
R14920	R15170	R15420	R15670	R15920	R16170	R16420	R16670		
R14921	R15171	R15421	R15671	R15921	R16171	R16421	R16671		
R14922	R15172	R15422	R15672	R15922	R16172	R16422	R16672		
R14923	R15173	R15423	R15673	R15923	R16173	R16423	R16673		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14924	R15174	R15424	R15674	R15924	R16174	R16424	R16674		MES interface library: G code modal status
R14925	R15175	R15425	R15675	R15925	R16175	R16425	R16675		
R14926	R15176	R15426	R15676	R15926	R16176	R16426	R16676		
R14927	R15177	R15427	R15677	R15927	R16177	R16427	R16677		
R14928	R15178	R15428	R15678	R15928	R16178	R16428	R16678		
R14929	R15179	R15429	R15679	R15929	R16179	R16429	R16679		
R14930	R15180	R15430	R15680	R15930	R16180	R16430	R16680		
R14931	R15181	R15431	R15681	R15931	R16181	R16431	R16681		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R14932	R15182	R15432	R15682	R15932	R16182	R16432	R16682		MES interface library: G code modal status
R14933	R15183	R15433	R15683	R15933	R16183	R16433	R16683		
R14934	R15184	R15434	R15684	R15934	R16184	R16434	R16684		MES interface library: Spindle 1 load value
R14935	R15185	R15435	R15685	R15935	R16185	R16435	R16685		MES interface library: Spindle 2 load value
R14936	R15186	R15436	R15686	R15936	R16186	R16436	R16686		MES interface library: Tool number
R14937	R15187	R15437	R15687	R15937	R16187	R16437	R16687		
R14938	R15188	R15438	R15688	R15938	R16188	R16438	R16688		MES interface library: Tool offset number
R14939	R15189	R15439	R15689	R15939	R16189	R16439	R16689		

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.								Abbrev.	Signal name
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8		
R14940	R15190	R15440	R15690	R15940	R16190	R16440	R16690		MES interface library: Tool length offset
R14941	R15191	R15441	R15691	R15941	R16191	R16441	R16691		
R14942	R15192	R15442	R15692	R15942	R16192	R16442	R16692		MES interface library: Tool radius offset
R14943	R15193	R15443	R15693	R15943	R16193	R16443	R16693		
R14944	R15194	R15444	R15694	R15944	R16194	R16444	R16694		MES interface library: Tool length wear amount
R14945	R15195	R15445	R15695	R15945	R16195	R16445	R16695		
R14946	R15196	R15446	R15696	R15946	R16196	R16446	R16696		MES interface library: Tool radius wear amount
R14947	R15197	R15447	R15697	R15947	R16197	R16447	R16697		

Device No.								Abbrev.	Signal name
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8		
R14948	R15198	R15448	R15698	R15948	R16198	R16448	R16698		MES interface library: Tool life
R14949	R15199	R15449	R15699	R15949	R16199	R16449	R16699		

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20200		Skip coordinate (PLC axis 1st axis) ▲	R20208		Skip coordinate (PLC axis 3rd axis) ▲
R20201			R20209		
R20202			R20210		
R20203			R20211		
R20204		Skip coordinate (PLC axis 2nd axis) ▲	R20212		Skip coordinate (PLC axis 4th axis) ▲
R20205			R20213		
R20206			R20214		
R20207			R20215		

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20216		Skip coordinate (PLC axis 5th axis) ▲	R20224		
R20217			R20225		
R20218			R20226		
R20219			R20227		
R20220		Skip coordinate (PLC axis 6th axis) ▲	R20228		
R20221			R20229		
R20222			R20230		
R20223			R20231		

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20232		Feedback machine position (PLC axis 1st axis) ▲	R20240		Feedback machine position (PLC axis 3rd axis) ▲
R20233			R20241		
R20234			R20242		
R20235			R20243		
R20236		Feedback machine position (PLC axis 2nd axis) ▲	R20244		Feedback machine position (PLC axis 4th axis) ▲
R20237			R20245		
R20238			R20246		
R20239			R20247		

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20248		Feedback machine position (PLC axis 5th axis) ▲	R20256		
R20249			R20257		
R20250			R20258		
R20251			R20259		
R20252		Feedback machine position (PLC axis 6th axis) ▲	R20260		
R20253			R20261		
R20254			R20262		
R20255			R20263		

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20264		Servo deflection amount (PLC axis 1st axis) ▲	R20272		Servo deflection amount (PLC axis 5th axis) ▲
R20265			R20273		
R20266		Servo deflection amount (PLC axis 2nd axis) ▲	R20274		Servo deflection amount (PLC axis 6th axis) ▲
R20267			R20275		
R20268		Servo deflection amount (PLC axis 3rd axis) ▲	R20276		
R20269			R20277		
R20270		Servo deflection amount (PLC axis 4th axis) ▲	R20278		
R20271			R20279		

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20280	RNASP	FL-net: Reference node address designation ▲	R20288		EcoMonitorLight connection: Read start bit
R20281	PNASP	FL-net: Participating node top address designation ▲	R20289		EcoMonitorLight connection: Station No.
R20282			R20290		EcoMonitorLight connection: Register address
R20283			R20291		EcoMonitorLight connection: Size of data to read
R20284			R20292		
R20285			R20293		
R20286			R20294		
R20287			R20295		

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20296			R20304		Interference check III: Interfering object enable/disable designation
R20297			R20305		Spare
R20298			R20306		Interference check III: 1st interfering object selection
R20299			R20307		Interference check III: 1st interfering object specification
R20300			R20308		Interference check III: 1st interfering model coordinate system I axis offset 1 (L)
R20301			R20309		Interference check III: 1st interfering model coordinate system I axis offset 1 (H)
R20302			R20310		Interference check III: 1st interfering model coordinate system J axis offset 1 (L)
R20303			R20311		Interference check III: 1st interfering model coordinate system J axis offset 1 (H)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20312		Interference check III: 1st interfering model coordinate system K axis offset 1 (L)	R20320		Interference check III: 2nd interfering model coordinate system K axis offset 1 (L)
R20313		Interference check III: 1st interfering model coordinate system K axis offset 1 (H)	R20321		Interference check III: 2nd interfering model coordinate system K axis offset 1 (H)
R20314		Interference check III: 2nd interfering object selection	R20322		Interference check III: 3rd interfering object selection
R20315		Interference check III: 2nd interfering object specification	R20323		Interference check III: 3rd interfering object specification
R20316		Interference check III: 2nd interfering model coordinate system I axis offset 1 (L)	R20324		Interference check III: 3rd interfering model coordinate system I axis offset 1 (L)
R20317		Interference check III: 2nd interfering model coordinate system I axis offset 1 (H)	R20325		Interference check III: 3rd interfering model coordinate system I axis offset 1 (H)
R20318		Interference check III: 2nd interfering model coordinate system J axis offset 1 (L)	R20326		Interference check III: 3rd interfering model coordinate system J axis offset 1 (L)
R20319		Interference check III: 2nd interfering model coordinate system J axis offset 1 (H)	R20327		Interference check III: 3rd interfering model coordinate system J axis offset 1 (H)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20328		Interference check III: 3rd interfering model coordinate system K axis offset 1 (L)	R20336		Interference check III: 4th interfering model coordinate system K axis offset 1 (L)
R20329		Interference check III: 3rd interfering model coordinate system K axis offset 1 (H)	R20337		Interference check III: 4th interfering model coordinate system K axis offset 1 (H)
R20330		Interference check III: 4th interfering object selection	R20338		Interference check III: 5th interfering object selection
R20331		Interference check III: 4th interfering object specification	R20339		Interference check III: 5th interfering object specification
R20332		Interference check III: 4th interfering model coordinate system I axis offset 1 (L)	R20340		Interference check III: 5th interfering model coordinate system I axis offset 1 (L)
R20333		Interference check III: 4th interfering model coordinate system I axis offset 1 (H)	R20341		Interference check III: 5th interfering model coordinate system I axis offset 1 (H)
R20334		Interference check III: 4th interfering model coordinate system J axis offset 1 (L)	R20342		Interference check III: 5th interfering model coordinate system J axis offset 1 (L)
R20335		Interference check III: 4th interfering model coordinate system J axis offset 1 (H)	R20343		Interference check III: 5th interfering model coordinate system J axis offset 1 (H)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20344		Interference check III: 5th interfering model coordinate system K axis offset 1 (L)	R20352		Interference check III: 6th interfering model coordinate system K axis offset 1 (L)
R20345		Interference check III: 5th interfering model coordinate system K axis offset 1 (H)	R20353		Interference check III: 6th interfering model coordinate system K axis offset 1 (H)
R20346		Interference check III: 6th interfering object selection	R20354		Interference check III: 7th interfering object selection
R20347		Interference check III: 6th interfering object specification	R20355		Interference check III: 7th interfering object specification
R20348		Interference check III: 6th interfering model coordinate system I axis offset 1 (L)	R20356		Interference check III: 7th interfering model coordinate system I axis offset 1 (L)
R20349		Interference check III: 6th interfering model coordinate system I axis offset 1 (H)	R20357		Interference check III: 7th interfering model coordinate system I axis offset 1 (H)
R20350		Interference check III: 6th interfering model coordinate system J axis offset 1 (L)	R20358		Interference check III: 7th interfering model coordinate system J axis offset 1 (L)
R20351		Interference check III: 6th interfering model coordinate system J axis offset 1 (H)	R20359		Interference check III: 7th interfering model coordinate system J axis offset 1 (H)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20360		Interference check III: 7th interfering model coordinate system K axis offset 1 (L)	R20368		Interference check III: 8th interfering model coordinate system K axis offset 1 (L)
R20361		Interference check III: 7th interfering model coordinate system K axis offset 1 (H)	R20369		Interference check III: 8th interfering model coordinate system K axis offset 1 (H)
R20362		Interference check III: 8th interfering object selection	R20370		Interference check III: 9th interfering object selection
R20363		Interference check III: 8th interfering object specification	R20371		Interference check III: 9th interfering object specification
R20364		Interference check III: 8th interfering model coordinate system I axis offset 1 (L)	R20372		Interference check III: 9th interfering model coordinate system I axis offset 1 (L)
R20365		Interference check III: 8th interfering model coordinate system I axis offset 1 (H)	R20373		Interference check III: 9th interfering model coordinate system I axis offset 1 (H)
R20366		Interference check III: 8th interfering model coordinate system J axis offset 1 (L)	R20374		Interference check III: 9th interfering model coordinate system J axis offset 1 (L)
R20367		Interference check III: 8th interfering model coordinate system J axis offset 1 (H)	R20375		Interference check III: 9th interfering model coordinate system J axis offset 1 (H)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20376		Interference check III: 9th interfering model coordinate system K axis offset 1 (L)	R20384		Interference check III: 10th interfering model coordinate system K axis offset 1 (L)
R20377		Interference check III: 9th interfering model coordinate system K axis offset 1 (H)	R20385		Interference check III: 10th interfering model coordinate system K axis offset 1 (H)
R20378		Interference check III: 10th interfering object selection	R20386		Interference check III: 11th interfering object selection
R20379		Interference check III: 10th interfering object specification	R20387		Interference check III: 11th interfering object specification
R20380		Interference check III: 10th interfering model coordinate system I axis offset 1 (L)	R20388		Interference check III: 11th interfering model coordinate system I axis offset 1 (L)
R20381		Interference check III: 10th interfering model coordinate system I axis offset 1 (H)	R20389		Interference check III: 11th interfering model coordinate system I axis offset 1 (H)
R20382		Interference check III: 10th interfering model coordinate system J axis offset 1 (L)	R20390		Interference check III: 11th interfering model coordinate system J axis offset 1 (L)
R20383		Interference check III: 10th interfering model coordinate system J axis offset 1 (H)	R20391		Interference check III: 11th interfering model coordinate system J axis offset 1 (H)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20392		Interference check III: 11th interfering model coordinate system K axis offset 1 (L)	R20400		Interference check III: 12th interfering model coordinate system K axis offset 1 (L)
R20393		Interference check III: 11th interfering model coordinate system K axis offset 1 (H)	R20401		Interference check III: 12th interfering model coordinate system K axis offset 1 (H)
R20394		Interference check III: 12th interfering object selection	R20402		Interference check III: 13th interfering object selection
R20395		Interference check III: 12th interfering object specification	R20403		Interference check III: 13th interfering object specification
R20396		Interference check III: 12th interfering model coordinate system I axis offset 1 (L)	R20404		Interference check III: 13th interfering model coordinate system I axis offset 1 (L)
R20397		Interference check III: 12th interfering model coordinate system I axis offset 1 (H)	R20405		Interference check III: 13th interfering model coordinate system I axis offset 1 (H)
R20398		Interference check III: 12th interfering model coordinate system J axis offset 1 (L)	R20406		Interference check III: 13th interfering model coordinate system J axis offset 1 (L)
R20399		Interference check III: 12th interfering model coordinate system J axis offset 1 (H)	R20407		Interference check III: 13th interfering model coordinate system J axis offset 1 (H)

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20408		Interference check III: 13th interfering model coordinate system K axis offset 1 (L)	R20416		Interference check III: 14th interfering model coordinate system K axis offset 1 (L)
R20409		Interference check III: 13th interfering model coordinate system K axis offset 1 (H)	R20417		Interference check III: 14th interfering model coordinate system K axis offset 1 (H)
R20410		Interference check III: 14th interfering object selection	R20418		Interference check III: 15th interfering object selection
R20411		Interference check III: 14th interfering object specification	R20419		Interference check III: 15th interfering object specification
R20412		Interference check III: 14th interfering model coordinate system I axis offset 1 (L)	R20420		Interference check III: 15th interfering model coordinate system I axis offset 1 (L)
R20413		Interference check III: 14th interfering model coordinate system I axis offset 1 (H)	R20421		Interference check III: 15th interfering model coordinate system I axis offset 1 (H)
R20414		Interference check III: 14th interfering model coordinate system J axis offset 1 (L)	R20422		Interference check III: 15th interfering model coordinate system J axis offset 1 (L)
R20415		Interference check III: 14th interfering model coordinate system J axis offset 1 (H)	R20423		Interference check III: 15th interfering model coordinate system J axis offset 1 (H)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20424		Interference check III: 15th interfering model coordinate system K axis offset 1 (L)	R20432		Interference check III: 16th interfering model coordinate system K axis offset 1 (L)
R20425		Interference check III: 15th interfering model coordinate system K axis offset 1 (H)	R20433		Interference check III: 16th interfering model coordinate system K axis offset 1 (H)
R20426		Interference check III: 16th interfering object selection	R20434		1st interfering object: Specifying disabled object with interference check III
R20427		Interference check III: 16th interfering object specification	R20435		2nd interfering object: Specifying disabled object with interference check III
R20428		Interference check III: 16th interfering model coordinate system I axis offset 1 (L)	R20436		3rd interfering object: Specifying disabled object with interference check III
R20429		Interference check III: 16th interfering model coordinate system I axis offset 1 (H)	R20437		4th interfering object: Specifying disabled object with interference check III
R20430		Interference check III: 16th interfering model coordinate system J axis offset 1 (L)	R20438		5th interfering object: Specifying disabled object with interference check III
R20431		Interference check III: 16th interfering model coordinate system J axis offset 1 (H)	R20439		6th interfering object: Specifying disabled object with interference check III

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20440		7th interfering object: Specifying disabled object with interference check III	R20448		15th interfering object: Specifying disabled object with interference check III
R20441		8th interfering object: Specifying disabled object with interference check III	R20449		16th interfering object: Specifying disabled object with interference check III
R20442		9th interfering object: Specifying disabled object with interference check III	R20450	SVIDDD AX	Diagnosis data output: Select axis for servomotor insulation degradation detection (PLC axis)
R20443		10th interfering object: Specifying disabled object with interference check III	R20451	SPIDDD AX	Diagnosis data output: Select spindle for motor insulation degradation detection
R20444		11th interfering object: Specifying disabled object with interference check III	R20452		
R20445		12th interfering object: Specifying disabled object with interference check III	R20453		Laser: Laser output override
R20446		13th interfering object: Specifying disabled object with interference check III	R20454		
R20447		14th interfering object: Specifying disabled object with interference check III	R20455		

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20456		Arbitrary-assigned PSW for each part system 1 to 16 interlock ▲	R20464		
R20457		Arbitrary-assigned PSW for each part system 17 to 32 interlock ▲	R20465		
R20458		Arbitrary-assigned PSW for each part system 33 to 48 interlock ▲	R20466		
R20459		Arbitrary-assigned PSW for each part system 49 to 64 interlock ▲	R20467		
R20460			R20468		
R20461			R20469		
R20462			R20470		
R20463			R20471		

Common (\$)	Abbrev.	Signal name	Common (\$)	Abbrev.	Signal name
R20472			R20480	TP_IN- VALID	Touchscreen operation disabled
R20473			R20481	IDDD	Diagnosis data output: Motor insulation degradation detection request
R20474			R20482		
R20475			R20483		
R20476			R20484		
R20477			R20485		
R20478			R20486		
R20479			R20487		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R22500	R22700	R22900	R23100	R23300	R23500	R23700	R23900		Program restart: Restart position return check invalid
R22501	R22701	R22901	R23101	R23301	R23501	R23701	R23901	SVIDDD AX	Diagnosis data output: Select axis for servomotor insulation degradation detection
R22502	R22702	R22902	R23102	R23302	R23502	R23702	R23902	PTPS	Manual arbitrary feed: Dedicated feedrate ▲
R22503	R22703	R22903	R23103	R23303	R23503	R23703	R23903		
R22504	R22704	R22904	R23104	R23304	R23504	R23704	R23904		
R22505	R22705	R22905	R23105	R23305	R23505	R23705	R23905		
R22506	R22706	R22906	R23106	R23306	R23506	R23706	R23906		
R22507	R22707	R22907	R23107	R23307	R23507	R23707	R23907		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R22508	R22708	R22908	R23108	R23308	R23508	R23708	R23908		
R22509	R22709	R22909	R23109	R23309	R23509	R23709	R23909		
R22510	R22710	R22910	R23110	R23310	R23510	R23710	R23910		
R22511	R22711	R22911	R23111	R23311	R23511	R23711	R23911		
R22512	R22712	R22912	R23112	R23312	R23512	R23712	R23912		
R22513	R22713	R22913	R23113	R23313	R23513	R23713	R23913		
R22514	R22714	R22914	R23114	R23314	R23514	R23714	R23914		
R22515	R22715	R22915	R23115	R23315	R23515	R23715	R23915		

2 Input/Output Signals with Controller

2.4 PLC Output Signals (Data Type: R***)

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R22532	R22732	R22932	R23132	R23332	R23532	R23732	R23932	VCC_IN-VAX	VCC: Temporary cancel of axis vibration
R22533	R22733	R22933	R23133	R23333	R23533	R23733	R23933		
R22534	R22734	R22934	R23134	R23334	R23534	R23734	R23934		
R22535	R22735	R22935	R23135	R23335	R23535	R23735	R23935		
R22536	R22736	R22936	R23136	R23336	R23536	R23736	R23936		
R22537	R22737	R22937	R23137	R23337	R23537	R23737	R23937		
R22538	R22738	R22938	R23138	R23338	R23538	R23738	R23938		
R22539	R22739	R22939	R23139	R23339	R23539	R23739	R23939		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R22540	R22740	R22940	R23140	R23340	R23540	R23740	R23940		CLC: Spindle selection
R22541	R22741	R22941	R23141	R23341	R23541	R23741	R23941		
R22542	R22742	R22942	R23142	R23342	R23542	R23742	R23942		
R22543	R22743	R22943	R23143	R23343	R23543	R23743	R23943		
R22544	R22744	R22944	R23144	R23344	R23544	R23744	R23944		
R22545	R22745	R22945	R23145	R23345	R23545	R23745	R23945		
R22546	R22746	R22946	R23146	R23346	R23546	R23746	R23946		
R22547	R22747	R22947	R23147	R23347	R23547	R23747	R23947		

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R22692	R22892	R23092	R23292	R23492	R23692	R23892	R24092		Load monitor I: Cutting torque estimation target axis ▲
R22693	R22893	R23093	R23293	R23493	R23693	R23893	R24093		Hob machining: Work piece axis selection ▲
R22694	R22894	R23094	R23294	R23494	R23694	R23894	R24094	SPPWS	Tool spindle synchronization IB: Spindle-spindle polygon cut workpiece axis selection ▲
R22695	R22895	R23095	R23295	R23495	R23695	R23895	R24095		
R22696	R22896	R23096	R23296	R23496	R23696	R23896	R24096		
R22697	R22897	R23097	R23297	R23497	R23697	R23897	R24097		
R22698	R22898	R23098	R23298	R23498	R23698	R23898	R24098		
R22699	R22899	R23099	R23299	R23499	R23699	R23899	R24099		

2.5 Special Relay/Special Register

Device	Abbrev.	Signal name	Device	Abbrev.	Signal name
SM00			SM08		
SM01			SM09		
SM02			SM10		
SM03			SM11		
SM04			SM12		
SM05			SM13		
SM06			SM14		
SM07			SM15		

Device	Abbrev.	Signal name	Device	Abbrev.	Signal name
SM16		Temperature rise	SM24		
SM17			SM25		
SM18			SM26		
SM19			SM27		
SM20			SM28		
SM21			SM29		
SM22			SM30		
SM23			SM31		

Device	Abbrev.	Signal name	Device	Abbrev.	Signal name
SM32			SM40		
SM33			SM41		
SM34			SM42		
SM35			SM43		
SM36			SM44		
SM37			SM45		
SM38			SM46		
SM39			SM47		

Device	Abbrev.	Signal name	Device	Abbrev.	Signal name
SM48			SM56		
SM49			SM57		
SM50			SM58		
SM51			SM59		
SM52			SM60		
SM53			SM61		
SM54			SM62		
SM55			SM63		

2 Input/Output Signals with Controller

2.5 Special Relay/Special Register

Device	Abbrev.	Signal name	Device	Abbrev.	Signal name
SM64			SM72		
SM65			SM73		
SM66			SM74		
SM67			SM75		
SM68			SM76		
SM69			SM77		
SM70			SM78		
SM71			SM79		

Device	Abbrev.	Signal name	Device	Abbrev.	Signal name
SM80			SM88		
SM81			SM89		
SM82			SM90		
SM83			SM91		
SM84			SM92		
SM85			SM93		
SM86			SM94		
SM87			SM95		

Device	Abbrev.	Signal name	Device	Abbrev.	Signal name
SM96			SM104		
SM97			SM105		
SM98			SM106		
SM99			SM107		
SM100			SM108		
SM101			SM109		
SM102			SM110		
SM103			SM111		

Device	Abbrev.	Signal name	Device	Abbrev.	Signal name
SM112			SM120		
SM113			SM121		
SM114			SM122		
SM115			SM123		
SM116			SM124		
SM117			SM125		
SM118			SM126		
SM119			SM127		

2.6 ZR Devices

■ Smart safety observation

[PLC -> CNC]

Device	Abbrev.	Signal name
ZR256	*SLSRm	SLS observation request (control axis) 1st axis to 16th axis
ZR257	*SLSRm	SLS observation request (control axis) 17th axis to 32nd axis
ZR258	*SLPRm	SLP observation request (control axis) 1st axis to 16th axis
ZR259	*SLPRm	SLP observation request (control axis) 17th axis to 32nd axis
ZR260	*SSMRm	SSM request (control axis) 1st axis to 16th axis
ZR261	*SSMRm	SSM request (control axis) 17th axis to 32nd axis
ZR262	*SCARm	Safe cam request (control axis) 1st axis to 16th axis
ZR263	*SCARm	Safe cam request (control axis) 17th axis to 32nd axis
ZR264	*SOSRm	SOS observation request (control axis) 1st axis to 16th axis
ZR265	*SOSRm	SOS observation request (control axis) 17th axis to 32nd axis
ZR266	*SS1Rm	Safe stop 1 request (control axis) 1st axis to 16th axis
ZR267	*SS1Rm	Safe stop 1 request (control axis) 17th axis to 32nd axis
ZR268	*SS2Rm	Safe stop 2 request (control axis) 1st axis to 16th axis
ZR269	*SS2Rm	Safe stop 2 request (control axis) 17th axis to 32nd axis
ZR270	*STORm	Safe torque OFF request (control axis) 1st axis to 16th axis
ZR271	*STORm	Safe torque OFF request (control axis) 17th axis to 32nd axis
ZR272	*SBCRm	SBC motor brake starting request (control axis) 1st axis to 16th axis
ZR273	*SBCRm	SBC motor brake starting request (control axis) 17th axis to 32nd axis
ZR274	SBTSTEXm	External brake SBT start (control axis) 1st axis to 16th axis
ZR275	SBTSTEXm	External brake SBT start (control axis) 17th axis to 32nd axis
ZR276	SBTSTMOm	Motor brake SBT start (control axis) 1st axis to 16th axis
ZR277	SBTSTMOm	Motor brake SBT start (control axis) 17th axis to 32nd axis
ZR278	SFABSPFXm	Safety absolute position confirm (control axis) 1st axis to 16th axis
ZR279	SFABSPFXm	Safety absolute position confirm (control axis) 17th axis to 32nd axis
ZR280	SRSTm	Safety reset (control axis) 1st axis to 16th axis
ZR281	SRSTm	Safety reset (control axis) 17th axis to 32nd axis

Device	Abbrev.	bit	Signal name
ZR312 to ZR343	SLSMImn	bit0	SLS speed change input (control axis) 1st axis to 32nd axis
	SLSMImn	bit1	SLS speed change input (control axis) 1st axis to 32nd axis
		bit2	vacant
		bit3	vacant
	SLSOVRImn	bit4	SLS speed override input (control axis) 1st axis to 32nd axis
	SLSOVRImn	bit5	SLS speed override input (control axis) 1st axis to 32nd axis
	SLSOVRImn	bit6	SLS speed override input (control axis) 1st axis to 32nd axis
	SLSOVRImn	bit7	SLS speed override input (control axis) 1st axis to 32nd axis
		bit8	vacant
		bit9	vacant
		bitA	vacant
		bitB	vacant
		bitC	vacant
		bitD	vacant
		bitE	vacant
		bitF	vacant

2 Input/Output Signals with Controller

2.6 ZR Devices

Device	Abbrev.	bit	Signal name
ZR344 to ZR375	SLPmImn	bit0	SLP position change input (control axis) 1st axis to 32nd axis
	SLPmImn	bit1	SLP position change input (control axis) 1st axis to 32nd axis
		bit2	vacant
		bit3	vacant
		bit4	vacant
		bit5	vacant
		bit6	vacant
		bit7	vacant
		bit8	vacant
		bit9	vacant
		bitA	vacant
		bitB	vacant
		bitC	vacant
		bitD	vacant
		bitE	vacant
		bitF	vacant

Device	Abbrev.	Signal name
ZR440	*SLSSRm	SLS observation request (spindle) 1st SP to 8th SP
ZR442	*SSMSRm	SSM request (spindle) 1st SP to 8th SP
ZR444	*SOSSRm	SOS observation request (spindle) 1st SP to 8th SP
ZR445	*SS1SRm	Safe stop 1 request (spindle) 1st SP to 8th SP
ZR446	*SS2SRm	Safe stop 2 request (spindle) 1st SP to 8th SP
ZR447	*STOSRm	Safe torque OFF request (spindle) 1st SP to 8th SP
ZR452	SRSTSm	Safety request (spindle) 1st SP to 8th SP

Device	Abbrev.	bit	Signal name
ZR468 to ZR475	SLSSmImn	bit0	SLS speed change input (spindle) 1st SP to 8th SP
	SLSSmImn	bit1	SLS speed change input (spindle) 1st SP to 8th SP
		bit2	vacant
		bit3	vacant
	SLSSOVRImn	bit4	SLS speed override input (spindle) 1st SP to 8th SP
	SLSSOVRImn	bit5	SLS speed override input (spindle) 1st SP to 8th SP
	SLSSOVRImn	bit6	SLS speed override input (spindle) 1st SP to 8th SP
	SLSSOVRImn	bit7	SLS speed override input (spindle) 1st SP to 8th SP
		bit8	vacant
		bit9	vacant
		bitA	vacant
		bitB	vacant
		bitC	vacant
		bitD	vacant
		bitE	vacant
		bitF	vacant

Device	Abbrev.	Signal name
ZR532	SARLS	Special safety alarm cancel (system common)
ZR1280	SIOFFCHK	Output off check request
-	SIOREQ	Safety I/O observation request
-	SCNSNDDAT	Safety communication send data
-	SCNCMD	Safety communication command

[CNC -> PLC]

Device	Abbrev.	Signal name
ZR544	SLSEm	SLS observation is active (control axis) 1st axis to 16th axis
ZR545	SLSEm	SLS observation is active (control axis) 17th axis to 32nd axis
ZR546	SLSSm	Under SLS limit (control axis) 1st axis to 16th axis
ZR547	SLSSm	Under SLS limit (control axis) 17th axis to 32nd axis
ZR548	SLPEm	SLP observation is active (control axis) 1st axis to 16th axis
ZR549	SLPEm	SLP observation is active (control axis) 17th axis to 32nd axis
ZR550	SLPSm	In SLP range (control axis) 1st axis to 16th axis
ZR551	SLPSm	In SLP range (control axis) 17th axis to 32nd axis
ZR552	SSMEem	SSM is active (control axis) 1st axis to 16th axis
ZR553	SSMEem	SSM is active (control axis) 17th axis to 32nd axis
ZR554	SCAEem	Safe cam is active (control axis) 1st axis to 16th axis
ZR555	SCAEem	Safe cam is active (control axis) 17th axis to 32nd axis
ZR556	SOSEem	SOS is active (control axis) 1st axis to 16th axis
ZR557	SOSEem	SOS is active (control axis) 17th axis to 32nd axis
ZR558	SOSSm	In SOS stop (control axis) 1st axis to 16th axis
ZR559	SOSSm	In SOS stop (control axis) 17th axis to 32nd axis
ZR560	SS1Em	SS1 is active (control axis) 1st axis to 16th axis
ZR561	SS1Em	SS1 is active (control axis) 17th axis to 32nd axis
ZR562	SS1Sm	In safe stop 1 (control axis) 1st axis to 16th axis
ZR563	SS1Sm	In safe stop 1 (control axis) 17th axis to 32nd axis
ZR564	SS2Em	SS2 is active (control axis) 1st axis to 16th axis
ZR565	SS2Em	SS2 is active (control axis) 17th axis to 32nd axis
ZR566	STOEm	STO is active (control axis) 1st axis to 16th axis
ZR567	STOEm	STO is active (control axis) 17th axis to 32nd axis
ZR568	STOSm	In safe torque OFF (control axis) 1st axis to 16th axis
ZR569	STOSm	In safe torque OFF (control axis) 17th axis to 32nd axis
ZR570	SBCEm	In SBC motor brake enabled (control axis) 1st axis to 16th axis
ZR571	SBCEm	In SBC motor brake enabled (control axis) 17th axis to 32nd axis
ZR572	SBCSm	In SBC motor brake start (control axis) 1st axis to 16th axis
ZR573	SBCSm	In SBC motor brake start (control axis) 17th axis to 32nd axis
ZR574	SBTNFEXm	External brake SBT incomplete (control axis) 1st axis to 16th axis
ZR575	SBTNFEXm	External brake SBT incomplete (control axis) 17th axis to 32nd axis
ZR576	SBTEXBRm	In SBT external brake test (control axis) 1st axis to 16th axis
ZR577	SBTEXBRm	In SBT external brake test (control axis) 17th axis to 32nd axis
ZR578	SBTNFMOm	Motor brake SBT incomplete (control axis) 1st axis to 16th axis
ZR579	SBTNFMOm	Motor brake SBT incomplete (control axis) 17th axis to 32nd axis
ZR580	SFABSPESTm	In safety absolute position establishing (control axis) 1st axis to 16th axis
ZR581	SFABSPESTm	In safety absolute position establishing (control axis) 17th axis to 32nd axis
ZR582	SFERR_SVm	Smart safety observation error occurring servo axis (control axis) 1st axis to 16th axis
ZR583	SFERR_SVm	Smart safety observation error occurring servo axis (control axis) 17th axis to 32nd axis
ZR584	SFWRG_SVm	Smart safety observation warning occurring servo axis (control axis) 1st axis to 16th axis
ZR585	SFWRG_SVm	Smart safety observation warning occurring servo axis (control axis) 17th axis to 32nd axis

2 Input/Output Signals with Controller

2.6 ZR Devices

Device	Abbrev.	bit	Signal name
ZR608 to ZR639	SLSMOmn	bit0	SLS speed change output (control axis) 1st axis to 32nd axis
	SLSMOmn	bit1	SLS speed change output (control axis) 1st axis to 32nd axis
		bit2	vacant
		bit3	vacant
	SLSOVROmn	bit4	SLS speed override output (control axis) 1st axis to 32nd axis
	SLSOVROmn	bit5	SLS speed override output (control axis) 1st axis to 32nd axis
	SLSOVROmn	bit6	SLS speed override output (control axis) 1st axis to 32nd axis
	SLSOVROmn	bit7	SLS speed override output (control axis) 1st axis to 32nd axis
		bit8	vacant
		bit9	vacant
		bitA	vacant
		bitB	vacant
		bitC	vacant
		bitD	vacant
		bitE	vacant
		bitF	vacant

Device	Abbrev.	Signal name
ZR640 to ZR671	SLPMOmn	SLP position change output (control axis) 1st axis to 32nd axis
ZR672 to ZR703	SSMSmn	Under SSM safe speed (control axis) 1st axis to 32nd axis
ZR704 to ZR767	SCASmn	Safe cam position (control axis) 1st axis to 32nd axis
ZR768 to ZR893	SBTPOSm	SBT start position (control axis) 1st axis to 32nd axis

Device	Abbrev.	Signal name
ZR1024	SLSSEm	SLS observation is active (spindle) 1st SP to 8th SP
ZR1025	SLSSSm	Under SLS limit (spindle) 1st SP to 8th SP
ZR1028	SSMSEm	SSM is active (spindle) 1st SP to 8th SP
ZR1030	SOSSEm	SOS is active (spindle) 1st SP to 8th SP
ZR1031	SOSSSm	In SOS stop (spindle) 1st SP to 8th SP
ZR1032	SS1SEm	SS1 is active (spindle) 1st SP to 8th SP
ZR1033	SS1SSm	In safe stop (spindle) 1st SP to 8th SP
ZR1034	SS2SEm	SS2 is active (spindle) 1st SP to 8th SP
ZR1035	STOSEm	STO is active (spindle) 1st SP to 8th SP
ZR1036	STOSSm	In safe torque OFF (spindle) 1st SP to 8th SP
ZR1043	SFERR_SPm	Smart safety observation error occurring spindle (spindle) 1st SP to 8th SP
ZR1044	SFWRG_SPm	Smart safety observation warning occurring spindle (spindle) 1st SP to 8th SP

2 Input/Output Signals with Controller

2.6 ZR Devices

Device	Abbrev.	bit	Signal name
ZR1056 to ZR1063	SLSSMOmn	bit0	SLS speed change output (spindle) 1st SP to 8th SP
	SLSSMOmn	bit1	SLS speed change output (spindle) 1st SP to 8th SP
		bit2	vacant
		bit3	vacant
	SLSSOV-ROmn	bit4	SLS speed override output (spindle) 1st SP to 8th SP
	SLSSOV-ROmn	bit5	SLS speed override output (spindle) 1st SP to 8th SP
	SLSSOV-ROmn	bit6	SLS speed override output (spindle) 1st SP to 8th SP
	SLSSOV-ROmn	bit7	SLS speed override output (spindle) 1st SP to 8th SP
		bit8	vacant
		bit9	vacant
		bitA	vacant
		bitB	vacant
		bitC	vacant
		bitD	vacant
		bitE	vacant
		bitF	vacant

Device	Abbrev.	Signal name
ZR1088 to ZR1095	SSMSSmn	Under SSM safe speed (spindle) 1st SP to 8th SP

Device	Abbrev.	Signal name
ZR1264	SEXTMG	In safety external emergency stop (system common)
ZR1268	SFERR_VNO	V number of smart safety observation error (system common)
ZR1269	SFERR_ENO	E number of smart safety observation error (system common)
ZR1270	SFWRG_VNO	V number of smart safety observation warning (system common)
ZR1271	SFWRG_ENO	W number of smart safety observation warning (system common)

Device	Abbrev.	Signal name
ZR1536	SIOERRSTS	Safety I/O observation state
ZR1538	SIOERRUNIT	Safety I/O unit observation state
ZR1540	SIOERRUNIT-STS1n	Safety I/O unit observation error details Unit1
ZR1541	SIOERRUNIT-STS2n	Safety I/O unit observation error details Unit2
ZR1542	SIOERRUNIT-STS3n	Safety I/O unit observation error details Unit3
ZR1543	SIOERRUNIT-STS4n	Safety I/O unit observation error details Unit4
ZR1544	SIOERRUNIT-STS5n	Safety I/O unit observation error details Unit5
ZR1545	SIOERRUNIT-STS6n	Safety I/O unit observation error details Unit6
ZR1546	SIOERRUNIT-STS7n	Safety I/O unit observation error details Unit7
ZR1547	SIOERRUNIT-STS8n	Safety I/O unit observation error details Unit8

Device	Abbrev.	Signal name
-	SIOERRUNITSIG	Safety I/O device observation error signal Unit1
-	SIOERRUNITSIG	Safety I/O device observation error signal Unit2
-	SIOERRUNITSIG	Safety I/O device observation error signal Unit3
-	SIOWRGUNIT	Safety I/O device observation warning status
-	SIOWRGUNIT-STS	Safety I/O device observation warning details Unit1
-	SIOWRGUNIT-STS	Safety I/O device observation warning details Unit2
-	SIOWRGUNIT-STS	Safety I/O device observation warning details Unit3
-	SIOWRGUNITSIG	Safety I/O device observation warning signal Unit1
-	SIOWRGUNITSIG	Safety I/O device observation warning signal Unit2
-	SIOWRGUNITSIG	Safety I/O device observation warning signal Unit3

Device	Abbrev.	Signal name
-	SCNRCVDAT	Safety communication receipt data
-	SCNSTS	Safety communication status
-	SCNCOMSTS	Safety station communication status

■ Memory switch (PLC switch)

Device	Signal name
ZR3200 to ZR3205	PLC switch non-display

■ MES interface library

Device	Signal name
ZR10000 to ZR10031	MES interface library: Common user area C1
ZR10032 to ZR10051	MES interface library: Common user area L1 to L10
ZR10054	MES interface library: Condition register (Extract sort condition)
ZR10055	MES interface library: Condition register (Combination condition)
ZR10056	MES interface library: Condition register (Field value) 1st set
ZR10057	MES interface library: Condition register (Comparison condition) 1st set
ZR10058 to ZR10089	MES interface library: Condition register (Condition value) 1st set
ZR10090	MES interface library: Condition register (Field value) 2nd set
ZR10091	MES interface library: Condition register (Comparison condition) 2nd set
ZR10092 to ZR10123	MES interface library: Condition register (Condition value) 2nd set
ZR10330 to ZR10913	Data I/O register for MES interface library (For update/extract)
ZR10940 to ZR10971	MES interface library: User area C1 at machining end
ZR10972 to ZR10991	MES interface library: User area L1 to L10 at machining end
ZR10994 to ZR11025	MES interface library: User area C1 at alarm
ZR11026 to ZR11045	MES interface library: User area L1 to L10 at alarm
ZR11048 to ZR11079	MES interface library: Arbitrary user area C1
ZR11080 to ZR11099	MES interface library: Arbitrary user area S1 to S20
ZR11100 to ZR11119	MES interface library: Arbitrary user area L1 to L10

■ Diagnosis data output

Device	Signal name
ZR12404, ZR12405	Diagnosis data output: Battery exchange
ZR12608, ZR12609 to ZR12670, ZR12671	Diagnosis data output: Battery exchange (drive) (servo)
ZR12784, ZR12785 to ZR12846, ZR12847	Diagnosis data output: Motor insulation resistance (motor) (servo)
ZR12848, ZR12849 to ZR12862, ZR12863	Diagnosis data output: Motor insulation resistance (motor) (spindle)
ZR12945	Diagnosis data output: Automatic log clear time
ZR12946, ZR12947 to ZR13008, ZR13009	Diagnosis data output: Accumulated travel distance (motor) (servo)

■ Spindle protection

Device	Abbrev.	Signal name
ZR13010	SPEQLD	Spindle protection: Motor equivalent load factor
ZR13018	PRSPERR	Spindle protection: Number of times log output error occurred

■ External encoder position output I/F

Device	Abbrev.	Signal name
ZR13020	ENC1POS	External encoder 1: Position output

■ Machine contact input/output I/F

Device	Abbrev.	Signal name
ZR13028 to ZR13039	TIn	Thermistor input n
ZR13040	TIOPN	Thermistor disconnection
ZR13041	TISRT	Thermistor short-circuit
ZR13050 to ZR13065	MAAn	Multi-analog input ch n
ZR13066 to ZR13081	MASTSn	Multi-analog input status ch n

■ PROFIBUS-DP

[PLC → CNC]

Device	Abbrev.	Signal name
ZR3613		PROFIBUS-DP: Diagnosis data acquisition request start/end flag
ZR3614		PROFIBUS-DP: Station No. of slave requesting diagnosis data acquisition
ZR3615		PROFIBUS-DP: Diagnosis data acquisition request command No.
ZR3616		PROFIBUS-DP: Diagnosis data-storing device type
ZR3617		PROFIBUS-DP: Top device No. for storing diagnosis data
ZR3623		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Request start/end flag
ZR3624		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Request command No.
ZR3625		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Request source slave station No.
ZR3626		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Request source slave station slot No.
ZR3627		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Request source slave station index
ZR3628		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Request source data length
ZR3629		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Send time-out
ZR3630		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Features supported
ZR3631		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Features supported 2
ZR3632		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Profile features supported
ZR3633		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Profile features supported 2
ZR3634		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Profile ID number
ZR3635		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): S_Type
ZR3636		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): S_Len
ZR3637		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): D_Type
ZR3638		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): D_Len
ZR3639		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Destination connection No.
ZR3642		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Type of device for storing data to write
ZR3643		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Top device No. for storing data to write
ZR3644		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Type of device for storing additional address parameter table
ZR3645		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Top device No. for storing additional address parameter table
ZR3646		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Subnet
ZR3647		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Instance
ZR3648		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Reason Code
ZR3664		PROFIBUS-DP: Alarm data acquisition request start/end flag
ZR3665		PROFIBUS-DP: Alarm data acquisition request command No.
ZR3666		PROFIBUS-DP: Station No. of slave requesting alarm data acquisition
ZR3667		PROFIBUS-DP: Alarm data-storing device type
ZR3668		PROFIBUS-DP: Top device No. for storing alarm data
ZR3673		PROFIBUS-DP:ACK send request start/end flag
ZR3674		PROFIBUS-DP:ACK send request command No.
ZR3675		PROFIBUS-DP:ACK send request destination slave station No.
ZR3676		PROFIBUS-DP: Type of alarm occurring on ACK send request destination slave station
ZR3677		PROFIBUS-DP: Slot No. of ACK send request destination slave station
ZR3678		PROFIBUS-DP: Alarm specifier of ACK send request destination slave station

[CNC -> PLC]

Device	Abbrev.	Signal name
ZR3600		PROFIBUS-DP: Startup complete (*1)
ZR3601		PROFIBUS-DP: Diagnosis data acquisition in progress
ZR3602		PROFIBUS-DP: Aperiodic data communication (Acyclic communication) in progress
ZR3603		PROFIBUS-DP: Alarm data acquisition active flag
ZR3604		PROFIBUS-DP: Alarm ACK send active flag
ZR3605		PROFIBUS-DP: Error occurrence state in the slave station (Station No. 0 to 15)
ZR3606		PROFIBUS-DP: Error occurrence state in the slave station (Station No. 16 to 31)
ZR3607		PROFIBUS-DP: Error occurrence state in the slave station (Station No. 32 to 47)
ZR3608		PROFIBUS-DP: Error occurrence state in the slave station (Station No. 48 to 63)
ZR3609		PROFIBUS-DP: Error occurrence state in the slave station (Station No. 64 to 79)
ZR3610		PROFIBUS-DP: Error occurrence state in the slave station (Station No. 80 to 95)
ZR3611		PROFIBUS-DP: Error occurrence state in the slave station (Station No. 96 to 111)
ZR3612		PROFIBUS-DP: Error occurrence state in the slave station (Station No. 112 to 125)
ZR3618		PROFIBUS-DP: Diagnosis data acquisition response command No.
ZR3619		PROFIBUS-DP: Diagnosis data acquisition status (H)
ZR3620		PROFIBUS-DP: Diagnosis data acquisition status (L)
ZR3621		PROFIBUS-DP: Station No. of slave that acquired diagnosis data
ZR3622		PROFIBUS-DP: Diagnosis data length
ZR3630		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Features supported
ZR3631		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Features supported 2
ZR3632		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Profile features supported
ZR3633		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Profile features supported 2
ZR3634		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Profile ID number
ZR3635		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): S_Type
ZR3636		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): S_Len
ZR3637		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): D_Type
ZR3638		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): D_Len
ZR3640		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Type of devices for storing read data
ZR3641		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Top device No. for storing read data
ZR3649		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Response command No.
ZR3650		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Execution status (H)
ZR3651		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Execution status (L)
ZR3652		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Execution station No.
ZR3653		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Execution slot
ZR3654		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Execution index
ZR3655		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Execution data length
ZR3656		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Connection-established connection No.
ZR3657		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Maximum data unit length
ZR3658		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Connection reference value
ZR3659		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Error decode
ZR3660		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Error code 1
ZR3661		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Error code 2

2 Input/Output Signals with Controller

2.6 ZR Devices

Device	Abbrev.	Signal name
ZR3662		PROFIBUS-DP: Aperiodic data communication (Acyclic communication): Additional error data
ZR3663		PROFIBUS-DP: Alarm-occurring station No.
ZR3669		PROFIBUS-DP: Alarm data acquisition response command No.
ZR3670		PROFIBUS-DP: Alarm data acquisition status (H)
ZR3671		PROFIBUS-DP: Alarm data acquisition status (L)
ZR3672		PROFIBUS-DP: Acquired alarm data length
ZR3679		PROFIBUS-DP:ACK send response command No.
ZR3680		PROFIBUS-DP:ACK send status (H)
ZR3681		PROFIBUS-DP:ACK send status (L)
ZR3682		PROFIBUS-DP:ACK send execution station No.
ZR3683		PROFIBUS-DP:ACK send execution alarm type
ZR3684		PROFIBUS-DP:ACK send execution slot No.
ZR3685		PROFIBUS-DP:ACK send execution alarm specifier
ZR3686		PROFIBUS-DP:ACK send error decode
ZR3687		PROFIBUS-DP:ACK send error code 1
ZR3688		PROFIBUS-DP:ACK send error code 2
ZR3692		PROFIBUS-DP: Communication error flag
ZR3693		PROFIBUS-DP: Global error bit
ZR3694		PROFIBUS-DP: Configuration status of slave station (Station No. 0 to 15)
ZR3695		PROFIBUS-DP: Configuration status of slave station (Station No. 16 to 31)
ZR3696		PROFIBUS-DP: Configuration status of slave station (Station No. 32 to 47)
ZR3697		PROFIBUS-DP: Configuration status of slave station (Station No. 48 to 63)
ZR3698		PROFIBUS-DP: Configuration status of slave station (Station No. 64 to 79)
ZR3699		PROFIBUS-DP: Configuration status of slave station (Station No. 80 to 95)
ZR3700		PROFIBUS-DP: Configuration status of slave station (Station No. 96 to 111)
ZR3701		PROFIBUS-DP: Configuration status of slave station (Station No. 112 to 125)
ZR3702		PROFIBUS-DP: Communication status of slave station (Station No. 0 to 15)
ZR3703		PROFIBUS-DP: Communication status of slave station (Station No. 16 to 31)
ZR3704		PROFIBUS-DP: Communication status of slave station (Station No. 32 to 47)
ZR3705		PROFIBUS-DP: Communication status of slave station (Station No. 48 to 63)
ZR3706		PROFIBUS-DP: Communication status of slave station (Station No. 64 to 79)
ZR3707		PROFIBUS-DP: Communication status of slave station (Station No. 80 to 95)
ZR3708		PROFIBUS-DP: Communication status of slave station (Station No. 96 to 111)
ZR3709		PROFIBUS-DP: Communication status of slave station (Station No. 112 to 125)

(*1) NC checks for the presence of slave stations for two times: when PROFIBUS-DP function extension unit is turned ON and when the time set to the parameter "#1332 Fieldbus" has elapsed since the startup. As a result of the check, if no slave stations is detected, the "Startup complete" signal (ZR3600) does not turn ON.

When ZR3600 does not turn ON, check the communication status of slave stations with ZR3702 to ZR3709, and adjust the slave stations and review the setting time of the parameter (#1332).

■ BiSS encoder I/F

Device	Abbrev.	Signal name
ZR13090	BENCSTS	BiSS encoder I/F: Communication status
ZR13091 to ZR13094	BENC1DATn	BiSS encoder I/F: Encoder 1 data output n

2.7 Classified for Each Application

Note

(1) Signals with " ▲ " are prepared for specific machine tool builders.

■ PLC axis indexing interfaces

Device No.		Abbrev.	Signal name
	bit		
R8098	bit0		PLC indexing axis operation adjustment mode valid (common for all axes)

PLC indexing axis								Abbrev.	Signal name
1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis		
R8050	R8056	R8062	R8068	R8074	R8080	R8086	R8092	AUX-CM4	PLC axis indexing control command 4
R8051	R8057	R8063	R8069	R8075	R8081	R8087	R8093	AUX-CM3	PLC axis indexing control command 3
R8052	R8058	R8064	R8070	R8076	R8082	R8088	R8094	AUX-CM2	PLC axis indexing control command 2
R8053	R8059	R8065	R8071	R8077	R8083	R8089	R8095	AUX-CM1	PLC axis indexing control command 1
R8054	R8060	R8066	R8072	R8078	R8084	R8090	R8096		PLC axis indexing control command position (L)
R8055	R8061	R8067	R8073	R8079	R8085	R8091	R8097		PLC axis indexing control command position (H)

Device No.		Abbrev.	Signal name
	bit		
R8048	bit0		PLC indexing axis in operation adjustment mode 1st axis
	bit1		PLC indexing axis in operation adjustment mode 2nd axis
	bit2		PLC indexing axis in operation adjustment mode 3rd axis
	bit3		PLC indexing axis in operation adjustment mode 4th axis
	bit4		PLC indexing axis in operation adjustment mode 5th axis
	bit5		PLC indexing axis in operation adjustment mode 6th axis

PLC indexing axis								Abbrev.	Signal name
1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis		
R8000	R8006	R8012	R8018	R8024	R8030	R8036	R8042	AUXST4	PLC axis indexing control status 4
R8001	R8007	R8013	R8019	R8025	R8031	R8037	R8043	AUXST3	PLC axis indexing control status 3
R8002	R8008	R8014	R8020	R8026	R8032	R8038	R8044	AUXST2	PLC axis indexing control status 2
R8003	R8009	R8015	R8021	R8027	R8033	R8039	R8045	AUXST1	PLC axis indexing control status 1
R8004	R8010	R8016	R8022	R8028	R8034	R8040	R8046		PLC axis indexing control machine position (L)
R8005	R8011	R8017	R8023	R8029	R8035	R8041	R8047		PLC axis indexing control machine position (H)

■ Other file registers (R)

Device No.	Signal name		
R2100 to R2397	Pallet program data (Drive unit -> PLC)		
R4100 to R4103	Pallet program data (PLC -> Drive unit)		
R7500 to R7799	PLC constant parameters (corresponds to parameters #18001 to #18150)		
R7800 to R7897	PLC bit selection parameters (corresponds to parameters #6401 to #6596)		
R7898 to R7947	PLC bit selection parameters (corresponds to parameters #59001 to #59100) ▲		
R8260 to R8289	Option status export to PLC		
R8290 to R8299	Optimum acceleration/deceleration estimated inertia level (spindle) ▲		
R12800 to R13099	Computer link interfaces		
R13200 to R13299	Special table interfaces		
R17300 to R18299	Modbus input/ouptu device ▲		
M system		L system	
R10600 to R11779	ATC command control information	R10600 and later	Tool life management interfaces I, II
R11800 and later	Tool life management interfaces		
R24884 to R25011	Total distance traveled by n-th axis during automatic operation		
R27500 to R28099	PLC constant parameters (corresponds to parameters #59301 to #59600) ▲		

■ Memory switch (PLC switch)

Device No.	Signal name
X680 to X6BF	PLC switch #1 to 64
X1C40 to X1C5F	PLC switch #65 to 96
X6F8 to X6FF	Skip input 1 to 8 for monitor
Y680 to Y6BF	PLC switch reversed display #1 to 64
Y1C40 to Y1C5F	PLC switch reversed display #65 to 96
Y6C0 to Y6FF	PLC switch for reverse #1 to 64
Y1C60 to Y1C7F	PLC switch for reverse #65 to 96
ZR3200 to ZR3205	PLC switch non-display

■ Fixed (semi-fixed) devices

Device No.	Signal name
X18 to X1B	Reference position return near-point detection 1 to 4
X20 to X23	Stroke end (-) 1 to 4
X28 to X2B	Stroke end (+) 1 to 4
X5C to X5F	Reference position return near-point detection 5 to 8
X64 to X67	Stroke end (-) 5 to 8
X6C to X6F	Stroke end (+) 5 to 8

Up to NC 8th axis can be set for fixed devices. The 9th axis or later cannot be set.

■ Maintenance

Device No.	Signal name
R13170	CRC count (servo #1)
R13171	CRC count (servo #2)
R13172	Address illegal (servo #1)
R13173	Address illegal (servo #2)
R13174	CRC count (display unit)
R13175	Address illegal (display unit)
R13176	CRC count (servo #3)
R13177	Address illegal (servo #3)

■ Spindle related devices

[CNC -> PLC]

Device No.									
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP	Abbrev.	Signal name
X1882	X18E2	X1942	X19A2	X1A02	X1A62	X1AC2	X1B22	SIGE	S command gear No. illegal
X1883	X18E3	X1943	X19A3	X1A03	X1A63	X1AC3	X1B23	SOVE	S command max./min. command value over
X1884	X18E4	X1944	X19A4	X1A04	X1A64	X1AC4	X1B24	SNGE	S command no gear selected
X1885	X18E5	X1945	X19A5	X1A05	X1A65	X1AC5	X1B25	GR1	Spindle gear shift command 1
X1886	X18E6	X1946	X19A6	X1A06	X1A66	X1AC6	X1B26	GR2	Spindle gear shift command 2
X1887	X18E7	X1947	X19A7	X1A07	X1A67	X1AC7	X1B27	-	(Always "0")
X1888	X18E8	X1948	X19A8	X1A08	X1A68	X1AC8	X1B28	ORAO2	Spindle 2nd in-position
X1889	X18E9	X1949	X19A9	X1A09	X1A69	X1AC9	X1B29	CDO	Current detection
X188A	X18EA	X194A	X19AA	X1A0A	X1A6A	X1ACA	X1B2A	VRO	Speed detection
X188B	X18EB	X194B	X19AB	X1A0B	X1A6B	X1ACB	X1B2B	FLO	In spindle alarm
X188C	X18EC	X194C	X19AC	X1A0C	X1A6C	X1ACC	X1B2C	ZSO	Zero speed
X188D	X18ED	X194D	X19AD	X1A0D	X1A6D	X1ACD	X1B2D	USO	Spindle up-to-speed
X188E	X18EE	X194E	X19AE	X1A0E	X1A6E	X1ACE	X1B2E	ORAO	Spindle in-position
X188F	X18EF	X194F	X19AF	X1A0F	X1A6F	X1ACF	X1B2F	LCSA	In L coil selection
X1890	X18F0	X1950	X19B0	X1A10	X1A70	X1AD0	X1B30	SMA	Spindle ready-ON
X1891	X18F1	X1951	X19B1	X1A11	X1A71	X1AD1	X1B31	SSA	Spindle servo-ON
X1892	X18F2	X1952	X19B2	X1A12	X1A72	X1AD2	X1B32	SEMG	In spindle emergency stop
X1893	X18F3	X1953	X19B3	X1A13	X1A73	X1AD3	X1B33	SSRN	In spindle forward run
X1894	X18F4	X1954	X19B4	X1A14	X1A74	X1AD4	X1B34	SSRI	In spindle reverse run
X1895	X18F5	X1955	X19B5	X1A15	X1A75	X1AD5	X1B35		Z phase passed
X1896	X18F6	X1956	X19B6	X1A16	X1A76	X1AD6	X1B36	SIMP	Position loop in-position
X1897	X18F7	X1957	X19B7	X1A17	X1A77	X1AD7	X1B37	STLQ	In spindle torque limit
X1898	X18F8	X1958	X19B8	X1A18	X1A78	X1AD8	X1B38		
X1899	X18F9	X1959	X19B9	X1A19	X1A79	X1AD9	X1B39		
X189A	X18FA	X195A	X19BA	X1A1A	X1A7A	X1ADA	X1B3A		Spindle torque limit reached
X189D	X18FD	X195D	X19BD	X1A1D	X1A7D	X1ADD	X1B3D	SD2	Speed detection 2
X189E	X18FE	X195E	X19BE	X1A1E	X1A7E	X1ADE	X1B3E	MCSA	In M coil selection
X189F	X18FF	X195F	X19BF	X1A1F	X1A7F	X1ADF	X1B3F		Index positioning completion

2 Input/Output Signals with Controller

2.7 Classified for Each Application

Device No.								Abbrev.	Signal name
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP		
X18A0	X1900	X1960	X19C0	X1A20	X1A80	X1AE0	X1B40	ENB	Spindle enable
X18A8	X1908	X1968	X19C8	X1A28	X1A88	X1AE8	X1B48	SPSYN1	In spindle synchronization
X18A9	X1909	X1969	X19C9	X1A29	X1A89	X1AE9	X1B49	FSPRV	Spindle rotation speed synchronization completion
X18AA	X190A	X196A	X19CA	X1A2A	X1A8A	X1AEA	X1B4A	FSPPH	Spindle phase synchronization completion
X18AB	X190B	X196B	X19CB	X1A2B	X1A8B	X1AEB	X1B4B	SPSYN2	In spindle synchronization 2
X18AC	X190C	X196C	X19CC	X1A2C	X1A8C	X1AEC	X1B4C	SPCMP	Chuck close confirmation
X18AD	X190D	X196D	X19CD	X1A2D	X1A8D	X1AED	X1B4D	TSS1	In tool spindle synchronization I (Polygon)
X18AE	X190E	X196E	X19CE	X1A2E	X1A8E	X1AEE	X1B4E	SPSYN3	In tool spindle synchronization II
X18AF	X190F	X196F	X19CF	X1A2F	X1A8F	X1AEF	X1B4F	SPNCH	Spindle superimposition control: Speed change disabled
X18B0	X1910	X1970	X19D0	X1A30	X1A90	X1AF0	X1B50	SP-PHOV	Spindle synchronization phase error over
X18B1	X1911	X1971	X19D1	X1A31	X1A91	X1AF1	X1B51	SPILE	Spindle superimposition control ON
X18B2	X1912	X1972	X19D2	X1A32	X1A92	X1AF2	X1B52	SPLCR	Spindle superimposition control: Spindle superimposition clamped
X18B3	X1913	X1973	X19D3	X1A33	X1A93	X1AF3	X1B53	PHOVR	Hob axis delay excess
X18B5	X1915	X1975	X19D5	X1A35	X1A95	X1AF5	X1B55	EXOFN	Holding power of spindle increased
X18B6	X1916	X1976	X19D6	X1A36	X1A96	X1AF6	X1B56	SPOFFA	In spindle off
X18C1	X1921	X1981	X19E1	X1A41	X1AA1	X1B01	X1B61	SVMD	Spindle position control (Spindle/C axis control): C axis mode ON
X18C2	X1922	X1982	X19E2	X1A42	X1AA2	X1B02	X1B62	GO1	Spindle gear selection output 1
X18C3	X1923	X1983	X19E3	X1A43	X1AA3	X1B03	X1B63	GO2	Spindle gear selection output 2
X18C8	X1928	X1988	X19E8	X1A48	X1AA8	X1B08	X1B68		Spindle oscillation in progress
X18C9	X1929	X1989	X19E9	X1A49	X1AA9	X1B09	X1B69	SPRTCT	Spindle protection: Mode in progress
X18CA	X192A	X198A	X19EA	X1A4A	X1AAA	X1B0A	X1B6A	VGHLD	Real-time tuning 1: Speed control gain changeover hold-down ON

Device No.								Abbrev.	Signal name
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8		
XC64	XDA4	XEE4	X1024	X1164	X12A4	X13E4	X1524	SF1	S function strobe 1
XC65	XDA5	XEE5	X1025	X1165	X12A5	X13E5	X1525	SF2	S function strobe 2
XC66	XDA6	XEE6	X1026	X1166	X12A6	X13E6	X1526	SF3	S function strobe 3
XC67	XDA7	XEE7	X1027	X1167	X12A7	X13E7	X1527	SF4	S function strobe 4
XC70	XDB0	XEF0	X1030	X1170	X12B0	X13F0	X1530	SF5	S function strobe 5
XC71	XDB1	XEF1	X1031	X1171	X12B1	X13F1	X1531	SF6	S function strobe 6
XC72	XDB2	XEF2	X1032	X1172	X12B2	X13F2	X1532	SF7	S function strobe 7
XC73	XDB3	XEF3	X1033	X1173	X12B3	X13F3	X1533	SF8	S function strobe 8
XCB0	XDF0	XF30	X1070	X11B0	X12F0	X1430	X1570		In spindle-NC axis polygon mode
XCB2	XDF2	XF32	X1072	X11B2	X12F2	X1432	X1572		In spindle-spindle polygon mode
XCB3	XDF3	XF33	X1073	X11B3	X12F3	X1433	X1573		Spindle-spindle polygon synchronization completion

2 Input/Output Signals with Controller

2.7 Classified for Each Application

[CNC -> PLC]

Device No.								Abbrev.	Signal name
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP		
R6500	R6550	R6600	R6650	R6700	R6750	R6800	R6850		Spindle command rotation speed input (L)
R6501	R6551	R6601	R6651	R6701	R6751	R6801	R6851		Spindle command rotation speed input (H)
R6502	R6552	R6602	R6652	R6702	R6752	R6802	R6852		Spindle command final data (rotation speed) (L)
R6503	R6553	R6603	R6653	R6703	R6753	R6803	R6853		Spindle command final data (rotation speed) (H)
R6504	R6554	R6604	R6654	R6704	R6754	R6804	R6854		Spindle command final data (12-bit binary) (L)
R6505	R6555	R6605	R6655	R6705	R6755	R6805	R6855		Spindle command final data (12-bit binary) (H)
R6506	R6556	R6606	R6656	R6706	R6756	R6806	R6856		Spindle actual speed (L)
R6507	R6557	R6607	R6657	R6707	R6757	R6807	R6857		Spindle actual speed (H)
R6508	R6558	R6608	R6658	R6708	R6758	R6808	R6858		
R6514	R6564	R6614	R6664	R6714	R6764	R6814	R6864		Optimum acceleration/deceleration estimated inertia ratio (spindle) ▲
R6515	R6565	R6615	R6665	R6715	R6765	R6815	R6865		Optimum acceleration/deceleration parameter group currently selected (spindle) ▲
R6516	R6566	R6616	R6666	R6716	R6766	R6816	R6866		Spindle synchronization: Phase error /Hob axis delay angle
R6517	R6567	R6617	R6667	R6717	R6767	R6817	R6867		Spindle synchronization: Maximum phase error/Maximum hob axis delay angle
R6518	R6568	R6618	R6668	R6718	R6768	R6818	R6868		Spindle synchronization: Phase offset data
R6519	R6569	R6619	R6669	R6719	R6769	R6819	R6869		Spindle synchronization: Phase error monitor
R6520	R6570	R6620	R6670	R6720	R6770	R6820	R6870		Spindle synchronization: Phase error monitor (lower limit)
R6521	R6571	R6621	R6671	R6721	R6771	R6821	R6871		Spindle synchronization: Phase error monitor (upper limit)
R6522	R6572	R6622	R6672	R6722	R6772	R6822	R6872		Spindle synchronization: Phase error 1
R6523	R6573	R6623	R6673	R6723	R6773	R6823	R6873		Spindle synchronization: Phase error 2
R6525	R6575	R6625	R6675	R6725	R6775	R6825	R6875		Spindle motor load ratio
R6526	R6576	R6626	R6676	R6726	R6776	R6826	R6876	SP-TEMP	Spindle temperature output
R6527	R6577	R6627	R6677	R6727	R6777	R6827	R6877		Spindle actual machining time ▲
R6528	R6578	R6628	R6678	R6728	R6778	R6828	R6878		Load monitor I: Spindle cutting torque output value ▲
R6529	R6579	R6629	R6679	R6729	R6779	R6829	R6879		Spindle alarm/warning No.
R6532	R6582	R6632	R6682	R6732	R6782	R6832	R6882		Synchronous tapping Current error width (L)
R6533	R6583	R6633	R6683	R6733	R6783	R6833	R6883		Synchronous tapping Current error width (H)
R6534	R6584	R6634	R6684	R6734	R6784	R6834	R6884		Synchronous tapping Maximum error width (L)
R6535	R6585	R6635	R6685	R6735	R6785	R6835	R6885		Synchronous tapping Maximum error width (H)
R6536	R6586	R6636	R6686	R6736	R6786	R6836	R6886		Synchronous tapping Current error angle (L)
R6537	R6587	R6637	R6687	R6737	R6787	R6837	R6887		Synchronous tapping Current error angle (H)
R6538	R6588	R6638	R6688	R6738	R6788	R6838	R6888		Synchronous tapping Maximum error angle (L)
R6539	R6589	R6639	R6689	R6739	R6789	R6839	R6889		Synchronous tapping Maximum error angle (H)
R6541	R6591	R6641	R6691	R6741	R6791	R6841	R6891		Load monitoring I: Estimated spindle disturbance torque output
R6542	R6592	R6642	R6692	R6742	R6792	R6842	R6892		Load monitoring I: Effective spindle torque output

2 Input/Output Signals with Controller

2.7 Classified for Each Application

Device No.									
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8	Abbrev.	Signal name
R512	R712	R912	R1112	R1312	R1512	R1712	R1912		S code data 1 (L)
R513	R713	R913	R1113	R1313	R1513	R1713	R1913		S code data 1 (H)
R514	R714	R914	R1114	R1314	R1514	R1714	R1914		S code data 2 (L)
R515	R715	R915	R1115	R1315	R1515	R1715	R1915		S code data 2 (H)
R516	R716	R916	R1116	R1316	R1516	R1716	R1916		S code data 3 (L)
R517	R717	R917	R1117	R1317	R1517	R1717	R1917		S code data 3 (H)
R518	R718	R918	R1118	R1318	R1518	R1718	R1918		S code data 4 (L)
R519	R719	R919	R1119	R1319	R1519	R1719	R1919		S code data 4 (H)
R520	R720	R920	R1120	R1320	R1520	R1720	R1920		S code data 5 (L)
R521	R721	R921	R1121	R1321	R1521	R1721	R1921		S code data 5 (H)
R522	R722	R922	R1122	R1322	R1522	R1722	R1922		S code data 6 (L)
R523	R723	R923	R1123	R1323	R1523	R1723	R1923		S code data 6 (H)
R524	R724	R924	R1124	R1324	R1524	R1724	R1924		S code data 7 (L)
R525	R725	R925	R1125	R1325	R1525	R1725	R1925		S code data 7 (H)
R526	R726	R926	R1126	R1326	R1526	R1726	R1926		S code data 8 (L)
R527	R727	R927	R1127	R1327	R1527	R1727	R1927		S code data 8 (H)

2 Input/Output Signals with Controller

2.7 Classified for Each Application

[PLC -> CNC]

Device No.								Abbrev.	Signal name
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP		
Y1885	Y18E5	Y1945	Y19A5	Y1A05	Y1A65	Y1AC5	Y1B25	GFIN	Gear shift completion
Y1888	Y18E8	Y1948	Y19A8	Y1A08	Y1A68	Y1AC8	Y1B28	SP1	Spindle speed override code 1
Y1889	Y18E9	Y1949	Y19A9	Y1A09	Y1A69	Y1AC9	Y1B29	SP2	Spindle speed override code 2
Y188A	Y18EA	Y194A	Y19AA	Y1A0A	Y1A6A	Y1ACA	Y1B2A	SP4	Spindle speed override code 4
Y188F	Y18EF	Y194F	Y19AF	Y1A0F	Y1A6F	Y1ACF	Y1B2F	SPS	Spindle override method selection
Y1890	Y18F0	Y1950	Y19B0	Y1A10	Y1A70	Y1AD0	Y1B30	GI1	Spindle gear selection code 1
Y1891	Y18F1	Y1951	Y19B1	Y1A11	Y1A71	Y1AD1	Y1B31	GI2	Spindle gear selection code 2
Y1893	Y18F3	Y1953	Y19B3	Y1A13	Y1A73	Y1AD3	Y1B33	EXOBS	Increase holding power of spindle
Y1894	Y18F4	Y1954	Y19B4	Y1A14	Y1A74	Y1AD4	Y1B34	SSTP	Spindle stop
Y1895	Y18F5	Y1955	Y19B5	Y1A15	Y1A75	Y1AD5	Y1B35	SSFT	Spindle gear shift
Y1896	Y18F6	Y1956	Y19B6	Y1A16	Y1A76	Y1AD6	Y1B36	SORC	Spindle orientation
Y1897	Y18F7	Y1957	Y19B7	Y1A17	Y1A77	Y1AD7	Y1B37		Spindle command invalid
Y1898	Y18F8	Y1958	Y19B8	Y1A18	Y1A78	Y1AD8	Y1B38	SRN	Spindle forward run start
Y1899	Y18F9	Y1959	Y19B9	Y1A19	Y1A79	Y1AD9	Y1B39	SRI	Spindle reverse run start
Y189A	Y18FA	Y195A	Y19BA	Y1A1A	Y1A7A	Y1ADA	Y1B3A	TL1	Spindle torque limit 1
Y189B	Y18FB	Y195B	Y19BB	Y1A1B	Y1A7B	Y1ADB	Y1B3B	TL2	Spindle torque limit 2
Y189C	Y18FC	Y195C	Y19BC	Y1A1C	Y1A7C	Y1ADC	Y1B3C	WRN	Spindle forward run index
Y189D	Y18FD	Y195D	Y19BD	Y1A1D	Y1A7D	Y1ADD	Y1B3D	WRI	Spindle reverse run index
Y189E	Y18FE	Y195E	Y19BE	Y1A1E	Y1A7E	Y1ADE	Y1B3E	ORC	Spindle orientation command
Y189F	Y18FF	Y195F	Y19BF	Y1A1F	Y1A7F	Y1ADF	Y1B3F	LRSL	L coil selection
Y18A2	Y1902	Y1962	Y19C2	Y1A22	Y1A82	Y1AE2	Y1B42		
Y18A3	Y1903	Y1963	Y19C3	Y1A23	Y1A83	Y1AE3	Y1B43		
Y18A5	Y1905	Y1965	Y19C5	Y1A25	Y1A85	Y1AE5	Y1B45	CMOD	Spindle position control (Spindle/C axis control): C axis selection
Y18A6	Y1906	Y1966	Y19C6	Y1A26	Y1A86	Y1AE6	Y1B46	LRSM	M coil selection
Y18A8	Y1908	Y1968	Y19C8	Y1A28	Y1A88	Y1AE8	Y1B48	SWS	Spindle selection
Y18AA	Y190A	Y196A	Y19CA	Y1A2A	Y1A8A	Y1AEA	Y1B4A	SPRR	Spindle rotation reversal
Y18AB	Y190B	Y196B	Y19CB	Y1A2B	Y1A8B	Y1AEB	Y1B4B	SPRS	Spindle rotation direction switch method selection
Y18AF	Y190F	Y196F	Y19CF	Y1A2F	Y1A8F	Y1AEF	Y1B4F	MPCSL	PLC coil changeover
Y18B0	Y1910	Y1970	Y19D0	Y1A30	Y1A90	Y1AF0	Y1B50	SPSY	Spindle synchronization
Y18B1	Y1911	Y1971	Y19D1	Y1A31	Y1A91	Y1AF1	Y1B51	SPPHS	Spindle phase synchronization
Y18B2	Y1912	Y1972	Y19D2	Y1A32	Y1A92	Y1AF2	Y1B52	SPSDR	Spindle synchronous rotation direction
Y18B3	Y1913	Y1973	Y19D3	Y1A33	Y1A93	Y1AF3	Y1B53	SSPHM	Phase shift calculation request
Y18B4	Y1914	Y1974	Y19D4	Y1A34	Y1A94	Y1AF4	Y1B54	SSPHF	Phase offset request
Y18B5	Y1915	Y1975	Y19D5	Y1A35	Y1A95	Y1AF5	Y1B55	SP-DRPO	Error temporary cancel
Y18B8	Y1918	Y1978	Y19D8	Y1A38	Y1A98	Y1AF8	Y1B58	SPSYC	Spindle synchronization/superimposition cancel
Y18B9	Y1919	Y1979	Y19D9	Y1A39	Y1A99	Y1AF9	Y1B59	SPC-MPC	Chuck close
Y18BF	Y191F	Y197F	Y19DF	Y1A3F	Y1A9F	Y1AFF	Y1B5F	SPOFF	Spindle off request
Y18C8	Y1928	Y1988	Y19E8	Y1A48	Y1AA8	Y1B08	Y1B68		Spindle oscillation command
Y18C9	Y1929	Y1989	Y19E9	Y1A49	Y1AA9	Y1B09	Y1B69		
Y18CA	Y192A	Y198A	Y19EA	Y1A4A	Y1AAA	Y1B0A	Y1B6A	VGH-LDC	Real-time tuning 1: Speed control gain changeover hold-down command

2 Input/Output Signals with Controller

2.7 Classified for Each Application

[PLC -> CNC]

Device No.								Abbrev.	Signal name
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8		
YCD1	YE11	YF51	Y1091	Y11D1	Y1311	Y1451	Y1591		Spindle-spindle polygon cancel
YCD2	YE12	YF52	Y1092	Y11D2	Y1312	Y1452	Y1592		Synchronous tapping command polarity reversal
YCD3	YE13	YF53	Y1093	Y11D3	Y1313	Y1453	Y1593		Spindle OFF mode
YCE1	YE21	YF61	Y10A1	Y11E1	Y1321	Y1461	Y15A1		Door open II
YCE2	YE22	YF62	Y10A2	Y11E2	Y1322	Y1462	Y15A2		Door open signal input (spindle speed monitor)
YCE3	YE23	YF63	Y10A3	Y11E3	Y1323	Y1463	Y15A3		Door interlock spindle speed clamp

[PLC -> CNC]

Device No.								Abbrev.	Signal name
1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP		
R7000	R7050	R7100	R7150	R7200	R7250	R7300	R7350		Spindle command rotation speed output (L)
R7001	R7051	R7101	R7151	R7201	R7251	R7301	R7351		Spindle command rotation speed output (H)
R7002	R7052	R7102	R7152	R7202	R7252	R7302	R7352	SLSP	Spindle command selection
R7003	R7053	R7103	R7153	R7203	R7253	R7303	R7353		Optimum acceleration/deceleration parameter group selection [spindle] ▲
R7004	R7054	R7104	R7154	R7204	R7254	R7304	R7354		Spindle target machining time ▲
R7008	R7058	R7108	R7158	R7208	R7258	R7308	R7358		S command override
R7009	R7059	R7109	R7159	R7209	R7259	R7309	R7359		Multi-point orientation position data
R7010	R7060	R7110	R7160	R7210	R7260	R7310	R7360	ORDIR	Orientation rotation direction ▲
R7016	R7066	R7116	R7166	R7216	R7266	R7316	R7366		Spindle synchronization: Reference spindle selection
R7017	R7067	R7117	R7167	R7217	R7267	R7317	R7367		Spindle synchronization: Synchronized spindle selection
R7018	R7068	R7118	R7168	R7218	R7268	R7318	R7368		Spindle synchronization: Phase shift amount
R7019	R7069	R7119	R7169	R7219	R7269	R7319	R7369		Spindle synchronization: Phase error tolerance
R7020	R7070	R7120	R7170	R7220	R7270	R7320	R7370		Spindle oscillation amplitude
R7021	R7071	R7121	R7171	R7221	R7271	R7321	R7371		Spindle oscillation frequency

Device No.								Abbrev.	Signal name
\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8		
R2567	R2767	R2967	R3167	R3367	R3567	R3767	R3967		Encoder selection

Other Devices

In addition to X, Y and R devices described above, the following devices exist:

Name	Symbol	Description
Internal relay Latch relay	M F L	<ul style="list-style-type: none"> Internal and latch relays are auxiliary relays in the sequence that cannot directly be output to the external. The latch relay L will be backed up even if the power is turned OFF. The internal relay F may be used as the interface for the alarm message display.
Timer	T ST	<ul style="list-style-type: none"> Timers T are count-up timers. Timer T and ST can set the timer value from either the sequence program or setting and display unit. The 100ms, 10ms and 100ms integral timer are available.
Counter	C	<ul style="list-style-type: none"> Counters C are count-up counters. Counter C can set the counter value from either the sequence program or setting and display unit.
Data register	D	<ul style="list-style-type: none"> The data register stores sequence data. One data register consists of 16 bits and can be read or written in 16-bit units. To handle 32-bit data, two data registers are used. The data register addressed by a 32-bit command is used as the low-order 16 bits; the data register addressed by the specified data register number +1 is used as the high-order 16 bits.
File register	R	<ul style="list-style-type: none"> The file register release area can be used in the same manner as the data register. One file register consists of 16 bits and can be read or written in 16-bit units. To handle 32-bit data, two data registers are used. The file register addressed by a 32-bit command is used as the low-order 16 bits; the file register addressed by the specified file register number +1 is used as the high-order 16 bits.

The assignment tables are on the following pages. Copy and use them as necessary.

[illegible]

Explanation of Interface Signals

■ How to read the signals

Cont.	Signal name	Abbrev.	Common(\$)
B	DATA PROTECT KEY 1	*KEY1	Y708



(1)



(2)



(3)



(4)

No.	Description
(1)	Types of contact A : Becomes valid when turned ON (A contact) B : Becomes valid when turned OFF (B contact) <Note> * An asterisk "*" is prefixed to a B-contact signal abbreviation.
(2)	Signal name
(3)	Signal abbreviation
(4)	Device No. Common(\$): Device No. common for part systems \$1 ~ \$n : Device No. per part system or axis device No. 1st SP ~ 8th SP : Device No. per spindle

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Board reset	BRST	X2F0

[Function]

This signal indicates that the NC keyboard or the soft keyboard reset button is pressed.

[Operation]

When the NC keyboard or the soft keyboard reset button is pressed, this signal turns ON; and then it turns OFF after 10ms.

NC will not be reset even if this signal is turned ON. In order to reset the NC, check the status of this signal with ladder, and turn NC reset (NRST1), etc. ON/OFF.

[Related signals]

- (1) NC reset 1 (NRST1)
- (2) NC reset 2 (NRST2)
- (3) Reset & rewind (RRW)

Cont.	Signal name	Abbrev.	Common (\$)
A	Power consumption computation: Consumption accumulation ON 1 to 4	IPCE1 to 4	X700 to 3

[Function]

This signal notifies that "Power consumption computation: Enable consumption accumulation 1 to 4" is ON.

[Operation]

When the "Power consumption computation: Enable consumption accumulation 1 to 4" signal (Y724 or later) is turned ON, this signal turns ON.

When the "Power consumption computation: Enable consumption accumulation 1 to 4" signal (Y724 or later) is turned OFF, this signal turns OFF.

[Related signals]

- (1) Power consumption computation: Enable consumption accumulation 1 to 4 (IPCE1 to 4: Y724 to 7)

Cont.	Signal name	Abbrev.	Common (\$)
A	Power OFF processing		X707

[Function] [Operation]

This signal notifies that the power OFF processing is in execution.

This signal remains ON until the control unit's power is turned OFF.

Refer to the section of the "Automatic power OFF request" signal (Y75D) for details.

0: Not executed

1: During execution

[Related signals]

- (1) Automatic power OFF request (Y75D)
- (2) Power OFF indication Y device No. (R215)

Cont.	Signal name	Abbrev.	Common (\$)
A	Power consumption computation: Clearing consumption accumulation 1 to 4 complete	IPCCC1 to 4	X708 to B

[Function]

This signal notifies that "Power consumption computation: Clear consumption accumulation 1 to 4" is completed.

[Operation]

When the "Power consumption computation: Clear consumption accumulation 1 to 4" signal (Y700 or later) is turned ON, this signal turns ON.

When the "Power consumption computation: Clear consumption accumulation 1 to 4" signal (Y700 or later) is turned OFF, this signal turns OFF.

[Caution]

- (1) When this signal is ON, turn OFF the "Power consumption computation: Clear consumption accumulation 1 to 4" signal (Y700 or later) OFF.

[Related signals]

- (1) Power consumption computation: Clear consumption accumulation 1 to 4 (IPCC1 to 4: Y700 to 3)

4 Explanation of Interface Signals**4.1 PLC Input Signals (Bit Type: X***)**

Cont.	Signal name	Abbrev.	Common (\$)
A	Battery warning	BATWR	X70E

[Function]

This signal indicates that the battery voltage that is supplied to the control equipment (NC controller or graphic control unit) to save data and to the absolute encoders has dropped below the battery warning detection threshold.

[Operation]

This signal turns ON when:

- The battery voltage for saving data, which is checked constantly, has dropped below the battery warning detection threshold.

The alarm message "Z52 Battery fault 0001" is displayed for NC control unit; "Z52 Battery fault 0010" for graphic control unit; and "Z52 Battery fault 0011" for both units.

The alarm display is cleared by reset, but the signal does not turn OFF.

- A drop in the battery voltage that is supplied to the absolute encoder is detected.

The alarm messages "Z73 Battery for abs data fault 0001" and "S52 Servo warning 009F" are displayed.

Even if this signal is ON, it is possible to start cycle operation.

This signal turns OFF when:

- The battery voltage drops below the battery alarm detection threshold, and the battery alarm signal (BATAL) turns ON.
- If the alarm was triggered by the (1) of conditions to turn the signal ON, this signal is turned OFF by reset after battery replacement.

[Caution]

- (1) When this signal (X70E) turns ON, battery replacement is recommended.
- (2) When the detection of battery alarm or battery warning is disabled (#6449 bit4=1), this signal will not turn ON, and no alarm messages are displayed.

[Related signals]

- (1) Battery alarm (BATAL: X70F)
- (2) Battery drop cause (R56)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Battery alarm	BATAL	X70F

[Function]

This signal indicates that the battery voltage that is supplied to the control equipment (NC controller or graphic control unit) to save data and to the absolute encoders has dropped below the battery alarm detection threshold.

[Operation]

The signal turns ON when:

- (1) The battery voltage for saving data, which is checked constantly, has dropped below the battery alarm detection threshold.
The alarm message "Z52 Battery fault 0003" is displayed for NC control unit, "Z52 Battery fault 0030" is displayed for graphic control unit, and "Z52 Battery fault 0033" is displayed for both units.
- (2) An error is detected in the circuit to monitor the battery voltage for saving data. The alarm message "Z52 Battery fault 0002" is displayed for NC control unit, "Z52 Battery fault 0020" is displayed for graphic control unit, and "Z52 Battery fault 0022" is displayed for both units.
- (3) The drop in the voltage of backup power supply (battery voltage) in an absolute encoder is detected. The alarm message "Z71 AbsEncoder: Backup voltage drop 0001" is displayed.
- (4) The absolute position is lost due to the drop in the voltage of backup power supply (battery voltage) in an absolute encoder.

The alarm message "Z70 Abs posn error (servo alm 25) 0101" is displayed.

When this signal is ON, cycle operation cannot be started.

The signal turns OFF when:

- ♦ Reset was done after battery replacement (if the alarm is caused by the ON condition (1)).
- ♦ After the error in power supply voltage is eliminated, the power was turned ON again (if the alarm is caused by the ON conditions (2) and (3)).

[Caution]

- (1) When the battery alarm occurs, especially due to the ON condition (1), turning OFF the power of the control equipment without battery replacement may corrupt stored data such as machining programs. Replace the battery and confirm that this signal is turned OFF before turning OFF the power of the control equipment.
If the battery alarm has already occurred when the power of the control equipment is turned ON, especially due to the ON condition (1), consider that the stored data such as machining programs have been corrupted.
- (2) If detection of battery alarm or battery warning is disabled (#6449/bit4 = 1), this signal is not turned ON and no alarm messages is displayed.
- (3) As a precaution against this alarm, ensure that data in control equipment are backed up.

[Related signals]

- (1) Battery warning (BATWR: X70E)
- (2) Battery drop cause (R56)

Cont.	Signal name	Abbrev.	Common (\$)
A	High-speed simple program check mode ON	SMLKO	X712

[Function]

This signal indicates that the high-speed simple program check mode has been entered.

[Operation]

This signal turns ON when the "High-speed simple program check mode" signal (SMLK: Y73E) is input.

[Related signals]

- (1) High-speed simple program check mode (SMLK: Y73E)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	Common (\$)
A	High-speed simple program check: Coordinate position check ON	SPSCO	X713

[Function]

This signal informs that the coordinate position check is enabled during the high-speed simple program check.

[Operation]

This signal turns ON when the "High-speed simple program check: Enable coordinate position check" signal (Y76B) is ON.

This signal turns OFF when the "High-speed simple program check: Enable coordinate position check" signal (Y76B) is OFF.

[Related signals]

- (1) High-speed simple program check mode (SMLK: Y73E)
- (2) High-speed simple program check mode ON (SMLKO: X712)
- (3) High-speed simple program check: Enable coordinate position check (SPSC: Y76B)

Cont.	Signal name	Abbrev.	Common (\$)
A	Manual arbitrary reverse run: Actual cutting mode ON	PNCMDO	X714

[Function]

When the parameter "#1260 set32/bit0" (Switching to actual cutting mode during automatic operation) is set to "1", this signal indicates that the actual cutting mode in manual arbitrary reverse run is valid.

When the parameter "#1260 set32/bit0" is set to "0", this signal does not turn ON/OFF.

[Operation]

This signal turns ON when:

- Except for the specific movement block during thread cutting, thread cutting cycle and tapping cycle, the "Manual arbitrary reverse run mode ON" (X715) is turned ON and the "Actual cutting mode (thread, tap) in manual arbitrary reverse run" (Y761) is turned ON.

This signal turns OFF when:

- Except for the specific movement block during thread cutting, thread cutting cycle and tapping cycle, the "Manual arbitrary reverse run mode ON" (X715) is turned OFF and the "Actual cutting mode (thread, tap) in manual arbitrary reverse run" (Y761) is turned OFF.

For the specific movement block, refer to the section "Actual cutting mode (thread, tap) in manual arbitrary reverse run (Y761)".

[Related signals]

- (1) Manual arbitrary reverse run mode (MORR: Y73C)
- (2) Manual arbitrary reverse run mode ON (PCHKO: X715)
- (3) Manual arbitrary reverse run speed selection (MORSP: Y73D)
- (4) Actual cutting mode (thread, tap) in manual arbitrary reverse run (MRCMD: Y761)
- (5) Manual arbitrary reverse run: MSTB reverse run prohibited (MRPSG: YCFC)
- (6) Manual arbitrary reverse run speed multiplier (R379)
- (7) Manual arbitrary reverse run: Reverse run ON (MOREV: X716)
- (8) Manual arbitrary reverse run handle selection (R375)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Manual arbitrary reverse run mode ON	PCHKO	X715


[Function]

This signal informs that the manual arbitrary reverse run mode is in operation.

[Operation]

This signal is turned ON while the manual arbitrary reverse run mode is in operation.

This signal is turned OFF when the manual arbitrary reverse run mode is cancelled.

[Operation sequence]**[Related signals]**

- (1) Manual arbitrary reverse run: Reverse run ON (MOREV: X716)
- (2) Thread, tap block stopping in manual arbitrary reverse run (MBSTP: X74D)
- (3) Thread, tap reverse run prohibition alarm in manual arbitrary reverse run (MRVNG: X74E)
- (4) Manual arbitrary reverse run mode (MORR: Y73C)
- (5) Manual arbitrary reverse run speed selection (MORSP: Y73D)
- (6) Manual arbitrary reverse run: Actual cutting mode ON (thread, tap) (MRCMD: Y761)
- (7) Manual arbitrary reverse run: Reverse run block stop designated part system (RBSSY: YD01)
- (8) Manual arbitrary reverse run: MSTB reverse run prohibited (MRPSG: YCFC)
- (9) Manual arbitrary reverse run handle selection (R375)
- (10) Manual arbitrary reverse run speed multiplier (R379)

Cont.	Signal name	Abbrev.	Common (\$)
A	Manual arbitrary reverse run: Reverse run ON	MOREV	X716

[Function]

This signal indicates the forward/reverse status during the manual arbitrary reverse run.

[Operation]

This signal turns ON when reverse run is performed during the manual arbitrary reverse run.

This signal is OFF during forward run.

[Related signals]

- (1) Manual arbitrary reverse run mode ON (PCHKO: X715)
- (2) Thread, tap block stopping in manual arbitrary reverse run (MBSTP: X74D)
- (3) Thread, tap reverse run prohibition alarm in manual arbitrary reverse run (MRVNG: X74E)
- (4) Manual arbitrary reverse run mode (MORR: Y73C)
- (5) Manual arbitrary reverse run speed selection (MORSP: Y73D)
- (6) Actual cutting mode (thread, tap) in manual arbitrary reverse run (MRCMD: Y761)
- (7) Manual arbitrary reverse run: MSTB reverse run prohibited (MRPSG: YCFC)
- (8) Manual arbitrary reverse run: Reverse run block stop designated part system (RBSSY: YD01)
- (9) Manual arbitrary reverse run handle selection (R375)
- (10) Manual arbitrary reverse run speed multiplier (R379)

Cont.	Signal name	Abbrev.	Common (\$)
A	Collecting diagnosis data		X723

[Function]

This signal informs that collecting history data is being executed by the operation history function.

[Operation]

This signal turns ON while collecting history data is executed.

[Related signals]

- (1) Collecting diagnosis data stop (Y72B)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Power OFF required after parameter change		X72F

[Function]

This signal informs that the set parameter is not valid unless the power is turned OFF and ON.

[Operation]

When the following operation is executed, the "Power OFF required after parameter change" signal is output, and the display symbol "PR" is displayed in the operation status section.

- When you set the parameters or input data to them that become valid after the power is turned OFF and ON.
- When you set the auxiliary axis parameters or input data to them that become valid after the power is turned OFF and ON.
- The maintenance data for the ALL1 is input.
- The backup data is input with the SRAM backup function.

When the power is turned OFF and ON, the "Power OFF required after parameter change" signal turns OFF, and the "PR" display disappears.

Note

- (1) Even if the same value is set to the parameter which requires the power OFF and ON, the "Power OFF required parameter change" signal is output, and the "PR" is displayed.
- (2) Even if the value is returned to the original value after setting the parameter which requires the power OFF and ON, the "Power OFF required after parameter change" signal remains ON, and the "PR" also remains displayed.
- (3) When the parameters with DDB or G10 are rewritten, the "Power OFF required after parameter change" signal is not output, and the "PR" is not displayed. Because they do not require the power OFF and ON.

Cont.	Signal name	Abbrev.	Common (\$)
A	Thread, tap block stopping in manual arbitrary reverse run	MBSTP	X74D

[Function]

This signal notifies the PLC that a block stop occurred before moving to thread cutting or tapping during the manual arbitrary reverse run.

[Operation]

When the "Actual cutting mode (thread, tap) in manual arbitrary reverse run" signal (MRCMD) is ON, a block stop occurs before moving to thread cutting and tapping.

This signal turns ON when this block stop occurs.

If cycle start is executed in this state, thread cutting and tapping start and this signal turns OFF.

[Related signals]

- (1) Manual arbitrary reverse run mode ON (PCHKO: X715)
- (2) Manual arbitrary reverse run: Reverse run ON (MOREV: X716)
- (3) Thread, tap reverse run prohibition alarm in manual arbitrary reverse run (MRVNG: X74E)
- (4) Manual arbitrary reverse run mode (MORR: Y73C)
- (5) Manual arbitrary reverse run speed selection (MORSP: Y73D)
- (6) Actual cutting mode (thread, tap) in manual arbitrary reverse run (MRCMD: Y761)
- (7) Manual arbitrary reverse run: MSTB reverse run prohibited (MRPSG: YCFC)
- (8) Manual arbitrary reverse run: Reverse run block stop designated part system (RBSSY: YD01)
- (9) Manual arbitrary reverse run handle selection (R375)
- (10) Manual arbitrary reverse run speed multiplier (R379)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Thread, tap reverse run prohibition alarm in manual arbitrary reverse run	MRVNG	X74E

[Function]

This signal notifies the PLC that the reverse run prohibition alarm occurred at the thread cutting or tapping block during the manual arbitrary reverse run.

[Operation]

If the "Actual cutting mode (thread, tap) in manual arbitrary reverse run" signal (MRCMD) is ON, the thread cutting and tapping blocks are not executed when reverse run is performed.

This reverse run prohibition alarm turns ON at these blocks.

The alarm signal is kept ON and turned OFF when forward run is executed.

[Related signals]

- (1) Manual arbitrary reverse run mode ON (PCHKO: X715)
- (2) Manual arbitrary reverse run: Reverse run ON (MOREV: X716)
- (3) Thread, tap block stopping in manual arbitrary reverse run (MBSTP: X74D)
- (4) Manual arbitrary reverse run mode (MORR: Y73C)
- (5) Manual arbitrary reverse run speed selection (MORSP: Y73D)
- (6) Actual cutting mode (thread, tap) in manual arbitrary reverse run (MRCMD: Y761)
- (7) Manual arbitrary reverse run: MSTB reverse run prohibited (MRPSG: YCFC)
- (8) Manual arbitrary reverse run: Reverse run block stop designated part system (RBSSY: YD01)
- (9) Manual arbitrary reverse run handle selection (R375)
- (10) Manual arbitrary reverse run speed multiplier (R379)

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Operation trigger status		X74F

[Function]

This signal notifies that one of the update, delete, or extraction operation requests is being sent to the database.

[Operation]

0: This signal notifies that update, delete, or extraction operation request is not being sent to the database.

1: This signal notifies that update, delete, or extraction operation request is being sent to the database.

[Related signals]

- (1) MES interface library: DB operation selection (R14598)
- (2) MES interface library: Operation table selection (R14599)
- (3) MES interface library: Operation trigger (Y1C80)

Cont.	Signal name	Abbrev.	Common (\$)
A	24 hours continuous operation	CNOP	X752

[Function]

This signal notifies that the connector status of the drive power has been ON for over 24 hours.

[Operation]

When the "Contactor shutoff test" signal (Y742) is turned ON and the contactor shutoff is confirmed by the contactor shutoff test, the "24 hours continuous operation" signal (X752) turns OFF.

[Caution]

There is a possibility that the contactor is welded and so your safety may not be secured when "24 hours continuous operation" signal is output. Thus, under this condition, do not input "speed monitor mode" signal to open the door.

[Related signals]

- (1) Contactor shutoff test (MCT: Y742)
- (2) Speed monitor mode (SOMD: R296)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	Common (\$)
A	In multi-step speed monitor	MSOE	X753

[Function]

This signal turns ON when the multi-step speed monitor is valid and the speed monitor mode is enabled.


[Operation]

When the "Contactor shutoff test" signal (Y742) is turned ON and the contactor shutoff is confirmed by the contactor shutoff test, the "24 hours continuous operation" signal (X752) turns OFF.

When the multi-step speed monitor is valid and one of the door groups (bit) of the "Door open enable" signal turns ON, this signal turns ON.

When the speed monitor mode turns OFF and all the "Door open enable" signals turn OFF, this signal turns OFF.

While the multi-step speed monitor is invalid, even in the speed monitor mode, this signal does not turn ON.



[Related signals]

- (1) Speed monitor mode (SOMD: R296)
- (2) Speed monitor door open possible (SMDOEN: R96)
- (3) Multi-step speed monitor selected speed output (SOPFN: R98)

Cont.	Signal name	Abbrev.	Common (\$)
A	Pallet program registration Ext. workpiece coordinate transfer completion		X758

[Function] [Operation]


Completion of transfer from extension workpiece coordinate to external workpiece coordinate offset (EXT) during pallet 4 page registration is displayed.

This signal turns ON at the completion of transfer processing.

This signal turns OFF when external workpiece coordinate transfer ready is turned OFF.

The transferred external workpiece coordinate offset (EXT) becomes effective when this signal is turned ON.

[Timing chart]



[Related signals]

- (1) Pallet program registration Ext. workpiece coordinate transfer ready (Y72F)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Graphic check (check method II) in progress		X759

[Function]

This signal notifies that the graphic check (check method II) is in progress.

[Operation]

The signal turns ON when:

- The program check is in operation by the graphic check (check method II).

The signal turns OFF when:

- The program check by the graphic check (check method II) is completed.
(Except for the program stop by check step)

Cont.	Signal name	Abbrev.	Common (\$)
A	\$1 to \$8 display		X760 to 7

[Function]

This signal indicates the part system displayed on the screen.

[Operation]

This signal turns ON when the part-system display has been changed by pressing the part system changeover key, by turning ON the "Display changeover \$1 to \$8" signal (DISP1 to 8), or with the touchscreen.

[Related signals]

- (1) Display changeover \$1 to \$8 (DISP1 to 8: Y730 to 737)

Cont.	Signal name	Abbrev.	Common (\$)
A	Interference check III: Interfering object selection data setting completed	ITF3DTF	X771

[Function]

This signal notifies that the interference check III interfering object selection data setting is enabled.

[Operation]

This signal turns ON when the interfering object selection data defined in the system variables (#40000 to #40097) or the "Interference check III: interfering object selection" (R20304 to R20449) has successfully been imported into NC as the interference check III execution data.

This signal turns OFF once the "Interference check III: Enable interfering object selection data" (Y769) is turned OFF.

[Related signals]

- (1) Interference check III: Enable interfering object selection data (ITF3VLDT: Y769)

Cont.	Signal name	Abbrev.	Common (\$)
A	Interference check III: In interference check III mode	ITF3MD	X772

[Function]

This signal notifies that the interference check III is in execution.

[Operation]

This signal turns ON while the interference check III is in execution.

This signal turns OFF once the "Interference check III: mode" (Y76A) is turned OFF.

Note

- (1) While the operation error (M03 0001) is occurring, this signal is not turned OFF even though the "Interference check III: mode" (Y76A) is turned OFF.

[Related signals]

- (1) Interference check III: Interference check III mode (ITF3CMD: Y76A)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Interference check between part systems: Mode is active		X773

[Function]

This signal notifies that the interference check between part systems is in execution.

[Operation]

This signal turns ON while the interference check between part systems is in execution.

This signal turns OFF once the "Interference check between part systems: Interference check enabled" (Y73F) is turned OFF.

[Related signals]

- (1) Interference check between part systems: Interference check enabled (Y73F)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronizing mode	GBMOD	X778

[Function]

This signal notifies that the guide bushing (G/B) spindle synchronization mode is in execution.

[Operation]

This signal is ON while the "G/B spindle synchronization valid" (GBON) is ON.

This signal turns OFF at an emergency stop or when the "G/B spindle synchronization: Temporary cancel" (GBOFF) turns ON.

[Related signals]

- (1) G/B spindle synchronization valid (GBON: Y778)
- (2) G/B spindle synchronization: Temporary cancel (GBOFF: Y77D)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization: Position control synchronizing	GBSYN	X779

[Function]

This signal notifies that the reference spindle and the guide bushing (G/B) spindle are in the spindle synchronization state.

[Operation]

This signal is ON while the reference spindle and the guide bushing spindle are in the spindle synchronization state.

This signal turns OFF at an emergency stop or when the "G/B spindle synchronization: Temporary cancel" (GBOFF) turns ON.

[Related signals]

- (1) G/B spindle synchronization valid (GBON: Y778)
- (2) G/B spindle synchronization: Temporary cancel (GBOFF: Y77D)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization: Phase alignment complete	GBPHF	X77A

[Function]

This signal notifies that the phase alignment between the reference spindle and the guide bushing (G/B) spindle is completed.

[Operation]

This signal turns ON when the phase alignment of the phase gap (relative position) between the reference spindle and the guide bushing spindle saved in advance is completed.

[Related signals]

- (1) G/B spindle synchronization valid (GBON: Y778)
- (2) G/B spindle synchronization: Phase alignment (GBPHS: Y77A)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization: Position error compensating	GBPCM	X77B

[Function]

This signal notifies that guide bushing (G/B) spindle synchronization position error compensation is in execution.

[Operation]

This signal turns ON when the guide bushing spindle synchronization position error compensation becomes in execution and when refreshing the compensation amount is completed to be repeated by the number of times set in R390 (Guide bushing spindle synchronization position error compensation scale and the number of times of compensations).

This signal turns OFF:

- ♦ When both the "G/B spindle synchronization: Keep position error compensation amount" signal (GBCM KP) and the "G/B spindle synchronization: Position error compensation" signal (GBCM ON) are turned OFF
- ♦ When the guide bushing spindle synchronization mode is canceled
- ♦ When the guide bushing spindle synchronization position error compensation amount is being measured

[Related signals]

- (1) G/B spindle synchronization valid (GBON: Y778)
- (2) G/B spindle synchronization: Position error compensation (GBCM ON: Y77C)
- (3) G/B spindle synchronization: Keep position error compensation amount (GBCM KP: Y77E)
- (4) G/B spindle synchronization: Position error compensation scale and the number of times of compensations (R390)
- (5) G/B spindle synchronization: Position error compensation amount (R465)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Servo ready n-th axis	RDY1 to 8	X780 to 7	X788 to F	X790 to 7	X798 to F

[Function]

This signal indicates that the drive section of the nth axis is ready for operation.


[Operation]

This signal turns ON when:

- ♦ The power supply of the controller is turned ON and the diagnosis on the servo system has been completed successfully.
- ♦ Servo alarm has been reset.
- ♦ Emergency stop has been reset.
- ♦ Servo off signal (*SVFn) is reset.

This signal turns OFF when:

- ♦ Servo alarm occurs.
- ♦ Emergency stop is issued.
- ♦ Servo off signal (*SVFn) is input.

[Operation sequence]**[Related signals]**

- (1) Servo ready completion (SA: XC11)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Axis selection n-th axis	AX1 to 8	X7A0 to 7	X7A8 to F	X7B0 to 7	X7B8 to F

[Function]

This signal indicates that motion command is issued to the control axis.

[Operation]

This signal turns ON when:

<Automatic operation>

The signal is ON while the motion command is issued to the end of movement, or to when automatic operation pause turns ON.

<Manual operation>

- For JOG mode

The signal is ON while "Feed axis selection +/-" signal (+Jn and -Jn) is ON.

- For handle mode

When "1st to 3rd handle axis selection code m" (HS1mn to HS3mn) and "Handle valid" signal (HS1Sn, HS2Sn, HS3Sn) have been selected, the "Axis selected" signal for the axis specified by the "1st to 3rd handle axis selection code m" signal (HS1mn to HS3mn) is ON.

- For incremental mode

The signal turns ON when "Feed axis selection +/-" signal (+Jn, -Jn) turns ON, and turns OFF when the specified motion is completed.

- For manual arbitrary feed mode

The signal turns ON when "Manual arbitrary feed strobe" signal (CXS8n) turns ON, and turns OFF when the specified motion is completed.


- For reference position return mode

The signal is ON while "Feed axis selection +/-" signal (+Jn and -Jn) is ON. After "Reference position return near point detection" signal is detected, and the motion speed changes to approach (creeping) speed, the "Axis selected" signal remains ON until the motion stops at the reference position, even when "Feed axis selection +/-" signal (+Jn and -Jn) turns OFF.

<Other conditions>

- The signal can turn ON even during machine lock (Z-axis is in cancellation). However, it does not turn ON during machine lock in manual operation mode.
- The signal remains on even when motion stops due to feedrate override set at 0%, manual control feedrate set at 0 mm/min, or 0 inch/min.
- Interlock does not affect status of this signal (the signal remains ON, or turns ON).
- Servo off signal does not affect status of this signal.
- The signal cannot be turned ON by G04 and G92.
- The signal turns OFF with "controller Reset & Rewind", or "Emergency stop".

(Example)



4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	In axis motion (+) n-th axis	MVP1 to 8	X7C0 to 7	X7C8 to F	X7D0 to 7	X7D8 to F

[Function]

This signal indicates that the specified axial motion is in plus (+) direction.


These signals are for each control axis. The last number (n = 1, 2, 3...) of the signal abbreviation indicates the control axis No.

[Operation]

The signal turns ON when the specified control axis starts moving in the plus direction or when it is moving.

The signal turns OFF when the specified control axis stops moving or when it moves in the minus direction.

An example of the timing chart for the jog mode is shown below.

**Note**

- (1) This signal operates regardless of the operation mode.
- (2) The real movement direction is indicated.
- (3) The signal does not turn ON during machine lock.

[Related signals]

- (1) In axis minus motion n-th axis (MVM1 to 8: X7E0 to 7)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	In axis motion (-) n-th axis	MVM1 to 8	X7E0 to 7	X7E8 to F	X7F0 to 7	X7F8 to F

[Function]

This signal indicates that the control axis is moving in the minus direction

[Operation]

This motion direction is the reverse of the plus motion, and the operation is the same as "In axis motion (+)" signal (MVPn).

[Related signals]

- (1) In axis plus motion n-th axis (MVP1 to 8: X7C0 to 7)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	1st reference position reached n-th axis	ZP11 to 18	X800 to 7	X808 to F	X810 to 7	X818 to F

[Function]

This signal indicates that the axial component of the nth axis is ON the 1st reference position.

These signals are for each control axis. The last number (n = 1, 2, 3...) of the signal abbreviation indicates the control axis No.

[Operation]

This signal turns ON when:

- 1st reference position reached is attained with reference position return mode in manual operation.
Refer to the "Reference position return" (ZRNn) section for details on returning.
- 1st reference position reached is attained with G28 command in automatic operation.

Note


- (1) If "1st reference position reached" is achieved in other operation mode, or by other command, the signal does not turn ON.

This signal turns OFF when:

- The axial component in position is relocated from the 1st reference position by motion command.
- Emergency stop signal is input or servo alarm occurs, causing stop to the machine.


<Reference position return operation pattern>

- Dog-type reference position return



- When basic machine coordinate system is not established.
- When dog-type return is selected with setup parameters, basic specification parameter "#1063 mandog" in the manual mode.

- High-speed reference position return



- When basic machine coordinate system is established.
- When high-speed return is selected with setup parameters, basic specification parameter "#1063 mandog" in the manual mode.

(Note)

Reference position return will be the high-speed return when the basic machine coordinate system is established (2nd time and following).

[Related signals]

- (1) 2nd reference position reached n-th axis (ZP21 to 28: X820 to 7)
- (2) 3rd reference position reached n-th axis (ZP31 to 38: X840 to 7)
- (3) 4th reference position reached n-th axis (ZP41 to 48: X860 to 7)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	2nd reference position reached n-th axis	ZP21 to 28	X820 to 7	X828 to F	X830 to 7	X838 to F

[Function]

This signal indicates that the axial component of the nth axis is on the 2nd reference position.

These signals are for each control axis. The last number (n = 1, 2, 3...) of the signal abbreviation indicates the control axis No.

[Operation]

This signal turns ON when:

- ♦ 2nd reference position reached is attained with G30 command (G30 P2) in automatic operation.
- ♦ 2nd reference position reached is attained with reference position return mode of automatic operation (Reference position selection code 1, 2).

Note

- (1) If "2nd reference position reached" is achieved in other operation mode, or by other command, the signal does not turn ON.

This signal turns OFF when:

- ♦ The axial component in position is relocated from the 1st reference position by motion command.
- ♦ Emergency stop signal is input or servo alarm occurs, causing stop to the machine.

[Related signals]

- (1) 1st reference position reached n-th axis (ZP11 to 18: X800 to 7)
- (2) 3rd reference position reached n-th axis (ZP31 to 38: X840 to 7)
- (3) 4th reference position reached n-th axis (ZP41 to 48: X860 to 7)
- (4) Reference position selection code m (ZSLmn: YC190,1)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	3rd reference position reached n-th axis	ZP31 to 38	X840 to 7	X848 to F	X850 to 7	X858 to F

[Function] [Operation]

This signal informs that the control axis is on the 3rd reference position.

Function and operation are the same as the 2nd reference position reached, but the reference position and G command are different.

- ♦ Reference position: 3rd reference position
- ♦ G command: G30 P3

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	4th reference position reached n-th axis	ZP41 to 48	X860 to 7	X868 to F	X870 to 7	X878 to F

[Function] [Operation]

This signal informs that the control axis is on the 4th reference position.

Function and operation are the same as the 2nd reference position reached, but the reference position and G command are different.

- ♦ Reference position: 4th reference position
- ♦ G command: G30 P4

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Near reference position n-th axis	NRF1 to 8	X880 to 7	X888 to F	X890 to 7	X898 to F

[Function]

This signal indicates that the control axis is near the 1st reference position in the absolute position detection system.

[Operation]

This signal turns ON when the control axis is in the range of the parameter set using the 1st reference position as a base point, and turns OFF when the range is exceeded. The parameter is set with #2057 (nrefp) and #2058 (nrefn) in the [ABS. POSI PARAM] screen.



Note

- (1) The "Near reference position" signal is output even while the axis is moving, but there may be deviation with the actual machine position.
 Rapid traverse: approximately 19 mm at 20 m/min
 Cutting feed: approximately 9.5 mm at 10 m/min
 If the distance of the setting value is shorter than the value indicated above, this signal may not be output.
- (2) This signal is valid only with the absolute position detection system.
- (3) When 0 is set for #2057 (nrefp) and #2058 (nrefn) in the [ABS. POSI PARAM] screen, it will be same as when the grid width is set.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Arbitrary axis superimposition complete n-th axis	PLFN1 to 8	X8A0 to 7	X8A8 to F	X8B0 to 7	X8B8 to F

[Function]

This signal indicates that which axis is controlled as the superimposition axis during the arbitrary axis superimposition control.

0: Axis not in the arbitrary axis superimposition control

1: Axis in the arbitrary axis superimposition control

[Operation]

This signal turns ON when the arbitrary axis superimposition control is established after the arbitrary axis superimposition control "start" is commanded.

This signal turns OFF when the arbitrary axis superimposition control "end" is commanded.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Zero point initialization set completed n-th axis	ZSF1 to 8	X8C0 to 7	X8C8 to F	X8D0 to 7	X8D8 to F

[Function]

This signal notifies that the basic machine coordinate system has been set (established) during zero point initialization set using the marked point alignment method in the absolute position detection system.


[Operation]

This signal is valid when "#2049 TYPE" on the [ABS. POSI PARAM] screen is set to "2", and turns ON when the basic machine coordinate system is set (established).


This signal will turn OFF if initializing is carried out again or if the power is turned ON again.

<Zero point initialization set method using marked point alignment method, and timing chart>

[Outline of zero point initialization set method]



[Time chart] (a) to (e) in the figure correspond to (a) to (e) above)

**[Related signals]**

- (1) Zero point initialization set error completed (ZSE1 to 8: X8E0 to 7)
- (2) In initialization (R574)
- (3) Initialization incompletion (R575)
- (4) Zero point initialization set mode (AZS1 to 8: Y960 to 7)
- (5) Zero point initialization set start (ZST1 to 8: Y980 to 7)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Zero point initialization set error completed n-th axis	ZSE1 to 8	X8E0 to 7	X8E8 to F	X8F0 to 7	X8F8 to F

[Function]

This signal is output when initializing is not possible during the marked point alignment method of the absolute position detection system.

[Operation]

This signal turns ON when the initializing is not possible at the rising edge of the "Zero point initialization set start" signal (ZSTn).

This signal is invalidated in the following cases:

- During emergency stop
- In "reset"
- When the "Zero point initialization set start" signal (ZSTn) is turned ON before the "Zero point initialization set mode" signal (AZSn).
- When grid has not been passed even once after the power has been turned ON. (Depends on the encoder type)

[Related signals]

- (1) Zero point initialization set completed (ZSF1 to 8: X8C0 to 7)
- (2) In initialization (R574)
- (3) Initialization incompleteness (R575)
- (4) Zero point initialization set mode (AZS1 to 8: Y960 to 7)
- (5) Zero point initialization set start (ZST1 to 8: Y980 to 7)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	In current limit n-th axis	ILI1 to 8	X900 to 7	X908 to F	X910 to 7	X918 to F

[Function] [Operation]

This signal turns ON during the current limit.

[Related signals]

- (1) Current limit reached n-th axis (ILA1 to 8: X920 to 7)
- (2) Current limit changeover n-th axis (ILC1 to 8: Y9A0 to 7)
- (3) Droop cancel request n-th axis (DOR1 to 8: Y9C0 to 7)
- (4) Current limit mode 1 and 2 (ILM1,2: YCC0,1)
- (5) Current limit changeover (R2593)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Current limit reached n-th axis	ILA1 to 8	X920 to 7	X928 to F	X930 to 7	X938 to F

[Function] [Operation]

This signal turns ON when the current reaches its limit during the current limit control.

[Related signals]

- (1) In current limit n-th axis (ILI1 to 8: X900 to 7)
- (2) Current limit changeover n-th axis (ILC1 to 8: Y9A0 to 7)
- (3) Droop cancel request n-th axis (DOR1 to 8: Y9C0 to 7)
- (4) Current limit mode 1 and 2 (ILM1,2: YCC0,1)
- (5) Current limit changeover (R2593)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	NC axis up-to-speed n-th axis	ARRFn	X940 to 7	X948 to F	X950 to 7	X958 to F


[Function]

This signal indicates that the actual axis feedrate has reached the feedrate commanded for each axis.

[Operation]

This signal turns ON when the difference of the speed commanded for each axis and the motor feedback feedrate is within a set range (approximately $\pm 15\%$).

This signal turns OFF when the speed difference exceeds the set range.

**[Related signals]**

- (1) In axis plus motion n-th axis (MVP1 to 8: X7C0 to 7)
- (2) In axis minus motion n-th axis (MVM1 to 8: X7E0 to 7)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Unclamp command n-th axis	UCLPn	X960 to 7	X968 to F	X970 to 7	X978 to F

[Function]

This signal is output when movement of the axis selected as the index table indexing axis is commanded.

[Operation]

"Type A" or "Type B" is selected by the parameter "#1282 ext18/bit3" (Index table clamp type).

<Type A ("#1282 ext18/bit3" is set to "0")>

When this signal turns ON, the index table indexing axis clamp is released by the PLC, and the "Unclamp completion" signal (UCLPFn) is set.

This signal turns OFF when movement of the index table indexing axis is completed.

This signal does not turn OFF if the axis movement is interrupted with an interlock or automatic operation suspension, etc.

When the "Unclamp completion" signal turns OFF during the movement of index table indexing axis in automatic operation, the "Unclamp command" remains ON and the index table indexing axis decelerates and stops.

Other axes commanded in the same block decelerate and stop in the same manner except for non-interpolation commands.

When the axis movement is stopped due to reset or emergency stop, etc., the "Unclamp command" is turned OFF even if the axis is not in the indexing position. Make sure not to clamp it.

<This signal turns ON in the following case>

- Movement of the indexing axis is commanded during automatic operation.

<This signal turns ON in the following case>

- Movement of the index table indexing axis is completed during automatic operation.
- The axis movement is forcibly terminated by reset or emergency stop, etc.

<Type B ("#1282 ext18/bit3" is set to "1")>

When this signal turns ON, the index table indexing axis clamp is released by the PLC, and the "Unclamp completion" signal (UCLPFn) is set.

<This signal turns ON in the following case>

- Movement of the index table indexing axis is commanded during automatic operation.

<This signal turns ON in the following case>

- The "Unclamp completion" signal turns ON by PLC. (Including during the axis movement.)
- The axis movement is forcibly terminated by reset or emergency stop, etc.

Note

- (1) This signal is turned ON and OFF when the index table indexing axis acceleration/deceleration has completed. Therefore, if the in-position has to be confirmed during the clamp and unclamp operation, confirm with the PLC.
- (2) Refer to the "Programming Manual" for operation details of each type A and type B.

[Related signals]

- (1) Unclamp completion (UCLPFn: YA20 to 7)
- (2) Clamp command (CLPn: XB00 to XB07)
- (3) Clamp completion (CLPFn: YB00 to YB07)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	In mixed control (cross axis control) n-th axis		X980 to 7	X988 to F	X990 to 7	X998 to F


[Function]

This signal is a status signal that indicates a state commanded by the "mixed control (cross axis control) request" signal.

[Operation]

The axis for which "in mixed control (cross axis control)" is "1".

(Example)

**[Related signals]**

- (1) Mixed control (cross axis control) request n-th axis (YA60 to 7)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	In synchronous/superimposition control n-th axis		X9A0 to 7	X9A8 to F	X9B0 to 7	X9B8 to F

[Function]

This signal informs the axis in the control axis synchronization between part systems/superimposition control.

0: Axis not in control axis synchronization between part systems/superimposition control

1: Axis in control axis synchronization between part systems/superimposition control

[Operation]

The synchronized axis/superimposed axis and synchronized reference axis/superimposed reference axis are indicated.

[Caution]

- (1) Since the control axis synchronization between part systems and the control axis superimposition control functions cannot be used simultaneously, when this signal is set to "1", it indicates that the axis is always in either synchronous control or superimposition control.

[Related signals]

- (1) Synchronous control request n-th axis (YA80 to 7)
 (2) Superimposition control request n-th axis (YAA0 to 7)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	In mirror image n-th axis	MIRn	X9C0 to 7	X9C8 to F	X9D0 to 7	X9D8 to F

[Function]

This signal indicates that a control axis is in mirror image.

There is a signal for each control axis. The number at the end of the signal name indicates the control axis No.

[Operation]

This signal turns ON when:

- ♦ Programmable mirror image
- ♦ Parameter setting mirror image
- ♦ External input mirror image
- ♦ Facing turret mirror image

This signal turns OFF when:

- ♦ The mirror image above is canceled.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Reference position establishment n-th axis		X9E0 to 7	X9E8 to F	X9F0 to 7	X9F8 to F

[Function]

This signal indicates that a reference position has been established.

There is a signal for each control axis. The number at the end of the signal name indicates the control axis No.

[Operation]

This signal turns ON when:

- ♦ Manual reference position return is completed and a reference position is established.
- ♦ A reference position is established by the absolute encoder when the power is turned ON.

This signal turns OFF when:

- ♦ The reference position is lost.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Reference position return direction n-th axis		XA00 to 7	XA08 to F	XA10 to 7	XA18 to F

[Function]

This signal indicates that whether the reference position selected by the "Reference position selection code 1, 2" or the "Each axis reference position selection" is in the positive direction or negative direction with respect to the current position.

[Operation]

This signal turns ON when:

- The reference position selected by the "Reference position selection code 1, 2" (ZSL1, ZSL2: YC90, YC91) or the "Each axis reference position selection" (R2584) is in the minus direction while reference position is established.

This signal turns OFF when:

- The reference position is in the plus direction.
- The current position is on the reference position
- The reference position is lost

Note

- (1) If the rotation axis type is other than all coordinate linear type, this signal turns ON when $0^\circ < \theta \leq 180^\circ$, and turns OFF when $180^\circ < \theta \leq 360^\circ$ (0°).
- (2) The "Reference position return direction" signal is not output for the reference position commanded by the machining program in an automatic operation.
- (3) The "Reference position selection code 1, 2" and the "Each axis reference position selection" hold the state of the reference position return start in the reference position return mode.
- (4) When the zero point is changed during reference position return while the "Reference position selection code 1, 2" is valid, the "Reference position return direction" is output to the zero point prior to the change.
- (5) When the zero point is changed during reference position return while the "Each axis reference position selection" is valid, the "Reference position return direction" is output to the zero point after the change.

[Related signals]

- (1) Reference position establishment (X9E0 to X9E7)
- (2) Reference position selection method (M: YC97)
- (3) Reference position selection code 1, 2 (ZSL1, 2: YC90, YC91)
- (4) Each axis reference position selection (R2584)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	In NC axis control n-th axis	-	XA20 to 7	XA28 to F	XA30 to 7	XA38 to F

[Function]

This signal indicates the control status (NC control or PLC control) of the NC axis which can be operated under PLC control.

[Operation]

This signal turns ON when the NC axis is under NC control.

This signal turns OFF when the NC axis is under the PLC control.

The following shows the correspondence of axis Nos. and device Nos.

Device No.	Signal name	Device No.	Signal name
XA20	In NC axis control 1st axis	XA24	In NC axis control 5th axis
XA21	In NC axis control 2nd axis	XA25	In NC axis control 6th axis
XA22	In NC axis control 3rd axis	XA26	In NC axis control 7th axis
XA23	In NC axis control 4th axis	XA27	In NC axis control 8th axis

[Caution]

- (1) The NC axis which can be operated under PLC control is the NC axis for which the axis No. for PLC axis indexing is set by the parameter "#12800 chgauxno".
- (2) If the axis is moving, turning ON/OFF the "NC axis control selection n-th axis" results in an operation error. After the axis decelerates and stops, the signal changes to ON/OFF.

[Related signals]

- (1) NC axis control selection n-th axis (YAC0 to YAC7)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Ext. machine coordinate system offset data illegal n-th axis	ECIL1 to 8	XA40 to 7	XA48 to F	XA50 to 7	XA58 to F

[Function]

This signal indicates that the external machine coordinate system offset data is illegal, as the changed amount by the data will exceed the rapid traverse feedrate.

[Operation]

This signal turns ON when the external machine coordinate system offset data is illegal.

Then the change of the external machine coordinate system offset data is ignored. The compensation is executed with the set value unchanged.

[Related signals]

- (1) Ext. machine coordinate system offset data n-th axis (R5700 to R5715)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Vertical axis pull-up prevented n-th axis		XA60 to 7	XA68 to F	XA70 to 7	XA78 to F

[Function]

This signal indicates that the vertical axis pull-up function has been prevented.

[Operation]

This signal is ON while the vertical axis pull-up function is prevented.

[Related signals]

- (1) Vertical axis pull-up prevention request (YAE0 to YAE7)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Clamp command n-th axis	CLPn	XB00 to 7	XB08 to F	XB10 to 7	XB18 to F

[Function]

This signal is output when movement of the axis selected as the index table indexing axis is completed.

[Operation]

"Type A" or "Type B" is selected by the parameter "#1282 ext18/bit3" (Index table clamp type).

<Type A ("#1282 ext18/bit3" is set to "0")>

This signal is not used.

<Type B ("#1282 ext18/bit3" is set to "1")>

When this signal is turned ON, the index table indexing axis is clamped by the PLC, and the "Clamp completion" signal turns ON.

<This signal turns ON in the following case>

- ♦ The movement of the index table indexing axis is completed by automatic operation.

<This signal turns ON in the following case>

- ♦ The "Clamp completion" signal is turned ON by PLC.
- ♦ At reset or emergency stop

Note

- (1) This signal is turned ON and OFF when acceleration/deceleration of the index table indexing axis is completed. Thus, if it is necessary to confirm the in-position during the clamp or unclamp operation, confirm with the PLC.
- (2) When this is stopped by reset while the index table indexing axis is moving in automatic operation, the clamp command is not output. Perform the necessary processing by PLC.
- (3) Refer to "Programming Manual" for operation details of each type A and type B.

[Related signals]

- (1) Unclamp command (UCLPn: X960 to X967)
- (2) Unclamp completion (UCLPFn: YA20 to YA27)
- (3) Clamp completion (CLPFn: YB00 to YB07)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Spindle-mode rotary axis control mode n-th axis	ROTSPM1 to 8	XB40 to 7	XB48 to F	XB50 to 7	XB58 to F

[Function]

This signal indicates that the control axis for which the rotary axis spindle control is enabled in the parameter setting is currently in the spindle mode.

This signal is a signal for each control axis, and the number at the end of the signal name indicates the control axis No.

[Related signals]

- (1) Spindle-mode rotary axis control command n-th axis (ROTSPCn: YB40 and following)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Each axis in-position n-th axis	AXINP1 to 8	XB60 to 7	XB68 to F	XB70 to 7	XB78 to F

[Function]

This signal informs the PLC that the control axis of the control unit is in-position state.

[Operation]

This signal turns ON when:

- There is no acceleration/deceleration delay on the control axis, and servo errors (remaining pulses) in positioning are within the range set by the parameter.


This signal turns OFF when:

- There is an acceleration/deceleration delay on the control axis.
- Servo positioning error (remaining pulses) of the control axis exceeds the range set by the parameter.

Note

- (1) The "Each axis in-position" signal may turn ON even while moving if the feedrate is extremely slow.

When all "Each axis in-position" signals in the part system turn ON, the "All axes in-position" signal turns ON.



[Caution]

- When the operation with machine lock is performed and variable-acceleration pre-interpolation acceleration/deceleration is enabled by the function such as high-accuracy control, the "Each axis in-position" signal is always ON.
- The "Each axis in-position" signal can not be used during the synchronous operation.

[Related signals]

- (1) All axes in-position (TIMP: XC19)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Real-time tuning 1: Speed control gain changeover hold-down ON	VGHLDC1 to 8	XB80 to 7	XB88 to F	XB90 to 7	XB98 to F

[Function]


This signal indicates that speed control gain switching is currently stopped in the real-time tuning 1 function.

[Operation]

This signal indicates that speed control gain switching is stopped and the value of speed control gain is retained.

This signal is output when the "Speed control gain changeover hold-down command" is ON or when the cutting command modal is effective, regardless of whether this function is enabled or disabled.

This signal is not output when speed control gain switching is performed. Also, the signal is not output when the additional specification of real-time tuning 1 is set to OFF.

**[Related signals]**

- (1) Real-time tuning 1: Speed control gain changeover hold-down command (VGHLDC1: YB80)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	NC axis/PLC axis switchover invalid status	NPCHGIS1 to 8	XBA0 to 7	XBA8 to F	XBB0 to 7	XBB8 to F

[Function]

This signal indicates that the NC axis/PLC axis switchover is disabled on the axis that is subject to the NC axis/PLC axis switchover.

This signal is available for each control axis.

[Operation]

This signal turns ON when the axis for which the NC axis/PLC axis switchover is valid is under the following conditions.

When the NC axis/PLC axis switchover is performed while this signal is ON, the operation error (M01 1250) occurs.

- While the axis is moving(*1)
- When the movement is stopped by the override zero or feed hold
- During the servo OFF
- While the axis is being removed
- While the axis is stopped for interlock
- During the current limit
- During the droop cancel
- During the H/W OT or soft limit
- During the manual machine lock
- The reference axis or superimposed axis that is under the control axis superimposition
- The reference axis or synchronized axis that is under the control axis synchronization between part systems
- The chopping axis during the chopping
- The rotary tool axis during the tool spindle synchronization II (polygon)
- The workpiece axis during the tool spindle synchronization II (hobbing)
- The axis of the part system which is during the high-speed machining mode II/high-speed high-accuracy control II

(*1) When a movement command is given to multiple axes in the same program block, even if the movement of the switchover target axis is completed and stopped, the switchover is disabled if the other axes are still moving.

[Related signals]

- (1) NC axis/PLC axis switchover in process (NPCHGMOD1 to 8: XBC0 to 7)
- (2) NC axis/PLC axis switchover request (NPCHGREQ1 to 8: YBC0 to 7)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	NC axis/PLC axis switchover n-th axis in process	NPCHG-MOD1 to 8	XBC0 to 7	XBC8 to F	XBD0 to 7	XBD8 to F

[Function]

This signal notifies that the NC axis/PLC axis switching axis is in a controllable state as a PLC axis.

This signal is available for each control axis.

[Operation]

This signal turns OFF while the NC axis is controlled and turns ON while the PLC axis is controlled.

[Related signals]

- (1) NC axis/PLC axis switchover invalid status (NPCHGIS1 to 8: XBA0 to 7)
- (2) NC axis/PLC axis switchover request (NPCHGREQ1 to 8: YBC0 to 7)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X**)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Machine group-based alarm stop: Machine group-based PLC interlock ON	GQEMGO1 to 8	XBE0 to 7	XBE8 to F	XBF0 to 7	XBF8 to F

[Function]

This signal indicates that operation is stopped by the machine group-based PLC interlock.

[Operation]

This signal indicates that operation is stopped by the machine group-based alarm stop function.

This signal is not output for alarm stops other than those caused by the machine group-based alarm stop function.

The signal assignments for each group are as follows:

Group 1	Group 2	Group 3	Group 4	Group 5	Group 6	Group 7	Group 8
XBE0	XBE1	XBE2	XBE3	XBE4	XBE5	XBE6	XBE7
Group 9	Group 10	Group 11	Group 12	Group 13	Group 14	Group 15	Group 16
XBE8	XBE9	XBEA	XBEB	XBEC	XBED	XBEE	XBEF
Group 17	Group 18	Group 19	Group 20	Group 21	Group 22	Group 23	Group 24
XBF0	XBF1	XBF2	XBF3	XBF4	XBF5	XBF6	XBF7
Group 25	Group 26	Group 27	Group 28	Group 29	Group 30	Group 31	Group 32
XBF8	XBF9	XBFA	XBFB	XBFC	XBFD	XBFE	XBFF


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In jog mode	JO	XC00	XD40	XE80	XFC0	X1100	X1240	X1380	X14C0

[Function]

This signal indicates that the JOG mode is selected.

[Operation]

After the "All axes smoothing zero" (TSMZ) (command acceleration/deceleration delay is zero) is verified, the mode changes from other mode to the JOG mode.

**[Related signals]**

- (1) All axes smoothing zero (TSMZ: XC1A)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In handle mode	HO	XC01	XD41	XE81	XFC1	X1101	X1241	X1381	X14C1

[Function]

This signal indicates that the handle mode is selected.

[Operation]

After the "All axes smoothing zero" (TSMZn) (command acceleration/deceleration delay is zero) is verified, the mode changes from other mode to the handle mode.

**[Related signals]**

- (1) All axes smoothing zero (TSMZ: XC1A)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In incremental mode	SO	XC02	XD42	XE82	XFC2	X1102	X1242	X1382	X14C2

[Function]

This signal indicates that the incremental mode is selected.

[Operation]

After the "All axes smoothing zero" (command acceleration/deceleration delay is zero) is verified, the mode changes from other mode to the incremental mode.



[Related signals]

- (1) All axes smoothing zero (TSMZ: XC1A)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In manual arbitrary feed mode	PTPO	XC03	XD43	XE83	XFC3	X1103	X1243	X1383	X14C3

[Function]

This signal indicates that the manual arbitrary feed mode is selected.

[Operation]

After the "All axes smoothing zero" (command acceleration/deceleration delay is zero) is verified, the mode changes from other mode to the manual arbitrary feed mode.



[Related signals]

- (1) All axes smoothing zero (TSMZ: XC1A)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In reference position return mode	ZRNO	XC04	XD44	XE84	XFC4	X1104	X1244	X1384	X14C4

[Function]

This signal indicates that the reference position return mode is selected.

[Operation]

After the "All axes smoothing zero" (command acceleration/deceleration delay is zero) is verified, the mode changes from other mode to the reference position return mode.



[Related signals]

- (1) All axes smoothing zero (TSMZ: XC1A)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In automatic initial set mode	ASTO	XC05	XD45	XE85	XFC5	X1105	X1245	X1385	X14C5

[Function]

This signal indicates that automatic initial set mode is selected.

[Operation]

After the "All axes smoothing zero" (command acceleration/deceleration delay is zero) is verified, the mode changes from other mode to the automatic initial set mode.

**[Related signals]**

- (1) All axes smoothing zero (TSMZ: XC1A)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In JOG-handle simultaneous mode	JHANO	XC06	XD46	XE86	XFC6	X1106	X1246	X1386	X14C6


[Function]

This signal indicates that the simultaneous operation of JOG and handle mode has been entered.

[Operation]

This signal turns ON regardless of the "All axes smoothing zero" signal (TSMZ) which informs there is no delay caused by the acceleration/deceleration time constants.

This signal will not turn ON when the "Jog mode" signal (J) is OFF, even if the "Jog handle synchronous" signal (JHAN) is ON.

[Timing chart]**[Related signals]**

- (1) Jog mode (J: YC00)
- (2) Jog handle synchronous (JHAN: YC7B)
- (3) All axes smoothing zero (TSMZ: XC1A)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In memory mode	MEMO	XC08	XD48	XE88	XFC8	X1108	X1248	X1388	X14C8

[Function]

This signal indicates that memory mode is selected.

[Operation]

When the "All axes smoothing zero" (command acceleration/deceleration delay is zero) is verified, the mode changes from other mode to memory mode.

**[Related signals]**

(1) All axes smoothing zero (TSMZ: XC1A)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In tape mode	TO	XC09	XD49	XE89	XFC9	X1109	X1249	X1389	X14C9

[Function]

This signal indicates tape mode is selected.

[Operation]

When the "All axes smoothing zero" (TSMZ) (command acceleration/deceleration delay is zero) is verified, the mode changes from other mode to tape mode.

**[Related signals]**

(1) All axes smoothing zero (TSMZ: XC1A)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In MDI mode	DO	XC0B	XD4B	XE8B	XFCB	X110B	X124B	X138B	X14CB

[Function]

This signal indicates that MDI mode is selected.

[Operation]

After the "All axes smoothing zero" (command acceleration/deceleration delay is zero) is verified, the mode changes from other mode to MDI mode.

**[Related signals]**

(1) All axes smoothing zero (TSMZ: XC1A)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Sub part system control: Sub part system control I mode ON	SBSMO	XC0E	XD4E	XE8E	XFCE	X110E	X124E	X138E	X14CE

[Function]

This signal indicates that the sub part system control I mode is selected for the operation mode.

The sub part system can be started by the sub part system control I command (G122) when this signal is ON.

[Operation]

This signal turns ON in the sub part system while the "Sub part system control: Sub part system control I mode" signal (SBSM) is ON.

[Related signals]

- (1) Sub part system control: Sub part system control I mode (SBSM: YC0E)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Controller ready completion	MA	XC10	XD50	XE90	XFD0	X1110	X1250	X1390	X14D0

[Function]

This signal indicates that the controller is ready for normal operation.

[Operation]

This signal turns ON when:

- ♦ The controller starts operating normally after the power of controller is turned ON or when no OFF-condition exists.

This signal turns OFF when:

- ♦ The controller is turned OFF.
- ♦ An error in the control device itself such as a CPU error or memory error is detected.
- ♦ A servo alarm which cannot be reset without turning OFF the power of the controller has occurred.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Servo ready completion	SA	XC11	XD51	XE91	XFD1	X1111	X1251	X1391	X14D1

[Function]

This signal indicates that the servo system is in a state where it can operate normally.

When this signal is OFF, it indicates that the servo system (position control) is not operating.

[Operation]

This signal turns ON when:

- ♦ The diagnosis on the servo system is completed successfully after the control unit is turned ON.
- ♦ The servo alarm occurs and then the alarm is canceled by reset. (Resetting may not be possible depending on the servo alarm contents.)
- ♦ Emergency stop input is canceled.
- ♦ The power is turned OFF and ON again by entering the decryption code upon expiration set in the system lock.

This signal turns OFF when:

- ♦ A servo alarm has occurred.
- ♦ An emergency stop occurs.
- ♦ The power of the controller is turned OFF.
- ♦ An error in the control device itself such as a CPU error or memory error is detected.
- ♦ The decryption code has not been entered to the controller by the specified expiration date in the system lock.

Note

- (1) This signal (SA) cannot be turned OFF only with the "Servo OFF" signal (*SVFn).

**CAUTION**

Do not refer to this signal on the PLC of the machine on which the system lock function is enabled. Reference to this signal can lead to unexpected operation after the expiration date.

[Related signals]

- (1) Servo ready completion output designation (R2625)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In automatic operation "run"	OP	XC12	XD52	XE92	XFD2	X1112	X1252	X1392	X14D2

[Function]

This signal indicates that the controller is in automatic operation by the "Auto operation "start" command" signal.

[Operation]

This signal stays ON from when automatic operation starts with the "Automatic operation "start" command (ST)" signal in the memory, MDI or tape mode, until the operation is reset.



Reset conditions include the followings:

- The "Reset & rewind" signal (RRW) is input.
- An emergency stop is entered due to an emergency stop input, servo alarm, etc.

Signals that indicates status of automatic operation include the "In automatic operation "start"" (STL) and the "In automatic operation "pause"" (SPL) besides the "In automatic operation "run"" (OP). The ON/OFF status of these three signals in each state is shown below.

	In automatic operation (OP)	In automatic operation "start" (STL)	In automatic operation "pause" (SPL)
Reset condition	0	0	0
Automatic operation stop condition	1	0	0
Automatic operation pause condition	1	0	1
Automatic operation start condition	1	1	0

Each state refers to the following states.

- Reset condition
Automatic operation is stopped by one of reset conditions described above.
(All states not in automatic operation are this state.)
- Automatic operation stop condition
The execution of one block is completed and the automatic operation is stopped.
(This state is entered during single block stop.)
- Automatic operation pause condition
Automatic operation is stopped in the middle of execution of one block.
(This state is entered when the "Automatic operation "pause" command" signal (*SP) is OFF.)
- Automatic operation start condition
Automatic operation is being executed.

[Related signals]

- (1) In automatic operation "start" (STL: XC13)
- (2) In automatic operation "pause" (SPL: XC14)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In automatic operation "start"	STL	XC13	XD53	XE93	XFD3	X1113	X1253	X1393	X14D3


[Function]

This signal informs the PLC that the controller is activated by the automatic operation start and the movement command and M, S, T, B processing is in execution.

[Operation]

In memory, MDI, or tape mode, this signal is turned ON by the "Automatic operation "start" command" signal (ST) from the start of automatic operation until the automatic operation is stopped, the block is stopped, or the reset state is reached.

The timing chart of the "In automatic operation "start"" signal (STL), including automatic operation suspension and block stop, is shown below.

**Note**

(1) For reset conditions, refer to the section on "In automatic operation "run"" (OP).

[Related signals]

- (1) In automatic operation "run" (OP: XC12)
- (2) In automatic operation "pause" (SPL: XC14)
- (3) Automatic operation "start" command (ST: YC10)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In automatic operation "pause"	SPL	XC14	XD54	XE94	XFD4	X1114	X1254	X1394	X14D4

[Function]

This signal informs that the controller is inactive due to the factors such as the "Automatic operation "pause" command" signal while the movement command or miscellaneous function command is being executed by automatic operation.

[Operation]

The "In automatic operation "pause"" signal (SPL) turns ON during automatic operation in the memory, MDI or tape mode in the following cases.

- When the "Automatic operation "pause" command" signal (*SP) turns OFF.
- When the mode is changed to the manual operation mode (jog, handle, incremental, reference position return mode, etc.).


Note

(1) This signal turns ON even during machine lock or a miscellaneous function (M, S, T, B) command.

This signal turns OFF in the following cases.

- When the "Automatic operation "start" command" signal (ST) turns from ON to OFF. However, this is invalid if the "Automatic operation "pause" command" signal (*SP) is not turned back ON or when the mode is not automatic operation (memory, MDI, tape).
- When reset conditions are input.

The timing chart for the "In automatic operation "pause"" signal (SPL) is shown below.



Note

(1) For reset conditions, refer to the section on "In automatic operation "run"" (OP).

[Related signals]

- (1) In automatic operation "run" (OP: XC12)
- (2) In automatic operation "start" (STL: XC13)
- (3) Automatic operation "start" command (ST: YC10)
- (4) Automatic operation "pause" command (*SP: YC11)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In "reset"	RST	XC15	XD55	XE95	XFD5	X1115	X1255	X1395	X14D5

[Function]

This signal informs that the controller is in the process of reset.

[Operation]

This signal turns ON when:

- For approximately 4 to 5 seconds after the power is turned ON.
- While the "Reset & rewind" signal (RRWn) is ON, and for approximately 0.5 to 1 second after the "Reset & rewind" signal (RRWn) turns OFF.
- While the "Emergency stop" signal is being input, and for approximately 1 to 1.5 seconds after the "Emergency stop" signal turns OFF.
- During the servo alarm, and for approximately 1 to 1.5 seconds after the servo alarm is released.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In manual arbitrary feed	CXN	XC16	XD56	XE96	XFD6	X1116	X1256	X1396	X14D6

[Function]

This signal is output during execution of the manual arbitrary feed command.


[Operation]

This signal turns ON when:

- ♦ The "Manual arbitrary feed strobe" signal (CXS8n) turns ON in the manual arbitrary feed mode.

This signal turns OFF when:

- ♦ The feed in the manual arbitrary feed mode is completed.
- ♦ The "Reset 1", "Reset 2", or "Reset & Rewind" signal is input during execution of the manual arbitrary feed command.

[Timing chart]**[Related signals]**

- (1) Manual arbitrary feed strobe (CXS8: YCBF)
- (2) In manual arbitrary feed (CXFIN: XC1C)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In rewind	RWD	XC17	XD57	XE97	XFD7	X1117	X1257	X1397	X14D7

[Function]

This signal informs that the controller is indexing the memory mode.

[Operation]

This signal turns ON when the "Reset & rewind" signal (RRWn) is turned ON by the PLC in memory mode (with M02 or M30 command), and turns OFF when the controller completes indexing the program in execution.

Note

- (1) Since the time to index a program in memory mode is instantaneous, it may not be verified by user PLC.

[Related signals]

- (1) Reset & rewind (RRW: YC1A)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Motion command completion	DEN	XC18	XD58	XE98	XFD8	X1118	X1258	X1398	X14D8

[Function]

This signal notifies that the axis movement command has completed by the controller.

When the movement command and the miscellaneous function (M, S, T, B) command are specified in the same block in the machining program, this signal can be used as a synchronization signal to determine whether the miscellaneous function command is processed at the same time as the movement command or after the movement command is completed.


[Operation]

This signal turns ON when:

- The system is initialized after the power is turned ON.
- The movement command in automatic operation is completed.
- Reset condition occurs.

(For reset conditions, refer to the section on "In automatic operation "run"" signal (OPn).)

The timing chart for the "Motion command completion" signal (DENn) is shown below.



Note

- (1) The "Motion command completion" signal is output even during machine lock.
- (2) Even if the movement is stopped due to interlock or automatic operation suspension, the "Motion command completion" signal does not turn ON as long as there is remaining distance.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	All axes in-position	TIMP	XC19	XD59	XE99	XFD9	X1119	X1259	X1399	X14D9

[Function]

This signal informs the PLC that all control axes of the controller are in commanded positions.

[Operation]

This signal turns ON when:


- There is no acceleration/deceleration delay in all control axes, and servo errors (remaining pulses) are within the range set by the parameter.

This signal turns OFF when:

- There is an axis with acceleration/deceleration delay among the control axes.
- There is a control axis in which the servo error (remaining pulses) exceeds the range set by the parameter.

Note

- The "All axes in-position" signal may turn ON even while moving if the feedrate is extremely slow.
- The condition that the servo errors must be within a certain limit to turn ON this signal can be disabled with parameters. In that case, this signal changes to ON/OFF only depending on whether the acceleration/deceleration delay is zero.

**[Related signals]**

- All axes smoothing zero (TSMZ: XC1A)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	All axes smoothing zero	TSMZ	XC1A	XD5A	XE9A	XFDA	X111A	X125A	X139A	X14DA


[Function]

This signal informs the PLC that there is no delay (caused by the acceleration/deceleration time constants) in any of the controller control axis command system.

The PLC axis is not included in the control axis.

[Operation]

This signal turns ON when all the output processing the movement amount commanded by automatic operation or manual operation, including the delay amount of acceleration/deceleration time constant, is completed. This signal turns OFF during execution of the movement command and when there is a delay amount of acceleration/deceleration time constant.

**Note**

- The "All axes smoothing zero" signal operates even during machine lock.
- The "All axes smoothing zero" signal may turn ON even while moving when the moving speed is extremely slow.
- In axis plus/minus motion signals are all turned OFF while the "All axes smoothing zero" is ON.

[Related signals]

- All axes in-position (TIMP: XC19)
- In axis plus motion n-th axis (MVP1 to MVP8: X7C0 to 7)
- In axis minus motion n-th axis (MVM1 to MVM8: X7E0 to 7)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed completion	CXFIN	XC1C	XD5C	XE9C	XFDC	X111C	X125C	X139C	X14DC

[Function]

This signal is output when the movement commanded by the manual arbitrary feed mode is completed.


[Operation]

This signal turns ON when:

- The movement commanded by the manual arbitrary feed mode is completed.

This signal turns OFF when:

- Moving in manual arbitrary feed mode. (This signal remains OFF when the movement is interrupted while moving by the "Reset 1", "Reset 2", "Reset & Rewind", etc.)
- This signal is OFF when the power is turned ON.

[Timing chart]**[Related signals]**


- (1) Manual arbitrary feed strobe (CXS8: YCBF)
- (2) In manual arbitrary feed (CXN: XC16)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	External search finished		XC1D	XD5D	XE9D	XFDD	X111D	X125D	X139D	X14DD

[Function] [Operation]

This signal turns ON when the external search is completed. It also turns ON when an error occurs.

This signal turns OFF when the "External search strobe" signal (YC1D) is turned OFF from the user PLC.

[Timing chart]**[Related signals]**

- (1) External search strobe (YC1D)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In high-speed machining mode (G05)		XC1F	XD5F	XE9F	XFDF	X111F	X125F	X139F	X14DF

[Function]

This signal notifies that the operation is in high-speed machining mode.

[Operation]

This signal turns ON when:

- The high-speed machining mode is commanded in the machining program.

This signal turns OFF when:

- Cancellation of the high-speed machining mode is commanded in the machining program.
- The high-speed machining mode ended due to an operation such as NC reset.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In rapid traverse	RPN	XC20	XD60	XEA0	XFE0	X1120	X1260	X13A0	X14E0

[Function]

This signal notifies that the movement command in automatic operation (memory, MDI, tape) is being performed in rapid traverse.

[Operation]

This signal turns ON when:

- The movement command in automatic operation is given in rapid traverse.

Fixed cycle positioning and reference position return (G28), etc., are included in the automatic operation rapid traverse besides the motion command by the G00 command.


This signal turns OFF when:

- The block in rapid traverse motion is completed during automatic operation.
- Rapid traverse motion is stopped by the "Automatic operation "pause" command (Feed hold)" signal (*SPn) during automatic operation.
- Rapid traverse motion axis is stopped by interlock during automatic operation.
- The ratio of the "Cutting feedrate override code m" (*FVmn) becomes 0% during automatic rapid traverse operation.
- A stroke end (hardware or software) occurs during automatic rapid traverse operation.
- Reset condition occurs.

Note

- (1) The "In rapid traverse" signal (RPNn) can turn ON and OFF even during machine lock.
- (2) The signal is not output in manual operation.
- (3) For reset condition, refer to the section on "In automatic operation "run"" signal (OPn).

The timing chart of the "In rapid traverse" signal (RPNn) is shown below.



4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In cutting feed	CUT	XC21	XD61	XEA1	XFE1	X1121	X1261	X13A1	X14E1

[Function]

This signal informs that given motion command is executed for cutting feed in automatic operation (memory, MDI, tape).

[Operation]

This signal turns ON when:


- Motion command is given for cutting feed in automatic operation.

This signal turns OFF when:

- The block in cutting feed in automatic operation is completed.
- Execution of cutting feed in automatic operation is stopped by the "Automatic operation "pause" command" signal (*SP).
- Execution of cutting feed is stopped by interlock during automatic operation.
- The ratio of the cutting feedrate override becomes 0% during automatic cutting feed operation.
- A stroke end (hardware or software) occurs during automatic cutting feed operation.
- Reset condition occurs.

Note

- (1) The "In cutting feed" signal (CUT) turns ON and OFF even when the machine lock is applied.
- (2) Cutting feed commands in automatic operation include G01, G02, G03 and G31.
- (3) This signal is not output in manual operation.
- (4) For reset condition, refer to the section on "In automatic operation "run"" signal (OP).



Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In tapping	TAP	XC22	XD62	XEA2	XFE2	X1122	X1262	X13A2	X14E2

[Function]

This signal informs that the movement command in automatic operation (memory, MDI, tape) is in the tapping cycle of the fixed cycle or in the tapping mode.

[Operation]


This signal turns ON when:

- The movement command in automatic operation is performed in the tapping cycle of the fixed cycle.
- The movement command in automatic operation is in tapping mode (G63).

This signal turns OFF when:

- The movement command is not in the tapping cycle and no longer in tapping mode.

This signal is canceled by G80 or G command (G00, G01, G02, G03, G33) of 01 group during the tapping cycle of the fixed cycle, and is canceled by G61, G62 or G64 during the tapping mode.



(Note 1) This signal is output even during machine lock.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In thread cutting	THRD	XC23	XD63	XEA3	XFE3	X1123	X1263	X13A3	X14E3

[Function]

This signal is output during execution of the thread cutting command.

[Operation]

This signal turns ON when:

- ♦ The thread cutting command is given.

This signal turns OFF when:

- ♦ A movement command other than the thread cutting command is given.
- ♦ A reset is applied for some reason during thread cutting.

Note

- (1) Spindle override is invalid (100%) during thread cutting.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In synchronous feed	SYN	XC24	XD64	XEA4	XFE4	X1124	X1264	X13A4	X14E4

[Function]

This signal is output during execution of the synchronous feed command.

[Operation]

The signal turns ON when the synchronous feed command (G95) is given.

The signal turns OFF when the asynchronous feed command (G94) is given.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In constant surface speed	CSS	XC25	XD65	XEA5	XFE5	X1125	X1265	X13A5	X14E5


[Function]

This signal informs that automatic operation is under constant circumferential (surface) speed control.

[Operation]

This signal turns ON when the constant surface speed control mode (G96) is selected during automatic operation.

This signal turns OFF when the constant surface speed control off command (G97) is issued.

**Note**

- (1) The "In constant surface speed" signal (CSS) is output even during machine lock.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In skip	SKIP	XC26	XD66	XEA6	XFE6	X1126	X1266	X13A6	X14E6

[Function]

This signal is output while the skip command (G31) is being executed.

[Operation]

The signal turns ON when the skip command (G31) is being executed by automatic operation.

The signal turns OFF when the block where the skip command is issued completes.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In reference position return	ZRNN	XC27	XD67	XEA7	XFE7	X1127	X1267	X13A7	X14E7

[Function]

This signal is output while the reference position return command is being executed.

[Operation]

This signal turns ON when:

- ♦ G28 command is executed.
- ♦ G30 command is executed.
- ♦ The manual reference position return mode is selected.

This signal turns OFF when:

- ♦ All cases other than above.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In inch unit selection	INCH	XC28	XD68	XEA8	XFE8	X1128	X1268	X13A8	X14E8

[Function]

This signal informs that the controller uses inch unit for data input.

[Operation]

This signal turns ON when inch unit is selected.

During G20 (Inch unit command) modal, the "In inch unit selection" signal turns ON.

This signal does not change with the machine parameter "#1041 I_inch".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In display lock	DLNK	XC29	XD69	XEA9	XFE9	X1129	X1269	X13A9	X14E9

[Function]

This signal informs that the results of the movement command executed by the control unit are not reflected in the POSITION screen (display is locked).

[Operation]

This signal turns ON while the "Display lock" signal (DLK) is input.

The display lock operation is enabled immediately after the "Display lock" signal (DLK) turns ON.

[Related signals]

(1) Display lock (DLK: YC29)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	F1-digit commanded	F1DN	XC2A	XD6A	XEAA	XFEA	X112A	X126A	X13AA	X14EA

[Function]

This signal informs that the controller is in operation by the F1-digit commands (F1 to F5).

[Operation]

This signal turns ON when:

- F1-digit command (F1 to F5) is selected for feedrate command currently being executed.

This signal turns OFF when:

- Block having a motion command specified with F1-digit code is completed.
- Operation is stopped by the "Automatic operation "pause" command" signal (*SP) during execution of motion command by F1-digit command.
- Operation is stopped by the "Interlock" signal during execution of motion command by F1-digit command.
- Reset condition occurs.

(For details of reset conditions, refer to the section on "In automatic operation "run"" signal (OP).)

Note

(1) To enable the F1-digit command, enable either the parameter "#1079 F1digit" or "#8145 Validate F1 digit".

[Related signals]

(1) F1-digit No. code (F11 to 18: XC30 to XC33)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In tool life management	TLFO	XC2B	XD6B	XEAB	XFEB	X112B	X126B	X13AB	X14EB

[Function]

This signal is output during the tool life management.

[Operation]

The "In tool life management" signal turns ON when the parameter of tool life management (#1103 T_Life) is ON.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool life management: Temporary cancel of tool life expiration ON		XC2C	XD6C	XEAC	XFEC	X112C	X126C	X13AC	X14EC

[Function]

This signal indicates that the "Tool life over" signal is being temporarily canceled.

[Operation]

This signal turns ON when:

- ♦ The "Temporary cancel of tool life expiration" signal turns ON.

This signal turns OFF when:

- ♦ The "Tool life over" signal is OFF at the falling edge of the "Temporary cancel of tool life expiration" signal.
(However, when the "Tool life over" signal is ON, this signal remains ON because it is canceled temporarily.)
- ♦ The NC is reset.
- ♦ The "Tool life over" signal turns OFF while this signal is output.

[Related signals]

- (1) Tool life over (TLOV: XC2E)
- (2) Tool life management: Temporary cancel of tool life expiration (YC98)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool life management: Temporary cancel of tool group life ex- piration ON		XC2D	XD6D	XEAD	XFED	X112D	X126D	X13AD	X14ED

[Function]

This signal indicates that the "Tool group life over" signal is being temporarily canceled.

[Operation]

This signal turns ON when:

- ♦ The "Temporary cancel of tool group life expiration" signal turns ON.

This signal turns OFF when:

- ♦ The "Tool group life over" signal is OFF at the falling edge of the "Temporary cancel of tool group life expiration" signal.
(However, when the "Tool group life over" signal is ON, this signal remains OFF because it is canceled temporarily.)
- ♦ The NC is reset.
- ♦ The "Tool group life over" signal turns OFF while this signal is output.

[Related signals]

- (1) Tool group life over (XC2F)
- (2) Tool life management: Temporary cancel of tool group life expiration (YC99)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool life over	TLOV	XC2E	XD6E	XEAE	XFEE	X112E	X126E	X13AE	X14EE

[Function]

This signal notifies that a tool has reached the end of tool life (cumulative tool usage data \geq estimated tool life data).

[Operation]

The signal turns ON when cumulative tool usage data of tool is same as or has exceeded estimated tool life data. Note that this signal is only output and automatic operation or other operations of the controller does not stop.

<For Tool life management I or III for M system>

ON condition	#1246 set18/bit4 = 0	The currently selected tool has reached the end of tool life (cumulative tool usage data \geq estimated tool life data). (Time-count type: during cutting feed) (Number of cuttings-count type: at the start of cutting feed for Type 1 and at Reset for Type 2)
		The selected tool has already reached the end of tool life at the time of tool selection. (Same timing as the "T function strobe 1" signal)
	#1246 set18/bit4 = 1	Even one of the tools in the currently selected group (or all the registered tool for Tool life management III) has reached the end of tool life (cumulative tool usage data \geq estimated tool life data). (Time-count type: during cutting feed) (Number of cuttings-count type: at the start of cutting feed for Type 1 and at Reset for Type 2)
		Even one of the tools in the group has reached the end of tool life at the time of group selection. (Same timing as the "T function strobe 1" signal)
OFF condition	#1246 set18/bit4 = 0	The tool selection has been completed. (At a T command. Note that the signal remains ON if the next tool has reached the end of tool life.)
		The tool status of the currently selected tool is cleared.
	#1246 set18/bit4 = 1	The group selection has been completed. (At a T command. Note that the signal remains ON if the next selected group contains any expired tool.)
		The cumulative tool usage data is smaller than the estimated tool life data (cumulative tool usage data < estimated tool life data).
	At the falling edge (1 \rightarrow 0) of the "Temporary cancel of tool life expiration" signal of corresponding part system. (However, this signal is turned ON again if the spindle tool used has reached the end of tool life when the NC is reset.)	

<For Tool life management I for L system>

ON condition	T command is given after a currently selected tool has reached the end of tool life (cumulative tool usage data \geq estimated tool life data)	
	The selected tool has already reached the end of tool life at the time of tool selection. (Same timing as the "T function strobe 1" signal)	
OFF condition	#1262 set34/bit3 = 0	The "M function finish" signal (FIN) is turned ON.
	#1262 set34/bit3 = 1	The tool selection has been completed. (At a T command. Note that the signal remains ON if the next tool has reached the end of tool life.)
	At the falling edge (1 \rightarrow 0) of the "Temporary cancel of tool life expiration" signal of corresponding part system. (However, this signal is turned ON again if the tool currently being used has reached the end of tool life when the NC is reset.)	

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

<For Tool life management II for M and L system>

ON condition	The currently selected tool has reached the end of tool life (cumulative tool usage data \geq estimated tool life data). (Time-count type: during cutting feed) (Number of cuttings-count type: at the start of cutting feed for Type 1 and at Reset for Type 2)
	All tools in the group have reached the end of tool lives at the time of group selection. (Same timing as the "T function strobe 1" signal)
OFF condition	The group selection has been completed. (At a T command. Note that the signal remains ON if the next group is an expired group.)
	The cumulative tool usage data for the currently selected group is cleared.
	At the falling edge (1 \rightarrow 0) of the "Temporary cancel of tool life expiration" signal of corresponding part system. (However, this signal is turned ON again if the tool currently being used has reached the end of tool life when the NC is reset.)

[Related signals]

(1) Temporary cancel of tool life expiration signal (YC98 to Y1558)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool group life over		XC2F	XD6F	XEAF	XFEF	X112F	X126F	X13AF	X14EF

[Function]

This signal notifies that all tools in the tool group have reached the end of tool lives.

This signal is valid only for tool life management II.

The output condition can be selected by the parameter "#1277 ext13/bit0". The count method of usage count will also be switched by this parameter.

[Operation]

This signal turns ON when all tools in the group mounted on the spindle have reached the end of tool lives or malfunction.

<Parameter "#1277 ext13/bit0" is set to "0">

This signal notifies that all tools in a group have reached the end of tool lives.

ON condition	The last tool of a currently selected group is determined as life-expired. (Note) (Time-count type: While cutting feed is performed) (Number of cuttings-count type: At the start of cutting feed for the Type 1, and at the Reset for the Type 2)
	Tool skip signal (to be described) is input to the last tool of a currently selected group.
	All the tools of the selected group are life-expired at the time of group selection. (Same timing as TF output)
OFF condition	The group currently selected is canceled. (When T command is issued. Note that this signal remains ON if the next group is an expired group.)
	The cumulative usage data of the currently selected group is cleared. (When the "Tool change reset" signal (to be described) is input, for example)
	The tool life management is disabled.
	At the falling edge (1 \rightarrow 0) of the "Temporary cancel of tool group life expiration" signal of corresponding part system. (However, this signal is turned ON again if all the tools in the mounted group have reached the end of tool lives when the NC is reset.)

Note

(1) The criterion to judge the end of tool life depends on the parameter "#1220 aux04/bit0".

<Parameter "#1277 ext13/bit0" is set to "1">

This signal notifies that there is a life-expired group among all the registered groups.

(Life-expired group: a group in which there is no usable tool (no "Unused" and "Used" tools).)

ON condition	There is any life-expired group among all the registered groups.
OFF condition	The life-expired group is cleared. (The condition when life-expired state of a group is canceled is the same as for Type 1.)

[Caution]

- When this signal is used in the tool life management II, refer to the next ladder cycle after the spindle tool is changed.
(This signal will not change in the same cycle in which the spindle tool was changed.)
- This signal is only output and does not stop automatic operation or other operations of the controller.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	F1-digit No. code (1, 2, 4, 8)	F11 to F18	XC30 to 3	XD70 to 3	XEB0 to 3	XFF0 to 3	X1130 to 3	X1270 to 3	X13B0 to 3	X14F0 to 3

[Function]

F1-digit feed function No. is output.

[Operation]

When the F1-digit command is executed in memory, MDI, or tape operation, F1-digit No. is set with a code.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Timing synchronization between part systems		XC34	XD74	XEB4	XFF4	X1134	X1274	X13B4	X14F4

[Function]

This signal informs that the timing synchronization between part systems is being executed.

[Operation]

This signal is output while the timing synchronization between part systems is commanded in one part system to when the corresponding timing synchronization between system command is commanded in the other part system (during the timing synchronization between part systems).

This signal is not output when the timing synchronization between part systems is not executed.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In PLC interrupt	PCINO	XC35	XD75	XEB5	XFF5	X1135	X1275	X13B5	X14F5

[Function] [Operation]

This signal turns ON at the beginning of a PLC interruption and turns OFF at the end of the PLC interruption by M99 or reset.

[Related signals]

- (1) PLC interrupt (PIT: YC2E)
- (2) PLC interrupt program number (R2518, R2519)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Illegal axis selected	ASLE	XC37	XD77	XEB7	XFF7	X1137	X1277	X13B7	X14F7

[Function]

This signal is output if axis No. selected in the handle mode or the manual arbitrary feed mode is illegal.

[Operation]

This signal turns ON when:

- The handle axis No. exceeds the maximum number of control axes in the system in the handle mode.
- The manual arbitrary feed axis No. exceeds the maximum number of control axes in the system in the manual arbitrary feed mode.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	M code independent output M00	DM00	XC40	XD80	XEC0	X1000	X1140	X1280	X13C0	X1500

[Function]

This signal informs that a specific miscellaneous function (M00) is output among the miscellaneous functions. Even with a specific M function, the normal miscellaneous function strobe and M code data are output.

As a similar signal, M code independent output includes M01, M02 and M30. This section explains details for these codes.

[Operation]

This signal turns ON during operation by automatic operation (memory, MDI, tape) or when M00, M01, M02, or M30 is commanded by a manual numerical command. This signal turns OFF when the "M function finish" signal or the "Reset & rewind" signal is given.

Machining program	M code independent output	Abbrev.	Answer back to controller
M00	M00	DM00	FIN1 or FIN2
M01	M01	DM01	FIN1 or FIN2
M02	M02	DM02	Reset & rewind signal ("Fin" is not sent back)
M30	M30	DM30	Reset & rewind signal ("Fin" is not sent back)

If motion command and/or dwell is present in the same block, the signal turns ON after completion of dwell. However, the signal is not output if M function finish signal turns ON before completion of motion command or dwell.

Generally, each M code is used for the following purpose:

M00 Program stop

M01 Optional stop

M02, M30 Program end

<Operation on user PLC side>

♦ For M00

When M00 is input, the "Single block" signal (SBK) is turned ON and the "M function finish" signal (FIN1 or FIN2) is sent back.

♦ For M01

When M01 is input, the optional stop switch is checked whether its setting is ON or OFF. If the setting is "ON", the "Single block" signal is turned ON and the "M function finish" signal is sent back, like the case with M00. If the setting is "OFF", the "M function finish" signal is sent back immediately.

♦ For M02, M30

When motion where M02 or M30 was input (spindle stop, coolant stop, etc.) is completed, the "Reset & rewind" signal (RRW) is sent back instead of the "M function finish" signal. If the "M function finish" signal (FIN1 or FIN2) is sent back, a program error may occur.

[Related signals]

(1) M code independent output M01 (DM01: XC41)

(2) M code independent output M02 (DM02: XC42)

(3) M code independent output M30 (DM30: XC43)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	M code independent output M01	DM01	XC41	XD81	XEC1	X1001	X1141	X1281	X13C1	X1501

[Function] [Operation]

Refer to the section on "M code independent output M00".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	M code independent output M02	DM02	XC42	XD82	XEC2	X1002	X1142	X1282	X13C2	X1502

[Function] [Operation]

Refer to the section on "M code independent output M00".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	M code independent output M30	DM30	XC43	XD83	XEC3	X1003	X1143	X1283	X13C3	X1503

[Function] [Operation]

Refer to the section on "M code independent output M00".

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In manual speed command valid		XC48	XD88	XEC8	X1008	X1148	X1288	X13C8	X1508

[Function]

This signal indicates that the manual speed command is valid in the controller by the "Manual speed command valid" signal.

[Operation]

This signal turns ON when the "Manual speed command valid" signal is turned ON and the manual speed command is enabled in the NC.

This signal turns OFF when the "Manual speed command valid" signal is turned OFF and the manual speed command is disabled in the NC.

[Related signals]

(1) Manual speed command valid (YC9D)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual numerical command	MMS	XC49	XD89	XEC9	X1009	X1149	X1289	X13C9	X1509

[Function]


This signal informs that the M, S, T or B (2nd miscellaneous function) command has been issued on the specific screen of the setting display unit. With this signal, the user PLC determines whether or not it is the M, S, T, B command commanded by normal automatic operation.

[Operation]

In the manual and automatic operation (except during cycle start), this signal turns ON when any of M, S, T, and B commands is issued on the specific screen of the setting display unit.

Similar to the "M function strobe" signal, this signal turns OFF when the "M function finish 1" signal or the "M function finish 2" signal turns ON, or reset.

(Example)



[Related signals]

- (1) M function strobe (MF_n: XC60)
- (2) S function strobe (SF_n: XC64)
- (3) T function strobe 1 (TF1: XC68)
- (4) 2nd M function strobe 1 (BF1: XC6C)
- (5) M function finish 1 (FIN1: YC1E)
- (6) M function finish 2 (FIN2: YC1F)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In tool escape and return mode		XC4A	XD8A	XECA	X100A	X114A	X128A	X13CA	X150A

[Function]

This signal indicates the tool escape and return mode is in progress.


[Operation]

To designate a halted point, turn ON a transit point switch while the operation is stopped by feed hold or single block. When recognition of the halted point is completed, this signal turns ON and the tool escape and return mode will be established.

Statuses of each signal after the machining program is halted are explained below.

The following (a) to (e) correspond to (a) to (e) in the figure below.

- The recognition of the transit point is performed in automatic operation but not in automatic operation start.
- When the user turns ON the "Tool escape and return transit point designation" signal (YC8D), the NC turns ON the "Tool escape and return transit point recognition finish" signal (XC87) and recognition will be completed.
- When the "Tool escape and return transit point recognition finish" signal (XC87) turns ON, the user turns OFF the "Tool escape and return transit point designation" signal (YC8D).
- When the "Tool escape and return transit point designation" signal (YC8D) turns OFF, the NC also turns OFF the "Tool escape and return transit point recognition finish" signal (XC87).
- The "In tool escape and return mode" signal turns OFF when a tool reaches the halted point, or when one of reset1, reset2, reset & rewind, or emergency stop is performed.

**Note**

- When one of reset1, reset2, reset & rewind, or emergency stop is attempted during the escape and return mode, the memorized transit point and halted point will be canceled. The escape and return mode will be ended with reset.

[Related signals]

- Tool escape and return transit point recognition finish (XC87)
- Tool escape and return transit point designation (YC8D)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Sub part system control: Sub part system processing	SBS	XC4E	XD8E	XECE	X100E	X114E	X128E	X13CE	X150E

[Function]

This signal notifies that the system is started as a sub part system.

If there is a PLC processing to be executed only when the sub part system is started, use this signal to check whether the sub part system is already started or not.

[Operation]

This signal turns ON at the sub part system when the system is started with the sub part system "start" command.

The PLC input signals related to the sub part system control return "0" when the "Sub part system control: Sub part system processing" signal (SBS) is OFF.

The following shows which part system outputs PLC input signals related to the sub part system control. Also, the output values and operation examples are given.

PLC input signal	Part system that outputs signals	Output signal value
Sub part system control: Sub part system processing (SBS: XC4E)	Sub part system	1: ON / 0: OFF
Sub part system control: Sub part system control II identification No. (SBSID: R616) (*1)	Sub part system	Sub part system identification No.
Sub part system control: Calling sub part system (SBSC: R617)	Caller of part system	System bit of sub part system
Sub part system control: Waiting for sub part system completion (SBSWT: R618)	Caller of part system	System bit of sub part system
Sub part system control: Caller of sub part system (SBSSY: R619)	Sub part system	System bit of calling part system

(*1) The "Sub part system control: Sub part system control II identification No." signal (SBSID) is used only for the sub part system control II.


The signal is not output from a sub part system started with the sub part system control I.

4 Explanation of Interface Signals



4.1 PLC Input Signals (Bit Type: X***)

For Main part system: 1st part system, 2nd part system, Sub part system: 3rd part system

Command format of sub part system control I



Command format of sub part system control II



[Related signals]

- (1) Sub part system control: Sub part system control II identification No. (SBSID: R616)
- (2) Sub part system control: Calling sub part system (SBSCl: R617)
- (3) Sub part system control: Waiting for sub part system completion (SBSWT: R618)
- (4) Sub part system control: Caller of sub part system (SBSSY: R619)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In circular feed in manual mode		XC4F	XD8F	XECF	X100F	X114F	X128F	X13CF	X150F

[Function]

This signal indicates that the circular feed in manual mode is valid.

[Operation]

This signal turns ON when the "Circular feed in manual mode valid" signal turns ON.

[Caution]

This signal does not turn ON in the following conditions.

- ♦ Either H axis or V axis is in machine lock. (In this case, even machine lock is not performed.)
- ♦ The reference position return of either H axis or V axis is not completed.
- ♦ Either H axis or V axis is in servo OFF.
- ♦ Either H axis or V axis detached.
- ♦ The NC is in one of the following states.
 - In automatic operation (OP)
 - Emergency stop
 - Reset
- ♦ The current position is outside of the specified movable range.
- ♦ The setting value which is specified with R register is illegal.

[Related signals]

- (1) Circular feed in manual mode valid (YC7E)
- (2) Circular feed in manual mode Operation mode data (R2636,7)
- (3) Circular feed in manual mode Reference point H data (R2644,5)
- (4) Circular feed in manual mode Reference point V data (R2648,9)
- (5) Circular feed in manual mode Gradient/arc center H data (R2668,9)
- (6) Circular feed in manual mode Gradient/arc center V data (R2672,3)
- (7) Circular feed in manual mode Travel range H (+) data (R2652,3)
- (8) Circular feed in manual mode Travel range H (-) data (R2656,7)
- (9) Circular feed in manual mode Travel range V (+) data (R2660,1)
- (10) Circular feed in manual mode Travel range V (-) data (R2664,5)
- (11) Circular feed in manual mode Current position H (R636,7)
- (12) Circular feed in manual mode Current position V (R640,1)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Coordinate rotation by parameter: Manual feed coordinate system		XC5F	XD9F	XEDF	X101F	X115F	X129F	X13DF	X151F

[Function]


This signal notifies the coordinate system which operates with the manual operation (jog feed, incremental feed and manual handle feed) during the coordinate rotation by parameter.

[Operation]

When this signal is turned OFF, the manual operation will be operated with the machine coordinate system.

When this signal is turned ON, the manual operation will be operated with the coordinate system rotated by the coordinate rotation by parameter.

When the coordinate rotation by parameter is invalid, this signal will be turned OFF even though the "Coordinate rotation by parameter: Coordinate switch for manual feed" (YC7F) is turned ON.

**[Related signals]**

- (1) Coordinate rotation by parameter: Coordinate switch for manual feed (YC7F)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	M function strobe 1	MF1	XC60	XDA0	XEE0	X1020	X1160	X12A0	X13E0	X1520
A	M function strobe 2	MF2	XC61	XDA1	XEE1	X1021	X1161	X12A1	X13E1	X1521
A	M function strobe 3	MF3	XC62	XDA2	XEE2	X1022	X1162	X12A2	X13E2	X1522
A	M function strobe 4	MF4	XC63	XDA3	XEE3	X1023	X1163	X12A3	X13E3	X1523

[Function]

This signal informs that the miscellaneous functions (M code) is commanded with the automatic operation (memory, MDI or tape) machining program or manual numerical command input.

The miscellaneous function, also called the M function, is used to issue miscellaneous functions of the target machine, such as ON/OFF of the cutting oil and forward rotation/reverse rotation/stop of the spindle.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

[Operation]

<Normal method (when the parameter "#1278 ext14/bit1" is set to "0")>

This signal turns ON when:

- The M function (M code) is specified in automatic operation (memory, MDI or tape mode).
- M function (M code) is specified by manual numerical command input.


This signal turns OFF when:

- The "M function finish 1" signal (FIN1) or the "M function finish 2" signal (FIN2) turns ON.
- Reset condition occurs. (Refer to the "In automatic operation "run"" signal (OP) section for details on the reset conditions.)

Note


- (1) When built-in PLC is used, multiple miscellaneous functions (M functions) can be specified in one block. The number of functions that can be specified in one block depends on the settings of the parameter "#12005 Mfig".

The relation of the machining program and M function strobe is shown below.



- (2) During operation with miscellaneous function lock (AFL signal is ON), the M function strobe will not be output. However, this signal will be output when the M code is commanded independently (M00, M01, M02, M30).
- (3) Since M98 (read of subprogram call), M99 (return from subprogram), etc. are handled within the controller, the M function strobe is not output.
- (4) The M function strobe will not be output when the M function is output while the "M function finish 1" signal (FIN1) or "M function finish 2" signal (FIN 2) is ON.

An example of the timing chart for the M function strobe signal (MF1, MF2 and MF3) is shown below.



4 Explanation of Interface Signals


4.1 PLC Input Signals (Bit Type: X***)

Point: The following points must be observed in the sequence processing.

- When the M function is commanded, the MF_n and M code data "n" is output.
- In sequence processing, MF_n is always used as a trigger to start processing of the M function.
- When the designated M function processing is completed, the "M function finish" signal is returned to the controller.
- The controller waits for the rising edge of the "M function finish" signal and then turns MF_n OFF.
- In the sequence processing, after the MF_n is confirmed to be OFF, the "M function finish" signal is turned OFF.

This completes a series of M function processing.

In sequence processing, by always including the condition of MF_n in the start and completion signals of the M function, handshaking with the controller and an accurate sequence processing becomes possible.



<High-speed method (when the parameter "#1278 ext14/bit1" is set to "1")>

Refer to the section of the "Miscellaneous function command high-speed output: M function finish n" signal (MF_{INn}).

[Related signals]

- (1) M function finish 1 (FIN1: YC1E)
- (2) M function finish 2 (FIN2: YC1F)
- (3) M code data n (R504)
- (4) Miscellaneous function command high-speed output: M function finish n (MF_{INn}: YD28)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	S function strobe 1 to 8	SF1 to 4	XC64 to 7	XDA4 to 7	XEE4 to 7	X1024 to 7	X1164 to 7	X12A4 to 7	X13E4 to 7	X1524 to 7
		SF5 to 8	XC70 to 3	XDB0 to 3	XEF0 to 3	X1030 to 3	X1170 to 3	X12B0 to 3	X13F0 to 3	X1530 to 3

[Function]

This signal informs that the spindle function (S code) is specified by the machining program of automatic operation (memory, MDI or tape mode) or a manual numerical command.

The spindle function is also called the S function, and is used to command the spindle speed.

The user PLC receives the corresponding S code data (1 to 8) with the signal.

[Operation]

<Normal method (when the parameter "#1278 ext14/bit1" is set to "0")>

This signal turns ON when:

- S function (S code) is specified in automatic operation (memory, MDI or tape mode).
- S function is specified by manual numerical command input.


This signal turns OFF when:

- The "M function finish 1" signal (FIN1) or the "M function finish 2" signal (FIN2) is turned ON.
- Reset condition occurs. (Refer to the "In automatic operation "run"" signal (OP) section for details on the reset conditions.)

Note

- (1) The S function strobe is not output during operation with M function lock (AFL signal ON).
- (2) When the S function is commanded, the "Spindle gear shift command" signal (GR1, GR2) and the "S command no gear selected" signal (SNGE) are output in addition to this signal (SF_n). Refer to the sections of each signal for details.
- (3) By combining this signal (SF_n), the "Spindle gear selection code" signal (GI1, GI2) and the "Gear shift completion" signal (GFIN), the data can be converted into S command data.
(Data is transferred when the spindle controller is the high-speed serial connection specification type.)
- (4) The "S function strobe 1 to 8" signals (SF1 to 8) correspond to the spindle function (S code) commands for the 1st to 8th spindles, respectively.

An example of the timing chart for the "S function strobe 1" signal (SF1) is shown below.



<High-speed method (when the parameter "#1278 ext14/bit1" is set to "1")>

Refer to the section on "Miscellaneous Function Command High-speed Output: S function finish" signal (SFIN1).

[Related signals]

- (1) S code data 1 to 8 (R512 to 27)
- (2) Spindle gear shift command (GR1, GR2: X1885, 6)
- (3) S command no gear selected (SNGE: X1884)
- (4) Spindle gear selection code 1, 2 (GI1, GI2: Y1890, Y1891)
- (5) Gear shift completion (GFIN: Y1885)
- (6) M function finish 1 (FIN1: YC1E)
- (7) M function finish 2 (FIN2: YC1F)
- (8) Miscellaneous Function Command High-speed Output: S function finish 1 to 8 (SFIN1 to 4, SFIN5 to 8: YD2C to F, YD38 to B)

IB-1501616-C

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

[Related signals]

- (1) T code data 1 to 4 (R536 to 43)
- (2) M function finish 1 (FIN1: YC1E)
- (3) M function finish 2 (FIN2: YC1F)
- (4) Miscellaneous Function Command High-speed Output: T function finish 1 to 4 (TFIN1 to 4: YD30 to 3)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	2nd M function strobe 1 to 4	BF1 to 4	XC6C to F	XDAC to F	XEEC to F	X102C to F	X116C to F	X12AC to F	X13EC to F	X152C to F

[Function]

This signal informs that the 1st set of 2nd M function is selected by the machining program in automatic operation (memory, MDI or tape) or by manual numerical command.

The 2nd M function is also called the B function.

With the signal (BF1), user PLC receives 2nd M function data 1 to 4.

[Operation]

<Normal method (when the parameter "#1278 ext14/bit1" is set to "0")>

This signal turns ON when:

- The 2nd M function (B code) is specified in automatic operation (memory, MDI or tape).
- 2nd M function (B code) is issued by manual numerical command input.


This signal turns OFF when:

- The "M function finish 1" signal (FIN1) or the "M function finish 2" signal (FIN2) is turned ON.
- Reset condition occurs. (Refer to the section on "In automatic operation "run"" signal (OP) for details on the reset conditions.)

Note

- (1) Four 2nd M functions can be issued in one block at a time.

The relationship between machining program and 2nd M function strobe is shown below.



- (2) The "2nd M function strobe 1 to 4" (BF1 to 4) is not output during operation with M function lock (AFL signal ON).
- (3) In the case of manual numerical command input, outputs are in accordance with the "2nd M function strobe 1" (BF1).
- (4) Address for 2nd M function can be selected from addresses A, B and C by using machine parameter. Set so that the address is different from the axis address.

<High-speed method (when the parameter "#1278 ext14/bit1" is set to "1")>

Refer to the section on "Miscellaneous Function Command High-speed Output: 2nd M function finish 1 to 4" (BFIN1 to 4).

[Related signals]

- (1) M function finish 1 (FIN1: YC1E)
- (2) M function finish 2 (FIN2: YC1F)
- (3) Miscellaneous Function Command High-speed Output: 2nd M function finish 1 to 4 (BFIN1 to 4: YD34 to 7)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Chopping compensation update prevented	CHPRCC	XC7F	XDBF	XEFF	X103F	X117F	X12BF	X13FF	X153F

[Function]

This signal indicates that the machine is in the state where it does not update the chopping compensation amount.

[Operation]

While this signal is turned ON:

- ♦ The chopping compensation amount is not updated.
- ♦ The "Stroke compensation completion" signal is not turned OFF.

When the control data is updated, turn this signal OFF and then update the chopping compensation amount.

[Related signals]

- (1) Chopping compensation update prevention request (CHPRCR: YCD7)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In chopping start	CHOP	XC80	XDC0	XF00	X1040	X1180	X12C0	X1400	X1540

[Function] [Operation]

This signal turns ON in the state of chopping start.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Basic position -> upper dead point path flag	CHP1	XC81	XDC1	XF01	X1041	X1181	X12C1	X1401	X1541

[Function] [Operation]

This signal turns ON while moving from the basic position to the upper dead center point.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Upper dead point -> bottom dead point path flag	CHP2	XC82	XDC2	XF02	X1042	X1182	X12C2	X1402	X1542

[Function] [Operation]

This signal turns ON while moving from the upper dead center point to the bottom dead center point.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Bottom dead point -> upper dead point path flag	CHP3	XC83	XDC3	XF03	X1043	X1183	X12C3	X1403	X1543

[Function] [Operation]

This signal turns ON while moving from the bottom dead center point to the upper dead center point.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Upper dead point -> basic position path flag	CHP4	XC84	XDC4	XF04	X1044	X1184	X12C4	X1404	X1544

[Function] [Operation]

This signal turns ON while moving from the upper dead center point to the basic position.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In chopping mode	CHPMD	XC85	XDC5	XF05	X1045	X1185	X12C5	X1405	X1545

[Function] [Operation]

This signal turns ON in the state of chopping mode.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Stroke compensation completion		XC86	XDC6	XF06	X1046	X1186	X12C6	X1406	X1546

[Function] [Operation]

This signal turns ON when the command stroke is compensated and the difference between the commanded stroke and the actual stroke becomes less than or equal to the tolerance specified with the parameter (#2080 chwid).

This signal turns OFF when the speed fluctuates, such as when the movement is stopped or the chopping control data is changed.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool escape and return transit point recognition completed		XC87	XDC7	XF07	X1047	X1187	X12C7	X1407	X1547

[Function]

With the tool escape and return function, a transit point can be designated by pressing the transit point switch while tool escapes. The tool returns to the position where machining was interrupted via the designated transit point.

This signal notifies that NC memorized the transit point.

[Operation]

Refer to the section on "In tool escape and return mode signal" (XC4A).

[Related signals]

- (1) In tool escape and return mode (XC4A)
- (2) Tool escape and return transit point designation (YC8D)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Search & start Error	SSE	XC8A	XDCA	XF0A	X104A	X118A	X12CA	X140A	X154A

[Function]

This signal is output when the program No. to be searched with search & start is illegally designated.

[Operation]

This signal is output when the program No. to be searched with search & start is illegal. Cycle start will not be carried out if this signal is output. This signal turns OFF by performing search & start again after normalizing the program No. input or by the reset signal.

Refer to the "Search & start" signal (RSST) for details.

When the multi-part system program management is valid, the signal for the 1st part system is output common to all part systems.

[Related signals]

- (1) Search & start (RSST: YC31)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Search & start Search	SSG	XC8B	XDCB	XF0B	X104B	X118B	X12CB	X140B	X154B

[Function]

This signal is output when searching for a program is started with search & start.

[Operation]

Informs the PLC that the controller is searching for a program with search & start.

Holds the "Search & start" signal until the "Search & start Search" signal turns ON.

If the program No. to be searched is illegal, the "Search & start Error" signal (SSE) is output.

When the multi-part system program management is valid, the signal for \$1 is output as common signal for all part systems.

[Related signals]

- (1) Search & start program No. (R2562, 2563)
- (2) Search & start Error (SSE: XC8A)
- (3) Search & start (RSST: YC31)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Punchtap cycle in progress	PTAPn	XC8E	XDCE	XF0E	X104E	X118E	X12CE	X140E	X154E

[Function]

This signal indicates that the Punchtap cycle is executed during the automatic operation (memory, MDI).

[Operation]

The signal turns ON when:

- The travel command of automatic operation is executed during the Punchtap cycle.

This signal turns ON also during the machine lock.

The signal turns OFF when:

- The machining status is no longer in the Punchtap cycle.

The Punchtap cycle is canceled by G80 or G command which is belonged in the G code group 01 (G00, G01, G02, G03, G33).

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool change position return completion	TCP	XC93	XDD3	XF13	X1053	X1193	X12D3	X1413	X1553

[Function]

This signal notifies that the axis commanded with the tool change position return command has completed return to the tool change position.

[Operation]


This signal turns ON when all axes commanded with the tool change position return command (G30.n) have moved to the tool change position.

This signal turns OFF when even one of the axes moved to the tool change position with the command has moved from the tool change position.

Refer to the "Programming Manual" for details on the tool change return command.

[Timing chart]

Example: When G30.1 command, additional axis tool change position return is valid



Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	New tool change	TCRQ	XC94	XDD4	XF14	X1054	X1194	X12D4	X1414	X1554

[Function]

This signal notifies that a new tool (unused tool) in the group is selected in the tool life management II.

[Operation]

The signal turns ON when the tool selected by T command is unused (status is "0").

The signal turns OFF when T command is completed by inputting the M function finish signal (FIN1, FIN2).

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool life prediction		XC96	XDD6	XF16	X1056	X1196	X12D6	X1416	X1556

[Function]

This signal notifies that the tool in use or the last tool in a group has reached the end of tool life. "Tool has reached the end of tool life" means that the value obtained by subtracting usage data from estimated tool life data has reached the set value of remaining tool life.

[Operation]

The life prediction is valid when the basic specification parameter "#1277 ext13/bit1" is set to "1".

The signal will not be output when the remaining tool life data is "0" or larger than the estimated tool life data.

Signal output judgment condition varies depending on the following parameter setting.

#1277 ext13/bit2 (Switching the timing of the "Tool life prediction" signal output)

0: Estimated tool life data - Cumulative usage data = Remaining tool life data

1: Estimated tool life data - Cumulative usage data ≤ Remaining tool life data

#1277 ext13/bit3 (Tool for which the life prediction signal is output)

0: This signal is output for each tool.

1: This signal is output for the last tool of a group.

The signal turns ON when:

- Remaining tool life data (Estimated tool life data - Cumulative usage data) reached its remaining tool life setting value.
(Same timing as count up of cumulative usage data)
- Remaining tool life data (Estimated tool life data - Cumulative usage data) has reached its remaining tool life setting value at the time of tool selection.
(Same timing as TF output)

This signal turns OFF when:

- The group currently selected is canceled.
(When the T command was issued. Note that if the next selected group has a condition of turning ON the signal, the signal remains ON.)
- Tool has reached the end of its tool life.
(Same timing as count up of cumulative usage data)
- The cumulative usage data of the currently selected group is cleared.
(e.g., when the "Tool change reset" signal (TRST) is input)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	NC alarm 1	AL1	XC98	XDD8	XF18	X1058	X1198	X12D8	X1418	X1558

[Function]

This signal informs that a system error has occurred in the controller.

[Operation]

This signal turns ON when "watch dog error", "memory parity check error", etc. occurs in the controller.

The system error can be reset by turning OFF the power.

Note

- (1) The "NC alarm 1" (AL1) may not be detected as a signal.
- (2) For details of system alarms, refer to the relevant "Instruction Manual" or "Alarm/Parameter Manual".

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	NC alarm 2 (Servo alarm)	AL2	XC99	XDD9	XF19	X1059	X1199	X12D9	X1419	X1559

[Function]

This signal informs that the controller is in servo alarm condition.

If servo alarm occurs, the "Servo ready completion" signal (SA) turns OFF.

[Operation]

The signal turns ON when the following servo alarms occur:

- ♦ Servo failure (overcurrent, overvoltage, etc.)
- ♦ Initial parameter error (parameter transferred to drive unit when the power is turned ON is illegal)
- ♦ Drive unit not mounted (cable is not connected between controller and servo controller).
- ♦ Parameter error (a parameter that will disrupt movement of the control axis was found).

Alarm can be canceled depending on the content of the alarm, such as turning OFF the power, resetting the controller, or resetting the parameters.

For details on how to reset the alarm and the contents of the servo alarm, refer to the Instruction Manual or Alarm/Parameter Manual for each model.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	NC alarm 3 (Program error)	AL3	XC9A	XDDA	XF1A	X105A	X119A	X12DA	X141A	X155A

[Function]

This signal informs that the controller is in a program error state.

[Operation]

This type of alarm occurs during automatic operation in memory, MDI or tape mode, mainly due to use of faulty machining program, or program incompatible with the controller specifications.

Some typical examples of program error are shown below. For details, refer to the relevant "Instruction Manual" or "Alarm/Parameter Manual".

- ♦ Illegal address (An address that is not in the specifications was used.)
- ♦ Absence of F command
- ♦ Arc end point excessive deviation
- ♦ Return incomplete axis found (A motion command was issued to an axis for which the reference position return has not been completed.)
- ♦ Program end error (M02 or M30 command is not inserted, or reset & rewind processing is not performed.)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	NC alarm 4 (Operation error)	AL4	XC9B	XDDB	XF1B	X105B	X119B	X12DB	X141B	X155B

[Function]

This signal informs that the controller is in operation alarm (error) condition.

[Operation]

The signal turns ON when an operation alarm occurs and turns OFF when the alarm condition is removed.

Some typical examples of operation errors are shown below. For details, refer to the operation manual or "Alarm/Parameter Manual" for each model.

- ♦ Hardware axis motion stroke end
- ♦ Software axis motion stroke end
- ♦ No operation mode set
- ♦ Cutting override zero
- ♦ Manual feedrate zero
- ♦ External interlock axis exists
- ♦ Warning regarding absolute position detection

Note

- (1) When the parameter "#1238 set10/bit7" is valid (when the "NC alarm 5" (XCB1) is valid), the following alarms are not output to the "NC alarm 4".

Error No.	Details
0004	External interlock axis exists
0102	Cutting override zero
0103	External feed speed zero
0109	Block start interlock
0110	Cutting block start interlock
0125	Rapid traverse override zero
0200	Interference check disabled
0205	Tool interfere. check disabled
1033	Spindle-Spindle polygon (G51.2/G251) cutting interlock

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	NC warning (Servo warning)	WR1	XC9C	XDDC	XF1C	X105C	X119C	X12DC	X141C	X155C

[Function]

This signal notifies that the servo warning (S52) occurs in the drive unit.

[Operation]**<For servo drive unit>**

- ♦ This signal turns ON when a warning in servo drive unit is occurring on one or more axes within the part system.
- ♦ This signal turns OFF when no warning in servo drive unit is occurring on any axis within the part system.

<For spindle/PLC axis drive unit>

- ♦ When a warning occurs, the signal of the 1st part system is output.

Note

- (1) This signal is not output if the servo warning "S52 00E6" (Control axis detachment warning) or "S52 00E7" (In NC emergency stop state) occurs.

[Related signals]

- (1) Servo alarm/warning No. (R5332 to R5339)
- (2) Spindle alarm/warning No. (R6529)
- (3) PLC axis alarm warning No. n-th axis (R168 to R175)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Thread cutting: Feed-forward control ON	FFCO	XCA4	XDE4	XF24	X1064	X11A4	X12E4	X1424	X1564

[Function]


This signal notifies that the feed forward control is valid in the thread cutting command.

[Operation]

This signal is turned ON when all the following conditions are met.

- During the cutting mode (G64) modal.
- While the "Thread cutting: Feed-forward control request" signal (FFC: YC94) is ON.
- While any of the commands in the table below is commanded.

G code	Function name
G32, G33	Thread cutting
G34	Variable lead thread cutting
G35	Arc thread cutting CW
G36	Arc thread cutting CCW



This signal turns OFF when:

- Any of the conditions listed above for turning ON the signal are not satisfied.
- However, when the "Thread cutting: Feed-forward control request" signal (FFC: YC94) is turned ON to OFF during the thread cutting command (G32 to G36) under the feed forward control, the "Thread cutting: Feed-forward control ON" signal (FFCO: XCA4) is held until the cutting up of the thread cutting command ends.

[Related signals]

- (1) Thread cutting: Feed-forward control request (FFC: YC94)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tap retract possible	TRVE	XCA5	XDE5	XF25	X1065	X11A5	X12E5	X1425	X1565

[Function]

This signal informs that tap retract is possible. This signal is output when the operation is interrupted during the tap cycle execution.

The tap retract is performed by turning ON the "Tap retract" signal (TRV: YC5C) when this signal (TRVE: XCA5) is ON.

[Operation]

This signal turns ON when the tap cycle is interrupted in the cutting feed area due to the following causes.

- ♦ Emergency stop
- ♦ Reset stop
- ♦ Power OFF (only in absolute position detection system)

Refer to the section on the "Tap retract" signal (TRV: YC5C) for the tap retract operation.

The signal turns OFF when:

- ♦ Tap retract is executed and completed.
- ♦ The target axis for the tap retract is moved automatically or with manual mode.
However, it is moved only when the following conditions are met.
 - The parameter "#1234 set06/bit3" is set to "1".
 - The "Tap retract" signal (YC5C) is OFF.
 - The target axis for the tap retract is stopped.
- ♦ The rising edge of the "Tap retract possible state cancel" signal (YCD6) is confirmed.

[Caution]

- (1) When the parameter "#1234 set06/bit3" (*1) is set to "0", all the axes are interlocked while the "Tap retract possible" signal (XCA5) is ON. If the automatic or manual axis movement is commanded, the operation error (M01 0057) occurs. To cancel the interlocked state, turn ON the "Tap retract possible state cancel" signal (YCD6) and then turn this signal OFF.
 - (2) When the parameter "#1234 set06/bit3" is set to "1", the axis interlock control is not performed on the CNC side even if the tapping is interrupted due to emergency stop, etc. The axis moves according to the movement command even during the tap retract operation. Safety measures are required on the machine side.
- (*1) The parameter "#1234 set06/bit3" is the parameter to select interlock when the tap retract is enabled.

[Related signals]

- (1) Tap retract (TRV: YC5C)
- (2) Tap retract possible state cancel (TRVEC: YCD6)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	No. of work machining over	PCNT	XCA6	XDE6	XF26	X1066	X11A6	X12E6	X1426	X1566

[Function]

This signal is output when the No. of work machining matches or exceeds the maximum No. of work machining.

[Operation]

This signal turns ON when the No. of work machining matches or exceeds the maximum work value (WRK LIMIT) set in the [Process parameter] screen.

Note

- (1) This signal turns ON when the No. of work machining matches or exceeds the maximum work value regardless of the count up by the controller or user PLC.
- (2) This signal is not output when "0" is set for the maximum work value.

[Related signals]

- (1) No. of work machining (current value) (R606, 7)
- (2) No. of work machining (maximum value) (R608, 9)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Absolute position warning	ABSW	XCA7	XDE7	XF27	X1067	X11A7	X12E7	X1427	X1567

[Function]

This signal notifies that the movement amount when the power is turned OFF exceeds the tolerable amount in the absolute position detection system.

[Operation]

This signal turns ON when the difference of the machine position at power OFF and at power ON exceeds the tolerable value ([ABS. POSI PARAM] "#2051 check" setting value) when using the absolute position detection system.

Note

- (1) The movement amount during power OFF depends on the "PON POS" (power ON position) and "POF POS" (power OFF position) on the [ABS SERVO MONITOR] (absolute position monitor) screen.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In axis name switch		XCA9	XDE9	XF29	X1069	X11A9	X12E9	X1429	X1569

[Function]

This signal informs that the axis name is being switched.

[Operation]

This signal turns ON by the axis name switch command (G111).

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Hob machining: Retracting	HO-BRTM	XCAE	XDEE	XF2E	X106E	X11AE	X12EE	X142E	X156E

[Function]

This signal informs that the hob retract operation is running.


[Operation]

This signal turns ON when:

- ♦ The retract operation is started by the "Hob machining: Retract request" signal (HOBRTTR) during the hob machining mode.
- ♦ The retract operation is started due to a program error or an operation error during the hob machining mode.

This signal turns OFF when:

- ♦ Retract operation is completed.
- ♦ The power is turned OFF and ON.
- ♦ Retract operation is stopped due to reset or emergency stop.

**[Related signals]**

- (1) Hob machining: Retract request (HOBRTTR: YCDE)
- (2) Hob machining: Retract amount selection (HOBRTV: YB20)
- (3) Hob machining: Retract complete (HOBRTF: XCAF)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Hob machining: Retract complete	HOBRTF	XCAF	XDEF	XF2F	X106F	X11AF	X12EF	X142F	X156F

[Function]

This signal informs that hob retract operation is completed.


[Operation]

This signal turns ON when:

- Retract is performed by the "Hob machining: Retract request" signal (HOBRTTR) in the hob machining mode, and the retract operations of all axes are completed.
- Retract is performed due to a program error or an operation error in the hob machining mode, and the retract operations of all axes are completed.

This signal turns OFF when:

- The power is turned OFF and ON.
- Reset or emergency stop is input, or automatic operation is restarted.
- Retract axis moves.

**[Related signals]**

- (1) Hob machining: Retract request (HOBRTTR: YCDE)
- (2) Hob machining: Retract amount selection (HOBRTV: YB20)
- (3) Hob machining: Retracting (HOBRTM: XCAE)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In spindle-NC axis polygon mode		XCB0	XDF0	XF30	X1070	X11B0	X12F0	X1430	X1570

[Function]

This signal informs the PLC that polygon machining (spindle-NC axis) mode is entered.

Note

- (1) Refer to the "In spindle-spindle polygon mode" signal for details on the spindle-spindle polygon.
 - #1501 polyax ≠ 0: Polygon machining (spindle-NC axis)
 - #1501 polyax = 0: Spindle-spindle polygon (spindle-spindle)

[Operation]

This signal turns ON by the polygon machining start command (G51.2/G251). The status ON is retained during the polygon machining mode.

This signal turns OFF when the polygon machining mode is canceled (G50.2/G250, reset, etc.), and remains OFF in modes other than the polygon machining mode. The OFF status is retained except during the polygon machining mode.

[Related signals]

- (1) In spindle-spindle polygon mode (XCB2)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	NC alarm 5	AL5	XCB1	XDF1	XF31	X1071	X11B1	X12F1	X1431	X1571

[Function]

This signal informs that the controller is in operation alarm (error) condition.

[Operation]

This signal is turned ON when:

- ♦ The parameter "#1238 set10/bit7" is ON and the following operation alarms occur.

This signal turns OFF when:

- ♦ The parameter "#1238 set10/bit7" is OFF.
- ♦ The parameter "#1238 set10/bit7" is ON and there are no following operation alarm conditions.

For details on the operation alarms, refer to the instruction manual for each model.

<Operation alarms output to the "NC alarm 5">

- ♦ External interlock axis exists (M01 0004)
- ♦ Override zero (M01 0102)
- ♦ External feed speed zero (M01 0103)
- ♦ Block start interlock (M01 0109)
- ♦ Cutting block start interlock (M01 0110)
- ♦ Rapid traverse override zero (M01 0125)
- ♦ Interference check disabled (M01 0200)
- ♦ Tool interfere. check disabled (M01 0205)
- ♦ Spindle-spindle polygon (G51.2/G251) cutting interlock (M01 1033)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In spindle-spindle polygon mode		XCB2	XDF2	XF32	X1072	X11B2	X12F2	X1432	X1572

[Function]

This signal informs that the spindle-spindle polygon machining mode is being executed.

Note

- (1) Refer to the explanation of the "In Spindle-NC axis polygon mode" signal for details on the spindle-NC axis polygon.
#1501 polyax ≠ 0: Polygon machining (spindle-NC axis)
#1501 polyax = 0: Spindle-spindle polygon (spindle-spindle)

[Operation]

This signal is turned ON when:

- ♦ The G51.2/G251 is commanded, and the spindle-spindle polygon machining is executed.

This signal turns OFF when:

- ♦ G50.2/G250 is commanded, and the spindle-spindle polygon machining is canceled.
- ♦ The "Spindle synchronization cancel" signal is input, and the spindle-spindle polygon machining is canceled.
- ♦ Emergency stop occurs.
- ♦ Reset is input.

When this signal turns ON and the spindle-spindle polygon synchronization is completed, the "Spindle-spindle polygon synchronization completion" signal turns ON.

[Related signals]

- (1) Spindle-spindle polygon cancel (YCD1)
- (2) Spindle-spindle polygon synchronization completion (XCB3)
- (3) In Spindle-NC axis polygon mode (XCB0)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Spindle-spindle polygon synchronization completion		XCB3	XDF3	XF33	X1073	X11B3	X12F3	X1433	X1573

[Function]

This signal informs that the workpiece spindle and rotary tool spindle are in the synchronized rotation state.

[Operation]

This signal turns ON when:

- The rotary tool spindle rotation speed, in respect to the rotation speed following the rotary tool spindle and workpiece spindle rotation ratio command, reaches the value set for the spindle-spindle polygon synchronization rotation speed attainment level during the spindle-spindle polygon machining mode.

This signal turns OFF when:

- The rotary tool spindle rotation speed, in respect to the rotation speed following the rotary tool spindle and workpiece spindle rotation ratio command, deviates from the value set for the spindle-spindle polygon synchronization rotation speed attainment level during the spindle-spindle polygon machining mode.
- The spindle-spindle polygon synchronization mode is canceled.

[Related signals]

- (1) Spindle-spindle polygon cancel (YCD1)
- (2) In spindle-spindle polygon mode (XCB2)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In 3-dimensional coordinate conversion		XCB9	XDF9	XF39	X1079	X11B9	X12F9	X1439	X1579

[Function]

This signal notifies that the controller is in 3-dimensional coordinate conversion.

[Operation]

This signal turns ON when:

- G68 (M system)/G68.1 (L system) (3-dimensional coordinate conversion) is commanded.

This signal turns OFF when:

- G69 (M system)/G69.1 (L system) (3-dimensional coordinate conversion cancel) is commanded.
- G68/G68.1 (3-dimensional coordinate conversion) modal is cleared by reset.

4 Explanation of Interface Signals


4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In synchronized tapping selection (M command)	RTAP	XCC0	XE00	XF40	X1080	X11C0	X1300	X1440	X1580

[Function]

This signal informs that the synchronized tapping mode is active.


(This signal is output only when the M function synchronized tapping cycle valid parameter (#1272 ext08 bit1) is ON.)

[Operation]**<ON timing>****Note**

- (1) Spindle position loop and in synchronized tapping selection turn ON only during synchronized tapping.
- (2) If synchronized tapping is applied even during tap retract, the "In synchronized tapping selection" signal turns ON.

<OFF timing>

This signal is turned OFF by commanding reset, G80 (hole drilling fixed cycle cancel), 01 group G codes, or other fixed cycle G codes.

**Note**

- (1) The gears are not selected until the S command is issued again.
- (2) This signal turns OFF when tap retract is interrupted or completed.

[Related signals]

- (1) Gear shift completion (GFIN: Y1885)
- (2) Spindle actual speed (R6506)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In small diameter deep hole cycle		XCC1	XE01	XF41	X1081	X11C1	X1301	X1441	X1581

[Function]

This signal outputs the state of "in drilling operation" of small diameter deep hole cycle.

[Operation]

This signal is output between the positioning to the R point for drilling axis and returning to the R point/initial point after finishing the drilling.

[Related signals]

- (1) Small diameter deep hole drilling cycle (YCCA)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In barrier valid (left)		XCC8	XE08	XF48	X1088	X11C8	X1308	X1448	X1588

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In barrier valid (right)		XCC9	XE09	XF49	X1089	X11C9	X1309	X1449	X1589


[Function]

This signal informs that the barrier area of left side (right side) is valid in the chuck/tailstock barrier function.

[Operation]

This signal is turned ON when all conditions below are satisfied and the barrier area is enabled. (When this signal is OFF, the barrier check is not executed.)

- The additional specification of chuck barrier check function is valid.
- The setting of the parameter "#8310 Barrier ON" on the barrier data screen is "1". (Except when the special display unit is used.)
- The setting of the parameter "#8315 Barrier Type (L)" ("#8316 Barrier Type (R)") on the barrier data screen is other than "0".
- The barrier valid signal input described above is ON or in G22 modal.

**[Related signals]**

- (1) Barrier valid (left) (YCD8)
 (2) Barrier valid (right) (YCD9)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Door open enable	DROPNS	XCD8	XE18	XF58	X1098	X11D8	X1318	X1458	X1598

[Function]

This signal informs the PLC that the drive power supply for all axes is being shut off or released due to the "Door open I" signal (DOOR1) or the "Door open II" signal (DOOR2).

[Operation]

This signal turns ON when the drive power supply for all axes is shut off by turning ON the "Door open I" signal (DOOR1) or the "Door open II" signal (DOOR2).

This signal turns OFF when all axes are ready ON and all servo axes are servo ON by turning OFF the "Door open I" signal (DOOR1) or the "Door open II" signal (DOOR2).

Release of the door lock is enabled at the rising edge of the "Door open enable" signal.

The operation is in a READY status at the falling edge of the "Door open enable" signal.

[Caution]**<Handling of the PLC axis>**

For the PLC axis, stop it at the PLC and then output the "Door open I" signal (DOOR1) or the "Door open II" signal (DOOR2) to the NC. If the "Door open I" signal (DOOR1) or the "Door open II" signal is input without stopping the PLC axis, the axis stops with a dynamic brake method due to the ready OFF. The remaining distance is held in the R register being used in the PLC axis control.

<Handling of the analog spindle>

When an analog spindle is connected, it is not possible to confirm that the spindle has completely stopped with the NC. Thus, confirm that the spindle has completely stopped using the PLC, before opening the door.

Since the spindle may resume rotation immediately after the door is closed, for safety, turn OFF the forward run and the reverse run signals when the door is opened.

<Opening the door during ATC operation>

To open the door while ATC is operating, apply an interlock with the user PLC.

[Related signals]

- (1) Door open I (DOOR1: Y768)
- (2) Door open II (DOOR2: YCE1)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	External search: Program return completed		XCEA	XE2A	XF6A	X10AA	X11EA	X132A	X146A	X15AA

[Function] [Operation]

This signal turns ON when the program return is completed by inputting the program return signal. This also turns ON when an error occurs.

This signal turns OFF when the program return signal is turned OFF from the user PLC.

The timing chart for program return is shown below.



4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Program format switch in progress	PFCHS	XCF0	XE30	XF70	X10B0	X11F0	X1330	X1470	X15B0

[Function]

This signal informs of the program format switch state.

0: Program format switch not in progress


1: Program format switch in progress

[Operation]

This signal notifies the PLC of the part system where program format switch is enabled.

When the "Program format switch request" (PFCHR: YD00) has turned ON and the format switch is completed, the PFCHS signal turns ON. When automatic operation is started while this signal is ON, the program is executed based on the switched program format (G code system).

L-system operation example

**[Caution]**

- (1) After the "Program format switch request" (PFCHR: YD00) is turned ON, do not start automatic operation until this signal turns ON. Otherwise, it cannot be assured that "the control runs a program based on the switched G code system from the top block of the program".

[Related signals]

- (1) Program format switch request (PFCHR: YD00)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Torque limitation skip: G160 torque limit ON	GLMT	XCF9	XE39	XF79	X10B9	X11F9	X1339	X1479	X15B9

[Function]

This signal indicates that the torque skip ON occurred while the torque skip (G160) is commanded.


[Operation]

This signal turns ON when:

- The torque skip ON occurs while the torque skip (G160) is commanded.

This signal turns OFF when:

- The "Reset 1", "Reset 2", or "Reset & rewind" signal is input for the target part system.
- An emergency stop occurred.
- An axis movement is commanded for the target part system with a machining program in the next or later block for the target part system.



4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Rapid traverse time constant: In switchover	G0AC	XD0B	XE4B	XF8B	X10CB	X120B	X134B	X148B	X15CB

[Function]

This signal indicates the currently selected rapid traverse time constant.

[Operation]

This signal turns ON when:

- The rapid traverse time constant has already been switched to the axis specifications parameter "#2598 G0tL_2" or the rapid traverse time constant (primary delay)/second-step time constant for soft acceleration/deceleration has been switched to the axis specifications parameter "#2599 G0t1_2".

This signal turns OFF when:

- The rapid traverse time constant has already been switched to the axis specifications parameter "#2004 G0tL" or the rapid traverse time constant (primary delay)/second-step time constant for soft acceleration/deceleration has been switched to the axis specifications parameter "#2005 G0t1".

[Related signals]

- (1) Rapid traverse time constant: Switchover request (ACCG: YD0B)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Real-time tuning 2: Acceleration/deceleration time constant in switchover	RT2CHG	XD0C	XE4C	XF8C	X10CC	X120C	X134C	X148C	X15CC

[Function]

This signal indicates that the switching process of acceleration/deceleration time constant is being performed in the real-time tuning 2 function.

[Operation]

This signal is ON while switching process of the acceleration/deceleration time constant is being performed.

This signal is OFF while switching process of the acceleration/deceleration time constant is not performed or real-time tuning 2 function is disabled.

[Related signals]

- (1) Real-time tuning 2: Acceleration/deceleration time constant in automatic switchover (RT2CHGA: YD0C)
- (2) Real-time tuning 2: Acceleration/deceleration time constant in manual switchover (RT2CHGM: YD0D)
- (3) Real-time tuning 2: Acceleration/deceleration time constant reset (RT2RST: YD0E)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Reserved tool wear compensation not reflected	TWNIN	XD0E	XE4E	XF8E	X10CE	X120E	X134E	X148E	X15CE

[Function]

This signal notifies the PLC that the reserved tool wear compensation memory has not been reflected to the tool wear compensation memory yet.

[Operation]

Refer to the page of the "Request for reflecting reserved tool wear compensation" signal (TWIN: YD0F).

[Related signals]

- (1) Reservation of tool wear compensation (TWR: Y1CB8)
- (2) Request for reflecting reserved tool wear compensation (TWIN: YD0F)
- (3) Reflection of reserved tool wear compensation is complete (TWOUT: XD0F)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Reflection of reserved tool wear compensation is complete	TWOUT	XD0F	XE4F	XF8F	X10CF	X120F	X134F	X148F	X15CF

[Function]

This signal notifies the PLC that the contents of the reserved tool wear compensation memory have been reflected to the tool wear compensation memory.

[Operation]

Refer to the page of the "Request for reflecting reserved tool wear compensation" signal (TWIN: YD0F).

When the "Request for reflecting reserved tool wear compensation" signal (TWIN) turns OFF, this signal also turns OFF.

[Related signals]

- (1) Reservation of tool wear compensation (TWR: Y1CB8)
- (2) Request for reflecting reserved tool wear compensation (TWIN: YD0F)
- (3) Reserved tool wear compensation not reflected (TWNIN: XD0E)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	3D coordinate conversion: Manual feed valid		XD14	XE54	XF94	X10D4	X1214	X1354	X1494	X15D4

[Function]

While this signal is ON, the coordinate system for manual operation is selected by the "3D coordinate conversion: Manual feed coordinates switch" signal (YD14).

While this signal is OFF, manual feed is carried out with respect to the machine coordinate system.

[Operation]

This signal turns ON when the following conditions are all satisfied:

- Jog, incremental or handle mode is being selected.
- G68 (M system)/G68.1 (L system) (3D coordinate conversion) has been commanded at least once.

However, if the command is canceled by G69 (M system)/G69.1 (L system) (3D coordinate conversion cancel), the signal will not turn ON until G68/G68.1 is commanded again.

[Related signals]

- (1) 3D coordinate conversion: Manual feed coordinates conversion (YD14)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Rotation center error compensation in progress	RCEI	XD15	XE55	XF95	X10D5	X1215	X1355	X1495	X15D5

[Function]

This signal indicates that the rotation center error compensation is valid.

[Operation]

This signal turns "1" when the additional specification of rotation center error compensation is enabled and the "Rotation center error compensation enabled" signal (RCEE) is "1".

This signal turns "0" when the rotation center error compensation is disabled.

[Related signals]

- (1) Rotation center error compensation enabled (RCEE: YD15)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Spatial error compensation in progress	SECI	XD17	XE57	XF97	X10D7	X1217	X1357	X1497	X15D7

[Function]



This signal indicates that the spatial error compensation is valid and error compensation can be performed.

[Operation]

When the spatial error compensation is invalid, this signal is set to "0".

When the "Spatial error compensation enabled" signal (SECE: YD17) is ON and the option of the spatial error compensation is valid, this signal is set to "1".

The spatial error compensation function can compensate errors only in the first part system.

[Timing chart]**<Without the spatial error compensation option>****<With the spatial error compensation option>****Note**

- (1) When the spatial error compensation is enabled and the error data is the same as when it was enabled the last time, the calculation processing is not performed.

[Related signals]

- (1) Spatial error compensation enabled (SECE: YD17)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	3D manual feed (JOG, INC): Tool axis coordinate system selected	MJST	XD18	XE58	XF98	X10D8	X1218	X1358	X1498	X15D8
A	3D manual feed (JOG, INC): Table coordinate system selected	MJSB	XD19	XE59	XF99	X10D9	X1219	X1359	X1499	X15D9
A	3D manual feed (JOG, INC): Feature coordinate system selected	MJSF	XD1A	XE5A	XF9A	X10DA	X121A	X135A	X149A	X15DA

[Function]

This signal indicates the coordinate system in which the 3D manual feed is carried out by the jog or incremental feed.

Jog feed or incremental feed is carried out on the coordinate system for which this signal is ON.

[Operation]

This signal turns ON when:

- The signal (YD18 to YD1A) to select the coordinate system for the 3D manual feed (JOG, INC) is turned ON during jog mode or incremental mode.

This signal turns OFF when:

- The signal (YD18 to YD1A) to select the coordinate system for the 3D manual feed (JOG, INC) is turned OFF.
- The jog feed mode or incremental feed mode is turned OFF.

[Related signals]

- (1) In jog mode (JO: XC00)
- (2) In incremental mode (SO: XC02)
- (3) 3D manual feed (JOG, INC): Tool axis coordinate system selection (MJCT: YD18)
- (4) 3D manual feed (JOG, INC): Table coordinate system selection (MJCB: YD19)
- (5) 3D manual feed (JOG, INC): Feature coordinate system selection (MJCF: YD1A)
- (6) In tool center point rotation (TCPRS: XD27)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	3D manual feed (1st handle): Tool axis coordinate system selected	MH1ST	XD1B	XE5B	XF9B	X10DB	X121B	X135B	X149B	X15DB
A	3D manual feed (1st handle): Table coordinate system selected	MH1SB	XD1C	XE5C	XF9C	X10DC	X121C	X135C	X149C	X15DC
A	3D manual feed (1st handle): Feature coordinate system selected	MH1SF	XD1D	XE5D	XF9D	X10DD	X121D	X135D	X149D	X15DD

[Function]

This signal indicates the coordinate system in which the 3D manual feed is carried out on the 1st handle axis.

The feed on the 1st handle axis is carried out on the coordinate system for which this signal is ON.

[Operation]

This signal turns ON when:

- The 1st handle feed is valid, the axis is selected and the signal (YD1B to YD1D) to select the coordinate system for the 3D manual feed (1st handle) is turned ON.

This signal turns OFF when:

- The signal (YD1B to YD1D) to select the coordinate system for the 3D manual feed (1st handle) is turned OFF.
- The "1st handle valid" signal is turned OFF.
- The signal to select the 1st handle axis is turned OFF.

[Related signals]

- (1) 1st handle axis selection code (HS11 to HS116: YC40 to 4)
- (2) 1st handle valid (HS1S: YC47)
- (3) 3D manual feed (1st handle): Tool axis coordinate system selection (MH1CT: YD1B)
- (4) 3D manual feed (1st handle): Table coordinate system selection (MH1CB: YD1C)
- (5) 3D manual feed (1st handle): Feature coordinate system selection (MH1CF: YD1D)
- (6) In tool center point rotation (TCPRS: XD27)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	3D manual feed (2nd handle): Tool axis coordinate system selected	MH2ST	XD1E	XE5E	XF9E	X10DE	X121E	X135E	X149E	X15DE
A	3D manual feed (2nd handle): Table coordinate system selected	MH2SB	XD1F	XE5F	XF9F	X10DF	X121F	X135F	X149F	X15DF
A	3D manual feed (2nd handle): Feature coordinate system selected	MH2SF	XD20	XE60	XFA0	X10E0	X1220	X1360	X14A0	X15E0

[Function]

This signal indicates the coordinate system in which the 3D manual feed is carried out on the 2nd handle axis.

The feed on the 2nd handle axis is carried out on the coordinate system for which this signal is ON.

[Operation]

This signal turns ON when:

- The 2nd handle feed is valid, the axis is selected and the signal (YD1E to YD20) to select the coordinate system for the 3D manual feed (2nd handle) is turned ON.

This signal turns OFF when:

- The signal (YD1E to YD20) to select the coordinate system for the 3D manual feed (2nd handle) is turned OFF.
- The "2nd handle valid" signal is turned OFF.
- The signal to select the 2nd handle axis is turned OFF.

[Related signals]

- (1) 2nd handle axis selection code (HS21 to HS216: YC48 to C)
- (2) 2nd handle valid (HS2S: YC4F)
- (3) 3D manual feed (2nd handle): Tool axis coordinate system selection (MH2CT: YD1E)
- (4) 3D manual feed (2nd handle): Table coordinate system selection (MH2CB: YD1F)
- (5) 3D manual feed (2nd handle): Feature coordinate system selection (MH2CF: YD20)
- (6) In tool center point rotation (TCPRS: XD27)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	3D manual feed (3rd handle): Tool axis coordinate system selected	MH3ST	XD21	XE61	XFA1	X10E1	X1221	X1361	X14A1	X15E1
A	3D manual feed (3rd handle): Table coordinate system selected	MH3SB	XD22	XE62	XFA2	X10E2	X1222	X1362	X14A2	X15E2
A	3D manual feed (3rd handle): Feature coordinate system selected	MH3SF	XD23	XE63	XFA3	X10E3	X1223	X1363	X14A3	X15E3

[Function]

This signal indicates the coordinate system in which the 3D manual feed is carried out on the 3rd handle axis.

The feed on the 3rd handle axis is carried out on the coordinate system for which this signal is ON.

[Operation]

This signal turns ON when:

- The 3rd handle feed is valid, the axis is selected and the signal (YD21 to YD23) to select the coordinate system for the 3D manual feed (3rd handle) is turned ON.

This signal turns OFF when:

- The signal (YD21 to YD23) to select the coordinate system for the 3D manual feed (3rd handle) is turned OFF.
- The "3rd handle valid" signal is turned OFF.
- The signal to select the 3rd handle axis is turned OFF.

[Related signals]

- (1) 3rd handle axis selection code (HS31 to HS316: YC50 to 4)
- (2) 3rd handle valid (HS3S: YC57)
- (3) 3D manual feed (3rd handle): Tool axis coordinate system selection (MH3CT: YD21)
- (4) 3D manual feed (3rd handle): Table coordinate system selection (MH3CB: YD22)
- (5) 3D manual feed (3rd handle): Feature coordinate system selection (MH3CF: YD23)
- (6) In tool center point rotation (TCPRS: XD27)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In tool center point rotation	TCPRS	XD27	XE67	XFA7	X10E7	X1227	X1367	X14A7	X15E7

[Function]

This signal informs the operation of the rotation axis of 3D manual feed (JOG/incremental/handle).

[Operation]

When the rotation axis of 3D manual feed (JOG/incremental/handle) is operated, this signal informs that the tool is operating while maintaining the positional relationship of tool center point as seen from the workpiece.

[Related signals]

- (1) 3D manual feed (JOG, INC): Tool axis coordinate system selected (MJST: XD18)
- (2) 3D manual feed (JOG, INC): Table coordinate system selected (MJSB: XD19)
- (3) 3D manual feed (JOG, INC): Feature coordinate system selected (MJSF: XD1A)
- (4) 3D manual feed (1st handle): Tool axis coordinate system selected (MH1ST: XD1B)
- (5) 3D manual feed (1st handle): Table coordinate system selected (MH1SB: XD1C)
- (6) 3D manual feed (1st handle): Feature coordinate system selected (MH1SF: XD1D)
- (7) 3D manual feed (2nd handle): Tool axis coordinate system selected (MH2ST: XD1E)
- (8) 3D manual feed (2nd handle): Table coordinate system selected (MH2SB: XD1F)
- (9) 3D manual feed (2nd handle): Feature coordinate system selected (MH2SF: XD20)
- (10) 3D manual feed (3rd handle): Tool axis coordinate system selected (MH3ST: XD21)
- (11) 3D manual feed (3rd handle): Table coordinate system selected (MH3SB: XD22)
- (12) 3D manual feed (3rd handle): Feature coordinate system selected (MH3SF: XD23)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	R-Navi: Machining surface being selected	RSSCT	XD28	XE68	XFA8	X10E8	X1228	X1368	X14A8	X15E8

[Function]

This signal notifies that a machining surface is being selected by the R-Navi function.

[Operation]

This signal turns ON when:

- A machining surface is selected on [S-sel] of the monitor screen.

This signal turns OFF when:

- The machining surface is canceled.
- The machining surface is canceled with emergency stop.

Note

- (1) This signal will not turn ON while a machining surface is being called by a program.

[Related signals]

- (1) R-Navi: Machining surface being indexed (RSIND: XD29)
- (2) R-Navi: Machining surface indexing completion (RSIDF: XD2A)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	R-Navi: Machining surface being indexed	RSIND	XD29	XE69	XFA9	X10E9	X1229	X1369	X14A9	X15E9

[Function]

This signal notifies that a selected machining surface is being indexed by the R-Navi function.

[Operation]

This signal turns ON when:

- ♦ "#11037 R-Navi Index Type" is set to "0".

The [Index exec] menu is pressed on [Surface Selection] of the Monitor screen while a machining surface is being selected.

- ♦ "#11037 R-Navi Index Type" is "1".

The [Index exec] menu is pressed on [Surface Selection] of the Monitor screen and then a tool length offset No. is entered while a machining surface is being selected.

This signal turns OFF when:

- ♦ Indexing is completed.
- ♦ The NC is reset.
- ♦ Emergency stop occurs.

[Related signals]

- (1) R-Navi: Machining surface being selected (RSSCT: XD28)
- (2) R-Navi: Machining surface indexing completion (RSIDF: XD2A)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	R-Navi: Machine surface index complete	RSIDF	XD2A	XE6A	XFAA	X10EA	X122A	X136A	X14AA	X15EA

[Function]

This signal notifies that indexing of a selected machining surface is completed by the R-Navi function.

[Operation]

This signal turns ON when:

- ♦ Machining surface indexing is completed, and the "Smoothing zero" is turned ON.

This signal turns OFF when:

- ♦ The machining surface is canceled.
- ♦ Another machining surface is selected while the surface is being selected (surfaces are switched).
- ♦ The machining surface is canceled with emergency stop.

[Related signals]

- (1) R-Navi: Machining surface being selected (RSSCT: XD28)
- (2) R-Navi: Machining surface being indexed (RSIND: XD29)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Simple inclined surface machining/Inclined surface control command ON	SLOP	XD2F	XE6F	XFAF	X10EF	X122F	X136F	X14AF	X15EF

[Function]

This signal notifies that the inclined surface machining command and simple inclined surface control command are in modal.

[Operation]

The signal turns ON when:

- A block of inclined surface machining command (G68.2) is executed.
- A block of simple inclined surface control command (G176) is executed.
- The parameter "#1247 set19/bit2" (Inclined surface machining mode hold) is set to "1" and the power is turned OFF and ON again during the simple inclined surface control command.

The signal turns OFF when:

- A cancel block of inclined surface machining command and simple inclined surface control command (G69.1) are executed.
- The parameter "#1247 set19/bit2" (Inclined surface machining mode hold) is set to "0" and the emergency stop is turned ON.
- The inclined surface machining command and simple inclined surface control command are canceled by reset.

The inclined surface machining command and simple inclined surface control command are canceled when:

#1151 rstint (Reset initial)	#1210 RstGmd/bitF (Modal G code reset)	Reset 1	Reset 2	Reset & rewind
0	0	Retains all modals.	Cancel	Cancel
	1	Retains all modals.	Retains only the inclined surface.	Retains only the inclined surface.
1	0	Cancel	Cancel	Cancel
	1	Retains only the inclined surface.	Retains only the inclined surface.	Retains only the inclined surface.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Sending user arbitrary information		XD30	XE70	XFB0	X10F0	X1230	X1370	X14B0	X15F0

[Function]

This signal notifies that DB operation is being performed to the arbitrary information accumulation table in the database.

[Operation]

This signal notifies that whether the DB operation is being performed to the arbitrary information accumulation table in the database.

0: The DB operation is not performing to the arbitrary information accumulation table in the database.

1: The DB operation is performing to the arbitrary information accumulation table in the database.

When MES interface library function is invalid, this signal is set to "0".

[Related signals]

- (1) MES interface library: User arbitrary information send request (YC9B to Y155B)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary reverse run: Reverse run invalid status		XD31	XE71	XFB1	X10F1	X1231	X1371	X14B1	X15F1

[Function]

This signal notifies that the reverse run is not possible.

[Operation]

This signal notifies that the reverse run is not possible when the reverse run is performed in the block where the reverse run is prohibited during manual arbitrary reverse.

This signal turns ON at the timing when the reverse run is performed in the block where the reverse run is prohibited. After that, as the state of the signal is retained, the signal continues to be output even when the reverse run stops. This signal turns OFF at the time of reset/emergency stop or forward run start.

Also, this signal turns OFF when manual arbitrary reverse run is canceled during reverse run invalid status.

[Related signals]

- (1) Manual arbitrary reverse run mode (MORR: Y73C)
- (2) Manual arbitrary reverse run mode ON (PCHKO: X715)
- (3) Manual arbitrary reverse run speed selection (MORSP: Y73D)
- (4) Actual cutting mode (thread, tap) in manual arbitrary reverse run (MRCMD: Y761)
- (5) Manual arbitrary reverse run: MSTB reverse run prohibited (MRPSG: YCFC)
- (6) Manual arbitrary reverse run speed multiplier (R379)
- (7) Manual arbitrary reverse run: Reverse run ON (MOREV: X716)
- (8) Manual arbitrary reverse run handle selection (R375)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	VCC: Mode in execution	VCC	X1810	X1811	X1812	X1813	X1814	X1815	X1816	X1817

[Function]

This signal notifies that the vibration cutting mode is being executed.

[Operation]

This signal turns ON during the vibration cutting mode.

This signal turns OFF when the vibration cutting mode is canceled.

[Related signals]

- (1) VCC: Mode in execution (VCC: X1810)
- (2) VCC: Numbers of vibrations (VCC_VIB: R20556)
- (3) VCC: Frequency (VCC_FRQ: R20557)
- (4) VCC: Spindle rotation speed (VCC_SPREV: R7024,R7025)
- (5) VCC: Vibrating axis (VCC_VIBAX: R20558)
- (6) VCC: Temporary cancel of axis vibration (VCC_INVAX: R22532)
- (7) VCC: Cause of non-vibration (VCC_FACT: R20559)

Cont.	Signal name	Abbrev.	Common (\$)
A	Edit/search window displayed		X1878

[Function]

This signal indicates that the "Edit/Search" window is displayed.

[Operation]

This signal is turned ON when the "Edit/Search" window is displayed on the monitor screen, and turned OFF when the window is closed.

[Related signals]

- (1) Edit/Search (Y1878)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	S command gear No. illegal	SIGE	X1882	X18E2	X1942	X19A2	X1A02	X1A62	X1AC2	X1B22

[Function]

This signal is output if specified gear No. is illegal.

[Operation]

This signal turns ON when the gear No. specified by the user exceeds the system maximum gear No.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	S command max./min. command value over	SOVE	X1883	X18E3	X1943	X19A3	X1A03	X1A63	X1AC3	X1B23

[Function]

This signal is output when S command value is clamped to the maximum or minimum value.

[Operation]

The signal turns ON when the S command value is larger than the value of the maximum spindle rotation speed parameter (Smax) or smaller than the value of the minimum spindle rotation speed parameter (Smin) for the currently selected gear.

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	S command no gear selected	SNGE	X1884	X18E4	X1944	X19A4	X1A04	X1A64	X1AC4	X1B24

[Function]

This signal is output when there is no gear to select for the S function (S code) commanded by automatic operation.

[Operation]

This signal turns ON when the S function (S code) is commanded in automatic operation and the S code does not apply to any gear stage set in the parameter (maximum spindle rotation speed).

This signal (SNGE) is output at the same time as the "S function strobe" signal (SF).

[Related signals]

- (1) S function strobe (SF_n: XC64)
- (2) Spindle gear shift (GR1, GR2: X1885, 6)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle gear shift command 1, 2	GR1, 2	X1885, 6	X18E5, 6	X1945, 6	X19A5, 6	X1A05, 6	X1A65, 6	X1AC5, 6	X1B25, 6

[Function]

This signal informs which gear stage in the spindle applies to the S command (S code) issued in the automatic operation (memory, MDI or tape) machining program.

For machines that have gear stage shift, the gear will be shifted on the machine side when this signal is received.

[Operation]

When the S command (S code) is issued in automatic operation, the gear stage of the currently commanded S code is output as a 2-bit (GR1, GR2) code according to the preset parameter (maximum spindle rotation speed).

The following table shows the relationship between the maximum spindle rotation speed parameter (Smax1 to Smax4) and the "Spindle gear shift" signal (GR1, GR2) output.

Gear stage	Maximum spindle rotation speed	Spindle gear shift command		
		GR2	GR1	
1	Smax1	0	0	Range SO to S (Smax1)
2	Smax2	0	1	Range S (Smax1) + 1 to S (Smax2)
3	Smax3	1	0	Range "S (Smax2) + 1 to S (Smax3)"
4	Smax4	1	1	When range over S (Smax3)+1 is specified.

This signal (GR1, GR2) is output simultaneously with the "Spindle function strobe" (SF_n).

Note

- (1) If the commanded S code does not apply to any of the gear stages, the "S command no gear selected" signal (SNGE) is output separately from this signal.

At this time, the output to this signal depends on the settings of Smax1 to Smax4.

- When a spindle speed exceeding Smax4 is commanded while Smax1 up to Smax4 are set: GR2=1, GR1=1
- When a spindle speed exceeding Smax3 is commanded while Smax1 up to Smax3 are set: GR2=1, GR1=0
- When a spindle speed exceeding Smax2 is commanded while Smax1 and Smax2 are set: GR2=0, GR1=1
- When a spindle speed exceeding Smax1 is commanded while only Smax1 is set: GR2=0, GR1=0

[Related signals]

- (1) S function strobe (SF_n: XC64)
- (2) S command no gear selected (SNGE: X1884)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle 2nd in-position	ORAO2	X1888	X18E8	X1948	X19A8	X1A08	X1A68	X1AC8	X1B28



[Function]

This signal informs that the spindle has been positioned within the specified range in accordance with the spindle orientation command. The information is sent earlier than the "Spindle in-position" signal. Since orientation completion can be predicted using this signal, it is possible to eliminate the sequence delay time, etc. for tool changes and other such operations, thereby achieving a shorter tact time.

[Operation]

Orientation is started by the "Spindle orientation command" (ORC), and this signal turns ON when the difference between the orientation position and the feedback position is within the range of the 2nd in-position width.

- The range of in-position can be set by the spindle specification parameter "#3132 ori_inp2".
- The in-position signal is turned OFF when the "Spindle orientation command" (ORC) is turned OFF.

**Note**

- (1) When the spindle orientation command is given, orientation starts regardless of the status of the "Spindle forward run start" (SRN) or "Spindle reverse run start" (SRI).
- (2) This signal is not available when an analog connection is used.
- (3) The spindle is in the servo-locked state during the spindle orientation command. However, if the spindle is rotated by an external force, the in-position signal may turn OFF.

[Related signals]

- (1) Spindle in-position (ORAO: X188E)
- (2) Spindle orientation command (ORC: Y189E)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Current detection	CDO	X1889	X18E9	X1949	X19A9	X1A09	X1A69	X1AC9	X1B29

[Function]

This signal is output from the spindle controller (spindle drive) with high-speed serial coupling specifications, and informs that the load current is about to reach the permissible maximum current. This signal is used to prevent the cutter from biting into the workpiece, for example.

[Operation]

This signal (CDO) turns ON when the motor current is above the threshold (110% output) close to the permissible maximum current (120%).

Note

(1) This signal is valid only for systems that are high-speed serially coupled to the spindle controller.


Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Speed detection	VRO	X188A	X18EA	X194A	X19AA	X1A0A	X1A6A	X1ACA	X1B2A

[Function]

This signal is output from the spindle controller (spindle drive) with high-speed serial coupling specifications and informs that motor speed is dropped below the speed specified by parameter.

[Operation]

This signal (VRO) turns ON when the motor speed (motor rotation speed) falls below the detection level specified by the spindle parameter "#13028 SP028 SDTS" (Speed detection set value).



Note

(1) This signal is valid only for systems that are high-speed serially coupled to the spindle controller.

[Related signals]

(1) Speed detection 2 (SD2: X189D)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	In spindle alarm	FLO	X188B	X18EB	X194B	X19AB	X1A0B	X1A6B	X1ACB	X1B2B

[Function]

This signal is output from the spindle controller (spindle drive) with high-speed serial coupling specifications and informs that some kind of alarm has occurred on the spindle controller.

[Operation]

This signal turns ON when an alarm is detected on the spindle controller side.

To cancel the alarm, reset (reset & rewind) the controller, turn OFF the controller, or turn OFF the spindle controller. The reset method depends on the type of alarm.

Typical examples of alarm are listed below. For details of alarm contents and cancel procedure, refer to the "Instruction Manual" of the spindle drive unit used.

- Overcurrent
- Breaker trip
- Motor overheat

Note

(1) This signal is valid only for systems that are high-speed serially coupled to the spindle controller.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Zero speed	ZSO	X188C	X18EC	X194C	X19AC	X1A0C	X1A6C	X1ACC	X1B2C

[Function]

This signal is output from the spindle controller (spindle drive) with high-speed serial coupling specifications and informs that motor speed has dropped below the set speed threshold.


[Operation]

This signal turns ON when:

- The actual spindle motor speed drops to the speed specified by the spindle parameter "#13027 SP027 ZSP" (Motor zero speed) or less.

This signal turns OFF when:

- The actual spindle motor speed reached the rotation speed which was added 15 (r/min) to the set value of the spindle parameter "#13027 SP027 ZSP" (Motor zero speed), then approximately 200 (ms) has passed.

**Note**

- (1) The signal is output regardless of the rotation direction commanded by the "Spindle forward run start" signal (SRN) or the "Spindle reverse run start" signal (SRI).
- (2) Minimum output pulse width of this signal is approximately 200 (ms).
- (3) Speed at which this signal is output can be set within range from 1 (r/min) to 1000 (r/min) with the spindle parameter "#13027 SP027 ZSP" (Motor zero speed).
- (4) This signal is valid only for systems that are high-speed serially coupled to the spindle controller.

4 Explanation of Interface Signals


4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle up-to-speed	USO	X188D	X18ED	X194D	X19AD	X1A0D	X1A6D	X1ACD	X1B2D

[Function]


This signal is output from the spindle controller (spindle drive) with high-speed serial coupling specifications and informs that the actual rotation speed of the spindle motor has reached the range specified by the parameter "#3105 sut" (standard setting $\pm 15\%$).

This signal is used for the completion condition of S command during automatic operation and for interlocking the control axis.

[Operation]

When a command is issued to change the rotation of the motor from "forward rotation" to "reverse rotation", the spindle motor starts decelerating and the "Spindle up-to-speed" signal (USO) turns OFF.

When the motor speed falls within the specified detection range, the "Spindle up-to-speed" signal turns ON.

**Note**

- (1) The signal cannot be output unless either the "Spindle forward run start" signal (SRN) or the "Spindle reverse run start" signal (SRI) is ON.
- (2) This signal is not output in the case of operation by a command that is not a speed command such as a synchronous tap.
- (3) This signal is valid only for systems that are high-speed serially coupled to the spindle controller.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle in-position	ORAO	X188E	X18EE	X194E	X19AE	X1A0E	X1A6E	X1ACE	X1B2E


[Function]

This signal informs that the spindle has been positioned within the specified range in accordance with the spindle orientation command.

[Operation]

Orientation is started by the "Spindle orientation command" signal (ORC), and this signal turns ON when the positioning of the spindle is completed within the specified range.

- The in-position range is set with the spindle parameter "#13024 SP024 INP".
- The in-position signal is turned OFF when the "Spindle orientation command" (ORC) is turned OFF.

**Note**

- (1) When the "Spindle orientation command" is turned ON, the orientation starts regardless of the status of the "Spindle forward run start" signal (SRN) or the "Spindle reverse run start" signal (SRI).
- (2) This signal is not available when an analog connection is used.
- (3) The spindle is under servo lock condition during the spindle orientation command. However, when the spindle is rotated by an external force, the in-position signal may turn OFF.

[Related signals]

- (1) Spindle 2nd in-position (ORAO2: X1888)
- (2) Spindle orientation command (ORC: Y189E)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	In L coil selection	LCSA	X188F	X18EF	X194F	X19AF	X1A0F	X1A6F	X1ACF	X1B2F

[Function]

This signal indicates that the low-speed coil is being selected in the spindle coil changeover function.

[Operation]

The high-speed coil and low-speed coil are changed over only with the "L coil selection" (LRSL) in the 2-step coil changeover specification. The high-speed coil, middle-speed coil and low-speed coil are changed over with the combination of the "L coil selection" (LRSL) and "M coil selection" (LRSM) in the 3-step coil changeover specification.

<2-step coil changeover>

Selected coil	L coil selection (LRSL)	In L coil selection (LCSA)
High-speed (H)	OFF	OFF
Low-speed (L)	ON	ON

<3-step coil changeover>

Selected coil	L coil selection (LRSL)	M coil selection (LRSM)	In L coil selection (LCSA)	In M coil selection (MCSA)
High-speed (H)	OFF	OFF	OFF	OFF
Middle-speed (M)	OFF	ON	OFF	ON
Low-speed (L)	ON	OFF	ON	OFF
	ON	ON	ON	ON

[Related signals]

- (1) L coil selection (LRSL: Y189F)
- (2) M coil selection (LRSM: Y18A6)
- (3) In M coil selection (MCSA: X189E)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle ready-ON	SMA	X1890	X18F0	X1950	X19B0	X1A10	X1A70	X1AD0	X1B30

[Function]


This signal is a signal output from the spindle controller (spindle drive) with high-speed serial coupling specifications, and informs that the spindle is ready for operation.

[Operation]

This signal (SMA) turns ON when the spindle controller is ready for operation.

The signal turns OFF (ready off) in the following conditions.

- A spindle alarm is detected.
- Ready-on signal (internal signal) from the controller is OFF.



(*1) The ready on signal is output from the controller to the spindle controller.

Note

- (1) This signal is valid only with the system that is high-speed serially coupled to the spindle controller.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle servo-ON	SSA	X1891	X18F1	X1951	X19B1	X1A11	X1A71	X1AD1	X1B31

[Function]


This signal is a signal output from spindle controller (spindle drive) with high-speed serial coupling specifications, and informs that the spindle is in the position control (synchronous tap control, etc.) state.

[Operation]

The "Spindle servo-ON" signal (SSA) turns ON when the spindle is ready (SMA signal is ON), the servo-ON command has been transferred from the controller to the spindle controller, and the spindle controller is in the servo-on state.

Note that this signal turns ON during rotation by the "Spindle forward run start" (SRN) or the "Spindle reverse run start" (SRI) other than during spindle synchronization, and during spindle orientation.

This signal (SSA) turns OFF when the servo-ON command is canceled.



(*1) The spindle servo-ON command is output from the controller to the spindle controller. It is mainly output during synchronous tap control.

Note

- (1) While the "Spindle servo-ON" signal is ON, the "Spindle forward run start" (SRN), "Spindle reverse run start" (SRI), and "Spindle orientation command" (ORC) signals are ignored.
- (2) This signal is valid only for systems that are high-speed serially coupled to the spindle controller.

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	In spindle forward run	SSRN	X1893	X18F3	X1953	X19B3	X1A13	X1A73	X1AD3	X1B33


[Function]

This signal is output from the spindle controller (spindle drive) with high-speed serial coupling specifications and informs that the spindle is rotating in the forward direction.

[Operation]

The "In spindle forward run" signal (SSRN) turns ON when the spindle motor is rotating in the forward direction.

This signal also turns ON if the spindle motor is rotating in the forward direction during orientation or synchronous tap.

**Note**

- (1) The "In spindle forward run" signal (SSRN) turns ON and OFF while the spindle motor is in the stop state with servo rigidity during oriented motion or synchronous tap.
- (2) This signal is valid only for systems that are high-speed serially coupled to the spindle controller.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	In spindle reverse run	SSRI	X1894	X18F4	X1954	X19B4	X1A14	X1A74	X1AD4	X1B34


[Function]

This signal is output from the spindle controller (spindle drive) with high-speed serial coupling specifications and informs that the spindle is rotating in the reverse direction.

[Operation]

The "In spindle reverse run" signal (SSRI) turns ON when the spindle motor rotates in the reverse direction.

This signal also turns ON when the spindle motor is in reverse rotation even during orientation or synchronous tap operation.

**Note**

- (1) The "In spindle reverse run" signal (SSRI) turns ON and OFF while the spindle motor is in the stop state with servo rigidity during oriented motion or synchronous tap.
- (2) This signal is valid only for systems that are high-speed serially coupled to the spindle controller.

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Position loop in-position	SIMP	X1896	X18F6	X1956	X19B6	X1A16	X1A76	X1AD6	X1B36

[Function]

When the connection with the spindle controller is high-speed serial, this signal informs that the spindle is in the in-position state during synchronous tap control.


[Operation]

This signal turns ON when:

- The droop amount (servo tracking delay error) is within the in-position range during synchronous tap control (servo ON).
- Synchronous tap control is not commanded. ((A) in the figure below)

This signal turns OFF when:

- The droop amount (servo tracking delay error) has exceeded the in-position range during synchronous tap control (servo ON).



4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	In spindle torque limit	STLQ	X1897	X18F7	X1957	X19B7	X1A17	X1A77	X1AD7	X1B37

[Function]

This signal is output from the spindle controller (spindle drive) with high-speed serial coupling specifications and informs that the spindle is under torque control.

[Operation]

This signal turns ON when:

- ♦ The "Spindle torque limit 1" (TL1) or the "Spindle torque limit 2" signal (TL2) is ON.

This signal turns OFF when:

- ♦ The "Spindle torque limit 1" (TL1) and the "Spindle torque limit 2" signal (TL2) is OFF.

Note

- (1) This signal is valid only for systems that are high-speed serially coupled to the spindle controller.

[Related signals]

- (1) Spindle torque limit 1 (TL1: Y189A)
- (2) Spindle torque limit 2 (TL2: Y189B)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle torque limit reached		X189A	X18FA	X195A	X19BA	X1A1A	X1A7A	X1ADA	X1B3A

[Function]

This signal informs that the actual torque has reached the limit on the torque limit target spindle.

[Operation]

This signal turns ON when:

- ♦ The actual torque has reached the limit on the torque limit target spindle.

This signal turns OFF when:

- ♦ The actual torque of the torque limit target spindle is under its limit.

[Related signals]

- (1) In spindle torque limit (STLQ: X1897)
- (2) Spindle torque limit 1 (TL1: Y189A)
- (3) Spindle torque limit 2 (TL2: Y189B)


Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Speed detection 2	SD2	X189D	X18FD	X195D	X19BD	X1A1D	X1A7D	X1ADD	X1B3D

[Function]

This signal is output from the spindle controller (spindle drive) with high-speed serial coupling specifications and informs that motor speed is dropped below the speed specified by the parameter.

[Operation]

This signal (SD2) turns ON if the motor speed (motor rotation speed) drops the detection threshold specified by the parameter "#13030 SP030".

**Note**

- (1) This signal is valid only for systems that are high-speed serially coupled to the spindle controller.

[Related signals]

- (1) Speed detection (VRO: X188A)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	In M coil selection	MCSA	X189E	X18FE	X195E	X19BE	X1A1E	X1A7E	X1ADE	X1B3E

[Function]

This signal indicates that the middle-speed coil is being selected in the 3-step coil changeover specification of the spindle coil changeover function.

[Operation]

The state of the selected coil is output in combination with the "In L coil selection" (LCSA).

Selected coil	L coil selection (LRSL)	M coil selection (LRSM)	In L coil selection (LCSA)	In M coil selection (MCSA)
High-speed (H)	OFF	OFF	OFF	OFF
Middle-speed (M)	OFF	ON	OFF	ON
Low-speed (L)	ON	OFF	ON	OFF
	ON	ON	ON	ON

[Related signals]

- (1) L coil selection (LRSL: Y189F)
- (2) M coil selection (LRSM: Y18A6)
- (3) In L coil selection (LCSA: X188F)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Index positioning completion		X189F	X18FF	X195F	X19BF	X1A1F	X1A7F	X1ADF	X1B3F

[Function]


This signal informs that positioning for the spindle forward run and reverse run indexing functions has been completed.

[Operation]

When the "Spindle forward run index" signal (WRN: Y189C) or the "Spindle reverse run index" signal (WRI: Y189D) is turned ON, this signal turns OFF.

For the turret indexing, when the time set by the parameter "#3126 tret_fin_off" (Index positioning complete signal OFF time) has passed after the "Spindle forward run index" signal (WRN: Y189C) or the "Spindle reverse run index" signal (WRI: Y189D) is turned ON, this signal turns ON. Even when the indexing movement is completed, this signal will not turn ON until the time set in the parameter #3126 has elapsed.

To use this signal, program the sequence so that the signal is referenced after the time set in the parameter #3126 has elapsed.



(*1) For the turret indexing, this signal turns ON when the time set to the parameter #3126 has passed.

[Related signals]

- (1) Spindle orientation command (ORC: Y189E)
- (2) Spindle forward run index (WRN: Y189C)
- (3) Spindle reverse run index (WRI: Y189D)
- (4) Multi-point orientation position data (R7009)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle enable	ENB	X18A0	X1900	X1960	X19C0	X1A20	X1A80	X1AE0	X1B40

[Function]

This signal informs whether there are command outputs to the spindle or not.

0: No command output to spindle

1: With command output to spindle

[Related signals]

- (1) Spindle selection (SWS: Y18A8)
- (2) Spindle command selection (SLSP: R7002)
- (3) Spindle stop (SSTP: Y1894)
- (4) Encoder selection (R2567)
- (5) Spindle forward run start (SRN: Y1898)
- (6) Spindle reverse run start (SRI: Y1899)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	In spindle synchronization	SPSYN1	X18A8	X1908	X1968	X19C8	X1A28	X1A88	X1AE8	X1B48

[Function]

This signal informs that the spindle synchronous control mode has been entered.

[Operation]

The signal turns ON when:

- ♦ The G114.1 is commanded and spindle synchronous control is entered. (Spindle synchronization control I)
- ♦ The spindle synchronous control signal (SPSY) turns ON. (Spindle synchronization control II)

The signal turns OFF when:

- ♦ Spindle synchronous control is canceled with the G113 command. Or, when the "Spindle synchronization cancel" signal (SPSYC) turns ON. (Spindle synchronization control I)
- ♦ When the "Spindle synchronous control" signal (SPSY) turns OFF. (Spindle synchronization control II)

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Use the synchronized spindle's signal when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) Spindle rotation speed synchronization completion (FSRPRV: X18A9)
- (2) Spindle phase synchronization completion (FSPPH: X18AA)
- (3) Spindle synchronization (SPSY: Y18B0)
- (4) Spindle phase synchronization (SPPHS: Y18B1)
- (5) Spindle synchronization cancel (SPSYC: Y18B8)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle rotation speed synchronization completion	FSPRV	X18A9	X1909	X1969	X19C9	X1A29	X1A89	X1AE9	X1B49

[Function]

This signal informs that the spindle synchronization state mode is entered.

Note

- (1) This signal uses the 1st spindle signal regardless of the hob spindle's number.

[Operation]

This signal turns ON when:

- The speeds of both the synchronization reference spindle and synchronized spindle reach the commanded synchronization rotation speed during the rotation synchronization mode. (Spindle synchronization I)
- The workpiece axis rotation speed reaches the value set for the spindle synchronization rotation speed attainment level corresponding to the workpiece axis and rotary tool axis rotation ratio command in spindle synchronization (without R command) mode. (Polygon)
- The workpiece axis rotation speed completes phase alignment at the rotation speed corresponding to the rotation ratio command for the workpiece axis and rotary tool axis in spindle synchronization (with R command) mode. (Polygon)
- The CNC is reset (any of Reset1, Reset2, or Reset & rewind) with the parameter "#1239 bit3" set to "1". (Polygon)

This signal turns OFF when:

- The actual rotation speed of the reference spindle or synchronized spindle, in respect to the spindle synchronous rotation speed command value, widely exceeds or deviates value set for the spindle synchronization rotation speed attainment level during the rotation synchronization mode.
- The spindle synchronous control mode is canceled.

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the signal of the hob axis during hobbing, or refer to the signal of the synchronized spindle during other machining when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) In spindle synchronization (SPSYN1: X18A8)
- (2) Spindle phase synchronization completion (FSPPH: X18AA)
- (3) Spindle synchronization (SPSY: Y18B0)
- (4) Spindle phase synchronization (SPPHS: Y18B1)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle phase synchronization completion	FSPPH	X18AA	X190A	X196A	X19CA	X1A2A	X1A8A	X1AEA	X1B4A

[Function]

This signal informs that the spindle synchronization state mode is entered.


[Operation]

This signal turns ON when:

- ♦ The phase alignment of the reference spindle and synchronized spindle is completed during the phase synchronization mode.

This signal turns OFF when:

- ♦ The phase difference of the reference spindle and synchronized spindle exceeds the value set for the spindle synchronization phase attainment level during the phase synchronization mode.
- ♦ The spindle synchronous control mode is canceled.



(*1) Temporarily turns OFF to change the rotation speed during the phase synchronization.

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Use the synchronized spindle's signal when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) In spindle synchronization (SPSYN1: X18A8)
- (2) Spindle rotation speed synchronization completion (FSPRV: X18A9)
- (3) Spindle synchronization (SPSY: Y18B0)
- (4) Spindle phase synchronization (SPPHS: Y18B1)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	In spindle synchronization 2	SPSYN2	X18AB	X190B	X196B	X19CB	X1A2B	X1A8B	X1AEB	X1B4B

[Function]

This signal informs that the spindle-spindle polygon machining mode is being executed.

[Operation]

This signal turns ON when:

- G114.2 is commanded, and the spindle-spindle polygon machining is started.

This signal turns OFF when:

- G113/G113.1 is commanded, and the spindle-spindle polygon machining is canceled.
- When the spindle synchronization cancel signal (SPSYC) is input, and spindle-spindle polygon machining is canceled.

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the synchronized spindle's signal when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) Spindle synchronization cancel (SPSYC: Y18B8)
- (2) Spindle rotation speed synchronization completion (FSPRV: X18A9)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Chuck close confirmation	SPCMP	X18AC	X190C	X196C	X19CC	X1A2C	X1A8C	X1AEC	X1B4C

[Function]


This signal informs that the "Chuck close" (SPCMPC) is input during the spindle synchronous control.

[Operation]

This signal turns ON when the "Chuck close" (SPCMPC) is ON.

This signal turns OFF when the "Chuck close" (SPCMPC) is OFF.

This signal turns OFF when the spindle synchronous control is canceled.

**Note**

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the synchronized spindle's signal when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".
- (3) Use the "Error temporary cancel" signal only when the synchronization error between two spindles still occurs even after the "Chuck close" signal is turned ON.

[Related signals]

- (1) Chuck close (SPCMPC: Y18B9)
- (2) In spindle synchronization (SPSYN1: X18A8)
- (3) Spindle rotation speed synchronization completion (FSPRV: X18A9)
- (4) Spindle synchronization (SPSY: Y18B0)
- (5) Error temporary cancel (SPDRPO: Y18B5)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	In tool spindle synchronization I (Polygon)	TSS1	X18AD	X190D	X196D	X19CD	X1A2D	X1A8D	X1AED	X1B4D

[Function]

This signal informs that the tool spindle synchronization I (polygon) mode has been entered.

[Operation]

This signal is turned ON when:

- The G114.2 is commanded, and the tool spindle synchronization I is entered.

This signal turns OFF when:

- The tool spindle synchronization I is canceled with the G113/G113.1 command.
- The tool spindle synchronization I is canceled with the "Spindle synchronization/superimposition cancel" signal (SPSYC).

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the synchronized spindle's signal when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) Spindle rotation speed synchronization completion (FSRV: X18A9)
- (2) Spindle synchronization/superimposition cancel (SPSYC: Y18B8)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	In tool spindle synchronization II	SPSYN3	X18AE	X190E	X196E	X19CE	X1A2E	X1A8E	X1AEE	X1B4E

[Function]

This signal informs that the tool spindle synchronization II (hob machining) is being executed.

Note

- (1) This signal uses the 1st spindle signal regardless of the hob spindle's number.

[Operation]

This signal is turned ON when:

- Tool spindle synchronization II (hob machining) is started with a G114.3 command.

This signal turns OFF when:

- Spindle synchronous control is canceled with a G113/G113.1 command, or when the "Spindle synchronization cancel" signal (SPSYC) turns ON.

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the signal of the hob axis when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".
- (3) For the G code system 6 and 7, substitute G114.3 with G81.4 and G113/G113.1 with G80.4/G113.1.

[Related signals]

- (1) Spindle synchronization/superimposition cancel (SPSYC: Y18B8)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle superimposition control: Speed change disabled	SPNCH	X18AF	X190F	X196F	X19CF	X1A2F	X1A8F	X1AEF	X1B4F

[Function]

This signal indicates that the spindle rotation speed command is invalid in the following situation: the spindle rotation speed is commanded to the reference spindle while a tapping or synchronized tapping cycle is executed for the superimposed spindle in the spindle superimposition control.

[Operation]

This signal turns ON when:

- ♦ The spindle rotation speed is commanded to the reference spindle while a tapping or synchronized tapping cycle is executed for the superimposed spindle in the spindle superimposition control mode.

This signal turns OFF when:

- ♦ A tapping or synchronized tapping cycle for the superimposed spindle in the spindle superimposition control is completed, and commands to the reference spindle become valid.
- ♦ The spindle superimposition mode is canceled.

Refer to the signal of the superimposed spindle.

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the signal of the superimposed spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) Spindle synchronization/superimposition cancel (SPSYC: Y18B8)
- (2) Spindle superimposition control ON (SPILE: X18B1)
- (3) Spindle rotation speed synchronization completion (FSPRV: X18A9)
- (4) Spindle superimposition control: Spindle superimposition clamped (SPLCR: X18B2)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle synchronization: Phase error over	SPPHOV	X18B0	X1910	X1970	X19D0	X1A30	X1A90	X1AF0	X1B50

[Function]

This signal informs that, after the phase alignment is completed under the absolute position spindle synchronization, the spindle synchronization phase error between the reference and synchronized spindles (R6516) is greater than the spindle synchronization phase error tolerance (R7019).

[Operation]

This signal turns ON when:

- When the phase error between the reference and synchronized spindles with respect to the position command has exceeded the spindle synchronization phase error tolerance (R7019) after the phase alignment under the absolute position spindle synchronization.

This signal turns OFF when:

- The spindle synchronization control I mode is cancelled.

Note

- (1) Refer to the 1st spindle's signal when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the synchronized spindle's signal when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) Chuck close (SPCMPC: Y18B9)
- (2) In spindle synchronization (SPSYN1: X18A8)
- (3) Spindle rotation speed synchronization completion (FSPRV: X18A9)
- (4) Spindle phase synchronization completion (FSPPH: X18AA)
- (5) Spindle synchronization: Phase error/Hob axis delay angle (R6516)
- (6) Spindle synchronization: Maximum phase error/Maximum hob axis delay angle (R6517)
- (7) Error temporary cancel (SPDRPO: Y18B5)
- (8) Spindle synchronization phase error tolerance (R7019)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle superimposition control ON	SPILE	X18B1	X1911	X1971	X19D1	X1A31	X1A91	X1AF1	X1B51

[Function]

This signal indicates that the spindle superimposition control mode has been entered.

[Operation]

The signal turns ON when:

- The G164 is commanded, and the spindle superimposition control mode is entered.

This signal turns OFF when:

- The spindle superimposition control is canceled with the G113 command.
- The spindle superimposition control is canceled with the "Spindle synchronization/superimposition cancel" signal (SPSYC).

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the signal of the superimposed spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) Spindle superimposition control: Speed change disabled (SPNCH: X18AF)
- (2) Spindle synchronization/superimposition cancel (SPSYC: Y18B8)
- (3) Spindle rotation speed synchronization completion (FSPRV: X18A9)
- (4) Spindle superimposition control: Spindle superimposition clamped (SPLCR: X18B2)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle superimposition control: Spindle superimposition clamped	SPLCR	X18B2	X1912	X1972	X19D2	X1A32	X1A92	X1AF2	X1B52

[Function]

This signal indicates that the following matters occurred during the spindle superimposition control:

- The reference spindle was clamped at the maximum rotation speed of the superimposed spindle
- The superimposed spindle was clamped during superimposition

(This means that the sum of the command rotation speeds determined based on the rotation direction of the reference spindle and superimposed spindles has exceeded the maximum rotation speed of the superimposed spindle.)

[Operation]

This signal turns ON when:

- The reference spindle was clamped at the maximum rotation speed of the superimposed spindle during the spindle superimposition control.
- The superimposed spindle was clamped during superimposition (the sum of the command rotation speeds determined based on the rotation direction of the reference and superimposed spindles has exceeded the maximum rotation speed of the superimposed spindle).

This signal turns OFF when:

- The rotation speed of the reference spindle falls below the maximum rotation speed of the superimposed spindle during the spindle superimposition control.
- The rotation speed of the superimposed spindle falls below the maximum rotation speed of the superimposed spindle during the spindle superimposition control.
- The spindle superimposition control mode is canceled.

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the signal of the superimposed spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) Spindle superimposition control: Speed change disabled (SPNCH: X18AF)
- (2) Spindle synchronization/superimposition cancel (SPSYC: Y18B8)
- (3) Spindle superimposition control ON (SPILE: X18B1)
- (4) Spindle rotation speed synchronization completion (FSPRV: X18A9)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Hob axis delay excess	PHOVR	X18B3	X1913	X1973	X19D3	X1A33	X1A93	X1AF3	X1B53

[Function]

This signal informs that after the spindle rotation speed synchronization is completed in the tool spindle synchronization II (Hobbing), the hob axis tracking delay between the actual position and the commanded position has exceeded the allowable delay angle.

Note

- (1) This signal uses the 1st spindle signal regardless of the hob spindle's number.

[Operation]

This signal turns ON when:


- The spindle rotation speed synchronization has been completed and the maximum delay angle of the hob axis (spindle) exceeded the delay allowable angle set in the parameter "#3133 spherr".

This signal turns OFF when:

- The tool spindle synchronization II is canceled.

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the signal of the hob axis when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Timing chart]**[Related signals]**

- (1) In tool spindle synchronization II (SPSYN3: X18AE)
- (2) Spindle rotation speed synchronization completion (FSPRV: X18A9)
- (3) Spindle synchronization Maximum phase error/Maximum hob axis delay angle (R6517)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Holding power of spindle increased	EXOFN	X18B5	X1915	X1975	X19D5	X1A35	X1A95	X1AF5	X1B55

[Function]

The increase holding power of spindle (disturbance observer) state is output to this signal.

[Operation]

This signal turns ON when the "Increase holding power of spindle" signal (EXOBS) turns ON and the spindle drive unit enables the disturbance observer.

Turning OFF the "Increase holding power of spindle" signal (EXOBS) turns this signal OFF.

[Related signals]

- (1) Increase holding power of spindle (EXOBS: Y1893)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	In spindle off	SPOFFA	X18B6	X1916	X1976	X19D6	X1A36	X1A96	X1AF6	X1B56

[Function]

The signal communicates that the spindle is being excluded from CNC control.

[Operation]

This signal turns ON when the spindle is excluded from CNC control by the "Exclude spindle" signal (SPOFF).

Any command to the spindle for which this signal is ON is invalid.

[Related signals]

- (1) Spindle off request (SPOFF: Y18BF)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)


Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle speed fluctuation detection: Spindle speed out of setting range	SSRD	X18B7	X1917	X1977	X19D7	X1A37	X1A97	X1AF7	X1B57

[Function]

This signal indicates that the spindle speed fluctuation detection function has detected a fluctuation in the actual spindle speed.

[Operation]

This signal is turned ON when the actual spindle speed exceeds the tolerance for the spindle speed command set with the Spindle speed fluctuation detection command (G162) or the parameter.



This signal is turned OFF when:

- The detection is canceled with the Spindle speed fluctuation detection cancel command (G163).
- The actual spindle speed returns back within the tolerance range.
- There is a change in the spindle command speed (including the spindle override and speed change for each function).
- There is a change in the spindle state (forward run, reverse run or stop).
- The reset is input.
- The emergency stop occurs.
- The spindle is in the C axis mode of spindle synchronous tapping, spindle orientation or spindle position control.

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

[Related signals]

- (1) Spindle stop (SSTP: Y1894)
- (2) Spindle forward run start (SRN: Y1898)
- (3) Spindle reverse run start (SRI: Y1899)
- (4) Spindle selection (SWS: Y18A8)
- (5) Spindle command final data (rotation speed) (R6502)
- (6) Spindle command selection (SLSP: R7002)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle position control (Spindle/C axis control): C axis mode ON	SVMD	X18C1	X1921	X1981	X19E1	X1A41	X1AA1	X1B01	X1B61

[Function]


This signal indicates that the mode is the C axis mode or spindle mode when the program command method ("#3129 cax_spec/bit0" is set to "1") is selected for the spindle in the spindle position control.

[Operation]

This signal is turned ON when a change to C-axis mode is commanded and remains ON until a change to the spindle mode is commanded. This signal indicates that a mode change command has been executed.

Note

- (1) The "Spindle position control (Spindle/C axis control): C axis mode ON" signal (SVMD) does not turn ON when the mode was changed with the "Servo OFF" signal (*SVFn) or the "Spindle position control (Spindle/C axis control): C axis selection" signal (CMOD).



4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle gear selection output 1, 2	GO1, 2	X18C2, 3	X1922, 3	X1982, 3	X19E2, 3	X1A42, 3	X1AA2, 3	X1B02, 3	X1B62, 3

[Function]


This signal informs which gear stage the spindle gear is at.

[Operation]

The gear stage of the spindle gear is output with a 2-bit (GO1, GO2) code.

While the "Spindle gear selection code" signal (GI1, GI2) and the "Spindle gear selection output" signal (GO1, GO2) are different during gear shift, it indicates that the gear shift operation is in progress.

When gear shift is completed, the gear stage of the "Spindle gear selection output" signal (GO1, GO2) changes, and it becomes the same as the "Spindle gear selection code" signal (GI1, GI2).



The following table shows the relationship between the gear stage and the "Spindle gear selection output" signal (GO1, GO2).

Gear stage	Spindle gear selection output	
	GO1	GO2
1	0	0
2	1	0
3	0	1
4	1	1

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle oscillation in progress		X18C8	X1928	X1988	X19E8	X1A48	X1AA8	X1B08	X1B68

[Function]

This signal informs that the spindle oscillation is in operation.

[Operation]

This signal turns ON when the spindle oscillation is started.

This signal turns OFF when the spindle oscillation is stopped.

[Related signals]

- (1) Spindle oscillation command (Y18C8)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle protection: Mode in progress	SPRTCT	X18C9	X1929	X1989	X19E9	X1A49	X1AA9	X1B09	X1B69

[Function]

This signal notifies that the acceleration/deceleration time constant of the spindle motor has changed for protection because of detecting overheat of the spindle motor.


[Operation]

This signal turns ON when the spindle starts rotating from speed zero with the motor already being overheated. The overheated state refers to the range of the spindle temperature from which is at or above the spindle protection start temperature (#43084) until which drops below the spindle protection cancel temperature (#43085). If the motor temperature reaches the spindle protection start temperature (#43084) during rotation of the spindle, this signal will not turn ON.

This signal turns OFF when the spindle rotation speed is "0".

<Status of the "Spindle protection: Mode in progress" signal when the spindle starts to rotate in an overheated state>

When the spindle temperature is at or above the spindle protection start temperature (#43084) at the start of rotation




4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

When the spindle rotation is started after its temperature has reached the spindle protection start temperature (#43084) but before it drops below the spindle protection cancel temperature (#43085), the acceleration/deceleration time constant during spindle protection is applied and this signal is turned ON.

<Status of the "Spindle protection: Mode in progress" signal when the spindle starts to rotate in an overheated state>

When the spindle temperature is lower than the spindle protection start temperature (#43084) at the start of rotation



4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Real-time tuning 1: Speed control gain changeover hold-down ON	VGHLD	X18CA	X192A	X198A	X19EA	X1A4A	X1AAA	X1B0A	X1B6A

[Function]


This signal indicates that speed control gain switching is currently stopped in the real-time tuning 1 function.

[Operation]

This signal indicates that speed control gain switching is stopped and the value of speed control gain is retained.

This signal is output when the "Speed control gain changeover hold-down command" is ON or when the cutting command modal is effective, regardless of whether this function is enabled or disabled.

This signal is not output when speed control gain switching is performed. Also, the signal is not output when the additional specification of real-time tuning 1 is set to OFF.

**[Related signals]**

- (1) Real-time tuning 1: Speed control gain changeover hold-down command (VGHLD: Y18CA)

Cont.	Signal name	Abbrev.	Common (\$)
A	Laser: Height control in progress		X1CA0

[Function]

This signal indicates that the height control is in progress.

[Operation]

This signal turns ON when:

- The "Laser: Height control" signal (Y1CD8) is turned ON, and approach control is started.

This signal turns OFF when the height control is canceled in any of the following cases:

- The "Laser: Height control" signal (Y1CD8) is turned OFF.
- A reset or emergency stop, etc. is performed.

When a retract control is to be made, turn this signal OFF after the retract is completed.

[Related signals]

- (1) Laser: Height control (Y1CD8)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Laser: Approach in height control completed		X1CA1

[Function]

When the target axis of the height control reaches the in-position width for the target height, this signal turns ON.

When the approach is completed, trace control is performed.

[Operation]

This signal turns ON when:

- The target axis of the height control reaches the target height after the "Laser: Height control" signal (Y1CD8) is turned ON and approach control is started.

This signal turns OFF in any of the following cases:

- The "Laser: Height control" signal (Y1CD8) is turned OFF.
- The "Laser: Enable height retention in height control" signal (Y1CD9) is turned OFF.
- The nozzle height or the sensor offset is changed.

[Related signals]

- (1) Laser: Height control (Y1CD8)
- (2) Laser: Height control in progress (X1CA0)

Cont.	Signal name	Abbrev.	Common (\$)
A	Laser: Height being retained in height control		X1CA2

[Function]

This signal indicates that the height retention control is in progress.

[Operation]

This signal turns ON when:

- The "Laser: Enable height retention in height control" signal (Y1CD9) is turned ON while the "Laser: Approach in height control completed" signal (X1CA1) is ON.

This signal turns OFF when:

- The "Laser: Enable height retention in height control" signal (Y1CD9) is turned OFF.
- The "Laser: Height control" signal (Y1CD8) is turned OFF and the height control is canceled.
- A reset or emergency stop, etc. is performed and the height control is canceled.

[Related signals]

- (1) Laser: Height control (Y1CD8)
- (2) Laser: Enable height retention in height control (Y1CD9)
- (3) Laser: Approach in height control completed (X1CA1)

Cont.	Signal name	Abbrev.	Common (\$)
A	Laser: Laser condition change strobe		X1CA6

[Function] [Operation]

When the current machining condition is changed on the "Laser Processing Condition" screen or the "Set Laser Process Cond." screen, this signal turns ON.

When the "Laser: Laser beam irradiation ON" signal (Y1CA7) is turned ON, the operation error (M95 9508) occurs, and laser is not irradiated. When the "Laser: Laser condition change complete" signal (Y1CA6) is turned ON, this error is canceled, and laser can be irradiated.

[Related signals]

- (1) Laser: Laser condition change complete (Y1CA6)

Cont.	Signal name	Abbrev.	Common (\$)
A	Laser: Laser beam irradiating		X1CA7

[Function] [Operation]

This signal indicates that laser is being irradiated from a laser oscillator.

When the "Laser: Laser beam irradiation ON" signal (Y1CA7) is turned ON while the "Laser: Laser beam irradiation ready" signal (Y1CE0) is ON, or when M code set in the parameter "#90023 Isr_M_beam_on" is commanded, this signal turns ON.

[Related signals]

- (1) Laser: Laser beam irradiation ready (Y1CE0)
- (2) Laser: Laser beam irradiation ON (Y1CA7)

4 Explanation of Interface Signals

4.1 PLC Input Signals (Bit Type: X***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Handy terminal key 1 to 45		X1CD0 to FC

[Function] [Operation]

This signal indicates the status of handy terminal key 1 to 45.

[Related signals]

- (1) Handle pulse encoder communication connector priority (Y70D)
- (2) Handle/Incremental feed magnification code m (MP1, MP2, MP4: YC80, YC81, YC82)
- (3) Handle/incremental feed magnification method selection (MPS: YC87)
- (4) Handy terminal Data area top address (R297)
- (5) Handy terminal Data valid number of registers (R298)
- (6) Handy terminal Cause of communication error (R299)
- (7) 1st handle/incremental feed magnification (R2508, 9)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Position switch 1 to 24	PSW1 to 24	X1D00 to 17	X1D20 to 37	X1D40 to 57	X1D60 to 77	X1D80 to 97	X1DA0 to B7	X1DC0 to D7	X1DE0 to F7

[Function]

This signal notifies that the machine position is within the area set by the parameters.

[Operation]

This signal turns ON when the machine position of the control axis reaches the range set by the parameters, and turns OFF when it goes out of the range. The axis name and range are set in parameters #7501 to #7734.

Whether this signal is valid or invalid depends on absolute position detection and incremental detection as follows.


<For absolute position detection system>

This signal is valid when the power is turned ON after zero point initialization is completed.

<For incremental position detection system>

This signal is not enabled until the first reference position return is completed after the power is turned ON. (All PSW1 to PSW24 remain OFF until this signal is enabled.)

Example of signal output



The setting range of the position switch uses the basic machine coordinate system as a reference.

Regardless of the size of the setting values of dog1 and dog2, the position switch signal is turned ON when the axis moves between dog1 and dog2. When dog1 and dog2 are set to the same value, the signal turns ON at the position.

Note that the change in the output signal is slightly delayed from the actual machine position. This maximum delay time (tmax), which depends on the area check method parameters #7504 to #7734, is as follows. Also, consider the delay due to the scan time as it depends on the scan time of the ladder.

When parameter is set to "0" (commanded machine position)	When parameter is set to "1" (encoder FB position)
tmax = 0.004 - TP [s] TP : Position loop time constant ($\frac{1}{\text{PGN}}$ [s]) PGN : Position loop gain	tmax = 0.004 [s]

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Analog input m	AI _n	R0 to 7

[Function]


When an analog voltage is input to the designated connector on the remote I/O unit or built-in AI/AO, which has the analog input function, the corresponding data can be read into the specified file register.

[Operation]

The following shows the interfaces.

Channel	File register	Data update cycle
AI0	R0	<Remote I/O unit with the analog input function> One channel is input per PC high-speed cycle. If one station has four channels, the four channels are input in four PC high-speed cycle times.
AI1	R1	
AI2	R2	
AI3	R3	
AI4	R4	<Built-in AI/AO> All channels are input per PC high-speed cycle. All analog input of four channels are input in one PC high-speed cycle time.
AI5	R5	
AI6	R6	
AI7	R7	

<How input voltages are read into the file registers>



Cont.	Signal name	Abbrev.	Common (\$)
A	Key in 1		R8

[Function]

Operator's key operation can be monitored on the user PLC side.

[Operation]

While operator is using the keyboard, the data corresponding to the key is set to "Key in 1".

[Related signals]

(1) Key out 1 (R212)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Clock data Year/Month		R11
A	Clock data Date/Hour		R12
A	Clock data Minute/Second		R13

[Function]

The year, month, date, hour, minute, second and millisecond data is informed by the controller to the PLC as the current clock information.

[Operation]

The date and time data is output as shown below. The data is output as binary data.

R11	Month	Year
R12	Hour	Date
R13	Second	Minute

(Example) For October 26, 2002, 14:56:36.

R11 ... 0 0 0 0 1 0 1 0 0 0 0 0 0 0 1 0 = 0A02H
 October 2002

R12 ... 0 0 0 0 1 1 1 0 0 0 0 1 1 0 1 0 = 0E1AH
 14 hundred hours 26th day

R13 ... 0 0 1 0 0 1 0 0 0 0 1 1 1 0 0 0 = 2438H
 36 seconds 56 minutes

Note

- (1) The time is displayed with the 24-hour system.
- (2) The data and time are set with the [TIME] screen on the setting and display unit.

Cont.	Signal name	Abbrev.	Common (\$)
A	CNC software version code		R16 to 9

[Function]

This indicates the CNC software version.

[Operation]

The version displayed at "MP" on the [Software Directory] screen is indicated.

Software list	
NCMAIN1	:BND-2051W000-A0B
NCMAIN2	:

The file registers R16 to R19 are set to the following data.

(Example) BND-2051W000-A0B

(1) (2) (3)

Item	File register	Type	Example
(1) Model function No.	R19	Binary	0803H = 2051 (decimal)
(2) Serial No.	R18	Binary	0000H = 000
(3) Version	bits F to 8 of R17	ASCII code	41H ("A")
	bits 7 to 0 of R17	ASCII code	30H ("0")
	bits F to 8 of R16	ASCII code(*1)	42H ("B")
-	bits 7 to 0 of R16	Always 20H	(Blank)

(*1) If the version is a 2-digit number, bits F to 8 of R16 are set to "20H".

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Battery drop cause		R56

[Function]

This signal provides information about under voltage.

[Operation]

The voltage in the battery voltage that is supplied to the control equipment (NC controller or graphic control unit) for saving data is monitored, and the status battery is indicated for each control unit.

- When the voltage is above the battery warning detection threshold, this signal is "0".

<Note>

When the detection of battery alarm or battery warning is disabled ("#6449/bit4" is "1", this signal is always "0".

- When the voltage is above the battery alarm detection threshold and below the battery warning detection threshold, this signal is "1".
- For the encoder errors, this signal is "2".
- When the voltage is below the battery alarm detection threshold, this signal is "3".

	F	8	7	4	3	0
R56	Not used			Graphic control unit		NC control unit

[Related signals]

- (1) Battery warning (BATWR: X70E)
- (2) Battery alarm (BATAL: X70F)

Cont.	Signal name	Abbrev.	Common (\$)
A	Temperature warning cause		R57/bit0

[Function]

If the internal temperature of the control unit exceeds a certain level, the overheat will be detected, and the following states will occur.

- The "Temperature rise" (SM16) is turned ON.
- The "Temperature warning cause" (R57/bit0) is turned ON.
- The alarm message (Z53) is displayed on the screen.

If the machine is in automatic operation, the operation will be continued, but restarting will not be possible after resetting or stopping with M02/M30. (Starting will be possible after block stop or feed hold.)

[Operation]**<Conditions for turning ON the "Temperature warning cause">**

The internal temperature of the control unit rise above the temperature at which the alarm occurs (Alarm temperature).
(This temperature depends on the model.)


Model	Alarm temperature
M800VW Series	98.0 °C
M800VS Series	84.5 °C
M80V Series	84.5 °C
M80VW Series	102.0 °C

<Conditions for turning OFF the "Temperature warning cause">

The internal temperature of the control unit has dropped by 2.0 °C or more from the above-described temperature at which the alarm occurs.

(Example) For the M800VW Series, this signal turns ON when the temperature of the control unit exceeds 98.0 °C and turns OFF when the temperature drops to 96 °C or lower.


The "Temperature warning cause" is a bit unit signal.



4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

<Operation example>



[Related signals]

- (1) Temperature rise (SM16)
- (2) Control unit temperature (R60)

Cont.	Signal name	Abbrev.	Common (\$)
A	Control unit temperature		R60

[Function]

This signal indicates the temperature in the control unit.

[Operation]

This signal indicates the temperature in the control unit. The unit is "°C".

[Related signals]

- (1) Temperature rise (SM16)
- (2) Temperature warning cause (R57)

Cont.	Signal name	Abbrev.	Common (\$)
A	PLC main scan time		R68

[Function]

Time taken for scanning in user PLC can be monitored.

[Operation]

Scanning time for user PLC main processing is continuously updated and set.

<File register contents and time calculation>

File register	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
---------------	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

Time calculation

$$\frac{\text{Data}}{256} \times 3.5 (\text{ms})$$

(Example)

F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	1	1	0	1	0	0	0	0

$$\frac{\text{Data}=208}{256} \times 3.5 (\text{ms})$$

Note

- (1) For this data, mean scanning time is approximately 0.9 sec.
- (2) I/O processing time for PLC control software (PLC BASIC) is included in this data processing time.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R^{***})

Cont.	Signal name	Abbrev.	Common (\$)
A	Emergency stop cause		R69

[Function]

The causes of emergency stop are shown with bit correspondence.

[Operation]

The cause of the emergency stop state is shown as follows with bit correspondence.

If there are multiple causes, the multiple bits corresponding to each cause are output.

The bit of this signal that is set to "0" is the emergency stop cause.

File register
(R)

F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0	← Bit
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	-------

SRV	Servo drive unit emergency stop output
SPIN	Spindle drive unit emergency stop output
PARA	Door interlock, dog/OT arbitrary allocation device illegal
PC-H	PLC high-speed processing error
LAD	User PLC Illegal codes exist.
	LINE
MCT	Contactor shutoff test
PLC	Built-in PLC Software emergency stop output device YC2C is "1".
CVIN	Power supply external emergency stop state
EXIN	Control unit EMG connector Emergency stop state
LINK	External PLC Communication error
WAIT	External PLC Not ready
XTEN	External PLC Communication error
STOP	Built-in PLC Stop state

← EMG Emergency stop ○○○○

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	DIO card information		R70

[Function]

The remote I/O unit connected to the controller can be found with the user PLC.


The user PLC finds the connection state of the remote I/O unit with this data.

[Operation]

- When remote I/O unit is connected, "1" is set, and when it is not connected, "0" is set. Note that, for the remote I/O units DX230, DX231 and DX654, two stations are occupied for one unit, and for DX651, three stations are occupied for one unit. Therefore, when one unit is connected, the corresponding two or three bits are set to "1".

<Note>

Only information from the 1st to 8th stations is output to R70. (Information about 9th and following stations is not output.)



- Number of occupied stations of remote I/O unit (DX***)

Unit	Number of occupied stations
DX220, DX202, DX213	1
DX230, DX231, DX654	2
DX651	3

- The position of the bit that turns ON depends on the rotary switch on the remote I/O unit.

Cont.	Signal name	Abbrev.	Common (\$)
A	Ball screw thermal displacement compensation: Compensation amount n-th axis		R72 to 5

[Function] [Operation]

Thermal expansion compensation amount for the current machine position is set by NC.

Refer to the section on "Ball screw thermal displacement compensation offset amount" (R400) for details.

Device No.	Signal name
R72	Ball screw thermal displacement compensation: Compensation amount 1st axis
R73	Ball screw thermal displacement compensation: Compensation amount 2nd axis
R74	Ball screw thermal displacement compensation: Compensation amount 3rd axis
R75	Ball screw thermal displacement compensation: Compensation amount 4th axis

[Related signals]

- Ball screw thermal displacement compensation offset amount n-th axis (R400)
- Ball screw thermal displacement compensation Max. compensation amount n-th axis (R401)
- Ball screw thermal displacement compensation part-system, axis No. n-th axis (R402)

4 Explanation of Interface Signals


4.2 PLC Input Signals (Data Type: R^{***})

Cont.	Signal name	Abbrev.	Common (\$)
A	Speed monitor door open possible	SMDOEN	R96

[Function]


This signal executes speed monitor function for the control axis for which a valid door No. is selected with parameter "#2118 SscDrSel" and the spindle for which a valid door No. is selected with parameter "#3071 SscDrSelSP". Then the signal notifies that the selected door can be opened.

The door No. corresponds to the following bits.

**[Operation]**

When both NC and drive unit start the speed monitor function with the speed monitor mode turned ON and speed monitor parameter check completed, the speed monitor door open signal will turn ON.

When the speed monitor mode is OFF, the speed monitor door open possible signal is OFF as well. After the "Speed monitor door open possible" signal is turned OFF, cancel the speed limit.

**[Caution]**

To use the speed monitor function, create user PLC that enables door open when the speed monitor door open possible signal is ON.

[Related signals]

- (1) Speed monitor mode (SOMD: R296)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Multi-step speed monitor selected speed output	SOPFN	R98

[Function]

The number of selected observation speed steps is output to this signal.


The following table shows the R register status and the selected number of observation speed steps.

Bit2	Bit1	Bit0	Observation speed
0	0	0	Observation speed 1 (#2181, #3141)
0	0	1	Observation speed 2 (#2182, #3142)
0	1	0	Observation speed 3 (#2183, #3143)
0	1	1	Observation speed 4 (#2184, #3144)
1	0	0	Observation speed 5 (#2185, #3149)
1	0	1	Observation speed 6 (#2186, #3150)
1	1	0	Observation speed 7 (#2191, #3151)
1	1	1	Observation speed 8 (#2192, #3152)

[Operation]

Observation speed change is performed with the "observation speed change" signals. When the observation speed actually switches, the number of selected observation speed steps is output to the "Multi-step speed monitor selected speed output" (R98).

Even if the "Speed monitor mode" signal is OFF, the number is output corresponding to the "observation speed change" signals.




- After confirming that the observation speed change signal and the "Multi-step speed monitor selected speed output" (R98) match on user PLC side, turn ON the "Speed monitor mode" signal (R296). After confirming that the observation speed change signal and the "Multi-step speed monitor selected speed output" (R98) match on user PLC side and the axis speed is the same as or slower than the observation speed, turn ON the speed monitor mode signal.
- To increase the observation speed, after the observation speed change signal and the "Multi-step speed monitor selected speed output" (R98) match on the user PLC side, increase the axis speed.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R^{***})

If the axis speed is equal to or higher than the changed observation speed when the observation speed change signal is changed in observation speed change during speed monitor, the alarm (Y21 0001) is output and the observation speed is not switched until the axis speed becomes smaller than the changed observation speed.



Cont.	Signal name	Abbrev.	Common (\$)
A	Interference check between part systems: Setting error alarm information		R101

[Function]

This signal notifies of the cause of the alarm with the value of bitC to bitF when the operation alarm (M01 1050) occurs.


This signal notifies which interfering object has setting error with bit0 to bit5 when the value of bitC to bitF is between 5 and 8.

[Operation]

When the operation alarm (M01 1050) occurs, the value of bitC to bitF is as follows depending on the cause:

Value of bitC to bitF (represented in binary)	Cause of the operation alarm (M01 1050)
1 (0001)	An attempt was made to start the interference check between part systems in a system configured with a single part system.
2 (0010)	Interference check between part systems: Data address (R468) is an odd number.
3 (0011)	The value set in "number of defined interference objects" is out of the setting range.
4 (0100)	Same axis has been set multiple times in one part system of "reference axis corresponding axes for each part system".
5 (0101)	The value set in "interfering object, moving object/fixed object selection" is out of the setting range, or of a nonexistent part system.
6 (0110)	Three or more fixed objects have been set in "interfering object, moving object/fixed object selection".
7 (0111)	Two or more moving objects have been set in "interfering object, moving object/fixed object selection" of one part system.
8 (1000)	"0" has been set in length I, J or K.

When a value of bitC to bitF is between 5 and 8, the bit which corresponds to the interfering object with setting error is turned ON.

**[Related signals]**

- (1) Interference check between part systems: Alarm information (R102)
- (2) Interference check between part systems: Interference check enabled (CCHK: Y73F)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)


Cont.	Signal name	Abbrev.	Common (\$)
A	Interference check between part systems: Alarm information		R102

[Function]

This signal notifies which interfering object is in the interference state when the operation alarm (M01 1051 or M01 1052) occurs.

[Operation]

The bit which corresponds to the interfering object in the interference state is turned ON.

**[Related signals]**

- (1) Interference check between part systems: Setting error alarm information (R101)
- (2) Interference check between part systems: Interference check enabled (CCHK: Y73F)

Cont.	Signal name	Abbrev.	Common (\$)
A	Handle feed: 1st handle pulse counter	HS1PCNT	R116
A	Handle feed: 2nd handle pulse counter	HS2PCNT	R117
A	Handle feed: 3rd handle pulse counter	HS3PCNT	R118

[Function]

Cumulative pulses of the 1st to 3rd handles are output in this signal.


[Operation]

The number of pulses increases or decreases depending on the direction in which the 1st to 3rd handles are turned.


(Range of increase/decrease: -32768 to 32767)

The following examples show how the number of pulses changes as the handle is turned.


(Example 1) Change of pulses when the handle is turned continuously in plus direction



(Example 2) Change of pulses when the handle is turned continuously in minus direction



(Example 3) Change of pulses when the handle is turned in plus and minus directions alternately



When the power supply is turned ON, the number of pulses is "0".


This value can be changed arbitrarily using the ladder, etc.

After the change, the number of pulses increases or decreases from the changed value.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R^{***})

(Example 4) Change of pulses when the value is changed during plus-direction operation.



The number of pulses increases or decreases as the handle is turned regardless of the operation mode.

For both 5V handle and 12V handle, the number of pulses increases or decreases in increments of 1 pulse per notch.

Regardless of the setting of the handle feed magnification, the number of pulses increases or decreases in increments of 1 pulse per notch.

The handle rotation direction can be determined by calculating the amount of change per scan in the ladder.

Cont.	Signal name	Abbrev.	Common (\$)
A	Power consumption computation: Present consumption of entire drive system	DTPPC	R120, 1

[Function]

This signal notifies the present consumption of entire drive system.

[Operation]

The present consumption of entire drive system is set.

The present consumption of entire drive system is the sum of present power consumption of servo axis in drive system (fluctuating part), present power consumption of spindle in drive system (fluctuating part), drive system's fixed consumption (base common #1464), and drive system's fixed consumption correction (R306, 7).

Setting size is 2 words, Setting unit is 1 (W), Setting range is -2147483648 to 2147483647 (W)

[Caution]

(1) The positive value represents power consumption and the negative value represents power regeneration.

[Related signals]

(1) Power consumption computation: Drive system's fixed consumption correction (DFPCC: R306, 7)

Cont.	Signal name	Abbrev.	Common (\$)
A	Power consumption computation: Accumulated consumption of entire drive system 1 to 4	DTIPC1 to 4	R122 to 9

[Function]

This signal notifies the accumulated consumption of entire drive system.

[Operation]

The accumulated consumption of entire drive unit is set.

The accumulated consumption of entire drive system is the accumulation of present power consumption of servo axis in drive system (fluctuating part), present power consumption of spindle in drive system (fluctuating part), drive system's fixed consumption (base common #1464), and drive system's fixed consumption correction (R306, 7).

Setting size is 2 words, Setting unit is 1 (Wh), Setting range is -2147483648 to 2147483647 (Wh)

[Caution]

(1) When the power is turned ON again, the state prior to the power ON is held.

(2) The positive value represents power consumption and the negative value represents power regeneration.

(3) When the accumulated value exceeds the maximum or minimum value of the setting range, each value is clamped to the maximum/minimum value.

[Related signals]

(1) Power consumption computation: Clear consumption accumulation 1 to 4 (IPCC1 to 4: Y700 to 3)

(2) Power consumption computation: Enable consumption accumulation 1 to 4 (IPCE1 to 4: Y724 to 7)

(3) Power consumption computation: Drive system's fixed consumption correction (DFPCC: R306, 7)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Power consumption computation: Accumulated consumption of devices other than drive system 1 to 4	NDIPC1 to 4	R130 to 7

[Function]

This signal notifies the accumulated value of total power consumption of devices other than drive system.

[Operation]

The accumulated consumption of devices other than drive system is set.

The accumulated consumption of devices other than drive system is the accumulation of power consumption of devices other than drive system (R304, 5).

Setting size is 2 words, Setting unit is 1 (Wh), Setting range is -2147483648 to 2147483647 (Wh)

[Caution]

- (1) When the power is turned ON again, the state prior to the power ON is held.
- (2) The positive value represents power consumption and the negative value represents power regeneration.
- (3) When the accumulated value exceeds the maximum or minimum value of the setting range, each value is clamped to the maximum/minimum value.

[Related signals]

- (1) Power consumption computation: Clear consumption accumulation 1 to 4 (IPCC1 to 4: Y700 to 3)
- (2) Power consumption computation: Enable consumption accumulation 1 to 4 (IPCE1 to 4: Y724 to 7)
- (3) Power consumption computation: Consumption of devices other than drive system (NDPC: R304, 5)

Cont.	Signal name	Abbrev.	Common (\$)
A	Interference check III: Entry in interference warning area interfering object information	ITF3CHWG- OBJ	R138

[Function] [Operation]

This signal notifies the interfering object No. of the interfering object selection in which the operation alarm (M03 0003) has occurred.

bit0: 1st interfering object entry in the interference warning area

:

bitF: 16th interfering object entry in the interference warning area

If more than one interfering object enters the interference warning area, all bits corresponding to the interfering objects which have entered the interference warning area are turned ON.

Cont.	Signal name	Abbrev.	Common (\$)
A	Interference check III: Interference detection interfering object information	ITF3CHAL- OBJ	R139

[Function] [Operation]

This signal notifies the interfering object No. of the interfering object selection in which the operation alarm (M03 0001) has occurred.

bit0: 1st interfering object interference detection

:

bitF: 16th interfering object interference detection

If the entry of more than one interfering object to the interference alarm area has been detected, all bits corresponding to the interfering objects in which the entry to the interference alarm area is detected are turned ON.

Cont.	Signal name	Abbrev.	Common (\$)
A	Interference check III: Entry in interference alarm area interfering object information	ITF3TRAL- OBJ	R140

[Function] [Operation]

This signal notifies the interfering object No. of the interfering object selection in which the operation alarm (M03 0002) has occurred.

bit0: 1st interfering object entry in the interference alarm area

:

bitF: 16th interfering object entry in the interference alarm area

If more than one interfering object enters the interference alarm area, all bits corresponding to the interfering objects which have entered the interference alarm area are turned ON.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Interference check III: Data setting error information 1	ITF3DTER1	R141

[Function] [Operation]

This signal notifies that the error of the data (operation alarm (M03 300*)) set in the interfering object selection has occurred when the "Interference check III: Enable interfering object selection data" (Y769) is ON.

bit0: 1st interfering object selection setting error

:

bitF: 16th interfering object selection setting error

Cont.	Signal name	Abbrev.	Common (\$)
A	Interference check III: Data setting error information 2	ITF3DTER2	R142 to R149

[Function] [Operation]

This signal notifies that the error of the data (operation alarm (M03 200*)) set in the interfering object definition has occurred when the "Interference check III: Enable interfering object selection data" (Y769) is ON.

<R142>

bit0: 1st interfering object definition setting error

:

bitF: 16th interfering object definition setting error

<R149>

bit0: 113th interfering object definition setting error

:

bitF: 128th interfering object definition setting error

Cont.	Signal name	Abbrev.	Common (\$)
A	PLC axis alarm/warning No. n-th axis		R168 to 175

[Function]

This signal indicates the alarm No./warning No. of the servo drive unit for PLC axis. (hexadecimal 2 digits)

This signal sets the 4-digit alarm No. which is displayed on the NC screen.

[Operation]

This signal is set up when the alarm/waring occurs in the servo drive unit for PLC axis.

This signal will be cleared when the alarm/warning is canceled.

This signal does not set if the servo warning "S52 00E6" (Control axis detachment warning) or "S52 00E7" (In NC emergency stop state) occurs.

If more than one alarm/warning occurs, the value displayed in the [LED display] of [Drv mon]-[Servo unit] screen is set.

[Related signals]

(1) NC warning (servo warning) (XC9C)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	External search status		R500	R700	R900	R1100	R1300	R1500	R1700	R1900

[Function] [Operation]

The status at the end of the external search is output.

The correspondence of the external search status values and details output from the NC based on the external search is shown below.

Status value	Details	Remedy
0	Normally finished.	-
1	Operation search is being carried out.	Wait for other function's operation search to finish before searching.
2	Search was attempted while external search was invalid.	Stop the program before searching. Cancel the emergency stop or reset before searching.
3	Any non-existent or inoperative device has been designated.	Confirm the presence of the device, and that the device is within the specifications.
4	The program file is not designated.	Designate the program No. or sequence No.
5	The block with the designated program No., sequence No. or block No. was not found.	Check the machining program.
6	-	-
7	The designated device does not support the batch program search across all part systems.	Designate a device which supports the batch program search across all part systems.

[Related signals]

(1) External search finished (XC1D)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	External search: Program return complete status		R501	R701	R901	R1101	R1301	R1501	R1701	R1901


[Function] [Operation]

This signal outputs the status of when the program return completed signal is ON.

The correspondence of the program return complete status values and details output from the NC based on the result of returning to the machining program before the external search is shown below.

Status value	Details	Remedy
0	Normally finished	-
1	Function is invalid	Check the parameter setting
2	Program return was attempted during the operation, reset, or emergency stop.	Input the signal after stopping the program operation. Confirm the cancellation of the emergency stop or reset, and then input the signal.
3	Program return is disabled because the external search has not been performed or due to any restriction.	Execute the external search first, and then input the signal. Do not execute a function that is restricted after the external search.

The timing chart for program return is shown below.



302

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	S code data 1 to 8		R512 to 27	R712 to 27	R912 to 27	R1112 to 27	R1312 to 27	R1512 to 27	R1712 to 27	R1912 to 27

[Function]

When S function is commanded, the value following address "S" of the S function is notified. The S code data output from the controller can be selected from 8-digit BCD data, unsigned 32-bit binary data, or signed 32-bit binary data, by the parameter "#12008 Sbin".

[Operation]

S code data (1 to 8) are updated when:

- ♦ "S**" is specified in automatic operation (tape, memory or MDI).
- ♦ "S**" is executed by manual numerical command input.

Data remain unchanged even when the "M function finish 1" signal (FIN1) or the "M function finish 2" signal (FIN2) is sent back. Reset or "Emergency stop" does not clear the data.

The S code data is assigned as follows.

Signal name	Register							
	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
S code data 1	R512, 3	R712, 3	R912, 3	R1112, 3	R1312, 3	R1512, 3	R1712, 3	R1912, 3
S code data 2	R514, 5	R714, 5	R914, 5	R1114, 5	R1314, 5	R1514, 5	R1714, 5	R1914, 5
S code data 3	R516, 7	R716, 7	R916, 7	R1116, 7	R1316, 7	R1516, 7	R1716, 7	R1916, 7
S code data 4	R518, 9	R718, 9	R918, 9	R1118, 9	R1318, 9	R1518, 9	R1718, 9	R1918, 9
S code data 5	R520, 1	R720, 1	R920, 1	R1120, 1	R1320, 1	R1520, 1	R1720, 1	R1920, 1
S code data 6	R522, 3	R722, 3	R922, 3	R1122, 3	R1322, 3	R1522, 3	R1722, 3	R1922, 3
S code data 7	R524, 5	R724, 5	R924, 5	R1124, 5	R1324, 5	R1524, 5	R1724, 5	R1924, 5
S code data 8	R526, 7	R726, 7	R926, 7	R1126, 7	R1326, 7	R1526, 7	R1726, 7	R1926, 7

[Caution]

- (1) If two or more S codes for one spindle are issued in a block, the S code defined last will be valid.

[Related signals]

- (1) S function strobe (SFn: XC64)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	T code data 1 to 4		R536 to 43	R736 to 43	R936 to 43	R1136 to 43	R1336 to 43	R1536 to 43	R1736 to 43	R1936 to 43

[Function]

When T function is commanded, the value following address "T" of the T function is notified. The T code data output from the controller can be selected from 8-digit BCD data, unsigned 32-bit binary data, or signed 32-bit binary data, by the parameter "#12010 Tbin".

[Operation]

T code data (1 to 4) are updated when:

- ♦ "T**" is specified in automatic operation (memory, MDI or tape).
- ♦ "T**" is executed by manual numerical command input.

Data remain unchanged even when the "M function finish 1" signal (FIN1) or the "M function finish 2" signal (FIN2) is sent back. Reset or "Emergency stop" does not clear the data.

T code data is assigned as follows.

Signal name	Register			
	\$1	\$2	\$3	\$4
T code data 1	R536, 7	R736, 7	R936, 7	R1136, 7
T code data 2	R538, 9	R738, 9	R938, 9	R1138, 9
T code data 3	R540, 1	R740, 1	R940, 1	R1140, 1
T code data 4	R542, 3	R742, 3	R942, 3	R1142, 3

[Caution]

- (1) Up to four T codes can be commanded in one block. When five or more commands are issued in one block, the later commands will be valid.

[M system]

T05 T15;

 Output to T code data 1
 This T code data is invalid.

[L system]

T0505 T1515;

 Output to T code data 1
 This T code data is invalid.

[Related signals]

- (1) Tool function strobe 1 (TF1: XC68)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	2nd M function data 1 to 4		R544 to 51	R744 to 51	R944 to 51	R1144 to 51	R1344 to 51	R1544 to 51	R1744 to 51	R1944 to 51

[Function]

When 2nd M function is commanded, the value following address "B" of the 2nd M function is notified.

The 2nd M function data output from the controller can be selected from 8-digit BCD data, unsigned 32-bit binary data, or signed 32-bit binary data, by the parameter "#12012 Bbin".

Signed binary data can also be output by setting "#1045 nskno".

Note

- (1) Select an address for the 2nd M function address from the machine parameters basic specification parameter "#1170 M2name" A, B or C address that is not being used for "#1013 axname" or "#1014 incax".

[Operation]

2nd M function data (1 to 4) are updated when:

- ♦ "B**" (or A** or C**) is specified in automatic operation (memory, MDI or tape).
- ♦ "B**" (or A** or C**) is executed by manual numerical command input.


Data remain unchanged even when the "M function finish 1" signal (FIN1) or the "M function finish 2" signal (FIN2) is sent back. Reset or "Emergency stop" does not clear the data.

2nd M function data is assigned as follows.

Signal name	Register			
	\$1	\$2	\$3	\$4
2nd M function data 1	R544, 5	R744, 5	R944, 5	R1144, 5
2nd M function data 2	R546, 7	R746, 7	R946, 7	R1146, 7
2nd M function data 3	R548, 9	R748, 9	R948, 9	R1148, 9
2nd M function data 4	R550, 1	R750, 1	R950, 1	R1150, 1

[Caution]

- (1) Up to four 2nd M functions can be commanded in one block. When five or more commands are issued in one block, the later commands will be valid.

**[Related signals]**

- (1) 2nd M function strobe 1 (BF1: XC6C)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R^{***})

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Chopping error No.		R554	R754	R954	R1154	R1354	R1554	R1754	R1954

[Function]

This signal notifies the user PLC the alarm details when an alarm occurs during chopping operation.

[Operation]

Chopping error No. and details are shown below.

Error No.	Details	Classification
0	No error	-
1	The number of chopping cycles is zero. (Operates when the number of cycles is 1.)	A
2	(Chopping axis feedrate) > (Cutting feed clamp speed) (The feedrate is clamped at the cutting feed clamp speed.)	A
3	(Acceleration of chopping axis) > (Cutting feed clamp speed)/(Cutting feed time constant) (The acceleration is clamped at (Cutting feed clamp speed)/(Cutting feed time constant))	A
4	(Number of cycles for chopping) > (1056/min) (The number of cycles for chopping is clamped at 1056/min.)	A
5	Chopping axis zero point return is not completed.	B
6	Chopping override is zero.	B
7	Commanded axis is the chopping axis.	B
8	The bottom dead center point position is zero.	B
9	The chopping axis is a manual feed axis.	B
10	Interlock	B
11	Stored stroke limit or stroke end	B
20	There is no specification for chopping.	-
21	Chopping control data area exceeds the R register area designated for the chopping control data. Chopping control data area and compensation amount record area are overlapped. Compensation amount record area exceeds R register's backup area (R8300 to R9799). ((Rm+14 x N sets+4) > 9799)	C
22	Multiple chopping axes are specified by the PLC interface.	C
23	Chopping axis is not specified by either PLC interface or parameter.	C
24	Compensation method is set to other than "0" or "1".	C
25	The mode for the compensation value fixed method is set to other than "0" (playback mode) or "1" (record mode).	C
26	Data No. of the chopping control data is a negative value.	C
27	Chopping axis's "#2081 chclsp" (Maximum chopping speed) and "#2002 clamp" (Cutting feedrate for clamp function) are both set to "0".	C
28	Chopping axis was changed during chopping operation. (Chopping axis cannot be changed during chopping.)	C
29	Rotary axis was specified as chopping axis.	C
30	Rapid traverse override valid/invalid is set to other than "0" (invalid) or "1" (valid).	A

Classification A:	The error is retained during chopping operation. The error is cleared at the rising edge of the "Chopping parameter valid" signal after the chopping control data is corrected, or when the NC is reset.
Classification B:	The error is cleared after the alarm factor is removed, or when the NC is reset.
Classification C:	The error is cleared at the falling edge of the "Chopping parameter valid" signal, or when the NC is reset.

[Related signals]

- (1) Chopping (CHPS: YC30)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual measurement status		R555	R755	R955	R1155	R1355	R1555	R1755	R1955

[Function]

This signal indicates measurement status during measurement corresponding to bit.

[Operation]

Measurement status during manual measurement is indicated corresponding to bit.

This register value is displayed on the screen during manual measurement shown as below.

R555	Display	Meaning
bit0	On mea0	Status other than "On mea1" to "On mea6".
bit1	On mea1	Status when a skip signal is input during manual measurement. It will shift to "On mea2" state after deceleration stop is confirmed.
bit2	On mea2	Status during the first retract operation. It will shift to "On mea3" state after completing retraction by the retract amount.
bit3	On mea3	Status in which retract has completed by the retract amount. If the skip signal is ON after confirming deceleration stop, a warning will appear, and status display will remain the same. It will shift to "On mea0" state by resetting.
bit4	On mea4	Status during the second measurement. If the skip signal is not input, even if moving to the designated position, a warning will appear, and status display will remain the same. It will shift to "On mea0" state by resetting.
bit5	On mea5	Status when a skip signal is input during the second measurement. It will shift to "On mea6" state after deceleration stop is confirmed.
bit6	On mea6	Status during the second retract operation. It will shift to "On mea0" state after completing retraction by the retract amount.

[Related signals]

(1) Tool length measurement 1 (TLM: YC20)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Group in tool life management		R567	R767	R967	R1167	R1367	R1567	R1767	R1967

[Function] [Operation]

This signal outputs group No. currently in life management with the tool life management II.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	CNC completion standby status		R572	R772	R972	R1172	R1372	R1572	R1772	R1972

[Function]

This signal outputs the operating status of the NC in bit units when it seems that the machine is not operating in automatic operation without an alarm. The alarm messages can be displayed using this signal in the user PLC.

[Operation]

The corresponding bit below turns ON.

bit0: Complete standby status of M, S, T, B

bit1: In rapid traverse deceleration check

bit2: In cutting feed deceleration check

bit3 : Waiting for spindle orientation complete


bit4: Waiting for spindle position loop

bit7: Door opened

bit8: In executing dwell

bitB: Waiting for unclamp signal

The following figure shows the bit correspondence.



4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R^{***})

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	In initialization		R574	R774	R974	R1174	R1374	R1574	R1774	R1974

[Function]


This signal is output when zero point initialization is being carried out in the absolute position detection system.

[Operation]

The axis for which "1" is set in #0 on the [ABS. POSITION SET] screen is set to "1" and is held until the power is turned OFF.

While this signal is set to "1", the stored stroke limit and stroke end signals are invalid, and the current limit during initialization is valid.

This signal is also set to "1" when the "Zero point initialization mode" signal (AZS1 to 8) is ON.



Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Initialization incompleteness		R575	R775	R975	R1175	R1375	R1575	R1775	R1975


[Function]

This signal is output when the absolute position is not established in the absolute position detection system.

[Operation]

This signal indicates an axis for which an initial set of the zero point has never been established or has lost its absolute position.

The stored stroke limit of the axis for which this signal is set to "1" in the absolute position detection system is invalid.



4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Reference position adjustment value parameter setting completed		R576	R776	R976	R1176	R1376	R1576	R1776	R1976

[Function] [Operation]

When NC receives the "Reference position adjustment completion" signal's ON from PLC and the axis is controlled for the dog-type reference position return in the synchronization at zero point initialization (#1493 ref_syn = 1), NC sets the reference position adjustment value to "#2036 slv_adjust" and then turns ON the bit corresponding to the master axis in the part system.

Turn OFF the "Reference position adjustment value completion" signal after this signal is ON.

NC turns this signal OFF when the "Reference position adjustment completion" signal is changed from ON to OFF.

**[Caution]**

- (1) Parameter screen is also available to change the reference position adjustment value (#2036 slv_adjust), which does not turn this signal ON.

[Related signals]

- (1) Reference position adjustment completion (R2592)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	User macro section and sub-section designated execution result	APIER	R577	R777	R977	R1177	R1377	R1577	R1777	R1977

[Function] [Operation]

Execution result is stored when NC data is read or written using the system variables (#100050 to #100054).

Execution contents	Results	Data to be stored in R register
Read	Successful completion	0x0000
	Section No. error	0x0191
	Sub-section No. error	0x0192
	Part system designation error	0x0190
	Axis designation error	0x01A0
	Write-only data	0x019F
Write	Successful completion	0x0000
	Section No. error	0x0291
	Sub-section No. error	0x0292
	Part system designation error	0x0290
	Axis designation error	0x02A0
	Read-only data	0x029B
	Unable to write data	0x029E

[Caution]

- (1) The values are updated when NC data is read or written.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Near reference position (per reference position)		R580, 1	R780, 1	R980, 1	R1180, 1	R1380, 1	R1580, 1	R1780, 1	R1980, 1

[Function]

This signal indicates that the control axis is near the reference position in the absolute position detection system.

This signal is output for the 1st reference position to the 4th reference position.

In the signal near the 1st reference position, the time required to output the signal is shorter than that of the "Near reference position n-th axis" signal (NRFn) (the accuracy of ON/OFF timing during axis movement is improved).


[Operation]

- Using the n-th reference position as a reference, when the control axis is in the range set with the parameters, this signal turns ON, and turns OFF when the axis is not within the range.


- The near reference position signal is output with four bits for each axis.

<R register and corresponding axes>

R580



R581

**<Output value and near n-th reference position>**

High-order bit	<----->		Low-order bit	Near n-th reference position
0	0	0	1	Near 1st reference position
0	0	1	0	Near 2nd reference position
0	1	0	0	Near 3rd reference position
1	0	0	0	Near 4th reference position

Note

- The near reference position signal devices include X devices (NRF1 and following) which output signal only for the 1st reference position, and the R registers (R580/R581) which outputs a signal for each reference position (1st reference position to 4th reference position).
- The near reference position signal output width is set with the absolute position parameters "#2057 nrefp" and "#2058 nrefn". The near reference position signal output width is the same width for the 1st reference position to the 4th reference position.
- Near the 1st reference position, the signals are output to the conventional X device (NRF1 and following) and the R registers (R580/R581) which output signals to each reference position.

[Related signals]

- Near reference position n-th axis (NRF1 to 8: X880 to 7)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Presetter contact		R582	R782	R982	R1182	R1382	R1582	R1782	R1982

[Function]

The axis movement direction at the moment when the skip signal is entered is output in the tool presetter.

[Operation]


The movement direction of the axis at the moment when the tool touches the sensor (skip signal is ON) in the tool measurement mode (TLMS is ON) is set to the corresponding bit.

This signal is turned OFF when the sensor is OFF.

This signal turns OFF when the tool measurement mode signal is turned OFF.

This signal is not output when the tool measurement mode is not entered.

This signal is "0xFFFF" when an axis with no movement contacts the sensor.



1: Sensor ON

0: Sensor OFF or tool measurement mode OFF

[Related signals]

(1) Tool length measurement 2 (TLMS: YC21)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R^{***})

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Presetter interlock		R583	R783	R983	R1183	R1383	R1583	R1783	R1983

[Function]

The interlock direction in the CNC is output after the sensor is entered in the tool presetter.


[Operation]

The interlock direction to the entrance direction in the CNC is output after the sensor is entered during the tool measurement mode (TLMS ON).

This signal is turned OFF when the escape operation completion conditions are satisfied.

This signal turns OFF when the tool measurement mode signal is turned OFF.

This signal is not output when the tool measurement mode is not entered.



1: In interlock

0: Interlock cancel or tool measurement mode OFF

[Related signals]

(1) Tool length measurement 2 (TLMS: YC21)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	No. of work machining (current value)		R606, 7	R806, 7	R1006, 7	R1206, 7	R1406, 7	R1606, 7	R1806, 7	R2006, 7
A	No. of work machining (maximum value)		R608, 9	R808, 9	R1008, 9	R1208, 9	R1408, 9	R1608, 9	R1808, 9	R2008, 9

[Function]

The No. of work machining current value and maximum value are notified by the controller to the PLC.

[Operation]

If data is set in the No. of work machining (WRK COUNT M) and work machining maximum value (WRK LIMIT) of the [Process parameters], the current value or maximum value of the No. of work machining is output.

<For 1st part system>

R606	No. of work machining	Low -order side
R607	Current value	High -order side
R608	No. of work machining	Low -order side
R609	Maximum value	High -order side

Note

- (1) If data is not set in "WRK COUNT M" and "WRK LIMIT" on the [Process Parameter] screen, data is not output to the file register.
- (2) If the No. of work machining matches or exceeds maximum value, the "No. of work machining over" signal (XCA6) turns ON.

<Counting of No. of work machining using user PLC>

- ♦ Set "0" in "WRK COUNT M" on the [Process Parameter] screen. With this setting, the controller side does not count up.
- ♦ Add "1" to R606, 7 with the user PLC
- ♦ The controller displays R606, 7 as the No. of work machining on the [COORDINATE] screen. Even in this case, if the No. of work machining matches or exceeds the work maximum value, the "No. of work machining over" signal (XCA6) turns ON.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R^{***})

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Sub part system control: Sub part system control II identification No.	SBSID	R616	R816	R1016	R1216	R1416	R1616	R1816	R2016

[Function]

This signal indicates the identification numbers of sub part systems.


Refer to this signal if it is necessary to identify the G144 command that is controlling the sub part system.

[Operation]

A sub part system under the sub part system control II outputs the sub part system identification number while the "Sub part system control: Sub part system processing" signal (SBS) is ON.

The value is "0" when sub part system processing is not performed.

PLC input signal	Part system that outputs signals	Output signal value
Sub part system control: Sub part system processing (SBS: XC4E)	Sub part system	1: ON / 0: OFF
Sub part system control: Sub part system control II identification No. (SBSID: R616)	Sub part system	Sub part system identification No.

**[Related signals]**

(1) Sub part system control: Sub part system processing (SBS: XC4E)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Sub part system control: Calling sub part system	SBSCl	R617	R817	R1017	R1217	R1417	R1617	R1817	R2017

[Function]

This signal indicates the system bit data of a part system which is started as a sub part system.

To divide the PLC processing of the calling part system based on the sub part system, use this signal to find out which number of the sub part system is started.

[Operation]



The system bit of the sub part system is ON at the calling part system while the "Sub part system control: Sub part system processing" signal (SBS) is ON.

The value is "0" when sub part system processing is not performed.

bitF	bitE	bitD	bitC	bitB	bitA	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Not used.								\$8	\$7	\$6	\$5	\$4	\$3	\$2	\$1

PLC input signal	Part system that outputs signals	Output signal value
Sub part system control: Sub part system processing (SBS: XC4E)	Sub part system	1: ON / 0: OFF
Sub part system control: Calling sub part system (SBSCl: R617)	Caller of part system	System bit of sub part system

When the 1st part system and the 2nd part system are Main part systems and the 3rd part system is Sub part system.

Command format of sub part system control I**Command format of sub part system control II****[Related signals]**

- (1) Sub part system control: Sub part system processing (SBS: XC4E)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Sub part system control: Waiting for sub part system completion	SBSWT	R618	R818	R1018	R1218	R1418	R1618	R1818	R2018

[Function]

This signal indicates which part system's completion the calling part system is waiting for.

To divide the PLC processing of the calling part system based on the starting method of the sub part system, use this signal to distinguish between the completion waiting method performed with this signal and the parallel processing method.

[Operation]



If a sub part system is started with the completion waiting method, the system bit of the sub part system whose completion is waited remains ON at the calling part system while the "Sub part system control: Sub part system processing" signal (SBS) is ON.

The value is "0" when sub part system processing is not performed.

bitF	bitE	bitD	bitC	bitB	bitA	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Not used.								\$8	\$7	\$6	\$5	\$4	\$3	\$2	\$1

PLC input signal	Part system that outputs signals	Output signal value
Sub part system control: Sub part system processing (SBS: XC4E)	Sub part system	1: ON / 0: OFF
Sub part system control: Waiting for sub part system completion (SBSWT: R618)	Caller of part system	System bit of sub part system

When the 1st part system and the 2nd part system are Main part systems and the 3rd part system is Sub part system.

Command format of sub part system control I**Command format of sub part system control II****[Related signals]**

(1) Sub part system control: Sub part system processing (SBS: XC4E)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Sub part system control: Caller of sub part system	SBSSY	R619	R819	R1019	R1219	R1419	R1619	R1819	R2019

[Function]

This signal indicates the part system that called the sub part system.

To divide the PLC processing of the sub part system based on the calling part system, use this signal to find out which part system (number) called the sub part system.

[Operation]



The system bit of the calling part system remains ON at the sub part system while the "Sub part system control: Sub part system processing" signal (SBS) is ON.

The value is "0" when sub part system processing is not performed.

bitF	bitE	bitD	bitC	bitB	bitA	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
Not used.								\$8	\$7	\$6	\$5	\$4	\$3	\$2	\$1

PLC input signal	Part system that outputs signals	Output signal value
Sub part system control: Sub part system processing (SBS: XC4E)	Sub part system	1: ON / 0: OFF
Sub part system control: Caller of sub part system (SBSSY: R619)	Sub part system	System bit of calling part system

When the 1st part system and the 2nd part system are Main part systems and the 3rd part system is Sub part system.

Command format of sub part system control I**Command format of sub part system control II****[Related signals]**

- (1) Sub part system control: Sub part system processing (SBS: XC4E)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Constant torque control: Axis under constant torque/proportional torque stopper control		R624	R824	R1024	R1224	R1424	R1624	R1824	R2024

[Function]

With bit data, this signal indicates which axis is under constant torque control or proportional torque stopper control.

BIT	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
Axis	8	7	6	5	4	3	2	1	8	7	6	5	4	3	2	1
	Axis in proportional torque stopper control								Axis in constant torque control							

Note

(1) The axis bit configuration for part systems are the same as the basic axis configuration.

[Operation]**<High-order 8 bits: Axis in proportional torque stopper control>**

The axis bit corresponding to the axis to which proportional torque stopper control is commanded with the "Proportional torque stopper control request axis" signal (R2620/high-order 8 bits) turns ON.

The axis bit corresponding to the axis for which proportional torque stopper control is canceled with the "Proportional torque stopper control request axis" signal turns OFF.

<Low-order 8 bits: Axis in torque constant control>

The axis bit corresponding the axis to which constant torque control is commanded with the "Constant torque control request axis" signal (R2620/low-order 8 bits) turns ON.

The axis bit corresponding the axis for which constant torque control is canceled with the "Constant torque control request axis" signal turns OFF.

[Related signals]

(1) Constant torque control: Constant torque/proportional torque stopper control request axis (R2620)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Constant torque control: Constant torque droop cancel axis status		R625	R825	R1025	R1225	R1425	R1625	R1825	R2025

[Function]

With bit data, this signal indicates the axis for which constant torque droop cancellation is being executed or the axis for which constant torque droop cancellation is completed.

BIT	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
Axis	8	7	6	5	4	3	2	1	8	7	6	5	4	3	2	1
	Axis for which constant torque droop cancellation is completed								Axis for which constant torque droop cancellation is being executed							

Note

(1) The axis bit configuration for part systems are the same as the basic axis configuration.

[Operation]**<High-order 8 bits: Axis for which constant torque droop cancellation is completed>**

The axis bit corresponding to the axis for which droop cancellation commanded with the "Constant torque droop cancel request axis" signal (R2621/high-order 8 bits) is completed turns ON.

When the axis bit of the "Constant torque droop cancel request axis" signal turns OFF, the corresponding axis bit of this signal turns OFF.

<Low-order 8 bits: Axis for which constant torque droop cancellation is being executed>

The axis bit corresponding to the axis for which droop cancellation commanded with the "Constant torque droop cancel request axis" signal (R2621/low-order 8 bits) is being executed turns ON.

When the axis bit of the "Constant torque droop cancel request axis" signal turns OFF, the corresponding axis bit of this signal turns OFF.

[Related signals]

(1) Constant torque control: Constant torque droop cancel request axis (R2621)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool life usage data		R628, 9	R828, 9	R1028, 9	R1228, 9	R1428, 9	R1628, 9	R1828, 9	R2028, 9

[Function] [Operation]

This signal outputs usage data of tools currently being used with the tool life management II. (For tools that use multiple compensation Nos, the total usage data for each compensation No. is output.)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Number of registered tool life control tools		R630	R830	R1030	R1230	R1430	R1630	R1830	R2030

[Function] [Operation]

This signal indicates the number of tools currently in life management.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Circular feed in manual mode Current position H		R636,7	R836,7	R1036,7	R1236,7	R1436,7	R1636,7	R1836,7	R2036,7
A	Circular feed in manual mode Current position V		R640,1	R840,1	R1040,1	R1240,1	R1440,1	R1640,1	R1840,1	R2040,1

[Function]

The current positions of H' and V' axes on the hypothetical coordinate are set when the circular feed in manual mode is valid.

[Operation]

The current positions of H' and V' axes on the hypothetical coordinate are set while the "Circular feed in manual mode valid" signal is ON.

In the "circular-linear" mode, the current position of H' on the hypothetical coordinate is set by an angle (0.000° to 360.000°) from the basic point defined as 0 degree.

The hypothetical coordinate value in the following state is input.

Linear-linear hypothetical coordinate	V axis: mirror image is not valid
Circular-linear hypothetical coordinate	H' axis: "+" indicates the inverse (CW) direction V' axis: mirror image is not valid

[Caution]

- (1) This data is valid only when the "Circular feed in manual mode being valid" signal is ON. If the signal is OFF, the current position data is uncertain. (The value is not ensured.)
- (2) The current positions are output with "0.5×PLC setting unit".
- (3) When the parameter "#1040 M_inch" is set to "1", this data is output in inches.

[Related signals]

- (1) In circular feed in manual mode (XC4F)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Thread recutting status		R648	R848	R1048	R1248	R1448	R1648	R1848	R2048

[Function]

This signal indicates the status of operation commanded with the "Thread recutting command" signal.

When the thread recutting operation from the ladder ("#1258 set30/bit4" is set to "1") is selected, the CNC outputs the status of thread recutting operation to this signal.

The status is not output when the thread recutting operation on the CNC screen ("#1258 set30/bit4" is set to "0") is selected.

**[Operation]****<Description of each bit>**

Bit of R648	Meaning	Factors that the bit turns ON
0	Memory completed	The "Memory" (bit0) operation commanded with the "Thread recutting command" signal (R2626) was completed normally.
1	Erase completed	The "Erase" (bit1) operation commanded with the "Thread recutting command" signal (R2626) was completed normally.
2 to 6		
7	Error completed	The "Memory" (bit0) or "Erase" (bit1) operation commanded with the "Thread recutting command" signal (R2626) was not completed normally.
8	Command illegal error	Operation was executed with both "Memory" (bit0) and "Erase" (bit1) of the "Thread recutting command" signal (R2626) turned OFF or both turned ON.
9	Command unavailable error	Conditions are not met to execute the "Memory" (bit0) or "Erase" (bit1) operation commanded with the "Thread recutting command" signal (R2626).
A	Lead axis illegal error	The lead axis coordinates are not established when the "Memory" (bit0) operation is commanded with the "Thread recutting command" signal (R2626).
B	Spindle illegal error	The spindle has rotated less than one revolution after the power is turned ON when the "Memory" (bit0) operation is commanded with the "Thread recutting command" signal (R2626).
C	Axis number illegal error	The lead axis number or spindle number is "0" or larger than the number of connected axes when the "Memory" (bit0) operation is commanded with the "Thread recutting command" signal (R2626).
D	Option illegal error	The thread recutting option is disabled when the "Memory" (bit0) or "Erase" (bit1) operation is commanded with the "Thread recutting command" signal (R2626).

<ON/OFF of this signal>

- The bits of this signal turn ON only when bit7 (Command execution) of the "Thread recutting command" signal (R2626) is ON.
- All bits of this signal turn OFF at the falling edge of bit7 (Command execution) of the "Thread recutting command" signal (R2626). Other signals such as a resetting signal cannot be used to turn this signal OFF.

[Related signals]

- (1) Thread recutting command (R2626)
- (2) Thread recutting spindle No. (R650)
- (3) Thread recutting lead axis No. (R651)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Thread recutting execution status		R649	R849	R1049	R1249	R1449	R1649	R1849	R2049

[Function]

This signal indicates whether thread recutting can be executed or not.

When the thread recutting operation from the ladder ("#1258 set30/bit4" is set to "1") is selected, the CNC outputs the status of thread recutting operation to this signal.

The status is not output when the thread recutting operation on the CNC screen ("#1258 set30/bit4" is set to "0") is selected.

**[Operation]**

Bit of R649	Meaning	Details
F	Thread recutting function enabled	Thread recutting is performed if thread cutting is performed while this bit is ON. This bit turns ON when bitF of the "Thread recutting execution operation" signal (R2627) has been turned ON and the data required to execute thread recutting is stored in the memory.

[Related signals]

(1) Thread recutting execution operation (R2627)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Thread recutting spindle No.		R650	R850	R1050	R1250	R1450	R1650	R1850	R2050

[Function] [Operation]

With binary data, this signal outputs the spindle number for which the position within one spindle revolution is memorized.

0: Not memorized

1: 1st spindle/1st axis

2: 2nd spindle/2nd axis

3: 3rd spindle/3rd axis

:

(Displays up to the number of connected axes.)

When the thread recutting operation from the ladder ("#1258 set30/bit4" is set to "1") is selected, the CNC outputs the status of thread recutting operation to this signal.

The status is not output when the thread recutting operation on the CNC screen ("#1258 set30/bit4" is set to "0") is selected.

[Related signals]

(1) Encoder selection (R2567)

(2) Thread recutting command (R2626)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Thread recutting lead axis No.		R651	R851	R1051	R1251	R1451	R1651	R1851	R2051

[Function] [Operation]

With binary data, this signal outputs the lead axis number for which the lead axis coordinates is memorized.

0: Not memorized

1: 1st spindle/1st axis

2: 2nd spindle/2nd axis

3: 3rd spindle/3rd axis

:

(Displays up to the number of connected axes.)

When the thread recutting operation from the ladder ("1258 set30/bit4" is set to "1") is selected, the CNC outputs the status of thread recutting operation to this signal.

The status is not output when the thread recutting operation on the CNC screen ("1258 set30/bit4" is set to "0") is selected.

[Related signals]

(1) Encoder selection (R2567)

(2) Thread recutting command (R2626)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Rotary axis configuration parameter output	RPAROUT	R656	R856	R1056	R1256	R1456	R1656	R1856	R2056

[Function]

This signal notifies configuration No. and switching status for the rotary axis configuration parameter that is being applied.

[Operation]**<Low-order 8 bits: Configuration No. of rotary axis configuration parameter>**


This notifies the configuration No. of the rotary axis configuration parameter that is being applied.

"0" is notified when there are no applicable rotary axis configuration parameters.

<High-order 8 bits: Switching status of rotary axis configuration parameter>

This notifies the switching status of rotary axis configuration parameter.

After the rotary axis configuration parameter switching request is made, the "Rotary axis configuration parameter switch completion signal" (bit8) is turned ON when the "Rotary axis configuration parameter switch request signal" is completed. When the "Rotary axis configuration parameter switch request signal" is turned OFF, the "Rotary axis configuration parameter switch completion signal" is also turned OFF.


**Note**

- Regardless of the setting of the parameter "#1450 5axis_Spec/bit2" (Application of rotary axis configuration parameters), the "Configuration No. of rotary axis configuration parameter" (R656/low-order 8 bits) is output. However, the "Rotary axis configuration parameter switch completion signal" (R656/bit8) is turned ON only when "#1450 5axis_Spec/bit2" is set to "1" (PLC signal method).

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

[Timing chart]



[Related signals]

- (1) Rotary axis configuration parameter switch (RPARCHG: R2615)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	R-Navi: Selected workpiece No.	RSWRK	R660	R860	R1060	R1260	R1460	R1660	R1860	R2060

[Function]

These signals notify the workpiece No. of the machining surface being selected by the R-Navi function.

[Operation]

These signals are set when:

- A machining surface is selected on [S-sel] of the monitor screen.

These signals are cleared when:

- The machining surface is canceled.
- The machining surface is canceled due to an emergency stop.

Note

- (1) These signals will not be set while a machining surface is being called by a program.

[Related signals]

- (1) R-Navi: Machining surface being selected (RSSCT: XD28)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	R-Navi: selecting machine surface number	RSSRF	R661	R861	R1061	R1261	R1461	R1661	R1861	R2061

[Function]

These signals notify the surface No. of the machining surface being selected by the R-Navi function.

[Operation]

These signals are set when:

- A machining surface is selected on [S-sel] of the monitor screen.

These signals are cleared when:

- The machining surface is canceled.
- The machining surface is canceled due to an emergency stop.

Note

- (1) These signals will not be set while a machining surface is being called by a program.

[Related signals]

- (1) R-Navi: Machining surface being selected (RSSCT: XD28)

4 Explanation of Interface Signals


4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Interference check III: Entry in interference warn area solid in- formation	ITF3CH WGS LD	R670,1	R870,1	R1070,1	R1270,1	R1470,1	R1670,1	R1870,1	R2070,1

[Function] [Operation]

This signal notifies the solid which has entered the interference warning area at the occurrence of the operation alarm (M03 0003).

This signal notifies the interfering object definition information (the interfering object No. (high-order 8 bits) and configured solid No. (low-order 8 bits) of the interfering objects) for the pair of interfering objects in which interference has occurred.




If more than one solid enters the interference warning area, this signal notifies the interfering object No. and configured solid No. of the interfering object which has first entered the interference warning area.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Interference check III: Interference detection solid information	ITF3CHA LS LD	R672,3	R872,3	R1072,3	R1272,3	R1472,3	R1672,3	R1872,3	R2072,3

[Function] [Operation]

This signal notifies the solid for which the entry to the interference alarm area has been detected at the occurrence of the operation alarm (M03 0001).

This signal notifies the interfering object definition information (the interfering object No. (high-order 8 bits) and configured solid No. (low-order 8 bits) of the interfering objects) for the pair of interfering objects in which interference has occurred.



If the entry of more than one solid to the interfering alarm area has been detected, this signal notifies the interfering object No. and configured solid No. of the interfering object which has first entered the interfering alarm area.

4 Explanation of Interface Signals


4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Interference check III: Entry in interference alarm area solid in- formation	ITF3- TRALSL D	R674, 5	R874, 5	R1074, 5	R1274, 5	R1474, 5	R1674, 5	R1874, 5	R2074, 5

[Function] [Operation]

This signal notifies the solid which has entered the interference alarm area at the occurrence of the operation alarm (M03 0002).

This signal notifies the interfering object definition information (the interfering object No. (high-order 8 bits) and configured solid No. (low-order 8 bits) of the interfering objects) for the pair of interfering objects in which interference has occurred.



If more than one solid enters the interference alarm area, this signal notifies the interfering object No. and configured solid No. of the interfering object which has first entered the interference alarm area.

Cont.	Signal name	Abbrev.	Common (\$)
A	3D machine interference check: Requested shape group No. 1 to 4		R2400 to 3

[Function]

This signal outputs the No. of shape group which has been selected as the target of 3D machine interference check or real-time 3D machine interference check on the shape selection screen.

[Operation]

This signal is updated when the target shape group is changed on the shape selection screen.

Change of the Requested shape group No. does not affect the interference check.

To reflect the Requested shape group No. in the interference check, update the "3D Machine Interference Check: Enabled shape group No." signal.

Note

- (1) Shapes defined in Group 1 are within the scope of the interference check. Interference check is not executed for the shape defined in Groups 2 to 4.

[Related signals]

- (1) 3D Machine Interference Check: Enabled shape group No. (R4400)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Machine position n-th axis		R4500,1 to R4528,9	R4532,3 to R4560,1	R4564,5 to R4592,3	R4596,7 to R4624,5

[Function]

This signal outputs the position (n-th axis) on the machine coordinate system by the PLC setting unit.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Feedback machine position n-th axis		R4628,9 to R4656,7	R4660,1 to R4688,9	R4692,3 to R4720,1	R4724,5 to R4552,3

[Function]

This signal outputs motor feedback position (n-th axis) on the machine coordinate system by the PLC setting unit.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Servo deflection amount n-th axis		R4756 to 71	R4772 to 87	R4788 to 803	R4804 to 19

[Function]

The deflection amount of the servo n-th axis is output always in the command unit.

[Operation]

Servo 1st part system 1st axis: R4756 (low) R4757 (high)

:

Servo 1st part system 8th axis: R4770 (low) R4771 (high)

Servo 2nd part system 1st axis: R4772 (low) R4773 (high)

:

Servo 2nd part system 8th axis: R4786 (low) R4787 (high)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Motor rotation speed n-th axis		R4820,1 to R4834,5	R4836,7 to R4850,1	R4852,3 to R4866,7	R4868,9 to R4882,3

[Function]

This signal outputs motor rotation speed (n-th axis) with r/min.

[Operation]

The motor rotation speed is assigned as below.

Signal name	File register			
	\$1	\$2	\$3	\$4
Motor rotation speed 1st axis	R4820, 1	R4836, 7	R4852, 3	R4868, 9
Motor rotation speed 2nd axis	R4822, 3	R4838, 9	R4854, 5	R4870, 1
Motor rotation speed 3rd axis	R4824, 5	R4840, 1	R4856, 7	R4872, 3
Motor rotation speed 4th axis	R4826, 7	R4842, 3	R4858, 9	R4874, 5
Motor rotation speed 5th axis	R4828, 9	R4844, 5	R4860, 1	R4876, 7
Motor rotation speed 6th axis	R4830, 1	R4846, 7	R4862, 3	R4878, 9
Motor rotation speed 7th axis	R4832, 3	R4848, 9	R4864, 5	R4880, 1
Motor rotation speed 8th axis	R4834, 5	R4850, 1	R4866, 7	R4882, 3

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Motor load current n-th axis		R4884,5 to R4898,9	R4900,1 to R4914,5	R4916,7 to R4930,1	R4932,3 to R4946,7

[Function]

This signal outputs motor load current (n-th axis) with continuous current (%) during stalling.

[Operation]

The motor load current is assigned as below.

Signal name	File register			
	\$1	\$2	\$3	\$4
Motor load current 1st axis	R4884, 5	R4900, 1	R4916, 7	R4932, 3
Motor load current 2nd axis	R4886, 7	R4902, 3	R4918, 9	R4934, 5
Motor load current 3rd axis	R4888, 9	R4904, 5	R4920, 1	R4936, 7
Motor load current 4th axis	R4890, 1	R4906, 7	R4922, 3	R4938, 9
Motor load current 5th axis	R4892, 3	R4908, 9	R4924, 5	R4940, 1
Motor load current 6th axis	R4894, 5	R4910, 1	R4926, 7	R4942, 3
Motor load current 7th axis	R4896, 7	R4912, 3	R4928, 9	R4944, 5
Motor load current 8th axis	R4898, 9	R4914, 5	R4930, 1	R4946, 7

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Skip coordinate position n-th axis		R4948,9 to R4976,7	R4980,1 to R5008,9	R5012,3 to R5040,1	R5044,5 to R5072,3

[Function]

This signal outputs skip coordinate position Y (n-th axis) with PLC setting unit.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Synchronous error amount n-th axis		R5076,7 to R5090,1	R5092,3 to R5106,7	R5108,9 to R5122,3	R5124,5 to R5138,9

[Function]

The synchronization error amount during the synchronous control is output. (Unit: command unit)

[Operation]

The synchronization error amount between the reference axis and synchronized axis during the synchronous control is output to the synchronized axis.

(The axis Nos. are not for each part system, but for the entire system.)

Synchronization error amount	R register	Synchronization error amount	R register
1st axis	R5076(L)/R5077(H)	17th axis	R5108(L)/R5109(H)
2nd axis	R5078(L)/R5079(H)	18th axis	R5110(L)/R5111(H)
3rd axis	R5080(L)/R5081(H)	19th axis	R5112(L)/R5113(H)
4th axis	R5082(L)/R5083(H)	20th axis	R5114(L)/R5115(H)
5th axis	R5084(L)/R5085(H)	21th axis	R5116(L)/R5117(H)
6th axis	R5086(L)/R5087(H)	22th axis	R5118(L)/R5119(H)
7th axis	R5088(L)/R5089(H)	23th axis	R5120(L)/R5121(H)
8th axis	R5090(L)/R5091(H)	24th axis	R5122(L)/R5123(H)
9th axis	R5092(L)/R5093(H)	25th axis	R5124(L)/R5125(H)
10th axis	R5094(L)/R5095(H)	26th axis	R5126(L)/R5127(H)
11th axis	R5096(L)/R5097(H)	27th axis	R5128(L)/R5129(H)
12th axis	R5098(L)/R5099(H)	28th axis	R5130(L)/R5131(H)
13th axis	R5100(L)/R5101(H)	29th axis	R5132(L)/R5133(H)
14th axis	R5102(L)/R5103(H)	30th axis	R5134(L)/R5135(H)
15th axis	R5104(L)/R5105(H)	31th axis	R5136(L)/R5137(H)
16th axis	R5106(L)/R5107(H)	32th axis	R5138(L)/R5139(H)

[Related signals]

- (1) Synchronous control request (SYNC1 to 8: YA80 to 7)
- (2) Superimposition control request (PILE1 to 8: YAA0 to 7)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Servo alarm/warning No.		R5332 to R5339	R5340 to R5347	R5348 to R5355	R5356 to R5363

[Function]

This signal indicates the alarm No./warning No. of servo drive unit. (hexadecimal 2 digits)

This signal sets the 4-digit alarm No. which is displayed on the NC screen.

[Operation]

This signal is set up when the alarm/warning occurs in the servo drive unit.

This signal will be cleared when the alarm/warning is canceled.

This signal is not set if the servo warning "S52 00E6" (Control axis detachment warning) or "S52 00E7" (In NC emergency stop state) occurs.

If more than one alarm/warning occurs, the value displayed in the [LED display] of [Drv mon]-[Servo unit] screen is set.

[Related signals]

- (1) NC warning (servo warning) (XC9C)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Skip coordinate position n-th axis feature coordinate		R5364,5 to R5392,3	R5396,7 to R5424,5	R5428,9 to R5456,7	R5460,1 to R5488,9

[Function]

This signal outputs skip coordinate position (n-th axis) by the PLC setting unit.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Load monitoring I: Effective torque output n-th axis		R5620 to R5627	R5628 to R5635	R5636 to R5643	R5644 to R5651

[Function]

The effective torque of the servo axis is output to these devices.

[Operation]

The effective torque of the servo axis is output to this signal.

R5620	Effective torque output 1st axis
R5621	Effective torque output 2nd axis
R5622	Effective torque output 3rd axis
R5623	Effective torque output 4th axis
R5624	Effective torque output 5th axis
R5625	Effective torque output 6th axis
R5626	Effective torque output 7th axis
R5627	Effective torque output 8th axis

[Related signals]

- (1) Load monitoring I: Axis selection (R2580)
- (2) Load monitoring I: Effective spindle torque output (R6542)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	User macro output #1132 (NC -> PLC)		R6372, 3	R6380, 1	R6388, 9	R6396, 7	R6404, 5	R6412, 3	R6420, 1	R6428, 9

[Function]

This is interface function used to coordinate user PLC to user macro.

[Operation]

When a value is set in the system variables #1100 to #1131 or #1132 with the user macro program, the value is output to the corresponding file registers Rn and Rn + 1 of the user PLC, and the value can be referenced by the user PLC.

The relationship between system variable and file register is as follows:

System variable	Points	Interface output signal	System variable	Points	Interface output signal
#1100	1	Register R6372/bit0	#1116	1	Register R6373/bit0
#1101	1	Register R6372/bit1	#1117	1	Register R6373/bit1
#1102	1	Register R6372/bit2	#1118	1	Register R6373/bit2
#1103	1	Register R6372/bit3	#1119	1	Register R6373/bit3
#1104	1	Register R6372/bit4	#1120	1	Register R6373/bit4
#1105	1	Register R6372/bit5	#1121	1	Register R6373/bit5
#1106	1	Register R6372/bit6	#1122	1	Register R6373/bit6
#1107	1	Register R6372/bit7	#1123	1	Register R6373/bit7
#1108	1	Register R6372/bit8	#1124	1	Register R6373/bit8
#1109	1	Register R6372/bit9	#1125	1	Register R6373/bit9
#1110	1	Register R6372/bit10	#1126	1	Register R6373/bit10
#1111	1	Register R6372/bit11	#1127	1	Register R6373/bit11
#1112	1	Register R6372/bit12	#1128	1	Register R6373/bit12
#1113	1	Register R6372/bit13	#1129	1	Register R6373/bit13
#1114	1	Register R6372/bit14	#1130	1	Register R6373/bit14
#1115	1	Register R6372/bit15	#1131	1	Register R6373/bit15

System variable	Points	Interface output signal
#1132	32	Register R6372, R6373
#1133	32	Register R6374, R6375
#1134	32	Register R6376, R6377
#1135	32	Register R6378, R6379

This correspondence table uses the file registers R6372 and R6373 as an example.

File registers R6372 and R6373 correspond to system variables #1100 to #1131, and #1132 (32-bit data).

To use the R register of the 2nd and subsequent part system, set "1" to "#1230 set02/bit7".

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

[Related signals]

- (1) User macro output #1133, #1134, #1135 (R6374/6375, R6376/6377, R6378/6379)
- (2) User macro input #1032, #1033, #1034, #1035 (R6436/6437, R6438/6439, R6440/6441, R6442/66443)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	User macro output #1133 (NC -> PLC)		R6374, 5	R6382, 3	R6390, 1	R6398, 9	R6406, 7	R6414, 5	R6422, 3	R6430, 1

[Function]

This is interface function used to coordinate user PLC to user macro.

[Operation]


When a value is set in the system variable #1133 with the user macro, it is output to the corresponding file registers Rn and Rn+1 of the user PLC, and the value can be referenced by the user PLC.

(Example)

User macro program

#1133 = 1000

Sequence program



1000 is input in D100 and 101 when the ACT signal turns ON.

[Related signals]

- (1) User macro output #1132, #1134, #1135 (R6372/6373, R6376/6377, R6378/6379)
- (2) User macro input #1032, #1033, #1034, #1035 (R6436/6437, R6438/6439, R6440/6441, R6442/66443)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	User macro output #1134 (NC -> PLC)		R6376, 7	R6384, 5	R6392, 3	R6400, 1	R6408, 9	R6416, 7	R6424, 5	R6432, 3

[Function] [Operation]

The function, operation, etc. are the same as those of "User macro output #1133".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	User macro output #1135 (NC -> PLC)		R6378, 9	R6386, 7	R6394, 5	R6402, 3	R6410, 1	R6418, 9	R6426, 7	R6434, 5

[Function] [Operation]

The function, operation, etc. are the same as those of "User macro output #1133".

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle command rotation speed input		R6500,1	R6550,1	R6600,1	R6650,1	R6700,1	R6750,1	R6800,1	R6850,1

[Function]

This signal informs the value of the spindle function (S) data specified by automatic operation (memory, MDI or tape) or manual numerical command. Spindle command rotation input speed output from the controller is binary data. Under the S command mode, the data can be monitored in the "S display" on the command value screen.


Spindle command rotation speed input directly denotes spindle speed (r/min) specified as S function command.

[Operation]

The "Spindle command rotation speed input" is renewed when:

- "S***" is specified in automatic operation (memory, MDI or tape) and the "M function finish 1" (FIN1), the "M function finish 2" signal (FIN2) or the "Gear shift completion" signal (GFIN) is sent back to the controller.
- "S***" is specified by manual numerical command input and the "M function finish 1" (FIN1), the "M function finish 2" signal (FIN2) or the "Gear shift completion" signal (GFIN) is sent back to the controller. (Reset or "Emergency stop" does not clear the data.)

<Data flow>



When the system is under constant surface speed control, constant surface speed data is set for "Spindle command rotation speed input".

[Related signals]

- (1) Spindle command rotation speed output (R7000, R7001)
- (2) Spindle command final data (R6502, R6503)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle command final data (rotation speed)		R6502, 3	R6552, 3	R6602, 3	R6652, 3	R6702, 3	R6752, 3	R6802, 3	R6852, 3

[Function]

The command value to the spindle controller is indicated.

[Operation]

The "Spindle command rotation speed input" indicates the value of the spindle function (S) data commanded by automatic operation or manual numerical command, whereas this data further indicates the value that take into account the conditions of the "Spindle override", "Spindle gear selection code" (GI1, GI2), "Spindle stop" (SSTP), "Spindle gear shift" (SSFT) and "Spindle orientation" (SORC).

[Related signals]

- (1) Spindle command rotation speed input (R6500, 1)
- (2) Spindle command rotation speed output (R7000, 1)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle actual speed		R6506, 7	R6556, 7	R6606, 7	R6656, 7	R6706, 7	R6756, 7	R6806, 7	R6856, 7

[Function]

When the system has spindle equipped with encoder, actual spindle speed can be monitored.

[Operation]

True spindle speed is always set by feedback signal from spindle encoder.

Data are multiplied by 1000 and stored.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle synchronization: Phase error/ Hob axis delay angle		R6516	R6566	R6616	R6666	R6716	R6766	R6816	R6866

[Function]

The synchronized spindle delay to the reference spindle is output in the spindle synchronization function.

The delay of the workpiece axis to the hob axis is output in the tool spindle synchronization II (Hobbing).

Note

- (1) This signal uses the 1st spindle signal regardless of the hob spindle's number.

[Operation]

The synchronized spindle delay to the reference spindle is output.

The delay of the workpiece axis to the hob axis is output in the tool spindle synchronization II (Hobbing).

Unit: 360°/4096

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the signal of the hob axis during hobbing, or refer to the signal of the synchronized spindle during other machining when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".
- (3) If the phase cannot be calculated because, for instance, the reference spindle or synchronized spindle (hob axis or workpiece axis) has not passed the Z-phase, "-1" is output.
- (4) This data is output only during the phase shift calculation or the spindle phase synchronization.

[Related signals]

- (1) Phase shift calculation request (SSPHM: Y18B3)
- (2) Phase offset request (SSPHF: Y18B4)
- (3) Spindle synchronization: Phase offset data (R6518)
- (4) Spindle synchronization: Maximum phase error/Maximum hob axis delay angle (R6517)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle synchronization: Maximum phase error/Maximum hob axis delay angle		R6517	R6567	R6617	R6667	R6717	R6767	R6817	R6867

[Function]

In spindle synchronization, the maximum value of the phase error between the reference spindle and the synchronized spindle is output.

In tool spindle synchronization II (Hobbing), when the hob axis and work axis rotate in synchronization, the maximum delay (advance) of the hob axis from the commanded position is output by angle.

Note

- (1) This signal uses the 1st spindle signal regardless of the hob spindle's number.

[Operation]

In spindle synchronization, the maximum value of the "Spindle synchronization: Phase error" (R6516) is output.

In the tool spindle synchronization II (Hobbing), when the hob axis and work axis rotate in synchronization, the maximum delay (advance) of the hob axis from the commanded position is output by angle.

The maximum value output is retained until the next spindle synchronization/tool spindle synchronization II turns ON or until the power turns OFF.

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the signal of the hob axis during hobbing, or refer to the signal of the synchronized spindle during other machining when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) Hob axis delay excess (PHOVR: X18B3)
- (2) Spindle synchronization: Phase error/Hob axis delay angle (R6516)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R^{***})

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle synchronization: Phase offset data		R6518	R6568	R6618	R6668	R6718	R6768	R6818	R6868

[Function]

With the spindle phase shift amount calculation function, the phase error of the reference spindle and synchronized spindle is obtained and memorized by turning the PLC signal ON at executing the spindle synchronization. The synchronized spindle can be rotated with the handle during the spindle phase shift calculation, so the phase relation between two spindles can be adjusted by seeing.

If the "Spindle phase synchronous control" signal (SPPHS) is input while the "Phase offset request" signal (SSPHF) is ON, the phase error will be aligned based on the position shifted by the memorized phase shift amount.

Such operation makes the phase alignment easy when clamping a profile material over.

[Operation]

The phase error memorized by the phase shift calculation is output.

Unit: 360°/4096

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the synchronized spindle's signal when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".
- (3) This data is output only during the spindle synchronous control.

[Related signals]

- (1) Spindle phase synchronization (SPPHS: Y18B1)
- (2) Phase shift calculation request (SSPHM: Y18B3)
- (3) Phase offset request (SSPHF: Y18B4)
- (4) Spindle synchronization: Phase error/Hob axis delay angle (R6516)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle synchronization: Phase error monitor		R6519	R6569	R6619	R6669	R6719	R6769	R6819	R6869

[Function]

The phase error during the spindle phase synchronous state can be monitored.

[Operation]

The phase error during the spindle phase synchronous control is output by the pulse unit.

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the synchronized spindle's signal when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) Spindle synchronization: Phase error monitor (lower limit) (R6520)
- (2) Spindle synchronization: Phase error monitor (upper limit) (R6521)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle synchronization: Phase error monitor (lower limit)		R6520	R6570	R6620	R6670	R6720	R6770	R6820	R6870

[Function]

The phase error during the spindle phase synchronous state can be monitored.

[Operation]

The lower limit value of the phase error during the spindle phase synchronous control is output by the pulse unit.

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the synchronized spindle's signal when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) Spindle synchronization: Phase error monitor (R6519)
- (2) Spindle synchronization: Phase error monitor (upper limit) (R6521)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle synchronization: Phase error monitor (upper limit)		R6521	R6571	R6621	R6671	R6721	R6771	R6821	R6871

[Function]

The phase error during the spindle phase synchronous state can be monitored.

[Operation]

The upper limit value of the phase error during the spindle phase synchronous control is output by the pulse unit.

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the synchronized spindle's signal when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) Spindle synchronization: Phase error monitor (R6519)
- (2) Spindle synchronization: Phase error monitor (lower limit) (R6520)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle synchronization: Phase error 1		R6522	R6572	R6622	R6672	R6722	R6772	R6822	R6872

[Function]**<During spindle synchronous function (G114.1)>**

This signal informs the phase error (value including the phase error memorized with the spindle synchronization phase shift calculation function) when the phase synchronization (with R command) or the "Phase shift calculation request" signal (SSPHM) is ON. The phase error is output by 1° increment.

<During phase synchronization of polygon machining between spindles (G114.2)>

This signal informs the phase error corresponding to the commanded phase shift amounts by 1° increment.

The data has no meaning in cases other than above.

[Operation]**<During spindle synchronous function (G114.1)>**

When the phase synchronization (with R command) or the "Phase shift calculation request" signal (SSPHM) is ON, and when the speeds of the reference spindle and the synchronized spindle are constant, the phase error between the reference spindle and the synchronized spindle is output.

<During phase synchronization of polygon machining between spindles (G114.2)>

This signal informs the phase error corresponding to the commanded phase shift amounts by 1° increment.

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the synchronized spindle's signal when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) Phase shift calculation request (SSPHM: Y18B3)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle synchronization: Phase error 2		R6523	R6573	R6623	R6673	R6723	R6773	R6823	R6873

[Function]**<During spindle synchronous function (G114.1)>**

This signal informs the phase error (value excluding the phase error memorized with the spindle synchronization phase shift calculation function) when the phase synchronization (with R command) or the "Phase shift calculation request" signal (SSPHM) is ON. The phase error is output by 1° increment.

<During phase synchronization of polygon machining between spindles (G114.2)>

This signal informs the phase error corresponding to the commanded phase shift amounts by 1° increment. (Same as R6522.)

The data has no meaning in cases other than above.

[Operation]**<During spindle synchronous function (G114.1)>**

When the phase synchronization (with R command) or the "Phase shift calculation request" signal (SSPHM) is ON, and when the speeds of the reference spindle and the synchronized spindle are constant, the phase error between the reference spindle and the synchronized spindle is output.

<During phase synchronization of polygon machining between spindles (G114.2)>

This signal informs the phase error corresponding to the commanded phase shift amounts by 1° increment. (Same as R6522.)

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the synchronized spindle's signal when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) Phase shift calculation request (SSPHM: Y18B3)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle motor load ratio		R6525	R6575	R6625	R6675	R6725	R6775	R6825	R6875

[Function]

The spindle load is output with 0.01% increment.

[Operation]

When the parameter "#1256 set28/bit2" is set to "1", the spindle load is output with 0.01% increment.

When the parameter "#1256 set28/bit2" is set to "0", "0" is output.

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle temperature output	SPTEMP	R6526	R6576	R6626	R6676	R6726	R6776	R6826	R6876

[Function] [Operation]

The spindle motor temperature is output to this register. The temperature is expressed in degrees Celsius (°C). The temperature is output as a signed integer between 0x0000 and 0xFFFF (-32768 (°C) to 32767 (°C)).

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle alarm/warning No.		R6529	R6579	R6629	R6679	R6729	R6779	R6829	R6879

[Function]

This signal indicates the alarm No./warning No. of spindle drive unit. (hexadecimal 2 digits)

This signal sets the 4-digit alarm No. which is displayed on the NC screen.

[Operation]

This signal is set up when the alarm/warning occurs in the spindle drive unit.

This signal will be cleared when the alarm/warning is canceled.

This signal is not set if the servo warning "S52 00E6" (Control axis detachment warning) or "S52 00E7" (In NC emergency stop state) occurs.

If more than one alarm/warning occurs, the value displayed in the [LED display] of [Drv mon]-[Spindle unit] screen is set.

[Related signals]

- (1) NC warning (servo warning) (XC9C)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Synchronous tapping Current error width		R6532, 3	R6582, 3	R6632, 3	R6682, 3	R6732, 3	R6782, 3	R6832	R6882

[Function] [Operation]

The current value of the synchronous tapping error width (motor tracking delay from each position commands on the spindle and the tapping axis) is output during the synchronous tapping.

A positive output value means that the tapping axis lags behind the spindle, while a negative output value means that the spindle lags behind the tapping axis. The output range is -99999.999 to 99999.999 mm.

[Caution]

- (1) The synchronous tapping error is not output during the spindle orientation or the R point positioning.
- (2) The current value is kept retrieved during the synchronous tapping.
- (3) If the synchronous tapping error is over the output range, the maximum value of the range is output.
- (4) Execute the synchronous tap R-point in-position check before using this signal.

Unless the synchronous tap R-point in-position check is executed, an illegal value of the synchronous tapping error may be detected.

[Related signals]

- (1) Synchronous tapping Maximum error width (R6534, 6535)
- (2) Synchronous tapping Current error angle (R6536, 6537)
- (3) Synchronous tapping Maximum error angle (R6538, 6539)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R^{***})

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Synchronous tapping Maximum error width		R6534, 5	R6584, 5	R6634, 5	R6684, 5	R6734, 5	R6784, 5	R6834, 5	R6884, 5

[Function] [Operation]

The largest absolute value of the synchronous tapping error width (-99999.999 to 99999.999 mm) is output during the synchronous tapping.

The value is initialized to "0" when the synchronous tapping starts or the power turns ON again.

[Caution]

- (1) The synchronous tapping error is not output during the spindle orientation or the R point positioning.
- (2) This output value is the largest one throughout the synchronous tapping mode.
- (3) If the synchronous tapping error is over the output range, the maximum value of the range is output.
- (4) Execute the synchronous tap R-point in-position check before using this signal.

Unless the synchronous tap R-point in-position check is executed, an illegal value of the synchronous tapping error may be detected.

[Related signals]

- (1) Synchronous tapping Current error width (R6532, 6533)
- (2) Synchronous tapping Current error angle (R6536, 6537)
- (3) Synchronous tapping Maximum error angle (R6538, 6539)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Synchronous tapping Current error angle		R6536, 7	R6586, 7	R6636, 7	R6686, 7	R6736, 7	R6786, 7	R6836, 7	R6886, 7

[Function] [Operation]

The synchronous tapping error (motor tracking delay from each position commands on the spindle and the tapping axis) is output with angle during the synchronous tapping.

A positive output value means that the tapping axis lags behind the spindle, while a negative output value means that the spindle lags behind the tapping axis. The output range is -99999.999 to 99,999.999°.

[Caution]

- (1) The synchronous tapping error is not output during the spindle orientation or the R point positioning.
- (2) The current value is kept retrieved during the synchronous tapping.
- (3) If the synchronous tapping error is over the output range, the maximum value of the range is output.
- (4) Execute the synchronous tap R-point in-position check before using this signal. Unless the synchronous tap R-point in-position check is executed, an illegal value of the synchronous tapping error may be detected.

[Related signals]

- (1) Synchronous tapping Current error width (R6532, 6533)
- (2) Synchronous tapping Maximum error width (R6534, 6535)
- (3) Synchronous tapping Maximum error angle (R6538, 6539)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Synchronous tapping Maximum error angle		R6538, 9	R6588, 9	R6638, 9	R6688, 9	R6738, 9	R6788, 9	R6838, 9	R6888, 9

[Function] [Operation]

The largest absolute value of the synchronous tapping error angle (-99999.999 to 99,999.999°) is output during the synchronous tapping.

The value is initialized to "0" when the synchronous tapping starts or the power turns ON again. The value is kept retrieved and displayed during the synchronous tapping.

[Caution]

- (1) The synchronous tapping error is not output during the spindle orientation or the R point positioning.
- (2) This output value is the largest one throughout the synchronous tapping mode.
- (3) If the synchronous tapping error is over the output range, the maximum value of the range is output.
- (4) Execute the synchronous tap R-point in-position check before using this signal.

Unless the synchronous tap R-point in-position check is executed, an illegal value of the synchronous tapping error may be detected.

[Related signals]

- (1) Synchronous tapping Current error width (R6532, 6533)
- (2) Synchronous tapping Maximum error width (R6534, 6535)
- (3) Synchronous tapping Current error angle (R6536, 6537)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Load monitoring I: Estimated spindle disturbance torque output		R6541	R6591	R6641	R6691	R6741	R6791	R6841	R6891

[Function]

The estimated disturbance torque of the spindle is output to this signal.

[Operation]

The estimated disturbance torque of the spindle is output to this signal.

Output unit: Stall current 0.01%

"0x2710" is output when the cutting torque reaches 100%.

"0xff9C" is output when the cutting torque reaches -1%.

[Related signals]

- (1) Load monitoring I: Axis selection (R2580)
- (2) Load monitoring I: Effective spindle torque output (R6542)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Load monitoring I: Effective spindle torque output		R6542	R6592	R6642	R6692	R6742	R6792	R6842	R6892

[Function]

The effective torque of the spindle is output to these devices.

[Operation]

The effective torque of the spindle is output to these devices.

Output unit: Stall current % (#2634 SrvFunc01/bit0 = 0)

0x64 is output when the effective torque reaches 100%.

0xffff is output when the effective torque reaches -1%.

[Related signals]

- (1) Load monitoring I: Axis selection (R2580)
- (2) Load monitoring I: Estimated spindle disturbance torque output (R6541)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	VCC: Spindle rotation speed	VC- C_SPREV	R7024, 5	R7074, 5	R7124, 5	R7174, 5	R7224, 5	R7274, 5	R7324, 5	R7374, 5

[Function]

This signal notifies PLC of the spindle rotation speed in the vibration cutting mode.

[Operation]

The rotation speed of the spindle selected in the part system in the vibration cutting mode is stored.

"0" is output for the spindle that is not used for vibration cutting control.

[Related signals]

- (1) VCC: Mode in execution (VCC: X1810)
- (2) VCC: Numbers of vibrations (VCC_VIB: R20556)
- (3) VCC: Frequency (VCC_FRQ: R20557)
- (4) VCC: Spindle rotation speed (VCC_SPREV: R7024,R7025)
- (5) VCC: Vibrating axis (VCC_VIBAX: R20558)
- (6) VCC: Temporary cancel of axis vibration (VCC_INVAX: R22532)
- (7) VCC: Cause of non-vibration (VCC_FACT: R20559)

Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
PLC axis indexing control status 4	AUXST4	R8000	R8006	R8012	R8018	R8024	R8030	R8036	R8042

Cont.	Signal name	Abbrev.	bit
A	Position switch 1 to 15	PSW1 to PSW15	AUXST4/bit0 to 7 AUXST3/bit9 to F

[Function] [Operation]

This signal turns ON when the axis is within the setting range of the respective position switches.

Cont.	Signal name	Abbrev.	bit
A	Start not possible	NST	AUXST4/bitB

[Function] [Operation]

This signal turns ON when:

- The "Operation start" signal is turned ON for an axis other than the PLC indexing axis.

Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
PLC axis indexing control status 3	AUXST3	R8001	R8007	R8013	R8019	R8025	R8031	R8037	R8043

Cont.	Signal name	Abbrev.	bit
A	Station position 1 to 256	STO1 to STO256	AUXST3/bit0 to 8

[Function] [Operation]

This signal shows a 9-digit binary No. of the present station.

This signal outputs the station position when the "Set position reached" (JST) is ON, and outputs "0" when the "Set position reached" is OFF.

Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
PLC axis indexing control status 2	AUXST2	R8002	R8008	R8014	R8020	R8026	R8032	R8038	R8044

Cont.	Signal name	Abbrev.	bit
A	In automatic operation mode	AUTO	AUXST2/bit0

[Function] [Operation]

This signal indicates that the automatic operation mode has been selected.

Cont.	Signal name	Abbrev.	bit
A	In manual operation mode	MANO	AUXST2/bit1

[Function] [Operation]

This signal indicates that the manual operation mode has been selected.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	bit
A	In JOG operation mode	JO	AUXST2/bit2

[Function] [Operation]

This signal indicates that the JOG operation mode has been selected.

Cont.	Signal name	Abbrev.	bit
A	In reference position return	ARNN	AUXST2/bit3

[Function] [Operation]

This signal indicates that the machine is in the reference position return.

Cont.	Signal name	Abbrev.	bit
A	In reference position return mode	ZRNO	AUXST2/bit4

[Function] [Operation]

This signal indicates that reference position return mode is selected.

Cont.	Signal name	Abbrev.	bit
A	In basic point initialization setting mode	AZSO	AUXST2/bit6

[Function] [Operation]

This signal indicates that the basic point initialization setting mode has been selected.

Cont.	Signal name	Abbrev.	bit
A	In incremental mode	SO	AUXST2/bit7

[Function] [Operation]

This signal indicates that incremental mode is selected.

Cont.	Signal name	Abbrev.	bit
A	Alarm 1	AL1	AUXST2/bit8

[Function] [Operation]

This signal indicates that an alarm has occurred requiring the power to be turned ON again after the cause is removed.

Cont.	Signal name	Abbrev.	bit
A	Alarm 2	AL2	AUXST2/bit9

[Function] [Operation]

This signal indicates that an alarm has occurred which can be released by the "Master reset" signal (MRST) after the cause is removed.

Cont.	Signal name	Abbrev.	bit
A	Alarm 4	AL4	AUXST2/bitA

[Function] [Operation]

This signal indicates that an operation alarm or absolute position alarm has occurred.

Cont.	Signal name	Abbrev.	bit
A	Absolute position power shutoff movement over	ABS	AUXST2/bitC

[Function] [Operation]

This signal indicates that the axis moved beyond the tolerable amount while the control power was OFF in the absolute position system.

Cont.	Signal name	Abbrev.	bit
A	Absolute position data loss	ZSN	AUXST2/bitD

[Function] [Operation]

This signal indicates that the absolute position data has been lost in the absolute position system.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	bit
A	Initialization setting completed	ZSF	AUXST2/bitE

[Function] [Operation]

This signal indicates that in the absolute position system the basic point initialization setting has completed normally, and that the absolute position coordinates have been established.

Cont.	Signal name	Abbrev.	bit
A	Initialization setting error completed	ZSE	AUXST2/bitF

[Function] [Operation]

This signal indicates that the basic point initialization setting has not finished normally in the absolute position system.

Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
PLC axis indexing control status 1	AUXST1	R8003	R8009	R8015	R8021	R8027	R8033	R8039	R8045

Cont.	Signal name	Abbrev.	bit
A	Servo ready	RDY	AUXST1/bit0

[Function]

This signal indicates that the servo system is in an operable status.

[Operation]

The signal turns ON when:

- The servo system diagnosis is normally completed after the power is turned ON.
- The servo alarm, which had occurred, has been released by the "Master reset" (MRST).
- The emergency stop has been released.
- The "Ready OFF" (RDF) or the "Servo OFF" (*SVF) has been released.

The signal turns OFF when:

- Servo ready completion (SA) is turned OFF.
- The "Servo OFF" signal is input and the drive unit is in a servo OFF state.

[Related signals]

- (1) Master reset (MRST: AUXCM1/bit3)
- (2) Ready OFF (RDF: AUXCM1/bit6)
- (3) Servo OFF (SVF: AUXCM1/bit0)
- (4) Servo ready completion (SA: AUXST1/bitC)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	bit
A	In-position	INP	AUXST1/bit1

[Function]

This signal notifies that the control axis is in-position.

[Operation]

The signal turns ON when:


- The "Smoothing zero" (SMZ) is turned ON and the droop is within the range set by the parameters.

The signal turns OFF when:

- The "Smoothing zero" (SMZ) is turned OFF. (When there is a movement command.)
- The droop exceeds the range set in the parameters.

[Caution]

- (1) The "In-position" (INP) may turn ON, even during movement, when the axis is moving at extremely low speeds.
- (2) The in-position detection range is set in the parameter "#2224 SV024 In-position detection width".
- (3) In the servo ready OFF state, the "Smoothing zero" (SMZ) turns OFF when the travel amount of servomotor is detected. Therefore, the "In-position" (INP) also turns OFF. The "In axis plus motion" (MVP) or the "In axis minus motion" (MVN) turns ON depending on the detected movement direction. Note that the "Smoothing zero" (SMZ), the "In axis plus motion" (MVP) and the "In axis minus motion" (MVN) will not change in the servo OFF state without error correction, because detected servomotor travel amount becomes a droop amount.

**[Related signals]**

- (1) Smoothing zero (SMZ: AUXST1/bit2)

Cont.	Signal name	Abbrev.	bit
A	Smoothing zero	SMZ	AUXST1/bit2

[Function] [Operation]

This signal indicates that the acceleration/deceleration process in the built-in controller is finished, and that no command to the control section remains.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	bit
A	Axis selection output	AX1	AUXST1/bit3

[Function]

This signal indicates that the control axis has received the movement command.

[Operation]

This signal turns ON in the following cases, and turns OFF after the "Smoothing zero" (SMZ) is detected.

<In automatic operation mode>

This signal turns ON while the "Operation start" (ST) is ON and the axis is moving.

<In manual operation mode>

This signal turns ON while the "Operation start" (ST) is ON and the axis is moving.


<In JOG operation mode>

This signal turns ON while the "Operation start" (ST) is ON and the axis is moving.

<In reference position return mode>

This signal turns ON while the "Operation start" (ST) is ON and the axis is moving.

When an interlock is applied, this signal remains ON even when the servo is OFF. This signal turns OFF at the emergency stop.

**[Related signals]**

- (1) Operation start (ST: AUXCM2/bit0)

Cont.	Signal name	Abbrev.	bit
A	In axis plus motion	MVP	AUXST1/bit4

[Function]

This signal indicates that the axis is moving in the "+" direction.

[Operation]

This signal turns ON when the axis starts moving in the "+" direction, and turns OFF after the "Smoothing zero" (SMZ) is detected or the axis starts moving in the "-" direction.

[Related signals]

- (1) Smoothing zero (SMZ: AUXST1/bit2)

Cont.	Signal name	Abbrev.	bit
A	In axis minus motion	MVM	AUXST1/bit5

[Function]

This signal indicates that the axis is moving in the "-" direction.

[Operation]

This signal turns ON when the axis starts moving in the "-" direction, and turns OFF after the "Smoothing zero" (SMZ) is detected or the axis starts moving in the "+" direction.

[Related signals]

- (1) Smoothing zero (SMZ: AUXST1/bit2)

Cont.	Signal name	Abbrev.	bit
A	In torque limit	TLQ	AUXST1/bit6

[Function] [Operation]

This signal indicates that the control axis has reached the current limit value. This signal turns ON when the motor output torque (motor current) is limited at the torque limit value of the selected operation parameter group.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	bit
A	Reference position reached	ZP	AUXST1/bit8

[Function]

This signal indicates that the control axis is on the reference position.

[Operation]

The signal turns ON when:

- ♦ The control axis reaches the reference position in the reference position return mode.

The signal does not turn ON even if the control axis is at the reference position in other operation modes or by other commands.

The signal turns OFF when:

- ♦ The axis is moved from the reference point by a travel command, etc.
- ♦ An emergency stop has been activated due to an emergency stop input or the occurrence of a servo alarm, etc.
- ♦ The axis has moved in the servo OFF state.

[Related signals]

(1) Reference position return mode (ZRN: AUXCM1/bitB)

Cont.	Signal name	Abbrev.	bit
A	In "reset"	RST	AUXST1/bit9

[Function]

This signal indicates that the built-in controller is being reset.

[Operation]

The signal turns ON when:

- ♦ The "Master reset" signal (MRST) is turned ON.
- ♦ The "Master reset" signal (MRST) is turned ON and the built-in controller is being reset.
- ♦ In an emergency stop status.

[Related signals]

(1) Master reset (MRST: AUXCM1/bit3)

Cont.	Signal name	Abbrev.	bit
A	In handle feed operation mode	HO	AUXST1/bitA

[Function] [Operation]

This signal indicates that handle feed operation mode is selected.

Cont.	Signal name	Abbrev.	bit
A	Controller ready completion	MA	AUXST1/bitB

[Function]

This signal indicates that the controller is ready for normal operation.

[Operation]

The signal turns ON when:

- ♦ Normal operation has begun after the power ON.

The signal turns OFF when:

- ♦ The power is turned OFF.
- ♦ An error in the control device itself such as a CPU error and memory error is detected.
- ♦ A servo alarm which cannot be reset without turning OFF the power of the controller has occurred.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	bit
A	Servo ready completion	SA	AUXST1/bitC

[Function]

This signal indicates that the servo system is ready for normal operation. In other words, the servo system (position control) is not working when this signal is OFF.

[Operation]

The signal turns ON when:

- The servo system diagnosis is normally completed after the power is turned ON.
- The servo alarm, which had occurred, has been released by the "Master reset" (MRST).
- The emergency stop has been released.
- The "Ready OFF" (RDF) is turned OFF.

The signal turns OFF when:

- The "Controller ready completion" (MA) is turned OFF.
- A servo alarm has occurred.
- Emergency stop is issued.
- The "Ready OFF" (RDF) is turned ON.

[Caution]

- (1) With the "Servo OFF" (*SVF), the "Servo ready completion" (SA) will not turn OFF unless there is another condition to turn OFF the SA.
- (2) In an emergency stop status, all I/O output points turn OFF.

[Related signals]

- (1) Master reset (MRST: AUXCM1/bit3)
- (2) Ready OFF (RDF: AUXCM1/bit6)
- (3) Controller ready completion (MA: AUXST1/bitB)

Cont.	Signal name	Abbrev.	bit
A	Automatic set position reached	JSTA	AUXST1/bitD

[Function]

In the automatic operation, this signal notifies that the positioning to the commanded station No. is completed. The tolerable width which this signal is regarded as ON is as same as that of the "Set position reached" (JST).

[Operation]

The signal turns ON when:

- The positioning to the designated station No. is completed in the automatic operation mode.

The signal actually turns ON when the tool enters the tolerable width before the positioning is completed.

The signal turns OFF when:

- The "Operation start" signal is input in any of the operation modes.
- The tool deviates outside the tolerable width.

[Caution]

- (1) This signal does not turn ON when positioning is performed to the nearest station by turning OFF the "Operation start" signal during automatic operation.
- (2) Even if the indexing of the same station No. is started when this signal is ON, this signal does not turn OFF.
- (3) When the indexing of the same station number is started with the positioning to the station completed in the manual mode, this signal turns ON. However, there is no movement.
- (4) Once this signal is turned OFF, it does not turn ON even if the axis returns to the tolerable width.
- (5) During the emergency stop or the servo OFF, when a tool once deviated outside the width of "Set position reached", then returns within the area, this signal turns ON again if "#12802 aux_Cont1/bit4" is set to "OFF", and does not turn ON if "#12802 aux_Cont1/bit4" is set to "ON".

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	bit
A	Set position reached	JST	AUXST1/bitE

[Function]

This signal notifies that the positioning to the station position has been completed. This signal turns ON when the machine position is at any of the station positions. The tolerable width which this signal is regarded as ON is set with a parameter.

[Operation]

The signal turns ON when:

- ♦ The positioning to the station is completed in automatic or manual operation.
The signal actually turns ON when the axis enters the tolerable width before the positioning is completed.
- ♦ The stop position after JOG operation is the station position or within the tolerable width.
- ♦ The reference position return position corresponds to those of the stop position in (2).

Other than the above conditions, this signal normally monitors the machine position, and carries out comparisons between stations. Therefore, this signal is output even when the machine moves to a station position other than each operation.

The signal turns OFF when:

- ♦ The "Operation start" signal is input in any of the operation modes.
When the operation is started by the "Operation start" signal, this signal will not turn ON even when a station position is passed during the operation.
- ♦ The axis deviates outside the tolerable width.

Cont.	Signal name	Abbrev.	bit
A	Near set position	NEAR	AUXST1/bitF

[Function]

This signal notifies that the machine position is near the station.

[Operation]

The operation is the same as the "Set position reached" (JST). However, the tolerable width is set with a different parameter. Generally, a value larger than the tolerable width of the "Set position reached" is set, and this signal is used, for example, to start the mechanical clamp operation immediately before the completion of positioning.

Cont.	Signal name	Abbrev.	Common (\$)
A	Option status export to PLC		R8260 to R8289

[Function]

The status for each additional specification (enabled/disabled) is exported to the R register (R8260 to R8289).

By confirming the R register to which the information is exported, ladders and macro programs can be shared between the machines with different additional specification status. In addition, the custom screens dedicated to the respective additional specification can be displayed or non-displayed.

For the PLC bit location and the corresponding additional specification for each bit, refer to "7 Appx.3: List of Option Status Exported to PLC".

[Operation]

The status of additional specification is automatically registered to the R register when the CNC is started.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R^{***})

Cont.	Signal name	Abbrev.	Common (\$)
A	No. of error occurrences n-th ch		R10000 to 23

[Function]

In communication between the control unit and the remote I/O unit (station), the number of errors is counted and output.

[Operation]

R register's high-order 8 bits output the number of CRC error occurrences (maximum value), and the low-order 8 bits output the number of connection error occurrences (maximum value).

R register allocations are as shown below.

Remote I/O unit connection system	1st ch	2nd ch	3rd ch	4th ch	5th ch	6th ch	7th ch	8th ch
RIO1	R10000	R10001	R10002	R10003	R10004	R10005	R10006	R10007
RIO2	R10008	R10009	R10010	R10011	R10012	R10013	R10014	R10015
RIO3	R10016	R10017	R10018	R10019	R10020	R10021	R10022	R10023

[Caution]

- (1) Control unit cannot identify the remote I/O unit to which the power cable or communication cable is not connected, or the remote I/O unit to which power is not supplied. Therefore, no remote I/O error will occur even if a malfunction exists in those remote I/O units.
- (2) To confirm that the physically existing remote I/O unit is operating normally, use the output of "Connection status" and the output of "No. of error occurrences".
- (3) Once the number of error occurrences exceeds 255, the output of "No. of error occurrences" is clamped to 255 and a remote I/O error occurs.
- (4) Output data of the number of error occurrences is retained even if the power is turned OFF and ON.
However, the data of the station where the specified value is exceeded and a remote I/O error occurs is cleared to zero.

[Related signals]

- (1) Connection status of each channel RIO1,2 (R10064)
- (2) Connection status of each channel RIO3 (R10065)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)


Cont.	Signal name	Abbrev.	Common (\$)
A	Connection status of each channel RIO1,2		R10064

[Function]

Connection status of remote I/O unit channel 1 & 2 is constantly output to R register.

[Operation]

When remote I/O unit is connected, "1" is set, and when it is not connected, "0" is set. High-order 8 bits of R register output the connection status of each station of RIO1, and the low-order 8 bits output the connection status of each station of RIO2.

**[Caution]**

- (1) Control unit cannot identify the remote I/O unit to which the power cable or communication cable is not connected, or the remote I/O unit to which power is not supplied. Therefore, the output of "Connection status" for those remote I/O units is "0".
- (2) To confirm that the physically existing remote I/O unit is operating normally, use the output of "Connection status" and the output of "No. of error occurrences".

[Related signals]

- (1) Connection status of each channel RIO3 (R10065)
- (2) No. of error occurrences (R10000 to 23)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R^{***})

Cont.	Signal name	Abbrev.	Common (\$)
A	Connection status of each channel RIO3		R10065


[Function]

Connection status of remote I/O unit channel 3 is constantly output to R register.

[Operation]

When remote I/O unit is connected, "1" is set, and when it is not connected, "0" is set. High-order 8 bits of R register output the connection status of each station of RIO3.

High-order 8 bits



[Caution]

- (1) Control unit cannot identify the remote I/O unit to which the power cable or communication cable is not connected, or the remote I/O unit to which power is not supplied. Therefore, the output of "Connection status" for those remote I/O units is "0".
- (2) To confirm that the physically existing remote I/O unit is operating normally, use the output of "Connection status" and the output of "No. of error occurrences".

[Related signals]

- (1) Connection status of each channel RIO1,2 (R10064)
- (2) No. of error occurrences (R10000 to 23)

Cont.	Signal name	Abbrev.	Common (\$)
A	Base PLC mounting check		R10188,9

[Function] [Operation]

This signal indicates the base PLC mounting status. (High priority from the top)

Value	Status
0xFFFFFFFF	Not mounted (no option) ("#11003 APLCvalid" is set to "0", invalid configuration, etc.)
0xFFFFFFFFE	Not mounted (failed to register the initialize function)
0x00000000	Mounted

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	EcoMonitorLight connection: Station #1 to #16 consumed power		R14000,1 to R14150,1

[Function]

This signal stores the consumed power value of EcoMonitorLight which is collected at fixed periods.

The consumed power value is stored across two words of register. Values from the 1st to 1000th digits are stored in R14000, and values 10000 and above are stored in R14001.

Station No.	Device No.	Station No.	Device No.
Station #1	R14000,1	Station #9	R14080,1
Station #2	R14010,1	Station #10	R14090,1
Station #3	R14020,1	Station #11	R14100,1
Station #4	R14030,1	Station #12	R14110,1
Station #5	R14040,1	Station #13	R14120,1
Station #6	R14050,1	Station #14	R14130,1
Station #7	R14060,1	Station #15	R14140,1
Station #8	R14070,1	Station #16	R14150,1

[Operation]

Updated every 1.5 seconds.

Cont.	Signal name	Abbrev.	Common (\$)
A	EcoMonitorLight connection: Station #1 to #16 regenerated power		R14002,3 to R14152,3

[Function]

This signal stores the regenerated power value of EcoMonitorLight which is collected at fixed periods.

The regenerated power value is stored across two words of register. Values from the 1st digit to 1000th digit are stored in R14002, and values 10000 and above are stored in R14003.

Station No.	Device No.	Station No.	Device No.
Station #1	R14002,3	Station #9	R14082,3
Station #2	R14012,3	Station #10	R14092,3
Station #3	R14022,3	Station #11	R14102,3
Station #4	R14032,3	Station #12	R14112,3
Station #5	R14042,3	Station #13	R14122,3
Station #6	R14052,3	Station #14	R14132,3
Station #7	R14062,3	Station #15	R14142,3
Station #8	R14072,3	Station #16	R14152,3

[Operation]

Updated every 1.5 seconds.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	EcoMonitorLight connection: Station #1 to #16 number of reception errors		R14200 to R14350
A	EcoMonitorLight connection: Station #1 to #16 maximum number of successive reception errors		R14201 to R14351
A	EcoMonitorLight connection: Station #1 to #16 number of transmission errors		R14202 to R14352
A	EcoMonitorLight connection: Station #1 to #16 maximum number of successive transmission errors		R14203 to R14353

[Function]

This signal stores the number of reception errors, maximum number of successive reception errors, the number of transmission errors, and maximum number of successive transmission errors of EcoMonitorLight.

Device No.				
Station No.	No. of reception errors	Max. No. of successive reception errors	No. of transmission errors	Max. No. of successive transmission errors
Station #1	R14200	R14201	R14202	R14203
Station #2	R14210	R14211	R14212	R14213
Station #3	R14220	R14221	R14222	R14223
Station #4	R14230	R14231	R14232	R14233
Station #5	R14240	R14241	R14242	R14243
Station #6	R14250	R14251	R14252	R14253
Station #7	R14260	R14261	R14262	R14263
Station #8	R14270	R14271	R14272	R14273
Station #9	R14280	R14281	R14282	R14283
Station #10	R14290	R14291	R14292	R14293
Station #11	R14300	R14301	R14302	R14303
Station #12	R14310	R14311	R14312	R14313
Station #13	R14320	R14321	R14322	R14323
Station #14	R14330	R14331	R14332	R14333
Station #15	R14340	R14341	R14342	R14343
Station #16	R14350	R14351	R14352	R14353

[Operation]

The number of reception errors and the number of transmission errors are updated when an error occurs on the communication with EcoMonitorLight.

The increment stops when the reception or transmission completes without an error.

The maximum number of successive reception errors is updated when the number of successive communication error is larger than the value of R14201 (for the case of station #1).

The maximum number of successive transmission error is updated when the number of successive communication error is larger than the value of R14203 (for the case of station #1).

Cont.	Signal name	Abbrev.	Common (\$)
A	EcoMonitorLight connection: Completion bit		R14400

[Function]

This bit indicates the completion of the power value collecting function.

[Operation]

Bit0 is set to "1" upon completion of collection.

The bit is cleared to zero in the next cycle.

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	EcoMonitorLight connection: Completion status		R14401

[Function]

This signal stores the completion status information of the power value collecting function.

[Operation]

0 indicates the completion.

Non-zero indicates the error.

Error code	Error description
1	Address setting illegal
2	Reception timeout error
3	Reception frame error (CRC error)
4	Function setting illegal
5	Station No. setting illegal
6	Size setting illegal
7	Transmission timeout error

Cont.	Signal name	Abbrev.	Common (\$)
A	EcoMonitorLight connection: Acquired data		R14402 to R14405

[Function]

This signal stores the acquired data of the power value collecting function.

[Operation]

The data which corresponds to the register address (R20290) of station specified by the "EcoMonitorLight connection: Station No." (R20289) is stored.

The data size is the size specified by "EcoMonitorLight connection: Size of data to read" (R20291).

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Serial number		R14500 to R14531

[Function]

The serial number of the workpiece is stored here.

[Operation]

The ASCII code (hexadecimal number) corresponding to the desirable character is set.

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Operator ID		R14532 to R14563

[Function]

The operator ID is stored here.

[Operation]

The ASCII code (hexadecimal number) corresponding to the desirable character is set.

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: NC unit number		R14564 to R14571

[Function]

The CNC unit number which sends the information to the database is stored here.

[Operation]

This data is automatically set at NC startup.

If the unit has a product number, the ASCII code (hexadecimal number) corresponding to the product number is set.

If the unit does not have a product number, this is set to "0".

When MES interface library function is invalid, this signal is set to "0".

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Line number		R14572 to R14587

[Function]

The line number is stored here.

[Operation]

The ASCII code (hexadecimal number) corresponding to the desirable character is set.

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Machine type		R14588

[Function]

The machine type (machining center or lathe) of the machine is stored here.

[Operation]

This data is automatically set at NC startup.

The ASCII code (hexadecimal number) corresponding to "M" (0x4D) is set for the machining center system and "L" (0x4C) is set for the lathe system.

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Database connection status		R14589

[Function]

The connection status between the NC and database, or the cause of DB operation failure is stored here.

[Operation]

The result of the operation request from NC to the database is set.

bit0: 0 (Not connected), 1 (Connected)

bit1: "1" is set when DB operation request condition is disabled.

bit2: "1" is set when no DB operation is selected.

bit3: "1" is set when the record corresponding to retrieval conditions does not exist during updating, deleting or extraction operation.

Bit1 to 3 are cleared when the next operation is requested. (These bits will be "0".)

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Database operation request register		R14590

[Function]

The content of an operation which NC requested to the database is stored here.

[Operation]

bit0: "1" is set when requesting the database operation for the machining result table.

bit1: "1" is set when requesting the database operation for the alarm history table.

bit2: "1" is set when requesting the database operation for the arbitrary information accumulation table.

"0" is set when "1" is set in the corresponding bit of the "MES interface library: Database operation reception register" (R14591).

[Related signals]

- (1) MES interface library: Database operation reception register (R14591)
- (2) MES interface library: Database operation result register (R14592 to R14597)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Database operation reception register		R14591

[Function]

The reception status of the database for the database operation from the NC is stored here.

[Operation]

bit0: "1" is set while accepting database operations for the machining result table.

bit1: "1" is set while accepting database operations for the alarm history table.

bit2: "1" is set while accepting database operations for the arbitrary information accumulation table.

"0" is set when the database operation is completed.

[Related signals]

(1) MES interface library: Database operation request register (R14590)

(2) MES interface library: Database operation result register (R14592 to R14597)

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Database operation result register		R14592 to R14597

[Function]

The result of the database operation is stored here.

[Operation]

0: Normal end

Other than 0: Occurrence of an error

Which registers to be used varies for each data table of the target database operations.

R14592 R14593: Notifies the result of the database operation for the machining result table.

R14594 R14595: Notifies the result of the database operation for the alarm history table.


R14596 R14597: Notifies the result of the database operation for the arbitrary information accumulation table.

[Related signals]

(1) MES interface library: Database operation request register (R14590)

(2) MES interface library: Database operation reception register (R14591)

The timing chart for the request register, the reception register and the result register is as follows.



4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: DB operation selection		R14598

[Function]

This signal is used to select the database operation at the machining end, alarm occurrence, user's option, and rising edge of operation trigger.

[Operation]

Specify "1" to each bit below to set the database operation at the time of machining end.

- bit0: Selecting the registration operation at the time of machining end
- bit1: Selecting the updating operation at the time of machining end
- bit2: Selecting the deleting operation at the time of machining end
- bit3: Selecting the extraction operation at the time of machining end
- bit4: Selecting the registration operation at the time of alarm occurrence
- bit5: Selecting the updating operation at the time of alarm occurrence
- bit6: Selecting the deleting operation at the time of alarm occurrence
- bit7: Selecting the extraction operation at the time of alarm occurrence
- bit8: Selecting the registration operation at the time of user's option
- bit9: Selecting the updating operation at the time of user's option
- bitA: Selecting the deleting operation at the time of user's option
- bitB: Selecting the extraction operation at the time of user's option
- (bitC: No DB operation)
- bitD: Selecting the updating operation at the rising edge of operation trigger
- bitE: Selecting the deleting operation at the rising edge of operation trigger
- bitF: Selecting the extraction operation at the rising edge of operation trigger

"0" is set when the power is turned ON again.

- When the bit0 to bit3 are all set to "0", select the registration operation at the time of machining end while "0" is specified in R14600/bit0 and the DB operation does not perform at the time of machining end while "1" is specified in R14600/bit0.
- When the bit4 to bit7 are all set to "0", select the registration operation at the time of alarm occurrence while "0" is specified in R14601/bit0 and the DB operation does not perform at the time of alarm occurrence while "1" is specified in R14601/bit0.
- When the bit8 to bitB are all set to "0", select the registration operation at the time of user's option while "0" is specified in R14602/bit0 and the DB operation does not perform at the time of user's option while "1" is specified in R14602/bit0.
- When the bitD to bitF are all set to "0", the DB operation does not perform at the rising edge of operation trigger.
- When MES interface library function is invalid, this signal is set to "0".

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

The tables below indicate the combination of each bit of "DB operation selection" (R14598) and following database operations.

- "Selecting the DB operation when "0" is specified for function selection" at machining end (R14600/bit0)
- "Selecting the DB operation when "0" is specified for function selection" at alarm (R14601/bit1)
- "Selecting the DB operation when "0" is specified for function selection" at user's option (R14602/bit0)

R14598				R14600	Operation at machining end
bit0	bit1	bit2	bit3	bit0	
1	0/1	0/1	0/1	0/1	register
0	1	0/1	0/1	0/1	update
0	0	1	0/1	0/1	delete
0	0	0	1	0/1	extract
0	0	0	0	1	no operation
0	0	0	0	0	register

R14598				R14601	Operation at alarm
bit4	bit5	bit6	bit7	bit0	
1	0/1	0/1	0/1	0/1	register
0	1	0/1	0/1	0/1	update
0	0	1	0/1	0/1	delete
0	0	0	1	0/1	extract
0	0	0	0	1	no operation
0	0	0	0	0	register

R14598				R14602	Operation at user's option
bit8	bit9	bitA	bitB	bit0	
1	0/1	0/1	0/1	0/1	register
0	1	0/1	0/1	0/1	update
0	0	1	0/1	0/1	delete
0	0	0	1	0/1	extract
0	0	0	0	1	no operation
0	0	0	0	0	register

R14598				Operation at rising edge of operation trigger
bitC	bitD	bitE	bitF	
0/1	1	0/1	0/1	update
0/1	0	1	0/1	delete
0/1	0	0	1	extract
0/1	0	0	0	no operation

[Related signals]

- (1) MES interface library: Operation trigger (Y1C80)
- (2) MES interface library: Function selection at machining end (R14600)
- (3) MES interface library: Function selection at alarm (R14601)
- (4) MES interface library: Function selection at user's option (R14602)

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Operation table selection		R14599

[Function]

This signal is used to select the data table to be the operation target at the rising edge of operation trigger.

[Operation]

Specify the data table to be the operation target at the rising edge of operation trigger as follows.

- 1: Machining result table
- 2: Alarm history table
- 3: Arbitrary information accumulated table

When "0" is set, none of the operations perform even if each bit of the operation trigger is turned ON.

When MES interface library function is invalid, this signal is set to "0".

[Related signals]

- (1) MES interface library: Operation trigger (Y1C80)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Function selection at machining end		R14600

[Function]

This signal is used to select the database operation-related functions at the time of machining completion.

[Operation]**<bit0: Selecting the DB operation when "0" is specified>**

0: When "0" is specified to R14598/bit0 to 3, registration operation is selected.

1: When "0" is specified to R14598/bit0 to 3, DB operation does not perform.

<bit1: Selecting the setting for data I/O register for MES interface library at the time of update>

0: When the machining is completed while update operation is selected, common data or machining-related data is not set to the data I/O register for MES interface library.

1: When the machining is completed while update operation is selected, common data and machining-related data are set to the data I/O register for MES interface library.

When MES interface library function is invalid, this signal is set to "0".

[Related signals]

(1) MES interface library: DB operation selection (R14598)

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Function selection at alarm		R14601

[Function]

This signal is used to select the database operation-related functions when an alarm occurs.

[Operation]**<bit0: Selecting the DB operation when "0" is specified>**

0: When "0" is specified to R14598/bit4 to 7, registration operation is selected.

1: When "0" is specified to R14598/bit4 to 7, DB operation does not perform.

<bit1: Selecting the setting for data I/O register for MES interface library at the time of update>

0: When an alarm occurs while update operation is selected, common data or alarm-related data is not set to the data I/O register for MES interface library.

1: When an alarm occurs while update operation is selected, common data and alarm-related data are set to the data I/O register for MES interface library.

When MES interface library function is invalid, this signal is set to "0".

[Related signals]

(1) MES interface library: DB operation selection (R14598)

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Function selection at user's option		R14602

[Function]

This signal is used to select the function related to DB operation at the time of user's option.

[Operation]**<bit0: Selecting the DB operation when "0" is specified>**

0: When "0" is specified to R14598/bit8 to B, registration operation is selected.

1: When "0" is specified to R14598/bit8 to B, DB operation does not perform.

When MES interface library function is invalid, this signal is set to "0".

[Related signals]

(1) MES interface library: DB operation selection (R14598)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: G code modal registration selection		R14604, 5

[Function]

This signal is used to set the group of information "G code modal" registered in the database at the time of alarm occurrence.

[Operation]

The G code modal group to be registered to the database is specified in bit units.

Set "1" to the bits corresponding to the group number to be registered.

Group numbers 1 to 19 can be specified.


A total of 12 group numbers can be registered.

When more than 12 group numbers are specified, the 12 groups are registered in ascending order.

When less than 12 group numbers are specified, a total of 12 group numbers, the unspecified group numbers in ascending order in addition to the specified group numbers, are registered.

The following indicates the operation when "1" is set to the bit of each register.

- ♦ R14604 bit0: (not used)
- ♦ R14604 bit1 to F: registers the G code modal in the group 1 to 15
- ♦ R14605 bit0 to 3: registers the G code modal in the group 16 to 19
- ♦ R14605 bit4 to F: (not used)




4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

(Example 1) When setting the group numbers from 1 to 15 (R14604 = 0xFFFE, R14605 = 0x0000)

Register the G code modal belonging in the group numbers 1 to 12.


(G code modals belonging in the group number 13 to 15 are not registered.)



(Example 2) When setting the group numbers from 8 to 15 (R14604 = 0xFF00, R14605 = 0x0000)

Register the G code modal belonging in the group numbers 1 to 4 and 8 to 15.

(G code modals belonging in the group number 1 to 4 are also registered even if R14604 is not specified.)



[Related signals]

(1) MES interface library: G code modal status (R14902 to R14933)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Diagnosis data output: Servomotor insulation degradation detection in progress (PLC axis)	SVIDDD	R20043

[Function]


This signal notifies that the PLC axis connected to the drive unit is under insulation resistance measurement.

[Operation]

This signal outputs that the PLC axis connected to the drive unit is under insulation degradation detection to each axis and spindle of each part system.

When the insulation resistance measurement is started, the bit of the corresponding axis turns ON.

When the insulation resistance measurement is completed, the bit of the corresponding axis turns OFF.

**[Related signals]**

- (1) Diagnosis data output: Motor insulation degradation detection request (IDDD: R20481)

Cont.	Signal name	Abbrev.	Common (\$)
A	Diagnosis data output: Spindle motor insulation degradation detection in progress	SPIDDD	R20048

[Function] [Operation] [Related signals]

Refer to the section on "Diagnosis data output: Servomotor insulation degradation detection in progress (PLC axis) (SVIDDD: R20043)".

Cont.	Signal name	Abbrev.	Common (\$)
A	Laser: Laser output feedback value (W)		R20062, 3

[Function]

The laser output feedback value from the laser I/F unit is stored here.

[Operation]

Two words of R register are used. The low-order 16 bits are stored to R20062, and the high-order 16 bits are stored to R20063.

To match the display of the laser output feedback value to that of the laser output command value, the adjustment value can be set by the parameter "#90008 Isr_fb_gain" or "#90009 Isr_fb_ofs".

[Related signals]

- (1) Laser: Laser beam irradiation ON (Y1CA7)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Current spatial error compensation value (orthogonal coordinate horizontal axis)		R20500, 1	R20700, 1	R20900, 1	R21100, 1	R21300, 1	R21500, 1	R21700, 1	R21900, 1
A	Current spatial error compensation value (orthogonal coordinate vertical axis)		R20502, 3	R20702, 3	R20902, 3	R21102, 3	R21302, 3	R21502, 3	R21702, 3	R21902, 3
A	Current spatial error compensation value (orthogonal coordinate height axis)		R20504, 5	R20704, 5	R20904, 5	R21104, 5	R21304, 5	R21504, 5	R21704, 5	R21904, 5
A	Current spatial error compensation value (1st rotary axis)		R20506, 7	R20706, 7	R20906, 7	R21106, 7	R21306, 7	R21506, 7	R21706, 7	R21906, 7
A	Current spatial error compensation value (2nd rotary axis)		R20508, 9	R20708, 9	R20908, 9	R21108, 9	R21308, 9	R21508, 9	R21708, 9	R21908, 9

[Function]

This signal indicates the current compensation value for each axis.

[Operation]

When the compensation values for each axis are set, these R registers are updated.

The spatial error compensation function can compensate errors only in the first part system.

[Related signals]

- (1) Spatial error compensation in progress (SECI: XD17)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Diagnosis data output: Servomotor insulation degradation detection in progress	SVIDDD	R20522	R20722	R20922	R21122	R21322	R21522	R21722	R21922

[Function] [Operation] [Related signals]

Refer to the section on "Diagnosis data output: Servomotor insulation degradation detection in progress (PLC axis) (SVIDDD: R20043)".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	T code data for L system		R20536, 7	R20736, 7	R20936, 7	R21136, 7	R21336, 7	R21536, 7	R21736, 7	R21936, 7

[Function]

When "#11038 T disp typ" is set to "1" in the lathe system (L system) and a tool function is commanded by automatic operation (memory, MDI), the numerical value following the tool function address T is notified. T code data 1 to 4 notify the tool number only, but this signal notifies the tool command number that is commanded by machining program.

T code data that is output by controller can be selected from 8-digit BCD data, a unsigned 32-bit binary data, or signed 32-bit binary data, by the parameter "#12010 Tbin".

[Operation]**<Program example>**

O100

N010 G28XYZ

N020 T0102

<In case of executing N020 T0102 command when "#11038 T disp typ" is set to "1">

T code data for L system (R20536) = 0x66

T code data (R536) = 0x01

<In case of executing N020 T0102 command when "#11038 T disp typ" is set to "0">

T code data for L system (R20536) = 0

T code data (R536) = 0x01

Data remain unchanged even when the "M function finish" signal (FIN1 or FIN2) is sent back. Reset or "Emergency stop" does not clear the data.

[Caution]

- (1) Commanding "Txx" by manual numerical input will not update this signal. T code data 1 is updated.
- (2) When "#11038 T disp typ" is set to "0", this signal is cleared.
- (3) In the M (machining center) system, this signal is cleared.

[Related signals]

- (1) T function strobe 1 (TF1:XC68)
- (2) T code data 1 (R536-R537)

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	VCC: Number of vibrations	VCC_VIB	R20556	R20756	R20956	R21156	R21356	R21556	R21756	R21956

[Function]

This signal notifies PLC of the number of vibrations in vibration cutting mode.

[Operation]

The value obtained by multiplying the number of vibrations per spindle rotation in the vibration cutting mode by "100" is stored in this register.

This signal is retained even after the vibration cutting mode is canceled. When the commanded spindle speed is "0", the previous information is retained.

[Caution]

The number of vibration in vibration cutting mode is a value rounded off to the second decimal place of the actual numbers of vibrations.

[Related signals]

- (1) VCC: Mode in execution (VCC: X1810)
- (2) VCC: Numbers of vibrations (VCC_VIB: R20556)
- (3) VCC: Frequency (VCC_FRQ: R20557)
- (4) VCC: Spindle rotation speed (VCC_SPREV: R7024,R7025)
- (5) VCC: Vibrating axis (VCC_VIBAX: R20558)
- (6) VCC: Temporary cancel of axis vibration (VCC_INVAX: R22532)
- (7) VCC: Cause of non-vibration (VCC_FACT: R20559)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	VCC: Frequency	VCC - FRQ	R20557	R20757	R20957	R21157	R21357	R21557	R21757	R21957

[Function]

This signal notifies PLC of the frequency in the vibration cutting mode.

[Operation]

The value obtained by multiplying the frequency in the vibration cutting mode by "100" is stored.

This signal is retained even after the vibration cutting mode is canceled. When the commanded spindle speed is "0", the previous information is retained.

[Caution]

The number of vibrations in the vibration cutting mode is a value rounded off to the second decimal place of the actual number of vibrations.

[Related signals]

Refer to the section of the "VCC: Number of vibrations" signal (VCC_VIB: R20556).


4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	VCC: Vibrating axis	VC- C_VIBAX	R20558	R20758	R20958	R21158	R21358	R21558	R21758	R21958

[Function]

This signal notifies PLC of the vibrating axes with bit data.

**Note**

(1) Switching an axis does not change a bit position.

[Operation]

When the control axis starts to vibrate in the vibration cutting mode, the bit corresponding to the control axis turns ON.

When vibration of the control axis converges, the corresponding bit turns OFF.

[Caution]

Only one axis in the programmed part system vibrates. Even for a cutting command with two or more axes such as taper, only the specified one axis vibrates.

[Related signals]

Refer to the section of the "VCC: Number of vibrations" signal (VCC_VIB: R20556).


4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	VCC: Cause of non-vibration	VCC_- FACT	R20559	R20759	R20959	R21159	R21359	R21559	R21759	R21959

[Function]

This signal notifies PLC of the cause of cutting without axis vibration in the cutting blocks or performing unintended vibration even during the vibration cutting mode.

**[Operation]**

When there is non-vibrating axis in the cutting blocks during the vibration cutting mode, the bit which is corresponding to the cause turns ON.

Each bit for devices and the corresponding cause of non-vibration for each vibration cutting mode are shown below.

Bit	Cause																
0	OMR-FF is disabled. ("SV113/bit0" is not set to "1".) Vibration cutting is performed with the OMR-FF disabled.																
1	Not used.																
2	The vibration target axis is the vibration cutting disabled axis. The "vibration cutting disabled axis" here refers to an axis whose corresponding bit of the "VCC: Temporarily disabled axis" signal (R22532 to R23932) is ON.																
3	Vibration condition cannot be obtained. (Example 1) The G94 (feed per minute) is executed and spindle rotation speed is commanded to "0". (Example 2) "G08.5" with different type of vibration condition was commanded to the spindle for which the vibration cutting is being executed in other part system.																
4	There is a superimposed axis during an control axis superimposition or arbitrary axis superimposition among the feed axes.																
5 to 6	Not used.																
7	<div> <div>The vibration target axis is not specified. (Example) When a cutting command for two or more axes is issued without specifying the vibration axis in the address "α" in the command "G08.5 P2"</div> <table> <tr> <th>Program example</th><th>Operation explanation</th></tr> <tr> <td>N01 M03 S3500;</td><td>The first spindle rotates at 3500 (r/min).</td></tr> <tr> <td>N02 G95;</td><td>The mode is set to feed per revolution (synchronous feed) mode.</td></tr> <tr> <td>N03 G08.5 P2;</td><td>The vibration cutting mode starts.</td></tr> <tr> <td>N04 G01 Z-1.0 F0.04;</td><td>Cutting is performed while vibrating the feed axis (Z axis).</td></tr> <tr> <td>N05 G01 X1.0;</td><td>Cutting is performed while vibrating the feed axis (X axis).</td></tr> <tr> <td>N06 G01 Z-2.0 X2.0;</td><td>Since the address "α" was omitted in the vibration cutting mode start command of the N03 block, the vibration cutting control of the N06 block is temporarily disabled. At this time, bit7 of the "VCC: Cause of non-vibration" is turned ON.</td></tr> <tr> <td>N07 G08.5 P0;</td><td>The vibration cutting mode is canceled.</td></tr> </table> </div>	Program example	Operation explanation	N01 M03 S3500;	The first spindle rotates at 3500 (r/min).	N02 G95;	The mode is set to feed per revolution (synchronous feed) mode.	N03 G08.5 P2;	The vibration cutting mode starts.	N04 G01 Z-1.0 F0.04;	Cutting is performed while vibrating the feed axis (Z axis).	N05 G01 X1.0;	Cutting is performed while vibrating the feed axis (X axis).	N06 G01 Z-2.0 X2.0;	Since the address "α" was omitted in the vibration cutting mode start command of the N03 block, the vibration cutting control of the N06 block is temporarily disabled. At this time, bit7 of the "VCC: Cause of non-vibration" is turned ON.	N07 G08.5 P0;	The vibration cutting mode is canceled.
Program example	Operation explanation																
N01 M03 S3500;	The first spindle rotates at 3500 (r/min).																
N02 G95;	The mode is set to feed per revolution (synchronous feed) mode.																
N03 G08.5 P2;	The vibration cutting mode starts.																
N04 G01 Z-1.0 F0.04;	Cutting is performed while vibrating the feed axis (Z axis).																
N05 G01 X1.0;	Cutting is performed while vibrating the feed axis (X axis).																
N06 G01 Z-2.0 X2.0;	Since the address "α" was omitted in the vibration cutting mode start command of the N03 block, the vibration cutting control of the N06 block is temporarily disabled. At this time, bit7 of the "VCC: Cause of non-vibration" is turned ON.																
N07 G08.5 P0;	The vibration cutting mode is canceled.																
8 to E	Not used.																
F	The vibration cutting control is temporarily disabled by the ",V0" command.																

[Related signals]

Refer to the section of the "VCC: Number of vibrations" signal (VCC_VIB: R20556).

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R^{***})

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	CLC: Maximum load		R20564	R20764	R20964	R21164	R21364	R21564	R21764	R21964

[Function]

The maximum value of the cutting load is output to this register.

[Operation]


The maximum value of the spindle load is output in binary. (Range: 0 to 327%)

The value is output in 1% unit regardless of the setting of the parameter "#1256 set28/bit2" (Change current FB (load) output unit).

While the "Spindle up-to-speed" signal (USO) is ON, the value is updated when the load value of the spindle set to "CLC: Spindle selection" (R22540) becomes maximum.

The spindle load when the spindle is stopped or accelerated is not updated as the maximum load.

The value becomes "0" at the rising edge of the "In automatic operation "run"" signal (OP).



(*1) When the "Spindle up-to-speed" signal is OFF, the value of "Maximum load" is not updated.

[Related signals]

- (1) Spindle up-to-speed (USO: X188D)
- (2) In automatic operation "run" (OP: XC12)
- (3) CLC: Spindle selection (R22540)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	CLC: Minimum load		R20565	R20765	R20965	R21165	R21365	R21565	R21765	R21965

[Function]

The minimum value of the cutting load is output to this register.

[Operation]


The minimum value of the spindle load is output in binary. (Range: 0 to 327%)

The value is output in 1% unit regardless of the setting of the parameter "#1256 set28/bit2" (Change current FB (load) output unit).

While the "Spindle up-to-speed" signal (USO) is ON, the value is updated when the load value of the spindle set to "CLC: Spindle selection" (R22540) becomes minimum.

The spindle load when the spindle is stopped or accelerated is not updated as the minimum load.

The value becomes "0" at the rising edge of the "In automatic operation "run"" signal (OP).



(*1) When the "Spindle up-to-speed" signal is OFF, the value of "Minimum load" is not updated.

[Related signals]

Refer to the section of "CLC: Maximum load" signal (R20564).

4 Explanation of Interface Signals

4.2 PLC Input Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Total distance traveled by n-th axis during automatic operation		R24884,5 to R24914,5	R24916,7 to R24946,7	R24948,9 to R24978,9	R24980,1 to R25010,1

[Function] [Operation]

The R register stores the accumulated value of movement amounts that were output to the drive unit.

Values to be stored depend on the settings of the parameter "#1005 plcunit" (PLC unit).

The value is initialized to "0" when the power is turned ON.

[Caution]

- (1) The movement amounts are not added to the total when the traveling direction reverses, for example, at quadrant transitions for circular contours or at joints of the blocks where direction reverses.
- (2) Values to be stored in the R register may decrease by the fractions which are caused by converting units to the one set in the parameter "#1005 plcunit".

[Related signals]

- (1) Cutting feed movement amount n-th axis (R5172)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Power consumption computation: Clear consumption accumulation 1 to 4	IPCC1 to 4	Y700 to 3

[Function]

This signal clears a variety of accumulated power consumption.

[Operation]

The following accumulated power consumption is cleared at the rising edge of this signal.

- Accumulated consumption of entire drive system 1 to 4 (R122 to 9)
- Accumulated consumption of devices other than drive system 1 to 4 (R130 to 7)
- Total accumulated consumption 1 to 4
- Drive system's fixed consumption correction 1 to 4
- Accumulated consumption of servo axis in drive system (fluctuating part) 1 to 4
- Accumulated regeneration of servo axis in drive system (fluctuating part) 1 to 4
- Accumulated consumption of spindle in drive system (fluctuating part) 1 to 4
- Accumulated regeneration of spindle in drive system (fluctuating part) 1 to 4

[Related signals]

- (1) Power consumption computation: Clearing consumption accumulation 1 to 4 complete (IPCCC1 to 4: X708 to B)
- (2) Power consumption computation: Accumulated consumption of entire drive system 1 to 4 (DTIPC1 to 4: R122 to 9)
- (3) Power consumption computation: Accumulated consumption of devices other than drive system 1 to 4 (NDIPC1 to 4: R130 to 7)

Cont.	Signal name	Abbrev.	Common (\$)
A	Integration time input 1	RHD1	Y704

[Function]

The total integration time of the signal specified by the user PLC can be counted and displayed. There are two types of integration time input, integration time input 1 and 2.

[Operation]

The total integration time while this signal (RHD1) is ON is displayed in hours, minutes, and seconds.

The counted (integrated) time is held even when the power is turned OFF. The integration time can be reset and settings such as presets can be changed.

Cont.	Signal name	Abbrev.	Common (\$)
A	Integration time input 2	RHD2	Y705

[Function] [Operation]

Both functions and operations are the same as those of the "Integration time input 1" (RHD1).

Cont.	Signal name	Abbrev.	Common (\$)
B	Data protection key 1	*KEY1	Y708

[Function]

General tool data and coordinate system presets by origin set can be protected with this signal.

[Operation]

When this signal is turned OFF (0), the tool data setting operation is prohibited.

[Caution]

- (1) When an attempt has been made to change the setting while this signal is OFF (0), a message "Data protect" appears in the message section of the screen.
- (2) Even when this signal is OFF (0), the setting of the tool wear compensation amount can be changed by the setting of the parameter "#1760 cfgPR10/bit6" (Wear compensation amount edit in Data protection ON).
- (3) This signal is set to ON (1) when the power is turned ON. This means that data protection has been canceled. Therefore, when the sequence program has no line to use data protection key, the signal is always turned ON (1).

[Related signals]

- (1) Data protection key 2 (*KEY2: Y709)
- (2) Data protection key 3 (*KEY3: Y70A)
- (3) Data protection key (memory card) (*KEY_MemC: Y1C81)
- (4) Data protection key (DS) (*KEY_DS: Y1C82)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
B	Data protection key 2	*KEY2	Y709

[Function]

Various data such as user parameters, common variables, Email notification to operator, range setting screen, machining condition selection, laser processing condition, etc. can be protected.

[Operation]

When this signal is turned OFF (0), the following data settings and operations are prohibited.

- ♦ User parameters
- ♦ Common variables
- ♦ Email notification to operator
- ♦ Data on range setting screen
- ♦ Switching selection parameter (machining condition selection)
- ♦ Setting application name and condition name (machining condition selection)
- ♦ Performing initialization (machining condition selection)

[Caution]

- (1) When an attempt has been made to change the setting while this signal is OFF (0), a message "Data protect" appears in the message section of the screen.
- (2) This signal is set to ON (1) when the power is turned ON. This means that data protection has been canceled. Therefore, when the sequence program has no line to use data protection key, the signal is always turned ON (1).

[Related signals]

- (1) Data protection key 1 (*KEY1: Y708)
- (2) Data protection key 3 (*KEY3: Y70A)
- (3) Data protection key (memory card) (*KEY_MemC: Y1C81)
- (4) Data protection key (DS) (*KEY_DS: Y1C82)

Cont.	Signal name	Abbrev.	Common (\$)
B	Data protection key 3	*KEY3	Y70A

[Function]

Data of the machining program of NC memory and NC memory 2 can be protected.

[Operation]

When this signal is turned OFF (0), the editing of the machining program of NC memory and NC memory 2 is prohibited. The target device is "memory".

[Caution]

- (1) When an attempt has been made to edit while this signal is OFF, a message "Data protect" appears in the message section of the screen.
- (2) This signal is set to ON (1) when the power is turned ON. This means that data protection has been canceled. Therefore, when the sequence program has no line to use data protection key, the signal is always turned ON (1).

[Related signals]

- (1) Data protection key 1 (*KEY1: Y708)
- (2) Data protection key 2 (*KEY2: Y709)
- (3) Data protection key (memory card) (*KEY_MemC: Y1C81)
- (4) Data protection key (DS) (*KEY_DS: Y1C82)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Handle pulse encoder communication connector priority		Y70D

[Function] [Operation]

The priority of the handle input pulse is determined when the parameter "#1239 set11/bit1" is OFF.

0: Remote I/O connecting handle priority

1: Handle pulse encoder communication connector connecting handle priority

[Related signals]

- (1) Handy terminal key 1 to 45 (X1CD0 to X1CFC)
- (2) Handle/Incremental feed magnification code m (MP1, MP2, MP4: YC80, YC81, YC82)
- (3) Handle/incremental feed magnification method selection (MPS: YC87)
- (4) Handy terminal Data area top address (R297)
- (5) Handy terminal Data valid number of registers (R298)
- (6) Handy terminal Cause of communication error (R299)
- (7) 1st handle/incremental feed magnification (R2508, 9)

Cont.	Signal name	Abbrev.	Common (\$)
B	PLC axis near point detection n-th axis	*PCD1 to 8	Y718 to F

[Function]

The near point dog signal of the PLC axis reference position return is input.

[Operation]

Set the near point dog signal of the PLC axis reference position return for the following devices in the PLC.

Device No.		Signal name
Y718	PCD1	PLC axis near point detection 1st axis
Y719	PCD2	PLC axis near point detection 2nd axis
Y71A	PCD3	PLC axis near point detection 3rd axis
Y71B	PCD4	PLC axis near point detection 4th axis
Y71C	PCD5	PLC axis near point detection 5th axis
Y71D	PCD6	PLC axis near point detection 6th axis
Y71E	PCD7	PLC axis near point detection 7th axis
Y71F	PCD8	PLC axis near point detection 8th axis

Note

- (1) Setting the dog signal in the medium-speed processing of the PLC is less responsive than setting the dog signal in the high-speed processing of the PLC.

Cont.	Signal name	Abbrev.	Common (\$)
A	PLC axis 1st to 3rd handle valid	PCH1 to 3	Y720 to 2

[Function]

This signal is designated when handle feeds using 1st to 3rd handles are to be carried out with the PLC axis.

[Operation]

Designate with the following devices to carry out handle feed with the PLC axis.

Device No.		Signal name
Y720	PCH1	PLC axis 1st handle valid
Y721	PCH2	PLC axis 2nd handle valid
Y722	PCH3	PLC axis 3rd handle valid

Note

- (1) When this signal is ON, each handle is dedicated to the PLC axis and is not valid for the NC control axis. The "n-th handle axis selection code" (HSn1 to HSn16) and the "n-th handle valid" (HSnS) are used to select each handle axis.
- (2) The handle feed magnification is common with that for the NC control axis.

4 Explanation of Interface Signals**4.3 PLC Output Signals (Bit Type: Y***)**

Cont.	Signal name	Abbrev.	Common (\$)
A	PLC axis control buffering mode valid	PABMI	Y723

[Function] [Operation]

In buffering mode, the PLC axis command (control information data) can be commanded to multiple blocks. This enables a smooth changeover of commands.


<Control information data>

The control data for the buffering mode is set in three blocks.

The contents of each control information data have the same configuration as the normal control information data.

At the time of execution, the axis moves in the order in which each control information data is started. After the movement is completed, the movement of the next block is started.

(If the start signals are turned ON simultaneously, it will be performed in the order of A, B, and C.)




4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

[Timing chart]

G1 -> G1 -> G0 -> G1 (Same axis)




Note

(1) Change and start the data after the busy signal turns OFF. Starting while the busy signal is ON is ignored.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

G0 -> G1 -> G1 -> G0 (Two axes)

**[Caution]**

Only one set of buffering mode can be commanded. When two or more sets are commanded simultaneously, the sets commanded later cause an alarm.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Power consumption computation: Enable consumption accumulation 1 to 4	IPCE1 to 4	Y724 to 7

[Function]

This signal enables "Consumption accumulation 1 to 4".

[Operation]

The following kinds of consumption accumulation are performed while this signal is ON.

- Accumulated consumption of entire drive system 1 to 4 (R122 to 9)
- Accumulated consumption of devices other than drive system 1 to 4 (R130 to 7)
- Total accumulated consumption 1 to 4
- Drive system's fixed consumption correction 1 to 4
- Accumulated consumption of servo axis in drive system (fluctuating part) 1 to 4
- Accumulated regeneration of servo axis in drive system (fluctuating part) 1 to 4
- Accumulated consumption of spindle in drive system (fluctuating part) 1 to 4
- Accumulated regeneration of spindle in drive system (fluctuating part) 1 to 4

[Related signals]

- (1) Power consumption computation: Consumption accumulation ON 1 to 4 (IPCE1 to 4: X700 to 3)
- (2) Power consumption computation: Accumulated consumption of entire drive system 1 to 4 (DTIPC1 to 4: R122 to 9)
- (3) Power consumption computation: Accumulated consumption of devices other than drive system 1 to 4 (NDIPC1 to 4: R130 to 7)
- (4) Power consumption computation: Consumption of devices other than drive system (NDPC: R304, 5)
- (5) Power consumption computation: Drive system's fixed consumption correction (DFPCC: R306, 7)


Cont.	Signal name	Abbrev.	Common (\$)
A	CRT changeover completion	CRTFN	Y728

[Function]

When one setting display device is used as the display device of multiple control devices, this signal is used to inform the controller that it has been switched as its own display device.

[Operation]

When this signal is turned ON, the currently selected screen is displayed at the rising edge. For the setting and display unit screen, the display screen of the control device before switching remains. Therefore, input this signal to switch to the own screen display.

[Timing chart]

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)


Cont.	Signal name	Abbrev.	Common (\$)
A	Screen display request	SCRON	Y729

[Function]

The screen backlight, which was turned OFF with the screen saver function, can be turned ON again.

[Operation]

- The backlight is turned ON again at the rising edge of this signal. Counting of the time until the the backlight turns OFF starts at the falling edge of this signal.
- When this signal is output to the CNC while the screen is displayed, the time until the screen is cleared is counted again.

**Note**

- (1) While the "Screen display request" signal is ON, the backlight is not turned OFF with the parameter "#8078 Screen Saver Timer". However, the backlight can be turned OFF using the [SHIFT] and [C.B/CAN] keys.
- (2) After switching the "Screen display request" signal (Y729), wait at least one scan before switching again.


Cont.	Signal name	Abbrev.	Common (\$)
A	Collecting diagnosis data stop		Y72B

[Function]

Data collection will be stopped by turning this signal ON while collecting history data using operation history function. Data collection will be started (resumed) by turning the signal OFF in data stop mode.

[Operation]

- Collecting diagnosis data stop signal stops data collection during rising edge movement following the signal turned ON from OFF.
This signal starts data collection during falling edge movement following the signal turned OFF from ON.
- Data collection will be stopped when this signal is turned ON while diagnosis data collection is in progress (when the "Collecting diagnosis data" signal is turned ON).
At that time, data collection will be stopped in approximately 500 ms after this signal is turned ON. The "Collecting diagnosis data" signal is turned OFF when data collection is stopped.
- Data collection is started when this signal is turned OFF while diagnosis data collection is stopped (when the "Collecting diagnosis data" signal is turned OFF).
Data collection is started in approximately 500 ms after this signal is turned OFF. The "Collecting diagnosis data" signal is turned ON when data collection is started.

**Note**

- (1) This signal is ignored this signal is operated from the first scan after the power is turned ON.

[Related signals]

- (1) Collecting diagnosis data (X723)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Sampling start/stop	SMPTRG	Y72C

[Function]

This signal is used when NC data sampling is started or stopped on the PLC device.

[Operation]

- When "2" (PLC device) is selected for "Start condition":
This signal is turned ON while "1" (Start sampling) is set in "Start sampling", data sampling is started.
- When "2" (PLC device) is selected for "Termination condition":
The sampling is terminated when this signal is turned OFF during sampling.
- This signal is ignored in the following cases:
 - When neither "Start condition" nor "Termination condition" is set to "2"
 - When "Start sampling" is set to "0" (Stop sampling)

Cont.	Signal name	Abbrev.	Common (\$)
A	Pallet program registration Ext. workpiece coordinate transfer ready		Y72F

[Function] [Operation]

To transfer external workpiece coordinate offset (EXT) in the pallet 4 page registration, turn this signal ON. NC starts transfer processing at the rising edge of this signal.

When the external workpiece coordinate transfer completion signal is turned ON, turn this signal OFF.

It takes approximately 8 ms from the start to the end of transfer processing. If the transfer completion signal is not turned ON even after 8 ms has passed since the transfer ready signal was turned ON, reconsider the value of R register 4100 and 4102.


NC turns the external workpiece coordinate transfer completion signal OFF at the falling edge of this signal.

To turn ON the transfer ready signal from the machining program, the "Recalculation request" and the "M function finish" (FIN1 or FIN2) must be turned ON after the external workpiece coordinate transfer completion signal is turned ON.

When recalculation is not requested, operation of the pre-read machining program will be carried out using the external workpiece coordinate offset prior to the change.

When M function has been completed before transfer is completed, the external workpiece coordinate offset data to be used in the machining program will not be changed from the one prior to the change until the transfer completion signal is turned ON.

This signal must be turned ON while the external workpiece coordinate transfer completion signal is OFF.

[Timing chart]**[Related signals]**

- (1) Pallet program registration Ext. workpiece coordinate transfer completion (X758)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Display changeover \$1 to \$8	DISP1 to 8	Y730 to 7

[Function]

The displayed part system of the multiple part systems can be changed.

[Operation]

The displayed part system is changed at the rising edge of each display changeover signal.

The screen display for the multiple part systems is a screen for displaying one of the part systems. Thus, which part system to be displayed is determined by these signals.

If both of these signals are started up simultaneously, they are invalid.

If "#11035 Sys. change limit" is set to "2", this signal is invalid.

An example of the displayed part system change is as follows.

(Example) When there are three effective part systems

	State A	State B	State C	State D	State E	State F
Y730 (\$1)	0	0	0	0	0	0
Y731 (\$2)	0	0	1	1	0	1
Y732 (\$3)	0	1	1	0	0	1
Y733 (\$4)	0	1	0	0	0	0
Y734 (\$5)	0	0	0	0	0	0
Y735 (\$6)	0	0	0	0	0	0
Y736 (\$7)	0	0	0	0	0	0
Y737 (\$8)	0	0	0	0	0	0
The state of display	Part system 1 is displayed (*1)	Change to Part system 3. (*2)	Part system 3 remains displayed.	Change to Part system 2.	Part system 2 remains displayed.	Part system 2 remains displayed. (*3)

(*1) If all signals are "0" when the power is turned ON, part system 1 is displayed.

(*2) If a signal of any inactive part system is changed, the displayed part system is unchanged.

(*3) If a signal of two or more part systems are changed at a time, the displayed part system is unchanged.

Cont.	Signal name	Abbrev.	Common (\$)
A	Single block between part systems	MSBK	Y73A

[Function]


This signal enables the "Single block between part systems" operation.

This is a function for performing single-block operation while maintaining the synchronization relationship between each system in the operation of two or more part systems in a multi-part system.

[Operation]

In a multi-part system in which single-block operation is performed while the "Single block between part systems" signal is ON, if single-block stop occurs in a part system, automatic operation pause occurs in other part systems.

This signal is enabled if any of the part systems is in single-block operation. If all part systems are in continuous operation, this signal is disabled.

**[Related signals]**

- (1) Single block (SBK: YC12)
- (2) Synchronization between part systems OFF (MSYNC: YCF8)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Manual arbitrary reverse run mode	MORR	Y73C

[Function]

This signal enables manual arbitrary reverse run function.


The manual arbitrary reverse run is performed by controlling the feedrate during automatic operation in the memory or MDI mode. The feedrate is controlled in proportion to the manual (jog) feed speed or manual rotation speed (handle).

[Operation]

The manual arbitrary reverse run is enabled while in memory or MDI mode and when this signal is ON. During the manual arbitrary reverse run, the manual mode (handle or jog) must be turned ON at the same time as this signal turns ON, as the axis is moved in the manual mode (handle or jog).

Speed control during manual arbitrary reverse run is also enabled if the "Manual arbitrary reverse run speed selection" (MORSP) and the "Manual arbitrary reverse run speed multiplier" (R379) are commanded.

However, when the parameter "#1260 set32/bit0" (Switching to actual cutting mode during automatic operation) is set to "1", switching ON/OFF of this signal in a specific operation block during thread cutting, thread cutting cycle and tapping cycle does not switch ON/OFF of the "Manual arbitrary reverse run mode ON" (X715). For the specific movement block, refer to the section of the "Actual cutting mode (thread, tap) in manual arbitrary reverse run" (Y761).

[Operation sequence]**[Related signals]**

- (1) Manual arbitrary reverse run mode ON (PCHKO: X715)
- (2) Manual arbitrary reverse run: Reverse run ON (MOREV: X716)
- (3) Thread, tap block stopping in manual arbitrary reverse run (MBSTP: X74D)
- (4) Thread, tap reverse run prohibition alarm in manual arbitrary reverse run (MRVNG: X74E)
- (5) Manual arbitrary reverse run speed selection (MORSP: Y73D)
- (6) Actual cutting mode (thread, tap) in manual arbitrary reverse run (MRCMD: Y761)
- (7) Manual arbitrary reverse run: MSTB reverse run prohibited (MRPSG: YCFC)
- (8) Manual arbitrary reverse run: Reverse run block stop designated part system (RBSSY: YD01)
- (9) Manual arbitrary reverse run handle selection (R375)
- (10) Manual arbitrary reverse run speed multiplier (R379)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Manual arbitrary reverse run speed selection	MORSP	Y73D

[Function]

In speed control during manual arbitrary reverse run, this signal enables the program check speed constant.

[Operation]

When this signal is ON, the program check speed constant is used for speed control. When this signal is OFF, the command speed in the normal machining program is used.

The feedrate for manual arbitrary reverse run is controlled by the "Manual arbitrary reverse run speed multiplier" (R379) when operation is in jog mode. In handle mode, the feedrate is controlled by the ratio of the handle pulses per unit time and "#19007 program check constant".

When this signal is OFF, the command speed in the normal machining program is used.

<The speed used when the "Manual arbitrary reverse run speed selection" (MORSP) is ON>

- ♦ When jog mode is selected:

Manual arbitrary reverse run speed is calculated from the following formula.

$$\frac{\text{Manual arbitrary reverse run speed multiplier}}{\text{Program check speed constant}} \times \text{Command speed in the machining program}$$

- ♦ When handle mode is selected:

The manual arbitrary reverse run speed can be calculated from the following formula.

$$\frac{\begin{array}{l} \text{Change amount of handle pulse per unit time} \\ \times \text{Manual arbitrary reverse run speed multiplier} \end{array}}{\text{Program check speed constant}} \times \text{Command speed in the machining program}$$

- ♦ Rapid traverse override or cutting override can be exerted on the command speed in the machining program.
- ♦ Reverse motion is performed if the value of the manual arbitrary reverse run speed calculated with the above formula is a negative value.
- ♦ As the same rate of change of the manual arbitrary reverse run speed is applied to all part systems, synchronization of the part systems can be maintained.
However, synchronization is not guaranteed when synchronization relationship is broken due to rapid traverse override or cutting override.
- ♦ If the value of the "Manual arbitrary reverse run speed multiplier" (R379) or the amount of change of handle pulses exceeds "#19007 Prg check constant", the value is clamped at "#19007 Prg check constant".

The manual arbitrary reverse run speed never exceeds the command speed.

[Related signals]

- (1) Manual arbitrary reverse run mode ON (PCHKO: X715)
- (2) Manual arbitrary reverse run: Reverse run ON (MOREV: X716)
- (3) Thread, tap block stopping in manual arbitrary reverse run (MBSTP: X74D)
- (4) Thread, tap reverse run prohibition alarm in manual arbitrary reverse run (MRVNG: X74E)
- (5) Manual arbitrary reverse run mode (MORR: Y73C)
- (6) Actual cutting mode (thread, tap) in manual arbitrary reverse run (MRCMD: Y761)
- (7) Manual arbitrary reverse run: MSTB reverse run prohibited (MRPSG: YCFC)
- (8) Manual arbitrary reverse run: Reverse run block stop designated part system (RBSSY: YD01)
- (9) Manual arbitrary reverse run handle selection (R375)
- (10) Manual arbitrary reverse run speed multiplier (R379)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	High-speed simple program check mode	SMLK	Y73E

[Function]

This signal enables the high-speed simple program check function.

[Operation]

When this signal is enabled, the machining program is executed while all axes are in machine lock.

In this operation, the feedrate of the machining program changes according to the value of the "High-speed simple program check: Time reduction coefficient" (R378).

[Related signals]

- (1) High-speed simple program check mode ON (SMLKO: X712)
- (2) High-speed simple program check: Time reduction coefficient (R378)
- (3) High-speed simple program check: Time measurement output (R372,3)

Cont.	Signal name	Abbrev.	Common (\$)
A	Interference check between part systems: Interference check enabled	CCHK	Y73F

[Function]

This signal enables interference check between part systems.

[Operation]

When this signal is turned ON, the interference check between part systems is started.

When this signal is turned OFF, the interference check between part systems is completed.

[Related signals]

- (1) Interference check between part systems: Mode is active (X773)
- (2) Interference check between part systems: Setting error alarm information (R101)
- (3) Interference check between part systems: Alarm information (R102)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Contactors shutoff test	MCT	Y742

[Function]

This signal carries out a contactor shutoff test.


[Operation]

Send a "ready OFF" command to the drive unit at the rising edge of the "Contactor shutoff test" signal and shut the drive unit side contactor OFF. Then, turn MC_ct1 of I/O unit connector (contactor shutoff output 1) output OFF and shut the NC side contactor OFF.

Confirm that the contactor's status is OFF by monitoring contactor's auxiliary B contact signal, then send a "ready ON" command to the drive unit to turn the drive unit side contactor ON. Turn ON the safety monitor connector output, then the NC side contactor. After that, turn the "24 hours continuous operation" signal OFF.

If the contactor shutoff could not be confirmed within 5 seconds, the alarm (Y20 0008) is output and the status turns to the emergency stop.

If the motor power cannot be shut off by STO within 5 seconds when STO function is enabled, the alarm (Y20 0013) is output and the status turns to the emergency stop.

[Timing chart]**[Caution]**

- (1) Contactor shutoff test must be carried out when the drive power can be shut off without causing any problem.
- (2) Vertical axis requires brake circuit, etc. for a fall prevention.

[Related signals]

- (1) 24 hours continuous operation (X752)
- (2) Emergency stop cause (R69)

Cont.	Signal name	Abbrev.	Common (\$)
A	PLC skip 1 to 8		Y748 to F

[Function]

This is the skip input signal from the PLC.

Skip operation can be performed under conditions set by built-in PLC.

PLC skip operates by logical sum of the high speed skip (a fixed signal on the hardware).

[Operation]

This can be used for the skip related functions. (G31 skip, tool length measurement, etc.)

[Caution]

- (1) The PLC skip signal is output to the skip input.
- (2) When PLC skip is used, the coasting amount from the skip signal input will be slightly longer than the high speed skip.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Automatic power OFF request		Y75D

[Function]

Automatic power OFF function notifies that the control unit's power can be turned OFF after shutting the display unit down (do not turn OFF the power) by inputting the "Automatic power OFF request" signal from user PLC to NC.

For M800VW/M80VW Series, an Windows-equipped display unit can be shut down automatically.

[Operation]

When the user PLC turns ON the "Automatic power OFF request" signal (Y75D), NC requests the display unit to be shut down after turning ON the "Power OFF processing" signal (X707).


<M800VW/M80VW Series>

The device specified by the "Power OFF indication Y device No." signal (R215) is turned ON after NC has received the shutdown completion notification from the display unit or the timeout time has passed.

When the control unit and display unit use different power supplies, confirm that the Y device which notifies the power failure (Y device specified by R215) is turned ON, and then turn OFF the power of the control unit.

<M800VS/M80V Series>

One second after the "Power OFF processing" signal (X707) is turned ON, turn ON the device specified by the "Power OFF indication Y device No." (R215) signal. Turn OFF the control unit's power after confirming the Y device (Y device designated with R215) which notifies that the power is turned OFF has turned ON.




4 Explanation of Interface Signals


4.3 PLC Output Signals (Bit Type: Y***)

[Timing chart]

<M800VW/M80VW Series>



<M800VS/M80V Series>



[Caution]

- (1) Time including the time required for HMI application termination and Windows shutdown has to be set in the machine parameter "#11007 PC Timeout".
- (2) Normal power OFF processing is executed when the control unit's power is turned OFF during automatic power OFF processing.
- (3) When an illegal IP address is set to the machine parameter "#11005 PC IP address", the personal computer on the network may be turned OFF.
- (4) Do not execute the automatic power OFF function during editing or file I/O operation, etc.
- (5) The automatic power OFF function is carried out to the display unit set to the machine parameter "#11005 PC IP address".
- (6) During spindle rotation or control axis movement, execute automatic power OFF after these actions stopped.

[Related signals]

- (1) Power OFF processing (X707)
- (2) Power OFF indication Y device No. (R215)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Actual cutting mode (thread, tap) in manual arbitrary reverse run	MRCMD	Y761

[Function]

This signal determines operation concerning the thread cutting and tapping blocks during manual arbitrary reverse run.


[Operation]

When this signal is ON, thread cutting and tapping during manual arbitrary reverse run operate in the actual cutting mode (the command speed of the machining program).

When this signal is turned OFF, the thread cutting and tapping during manual arbitrary reverse run operate in dry run operation mode (program check speed).

However, even if this signal is switched ON/OFF in the specific operation block during reverse run, thread cutting, thread cutting cycle and tapping cycle, ON/OFF of the "Manual arbitrary reverse run: Actual cutting mode ON" signal (X714) is not switched.

Specific operation block



----- Specific operation block


In the figure above, when this signal is turned ON/OFF while the block with dotted line is moving, ON/OFF of the "Manual arbitrary reverse run: Actual cutting mode ON" signal (X714) is switched at the following timing:

Thread cutting: At the end point of (3) block

Thread cutting cycle: At the end point of (4) block

Tapping cycle: At the end point of (5) block

The following shows the operation sequence when this signal turns ON while (2) block of thread cutting is executed in the figure above.



The "Manual arbitrary reverse run: Actual cutting mode ON" signal (PNCMDO: X714) does not turn ON at the timing when the "Actual cutting mode (thread, tap) in manual arbitrary reverse run" signal (MRCMD: Y761) turns ON. ((a) in the operation sequence)

At the end point of "(3) Block", the "Manual arbitrary reverse run: Actual cutting mode ON" signal (PNCMDO: X714) turns ON. ((b) in the operation sequence)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

[Related signals]

- (1) Manual arbitrary reverse run: Actual cutting mode ON (PNCMD0: X714)
- (2) Manual arbitrary reverse run mode ON (PCHKO: X715)
- (3) Manual arbitrary reverse run: Reverse run ON (MOREV: X716)
- (4) Thread, tap block stopping in manual arbitrary reverse run (MBSTP: X74D)
- (5) Thread, tap reverse run prohibition alarm in manual arbitrary reverse run (MRVNG: X74E)
- (6) Manual arbitrary reverse run mode (MORR: Y73C)
- (7) Manual arbitrary reverse run speed selection (MORSP: Y73D)
- (8) Manual arbitrary reverse run: MSTB reverse run prohibited (MRPSG: YCFC)
- (9) Manual arbitrary reverse run: Reverse run block stop designated part system (RBSSY: YD01)
- (10) Manual arbitrary reverse run handle selection (R375)
- (11) Manual arbitrary reverse run speed multiplier (R379)

Cont.	Signal name	Abbrev.	Common (\$)
A	Encoder 1 arbitrary pulse selection		Y764
A	Encoder 2 arbitrary pulse selection		Y765


[Function]

These signals select encoder arbitrary pulse.

[Operation]

Device No.	Signal name	Details
Y764	Encoder 1 arbitrary pulse selection	Select arbitrary pulse input 1 and 2 set in R register when entering arbitrary pulse with encoder input 1. 0: Encoder 1 arbitrary pulse 1 1: Encoder 1 arbitrary pulse 2
Y765	Encoder 2 arbitrary pulse selection	Select arbitrary pulse input 1 and 2 set in R register when entering arbitrary pulse with encoder input 2. 0: Encoder 2 arbitrary pulse 1 1: Encoder 2 arbitrary pulse 2

[Timing chart]



[Caution]

Switching each encoder's arbitrary pulse selection (Y764 and 765) must be carried out during the spindle stop.

[Related signals]

- (1) Encoder 1 arbitrary pulse valid (Y766)
- (2) Encoder 2 arbitrary pulse valid (Y767)
- (3) Encoder 1 arbitrary pulse 1 (R456)
- (4) Encoder 1 arbitrary pulse 2 (R457)
- (5) Encoder 2 arbitrary pulse 1 (R458)
- (6) Encoder 2 arbitrary pulse 2 (R459)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Encoder 1 arbitrary pulse valid		Y766
A	Encoder 2 arbitrary pulse valid		Y767

[Function]

These signals select valid/invalid for encoder arbitrary pulse.

[Operation]

Device No.	Signal name	Details
Y766	Encoder 1 arbitrary pulse valid	Select valid/invalid for arbitrary pulse with the encoder input 1. 0: Invalid (conventional 1024 pulse fixed input) 1: Valid (arbitrary pulse input)
Y767	Encoder 2 arbitrary pulse valid	Select valid/invalid for arbitrary pulse with the encoder input 2. 0: Invalid (conventional 1024 pulse fixed input) 1: Valid (arbitrary pulse input)

Turn OFF the arbitrary pulse valid signal when using the conventional 1024 pulse encoder.

[Caution]

Turning ON/OFF the encoder arbitrary pulse valid (Y766 and Y767) of the each encoder must be carried out during the spindle stop.

[Related signals]

- (1) Encoder 1 arbitrary pulse selection (Y764)
- (2) Encoder 2 arbitrary pulse selection (Y765)
- (3) Encoder 1 arbitrary pulse 1 (R456)
- (4) Encoder 1 arbitrary pulse 2 (R457)
- (5) Encoder 2 arbitrary pulse 1 (R458)
- (6) Encoder 2 arbitrary pulse 2 (R459)

Cont.	Signal name	Abbrev.	Common (\$)
A	Door open I	DOOR1	Y768

[Function]

This signal stops all axes, and shuts OFF the contactor.

[Operation]

The NC carries out the following operations when the "Door open I" signal turns ON.

- A deceleration stop is carried out for all axes (servo axes and spindles).
- A ready OFF state occurs after all axes stop, and each drive unit shuts OFF the contactor.
- The "Door open enable" signal turns ON.

The NC carries out the following operations when the "Door open I" signal turns OFF.

- A ready ON and servo ON state occurs for all axes.
- The "Door open enable" signal turns OFF.

[Caution]

- (1) Handling of the PLC axis

For the PLC axis, stop it at the PLC and then output the "Door open I" signal to the NC. If the "Door open I" signal is input without stopping the PLC axis, the axis stops with a dynamic brake method due to the ready OFF state.

- (2) Handling of the analog spindle

When an analog spindle is connected, it is not possible to confirm that the spindle has completely stopped with the NC. Thus, confirm that the spindle has completely stopped using the PLC, before opening the door.

Since the spindle may resume rotation immediately after the door is closed, for safety, turn the forward run and reverse run signals OFF when the door is opened.

- (3) Opening the door during ATC operation

To open the door while ATC is operating, apply an interlock with the user PLC.

[Related signals]

- (1) Door open enable (DROPNS: XCD8)

4 Explanation of Interface Signals


4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Interference check III: Enable interfering object selection data	ITF3VLDT	Y769

[Function] [Operation]

This signal enables the interfering object selection set in the system variables (#40000 to #40097) or the "Interference check III: Interfering object selection" (R20304 to R20449).

The "Interference check III: Interfering object selection" is incorporated into NC as the interference check III execution data at the rising edge of this signal.

**[Related signals]**

- (1) Interference check III: Interfering object selection data setting completed (ITF3DTF: X771)


Cont.	Signal name	Abbrev.	Common (\$)
A	Interference check III: Interference check III mode	ITF3CMD	Y76A

[Function]

The interference check III is executed.

[Operation]

While this signal is ON, interference check between interfering objects is performed using the interfering object data set. If the interfering object selection is changed while this signal is ON, the interference check is performed using the changed data at the completion of the interfering object selection.

**[Related signals]**

- (1) Interference check III: In interference check III mode (ITF3MD:X772)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	High-speed simple program check: Enable coordinate position check	SPSC	Y76B

[Function]


This signal enables the following check when NC reset is input during high-speed simple program check: difference check for the workpiece coordinate position and command machine coordinate position at the beginning of the machining program and at NC reset input.

[Operation]

If the following conditions are met, the workpiece coordinate position and command machine coordinate position at the beginning of the machining program are compared with these positions at NC reset input: this signal is turned ON during high-speed simple program check and NC reset is input while the "High-speed simple program check: Coordinate position check ON" signal (X713) is ON.

If any difference is detected, an operation error occurs.

This check is performed only for the following axes: the axes for which workpiece coordinate position/command machine coordinate position checks are enabled with parameters "#8226 work position check" and "#8227 machine position check".

[Timing chart]**[Related signals]**

- (1) High-speed simple program check mode (SMLK: Y73E)
- (2) High-speed simple program check mode ON (SMLKO: X712)
- (3) High-speed simple program check: Coordinate position check ON (SPSCO: X713)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	PLC axis control valid n-th axis	PLCAEn	Y770 to 7

[Function]

PLC axis control process is executed with the control information data while the PLC axis control valid signal is ON.

[Operation]

To turn ON the PLC axis control valid signal, specify it with the following device.

Device No.	Signal name
Y770	PLC axis control valid 1st axis
Y771	PLC axis control valid 2nd axis
Y772	PLC axis control valid 3rd axis
Y773	PLC axis control valid 4th axis
Y774	PLC axis control valid 5th axis
Y775	PLC axis control valid 6th axis
Y776	PLC axis control valid 7th axis
Y777	PLC axis control valid 8th axis

Note

- (1) When the PLC axis control valid signal is turned OFF, the reset state is activated.

[Related signals]

- (1) PLC axis control buffering mode valid (PABMI: Y723)
- (2) PLC axis control information address (R440 to R443)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization valid	GBON	Y778

[Function]

This signal enables the guide bushing (G/B) spindle synchronization function.

[Operation]

The spindle synchronization state is entered by turning ON this signal.

[Related signals]

- (1) G/B spindle synchronizing mode (GBMOD: X778)
- (2) G/B spindle synchronization: Position control synchronizing (GBSYN: X779)
- (3) G/B spindle synchronization: Phase shift amount (R466)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization: Phase alignment	GBPHS	Y77A

[Function]

This signal aligns the phase (relative position) of the rotating reference spindle and the guide bushing (G/B) spindle.

[Operation]

When this signal is ON, and when the reference spindle and the guide bushing spindle are in the synchronous state (the "G/B spindle synchronization valid" signal (GBON) is ON) and also when they are in the steady rotation state, a phase alignment of the reference spindle and the G/B spindle is carried out targeting the phase gap (relative position) between the reference spindle and the G/B spindle that have been saved by the "G/B spindle synchronization phase memory" (GBPHM).

[Related signals]

- (1) G/B spindle synchronization valid (GBON: Y778)
- (2) G/B spindle synchronization: Phase memory (GBPHM: Y77B)
- (3) G/B synchronization: Phase alignment complete (GBPHF: X77A)
- (4) Spindle up-to-speed (USO: X188D)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization: Phase memory	GBPHM	Y77B

[Function]

This signal saves the phase gap (relative position) between the reference spindle and the guide bushing (G/B) spindle in the NC.

[Operation]

The reference spindle and the guide bushing spindle are rotated by one revolution or more (until the Z phase is passed) in synchronous state (the "G/B spindle synchronization valid" (GBON) is ON), and then stopped. After both of them stop, the NC saves the phase gap (relative position) at the rising edge of this signal.

[Related signals]

- (1) G/B spindle synchronization valid (GBON: Y778)
- (2) Z phase passed (SZPH: X1895)
- (3) Zero speed (ZSO: X188C)
- (4) G/B spindle synchronization: Phase shift amount (R466)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization: Position error compensation	GBCMON	Y77C

[Function]

This signal carries out compensation by finding the position error compensation amount based on the position error of the reference spindle and the guide bushing (G/B) spindle caused by a square bar's torsion.

[Operation]

When this signal is turned ON, the position error compensation amount of the reference spindle and the guide bushing spindle is found, and the guide bushing spindle synchronization position error compensation starts.

[Related signals]

- (1) G/B spindle synchronization valid (GBON: Y778)
- (2) G/B spindle synchronization: Keep position error compensation amount (GBCMKP: Y77E)
- (3) G/B spindle synchronization: Position error compensation scale and the number of times of compensations (R390)
- (4) G/B spindle synchronization: Position error compensating (GBPCM: X77B)
- (5) G/B spindle synchronization: Position error compensation amount (R465)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization: Temporary cancel	GBOFF	Y77D

[Function]

The reference spindle and the guide bushing (G/B) spindle can be controlled independently by temporarily canceling the guide bushing spindle synchronization using this signal.

[Operation]

- ON: Guide bushing spindle synchronization temporarily canceled
 OFF: Guide bushing spindle synchronization can be enabled

The following signals are disabled when this signal is ON, and they are enabled when this signal is OFF.

- Y778 (G/B spindle synchronization valid)
- Y77A (G/B spindle synchronization: Phase alignment)
- Y77B (G/B spindle synchronization: Phase memory)
- Y77C (G/B spindle synchronization: Position error compensation)
- Y77E (G/B spindle synchronization: Keep position error compensation amount)

The operation error (M01 1137) occurs if this signal is turned ON/OFF when the reference spindle or the guide bushing spindle is in any of the following modes.

- During rotation (when not stopped)
- During tap cycle synchronization mode
- During spindle synchronization mode/tool-spindle synchronization I (polygon machining) mode/tool-spindle synchronization II (hobbing) mode
- During C axis mode of spindle/C axis control
- During orientation/indexing

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization: Keep position error compensation amount signal	GBCM KP	Y77E

[Function]

Select whether to cancel or hold the guide bushing (G/B) spindle synchronization position error compensation execution state when the "G/B spindle synchronization: position error compensation" signal (GBCMON) is OFF.

[Operation]

OFF: Position error compensation execution state is canceled

(The guide bushing spindle returns to the position before compensation. The guide bushing spindle synchronization position error compensation execution state is canceled.)

ON: Position error compensation execution state is held

(The guide bushing spindle does not return to the position before compensation. The guide bushing spindle synchronization position error compensation execution state is held.)

[Related signals]


- (1) G/B spindle synchronization valid (Y778)
- (2) G/B spindle synchronization: Position error compensation (GBCMON: Y77C)
- (3) G/B spindle synchronization: Position error compensation scale and the number of times of compensations (R390)
- (4) G/B spindle synchronization: Position error compensating (GBPCM: X77B)
- (5) G/B spindle synchronization: Position error compensation amount (R465)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Control axis detachment n-th axis	DTCH1 to 8	Y780 to 7	Y788 to F	Y790 to 7	Y798 to F

[Function]

Desired control axis can be excluded from the control target.

This is a signal for each control axis, and the number at the end of the signal name indicates the control axis No.

**[Operation]**

When the "Control axis detachment" signal (DTCH_n) turns ON, the corresponding axis is excluded from control.

- ♦ Specified axis is not under any positioning control (oriented spindle stop, index, etc.)
- ♦ Alarms related to specified axis, such as servo alarms, stroke end alarms are ignored.
- ♦ The interlock signal of the corresponding axis is deemed to be ON.
- ♦ Specified axis is displayed in the position counter on the screen.

Note

- (1) The same function can be used by setting parameter on the screen. (See below)

The control axis detachment is valid when the following settings are enabled.

Basic specification parameter
"#1070 axoff" (axis detach), and
control axis detach n-th axis(DTCH_n)

or

Basic specification parameter
"#1070 axoff" (axis detach), and
axis parameter of machining parameter
"#8201 AX. RELEASE"

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
B	Servo OFF n-th axis	*SVFn to 8	Y7A0 to 7	Y7A8 to F	Y7B0 to 7	Y7B8 to F

[Function]

The control axis can be in the servo OFF state (the state in which the servo motor loses driving force).

In servo OFF condition, positioning control is impossible but the position detection function itself remains enabled.

Therefore, the position is not lost.

This is a signal for each control axis, and the number at the end of the signal abbreviation (n = 1,2,3 ...) indicates the control axis No.

[Operation]

When the "Servo OFF" signal (*SVFn) turns OFF, the corresponding control axis is set to servo OFF condition.


If the axis has moved for some reason while the servo is OFF, whether to compensate the movement amount at the next servo ON can be determined by the parameter settings. ("#1064 svof" (Error correction))

<When displacement is corrected (follow-up)>

- An amount of motion equal to the displacement is commanded so that positioning error becomes zero.
- In this case, even if the "Servo OFF" signal is restored, machine position remains deviated from in-position. However, the current position of the position counter has been updated by the amount of deviation, and the machine position is corrected with the next absolute command. (The "Manual absolute" signal (ABS_n) is turned ON when manual operation is selected.)

<When displacement is not corrected>

- In this case, when the "Servo OFF" signal is restored, machine is moved to its original position by the amount of movement.

<Servo-OFF during motion>

(*1) While the axis is moving, the servo turns OFF after decelerated and stopped.

(*2) Controller internal interlock by servo OFF (axis motion not possible)

[Caution]

These signals are all handled as B contacts.


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Mirror image n-th axis	MI1 to 8	Y7C0 to 7	Y7C8 to F	Y7D0 to 7	Y7D8 to F

[Function]

This signal is used to machine a symmetrical shape by reversing the sign of the movement amount for each block.

This is a signal for each control axis, and the number at the end of the signal name indicates the control axis No.

M I n

**[Operation]**

Symmetrical cutting is enabled by reversing the sign of the value commanded for memory or MDI operation.

Regardless of whether the coordinate is commanded with an incremental command or absolute command, the mirror image is applied on the incremental amount to be executed for all axes that can be controlled.

[Caution]

The mirror image is changed after block stop.

[Related signals]

- (1) In mirror image n-th axis (MIR_n: X9C7)

4 Explanation of Interface Signals


4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
B	External deceleration+ n-th axis	*+EDT1 to 8	Y7E0 to 7	Y7E8 to F	Y7F0 to 7	Y7F8 to F

[Function]


While this signal (*+EDTn) is OFF, the feedrate when the control axis moves in the "+" direction can be set to the constant speed set by the parameters.

This signal is a signal for each control axis, and the number at the end of the signal name indicates the control axis No.

**[Operation]**

When the "External deceleration" signal (*+EDTn) turns OFF, each axis decelerates independently in manual operation. However, in automatic operation, when even one axis matches the external deceleration conditions, all axes will be decelerated. The deceleration occurs when the direction of the moving axis and the direction of the "External deceleration" signal of the corresponding axis match.

- The external deceleration speed can be set arbitrarily by setting the parameters. (#1216 extdcc)
- When the speed is slower than the external deceleration speed, it will not be affected even if this signal turns OFF.
- The deceleration speed during automatic operation will be the combined deceleration speed, if the deceleration conditions match and the external deceleration speed is exceeded.
- To return in the reverse direction, the speed immediately returns to the correct command speed.
- For G28, G29 and G30 commands, even in automatic operation, the speed becomes the external deceleration speed only for the axis for which this signal is OFF.
- The speed becomes the external deceleration speed even in rapid traverse during synchronous tapping.

**[Caution]**

- (1) The "External deceleration" signal is handled as a B contact (*) signal; however, it changes to "1" (ON) when the power is turned ON. When this signal is not used, there is no need to program for external deceleration.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
B	External deceleration- n-th axis	*-EDT1 to 8	Y800 to 7	Y808 to F	Y810 to 7	Y818 to F

[Function] [Operation]

The functions and operations of this signal are the same as those of the "External deceleration+ n-th axis" signal (*+EDTn). The deceleration occurs when the movement is in the minus direction and the "External deceleration- n-th axis" signal (*-EDTn) is turned OFF.

4 Explanation of Interface Signals


4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
B	Automatic interlock+ n-th axis	*+AIT1 to 8	Y820 to 7	Y828 to F	Y830 to 7	Y838 to F

[Function]

All axis motions of machine can be decelerated and stopped immediately during automatic operation when motion of a specific axis (n-th axis) in plus direction activates the interlock function.

This signal is a signal for each control axis, and the number at the end of the signal name indicates the control axis No.

**[Operation]**

When this signal turns OFF for a specific axis in motion in the plus direction under automatic operation mode (memory, MDI or tape), motion of all axis decelerates and stops with the NC alarm (operation error (M01 0004)).

When this signal is OFF before the axis movement, the system completes calculation for axis motion but makes it remain stopped with the same operation error code displayed. In either case, setting the signal ON (1) resumes or starts axis motion.

[Caution]

- (1) All automatic interlock signals are for B contact.
- (2) When the power is turned ON, the "Automatic interlock" signal is set to "1". Therefore, there is no need to create an interlock cancel state in the sequence program for unused axes.

[Related signals]

- (1) Automatic interlock- n-th axis (*-AIT_n: Y840)
- (2) Manual interlock+/- n-th axis (*+/-MIT_n: Y860/Y880)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
B	Automatic interlock- n-th axis	*-AIT1 to 8	Y840 to 7	Y848 to F	Y850 to 7	Y858 to F

[Function] [Operation]

The details are the same as the "Automatic interlock+ n-th axis" signal, except that the direction is opposite.

The "Automatic interlock+ n-th axis" signal is valid for the axis moving in the plus direction, and this signal is valid for the axis moving in the minus direction.

This signal is a signal for each control axis, and the number at the end of the signal name indicates the control axis No.

**[Related signals]**

- (1) Automatic interlock+ n-th axis (*+AIT_n: Y820)
- (2) Manual interlock+/- n-th axis (*+/-MIT_n: Y860/Y880)

4 Explanation of Interface Signals


4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
B	Manual interlock+ n-th axis	*+MIT1 to 8	Y860 to 7	Y868 to F	Y870 to 7	Y878 to F

[Function]

When the corresponding axis is moving in the plus direction with manual operation (jog, manual, incremental, reference position return), only the corresponding axis can be decelerated and stopped by turning OFF this signal that corresponds to that axis.

This signal is the signal for each control axis, and the number at the end of the signal name indicates the control axis No.

**[Operation]**

When this signal turns OFF (0) for a specific axis in motion in the plus direction under manual operation mode (jog, handle, incremental, reference position return), motion of the axis decelerates and stops with the NC alarm (operation error (M01 0004)).

When this signal is OFF before the axis movement, the axis does not start moving and the same operation error code is displayed. In either case, setting the signal ON resumes or starts axis motion.

[Caution]

- (1) All interlock signals are for B contact.
- (2) When the power is turned ON, the "Manual interlock" signal is set to "1". Therefore, there is no need to create an interlock cancel state in the sequence program for unused axis.

[Related signals]

- (1) Manual interlock- n-th axis (*-MIT_n: Y880)
- (2) Automatic interlock+/- n-th axis (*+/-AIT_n: Y820/Y840)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
B	Manual interlock- n-th axis	*-MIT1 to 8	Y880 to 7	Y888 to F	Y890 to 7	Y898 to F

[Function] [Operation]

The details are the same as the "Manual interlock+ n-th axis" signal, except that the direction is opposite.

The "Manual interlock+ n-th axis" signal is valid for the axis moving in the plus direction, and this signal is valid for the axis moving in the minus direction.

This signal is a signal for each control axis, and the number at the end of the signal name indicates the control axis No.

**[Related signals]**

- (1) Manual interlock+ n-th axis (*+MIT_n: Y860)
- (2) Automatic interlock+/- n-th axis (*+/-AIT_n: Y820/Y840)

4 Explanation of Interface Signals


4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Automatic machine lock n-th axis	AMLK1 to 8	Y8A0 to 7	Y8A8 to F	Y8B0 to 7	Y8B8 to F

[Function]

During automatic operation, the current position (counter) can be updated and the program can be checked without moving the desired axis.

This signal is a signal for each control axis, and the number at the end of the signal name indicates the control axis No.

**[Operation]**

In the automatic operation (memory, MDI or tape), when this signal is ON, the current position (counter) is updated without moving the corresponding axis (for which the signal is ON) of the machine. However, if this signal turns ON in the middle of a block (during movement), block termination occurs after the completion of that block, and then the machine lock is enabled from the next block.

[Caution]

- (1) If the "Automatic machine lock" signal changes during automatic operation, block stop occurs after completion of the block in execution.
- (2) To move only the table without drilling to confirm the drilling position of the drilling operation, turn ON the signal of the 3rd axis of this signal (AMLK3) if the drilling axis is the 3rd axis. (Equivalent to Z axis cancel)

[Related signals]

- (1) Manual machine lock n-th axis (MMLKn: Y8C0)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Manual machine lock n-th axis	MMLK1 to 8	Y8C0 to 7	Y8C8 to F	Y8D0 to 7	Y8D8 to F


[Function]

When manual operation is performed, only the current position (counter) can be updated without moving the desired axis.

[Operation]

When this signal is ON during manual operation, only the current position is updated without moving the corresponding axis (signal ON axis) of the machine. However, even if this signal turns ON or OFF while moving the axis, the operation is processed in the state at the start of movement. It is required to stop motion of all axes to enable the machine lock.

This signal is a signal for each control axis, and the number at the end of the signal name indicates the control axis No.

**[Related signals]**

- (1) Automatic machine lock n-th axis (AMLKn: Y8A0)

4 Explanation of Interface Signals


4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Feed axis selection+ n-th axis	+J1 to 8	Y8E0 to 7	Y8E8 to F	Y8F0 to 7	Y8F8 to F

[Function]


This signal is used to start movement (jog feed, incremental feed or reference position return mode) in plus direction during manual operation.

This signal is a signal for each control axis, and the number at the end of the signal name indicates the control axis No.


**[Operation]**

When the feed axis selection signal (+Jn) is turned ON, the controller operates as follows.

- When jog feed, incremental feed or reference position return is possible, motion in plus direction occurs on the selected axis.
- In jog feed, motion continues while the signal is ON.



- In incremental feed, the amount of movement set in the "Handle/Incremental feed magnification code m" is fed in the plus direction. Even when this signal (+Jn) turns OFF during movement, the feed does not stop. To start the movement again, turn this signal OFF, confirm the movement is completed, then turn this signal ON.



- After reference position return mode is decelerated to approach speed by the near point detection dog, the motion continues, even after the feed axis selection signal is turned OFF, until motion reaches the reference position.

Note

- If the "+" direction selection and the "-" direction selection of the feed axis selection signal are turned ON at the same time, neither is selected and it is equivalent to the case where the feed axis selection signal is OFF.
- If the feed axis selection signal turns ON before jog, incremental or reference position return mode is selected, the feed axis selection signal is ignored. In this case, the feed axis selection signal need to be turned OFF and then turn it ON again.
- If reset is exerted while the feed axis selection signal is ON, or the feed axis selection signal turns ON during the reset, the feed axis selection signal is invalid even when the reset is canceled. In this case, the feed axis selection signal need to be turned OFF and then turn it ON again.
- When the relevant axis is decelerating (when the command output is not completed), the feed axis selection signal is invalid even if it is turned ON. This signal must be turned from OFF to ON again after the deceleration is completely finished (command output is completed). Be especially careful when the feed axis direction changes.
- In the case of two part systems, even if the feed axis selection of the 1st part system and the 2nd part system is turned ON in the same cycle (scan) of the sequence, they may not start at exactly the same time.

[Related signals]

- Feed axis selection- n-th axis (-Jn: Y900)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Feed axis selection- n-th axis	-J1 to 8	Y900 to 7	Y908 to F	Y910 to 7	Y918 to F

[Function]

This signal is used to feed the axis in the minus (-) direction during jog feed, incremental feed or reference position return mode in manual operation.

This signal is a signal for each control axis, and the number at the end of the signal name indicates the control axis No. (Refer to the "Feed axis selection+ n-th axis" for details.)

[Operation]

The operation is the same as the feed axis selection+.

Use this signal to move the axis in the minus (-) direction.

[Related signals]

- (1) Feed axis selection+ n-th axis (+Jn: Y8E0)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Manual/Automatic simultaneous valid n-th axis	MAE1 to 8	Y920 to 7	Y928 to F	Y930 to 7	Y938 to F

[Function]

The automatic mode (tape, MDI, memory) and manual mode (handle, step, jog, manual reference position return) can be simultaneously selected, and manual operation can be performed during automatic operation. (Arbitrary feed with the PLC is also possible.)

[Operation]

The manual/automatic simultaneous mode is entered when the automatic mode and manual mode are selected simultaneously. The manual operation axis operated during the manual/automatic simultaneous mode are selected by this signal. The axis selected with this signal can be operated in the manual mode during automatic operation.

Note

- (1) If an axis command is issued to an axis selected by this signal from the automatic mode, the "M01 OPERATION ERROR 0005" occurs. The automatic operation is interlocked until the operation error is canceled.
- (2) During the automatic mode (when manual is not selected and manual/automatic simultaneous mode is not entered), this signal will be invalid and the interlock will not be applied.
- (3) If this signal turns ON in respect to an axis commanded with automatic during the manual/automatic simultaneous mode, an interlock is applied on the axis, and the axis immediately decelerates and stops. (The "M01 OPERATION ERROR 0005" will occur.)
After the axis decelerates and stops, operation with the manual mode is possible. Note that the interlock is also be applied during the tap modal.
- (4) In the manual/automatic simultaneous mode and the automatic mode, the manual axis command with this signal is OFF completely invalid. Note that interruption with the manual handle is possible.
- (5) The feedrates of the automatic command axis and the manual command axis are independent. The acceleration/ deceleration modes (rapid traverse, cutting feed) are also independent.
- (6) The rapid traverse override, cutting feed override and 2nd cutting feedrate override are valid for both the automatic command axis and manual command axis. (Note that the cutting and 2nd cutting overrides to the manual command axis are valid when the manual cutting override is valid.) Override cancel is valid for the automatic command axis.
- (7) The manual interlock is valid for the manual command axis, and the automatic interlock is valid for the automatic command axis.
- (8) The signals during cutting feed and rapid traverse follow the movement mode of the automatic command axis.
- (9) The axis movement with manual movement axis does not stop with a single block stop or feed hold.
- (10) If the G92 and G53 commands are issued in the automatic mode to an axis for which this signal is ON, the G92 and G53 commands are executed after the manual axis movement is stopped (An axis command by G53 will cause an operation error after the manual axis movement is stopped.)
- (11) If a soft limit or OT is applied on the manual command axis during the manual/automatic simultaneous mode, the automatic command axis also decelerates to a stop, and enters the feed hold state.
- (12) When the high-accuracy control or high-speed high-accuracy control mode is valid, if this signal has been changed during execution of movement blocks for the pre-interpolation acceleration/deceleration, the change to this signal is not enabled immediately even if the axis is not moving. The change is enabled when all the axes of the part system decelerate to stop.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

<Relation with manual handle interrupt>

The operation of the automatic handle interruption during the manual/auto mode is as follows.

		Axis for which manual/automatic valid signal is ON	Axis for which manual/automatic valid signal is OFF
Handle mode selection	Automatic handle interrupt	The specifications of the manual/automatic simultaneous mode will be followed. The automatic axis command will cause an operation error, and only the manual axis command will be valid.	The specifications of the automatic handle interruption will be followed. Interruption with the handle can be applied in respect to the automatic axis movement.
Manual mode other than handle		Same as above	Same as above

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Manual feedrate B valid n-th axis	FBEn	Y940 to 7	Y948 to F	Y950 to 7	Y958 to F

[Function]

This signal enables manual feed using the manual feedrate B.

[Operation]

If this signal is enabled when manual feed is carried out in the jog mode, the axis moves at the speed commanded by manual feedrate B which is commanded separately from the manual feedrate.

This signal is independent for the axes.

<Using the manual feedrate B (Example for 1st part system)>

- ♦ To set the feedrate common for all axes as the manual feedrate B
 - (i) Select the "JOG mode" signal (J).
 - (ii) Turn ON the "Manual feedrate B valid n-th axis" signal (this signal) of the axis to be moved at the manual feedrate B.
 - (iii) Set the feedrate set as manual feedrate B in the "Manual feedrate B" register.
 - (iv) Turn ON the "Feed axis selection+" signal or "Feed axis selection-" signal for the axis to be moved at the manual feedrate B.
- ♦ To set the feedrate independent for each axis as the manual feedrate B
 - (i) Select the "JOG mode" signal (J).
 - (ii) Turn ON the "Manual feedrate B valid n-th axis" signal (this signal) of the axis to be moved at the manual feedrate B. Also, turn ON the "Each axis manual feedrate B valid" signal.
 - (iii) Set the feedrate set as each axis manual feedrate B in the "Each axis manual feedrate B n-th axis" register.
 - (iv) Turn ON the "Feed axis selection+" signal or "Feed axis selection-" signal for the axis to be moved at the each axis manual feedrate B.

Note

- (1) Manual feedrate B is valid only for JOG feed, and is invalid in all other manual modes.
- (2) The rapid traverse mode is invalid for the manual feedrate B valid axis.
- (3) Manual override is invalid for the manual feedrate B valid axis.
- (4) The axis moving at the manual feedrate B decelerates and stops when NC reset is input. To move the axis at the manual feedrate B again, cancel the NC reset, and then turn the axis selection signal OFF and ON.
- (5) Even if the feed axis selection signal is turned ON when the command speed is "0", an error occurs and the manual feedrate B valid axis does not move.
- (6) The manual/automatic simultaneous signal must be valid to move an arbitrary axis at the manual feedrate B during automatic operation.
- (7) When the manual operation mode other than the JOG mode is enabled, the "Jog mode" signal must be enabled simultaneously to move an arbitrary axis at the manual feedrate B.
- (8) During synchronous control, the "Manual feedrate B valid n-th axis" signal for the slave axis is invalid, and the manual feed rate B is also valid for the slave axis with the signal for the master axis.

[Related signals]

- (1) Jog mode (J: YC00)
- (2) Manual feedrate B (R2506, R2507)
- (3) Each axis manual feedrate B valid (YC7C)
- (4) Each axis manual feedrate B n-th axis (R5764 to R5779)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Zero point initialization set mode n-th axis	AZS1 to 8	Y960 to 7	Y968 to F	Y970 to 7	Y978 to F

[Function]

This selects the zero point initialization set with the marked point alignment method in the absolute position detection system.

[Operation]

The zero point initialization set is selected with this signal.

Refer to the section on "Zero point initialization set completed" signal (ZSF_n) for details on the operations.

Note

- (1) This signal is a function signal for zero point initialization set, and is not a signal that selects the operation mode. Select the jog mode or handle mode to move the axis to a required position.
- (2) This signal is valid for the following specifications.
 - When servo detection specification (motor encoder, servo system) is the absolute position detection system.
 - When "TYPE" on the [ABS. POSI PARAM] screen is set to "2".

[Related signals]

- (1) Zero point initialization set completed (ZSF_n: X8C0 to 7)
- (2) Zero point initialization set error completed (ZSE_n: X8E0 to 7)
- (3) In initialization (R574)
- (4) Initialization incompleteness (R575)
- (5) Zero point initialization set start (ZST_n: Y980 to 7)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Zero point initialization set start n-th axis	ZST1 to 8	Y980 to 7	Y988 to F	Y990 to 7	Y998 to F

[Function]

This signal is used to set a desired position as the zero point during the zero point initialization set by the reference point alignment method of the absolute position detection system.

[Operation]

This signal turns ON when a corresponding axis is moved in the zero point initialization set mode, and the position desired as the zero point is reached.

Refer to the section on "Zero point initialization set completed" signal (ZSF_n) for details on the operations.

Note

- (1) This signal is a function signal for zero point initialization set, and is not a signal that selects the operation mode. Select the jog mode or handle mode to move the axis to a desired position.
- (2) This signal is valid for the following specifications.
 - When servo detection specification (motor encoder, servo system) is the absolute position detection system.
 - When "type" on the [ABS. POSI PARAM] screen is set to "2".
- (3) This signal is disabled in the following cases:
 - During emergency stop
 - In "reset"
 - When the "Zero point initialization set start" signal (ZST_n) is turned ON before the "Zero point initialization set mode" signal (AZS_n).

In this case, turn this signal OFF once, and then turn it ON again.

 - When the grid (Z-phase signal provided per motor rotation) has never passed after the power is turned ON.

[Related signals]

- (1) Zero point initialization set completed (ZSF_n: X8C0 to 7)
- (2) Zero point initialization set error completed (ZSE_n: X8E0 to 7)
- (3) In initialization (R574)
- (4) Initialization incompleteness (R575)
- (5) Zero point initialization set mode (AZS_n: Y960 to 7)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Current limit changeover n-th axis	ILC1 to 8	Y9A0 to 7	Y9A8 to F	Y9B0 to 7	Y9B8 to F

[Function]

This signal switches current limit value.

[Operation]

This signal turns ON when the current limit is enabled.

The current limit parameter is switched from SV013 to SV014. When the position droop exceeds a certain level, the "Current limit reached" signal (ILA) turns ON.


When the current limit is canceled (from ON to OFF), the parameter is switched from SV014 to SV013. After confirming smoothing zero, cancel the accumulated position droop and adjust the command position to the machine position.

To cancel the droop while the current limit is enabled, turn ON the "Droop cancel request" signal (DOR) instead of turning OFF the "Current limit changeover" signal (ILC) in the timing chart below.

To cancel the current limit without canceling the droop, set the parameter "#1236/bit2" to "1" or turn ON the bit of the target axis of the "Current limit changeover" signal (ILC).

The "In current limit" signal (ILI) turns ON when current limit is enabled. When the current limit is canceled, the signal turns OFF after waiting for the droop to be canceled and the current limit value to be switched.

The user can select whether to interlock when the current limit is reached by the "Current limit mode 1" signal (ILM1) and the "Current limit mode 2" signal (ILM2).

**[Related signals]**

- (1) In current limit n-th axis (ILI1 to 8: X900 to 7)
- (2) Current limit reached n-th axis (ILA1 to 8: X920 to 7)
- (3) Droop cancel request n-th axis (DOR1 to 8: Y9C0 to 7)
- (4) Current limit mode 1 and 2 (ILM1,2: YCC0,1)
- (5) Current limit changeover (R2593)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Droop cancel request n-th axis	DOR1 to 8	Y9C0 to 7	Y9C8 to F	Y9D0 to 7	Y9D8 to F

[Function] [Operation]

During the current limit control, the droop generated by the current limit can be released.

[Related signals]

- (1) In current limit n-th axis (IL1 to 8: X900 to 7)
- (2) Current limit reached n-th axis (ILA1 to 8: X920 to 7)
- (3) Current limit changeover n-th axis (ILC1 to 8: Y9A0 to 7)
- (4) Current limit mode 1 and 2 (ILM1,2: YCC0,1)
- (5) Current limit changeover (R2593)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Workpiece coordinate Measurement 2nd axis		Y9E1	Y9E9	Y9F1	Y9F9

[Function] (L system)

The Z axis external workpiece coordinate offset data can be set by cutting the workpiece face with manual operations and inputting workpiece coordinate measurement 2nd axis.

[Operation]**<Mode selection>**

Set the mode selection switch to the manual mode ([Handle], [Jog] or [Rapid Traverse]).

<Tool measurement mode signal input>

Set the tool measurement mode signal to "1".

<Main/sub selection>

Using the tool presetter sub-side valid signal, select whether to measure the workpiece coordinates on the main spindle side or sub-spindle side.

- Tool presetter sub-side valid signal
 - OFF: The compensation No. is retrieved from the main spindle side R registers.
 - ON: The compensation No. is retrieved from the sub-spindle side R registers.

Note

- (1) Hold the state of this signal until the measurement with the selected tool is completed.

<Tool selection>

Issue the T command with MDI operation, etc., and select the tool.

Note

- (1) Set the selected tool compensation No. in the R register. The set R register differs according to the parameter setting and the state of the tool presetter sub-side valid signal.
- (2) Set the "tool length/wear data" for the tool being used beforehand.

Compensation No. R registers

#1098 TIno.	#1130 set_t	#1218 aux02/ bit4	Tool length compensation No.		Tool nose wear compensation No.	
			Main side	Sub-side	Main side	Sub-side
0	0	0/1	R2600, R2601	R2604, R2605	R2600, R2601	R2604, R2605
	1	0/1				
1	0	0	R536, R537		R2600, R2601	R2604, R2605
		1	R2602, R2603	R2606, R2607	R2600, R2601	R2604, R2605
	1	0/1	R2602, R2603	R2606, R2607	R2600, R2601	R2604, R2605

- When the compensation No. is 0, the compensation amount is calculated as "0".
- If the compensation No. exceeds the number of specified offset sets, the "Compensation No. illegal" error occurs.
- Whether to use the main side or sub-side is selected with the tool presetter sub-side valid signal. (OFF: Main side, ON: Sub-side)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

<Cutting the workpiece face>

If the workpiece face has not been cut, cut the workpiece face slightly to even it.

Note

- (1) Do not move the tool in the detection of Z axis after cutting the workpiece face.
- (2) If the workpiece does not need to be cut, carry out positioning to the measurement position.

<Setting the Z axis external workpiece coordinate offset data with the workpiece coordinate measurement 2nd axis signal input>

Input the "Workpiece coordinate Measurement 2nd axis" signal (this signal). The Z axis external workpiece coordinate offset data is automatically calculated from the tool compensation data of the used tool and the machine value at the point this signal is input. The results are set as the data.


- Details of automatic calculation formula

The external workpiece coordinate offset data is automatically calculated with the following formula.

External workpiece coordinate offset = Machine coordinate value - tool compensation data

The tool compensation data used for the measurement is selected with the base specification parameter "#1226 aux10/bit0".

aux10/bit0	Tool compensation data
0	Tool length data + nose wear data
1	Tool length data



<Turning the tool measurement mode signal OFF>

Measurement of the external workpiece coordinate offset is completed.

[Related signals]

- (1) Tool compensation No. (Main side: R2600 to R2603, Sub side: R2604 to R2607)
- (2) Tool length measurement 2 (TLMS: YC21)

4 Explanation of Interface Signals


4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Control axis detachment 2 n-th axis	DTCH2n	YA00 to 7	YA08 to F	YA10 to 7	YA18 to F

[Function]

Desired control axis can be specified to be exempted from control function.

This is a signal for each control axis, and the number at the end of the signal name indicates the control axis No.

**[Operation]**

When the "Control axis detachment 2" signal (DTCH2n) turns ON, the corresponding axis is excluded from the control targets.

- Position control cannot be carried out, but the position is not lost because the position detection is valid.
- The interlock signal of the corresponding axis is deemed to be ON.
- The specified axis is also displayed in the position display on the CRT.

[Related signals]

(1) Control axis detachment n-th axis (DTCHn: Y780)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Unclamp completion n-th axis	UCLPFn	YA20 to 7	YA28 to F	YA30 to 7	YA38 to F

[Function]

This signal indicates that unclamping has been completed in respect to the unclamp command from the CNC.

[Operation]

"Type A" or "Type B" is selected by the parameter "#1282 ext18/bit3" (Index table clamp type).

<Type A ("#1282 ext18/bit3" is set to "0")>

When the "Unclamp command" turns ON, the clamp on the corresponding axis is released by the PLC, and then this signal turns ON.

When the "Unclamp command" turns OFF, the corresponding axis is clamped by the PLC, and then this signal turns OFF.

<Type B ("#1282 ext18/bit3" is set to "1")>

When the "Unclamp command" signal turns ON, the clamp on the corresponding axis is released by the PLC, and the "Unclamp completion" signal turns ON.

This signal is turned OFF by the PLC after the "Unclamp command" signal turns OFF.

<This signal turns ON in the following case>

- When the "Unclamp command" turns ON, the clamp on the corresponding axis is released by the PLC, and then this signal turns ON.

< This signal turns ON in the following case >

- The "Unclamp command" signal is turned OFF by the CNC.

Note

(1) Refer to the "Programming Manual" for operation details of each type A and type B.

[Related signals]

- (1) Unclamp command (UCLPn: X960 to X967)
- (2) Clamp command (CLPn: XB00 to XB07)
- (3) Clamp completion (CLPFn: YB00 to YB07)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Mixed control (cross axis control) request n-th axis	CRS1 to 8	YA60 to 7	YA68 to F	YA70 to 7	YA78 to F

[Function]

The mixed control (cross axis control) is turned ON and OFF with the PLC signal. Which axis is to be in the mixed control (cross axis control) state for each PLC signal is set by the parameter.

[Operation]**<Mixed control (cross axis control) control command using PLC signals>**

There are mixed control (cross axis control) request signals (CRS1 to CRS8) for eight axes in each part system. (There are signals for eight axes regardless of the actual number of axes.)

Cross machining is carried out by exchanging the axis for which the PLC signal is input and the axis designated with parameter at the rising edge (0 to 1) of this signal. If an axis is not mounted at the section where the PLC signal is input, the axis designated with the parameter will be moved from another part system.

The axis cross machining state is canceled at the falling edge (1 to 0) of this signal, and normal control is applied.

<Commanding in the machining program>

Turn ON/OFF the mixed control (cross axis control) signal using M or T command, etc. to carry out the mixed control (cross axis control).

Carry out timing synchronization operation before the M command and T command, etc., for mixed control (cross axis control) so that the timing for the mixed control (cross axis control) matches.

[Related signals]

- (1) In mixed control (cross axis control) (X980 to X987)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Synchronous control request n-th axis	SYNC1 to 8	YA80 to 7	YA88 to F	YA90 to 7	YA98 to F

[Function]

Whether to start or cancel synchronous control is selected with a signal corresponding to the synchronized axis.

1 -> 0 (falling edge) Synchronous control cancel

0 -> 1 (rising edge) Synchronous control start

[Operation]

Synchronous control is started and canceled with the rising edge (OFF to ON) or falling edge (ON to OFF) of the PLC signal (SYNC1 to 8) corresponding to the synchronized axis.

Thus, if synchronous control is canceled by a cause other than the PLC signal turning OFF, such as by emergency stop, and synchronous control is to be started again, turn the PLC signal OFF and then ON again.

The synchronization reference axis corresponding to each synchronized axis is set with the parameter "#2088 bsax_sy".

The movement direction of the synchronized axis in respect to the movement of the synchronized reference axis is determined by the value of the parameter "#2087 syncnt".

0: moves in the same direction as the reference axis

1: moves in the opposite direction of the reference axis

[Caution]

- (1) The two axes related to control (synchronous/superimposition control) are both controlled in the smoothing zero state. Control is started after the axis movement has ended and smoothing zero is established.
- (2) Control (synchronous/superimposition control) are affected by the state of the two target part systems. Thus, attention must be paid to the timing between part systems. Always command synchronization before commanding the control PLC signal.
- (3) Control (synchronous/superimposition control) cannot be commanded to an axis in inclined axis control. An operation error occurs if this type of command is issued.
- (4) Before control (synchronous/superimposition control) is started, the target axis must have completed reference position return after the power is turned ON, or the absolute position must be established. An operation error occurs if the above state is not established.
- (5) A movement command cannot be issued to a synchronized axis during synchronous control. An operation error occurs if movement is commanded.
- (6) An axis in synchronous control cannot be commanded as the superimposition control axis. An operation error occurs if this type of command is issued.
- (7) A synchronized axis in synchronous control cannot be commanded as the synchronized axis for other synchronous control. An operation error occurs if this type of command is issued. However, a synchronized reference axis for multiple synchronized controls can be specified on a single axis.

[Related signals]

- (1) In synchronous/superimposition control (X9A0 to X9A7)
- (2) Synchronous error amount (R5076 to R5139)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Superimposition control request n-th axis	PILE1 to 8	YAA0 to 7	YAA8 to F	YAB0 to 7	YAB8 to F

[Function]

Whether to start or cancel superimposition control is selected with a signal corresponding to the superimposed axis.

1 -> 0 (falling edge) Superimposition control cancel

0 -> 1 (rising edge) Superimposition control start

[Operation]

Superimposition control is started and canceled at the rising edge (OFF to ON) or at the falling edge (ON to OFF) of the PLC signal (PILE1 to 8) corresponding to the superimposed axis.

Thus, to perform the superimposition control again when the superimposition control is canceled due to a factor other than turning OFF the PLC signal such as an emergency stop, turn OFF the PLC signal and then turn it ON again.

The reference axis corresponding to each superimposed axis set with the parameter "#2089 bsax_pl".

The movement direction of the superimposed axis in respect to the movement of the reference axis is determined by the value set for parameter "#2143 polar".

0: moves in the same direction as the reference axis

1: moves in the opposite direction of the reference axis

[Caution]

(1) This signal is ignored if "0" is set to the parameter "#1280 ext16/bit7".

(2) Make sure to command a timing synchronization for the superimposed axis and the reference axis in the blocks before and after the command of this signal.

[Related signals]

(1) In synchronous/superimposition control (X9A0 to X9A7)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	NC axis control selection n-th axis	-	YAC0 to 7	YAC8 to F	YAD0 to 7	YAD8 to F

[Function]

This signal is used to select the control method of the NC axes which can be controlled by PLC.

0: PLC control

1: NC control


[Operation]

When this signal is ON, the axis is controlled with a machining program. (The axis is handled as an NC axis.)

When this signal is OFF, the axis is controlled with the PLC axis indexing interfaces. (The axis is handled as a PLC axis.)

The correspondence between the axis Nos. and the device Nos. is as follows.

Device No.	Signal name	Device No.	Signal name
YAC0	NC axis control selection 1st axis	YAC4	NC axis control selection 5th axis
YAC1	NC axis control selection 2nd axis	YAC5	NC axis control selection 6th axis
YAC2	NC axis control selection 3rd axis	YAC6	NC axis control selection 7th axis
YAC3	NC axis control selection 4th axis	YAC7	NC axis control selection 8th axis

[Timing chart]

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

[Caution]

- (1) This signal is valid only for the NC axis that can be controlled by PLC. The NC axis that can be controlled by PLC is the NC axis for which the axis No. for PLC axis indexing is set by the parameter "#12800 chgauxno".
- (2) Confirm that the axis is not moving before turning this signal ON/OFF.
When this signal is turned ON/OFF during the axis movement, an operation error occurs, and then the axis decelerates and stops.

(Usage example) When the parameters are set as follows

Axis No.	1	2	3	4	5
#1013 axname	X	Y	Z	A	C
#12800 chgauxno	0	0	0	1	2

A-axis and C-axis are axes that can be controlled by PLC. To control the A-axis with NC, turn ON the signal YAC3. The signals YAC0 to YAC2 and YAC5 to YAC7 are disabled.

[Related signals]

- (1) In NC axis control n-th axis (XA20 to XA27)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Vertical axis pull-up prevention request n-th axis		YAE0 to 7	YAE8 to F	YAF0 to 7	YAF8 to F

[Function]

This signal suppresses the vertical axis pull-up function and prevents the vertical axis to be pulled up.

[Operation]

By turning on this signal, NC performs the following operations.

- Command the drive unit to prevent vertical axis pull-up.
- Turns ON the "Vertical axis pull-up prevented" signal.

By turning off this signal, NC performs the following operations.

- Command the drive unit to cancel the prevention of vertical axis pull-up.
- Turns OFF the "Vertical axis pull-up prevented" signal.

[Related signals]

- (1) Vertical axis pull-up prevented (XA60 to 7)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Clamp completion n-th axis	CLPFn	YB00 to 7	YB08 to F	YB10 to 7	YB18 to F

[Function]

This signal indicates that clamping has been completed in respect to the clamp command from the CNC.

[Operation]

"Type A" or "Type B" is selected by the parameter "#1282 ext18/bit3" (Index table clamp type).

<Type A ("#1282 ext18/bit3" is set to "0")>

This signal is not used.

<Type B ("#1282 ext18/bit3" is set to "1")>

When the "Clamp command" signal is turned ON, the index table indexing axis is clamped by the PLC, and the clamp completion signal is turned ON. After the "Clamp command" signal turns OFF, this signal is turned OFF by the PLC.

<This signal turns ON in the following case>

- After the corresponding axis is clamped by the PLC when the "Clamp command" is turned ON.

<This signal turns ON in the following case>

- The "Clamp command" signal is turned OFF by the CNC.

Note

- (1) Refer to the "Programming Manual" for operation details of each type A and type B.

[Related signals]

- (1) Unclamp command (UCLPn: X960 to X967)
- (2) Clamp command (CLPn: XB00 to XB07)
- (3) Unclamp completion (UCLPFn: YA20 to YA27)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Hob machining: Retract amount selection n-th axis	HOBRTVn	YB20 to 7	YB28 to F	YB30 to 7	YB38 to F

[Function]

This signal is used to select the parameter for setting the travel distance in hob retract.

[Operation]

When this signal is OFF:

The setting value of "#8219 Hob retract amount 1" is used as the hob retract amount.

When this signal is ON:

The setting value of "#8220 Hob retract amount 2" is used as the hob retract amount.

[Related signals]

- (1) Hob machining: Retract request (HOBTRT: YCDE)
- (2) Hob machining: Retracting (HOBRTM: XCAE)
- (3) Hob machining: Retract complete (HOBRTF: XCAF)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Spindle-mode rotary axis control command n-th axis	ROTSPC1 to 8	YB40 to 7	YB48 to F	YB50 to 7	YB58 to F

[Function]

This signal turns ON when an axis, for which rotary axis spindle control is enabled with the parameter, is controlled as a spindle (spindle control mode).

This signal turns OFF when the axis is controlled as a rotary axis (servo axis control mode).

This signal is a signal for each control axis, and the number at the end of the signal name indicates the control axis No.

**[Operation]**

- (1) The axis for which rotary axis spindle control is enabled enters the spindle control mode when the following operation is performed: turning the "Spindle-mode rotary axis control command" (ROTSPCn) ON while the "Reference position establishment" (1st axis (X9E0) to 8th axis (X9E7) of part system 1, and following) is ON and the "All axes smoothing zero" (TSMZ) is ON.
- (2) When the spindle control mode is set, the "Spindle-mode rotary axis control mode" (ROTSPMn) turns ON. The axis can be controlled as a spindle by executing S commands after checking that this signal is ON.
- (3) The control mode changes from the spindle control mode to servo axis control mode when the "Spindle-mode rotary axis control command" (ROTSPCn) turns OFF. When the servo axis control mode is set, the "Spindle-mode rotary axis control mode" (ROTSPMn) turns OFF.

[Related signals]

- (1) Spindle-mode rotary axis control mode n-th axis (ROTSPMn: XB40 and follows)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Stored stroke limit I: Change request n-th axis	SLMCn	YB60 to YB67	YB68 to YB6F	YB70 to YB77	YB78 to YB7F


[Function]

This signal is used to update the range of the stored stroke limit I to the value set in R registers.

[Operation]

At the rising edge (OFF to ON) of this signal, the value set in the R register specified by the parameter "#2190 OT_Rreg" is set as the range of the stored stroke limit I. Note that the stored stroke limit I is updated at the rising edge of this signal only when the parameter "#1278 ext14/bit2" is ON and the R register number of the user area is set in the parameter "#2190 OT_Rreg" of the corresponding axis.

User area	R8300 to R9799	1500 points of backup area
	R9800 to R9899	100 points of non-backup area
	R18300 to R19799	1500 points of backup area
	R19800 to R19899	100 points of non-backup area
	R28300 to R29799	1500 points of backup area
	R29800 to R29899	100 points of non-backup area



4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Real-time tuning 1: Speed control gain changeover hold-down command	VGHLDC1 to 8	YB80 to 7	YB88 to F	YB90 to 7	YB98 to F


[Function]

This signal is used to stop speed control gain switching of the real-time tuning 1 function. Speed control gain switching is stopped if this signal turns ON while this function is enabled.

[Operation]

ON: Speed control gain switching is stopped.

OFF: Speed control gain switching is not stopped.

**[Related signals]**

- (1) Real-time tuning 1: Speed control gain changeover hold-down ON (VGHLDC1: XB80)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	NC axis/PLC axis switchover request	NPCH-GREQ1 to 8	YBC0 to 7	YBC8 to F	YBD0 to 7	YBD8 to F

[Function]


This function switches the control mode for the NC axis/PLC axis switching axis (whether to use the axis as an NC axis or a PLC axis).

This signal is available for each control axis.

[Operation]

Turn ON this signal to control the NC axis/PLC axis switchover axis as a PLC axis, or turn OFF the signal to control the axis as an NC axis. Confirm that the "NC axis/PLC axis switchover invalid status" signal is OFF before switching ON/OFF of this signal.

When the NC axis and the PLC axis is switched while the "NC axis/PLC axis switchover invalid status" signal is ON, the operation error (M01 1250) occurs. After that, when the "NC axis/PLC axis switchover invalid status" signal turns OFF, the control is switched and the alarm is canceled. If this signal is switched while the axis is moving, the control is switched at the time when the movement command is completed and the "NC axis/PLC axis switchover invalid status" signal is turned OFF.

[Operation sequence]

- (1) The "NC axis/PLC axis switchover request" signal is switched from OFF to ON, and the "NC axis/PLC axis switchover invalid status" signal is turned OFF (switching is permitted). Therefore, the control is switched to PLC axis and the "NC axis/PLC axis switchover in process" signal is turned ON.
- (2) The "NC axis/PLC axis switchover request" signal is turned OFF, but the "NC axis/PLC axis switchover invalid status" signal is ON (switching is prohibited). Therefore, the control does not move to NC axis and the operation error (M01 1250) occurs.
- (3) The axis movement is completed and the "NC axis/PLC axis switchover invalid status" signal is turned OFF. Then the control is switched to NC axis, and the "NC axis/PLC axis switchover in process" signal is turned OFF.

[Related signals]

- (1) NC axis/PLC axis switchover invalid status (NPCHGIS1 to 8: XBA0 to 7)
- (2) NC axis/PLC axis switchover in process (NPCHGMOD1 to 8: XBC0 to 7)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Machine group-based alarm stop: Machine group-based PLC interlock	GQEMG1 to 8	YBE0 to 7	YBE8 to F	YBF0 to 7	YBF8 to F

[Function]

The "Machine group-based PLC interlock" signal is transmitted.

[Operation]

When the "Machine group-based PLC interlock" (GQEMG) is turned ON, the controller to which the axes belong enters the interlock state, and signals such as the "Servo ready completion" (SA) also turn OFF.

The signal assignments for each group are as follows:

Group 1	Group 2	Group 3	Group 4	Group 5	Group 6	Group 7	Group 8
YBE0	YBE1	YBE2	YBE3	YBE4	YBE5	YBE6	YBE7
Group 9	Group 10	Group 11	Group 12	Group 13	Group 14	Group 15	Group 16
YBE8	YBE9	YBEA	YBEB	YBEC	YBED	YBEE	YBEF
Group 17	Group 18	Group 19	Group 20	Group 21	Group 22	Group 23	Group 24
YBF0	YBF1	YBF2	YBF3	YBF4	YBF5	YBF6	YBF7
Group 25	Group 26	Group 27	Group 28	Group 29	Group 30	Group 31	Group 32
YBF8	YBF9	YBFA	YBFB	YBFC	YBFD	YBFE	YBFF

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Jog mode	J	YC00	YD40	YE80	YFC0	Y1100	Y1240	Y1380	Y14C0

[Function]

JOG operation mode for manual operation is selected.

[Operation]

When the "JOG mode" signal (J) is turned ON, JOG operation mode is selected.

Axis motion is started by turning ON the feed axis selection+ signal (+J1 to +J8) or the feed axis selection- signal (-J1 to -J8) after turning ON the jog mode and setting the manual feedrate code (*JV1 to *JV16).

The axis movement speed is set by "#2642 jogfeed" (Jog feed rate) or by PLC signal selected by the "Manual feedrate method selection" signal (YC77).

Rapid traverse operation is performed by superimposing the "Rapid traverse" signal (RT) described later on this signal (J) and turning it ON.

When the operation mode conflicts with any other mode or when no mode is selected, the NC alarm (operation error (M01 0101)) occurs.

[Related signals]

- (1) Feed axis selection (+J1 to 8: Y8E0, -J1 to 8: Y900)
- (2) Manual feedrate method selection (JVS: YC77)
- (3) Manual feedrate code m (*JV1 to *JV16: YC70 to 4)
- (4) Manual feedrate (method selection) (R2504,5)
- (5) Rapid traverse (RT: YC26)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Handle mode	H	YC01	YD41	YE81	YFC1	Y1101	Y1241	Y1381	Y14C1

[Function]

Handle feed operation mode (manual operation) is selected.

[Operation]

When the "Handle mode" signal (H) is turned ON, handle feed mode is selected.

Axis motion starts when the manual pulse generator hand wheel is rotated after axis is selected by the "n-th handle axis selection code" (HSn1 to HSn16) and the "n-th handle valid" (HSnS), and this signal is turned ON. Speed of the axis motion depends on setting of feedrate magnification (MP1 to 4).

When the operation mode conflicts with any other mode or when no mode is selected, the NC alarm (operation error (M01 0101) occurs.

Automatic operation handle interruption function is valid when the "Handle mode" signal is turned ON while the automatic operation mode is selected.

[Related signals]

- (1) 1st handle axis selection code (HS11 to 116: YC40), 1st handle valid (HS1S: YC47)
- (2) 2nd handle axis selection code (HS21 to HS216: YC48), 2nd handle valid (HS2S: YC4F):
Valid only for handle 2-axis specification.
- (3) 3rd handle axis selection code (HS31 to 316: YC50), 3rd handle valid (HS3S: YC57):
Valid only for handle 3-axis specification.
- (4) Handle/Incremental feed magnification code m (MP1 to 4: YC80 to YC82)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Incremental mode	S	YC02	YD42	YE82	YFC2	Y1102	Y1242	Y1382	Y14C2

[Function]

Incremental feed mode for manual operation is selected.

[Operation]

When the "Incremental mode" signal (S) is turned ON, incremental feed mode is selected.

Every time the "Incremental mode" (S) is turned ON and the feed axis selection signal (+J1 to 8, -J1 to 8) of the desired axis is turned ON, axis movement is performed. Axis movement depends on setting of the "Handle/Incremental feed magnification code m" (MP1 to 4) at that time.

The movement speed at that time is the rapid traverse speed when the "Rapid traverse" signal (RT) is ON, and the manual feedrate (*JV1 to *JV16) when the signal (RT) is OFF.

When the operation mode conflicts with any other mode or when no mode is selected, the NC alarm (operation error (M01 0101)) occurs.

Note

- (1) The incremental mode is also called as step mode.

[Related signals]

- (1) Handle/Incremental feed magnification code m (MP1 to 4: YC80 to YC82)
- (2) Feed axis selection (+J1 to 8: Y8E0, -J1 to 8: Y900)
- (3) Manual feedrate code m (*JV1 to *JV16: YC70)
- (4) Rapid traverse (RT: YC26)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed mode	PTP	YC03	YD43	YE83	YFC3	Y1103	Y1243	Y1383	Y14C3

[Function]

Manual arbitrary feed mode in manual operation is selected.

[Operation]

Manual arbitrary feed mode is selected when the "Manual arbitrary feed mode" signal (PTP) is turned ON (1).

[Caution]

To turn ON (1) the "Manual arbitrary feed mode", turn OFF (0) other modes and automatic mode.

If the other manual mode and automatic mode are ON (1), the manual arbitrary feed mode will not be set. Note that these modes can be selected simultaneously when manual and automatic modes are enabled at the same time.

[Related signals]

(1) Signals from PLC to controller

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YCA0	YDE0	YF20	Y1060	CX11	Manual arbitrary feed 1st axis selection code 1
YCA1	YDE1	YF21	Y1061	CX12	Manual arbitrary feed 1st axis selection code 2
YCA2	YDE2	YF22	Y1062	CX14	Manual arbitrary feed 1st axis selection code 4
YCA3	YDE3	YF23	Y1063	CX18	Manual arbitrary feed 1st axis selection code 8
YCA4	YDE4	YF24	Y1064	CX116	Manual arbitrary feed 1st axis selection code 16
YCA5	YDE5	YF25	Y1065		
YCA6	YDE6	YF26	Y1066		
YCA7	YDE7	YF27	Y1067	CX1S	Manual arbitrary feed 1st axis valid

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YCA8	YDE8	YF28	Y1068	CX21	Manual arbitrary feed 2nd axis selection code 1
YCA9	YDE9	YF29	Y1069	CX22	Manual arbitrary feed 2nd axis selection code 2
YCAA	YDEA	YF2A	Y106A	CX24	Manual arbitrary feed 2nd axis selection code 4
YCAB	YDEB	YF2B	Y106B	CX28	Manual arbitrary feed 2nd axis selection code 8
YCAC	YDEC	YF2C	Y106C	CX216	Manual arbitrary feed 2nd axis selection code 16
YCAD	YDED	YF2D	Y106D		
YCAE	YDEE	YF2E	Y106E		
YCAF	YDEF	YF2F	Y106F	CX2S	Manual arbitrary feed 2nd axis valid

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YCB0	YDF0	YF30	Y1070	CX31	Manual arbitrary feed 3rd axis selection code 1
YCB1	YDF1	YF31	Y1071	CX32	Manual arbitrary feed 3rd axis selection code 2
YCB2	YDF2	YF32	Y1072	CX34	Manual arbitrary feed 3rd axis selection code 4
YCB3	YDF3	YF33	Y1073	CX38	Manual arbitrary feed 3rd axis selection code 8
YCB4	YDF4	YF34	Y1074	CX316	Manual arbitrary feed 3rd axis selection code 16
YCB5	YDF5	YF35	Y1075		
YCB6	YDF6	YF36	Y1076		
YCB7	YDF7	YF37	Y1077	CX3S	Manual arbitrary feed 3rd axis valid

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
YCB8	YDF8	YF38	Y1078	CXS1	Manual arbitrary feed Smoothing off
YCB9	YDF9	YF39	Y1079	CXS2	Manual arbitrary feed Axis independent
YCBA	YDFA	YF3A	Y107A	CXS3	Manual arbitrary feed EX.F/MODAL.F
YCBB	YDFB	YF3B	Y107B	CXS4	Manual arbitrary feed G0/G1
YCBC	YDFC	YF3C	Y107C	CXS5	Manual arbitrary feed MC/WK
YCBD	YDFD	YF3D	Y107D	CXS6	Manual arbitrary feed ABS/INC
YCBE	YDFE	YF3E	Y107E	*CXS7	Manual arbitrary feed Stop
YCBF	YDFF	YF3F	Y107F	CXS8	Manual arbitrary feed Strobe

Device No.					
\$1	\$2	\$3	\$4	Abbrev.	Signal name
R2508	R2708	R2908	R3108		1st handle/incremental feed magnification
R2509	R2709	R2909	R3109		
R2510	R2710	R2910	R3110		2nd handle feed magnification
R2511	R2711	R2911	R3111		
R2512	R2712	R2912	R3112		3rd handle feed magnification
R2513	R2713	R2913	R3113		
R2544	R2744	R2944	R3144		Manual arbitrary feed 1st axis travel amount
R2545	R2745	R2945	R3145		
R2546	R2746	R2946	R3146		
R2547	R2747	R2947	R3147		
R2548	R2748	R2948	R3148		Manual arbitrary feed 2nd axis travel amount
R2549	R2749	R2949	R3149		
R2550	R2750	R2950	R3150		
R2551	R2751	R2951	R3151		
R2552	R2752	R2952	R3152		Manual arbitrary feed 3rd axis travel amount
R2553	R2753	R2953	R3153		
R2554	R2754	R2954	R3154		
R2555	R2755	R2955	R3155		

(2) Signals from controller to PLC

- In manual arbitrary feed mode (PTPO: XC03)
- In manual arbitrary feed (CXN: XC16)
- Manual arbitrary feed completion (CXFIN: XC1C)

(3) Others

- Feedrate least increment code 1, 2 (PCF1: YC78, PCF2: YC79)
- Manual/Automatic simultaneous valid n-th axis (MAE1 to 8)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Reference position return mode	ZRN	YC04	YD44	YE84	YFC4	Y1104	Y1244	Y1384	Y14C4

[Function]

Reference position return mode is selected.

Reference position return is the return of the axis movement components (tools, tables, etc.) to a previously determined position for an individual machine.

[Operation]

The reference position return mode is selected when the "Reference position return mode" signal (ZRN) is turned ON. Select the reference position return mode and turn ON the feed axis selection signal (+J1 to 8, -J1 to 8) of the specified axis to return to the reference position.


When the operation mode conflicts with any other mode or when no mode is selected, the NC alarm (operation error (M01 0101) occurs.

The first reference position return after the controller power is turned ON is the dog-type return (excluding when the basic machine coordinate system is established for the absolute position detection specifications). After the second manual reference position return (when basic machine coordinate system is established), the dog-type return or high-speed return is selected with the machine parameter/basic specification parameter "#1063 mandog".


<Dog-type reference position return pattern>

The return pattern is determined by the final entry method of the machine parameter reference position return.

(a) Operation when axis is moved in same direction as the final entry method, and dog is tripped.



(b) When axis is moved in opposite direction from final entry method, and dog is tripped.



- After the near-point dog is detected and the approach speed is applied, the axis will move to the reference position even if the "Feed axis selection" signal is turned OFF. Thus, after the approach speed is applied, another axis can be switched to and reference position return executed.
- The entry direction (final entry direction) after the near-point dog is tripped is set with parameters.
- The feedrate before the approach speed is the reference position return reapid traverse feedrate if the "Rapid traverse" signal (RT) is ON, and the manual feedrate (*JV1 to *JV16) if the signal is OFF.
- The approach speed is set with the parameters.
- When the reference position is reached, the movement stops even if the feed axis selection signal is ON, and the "1st reference position reached" signal (ZP1n) turns ON.

<High-speed return and reference position return>

- The axis moves toward the reference position. The movement speed is rapid traverse if the "Rapid traverse" signal is ON, and manual feedrate if it is OFF.
- When the axis reaches the reference position, it stops moving even if the feed axis selection signal is ON, and the "1st reference position reached" signal (ZP1n) turns ON.
- The feed axis selection signal for high-speed return is valid only in the reference position direction. If a signal in the opposite direction is specified, the NC alarm (operation error (M01 0003)) occurs.

[Related signals]

- (1) Feed axis selection (+J1 to 8: Y8E0, -J1 to 8: Y900)
- (2) Manual feedrate code m (*JV1 to 16: YC70)
- (3) Rapid traverse (RT: YC26)
- (4) 1st reference position reached (ZP11 to 18: X800 to 7)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Automatic initialization mode	AST	YC05	YD45	YE85	YFC5	Y1105	Y1245	Y1385	Y14C5

[Function]

The automatic initialization mode is selected.

[Operation]

This mode is selected when automatic initialization is to be carried out with the machine end stopper method of absolute position detection.

The initialization is started when the automatic initialization mode is selected, and the Feed axis selection signal (+Jn, -Jn) in the direction of the machine end of the axis to be initialized is turned ON.

Note

- (1) The automatic initialization mode is invalid when the absolute position encoder is not provided and when the machine end stopper method is not selected for the absolute position detection. (During feed axis selection, "M01 OPERATION ERROR 0024" occurs.)
- (2) This mode will not start in the following cases of the machine end stopper method absolute position detection. (The message "Start not possible" is displayed.)
 - When "#0 Absolute posn set" on the [ABS. POSITION SET] screen is not set to "1".
 - When "#2 Zero-P" on the [ABS. POSITION SET] screen is set incorrectly.
 - When "#2055 pushf" on the [ABS. POSITION PARAMETER] screen has not been set.
 - When "Z71 0005" has occurred.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Memory mode	MEM	YC08	YD48	YE88	YFC8	Y1108	Y1248	Y1388	Y14C8

[Function]

Memory mode of automatic operation is selected.

In this mode of operation, automatic operation is based on programs stored in the memory.

[Operation]

- Memory mode is selected when the "Memory mode" signal (MEM) turns ON.
- The program is started with the "Automatic operation "start" command" signal (ST).
- When the mode conflicts with any other automatic operation mode or when no automatic operation mode is selected while automatic operation is active, the NC alarm (operation error (M01 0101)) occurs and the operation stops at the block.

Note

- (1) Even if it is not in automatic operation, any invalid mode of operation triggers the operation error.

[Related signals]

- (1) Automatic operation "start" command (ST: YC10)
- (2) Automatic operation "pause" command (*SP: YC11)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tape mode	T	YC09	YD49	YE89	YFC9	Y1109	Y1249	Y1389	Y14C9

[Function]

TAPE mode of automatic operation is selected.

In this mode of operation, automatic operation is based on tape command (RS232C input) programs stored in NC tape.

[Operation]

- Tape mode is selected when the "Tape mode" signal (T) turns ON.
- The program is started with the "Automatic operation "start" command" signal (ST).
- When the mode conflicts with any other automatic operation mode or when no automatic operation mode is selected while automatic operation is active, the NC alarm (operation error (M01 0101)) occurs and the operation stops at the end of the block.

Note

- (1) Even if it is not in automatic operation, any invalid mode of operation will trigger the operation error.

[Related signals]

- (1) Automatic operation "start" command (ST: YC10)
- (2) Automatic operation "pause" command (*SP: YC11)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MDI mode	D	YC0B	YD4B	YE8B	YFCB	Y110B	Y124B	Y138B	Y14CB

[Function]

MDI (Manual Data Input) mode of automatic operation is selected.

Automatic operation is performed with the program set in the MDI screen.

[Operation]

- MDI mode is selected when the "MDI mode" signal (D) turns ON.
- The program is started with the "Automatic operation "start" command" signal (ST).
- When the mode conflicts with any other automatic operation mode or when no automatic operation mode is selected while automatic operation is active, the NC alarm ("M01 operation error 0101") occurs, and the operation will stop at the block.

Note

- (1) Even if it is not in automatic operation, any invalid mode of operation triggers the operation error.

[Related signals]

- (1) Automatic operation "start" command (ST: YC10)
- (2) Automatic operation "pause" command (*SP: YC11)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Sub part system control: Sub part system control I mode	SBSM	YC0E	YD4E	YE8E	YFCE	Y110E	Y124E	Y138E	Y14CE

[Function]

This signal specifies the sub part system in the sub part system control I.

After this signal turns ON and the sub part system control I mode is entered, the sub part system can be started by commanding the sub part system control I (G122).

[Operation]

In the part system in which this signal is turned ON, the "Sub part system control: Sub part system control I mode ON" signal (SBSMO: XC0E) is output to the PLC.

[Related signals]

- (1) Sub part system control: Sub part system control I mode ON (SBSMO: XC0E)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Automatic operation "start" command (Cycle start)	ST	YC10	YD50	YE90	YFD0	Y1110	Y1250	Y1390	Y14D0

[Function]

This signal is used to start automatic operation in MEMORY mode, MDI mode or TAPE mode, or to restart after automatic operation pause (halt) or block stop.

[Operation]

- The "Automatic operation "start" command" signal (ST) is enabled when the pressed "auto operation start" push button is released. That is, the operation starts when the automatic operation signal changes from ON to OFF. The signal must be ON at least 100 ms.
- The "In automatic operation start"" signal (STL) turns ON when the pressed "auto operation start" push button is released, and turns OFF when "auto operation pause (or halt)" push button is pressed or block stop occurs in single-block operation.
- The "Automatic operation "start" command" signal (ST) is disabled when:
 - Automatic operation starts.
 - The "Automatic operation "pause" command" signal (*SP) is OFF.
 - During reset (The "Reset & rewind" signal is ON)
 - An alarm is occurring.
 - Sequence No. is being searched for.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

- ♦ Automatic operation stops or is suspended or block stops when:
 - The "Automatic operation "pause" command" signal (*SP) turns OFF.
 - Reset occurs. (The "Reset & rewind" signal turns ON)
 - Alarm which causes stop to automatic operation occurs.
 - Automatic operation mode is changed to manual operation mode.
 - Mode is changed to other automatic operation mode and then the block in execution is completed.
 - Block in execution is completed after the "Single-block" signal (SBK) turns ON.
 - Block in execution is completed after the "Automatic machine lock" signal (AMKL) turns ON.
 - Program specified in MDI mode has been executed completely.

[Related signals]

- (1) Memory mode (MEM: YC08)
- (2) Tape mode (T: YC09)
- (3) MDI mode (D: YC0B)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
B	Automatic operation "pause" command (Feed hold)	*SP	YC11	YD51	YE91	YFD1	Y1111	Y1251	Y1391	Y14D1

[Function]

The axis movement can be decelerated and stopped halfway while the machine is moving by automatic operation with this command signal. The restart is based on the "Automatic operation "start" command" signal (ST).

[Operation]

- ♦ When the "Automatic operation "pause" command" signal (*SP) turns OFF, the operation is as follows.
 - During automatic operation, the automatic operation stops. The "In automatic operation "pause"" (SPL) will be turned ON.
 - Restart with the automatic start (ST) button. (Perform it after turning OFF the *SP signal.)
- ♦ Automatic operation does not immediately stop even when the "Automatic operation "pause" command" signal (*SP) is turned OFF. It will stop only after it reaches a place where it can be stopped.
 - During tapping in fixed cycle. Automatic operation stops when tapping is completed and the tool returns to "R" point.
 - During thread cutting. Automatic operation stops when a block for axis motion (other than thread cutting), which comes first after the "Automatic operation "pause" command" signal (*SP) turns OFF, is completed. If the "Automatic operation "pause" command" signal (*SP) remains OFF, however, automatic operation stops immediately after a block (other than thread cutting) is started.
 - When control variable "feed hold invalid" has been set by user macro. Automatic operation stops immediately after a block where the control variable "feed hold invalid" is cleared starts.
- ♦ The "Automatic operation "pause" command" signal (*SP) is valid even during machine lock.

[Related signals]

- (1) Memory mode (MEM: YC08)
- (2) Tape mode (T: YC09)
- (3) MDI mode (D: YC0B)
- (4) Automatic operation "start" command (ST: YC10)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Single block	SBK	YC12	YD52	YE92	YFD2	Y1112	Y1252	Y1392	Y14D2

[Function]

Machining program can be executed block by block in automatic operation.

[Operation]


When the "Single block" signal (SBK) turns ON, the controller operates as follows.

- If automatic operation is being executed, it will stop after the running block ends. To execute the command of the next block, the "Automatic operation start" command (ST) must be turned from ON to OFF again.
- No particular operation occurs unless automatic operation is in progress. However, if automatic operation is started while the "Single block" signal (SBK) is ON, one block is executed and stopped. This allows the commanded program to be executed one block at a time.

If the "Single block" signal (SBK) is ON at the end of the block, operation usually stops immediately. However, in the following case, the operation will continue and stop only after it reaches the point where it can be stopped.

- During cycle operation such as a fixed cycle.

At this time, which block during cycle operation accepts a single block depends on each cycle. Refer to the section for each cycle in the Programming Manual.



Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
B	Block start interlock	*BSL	YC13	YD53	YE93	YFD3	Y1113	Y1253	Y1393	Y14D3

[Function]

This signal prohibits start of the next block in automatic operation (memory, MDI or tape).

[Operation]

While the "Block start interlock" signal (*BSL) is OFF, execution of the next block will not be started in automatic operation. When the signal is given during execution of a block, the execution of the block continues until it is completed. Automatic operation is not suspended. Since a command for the next block is waiting as a valid command, execution of program starts when the "Block start interlock" signal (*BSL) turns ON.

Note

- (1) This signal is valid to all blocks including blocks internally generated in controller by fixed cycle, etc.
- (2) The signal (*BSL) is ON when the power is turned ON. When the signal is not used, programming on the PLC is not required for this signal.
- (3) When the machining surface is selected or canceled while the "Block start interlock" signal (*BSL) is OFF with the R-Navi function, the operation error (M01 0109) occurs. After turning ON the "Block start interlock" signal (*BSL) again, the machining surface is selected or canceled.

When the axis is moved automatically or manually in machining surface indexing, the operation error (M01 0109) occurs in both cases.

[Related signals]

- (1) Cutting block start interlock (*CSL: YC14)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
B	Cutting block start interlock	*CSL	YC14	YD54	YE94	YFD4	Y1114	Y1254	Y1394	Y14D4

[Function]

This signal prohibits start of an axis motion command block other than that for positioning in automatic operation (memory, MDI or tape).

[Operation]

While the "Cutting block start interlock" signal (*CSL) is OFF, execution of an axis motion command block other than that for positioning may not be started in automatic operation. When the signal is given during execution of a block, the execution of the block continues until it is completed.

Automatic operation is not suspended. Since a command for the next block is waiting validly, execution of program starts when the "Cutting block start interlock" signal (*CSL) turns ON.

Note

- (1) This signal is valid to all blocks including blocks internally generated in controller by fixed cycle, etc.
- (2) The signal (*CSL) is ON when the power is turned ON. When the signal is not used, programming on the PLC is not required for this signal.

[Related signals]

- (1) Block start interlock (*BSL: YC13)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Dry run	DRN	YC15	YD55	YE95	YFD5	Y1115	Y1255	Y1395	Y14D5

[Function]

Feedrate in automatic operation is specified by manually set value instead of program command value (F value).

[Operation]**<The "Dry run" signal given during cutting feed>**

- When the "Rapid traverse" signal (RT) is ON, the cutting feedrate is equal to the maximum cutting feedrate. In this case, "cutting feedrate override" and "rapid traverse override" are ignored.
- When the "Rapid traverse" signal (RT) is OFF, the manual feedrate (*JV1 to *JV16) is applied. Cutting feed override will also be valid if the "Manual override method selection" signal (OVSL) is ON.

<The "Dry run" signal given during rapid traverse>

- The parameter must be turned ON to enable dry run for rapid traverse (G0, G27, G28, G29, G30).
- When the "Rapid traverse" signal (RT) is ON, the "Dry run" signal is ignored.
- When "Rapid traverse" signal (RT) is OFF, the speed is equal to manually set speed.

Note

- (1) Dry run is not applicable to manual operation.
- (2) Dry run is valid even during G84 or G74 operation.

<Dry run of thread cutting>

- Whether to enable or disable dry run for thread cutting is set with "#1279 ext15/bit4" (Dry run OFF during thread cutting).
When "#1279 ext15/bit4" (Dry run OFF during thread cutting) is set to "1", dry run is disabled. However, while the "Spindle OFF mode" signal is ON, dry run is enabled regardless of the parameter setting, and the state of dry run follows the "Dry run" signal.
- The feedrate by the dry run is not synchronized with the spindle rotation.
- The "Dry run" signal is checked at the start of thread cutting. If the signal is changed during thread cutting, the change is ignored.

[Related signals]

- (1) Manual feedrate code m (*JV1 to *JV16: YC70)
- (2) Rapid traverse (RT: YC26)
- (3) Manual override method selection (OVSL: YC59)
- (4) Spindle OFF mode (YCD3)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Error detection	ERD	YC17	YD57	YE97	YFD7	Y1117	Y1257	Y1397	Y14D7


[Function]

Machine motion is stopped momentarily in transition from a cutting feed block to other block during automatic operation to provide time for determination whether in-position check is made or not before start of the next block.

Block-to-block transition may cause rounding in cutting because of delay caused by acceleration or deceleration, and servo response delay. Rounding can be eliminated by stopping the machine motion between the blocks by turning ON the "Error detection" signal (ERD).

[Operation]

When the "Error detection" signal (ERD) is ON in block-to-block transition during cutting in automatic operation, in-position check is accomplished. If this signal is OFF, the next block starts after completion of the preceding block without stop.

**Note**

- Generally, this signal (ERD) is turned ON and OFF using an appropriate miscellaneous function (M code, etc.) so that command program can determine whether machine motion should be stopped or not. When this signal is ON, the status is same as the case where G09 is specified by the command program. Consequently, it is recommended to use G function instead unless there is a specific reason.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	NC reset 1	NRST1	YC18	YD58	YE98	YFD8	Y1118	Y1258	Y1398	Y14D8

[Function]


This signal is used to reset the control unit.

[Operation]

When this signal (NRST1) is turned ON, the control unit can be reset.

Generally, the signal of the reset button on the NC operation board is set to the "NC reset 1" (NRST1). At this time, the control unit will be in the following states.

- The G command modal is held.
- The tool compensation data is held.
- The memory is indexed.
- The error/alarm is reset.
- The MST code output is held.
- The M code independent output (M00, M01, M02, M30) turns OFF.
- The axis movement stops.
- The "In reset" signal (RST) is output.

**[Related signals]**

- (1) NC reset 2 (NRST2: YC19)
- (2) Reset & rewind (RRW: YC1A)
- (3) In "reset" (RST: XC15)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	NC reset 2	NRST2	YC19	YD59	YE99	YFD9	Y1119	Y1259	Y1399	Y14D9

[Function]

This signal is used to reset the control unit.


[Operation]

When this signal (NRST2) is turned ON, the control unit can be reset.

Generally, this is turned ON when the miscellaneous function M02 or M30 is executed. In some cases, the "Reset & rewind" (RRW), which is explained later, may turn ON.

At this time, the control unit will be in the following states.

- The G command modal is initialized.
- The tool compensation data is canceled. (Will not be applied.)
- The memory is not indexed.
- The error/alarm is reset.
- The MST code output is held.
- The M code independent output (M00, M01, M02, M30) turns OFF.
- The axis movement stops.
- The "In reset" signal (RST) is output.

**[Related signals]**

- (1) NC reset 1 (NRST1: YC18)
- (2) Reset & rewind (RRW: YC1A)
- (3) In "reset" (RST: XC15)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Reset & rewind	RRW	YC1A	YD5A	YE9A	YFDA	Y111A	Y125A	Y139A	Y14DA

[Function]

This signal is used to reset the control unit.

During memory operation, the head of the machining program currently in operation can be called.

The reset key in the communication terminal is also set to YC1A by the sequence program.

[Operation]


When the "Reset & rewind" signal (RRW) turns ON, the controller operates as follows.

- (1) The moving control axis decelerates and stops.
- (2) After axis motion stops, the CNC is reset. In approximately 0.5 second after the CNC is reset, the "In reset" signal (RST) turns ON.
- (3) The rewind is also applied at the same time as the reset, and the "In rewind" signal (RWD) turns ON.
In memory operation mode, the head of the program in execution is called. (Memory indexing)
- (4) While the "Reset & rewind" signal (RRW) is ON, automatic operation and manual operation are not possible.
- (5) G command modal is initialized.
- (6) Tool compensation (offset) data are canceled. (The axis does not move.)
- (7) Error/alarm is reset.
- (8) M, S, T code outputs are held. (Strobe signal turns OFF.)
- (9) M code independent output (M00, M01, M02 and M30) is turned OFF.

<Operation example>

The processing when M02 or M30 is commanded by the program is shown below.

Generally, when M02 (or M30) is executed by the program, this signal (RRW) is returned after the specified operation is completed. This signal is not returned to the "M function finish 1" (FIN1) or the "M function finish 2" (FIN2). (See *1 in the figure below.)

**[Related signals]**

- (1) In "reset" (RST: XC15)
- (2) In rewind (RWD: XC17)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
B	Chamfering	*CDZ	YC1B	YD5B	YE9B	YFDB	Y111B	Y125B	Y139B	Y14DB

[Function]


Chamfering can be ignored in the thread cutting cycle.

[Operation]


Status of this signal is determined at start of thread cutting cycle.

<When the "Chamfering" (*CDZ) is OFF>

Chamfering (at end of thread cutting) is performed.

**<When the "Chamfering" (*CDZ) is ON>**

Chamfering is not performed (the signal is ignored).



4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Automatic restart	ARST	YC1C	YD5C	YE9C	YFDC	Y111C	Y125C	Y139C	Y14DC

[Function]

If this signal is turned ON after the end of the machining program execution, the same machining program is restarted.

[Operation]

The same machining program is restarted if this signal is turned ON during cycle start.

[Timing chart]**Note**

- (1) The modal is initialized with this signal.
- (2) This signal is valid only during cycle start.
- (3) This signal is valid during the memory and MDI automatic operation modes.
- (4) Normally, the "M code independent output" signal for M02 or M30 is input into this signal, but in this case, do not input the completion signal (FIN1, FIN2) of M02 or M30.
- (5) If the "Automatic operation "pause" command" signal (*SP) is valid, the "Automatic restart" signal is invalid.
- (6) This signal is invalid during single block stop.
- (7) Note that if an M command other than M02 or M30 is input into this signal, the program returns to the start point without completing the program, and the program is restarted.
- (8) If the "Reset & rewind" (RRW) is applied during the automatic restart process (*2 in the time chart above), modal initialization and rewind will be performed, but the "Automatic restart" signal will be disabled.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	External search strobe		YC1D	YD5D	YE9D	YFDD	Y111D	Y125D	Y139D	Y14DD

[Function] [Operation]

The NC starts the external search at the rising edge of this signal.

A block specified with program No. (R2526), sequence No. (R2528), and block No. (R2530) is searched for operation.

When program No. and/or sequence No. is omitted, the operation changes as shown in the following table.

Program No. (R2526)	Sequence No. (R2528)	Starting point for searching the block No. (R2530)
Designated	Designated	Designated sequence No. for designated program
Designated	Not specified (*1)	Head of designated program
Not specified (*1)	Designated	Designated sequence No. in currently selected program
Not specified (*1)	Not specified (*1)	Error: 4 Refer to "External search status" (R500).

(*1) "Not designated" indicates that the value of the signal is "0" (OFF).

[Related signals]

- (1) External search finished (XC1D)
- (2) External search device No. (R2525)
- (3) External search program No. (R2526)
- (4) External search sequence No. (R2528)
- (5) External search block No. (R2530)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	M function finish 1	FIN1	YC1E	YD5E	YE9E	YFDE	Y111E	Y125E	Y139E	Y14DE

[Function]

This status signal informs the controller that specified miscellaneous (M) function, spindle (S) function, tool (T) function or 2nd miscellaneous function (A, B or C) is completed on the PLC side.

[Operation]

If the M, S, T or 2nd M function command is executed during automatic operation, the code and each function strobe (MF_n, SF_n, TF_n, BF_n) turns ON.


The PLC executes the specified operation after verifying that one (or more) of the M, S, T and B functions has been commanded by each function strobe. After the execution is completed, turn ON the "M function finish 1" signal (FIN1).

When the controller verifies that the "M function finish 1" signal turns ON, each function strobe is turned OFF.

For PLC, check that each function strobe is turned OFF, and then turn OFF the "M function finish 1".

With the signal FIN1 turned OFF, the controller proceeds to the next block.

The following is an example of a time chart when the auxiliary function (M) is used.



M function finish signals include "M function finish 1" and "M function finish 2" (refer to the next page). The difference is whether to proceed to the next block at the falling edge or at the rising edge. These can be used properly for each operation in one PLC.

Note

- (1) The "M function finish 1" signal (FIN1) is common to M, S, T and B functions.
- (2) The "M function finish 1" signal is also a signal for updating the spindle rotation speed output (S command data, etc.) when the S function is executed.
- (3) If the "M function finish 1" signal is ON before M, S, T or B function is specified, data pertinent to M, S, T or B function are not output.
- (4) When the "Reset & rewind" signal (RRW) is sent to the controller by the M02 or M30 command, do not return "M function finish 1" signal. If the "M function finish 1" signal is returned by the M02 command at the end of the machining program, the NC alarm (the program error (P36)) occurs.
- (5) This signal is not used in the high-speed method (parameter "#1278 ext14/bit1" is set to "1").

[Related signals]

- (1) M function finish 2 (FIN2: YC1F)
- (2) M function strobe n (MF_n: XC60)
- (3) S function strobe n (SF_n: XC64)
- (4) T function strobe n (TF_n: XC68)
- (5) 2nd M function strobe n (BF_n: XC6C)
- (6) M, S, T, B function data (output to file register R: R504 and later)
- (7) Reset & rewind (RRW: YC1A)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	M function finish 2	FIN2	YC1F	YD5F	YE9F	YFDF	Y111F	Y125F	Y139F	Y14DF

[Function]

This status signal informs the controller that specified miscellaneous (M) function, spindle (S) function, tool (T) function or 2nd miscellaneous function (A, B or C) is completed on the PLC side. This signal is effective in shortening the cycle time in machining programs with more M, S, T, and 2nd miscellaneous function commands compared to the "M function finish 1" signal (FIN1).

[Operation]


If the M, S, T or 2nd M function command is executed during automatic operation, the code and each function strobe (MF_n, SF_n, TF_n, BF_n) turns ON.

The PLC executes the specified operation after verifying that one (or more) of M, S, T and 2nd M function has been commanded. After the execution is completed, turn ON the "M function finish 2" signal (FIN2).

When the controller verifies that the "M function finish 2" signal is turned ON, it turns OFF each function strobe and at the same time proceeds to the next block.

For PLC, confirm that each function strobe is turned OFF, and turn OFF the "M function finish 2" signal.

The following is an example of a time chart when the auxiliary function (M) is used.



The M function finish signals include the "M function finish 1" (refer to the previous page) and the "M function finish 2". The only difference is if the next block is proceeded to at the falling edge or at the rising edge. These can be used separately per operation in one PLC.

Note

- (1) The "M function finish 2" signal (FIN2) is common to M, S, T and B functions.
- (2) The "M function finish 2" signal is also the signal for upgrading the spindle speed output (S analog data, etc.) during S function execution.
- (3) If signal FIN2 has been ON before M, S, T or B function is specified, data pertinent to M, S, T or B function are not output.
- (4) When the "Reset & rewind" signal (RRW) is sent back to the controller by M02 or M30 command, do not send back the "M function finish 2" signal or the "M function finish 1" signal. If the "M function finish 2" signal or the "M function finish 1" signal is returned by the M02 command at the end of the machining program, the NC alarm (the program error (P36)) occurs.
- (5) This signal is not used in the high-speed method (parameter "#1278 ext14/bit1" is set to "1").

[Related signals]

- (1) M function finish 1 (FIN1: YC1E)
- (2) M function strobe n (MF_n: XC60)
- (3) S function strobe n (SF_n: XC64)
- (4) T function strobe n (TF_n: XC68)
- (5) 2nd M function strobe n (BF_n: XC6C)
- (6) M, S, T, B function data (output to file register R: R504 and later)
- (7) Reset & rewind (RRW: YC1A)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool length measurement 1	TLM	YC20	YD60	YEA0	YFE0	Y1120	Y1260	Y13A0	Y14E0

[Function]

The tool length manual measurement 1 is used by this signal. For M system, the tool length manual measurement 1 and 2 are used by this signal.

[Operation]

When the "Tool length measurement 1" signal (TLM) is turned ON (1), the tool length compensation amount starts to be calculated automatically inside the controller.

[Caution]

- (1) This signal is invalid if the tool measurement screen is not selected.
- (2) Turn this signal OFF before executing a program with manual speed command.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool length measurement 2	TLMS	YC21	YD61	YEA1	YFE1	Y1121	Y1261	Y13A1	Y14E1


[Function]

Tool length measurement 2 is selected by this signal.

[Operation]

When the "Tool length measurement 2" signal (TLMS) is turned ON (1), calculation of tool length compensation amount is automatically started in the controller.

When a skip signal is input during the tool length measurement, the tool length compensation amount is calculated at that point.

[Timing chart]**[Caution]**

- (1) To use the tool length measurement 2 function, select manual operation mode. If the manual mode is not selected, the measurement mode will not be set.
- (2) The tool length measurement 2 can be used with a machine equipped with tool measurement sensor.
- (3) The tool length compensation amount calculation result is automatically written inside the controller.
- (4) With the tool length measurement 2, multiple part systems cannot be measured simultaneously.

[Related signals]

- (1) Tool length measurement 2 Tool No. (R2618)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Synchronization correction mode	SYCM	YC22	YD62	YEA2	YFE2	Y1122	Y1262	Y13A2	Y14E2

[Function]

When the "M01 OPERATION ERROR 0051" (Synchronization error too large) occurs, the occurring error is corrected without changing the operation method with this mode.


[Operation]

In the correction mode, the operation is as follows.

- The synchronous control is not carried out even in the synchronized axis, and the reference axis and synchronized axis are handled as independent two axes in the each control part. Thus, the reference axis and synchronized axis can be moved individually.
- If the zero point is fixed, the synchronization error check is carried out.
- If the correction mode switch is turned ON during selecting the mode except the handle or manual arbitrary feed mode, the "M01 OPERATION ERROR 0120" (Synchronization correction mode ON) occurs.

In the handle mode or manual arbitrary feed mode, the correction mode can be set by turning ON the correction mode switch, and "CORRECTION MODE" is displayed at the operation mode display position.

The operation procedure is shown below.

**[Related signals]**

- (1) Synchronous control operation method (R2589)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Program restart	PRST	YC23	YD63	YEA3	YFE3	Y1123	Y1263	Y13A3	Y14E3

[Function]

With the program restart function, when the axis is returned to the restart position with the manual mode after the restart search is performed, the direction can be checked and the axis can be stopped at the restart position.

[Operation]

If the "Program restart" signal (PRST) is turned ON after the restart search is performed and the axis is moved to the restart position direction with the manual mode, the axis is stopped at the restart position automatically. The [RESTART-R] values on the program restart screen are set to zero and "RP" appears by the side of the [RESTART-P] values. Attempting to move the axis in the opposite direction of the restart position results in an operation error.

[RESTART – (G54)]		[RESTART – R]	
X	- 130.000RP	X	0.000
Y	-10.000RP	Y	0.000
Z	0.000RP	Z	0.000

When the parameter "#1302 AutoRP" (Automatic return by program restart) is set to "1", there is no need to use this signal (PRST:YC23). This is because when the parameter is set to "1", the machining is restarted after the axis has returned to the restart position at the same speed as when the "Dry run" signal (YC15) is turned ON at cycle start and all the axes have returned. Even when the parameter "#1302 AutoRP" is set to "1", the axis can be returned to the restart position manually by turning ON this signal (YC23).

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Macro interrupt	UIT	YC25	YD65	YEA5	YFE5	Y1125	Y1265	Y13A5	Y14E5

[Function]

When the controller is ready for user macro interrupt, the program being in execution can be interrupted, or other program can be executed after the former program has been executed, by turning ON the "Macro interrupt" signal (UIT).

[Operation]

When the "Macro interrupt" signal (UIT) turns ON within time interval starting with M96 command and ending with M97 command or reset, the program being in execution can be interrupted for execution of other program.

The "Macro interrupt" signal (UIT) becomes valid when:

- Memory, tape or MDI is selected.
- Automatic operation is selected. (STL is ON.)
- Other user macro is not being executed.

The "Macro interrupt" signal (UIT) is accepted in "status trigger" method or "edge trigger" method. The method is selected by the parameter #1112.

<Status trigger method>

While the "Macro interrupt" signal (UIT) is ON, the signal is accepted as valid.

When the "Macro interrupt" signal (UIT) is turned ON when the user macro interrupt is enabled by M96, the interrupt program is executed.


By keeping the "Macro interrupt" signal (UIT) ON, the interrupt program can be executed repeatedly.

<Edge trigger method>

When the "Macro interrupt" signal (UIT) status changes from OFF to ON at the rising edge, the signal is accepted as valid.

This method is used when interrupt program is executed only once.

<Command format>



Refer to the "Programming Manual" for details on the user macro interrupt function, including the interrupt method and call method, when the "Macro interrupt" signal (UIT) is turned ON.

Note

- (1) M96 and M97 can be changed to other M code by using a parameter.
- (2) The M code for user macro interrupt control is processed internally and is not output to an external source (PLC).

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Rapid traverse	RT	YC26	YD66	YEA6	YFE6	Y1126	Y1266	Y13A6	Y14E6


[Function]

This signal is for setting the moving speed or feedrate of axis motion in the jog mode, incremental feed mode, or reference position return mode of manual operation as the rapid traverse speed.

[Operation]

When the "Rapid traverse" signal (RT) is turned ON, the controller operates as follows.

- The jog and incremental feedrate will be the rapid traverse feedrate set with parameters.
- The speed until the near-point detection dog signal is detected during dog-type reference position return will be the reference position return rapid traverse feedrate set with parameters.
- The speed changes to rapid traverse feedrate when this signal (RT) is turned OFF during jog, incremental feed or reference position return. When the signal is turned OFF the speed changes to the previous speed or feedrate. During that time, the feed axis selection signal ($\pm J1$ to ± 8) can be kept turned ON.
- Turn ON this signal at the same time of selecting the mode or feed axis to move with rapid traverse feedrate from the beginning.
- The "Rapid traverse override code 1,2" (ROV1, ROV2) is enabled when the "Rapid traverse" signal is ON.

**Note**

- (1) The "Rapid traverse" signal (RT) operates as an interrupt signal for jog mode, incremental feed mode, etc., not for mode.
- (2) This signal can be used likewise during machine lock.
- (3) For information on handling the "Rapid traverse" signal (RT) during a dry run, refer to the section of the "Dry run" signal (DRN).

[Related signals]

- (1) Rapid traverse override code 1,2 (ROV1, ROV2: YC68, YC69)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Reverse run	VRV	YC27	YACA	YAD2	YADA	Y1127	Y1267	Y13A7	Y14E7

[Function]

This signal is used to select reverse/forward run in the arbitrary reverse run.

[Operation]

Forward run is executed when this signal is OFF.

Reverse run is executed when this signal is ON.

This signal is available only in the reverse run control mode.

[Related signals]

- (1) Reverse run from block start (RVSP: YD08)
- (2) Macro interrupt priority (RVIT: YD09)
- (3) Reverse run control mode (RVMD: YD0A)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual absolute	ABS	YC28	YD68	YEA8	YFE8	Y1128	Y1268	Y13A8	Y14E8

[Function]


This signal selects whether to update the program coordinate system by the amount moved by manual operation (jog, handle, etc.).

[Operation]**<When the "Manual absolute" signal (ABS) is OFF>**

The amount moved with manual operation is not added to the absolute position register in the controller. In other words, when manual intervention is performed during automatic operation, the axis moves in parallel at the end point of the intervened block and the end points of subsequent blocks by the amount of manual movement. (The axis moves in parallel regardless of the absolute command or incremental command on the machining program.)

**<When the "Manual absolute" signal (ABS) is ON>**

The amount moved by manual operation is added to the absolute position register in the controller, and the coordinate system is not changed. In other words, when manual intervention is performed during automatic operation by absolute command, the axis returns to the position commanded by the machining program at the block end point after the intervened block. However, if the incremental command is used after manual intervention, the axis moves in parallel by the amount manually moved. (At the end of the inserted block, the axis moves in parallel regardless of the absolute command or incremental command.)



4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Display lock	DLK	YC29	YD69	YEA9	YFE9	Y1129	Y1269	Y13A9	Y14E9

[Function]

By using this signal, the current position displayed on the display unit can be prevented from being updated even if the machine is moved by automatic operation or manual operation.

[Operation]

When the "Display lock" signal (DLK) is turned ON, the movement of the machine and the update of the program coordinate system are performed as usual, but the current position display of the display unit remains locked.

Note

- (1) This signal (DLK) is always valid and can be turned ON or OFF immediately.
- (2) This signal is also valid during machine lock operation.

[Related signals]

- (1) In display lock (DLKN: XC29)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	F1-digit speed change valid	F1D	YC2A	YD6A	YEA A	YFEA	Y112A	Y126A	Y13AA	Y14EA

[Function]

When this signal is ON and F1-digit feed is commanded, the feedrate registered in the parameters can be increased or decreased by turning the manual handle.

[Operation]**<Enabling conditions of the speed change with the handle>**

When the F1-digit command is valid, the feedrate can be increased or decreased by operating the first manual handle. (The feedrate cannot be changed by the 2nd and 3rd handles.)

Changing the feedrate by the handle is available satisfying the following conditions:

- ♦ The operation must be in automatic start.
- ♦ The operation must be in cutting feed, and F1-digit feedrate command must be issued.
- ♦ The F1-digit feed parameter must be ON.
- ♦ The F1-digit feed switch must be ON.
- ♦ The operation must not be in handle mode.
- ♦ The operation must not be in dry run.
- ♦ Upper limit of F1-digit feedrate ("#1506 F1_FM") and F1-digit feedrate change constant ("#1507 F1_K F1") are not zero.

<Conversion of the F1-digit feedrate changing with handle operation>

Once the F1-digit feedrate is changed with manual handle, the changed feedrate is valid until parameter is changed or the power is turned OFF. Changed feedrate can be checked only during the operation. However, if the parameter "#1246 set18/bit6" (Switch F1-digit feedrate change method) is set to "1", by changing the F1-digit feedrate parameter to the changed feedrate, operation is kept at the changed feedrate even after the power is turned OFF. In this case, if the screen is not switched, the changed parameter values are not reflected to the display.

The increase/decrease amount per handle gradient is expressed by the following formula.

$$\Delta F = \Delta P \times (FM / K)$$

ΔP : Handle pulse (\pm)

FM: Upper limit of F1-digit feedrate (#1506 F1_FM)

K: F1-digit feedrate change constant (#1507 F1_K)

(Example) When the handle scale unit is to be made ± 10 mm/min

Assuming that FM is 3600 mm/min, feedrate change constant (K) must be set "360" according to the following formula.

$$\Delta F = 10 = 1 \times (3600 / K)$$

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

- If F1-digit feedrate changing valid signal is turned ON when F1-digit feed is commanded and changing feedrate with the manual handle is valid, it is clamped at the upper limit of F1-digit feedrate if the F1-digit feedrate is greater than the upper limit of F1-digit feedrate.
- When the F1-digit feedrate is "0" with the handle operation during the F1-digit feedrate command, the alarm "M01 F1-digit feedrate zero 0104" occurs. This alarm can be cleared by returning the F1-digit feedrate to a value greater than "0" with the handle operation.
- When K is "0", the speed is not changed.

[Related signals]

- (1) F1-digit commanded (F1DN: XC2A)
- (2) F1-digit No. code (F11 to F18: XC30 to XC33)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Recalculation request	CRQ	YC2B	YD6B	YEAB	YFEB	Y112B	Y126B	Y13AB	Y14EB

[Function]

This signal is turned ON (1) when a calculated block (next block) is recalculated during operation of the machining program.

[Operation]


For example, when a mirror image etc. is operated with the miscellaneous (M) command in the program as follows.

```

:
N1 M45 ;
N2 G0X100 ;
:

```

When the N1 block is reached in the above program example, the "Recalculation request" signal turns ON before FIN is output or simultaneously with FIN. This enables the mirror image from the N2 block.

**[Caution]**

The "Recalculation request" signal (CRQ) latches the rising edge in the controller. Therefore, even if the "Recalculation request" signal (CRQ) is ON (1), "recalculation" is not performed except at the rising edge.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	PLC emergency stop	QEMG	YC2C

[Function]

The controller can be set to an emergency stop state in the same way as an external emergency stop is given by the user PLC.

[Operation]

An emergency stop occurs in the controller when the "PLC emergency stop" signal (QEMG) is turned ON. In this case, the "Servo ready completion" signal (SA) etc. is also turned OFF.

Note

- (1) Since the "PLC emergency stop" signal is processed by software, the response is slightly slower than the external emergency stop. The approximate response is equal to one scan by the user PLC plus 100 ms.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Reference position retract	RTN	YC2D	YD6D	YEAD	YFED	Y112D	Y126D	Y13AD	Y14ED

[Function]

This function returns immediately to the specified reference position when the return signal is input. This function is used to return the tool to a fixed position for changing the tool with a single touch.


[Operation]

Reference position return is executed when this signal is turned ON. At the rising edge of this signal, the program is automatically reset (reset & rewind) and then reference position return is started.

During the automatic or MDI operation, the operation is interrupted and stopped by the reset, and reference position return is executed.

If this signal is input during execution of a tap cycle in the automatic or MDI operation mode, the "Tap retract possible" signal is output by the reset interruption, and the return operation will be the tap retract operation. The tap retract is completed at the initial point, and after that the reference position return is carried out.

- If there are two or more axes, set the return order with the parameter "#2019 revnum".
- When the reference position is reached, the corresponding "Reference position reached" signal is output.
- This signal must be held until the "Reference position reached" signal is output. If it is turned OFF in the middle, the return operation will be interrupted and stopped. If the signal is input again, the operation will restart from execution of resetting.
- The reference position return speed is handled in the same manner as the normal reference position return speed.
- The reference position returned to during reference position retract depends on the YC90 and YC91 reference position selection code 1,2.
- Even if the return signal is input during the thread cutting cycle, it is invalid. However, if the return signal is executed in a block other than the thread cutting block, the return operation is executed.
- The return signal is invalid if the coordinate system is not established. The alarm "M01 Ref point retract invalid" occurs when the return signal is input.

[Timing chart]**[Related signals]**

- (1) Tap retract possible (TRVE: XCA5)
- (2) Tap retract (TRV: YC5C)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	PLC interrupt	PIT	YC2E	YD6E	YEA E	YFEE	Y112E	Y126E	Y13AE	Y14EE

[Function]

Interruption is executed with the interrupt program set with the R register when a signal is issued from the PLC during single block stop in automatic operation, or when the automatic operation is not in progress.

[Operation]

PLC interruption categorized as "start during the automatic operation" and "start with other mode" and some operations differ. Whether automatic operation is in progress is determined by whether the "In automatic operation" signal (OP) is output.


<Operation when the interrupt starts during the automatic operation>

The following operation is performed when this signal is turned ON at a single block stop during the cycle operation.

- The PLC interruption is not executed if this signal is turned ON while the automatic operation is activated.
The operation error (M01 0129) occurs. Cancel the alarm by turning OFF or reset the "PLC interrupt" signal.
- In memory mode, when a cycle operation is started, the program resumes from the next block of the block which was completed immediately before the interruption. When MDI operation is interrupted, the MDI program after the interrupted block is cancelled.


<Operation example>

(Example 1) When program is interrupted during memory operation single block stop



After the O100 N10 block ends, the designated interrupt program (O9900) is called when this signal turns ON. The PLC interruption ends at the M99 block, and the block will stop. (When the block stops, it is possible to turn this signal ON and then execute the PLC interruption again.) O100 N20 is executed from the next cycle start.

(Example 2) When program is interrupted during MDI operation single block stop



After the MDI N10 block ends, the designated interrupt program (O9900) is called when this signal is turned ON. The PLC interruption ends at the M99 block and the block stops. However, the next and subsequent blocks of the MDI program are canceled. Therefore, operation cannot be continued.


4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

<Operation when the interruption starts during other than automatic operation>

The following operation is performed if this signal is turned ON when the machine is in manual mode such as jog mode or handle mode, etc. or when the machine is not in program operation even it is in the memory mode.

<Operation example> When program is interrupted during manual mode



During manual mode, the designated interrupt program (O9900) is called when this signal is turned ON. The PLC interruption will be reset and finished at the M99 block, and the machine enters into the manual mode.

Note that the interrupt program will not be executed when this signal is turned ON during manual feed.

Note

- (1) To turn this signal ON during the manual mode, use the manual/automatic simultaneous function concurrently.
- (2) Interrupt program is finished at M99 and reset 1 is input automatically.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

[Caution]

- (1) Single block operation and automatic operation pause are valid even when the interrupt program is executed. To disable single block during the interrupt program execution, set system variable #3003. To disable automatic operation pause, set system variable #3004.
- (2) Other PLC interruption and MDI interruption cannot be commanded during execution of the interrupt program.
- (3) To disable the display of the interrupt program being executed on the Monitor screen, set the basic specification parameter "#1122 pglk_c" to "1" or "2".
- (4) The "PLC interrupt" signal is ignored even if it is turned ON during cycle start or automatic operation pause.
- (5) The "In cycle start" signal (OP) is output while the interrupt program is executed regardless of the operation mode which is active before the interruption.
- (6) PLC interruption is valid for each part system.
- (7) If PLC interruption is executed when there is no interrupt program or when program search has not been executed, the program error (P232) occurs when M99 is commanded.
- (8) If the interrupt program No. set in the R register is not within the setting range, the program error (P232) occurs.
- (9) Cancel the program error (P232) with reset.
- (10) The interruption is not executed in the part system where the "PLC interrupt" signal is OFF.
- (11) The "In automatic operation run" signal (OP) and the "In automatic operation start" signal (STL) are output during the PLC interrupt program execution.

Likewise, they are output during the execution of the PLC interrupt program other than during automatic operation.

- (12) Even though the "Memory mode" signal (MEM) is OFF, such as in manual feed mode or handle feed mode, when a PLC interruption is executed, the macro is automatically started and the CNC will be in cycle operation mode. At this time, when the "Single block" signal (SBK) is ON, a single block stop occurs. However, even though the "Automatic operation start" command signal (ST) is turned ON, the next block cannot be executed.

Make sure that a single block stop does not occur by turning ON the system variable "#3003/bit0" at the beginning of the macro to be called in advance.

Similarly, when the "Automatic operation pause" command signal (*SP) is turned ON, the machine decelerates and stops. However, the operation cannot be resumed even though the "Automatic operation start" command signal (ST) is turned ON.

Suppress feed hold by taking actions such as turning ON the system variable "#3004/bit0" at the beginning of the macro to be called.

When a single block stop or a feed hold stop occurs in a mode other than memory mode, reset the CNC.

- (13) Register an interrupt program in NC memory. When an interrupt program is registered in a device other than NC memory, including NC memory 2, the program error (P232) occurs.

[Related signals]

- (1) PLC interrupt program No. (R2518)
- (2) In PLC interrupt (PCINO: XC35)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Chopping	CHPS	YC30	YD70	YEB0	YFF0	Y1130	Y1270	Y13B0	Y14F0

[Function]

This signal enables the chopping function.

[Operation]

The chopping mode is entered at the rising edge of this signal.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Search & start	RSST	YC31	YD71	YEB1	YFF1	Y1131	Y1271	Y13B1	Y14F1

[Function]


This signal is input to the controller when the operation search is performed in the memory mode and cycle start is carried out.

[Operation]


If this signal is input when the memory operation mode is selected, an operation search of the machining program with the designated No. (R2562, R2563) will be carried out. After the search, the program will carry out cycle start.

If this signal is input during automatic operation, the program will be reset before the search. After the resetting is completed, the search and cycle start operations will be executed.

(Example1) Search & start is executed by designating O900 machining program from the reset state.



(Example2) Search & start is executed by designating O900 machining program during the operation of the O1 machining program.

**[Caution]**

- (1) This signal is valid only when the memory mode is selected.
- (2) An error signal will be output if the machining program No. is not designated or if the designated program No. is illegal (0 or exceeding 99999999).
- (3) This signal is valid at the rising edge.
- (4) If this signal is input during resetting, the search & start will not be executed.
- (5) When the multi-part system program management is valid, the search is executed for all part systems in batch with the signal for 1st part system. Only the programs with "0" No. are searched.

[Related signals]

- (1) Search & start program No. (R2562, R2563)
- (2) Search & start Error (SSE: XC8A)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Chopping parameter valid		YC34	YD74	YEB4	YFF4	Y1134	Y1274	Y13B4	Y14F4

[Function]

This signal enables the chopping control data assigned to R register.

[Operation]

- (1) The chopping control data is enabled at the rising edge of this signal.
- (2) After confirming that the chopping start ready completion signal has been turned ON, turn this signal OFF.
The chopping start ready completion signal is included in the control status of the chopping control data.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Inclined axis control valid		YC35	YD75	YEB5	YFF5	Y1135	Y1275	Y13B5	Y14F5

[Function]

This signal enables the inclined axis control.

[Operation]

When this signal is turned ON, the inclined axis control is performed in accordance with the set parameters.

If this signal is turned from ON to OFF, the inclined axis control will be invalid.

[Caution]

Even if this signal is changed over during the axis movement or the automatic operation, this signal will not be valid.

If this signal is changed over during the axis movement, this signal will be valid after the axis movement is stopped.

If this signal is changed over during the automatic operation, the block stop occurs.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Inclined axis control: No Z axis compensation		YC36	YD76	YEB6	YFF6	Y1136	Y1276	Y13B6	Y14F6

[Function]

Selects whether or not the movement with respect to the inclined axis during the manual operation affects the corresponding basic axis.

[Operation]

When this signal is turned ON and the manual operation for the inclined axis is executed, the corresponding basic axis is not moved.

When this signal is turned OFF and the inclined axis is manually operated, the compensation operation is performed on the corresponding basic axis as the inclined axis moves.

[Caution]

Even if this signal is changed over during the axis movement, this signal will not be valid.

If this signal is changed over during the axis movement, this signal will be valid after the axis movement is stopped.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Optional block skip m	BDT1 to 9	YC37 to F	YD77 to F	YEB7 to F	YFF7 to F	Y1137 to F	Y1277 to F	Y13B7 to F	Y14F7 to F

[Function]

Whether to execute the block with "/" (n: 1 to 9) (slash) during automatic operation and search can be selected.

By creating a machining program with the "/" code, a different part can be machined with one program.

[Operation]

When a program that has a block with "/" (n) (slash code) at the head of block is executed with the "Optional block skip" signal turned ON, the block is skipped. Note that the block with the "/" code in the middle of the block, not at the head, is executed.

When the "Optional block skip" signal is OFF, block with "/" is executed.

(Example) If machining the two parts as shown in the figure below, create the following program. When the "Optional block skip" signal is turned ON and machined, part 1 is obtained. When the signal is turned OFF, part 2 is obtained.

<Program>

N1 G54 ;

N2 G90G81X50. Z — 20. R3. F100 ;


/N3 X30. ;

N4 X10. ;


N5 G80 ;

M02 ;

Part 1
Optional block skip ON



Part 2
Optional block skip OFF



4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	1st handle axis selection code m	HS11 to 116	YC40 to 4	YD80 to 4	YEC0 to 4	Y1000 to 4	Y1140 to 4	Y1280 to 4	Y13C0 to 4	Y1500 to 4

[Function]

In the handle mode, axis component to be moved is selected.

This signal is used to select the axis to be moved for the 1st handle.


The axis for the 2nd handle is selected with YC48, while that of the 3rd handle is selected with YC50.

[Operation]

- (1) Select handle mode.
- (2) Specify axis No. for n-th handle axis selection code (Refer to the table below, "Relationship between "handle axis No." and "corresponding axis"".)
- (3) Turn ON the "n-th handle valid" signal (HSnS) .
- (4) By turning the handle (hand wheel), the axis moves in accordance with the magnification (MP1 to MP4) at the time.

Relationship between "handle axis No." and "motion axis"

Motion axis	n-th handle valid (HSnS)	n-th handle axis selection code				
		HSn16	HSn8	HSn4	HSn2	HSn1
X axis (1st axis) selected	1	0	0	0	0	1
Y axis (2nd axis) selected	1	0	0	0	1	0
Z axis (3rd axis) selected	1	0	0	0	1	1
#4 axis (4th axis) selected	1	0	0	1	0	0
#5 axis (5th axis) selected	1	0	0	1	0	1
#6 axis (6th axis) selected	1	0	0	1	1	0
#7 axis (7th axis) selected	1	0	0	1	1	1
#8 axis (8th axis) selected	1	0	1	0	0	0

**[Related signals]**

- (1) Handle mode (H: YC01)
- (2) 1st handle valid (HS1S: YC47)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	1st handle valid	HS1S	YC47	YD87	YEC7	Y1007	Y1147	Y1287	Y13C7	Y1507

[Function]

In HANDLE mode, axis No. of axis motion component to be moved is set to the "1st handle axis selection code" (HS11 to HS116). These signals are used to enable the specified handle axis Nos.

The axis No. for the 2nd handle is enabled with YC4F, while that of the 3rd handle is enabled with YC57.

[Operation]

Axis motion does not start when the 1st handle (hand wheel) is rotated after HANDLE mode is selected and the desired axis No. is set for the 1st handle axis selection code. To move the axis, this signal is required. Although it does not matter whether the "1st handle axis selection code" signal or the "1st handle valid" signal is issued first, both of these signals must be established at the same time when manual axis motion is started.

[Related signals]

(1) 1st handle axis selection code m (HS11 to 116: YC40 to 4)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	2nd handle axis selection code m	HS21 to 216	YC48 to C	YD88 to C	YEC8 to C	Y1008 to C	Y1148 to C	Y1288 to C	Y13C8 to C	Y1508 to C

[Function]

This signal is used to select the axis to be moved with the 2nd handle.

[Operation] [Related signals]

Refer to the section on "1st handle axis selection code m" (HS11 to 116: YC40 to 4).

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	2nd handle valid	HS2S	YC4F	YD8F	YECF	Y100F	Y114F	Y128F	Y13CF	Y150F

[Function] [Operation]

This signal is the same as the "1st handle valid" signal in both function and operation.

For the relationship with the "2nd handle axis selection code" (HS21 to 216), refer to the section of 2nd handle axis number.

[Related signals]

(1) 2nd handle axis selection code m (HS21 to 216: YC48 to C)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	3rd handle axis selection code m	HS31 to 316	YC50 to 4	YD90 to 4	YED0 to 4	Y1010 to 4	Y1150 to 4	Y1290 to 4	Y13D0 to 4	Y1510 to 4

[Function]

This signal is used to select the axis to be moved with the 3rd handle.

[Operation] [Related signals]

Refer to the section on "1st handle axis selection code m" (HS11 to 116: YC40 to 4).

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	3rd handle valid	HS3S	YC57	YD97	YED7	Y1017	Y1157	Y1297	Y13D7	Y1517

[Function] [Operation]

This signal is the same as the "1st handle valid" signal in both function and operation.

Refer to the section of the "3rd handle axis selection code" for the relationship with the "3rd handle axis selection code" (HS31 to HS316).

[Related signals]

(1) 3rd handle axis selection code m (HS31 to HS316: YC50 to YC4)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Override cancel	OVC	YC58	YD98	YED8	Y1018	Y1158	Y1298	Y13D8	Y1518

[Function]

This signal is used to fix the feedrate according to the issued F command, ignoring the value of the cutting feed override input from the PLC to the controller in automatic operation.

[Operation]

When the "Override cancel" signal (OVC) turns ON, the controller operates as follows.

- The setting of the cutting feed override code (*FV1 to *FV16) is ignored and the feedrate specified by F command is used.
- When the set cutting override is "0%", the "Override cancel" signal (OVC) is invalid. That is, the feedrate is "0" and no motion occurs. (The set cutting override "0%" takes precedence over this signal.)
- The signal does not affect to the manual feedrate and the rapid traverse speed.

[Related signals]

- (1) Cutting feedrate override code m (*FV1 to 16: YC60)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual override method selection	OVSL	YC59	YD99	YED9	Y1019	Y1159	Y1299	Y13D9	Y1519

[Function]

Cutting override can be applied to control the manual feedrate such as manual feed for jog feed and incremental feed.

[Operation]

When this signal (OVSL) is turned ON in the manual operation mode in which the manual feedrate is enabled and operating, the actual feedrate is obtained by multiplying the manual feedrate at that time by the cutting feed override.

**Note**

- (1) For details of manual feedrate, cutting feed override, and 2nd cutting feed override, refer to the relevant descriptions.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Miscellaneous function lock	AFL	YC5A	YD9A	YEDA	Y101A	Y115A	Y129A	Y13DA	Y151A

[Function]

The output of each function strobe of the commanded miscellaneous function (M, S, T and B) in automatic operation can be disabled with this signal. This signal (AFL) can be used to check machining program, for example.

[Operation]

When the "Miscellaneous function lock" signal (AFL) turns ON, the controller operates as follows.

- Miscellaneous function (M, S, T and B) specified in automatic operation cannot be executed. That is, the output of code data and function strobe signals (MF1 to 4, SF1 to 4, TF1 to 4, BF1 to 4) stops.
- If this signal is turned ON after the code data has already been output, the output continues normally until the M function finish (FIN1, FIN2) is received and the function strobe is turned OFF.
- The M00, M01, M02 and M30 commands included in the miscellaneous function are executed even when this signal (AFL) is ON and the decoded signals, code data, and the "M function strobe" signal are also output as usual.
- Miscellaneous functions which are executed only inside the controller and do not output code data and the "M function strobe" signal (M98 and M99 commands), are executed normally even when this signal is ON.

Note

- (1) As for the S command output data, even when the "Miscellaneous function lock" signal (AFL) is turned ON, the data before it is turned ON is retained. When this signal is ON from the time the power is turned ON, S command data will be 0V.

[Related signals]

- (1) M function strobe (MF_n: XC60)
- (2) M code data (R504)
- (3) S function strobe (SF_n: XC64)
- (4) S code data (R512)
- (5) T function strobe (TF_n: XC68)
- (6) T code data (R536)
- (7) 2nd M function strobe (BF_n: XC6C)
- (8) 2nd M function data (R544)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tap retract	TRV	YC5C	YD9C	YEDC	Y101C	Y115C	Y129C	Y13DC	Y151C

[Function]

This function is used to remove the tap from the workpiece when the tap cycle is interrupted by emergency stop, etc.

[Operation]

If the "Tap retract" signal (TRV: YC5C) is turned ON while the "Tap retract possible" signal (TRVE: XCA5) is ON due to an interruption in the tap cycle, the tap retract operation can be started.

The following items are conditions for tap retract. (The "Tap retract possible" signal (XCA5) turns ON at this time.)


- Emergency stop during tap cycle
- Reset during tap cycle
- Power OFF during tap cycle (Only in absolute position detection system)

Tap retract is executed as follows:

- Execute the synchronous tap cycle command. -> (a)
- The tap cycle is interrupted by emergency stop. -> (b)
- The "Tap retract possible" signal (XCA5) is turned ON. -> (c)
- Release the emergency stop. (The "Servo ready completion" signal (SA: XC11) is turned ON.) -> (d)
- Turn ON the "Tap retract" signal (YC5C). -> (e)
- The tap axis moves toward the initial point of the tap cycle while the spindle rotates in the reverse direction. Refer to <Feedrate at the tap retract> for the feedrate. -> (f)
- When the tap axis reaches the tap cycle initial point, the spindle and tap axis stop and the tap retract is completed. The "Tap retract possible" signal (XCA5) is turned OFF. -> (g)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

**Note**

- (1) The "Tap retract possible" signal (XCA5) is turned ON when the reset or emergency stop occurs during tapping operation. (The "Tap retract possible" signal (XCA5) is not turned ON even when the reset or the emergency stop occurs in the area other than the area between R point and tap bottom.)
- (2) The tap retract is started when the "Tap retract" signal (YC5C) is turned ON while the "Tap retract possible" signal (XCA5) is ON. The tap retract is interrupted when the "Tap retract" signal (YC5C) is turned OFF during the tap retract.
- (3) When an emergency stop or reset occurs, the tap retract is not performed even if the "Tap retract" signal (YC5C: TRV) is turned ON.
- (4) When the parameter "#1234 set06/bit3" is set to "0", the tap retract operation is not performed even if this signal is turned ON while the operation error (M01 0057) occurs.
- (5) Even in the R point return mode, the tap retract is performed till the initial point.

<Feedrate at the tap retract>

The tap retract is performed at the following feedrate.

Tap retract feedrate = Tap cycle feedrate x Tapping retract override

(The tapping retract override is set with the parameter "#1171 taprov".)

However, after the power is turned ON again, the tap retract is performed at the Z phase detection speed when "#3106 zrn_tpy/bit3" is set to "1" (Phase Z detection operation ON) and the Z phase detection speed is less than the tap retract feedrate.

When the parameter "#13018 SP018 SPEC2/bit5" is set to "1" and "#1239 set11/bit0" is set to "1", the spindle speed at the tap retract is clamped at "#13028 SP028 SDTS" (Speed detection set value).

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

[Caution]

- (1) When the parameter "#1234 set06/bit3" (*1) is set to "0", all the axes are interlocked while the "Tap retract possible" signal (XCA5) is ON. If the automatic or manual axis movement is commanded, the operation error (M01 0057) occurs. To cancel the interlocked state, turn ON the "Tap retract possible state cancel" signal (YCD6) and then turn this signal OFF.
 - (2) When the parameter "#1234 set06/bit3" is set to "1", the axis interlock control is not performed on the CNC side even if the tapping is interrupted by emergency stop, etc. The axis moves according to the movement command even during the tap retract operation. Safety measures are required on the machine side.
 - (3) When the parameter "#13018 SP018 SPEC2/bit5" is set to "1" and "#1239 set11/bit0" is set to "0", perform the coil switch, and then turn ON the "Tap retract" signal (YC5C) after the total time set to the parameter "#13114 SP114 MKT" and the parameter "#13115 SP115 MKT2" has passed. (*2)
- (*1) The parameter "#1234 set06/bit3" is the parameter to select interlock when the tap retract is enabled.
 (*2) Each parameter means as follows.

No.	Name	Meaning
#13018	SP018 SPEC2/bit5	0: Coil switch is invalid. 1: Coil switch is valid.
#1239	set11/bit0	0: Coil switch is performed via PLC. 1: Coil switch is performed by the NC internal process.
#13114	SP114 MKT	Coil switch gate cutoff timer
#13115	SP115 MKT2	Coil switch current limit timer

[Related signals]

- (1) Tap retract possible (TRVE: XCA5)
- (2) Tap retract possible state cancel (TRVEC: YCD6)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool handle feed mode		YC5E	YD9E	YEDE	Y101E	Y115E	Y129E	Y13DE	Y151E

[Function]

When this signal is turned ON, the tool handle feed mode is activated.

In the tool handle feed mode, the axis can be moved with the manual pulse generator in each of the tool axis direction, the tool radius direction X, and the tool radius direction Y in the hypothetical coordinate system on the tool axis.

[Operation]

When the tool handle feed mode is selected, the axis is moved by the manual pulse generator in the tool axis direction, the tool radius direction X, and the tool radius direction Y.

Operate in the following procedure.

- (1) Select handle mode at the mode selection.
- (2) Turn ON the signal (YC5E).
- (3) Move in the tool axis direction and the tool radius directions X and Y.

Handle feed magnification is shown as below.

Handle feed magnification	YC82	YC81	YC80
1-fold	0/1	0	0
10-fold	0/1	0	1
100-fold	0/1	1	0
1000-fold	0/1	1	1

Note

- (1) When the signal (YC5E) is "0", it is treated as normal handle mode.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
B	Cutting feed override code m	*FV1 to 16	YC60 to 4	YDA0 to 4	YEE0 to 4	Y1020 to 4	Y1160 to 4	Y12A0 to 4	Y13E0 to 4	Y1520 to 4

[Function]

This is a signal to apply an override (magnification) to the cutting feedrate (F speed) during automatic operation.

[Operation]

In the cutting feed during automatic operation, the actual feedrate is the obtained by multiplying the commanded speed by override value specified by this signal.

However, the override is 100% regardless of this signal, in the following cases:

- When the "Override cancel" signal (OVC) is ON.
- During tapping mode.
- During thread cutting.

These signals (*FV1 to 16) are set with the code method. The following table shows the relationship.

*FV16	*FV8	*FV4	*FV2	*FV1	Cutting feed override
1	1	1	1	1	0%
1	1	1	1	0	10%
1	1	1	0	1	20%
1	1	1	0	0	30%
1	1	0	1	1	40%
1	1	0	1	0	50%
1	1	0	0	1	60%
1	1	0	0	0	70%
1	0	1	1	1	80%
1	0	1	1	0	90%
1	0	1	0	1	100%
1	0	1	0	0	110%
1	0	0	1	1	120%
1	0	0	1	0	130%
1	0	0	0	1	140%
1	0	0	0	0	150%
0	1	1	1	1	160%
0	1	1	1	0	170%
0	1	1	0	1	180%
0	1	1	0	0	190%
0	1	0	1	1	200%
0	1	0	1	0	210%
0	1	0	0	1	220%
0	1	0	0	0	230%
0	0	1	1	1	240%
0	0	1	1	0	250%
0	0	1	0	1	260%
0	0	1	0	0	270%
0	0	0	1	1	280%
0	0	0	1	0	290%
0	0	0	0	1	300%

Generally, a rotary switch (5-step, 21-notch, compliment binary code output) is connected to the operation board and used between 0% and 200%.

When *FV1 to *FV16 are all OFF, the previous value is retained. The value will change to 0% when the power is turned OFF.

[Related signals]

- (1) Override cancel (OVC: YC58)
- (2) 2nd cutting feedrate override valid (FV2E: YC66)
- (3) Cutting feedrate override method selection (FVS: YC67)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	2nd cutting feed override valid	FV2E	YC66	YDA6	YEE6	Y1026	Y1166	Y12A6	Y13E6	Y1526

[Function]

Override normally exerted on the cutting feedrate in automatic operation is within a range from 0% to 300%. When this signal is used, an additional override (ranging from 0% to 327.67%) can be applied.

[Operation]

By turning ON the "2nd cutting feedrate override valid" signal (FV2E), the override set by the code method (*FV1 to *FV16) or file register method (by setting numerals manually) can be further overridden. Applicable range of the override is from 0% to 327.67% in 0.01% increments. The value is set in the file register in binary.




Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Cutting feedrate override method selection	FVS	YC67	YDA7	YEE7	Y1027	Y1167	Y12A7	Y13E7	Y1527

[Function]

When override is exerted on cutting feedrate in automatic operation, override method can be selected between "code method" and "file register method".

[Operation]

When the "Cutting feedrate override method selection" signal (FVS) is OFF, code method (*FV1 to *FV16) is selected. When the "Cutting feedrate override method selection" signal (FVS) is ON, file register method (value is specified by manual setting) is selected.

**Note**

(1) For details of code method and file register method, refer to the relevant descriptions.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Rapid traverse override code 1, 2	ROV1, 2	YC68, 9	YDA8, 9	YEE8, 9	Y1028, 9	Y1168, 9	Y12A8, 9	Y13E8, 9	Y1528, 9

[Function]

This signal is used to exert override on rapid traverse speed set by parameter (for rapid traverse) in automatic operation (memory, MDI or tape) or manual operation.

[Operation]

The actual feedrate at the time of rapid traverse is the value obtained by multiplying rapid traverse speed set by parameter by override value specified by this signal.

This signal is invalid when the "Rapid traverse" signal (RT) is OFF during cutting feed during automatic operation or during manual operation.

These signals (ROV1, 2) are set with the code method. The following table shows the relationship.

ROV2	ROV1	Rapid traverse override
0	0	100%
0	1	50%
1	0	25%
1	1	1%

[Related signals]

(1) Rapid traverse override method selection (ROVS: YC6F)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Rapid traverse override method selection	ROVS	YC6F	YDAF	YEEF	Y102F	Y116F	Y12AF	Y13EF	Y152F


[Function]

When speed override is exerted on rapid traverse speed specified in automatic operation or manual operation, override method is selected between code method and file register method (manually set).

[Operation]

When the "Rapid traverse override method selection" signal (ROVS) is OFF, code method (ROV1, 2) is used.

When the "Rapid traverse override method selection" signal (ROVS) is ON, file register method is used.

**Note**

(1) For details of code method and file register method, refer to the relevant descriptions.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
B	Manual feedrate code m	*JV1 to 16	YC70 to 4	YDB0 to 4	YEF0 to 4	Y1030 to 4	Y1170 to 4	Y12B0 to 4	Y13F0 to 4	Y1530 to 4

[Function]

Feedrate in manual operation (JOG mode, incremental feed mode, etc.) or in dry run of automatic operation (memory, MDI, tape) is selected.

[Operation]

This signal is valid in the following cases. However, it is invalid when the "Rapid traverse" signal (RT) is ON.

- Jog mode, incremental mode or reference position return mode is ON.
- During cutting feed in automatic operation and the "Dry run" signal (DRN) is ON.
- The "Dry run" signal is ON during rapid traverse in the automatic operation. Note that the parameter "#1085 G00Drm" (G00 dry run) must be ON.

These signals (*JV1 to *JV16) are set with the code method. The following table shows the relationship.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

*JV16	*JV8	*JV4	*JV2	*JV1	Manual feedrate			
					Machine parameter set in meters		Machine parameter set in inches	
					Metric mode (mm/min)	Inch mode (inch/min)	Metric mode (mm/min)	Inch mode (inch/min)
1	1	1	1	1	0.00	0.000	0.00	0.000
1	1	1	1	0	1.00	0.040	0.51	0.020
1	1	1	0	1	1.40	0.054	0.71	0.028
1	1	1	0	0	2.00	0.079	1.02	0.040
1	1	0	1	1	2.70	0.106	1.37	0.054
1	1	0	1	0	3.70	0.146	1.88	0.074
1	1	0	0	1	5.20	0.205	2.64	0.104
1	1	0	0	0	7.20	0.283	3.66	0.144
1	0	1	1	1	10.00	0.394	5.08	0.200
1	0	1	1	0	14.00	0.551	7.11	0.280
1	0	1	0	1	20.00	0.787	10.16	0.400
1	0	1	0	0	27.00	1.060	13.72	0.540
1	0	0	1	1	37.00	1.460	18.80	0.740
1	0	0	1	0	52.00	2.050	26.42	1.040
1	0	0	0	1	72.00	2.830	36.58	1.440
1	0	0	0	0	100.00	3.940	50.80	2.000
0	1	1	1	1	140.00	5.510	71.12	2.800
0	1	1	1	0	200.00	7.870	101.60	4.000
0	1	1	0	1	270.00	10.600	137.16	5.400
0	1	1	0	0	370.00	14.600	187.96	7.400
0	1	0	1	1	520.00	20.500	264.16	10.400
0	1	0	1	0	720.00	28.300	365.76	14.400
0	1	0	0	1	1000.00	39.400	508.00	20.000
0	1	0	0	0	1400.00	55.100	711.20	28.000
0	0	1	1	1	2000.00	78.700	990.60	39.000
0	0	1	1	0	2700.00	106.000	1371.60	54.000
0	0	1	0	1	3700.00	146.000	1879.60	74.000
0	0	1	0	0	5200.00	205.000	2641.60	104.000
0	0	0	1	1	7200.00	283.000	3657.60	144.000
0	0	0	1	0	10000.00	394.000	5080.00	200.000
0	0	0	0	1	14000.00	551.000	7112.00	280.000

When *JV1 to *JV16 are all OFF, the previous value is retained. The value is set to "0" when the power is turned OFF.

Note

- (1) In JOG mode, if this signal changes during feed motion, the actual feedrate will also change.
- (2) In incremental mode, if this signal changes during feed motion, the actual feedrate does not change.

[Related signals]

- (1) Manual feedrate method selection (JVS: YC77)
- (2) Manual override method selection (OVSL: YC59)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual speed clamp ON	MCLMP	YC76	YDB6	YEF6	Y1036	Y1176	Y12B6	Y13F6	Y1536

[Function]

This signal selects the maximum speed for handle feed or jog feed during manual operation.

[Operation]

<When "#1449 m_clamp_on" (Manual feed rate clamp ON) is set to "0" (Invalid)>

ON: The speed designated with "#2641 m_clamp" (Manual feed clamp speed) is used as the maximum speed.

OFF: The speed designated with "#2001 rapid" (Rapid traverse rate) is used as the maximum speed.

<When "#1449 m_clamp_on" (Manual feed rate clamp ON) is set to "1" (Valid)>

The speed designated with "#2641 m_clamp" (Manual feed clamp speed) is used as the maximum speed regardless of the state of this signal.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual feedrate method selection	JVS	YC77	YDB7	YEF7	Y1037	Y1177	Y12B7	Y13F7	Y1537


[Function]

When feedrate is specified in manual operation (JOG mode, incremental feed mode, etc.) or dry run (automatic operation), feedrate command method is selected between code method and file register method.

[Operation]

When the "Manual feedrate method selection" signal (JVS) is OFF, code method (*JV1 to *JV16) is selected.

When the "Manual feedrate method selection" signal (JVS) is ON, file register method is selected.

**Note**

- (1) For details of code method and file register method, refer to the relevant descriptions.
- (2) For axes for which a value other than "0" is set for "#2642 jogfeed" (Jog feed rate), the setting value is treated as the feedrate.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Feedrate least increment code 1, 2	PCF1, 2	YC78, 9	YDB8, 9	YEF8, 9	Y1038, 9	Y1178, 9	Y12B8, 9	Y13F8, 9	Y1538, 9

[Function]

When the manual feedrate is specified in file register method (JVS is "ON") or when manual arbitrary feed is performed, the speed is specified by R2504 and R2505 of the file registers (R). In this case, least increment of feedrate entered into file registers R2504 and R2505 is specified by this signal.

[Operation]

The relationship between PCF1/PCF2 and least increment is as follows:

PCF2	PCF1	Least increment (mm/min or inch/min)	Operation
0	0	10	10 mm/min (inch/min) when "1" is set in file registers.
0	1	1	1 mm/min (inch/min) when "1" is set in file registers.
1	0	0.1	0.1 mm/min (inch/min) when "1" is set in file registers.
1	1	0.01	0.01 mm/min (inch/min) when "1" is set in file registers.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Jog handle synchronous	JHAN	YC7B	YDBB	YEFB	Y103B	Y117B	Y12BB	Y13FB	Y153B

[Function]

Jog feed and handle feed can be carried out without changing the operation mode.

[Operation]


If the "Jog mode" signal (J) and this signal are input simultaneously, the "jog/handle synchronous mode" is entered.

If the "Rapid traverse" signal (RT) is turned ON during the "jog/handle synchronous mode", the jog feed is carried out at the rapid traverse feedrate. When the "Rapid traverse" signal is OFF, the jog feed is carried out at the manual feedrate.


Operation mode	Jog handle synchronous signal (JHANn)	Rapid traverse signal (RTn)	Operation during jog feed	Handle feed
Jog feed	On	On	Rapid traverse feedrate	Possible
		Off	Manual feedrate	Possible
	Off	On	Rapid traverse feedrate	Impossible
		Off	Manual feedrate	Impossible

During the "jog/handle synchronous mode", jog feed and handle feed can be carried out arbitrarily. However, jog feed and handle feed cannot be carried out on the same axis simultaneously. If both are carried out simultaneously, the jog feed has priority. The changeover between jog feed and handle feed on the same axis is carried out when the relevant axis has stopped.

- If handle feed is carried out on an axis that is being jog fed, the jog feed will have a priority, so after movement with jog feed has completed (the axis has stopped), handle feed movement will start.



- If jog feed is carried out on an axis that is being handle fed, the handle feed movement will stop at the rising edge of the jog feed command. After the axis stops, the jog feed movement will start.

**Note**

- (1) If only the "Jog handle synchronous" signal is input, "M01 OPERATION ERROR 0101" occurs. Even though the "Jog handle synchronous" signal is input simultaneously with an operation mode signal other than the "Jog mode", the "Jog handle synchronous" signal is ignored.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Each axis manual feedrate B valid		YC7C	YDBC	YEFC	Y103C	Y117C	Y12BC	Y13FC	Y153C

[Function]

This signal enables manual feed using at the manual feedrate B for each axis.

[Operation]

- When manual feed is performed in jog mode and this signal and the "Manual feedrate B valid" signal of the corresponding axis are enabled, the axis moves at the speed commanded by each axis manual feedrate B, which is separate from the manual feedrate or manual feedrate B.
- This signal is common for all axes.

[Related signals]

- (1) Manual feedrate B valid (FBEn: Y940 to Y947)
- (2) Each axis manual feedrate B (R5764 to R5779)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual feedrate B surface speed control valid		YC7D	YDBD	YEFD	Y103D	Y117D	Y12BD	Y13FD	Y153D

[Function]

This signal enables the manual feedrate B surface speed control.

[Operation]


The manual feedrate B surface speed control is enabled for a rotary axis selected by the "Manual feedrate B valid" signal. Setting this signal to "0" disables the control.

This signal is common for all axes.

Normally, when machining is performed by moving the orthogonal axis while rotating the rotary table with the manual feedrate B surface speed control function, the relative speed of tool nose and workpiece decreases as the tool approaches the center of rotation under the condition that the rotation speed of the table is constant.

The table rotation speed can be controlled according to the distance from the rotation center by enabling the manual feedrate B surface speed control.

As shown below, the distances (radiuses) from the rotation center to two points (R1 and R2) and the rotary axis speed at the two points (R1 and R2) are set as parameters. When the "Manual feedrate B surface speed control valid" signal (YC7D) is turned ON, the rotary axis speed is calculated automatically in accordance with a current radius.



Override can be applied in the range of 0% to 200% in respect to the rotary axis speed.

[Caution]

- (1) For a linear axis, the manual feedrate B surface speed control is not valid. However, the manual feedrate B override is valid.
- (2) When the power is turned ON, enable the manual feedrate B surface speed control after returning the orthogonal axis to the reference position and establishing the coordinate system. If the surface speed control is applied to the rotary axis without establishing the coordinate system, the rotary axis moves at unexpected speed.

[Related signals]

- (1) Manual feedrate B valid (FBE: Y940 to Y947)
- (2) Manual feedrate B override (R2524)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Circular feed in manual mode valid		YC7E	YDBE	YEFE	Y103E	Y117E	Y12BE	Y13FE	Y153E

[Function]

This signal is used to execute JOG or handle feed for the H and V axes on the specified coordinate ("linear-linear" or "circular-linear").

[Operation]

After this signal turns ON in the JOG or handle mode, the H and V axes move on the specified hypothetical coordinate. (Coordinates etc. are specified with the R registers explained below.)

[Caution]

- (1) This signal does not effect on the operation of the axes other than H and V axes, nor the PLC axis.
- (2) This signal does not turn ON in the following conditions.
 - (i) Either H axis or V axis is in machine lock. (In this case, even machine lock is not performed.)
 - (ii) The reference position return of either H axis or V axis is not completed.
 - (iii) Either H axis or V axis is in servo OFF.
 - (iv) Either H axis or V axis is detached.
 - (v) The NC is in one of the following states.
 - Automatic operation (OP)
 - Emergency stop
 - Reset
 - (vi) The current position is outside of the specified movable range.
 - (vii) The setting value which is specified with R register is illegal.

[Related signals]

- (1) In circular feed in manual mode (XC4F)
- (2) Circular feed in manual mode Operation mode data (R2636,7)
- (3) Circular feed in manual mode Reference point H data (R2644,5)
- (4) Circular feed in manual mode Reference point V data (R2648,9)
- (5) Circular feed in manual mode Gradient/arc center H data (R2668,9)
- (6) Circular feed in manual mode Gradient/arc center V data (R2672,3)
- (7) Circular feed in manual mode Travel range H (+) data (R2652,3)
- (8) Circular feed in manual mode Travel range H (-) data (R2656,7)
- (9) Circular feed in manual mode Travel range V (+) data (R2660,1)
- (10) Circular feed in manual mode Travel range V (-) data (R2664,5)
- (11) Circular feed in manual mode Current position H (R636,7)
- (12) Circular feed in manual mode Current position V (R640,1)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Coordinate rotation by parameter: Coordinate switch for manual feed		YC7F	YDBF	YEFF	Y103F	Y117F	Y12BF	Y13FF	Y153F

[Function]

This signal specifies whether or not the manual operation (jog feed, incremental feed, manual handle feed) operates with the coordinate system rotated by the coordinate rotation by parameter.

[Operation]

When this signal is turned OFF, the manual operation is operated with the machine coordinate system.

When this signal is turned ON, the manual operation is operated with the coordinate system rotated by the coordinate rotation by parameter.

[Related signals]

- (1) Coordinate rotation by parameter: Manual feed coordinate system (XC5F)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Handle/Incremental feed magnification code m	MP1 to 4	YC80 to 2	YDC0 to 2	YF00 to 2	Y1040 to 2	Y1180 to 2	Y12C0 to 2	Y1400 to 2	Y1540 to 2

[Function]

This signal is used to specify the magnification of one pulse of the handle in the HANDLE feed mode, or the amount of feed motion per shot when the "Feed axis selection" signal ($\pm J1$ to 8) in incremental feed mode is ON.

When the "Handle/incremental feed magnification method selection" signal (MPS) is OFF, this magnification is applied for the hand pulse from handy terminal.

[Operation]

This signal (MP1 to 4) is set with the code method.

The amount of movement per handle feed and incremental feed (1 pulse feed in the case of handle feed, and " $\pm Jn$ " value per change from OFF to ON in the case of incremental feed) is the magnification determined by MP1, MP2, and MP4.

When the parameter "#1003 iunit" is set to either "B" or "C", only values of 1000 or less can be set regardless of whether MP4 is ON or OFF.

The relationship between multiplier code (MP1 to 4) and multiplication in each feed mode is as follows.

MP4	MP2	MP1	Movement amount per handle feed or incremental feed	
			#1003 iunit: B or C	#1003 iunit: Other than B or C
0	0	0	1	1
0	0	1	10	10
0	1	0	100	100
0	1	1	1000	1000
1	0	0	1	5000
1	0	1	10	10000
1	1	0	100	50000
1	1	1	1000	100000

[Related signals]

- (1) Handle mode (H: YC01)
- (2) Incremental mode (S: YC02)
- (3) Handle/incremental feed magnification method selection (MPS: YC87)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Magnification valid for each handle	MPP	YC86	YDC6	YF06	Y1046	Y1186	Y12C6	Y1406	Y1546

[Function] [Operation]

This signal sets magnification for each handle when the feed magnification is set arbitrarily.

<When the signal is ON>

When the feed magnification is set with an arbitrary value, magnification can be set for each handle. When the magnification is selected with code method, the feed magnification is common to all handles.

Handle	Magnification of feed	
	File register method	Code method
1st handle	R2508, 2509	YC80 to YC82
2nd handle	R2510, 2511	
3rd handle	R2512, 2513	

<When the signal is OFF>

When the feed magnification is set with an arbitrary value, the "1st handle/incremental feed magnification" (R2508, R2509) is enabled for all handles. When the magnification is selected with code method, the feed magnification is common to all handles.

[Related signals]

- (1) Handle/incremental feed magnification method selection (MPS: C87)
- (2) Handle/Incremental feed magnification code m (MP1, MP2, MP4: YC80, YC81, YC82)
- (3) 1st handle/incremental feed magnification (R2508, R2509)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Handle/incremental feed magnification method selection	MPS	YC87	YDC7	YF07	Y1047	Y1187	Y12C7	Y1407	Y1547


[Function]

This signal is a signal to switch whether the movement magnification for the basic movement amount of handle feed and incremental feed is performed by the "code method" and the "file register method".

[Operation]

When the "Handle/incremental feed magnification method selection" signal (MPS) is OFF, the MP1, MP2, MP4 code method is selected.

When the "Handle/incremental feed magnification method selection" signal (MPS) is ON, the file register magnification method is selected.

**Note**

(1) For details of the code method and the file register method, refer to the relevant descriptions.

[Related signals]

- (1) Handle/Incremental feed magnification code m (MP1, MP2, MP4: YC80, YC81, YC82)
- (2) 1st handle/incremental feed magnification (R2508, R2509)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool alarm 1/Tool-skip	TAL1	YC88	YDC8	YF08	Y1048	Y1188	Y12C8	Y1408	Y1548

[Function]

This signal sets the spindle tool status during tool life management to status 3 (Tool alarm 1/Tool skip).

[Operation]

By turning ON the signal in the tool life management specification, the tool status of a spindle tool can be changed to "3".

When the tool life is managed for each tool group, the tool status of a tool selected when a tool group No. is designated can be changed to "3".

However, the "Tool life management input" signal (YC8B) needs to be turned ON to enable this function.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool alarm 2	TAL2	YC89	YDC9	YF09	Y1049	Y1189	Y12C9	Y1409	Y1549

[Function]

This signal sets the tool data status during tool life management to status 4 (Tool alarm 2).

[Operation]

By turning ON the signal in the tool life management specification, the tool status of a spindle tool can be changed to "4".

When the tool life is managed for each tool group, the tool status of a tool selected when a tool group No. is designated can be changed to "4".

However, the "Tool life management input" signal (YC8B) needs to be turned ON to enable this function.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Usage data count valid	TCEF	YC8A	YDCA	YF0A	Y104A	Y118A	Y12CA	Y140A	Y154A

[Function]

This signal enables tool life count during the tool life management.

[Operation]

For the tool life management specifications, the tool life count (usage time or usage count corresponding to tool) is enabled.

However, the "Tool life management input" signal (YC8B) needs to be turned ON to enable this function.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool life management input	TLF1	YC8B	YDCB	YF0B	Y104B	Y118B	Y12CB	Y140B	Y154B

[Function]

This signal enables the tool life management.

[Operation]

When the tool life management specification is specified, the tool life management process is executed by turning ON this signal.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool change reset	TRST	YC8C	YDCC	YF0C	Y104C	Y118C	Y12CC	Y140C	Y154C

[Function]

This signal is used to turn all the tools of a group into an unused state in the tool life management II.

[Operation]

Select with the tool group No. designation (file register R2590, 2591) whether all groups that have exceeded their lifetimes or specific group to turn the tool into an unused state.

After this signal is input, the first tool of the group is selected at the next group selection.

Note

- (1) When the tool change reset or the tool skip is performed on the group currently selected, usage data count is carried out on the tool used at the time of signal input until the next tool selection. Therefore, if a tool selected needs to be changed along with the signal input, select a group again. However, a tool may not be selected due to a preceding process if there is no movement command up to the next group selection after the signal input. In this case, contents of the preceding process can be disabled by turning ON the "Recalculation request" signal (CRQ) before selecting the group.

[Related signals]

- (1) Recalculation request (CRQ: YC2B)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool escape and return Transit point designation		YC8D	YDCD	YF0D	Y104D	Y118D	Y12CD	Y140D	Y154D

[Function]

With the tool escape and return function, a transit point can be designated by pressing the transit point switch when the tool escapes. The tool returns to the position where machining was interrupted via the designated transit point.

This signal turns ON when the transit point switch is pressed and turns OFF when recognition of the transit point is completed.

[Operation]

Refer to the section of the "In tool escape and return mode" signal (XC4A).

[Related signals]

- (1) In tool escape and return mode (XC4A)
- (2) Tool escape and return transit point recognition finish (XC87)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Reference position selection code 1,2	ZSL1,2	YC90,1	YDD0,1	YF10,1	Y1050,1	Y1190,1	Y12D0,1	Y1410,1	Y1550,1

[Function]

The n-th reference position return can be performed even in the manual reference position return mode. This signal is used to select "n" of the n-th reference position return. Normally, both the "Reference position selection code 1" signal (ZSL1n) and the "Reference position selection code 2" signal (ZSL2n) are turned OFF to return to the first reference position.

[Operation]


The "Reference position selection code 1" signal (ZSL1n) and the "Reference position selection code 2" signal (ZSL2n) are valid when:

- ♦ The "Reference position return mode" is ON (1).
- ♦ Manual start condition is held.

Reference position selection code 2	Reference position selection code 1	Return position
0	0	1st reference position
0	1	2nd reference position
1	0	3rd reference position
1	1	4th reference position

Note

- (1) Returning to the first reference position must be performed before returning to the second, third or forth reference position.

[Operation sequence]**[Related signals]**

- (1) Reference position return mode (ZRN: YC04)
- (2) Feed axis selection (+Jn: Y1D8, -Jn: Y900)
- (3) N-th reference position reached (ZP11 to 48: X800 to X867)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool length compensation along the tool axis Compensation amount change mode		YC92	YDD2	YF12	Y1052	Y1192	Y12D2	Y1412	Y1552

[Function]

This signal controls the tool length compensation along the tool axis compensation amount change mode.

[Operation]

- When the signal is ON:
When the handle is operated, only compensation amount of tool length compensation along the tool axis will be changed. Handle interrupt function will be invalid.
- When the signal is OFF:
Compensation amount of tool length compensation along the tool axis cannot be changed by the manual handle even during the tool length compensation along the tool axis mode.

[Related signals]

- (1) Mechanical axis specifications 1st rotary axis angle/2nd rotary axis angle (R2628,R2629/R2630,R2631)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Thread cutting: Feed-forward control request	FFC	YC94	YDD4	YF14	Y1054	Y1194	Y12D4	Y1414	Y1554

[Function]

This signal enables the feed forward control during the thread cutting.

[Operation]

- When this signal is turned ON, the feed forward control is enabled during the thread cutting.
Turn ON this signal prior to the thread cutting command which performs the feed forward control.

[Related signals]

- (1) Thread cutting: Feed-forward control ON (FFCO: XCA4)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Reference position selection method	M	YC97	YDD7	YF17	Y1057	Y1197	Y12D7	Y1417	Y1557

[Function]

This signal selects whether the reference position selection is common for all axes or independent for each axis.

[Operation]

- When this signal is OFF, the reference position selection is common for all axes, and ZSL1 and ZSL2 are valid.
When this signal is ON, the reference position selection is independent for each axis, and "Each axis reference position selection" is valid.

[Related signals]

- (1) Reference position selection code 1, 2 (ZSL1, 2: YC90, YC91)
(2) Each axis reference position selection (R2584)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool life management: Temporary cancel of tool life expiration		YC98	YDD8	YF18	Y1058	Y1198	Y12D8	Y1418	Y1558

[Function]


This signal temporarily cancels the "Tool life over" signal.

[Operation]

If the corresponding "Tool life over" signal is ON at the falling edge, this signal turns OFF the "Tool life over" signal.

The "Tool life over" signal temporarily canceled by this signal turns ON again if the lifetime of the tool in use is expired after NC reset.

The timing chart for this signal is shown below.

**[Caution]**

This signal is used only for resetting the "Tool life over" signal temporarily and does not affect other operations.

[Related signals]

- (1) Tool life over (TLOV: XC2E)
- (2) NC reset 1 (NRST1: YC18)
- (3) NC reset 2 (NRST2: YC19)
- (4) Reset & rewind (RRW: YC1A)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool life management: Temporary cancel of tool group life expiration		YC99	YDD9	YF19	Y1059	Y1199	Y12D9	Y1419	Y1559

[Function]


This signal temporarily cancels the Tool group life over signal.

[Operation]

If the corresponding "Tool group life over" signal is ON at the falling edge, this signal turns OFF the "Tool group life over" signal.

The "Tool group life over" signal temporarily canceled by this signal turns ON again if the lifetimes of all tools in a group that are mounted after NC reset are expired.

The timing chart for this signal is shown below.

**[Caution]**

This signal is used only for resetting the "Tool group life over" signal temporarily and does not affect other operations.

[Related signals]

- (1) Tool group life over (XC2F)
- (2) NC reset 1 (NRST1: YC18)
- (3) NC reset 2 (NRST2: YC19)
- (4) Reset & rewind (RRW: YC1A)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	External search: Program return	PRTN	YC9A	YDDA	YF1A	Y105A	Y119A	Y12DA	Y141A	Y155A

[Function]

After the completion of external search, this signal is input to the control unit to return the previous program selected before the external search.

[Operation]

The control returns the previous program selected before the external search at the rising edge of this signal.

To enable this signal, set "#1288 ext24/bit3" (Restore previous program before external search by Program restore signal) to "1".

[Caution]

- (1) When "#1288 ext24/bit3" (Restore previous program before external search by Program restore signal) is set to "0", the program does not return to the previous one selected before the external search even if this signal is turned ON.
- (2) When another search operation is executed after the external search is completed, the program does not return to the previous one selected before the external search even if this signal is turned ON.
- (3) When the macro interruption function is executed after the external search is completed or while the externally searched program is operating, the program does not return to the previous one selected before the external search even if this signal is turned ON.
- (4) Even if this signal is turned ON while the externally searched program is operating, the program does not return to the previous one selected before the external search.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: User arbitrary information send request		YC9B	YDDB	YF1B	Y105B	Y119B	Y12DB	Y141B	Y155B

[Function]

This signal sends the request of DB operation to the arbitrary information accumulation table in the database.

[Operation]

The processing of DB operation for the arbitrary information accumulation table in the database starts at the rising edge of this signal.

[Related signals]

- (1) MES interface library: Sending user arbitrary information (XD30 to X15F0)
- (2) MES interface library: DB operation selection (R14598)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual speed command valid		YC9D	YDDD	YF1D	Y105D	Y119D	Y12DD	Y141D	Y155D

[Function]

This signal is used to run the machining program with handle feedrate or JOG feedrate (manual feedrate).

[Operation]

When this signal is turned ON, the manual speed (handle feedrate or manual feedrate) is applied to all subsequent axis feedrate for automatic operation, and the speed specified by the program is not used.

If the program has not started, the automatic operation start is executed with handle or manual feedrate.

Whether to use the manual feedrate or the handle feedrate depends on the manual operation mode.

<In handle mode>

The program under operation is executed at the feedrate of the 1st handle, 1st axis.

During the reset, block stop or pause in the automatic operation mode, the automatic operation starts at the time when the handle feedrate has been commanded.

When the reverse run is valid, a command with "+" direction progress the movement in the programmed direction, while a command with "-" direction reverses the movement against the program. The reversed movement, however, is available only within the current block.

<In JOG mode>

The program under operation is executed at the manual feedrate as long as the JOG mode signal is ON for the 1st axis.

During the reset, block stop or pause in the automatic operation mode, the automatic operation starts at the time when the JOG mode has been turned ON.

When the reverse run is valid, a command with "+" direction progress the movement in the programmed direction, while a command with "-" direction reverses the movement against the program. The reversed movement, however, is available only within the current block.

When the "Rapid traverse" signal is ON, the axis moves at the rapid traverse feedrate.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

[Caution]

- (1) Turning ON this signal in the automatic operation leads to an automatic operation pause.
- (2) While this signal is ON, the "Automatic operation "start" command" signal is invalid.
- (3) When the automatic operation is carried out with the manual speed command, the "In automatic operation "pause"" signal is output regardless of the axis movement.
- (4) The manual speed command makes the movement follow the command on the 1st axis, even though the other axis is commanded in the program. If a command is given to another axis, the operation error (M01 0005) (Internal interlock axis exists) occurs.
- (5) The following G commands and the operation during modal are different from the operation during normal automatic operation.
 - G00: The manual feedrate is applied, not the rapid traverse feedrate.
 - G28: The manual feedrate is applied, not the reference position return feedrate. G31: The manual feedrate is applied, not the skip feedrate. The movement when the skip signal is input, however, is the same as the normal operation.
 - G33, G34 to 36 (L system): The thread cutting (G33), the variable lead thread cutting (G34: L system only), and the arc thread cutting (G35/36: L system only) operate the same as the dry run. The manual feedrate is applied. (When the parameter "#1247 set19/bit1" is set to "1", it operates in accordance with the program command.)
 - G95: The feed per rotation operates the same as the dry run.
 - F1-digit feed: The manual feedrate is applied, not the F1-digit feedrate. The "F1-digit commanded" signal is not output, either.
- (6) Only the 1st handle is used. The other handles are ignored.
- (7) When this signal is valid, the feedrate is not changed by the inch/metric changeover command (G20/G21). If the rotary axis command speed is set to "10-fold", it is also disabled.
- (8) The manual interruption and the thread cutting cycle retract are available when this signal is ON. The automatic handle interruption, as well as the manual operation in the manual/auto simultaneous mode, cannot be used on the 1st axis because the axis applies the manual input upon this signal.

[Related signals]

- (1) Manual speed command sign reversed (YC9E)
- (2) Manual speed command reverse run valid (YC9F)
- (3) In automatic operation "pause" (SPL: XC14)
- (4) In manual speed command valid (XC48)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual speed command sign reversed		YC9E	YDDE	YF1E	Y105E	Y119E	Y12DE	Y141E	Y155E

[Function]

When the manual speed is commanded, this signal reverses the direction that has been commanded with the handle feed or JOG feed.

[Operation]

When this signal is ON, a speed command in the (+) direction reverses the movement against the program. (Note that this operation is not available unless the reverse run is valid.) A command in the (-) direction makes the movement as commanded in the program.

Manual speed command Reverse run valid	Manual speed command Sign reversed	Movement direction	
		by (+) operation	by (-) operation
OFF	(Invalid)	+	+
ON	OFF	+	-
ON	ON	-	+
In the modals that do not allow the reverse run (thread cutting and synchronous tapping)		+	The operation is ignored

[Caution]

- (1) This signal is not valid when the "Manual speed command reverse run valid" signal is OFF.

[Related signals]

- (1) Manual speed command valid (YC9D)
- (2) Manual speed command reverse run valid (YC9F)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual speed command reverse run valid		YC9F	YDDF	YF1F	Y105F	Y119F	Y12DF	Y141F	Y155F

[Function]

This signal allows the manual speed command in the (-) direction to reverse the movement against the program.

[Operation]

When this signal turns ON during the manual speed is commanded, a speed command in the (-) direction in handle or JOG mode reverses the movement against the program.

When this signal is OFF, a command in the (-) direction makes the same movement as commanded in the (+) direction: the movement follows the program.

[Caution]

- (1) The reverse run is available within the block in execution. The reversed axis movement stops at the start point of the block in execution.
- (2) Unless all the axes stop, this signal cannot be changed ON/OFF. The ON/OFF change of this signal during the axis movement is realized after all the axes have stopped.
- (3) The reverse run is not allowed in the following operations. The axis stays stopped if a speed command is given in the (-) direction.
 - (i) In the reference position return (G28, G29). When G28 is commanded, however, the reverse run is available from the start point and to the intermediate point. When G29 is commanded, the reverse run is available from the intermediate point to the end point.
 - (ii) In cutting cycle in the synchronous or asynchronous tap.
 - (iii) In shift amount operation in a fixed cycle.
 - (iv) In tool center point control.
 - (v) In normal line control.
 - (vi) In milling interpolation, pole coordinate rotation or cylindrical interpolation.
 - (vii) When the thread cutting command (G33) is given.
 - (viii) In exponential interpolation.
 - (ix) In spline interpolation.
 - (x) In NURBS interpolation.
 - (xi) In tool change position return or 2nd/3rd/4th reference position return (from the intermediate point to the block end).

[Related signals]

- (1) Manual speed command valid (YC9D)
- (2) Manual speed command sign reversed (YC9E)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed 1st axis selection code m	CX11 to 116	YCA0 to 4	YDE0 to 4	YF20 to 4	Y1060 to 4	Y11A0 to 4	Y12E0 to 4	Y1420 to 4	Y1560 to 4

[Function]

This signal specifies a number of the axis component to move in manual arbitrary feed mode.

Up to three axes can be moved simultaneously in manual arbitrary feed mode. This signal is for specifying the axis number of one of them.

[Operation]

- The "Manual arbitrary feed 1st axis selection code m" (CX11 to CX116) must be set before the "Manual arbitrary feed Strobe" signal (CXS8) is turned ON. An attempt to set it during motion shall fail.
- Besides this signal (CX11 to CX116), there are two signals to specify a "Manual arbitrary feed 2nd axis selection code m" (CX21 to CX216) and a "Manual arbitrary feed 3rd axis selection code m" (CX31 to CX316). The axis numbers need not be specified in ascending order.
- The "Manual arbitrary feed 1st axis selection code m" is enabled by turning ON the "Manual arbitrary feed 1st axis valid" signal (CX1S) described later. Similarly, the specific validity signals (CX2S and CX3S) are also provided for the 2nd and 3rd axis number signals.
- Axis numbers can be specified as follows:

n: 1 to 3

Signal Axis specification	CXnS	—	—	CXn16	CXn8	CXn4	CXn2	CXn1
1st axis	1	—	—	0	0	0	0	1
2nd axis	1	—	—	0	0	0	1	0
3rd axis	1	—	—	0	0	0	1	1
4th axis	1	—	—	0	0	1	0	0

Validity signal

Axis number

- Motion of the specified axis component is as follows:
 - The motion of the axis component specified by the "Manual arbitrary feed 1st axis selection code m" signal corresponds to the contents of the "Manual arbitrary feed 1st axis travel amount" (R2544 and R2545).
 - The motion of the axis component specified by the "Manual arbitrary feed 2nd axis selection code m" signal corresponds to the contents of the "Manual arbitrary feed 2nd axis travel amount" (R2548 and R2549).
 - The motion of the axis component specified by the "Manual arbitrary feed 3rd axis selection code m" signal corresponds to the contents of the "Manual arbitrary feed 3rd axis travel amount" (R2552 and R2553).

[Related signals]

For related signals, refer to the section on "Manual arbitrary feed mode" (PTP: YC03).

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed 1st axis valid	CX1S	YCA7	YDE7	YF27	Y1067	Y11A7	Y12E7	Y1427	Y1567

[Function]

This signal is used to enable the axis specified by the "Manual arbitrary feed 1st axis selection code m" signal so that the axis component can move in manual arbitrary feed mode.

[Operation]

The specification of the axis by the "Manual arbitrary feed 1st axis selection code m" signal explained earlier is enabled only when this signal (CX1S) is turned ON.

[Related signals]

For related signals, refer to the section on "Manual arbitrary feed mode" (PTP: YC03).

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed 2nd axis selection code m	CX21 to 216	YCA8 to C	YDE8 to C	YF28 to C	Y1068 to C	Y11A8 to C	Y12E8 to C	Y1428 to C	Y1568 to C

[Function] [Operation]

For both function and operation, refer to the section of the "Manual arbitrary feed 1st axis selection code m" signal (CX11 to CX116: YCA0 to 4) explained above.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed 2nd axis valid	CX2S	YCAF	YDEF	YF2F	Y106F	Y11AF	Y12EF	Y142F	Y156F

[Function] [Operation]

For both function and operation, refer to the section of the "Manual arbitrary feed 1st axis valid" signal (CX1S: YCA7) explained above.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed 3rd axis selection code m	CX31 to 316	YCB0 to 4	YDF0 to 4	YF30 to 4	Y1070 to 4	Y11B0 to 4	Y12F0 to 4	Y1430 to 4	Y1570 to 4

[Function] [Operation]

For both function and operation, refer to the section of the "Manual arbitrary feed 1st axis selection code m" signal (CX11 to CX116: YCA0 to 4) explained above.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed 3rd axis valid	CX3S	YCB7	YDF7	YF37	Y1077	Y11B7	Y12F7	Y1437	Y1577

[Function] [Operation]

For both function and operation, refer to the section of the "Manual arbitrary feed 1st axis valid" signal (CX1S: YCA7) explained above.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed Smoothing off	CXS1	YCB8	YDF8	YF38	Y1078	Y11B8	Y12F8	Y1438	Y1578

[Function]

This signal is used to move an axis component under the condition where the acceleration/deceleration time constant is "0" in the manual arbitrary feed mode.

[Operation]

When manual arbitrary feed is performed with the "Manual arbitrary feed Smoothing off" signal (CXS1) turned ON, the axis moves in the same state as when the acceleration/deceleration time constant is set to "0".

Note

- (1) Since the axis moves when the acceleration/deceleration time constant is "0", if the axis is moved too fast, a servo alarm (excessive error) may occur. Move it at a slow speed.

[Related signals]

For related signals, refer to the section on "Manual arbitrary feed mode" (PTP: YC03).

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed Axis independent	CXS2	YCB9	YDF9	YF39	Y1079	Y11B9	Y12F9	Y1439	Y1579

[Function]


This signal can be used to position each axis independently without performing interpolation when two or more axis components are moved simultaneously in the manual arbitrary feed mode.

[Operation]


When manual arbitrary feed is executed for two or more axes at the same time with "Manual arbitrary feed Axis independent" (CXS2) turned ON, positioning is performed independently for each axis without interpolation. Normally, the "Manual arbitrary feed Axis independent" (CXS2) signal is used when the "Manual arbitrary feed G0/G1" signal (CXS4) described later is OFF (G0 selected).

Specific examples are shown below when the rapid traverse speeds of the X-axis and Z-axis are both 9600 mm/min, and the movement amounts of the X-axis and Z-axis are 300 mm and 200 mm, respectively.

(Example 1)



(Example 2)

**[Related signals]**

For related signals, refer to the section on "Manual arbitrary feed mode" (PTP: YC03).

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed EX.F/MODAL.F	CXS3	YCBA	YDFA	YF3A	Y107A	Y11BA	Y12FA	Y143A	Y157A

[Function]

This signal selects whether a manual arbitrary feed in G1 mode is done at manual feed rate or at modal speed in automatic operation.

[Operation]

When the "Manual arbitrary feed G0/G1" signal (CXS4) described later is ON, the operation is as follows:


<When the "Manual arbitrary feed EX.F/MODAL.F" (CXS3) is OFF>

When the "Manual feedrate method selection" signal (JVS) is OFF, the speed selected by the manual feedrate code (*JV1 to *JV16) is applied.

When the "Manual feedrate method selection" signal (JVS) is ON, the speed moves at the speed determined by the relationship between the contents of the corresponding file register (R) and the "Feedrate least increment code 1, 2" signal (PCF1 or PCF2).

<When the "Manual arbitrary feed EX.F/MODAL.F" (CXS3) is ON>

Manual arbitrary feed is done at a modal speed (F***) set in automatic operation. However, if the F command has never been executed, manual arbitrary feed does not work.

**[Related signals]**

For related signals, refer to the section on "Manual arbitrary feed mode" (PTP: YC03).

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed G0/G1	CXS4	YCBB	YDFB	YF3B	Y107B	Y11BB	Y12FB	Y143B	Y157B

[Function]

This signal selects a manual feed speed or rapid traverse speed in manual arbitrary feed mode.

[Operation]

This signal operates as shown below depending on the status of the "Manual arbitrary feed G0/G1" signal (CXS4).

<When the "Manual arbitrary feed G0/G1" signal is OFF>

The rapid traverse speed originally set to the corresponding axis applies. Rapid traverse override is also valid. The rapid traverse speed applicable when moving two or more axis components at the same time varies with the status of the "Manual arbitrary feed Axis independent" signal (CXS2). See the descriptions on the "Manual arbitrary feed axis independent" signal (CXS2).

<When the "Manual arbitrary feed G0/G1" signal is ON>

The manual feed speed or the speed specified by the F command in automatic operation apply. For details, refer to the section on "Manual arbitrary feed EX.F/MODAL.F" (CXS3).

Cutting override, "2nd cutting override" and "Override cancel" are valid as well.

[Related signals]

For related signals, refer to the section on "Manual arbitrary feed mode" (PTP: YC03).

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed MC/WK	CXS5	YCBC	YDFC	YF3C	Y107C	Y11BC	Y12FC	Y143C	Y157C

[Function]

This signal selects a machine coordinate system or a modal workpiece coordinate system on which positioning is done in manual arbitrary feed mode.

[Operation]

The "Manual arbitrary feed MC/WK" signal (CXS5) becomes valid when the "Manual arbitrary feed ABS/INC" signal (CXS6) described later is OFF in manual arbitrary feed mode.

<When the "Manual arbitrary feed MC/WK" signal is OFF>

Manual arbitrary feed n-th axis travel amount set in a file register (R) is used for positioning on the machine coordinate system.

Amount of motion =

Manual arbitrary feed n-th travel amount - Coordinate value on machine coordinate system

<When the "Manual arbitrary feed MC/WK" signal is ON>

Manual arbitrary feed n-th axis travel amount set in a file register (R) is used for positioning on the modal workpiece coordinate system.

Amount of motion =

Manual arbitrary feed n-th travel amount - Coordinate value on modal workpiece coordinate system

[Related signals]

For related signals, refer to the section on "Manual arbitrary feed mode" (PTP: YC03).

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed ABS/INC	CXS6	YCBD	YDFD	YF3D	Y107D	Y11BD	Y12FD	Y143D	Y157D

[Function]

This signal is used to select whether the traveling data given for the manual arbitrary feed is to be handled as positioning point (absolute position) or as travel distance (incremental value).

[Operation]**<When the "Manual arbitrary feed ABS/INC" signal (CXS6) is OFF>**

Manual arbitrary feed n-th axis travel amount set in a file register (R) is handled as a positioning point (absolute position).

For the coordinate systems, see the descriptions on the "Manual arbitrary feed MC/WK" signal (CXS5) explained before.

<When the "Manual arbitrary feed ABS/INC" signal is ON>

Manual arbitrary feed n-th axis travel amount set in a file register (R) is handled as a travel distance (incremental value).

[Related signals]

For related signals, refer to the section on "Manual arbitrary feed mode" (PTP: YC03).

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
B	Manual arbitrary feed stop	*CXS7	YCBE	YDFE	YF3E	Y107E	Y11BE	Y12FE	Y143E	Y157E

[Function]

This signal stops an ongoing axis component halfway in manual arbitrary feed mode.

The function of this signal is equivalent to those of the "Manual interlock+ n-th axis" signal (*+MITn) and the "Manual interlock- n-th axis" signal (*-MITn).

[Operation]

When the "Manual arbitrary feed stop" signal (*CXS7) is turned OFF (0), the following operations are performed.

- Motion of axis in manual arbitrary feed mode is decelerated and stopped.
- The axis component which is going to move in manual arbitrary feed mode remains stopped. When the "Manual arbitrary feed stop" signal (*CXS7) is turned ON (1) while an axis component is in the stop state, the axis movement is resumed immediately.

Note

- (1) When the power is turned ON, the "Manual arbitrary feed stop" signal (*CXS7) is automatically set to "1". If the "Manual arbitrary feed stop" signal is not to be used, there is no need to make a sequence program for it.

[Related signals]

For related signals, refer to the section of the "Manual arbitrary feed mode" (PTP: YC03).

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed Strobe	CXS8	YCBF	YDFF	YF3F	Y107F	Y11BF	Y12FF	Y143F	Y157F

[Function]

This signal is a trigger signal for moving an axis component in manual arbitrary feed mode. The axis component starts moving at the rising edge of this signal.

[Operation]

The "Manual arbitrary feed Strobe" signal (CXS8) turns ON after the signal necessary for manual arbitrary feed are set to the specified value.

<Signals that must be appropriately set before turning ON the strobe signal>

- (a) Manual arbitrary feed mode (PTP)
- (b) Manual arbitrary feed n-th axis selection code (CXn1 to CXn16)
- (c) Manual arbitrary feed n-th axis valid (CXnS)
- (d) Manual arbitrary feed n-th axis travel amount (file registers R2544 to R2553)
- (e) Manual arbitrary feed Smoothing off (CXS1)
- (f) Manual arbitrary feed Axis independent (CXS2)
- (g) Manual arbitrary feed EX.F/MODAL.F (CXS3)
- (h) Manual arbitrary feed G0/G1 (CXS4)
- (i) Manual arbitrary feed MC/WK (CXS5)
- (j) Manual arbitrary feed ABS/INC (CXS6)


<The following signals can be changed even after this strobe signal is turned ON>

- (k) Manual feedrate code m
- (l) Rapid traverse override for a rapid traverse speed when the "Manual arbitrary feed G0/G1" signal (CXS4) is OFF.
- (m) Manual arbitrary feed Stop (*CXS7)

Note

- (1) This strobe signal can be accepted even when the "Manual arbitrary feed Stop" signal (*CXS7) is OFF (0).

Example of operation timing chart



- (2) This strobe signal (CXS8) must be ON for at least 100 ms.

[Related signals]

Signals listed in (a) to (m) above

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Current limit mode 1	ILM1	YCC0	YE00	YF40	Y1080	Y11C0	Y1300	Y1440	Y1580
A	Current limit mode 2	ILM2	YCC1	YE01	YF41	Y1081	Y11C1	Y1301	Y1441	Y1581

[Function]

This signal selects process of current limit reached.

[Operation]

When the current reaches its limit during current control, the "Current limit reached" signal is output and the following modes are selected and performed.

Current limit mode 2	Current limit mode 1	Mode
0	0	Normal
0	1	Interlock
1	0	Normal
1	1	Normal

<Normal mode>

Movement command is executed in the current state.

In automatic operation, the movement command is executed to the end and moves to the next block with droops accumulated.

<Interlock mode>

Movement command is blocked (internal interlock).

In automatic operation, the operation stops at the corresponding block and does not move to the next block.

In manual operation, the subsequent commands to the same direction will be ignored.

[Related signals]

- (1) In current limit n-th axis (IL1 to 8: X900 to 7)
- (2) Current limit reached n-th axis (ILA1 to 8: X920 to 7)
- (3) Current limit changeover n-th axis (ILC1 to 8: Y9A0 to 7)
- (4) Droop cancel request n-th axis (DOR1 to 8: Y9C0 to 7)
- (5) Current limit changeover (R2593)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
B	2nd reference position return interlock	*ZRIT	YCC8	YE08	YF48	Y1088	Y11C8	Y1308	Y1448	Y1588

[Function]

The axis is interlocked at a designated position during manual 2nd reference position return.

[Operation]

In 2nd reference point return while this signal is valid (the base specification parameter "#1505 ckref2" is set to "1"), when this signal is OFF, the axis that has reached the designated position stops moving and an interlock is applied. The axis that has not reached the designated position are interlocked after reaching the designated position.

When this signal is ON, the axis movement does not stop and the 2nd reference position return continues.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Small diameter deep hole drilling cycle		YCCA	YE0A	YF4A	Y108A	Y11CA	Y130A	Y144A	Y158A

[Function]

The cutting operation of the small diameter deep hole drilling cycle is skipped.

[Operation]

The remaining cutting command is skipped and move on to the next operation by turning ON this signal during the cutting operation of the small diameter deep hole drilling cycle.

[Caution]

- (1) The cutting operation is skipped when this signal is turned ON.

[Related signals]

- (1) In small diameter deep hole cycle (XCC1)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Timing synchronization ignore		YCD0	YE10	YF50	Y1090	Y11D0	Y1310	Y1450	Y1590

[Function]

This signal designates the part system to ignore the timing synchronization command. The timing synchronization command in the machining program can be ignored. It is possible to operate with only a single part system without deleting the timing synchronization command in the machining program.

[Operation]

- 1: The timing synchronization is not executed. The timing synchronization command issued during the machining program is ignored.
- 0: The timing synchronization is executed.

Note

- (1) This signal is valid only when "#1279 ext15/bit0" (Part system synchronization method) is set to "1" (Timing synchronization between part systems ignore method).

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Spindle-spindle polygon cancel		YCD1	YE11	YF51	Y1091	Y11D1	Y1311	Y1451	Y1591

[Function]

Spindle-spindle polygon machining is canceled.

[Operation]

If this signal is input during spindle-spindle polygon, the spindle-spindle polygon machining mode is canceled.

[Related signals]

- (1) In spindle-spindle polygon mode (XCB2)
- (2) Spindle-spindle polygon synchronization completion (XCB3)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Synchronous tapping command polarity reversal		YCD2	YE12	YF52	Y1092	Y11D2	Y1312	Y1452	Y1592

[Function]

Specifies whether to reverse the rotation direction of the spindle during synchronous tapping.

[Operation]

When the "Synchronous tapping command polarity reversal" signal is turned ON, the spindle rotation direction is reversed during synchronous tapping.



4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Spindle OFF mode		YCD3	YE13	YF53	Y1093	Y11D3	Y1313	Y1453	Y1593

[Function]

This function is used to check the program by moving the machine without rotating the spindle.

[Operation]**<Synchronized tapping mode>**

By turning on the spindle OFF mode, the spindle does not turn ON or rotate.

Even if the spindle OFF mode is changed during the synchronized tapping mode, the operation does not change until the synchronized tapping mode is turned OFF. It is recommended to turn ON this signal from the beginning of operation.

<Asynchronous tapping mode>

- During synchronous (every revolution) feed

In addition to M03, M04 processing and dry run signal, turn ON the spindle OFF mode. The program proceeds when the signal is turned ON.

- During asynchronous feed (every minute) feed

The program proceeds even if the spindle OFF mode is not turned ON.

<Thread cutting>

When the parameter "#1279 ext15/bit4" (Dry run OFF during thread cutting) is set to "1", the dry run is disabled for thread cutting. However, when the "Spindle OFF mode" signal is ON, dry run is enabled regardless of the parameter setting, and the status of dry run is determined by the "Dry run" signal.

ext15/bit4	Dry run	Spindle OFF mode	Thread cutting motion
0	0	0/1	Command speed
0	1	0/1	Dry run speed
1	0	0/1	Command speed
1	1	0	Command speed
1	1	1	Dry run speed

[Related signals]

- (1) Dry run (DRN: YC15)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Longitudinal hole drilling axis selection	-	YCD4	YE14	YF54	Y1094	Y11D4	Y1314	Y1454	Y1594

[Function]

This signal is used to specify the hole drilling axis for the longitudinal hole drilling fixed cycle (G87, G88, G88.1, and G89).

[Operation]

When this signal is OFF (0), the X axis becomes the hole drilling axis.

When this signal is ON (1), the Y axis becomes the hole drilling axis.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tap retract possible state cancel	TRVEC	YCD6	YE16	YF56	Y1096	Y11D6	Y1316	Y1456	Y1596

[Function]

Turning ON this signal allows to move the axis, both automatically and manually, without tap retract.

This signal is used when it is judged that the spindle rotation due to tap retract is dangerous, such as when the tap is damaged.

[Operation]

Turning this signal ON turns OFF the "Tap retract possible" signal (TRVE).

[Related signals]

- (1) Tap retract (TRV: YC5C)
 (2) Tap retract possible (TRVE: XCA5)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Chopping compensation update prevention request	CHPRCR	YCD7	YE17	YF57	Y1097	Y11D7	Y1317	Y1457	Y1597

[Function] [Operation]

This signal prevents the chopping compensation amount from being updated.

[Related signals]

- (1) Chopping compensation update prevented (CHPRCC: XC7F)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Barrier valid (left)		YCD8	YE18	YF58	Y1098	Y11D8	Y1318	Y1458	Y1598
A	Barrier valid (right)		YCD9	YE19	YF59	Y1099	Y11D9	Y1319	Y1459	Y1599

[Function]

This signal is used to enable the left (right) barrier range for the chuck/tailstock barrier function.

[Operation]

The chuck/tailstock barrier function's barrier range is enabled when this signal turns ON. If the tool nose attempts to enter the range, an error occurs.

However, to enable the barrier function, this signal must be ON, and the parameter "#8310 Barrier ON" must be set to "1", and "#8315 BARRIER TYPE (L)" ("8316 BARRIER TYPE (R)") must not be set to "0" on the BARRIER screen. (Except when a special display unit is used.)

The barrier range can be enabled or disabled with the G22/G23 command instead of this signal input. In this case, the left and right settings are changed at the same time. (Depending on the selected G code series, some systems may not be able to issue G22/G23 commands.)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Hob machining: Retract request	HOBRTTR	YCDE	YE1E	YF5E	Y109E	Y11DE	Y131E	Y145E	Y159E

[Function]

This signal is used to implement retract during hob machining.

[Operation]

When this signal is turned ON during hobbing, the retract (axis movement) is performed and the automatic operation is stopped.

The movement amount speed of the axis to be retracted are set by the following parameters.

Movement amount: "#8219 Hob retract amount 1" and "#8220 Hob retract amount 2"

Speed: "#8221 Hob retract speed"

Retract operation continues even if this signal is turned OFF during the retract operation.

[Related signals]

- (1) Hob machining: Retract amount selection (HOBRTV: YB20)
- (2) Hob machining: Retracting (HOBRTM: XCAE)
- (3) Hob machining: Retract complete (HOBRTF: XCAF)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Hob machining: Alarm retract inhibit	HO-BARTC	YCDF	YE1F	YF5F	Y109F	Y11DF	Y131F	Y145F	Y159F

[Function]

This signal is used to inhibit retract operation caused by an alarm during hob machining.

[Operation]

While this signal is ON, retract operation is not carried out even if a program error or operation error occurs during hob machining.

Whether to perform retract due to a program error or operation error while this signal is OFF depends on the setting of the parameter "#19406 Hob retract ON at alarm".

Retract operation continues even if this signal is turned ON during the retract operation.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Door open II	DOOR2	YCE1	YE21	YF61	YF61	Y11E1	Y1321	Y1461	Y15A1

[Function]

This signal stops all axes and shuts OFF the contactor.

[Operation]

The NC carries out the following operations when the "Door open II" signal turns ON.

- A deceleration stop is carried out for all axes (servo axes and spindles). (Axis interlock)
- After all axes are stopped, the contactor of each drive unit is shut OFF. The "Servo ready completion" signal (SA) does not turn OFF.
- The "Door open enable" signal turns ON.

The NC carries out the following operations when the "Door open II" signal turns OFF.

- A ready ON and servo ON state occurs for all axes.
- The "Door open enable" signal turns OFF.

[Caution]**<Handling of the PLC axis>**

For the PLC axis, stop it at the PLC and then output a door open signal to the NC. If a door open signal is input without stopping the PLC axis, the axis stops with a dynamic brake method due to the ready OFF state. The remaining distance will be held in the R register being used in the PLC axis control.

<Handling of the analog spindle>

When an analog spindle is connected, it is not possible to confirm that the spindle has completely stopped with the NC. Thus, confirm that the spindle has completely stopped using the PLC before opening the door.

Since the spindle may resume rotation immediately after the door is closed, for safety, turn the forward run and reverse run signals OFF when the door is opened.

<Opening the door during ATC operation>

To open the door while ATC is operating, apply an interlock with the user PLC.

[Related signals]

- (1) Door open enable (DROPNS: XCD8)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Door open signal input (spindle speed monitor)		YCE2	YE22	YF62	Y10A2	Y11E2	Y1322	Y1462	Y15A2

[Function]

This signal informs the door open or close state to the spindle drive unit with the spindle speed monitor function.

[Operation]

When the door is in the open state, turn ON (1) this signal.

The compatibility check of this signal and the door close signal connected with the spindle drive unit is performed in the spindle drive unit.

If those signals are not compatible for continuous 3 seconds, the servo alarm (S01 5D) occurs.

[Related signals]

- (1) Door open enable (DROPNS: XCD8)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Door interlock spindle speed clamp		YCE3	YE23	YF63	Y10A3	Y11E3	Y1323	Y1463	Y15A3

[Function]

This signal is used to change the spindle's clamp speed.

[Operation]

When the "Door interlock spindle speed clamp" signal is turned ON, the spindle rotation speed is limited by the clamp speed set value.

The table below shows the relationship between the "Door interlock spindle speed clamp" signal and the clamp speed parameter for each operation.

Spindle operation	Clamp speed parameter (spindle parameter)	
	Door interlock spindle speed clamp OFF	Door interlock spindle speed clamp ON
Orientation (multi-point orientation)	#3205 SP005	#3315 SP115
Turret indexing	#3312 SP112	#3211 SP011
Synchronized tapping (zero point return)	#3414 SP214	#3315 SP115
Spindle C axis (C axis zero point return)	#3349 SP149	#3315 SP115

[Caution]

- (1) This signal is valid only when the parameter "#1239 set11/bit5" (Door interlock spindle speed clamp valid) is set to "1".
- (2) The clamp speed parameter setting value that is enabled when the "Door interlock spindle speed clamp" signal is ON must be smaller than the original clamp speed setting value (the clamp speed that is valid when the signal is OFF). The clamp speed is switched when the signal turns ON regardless of the size of the parameter setting values.
- (3) Do not change the state of the "Door interlock spindle speed clamp" signal during multi-point indexing. If the signal state changes during operation, the clamp speed also changes.
- (4) Even if the "Door interlock spindle speed clamp" signal is switched during orientation, during zero point return at synchronized tapping, or during reference position return after changing from the spindle mode to the C axis mode under the spindle/C-axis control function, the clamp speed does not change. The rotation speed is clamped by the clamp speed set with the signal state before each operation is executed.
- (5) The combination of the "Door interlock spindle speed clamp" signal with the spindle for which the clamp speed is to be switched differs depending on the "#1154 pdoor" setting and system configuration. The combinations are shown below.

#1154 pdoor setting value	The number of part systems	Door interlock spindle speed clamp signal
0	1	YCE3
0	2	YCE3
1	1	YCE3
1	2	YCE3

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Barrier check invalid	BCHK	YCF4	YE34	YF74	Y10B4	Y11F4	Y1334	Y1474	Y15B4

[Function]

This signal disables barriers of chuck barrier and tail stock barrier (G22).

[Operation]

When this signal is ON, the chuck barrier and tail stock barrier is disabled regardless of whether the chuck barrier and tail stock barrier command (G22/G23) is ON/OFF during the machining program.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Synchronization between part systems OFF	MSYNC	YCF8	YE38	YF78	Y10B8	Y11F8	Y1338	Y1478	Y15B8

[Function]

This signal disables the functions for synchronization between part systems such as the "Single block between part systems" (MSBK) operation.

[Operation]

If the "Synchronization between part systems OFF" signal (MSYNC) is ON, the functions for synchronization between part systems such as the "Single block between part systems" (MSBK) operation are ignored.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Dry run invalid	DRNC	YCFA	YE3A	YF7A	Y10BA	Y11FA	Y133A	Y147A	Y15BA

[Function]

This signal disables dry run in dry run operation.

[Operation]

When the "Dry run invalid" signal (DRNC) is ON, the NC ignores the "Dry run" (DRN) function and operates at the specified speed.

[Related signals]

(1) Dry run (DRN: YC15)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Automatic error detection	AUTED	YCFB	YE3B	YF7B	Y10BB	Y11FB	Y133B	Y147B	Y15BB

[Function]

With the "Automatic error detection" signal (AUTED), the timing for starting the next cutting block is controlled until the amount of position error becomes equal to or less than the parameter value (corner deceleration check width), in order to cut edges with high precision.

The timing for starting the next block is controlled when the result of corner angle calculation is smaller than the parameter value (corner deceleration check angle).


[Operation]

The following operation is performed when the "Automatic error detection" signal (AUTED) is ON.


<Corner angle calculation control>

The timing for starting the next cutting block is controlled only when the corner angle θ (interior angle) calculated for consecutive cutting blocks is equal to or smaller than the parameter value (corner deceleration check angle). The timing for starting the next cutting block is not controlled when the corner angle is larger than the parameter value.

Angle calculation is performed for the plane axis selected with the plane selection command. Angle calculation is not performed for the rotational axes.

**<Start timing control>**

Checking the amount of error is started after deceleration starts in the currently executed block. The next cutting block starts when the amount of error (remaining distance after composition) between the machine position of the target axis and the feedback machine position becomes equal to or less than the parameter value (corner deceleration check width).

**Note**

(1) Turn OFF the normally used "Error detection" signal (ERD) before using the "Automatic error detection" signal (AUTED). When the "Error detection" signal (ERD) is ON, the normal error detection is given priority.

[Related signals]

(1) Error detection (ERD: YC17)

IB-1501616-C

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Program format switch request	PFCHR	YD00	YE40	YF80	Y10C0	Y1200	Y1340	Y1480	Y15C0


[Function]

This signal starts or ends the program format switch.

[Operation]


When this signal turns ON, the control starts the program format switch. When this signal turns OFF, the program format switch is finished (canceled).

L-system operation example



There are two types of means to switch the program format: G code method and PLC I/F method (this signal). The two methods interact with each other. Thus, even though this signal is ON, it does not always mean the "Program format switch in progress" (PFCHS: XCF0) is ON. (The "Program format switch in progress" (PFCHS: XCF0) is dynamically changed by G188/G189 during automatic operation. After automatic operation is finished; however, the "Program format switch in progress" (PFCHS: XCF0) is updated based on this signal, regardless of whether the "Program format switch in progress" (PFCHS: XCF0) is ON or OFF at the completion of automatic operation.)

Interaction with G code method



(*1) The G group 24 modal state is refreshed only during automatic operation.

[Caution]

- (1) If this signal is turned ON during automatic cycle operation (while the "In automatic operation "run"" (OP: XC12) is ON), the operation error (M01 0215) occurs and the program format switch is not implemented. When this signal is turned OFF, the operation error (M01 0215) disappears.
- (2) When this signal is switched from OFF to ON and automatic operation is started, the program error (P29) occurs and the automatic operation is not implemented if the program format cannot be switched during G modal.
- (3) After this signal is turned ON, wait until the "Program format switch in progress" (PFCHS: XCF0) turns ON before you execute automatic cycle operation. Otherwise, it cannot be assured that "the control runs a program based on the switched G code system from the top block of the program".
- (4) Program format switch is available for the maximum number of M-system part systems specified by the system. If this signal is turned ON for a part system where the switch is disabled, the signal is ignored.
- (5) When the modal retention reset is performed while the parameter "#1319 Grp24_mdrst_off" (G group 24 modal retention reset OFF) is set to "0", the state of the program format switch or the switch cancel is held even if the automatic operation is started with this signal OFF.

[Related signals]

- (1) Program format switch in progress (PFCHS: XCF0)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary reverse run: Reverse run block stop designated part system	RBSSY	YD01	YE41	YF81	Y10C1	Y1201	Y1341	Y1481	Y15C1

[Function]

Turning this signal ON specifies the part system in which single-block stop occurs when reverse run is executed during the manual arbitrary reverse run.

[Operation]

- This signal is ON.
- The "Single block between part systems" is ON.
- Modal information memory block

Block stop occurs for reverse run only when all of the above three conditions are met.

[Related signals]

- (1) Manual arbitrary reverse run mode ON (PCHKO: X715)
- (2) Manual arbitrary reverse run: Reverse run ON (MOREV: X716)
- (3) Thread, tap block stopping in manual arbitrary reverse run (MBSTP: X74D)
- (4) Thread, tap reverse run prohibition alarm in manual arbitrary reverse run (MRVNG: X74E)
- (5) Single block between part systems (MSBK: Y73A)
- (6) Manual arbitrary reverse run mode (MORR: Y73C)
- (7) Manual arbitrary reverse run speed selection (MORSP: Y73D)
- (8) Actual cutting mode (thread, tap) in manual arbitrary reverse run (MRCMD: Y761)
- (9) Manual arbitrary reverse run: MSTB reverse run prohibited (MRPSG: YCFC)
- (10) Manual arbitrary reverse run handle selection (R375)
- (11) Manual arbitrary reverse run speed multiplier (R379)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Reverse run from block start	RVSP	YD08	YE48	YF88	Y10C8	Y1208	Y1348	Y1488	Y15C8

[Function]

This signal is used to designate where a reverse run starts in the arbitrary reverse run.

[Operation]

When this signal is OFF, a reverse run starts from the block stop point.

When this signal is ON, a reverse run starts from the start point of the block where the movement stopped.

Return to the start point for the reverse run from block start, turn this signal ON, and then start an automatic operation.

Keep this signal ON until the "In auto operation "start"" signal (STL) turns ON.

This signal is available only in the reverse run control mode.

[Related signals]

- (1) Macro interrupt priority (RVIT: YD09)
- (2) Reverse run control mode (RVMD: YD0A)
- (3) Reverse run (VRV: YC27)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Macro interrupt priority	RVIT	YD09	YE49	YF89	Y10C9	Y1209	Y1349	Y1489	Y15C9

[Function]

In the arbitrary reverse run, turning ON the "Macro interrupt" signal (UIT) executes a block stop during the reverse run.

Then this signal is used to select the operation when an automatic operation is started while the "Reverse run" signal (VRV) is OFF.

[Operation]

When this signal is OFF, a forward run is executed with the falling edge of the "Automatic operation "start" command" signal.

When this signal is ON, a macro interrupt program is executed with the falling edge of the "Automatic operation "start" command" signal.

This signal is available only in the reverse run control mode.

[Related signals]

- (1) Reverse run from block start (RVSP: YD08)
- (2) Reverse run control mode (RVMD: YD0A)
- (3) Reverse run (VRV: YC27)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Reverse run control mode	RVMD	YD0A	YE4A	YF8A	Y10CA	Y120A	Y134A	Y148A	Y15CA

[Function]

This signal is used to save the reverse run information used for the reverse run control in the arbitrary reverse run.

[Operation]

When this signal is ON, the reverse run information is saved.

Turn this signal ON at the start of the block where the reverse run control is executed and turn it OFF at the time of reset.

Turn ON the "Recalculation request" signal (CRQ) when this signal is turned ON.

When a recalculation request is not made, blocks already created by pre-reading are not retained as reverse run information.

[Related signals]

- (1) Reverse run from block start (RVSP: YD08)
- (2) Macro interrupt priority (RVIT: YD09)
- (3) Reverse run (VRV: YC27)
- (4) Recalculation request (CRQ: YC2B)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Rapid traverse time constant: Switch-over request	ACCG	YD0B	YE4B	YF8B	Y10CB	Y120B	Y134B	Y148B	Y15CB

[Function]

The rapid traverse time constant can be switched over.

- 1: Switch the rapid traverse time constant of all axes in the part system to the axis specification parameter "#2598 G0tL_2", and switch the rapid traverse time constant (primary delay)/second-step time constant for soft acceleration/deceleration to the axis specification parameter "#2599 G0t1_2".

- 0: Switch back the rapid traverse time constant of all axes in the part system to the axis specification parameter "#2004 G0tL", and switch back the rapid traverse time constant (primary delay)/second-step time constant for soft acceleration/deceleration to the axis specification parameter "#2005 G0t1".

[Operation]

When this signal is turned ON (1), the NC operates as follows:

- When any of the axes in the part system is moving, the time constant is switched after all the axes in the part system have decelerated to a stop.
- When any of the axes in the part system is at a standstill, the time constant is switched immediately.

When this signal is turned OFF (0), the NC operates as follows:

- When any of the axes in the part system is moving, the time constant is switched back after all the axes in the part system have decelerated to a stop.
- When any of the axes in the part system is at a standstill, the time constant is switched back immediately.

[Related signals]

- (1) Rapid traverse time constant: In switchover (G0AC: XD0B)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Real-time tuning 2: Acceleration/deceleration time constant in automatic switchover	RT2CHGA	YD0C	YE4C	YF8C	Y10CC	Y120C	Y134C	Y148C	Y15CC

[Function]

This signal automatically switches acceleration/deceleration time constant in the real-time tuning 2 function.

[Operation]

While this signal is ON, the acceleration/deceleration time constant is always switched to a value based on the current estimated inertia ratio.

While this signal is OFF, the switching process is not performed for the acceleration/deceleration time constant.

[Related signals]

- (1) Real-time tuning 2: Acceleration/deceleration time constant in switchover (RT2CHG: XD0C)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Real-time tuning 2: Acceleration/deceleration time constant in manual switchover	RT2CHGM	YD0D	YE4D	YF8D	Y10CD	Y120D	Y134D	Y148D	Y15CD

[Function]

This signal manually switches acceleration/deceleration time constant in the real-time tuning 2 function.

[Operation]

While this signal is ON, the acceleration/deceleration time constant is manually switched to a value based on the current estimated inertia ratio.

While this signal is OFF, the switching process is not performed for the acceleration/deceleration time constant.

[Related signals]

- (1) Real-time tuning 2: Acceleration/deceleration time constant in switchover (RT2CHG: XD0C)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Real-time tuning 2: Acceleration/deceleration time constant reset	RT2RST	YD0E	YE4E	YF8E	Y10CE	Y120E	Y134E	Y148E	Y15CE

[Function]

This signal maximizes the value of acceleration/deceleration time constant in the real-time tuning 2 function.

This signal is valid only at rising edge of the signal.

[Operation]

While this signal is ON, the control maximizes the value of acceleration/deceleration time constant.

While this signal is OFF, the maximizing process is not performed for acceleration/deceleration time constant.

[Related signals]

- (1) Real-time tuning 2: Acceleration/deceleration time constant in switchover (RT2CHG: XD0C)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Request for reflecting reserved tool wear compensation	TWIN	YD0F	YE4F	YF8F	Y10CF	Y120F	Y134F	Y148F	Y15CF

[Function]

Reserved tool wear compensation memory is reflected to tool wear compensation memory.


[Operation]

This signal is available when the reservation of tool wear compensation function is valid.

- When the reserved tool wear compensation memory or the tool wear compensation memory is set, the "Reserved tool wear compensation not reflected" signal (TWNIN) is turned ON.
- When the "Request for reflecting reserved tool wear compensation" signal (TWIN) is turned ON, reflection of data from the reserved tool wear compensation memory to the tool wear compensation memory starts.
- When the reserved value has been reflected, the "Reflection of reserved tool wear compensation is complete" signal (TWOUT) turns ON and the "Reserved tool wear compensation not reflected" signal (TWNIN) turns OFF. However, when writing is performed to the reserved tool wear compensation memory or the tool wear compensation memory while the "Request for reflecting reserved tool wear compensation" signal (TWIN) is ON, the "Reserved tool wear compensation not reflected" signal (TWNIN) will not turn OFF.

This is because the reflection of the reserved value is not guaranteed. When the "Reserved tool wear compensation not reflected" signal (TWNIN) does not turn OFF even though the "Reflection of reserved tool wear compensation is complete" signal (TWOUT) is turned ON, turn OFF the "Request for reflecting reserved tool wear compensation" signal (TWIN) once then turn it ON again.

- When the "Request for reflecting reserved tool wear compensation" signal (TWIN) is turned OFF, the "Reflection of reserved tool wear compensation is complete" signal (TWOUT) also turns OFF.

**Note**

- When the parameter "#1051 MemTol" is set to "1", a signal of the first part system (TWNIN, TWIN, TWOUT) is used.

[Related signals]

- Reservation of tool wear compensation (TWR: Y1CB8)
- Reflection of reserved tool wear compensation is complete (TWOUT: XD0F)
- Reserved tool wear compensation not reflected (TWNIN: XD0E)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	3D coordinate conversion: Manual feed coordinates conversion		YD14	YE54	YF94	Y10D4	Y1214	Y1354	Y1494	Y15D4

[Function]

When the "3D coordinate conversion: Manual feed valid signal" signal (XD14) is set to "1", manual operation (jog feed, incremental feed, or manual handle feed) can be performed on the coordinate system generated by the 3D coordinate conversion command (G68 for M system or G68.1 for L system).

[Operation]

This signal is enabled while the "3D coordinate conversion: Manual feed valid" signal (XD14) is set to "1".

When this signal is set to "0", manual operation is performed with respect to the machine coordinate system.

When this signal is set to "1", manual operation is performed with respect to the G68/G68.1 program coordinate system.

[Related signals]

- (1) 3D coordinate conversion: Manual feed valid (XD14)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Rotation center error compensation enabled	RCEE	YD15	YE55	YF95	Y10D5	Y1215	Y1355	Y1495	Y15D5

[Function]

The signal enables the rotation center error compensation.

[Operation]

While this signal is set to "1", rotation center error compensation is enabled.

Note

- (1) Do not switch ON/OFF of this signal during machining.

If ON/OFF of the signal is switched, the error compensation amount is immediately be reflected on the machine travel amount.

[Related signals]

- (1) Rotation center error compensation in progress (RCEI: XD15)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Spatial error compensation enabled	SECE	YD17	YE57	YF97	Y10D7	Y1217	Y1357	Y1497	Y15D7

[Function]

This signal enables the spatial error compensation.

Do not switch ON/OFF of the "Spatial error compensation enabled" signal during machining. If the signal is switched, the error compensation amount is immediately reflected on the machine travel amount.

[Operation]

When this signal is set to "0", the spatial error compensation is invalid.

When this signal is set to "1", the spatial error compensation is valid.

The spatial error compensation function can compensate errors only in the first part system.

[Related signals]

- (1) Spatial error compensation in progress (SECI: XD17)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	3D manual feed (JOG, INC): Tool axis coordinate system selection	MJCT	YD18	YE58	YF98	Y10D8	Y1218	Y1358	Y1498	Y15D8
A	3D manual feed (JOG, INC): Table coordinate system selection	MJCB	YD19	YE59	YFB9	Y10D9	Y1219	Y1359	Y1499	Y15D9
A	3D manual feed (JOG, INC): Feature coordinate system selection	MJCF	YD1A	YE5A	YFBA	Y10DA	Y121A	Y135A	Y149A	Y15DA

[Function]

This signal is used to select the coordinate system for the 3D manual feed.

It is possible to set different coordinate systems for each manual mode or each handle to be used.

[Operation]

This signal is used to select the coordinate system when the 3D manual feed is carried out in the jog mode or incremental mode.

[Related signals]

- (1) Jog mode (J: YC00)
- (2) Incremental mode (S: YC02)
- (3) Tool center point rotation (TCPRC: YD27)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	3D manual feed (1st handle): Tool axis coordinate system selection	MH1CT	YD1B	YE5B	YFBB	Y10DB	Y121B	Y135B	Y149B	Y15DB
A	3D manual feed (1st handle): Table coordinate system selection	MH1CB	YD1C	YE5C	YFBC	Y10DC	Y121C	Y135C	Y149C	Y15DC
A	3D manual feed (1st handle): Feature coordinate system selection	MH1CF	YD1D	YE5D	YFBD	Y10DD	Y121D	Y135D	Y149D	Y15DD

[Function]

This signal is used to select the coordinate system for the 3D manual feed.

It is possible to set different coordinate systems for each manual mode or each handle to be used.

[Operation]

This signal is used to select the coordinate system when the 3D manual feed is carried out by the 1st handle, in this device.

[Related signals]

- (1) 1st handle axis selection code (HS11 to HS116: YC40 to 4)
- (2) 1st handle valid (HS1S: YC47)
- (3) Tool center point rotation (TCPRC: YD27)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	3D manual feed (2nd handle): Tool axis coordinate system selection	MH2CT	YD1E	YE5E	YFBE	Y10DE	Y121E	Y135E	Y149E	Y15DE
A	3D manual feed (2nd handle): Table coordinate system selection	MH2CB	YD1F	YE5F	YFBF	Y10DF	Y121F	Y135F	Y149F	Y15DF
A	3D manual feed (2nd handle): Feature coordinate system selection	MH2CF	YD20	YE60	YFA0	Y10E0	Y1220	Y1360	Y14A0	Y15E0

[Function]

This signal is used to select the coordinate system for the 3D manual feed.

It is possible to set different coordinate systems for each manual mode or each handle to be used.

[Operation]

This signal is used to select the coordinate system when the 3D manual feed is carried out by the 2nd handle, in this device.

[Related signals]

- (1) 2nd handle axis selection code (HS21 to HS216: YC48 to C)
- (2) 2nd handle valid (HS2S: YC4F)
- (3) Tool center point rotation (TCPRC: YD27)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	3D manual feed (3rd handle): Tool axis coordinate system selection	MH3CT	YD21	YE61	YFA1	Y10E1	Y1221	Y1361	Y14A1	Y15E1
A	3D manual feed (3rd handle): Table coordinate system selection	MH3CB	YD22	YE62	YFA2	Y10E2	Y1222	Y1362	Y14A2	Y15E2
A	3D manual feed (3rd handle): Feature coordinate system selection	MH3CF	YD23	YE63	YFA3	Y10E3	Y1223	Y1363	Y14A3	Y15E3

[Function]

This signal is used to select the coordinate system for the 3D manual feed.

It is possible to set different coordinate systems for each manual mode or each handle to be used.

[Operation]

This signal is used to select the coordinate system when the 3D manual feed is carried out by the 3rd handle, in this device.

[Related signals]

- (1) 3rd handle axis selection code (HS31 to HS316: YC50 to 4)
- (2) 3rd handle valid (HS3S: YC57)
- (3) Tool center point rotation (TCPRC: YD27)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool center point rotation	TCPRC	YD27	YE67	YFA7	Y10E7	Y1227	Y1367	Y14A7	Y15E7

[Function]

This signal is used to select the operation of the rotary axis of 3D manual feed (JOG/incremental/handle).

[Operation]

It operates with keeping the positional relationship of tool center point looking from the workpiece, when the rotation axis of 3D manual feed (JOG/incremental/handle) is operated.

Input					Output	
#7912 NO_MANUAL	Hypothetical coordinate system selection signal			Tool center point rotation signal	Selection coordinate system	Tool center point rotation valid/invalid
	YD18	YD19	YD1A	YD27		
Valid	All 0			0	Machine coordinate system selection	Invalid
				1		Valid
	Only any one of them is 1			0	In accordance with the hypothetical coordinate system selection signal	Invalid
				1		Valid
	Other than the above.			0/1	The operation error (M01 0231)	
Invalid	0/1	0/1	0/1	0/1	Machine coordinate system selection	Invalid

[Related signals]

- (1) 3D manual feed (JOG, INC): Tool axis coordinate system selection (MJCT: YD18)
- (2) 3D manual feed (JOG, INC): Table coordinate system selection (MJCB: YD19)
- (3) 3D manual feed (JOG, INC): Feature coordinate system selection (MJCF: YD1A)
- (4) 3D manual feed (1st handle): Tool axis coordinate system selection (MH1CT: YD1B)
- (5) 3D manual feed (1st handle): Table coordinate system selection (MH1CB: YD1C)
- (6) 3D manual feed (1st handle): Feature coordinate system selection (MH1CF: YD1D)
- (7) 3D manual feed (2nd handle): Tool axis coordinate system selection (MH2CT: YD1E)
- (8) 3D manual feed (2nd handle): Table coordinate system selection (MH2CB: YD1F)
- (9) 3D manual feed (2nd handle): Feature coordinate system selection (MH2CF: YD20)
- (10) 3D manual feed (3rd handle): Tool axis coordinate system selection (MH3CT: YD21)
- (11) 3D manual feed (3rd handle): Table coordinate system selection (MH3CB: YD22)
- (12) 3D manual feed (3rd handle): Feature coordinate system selection (MH3CF: YD23)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Miscellaneous function command high-speed output: M function finish 1 to 4	MFIN 1 to 4	YD28 to B	YE68 to B	YFA8 to B	Y10E8 to B	Y1228 to B	Y1368 to B	Y14A8 to B	Y15E8 to B

[Function]

This status signal informs the controller that specified miscellaneous (M) function is accomplished on the PLC side when the high-speed method is selected for the miscellaneous command completion method.


[Operation]

If the M function command is executed during automatic operation, the M function data is output and the "M function strobe" signals (MF_n) are logically inverted.

When the PLC verifies that one or more M functions are commanded by the auxiliary function strobe, it performs the specified operation, and after the execution is completed, logically invert this signal.

When the controller verifies that the "M function strobe" and the "High-speed M function finish" match at the logic level, the M function is considered to be completed and the controller proceeds to the next block.

The following is an example of a time chart when the auxiliary function (M) is used.

**Note**

- (1) At NC reset, those signals must be set to "0" because the "M function strobe" signals (MF_n) are also set to "0" at NC reset.
- (2) This signal is not used in the normal method (the parameter "#1278 ext14/bit1" is set to "0").

[Related signals]

- (1) M function strobe n (MF_n: XC60)
- (2) M, S, T, B function data (output to file register R: R504 and later)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Miscellaneous function command high-speed output: S function finish 1 to 8	SFIN1 to 8	YD2C to F, YD38 to B	YE6C to F, YE78 to B	YFAC to F, YFB8 to B	Y10EC to F, Y10F8 to B	Y122C to F, Y1238 to B	Y136C to F, Y1378 to B	Y14AC to F, Y14B8 to B	Y15EC to F, Y15F8 to B

[Function]

This status signal informs the controller that specified spindle (S) function is accomplished on the PLC side when the high-speed method is selected for the miscellaneous command completion method.


[Operation]

If the S function command is executed during automatic operation, the S function data is output and the S function strobe signals (SF_n) are logically inverted.

When the PLC verifies that one or more S function has been specified, it performs that function (s) and, after completion of the function (s), those signals are logically inverted.

When the controller verifies that the "S function strobe" and the "High-speed S function finish" have become the same logic level, the S function is considered to be completed and the controller will proceed to the next block.

An example of timing chart, where S function is specified, is as follows:

**Note**

- (1) At NC reset, those signals must be set to "0" because the S function strobe signals (SF_n) are also set to "0" at NC reset.
- (2) This signal is not used in the normal method (the parameter "#1278 ext14/bit1" is set to "0").

[Related signals]

- (1) S function strobe n (SF_n: XC64)
- (2) M, S, T, B function data (output to file register R: R504 and later)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Miscellaneous function command high-speed output: T function finish 1 to 4	TFIN1 to 4	YD30 to 3	YE70 to 3	YFB0 to 3	Y10F0 to 3	Y1230 to 3	Y1370 to 3	Y14B0 to 3	Y15F0 to 3

[Function]

This status signal informs the controller that specified tool (T) function is accomplished on the PLC side when the high-speed method is selected for the miscellaneous command completion method.


[Operation]

If the T function command is executed during automatic operation, the T function data is output and the T function strobe signals (TF1 to 4) are logically inverted.

When the PLC verifies that one or more T function has been specified, it performs that function (s) and, after completion of the function (s), those signals are logically inverted.

When the controller verifies that the "T function strobe" and the "High-speed T function finish" have become the same logic level, the T function is considered to be completed and the controller will proceed to the next block.

An example of timing chart, where T function is specified, is as follows:

**Note**

- (1) At NC reset, those signals must be set to "0" because the T function strobe signals (TF 1 to 4) are also set to "0" at NC reset.
- (2) This signal is not used in the normal method (the parameter "#1278 ext14/bit1" is set to "0").

[Related signals]

- (1) T function strobe 1 to 4 (TF1 to 4: XC68)
- (2) M, S, T, B function data (output to file register R: R504 and later)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Miscellaneous function command high-speed output: 2nd M function finish 1 to 4	BFIN1 to 4	YD34 to 7	YE74 to 7	YFB4 to 7	Y10F4 to 7	Y1234 to 7	Y1374 to 7	Y14B4 to 7	Y15F4 to 7

[Function]

This status signal informs the controller that specified 2nd miscellaneous (B) function is accomplished on the PLC side when the high-speed method is selected for the miscellaneous command completion method.


[Operation]

If the B function command is executed during automatic operation, the B function data is output and the 2nd M function strobe signals (BF1 to 4) are logically inverted.

When the PLC verifies that one or more B function has been specified, it performs that function (s) and, after completion of the function(s), those signals are logically inverted.

When the controller verifies that the "2nd M function strobe" and the "High-speed 2nd M function finish" have become the same logic level, the B function is considered to be completed and the controller will proceed to the next block.

An example of timing chart, where 2nd miscellaneous (B) function is specified, is as follows:

**Note**

- (1) At NC reset, those signals must be set to "0" because the 2nd M function strobe signals (BF 1 to 4) are also set to "0" at NC reset.
- (2) This signal is not used in the normal method (the parameter "#1278 ext14/bit1" is set to "0").

[Related signals]

- (1) 2nd M function strobe 1 to 4 (BF1 to 4: XC6C)
- (2) M, S, T, B function data (output to file register R: R504 and later)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Edit/Search		Y1878


[Function]

This signal indicates that the edit/search state has been entered.

[Operation]

Turning this signal ON identifies the edit/search state, displaying the Edit/Search window on the Monitor screen when the basic specification parameter "#11031 Cursor pos search" (Cursor position search) is set to "2". Moving the cursor at a position in the Edit/Search window and turning this signal OFF starts an operation search of the cursor position.

Allow at least 500 ms between turning the "Edit/Search" signal ON and OFF.

[Timing chart]**[Related signals]**

- (1) Edit/Search window displayed (X1878)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Gear shift completion	GFIN	Y1885	Y18E5	Y1945	Y19A5	Y1A05	Y1A65	Y1AC5	Y1B25


[Function]

This signal changes the spindle speed to the speed (S command) specified in the machining program.

This signal is used to smoothly perform the spindle speed (S command, etc.) control.

[Operation]


To match the actual spindle speed to the speed specified by the S command during automatic operation (memory, MDI, or tape), turn ON the "Gear shift completion" (GFIN), or "M function finish 1" (FIN1) or "M function finish 2" (FIN2).




The timing chart for operation example is shown below: When this signal is used, the following two conditions should be considered.

- ♦ Whether gear shift (gear change) is applicable. (Whether there are two or more states of gear shift)
- ♦ Whether the "Spindle up-to-speed" signal output from the spindle controller is used to check the rotation of the spindle.

<(Operation example 1) There is no gear shift and the "Spindle up-to-speed" signal is not used.>




<(Operation example 2) There is no gear shift, but the "Spindle up-to-speed" signal is used.>




4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

<(Operation example 3) There is gear shift, but the "Spindle up-to-speed" signal is not used.>



<(Operation example 4) There is gear shift and the "Spindle up-to-speed" signal are used.>



[Related signals]

- (1) S function strobe 1, 2 (SF_n: XC64)
- (2) Spindle gear shift (GR1, GR2: X1885, X1886)
- (3) M function finish (FIN1, FIN2: YC1E, YC1F)
- (4) Spindle gear selection code 1, 2 (GI1, GI2: Y1890, Y1891)
- (5) Spindle stop (SSTP: Y1894), Spindle gear shift (SSFT: Y1895)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle speed override code m	SP1 to 4	Y1888 to A	Y18E8 to A	Y1948 to A	Y19A8 to A	Y1A08 to A	Y1A68 to A	Y1AC8 to A	Y1B28 to A

[Function]

This is a signal for applying an override (magnification) to the S command issued by automatic operation (memory, MDI, tape).

[Operation]

By selecting the "Spindle speed override code m" signal (SP1 to 4), override ratio can be selected from the range of 50% to 120% in 10% increments.

Override cannot be set when:

- ♦ The "Spindle stop" signal is ON.
- ♦ During tapping mode
- ♦ During thread cutting

This signal (SP1 to 4) is set with the code method. The following table shows the relationship.

SP4	SP2	SP1	Spindle override
1	1	1	50%
0	1	1	60%
0	1	0	70%
1	1	0	80%
1	0	0	90%
0	0	0	100%
0	0	1	110%
1	0	1	120%

[Related signals]

(1) Spindle override method selection (SPS: Y188F)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle override method selection	SPS	Y188F	Y18EF	Y194F	Y19AF	Y1A0F	Y1A6F	Y1ACF	Y1B2F


[Function]

This is a signal to switch whether to apply the override (magnification) to the S command issued in automatic operation (memory, MDI or tape) by the above mentioned "code method" or "file register method".

[Operation]

When the "Spindle override method selection" (SPS) is OFF, code method override (signal SP1 to SP4 is applicable) is selected.

When the "Spindle override method selection" (SPS) is ON, file register method override (value set in file register is applicable) is selected.

**Note**

(1) For each operation of the code method and file register method, refer to the relevant descriptions.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle gear selection code 1, 2	GI1, 2	Y1890, 1	Y18F0, 1	Y1950, 1	Y19B0, 1	Y1A10, 1	Y1A70, 1	Y1AD0, 1	Y1B30, 1


[Function]

This signal informs the controller which spindle gear has been selected on the machine side.

[Operation]

This signal is set according to the machine's spindle gear stage. The controller calculates the S command data (data is transferred when the spindle controller is the high-speed serial connection specification) based on this signal.

The flow after the S command is executed and output to the spindle is shown below.



The relation of the gear stage, spindle gear selection code signal and spindle limit speed is as shown below.

Gear stage	Spindle gear selection code		Spindle speed limit
	GI2	GI1	
1	0	0	Slimt1
2	0	1	Slimt2
3	1	0	Slimt3
4	1	1	Slimt4

- Slimt1 to 4 are set with parameters. These set the rotation speed of the spindle when the S command data is maximum, that is, when the motor rotates at the maximum rotation.

This setting is used for each gear unit, and is determined by the deceleration ratio (gear ratio) of the motor and spindle. For example, if the maximum motor speed is 6000 r/min, and the 1st gear stage is decelerated to half, "3000" will be set in parameter Slimt1.

- The controller calculates the spindle speed output data as shown below.
For example, when S command is issued, gear selection input is the 2nd stage ("GI1" is ON and "GI2" is OFF), spindle override value (%) is SOVR, and S command data's maximum value is "10":

$$\text{S command data} = \frac{\text{S command}}{\text{Slimt2}} \times \frac{\text{SOVR}}{100} \times 10$$

- Specifically, when S1300 command is executed with the S command output (maximum 10V), Slimt2 is "2000", and the spindle override is "100%":

$$\text{S command output} = \frac{1300}{2000} \times \frac{100}{100} \times 10 \text{ (V)} = 6.5 \text{ (V)}$$

- The S command is clamped with a value of Smaxn (n = 1 to 4).
In the same state as the previous example, the S command output when Smax2 is "1000" is:

$$\text{S command output} = \frac{1000}{2000} \times \frac{100}{100} \times 10 \text{ (V)} = 5.0 \text{ (V)}$$

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Increase holding power of spindle	EXOBS	Y1893	Y18F3	Y1953	Y19B3	Y1A13	Y1A73	Y1AD3	Y1B33

[Function]

This signal is used to enable the disturbance observer of the spindle drive unit to increase the spindle torque up.

[Operation]

- (1) Confirm the spindle is stopped and turn this signal ON.
- (2) Turning ON this signal enables the disturbance observer.
- (3) When the spindle holding force gets high enough to execute the cutting, NC outputs the "Holding power of spindle increased" signal (EXOFN).
- (4) To cancel the increase holding power of spindle, confirm the spindle is stopped and then turn this signal OFF.

[Related signals]

- (1) Holding power of spindle increased (EXOFN: X18B5)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle stop	SSTP	Y1894	Y18F4	Y1954	Y19B4	Y1A14	Y1A74	Y1AD4	Y1B34

[Function]

In spindle control, S command data (spindle speed) can be set to "0" by using this signal (SSTP). Usually, the signal is not used alone, but combined with the "Spindle gear shift" signal (SSFT) explained later.

[Operation]

When the "Spindle stop" signal (SSTP) is turned ON, S command data is set to "0". Analog data is restored when the signal is turned OFF.

When the "Spindle gear shift" signal (SSFT) turns ON while the "Spindle stop" signal is ON, S command data which corresponds to speed set by the spindle speed parameter is output.

The "Spindle speed override code m" (SP1 to 4) is ignored while the "Spindle stop" signal is ON.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle gear shift	SSFT	Y1895	Y18F5	Y1955	Y19B5	Y1A15	Y1A75	Y1AD5	Y1B35

[Function]

This signal is used to rotate the spindle motor at a slow and constant rotation to smoothly shift the gear stage of the spindle.

[Operation]

When the "Spindle gear shift" signal (SSFTn) is turned ON, the S command data corresponding to the shift rotation speed previously set by the parameter is output.

When gears are not engaged properly when the gear stage is shifted, turn on this signal (SSFTn) and slowly rotate the spindle (motor) to align the gear teeth

Note that, to turn this signal (SSFTn) ON, the "Spindle stop" signal (SSTPn) must be turned ON in advance.

At the same time as this signal (SSFTn), the forward run signal or the reverse run signal must be turned ON.

The shift rotation speed when the spindle gear is shifted is selected by the "Spindle gear selection code m" (Glmn). The relationship is shown in the following table.

Gear stage	Spindle gear selection code		Spindle speed at gear shift	Spindle speed limit
	GI2n	GI1n		
1	0	0	Ssift1	Slimt1
2	0	1	Ssift2	Slimt2
3	1	0	Ssift3	Slimt3
4	1	1	Ssift4	Slimt4

S command data (spindle speed data) while the "Spindle gear shift" signal (SSFTn) is ON can be calculated by the following formula.

For example, when the "Spindle gear selection code m" (Glmn) is the 1st stage ("GI1n" is OFF and "GI2n" is OFF), the spindle rotation speed data is as follows:

$$\text{Spindle rotation speed (Motor rotation speed)} = \frac{\text{Ssift1}}{\text{Slimt1}} \times \text{Maximum motor rotation speed}$$

Actual value is as follows: Spindle command final data (SBINn) = Ssift1 / Slimt1 × 4095

When the spindle command final data (SBINn) is "4095", the rotation speed of the motor becomes maximum.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle orientation	SORC	Y1896	Y18F6	Y1956	Y19B6	Y1A16	Y1A76	Y1AD6	Y1B36

[Function]

This signal is used to run the spindle motor at low speed when executing mechanical orientation(*1) during spindle control.
<Supplement>

Since most spindle drive/control units recently marketed are equipped with spindle orientation function, this signal (SORCn) is rarely used for mechanical orientation. This signal (SORCn) is used for application such as rotating the spindle by constant rotation speed.

(*1) The mechanical orientation is assumed to be in the form of orientation by performing the following operations.

- (1) Rotate the spindle at low speed.
- (2) It detects when the spindle has reached the area where such as proximity switch is used and then stops the spindle.
The spindle coasts to some extent and stops.
- (3) The position (the orientation position) is determined by hitting the pin against the spindle under the status of (2).

[Operation]

When the "Spindle orientation" signal (SORCn) is turned ON, the spindle can be rotated at the rotation speed set with the parameter in advance. Note that, to turn this signal (SORCn) ON, the "Spindle stop" signal (SSTPn) must be turned ON in advance.

At the same time as this signal (SORCn), the forward run signal or the reverse run signal is required.

The table below shows the relationship between the oriented spindle speed and the "Spindle gear selection code m" (Glmn).

Gear stage	Spindle gear selection code		Orientation spindle speed	Spindle speed limit
	GI2n	GI1n		
1	0	0	SORI	Slimt1
2	0	1		Slimt2
3	1	0		Slimt3
4	1	1		Slimt4

Spindle speed data while the "Spindle orientation" signal (SORCn) is ON can be calculated by the following formula.

For example, when the "Spindle gear selection code m" (Glmn) has a combination of "0" for "GI2n" and "1" for "GI1n", the spindle rotation speed data is as follows:

$$\text{Orientation spindle speed data (Motor rotation speed)} = \frac{\text{SORI}}{\text{Slimt2}} \times \text{Maximum motor rotation speed}$$

Actual spindle rotation speed is as follows: Spindle command final data (SBINn) = SORI / Slimt2 × 4095

When the spindle command final data (SBINn) is "4095", the rotation speed of the motor becomes maximum.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle forward run start	SRN	Y1898	Y18F8	Y1958	Y19B8	Y1A18	Y1A78	Y1AD8	Y1B38

Spindle controller (spindle drive) with high-speed serial coupling specifications:**[Function]**

When this signal turns ON, the spindle motor starts rotating in CCW direction as viewed from the shaft side.


[Operation]

When this signal is turned ON, the spindle can be rotated at the speed specified by S command (S command data) at that time.

When this signal is turned OFF, the spindle decelerates and stops.

When this signal is turned OFF during acceleration of spindle forward rotation, the acceleration is interrupted and the spindle decelerates to stop immediately.

When this signal is turned OFF during deceleration stop of spindle forward rotation, the spindle deceleration is interrupted and the acceleration starts immediately.



- Spindle decelerates to stop if this signal and the "Spindle reverse run start" signal (SRI) are turned ON at the same time. To resume forward rotation, turn OFF both signals and then turn ON this signal.
- The operation may stop even during forward rotation due to an emergency stop, spindle alarm or reset. Turn this signal OFF and ON after the "Servo ready completion" signal (SA) turns ON.
- The motor does not rotate if the S command data is "0". In this case, the motor rotates at the equivalent rotation speed every time the S command data changes.
- When the "Spindle orientation command" signal (ORC) is turned ON, an orientation takes precedence over this signal.
- Servo ON command (SRV) of the spindle control input signal is controlled by the NC side to turn ON when the spindle rotation starts and to turn OFF when the spindle decelerates to stop.

[Related signals]

- (1) Spindle reverse run start (SRI: Y1899)
- (2) Spindle orientation command (ORC: Y189E)

For spindle control with pulse train output:**[Function]**

This signal initiates the forward rotation of the spindle by outputting pulse trains for forward spindle rotation from RIO1 and RIO2.

[Operation]

When this signal is turned ON for the pulse train output spindle, the spindle starts rotating in the forward direction at the current S command speed.

In this case, the NC outputs the command without performing acceleration/deceleration.

Note that the "Spindle orientation command" signal (ORC: Y189E) becomes invalid.

[Related signals]

- (1) Spindle reverse run start (SRI: Y1899)
- (2) Spindle orientation command (ORC: Y189E)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle reverse run start	SRI	Y1899	Y18F9	Y1959	Y19B9	Y1A19	Y1A79	Y1AD9	Y1B39

Spindle controller (spindle drive) with high-speed serial coupling specifications:**[Function]**

When this signal is turned ON, the spindle motor starts rotating in CW direction as viewed from the shaft side.


[Operation]

Spindle starts running at speed specified by S command (S command data) when the signal is turned ON. (The operation of this signal is the same as the "Spindle forward run start" (SRN) except for its rotation direction.)


When this signal is turned OFF, spindle motion decelerates and stops.

When this signal is turned OFF during acceleration of spindle reverse rotation, the acceleration is interrupted and the spindle decelerates to stop immediately.

When this signal is turned OFF during deceleration to stop of spindle reverse rotation, the spindle deceleration is interrupted and the acceleration starts immediately.



- Spindle decelerates to stop if this signal and the "Spindle forward run start" signal (SRN) turn ON at the same time. To resume reverse rotation, turn OFF both signals and then turn this signal ON.
- The operation may stop even during reverse rotation due to an emergency stop, spindle alarm or reset. Turn this signal OFF and ON once after the "Servo ready completion" signal (SA) turns ON.



- The motor does not rotate if the S command data is "0". The motor rotates at the equivalent rotation speed every time the S command data changes.
- When the "Spindle orientation command" signal (ORC) is turned ON, an orientation takes precedence over this signal.
- The servo ON command (SRV) of the spindle control input signal is controlled on the NC side so that it turns ON when the spindle rotation starts and turns OFF when the spindle decelerates to stop.

[Related signals]

- (1) Spindle forward run start (SRN: Y1898)
- (2) Spindle orientation command (ORC: Y189E)

For spindle control with pulse train output:**[Function]**

This signal initiates the reverse rotation of the spindle by outputting pulse trains for reverse spindle rotation from RIO1 and RIO2.

[Operation]

When this signal is turned ON for the pulse train output spindle, the spindle starts rotating in the reverse direction at the current S command speed, when the NC outputs the command without performing acceleration/deceleration.

In this case, the NC outputs the command without performing acceleration/deceleration.

Note that "Spindle orientation command" signal (ORC: Y189E) becomes invalid.

[Related signals]

- (1) Spindle forward run start (SRN: Y1898)
- (2) Spindle orientation command (ORC: Y189E)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle torque limit 1	TL1	Y189A	Y18FA	Y195A	Y19BA	Y1A1A	Y1A7A	Y1ADA	Y1B3A
A	Spindle torque limit 2	TL2	Y189B	Y18FB	Y195B	Y19BB	Y1A1B	Y1A7B	Y1ADB	Y1B3B

[Function]

This signal is for the spindle controller (spindle drive) with high-speed serial coupling specifications. When this signal is turned ON, the output torque of the spindle motor can be temporarily reduced to rotate the motor.

This signal is used for mechanical spindle orientation and gear shift.


[Operation]

There are two types of torque limit signals: the "Spindle torque limit 1" (TL1) and the "Spindle torque limit 2" (TL2).

Torque limit ratio is determined depending on the combination of the "Spindle torque limit 1" (TL1) and the "Spindle torque limit 2" (TL2), and the output torque decreases accordingly.

Signal selection	Spindle torque limit (TL1)	Spindle torque limit (TL2)	Note
Torque limit invalid	0	0	
Torque limit 001	1	0	Limits with value of the spindle parameter SP065
002	0	1	Limits with value of the spindle parameter SP066
003	1	1	Limits with value of the spindle parameter SP067

(Example) When TL1 is "1", TL2 is "1", and SP067 is "50"

**Note**

- (1) This signal is valid only for systems that are high-speed serially coupled to the spindle controller.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y^{***})


Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle forward run index	WRN	Y189C	Y18FC	Y195C	Y19BC	Y1A1C	Y1A7C	Y1ADC	Y1B3C

[Function]

This signal is used for the spindle forward run index in multi-point indexing.

[Operation]**<Multi-point indexing>**







- This signal turns ON after the "Spindle in-position" signal (ORAO) is output.
- Indexing can be carried out continuously by turning this signal ON and OFF while the "Spindle orientation command" signal (ORC) is ON.
- When the "Spindle orientation command" signal (ORC) is turned ON and this signal is turned ON before the "Spindle in-position" signal (ORAO) is output, first, the "Spindle orientation command" signal (ORC) turns ON, and the orientation is completed with the read "Multi-point orientation position data" (R7009). Then, the spindle is indexed to the read position command value when this signal is ON.
If the position command value is the same when the "Spindle orientation command" (ORC) is ON and when this signal is ON, the indexing operation is not carried out.
- The index position command value is read at the rising edge of this signal. Therefore, the stop position does not change even if the index position command value is changed after this signal is input.
- Even if this signal is turned OFF while the "Spindle orientation command" (ORC) is ON, the spindle will continue to stop at the position before this signal was turned OFF. Even if this signal is turned OFF during the indexing operation, the spindle stops at the position command value read at the rising edge of this signal.
- If the stop point and indexing position command value are close to each other (within the in-position range), the indexing operation may be carried out without turning OFF the "Spindle in-position" signal (ORAO).
- If the "Spindle orientation command" signal (ORC) is turned OFF during indexing operation or stop, the servo lock turns OFF and the motor coasts. Orientation must be carried out again the next time the indexing operation is performed.



4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

<Indexing operation according to encoder installation direction>

	Case 1	Case 2
Installation method		
Indexing		
Orienting		

Note

- (1) Case 1 above applies when using the motor built-in encoder with Z-phase.

[Related signals]

- (1) Multi-point orientation position data (R7009)
- (2) Spindle in-position (ORAO: X188E)
- (3) Spindle orientation command (ORC: Y189E)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle reverse run index	WRI	Y189D	Y18FD	Y195D	Y19BD	Y1A1D	Y1A7D	Y1ADD	Y1B3D

[Function]

This signal is used for the spindle reverse run index in multi-point indexing.

[Operation]

The operation is the same as forward run indexing, except that the direction is different. Refer to the section on "Spindle forward run index".

[Related signals]

- (1) Spindle forward run index (WRN: Y189C)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle orientation command	ORC	Y189E	Y18FE	Y195E	Y19BE	Y1A1E	Y1A7E	Y1ADE	Y1B3E

[Function]

When this signal is turned ON, the spindle can be positioned at the specified indexing position.

[Operation]

If the "Spindle orientation command" signal (ORC) turns ON while the spindle is rotating or stopped, the spindle starts orientation (stops at set position). When the positioning is completed at the specified position, the "Spindle in-position" signal (ORAO) is output and the orientation is completed.

While oriented spindle is at a standstill, the spindle is in the servo lock state. Servo lock is released when the "Spindle orientation command" signal (ORC) is turned OFF. While the servo lock is required, keep the "Spindle orientation command" signal turned ON.

The encoder or proximity switch method can be used for orientation.


The orientation rotation direction is determined with the parameters.

The orientation stop position is determined by the Z-phase for the encoder method, and by the sensor installation position for the proximity switch method. The stopping position can be changed with the following items when the encoder method is used.

- ♦ By parameters (position shift amount)
- ♦ By multi-point orientation position data (data specification by R7009) value

The multi-point orientation position data by the parameter and R7009 is added.

The timing chart for basic orientation is shown below.

**Note**

- (1) The "Spindle orientation command" (ORC) takes precedence over the "Spindle forward run start" signal (SRN) and the "Spindle reverse run start" signal (SRI).
- (2) This signal is valid only for systems that are high-speed serially coupled to the spindle controller.

[Related signals]

- (1) Multi-point orientation position data (R7009)
- (2) Spindle in-position (ORAO: X188E)
- (3) Spindle 2nd in-position (ORAO2: X1888)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	L coil selection	LRSL	Y189F	Y18FF	Y195F	Y19BF	Y1A1F	Y1A7F	Y1ADF	Y1B3F

[Function]

This signal is used to select the low-speed coil in the spindle coil changeover function.

[Operation]

The high-speed coil and low-speed coil are changed over only with the "L coil selection" (LRSL) in the 2-step coil changeover specification. The high-speed coil, middle-speed coil and low-speed coil are changed over with the combination of the "L coil selection" (LRSL) and the "M coil selection" (LRSM) in the 3-step coil changeover specification.

Note

- (1) The coil is not changed over during the position loop control mode even if this signal is changed.
The coil selected immediately before the position loop control mode is entered is retained.

<2-step coil changeover>

Selected coil	L coil selection (LRSL)	In L coil selection (LCSA)
High-speed (H)	OFF	OFF
Low-speed (L)	ON	ON

<3-step coil changeover>

Selected coil	L coil selection (LRSL)	M coil selection (LRSM)	In L coil selection (LCSA)	In M coil selection (MCSA)
High-speed (H)	OFF	OFF	OFF	OFF
Middle-speed (M)	OFF	ON	OFF	ON
Low-speed (L)	ON	OFF	ON	OFF
	ON	ON	ON	ON

[Related signals]

- (1) M coil selection (LRSM: Y18A6)
 (2) In L coil selection (LCSA: X188F)
 (3) In M coil selection (MCSA: X189E)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle position control (Spindle/C axis control): C axis selection	CMOD	Y18A5	Y1905	Y1965	Y19C5	Y1A25	Y1A85	Y1AE5	Y1B45

[Function]


When the program command method ("#3129 cax_spec/bit0" is set to "1") is selected for the spindle of the spindle position control, this signal can be used to switch between the C axis mode and spindle mode during manual operation.

[Operation]

The C axis mode is entered when the "C axis selection" signal turns ON, and the spindle mode is entered when this signal turns OFF.

Note

- (1) This signal is valid only when the program command method is selected for spindle position control.
- (2) The "Spindle position control (Spindle/C axis control): C axis mode ON" signal (SVMD), which gives the mode information during spindle position control in the program command method, is not notified when switching is performed by selecting the C axis.



4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	M coil selection	LRSM	Y18A6	Y1906	Y1966	Y19C6	Y1A26	Y1A86	Y1AE6	Y1B46

[Function]

This signal is used to select the middle-speed coil in the 3-step coil changeover specification of the spindle coil changeover function.

[Operation]

The coil is selected depending on the combination of this signal and the "L coil selection" (LRSL).

Note

- (1) The coil is not changed over during the position loop control mode even if this signal is changed. The coil selected immediately before the position loop control mode is entered is retained.

Selected coil	L coil selection (LRSL)	M coil selection (LRSM)	In L coil selection (LCSA)	In M coil selection (MCSA)
High-speed (H)	OFF	OFF	OFF	OFF
Middle-speed (M)	OFF	ON	OFF	ON
Low-speed (L)	ON	OFF	ON	OFF
	ON	ON	ON	ON

[Related signals]

- (1) L coil selection (LRSL: Y189F)
- (2) In L coil selection (LCSA: X188F)
- (3) In M coil selection (MCSA: X189E)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)


Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle selection	SWS	Y18A8	Y1908	Y1968	Y19C8	Y1A28	Y1A88	Y1AE8	Y1B48

[Function]

The spindle to which the S command for the spindle is output is selected when the multi-spindle control II is valid.

0: Not select

1: Select

[Operation]

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

When the "Spindle selection" (SWS) and the "Spindle command selection" (SLSP) are input in advance through different blocks, the S command to the spindle is output as a rotation speed command for the selected spindle. The selected spindle rotates at the output rotation speed. The spindles which were deselected by turning OFF the "Spindle selection" signal (SWS) continue to rotate at the same speed as the rotation speed immediately before the deselection. This allows each spindle to be rotated simultaneously at a different rotation speed. The "Spindle command selection" signal is used to select from which part system each spindle receives the S command.

[Caution]

Even though the "Spindle selection" (SWS) or the "Spindle command selection" (SLSP) is performed with an M command given in the same block as an S command, the spindle selection command (spindle rotation speed) is not updated.

[Related signals]

- (1) Spindle command selection (SLSP: R7002)
- (2) Spindle stop (SSTP: Y1894)
- (3) Spindle enable (ENB: X18A0)
- (4) Encoder selection (R2567)
- (5) Spindle forward run start (SRN: Y1898)
- (6) Spindle reverse run start (SRI: Y1899)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle rotation reversal	SPRR	Y18AA	Y190A	Y196A	Y19CA	Y1A2A	Y1A8A	Y1AEA	Y1B4A

[Function]

This signal is for the spindle controller (spindle drive). This signal can reverse the rotation signals of the spindle (the "Spindle forward run start" signal (SRN: Y1898) and the "Spindle reverse run start" signal (SRI: Y1899)).

This signal is valid only when the "Spindle rotation direction switch method selection" signal (SPRS: Y18AB) is ON.

[Operation]

Turning ON this signal reverses the direction of the spindle rotation command.

Rotation signal	Spindle rotation reversal (SPRR: Y18AA)	Motor rotation direction
Spindle forward run start (SRN: Y1898)	OFF	Forward rotation
	ON	Reverse rotation
Spindle reverse run start (SRI: Y1899)	OFF	Reverse rotation
	ON	Forward rotation

This signal is also valid for the following functions.

- Synchronous tapping cycle command
This signal reverses the rotation direction of the tapping spindle motor.
- Spindle synchronization
This signal reverses the rotation direction of the reference and synchronized spindles.
- Tool spindle synchronization I A (Spindle-Spindle, Polygon)
This signal reverses the rotation direction of the reference and synchronized spindles.
- Tool spindle synchronization I B (Spindle-Spindle, Polygon)
This signal reverses the rotation direction of the workpiece and rotary tool spindles.
- Tool spindle synchronization I C (Spindle-NC axis, Polygon)
This signal reverses the rotation direction of the polygon-related spindles.
- Tool spindle synchronization II (Hobbing)
This signal reverses the rotation direction of the reference spindle.
- Spindle superimposition control
This signal reverses the rotation direction of the reference and superimposed spindles.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Note

- (1) While the above functions are being executed, a change of this signal is disabled for the target spindle. Thus, change this signal before executing the program command of each function.

If none of the above functions are executed, this signal is enabled immediately upon input.

- (2) This signal is disabled for the following functions and conditions.
- ♦ At zero point return in the C axis mode of spindle position control (spindle/C axis control)
 - ♦ In C axis mode of spindle position control (spindle/C axis control)
 - ♦ Spindle orientation command
 - ♦ Spindle forward run indexing/Spindle reverse run indexing
 - ♦ Turret indexing

<Synchronous tapping cycle command>

Turning ON the "Spindle rotation reversal" signal (SPRR: Y18AA) reverses the spindle rotation direction at the synchronous tapping cycle command. For the "Spindle rotation reversal" signal, the signal corresponding to the tapping spindle specified in the synchronous tapping cycle command is valid. As listed below, the motor rotation direction of the tapping spindle differs depending on the combination of the "Spindle rotation reversal" signal and "#3052 spplr" (Spindle synchronization relative polarity).

Forward tapping command

(when a synchronous tapping command is given with the unsigned D (tapping spindle No.))

Spindle rotation reversal (SPRR: Y18AA)	spplr	Spindle motor rotation in the cutting	Spindle motor rotation in the returning
OFF	0	Forward rotation	Reverse rotation
	1	Reverse rotation	Forward rotation
ON	0	Reverse rotation	Forward rotation
	1	Forward rotation	Reverse rotation

Reverse tapping command

(when a synchronous tapping command is given, the sign of the tapping spindle No. (D address) is "-")

Spindle rotation reversal (SPRR: Y18AA)	spplr	Spindle motor rotation in the cutting	Spindle motor rotation in the returning
OFF	0	Reverse rotation	Forward rotation
	1	Forward rotation	Reverse rotation
ON	0	Forward rotation	Reverse rotation
	1	Reverse rotation	Forward rotation

Note

- (1) Turn ON the "Spindle rotation reversal" signal for the tapping spindle before the synchronous tapping cycle command is issued. Even though the "Spindle rotation reversal" signal is switched from ON to OFF or from OFF to ON during the synchronous tapping cycle, the direction of the spindle motor rotation does not change.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

<Spindle synchronization control command>

Turning ON the "Spindle rotation reversal" signal (SPRR: Y18AA) reverses the rotation direction of the reference spindle motor and the synchronized spindle motor at the spindle synchronization control command. When the "Spindle rotation reversal" signal for the reference spindle is ON, the reference spindle motor rotates in the opposite direction to the spindle rotation signal (the "Spindle forward run start" signal (SRN: Y1898) or the "Spindle reverse run start" signal (SRI: Y1899)). However, the synchronized spindle motor remains in the same rotation direction as when the "Spindle rotation reversal" signal is OFF for the reference spindle. When the "Spindle rotation reversal" signal is ON for the synchronized spindle, the rotation direction of the synchronized spindle motor is reversed.

<Motion example>

Listed below are the state of the "Spindle rotation reversal" signal and the rotation direction of the reference and synchronized spindle motors when you execute a spindle synchronous control command that rotates the reference and synchronized spindles in the same direction while the forward run command is issued for the reference spindle.

Rotation signal	Reference spindle		Synchronized spindle	
	Spindle rotation reversal (SPRR: Y18AA)	Motor rotation direction	Spindle rotation reversal (SPRR: Y18AA)	Motor synchronous rotation direction
Spindle forward run start (SRN: Y1898)	Invalid	Forward rotation	Invalid	Forward rotation
			Valid	Reverse rotation
	Valid	Reverse rotation	Invalid	Forward rotation
			Valid	Reverse rotation
Spindle reverse run start (SRI: Y1899)	Invalid	Reverse rotation	Invalid	Reverse rotation
			Valid	Forward rotation
	Valid	Forward rotation	Invalid	Reverse rotation
			Valid	Forward rotation

Note

- Turn ON the "Spindle rotation reversal" signal for the reference spindle and the synchronized spindle before the spindle synchronization control command is issued.

Even though the "Spindle rotation reversal" signal is switched from ON to OFF or from ON to OFF during the spindle synchronization, the direction of the spindle motor rotation does not change.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

<Tool spindle synchronization I A (Spindle-Spindle, Polygon) command>

Turning ON the "Spindle rotation reversal" signal (SPRR: Y18AA) reverses the rotation direction of the reference spindle motor and the synchronized spindle motor at the tool spindle synchronization I A command. When the "Spindle rotation reversal" signal for the reference spindle is ON, the reference spindle motor rotates in the opposite direction to the spindle rotation signal (the "Spindle forward run start" signal (SRN: Y1898) or the "Spindle reverse run start" signal (SRI: Y1899)). However, the synchronized spindle motor remains in the same rotation direction as when the "Spindle rotation reversal" signal is OFF for the reference spindle. When the "Spindle rotation reversal" signal is ON for the synchronized spindle, the rotation direction of the synchronized spindle motor is reversed.

<Motion example>

Listed below are the state of the "Spindle rotation reversal" signal and the rotation direction of the reference and synchronized spindle motors when you execute a tool spindle synchronization control I A command that rotates the reference and synchronized spindles in the same direction while the forward run command is issued for the reference spindle.

Reference spindle			Synchronized spindle	
Rotation signal	Spindle rotation reversal (SPRR: Y18AA)	Motor rotation direction	Spindle rotation reversal (SPRR: Y18AA)	Motor synchronous rotation direction
Spindle forward run start (SRN: Y1898)	Invalid	Forward rotation	Invalid	Forward rotation
			Valid	Reverse rotation
	Valid	Reverse rotation	Invalid	Forward rotation
			Valid	Reverse rotation
Spindle reverse run start (SRI: Y1899)	Invalid	Reverse rotation	Invalid	Reverse rotation
			Valid	Forward rotation
	Valid	Forward rotation	Invalid	Reverse rotation
			Valid	Forward rotation

Note

- Turn ON the "Spindle rotation reversal" signal for the reference spindle and the synchronized spindles before the tool spindle synchronization control I A command.
Even though the "Spindle rotation reversal" signal is switched from ON to OFF or from OFF to ON during the tool spindle synchronization I A, the direction of the spindle motor rotation does not change.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

<Tool spindle synchronization I A (Spindle-Spindle, Polygon) command>

Turning ON the "Spindle rotation reversal" signal (SPRR: Y18AA) reverses the rotation direction of the workpiece spindle motor and the rotary tool spindle motor at the tool spindle synchronization I B command. When the "Spindle rotation reversal" signal for the workpiece spindle is ON, the workpiece spindle motor rotates in the opposite direction to the spindle rotation signal (the "Spindle forward run start" signal (SRN: Y1898) or the "Spindle reverse run start" signal (SRI: Y1899)). At this time, the synchronized rotation direction of the rotary tool spindle motor remains the same as when the "Spindle rotation reversal" signal for the workpiece spindle is OFF. When the "Spindle rotation reversal" signal for the rotary tool spindle is ON, the synchronized rotation direction of the rotary tool spindle motor is reversed.

<Motion example>

Listed below are the state of the "spindle rotation reversal" signal and the rotation direction of the workpiece and rotary tool spindle motors when you execute a tool spindle synchronization control I B command that rotates the workpiece and rotary tool spindles in the same direction while the forward run command is ON for the workpiece spindle.

Workpiece spindle			Synchronized spindle	
Rotation signal	Spindle rotation reversal (SPRR: Y18AA)	Motor rotation direction	Spindle rotation reversal (SPRR: Y18AA)	Motor synchronous rotation direction
Spindle forward run start (SRN: Y1898)	Invalid	Forward rotation	Invalid	Forward rotation
			Valid	Reverse rotation
	Valid	Reverse rotation	Invalid	Forward rotation
			Valid	Reverse rotation
Spindle reverse run start (SRI: Y1899)	Invalid	Reverse rotation	Invalid	Reverse rotation
			Valid	Forward rotation
	Valid	Forward rotation	Invalid	Reverse rotation
			Valid	Forward rotation

Note

- Turn ON the "Spindle rotation reversal" signal for the workpiece spindle and rotary tool spindle before the tool spindle synchronization control I B command is issued. Even though the "Spindle rotation reversal" signal is switched from ON to OFF or from OFF to ON while the tool spindle synchronization IB is being executed, the direction of the spindle motor rotation does not change.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

<Tool spindle synchronization II (hob machining) command>

Turning ON the "Spindle rotation reversal" signal (SPRR: Y18AA) reverses the rotation direction of the reference spindle motor at the tool spindle synchronization II command. When the "Spindle rotation reversal" signal for the reference spindle is ON, the reference spindle motor rotates in the opposite direction to the spindle rotation signal (the "Spindle forward run start" signal (SRN: Y1898) or the "Spindle reverse run start" signal (SRI: Y1899)). At this time, the rotation direction of the C axis motor remains the same rotation direction as when the "Spindle rotation reversal" signal for the reference spindle of the spindle synchronization control and spindle superimposition control is OFF.

<Motion example>

Listed below are the state of the "spindle rotation reversal" signal and the rotation direction of the reference and synchronized spindle motors when you execute a tool spindle synchronization control II command that rotates the C axis motor to CCW direction in the reference spindle motor forward run while the forward run command is issued for the reference spindle.

Reference spindle			C axis
Rotation signal	Spindle rotation reversal (SPRR: Y18AA)	Motor rotation direction	Motor synchronous rotation direction
Spindle forward run start (SRN: Y1898)	Invalid	Forward rotation	CCW
	Valid	Reverse rotation	
Spindle reverse run start (SRI: Y1899)	Invalid	Reverse rotation	CW
	Valid	Forward rotation	

Note

- (1) Select the "Spindle rotation reversal" signal for the reference spindle before the tool spindle synchronization control II command is issued. Even though the "Spindle rotation reversal" signal is switched from ON to OFF or from OFF to ON while the tool spindle synchronization II is being executed, the direction of the spindle motor rotation does not change.

<Spindle superimposition control command>

Turning ON the "Spindle rotation reversal" signal (SPRR: Y18AA) reverses the rotation direction of the workpiece spindle motor and the rotary tool spindle motor at the spindle superimposition control command. When the "Spindle rotation reversal" signal for the reference spindle is ON, the reference spindle motor rotates in the opposite direction to the spindle rotation signal (the "Spindle forward run start" signal (SRN: Y1898) or the "Spindle reverse run start" signal (SRI: Y1899)). At this time, the synchronized rotation direction of the superimposed spindle motor remains the same as when the "Spindle rotation reversal" signal for the reference spindle is OFF. The superimposed spindle motor for the spindle rotation signal of the superimposed spindle (the "Spindle forward run start" signal (SRN: Y1898) or "Spindle reverse run start" signal (SRI: Y1899)) rotates in the same direction as the command. When the "Spindle rotation reversal" signal for the superimposed spindle is ON, the rotation direction of the superimposed spindle motor rotates in the opposite direction. The superimposed spindle motor for the spindle rotation signal of the superimposed spindle (the "Spindle forward run start" signal (SRN: Y1898) or "Spindle reverse run start" signal (SRI: Y1899)) rotates in the opposite direction to the command.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

<Motion example>

Listed below are the state of the "Spindle rotation reversal" signal and the rotation direction of the reference spindle motor and superimposed spindle motor when the spindle superimposition control command in which the reference spindle motor and superimposed spindle motor rotate synchronously in the same direction at the time of the reference spindle forward rotation command.

Reference spindle			Superimposed spindle			
Rotation signal	Spindle rotation reversal (SPRR: Y18AA)	Motor rotation direction	Spindle rotation reversal (SPRR: Y18AA)	Motor synchronous rotation direction (Synchronous rotation for the reference spindle)	Rotation signal	Motor rotation direction (Rotation command for the superimposed spindle)
Spindle forward run start (SRN: Y1898)	Invalid	Forward rotation	Invalid	Forward rotation	Spindle forward run start	Forward rotation
					Spindle reverse run start	Reverse rotation
			Valid	Reverse rotation	Spindle forward run start	Reverse rotation
					Spindle reverse run start	Forward rotation
	Valid	Reverse rotation	Invalid	Forward rotation	Spindle forward run start	Forward rotation
					Spindle reverse run start	Reverse rotation
			Valid	Reverse rotation	Spindle forward run start	Reverse rotation
					Spindle reverse run start	Forward rotation
Spindle reverse run start (SRI: Y1899)	Invalid	Reverse rotation	Invalid	Reverse rotation	Spindle forward run start	Forward rotation
					Spindle reverse run start	Reverse rotation
			Valid	Forward rotation	Spindle forward run start	Reverse rotation
					Spindle reverse run start	Forward rotation
	Valid	Forward rotation	Invalid	Reverse rotation	Spindle forward run start	Forward rotation
					Spindle reverse run start	Reverse rotation
			Valid	Forward rotation	Spindle forward run start	Reverse rotation
					Spindle reverse run start	Forward rotation

Note

- Turn ON the "Spindle rotation reversal" signal for the reference spindle and the superimposed spindle before the spindle superimposition control command is issued. Even though the "Spindle rotation reversal" signal is switched from ON to OFF or from OFF to ON during the spindle superimposition control, the direction of the spindle motor rotation does not change.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle rotation direction switch method selection	SPRS	Y18AB	Y190B	Y196B	Y19CB	Y1A2B	Y1A8B	Y1AEB	Y1B4B

[Function]

This signal is used to select the method to reverse the rotation signals (forward run start and reverse run start) of the spindle.

[Operation]

Depending on the status of this signal, the spindle rotation signal (forward run start or reverse run start) can be switched to the opposite direction by "#3127 SPECSP/bit3" (Spindle specification/Spindle rotation direction) or the "Spindle rotation reversal" signal (SPRR: Y18AA).

OFF: Switched by "#3127 SPECSP/bit3" (Spindle specification/Spindle rotation direction).

ON: Switched by the "Spindle rotation reversal " signal (SPRR: Y18AA).

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	PLC coil changeover	MPCSL	Y18AF	Y190F	Y196F	Y19CF	Y1A2F	Y1A8F	Y1AEF	Y1B4F

[Function]

When the coil changeover is the NC internal process, the coil changeover with the PLC signal can be performed with this signal.

[Operation]

If the coil changeover is the NC internal process, the NC internal process selection is interrupted and changed to the selection with the PLC signal when this signal is turned ON.

The coil changeover in the NC internal process and the coil changeover via the PLC are changed over with the parameter "#1239 set11/bit0".

0: Via PLC

1: NC internal process

<H/L coil changeover>

- The L -> H coil changeover is changed over at the same time when the H coil selection is entered.
- The H -> L coil changeover is not changed over during the "Speed detection" signal (VRO) OFF even if the L coil selection is entered. This is changed over after the "Speed detection" signal (SD) is turned ON.

<H/M/L coil changeover>

- The L -> M coil changeover is changed over at the same time when the M coil selection is entered.
- The L -> H coil changeover is changed over at the same time when the H coil selection is entered.
- The M -> H coil changeover is changed over at the same time when the M coil selection is entered.
- The H -> M coil changeover is not changed over during the "Speed detection 2" signal (SD2) OFF even if the M coil selection is entered. The coil changeover is changed over after the "Speed detection 2" signal (SD2) is turned ON.
- The H -> L coil changeover is not changed over during the "Speed detection" signal (VRO) OFF even if the L coil selection is entered. The coil changeover is changed over after the "Speed detection" signal (VRO) is turned ON.
- The M -> L coil changeover is not changed over during the "Speed detection" signal (VRO) OFF even if the L coil selection is entered. The coil changeover is changed over after the "Speed detection" signal (VRO) is turned ON.

Note

- (1) This signal must be turned ON after the "L coil selection" signal (LRSL)/"M coil selection" signal (LRSM) has been decided. The NC internal changeover process is entered when this signal is turned OFF, so note the spindle rotation speed.

[Related signals]

- (1) L coil selection (LRSL: Y189F)
- (2) M coil selection (LRSM: Y18A6)
- (3) In L coil selection (LCSA: X188F)
- (4) In M coil selection (MCSA: X189E)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle synchronization	SPSY	Y18B0	Y1910	Y1970	Y19D0	Y1A30	Y1A90	Y1AF0	Y1B50

[Function]

The spindle synchronous control mode is entered by turning this signal ON.

[Operation]

The spindle synchronous control mode is entered by inputting the "Spindle synchronous control" signal (SPSY). During the spindle synchronous control mode, the synchronized spindle is controlled in synchronization with the rotation speed commanded for the reference spindle.

Set the reference spindle, synchronized spindle and rotation direction beforehand.

Device No.	Signal name	Abbrev.	Explanation
R7016	Spindle synchronous control reference spindle selection	-	Select the spindle to be controlled as the reference spindle from the serially connected spindles. (0: 1st spindle, 1: 1st spindle, 2: 2nd spindle, 3: 3rd spindle, 4: 4th spindle, 5: 5th spindle, 6: 6th spindle) <Note> • Spindle synchronization control will not take place if a spindle not connected in serial is selected. • When "0" is designated, the 1st spindle will be controlled as the reference spindle.
R7017	Spindle synchronous control synchronized spindle selection	-	Select the spindle to be controlled as the synchronized spindle from the serially connected spindles. (0: 2nd spindle), 1: 1st spindle, 2: 2nd spindle, 3: 3rd spindle, 4: 4th spindle, 5: 5th spindle, 6: 6th spindle <Note> • When a spindle that is not serially connected is selected or if the same spindle as the reference spindle is selected, spindle synchronous control will not be executed. • When "0" is designated, the 2nd spindle will be controlled as the synchronized spindle.
Y18B2	Spindle synchronous rotation direction	-	Designate the rotation direction for the reference spindle and synchronized spindle during spindle synchronous control. 0: Synchronized spindle rotates in the same direction as the reference spindle. 1: The synchronized spindle rotates in the reverse direction of the reference spindle.

[Related signals]

- (1) In spindle synchronization (SPSYN1: X18A8)
- (2) Spindle rotation speed synchronization completion (FSPRV: X18A9)
- (3) Spindle synchronous rotation direction (SPSDR: Y18B2)
- (4) Spindle phase synchronization (SPPHS: Y18B1)
- (5) Spindle phase synchronization completion (FSPPH: X18AA)
- (6) Spindle synchronization: Reference spindle selection (R7016)
- (7) Spindle synchronization: Synchronized spindle selection (R7017)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle phase synchronization	SPPHS	Y18B1	Y1911	Y1971	Y19D1	Y1A31	Y1A91	Y1AF1	Y1B51

[Function]


Spindle phase synchronization starts when this signal is turned ON during the spindle synchronous control mode.

[Operation]

Spindle phase synchronization starts when the "Spindle phase synchronous control" signal (SPPHS) is input during the spindle synchronous control mode. The "Spindle phase synchronization completion" signal is output when the value reached the spindle phase synchronization attainment level setting value (#3051 spplv).

Note

(1) This signal is ignored even if it is turned ON during a mode other than the spindle synchronous control mode.



(*1) This signal is turned OFF once to change the rotation speed during phase synchronization.

[Related signals]

- (1) In spindle synchronization (SPSYN1: X18A8)
- (2) Spindle rotation speed synchronization completion (FSPRV: X18A9)
- (3) Spindle synchronization (SPSY: Y18B0)
- (4) Spindle synchronous rotation direction (SPSDR: Y18B2)
- (5) Spindle phase synchronization completion (FSPPH: X18AA)
- (6) Spindle synchronization: Phase shift amount (R7018)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle synchronous rotation direction	SPSDR	Y18B2	Y1912	Y1972	Y19D2	Y1A32	Y1A92	Y1AF2	Y1B52

[Function]

The rotation direction of the synchronized spindle is designated with this signal. Select whether the direction is the same as or the reverse of the reference spindle.

[Operation]

Designate the rotation direction of the reference spindle and synchronized spindle during spindle synchronous control.

0: Synchronized spindle rotates in same direction as reference spindle.

1: Synchronized spindle rotates in reverse direction of reference spindle.

[Related signals]

- (1) In spindle synchronization (SPSYN1: X18A8)
- (2) Spindle rotation speed synchronization completion (FSPRV: X18A9)
- (3) Spindle synchronization (SPSY: Y18B0)
- (4) Spindle phase synchronization (SPPHS: Y18B1)
- (5) Spindle phase synchronization completion (FSPPH: X18AA)
- (6) Spindle synchronization: Phase shift amount (R7018)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Phase shift calculation request	SSPHM	Y18B3	Y1913	Y1973	Y19D3	Y1A33	Y1A93	Y1AF3	Y1B53


[Function]

This signal requests that the phase error of the reference spindle during rotation synchronization be calculated and saved in the NC memory.

[Operation]

The phase error of the reference spindle and synchronized spindle is saved in the NC memory when this signal is ON and the rotation synchronization command's (with no R address command) spindle synchronization is completed (when the "Spindle rotation speed synchronization completion" signal is turned ON).

This signal turns ON when the spindle rotation is stopped before the rotation synchronization command.

**Note**

- (1) The phase cannot be aligned when calculating the phase shift.
To perform the phase alignment, cancel the spindle synchronization once.
- (2) If the handle mode is selected as the manual operation mode, the synchronized spindle cannot be rotated with the handle.

[Related signals]

- (1) Phase offset request (SSPHF: Y18B4)
- (2) Spindle synchronization: Phase error/Hob axis delay angle (R6516)
- (3) Spindle synchronization: Phase offset data (R6518)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Phase offset request	SSPHF	Y18B4	Y1914	Y1974	Y19D4	Y1A34	Y1A94	Y1AF4	Y1B54

[Function]

This signal requests that the phase be aligned to the value obtained by adding the value commanded with the phase synchronization command's R address to the phase error of the reference spindle and synchronized spindle saved with the "Phase shift calculation request" signal (SSPHM).

[Operation]

If phase synchronization is commanded (with R address command) while this signal is ON, the reference spindle and synchronized spindle phases will be aligned to attain the phase error obtained by adding the value commanded with the R address command to the phase error of the reference spindle and synchronized spindle saved in the NC memory.

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the synchronized spindle's signal when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) Phase shift calculation request (SSPHM: Y18B3)
- (2) Spindle synchronization: Phase error/Hob axis delay angle (R6516)
- (3) Spindle synchronization: Phase offset data (R6518)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Error temporary cancel	SPDRPO	Y18B5	Y1915	Y1975	Y19D5	Y1A35	Y1A95	Y1AF5	Y1B55

[Function]

This signal cancels the error caused by the speed fluctuation when the chuck is closed.

When the chuck is closed, the speed will fluctuate due to external causes. An error will occur between the reference spindle's position and the synchronized spindle's position due to this speed fluctuation. This signal is used to cancel this error. (If spindle synchronization is attempted when closing the chuck without canceling this error, torsion could occur.)

[Operation]

The error between the reference spindle's position and synchronized spindle's position is saved when this signal changes from OFF to ON. The saved error is canceled and the spindle is synchronized while this signal is ON. (Even if the chuck close signal is OFF, the error will be canceled while the "Error temporary cancel" signal is ON.)

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the synchronized spindle's signal when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".
- (3) Turn this signal ON after the chucks on both the reference spindle side and synchronized spindle side have closed and grasped the workpiece.
- (4) Turn this signal OFF when the either the reference spindle side or synchronized spindle side chuck is open.

(Example)

- (1) Close the reference spindle side chuck.
- (2) Start spindle synchronization (G114.1).
- (3) Close the synchronized spindle side chuck.
(The speed will fluctuate due to external causes at this time, and an error occurs.)
- (4) Using the "Chuck close confirmation" signal (SPCMP), check that the chucks are closed.
- (5) Turn the "Error temporary cancel" signal (SPDRPO) ON, and cancel the error.
- (6) Execute machining with spindle synchronous control.
- (7) Open the chuck on the synchronized spindle side.
- (8) Using the "Chuck close confirmation" signal (SPCMP), check that the chuck is opened.
- (9) Turn the "Error temporary cancel" signal (SPDRPO) OFF, and stop the error cancellation.

[Related signals]

- (1) In spindle synchronization (SPSYN1: X18A8)
- (2) Spindle rotation speed synchronization completion (FSPRV: X18A9)
- (3) Spindle phase synchronization completion (FSPPH: X18AA)
- (4) Chuck close confirmation (SPCMP: X18AC)
- (5) Chuck close (SPCMPC: Y18B9)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle synchronization/superimposition cancel	SPSYC	Y18B8	Y1918	Y1978	Y19D8	Y1A38	Y1A98	Y1AF8	Y1B58

[Function]

This signal is used to cancel the spindle synchronous control and spindle superimposition with the G114.n command.

The spindle synchronous control with the "Spindle synchronization" signal (Y18B0) is not canceled.

[Operation]

The spindle synchronous control mode and spindle superimposition can be canceled by turning this signal ON.

Note

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the signal of the hob axis during hobbing, or refer to the signal of the synchronized spindle during other machining when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".

[Related signals]

- (1) In spindle synchronization (SPSYN1: X18A8)
- (2) Spindle rotation speed synchronization completion (FSRPV: X18A9)
- (3) Spindle phase synchronization completion (FSPPH: X18AA)
- (4) Spindle phase synchronization (SPPHS: Y18B1)
- (5) Spindle synchronization: Phase error 1 (R6522)
- (6) Spindle synchronization: Phase error 2 (R6523)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Chuck close	SPCMPC	Y18B9	Y1919	Y1979	Y19D9	Y1A39	Y1A99	Y1AF9	Y1B59


[Function]

This signal is turned ON while the reference spindle and synchronized spindle clamp the same work.

[Operation]

The "Spindle chuck close confirmation" signal is turned ON when the "Chuck close" signal is ON.

The "Spindle chuck close confirmation" signal is turned OFF when the "Chuck close" signal is OFF.

**Note**

- (1) Refer to the signal of the 1st spindle when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "0".
- (2) Refer to the synchronized spindle's signal when the parameter "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is set to "1".
- (3) Use the "Error temporary cancel" signal only when the rotation error between the reference spindle and synchronized spindle occurs because of the "Chuck close" signal.

[Related signals]

- (1) Chuck close confirmation (SPCMP: X18AC)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Exclude spindle	SPOFF	Y18BF	Y191F	Y197F	Y19DF	Y1A3F	Y1A9F	Y1AFF	Y1B5F

[Function]

This signal commands to exclude the spindle from CNC control.

[Operation]

The corresponding spindle will be excluded from CNC control when this signal is ON.

[Related signals]

- (1) In spindle off (SPOFFA: X18B6)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle oscillation command		Y18C8	Y1928	Y1988	Y19E8	Y1A48	Y1AA8	Y1B08	Y1B68

[Function]

This signal is used to start or stop the spindle oscillation.

[Operation]

The spindle oscillation is started by turning this signal ON.

The spindle oscillation is stopped by turning this signal OFF.

[Related signals]

- (1) Spindle oscillation amplitude (R7020)
- (2) Spindle oscillation frequency (R7021)
- (3) Spindle oscillation in progress (X18C8)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Real-time tuning 1: Speed control gain changeover hold-down command	VGHLDC	Y18CA	Y192A	Y198A	Y19EA	Y1A4A	Y1AAA	Y1B0A	Y1B6A


[Function]

This signal is used to stop speed control gain switching of the real-time tuning 1 function. Speed control gain switching is stopped if this signal turns ON while this function is enabled.

[Operation]

ON: Speed control gain switching is stopped.

OFF: Speed control gain switching is not stopped.

**[Related signals]**

- (1) Real-time tuning 1: Speed control gain changeover hold-down ON (VGHLDC: X18CA)

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Operation trigger		Y1C80

[Function]

This signal is used to request the database for one of the update, delete, and extract operations.

[Operation]

The operations perform for the database at the rising edge of this signal.

The operation details follow the bitD to bitF of R14598 (DB operation selection), and operation target table follows the R14599 (Operation table selection).

[Related signals]

- (1) MES interface library: DB operation selection (R14598)
- (2) MES interface library: Operation table selection (R14599)
- (3) MES interface library: Operation trigger status (X74F)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
B	Data protection key (memory card)	*KEY_MemC	Y1C81

[Function]

This signal protects the data on the front side SD (memory card).

[Operation]

When the "Data protection key (memory card)" is turned OFF (0), the editing operation of the memory card will be prohibited.

[Caution]

- (1) If a setting is changed while the "Data protection key (memory card)" is OFF (0), "Data protect" appears in the message section of the screen.
- (2) This signal is set to ON (1) when the power is turned ON. This means that data protection has been canceled. Therefore, when the sequence program has no line to use data protection key, the signal is always turned ON (1).

[Related signals]

- (1) Data protect key 1 (*KEY1: Y708)
- (2) Data protect key 2 (*KEY2: Y709)
- (3) Data protect key 3 (*KEY3: Y70A)
- (4) Data protect key (DS) (*KEY_DS: Y1C82)

Cont.	Signal name	Abbrev.	Common (\$)
B	Data protection key (DS)	*KEY_DS	Y1C82

[Function]

This signal protects the data on the back side SD2 (DS).

[Operation]

When the "Data protection key (DS)" is turned OFF (0), the editing operation of the DS will be prohibited.

[Caution]

- (1) If a setting is changed while the "Data protection key (DS)" is OFF (0), "Data protect" appears in the message section of the screen.
- (2) This signal is set to ON (1) when the power is turned ON. This means that data protection has been canceled. Therefore, when the sequence program has no line to use data protection key, the signal is always turned ON (1).

[Related signals]

- (1) Data protect key 1 (*KEY1: Y708)
- (2) Data protect key 2 (*KEY2: Y709)
- (3) Data protect key 3 (*KEY3: Y70A)
- (4) Data protect key (memory card) (*KEY_MemC: Y1C81)

Cont.	Signal name	Abbrev.	Common (\$)
A	Buzzer sound control: Buzzer ON	BZR	Y1C83

[Function]

This signal turns ON the buzzer.

[Operation]

While this signal is turned ON, the buzzer keeps sounding.

The buzzer stops by turning OFF this signal.

Cont.	Signal name	Abbrev.	Common (\$)
A	Spindle protection: Resetting alarm of equivalent load factor over limit	EQLDWR	Y1C84

[Function]

This signal resets the warning of equivalent load factor over limit.

[Operation]

When this signal is turned ON, the operation error (M01 1120) is reset.

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Image input I/F: Screen selection	DSPCRD	Y1C85

[Function]

This signal is used to select the screen to display on the CNC display unit.

This signal is valid when the parameter "#1057 disp_input" is set to any of "2" to "4".

[Operation]

At CNC startup, regardless of the signal status, the operation follows the parameter setting.

When the PLC signal is switched, the display contents are changed accordingly.

[When the parameter #1057 is "2" or "3"]

Status of this signal	Display contents	Operation information of CNC keyboard, menu key and touch screen
OFF	Image input from the image input expansion unit	Output to the partial display screen (IPC screen or camera image).
ON	Mitsubishi Electric standard screen	Output to the CNC display unit. Not output to the partial display screen (IPC screen or camera image).

[When the parameter #1057 is "4"]

When the image input from the image input expansion unit is partially displayed, it is possible to switch whether the operation information of the CNC keyboard, menu key and touch screen is output to the partial display screen (IPC screen or camera image), depending on the PLC signal (R328/bit0).

[Caution]

(1) This signal is valid only when the image input expansion unit is connected to the CNC unit.

[Related signals]

- (1) Image input I/F: Display range (DSPSZH: R322, DSPSZV: R323)
- (2) Image input I/F: IPC screen transfer range (IPCSZH: R326, IPCSZV: R327)
- (3) Image input I/F: Behavior at key entry (DSPACT: R328/bit0)

Cont.	Signal name	Abbrev.	Common (\$)
A	External encoder 1: Position output clear request	ENC1PCLR	Y1C88

[Function]

This signal clears the "External encoder 1: Position output".

[Operation]

Input this signal as a pulse instruction.

At the rising edge of this signal, the "External encoder 1: Position output" signal (ENC1POS: ZR13020, ZR13021) is set to zero.

The external encoder position (angle) displayed in the "Machine end FB" section of the "Servo unit" on the Drive monitor screen is also set to "0" at the same time.

[Related signals]

- (1) External encoder 1: Position output (ENC1POS: ZR13020,1)

Cont.	Signal name	Abbrev.	Common (\$)
A	Image input I/F: IPC screen vertical inversion	DSPFLPV	Y1C8D
A	Image input I/F: IPC screen horizontal inversion	DSPFLPH	Y1C8E

[Function] [Operation]

The IPC screen displayed on the Mitsubishi Electric standard screen is inverted vertically or horizontally.

[Caution]

- (1) This signal is valid in the following cases.
 - The image input expansion unit is connected to the CNC unit.
 - The parameter "#1057 disp_input" is set to "4", and the IPC screen or camera image is partially displayed on the Mitsubishi Electric standard screen.

[Related signals]

- (1) Image input I/F: Screen selection (DSPCRD: Y1C85)
- (2) Image input I/F: Display range (DSPSZH: R322, DSPSZV: R323)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Laser: Laser condition change complete		Y1CA6

[Function]

This signal informs the CNC that the current machining condition is changed from the "Laser Processing Condition" screen or the "Set Laser Process Cond." screen and the specified operation is completed on the PLC side.

[Operation]


When the current machining condition is changed on the "Laser Processing Condition" screen or the "Set Laser Process Cond." screen, the "Laser condition change strobe" signal (X1CA6) turns ON.

On the PLC side, turn ON the "Laser: Laser condition change complete" signal (Y1CA6) after gas control and lens position control are completed.

When the CNC confirms that the "Laser: Laser condition change complete" signal (Y1CA6) is turned ON, the CNC turns OFF the "Laser: Laser condition change strobe" signal (X1CA6).

On the PLC side, confirm that the "Laser: Condition of laser changed strobe" signal (X1CA6) is turned OFF and then turn OFF the "Laser: Laser condition change complete" signal (Y1CA6).

The following is an example of a time chart when the "Laser: Laser condition change strobe" signal (X1CA6) is used.

**[Related signals]**

- (1) Laser: Laser condition change strobe (X1CA6)

Cont.	Signal name	Abbrev.	Common (\$)
A	Laser: Laser beam irradiation ON		Y1CA7

[Function]

This signal makes the laser oscillator to irradiate the laser.

[Operation]

When this signal is turned ON during manual operations, the laser oscillator starts laser irradiation at the rising edge of this signal.

When the laser irradiation of the laser oscillator is started by this signal, the "Laser: Laser beam irradiating" signal (X1CA7) turns ON.

When the "Laser: Laser beam irradiation ready" signal (Y1CE0) is not ON, the laser irradiation is not started even by turning ON this signal.

[Related signals]

- (1) Laser: Laser beam irradiating (X1CA7)
- (2) Laser: Laser beam irradiation ready (Y1CE0)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Reservation of tool wear compensation	TWR	Y1CB8

[Function]

The reservation of tool wear compensation function is enabled.

[Operation]

The reservation of tool wear compensation function is enabled when the power is turned ON again with the parameter "#8140 Reserve T wear com" set to "1" and this signal is turned ON.

When this signal is turned OFF, the "Reserved tool wear compensation not reflected" signal (TWNIN) does not turn ON.

The "Request for reflecting reserved tool wear compensation" signal (TWIN) cannot be used either.

[Related signals]

- (1) Request for reflecting reserved tool wear compensation (TWIN: YD0F)
- (2) Reflection of reserved tool wear compensation is complete (TWOUT: XD0F)
- (3) Reserved tool wear compensation not reflected (TWNIN: XD0E)

Cont.	Signal name	Abbrev.	Common (\$)
A	Laser: Height control		Y1CD8

[Function]

This signal starts the height control.

[Operation]

When this signal is turned ON, the approach control is performed at the rising edge of this signal, and the height control is started.

When the approach operation is completed, trace control is performed.

When this signal is turned OFF, the retract control is performed, and the height control is completed.

[Caution]

- (1) Even though the automatic machine lock or manual machine lock is valid, when the "Laser: Height control" signal (Y1CD8) is turned ON, the approach operation of the height control is performed. To prevent the approach operation during the machine lock, make a sequence program not to turn ON Y1CD8.
- (2) When the "Laser: Height control" signal (Y1CD8) is turned ON during the axis movement, the approach operation is performed after all the axes stop (*1).
(*1) It depends on the parameter "#1254 set26/bit3" (Select timing for updating axis parameter) whether it is after the axes of all part systems stop or after the axes in the part system stop.

[Related signals]

- (1) Laser: Height control in progress (X1CA0)

Cont.	Signal name	Abbrev.	Common (\$)
A	Laser: Enable height retention in height control		Y1CD9

[Function]

This signal starts the height retention control.

[Operation]

When this signal is turned ON while the "Laser: Approach in height control completed" signal (X1CA1) is ON, the height retention control is started.

When this signal is turned OFF, the approach control is started to perform the trace control.

[Related signals]

- (1) Laser: Height control (Y1CD8)
- (2) Laser: Approach in height control completed (X1CA1)

Cont.	Signal name	Abbrev.	Common (\$)
A	Laser: Laser beam irradiation ready		Y1CE0

[Function] [Operation]

This signal enables the laser oscillator to irradiate laser.

Turn ON this signal after all the processes necessary for laser irradiation are completed, for example, peripheral devices such as chiller, gas feeder, etc. are operated, emission of the laser oscillator is turned ON.

Laser irradiation is enabled when this signal is turned ON.

[Related signals]

- (1) Laser: Laser beam irradiating (X1CA7)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Laser: Axis stop time with beam ON monitoring OFF		Y1CE1

[Function] [Operation]

When the axis movement stops while the laser beam is ON, if the time set by the parameter "#90005 lsr_max_stop_t" (Maximum stop time with beam ON) has passed since the axis movement stop, the laser beam is automatically turned OFF.

By turning this signal ON, the beam irradiation can be continued even after the time set by the parameter #90005 has passed.

This signal is used to calibrate the output of the laser beam.

[Caution]

- (1) Turn this signal ON only while the output is calibrated. In the other cases, turn it OFF for safety.
- (2) The operation error (M95 9509) occurs while this signal is ON.

When this signal is ON, even if the beam is ON and the axis movement still stops after the time set by the parameter #90005 has passed, the laser beam is not turned OFF. The operation error also does not occur.

[Related signals]

- (1) Laser: Laser beam irradiation ON (Y1CA7)

4 Explanation of Interface Signals

4.3 PLC Output Signals (Bit Type: Y***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Position switch n interlock		Y1D00 to 17	Y1D20 to 37	Y1D40 to 57	Y1D60 to 77	Y1D80 to 97	Y1DA0 to B7	Y1DC0 to D7	Y1DE0 to F7

[Function]

An interlock is applied on the axis when outside the position switch range, and movement of the axis targeted by the position switch is prohibited.

[Operation]

When this signal turns ON and the axis targeted for the corresponding position switch is outside the range, an interlock is applied on the axis, and movement is prohibited. Movement is possible within the set range.

<Movement in interlock range>

♦ [For linear axis]

The axis can move only in the direction toward the position switch range. If a command is issued in the direction that moves away from the position switch range, "M01 OPERATION ERROR 0004 *" ("*" is axis name) occurs.

♦ [For rotary axis]

If axis movement is commanded in the interlock state, "M01 OPERATION ERROR 0004 *" ("*" is axis name) occurs. To move the axis, turn OFF the "Position switch interlock" signal input and cancel the interlock state. Note that even if the axis is moved away from the position switch range in this state, the interlock will not be applied.

<Coasting distance>

The coasting distance when outside the position switch range by axis movement depends on the commanded speed and parameter setting.

<Coasting distance for position switch interlock>

Pcheck	<check>	Coasting distance
0	0	The acceleration/deceleration delay is added to the movement distance within the commanded speed $\times 0.060$ [s] or less.
0	1	Same as the above distance. (When Pcheck is "0", the <check> setting is invalid.)
1	0	Within commanded speed $\times 0.015$ [s] or less (During manual mode, commanded speed $\times 0.030$ [s] or less)
1	1	Acceleration/deceleration delay or position loop gain delay is added to above distance.

[Caution]

- (1) When the axis moves from the set range to outside the set range, the coasting distance until the axis stops depends on the method switching of the position switch.
- (2) The position switch interlock is invalid for a reference position return incomplete axis (incremental specifications), absolute position initialization incomplete axis, and an axis for which absolute position initialization is being carried out.
- (3) The position switch range is judged with the machine coordinate system. Thus, the inclined axis is judged with the oblique (actual axis).
If the basic axis moves with a command issued for the inclined axis, the axis interlock will not be applied even if the basic axis moves out of the position switch range. (The interlock is valid only for the commanded axis.)

[Related signals]

- (1) Position switch (PSW1 to 24: X1D00 to X1D17)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Analog output m	AOm	R200 to 3

[Function]


An analog voltage can be output from the designated connector on the remote I/O unit with analog output or built-in AI/AO by setting designated data in the file registers.

[Operation]

Analog voltage signal (for speed control) can be output by setting signed binary data to the corresponding file register.

The analog output interface is explained below.

Channel	File register (R)
AO1	R200
AO2	R201
AO3	R202
AO4	R203



Output voltage : -10V to +10V ($\pm 5\%$)
 Resolution : $2^{-12} (1/4095) \times \text{Fullscale (10V)}$
 Load conditions : 10kohm resistance load (standard)
 Output impedance: 220ohm

$$\text{Output voltage} = \frac{-1000}{4095} \times 10\text{V} = -2.44\text{V}$$

<Relation of file register details and output voltage>

Rn n = 100 to 103															
2^{15}	2^{14}	2^{13}	2^{12}	2^{11}	2^{10}	2^9	2^8	2^7	2^6	2^5	2^4	2^3	2^2	2^1	2^0
1	1	1	1	1	1	0	0	0	0	0	1	1	0	0	0

When -1000
(FC18 with hexadecimal)

The output voltage is

4 Explanation of Interface Signals










4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Displayed screen No.		R210

[Function] [Operation]

The No. of the screen displayed by the screen change key is registered.

The following table shows the screen change keys and the corresponding Nos. to be registered.

Screen change key	Displayed screen No. to be set in the R register
 (MONITOR) Monitor	1
 (SETUP) Setup	2
 (EDIT) Edit	3
 (DIAGN) Diagnosis	4
 (MAINTE) Maintenance	5
 SFP	9*
 F0	10
 Window display	13*
 Window selection	14*

*: M8V only

[Caution]

- (1) This register is not retained after the power is turned OFF. The data is initialized to "0" when the power is turned ON.
- (2) The displayed screen No. is not set in this register when the PLC onboard or the custom application (EXE) is closed without the screen change keys (e.g., [x] or [Close] button). When the standard screen is displayed in the forefront after the application has been closed, the displayed screen No. on the standard screen is set in this register.


4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	KEY OUT 1		R212

[Function]

When this signal is used, key data can be entered on the user PLC side instead of the CNC keyboard.

[Operation]

- (1) Key data is set to file registers R8 and R212 at the head of user PLC main program.
- (2) The user PLC refers to the key data and performs required processing.
- (3) The user PLC sets the key data which matches the keyboard used at that time in R212.
- (4) The controller processes the valid key data according to the settings of R8 and R212 after the main program of user PLC has been processed.

[Related signals]

- (1) KEY IN 1 (R8)

Cont.	Signal name	Abbrev.	Common (\$)
A	Power OFF indication Y device No.		R215

[Function] [Operation]

This signal sets the Y device No. that notify the power OFF of the control unit.

The setting range is 0 to 5FF (HEX).

Set the Y device No. taking the hardware configuration into consideration.

Designate binary data for Y device No.

When a Y device No. outside the setting range is set, this signal will not be output to the Y device.

Refer to the "Automatic power OFF request" signal (Y75D) for details.

[Related signals]

- (1) Power OFF processing (X707)
- (2) Automatic power OFF request (Y75D)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Detailed screen No.		R216

[Function] [Operation]

The detailed screen No. of the screen displayed by the menu key is registered.

The following table shows the correspondence between the menu keys and the detailed screen numbers set in this register.

Monitr		Setup		Edit		Diagn		Mainte	
Monitor Screens	100	T-ofs	201	Edit	301	Config	401	Mainte	501
Search	101	T-meas	202	Check (3D)	302	Option	402	Param	502
Reserch	102	T-reg	203	Check (2D)	351	I/F dia	403	I/O	503
Edit	103	T-life	204	NAVI MILL	10001	Drv mon	404		
Trace (2D)	104	Coord	205	NAVI LATHE	10301	Mem dia	405		
Trace (3D)	152	W-meas	206	I/O	305	Alarm	406	All backup	551
Check (3D)	105	User	207			-	-	HMI config.	552
Check (2D)	151	MDI	208			-	-	Adjust S-ana	553
Cnt exp	106	Cnt set	209			-	-	To Abs pos	554
T-ofs	107	MST	210			-	-	Protect setting	555
Coord	108	T-list	211			Selfdia	411	Servo diagn	556
Cnt set	109	Pallet	212			NC Smp	412	Collect set	557
MST	110	T-Mng.	213			Safety	413	Open device	558
Modal	111	-	-					Open SRAM	559
Tree	112	Storage	215					Ext PLC link	560
Time	113	Surf	216						
Com var	114	Mac cond	217					RCE mea	562
Loc var	115	Barrier data	218						
P corr	116	E-mail	219					Home screen	601
PLC SW	117	WE mea.	220						
G92 set	118	Range	221					PLC onboard	11000
Col stp	119	History	222						
LD MTR	120								
Sp-stby	121								
TipDisp	122								
All sp	123								
Dsp sw.	(*1)								
-	-								
S-sel	126								
Next axis	(*1)								
W-shift	128								

(*1) As there is no screen for [Next axis] and [Dsp change] menu keys, use the detailed screen No. for the operation screen (100).

Custom open screen	
F0 open (compile method, interpreter method)	6000 to 7999
Menu open (compile method, interpreter method)	8000 to 9999
Menu open (execution file registration method)	20000 to 20099
F0 open (execution file registration method)	20100

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

[Caution]

- (1) This register is not retained when the power is turned OFF. The data is initialized to "0" when the power is turned ON.
- (2) When the application is terminated with a key other than the screen switching keys ([x], [Close] button, etc.) while the PLC onboard or custom application (EXE) is displayed, the displayed screen No. is not registered in this register. However, when the standard screen is displayed in the forefront after the application has been closed, the displayed screen No. on the standard screen is registered in this register.
- (3) Even though the guidance screen and the menu list screen are displayed, the display screen No. and detailed screen No. are not updated.
The previously displayed screen No. and detailed screen No. remain the same.



Cont.	Signal name	Abbrev.	Common (\$)
A	User sequence program version code		R224 to 7

[Function]

The user sequence program version can be displayed with the software version that controls the other controller on the diagnosis screen of the setting and display unit (communication terminal).

[Operation]

The ASCII code that corresponds to the character to be displayed in the version display interface is set.

<Display format and usage example>**<Program example>**

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	User sequence program version code 2		R232 to 9

[Function]

The user sequence program version can be displayed with the software version that controls the other controller on the diagnosis screen of the setting and display unit (communication terminal).


[Operation]

The ASCII code that corresponds to the character to be displayed in the version display interface is set.


<Display format and usage example>

PLC u ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ : Random alphanumeric characters are used.

Total of 14 characters



<Program example>



4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	APLC version		R240 to 3

[Function]

This signal indicates APLC software version.

[Operation]

File register R240 to R243 is as the following data.

R240 to R243 is as the following data.

(Example) BND-1003W400-A0B

(1) (2) (3)

Item		File register	Type	Example
(1)	Model function No.	R240	Binary	1003=03EBH
(2)	Serial No.	R241	Binary	400=0190H
(3)	Version	bits 7 to 0 of R242	ASCII code	A=41H
		bits F to 8 of R242	ASCII code(*1)	0=30H
		bits 7 to 0 of R243	ASCII code(*1)	B=42H
-	-	bits F to 8 of R243	Always FFH(*2)	FFH

(*1) If the version is 1-digit No., set the version in bits 7 to 0 of R242, and set "00H" in bits F to 8 of R242 and bits 7 to 0 of R243.

(*2) Always set "FFH" in bits F to 8 of R243. If "FFH" is not set, it will not be displayed correctly.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	OT ignored		R248, 9


[Function]

When the "OT ignored" signal is used, a "stroke end error" can be prevented without external wiring for the stroke end signal (remote I/O connector pin No. fixed signal) provided for each axis. The stroke end signal of the axis for which the "OT ignored" signal is set can be used for other purposes.

[Operation]

When the "OT ignored" signal is used at all times or as necessary, the stroke end signal of the corresponding control axis can be ignored.

The interface for this signal is as follows:

**Note**

- (1) The signal is applicable to (+) and (-) motion at the same time. (Ignored when it turns ON.)
- (2) "OT" is abbreviation of "Over Travel".

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	PLC axis OT ignored		R255


[Function]

When the "PLC axis OT ignored" signal is used, a "stroke end error" can be prevented without external wiring of the stroke end signal (remote I/O connector pin No. fixed signal) provided for each axis. The stroke end signal of the axis for which the "PLC axis OT ignored" signal is set can be used for other purposes.

[Operation]

When the "PLC axis OT ignored" signal is used at all times or as necessary, the stroke end signal of the corresponding control axis can be ignored.

The interface for this signal is as follows:

**Note**

- (1) The "PLC axis OT ignored" signal is applicable to "+" and "-" motion at the same time. (Ignored when it turns ON.)
- (2) "OT" is abbreviation of "Over Travel".

Cont.	Signal name	Abbrev.	Common (\$)
A	Near-point dog ignored		R272, 3

[Function]


When this signal is used, the "Near point detection" signal (remote I/O connector pin No. fixed signal) which is used for dog type reference position return can be ignored (dog not-passed state).

Furthermore, the "Near point detection" signal for an axis to which the "Near-point ignored" signal is set can be used for other applications.

[Operation]

When the signal is turned ON, the "Near point detection" signal for the corresponding control axis can be ignored.

The interface for this signal is as follows: Near-point dog is ignored when "Near-point dog ignored" signal is turned ON.



4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	PLC axis near-point dog ignored		R279

[Function]


When this signal is used, the "Near point detection" signal (remote I/O connector pin No. fixed signal) which is used for dog type reference position return can be ignored (dog not-passed state).

Furthermore, the "Near point detection" signal for an axis to which the "PLC axis near-point ignored" signal is set can be used for other applications.

[Operation]

When the signal is turned ON, the "Near point detection" signal for the corresponding control axis can be ignored.

The interface for this signal is as follows: PLC axis near-point dog is ignored when "Near-point dog ignored" signal is turned ON.




Cont.	Signal name	Abbrev.	Common (\$)
A	Speed monitor mode	SOMD	R296

[Function]

This signal executes speed monitor function for the control axis for which a valid door No. is selected with the parameter "#2118 SscDrSel" and the spindle for which a valid door No. is selected with the parameter "#3071 SscDrSelSp".

The door No. corresponds to the following bits.

**[Operation]**

NC performs as follows by turning ON the "Speed monitor mode" signal.

- (1) Checks compatibility of speed monitor parameter
- (2) Checks if NC's speed monitor parameter matches with the speed monitor parameter sent to servo drive unit and spindle drive unit.
- (3) Notifies speed monitor command to the drive unit
- (4) Executes the speed monitor function on NC
- (5) Turns ON speed monitor door open possible signal when NC receives the in speed monitor mode signal from the drive unit

The followings are performed while the speed monitor function is executed.

Item	Details
Monitoring command speed	When a command speed NC outputs to the drive unit exceeds a safety speed set with parameter, an emergency stop occurs.
Monitoring feed back speed	When a motor rotation speed sent to NC from the drive unit exceeds a safety rotation speed set with parameter, an emergency stop occurs.
Monitoring feed back position	When a difference between feedback position sent to NC from the drive unit and a position commanded by NC is large, an emergency stop occurs.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

[Caution]

- (1) Be sure to turn ON the "Speed monitor mode" signal (SOMD) after confirming deceleration of all axes.
If the "Speed monitor mode" signal (SOMD) is turned ON without deceleration, and the motor rotation speed exceeds the set speed, a speed monitor alarm will occur, resulting in an emergency stop state. Then, power of the drive section will be shut off.
- (2) Turn OFF the "Speed monitor mode" signal after confirming the door lock is OFF.
- (3) Even if the "Speed monitor mode" signal (SOMD) is turned ON while parameter error is output, speed monitoring is not initiated. Set the parameter with appropriate value, and then turn ON the "Speed monitor mode" signal (SOMD).
- (4) While the axis is being removed, it will be taken off from the watch list even if the parameters "#2313 SV113/bitF" (safety observation function) and "#13229 SP229/bitF" are ON. However, the emergency stop will occur when axis detachment is performed for all axes in the group which the door state signal is turned ON with "#2282 SV082/bitF-C" (Digital signal input selection) and "#13227 SP227/bitF-C" (Digital signal input selection). Do not remove the axis which the door state signal is to be input.

[Related signals]

- (1) Speed monitor door open possible (SMDOEN: R96)

Cont.	Signal name	Abbrev.	Common (\$)
A	Handy terminal Data area top address		R297

[Function]

The top address of the area that stores the data to be transmitted to and received from the handy terminal is set.

[Operation]

Set the R register top address on the CNC side corresponding to D0 on the handy terminal side to the "Handy terminal Data area top address" (R297), and set the number of registers required for communication to the "Handy terminal Data valid number of registers" (R298).

<Setting example>

The following is the setting value used for allocating the data from R9800 to R9849, the CNC side user area, by using 50 registers from D0 to D49 in the handy terminal side.


"9800 (0x2648)" for "Handy terminal Data area top address" (R297)

"50 (0x32)" for "Handy terminal Data valid number of registers" (R298)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

<Image drawing of internal register>



[Related signals]

- (1) Handy terminal key 1 to 45 (X1CD0 to X1CFC)
- (2) Handle pulse encoder communication connector priority (Y70D)
- (3) Handle/Incremental feed magnification code m (MP1, MP2, MP4: YC80, YC81, YC82)
- (4) Handle/incremental feed magnification method selection (MPS: YC87)
- (5) Handy terminal Data valid number of registers (R298)
- (6) Handy terminal Cause of communication error (R299)
- (7) 1st handle/incremental feed magnification (R2508, R2509)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Handy terminal Data valid number of registers		R298

[Function] [Operation]

Set the number of valid registers from D0 within the handy terminal transmission/reception area (D0 to 1023).

With CNC, the range of handy terminal transmission/reception area is the number of registers set starting from the "Handy terminal Data area top address" (R297).

Refer to the section of the "Handy terminal Data area top address" for details.

[Related signals]

- (1) Handy terminal key 1 to 45 (X1CD0 to X1CFC)
- (2) Handle pulse encoder communication connector priority (Y70D)
- (3) Handle/Incremental feed magnification code m (MP1, MP2, MP4: YC80, YC81, YC82)
- (4) Handle/incremental feed magnification method selection (MPS: YC87)
- (5) Handy terminal Data area top address (R297)
- (6) Handy terminal Cause of communication error (R299)
- (7) 1st handle/incremental feed magnification (R2508, R2509)

Cont.	Signal name	Abbrev.	Common (\$)
A	Handy terminal Cause of communication error		R299

[Function] [Operation]

For details on communication error, refer to the table below.

Hexadecimal (HEX)	Decimal (DEC)	Details
0000	0	No error
FFFE	-2	Serial port in use
FFFC	-4	Timeout terminated
FFF9	-7	Serial driver forcibly terminated
FFF6	-10	Serial driver not ready (SIO cable is disconnected)
FFF1	-15	Parity error
FFEF	-17	Number of received characters over
FFEC	-20	Flaming error, H/W error
FC18	-1000	Handy terminal data area illegal (Out of user area)

[Related signals]

- (1) Handy terminal key 1 to 45 (X1CD0 to X1CFC)
- (2) Handle pulse encoder communication connector priority (Y70D)
- (3) Handle/Incremental feed magnification code m (MP1, MP2, MP4: YC80, YC81, YC82)
- (4) Handle/incremental feed magnification method selection (MPS: YC87)
- (5) Handy terminal Data valid number of registers (R298)
- (6) Handy terminal Cause of communication error (R299)
- (7) 1st handle/incremental feed magnification (R2508, R2509)

Cont.	Signal name	Abbrev.	Common (\$)
A	Power consumption computation: Consumption of devices other than drive system	NDPC	R304, 5

[Function]

This signal sets the power consumption of devices other than drive system.

[Operation]

This data is set with the PLC.

Setting size is 2 words, Setting unit is 1 (W), Setting range is -2147483648 to 2147483647 (W)

[Caution]

- (1) When the power is turned on again, the state before the power was turned on is retained.
- (2) The positive value represents power consumption and the negative value represents power regeneration.

[Related signals]

- (1) Power consumption computation: Enable consumption accumulation 1 to 4 (IPCE1 to 4: Y724 to 7)
- (2) Power consumption computation: Accumulated consumption of devices other than drive system 1 to 4 (NDIPC1 to 4: R130 to 137)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Power consumption computation: Drive system's fixed consumption correction	DFPCC	R306, 7

[Function]

This signal sets the drive system's fixed consumption correction amount.

[Operation]

This data is set with the PLC.

With this data, the drive system's fixed consumption (base common #1464), which is set by parameter, can be adjusted by the ladder.

Setting size is 2 words, Setting unit is 1 (W), Setting range is -2147483648 to 2147483647 (W)

[Caution]

- (1) When the power is turned ON again, the state before the power was turned ON is retained.
- (2) The positive value represents power consumption and the negative value represents power regeneration.

[Related signals]

- (1) Power consumption computation: Enable consumption accumulation 1 to 4 (IPCE1 to 4: Y724 to 7)
- (2) Power consumption computation: Present consumption of entire drive system (DTPPC: R120, 1)
- (3) Power consumption computation: Accumulated consumption of entire drive system 1 to 4 (DTIPC1 to 4: R122 to 9)

Cont.	Signal name	Abbrev.	Common (\$)
A	Operator message I/F 1 to 4		R308 to R311

[Function]

The desired operator message created by the PLC development tool (personal computer) can be displayed by setting a value (binary code) in the operator message interface file register (Rn). An operator message appears on the alarm diagnosis screen of the setting display unit.

[Operation]

If table No. of previously prepared operator message table has been set to operator message interface file register, operator message can be displayed on alarm diagnosis screen. The operator message can be erased by setting interface file register to "0".

For details on displaying operator messages, refer to the "PLC Programming Manual".

[Caution]

- (1) Set the machine parameter PLC "#6450/bit2" to "1" to display the operator messages.
- (2) There are two types of interface for operator messages: the R method which uses the file register (R) and the F method which uses the temporary memory. The selection of R method and F method depends on the machine parameter PLC "#6455/bit3".
- (3) In both R method and F method, displaying an operator message does not cause any alarm on the controller side. If the controller needs to be stopped, take appropriate action on the PLC side, including the "Automatic operation "pause" command" (*SP), the "Single block" (SBK) and the interlock.
- (4) R2560 and R308 cannot be used at a time. When you use R308, set "0" to R2560. R309 to R311 can be used regardless of the value of R2560.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Image input I/F: Image display position (H)	DSPPOSH	R320
A	Image input I/F: Image display position (V)	DSPPOSV	R321
A	Image input I/F: Display range (width)	DSPSZH	R322
A	Image input I/F: Display range (height)	DSPSZV	R323

[Function] [Operation]

These are the registers to set the display position and display range of the partial display screen (IPC screen or camera image) to be displayed on the Mitsubishi Electric standard screen.

The reference coordinate on the Mitsubishi Electric standard screen is set to R320 and R321.

The display range (width and height) of the partial display screen is set to R322 and R323.

Based on the coordinate set to R320 and R321, the IPC screen or camera image is displayed in the range set to R322 and R323.

Display position on Mitsubishi Electric standard screen	Display contents (IPC screen or camera image)
<p>(R320, R321)</p> <p>R322</p> <p>R323</p>	<p>(R324, R325)</p> <p>R326</p> <p>R327</p>

When "0" is set to both R322 and R323, the IPC screen is displayed on the entire Mitsubishi Electric standard screen.

[Caution]

- (1) This signal is valid in the following cases.
 - The image input expansion unit is connected.
 - The parameter "#1057 disp_input" is set to "4", and the contents of the IPC screen or camera image are partially displayed.
- (2) When the resolution of the partial display screen (IPC screen or camera image) is changed, the entire screen is displayed with the changed resolution regardless of the setting of the R registers R320 to R327 even while the screen is partially displayed. When the resolution of the partial display screen (IPC screen or camera image) is changed after the CNC is started, turn the CNC OFF and ON.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Image input I/F: IPC screen transfer start position (H)	IPCPOSH	R324
A	Image input I/F: IPC screen transfer start position (V)	IPCPOSV	R325
A	Image input I/F: IPC screen transfer range (width)	IPCSZH	R326
A	Image input I/F: IPC screen transfer range (height)	IPCSZV	R327

[Function] [Operation]

These are the registers to set the transfer start position and transfer range of the IPC screen to be displayed on the Mitsubishi Electric standard screen.

Set the reference coordinate on the IPC screen to these registers (R324 and R325).

Based on the coordinate set to R324 and R325, the IPC screen is transferred in the range set to R326 and R327. (See the figure of R320.)

When "0" is set to both "R326" and "R327", the width and height of the IPC screen are set as the transfer range.

[Caution]

- (1) This signal is valid in the following cases.
 - The image input expansion unit is connected.
 - The parameter "#1057 disp_input" is set to "4", and the contents of the IPC screen or camera image are partially displayed.
- (2) When the resolution of the partial display screen (IPC screen or camera image) is changed, the entire screen is displayed with the changed resolution regardless of the setting of the R registers R320 to R327 even while the screen is partially displayed.
 When the resolution of the partial display screen (IPC screen or camera image) is changed after the CNC is started, turn the CNC OFF and ON.

[Related signals]

- (1) Image input I/F: Screen selection (DSPCRD: Y1C85)
- (2) Image input I/F: Display range (DSPSZH: R322, DSPSZV: R323)
- (3) Image input I/F: Behavior at gesture (DSPACT: R328/bit1)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Image input I/F: Behavior at operation	DSPACT	R328

[Function]

This signal is used to specify the behavior when the input from the keyboard, menu key or gesture operation is made.

[Operation]

R328	Name	Operation
bit0	Image input: Behavior at key entry	The screen to be the operation target of the function key and menu key is switched. The contents operated on the touch screen are transmitted to the touched screen. It is transmitted to the IPC screen when the IPC screen is touched and to the Mitsubishi Electric standard screen when the Mitsubishi Electric standard screen is touched. However, only when the IPC is connected to the image expansion unit by USB, touch operation is available on the IPC screen partially displayed.
		0 The operation using the keyboard is handled as that for the IPC screen. The CNC keyboard and menu key operation information is transmitted to the IPC screen via the image expansion unit.
		1 The operation using the keyboard is handled as that for the Mitsubishi Electric standard screen. The CNC keyboard and menu key operation information is transmitted to the Mitsubishi Electric standard screen.
bit1	Image input: Behavior at gesture	The behavior when the gesture operation is performed in the area on the partial display screen (IPC screen or camera image) is switched.
		0 The gesture operation is handled as that for the IPC screen. The gesture operation information is transmitted to the IPC screen via the image expansion unit.
		1 The gesture operation is handled as that for the Mitsubishi Electric standard screen. The gesture operation information is not transmitted to the IPC screen. When the gesture operation is performed, the contents in partial display screen (IPC screen or camera image) on the standard screen can be moved and enlarged/reduced. The transfer start position (R324, R325) can be changed by drag/flick. The transfer range (R326, R327) can be changed by pinch-in/pinch-out.

[Caution]

- (1) This signal is valid in the following cases.
 - The image input expansion unit is connected to the CNC unit.
 - The parameter "#1057 disp_input" is set to "4", and the IPC screen or camera image is partially displayed on the Mitsubishi Electric standard screen.

[Related signals]

- (1) Image input I/F: Screen selection (DSPCRD: Y1C85)
- (2) Image input I/F: Display range (DSPSZH: R322, DSPSZV: R323)
- (3) Image input I/F: IPC screen transfer start position (IPCPOSH: R324, IPCPOSV: R325)
- (4) Image input I/F: IPC screen transfer range (IPCSZH: R326, IPCSZV: R327)

Cont.	Signal name	Abbrev.	Common (\$)
A	Machine manufacturer macro password No.		R354, 5

[Function]

This function can prohibit the editing and input/output of the user PLC by using password to prevent the end user from illegally rewriting the user PLC created by the machine manufacturer.

[Operation]

The machine manufacturer's original password is registered in R354[L]/R355[H] with the user PLC.

Set the password in the range of "2" to "99999999". "0" and "1" cannot be set. Note that if the R354/R355 value is "0" or "1", "5963" (default value) will be used as the password No.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Direct screen selection		R356 to 9

[Function]

This signal allows an automatic transition to a desired screen by setting the screen selection information in the file register through the user PLC.

[Operation]

The following table describes the file registers.

Register No.	Signal name	Meaning	Abbreviations in this manual	Supplementary information
R356	R_DRCTSTS	Selection request completion data	(1) User PLC confirms the initial state (=0), and then sets data in R357 to R359. (2) User PLC sets the screen selection request (=1). (3) NC confirms the screen selection request, and sets the screen selection completion (=4) to perform screen transition. (4) After the transition, User PLC confirms the screen selection completion (=4) and then sets the initial state (=0).	0: Initial state 1: Screen selection request 4: Screen selection completion 8: No screen selection request application
R357	R_DRCTFUNCTION	Function No.	Set "4" to transition to the alarm message display screen.	Selection request
R358	R_DRCTMANMENU	Main menu No.	Set "6" to transition to the alarm message display screen.	
		Menu No.	Set "1" to specify the 1st menu of a customized screen.	
		Screen No.	Set "6001" to transition to the customized screen No. 6001.	
R359	R_DRCTSUBMENU	Sub menu No.	Set "1" to transition to the alarm display screen, or "2" to transition to the PLC alarm display screen.	
		Window No.	Set "8002" to display the window No. 8002 of a customized screen.	

- Specify the function No., main menu No. (or menu and screen Nos. of a customized screen), and sub menu No. (or window No. of a customized screen). Then, set the selection request completion data to "1" at the end.
- Make sure to specify the function No. If the function No. is not specified, screen transition is not performed.
- If you omit specifying the main menu No. (or menu and screen of a customized screen) (if you leave the No. zero), the NC transitions to a screen specified with the function No. To which screen to transition is determined according to the destination assigned to each function key.
- When the sub menu No. has been set, the main menu No. has also to be set. When no main menu No. is set, the operation is the same as when only the function No. is set.
- When a screen No. is specified, the NC opens the customized screen of the specified function No., and then transitions to the screen of the specified screen No.
- When a window No. is specified, the window of the specified No. appears after the screen transition (when a screen No. is specified, the specified screen is displayed). Thus, even when no screen No. is specified (0), a window can be displayed by specifying the window No.
- If you specify either the function No., main menu No. (or screen No.), or sub menu No. outside the range, the screen transition is not executed. In this case, the selection request/completion data (R356: R_DRCTSTS) remains "1".

Specify the values in the following table for each file register.

Setting options of R358/R359 are different according to the specified function No.

Screen	R357 value Function No.	R358 value	R359 value
Monitor	1	Main menu (0 to 30)	Sub menu (0 to 70)
Setup	2		
Edit	3		
Diagnostic	4		
Maintenance	5		

4 Explanation of Interface Signals


4.4 PLC Output Signals (Data Type: R***)

Main menu No. (R358) and sub menu No. (R359) are designated using the position from the left-end of menu.

Menu No. = Number of menu changes \times 10 + Position from the left-end of menu (1 to 10)

- If you specify no menu, set main menu No. and sub menu No. to "0".
- Refer to "Direct Screen Selection Specifications Manual" to enable direct screen selection for customized screens.

[Timing chart]



- Set the screen selection completion (R356=4) after completion of screen transition.
- If screen transition is disabled, the selection completion data (R356) may remain "1".
If R356 remains unchanged for two seconds or longer after the screen selection request (R356=1), set "0" in R356 through the PLC.

[Precautions and restrictions]

- (1) If screen selection request is made while any screen process is executed, the subsequent operation will be the same as when a key that causes a screen transition (a function key, for example) is pressed. The operation examples are given below.
 - When a file is being edited on the edit screen, the screen transits after the file is saved.
 - When a data is being input/output, the screen transits immediately. At this time, the input/output is executed in the background.
 - When buffer correction is being performed, the screen transits immediately. The buffer correction data is not saved.
 - When operation search is being performed, the screen transits after the search is completed.
- (2) For a screen that requires a password entry before it is displayed, a screen transition to the said screen is disabled if no password is input.
- (3) If the target main menu designation or screen No. designation is not processed, processing of sub menu or window No. will not be carried out.
- (4) When screen transition is disabled, no specific error is set or displayed, and the selection completion data (R356) remains "1". If there is no changes for 2 seconds or longer after the screen selection request (R356=1), set "0" in R356 through the PLC. However, if the control fails to find the application for the direct screen selection request, "8" is set in R356.
- (5) This function implements a screen transition to each display screen of Monitor, Setup, Edit, Diagnosis, Maintenance and customized screens. The execution file registration type customized screens do not transit.
- (6) If a transition to the identical window screen is carried out, the target window screen is closed once, and then displayed again.
- (7) The menu No. specified for direct screen selection (R358) is applied to the menus configured when the menu selection parameter "#11032 Menu sel para lkof" (Validate menu selection parameter setting) is set to either "0" or "1". Thus, the control may transition to a screen not intended by the machine tool builder.
- (8) While NAVI MILL or NAVI LATHE is displayed, screen transition may fail depending on the working condition.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	User level-based data protection: Operation level		R361

[Function]

This operation level signal switches the protection level of various data.

The operation levels with R361 setting value are as follows.

Other than 1 to 3: Operation level 0

1: Operation level 1

2: Operation level 2

3: Operation level 3

[Operation]

The operation level is switched depending on the state of the user level-based data protection operation level signal.


Various data is protected according to the operation level.

Cont.	Signal name	Abbrev.	Common (\$)
A	Machine parameter lock I/F		R364

[Function]

When the parameter "#11018 M password hold" is valid and the parameter "#1222 aux06/bit3" is valid, this signal switches the lock/release state of the setup parameter.

The lock/release state corresponds to the following bits.

**[Operation]**

Turning ON the "Machine parameter lock I/F" signal releases the machine parameter lock.

Turning OFF this signal locks the machine parameter.

Cont.	Signal name	Abbrev.	Common (\$)
A	High-speed simple program check: Time measurement output		R372,3

[Function]

This signal outputs an estimated machining time during the high-speed simple program check.

The unit of time output is [ms].

[Operation]

During the high-speed simple program check, this signal outputs the time from the start of the machining program execution until NC reset.

[Related signals]

- (1) High-speed simple program check mode (SMLK: Y73E)
- (2) High-speed simple program check mode ON (SMLKO: X712)
- (3) High-speed simple program check: Time reduction coefficient (R378)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Manual arbitrary reverse run handle selection		R375

[Function]


This signal is used to select which handle to use for the manual arbitrary reverse run.

[Operation]

The setting value "n" of this signal (R375) corresponds to the ordinal number of the handle. For example, when the setting value is "2", the machine follows the pulse input of the handle selected in "#1396 H2_pno" (2nd handle selection).

The handle selected at the start of the manual arbitrary reverse run mode is used during the mode.

If any non-existent handle number is set in the "Manual arbitrary reverse run selection" (R375) at the start of the mode, the 1st handle is used.

[Operation sequence]**[Related signals]**

- (1) Manual arbitrary reverse run mode ON (PCHKO: X715)
- (2) Manual arbitrary reverse run: Reverse run ON (MOREV: X716)
- (3) Thread, tap block stopping in manual arbitrary reverse run (MBSTP: X74D)
- (4) Thread, tap reverse run prohibition alarm in manual arbitrary reverse run (MRVNG: X74E)
- (5) Manual arbitrary reverse run mode (MORR: Y73C)
- (6) Manual arbitrary reverse run speed selection (MORSP: Y73D)
- (7) Actual cutting mode (thread, tap) in manual arbitrary reverse run (MRCMD: Y761)
- (8) Manual arbitrary reverse run: Reverse run block stop designated part system (RBSSY: YD01)
- (9) Manual arbitrary reverse run: MSTB reverse run prohibited (MRPSG: YCFC)
- (10) Manual arbitrary reverse run speed multiplier (R379)

Cont.	Signal name	Abbrev.	Common (\$)
A	High-speed simple program check: Time reduction coefficient		R378

[Function]

This signal reduces an execution time for the high-speed simple program check.

[Operation]

With the time reduction coefficient, the time for operations such as axis movement and dwell can be reduced.

If a machining program that requires T seconds for normal execution is performed while the "High-speed simple program check mode ON" (SMLKO: X712) is ON, the execution time is calculated by the following formula.

<When the "High-speed simple program check mode ON" (SMLKO:X712) is ON>

Execution time = $T \times (1/2^n)$ n: High-speed simple program check: Time reduction coefficient

<When the "High-speed simple program check mode ON" (SMLKO:X712) is OFF>

Execution time = T

[Related signals]

- (1) High-speed simple program check mode (SMLK: Y73E)
- (2) High-speed simple program check mode ON (SMLKO: X712)
- (3) High-speed simple program check: Time measurement output (R372,3)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Manual arbitrary reverse run speed multiplier		R379

[Function]

This signal adjusts the speed for manual arbitrary reverse run when jog mode or handle mode is selected for speed control during manual arbitrary reverse run.

[Operation]

If the "Manual arbitrary reverse run speed selection" signal (MORSP) turns ON, the parameter "#19007 program check constant" is used for speed control. If the "Manual arbitrary reverse run speed selection" signal (MORSP) is OFF, the command speed of the normal machining program is used.

The feedrate for manual arbitrary reverse run is controlled by the ratio of the "Manual arbitrary reverse run speed multiplier" (R379) and the parameter "#19007 program check constant" when operation is in jog mode. In handle mode, the feedrate is controlled by the sum of the handle pulses per unit time and manual arbitrary reverse run speed multiplier, and the ratio of the parameter "#19007 program check constant".

If the "Manual arbitrary reverse run speed selection" signal (MORSP) is OFF, the command speed of the normal machining program is used.

<The speed used when the "Manual arbitrary reverse run speed selection" (MORSP) is ON>

- When jog mode is selected:

The manual arbitrary reverse run speed can be calculated from the following formula.

$$\frac{\text{Manual arbitrary reverse run speed multiplier}}{\text{Program check speed constant}} \times \text{Command speed in the machining program}$$

- When handle mode is selected:

The manual arbitrary reverse run speed can be calculated from the following formula.

$$\frac{\begin{array}{l} \text{Change amount of handle pulse per unit time} \\ \times \text{Manual arbitrary reverse run speed multiplier} \end{array}}{\text{Program check speed constant}} \times \text{Command speed in the machining program}$$

- Rapid traverse override or cutting override can be exerted on the command speed in the machining program.
- Reverse motion is performed if the value of the manual arbitrary reverse run speed calculated with the above formula is a negative value.
- As the same rate of change of the manual arbitrary reverse run speed is applied to all part systems, synchronization of the part systems can be maintained. However, synchronization is not guaranteed when synchronization relationship is broken due to rapid traverse override or cutting override.
- If the value of the "Manual arbitrary reverse run speed multiplier" (R379) or the amount of change of handle pulses exceeds "#19007 program check constant", the value is clamped at the program check constant. The manual arbitrary reverse run speed never exceeds the command speed.

[Related signals]

- (1) Manual arbitrary reverse run: Reverse run ON (MOREV: X716)
- (2) Thread, tap block stopping in manual arbitrary reverse run (MBSTP: X74D)
- (3) Thread, tap reverse run prohibition alarm in manual arbitrary reverse run (MRVNG: X74E)
- (4) Manual arbitrary reverse run mode (MORR: Y73C)
- (5) Manual arbitrary reverse run speed selection (MORSP: Y73D)
- (6) Actual cutting mode (thread, tap) in manual arbitrary reverse run (MRCMD: Y761)
- (7) Manual arbitrary reverse run: Reverse run block stop designated part system (RBSSY: YD01)
- (8) Manual arbitrary reverse run: MSTB reverse run prohibited (MRPSG: YCFC)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization: Position error compensation scale, and the number of times of compensations		R390

[Function]

Set the magnification for the position error compensation amount obtained the first time and the number of times to update the compensation amount after the "G/B spindle synchronization: Position error compensation" signal (GBCMON) is turned ON.

[Operation]

	F	8 7	0
R390	(1)	(2)	

(1) Magnification for the first compensation amount

(2) The number of times of compensations

- In "Magnification for the first compensation amount", set the magnification for the position error compensation amount obtained the first time after the "G/B spindle synchronization: Position error compensation" signal (GBCMON) is turned ON. (Setting increment: 1/10 times)
When "0" is set, it will be treated as "1".
- In "The number of times of compensations", set the number of times to update the compensation amount after the "G/B spindle synchronization: Position error compensation" signal (GBCMON) is turned ON.
When "0" is set, compensation is repeated by 16 times.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

<Setting example>

Compensation scale applied to the first compensation	The number of times of compensations	R390's setting value
1.5 times	5 times	0F05 (HEX)

<Operation example: When R390 is set to "0F05">

[Signal from PLC to CNC]

(a) G/B spindle synchronization valid (GBON : Y778)

(b) G/B spindle synchronization: position error compensation (GBON : Y77C)


[Signal from CNC to PLC]

(c) G/B spindle synchronizing mode (GBMOD : X778)

(d) G/B spindle synchronization: position error compensating (GBPCM : X77B)

Gap between the feedback position of guide bushing (G/B) spindle synchronization and the workpiece's torsion

Guide bushing spindle synchronization position error compensation amount



<Refreshing the position error compensation amount after turning ON the "G/B spindle synchronization: Position error compensation" (GBCMON)>

When the "G/B spindle synchronization: Position error compensation" (GBCMON) is turned ON, the first position error compensation amount is measured and compensation is carried out. (*1 in the figure above)

Next, the second position error compensation amount is measured and compensation is carried out. (*2 in the figure above)

In the same manner, the third and fourth measurements are carried out.

The data of the fifth measurement are dealt as the final data to carry out the compensation. (*5 in the figure above)

The compensation scale is applied only to the first position error compensation.

[Related signals]

- (1) G/B spindle synchronization valid (GBON: Y778)
- (2) G/B spindle synchronization: Position error compensation (GBCMON: Y77C)
- (3) G/B spindle synchronization: Keep position error compensation amount (GBCMKP: Y77E)
- (4) G/B spindle synchronization: Position error compensating (GBPCM: X77B)
- (5) G/B spindle synchronization: Position error compensation amount (R465)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis
A	Ball screw thermal displacement compensation: Offset amount n-th axis		R400	R403	R406	R409
A	Ball screw thermal displacement compensation: Max. compensation amount n-th axis		R401	R404	R407	R410
A	Ball screw thermal displacement compensation: Part-system, axis No. n-th axis		R402	R405	R408	R411

[Function]


These signals use R register as interface for PLC and NC. Up to 4 sets of axis can be set in R register, including axis No., offset amount, and max. compensation amount in one set.

[Operation]

- Part-system, axis No. (raxno): R402

F ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ 8

7 ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ 0



- Offset amount (offset): R400
Set compensation amount for the farthest negative side (mdvno position) in the compensation range by using ladder, etc.
- Max. compensation amount (maxcmp): R401
Set compensation amount for the farthest positive side (pdvno position) in the compensation range by using ladder, etc.
This compensation amount is a value using offset position as a criterion.
- Compensation amount (legcmp): R72
This is compensation amount for the current machine position set by NC.
Refer to the section on "Ball screw thermal displacement compensation Compensation amount" (R72) for details.

Note

- Raxno, offset, and maxcmp cannot be set from the program or NC screen.
Set them in R register by using ladder, etc.
- Unit of the offset amount, the maximum compensation amount, the compensation amount follows the setting of "#1006 mcmpunit".
Parameters (backlash and pitch error compensation, etc.) regarding machine error compensation and external machine coordinate system compensation also follow this unit.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

<Setting example>

When only the ball screw thermal displacement compensation is valid:

(Example 1)

Compensation range

cmpax X

drcax X

rdvno 4105

mdvno 4101

pdvno 4110


spcdv 1000

Compensation amount

offset -600

maxcmp 1000

raxno 1



When the ball screw thermal displacement compensation is used with the machine error compensation:

(Example 2)

Compensation range

cmpax X

drcax X

rdvno 4105

mdvno 4101

pdvno 4110

spcdv 1000

(Absolute value method)

Division Compensation

No. amount

1 200

2 200

3 100

4 100

5 -100

6 -200

7 -200

8 -300

9 -200


10 -100

Compensation amount

offset -600

maxcmp 1000

raxno 1



— Thermal expansion compensation
 Machine position compensation
 --- Total compensation amount

[Related signals]

- (1) Ball screw thermal displacement compensation Offset amount n-th axis (R400)
- (2) Ball screw thermal displacement compensation Max. compensation amount n-th axis (R401)
- (3) Ball screw thermal displacement compensation Part-system, axis No. n-th axis (R402)
- (4) Thermal expansion compensation amount (R72)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	PLC axis control information address n-th axis		R440 to 7

[Function]

The PLC axis control information address stores control information head R register for each PLC axis.

[Operation]

PLC axis control information address is designated by the following devices.

Device No.	Signal name
R440	PLC axis control information address 1st axis
R441	PLC axis control information address 2nd axis
R442	PLC axis control information address 3rd axis
R443	PLC axis control information address 4th axis
R444	PLC axis control information address 5th axis
R445	PLC axis control information address 6th axis
R446	PLC axis control information address 7th axis
R447	PLC axis control information address 8th axis

Note

- (1) The following R registers can be used.
- R8300 to R9799 (Battery backup area)
 - R9800 to R9899 (Non battery backup area)
 - R18300 to R19799 (Battery backup area)
 - R19800 to R19899 (Non battery backup area)
 - R28300 to R29799 (Battery backup area)
 - R29800 to R29899 (Non battery backup area)

[Related signals]

- (1) PLC axis control buffering mode valid (PABMI: Y723)
- (2) PLC axis control valid (PLCAEn: Y770 to Y775)

Cont.	Signal name	Abbrev.	Common (\$)
A	PLC axis control buffering mode information address		R448

[Function] [Operation]

The PLC axis control buffering mode information address stores PLC axis control buffering mode information.

[Related signals]

- (1) PLC axis control buffering mode valid (PABMI: Y723)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Encoder 1 arbitrary pulse 1		R456
A	Encoder 1 arbitrary pulse 2		R457
A	Encoder 2 arbitrary pulse 1		R458
A	Encoder 2 arbitrary pulse 2		R459

[Function]

Encoder pulse input used to be fixed to 1024 pulse input in the conventional analogue I/F. With this function, arbitrary pulse can be input by parameters set in R register. The maximum number of input pulse is 76800.

[Operation]

In order to input encoder arbitrary pulse, set the number of pulses necessary in R register. Switch encoder to be used by ON/OFF on the PLC device, and turn ON the arbitrary pulse input valid signal.

Turn OFF the arbitrary pulse input valid signal when the conventional 1024 pulse encoder is used.

Device No.	Signal name	Details	
R456	Encoder 1 arbitrary pulse 1	This signal is selected when the "Encoder 1 arbitrary pulse selection" (Y764) is OFF.	Input 1/2 of the number of pulses necessary for arbitrary pulse input with the encoder input 1. This number of pulses must be in hexadecimal but not in quad edge evaluation. The setting range is 0x200 (512) to 0x9600 (38400).
R457	Encoder 1 arbitrary pulse 2	This signal is selected when the "Encoder 1 arbitrary pulse selection" (Y764) is ON.	
R458	Encoder 2 arbitrary pulse 1	This signal is selected when the "Encoder 2 arbitrary pulse selection" (Y765) is OFF.	Input 2/2 of the number of pulses necessary for arbitrary pulse input with the encoder input 1. This number of pulses must be in hexadecimal but not in quad edge evaluation. The setting range is 0x200 (512) to 0x9600 (38400).
R459	Encoder 2 arbitrary pulse 2	This signal is selected when the "Encoder 2 arbitrary pulse selection" (Y765) is ON.	

[Caution]

- (1) Arbitrary pulse cannot be input from a bus-connected encoder.
- (2) Input 1/2 of the number of pulses actually used with the encoder 1 arbitrary pulse 1 and 2 (R456 to 457), and the encoder 2 arbitrary pulse 1 and 2 (R458 to 459) in hexadecimal. If a different number of pulses is input, the speed at feed per rotation changes. If a different number of pulses is input, the speed at feed per rotation changes.
- (3) When 0 to 0x1FF are set in R456 to R459, the encoder input pulse will be 1024 pulse input. When a value exceeding 0x9600 is set, it will be 76800 pulse input.

[Related signals]

- (1) Encoder 1 arbitrary pulse selection (Y764)
- (2) Encoder 2 arbitrary pulse selection (Y765)
- (3) Encoder 1 arbitrary pulse valid (Y766)
- (4) Encoder 2 arbitrary pulse valid (Y767)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization: Maximum range of the relative position error		R460

[Function]

This signal outputs the maximum range of the relative position error during acceleration/deceleration after the spindle motor completes the acceleration/deceleration.


[Operation]

During guide bushing spindle (G/B) synchronization mode, the following five values are calculated based on the relative position error between the reference spindle and the guide bushing spindle, and they are output to the registers when the state changes between the acceleration/deceleration state and the steady state. (Unit is pulse, 1pulse \approx 0.088°)


- Maximum range of the relative position error during acceleration/deceleration
- Maximum value of the relative position error during acceleration/deceleration
- Maximum range of the relative position error during the steady state
- Maximum value of the relative position error during the steady state
- Average value of the relative position error during the steady state

This sampling is constantly carried out during the guide bushing spindle synchronization mode. It stops when the guide bushing spindle synchronization mode is canceled.

Spindle rotation speed



Relative position error



- R460 Maximum range ((a) above) of the relative position error is written after the spindle motor completes acceleration.
Maximum range ((b) above) of the relative position error is written after the spindle motor decelerates and stops.
- R461 Maximum value ((c) above) of the relative position error is written after the spindle motor completes acceleration.
Maximum value ((d) above) of the relative position error is written after the spindle motor.
- R462 Average value ((e) above) of the relative position error is written after the spindle motor finishes steady rotation.
- R463 Maximum range ((f) above) of the relative position error is written after the spindle motor finishes steady rotation.
- R464 Maximum value ((g) above) of the relative position error is written after the spindle motor finishes steady rotation.

Note

- (1) The relative position error is calculated by ""Reference spindle's feedback position" - "Guide bushing spindle's feedback position"".

[Related signals]

- (1) G/B spindle synchronization valid (GBON: Y778)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization: Maximum value of the relative position error		R461

[Function]

This signal outputs the maximum value of the relative position error after the spindle motor completes the acceleration/deceleration.

[Operation]

Refer to "G/B spindle synchronization: Maximum range of the relative position error" (R460).

[Related signals]

- (1) G/B spindle synchronization valid (GBON: Y778)
- (2) G/B spindle synchronization: Maximum range of the relative position error (R460)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization: Average value of the relative position error during the steady state		R462

[Function]

This signal outputs the average value of the relative position error during steady rotation after the spindle motor completes steady rotation.

[Operation]

Refer to "G/B spindle synchronization: Maximum range of the relative position error" (R460).

[Related signals]

- (1) G/B spindle synchronization valid (GBON: Y778)
- (2) G/B spindle synchronization: Maximum range of the relative position error (R460)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization: Maximum range of the relative position error during the steady state		R463

[Function]

This signal outputs the maximum range of the relative position error during steady rotation after the spindle motor completes steady rotation.

[Operation]

Refer to "G/B spindle synchronization: Maximum range of the relative position error" (R460).

[Related signals]

- (1) G/B spindle synchronization valid (GBON: Y778)
- (2) G/B spindle synchronization: Maximum range of the relative position error (R460)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization: Maximum value of the relative position error during the steady state		R464

[Function]

This signal outputs the maximum value of the relative position error during steady rotation after the spindle motor completes steady rotation.

[Operation]

Refer to "G/B spindle synchronization: Maximum range of the relative position error" (R460).

[Related signals]

- (1) G/B spindle synchronization valid (GBON: Y778)
- (2) G/B spindle synchronization: Maximum range of the relative position error (R460)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization: Position error compensation amount		R465

[Function]

This signal outputs the position error compensation amount in the guide bushing (G/B) spindle synchronization position error compensation state.

[Operation]

When the "G/B spindle synchronization: Position error compensation" signal (GBCMON) is turned ON, this signal outputs the position error compensation amount during the guide bushing spindle synchronization position error compensation.

(Unit is pulse, 1pulse \approx 0.088°)

When the guide bushing spindle synchronization position error compensation is finished, this signal becomes "0".

[Related signals]

- (1) G/B spindle synchronization valid (GBON: Y778)
- (2) G/B spindle synchronization: position error compensation (GBCMON: Y77C)
- (3) G/B spindle synchronization: keep position error compensation amount (GBCMKP: Y77E)
- (4) G/B spindle synchronization: Position error compensation scale and the number of times of compensations (R390)
- (5) G/B spindle synchronization: position error compensating (GBPCM: X77B)

Cont.	Signal name	Abbrev.	Common (\$)
A	G/B spindle synchronization: Phase shift amount		R466

[Function]

This signal outputs the phase error (relative position) of the reference spindle and guide bushing (G/B) spindle saved when the "G/B spindle synchronization: Phase memory" signal (GBPHM) was turned ON.

[Operation]

This signal displays the phase error (relative position) of the reference spindle and guide bushing spindle saved when the "G/B spindle synchronization: Phase memory" signal (GBPHM) was turned ON during guide bushing spindle synchronization. (Unit is pulse, 1pulse \approx 0.088°)

When guide bushing spindle synchronization is canceled, this signal becomes "0".

[Related signals]

- (1) G/B spindle synchronization valid (GBON: Y778)
- (2) G/B spindle synchronization: Phase memory (GBPHM: Y77B)

Cont.	Signal name	Abbrev.	Common (\$)
A	Interference check between part systems: Data address		R468

[Function] [Operation]

This signal designates the R register head No. which is used for the setting of the interfering object or coordinate system of the interference check between part systems.

[Caution]

- (1) Set an even number in the R register.
- (2) Set the R register number within the range of user backup area or user work area.

[Related signals]

- (1) Interference check between part systems: Setting error alarm information (R101)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	1st cutting feed override		R2500	R2700	R2900	R3100	R3300	R3500	R3700	R3900

[Function]

When the "Cutting feed override method selection" (FVS) is set to "file register method", override control can be performed in the range of 0% to 300% in 1% increments. Desired value is set to file register (R) in binary code.

[Operation]

As for the cutting feed during the automatic operation, the actual feedrate is the value obtained by multiplying the specified feedrate (F) by this override ratio. (When the "2nd cutting feed override" is not valid).

However, the override ratio is fixed to 100%, irrespective of this override setting, under the following conditions:

- ♦ The "Override cancel" signal (OVC) is ON.
- ♦ During tapping in fixed cycle
- ♦ During tapping mode
- ♦ During thread cutting

Note

- (1) Only when override value is 0%, override is exerted even on rapid traverse speed in automatic operation. That is, cutting feed as well as rapid traverse stop if the 1st feedrate override is set to 0% during automatic operation.

When override value is 0%, "M01 OPERATION ERROR" appears in the alarm display section of setting display device and "M01 OPERATION ERROR 0102" appears on the ALARM DIAGNOSIS display.

[Related signals]

- (1) Cutting feed override code m (*FV1 to 16: YC60)
- (2) Cutting feed override method selection (FVS: YC67)
- (3) 2nd cutting feed override valid (FV2E: YC66)
- (4) 2nd cutting feed override (R2501)

Note

- (1) For relationship among these signals, refer to the description for the cutting feedrate override.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	2nd cutting feed override		R2501	R2701	R2901	R3101	R3301	R3501	R3701	R3901

[Function]

When the "2nd cutting feed override valid" signal (FV2E) is used, another override can be exerted on the "Cutting feed override code m" (*FV1 to *FV16), or on the "1st cutting feed override" (file register value) when the "Cutting feed override method selection" (FVS) is set to file register method. Applicable range of the override is 0% to 327.67% in 0.01% increments. The value is set in the file register in binary.

[Operation]

When this override function is used, the actual feedrate is the value obtained by multiplying commanded feedrate (F) by the "1st cutting feed override" ratio and the "2nd cutting feed override" ratio.

Since the least increment of 2nd feedrate override is 0.01%, override setting "10000" corresponds to 100%.

The override ratio is fixed to 100%, irrespective of the "1st cutting feed override" or the "2nd cutting feed override" setting, under the following condition:

- The "Override cancel" signal (OVC) is ON.
- During tapping in fixed cycle
- During TAPPING mode
- During thread cutting

Note

- (1) Only when the 1st cutting feed override or the 2nd cutting feed override is 0% or both of them are 0%, override is exerted not only on the cutting feedrate but on rapid traverse rate in automatic operation. That is, rapid traverse stops as well as cutting feed if the cutting feedrate override is set to 0%. When override setting is 0%, "M01 OPERATION ERROR" appears in the alarm display section of setting and display unit, and "M01 OPERATION ERROR 0102" in the ALARM DIAGNOSIS display.

[Related signals]

- (1) Cutting feed override code m (*FV1 to 16: YC60)
- (2) Cutting feed override method selection (FVS: YC67)
- (3) 2nd cutting feed override valid (FV2E: YC66)
- (4) 1st cutting feed override (R2500)

Note

- (1) For relationship among these signals, refer to the description for the cutting feedrate override.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Rapid traverse override		R2502	R2702	R2902	R3102	R3302	R3502	R3702	R3902

[Function]

When the "Rapid traverse override method selection" signal (ROVS) is set to "file register method", override can be exerted, besides the code method override (ROV1, ROV2), by setting within the range of 0% to 100% by 1% increments. Desired value is set to file register (R) in binary code.

[Operation]

During rapid traverse in the automatic or manual operation, the actual feedrate will be the result of multiplying the rapid traverse speed set in a parameter by this override ratio.

Note

- (1) The override will be clamped at 100%.
- (2) The "M01 Rapid traverse override zero 0125" occurs when the override value is 0%.

[Related signals]

- (1) Rapid traverse override code 1, 2 (ROV1, ROV2: YC68, YC69)
- (2) Rapid traverse override method selection (ROVS: YC6F)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Chopping override	CHPOV	R2503	R2703	R2903	R3103	R3303	R3503	R3703	R3903

[Function]

The chopping override can be set in the range between 0% and 100% .

The value is set directly in the R register for chopping override. (The code method setting is not available.)

The data is set in R2503.

[Operation]

- Only the chopping override is valid for the chopping operation.
When rapid traverse override valid is commanded from the PLC window, the rapid traverse override can be enabled for the rapid traverse between the basic position and upper dead center point.
The rapid traverse override can be set with either the code method (1, 25, 50, 100%) or the file register (value setting) method (0% to 100%, 1% increment).
- The chopping override is set between 0% and 100%.
Select either "1%" or "0.01%" by the control data for the setting unit.
If a value outside the range of 0% to 100% is set, the override will be clamped at 100%.
- Set the data with one command.
- When the "Chopping override" signal is set to "0", the operation error (M01 0150) occurs.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual feedrate		R2504, 5	R2704, 5	R2904, 5	R3104, 5	R3304, 5	R3504, 5	R3704, 5	R3904, 5

[Function]

When the "file register method" of the "Manual feedrate method selection" signal (JVS) is selected, the manual feedrate can be specified separately from the manual feedrate by the normal code method (*JV1 to *JV16). The value is set in the file register (R) in binary.

[Operation]

This mode of feedrate setting can be used in JOG feed, incremental feed, reference position return feed and manual arbitrary feed mode. For JOG, incremental, and reference position return mode, the "Rapid traverse speed" signal (RT) should be turned OFF. For manual arbitrary feed mode, the "Manual arbitrary feed EX.F/MODAL.F" signal (CXS3) should be turned OFF. This manual feedrate is also effective for the feedrate during dry run operation in the case of automatic operation.

Other conditions for using this signal are as follows:

- When the "Manual override method selection" signal (OVSL) is OFF, the originally set feedrate is applied.
- When the "Manual override method selection" signal (OVSL) is ON, the actual feedrate can be obtained by multiplying the feedrate specified by the 1st/2nd cutting feed override value.
- Manual feedrate is set to file registers Rn and Rn+1. The feedrate depends on the "Feedrate least increment code 1" (PCF1) or the "Feedrate least increment code 2" (PCF2) as listed below.

PCF2	PCF1	Least increment (mm/min or inch/min)	Operation
0	0	10	10 mm/min (inch/min) when "1" is set in file registers.
0	1	1	1 mm/min (inch/min) when "1" is set in file registers.
1	0	0.1	0.1 mm/min (inch/min) when "1" is set in file registers.
1	1	0.01	0.01 mm/min (inch/min) when "1" is set in file registers.

- The speed clamp depends on the cutting clamp speed of the axis parameter. (When the "Rapid traverse" signal (RT) is OFF)

Note

- In incremental feed mode, the actual feedrate does not change even when the manual feedrate setting is changed while moving.
- The file registers that specify the manual feedrate include Rn and Rn+1, with Rn being the lower order. As for the file register that specifies the speed, if the value is within 2 bytes (1 word) of Rn and Rn+1, the higher one does not need to do anything.

[Related signals]

- Manual feedrate code m (*JV1 to *JV16: YC70 to YC74)
- Manual feedrate method selection (JVS: YC77)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual feedrate B		R2506, 7	R2706, 7	R2906, 7	R3106, 7	R3306, 7	R3506, 7	R3706, 7	R3906, 7

[Function] [Operation]

Designate the manual feedrate for the axis selected with the "Manual feedrate B valid" signal.

[Caution]

- (1) The speed designated with this register is valid for the manual feedrate of an axis for which the "Manual feedrate B valid" signal is valid.
- (2) Cutting override and manual override are invalid for this register's speed.
- (3) This register is not related to the dry run speed.
- (4) A binary value is directly set for this register. The setting unit is 0.01 mm/min (°/min).
- (5) This signal is a register common for all axes.

[Related signals]

- (1) Manual feedrate B valid (FBEn: Y940 to Y947)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	1st handle/incremental feed magnification		R2508, 9	R2708, 9	R2908, 9	R3108, 9	R3308, 9	R3508, 9	R3708, 9	R3908, 9

[Function]

By selecting the handle/incremental feed magnification method (MPS), an arbitrary magnification can be designated separately from magnification set by regular code method. The numerical value specified by the magnification is set in the file register (R) in binary.

When the "Handle/incremental feed magnification method selection" signal (MPS) is ON, this magnification is applied for the hand pulse from handy terminal.

[Operation]

Magnification is applied to amount of feed per pulse in handle feed mode (output from manual pulse generator), or to amount of feed per signal in incremental feed mode (+J1, -J1, etc.).

For example, when the magnification is set to "500" and one pulse is given in handle feed mode, 500 μ m of feed motion occurs. (Time constant for feed motion is equal to time constant for cutting feed or step.)

When the magnification is set to "30000" and once the feed axis selection signal is turned ON in incremental feed mode, 30 mm of feed motion occurs. (Time constant for feed motion is equal to time constant for rapid traverse.)

Note

- (1) Changing magnification during feed motion is invalid.
- (2) Considerably large magnification can be set in the arbitrary magnification setting method. Be especially careful when setting the magnification.

[Related signals]

- (1) Handle mode (H: YC01)
- (2) Incremental mode (S: YC02)
- (3) Handle/Incremental feed magnification code m (MP1, MP2, MP4: YC80, YC81, YC82)
- (4) Handle/incremental feed magnification method selection (MPS: YC87)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	2nd handle feed magnification		R2510, 1	R2710, 1	R2910, 1	R3110, 1	R3310, 1	R3510, 1	R3710, 1	R3910, 1
A	3rd handle feed magnification		R2512, 3	R2712, 3	R2912, 3	R3112, 3	R3312, 3	R3512, 3	R3712, 3	R3912, 3

[Function]

By selecting the handle/incremental feed magnification method, an arbitrary magnification can be designated separately from magnification set by regular code method. Magnification value (multiplier) is set in file register (R) in binary.

When the 2nd or 3rd handle is used, the arbitrary magnification is designated here.

[Operation]

When 1 pulse is sent by 2nd or 3rd handle, its feed amount conforms to this feed magnification.

For example, when 1 pulse is sent in handle mode with magnification set at "500", its feed amount will be 500 μ m. (Time constant for feed motion is equal to time constant for cutting feed or step.)

Note

- (1) Changing magnification during feed motion is invalid.
- (2) Considerably large magnification can be set in the handle/incremental feed magnification method. Pay extra attention when setting magnification.

[Related signals]

- (1) Handle mode (H: YC01)
- (2) Incremental mode (S: YC02)
- (3) Handle/incremental feed magnification code m (MP1,MP2,MP4: YC80,C81,C82)
- (4) 1st handle/incremental feed magnification (R2508)
- (5) Handle/incremental feed magnification method selection (MPS: YC87)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	PLC interrupt program No.		R2518, 9	R2718, 9	R2918, 9	R3118, 9	R3318, 9	R3518, 9	R3718, 9	R3918, 9

[Function]

Set the program No. to execute the PLC interrupt.

[Operation] [Caution]

Refer to "PLC interrupt" (PIT) for details of PLC interrupt operation.

[Related signals]

- (1) PLC interrupt (PIT: YC2E)
- (2) In PLC interrupt (PCINO: XC35)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual feedrate B override (File register method)		R2524	R2724	R2924	R3124	R3324	R3524	R3724	R3924

[Function]

Override for manual feedrate B valid axis is set.

[Operation]

The override set with this register will be valid for the axis selected with the "Manual feedrate B valid" signal.

This register can be set within the range of 0% to 200% in 0.01% increment.

When a value larger than 200% (the setting value is "20000") is set, the value is regarded as 200% during the operation.

This register is common for axes.

[Caution]

- (1) When the manual feedrate B override commanded by the user PLC is 0%, even if the "Feed axis selection" signal for the axis selected by the "Manual feedrate B valid" signal is turned ON, an error occurs and the axis will not move.
- (2) For a linear axis, the manual feedrate B surface speed control is not valid. However, the manual feedrate B override is valid.
- (3) To use the manual feedrate B override, the additional specification of the manual feedrate B surface speed control is required.

[Related signals]

- (1) Manual feedrate B valid (FBEn: Y940 to Y947)
- (2) Manual feedrate B surface speed control valid (YC7D)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	External search device No.		R2525	R2725	R2925	R3125	R3325	R3525	R3725	R3925

[Function] [Operation]

The device storing the machining program to be searched is designated with a No.

When a front-side SD card is selected in M800VS/M80V Series, select either "2" or "4" for the device number.

When a rear-side SD card is selected in M800VS/M80V Series, select "1" for the device number.

When a front USB port of the display unit is selected, select "6" for the device number.

HD operation with industrial personal computer (IPC) connection can be specified only for M80V Series.

To enable HD operation with industrial personal computer, the following parameter settings are required.

- Set "#1760 cfgPR10/bit2" (Enable HD mode on IPC) to "1".
- Set the IP address of industrial personal computer to connect to "#11005 PC IP address" (IP address setting).

Setting value	Device
0	Memory
1	Display unit-side high-speed program server
2	Memory card (E drive), front-side SD card
3	-
4	Control unit-side high-speed program server
5	Tape (RS232C)
6	Front-side USB port of display unit
7	HD for industrial personal computer (D: /NCFIL) (Only for M80V Series)
8	Extended area (memory 2)

[Related signals]

- (1) External search program No. (R2526)
- (2) External search sequence No. (R2528)
- (3) External search block No. (R2530)
- (4) External search strobe (YC1D)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	External search program No.		R2526, 7	R2726, 7	R2926, 7	R3126, 7	R3326, 7	R3526, 7	R3726, 7	R3926, 7

[Function] [Operation]

Designate the No. of the machining program to be searched as a binary. (0 to 99999999 (8 digits))

[Related signals]

- (1) External search device No. (R2525)
- (2) External search sequence No. (R2528)
- (3) External search block No. (R2530)
- (4) External search strobe (YC1D)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	External search sequence No.		R2528, 9	R2728, 9	R2928, 9	R3128, 9	R3328, 9	R3528, 9	R3728, 9	R3928, 9

[Function] [Operation]

Designate the No. of the machining program to be searched as a binary. (0 to 99999999 (8 digits))

[Related signals]

- (1) External search device No. (R2525)
- (2) External search program No. (R2526)
- (3) External search block No. (R2530)
- (4) External search strobe (YC1D)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	External search block No.		R2530, 1	R2730, 1	R2930, 1	R3130, 1	R3330, 1	R3530, 1	R3730, 1	R3930, 1

[Function] [Operation]

Designate the block No. as a binary. (0 to 999999999 (9 digits))

[Related signals]

- (1) External search device No. (R2525)
- (2) External search program No. (R2526)
- (3) External search sequence No. (R2528)
- (4) External search strobe (YC1D)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Handle polarity		R2540	R2740	R2940	R3140	R3340	R3540	R3740	R3940

[Function]

In handle mode, the axis movement direction for the pulse of manual pulse generator can be reversed.


[Operation]

When the "Handle polarity" signal turns ON, the axis corresponding to the bit moves in the reverse direction of the pulse of manual pulse generator.



The "Handle polarity" signal when the axis to be moved is selected (when the "n-th handle valid" signal turns ON while the "n-th handle axis selection code" signal is set, or when the "n-th handle axis selection code" signal is changed with the "n-th handle valid" signal ON) is used.

When the "Handle polarity" signal is changed, select the axis to be moved again.

**[Caution]**

- (1) During the manual speed command, the handle polarity with the "Handle polarity" signal cannot be switched. To reverse the command direction input with the handle during manual speed command, use the "Manual speed command sign reversed" signal (YC9E).
- (2) During the manual arbitrary reverse run, the handle polarity cannot be switched with the "Handle polarity" signal.

[Related signals]

- (1) 1st handle axis selection code (HS11 to HS116: YC40 to YC44), 1st handle valid (HS1S: YC47)
- (2) 2nd handle axis selection code (HS21 to HS216: YC48 to YC4C), 2nd handle valid (HS2S: YC4F)
- (3) 3rd handle axis selection code (HS31 to HS316: YC50 to YC54), 3rd handle valid (HS3S: YC57)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed 1st axis travel amount		R2544, 5	R2744, 5	R2944, 5	R3144, 5	R3344, 5	R3544, 5	R3744, 5	R3944, 5

[Function]

This data specifies the travel amount or positioning point in manual arbitrary feed mode.

[Operation]

"Manual arbitrary feed 1st axis travel amount" is the movement data corresponding to the axis number specified by the "Manual arbitrary feed 1st axis selection code m" (CX11 to 116: YCA0 to YCA4).

The meaning of the "Manual arbitrary feed 1st axis travel amount" differs depending on the ON/OFF status of the "Manual arbitrary feed MC/WK" signal (CXS5) and the "Manual arbitrary feed ABS/INC" signal (CXS6).

- ♦ When the "Manual arbitrary feed ABS/INC" signal (CXS6) is ON:
"Manual arbitrary feed 1st axis travel amount" means travel amount (incremental amount).
 - ♦ When the "Manual arbitrary feed ABS/INC" signal (CXS6) is OFF, it depends on the status of the "Manual arbitrary feed MC/WK" signal (CXS5) as follows:
 - When the "Manual arbitrary feed MC/WK" signal (CXS5) is OFF:
"Manual arbitrary feed 1st axis travel amount" means a coordinate position (positioning point) of the machine coordinate system.
 - When the "Manual arbitrary feed MC/WK" signal (CXS5) is OFF:
"Manual arbitrary feed 1st axis travel amount" means a coordinate position (positioning point) of the modal workpiece.
- "Manual arbitrary feed 1st axis travel amount" is written in binary notation with a sign. The unit of the specified value matches that of data entered.
- (Example) When "1" is specified for (R2545, R2544) in a 1-micrometer system, the axis moves 1 μ m (when the increment amount is specified).

[Caution]

- (1) Set the data in millimeters. The data cannot be set by inch system.
- (2) "Manual arbitrary feed 1st axis travel amount" forms one data by R2544 and R2545 or R2744 and R2745. Handle negative data carefully.
- (3) Travel amount is within 360° when a positioning is carried out with the absolute command for the following axes. (The axis does not move in the short-cut direction.)
 - ♦ A rotation-type rotary axis
 - ♦ A linear-type rotary axis of workpiece coordinate (to be positioned on the machine coordinate system)

[Related signals]

For related signals, refer to the section on "Manual arbitrary feed mode" (PTP: YC03).

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed 2nd axis travel amount		R2548, 9	R2748, 9	R2948, 9	R3148, 9	R3348, 9	R3548, 9	R3748, 9	R3948, 9

[Function] [Operation]

"Manual arbitrary feed 2nd axis travel amount" is the movement data corresponding to the axis number specified by the "Manual arbitrary feed 2nd axis selection code m" (CX21 to CX216).

The other conditions are the same as the "Manual arbitrary feed 1st axis travel amount" explained in the previous section.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Manual arbitrary feed 3rd axis travel amount		R2552, 3	R2752, 3	R2952, 3	R3152, 3	R3352, 3	R3552, 3	R3752, 3	R3952, 3

[Function] [Operation]

"Manual arbitrary feed 3rd axis travel amount" is the movement data corresponding to the axis number specified by the "Manual arbitrary feed 3rd axis selection code m" (CX31 to CX316).

The other conditions are the same as the "Manual arbitrary feed 1st axis travel amount" explained in the previous section.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Alarm message I/F 1 to 4		R2556 to 9	R2756 to 9	R2956 to 9	R3156 to 9	R3356 to 9	R3556 to 9	R3756 to 9	R3956 to 9

[Function]

Desired alarm messages prepared using PLC development tool (personal computer) can be displayed in alarm diagnosis screen of the setting and display unit by setting values (binary code) to alarm interface file registers (Rn, Rn+1, Rn+2, Rn+3).

[Operation]

By setting the table No. of the alarm message table created in advance in the file register for the alarm interface, the alarm message is displayed on the alarm diagnosis screen. Up to 4 alarm messages can be displayed at the same time.

Alarm message can be cleared by setting "0" to alarm interface file registers.

For details on alarm message display, refer to the "PLC Programming Manual".

[Caution]

- (1) Set machine parameter PLC "#6450/bit0" to "1" to display the alarm messages.
- (2) For alarm message interface, file register (R method) or temporary storage (F method) can be used. The selection is made with machine parameter PLC "#6450/bit1".
- (3) In either R method (file register) or F method (temporary storage), the alarm display does not cause an alarm on the controller side. When it is necessary to stop the controller according to the type of alarm, take appropriate action on the PLC side, including the "Automatic operation "pause" command" (*SP), the "Single block" (SBK), and the interlock.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Operator message I/F		R2560	R2760	R2960	R3160	R3360	R3560	R3760	R3960

[Function]

Desired operator message prepared using PLC development tool (personal computer) can be displayed by setting value (binary code) to operator message interface file register (Rn). Operator message appears in alarm diagnosis screen of the setting and display unit.

[Operation]

If table No. of previously prepared operator message table has been set to operator message interface file register, operator message can be displayed in alarm diagnosis screen. Operator message can be cleared by setting "0" to operator message interface file register.

For details on displaying operator messages, refer to the "PLC Programming Manual".

[Caution]

- (1) Set the machine parameter PLC "#6450/bit2" to "1" to display the operator messages.
- (2) There are two types of interface for an operator message: type R which uses a file register (R) and type F which uses a temporary memory. The selection of R method and F method depends on the machine parameter PLC "#6455/bit3".
- (3) In either R method or F method, the alarm does not occur on the controller by displaying the operator message. If the controller needs to be stopped, take appropriate action on the PLC side, including the "Automatic operation "pause" command" (*SP), the "Single block" (SBK) and the interlock.
- (4) R2560 and R308 cannot be used at the same time. When you use R308, set "0" to R2560. R309 to R311 can be used regardless of the value of R2560.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Search & start program No.		R2562, 3	R2762, 3	R2962, 3	R3162, 3	R3362, 3	R3562, 3	R3762, 3	R3962, 3

[Function]

The No. of the program to be searched with search & start is designated.

[Operation]

Set the No. of the program to be searched with search & start with a binary value.

Note

- (1) The program No. must be set before the "Search & start" signal is input.
- (2) If a machining program No. is not designated or if an illegal No. is designated, and error signal will be output when the search operation is executed.

[Related signals]

- (1) Search & start (RSST: YC31)
- (2) Search & start Error (SSE: XC8A)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Encoder selection		R2567	R2767	R2967	R3167	R3367	R3567	R3767	R3967

[Function]

Using a binary setting, select which spindle's encoder feedback to use.

- 0: 1st spindle
- 1: 2nd spindle
- 2: 3rd spindle
- 3: 4th spindle
- 4: 5th spindle
- 5: 6th spindle
- 6: 7th spindle
- 7: 8th spindle

Note

- (1) If a setting exceeds the number of connected spindles, it will be interpreted that a selection has not been made.

[Related signals]

- (1) Spindle selection (SWS: X18A8)
- (2) Spindle command selection (SLSP: R7002)
- (3) Spindle stop (SSTP: Y1894)
- (4) Spindle enable (ENB: X18A0)
- (5) Spindle forward run start (SRN: Y1898)
- (6) Spindle reverse run start (SRI: Y1899)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	C axis selection		R2568	R2768	R2968	R3168	R3368	R3568	R3768	R3968

[Function]

The "C axis selection" signal is used to issue the commands with the axis name command address to the axis selected from the Spindle/C-axis having the same axis name in the part system.

[Operation]

Using the axis number, set which spindle or C axis to output the commands to.

0: First C axis, 1: 1st axis, 2: 2nd axis, 3: 3rd axis, 4: 4th axis, ... 8: 8th axis

The setting is made with the axis number used in the part system.

Note

- (1) This signal must always be input simultaneously with the "Recalculation request" signal (CRQ).
- (2) This signal is valid even when the multi-spindle function is invalid.
- (3) If an axis name (#1013 axname) is different from the initial C axis name, the operation error (M01 1031) will occur.


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Load monitoring I: Axis selection		R2580	R2780	R2980	R3180

[Function]

The axes to perform the effective torque output, cutting torque output and disturbance torque output of the spindle and servo axis are designated.

[Operation]

The cutting torque, disturbance torque and effective torque output for all the spindle and servo axis designated with this signal are output simultaneously.

**[Caution]**

Specify the servo axes in the devices of each part system.

Specify the spindle in the device of the 1st part system.

[Related signals]

- (1) Load monitoring I: Effective torque output n-th axis (R5620 to R5627)
- (2) Load monitoring I: Estimated spindle disturbance torque output (R6541)
- (3) Load monitoring I: Effective spindle torque output (R6542)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Each axis reference position selection		R2584	R2784	R2984	R3184	R3384	R3584	R3784	R3984

[Function]


Select the each axis reference position return position for manual reference position return.

[Operation]

- (1) This signal is valid when the reference position select method is ON.
- (2) Two bits are used for each axis to select the reference position.

- ♦ R register and corresponding axis

Each axis reference position selection



- ♦ Setting value and reference position No.

High-order bit	Low-order bit	Return position
0	0	1st reference position
0	1	2nd reference position
1	0	3rd reference position
1	1	4th reference position

[Related signals]

- (1) Reference position selection method (M: YC97)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Chopping control data address		R2587	R2787	R2987	R3187	R3387	R3587	R3787	R3987

[Function] [Operation]

This signal designates the chopping control data head No. (R register No.) assigned to R register.

R register area that can be used for assigning the chopping control data is as shown below.

R8300 to R9768 (Backup area)

R9800 to R9886 (Non back up area)

[Caution]

- (1) Setting error occurs if an odd number is set.
- (2) When the backup area is used, set the area ahead of the compensation amount record area (#1324 chop_R).
- (3) An error occurs if the chopping control data overlaps with the other part system or the compensation amount record area.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool life management data sort		R2588	R2788	R2988	R3188	R3388	R3588	R3788	R3988

[Function] [Operation]

This signal is a flag that sorts the required/unnecessary tool life data.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Synchronous control operation method		R2589	R2789	R2989	R3189	R3389	R3589	R3789	R3989

Synchronous control:**[Function] [Operation]**

Synchronous control for the 1st part system is designated with the R2589 register, and for the 2nd part system with the R2789 register.

Synchronous control can be turned ON and OFF by setting the bits corresponding to each axis in this register.

The CNC changes the operation when all axes reach the in-position state.



♦ Designating the synchronous operation method

Turn ON both of bits corresponding to the axes, which are in a master-slave relationship, with the base specification parameter "#1068 slavno".

(Example) To operate the 2nd axis (master axis) and 3rd axis (slave axis) in synchronization

	7	6	5	4	3	2	1	0	HEX
R2589	0	0	0	0	0	0	0	0	00
	0	0	0	0	0	1	1	0	06

♦ Designating the independent operation method


Turn ON the bit corresponding to only one of the axes to be moved with the command of the master axis.

(Example) To move only the 3rd axis (slave axis)

	7	6	5	4	3	2	1	0	HEX
R2589	0	0	0	0	0	0	0	0	00
	0	0	0	0	0	1	0	0	04

When it is necessary to keep the synchronous state immediately after the power is turned ON due to the machine structure, set the R2589 register with the first ladder after the power is turned ON.

<Example of ladder creation>



When changing the operation with this register during automatic operation, turn ON the "Recalculation request" signal (YC2B) to calculate the coordinates again.

After slave axis independent operation is carried out, the end point coordinates of the slave axis are substituted in the program end point coordinates for the master axis. Thus, unless the coordinates are recalculated, the master axis' movement command is not created properly.

Request recalculation immediately after this register is changed.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)



<Example of ladder creation>

Example of when the 2nd axis is the master axis, the 3rd axis is the slave axis, and the M code is assigned as follows

M10: Asynchronous operation

M20: Independent operation

M40: Synchronous operation



4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

[Caution]

- (1) During synchronous operation or independent operation, the master axis signals are valid for the "Interlock" and "Machine lock" signals, etc.
- (2) The conditions of the "Reference position reached" signal (X800) of the master axis in the synchronous operation method follow the setting of the parameter "#1282 ext18/bit1".
- (3) When any of G27, G28 and G30 is commanded during the slave axis independent operation, the slave axis returns to its own zero point.
- (4) The position switches are processed independently for the master axis and slave axis.
- (5) When bit5 of the parameter #1261 is OFF, use the same "Stroke end" signal for the master axis and slave axis.
Set the same soft limit value for the master axis and slave axis.
If the above settings cannot be made because of the machine specifications, observe the following points.
 - If stroke end or soft limit occurs during the manual operation mode, the master axis does not stop even when an alarm occurs for the slave axis. Thus, make sure that the master axis alarm turns ON before the slave axis alarm.
 - Stroke end during the manual operation mode causes the slave axis to stop when the "Stroke end" signal for the master axis turns ON. The master axis is stopped by the position controller, and the slave axis is stopped by the NC control unit. Thus, there may be a difference in their stop positions. If an excessive error alarm occurs because of stroke end, enter the correction mode, and cancel the alarm.
- (6) In the slave axis independent operation, even when the machine lock signal is ON, the current value counter of the master axis is updated. The master axis and the slave axis are not identified in the playback. The movement amount of the specified axis is set as it is.
- (7) The master axis independent operation is handled as asynchronous. Therefore, the PLC input/output signal is not reflected on the slave axis.
- (8) Immediately after the synchronous control operation method is changed when the parameter "#1281 ext17/bit6" is ON, the compensation amount used for the slave axis in the external machine coordinate compensation and the ball screw thermal expansion compensation is as follows.
 - When the synchronous operation is switched to the independent operation method; the slave axis compensation amount is applied instead of the master axis compensation amount.
 - When the independent operation is switched to the synchronous operation method; the master axis compensation amount is applied instead of the slave axis compensation amount.
- (9) When the parameter "#1281 ext17/bit6" is ON and the synchronous operation method is designated, the slave axis is compensated with the master axis compensation amount in the ball screw thermal expansion compensation, and the compensation amount of each axis is output to "Ball screw thermal displacement compensation: Compensation amount" (R72 to R75).
- (10) When the "Synchronous control operation method" (R2589) is changed (when the independent operation or synchronous operation is finished) for the axis (master axis or slave axis) where both synchronous operation and chopping are performed, the operation error (M01 1270) occurs and all the axes decelerate and stop.
- (11) While the operation error "M01 1270", "M01 1271" or "M01 1272" is occurring, all the axes are interlocked and the synchronous control operation method cannot be changed.
- (12) The "Reference position reached" signal (ZP1n to Zp4n) (X800) of the main axis and the sub axis in the simple synchronous control is output when the main axis reaches the reference position.
- (13) In the simple synchronous control, the signals to output to the sub axis (from NC to PLC) are uncertain except for the "Reference position reached" signal.
- (14) In the simple synchronous control, the signals to input to the sub axis (from PLC to NC) are ignored.
The sub axis in the simple synchronous control follows the "Servo OFF" signal (*SVFn) (Y7A0) of the main axis in the simple synchronous control.
When the main axis in the simple synchronous control is used as the slave axis in the synchronous control, the sub axis follows the "Servo OFF" signal of the master axis.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)


Multiple-axis synchronization control:

[Function] [Operation]

Multiple-axis synchronization control for the 1st part system is designated with the R2589 register, and for the 2nd part system with the R2789 register.

Multiple-axis synchronization control can be turned ON and OFF by setting the bits corresponding to each axis in this register.

The CNC changes the operation when all axes reach the in-position state.



• Designating the synchronous operation method

Turn ON both of bits corresponding to the axes, which are in a master-slave relationship, with the axis specification parameter "#2674 primno".

(Example) To operate the 2nd axis (master axis), 3rd axis (slave axis) and 4th axis (slave axis) in synchronization


	7	6	5	4	3	2	1	0	HEX
R2589	0	0	0	0	0	0	0	0	00
	0	0	0	0	1	1	1	0	0E

• Designating the independent operation method

This does not support the independent operation method.

When it is necessary to keep the synchronous state immediately after the power is turned ON due to the machine structure, set the R2589 register with the first ladder after the power is turned ON.

<Example of ladder creation>



When changing the operation with this register during automatic operation, turn ON the "Recalculation request" signal (YC2B) to calculate the coordinates again.

Request recalculation immediately after this register is changed.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

[Caution]

- (1) When bit5 of the parameter #1261 is OFF, use the same "Stroke end" signal (OT) for the master axis and slave axis.
Set the same soft limit value for the master axis and slave axis.
If the above settings cannot be made because of the machine specifications, observe the following points.
 - If stroke end or soft limit occurs during the manual operation mode, the master axis does not stop even when an alarm occurs for the slave axis. Thus, make sure that the master axis alarm turns ON before the slave axis alarm.
 - Stroke end during the manual operation mode causes the slave axis to stop when the "Stroke end" signal (OT) for the master axis turns ON; however, there may be a difference in their stop positions.
- (2) Set the same value of the SBT operation setting parameter for the master axis and slave axis.
The safe brake test (SBT: Safe Brake Test) of the master axis and slave axis is started by inputting the SBT start signal to the master axis during multiple-axis synchronization control.
When the SBT start signal is input to the slave axis, the smart safety observation alarm (V51 0005) occurs during multiple-axis synchronization control.
- (3) When the following signals are turned ON during multiple-axis synchronization control, the operation error (M01 0186) occurs.
When the multiple-axis synchronization control is performed while these functions are valid, the operation error (M50 5005) occurs.
 - "Tool handle feed mode" signal (YC5E)
 - "Rotation center error compensation enabled" signal (YD15)
 - "Spatial error compensation enabled" signal (YD17) (Machine with 4 axes or machine with 5 axes)
- (4) During multiple-axis synchronization operation, the master axis signals are valid for the "Interlock" and "Machine lock" signals, etc.
- (5) Do not turn OFF only the bit of the master axis while both bits of the master axis and the slave axis of this signal (R2589) are ON. To turn ON only the bit of the slave axis of this signal (R2589), once turn OFF all the bits of this signal (R2589), and then turn ON the bit of the slave axis.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool group No. designation		R2590, 1	R2790, 1	R2990, 1	R3190, 1	R3390, 1	R3590, 1	R3790, 1	R3990, 1

[Function]

The group No. is designated when the unused tool of a group that has exceeded lifetime with the tool life management II or when forcibly changing tools currently in use.

[Operation]

The group designation range is as follows.

For group designation: 1 to 9999 of group No.

For all groups: 65535 (all 1)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Reference position adjustment completion		R2592	R2792	R2992	R3192	R3392	R3592	R3792	R3992

[Function] [Operation]

Upon the completion of the reference position adjustment to establish the reference position in the dog-type reference position return, turn ON the bit corresponding to the master axis of the part system from PLC.

Then, turn OFF this signal after the corresponding bit of the "Reference position adjustment value parameter setting completed" signal is turned ON.

When the axis is outside the position switch range, execute an interlock on the axis and prohibit the movement of the target axis of the position switch.



(Example) When the 2nd axis is the master axis, set the bits as follows after the completion of the reference position adjustment for the slave axis.

	7 6 5 4 3 2 1 0 HEX
R2592	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 0 0 2

[Caution]

A change of the reference position adjustment value requires another reference position return. If the automatic operation is started without the reference position return, an alarm occurs to inform the incompleting return.


[Related signals]

- (1) Reference position adjustment value parameter setting completed (R576)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Current limit changeover		R2593	R2793	R2993	R3193	R3393	R3593	R3793	R3993

[Function] [Operation]

Droop will be released when the corresponding bit for the droop cancel request signal is OFF.

**[Related signals]**

- (1) In current limit n-th axis (ILI1 to 8: X900 to 7)
- (2) Current limit reached n-th axis (ILA1 to 8: X920 to 7)
- (3) Current limit changeover n-th axis (ILC1 to 8: Y9A0 to 7)
- (4) Droop cancel request n-th axis (DOR1 to 8: Y9C0 to 7)
- (5) Current limit mode 1 and 2 (ILM1,2: YCC0,1)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Wear compensation No. (tool presetter)		R2594	R2794	R2994	R3194	R3394	R3594	R3794	R3994

[Function]

To clear the wear compensation amount after measuring the tool compensation amount with manual tool length measurement, set the wear compensation No. in a BCD code.

[Operation]

When the sensor is touched by the tool, wear data of the compensation No. automatically specified will be cleared to "0". If "0" or a non-existing compensation No. is set, the wear data will not be cleared.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Workpiece coordinate offset measurement: Tool compensation No./Selected compensation tool No. (main)		R2600, 1	R2800, 1	R3000, 1	R3200, 1	R3400, 1	R3600, 1	R3800, 1	R4000, 1

[Function]**<External workpiece coordinate offset measurement function>**

Set the tool No. (R2602, 2603) and the tool compensation No. (R2600, 2601) used for workpiece coordinate offset measurement in a BCD code.

<Chuck barrier check>

Set the tool No. (R2602, 2603) and the compensation No. (R2600, 2601) selected for the chuck barrier check.

[Operation]**<Workpiece coordinate offset measurement function>**

Set the tool No. and the tool compensation No. used for workpiece coordinate offset measurement in a BCD code.

This is set with the user PLC. This tool No. (R2602, 2603) is interpreted as the tool offset No. by the CNC.

<Chuck barrier check>

The file register used differs according to the parameter (#1097 TIno.).

#1097 TIno.	R2600,2601/R2800,2801	R2602,2603/R2802,2803
0	Tool length, tool nose wear offset No.	Tool No.
1	Tool nose wear offset No.	Tool No., tool length compensation No.

If the tool length compensation No. is not designated (if the contents are 0), the tool length and tool nose wear offset will both follow the T command modal.

The T command modal will also be followed if the designated offset No. is not within the specified range.

If the T command modal value is "0", the compensation amount will be interpreted as "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Workpiece coordinate offset measurement: Tool No./Selected tool No. (main)		R2602, 3	R2802, 3	R3002, 3	R3202, 3	R3402, 3	R3602, 3	R3802, 3	R4002, 3

[Function] [Operation]

Refer to the explanation for R2600 and R2601 for details.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Selected tool compensation No. (sub)		R2604, 5	R2804, 5	R3004, 5	R3204, 5	R3404, 5	R3604, 5	R3804, 5	R4004, 5

[Function]**<Workpiece coordinate offset measurement function>**

Set the tool compensation No. used in the sub spindle side for external workpiece coordinate offset measurement in a BCD code.

<Chuck barrier check>

Designate the tool No. and compensation No. selected on the sub-spindle side for chuck barrier check.

[Operation]**<Workpiece coordinate offset measurement function>**

Set the tool compensation No. used in the sub spindle side for external workpiece coordinate offset measurement in a BCD code.

This is set with the user PLC.

<Chuck barrier check>

The file register used differs according to the parameter (#1097 TIno.).

#1097 TIno.	R2604,2605/R2804,2805	R2606,2607/R2806,2807
0	Tool length, tool nose wear offset No.	Tool No.
1	Tool nose wear offset No.	Tool No., tool length compensation No.

If the tool length compensation No. is not designated (if the contents are 0), both the tool length and tool nose wear offset follow the details designated for the main spindle. The details for the main spindle will also be set if the designated offset No. is not within the specified range.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Selected tool wear No. (sub)		R2606, 7	R2806, 7	R3006, 7	R3206, 7	R3406, 7	R3606, 7	R3806, 7	R4006, 7

[Function] [Operation]

Refer to the section for the "Selection tool compensation No. (sub) (R2604, 5)".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool mounting information m		R2608, 9	R2808, 9	R3008, 9	R3208, 9	R3408, 9	R3608, 9	R3808, 9	R4008, 9

[Function]

Designate the presence of a tool mounted on the tool post (tool compensation amount validity).

[Operation]

When the tool designated for tool mounting is selected, the tool compensation amount will be added to the chuck barrier check.

<Bit allocation>

Tool mounting information (high order)	bitF	bitE	bitD	bitC	bitB	bitA	bit9	bit8
R2609/ R2809	Tool 32	Tool 31	Tool 30	Tool 29	Tool 28	Tool 27	Tool 26	Tool 25
	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
	Tool 24	Tool 23	Tool 22	Tool 21	Tool 20	Tool 19	Tool 18	Tool 17

Tool mounting information (low order)	bitF	bitE	bitD	bitC	bitB	bitA	bit9	bit8
R2608/ R2808	Tool 16	Tool 15	Tool 14	Tool 13	Tool 12	Tool 11	Tool 10	Tool 9
	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
	Tool 8	Tool 7	Tool 6	Tool 5	Tool 4	Tool 3	Tool 2	Tool 1

Bit OFF: Tool not mounted (tool compensation amount not added)

Bit ON: Tool mounted (tool compensation amount added)

In a machine that uses tools 1 to 12 on the main spindle's tool post and tools 17 to 28 on the sub-spindle's tool post, if the tools are mounted in either tool post, H0FFF is set for both R2608 and R2609.

When tool 28 is detached from the sub-spindle side next, R2609 will be set to H07FF.

[Remark]

This signal is initialized to HFFFF when the power is turned ON.

Thus, if this signal is not used, the tool compensation amount will always be added to the chuck barrier check.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Multiple-spindle control I: Selected spindle No.	SLSPNO	R2614	R2814	R3014	R3214	R3414	R3614	R3814	R4014

[Function]

This signal gives information on the selected spindle (G43.1/G44.1 mode, spindle number) of each part system.

Note

- (1) The given information is the spindle number, not spindle name.
- (2) Bit8 and bit0 to bit7 become "0" when G47.1 (all spindle selection) mode is entered.

**[Operation]**

The information on selected spindle is output at the following timing.

<At power ON/NC reset>

The information on the currently selected spindle is output based on the parameter settings.

(Example)

\$1: Initial G43.1 mode ("#1199 Sselect" is "0", "#12090 SnG43.1" is "1", "#1534 SnG44.1" is "2")

R register for part systems (\$1)		
R2614	BIT8 = 0	1

\$2: Initial G44.1 mode ("#1199 Sselect" is "1", "#12090 SnG43.1" is "1", "#1534 SnG44.1" is "2")

R register for part systems (\$2)		
R2814	BIT8 = 1	2

\$3: Initial G47.1 mode ("#1199 Sselect" is "2")

R register for part systems (\$3)		
R3014	BIT8 = 0	0

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

<When G43.1/G44.1/G47.1 is commanded>




When G43.1/G44.1/G47.1 command is executed, the information on selected spindle after command execution is output.

(Example) 1st spindle Spindle name: 1 ("#3077 Sname" is "1")

"#12090 SnG43.1" is "1"

2nd spindle Spindle name: 2 ("#3077 Sname" is "2")

"#1534 SnG44.1" is "2"



<When G44.1D is commanded>

When G44.1D command is executed, the information on selected spindle after command execution is output.



(Example) 1st spindle Spindle name: 1 ("#3077 Sname" is "1")

2nd spindle Spindle name: 2 ("#3077 Sname" is "2")

3rd spindle Spindle name: 5 ("#3077 Sname" is "5")

4th spindle Spindle name: 8 ("#3077 Sname" is "8")

"#1534 SnG44.1" is "2"



4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Rotary axis configuration parameter switch	RPARCH G	R2615	R2815	R3015	R3215	R3415	R3615	R3815	R4015

[Function]

This switches the rotary axis configuration parameters.


[Operation]**<Low-order 8 bits: Configuration No. of rotary axis configuration parameter>**

This specifies the configuration No. of rotary axis configuration parameter.


Setting range: 1 to the number of effective part systems

<High-order 8 bits: Switching command of rotary axis configuration parameter>

When "Rotary axis configuration parameter switch request" signal (bit8) turns ON, the configuration set to the "Configuration No. of rotary axis configuration parameter" will be valid.



- ♦ This register is cleared when the power is turned ON.
- ♦ Turn ON the "Rotary axis configuration parameter switch request" signal before using the following functions.
If the "Rotary axis configuration parameter switch request" signal is turned ON while any of the following functions is performed, the operation error (M01 0187) occurs.
 - Tool center point control
 - Inclined surface machining
 - Workpiece installation error compensation
 - Tool length compensation along the tool axis
 - Simple inclined surface machining
 - 3-dimensional tool radius compensation
 - 3-dimensional manual feed
 - Tool handle feed & interruption
 - R-Navi
- ♦ This signal is valid only when "#1450 5axis_Spec/bit0" (Axis name setting method of rotary axis configuration parameter) is set to "1" and "#1450 5axis_Spec/bit2" (Application of rotary axis configuration parameters) is set to "1".

[Timing chart]**[Related signals]**

- (1) Rotary axis configuration parameter output (RPAROUT: R656)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Tool length measurement 2 Tool No.		R2618	R2818	R3018	R3218	R3418	R3618	R3818	R4018

[Function]

Set the compensation No. of the tool data for setting the measurement result during manual tool length measurement II.
This is set in BCD code.

[Operation]

When the sensor is touched by the tool, compensation amount will be written into the tool data of the compensation No. automatically specified.

This tool No. is interpreted as the tool compensation No. by the CNC.

[Related signals]

- (1) Wear compensation No. (R2594)
- (2) Tool length measurement 2 (TLMS: YC21)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Constant torque control: Constant torque/proportional torque stopper control request axis		R2620	R2820	R3020	R3220	R3420	R3620	R3820	R4020

[Function]

This signal commands constant torque control or proportional torque stopper control. By turning the axis bit of a part system ON, constant torque control or proportional torque stopper control is performed for the corresponding axis.

BIT	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
Axis	8	7	6	5	4	3	2	1	8	7	6	5	4	3	2	1
	Proportional torque stopper control request axis								Constant torque control request axis							

Note

- (1) The axis bit configuration for part systems are the same as the basic axis configuration.

[Operation]**<High-order 8 bits: The Proportional torque stopper control request axis bit>**

When the bit of the specified axis turns ON, the servomotor for the axis generates a constant torque in the stopper direction according to the value that is set in "#2296 SV096 TQC" (Stopper torque for constant torque control). When a position droop occurs, the stopper position is maintained with a torque generated in proportion of the position droop.

<Low-order 8 bits: The Constant torque control request axis bit>

When the bit of the specified axis turns ON, the servomotor for the axis outputs a constant torque in a constant direction according to the value that is set in "#2296 SV096 TQC" (Stopper torque for constant torque control).

[Related signals]

- (1) Constant torque control: Axis under constant torque/proportional torque stopper control (R624)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Constant torque control: Constant torque droop cancel request axis		R2621	R2821	R3021	R3221	R3421	R3621	R3821	R4021

[Function]

This signal commands constant torque droop cancellation. By turning the axis bit of a part system ON, constant torque droop cancellation is performed for the corresponding axis.

BIT	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
Axis	8	7	6	5	4	3	2	1	8	7	6	5	4	3	2	1
	Not used.								Constant torque droop cancel request axis							

Note

- (1) The axis bit configuration for part systems are the same as the basic axis configuration.

[Operation]

Position droop cancellation and command position update are performed when the axis bit is turned ON for an axis for which you want to clear the position droop generated during constant torque control.

[Related signals]

- (1) Constant torque control: Constant torque droop cancel axis status (R625)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Servo ready completion output designation		R2625	R2825	R3025	R3225	R3425	R3625	R3825	R4025

[Function]

The "Servo ready completion" signal (SA) indicates that the servo system is ready for normal operation. The signal can be output to a Y device of remote I/O, which is designated by this register.

The direct transfer of the signal from CNC to remote I/O allows the output of the signal during PLC is stopped.

[Operation]

The first setting data since the power ON is valid. Only the first setting is valid. The value changed later is invalid.

The setting range is 1 to 5FF (HEX). 2C0 to 2FF is excluded from the range.

If the first setting of Y device No. is out of range, the signal is not output to the Y device. To output the signal, turn the power ON again and then set the Y device No. again within the range.

[Caution]

- (1) Setting "0" does not mean the output to Y0. This setting is invalid.
- (2) If the "Servo ready completion" signal is OFF on either of the R registers (among R2625/R2825/R3025/R3225) with the overlapped setting value, the signals to be output to Y device turn OFF.
- (3) Y2C0 to 2FF, which are used by the system, cannot be set as servo ready completion output designation.
- (4) This register, if designated after the "Servo ready completion" signal is ON without initial ladders, turns valid from the time of the setting and the signal is output to Y device.
- (5) The devices Y300 to Y5FF are available when the external PLC link such as PROFIBUS-DP and CC-Link is connected.
- (6) Do not control the designated Y devices with user PLC. When the device is controlled with user PLC, the "Servo ready completion" signal is overwritten and turns invalid.
- (7) If the servo ready completion output designation, which has not been set with this register, is written twice in 1 scan of user PLC, the latter setting is valid.

[Related signals]

- (1) Servo ready completion (SA: XC11)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Thread recutting command		R2626	R2826	R3026	R3226	R3426	R3626	R3826	R4026

[Function]

This signal commands memorization or deletion of the position data that is used by the thread recutting function.

This signal needs to be set from the ladder when the thread recutting operation from the ladder ("#1258 set30/bit4" is set to "1") is selected.

When the thread recutting operation on the CNC screen ("#1258 set30/bit4" is set to "0") is selected, thread recutting operation is disabled even if this signal is set.

**[Operation]**

Bit of R2626	Meaning	Details
0	Memory	If this bit is ON when the command is executed, the CNC stores "spindle number", "spindle position", "lead axis number" and "lead axis machine coordinate" in the CNC memory.
1	Erase	If this bit is ON when the command is executed, the CNC erases "spindle number", "spindle angle", "lead axis number" and "lead axis machine coordinate" from the CNC memory.
7	Command execution	The CNC performs "Memory" (bit0) or "Erase" (bit1) operation at the rising edge of this bit. An error occurs if both "Memory" and "Erase" bits are ON or OFF.
8 to F	Lead axis number	The lead axis number of the axis that performs thread recutting is set in binary using these bits. The range of numbers that can be set is 0x00 to 0xFF. Set the 1st axis to "1" in the command. The number in the command is memorized as the lead axis number.

[Related signals]

- (1) Thread recutting status (R648)
- (2) Thread recutting lead axis No. (R651)


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Thread recutting execution operation		R2627	R2827	R3027	R3227	R3427	R3627	R3827	R4027

[Function]

This signal commands various operations related to thread recutting.

This signal needs to be set from the ladder when the thread recutting operation from the ladder ("#1258 set30/bit4" is set to "1") is selected.

When the thread recutting operation on the CNC screen ("#1258 set30/bit4" is set to "0") is selected, thread recutting operation is disabled even if this signal is set.

**[Operation]**

Bit of R2627	Meaning	Details
F	Thread recutting function enabled	Turn this bit ON to perform thread recutting. When thread recutting can be performed, bitF of the "Thread recutting execution status" signal (R649) turns ON. To perform normal thread cutting, turn this bit OFF.

[Related signals]

- (1) Thread recutting execution status (R649)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Mechanical axis specifications 1st rotary axis angle		R2628, 9	R2828, 9	R3028, 9	R3228, 9	R3428, 9	R3628, 9	R3828, 9	R4028, 9
A	Mechanical axis specifications 2nd rotary axis angle		R2630, 1	R2830, 1	R3030, 1	R3230, 1	R3430, 1	R3630, 1	R3830, 1	R4030, 1


[Function]

This signal sets rotary axis angle of the mechanical axis specifications.

The setting range is 0 to ± 720000 (1 degree/1000).

[Operation]

When the handle is fed in the tool axis direction/tool radius direction in the mechanical axis specifications, the angle of the rotation axis, which is the direction of the tool, can be input by writing the angle in the R register with the user PLC.



R register	Details	Input range
R2628 R2629	Mechanical axis specifications 1st rotary axis angle R2628 (low order)/R2629 (high order)	0 to ± 720000 (1 degree/1000)
R2630 R2631	Mechanical axis specifications 2nd rotary axis angle R2630 (low order)/R2631 (high order)	0 to ± 720000 (1 degree/1000)

(Example) Writing 90 degrees on A axis and 180 degrees on C axis with A-C axes configuration is shown below.

A axis: 90 \times 1000 = 90000 \rightarrow [DMOV K90000 R2628]
 angle 1/1000degree System unit

C axis: 180 \times 1000 = 180000 \rightarrow [DMOV K180000 R2630]
 angle 1/1000degree System unit

[Caution]

- (1) The tool center point rotation mode cannot be used while the mechanical axis is in use.
- (2) Do not change the rotary axis angle of the mechanical axis during tool handle feed & interruption.
- (3) When the angle of the mechanical axis is written to the R register, only the tool center point value counter on the position display screen is updated. Other counters are not updated.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Simple inclined surface machining command: Tool axis rotation angle compensation amount	TAN-GOFS	R2634, 5	R2834, 5	R3034, 5	R3234, 5	R3434, 5	R3634, 5	R3834, 5	R4034, 5

[Function]

This signal is to compensate the reference position of rotation angle for the rotary axis of tool side during the modal of simple tool center point control (G174) or when tool axis direction control (G53.1) is commanded.

R register of the part system where the rotary axis exists is applied by the reset condition.

[Operation]

The angle of tool side rotary axis is based on the angle set in the tool axis rotation angle compensation amount.

The tool axis rotation angle compensation amount validates the data at the time of G174/G53.1 command. However, when the data is changed during G174 mode, it will not be valid.

Setting range: -359999 to 359999 (Increment 0.001[°])

Regardless of the input unit, a value is incremented by 0.001[°] .


Note

- (1) The tool axis rotation angle compensation amount is cleared at the power ON. Set this signal before commanding G174/G53.1.
- (2) To use a tool with turret, set the offset angle information of the tool for the reference position rotation angle to this compensation amount. It is possible to perform machining using an arbitrary tool on the turret by setting the angle information before commanding G174/G53.1.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Circular feed in manual mode Operation mode data		R2636, 7	R2836, 7	R3036, 7	R3236, 7	R3436, 7	R3636, 7	R3836, 7	R4036, 7

[Function]

The operation mode for the circular feed in manual mode is designated.

[Operation]

R2637
R2837
R3037
R3237

F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

Operation mode: Designate the coordinate setting.

Setting value	Description
1	Linear-linear coordinate is selected.
2	Circular-linear coordinate is selected. ("+" indicates the CW direction of the horizontal axis (H).)
3	Circular-linear coordinate is selected. ("+" indicates the CCW direction of the horizontal axis (H).)

The setting value other than above is invalid.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Vertical axis (V) mirror image: Reverse the "+" direction of the vertical axis (V).

Vertical axis (V) is determined by the plane selection mode.

Setting value	Description
0	Vertical axis (V) mirror image is not valid
1	Vertical axis (V) mirror image is valid

Plane selection mode: Specifies a virtual coordinate system plane on the machine coordinate system.

Plane selection mode		Plane	Horizontal axis (H)	Vertical axis (V)
bitF	bitE			
0	0	Not specified	1st axis of NC axis	2nd axis of NC axis
0	1	XY	#1026 Base axis I	#1027 Base axis J
1	0	ZX	#1028 Base axis K	#1026 Base axis I
1	1	YZ	#1027 Base axis J	#1028 Base axis K

[Caution]

- (1) This data is enabled at the rising edge of the "Circular feed in manual mode valid" signal.
- (2) The data is not enabled even if it is changed while the "Circular feed in manual mode valid" signal is ON.

[Related signals]

- (1) Circular feed in manual mode valid (YC7E)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Circular feed in manual mode Reference point H data		R2644, 5	R2844, 5	R3044, 5	R3244, 5	R3444, 5	R3644, 5	R3844, 5	R4044, 5
A	Circular feed in manual mode Reference point V data		R2648, 9	R2848, 9	R3048, 9	R3248, 9	R3448, 9	R3648, 9	R3848, 9	R4048, 9

[Function]

Designate a reference point on the hypothetical coordinate.

[Operation]

Designate a reference point on the hypothetical coordinate using the machine coordinate system.

The setting range differs in each PLC setting unit.

	PLC setting unit	
	mm	inch
(B)	±99999.999 mm	±3937.0078 inch
(C)	±9999.9999 mm	±393.70078 inch

[Caution]

- (1) This data is enabled at the rising edge of the "Circular feed in manual mode valid" signal.
- (2) The data is not enabled even if it is changed while the "Circular feed in manual mode valid" signal is ON.
- (3) The reference point coordinate is designated with "0.5×PLC setting unit".
- (4) When the parameter "#1040 M_inch" is set to "1", the data is set in inches.

[Related signals]

- (1) Circular feed in manual mode valid (YC7E)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Circular feed in manual mode travel range H (+) data		R2652, 3	R2852, 3	R3052, 3	R3252, 3	R3452, 3	R3652, 3	R3852, 3	R4052, 3
A	Circular feed in manual mode travel range H (-) data		R2656, 7	R2856, 7	R3056, 7	R3256, 7	R3456, 7	R3656, 7	R3856, 7	R4056, 7
A	Circular feed in manual mode travel range V (+) data		R2660, 1	R2860, 1	R3060, 1	R3260, 1	R3460, 1	R3660, 1	R3860, 1	R4060, 1
A	Circular feed in manual mode travel range V (-) data		R2664, 5	R2864, 5	R3064, 5	R3264, 5	R3464, 5	R3664, 5	R3864, 5	R4064, 5

[Function]

Designate the travel range on the hypothetical coordinate.

[Operation]

Designate the travel ranges with the value in the "+" or "-" direction on the hypothetical coordinate. Set the hypothetical coordinate value in the following state.

Linear-linear hypothetical coordinate	V' axis: mirror image is not valid
Circular-linear hypothetical coordinate	H' axis: "+" indicates the inverse (CW) direction V' axis: mirror image is not valid

In the "circular-linear" mode, set the travel range of H' on the hypothetical coordinate by an angle with the basic point defined as 0 degree.

The setting range differs in each PLC setting unit.

	PLC setting unit		
	mm	inch	angle
(B)	±99999.999 mm	±3937.0078 inch	±360.000°
(C)	±9999.9999 mm	±393.70078 inch	±360.0000°

[Caution]

- (1) The data is enabled as soon as it is changed while the "Circular feed in manual mode valid" signal is ON.
- (2) The reference point is treated as zero point on the hypothetical coordinate.
- (3) The moving range is designated with "0.5×PLC setting unit".
- (4) When the parameter "#1040 M_inch" is set to "1", the data is set in inches.

[Related signals]

- (1) Circular feed in manual mode valid (YC7E)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Circular feed in manual mode gradient/ arc center H data		R2668, 9	R2868, 9	R3068, 9	R3268, 9	R3468, 9	R3668, 9	R3868, 9	R4068, 9
A	Circular feed in manual mode gradient/ arc center V data		R2672, 3	R2872, 3	R3072, 3	R3272, 3	R3472, 3	R3672, 3	R3872, 3	R4072, 3

[Function]

Designate the gradient on the "linear-linear" hypothetical coordinate, or the arc center on the "circular-linear" hypothetical coordinate.

[Operation]

How to designate differs in each operation mode.

Operation mode is "Linear-linear"(*1)	Use the ratio of H/V to designate the gradients of H axis on the machine coordinate and H' axis on the hypothetical coordinate. Signs are available. "+" indicates the CCW direction from the H axis. If the gradient is 45°, H and V should have the same value. The designation unit follows the PLC setting unit. PLC setting unit (B) : ±99999.999 PLC setting unit (C) : ±9999.9999
Operation mode is "Arc-linear"(*1)	Designate an arc center on the hypothetical coordinate using the machine coordinate system. The designation unit follows the PLC setting unit. [Millimeter] PLC setting unit (B) : ±99999.999 [mm] PLC setting unit (C) : ±9999.9999 [mm] [Inch] PLC setting unit (B) : ±3937.0078 [inch] PLC setting unit (C) : ±393.70078 [inch]

(*1) Refer to the section on "Circular feed in manual mode operation mode data" (R2636) for the operation mode.

[Caution]

- (1) This data is enabled at the rising edge of the "Circular feed in manual mode valid" signal.
- (2) The data is not enabled even if it is changed while the "Circular feed in manual mode valid" signal is ON.
- (3) The arc center coordinate and gradient are designated with "0.5×PLC setting unit".
- (4) When the parameter "#1040 M_inch" is set to "1", set the data in inches.

[Related signals]

- (1) Circular feed in manual mode valid (YC7E)

Cont.	Signal name	Abbrev.	Common (\$)
A	3D machine interference check: Enabled shape group No. 1 to 4		R4400 to 3

[Function]

This signal is used to update the shape group of the 3D machine interference check or real-time 3D machine interference check. Set the No. of shape group which is currently specified as the interference check target. This signal is enabled while the machine interference check is being performed.

If a shape group is selected on the [3D Monitor] screen, the group No. is set in the "3D machine interference check: Requested shape group No." signal (R2400). Then set this value in the "Enabled shape group No." signal.

[Operation]

When the "Enabled shape group No." changes, the jig or workpiece model is updated. The machine interference check is implemented using the updated model.

If the setting is changed during axis movement, the axis will decelerate to a stop while the model is being updated.

Note

- (1) This signal is inoperative during automatic operation.
- (2) Shapes defined in Group 1 are within the scope of the interference check. Interference check is not executed for the shape defined in Groups 2 to 4.

[Related signals]

- (1) 3D Machine Interference Check : Requested shape group No. (R2400)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Ext. machine coordinate system offset data n-th axis		R5700 to 15	R5716 to 31	R5732 to 47	R5748 to 63

[Function]

This data compensates the basic machine coordinate system. The axis moves the amount equivalent to the set data (machine error compensation unit). The entire coordinate system value, including the basic machine coordinate system, will not change.

[Operation]

When the "Ext. machine coordinate system offset data" (R5700 to 15) is set, the axis will move the amount equivalent to that set value.

The entire coordinate system value, including the basic machine coordinate system, will not change.

If the changed amount of the set value exceeds the rapid traverse feedrate, the set value turns invalid: the compensation is executed with the set value unchanged.

<Data range>

80000000 (HEX) to 7FFFFFFF (HEX) (Absolute compensation amount -2147483648 to 2147483647)

Unit: Machine error compensation unit

[Related signals]

(1) Ext. machine coordinate system offset data illegal n-th axis (XA40 to XA47)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4
A	Each axis manual feedrate B n-th axis		R5764 to 5779	R5780 to 5795	R5796 to 5811	R5812 to 5827

[Function]

When the "Each axis manual feedrate B valid" signal is valid, designate the manual feedrate for the axis selected with the "Manual feedrate B valid" signal.

[Operation]

- When the "Each axis manual feedrate B valid" signal is valid, the each axis speed designated with this register is valid for the manual feedrate of an axis for which the "Manual feedrate B valid" signal is valid.
- Cutting override and manual override are invalid for this register's speed.
- This register is not related to the dry run speed.
- A binary value is directly set for this register. The setting unit is 0.01mm/min (°/min).
- This signal is a register independent for each axis.

[Related signals]

(1) Manual feedrate B valid (FBEn: Y940 to Y947)

(2) Each axis manual feedrate B valid (YC7C)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	User macro input #1032 (PLC -> NC)		R6436, 7	R6444, 5	R6452, 3	R6460, 1	R6468, 9	R6476, 7	R6484, 5	R6492, 3

[Function]

This provides interface function used to coordinate user PLC to user macro.

Note

- (1) The other signals from R0 to R99 are PLC inputs, but this signal is output to the NC from PLC.

[Operation]

The data set in file registers Rn and Rn+1 with the user PLCs, can be referred to on the user macro side with the user macro system variables #1000 to #1031 or #1032.

The relationship between system variable and file register is as follows:

System variable	Points	Interface input signal	System variable	Points	Interface input signal
#1000	1	Register R6436 bit0	#1016	1	Register R6437 bit0
#1001	1	Register R6436 bit1	#1017	1	Register R6437 bit1
#1002	1	Register R6436 bit2	#1018	1	Register R6437 bit2
#1003	1	Register R6436 bit3	#1019	1	Register R6437 bit3
#1004	1	Register R6436 bit4	#1020	1	Register R6437 bit4
#1005	1	Register R6436 bit5	#1021	1	Register R6437 bit5
#1006	1	Register R6436 bit6	#1022	1	Register R6437 bit6
#1007	1	Register R6436 bit7	#1023	1	Register R6437 bit7
#1008	1	Register R6436 bit8	#1024	1	Register R6437 bit8
#1009	1	Register R6436 bit9	#1025	1	Register R6437 bit9
#1010	1	Register R6436 bit10	#1026	1	Register R6437 bit10
#1011	1	Register R6436 bit11	#1027	1	Register R6437 bit11
#1012	1	Register R6436 bit12	#1028	1	Register R6437 bit12
#1013	1	Register R6436 bit13	#1029	1	Register R6437 bit13
#1014	1	Register R6436 bit14	#1030	1	Register R6437 bit14
#1015	1	Register R6436 bit15	#1031	1	Register R6437 bit15

System variable	Points	Interface input signal
#1032	32	Register R6436, R6437
#1033	32	Register R6438, R6439
#1034	32	Register R6440, R6441
#1035	32	Register R6442, R6443

This correspondence table shows the example for file registers R6436 and R6437.

File registers R6436 and R6437 correspond to system variables #1000 to #1031, and #1032 (32-bit data).

To use the R register of the 2nd and subsequent part system, set "#1230 set02/bit7" to "1".

[Related signals]

- (1) User macro input #1033, #1034, #1035 (R6436/6437, R6438/6439, R6440/6441, R6442/6443)
- (2) User macro output #1132, #1133, #1134, #1135 (R6372/6373, R6374/6375, R6376/6377, R6378/6379)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	User macro input #1033 (PLC -> NC)		R6438, 9	R6446, 7	R6454, 5	R6462, 3	R6470, 1	R6478, 9	R6486, 7	R6494, 5


[Function]

This provides interface function used to coordinate user PLC to user macro.

[Operation]

The data set in file registers Rn and Rn+1 with the user PLCs, can be referred to on the user macro side with the user macro system variables #1033.

(Example)

**[Related signals]**

- (1) User macro input #1032, #1034, #1035 (R6436/6437, R6440/6441, R6442/6443)
- (2) User macro output #1132, #1133, #1134, #1135 (R6372/6373, R6374/6375, R6376/6377, R6378/6379)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	User macro input #1034 (PLC -> NC)		R6440, 1	R6448, 9	R6456, 7	R6464, 5	R6472, 3	R6480, 1	R6488, 9	R6496, 7

[Function] [Operation]

The function, operation, etc. are the same as those of "User macro input #1033".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	User macro input #1035 (PLC -> NC)		R6442, 3	R6450, 1	R6458, 9	R6466, 7	R6474, 5	R6482, 3	R6490, 1	R6498, 9

[Function] [Operation]

The function, operation, etc. are the same as those of "User macro input #1033".

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle command rotation speed output		R7000, 1	R7050, 1	R7100, 1	R7150, 1	R7200, 1	R7250, 1	R7300, 1	R7350, 1


[Function]

By setting data of desired spindle speed to this signal, the spindle can be rotated at that speed.

[Operation]

When this signal is used, operation is same as the case where usual spindle command rotation speed input signal (R6500, 1) is given. Difference is that when data is set by user PLC, priority is given to that data over spindle (S) command data specified in automatic operation, or by manual command setting.

User PLC main (medium-speed) operation pattern

**Note**

- (1) Spindle command rotation speed output data is rewritten by user PLC for each scan (constant).
- (2) Spindle speed override, "Spindle gear selection code 1,2" (GI1, GI2), "Spindle stop" (SSTP), "Spindle gear shift" (SSFT) and "Spindle orientation" (SORC) conditions are added to Spindle command rotation speed output data and sent to the spindle controller.
- (3) For flow of spindle (S) function command data, data update timing, etc., refer to the section for normal "Spindle command rotation speed input" signal (R6500, 1).

[Related signals]

- (1) Spindle command rotation speed input (R6500, R6501)
- (2) Spindle command final data (R6502, R6503)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle command selection	SLSP	R7002	R7052	R7102	R7152	R7202	R7252	R7302	R7352

[Function]

This signal sets from which system the S command is received when the multiple-spindle control II is valid.

0: 1st part system

1: 2nd part system

2: 3rd part system

3: 4th part system

Note

- (1) If a setting value exceeds the maximum number of part systems determined by specifications, it will be interpreted that a selection has not been made.

[Operation]

If an S command is given while the "Spindle selection" (SWS) and the "Spindle command selection" (SLSP) have already been input through different blocks, this S command is handled as a rotation speed command of the selected spindle. The selected spindle rotates at the rotation speed which was output. The spindle deselected by turning OFF the "Spindle selection" signal (SWS) continues to rotate at the same rotation speed as the rotation speed immediately before the deselection. This allows each spindle to be rotated simultaneously at a different rotation speed. The "Spindle command selection" signal is used to select which of the spindles is to receive the S command from which part system.

[Caution]

Even though the "Spindle selection" (SWS) or the "Spindle command selection" (SLSP) is performed with the M command in the same block as the S command, the spindle selection command (spindle rotation speed) is not updated.

[Related signals]

- (1) Spindle selection (SWS: Y18A8)
- (2) Spindle stop (SSTP: Y1894)
- (3) Spindle enable (ENB: X18A0)
- (4) Encoder selection (R2567)
- (5) Spindle forward run start (SRN: Y1898)
- (6) Spindle reverse run start (SRI: Y1899)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	S command override		R7008	R7058	R7108	R7158	R7208	R7258	R7308	R7358

[Function]

When "Spindle override method selection" signal is set to "file register method", override can be exerted on the spindle rotation speed besides the code method override (SP1 to SP4).

Override can be exerted within range of 0% to 200% (1% increment).


Desired value is set to file register (R) in binary code.

[Operation]

When this function is used, the true spindle speed is obtained by multiplying the originally set spindle speed by override ratio set with this signal.

Clamp spindle speed is the maximum or minimum speed set with parameters, which depends on the "Spindle gear selection code 1,2" signal (GI1, GI2). (Both are set to parameters.)

Even when spindle speed exceeds the maximum or minimum speed at the currently selected gear stage, due to change of override setting, the "Spindle gear shift" signal (GR1, GR2) does not automatically change.



Applicable override range at gear stage 3

GR10 : Applicable override range at gear stage
 GR20 : Applicable override range at gear stage
 GR30 : Applicable override range at gear stage
 Smini : Minimum spindle speed (parameter)
 Smax1: Maximum spindle speed at gear stage 1 (parameter)
 Smax2: Maximum spindle speed at gear stage 2 (parameter)
 Smax3: Maximum spindle speed at gear stage 3 (parameter)

Note

(1) Override is not valid (100%) under the following conditions:

- ♦ The "Spindle stop" signal (SSTP) is ON.
- ♦ During tapping mode
- ♦ During thread cutting

[Related signals]

- (1) Spindle speed override code m (SPn: Y1888)
- (2) Spindle override method selection (SPS: Y188F)
- (3) Spindle gear selection code 1,2 (GI1, GI2: Y1890, Y1891)
- (4) Spindle stop (SSTP: Y1894)
- (5) Spindle gear shift (SSFT: Y1895)
- (6) Spindle orientation (SORC: Y1896)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Multi-point orientation position data		R7009	R7059	R7109	R7159	R7209	R7259	R7309	R7359

[Function]

This signal has the following two functions:

- Notification of orientation position to control unit (spindle controller) at orientation command.
Position data where the "Spindle orientation command" (ORC) is turned ON.
- During multi-point indexing, notification of indexing position during forward run indexing or reverse run indexing to control unit (spindle controller).
Position data where the "Spindle forward run index" (WRN), the "Spindle reverse run index" (WRI) is turned ON.

[Operation]**<Orientation command>**

The orientation position, at which the "Spindle orientation command" (ORC) turns ON, is input.

The values designated with the spindle specification parameter (position shift amount for orientation) and with the "Multi-point orientation position data" signal are totaled to determine the orientation position.

<Multi-point indexing>

Each time the "Spindle forward run index" (WRN) and "Spindle reverse run index" (WRI) turn ON, the axis rotates by the amount designated with the multi-point orientation position data.

Command value is handled as 16-bit binary data and its increment is as follows.


Command increment = 360/36000 (0.01°)

<Turret indexing>

The turret angle is designated when the turret indexing is valid (when "#3121 tret" is set to "1").

The spindle rotation angle will be the multi-point orientation position data which is multiplied by the turret side gear ratio (in "#3122 GRC").

This signal must be validated before the "Spindle orientation command" signal turns ON (at least 100 ms before).

**[Related signals]**

- (1) Spindle orientation command (ORC: Y189E)
- (2) Spindle forward run index (WRN: Y189C)
- (3) Spindle reverse run index (WRI: Y189D)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Interface of load meter for analog I/F spindle	ANSLD	R7012	R7062	R7112	R7162	R7212	R7262	R7312	R7362

[Function] [Operation]

When the parameter "#3024 sout" (spindle connection) is set to "2" to "5", the value set in this signal appears as an absolute value in the "Load" (%) on the load meter display screen. The graphical display for load meter varies depending on the value set in this signal.

Set the load in the range of "-999" to "999".

When the set value exceeds the setting range, a value clamped with the upper or lower limit is displayed.

Note

- (1) The unit is percentage (%).
- (2) The data format is signed binary.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle synchronization: Reference spindle selection		R7016	R7066	R7116	R7166	R7216	R7266	R7316	R7366

[Function]

Select the reference spindle to be used for synchronous control from the PLC.

[Operation]

Select the spindle to be controlled as the reference spindle from the serially connected spindles.

(0: 1st spindle), 1: 1st spindle, 2: 2nd spindle, 3: 3rd spindle, 4: 4th spindle, 5: 5th spindle, 6: 6th spindle, 7: 7th spindle, 8: 8th spindle

Note

- (1) When a spindle that is not serially connected is selected, spindle synchronous control will not be executed.
- (2) When "0" is designated, the 1st spindle will be controlled as the reference spindle.

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle synchronization: Synchronized spindle selection		R7017	R7067	R7117	R7167	R7217	R7267	R7317	R7367

[Function]

Select the synchronized spindle to be used for synchronous control from the PLC.

[Operation]

Select the spindle to be controlled as the synchronized spindle from the serially connected spindles.

(0: 2nd spindle), 1: 1st spindle, 2: 2nd spindle, 3: 3rd spindle, 4: 4th spindle, 5: 5th spindle, 6: 6th spindle, 7: 7th spindle, 8: 8th spindle

Note

- (1) If a spindle that is not serially connected is selected or if the same spindle as the reference spindle is selected, spindle synchronous control will not be executed.
- (2) If "0" is designated, the 2nd spindle will be controlled as the synchronized spindle.

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle synchronization: Phase shift amount		R7018	R7068	R7118	R7168	R7218	R7268	R7318	R7368

[Function]

The phase shift amount for the synchronized spindle can be designated from the PLC.

[Operation]

Designate the phase shift amount for the synchronized spindle.

Unit: 360°/4096

[Related signals]

- (1) In spindle synchronization (SPSYN1: X18A8)
- (2) Spindle rotation speed synchronization completion (FSPRV: X18A9)
- (3) Spindle phase synchronization completion (FSPPH: X18AA)
- (4) Spindle synchronization (SPSY: Y18B0)
- (5) Spindle phase synchronization (SPPHS: Y18B1)
- (6) Spindle synchronous rotation direction (Y18B2)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle synchronization: Phase error tolerance		R7019	R7069	R7119	R7169	R7219	R7269	R7319	R7369

[Function]

This signal specifies the tolerable range of the actual position delay (or advance) of the reference and synchronized spindles with respect to the position command, which is applied after the phase alignment under the absolute position spindle synchronization. The tolerance is specified by the angle.

[Operation]

Delay or advance angle of the actual position with respect to the commanded position

<Data range>

F001 (HEX) to 0FFF (HEX) (-359.9° to 359.9°)

Unit: 360°/4096

Note

- (1) Output the 1st spindle's signal while "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is "0".
- (2) Output the synchronized spindle's signal while "#1440 multi_sp_syn" (Multiple spindle synchronization valid) is "1".

[Related signals]

- (1) In spindle synchronization (SPSYN1: X18A8)
- (2) Spindle rotation speed synchronization completion (FSPRV: X18A9)
- (3) Spindle phase synchronization completion (FSPPH: X18AA)
- (4) Spindle synchronization/superimposition cancel (SPSYC: Y18B8)
- (5) Spindle synchronization: Phase error over (SPPHOV: X18B0)
- (6) Spindle synchronization: Phase error/Hob axis delay angle (R6516)
- (7) Spindle synchronization: Maximum phase error/Maximum hob axis delay angle (R6517)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle oscillation amplitude		R7020	R7070	R7120	R7170	R7220	R7270	R7320	R7370

[Function]

This signal is used to set the amplitude of the spindle oscillation.

The effective setting range: 1 to 32767 [0.01°]

[Related signals]

- (1) Spindle oscillation command (Y18C8)
- (2) Spindle oscillation frequency (R7021)

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle oscillation frequency		R7021	R7071	R7121	R7171	R7221	R7271	R7321	R7371

[Function]

This signal is used to set the frequency of the spindle oscillation.

The effective setting range: 1 to 140 [Hz]

[Related signals]

- (1) Spindle oscillation command (Y18C8)
- (2) Spindle oscillation amplitude (R7020)

Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
PLC axis indexing control command 4	AUXCM4	R8050	R8056	R8062	R8068	R8074	R8080	R8086	R8092

Cont.	Signal name	Abbrev.	bit
A	Speed override 1 to 64	OV1 to OV64	AUXCM4/bit0 to 6

[Function] [Operation]

This signal designates the override value added to the selected feedrate. Set a binary value for the override. Values over 100% are regarded as 100%.

Effective feedrate = (Selected speed × Speed override) / 100

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	bit
A	Speed override valid	OVR	AUXCM4/bit7

[Function] [Operation]

This is a signal to validate the speed override. When this signal is turned OFF, the set feedrate becomes the operation speed without calculating the override.

Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
PLC axis indexing control command 3	AUXCM3	R8051	R8057	R8063	R8069	R8075	R8081	R8087	R8093

Cont.	Signal name	Abbrev.	bit
A	Station selection 1 to 256	ST1 to ST256	AUXCM3/bit0 to 8

[Function]

This signal designates an index station No. in the automatic operation mode.

[Operation]

Set an index station No. before inputting the "Operation start" (ST) in the automatic operation mode.

Input a 9-digit binary number. An input "000000001" corresponds to station No.1.

This signal is read in at the rising edge of the "Operation start" (ST). The signal changes are ignored after the startup.

When this signal is set to "000000000" and the automatic operation is started, a one-station rotation special command is issued. (Note that this cannot be used when the station positions are determined in non-uniform assignments.)

Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
PLC axis indexing control command 2	AUXCM2	R8052	R8058	R8064	R8070	R8076	R8082	R8088	R8094

4 Explanation of Interface Signals


4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	bit
A	Operation start	ST	AUXCM2/bit0

[Function] [Operation]

When this signal is turned ON in the operation mode, the operation starts. Since the "Operation start" signal is handled as a status, the ON status must be maintained until the end of operation.

Operation movement in each operation mode

<Automatic operation mode>


The "Station selection" (ST1 to ST256) and the "Operation parameter selection 1, 2" (PR1, PR2) are established before the "Operation start" signal is input. Since these two signals are read at the rising edge of the "Operation start" signal, they are held even though they are changed after the startup.

When the "Operation start" signal is input, the output signals related to the set position all turn OFF. Station position will be output as "0". When the positioning is completed, the "Automatic set position reached" (JSTA) and the "Set position reached" (JST) are output. Then turn OFF the "Operation start" signal.

When the "Operation start" signal is turned OFF during axis movement, the axis will stop at the nearest station. Note that, for a linear axis, if there is no nearest point in the movement direction, the commanded station becomes the nearest point.

Note

- (1) When the shortcut function is OFF for the rotary axis, the positioning direction can be designated with the "Rotation direction" (DIR).

<Manual operation mode>

The "Rotation direction" (DIR) and the "Operation parameter selection 1, 2" (PR1, PR2) are established before the Operation start signal is input. Since these two signals are read in at the rising edge of the "Operation start" signal, they are held even if they are changed after the startup.

When the "Operation start" signal is input, the output signals related to the set position all turn OFF. Station position will be output as "0".

While the "Operation start" signal is ON, the rotation continues in the designated direction. When the "Operation start" signal is turned OFF, a positioning is carried out to the nearest station where the axis can stop in the rotation direction.

Note that, for a linear axis, if there is no nearest point in the movement direction, the axis will immediately decelerate to a stop.

When the positioning is completed, the "Set position reached" (JST) is output.


Note

- (1) The "Automatic set position reached" (JSTA) will not be output.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

<JOG operation mode>



The "Rotation direction" (DIR) and the "Operation parameter selection 1, 2" (PR1, PR2) are established before the Operation start signal is input. Since these two signals are read in at the rising edge of the "Operation start" signal, they are held even if they are changed after the startup.

When the "Operation start" signal is input, the output signals related to the set position all turn OFF. Station position will be output as "0". While the "Operation start" signal is ON, the rotation continues in the designated direction. When the "Operation start" signal is turned OFF, the axis decelerates to stop. The "Set position reached" (JST) and the "Near set position" (NEAR) are output if the axis is stopped within each tolerable width from the station position.

Cont.	Signal name	Abbrev.	bit
A	Rotation direction	DIR	AUXCM2/bit1

[Function]

This signal designates the rotation direction of the operation in each operation mode.

[Operation]

Turn this signal ON to designate the rotation direction before the "Operation start" signal (ST) is input.

This signal is invalid in the automatic operation mode when the shortcut control is set and selected by the parameter.

When the shortcut control is not selected, a positioning is carried out in the direction designated by this signal.

This signal is read in at the rising edge of the "Operation start" (ST). Therefore, the signal changes are ignored after the startup.

DIR	Axis rotation direction	Station movement direction
0	Forward run	Direction of increasing station No.
1	Reverse run	Direction of decreasing station No.

The actual motor rotation direction is reversed by changing the setting of the parameter "#1018 ccw".

[Related signals]

(1) Operation start (ST: AUXCM2/bit0)

Cont.	Signal name	Abbrev.	bit
A	Arbitrary point feed command valid	STS	AUXCM2/bit2

[Function] [Operation]

This signal selects the mode that executes the positioning, with the command unit specified by the parameter "#1005 plcunit", to the arbitrary position (coordinate) transferred from the NC. To execute the arbitrary point feed command, the "Automatic operation mode" (AUT) must be turned ON at the same time.

[Related signals]

(1) Automatic operation mode (AUT: AUXCM1/bit8)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	bit
A	Incremental feed magnification 1, 2	MP1, MP2	AUXCM2/bit4,5

[Function] [Operation]


This signal selects the incremental feed amount and the handle feed magnification. In the handle feed, the movement amount per handle pulse is selected.

MP2	MP1	Feed amount
0	0	0.001°
0	1	0.01°
1	0	0.1°
1	1	1°

Cont.	Signal name	Abbrev.	bit
A	Operation parameter selection 1, 2	PR1, PR2	AUXCM2/bit6,7

[Function] [Operation]

This signal selects one parameter group to be actually used from four parameter groups that designate the axis feed operation. The parameter group cannot be changed while the "Operation start" (ST) is ON. (The group is held in NC.) If Smoothing zero is confirmed for the target axis, the operation parameter group can be changed with the Operation start. Changing the parameter setting values of the time constant, torque limit value and excessive error detection width, however, is not possible unless Smoothing zero is confirmed for all the NC axes. The parameter values, if changed during the NC axis movement, are valid after the smoothing zero is confirmed.



PR2	PR1	Selected operation parameter group
0	0	1
0	1	2
1	0	3
1	1	4

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
PLC axis indexing control command 1	AUXCM1	R8053	R8059	R8065	R8071	R8077	R8083	R8089	R8095

Cont.	Signal name	Abbrev.	bit
B	Servo OFF	*SVF	AUXCM1/bit0

[Function] [Operation]

When the Servo OFF signal is set to "0" (B contact), the control axis enters the servo OFF status. No matter which operation mode the servo is in and turned OFF, the axis movement will stop, and the servo will turn OFF. The axis movement restarts when the servo is turned ON again.

If the axis moves for any reason while the servo is OFF, it can be selected whether to compensate that movement amount when the servo turns ON the next time. Select with parameter "#1064 svof".

<When carrying out movement amount compensation (#1064 svof = 1)>

- When the servo is OFF, the coordinates are always updated by the amount the axis has moved. When the servo is OFF, the coordinates show the machine position.

<When not carrying out movement amount compensation (#1064 svof = 0)>

- When the servo is OFF, the coordinates are not updated even when the axis moves. When the servo is OFF, the coordinates show the machine position when the servo is OFF.
- When the servo is turned ON, the axis is moved to the position where the servo was turned OFF.
- When the servo is OFF and the axis movement exceeds the excessive error width (designated with parameter "#2226 SV026"), a servo alarm occurs.

[Caution]

- The actual servo OFF operation is validated after In-position (INP) is completed. When using a mechanical clamp, carry out the clamp operation after confirming the in-position status.
- When the power is turned ON, the Servo OFF signal turns OFF ("0") and the servo OFF function becomes valid. It is necessary before operation to turn the Servo OFF signal ON ("1") in the PLC program to release the servo OFF.

Cont.	Signal name	Abbrev.	bit
A	Master reset	MRST	AUXCM1/bit3

[Function]

This signal resets the PLC indexing axis.

[Operation]

When this signal is ON, the following reset operations are carried out.

- The axis movement decelerates to a stop.
- Alarms that can be released by the reset are released.
- The "In reset" signal (RST) is output.
- The operation alarm is released while resetting.

[Related signals]

- In reset (RST: AUXST1/bit9)

Cont.	Signal name	Abbrev.	bit
A	Interlock+	*IT+	AUXCM1/bit4

[Function] [Operation]

When the control axis is moving in the (+) direction, this signal decelerates and stops the axis movement immediately.

When this signal is OFF from before movement, the motion is stopped in the same manner as without starting. In any case the movement is started or restarted by turning this signal ON.

Cont.	Signal name	Abbrev.	bit
A	Interlock-	*IT-	AUXCM1/bit5

[Function] [Operation]

This is the same as the "Interlock +" signal (IT+), the only difference being the direction.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	bit
A	Ready OFF	RDF	AUXCM1/bit6

[Function]

This is a signal to turn OFF the READY status.

[Operation]

When put into a READY OFF status, the power supply to the servomotor is shut off, and the contactor control output is simultaneously turned OFF. If the motor is in operation, it will stop by a dynamic brake stop or a deceleration control stop. The "Servo ready completion" (SA) and the "Servo ready" (RDY) are also turned OFF, but an alarm does not occur. When this signal is turned OFF, the machine immediately returns to the original state.

[Related signals]

- (1) Servo ready completion (SA: AUXST1/bitC)
- (2) Servo ready (RDY: AUXST1/bit0)

Cont.	Signal name	Abbrev.	bit
A	Handle feed operation mode	H	AUXCM1/bit7

[Function]

This signal selects the handle feed operation mode.

[Operation]

The axis will move for the amount determined by input pulse multiplied by feed magnification after this signal is turned ON, each signal [Operation parameter selection (PR1, PR2) and Incremental feed magnification (MP1, MP2)] is determined, and the handle pulse is input.

[Caution]

- (1) Turning this signal ON when other operation modes are ON will result in the operation error (M01 0101).
- (2) The handle mode acceleration/deceleration time is the acceleration/deceleration time constant 2 linear acceleration/deceleration of the selected operation parameter group.

[Related signals]

- (1) Operation parameter selection 1, 2 (PR1, PR2: AUXCM2/bit6,7)
- (2) Incremental feed magnification 1, 2 (MP1, MP2: AUXCM2/bit4,5)

Cont.	Signal name	Abbrev.	bit
A	Automatic operation mode	AUT	AUXCM1/bit8

[Function]

This signal selects the automatic operation mode.

[Operation]

Turn this signal ON, set the "Station selection 1 to 256" (ST1 to ST256) and then turn ON the "Operation start" (ST) to move the axis to the designated station. The shortcut control or the rotation direction can be selected with parameters.

[Caution]

Turning this signal ON when other operation modes are ON will result in the operation error (M01 0101).

[Related signals]

- (1) Rotation direction (DIR: AUXCM2/bit1)
- (2) Operation parameter selection 1, 2 (PR1, PR2: AUXCM2/bit6,7)
- (3) Station selection 1 to 256 (ST1 to ST256: AUXCM3/bit0 to 8)

Cont.	Signal name	Abbrev.	bit
A	Manual operation mode	MAN	AUXCM1/bit9

[Function]

This signal selects the manual operation mode.

[Operation]

When the rotation direction is designated and Operation start (ST) is turned ON, the axis will begin moving, and the rotation will continue in the designated direction until Operation start is turned OFF. When Operation start turns OFF, the axis will be positioned to the nearest station.

[Caution]

Turning this signal ON when other operation modes are ON will result in the operation error (M01 0101).

[Related signals]

- (1) Rotation direction (DIR: AUXCM2/bit1)
- (2) Operation parameter selection 1, 2 (PR1, PR2: AUXCM2/bit6,7)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	bit
A	JOG operation mode	J	AUXCM1/bitA

[Function]

This signal selects the JOG operation mode.

[Operation]

When the rotation direction is designated and the "Operation start" (ST) is turned ON, the axis will begin moving, and the rotation will continue in the designated direction until the "Operation start" is turned OFF. Unlike the manual operation mode, when the "Operation start" is turned OFF, the axis immediately decelerate to a stop.

[Caution]

Turning this signal ON when other operation modes are ON will result in the operation error (M01 0101).

[Related signals]

- (1) Rotation direction (DIR: AUXCM2/bit1)
- (2) Operation parameter selection 1, 2 (PR1, PR2: AUXCM2/bit6,7)

Cont.	Signal name	Abbrev.	bit
A	Reference position return mode	ZRN	AUXCM1/bitB

[Function]

This signal selects the reference position return mode.

[Operation]

When this signal (ZRN) is turned ON, the reference position return mode is designated. To start the reference position return, turn this signal ON, select the operation parameter group, then turn ON the "Operation start" signal (ST).

When the absolute position coordinate system has been established in the absolute position specifications, the high-speed return will be applied in every operation.

[Related signals]

- (1) Operation parameter selection 1, 2 (PR1, PR2: AUXCM2/bit6,7)

Cont.	Signal name	Abbrev.	bit
A	Basic point initialization setting mode	AZS	AUXCM1/bitD

[Function]

This signal selects the mode that initializes the basic point for the absolute position detection system.

[Operation]

When this signal is turned ON, the basic point initialization setting mode is held until the NC power is turned OFF. (Cannot be canceled)

When the stopper method is selected by setting "1" to "#2049 type", the torque limit value and the excessive error detection width in the operation parameter group 4 are automatically selected.

Cont.	Signal name	Abbrev.	bit
A	Basic point setting	ZST	AUXCM1/bitE

[Function]

This signal turns ON when designating the basic point with the basic point initialization in the absolute position detection system.

[Operation]

When this signal is turned ON in the basic point initialization setting mode, the designated position is set as the absolute position basic point.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)


Cont.	Signal name	Abbrev.	bit
A	Incremental mode	S	AUXCM1/bitF

[Function]

This signal selects the incremental mode.

[Operation]

After turning ON this signal, designate the operation parameter group (with PR1 and PR2), the incremental feed magnification (with MP1 and MP2) and the rotation direction (with DIR). Then turn ON the "Operation start" signal (ST) to move the axis.

**[Caution]**

- (1) Turning this signal ON when other operation modes are ON will result in the operation error (M01 0101).
- (2) In the incremental mode, the axis travel will be maintained at a constant amount, even if the "Operation start" signal is OFF.

[Related signals]

- (1) Operation parameter selection 1, 2 (PR1, PR2: AUXCM2/bit6,7)

Cont.	Signal name	Abbrev.	Common (\$)
A	ATC control parameter		R10600

[Function]

Combination of the number of digits for tool No. to be displayed, magazine No. start value, and spindle and standby tool to be displayed are designated.

[Operation]**<Control parameter details>**

R10600

F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

Designation of the number of spindles and standby tools to be displayed

- 00000000: Spindle
- 00000001: Spindle, standby 1
- 00000010: Spindle, standby 1 to standby 2
- 00000011: Spindle, standby 1 to standby 3
- 00000100: Spindle, standby 1 to standby 4
- Others: Do not display

Designation of number of digits for tool No. to be displayed

- 0: T4-digit Display only the last 4 digits of the tool No.
- 1: T8-digit Arrange the first and last 4 digits of the tool No. to display in 8 digits.

Magazine No. start value

- 0: 1 start magazine (Pot No. starts from 1.)
- 1: 0 start magazine (Pot No. starts from 0.)

Pot No. expansion

- 0: Do not set arbitrarily
- 1: Set arbitrarily

Number of tools per magazine

- 0: Do not set arbitrarily
- 1: Set arbitrarily

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

<Pot No. expansion>

This function allows pot head No. for each magazine to be set arbitrarily.

<Do not set arbitrarily>

The head No. for each magazine is "1" or "0", depending on the setting of the "magazine No. start value" of the ATC control parameter (R10600/bit1).

(Example 1) 1 start magazine

Set the following R registers.

R10600 : 0x0000

→ Number of digits for tool No. to be displayed : T4-digit

→ Magazine No. start value: 1 start magazine

→ Pot No. expansion : No arbitrary setting

→ Number of tools per magazine : No arbitrary setting

R10610 : 0x000C

→ Number of tools for magazine 1 : 12



Pot	Tool No.	-D
1	25	0
2	7	0
3	10	0
4	58	0
5	0	0
6	0	0
7	0	0
8	0	0
9	0	0
10	0	0
11	0	0
12	0	0

(Example 2) 0 start magazine

Set the following R registers.

R10600 : 0x0002

→ Number of digits for tool No. to be displayed : T4-digit

→ Magazine No. start value: 0 start magazine

→ Pot No. expansion : No arbitrary setting

→ Number of tools per magazine : No arbitrary setting

R10610 : 0x000C

→ Number of tools for magazine 1 : 12



Pot	Tool No.	-D
0	25	0
1	7	0
2	10	0
3	58	0
4	0	0
5	0	0
6	0	0
7	0	0
8	0	0
9	0	0
10	0	0
11	0	0

<To set arbitrarily>

Set pot head No. for each magazine in the "each magazine pot head No. designation" register.

1st magazine pot head No. (R10695)

2nd magazine pot head No. (R10696)

3rd magazine pot head No. (R10697)

4th magazine pot head No. (R10698)

5th magazine pot head No. (R10699)

Note

- (1) The head No. for each magazine is the value set in the register for "pot head No. for each magazine" (R10695 to R10699) regardless of "magazine No. start value" of the ATC control parameter (R10600/bit1).
- (2) Numerical value "0" to "8999" can be set in the register for "pot head No. for each magazine" (R10695 to R10699). When a value outside the range is set, pot head No. is displayed from "1" or "0", depending on the setting of "magazine No. start value" (R10600/bit1).

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

(Example 1) Pot head No. for each magazine: 10; number of magazines: 12

Set the following R registers.

R10600 : 0x0004

→ Number of digits for tool No. to be displayed: T4-digit

→ Magazine No. start value: 1 start magazine

→ Pot No. expansion : Arbitrary setting

→ Number of tools per magazine : No arbitrary setting

R10610 : 0x000C

→ Number of tools for magazine 1 : 12

R10695 : 0x000A

→ Pot head No. for magazine 1: 10



Pot	Tool No.	-D
10	25	0
11	7	0
12	10	0
13	58	0
14	0	0
15	0	0
16	0	0
17	0	0
18	0	0
19	0	0
20	0	0
21	0	0

If the pot head No. for each magazine is outside the range of 0 to 8999, follow the setting for "magazine No. start value".

(Example 2) Pot head No. for each magazine: 9000; number of magazines: 12; magazine No. start value: 0

Set the following R registers.

R10600 : 0x0006

→ Number of digits for tool No. to be displayed : T4-digit

→ Magazine No. start value : 0 start magazine

→ Pot No. expansion : Arbitrary setting

→ Number of tools per magazine : No arbitrary setting

R10610 : 0x000C

→ Number of tools for magazine 1 : 12

R10695 : 0x2328

→ Pot head No. for magazine 1: 9000



Pot	Tool No.	-D
0	25	0
1	7	0
2	10	0
3	58	0
4	0	0
5	0	0
6	0	0
7	0	0
8	0	0
9	0	0
10	0	0
11	0	0

<Number of tools per magazine>

This function allows the number of tools per magazine to be set arbitrarily.

<Do not set arbitrarily>

There is a maximum of three rows of magazine, and the total number of tools that can be registered per magazine is 120. Magazine tool data assignment is fixed.

<To set arbitrarily>

There is a maximum of five rows of magazine, and the total number of tools that can be registered for all the magazines is 360.

Set the number of tools per magazine in the "number of magazine designation" register. (If there are any magazines not being used, set the designation register to "0".)

Number of magazine designation register

No.1 magazine ... R10610

No.2 magazine ... R10611

No.3 magazine ... R10612

No.4 magazine ... R10613

No.5 magazine ... R10614

The magazine tool data is assigned for the number of tools set in order from No.1 magazine.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

<ATC file register>

The file registers used with ATC are as shown below.

		Corresponding file (R) register										Remarks (Data type)
Magazine		No.1 magazine		No.2 magazine		No.3 magazine		No.4 magazine		No.5 magazine		
T4-digit/T8-digit specifications		T4-digit	T8-digit	T4-digit	T8-digit	T4-digit	T8-digit	T4-digit	T8-digit	T4-digit	T8-digit	
ATC control parameter		R10600	<-	<-	<-	<-	<-	<-	<-	<-	<-	
AUX data		R10604	<-	<-	<-	<-	<-	<-	<-	<-	<-	Binary (0 to 99)
Number of magazines designation		R10610	<-	R10611	<-	R10612	<-	R10613	<-	R10614	<-	Binary
Pointer designation		R10615	<-	R10616	<-	R10617	<-	R10618	<-	R10619	<-	Binary
Spindle tool		R10620	R10620 R10621	R10630	R10630 R10631	R10640	R10640 R10641	R10650	R10650 R10651	R10660	R10660 R10661	BCD
Standby 1 tool		R10621	R10622 R10623	R10631	R10632 R10633	R10641	R10642 R10643	R10651	R10652 R10653	R10661	R10662 R10663	BCD
Standby 2 tool		R10622	R10624 R10625	R10632	R10634 R10635	R10642	R10644 R10645	R10652	R10654 R10655	R10662	R10664 R10665	BCD
Standby 3 tool		R10623	R10626 R10627	R10633	R10636 R10637	R10643	R10646 R10647	R10653	R10656 R10657	R10663	R10666 R10667	BCD
Standby 4 tool		R10624	R10628 R10629	R10634	R10638 R10639	R10644	R10648 R10649	R10654	R10658 R10659	R10664	R10668 R10669	BCD
Spindle tool D		R10670	<-	R10675	<-	R10680	<-	R10685	<-	R10690	<-	Binary
Standby 1 tool D		R10671	<-	R10676	<-	R10681	<-	R10686	<-	R10691	<-	Binary
Standby 2 tool D		R10672	<-	R10677	<-	R10682	<-	R10687	<-	R10692	<-	Binary
Standby 3 tool D		R10673	<-	R10678	<-	R10683	<-	R10688	<-	R10693	<-	Binary
Standby 4 tool D		R10674	<-	R10679	<-	R10684	<-	R10689	<-	R10694	<-	Binary
Pot head No. for each magazine		R10695	<-	R10696	<-	R10697	<-	R10698	<-	R10699	<-	Binary
Magazine tool data	Pot 1 (MG1):	♦ When not setting arbitrarily There is a maximum of three rows of magazine, and the total number of tools that can be registered per magazine is 120. Magazine tool data assignment is fixed. Refer to "Example of tool data assignment when not setting arbitrarily" for details.										
Magazine tool data (Aux. D)	Pot 1:											
		♦ When setting arbitrarily There is a maximum of five rows of magazine, and the total number of tools that can be registered for all the magazines is 360. The tool data assignment varies between R10700 and R11779. Refer to "Example of tool data assignment when setting arbitrarily" for details on assignment method.										

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

<Example of tool data assignment when not setting arbitrarily>

There is a maximum of three rows of magazine, and the total number of tools that can be registered per magazine is 120.

The tool data assignment is fixed between R10700 and R11779 as shown below.

		Corresponding file (R) register										Remarks (Data type)
Magazine		No.1 magazine		No.2 magazine		No.3 magazine		No.4 magazine		No.5 magazine		
T4-digit/T8-digit specifications		T4-digit	T8-digit	T4-digit	T8-digit	T4-digit	T8-digit	T4-digit	T8-digit	T4-digit	T8-digit	
Magazine tool data	Pot 1 (MG1)	R10700	R10700 R10701	R11060	R11060 R11061	R11420	R11420 R11421	-	-	-	-	BCD
	Pot 2 (MG2)	R10701	R10702 R10703	R11061	R11062 R11063	R11421	R11422 R11423	-	-	-	-	BCD
	Pot 3 (MG3)	R10702	R10704 R10705	R11062	R11064 R11065	R11422	R11424 R11425	-	-	-	-	BCD
	Pot 119 (MG119)	R10818	R10936 R10937	R11178	R11296 R11297	R11538	R11656 R11657	-	-	-	-	BCD
	Pot 120 (MG120)	R10819	R10938 R10939	R11179	R11298 R11299	R11539	R11658 R11659	-	-	-	-	BCD
Magazine tool data (Aux. D)	Pot 1	R10940	<-	R11300	<-	R11660	<-	-	-	-	-	Binary
	Pot 2	R10941	<-	R11301	<-	R11661	<-	-	-	-	-	Binary
	Pot 3	R10942	<-	R11302	<-	R11662	<-	-	-	-	-	Binary
	Pot 119	R11058	<-	R11418	<-	R11778	<-	-	-	-	-	Binary
	Pot 120	R11059	<-	R11419	<-	R11779	<-	-	-	-	-	Binary

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

<Example of tool data assignment when setting arbitrarily>

There is a maximum of five rows of magazine, and the total number of tools that can be registered for all the magazines is 360.

The tool data assignment varies between R10700 and R11779.

The magazine tool data is assigned for the number of tools set in order from No.1 magazine.

(Example) Number of magazines: 5 magazines Number of tools: No.1 magazine [100 tools], No.2 to No.5 magazines [50 tools each]

		Corresponding file (R) register										Remarks (Data type)
Magazine		No.1 magazine		No.2 magazine		No.3 magazine		No.4 magazine		No.5 magazine		
T4-digit/T8-digit specifications		T4-digit	T8-digit	T4-digit	T8-digit	T4-digit	T8-digit	T4-digit	T8-digit	T4-digit	T8-digit	
Magazine tool data	Pot 1 (MG1)	R10700	R10700 R10701	R11000	R11060 R11061	R11150	R11150 R11151	R11300	R11300 R11301	R11450	R11450 R11451	BCD
	Pot 2 (MG2)	R10701	R10702 R10703	R11001	R11062 R11063	R11151	R11152 R11153	R11301	R11302 R11303	R11451	R11452 R11453	BCD
	Pot 3 (MG3)	R10702	R10704 R10705	R11002	R11064 R11065	R11152	R11154 R11155	R11302	R11304 R11305	R11452	R11454 R11455	BCD
	Pot 49 (MG49)	R10748	R10796 R10797	R11048	R11296 R11297	R11198	R11246 R11247	R11348	R11396 R11397	R11498	R11546 R11547	BCD
	Pot 50 (MG50)	R10749	R10798 R10799	R11049	R11298 R11299	R11199	R11248 R11249	R11349	R11398 R11399	R11499	R11548 R11549	BCD
	Pot 99 (MG99)	R10798	R10896 R10897	-	-	-	-	-	-	-	-	-
Pot 100 (MG100)	R10799	R10898 R10899	-	-	-	-	-	-	-	-	-	BCD
Magazine tool data (Aux. D)	Pot 1	R10900	<-	R11100	<-	R11250	<-	R11400	<-	R11550	<-	Binary
	Pot 2	R10901	<-	R11101	<-	R11251	<-	R11401	<-	R11551	<-	Binary
	Pot 3	R10902	<-	R11102	<-	R11252	<-	R11402	<-	R11552	<-	Binary
	Pot 49	R10948	<-	R11148	<-	R11298	<-	R11448	<-	R11598	<-	Binary
	Pot 50	R10949	<-	R11149	<-	R11299	<-	R11449	<-	R11599	<-	Binary
	Pot 99	R10998	<-	-	-	-	-	-	-	-	-	Binary
Pot 100	R10999	<-	-	-	-	-	-	-	-	-	Binary	

[Related signals]

- (1) Display tool selection parameter (R10603)


4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	Display tool selection parameter		R10603

[Function]

Whether or not to display spindle standby is designated.

[Operation]**[Related signals]**

(1) ATC control parameter (R10600)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Spindle tool No.		R12200, 1	R12210, 1	R12220, 1	R12230, 1	R12240, 1	R12250, 1	R12260, 1	R12270, 1

[Function] [Operation]

This signal indicates spindle No. in use.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Standby tool No.		R12202, 3	R12212, 3	R12222, 3	R12232, 3	R12242, 3	R12252, 3	R12262, 3	R12272, 3

[Function] [Operation]

This signal indicates standby tool No.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Machining start time		R14700, 1	R14950, 1	R15200, 1	R15450, 1	R15700, 1	R15950, 1	R16200, 1	R16450, 1

[Function]

The time at which the machining starts is stored in the total (seconds) from January 1, 1970.

[Operation]

When the machining is completed, this sets the time of cycle start automatically.

The time is not set in the case of restarting after automatic operation pause (halt) or block stop.

In the case of repeating with M99, the time at which the machining is completed is set as the start time of the next cycle.

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Machining end time		R14702, 3	R14952, 3	R15202, 3	R15452, 3	R15702, 3	R15952, 3	R16202, 3	R16452, 3

[Function]

The time at which the machining is complete is stored in the total (seconds) from January 1, 1970.

[Operation]

When the M code registered in "#8001 WRK COUNT M" is executed, the time of execution is set automatically.

When "0" is set in "#8001 WORK COUNT M" and when M02 or M30 is executed, the time of execution is set automatically.

When MES interface library function is invalid, this signal is set to "0".

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Cycle time		R14704, 5	R14954, 5	R15204, 5	R15454, 5	R15704, 5	R15954, 5	R16204, 5	R16454, 5

[Function]

The cycle time is stored here. The unit is [ms].

[Operation]

This signal specifies the time (ms) from cycle start until the M code registered in "#8001 WRK COUNT M" is performed. When "0" is set in "#8001 WRK COUNT M", this signal specifies the time (ms) from cycle start until M02 or M30 is performed.

When the cycle time exceeds "499:59:59.999", "1799999999" is set.

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Program number at machining start		R14706 to R14721	R14956 to R14971	R15206 to R15221	R15456 to R15471	R15706 to R15721	R15956 to R15971	R16206 to R16221	R16456 to R16471

[Function]

The program number at the time of the machining start is stored here.

[Operation]

When the machining is completed, this sets the ASCII code (hexadecimal number) corresponding to the program number of that machining start automatically.

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: N number at machining start		R14722, 3	R14972, 3	R15222, 3	R15472, 3	R15722, 3	R15972, 3	R16222, 3	R16472, 3

[Function]

The N number at the time of the machining start is stored here.

[Operation]

When the machining is completed, this sets the N number of that machining start automatically.

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: B number at machining start		R14724, 5	R14974, 5	R15224, 5	R15474, 5	R15724, 5	R15974, 5	R16224, 5	R16474, 5

[Function]

The B number at the time of the machining start is stored here.

[Operation]

When the machining is completed, this sets the B number of that machining start automatically.

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Spindle 1 maximum load		R14726	R14976	R15226	R15476	R15726	R15976	R16226	R16476

[Function]

The maximum current of the 1st spindle at the time of the machining completion is stored here.

[Operation]

When the machining is completed, the maximum current of the 1st spindle since the machining start is automatically set. The maximum current is set by 1% increments regardless of the value of "#1256 set28/bit2" (Change current FB (load) output unit).

When MES interface library function is invalid, this signal is set to "0".

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Spindle 2 maximum load		R14727	R14977	R15227	R15477	R15727	R15977	R16227	R16477

[Function]

The maximum current of the 2nd spindle at the time of the machining completion is stored here.

[Operation]

When the machining is completed, the maximum current of the 2nd spindle since the machining start is automatically set.

The maximum current is set by 1% increments regardless of the value of "#1256 set28/bit2" (Change current FB (load) output unit).

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Power consumption amount		R14728, 9	R14978, 9	R15228, 9	R15478, 9	R15728, 9	R15978, 9	R16228, 9	R16478, 9

[Function]

The power consumption amount at the time of the machining completion is stored here.

[Operation]

When the machining is completed, the power consumption amount (Wh) obtained by EcoMonitorLight station #1 is automatically set.

When the MES interface library function is invalid or the device is not connected with EcoMonitorLight, this signal is set to "0".

[Related signals]

(1) EcoMonitorLight connection: Station #1 consumed power (R14000,1)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Power regeneration amount		R14730, 1	R14980, 1	R15230, 1	R15480, 1	R15730, 1	R15980, 1	R16230, 1	R16480, 1

[Function]

The power regeneration amount at the time of machining completion is stored here.

[Operation]

When the machining is completed, the power regeneration amount (Wh) obtained by EcoMonitorLight station #1 is automatically set.

When the MES interface library function is invalid or the device is not connected with EcoMonitorLight, this signal is set to "0".

[Related signals]

(1) EcoMonitorLight connection: Station #1 regenerated power (R14002,3)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Tool number 1 to 5		R14732, 3 to R14740, 1	R14982, 3 to R14990, 1	R15232, 3 to R15240, 1	R15482, 3 to R15490, 1	R15732, 3 to R15740, 1	R15982, 3 to R15990, 1	R16232, 3 to R16240, 1	R16482, 3 to R16490, 1

[Function]

This signal displays the tool number.

[Operation]

The tool number displayed on the R register "T code data 1" commanded by the T command is automatically stored when machining is completed.

Up to five tool number histories from the latest are stored in the R registers "Tool number 1" to "Tool number 5".

The latest is set in the R register "Tool number 1".

When MES interface library function is invalid, this signal is set to "0".

[Related signals]

(1) T code data (R536,7)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Tool offset number 1 to 5		R14742 to R14746	R14992 to R14996	R15242 to R15246	R15492 to R15496	R15742 to R15746	R15992 to R15996	R16242 to R16246	R16492 to R16496

[Function]

The tool offset number is stored here.

[Operation]

The tool offset number commanded by the T command is automatically set when machining is completed.

Up to five tool offset number histories from the latest are set in the R registers "Tool offset number 1" to "Tool offset number 5".

The latest is set in the R register "Tool offset number 1".

Compensation number is set for the machining center system, or tool length offset number is set for the lathe system.

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Tool length offset 1 to 5		R14748, 9 to R14756, 7	R14998, 9 to R15006, 7	R15248, 9 to R15256, 7	R15498, 9 to R15506, 7	R15748, 9 to R15756, 7	R15998, 9 to R16006, 7	R16248, 9 to R16256, 7	R16498, 9 to R16506, 7

[Function]

The tool length offset amount (M system) or the X axis tool length offset amount (L system) is stored here.

[Operation]

The tool length offset amount commanded by the T command is automatically set when machining is completed.

Up to five tool length offset histories from the latest are set in the R registers "Tool length offset 1" to "Tool length offset 5".

The latest is set in the R register "Tool length offset 1".

For M system, offset amount (for offset type I), length dimension (for offset type II), or Z axis tool length offset amount (for offset type III) is displayed. For L system, X axis tool length offset amount is displayed.

"0" is set when the tool length offset amount cannot be set, such as when the tool number is not designated.

The unit is [μ m].

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Tool radius offset 1 to 5		R14758, 9 to R14766, 7	R15008, 9 to R15016, 7	R15258, 9 to R15266, 7	R15508, 9 to R15516, 7	R15758, 9 to R15766, 7	R16008, 9 to R16016, 7	R16258, 9 to R16266, 7	R16508, 9 to R16516, 7

[Function]

The tool radius compensation amount (M system) or the tool nose radius compensation amount (L system) is stored here.

[Operation]

The tool radius compensation amount when T command was issued is automatically set when machining is completed.

Up to five tool radius offset histories from the latest are set in the R registers "Tool radius offset 1" to "Tool radius offset 5".

The latest is set in the R register "Tool radius offset 1".

For M system, offset amount (for offset type I), radius dimension (for offset type II), or tool nose radius offset (for offset type III) is displayed. For L system, tool nose radius offset is displayed.

"0" is set when the tool radius compensation amount cannot be set, such as when the tool number is not designated.

The unit is [μ m].

When MES interface library function is invalid, this signal is set to "0".

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Tool length wear amount 1 to 5		R14768, 9 to R14776, 7	R15018, 9 to R15026, 7	R15268, 9 to R15276, 7	R15518, 9 to R15526, 7	R15768, 9 to R15776, 7	R16018, 9 to R16026, 7	R16268, 9 to R16276, 7	R16518, 9 to R16526, 7

[Function]

The tool length wear amount (M system) or the X axis tool wear amount (L system) is stored here.

[Operation]

The tool length wear amount is automatically set when a T command is commanded. Up to five tool length wear amount histories from the latest tool length wear amount are set in the R register "Tool length wear amount 1" to "Tool length wear amount 5". The latest is set in the R register "Tool length wear amount 1".

For M system, compensation amount (for compensation type I), length wear (for compensation type II), or Z axis tool wear (for compensation type III) is displayed. For L system, X axis tool wear is displayed.

"0" is set when the tool length wear amount cannot be set, such as when the tool number is unspecified. The unit is [μ m].

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Tool radius wear amount 1 to 5		R14778, 9 to R14786, 7	R15028, 9 to R15036, 7	R15278, 9 to R15286, 7	R15528, 9 to R15536, 7	R15778, 9 to R15786, 7	R16028, 9 to R16036, 7	R16278, 9 to R16286, 7	R16528, 9 to R16536, 7

[Function]

The tool radius wear amount (M system) or the X axis tool radius wear amount (L system) is stored here.

[Operation]

The tool radius wear amount when T command is issued is automatically set. Up to five tool radius wear amount histories from the latest tool radius wear amount are set in the R register "Tool radius wear amount 1" to "Tool radius wear amount 5". The latest is set in the R register "Tool radius wear amount 1".

For M system, compensation amount (for compensation type I), radius wear (for compensation type II), or tool nose radius wear (for compensation type III) is displayed. For L system, tool nose radius wear is displayed.

"0" is set when the tool radius wear amount cannot be set, such as when the tool number is unspecified. The unit is [μ m].

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Tool life 1 to 5		R14788, 9 to R14796, 7	R15038, 9 to R15046, 7	R15288, 9 to R15296, 7	R15538, 9 to R15546, 7	R15788, 9 to R15796, 7	R16038, 9 to R16046, 7	R16288, 9 to R16296, 7	R16538, 9 to R16546, 7

[Function]

The tool lives data at the time of machining completion are stored here.

[Operation]

The tool lives (cumulative cutting hours or cumulative number of cuttings) for the tools set in the R register "Tool number 1" to "Tool number 5" (R14732 to R14741) are automatically set at the time of the machining completion.

Five tool life histories from the latest tool life are set in the R register "Tool life 1" to R register "Tool life 5". The latest is set in the R register "Tool life 1".

The tool life is set only when the tool life management I is valid for both M and L systems.

"0" is set when tool life management II or III is valid or tool life management function is invalid.

Data type depends on the setting of management method for M system. Specify the data type in minutes in the case of usage time and specify it by the number of times in the case of usage count. Specify usage time in minutes for L system.

"0" is set when tool lives are unsettingable, such as when the tool numbers are unspecified.

When MES interface library function is invalid, this signal is set to "0".

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Time of alarm occurrence		R14798, 9	R15048, 9	R15298, 9	R15548, 9	R15798, 9	R16048, 9	R16298, 9	R16548, 9

[Function]

The time at which an alarm occurs is stored in the total (seconds) from January 1, 1970.

[Operation]

When an alarm occurs, the time of alarm occurrence is automatically set.

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Alarm number 1		R14800 to R14815	R15050 to R15065	R15300 to R15315	R15550 to R15565	R15800 to R15815	R16050 to R16065	R16300 to R16315	R16550 to R16565
A	MES interface library: Alarm number 2		R14816 to R14831	R15066 to R15081	R15316 to R15331	R15566 to R15581	R15816 to R15831	R16066 to R16081	R16316 to R16331	R16566 to R16581
A	MES interface library: Alarm number 3		R14832 to R14847	R15082 to R15097	R15332 to R15347	R15582 to R15597	R15832 to R15847	R16082 to R16097	R16332 to R16347	R16582 to R16597
A	MES interface library: Alarm number 4		R14848 to R14863	R15098 to R15113	R15348 to R15363	R15598 to R15613	R15848 to R15863	R16098 to R16113	R16348 to R16363	R16598 to R16613

[Function]

The alarm numbers at the alarm occurrence are stored here.

[Operation]

When an alarm occurs, the latest alarm number is automatically set.

Up to four alarm number histories from the latest are set in the R registers "Alarm number 1" to "Alarm number 4".

The latest is set in the R register "Alarm number 1".

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Power ON time		R14864, 5	R15114, 5	R15364, 5	R15614, 5	R15864, 5	R16114, 5	R16364, 5	R16614, 5

[Function]

The power ON time at an alarm occurrence is stored. The unit is [s].

[Operation]

When an alarm occurs, the power ON time at that time is automatically set.

The power ON time is the total integrated time of the time from NC power ON to OFF.

When the power ON time exceeds "59999:59:59", "215999999" is set.

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Program number at alarm		R14866 to R14881	R15116 to R15131	R15366 to R15381	R15616 to R15631	R15866 to R15881	R16116 to R16131	R16366 to R16381	R16616 to R16631

[Function]

The program number at the alarm occurrence is stored here.

[Operation]

When an alarm occurs, this automatically sets the ASCII code (hexadecimal number) corresponding to the program number at that time.

When MES interface library function is invalid, this signal is set to "0".

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Subprogram number at alarm		R14882 to R14897	R15132 to R15147	R15382 to R15397	R15632 to R15647	R15882 to R15897	R16132 to R16147	R16382 to R16397	R16632 to R16647

[Function]

The subprogram number at the alarm occurrence is stored here.

[Operation]

When an alarm occurs, the ASCII code (hexadecimal number) corresponding to the subprogram at that time is specified automatically.

"0" is specified while subprogram is not in execution.

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: N number at alarm		R14898, 9	R15148, 9	R15398, 9	R15648, 9	R15898, 9	R16148, 9	R16398, 9	R16648, 9

[Function]

The sequence number at the alarm occurrence is stored here.

[Operation]

When an alarm occurs, the sequence number at that time is automatically set.

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: B number at alarm		R14900, 1	R15150, 1	R15400, 1	R15650, 1	R15900, 1	R16150, 1	R16400, 1	R16650, 1

[Function]

The block number at the alarm occurrence is stored here.

[Operation]

When an alarm occurs, the block number at that time is automatically set.

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: G code modal status		R14902 to R14933	R15152 to R15183	R15402 to R15433	R15652 to R15683	R15902 to R15933	R16152 to R16183	R16402 to R16433	R16652 to R16683

[Function]

The G code at the alarm occurrence is stored here.

[Operation]

When an alarm occurs, the G code corresponding to the G code modal is set in ASCII code.

The modal status of G code is set according to R register "G code modal registration selection" (R14604,5).

When MES interface library function is invalid, this signal is set to "0".

[Related signals]

(1) MES interface library: G code modal registration selection (R14604,5)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Spindle 1 load		R14934	R15184	R15434	R15684	R15934	R16184	R16434	R16684

[Function]

The current of the 1st spindle at the alarm occurrence is stored here.

[Operation]

When an alarm occurs, the current of the 1st spindle is automatically set.

The maximum current is set by 1% increments regardless of the value of "#1256 set28/bit2" (Change current FB (load) output unit).

When MES interface library function is invalid, this signal is set to "0".

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Spindle 2 load value		R14935	R15185	R15435	R15685	R15935	R16185	R16435	R16685

[Function]

The current of the 2nd spindle at the alarm occurrence is stored here.

[Operation]

When an alarm occurs, the current of the 2nd spindle is automatically set.

The maximum current is set by 1% increments regardless of the value of "#1256 set28/bit2" (Change current FB (load) output unit).

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Tool number		R14936, 7	R15186, 7	R15436, 7	R15686, 7	R15936, 7	R16186, 7	R16436, 7	R16686, 7

[Function]

The tool number at the alarm occurrence is stored here.

[Operation]

When an alarm occurs, this automatically sets the tool number displayed on the R register "T code data 1" at that time.

When MES interface library function is invalid, this signal is set to "0".

[Related signals]

(1) T code data (R536,7)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Tool offset number		R14938	R15188	R15438	R15688	R15938	R16188	R16438	R16688

[Function]

The tool offset number at the alarm occurrence is stored here.

[Operation]

When an alarm occurs, the tool offset number of that time is automatically set.

Compensation number is set for the machining center system, and tool length offset number is set for the lathe system.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Tool length offset		R14940, 1	R15190, 1	R15440, 1	R15690, 1	R15940, 1	R16190, 1	R16440, 1	R16690, 1

[Function]

The tool length offset amount (M system) or the X axis tool length offset amount (L system) at the alarm occurrence is stored here.

[Operation]

When an alarm occurs, the tool length offset of that time is automatically set.

For M system, offset amount (for offset type I), length dimension (for offset type II), or Z axis tool length offset amount (for offset type III) is displayed. For L system, the X axis tool length offset amount is displayed.

"0" is set when the tool length offset amount cannot be set, such as when the tool number is not designated.

The unit is [μ m].

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Tool radius offset		R14942, 3	R15192, 3	R15442, 3	R15692, 3	R15942, 3	R16192, 3	R16442, 3	R16692, 3

[Function]

The tool radius compensation amount (M system) or the tool nose radius compensation amount (L system) is stored here.

[Operation]

When an alarm occurs, this automatically sets the tool radius compensation amount of that time.

For M system, offset amount (for offset type I), radius dimension (offset type II), or tool nose radius (offset type III) is displayed. For L system, the tool nose radius offset is displayed.

"0" is set when the tool radius compensation amount cannot be set, such as when the tool number is not designated.

The unit is [μ m].

When MES interface library function is invalid, this signal is set to "0".

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Tool length wear amount		R14944, 5	R15194, 5	R15444, 5	R15694, 5	R15944, 5	R16194, 5	R16444, 5	R16694, 5

[Function]

The tool length wear amount (M system) or the X axis tool wear amount (L system) when an alarm occurs is stored here.

[Operation]

The tool length wear amount at the time of alarm occurrence is automatically set.

For M system, compensation amount (for compensation type I), length wear (for compensation type II), or Z axis tool wear (for compensation type III) is displayed. For L system, X axis tool wear is displayed.

"0" is set when the tool length wear amount cannot be set, such as when the tool number is unspecified. The unit is [μ m].

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Tool radius wear amount		R14946, 7	R15196, 7	R15446, 7	R15696, 7	R15946, 7	R16196, 7	R16446, 7	R16696, 7

[Function]

The tool radius wear amount (M system) or the tool nose radius wear amount (L system) is stored here.

[Operation]

The tool radius wear amount at the time of alarm occurrence is automatically set.

For M system, compensation amount (for compensation type I), length wear (for compensation type II), or Z axis tool wear (for compensation type III) is displayed. For L system, X axis tool wear is displayed.

"0" is set when the tool radius wear amount cannot be set, such as when the tool number is unspecified. The unit is [μ m].

When MES interface library function is invalid, this signal is set to "0".

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Tool life		R14948, 9	R15198, 9	R15448, 9	R15698, 9	R15948, 9	R16198, 9	R16448, 9	R16698, 9

[Function]

The tool life data when an alarm occurs is stored.

[Operation]

The tool life (cumulative cutting hours and cumulative number of cuttings) for the tool being used at the time of alarm occurrence is automatically set.

The tool life data is set only when the tool life management I is valid for both M and L systems.

"0" is set when tool life management II or III is valid or tool life management function is invalid.

Data type depends on the setting of management method for M system. Specify the data type in minutes in the case of usage time and specify it by the number of times in the case of usage count. Specify usage time in minutes for L system.

"0" is set when tool lives are unsettingtable such as tool numbers are unspecified.

When MES interface library function is invalid, this signal is set to "0".

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	Common (\$)
A	EcoMonitorLight connection: Read start bit		R20288

[Function]

This start bit executes the power value collection.

[Operation]

When "1" is written to Bit0, the power value collecting function is executed based on the setting values written in R20289 to R20291.

The bit is cleared to zero in the next cycle.

Bit0

1: Start

0: Stop

This register holds the value even after the power is turned OFF.

[Related signals]

- (1) EcoMonitorLight connection: Completion bit (R14400)
- (2) EcoMonitorLight connection: Completion status (R14401)
- (3) EcoMonitorLight connection: Acquired data (R14402 to R14405)
- (4) EcoMonitorLight connection: Station No. (R20289)
- (5) EcoMonitorLight connection: Register address (R20290)
- (6) EcoMonitorLight connection: Size of data to read (R20291)

Cont.	Signal name	Abbrev.	Common (\$)
A	EcoMonitorLight connection: Station No.		R20289
A	EcoMonitorLight connection: Register address		R20290
A	EcoMonitorLight connection: Size of data to read		R20291

[Function]

This register sets the information required for the power value collection.

[Operation]

The required information is set with user's ladder program.

These data is read into CNC by writing "1" to R20288.

This register holds the value even after the power is turned OFF.

[Related signals]

- (1) EcoMonitorLight connection: Read start bit (R20288)
- (2) EcoMonitorLight connection: Completion bit (R14400)
- (3) EcoMonitorLight connection: Completion status (R14401)
- (4) EcoMonitorLight connection: Acquired data (R14402 to R14405)

Cont.	Signal name	Abbrev.	Common (\$)
A	Interference check III: Interfering object selection	ITF3DFTH	R20304 to R20449

[Function] [Operation]

An interfering object to be used in the interference check III is selected.

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

System variable	R register	Item	Details	Setting range (unit) Upper: System variable Lower: R register
#40000	R20304	Interfering object enable/disable designation	Set enable/disable for each interfering object. Bit designation (0: enable 1: disable) bit0: Disable 1st interfering object : bitF: Disable 16th interfering object	0 to 65535 (decimal) 0x0000 to 0xFFFF (hexadecimal)
#40001	R20305	Spare		0 0
40002	R20306	1st interfering object selection	Select interfering object definition No. to use.	0 to 128 (0: not selected) 0 to 128 (0: not selected)
#40003	R20307	1st interfering object specification	In the configured solid specification of the interfering object definition, specify alarm area/warning area/solid setting invalid of the solid in which switching method is selected. 0, 1: Alarm area 2: Warning area 3: Solid setting invalid	0 to 3 0 to 3
#40004	R20308 (L) R20309 (H)	1st interfering model coordinate system I axis offset 1	Set the interfering model coordinate system offset with a radius value. (I axis direction) (*1)	-99999.999 to 99999.999 (mm) (radius value)
#40005	R20310 (L) R20309 (H)	1st interfering model coordinate system J axis offset 1	Set the interfering model coordinate system offset with a radius value. (J axis direction) (*1)	-999999999 to 999999999 (mm) (radius value)
#40006	R20312 (L) R20313 (H)	1st interfering model coordinate system K axis offset 1	Set the interfering model coordinate system offset with a radius value. (K axis direction) (*1)	
:	:			
#40077	R20426	16th interfering object selection	Same as above	Same as above
#40078	R20427	16th interfering object specification selection	Same as above	Same as above
#40079	R20428 (L) R20429 (H)	16th interfering model coordinate system I axis offset 1	Same as above	Same as above
#40080	R20430 (L) R20431 (H)	16th interfering model coordinate system J axis offset 1	Same as above	Same as above
#40081	R20432 (L) R20433 (H)	16th interfering model coordinate system K axis offset 1	Same as above	Same as above
#40082	R20434	1st interfering object Interference check III: Specifying disabled interference object	Select an interfering object that you do not check the interference with the 1st interfering object. bit0: Disable 1st interfering object (inaction data) bit1: Disable 2nd interfering object : bitF: Disable 16th interfering object	0 to 65535 (decimal) 0x0000 to 0xFFFF (hexadecimal)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

System variable	R register	Item	Details	Setting range (unit) Upper: System variable Lower: R register
#40083	R204325	2nd interfering object: Specifying disabled object with interference check III	Select an interfering object that you do not check the interference with the 2nd interfering object. bit0: Disable 1st interfering object bit1: Disable 2nd interfering object (inaction data) : bitF: Disable 16th interfering object	0 to 65535 (decimal) 0x0000 to 0xFFFF (hexadecimal)
:	:			
#40097	R20449	16th interfering object: Specifying disabled object with interference check III	Select an interfering object that you do not check the interference with the 16th interfering object. bit0: Disable 1st interfering object bit1: Disable 2nd interfering object : bitF: Disable 16th interfering object (inaction data)	0 to 65535 (decimal) 0x0000 to 0xFFFF (hexadecimal)

(*1) The interfering model coordinate system offset is the sum of interfering model coordinate system offsets 1 and 2.


Cont.	Signal name	Abbrev.	Common (\$)
A	Diagnosis data output: Select axis for servomotor insulation degradation detection (PLC axis)	SVIDDDAX	R20450

[Function]

This signal is used to select the PLC axis for insulation resistance measurement.

[Operation]

When the control starts measuring the motor insulation resistance, the measurement starts on the axis for which the signal is ON.

**[Related signals]**

- (1) Diagnosis data output: Motor insulation degradation detection request (IDDD: R20481)

4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)


Cont.	Signal name	Abbrev.	Common (\$)
A	Diagnosis data output: Select spindle for motor insulation degradation detection	SPIDDDAX	R20451

[Function]

This signal is used to select the spindle for insulation resistance measurement.

[Operation]

When the control starts measuring the motor insulation resistance, the measurement starts on the spindle for which the signal is ON.

**[Related signals]**

- (1) Diagnosis data output: Motor insulation degradation detection request (IDDD: R20481)

Cont.	Signal name	Abbrev.	Common (\$)
A	Laser: Laser output override		R20453

[Function]

This signal is used to set the override value of the laser output (W).

[Operation]

This register can be set within the range of 0% to 100% in 1% increment.

When a value larger than 100% is set, the value is regarded as 100%.

[Related signals]

- (1) Laser: Laser beam irradiation ON (Y1CA7)

Cont.	Signal name	Abbrev.	Common (\$)
A	Touchscreen operation disabled	TP_INVALID	R20480

[Function]

Touchscreen operation can be temporarily disabled by using this signal (TP_INVALID).


[Operation]

When you turn ON (disable) R20480 bit0, the touchscreen operation is disabled.

When you change R20480 bit0 from OFF (enable) to ON (disable) with the touchscreen pressed, the touch is interpreted to be released at the time of ON.

When you change R20480 bit0 from ON (disable) to OFF (enable) with the touchscreen pressed, the touch is interpreted to be made at the time of OFF.

The servo ready sequence is held until the measurement of insulation resistance is completed.



- (1) Diagnosis data output: Servomotor insulation degradation detection in progress (SVIDDD: R20522)
- (2) Diagnosis data output: Spindle motor insulation degradation detection in progress (SPIDDD: R20048)
- (3) Diagnosis data output: Select axis for servomotor insulation degradation detection (SVIDDDAX: R22501)
- (4) Diagnosis data output: Select spindle for motor insulation degradation detection (SPIDDDAX: R20451)


4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Program restart: Restart position return check invalid		R22500	R22700	R22900	R23100	R23300	R23500	R23700	R23900

[Function]

This signal disables the program restart function from checking whether the axis has returned to the restart position after restart search.

**[Operation]**

When restarting a machining program after restart search while this signal is ON, NC will not check if the axis selected by the bit of this signal has returned to the restart position, regardless of whether the command is programmed or not.

The program operation restarts at cycle start even when the said axis has not returned to the restart position.

Finish the restart search, then turn on this signal before restart the cycle. Keep this signal ON until the "In automatic operation "run"" signal (OP: XC12) turns ON.

[Caution]

- (1) While this signal is ON, restart position return operation is not performed on an axis for which the parameter "#1302 AutoRP" is "1" (Automatic return to restart position) and the parameter "#2082 a_rstax" is other than "0".
- (2) If an axis selected by the bit of this signal is programmed while this signal is ON, the program is able to restart even when the axis is not in the restart position. This may change the tool path after the program restart. Thus before executing a cycle start, make sure that the said axis is in a position where the program is possible to restart.


Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	Diagnosis data output: Select axis for servomotor insulation degradation detection	SVIDDD AX	R22501	R22701	R22901	R23101	R23301	R23501	R23701	R23901

[Function]

This signal is used to select the servo axis for insulation resistance measurement.

[Operation]

When the control starts measuring the motor insulation resistance, the measurement starts on the axis for which the signal is ON.

**[Related signals]**

- (1) Diagnosis data output: Motor insulation degradation detection request (IDDD: R20481)


4 Explanation of Interface Signals

4.4 PLC Output Signals (Data Type: R***)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	VCC: Temporary cancel of axis vibration	VCC_IN-VAX	R22532	R22732	R22932	R23132	R23332	R23532	R23732	R23932

[Function]

This signal is used to temporarily disable the vibration cutting control. (This can be set for each axis.)

**Note**

- (1) Switching an axis does not change a bit position.

[Operation]

Turning this signal ON can temporarily disable the vibration cutting control of the control axis corresponding to the bits. When this signal is ON for the axis to be vibrated at the time of cutting command in the vibration cutting mode, the operation error (M01 1302) occurs. Machining continues without the vibration cutting control.

[Caution]

After all axes in the part system are stopped, the setting of this signal becomes valid from the subsequent program blocks. When the axes are moving, the previous status of the signal is retained. However, when the axis is stopped during the fixed cycle execution, the signal retains its status at the start of fixed cycle.

[Related signals]

- (1) VCC: Mode in execution (VCC: X1810)
- (2) VCC: Numbers of vibrations (VCC_VIB: R20556)
- (3) VCC: Frequency (VCC_FRQ: R20557)
- (4) VCC: Spindle rotation speed (VCC_SPREV: R7024,R7025)
- (5) VCC: Vibrating axis (VCC_VIBAX: R20558)
- (6) VCC: Temporary cancel of axis vibration (VCC_INVAX: R22532)
- (7) VCC: Cause of non-vibration (VCC_FACT: R20559)

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	CLC: Spindle selection		R22540	R22740	R22940	R23140	R23340	R23540	R23740	R23940

[Function]

The cutting load of spindle to be used during the cutting load control is specified in binary.

Setting value	Spindle	Setting value	Spindle
0	1st spindle	4	5th spindle
1	2nd spindle	5	6th spindle
2	3rd spindle	6	7th spindle
3	4th spindle	7	8th spindle

Note

- (1) When the set value is larger than the maximum number of connected spindles, the cutting load control will be disabled.

[Operation]

During the cutting load control, the cutting load is controlled using the load value of the spindle selected by this signal. Set the spindle to be used in the part system.

[Related signals]

- (1) CLC: Maximum load (R20564)
- (2) CLC: Minimum load (R20565)

4 Explanation of Interface Signals

4.5 Explanation of Special Relays (SM^{***})

4.5 Explanation of Special Relays (SM^{***})

Cont.	Signal name	Abbrev.	Common (\$)
A	Temperature rise		SM16

[Function] [Operation]

If the alarm is displayed when an overheat alarm is detected in the control unit or communication terminal, the overheat signal will be output simultaneously. If the machine is in automatic operation, the operation will be continued, but restarting will not be possible after resetting or stopping with M02/M30. (Starting will be possible after block stop or feed hold.)

For details on the operation, etc., refer to "Temperature warning cause".



CAUTION

If the temperature rise detection function is invalidated with the parameters, the control could be disabled when the temperature is excessive. This could result in machine damage or personal injuries due to runaway axis, and could damage the device. Enable the detection function for normal use.

[Related signals]

- (1) Temperature warning cause (R57)
- (2) Control unit temperature (R60)

4.6 Explanation of ZR Device

4.6.1 Smart Safety Observation

4.6.1.1 PLC -> CNC

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
B	SLS observation request (control axis)	*SLSRm	ZR256 bit0	ZR256 bit1	ZR256 bit2	ZR256 bit3	ZR256 bit4	ZR256 bit5	ZR256 bit6	ZR256 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR256 bit8	ZR256 bit9	ZR256 bit10	ZR256 bit11	ZR256 bit12	ZR256 bit13	ZR256 bit14	ZR256 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR257 bit0	ZR257 bit1	ZR257 bit2	ZR257 bit3	ZR257 bit4	ZR257 bit5	ZR257 bit6	ZR257 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR257 bit8	ZR257 bit9	ZR257 bit10	ZR257 bit11	ZR257 bit12	ZR257 bit13	ZR257 bit14	ZR257 bit15

[Function]

This signal is used to start execution of the SLS observation function on the control axis.

This signal is available when the parameter "#51002 SLS_Enable" (Enable SLS observation) is set to "1" (Enable).

(This signal is ignored when the parameter "#51002 SLS_Enable" (Enable SLS observation) is set to "0" (Disable).)

[Operation]

When the "SLS observation request" signal is turned OFF (when SLS is requested), the NC carries out the following operations:

- (1) Checks the SLS parameters to be used.
- (2) Executes the NC's SLS observation function, and turns ON the "SLS observation is active" (SLSEm).
- (3) Turns ON the "Under SLS limit" signal (SLSSm) when the axis is confirmed to have decelerated to the safely-limited speed or below.

[Related signals]

- (1) SLS speed change input (SLSMIIn)
- (2) SLS speed change output (SLSMOmn)
- (3) SLS speed override input (SLSOVRImn)
- (4) SLS speed override output (SLSOVROmn)
- (5) SLS observation is active (SLSEm)
- (6) Under SLS limit (SLSSm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
B	SLP observation request (control axis)	*SLPRm	ZR258 bit0	ZR258 bit1	ZR258 bit2	ZR258 bit3	ZR258 bit4	ZR258 bit5	ZR258 bit6	ZR258 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR258 bit8	ZR258 bit9	ZR258 bit10	ZR258 bit11	ZR258 bit12	ZR258 bit13	ZR258 bit14	ZR258 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR259 bit0	ZR259 bit1	ZR259 bit2	ZR259 bit3	ZR259 bit4	ZR259 bit5	ZR259 bit6	ZR259 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR259 bit8	ZR259 bit9	ZR259 bit10	ZR259 bit11	ZR259 bit12	ZR259 bit13	ZR259 bit14	ZR259 bit15

[Function]

This signal is used to start execution of the SLP observation function on the control axis.

This signal is available when the parameter "#51003 SLP_Enable" (Enable SLP observation) is set to "1" (Enable).

(This signal is ignored when the parameter "#51003 SLP_Enable" (Enable SLP observation) is set to "0" (Disable).)

[Operation]

When the "SLP observation request" signal is turned OFF (when SLP is requested), the NC carries out the following operations:

- (1) Checks the SLP parameters to be used.
- (2) Executes the NC's SLP observation function, and turns ON the "SLP observation is active" (SLPEm).
- (3) Turns ON the "In SLP range" signal (SLPSm) when the axis is confirmed to be in the SLP position tolerance range.

[Related signals]

- (1) SLP position change input (SLPMImn)
- (2) SLP position change output (SLPMOm)
- (3) SLP observation is active (SLPEm)
- (4) In SLP range (SLPSm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
B	SSM request (control axis)	*SSMRm	ZR260 bit0	ZR260 bit1	ZR260 bit2	ZR260 bit3	ZR260 bit4	ZR260 bit5	ZR260 bit6	ZR260 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR260 bit8	ZR260 bit9	ZR260 bit10	ZR260 bit11	ZR260 bit12	ZR260 bit13	ZR260 bit14	ZR260 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR261 bit0	ZR261 bit1	ZR261 bit2	ZR261 bit3	ZR261 bit4	ZR261 bit5	ZR261 bit6	ZR261 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR261 bit8	ZR261 bit9	ZR261 bit10	ZR261 bit11	ZR261 bit12	ZR261 bit13	ZR261 bit14	ZR261 bit15

[Function]

This signal is used to start execution of SSM on the control axis.

This signal is available when the parameter "#51004 SSM_Enable" (Enable Safe speed monitor) is set to "1" (Enable).

(This signal is ignored when the parameter "#51004 SSM_Enable" (Enable Safe speed monitor) is set to "0" (Disable).)

[Operation]

When the "SSM request" signal is turned OFF (when SSM is requested), the NC carries out the following operations:

- (1) Checks the SSM parameters to be used.
- (2) Executes the NC's Safe speed monitor function, and turns ON the "SSM is active" signal (SSMEm).
- (3) Turns ON 1 to 4 of the "Under SSM safe speed" signal (SSMSmn) when the axis is confirmed to be at the safe speed or below.

[Related signals]

- (1) SSM is active (SSMEm)
- (2) Under SSM safe speed (SSMSmn)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
B	Safe cam request (control axis)	*SCARm	ZR262 bit0	ZR262 bit1	ZR262 bit2	ZR262 bit3	ZR262 bit4	ZR262 bit5	ZR262 bit6	ZR262 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR262 bit8	ZR262 bit9	ZR262 bit10	ZR262 bit11	ZR262 bit12	ZR262 bit13	ZR262 bit14	ZR262 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR263 bit0	ZR263 bit1	ZR263 bit2	ZR263 bit3	ZR263 bit4	ZR263 bit5	ZR263 bit6	ZR263 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR263 bit8	ZR263 bit9	ZR263 bit10	ZR263 bit11	ZR263 bit12	ZR263 bit13	ZR263 bit14	ZR263 bit15

[Function]

This signal is used to start execution of the Safe cam function on the control axis.

This signal is available when the parameter "#51005 SCA_Enable" (Enable safe cam) is set to "1" (Enable).

(This signal is ignored when the parameter "#51005 SCA_Enable" (Enable safe cam) is set to "0" (Disable).)

[Operation]

When the "Safe cam request" signal is turned OFF (when SCA is requested), the NC carries out the following operations:

- (1) Checks the SCA parameters to be used.
- (2) Executes the NC's Safe cam function and turns ON the "Safe cam is active" signal (SCAEm).
- (3) Outputs the safe cam position status to the "Safe cam position" signal (SCASm).

[Related signals]

- (1) Safe cam is active (SCAEm)
- (2) Safe cam position (SCASmn)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
B	SOS observation request (control axis)	*SOSRm	ZR264 bit0	ZR264 bit1	ZR264 bit2	ZR264 bit3	ZR264 bit4	ZR264 bit5	ZR264 bit6	ZR264 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR264 bit8	ZR264 bit9	ZR264 bit10	ZR264 bit11	ZR264 bit12	ZR264 bit13	ZR264 bit14	ZR264 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR265 bit0	ZR265 bit1	ZR265 bit2	ZR265 bit3	ZR265 bit4	ZR265 bit5	ZR265 bit6	ZR265 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR265 bit8	ZR265 bit9	ZR265 bit10	ZR265 bit11	ZR265 bit12	ZR265 bit13	ZR265 bit14	ZR265 bit15

[Function]

This signal is used to start execution of the SOS observation function on the control axis.

This signal is available when the parameter "#51006 SOS_Enable" (Enable Safe operating stop) is set to "1" (Enable).

(This signal is ignored when the parameter "#51006 SOS_Enable" (Enable Safe operating stop) is set to "0" (Disable).)

[Operation]

When the "SOS observation request" is turned OFF (when SOS is requested), the NC carries out the following operations:

- (1) Checks the SOS parameters to be used.
- (2) Executes the NC's Safe operating stop function, and turns ON the "SOS is active" signal (SOSEm).
- (3) Turns ON the "In SOS stop" signal (SOSSm) when the safe standstill state of the axis is confirmed.

[Related signals]

- (1) SOS is active (SOSEm)
- (2) In SOS stop (SOSSm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
B	Safe stop 1 request (control axis)	*SS1Rm	ZR266 bit0	ZR266 bit1	ZR266 bit2	ZR266 bit3	ZR266 bit4	ZR266 bit5	ZR266 bit6	ZR266 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR266 bit8	ZR266 bit9	ZR266 bit10	ZR266 bit11	ZR266 bit12	ZR266 bit13	ZR266 bit14	ZR266 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR267 bit0	ZR267 bit1	ZR267 bit2	ZR267 bit3	ZR267 bit4	ZR267 bit5	ZR267 bit6	ZR267 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR267 bit8	ZR267 bit9	ZR267 bit10	ZR267 bit11	ZR267 bit12	ZR267 bit13	ZR267 bit14	ZR267 bit15

[Function]

This signal is used to start execution of Safe stop 1 on the control axis.

This signal is available when the parameter "#51007 SS1_Enable" (Enable Safe stop 1) is set to "1" (Enable).

(This signal is ignored when the parameter "#51007 SS1_Enable" (Enable Safe stop 1) is set to "0" (Disable).)

[Operation]

When the "Safe stop 1 request" signal is turned OFF (when SS1 is requested), the NC carries out the following operations:

- (1) Checks the SS1 parameters to be used.
- (2) Executes the NC's Safe stop 1 function, and turns ON the "SS1 is active" signal (SS1Em).
- (3) Turns ON the "In Safe stop 1" signal (SS1Sm) when the axis deceleration is confirmed.

[Related signals]

- (1) SS1 is active (SS1Em)
- (2) In safe stop 1(SS1Sm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
B	Safe stop 2 request (control axis)	*SS2Rm	ZR268 bit0	ZR268 bit1	ZR268 bit2	ZR268 bit3	ZR268 bit4	ZR268 bit5	ZR268 bit6	ZR268 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR268 bit8	ZR268 bit9	ZR268 bit10	ZR268 bit11	ZR268 bit12	ZR268 bit13	ZR268 bit14	ZR268 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR269 bit0	ZR269 bit1	ZR269 bit2	ZR269 bit3	ZR269 bit4	ZR269 bit5	ZR269 bit6	ZR269 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR269 bit8	ZR269 bit9	ZR269 bit10	ZR269 bit11	ZR269 bit12	ZR269 bit13	ZR269 bit14	ZR269 bit15

[Function]

This signal is used to start execution of the Safe stop 2 function on the control axis.

This signal is available when the parameter "#51008 SS2_Enable" (Enable Safe stop 2) is set to "1" (Enable).

(This signal is ignored when the parameter "#51008 SS2_Enable" (Enable Safe stop 2) is set to "0" (Disable).)

[Operation]

When the "Safe stop 2 request" signal is turned OFF (when SS1 is requested), the NC carries out the following operations:

- (1) Checks the SS2 parameters to be used.
- (2) Executes the NC's Safe stop 2 function, and turns ON the "SS1 is active" signal (SS2Em).
- (3) Executes Safe operating stop (SOS) when the axis deceleration is confirmed.

[Related signals]

- (1) SS2 is active (SS2Em)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
B	Safe torque OFF request (control axis)	*STORM	ZR270 bit0	ZR270 bit1	ZR270 bit2	ZR270 bit3	ZR270 bit4	ZR270 bit5	ZR270 bit6	ZR270 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR270 bit8	ZR270 bit9	ZR270 bit10	ZR270 bit11	ZR270 bit12	ZR270 bit13	ZR270 bit14	ZR270 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR271 bit0	ZR271 bit1	ZR271 bit2	ZR271 bit3	ZR271 bit4	ZR271 bit5	ZR271 bit6	ZR271 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR271 bit8	ZR271 bit9	ZR271 bit10	ZR271 bit11	ZR271 bit12	ZR271 bit13	ZR271 bit14	ZR271 bit15

[Function]

This signal is used to start execution of the Safe torque off function on the control axis.

This signal is available when the parameter "#51009 STO_Enable" (Enable Safe torque off) is set to "1" (Enable).

(This signal is ignored when the parameter "#51009 STO_Enable" (Enable Safe torque off) is set to "0" (Disable).)

[Operation]

When the "Safe torque off request" signal is turned OFF (when STO is requested), the NC carries out the following operations:

- (1) Checks the STO parameters to be used.
- (2) Executes the NC's Safe torque off function, and turns ON the "STO is active" signal (STOEm).
- (3) Turns ON the "In Safe torque off" signal (STOSm) when the main power supply for driving the axis is shut OFF.

[Related signals]

- (1) STO is active (STOEm)
- (2) In Safe torque off (STOSm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
B	SBC motor brake starting request (control axis)	*SBCRM	ZR272 bit0	ZR272 bit1	ZR272 bit2	ZR272 bit3	ZR272 bit4	ZR272 bit5	ZR272 bit6	ZR272 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR272 bit8	ZR272 bit9	ZR272 bit10	ZR272 bit11	ZR272 bit12	ZR272 bit13	ZR272 bit14	ZR272 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR273 bit0	ZR273 bit1	ZR273 bit2	ZR273 bit3	ZR273 bit4	ZR273 bit5	ZR273 bit6	ZR273 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR273 bit8	ZR273 bit9	ZR273 bit10	ZR273 bit11	ZR273 bit12	ZR273 bit13	ZR273 bit14	ZR273 bit15

[Function]

This signal is for starting the motor brake by safety brake control.

This signal is available when the parameter "#51010 SBC_Enable" (Safe brake control enabled) is set to "1" (Enable).

(This signal is ignored when the parameter "#51010 SBC_Enable" (Safe brake control enabled) is set to "0" (Disable).)

[Operation]

By turning OFF this signal (when SBC is requested), the NC outputs the motor brake starting request to the drive unit.

When the motor brake starts, the "In SBC motor brake start" signal (SBCSm) turns ON.

When the power is shut OFF (at Safety related error, at the *STORM signal OFF, and the *SS1Rm signal OFF), the motor brake start is performed automatically. To start the motor brake independently, turn this signal OFF.

[Caution]

Even though this signal is turned OFF for the axis where the parameter "#51200 SFSPEC1/bit3" is set to "1", it is ignored.

[Related signals]

- (1) Safe torque off request (*STORM)
- (2) Safe stop 1 request (*SS1Rm)
- (3) In SBC motor brake enabled (*SBCEm)
- (4) In SBC motor brake start (SBCSm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	External brake SBT start (control axis)	SBT- STEXm	ZR274 bit0	ZR274 bit1	ZR274 bit2	ZR274 bit3	ZR274 bit4	ZR274 bit5	ZR274 bit6	ZR274 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR274 bit8	ZR274 bit9	ZR274 bit10	ZR274 bit11	ZR274 bit12	ZR274 bit13	ZR274 bit14	ZR274 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR275 bit0	ZR275 bit1	ZR275 bit2	ZR275 bit3	ZR275 bit4	ZR275 bit5	ZR275 bit6	ZR275 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR275 bit8	ZR275 bit9	ZR275 bit10	ZR275 bit11	ZR275 bit12	ZR275 bit13	ZR275 bit14	ZR275 bit15

[Function]

This signal is for testing external brakes with Safety Brake Control.

This signal is available only when the parameter "#51010 SBC_Enable" (Safe brake control enabled) is set to "1" (Enable) and "#51186 SBTEX_Enable" (External brake SBT enabled) is set to "1" (Enable).

(This signal is ignored when the parameter "#51010 SBC_Enable" (Safe brake control enabled) is set to "0" (Disable), or "#51186 SBTEX_Enable" (External brake SBT enabled) is set to "0" (Disable).)


[Operation]

When the NC is turned ON, and after a certain period of time has elapsed since the last brake test (parameter "#51011 SBT_INT"), the "External brake SBT incomplete" signal (SBTNFEXm) turns ON as a warning.

Turn ON the SBTSTEXm and perform the brake test. When the test completes successfully, the SBTNFEXm turns OFF.

The test can be temporarily stopped by turning OFF the SBTSTEXm during the test.

After the temporary stop, the test can be resumed by turning ON the SBTSTEXm.



4 Explanation of Interface Signals

4.6 Explanation of ZR Device

[Caution]

When SBTSTEXm is turned ON without meeting the following conditions, the brake test does not start. When this signal is turned ON without satisfying (1) to (12) of (Condition), the smart safety observation alarm (V51 0001) occurs.

(Condition)

- (1) All part systems are not in automatic operation.
- (2) The target axis to be tested is in in-position.
- (3) The target axis to be tested is in servo ON state.
- (4) The target axis to be tested is not in current limit.
- (5) The target axis to be tested is not the slave axis in the synchronous control.
- (6) The target axis to be tested is not in superimposition control.
- (7) There is no axis which is in arbitrary axis exchange control in the part system to which the target axis to be tested belongs.
- (8) There is no axis which is in mixed control in the part system to which the target axis to be tested belongs.
- (9) The parameter "#51191 SBT_ILIM" (SBT current limit value) of target axis to be tested is not "0".
- (10) The parameter "#51193 SBT_FD" (SBT movement command amount) of target axis to be tested is not "0".
- (11) The parameter "#51194 SBT_FDRATE" (SBT command speed) of target axis to be tested is not "0".
- (12) The "Reference position establishment" signal of the target axis to be tested is ON.
- (13) The target axis is not in PLC axis mode of NC axis/PLC axis switchover function.

[Related signals]

- (1) External brake SBT Incomplete (SBTNFEXm)
- (2) In SBT External brake test (SBTEXBRm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Motor brake SBT start (control axis)	SBTSTMom	ZR276 bit0	ZR276 bit1	ZR276 bit2	ZR276 bit3	ZR276 bit4	ZR276 bit5	ZR276 bit6	ZR276 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR276 bit8	ZR276 bit9	ZR276 bit10	ZR276 bit11	ZR276 bit12	ZR276 bit13	ZR276 bit14	ZR276 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR277 bit0	ZR277 bit1	ZR277 bit2	ZR277 bit3	ZR277 bit4	ZR277 bit5	ZR277 bit6	ZR277 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR277 bit8	ZR277 bit9	ZR277 bit10	ZR277 bit11	ZR277 bit12	ZR277 bit13	ZR277 bit14	ZR277 bit15

[Function]

This signal is for testing motor brakes with Safety Brake Control.

This signal can be used only when the parameter "#51010 SBC_Enable" (Safe brake control enabled) is set to "1" (Enable) and "#51187 SBTMO_Enable" (Motor brake SBT enabled) is set to "1" (Enable).

(This signal is ignored when the parameter "#51010 SBC_Enable" (Safe brake control enabled) is set to "0" (Disable), or "#51187 SBTMO_Enable" (Motor brake SBT enabled) is set to "0" (Disable).)


[Operation]

When the NC is turned ON, and after a certain period of time has elapsed since the last brake test (parameter "#51011 SBT_INT" (SBT interval)), the "Motor brake SBT incomplete" signal (SBTNFMom) turns ON as a warning.

Turn ON the SBTSTMom and perform the brake test. When the test completes successfully, the SBTNFMom turns OFF.

The test can be temporarily stopped by turning OFF the SBTSTMom during the test.

After the temporary stop, the test can be resumed from the test pattern1 by turning ON the SBTSTMom.



4 Explanation of Interface Signals

4.6 Explanation of ZR Device

[Caution]

When SBTSTMOM is turned ON without meeting the following conditions, the brake test does not start. When this signal is turned ON without satisfying (1) to (12) of (Condition), the smart safety observation alarm (V51 0001) occurs.

(Condition)

- (1) All part systems are not in automatic operation.
- (2) The target axis to be tested is in in-position.
- (3) The target axis to be tested is in servo ON state.
- (4) The target axis to be tested is not in current limit.
- (5) The target axis to be tested is not the slave axis in the synchronous control.
- (6) The target axis to be tested is not in superimposition control.
- (7) There is no axis which is in arbitrary axis exchange control within the part system to which target axis to be tested belongs.
- (8) There is no axis which is in mixed control within the part system to which target axis to be tested belongs.
- (9) The parameter "#51191 SBT_ILIM" (SBT current limit value) of target axis to be tested is not "0".
- (10) The parameter "#51193 SBT_FD" (SBT movement command amount) of target axis to be tested is not "0".
- (11) The parameter "#51194 SBT_FDRATE" (SBT command speed) of target axis to be tested is not "0".
- (12) The reference position establishment signal of target axis to be tested is ON.
- (13) The target axis is not in PLC axis mode of NC axis/PLC axis switchover function.

[Related signals]

- (1) Motor brake SBT incomplete (SBTNFMOM)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Safety absolute position confirm (control axis)	SFABSPFXm	ZR278 bit0	ZR278 bit1	ZR278 bit2	ZR278 bit3	ZR278 bit4	ZR278 bit5	ZR278 bit6	ZR278 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR278 bit8	ZR278 bit9	ZR278 bit10	ZR278 bit11	ZR278 bit12	ZR278 bit13	ZR278 bit14	ZR278 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR279 bit0	ZR279 bit1	ZR279 bit2	ZR279 bit3	ZR279 bit4	ZR279 bit5	ZR279 bit6	ZR279 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR279 bit8	ZR279 bit9	ZR279 bit10	ZR279 bit11	ZR279 bit12	ZR279 bit13	ZR279 bit14	ZR279 bit15

[Function]

This signal is used to cancel the alarm "Safe absol. posn unestablished" and establish the safety absolute position in SLP/SCA encoder diagnosis during power OFF.

[Operation]

When the "Safe absol. posn unestablished" alarm is occurring, turning ON this signal will cancel the alarm and bring it to the safety absolute position established state (the "In safety position establishing" signal is ON.). By establishing the safety absolute position, the observation with SLP and the signal output with SCA is possible. (SLP/SCA will not operate while the "Safe absol. posn unestablished" alarm is occurring.)

[Caution]

This alarm is to show that users have checked the correctness of the absolute position. Before turning ON this signal, manually move the axis to a position where the coordinate values are clear (marked position, reference position, etc.) (in the case of a relative position detection system, operate the reference position return), then compare the actual position and the displayed position to confirm the both positions are corresponding.

[Related signals]

- (1) In safety absolute position establishing (Control axis) (SFABSPESTm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Safety reset (control axis)	SRSTm	ZR280 bit0	ZR280 bit1	ZR280 bit2	ZR280 bit3	ZR280 bit4	ZR280 bit5	ZR280 bit6	ZR280 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR280 bit8	ZR280 bit9	ZR280 bit10	ZR280 bit11	ZR280 bit12	ZR280 bit13	ZR280 bit14	ZR280 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR281 bit0	ZR281 bit1	ZR281 bit2	ZR281 bit3	ZR281 bit4	ZR281 bit5	ZR281 bit6	ZR281 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR281 bit8	ZR281 bit9	ZR281 bit10	ZR281 bit11	ZR281 bit12	ZR281 bit13	ZR281 bit14	ZR281 bit15

[Function]

This signal is used to reset the alarm for the control axis's safety function. When the alarm for the safety function has not been occurred, this signal is ignored.

[Operation]

By turning ON this signal, the NC carries out the following operations:

(1) Check whether the occurring alarm for safety function is in the state that is possible to cancel(*1).

(*1) The alarm is possible to cancel in any of the following status.

When the function corresponding to the occurring alarm (SLS/SLP/SOS/SS1/SS2) is enabled, the enabled function is determined to be in safety status. ("In Safely-limited speed"/"In Safely-limited position"/"In Safe operating stop"/"In Safe stop 1" are ON. (The safety status of SS2 is determined by the "In Safe operating stop".))

The function corresponding to the occurring alarm (SLS/SLP/SOS/SS1/SS2) is disabled. (The request signal is OFF.)

(2) Cancel the alarm after the check proves the alarm status is possible to cancel.

(3) Turn back the drive power ON.

[Caution]

When the safety functions alarm, including the parameter error, are not in state that to be canceled, ("In Safely-limited speed"/"In Safely-limited position"/"In Safe operating stop"/"In Safe stop 1" are OFF in enabled SLS, SLP, SOS, SS1, and SS2), the alarm will not be canceled even when this signal is turned ON. (This signal will be ignored.)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SLS speed change input (control axis)	SLS- Mlmn	ZR312	ZR313	ZR314	ZR315	ZR316	ZR317	ZR318	ZR319
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR320	ZR321	ZR322	ZR323	ZR324	ZR325	ZR326	ZR327
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR328	ZR329	ZR330	ZR331	ZR332	ZR333	ZR334	ZR335
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR336	ZR337	ZR338	ZR339	ZR340	ZR341	ZR342	ZR343

[Function]

This signal specifies the SLS speed tolerance to be used for the SLS observation function.

This signal is available when the parameter "#51002 SLS_Enable" (Enable SLS observation) is set to "1" (Enable).

(This signal is ignored when the parameter "#51002 SLS_Enable" (Enable SLS observation) is set to "0" (Disable).)

<SLS speed input selection method>

SLS speed change input		No. of step to be select- ed	Corresponding SLS speed toler- ance parameter
Bit1	Bit0		
0	0	1	#51103 SLS_Speed1
0	1	2	#51104 SLS_Speed2
1	0	3	#51105 SLS_Speed3
1	1	4	#51106 SLS_Speed4

[Operation]

When this signal is changed, the "SLS speed change output" (SLSMOmn) is also changed.

(SLSMOmn is changed even though the "SLS observation request" (*SLSRm) is ON (when SLS is not requested).)

[Related signals]

- (1) SLS speed change output (SLSMOmn)
- (2) SLS speed override input (SLSOVRImn)
- (3) SLS speed override output (SLSOVROmn)
- (4) SLS observation request (*SLSRm)
- (5) SLS observation is active (SLSEm)
- (6) Under SLS limit (SLSSm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SLS speed override input (control axis)	SLSOVRImn	ZR312	ZR313	ZR314	ZR315	ZR316	ZR317	ZR318	ZR319
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR320	ZR321	ZR322	ZR323	ZR324	ZR325	ZR326	ZR327
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR328	ZR329	ZR330	ZR331	ZR332	ZR333	ZR334	ZR335
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR336	ZR337	ZR338	ZR339	ZR340	ZR341	ZR342	ZR343

[Function]

This signal specifies the SLS speed override to be used for the SLS observation function.

This signal is available when the parameter "#51002 SLS_Enable" (Enable SLS observation) is set to "1" (Enable).

(This signal is ignored when the parameter "#51002 SLS_Enable" (Enable SLS observation) is set to "0" (Disable).)

<SLS speed override selection method>

SLS speed override input				No. of step to be selected	Corresponding SLS speed override parameter
Bit7	Bit6	Bit5	Bit4		
0	0	0	0	1	#51107 SLS_Override1
0	0	0	1	2	#51108 SLS_Override2
0	0	1	0	3	#51109 SLS_Override3
0	0	1	1	4	#51110 SLS_Override4
0	1	0	0	5	#51111 SLS_Override5
0	1	0	1	6	#51112 SLS_Override6
0	1	1	0	7	#51113 SLS_Override7
0	1	1	1	8	#51114 SLS_Override8
1	0	0	0	9	#51115 SLS_Override9
1	0	0	1	10	#51116 SLS_Override10
1	0	1	0	11	#51117 SLS_Override11
1	0	1	1	12	#51118 SLS_Override12
1	1	0	0	13	#51119 SLS_Override13
1	1	0	1	14	#51120 SLS_Override14
1	1	1	0	15	#51121 SLS_Override15
1	1	1	1	16	#51122 SLS_Override16

[Operation]

When this signal is changed, the "SLS speed override output" (SLSOVROmn) is also changed.

(This signal is changed even though the "SLS observation request" (*SLSRm) is ON (when SLS is not requested).)

[Related signals]

- (1) SLS speed change input (SLSMImn)
- (2) SLS speed change output (SLSMOmn)
- (3) SLS speed override output (SLSOVROmn)
- (4) SLS observation request (*SLSRm)
- (5) SLS observation is active (SLSEm)
- (6) Under SLS limit (SLSSm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SLP position change input (control axis)	SLPMImn	ZR344	ZR345	ZR346	ZR347	ZR348	ZR349	ZR350	ZR351
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR352	ZR353	ZR354	ZR355	ZR356	ZR357	ZR358	ZR359
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR360	ZR361	ZR362	ZR363	ZR364	ZR365	ZR366	ZR367
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR368	ZR369	ZR370	ZR371	ZR372	ZR373	ZR374	ZR375

[Function]

This signal specifies the SLP position tolerance to be used for the SLP observation function.

This signal is available when the parameter "#51003 SLP_Enable" (Enable SLP observation) is set to "1" (Enable).

(This signal is ignored when the parameter "#51003 SLP_Enable" (Enable SLP observation) is set to "0" (Disable).)

<SLP position input selection method>

SLP position change input		No. of step to be select- ed	Corresponding SLP position tolerance parameter
Bit1	Bit0		
0	0	1	#51126/51127 SLP_Position (P/M) 1
0	1	2	#51128/51129 SLP_Position (P/M) 2
1	0	3	#51130/51131 SLP_Position (P/M) 3
1	1	4	#51132/51133 SLP_Position (P/M) 4

[Operation]

When this signal is changed, the "SLP position change output" (SLPMOmn) is also changed.

(This signal is changed even though the "SLP observation request" (*SLPRm) is ON (when SLP is not requested).)

[Related signals]

- (1) SLP position change output (SLPMOmn)
- (2) SLP observation request (*SLPRm)
- (3) SLP observation is active (SLPEm)
- (4) In SLP range (SLPSm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
B	SLS observation request (spindle)	*SLSS- Rm	ZR440 bit0	ZR440 bit1	ZR440 bit2	ZR440 bit3	ZR440 bit4	ZR440 bit5	ZR440 bit6	ZR440 bit7

[Function]

This signal starts execution of the SLS observation function on the spindle.

This signal is available when the parameter "#51002 SLS_Enable" (Enable SLS observation) is set to "1" (Enable).

(This signal is ignored when the parameter "#51002 SLS_Enable" (Enable SLS observation) is set to "0" (Disable).)

[Operation]

When the "SLS observation request" signal is turned OFF (when SLS is requested), the NC carries out the following operations:

- (1) Checks the SLS parameters to be used.
- (2) Executes the NC's SLS observation function, and turns ON the "SLS observation is active" (SLSSEm).
- (3) Turns ON the "Under SLS limit" signal (SLSSSm) when the spindle is confirmed to have decelerated to the safe-limited speed or lower.

[Related signals]

- (1) SLS speed change input (SLSSMImn)
- (2) SLS speed change output (SLSSMOmn)
- (3) SLS speed override input (SLSSOVRI mn)
- (4) SLS speed override output (SLSSOVROmn)
- (5) SLS observation is active (SLSSEm)
- (6) Under SLS limit (SLSSSm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
B	SSM request (spindle)	*SSMSRm	ZR442 bit0	ZR442 bit1	ZR442 bit2	ZR442 bit3	ZR442 bit4	ZR442 bit5	ZR442 bit6	ZR442 bit7

[Function]

This signal is used to start execution of the Safe speed monitor function on the control axis.

This signal is available when the parameter "#51004 SSM_Enable" (Enable Safe speed monitor) is set to "1" (Enable).

(This signal is ignored when the parameter "#51004 SSM_Enable" (Enable Safe speed monitor) is set to "0" (Disable).)

[Operation]

When the "SSM request" signal is turned OFF (when SSM is requested), the NC carries out the following operations:

- (1) Checks the SSM parameters to be used.
- (2) Execute the NC's Safe speed monitor function, and turns ON the "SSM is active" signal (SSMSEm).
- (3) Turns ON 1 to 4 of the "Under SSM safe speed" signal (SSMSmn) when the axis is confirmed to be at the safe speed or below.

[Related signals]

- (1) SSM is active (SSMSEm)
- (2) Under SSM safe speed (SSMSmn)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
B	SOS observation request (spindle)	*SOSSRm	ZR444 bit0	ZR444 bit1	ZR444 bit2	ZR444 bit3	ZR444 bit4	ZR444 bit5	ZR444 bit6	ZR444 bit7

[Function]

This signal is used to start execution of the SOS observation function on the spindle.

This signal is available when the parameter "#51006 SOS_Enable" (Enable Safe operating stop) is set to "1" (Enable).

(This signal is ignored when the parameter "#51006 SOS_Enable" (Enable Safe operating stop) is set to "0" (Disable).)

[Operation]

When the "SOS observation request" signal is turned OFF (when SOS is requested), the NC carries out the following operations:

- (1) Checks the SOS parameters to be used.
- (2) Executes the NC's Safe operating stop function and turns ON the "SOS is active" signal (SOSSEm).
- (3) Turns ON the "In SOS stop" signal (SOSSSm) when the safe standstill state of the spindle is confirmed.

[Related signals]

- (1) SOS is active (SOSSEm)
- (2) In SOS stop (SOSSSm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
B	Safe stop 1 request (spindle)	*SS1SRm	ZR445 bit0	ZR445 bit1	ZR445 bit2	ZR445 bit3	ZR445 bit4	ZR445 bit5	ZR445 bit6	ZR445 bit7

[Function]

This signal is used to start execution of Safe stop 1 on the spindle.

This signal is available when the parameter "#51007 SS1_Enable" (Enable Safe stop 1) is set to "1" (Enable).

(This signal is ignored when the parameter "#51007 SS1_Enable" (Enable Safe stop 1) is set to "0" (Disable).)

[Operation]

When the "Safe stop 1 request" signal is turned OFF (when SS1 is requested), the NC carries out the following operations:

- (1) Checks the SS1 parameters to be used.
- (2) Executes the NC's Safe stop 1 function, and turns ON the "SS1 is active" signal (SS1SEm).
- (3) Turns ON the "In SS1 stop" signal (SS1SSm) when the spindle deceleration is confirmed.

[Related signals]

- (1) SS1 is active (SS1SEm)
- (2) In SS1 stop (SS1SSm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
B	Safe stop 2 request (spindle)	*SS2SR m	ZR446 bit0	ZR446 bit1	ZR446 bit2	ZR446 bit3	ZR446 bit4	ZR446 bit5	ZR446 bit6	ZR446 bit7

[Function]

This signal is used to start execution of Safe stop 2 on the spindle.

This signal is available when the parameter "#51008 SS2_Enable" (Enable Safe stop 2) is set to "1" (Enable).

(This signal is ignored when the parameter "#51008 SS2_Enable" (Enable Safe stop 2) is set to "0" (Disable).)

[Operation]

When the "Safe stop 2 request" signal is turned OFF (when SS2 is requested), the NC carries out the following operations:

- (1) Checks the SS2 parameters to be used.
- (2) Executes the NC's Safe stop 2 function, and turns ON the "SS2 is active" signal (SS2SEm).
- (3) Executes Safe operating stop (SOS) when the spindle deceleration is confirmed.

[Related signals]

- (1) SS2 is active (SS2SEm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
B	Safe torque OFF request (spindle)	*STOSRm	ZR447 bit0	ZR447 bit1	ZR447 bit2	ZR447 bit3	ZR447 bit4	ZR447 bit5	ZR447 bit6	ZR447 bit7

[Function]

This signal is used to start execution of the Safe torque off function on the spindle.

This signal is available when the parameter "#51009 STO_Enable" (Enable Safe torque off) is set to "1".

(This signal is ignored when the parameter "#51009 STO_Enable" (Enable Safe torque off) is set to "0".)

[Operation]

When the "Safe torque off request" signal is turned OFF (when STO is requested), the NC carries out the following operations:

- (1) Checks the STO parameters to be used.
- (2) Executes the NC's Safe torque off function, and turns ON the "STO is active" signal (STOSEm).
- (3) Turns ON the "In Safe torque off" signal (STOSSm) when the main drive power to the spindle has been shut OFF.

[Related signals]

- (1) STO is active (STOSEm)
- (2) In Safe torque off (STOSSm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Safety reset (spindle)	SRSTSm	ZR452 bit0	ZZR452 bit1	ZR452 bit2	ZR452 bit3	ZR452 bit4	ZR452 bit5	ZR452 bit6	ZR452 bit7

[Function]

This signal is used to reset the safety function's alarm. When the alarm for the safety function has not been occurred, this signal is ignored.

[Operation]

By turning ON this signal, the NC carries out the following operations.

- (1) Check whether the occurring alarm for safety function is in the state that is possible to cancel(*1).

(*1) The alarm is possible to cancel in any of the following status.

When the function corresponding to the occurring alarm (SLS/SOS/SS1/SS2) is enabled, the enabled function is determined to be in safety status. ("In Safely-limited speed"/"In Safe operating stop"/"In Safe stop 1" are ON. (The safety status of SS2 is determined by the "In Safe operating stop".))

The function corresponding to the occurring alarm (SLS/SOS/SS1/SS2) is disabled. (The request signal is OFF.)

- (2) Cancel the alarm after the check proves the alarm status is possible to cancel.
- (3) Turn back the drive power ON.

[Caution]

When the safety functions alarm, including the parameter error, are not in state that to be canceled, ("In Safely-limited speed", "In Safe operating stop", and "In Safe stop 1" are OFF in enabled SLS, SOS, SS1, and SS2), the alarm will not be canceled even when this signal is turned ON. (This signal will be ignored.)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SLS speed change input (spindle)	SLSSMImn	ZR468	ZR469	ZR470	ZR471	ZR472	ZR473	ZR474	ZR475

[Function]

This signal specifies the SLS speed tolerance to be used for the SLS observation function.

This signal is available when the parameter "#51002 SLS_Enable" (Enable SLS observation) is set to "1" (Enable).

(This signal is ignored when the parameter "#51002 SLS_Enable" (Enable SLS observation) is set to "0" (Disable).)

<SLS speed input selection method>

SLS speed change input		No. of step to be selected	Corresponding SLS speed tolerance parameter
Bit1	Bit0		
0	0	1	#51303 SLS_SSspeed1
0	1	2	#51304 SLS_SSspeed2
1	0	3	#51305 SLS_SSspeed3
1	1	4	#51306 SLS_SSspeed4

[Operation]

When this signal is changed, the "SLS speed change output" (SLSSMOMn) is also changed.

(This signal is changed even though the "SLS observation request" (*SLSSRm) is ON (when SLS is not requested).)

[Related signals]

- (1) SLS speed change output (SLSSMOMn)
- (2) SLS speed override input (SLSSOVRImn)
- (3) SLS speed override output (SLSSOVROmn)
- (4) SLS observation request (*SLSSRm)
- (5) SLS observation is active (SLSSEm)
- (6) Under SLS limit (SLSSSm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SLS speed override input (spindle)	SLSSOVRImn	ZR468	ZR469	ZR470	ZR471	ZR472	ZR473	ZR474	ZR475

[Function]

This signal specifies the SLS speed override to be used for the SLS observation function.

This signal is available when the parameter "#51002 SLS_Enable" (Enable SLS observation) is set to "1" (Enable).

(This signal is ignored when the parameter "#51002 SLS_Enable" (Enable SLS observation) is set to "0" (Disable).)

<SLS speed override selection method>

SLS speed override input				No. of step to be selected	Corresponding SLS speed override parameter
Bit7	Bit6	Bit5	Bit4		
0	0	0	0	1	#51307 SLS_SOOverride1
0	0	0	1	2	#51308 SLS_SOOverride2
0	0	1	0	3	#51309 SLS_SOOverride3
0	0	1	1	4	#51310 SLS_SOOverride4
0	1	0	0	5	#51311 SLS_SOOverride5
0	1	0	1	6	#51312 SLS_SOOverride6
0	1	1	0	7	#51313 SLS_SOOverride7
0	1	1	1	8	#51314 SLS_SOOverride8
1	0	0	0	9	#51315 SLS_SOOverride9
1	0	0	1	10	#51316 SLS_SOOverride10
1	0	1	0	11	#51317 SLS_SOOverride11
1	0	1	1	12	#51318 SLS_SOOverride12
1	1	0	0	13	#51319 SLS_SOOverride13
1	1	0	1	14	#51320 SLS_SOOverride14
1	1	1	0	15	#51321 SLS_SOOverride15
1	1	1	1	16	#51322 SLS_SOOverride16

[Operation]

When this signal is changed, the "SLS speed override output" (SLSSOVROmn) is also changed.

(This signal is changed even though the "SLS observation request" (*SLSSRm) is ON (when SLS is not requested).)

[Related signals]

- (1) SLS speed change input (SLSSMIImn)
- (2) SLS speed change output (SLSSMOmn)
- (3) SLS speed override output (SLSSOVROmn)
- (4) SLS observation request (*SLSSRm)
- (5) SLS observation is active (SLSSEm)
- (6) Under SLS limit (SLSSSm)

Cont.	Signal name	Abbrev.	Common (\$)
A	Special safety alarm cancel (system common)	SARLS	ZR532 bit0

[Function]

This signal is used to turn the cancel prevention alarm into the cancel possible mode. The cancel prevention alarm occurs in the Smart safety observation diagnosis function.

[Operation]

When the cancel prevention alarm is occurring, NC can be in special safety alarm cancel mode by turning ON this signal.

With this signal turned ON, the cancel prevention alarm can be canceled by turning OFF -> ON -> OFF the "Safety reset" signal (SRSTm/SRSTSm) for the alarm cancel target axis.

[Caution]

The cancel operation of the cancel prevention alarm should be carried out after solving the cause of the alarm occurrence (encoder replacement, motor replacement, etc.).

[Related signals]

- (1) Safety reset (Control axis) (SRSTm)
- (2) Safety reset (Spindle) (SRSTSm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	Output OFF check request	SIOFFCHK	ZR1280 bit0

[Function]

This signal enables the output OFF check function. This function can also be enabled while the "Output OFF check not complete" signal (SIOERRSTS/bit2) is OFF.

[Operation]

When the "Output OFF check request" signal is turned ON, the NC carries out the following operations:

- (1) Turns OFF all the output signals of the dual signal unit.
- (2) Confirms that the feedback input signals of the output signals turn OFF within a certain period of time.
- (3) Returns the output statuses to the original.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

4.6.1.2 CNC -> PLC

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SLS observation is active (control axis)	SLSEm	ZR544 bit0	ZR544 bit1	ZR544 bit2	ZR544 bit3	ZR544 bit4	ZR544 bit5	ZR544 bit6	ZR544 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR544 bit8	ZR544 bit9	ZR544 bit10	ZR544 bit11	ZR544 bit12	ZR544 bit13	ZR544 bit14	ZR544 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR545 bit0	ZR545 bit1	ZR545 bit2	ZR545 bit3	ZR545 bit4	ZR545 bit5	ZR545 bit6	ZR545 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR545 bit8	ZR545 bit9	ZR545 bit10	ZR545 bit11	ZR545 bit12	ZR545 bit13	ZR545 bit14	ZR545 bit15

[Function]

This signal indicates that SLS observation has been enabled on the target axis.

[Operation]

This signal turns ON when the "SLS observation request" (*SLSRm) is turned OFF (when SLS is requested) and the NC starts execution of SLS. This signal turns OFF when the "SLS observation request" (*SLSRm) is turned ON (when SLS is not requested).

[Related signals]

- (1) SLS observation request (*SLSRm)
- (2) Under SLS limit (SLSSm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Under SLS limit (control axis)	SLSSm	ZR546 bit0	ZR546 bit1	ZR546 bit2	ZR546 bit3	ZR546 bit4	ZR546 bit5	ZR546 bit6	ZR546 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR546 bit8	ZR546 bit9	ZR546 bit10	ZR546 bit11	ZR546 bit12	ZR546 bit13	ZR546 bit14	ZR546 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR547 bit0	ZR547 bit1	ZR547 bit2	ZR547 bit3	ZR547 bit4	ZR547 bit5	ZR547 bit6	ZR547 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR547 bit8	ZR547 bit9	ZR547 bit10	ZR547 bit11	ZR547 bit12	ZR547 bit13	ZR547 bit14	ZR547 bit15

[Function]

This signal indicates that SLS observation has been enabled on the target axis and that the axis is at the safely-limited speed or lower.

[Operation]

This signal turns ON when the "SLS observation request" (*SLSRm) is turned OFF (when SLS is requested), the NC starts execution of SLS, and then the speed of the target axis drops to the safely-limited speed or lower. This signal remains OFF if the speed of the target axis exceeds the safely-limited speed.

This signal turns OFF when the "SLS observation request" (*SLSRm) is turned ON (when SLS is not requested).

[Related signals]

- (1) SLS observation request (*SLSRm)
- (2) SLS observation is active (SLSEm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SLP observation is active (control axis)	SLPEm	ZR548 bit0	ZR548 bit1	ZR548 bit2	ZR548 bit3	ZR548 bit4	ZR548 bit5	ZR548 bit6	ZR548 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR548 bit8	ZR548 bit9	ZR548 bit10	ZR548 bit11	ZR548 bit12	ZR548 bit13	ZR548 bit14	ZR548 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR549 bit0	ZR549 bit1	ZR549 bit2	ZR549 bit3	ZR549 bit4	ZR549 bit5	ZR549 bit6	ZR549 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR549 bit8	ZR549 bit9	ZR549 bit10	ZR549 bit11	ZR549 bit12	ZR549 bit13	ZR549 bit14	ZR549 bit15

[Function]

This signal indicates that SLP observation has been enabled on the target axis.

[Operation]

This signal turns ON when the "SLP observation request" (*SLPRm) is turned OFF (when SLP is requested) and the NC starts execution of SLP. This signal turns OFF when the "SLP observation request" (*SLPRm) is turned ON (when SLP is not requested).

[Related signals]

- (1) SLP observation request (*SLPRm)
- (2) In SLP range (SLPSm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	In SLP range (control axis)	SLPSm	ZR550 bit0	ZR550 bit1	ZR550 bit2	ZR550 bit3	ZR550 bit4	ZR550 bit5	ZR550 bit6	ZR550 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR550 bit8	ZR550 bit9	ZR550 bit10	ZR550 bit11	ZR550 bit12	ZR550 bit13	ZR550 bit14	ZR550 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR551 bit0	ZR551 bit1	ZR551 bit2	ZR551 bit3	ZR551 bit4	ZR551 bit5	ZR551 bit6	ZR551 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR551 bit8	ZR551 bit9	ZR551 bit10	ZR551 bit11	ZR551 bit12	ZR551 bit13	ZR551 bit14	ZR551 bit15

[Function]

This signal indicates that SLP observation has been enabled on the target axis and that the axis is within the SLP position tolerance range.

[Operation]

This signal turns ON when the "SLP observation request" (*SLPRm) is turned OFF (when SLP is requested), the NC starts execution of SLP, and then the position of the control axis reaches the SLP position tolerance range. This signal remains OFF if the position of the target axis is outside the SLP position tolerance range. This signal turns OFF when the "SLP observation request" (*SLPRm) is turned ON (when SLP is not requested).

[Related signals]

- (1) SLP observation request (*SLPRm)
- (2) SLP observation is active (SLPEm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SSM is active (control axis)	SSMEm	ZR552 bit0	ZR552 bit1	ZR552 bit2	ZR552 bit3	ZR552 bit4	ZR552 bit5	ZR552 bit6	ZR552 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR552 bit8	ZR552 bit9	ZR552 bit10	ZR552 bit11	ZR552 bit12	ZR552 bit13	ZR552 bit14	ZR552 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR553 bit0	ZR553 bit1	ZR553 bit2	ZR553 bit3	ZR553 bit4	ZR553 bit5	ZR553 bit6	ZR553 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR553 bit8	ZR553 bit9	ZR553 bit10	ZR553 bit11	ZR553 bit12	ZR553 bit13	ZR553 bit14	ZR553 bit15

[Function]

This signal indicates that the safe speed monitor has been enabled on the spindle.

[Operation]

This signal turns ON when the "SSM request" (*SSMRm) is turned OFF (when SSM is requested) and the NC starts execution of SSM. This signal turns OFF when the "SSM request" (*SSMRm) is turned ON (when SSM is not requested).

[Related signals]

- (1) SSM request (*SSMRm)
- (2) Under SSM safe speed (SSMSmn)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Safe cam is active (control axis)	SCAEm	ZR554 bit0	ZR554 bit1	ZR554 bit2	ZR554 bit3	ZR554 bit4	ZR554 bit5	ZR554 bit6	ZR554 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR554 bit8	ZR554 bit9	ZR554 bit10	ZR554 bit11	ZR554 bit12	ZR554 bit13	ZR554 bit14	ZR554 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR555 bit0	ZR555 bit1	ZR555 bit2	ZR555 bit3	ZR555 bit4	ZR555 bit5	ZR555 bit6	ZR555 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR555 bit8	ZR555 bit9	ZR555 bit10	ZR555 bit11	ZR555 bit12	ZR555 bit13	ZR555 bit14	ZR555 bit15

[Function]

This signal indicates that Safe cam has been enabled on the control axis.

[Operation]

This signal turns ON when the "Safe cam request" (*SCARm) is turned OFF (when SCA is requested) and the NC starts execution of SCA. This signal turns OFF when the "Safe cam request" (*SCARm) is turned ON (when SCA is not requested).

[Related signals]

- (1) Safe cam request (*SCARm)
- (2) Safe cam position (SCASmn)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SOS is active (control axis)	SOSEm	ZR556 bit0	ZR556 bit1	ZR556 bit2	ZR556 bit3	ZR556 bit4	ZR556 bit5	ZR556 bit6	ZR556 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR556 bit8	ZR556 bit9	ZR556 bit10	ZR556 bit11	ZR556 bit12	ZR556 bit13	ZR556 bit14	ZR556 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR557 bit0	ZR557 bit1	ZR557 bit2	ZR557 bit3	ZR557 bit4	ZR557 bit5	ZR557 bit6	ZR557 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR557 bit8	ZR557 bit9	ZR557 bit10	ZR557 bit11	ZR557 bit12	ZR557 bit13	ZR557 bit14	ZR557 bit15

[Function]

This signal indicates that safety operating stop has been enabled on the control axis in response to the "SOS observation request" (*SOSRm).

Note that there is no output to this signal when SOS is enabled at the request of SS2.

[Operation]

This signal turns ON when the "SOS observation request" (*SOSRm) is turned OFF (when SOS is requested) and the NC starts execution of SOS. This signal turns OFF when the "SOS observation request" (*SOSRm) is turned ON (when SOS is not requested).

[Related signals]

- (1) SOS observation request (*SOSRm)
- (2) In SOS stop (SOSSm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	In SOS stop (control axis)	SOSSm	ZR558 bit0	ZR558 bit1	ZR558 bit2	ZR558 bit3	ZR558 bit4	ZR558 bit5	ZR558 bit6	ZR558 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR558 bit8	ZR558 bit9	ZR558 bit10	ZR558 bit11	ZR558 bit12	ZR558 bit13	ZR558 bit14	ZR558 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR559 bit0	ZR559 bit1	ZR559 bit2	ZR559 bit3	ZR559 bit4	ZR559 bit5	ZR559 bit6	ZR559 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR559 bit8	ZR559 bit9	ZR559 bit10	ZR559 bit11	ZR559 bit12	ZR559 bit13	ZR559 bit14	ZR559 bit15

[Function]

This signal indicates that the "SOS is active" signal (SOSEm) of the control axis is ON or there is a request from the SS2 function, and the control axis is at a standstill.

[Operation]

This signal turns ON when the NC has started execution of SOS due to turning-OFF of the "SOS observation request" (*SOSRm) (when SOS is requested) or due to a start request from SS2, and the control axis is at a standstill. This signal remains OFF while the control axis is not at a standstill. This signal turns OFF when the "SOS observation request" (*SOSRm) is turned ON (when SOS is not requested) and when there is no request from SS2.

[Related signals]

- (1) SOS observation request (*SOSRm)
- (2) SOS is active (SOSEm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SS1 is active (control axis)	SS1Em	ZR560 bit0	ZR560 bit1	ZR560 bit2	ZR560 bit3	ZR560 bit4	ZR560 bit5	ZR560 bit6	ZR560 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR560 bit8	ZR560 bit9	ZR560 bit10	ZR560 bit11	ZR560 bit12	ZR560 bit13	ZR560 bit14	ZR560 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR561 bit0	ZR561 bit1	ZR561 bit2	ZR561 bit3	ZR561 bit4	ZR561 bit5	ZR561 bit6	ZR561 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR561 bit8	ZR561 bit9	ZR561 bit10	ZR561 bit11	ZR561 bit12	ZR561 bit13	ZR561 bit14	ZR561 bit15

[Function]

This signal indicates that Safe stop 1 has been enabled in response to the "Safe stop 1 request" (*SS1Rm).

Note that if SS1 is activated due to occurrence of a smart safety observation error, there is no output to this signal.

[Operation]

This signal turns ON when the "Safe stop 1 request" (*SS1Rm) is turned OFF (when STO is requested) and the NC starts execution of the Safe stop 1 function. This signal turns OFF when the "Safe stop 1 request" (*SS1Rm) is turned ON (when STO is not requested).

[Related signals]

- (1) Safe stop 1 request (*SS1Rm)
- (2) In safe stop 1(SS1Sm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	In SS1 stop (control axis)	SS1Sm	ZR562 bit0	ZR562 bit1	ZR562 bit2	ZR562 bit3	ZR562 bit4	ZR562 bit5	ZR562 bit6	ZR562 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR562 bit8	ZR562 bit9	ZR562 bit10	ZR562 bit11	ZR562 bit12	ZR562 bit13	ZR562 bit14	ZR562 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR563 bit0	ZR563 bit1	ZR563 bit2	ZR563 bit3	ZR563 bit4	ZR563 bit5	ZR563 bit6	ZR563 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR563 bit8	ZR563 bit9	ZR563 bit10	ZR563 bit11	ZR563 bit12	ZR563 bit13	ZR563 bit14	ZR563 bit15

[Function]

This signal indicates that SS1 has been executed due to turning-ON of the "SS1 is active" signal (SS1Em) or due to occurrence of a smart safety observation error, and that the control axis is at a standstill.

[Operation]

When the "Safe stop 1 request" (*SS1Rm) is turned OFF (when SS1 is requested) or when a smart safety observation error occurs, SS1 starts to be executed. When the control axis decelerates to a stop, this signal is turned ON. This signal remains OFF while the control axis is not at a standstill. This signal turns OFF when the "Safe stop 1 request" (*SS1Rm) is turned ON (when SS1 is not requested) and when SS1 is not executed due to occurrence of a smart safety observation error.

[Related signals]

- (1) Safe stop 1 request (*SS1Rm)
- (2) SS1 is active (SS1Em)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SS2 is active (control axis)	SS2Em	ZR564 bit0	ZR564 bit1	ZR564 bit2	ZR564 bit3	ZR564 bit4	ZR564 bit5	ZR564 bit6	ZR564 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR564 bit8	ZR564 bit9	ZR564 bit10	ZR564 bit11	ZR564 bit12	ZR564 bit13	ZR564 bit14	ZR564 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR565 bit0	ZR565 bit1	ZR565 bit2	ZR565 bit3	ZR565 bit4	ZR565 bit5	ZR565 bit6	ZR565 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR565 bit8	ZR565 bit9	ZR565 bit10	ZR565 bit11	ZR565 bit12	ZR565 bit13	ZR565 bit14	ZR565 bit15

[Function]

This signal indicates that Safe stop 2 has been enabled on the control axis.

[Operation]

This signal turns ON when the "Safe stop 2 request" (*SS2Rm) is turned OFF (when SS2 is requested) and the NC starts execution of SS2. This signal turns OFF when the "Safe stop 2 request" (*SS2Rm) is turned ON (when SS2 is not requested).

[Related signals]

- (1) Safe stop 2 request (*SS2Rm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	STO is active (control axis)	STOEm	ZR566 bit0	ZR566 bit1	ZR566 bit2	ZR566 bit3	ZR566 bit4	ZR566 bit5	ZR566 bit6	ZR566 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR566 bit8	ZR566 bit9	ZR566 bit10	ZR566 bit11	ZR566 bit12	ZR566 bit13	ZR566 bit14	ZR566 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR567 bit0	ZR567 bit1	ZR567 bit2	ZR567 bit3	ZR567 bit4	ZR567 bit5	ZR567 bit6	ZR567 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR567 bit8	ZR567 bit9	ZR567 bit10	ZR567 bit11	ZR567 bit12	ZR567 bit13	ZR567 bit14	ZR567 bit15

[Function]

This signal indicates that the Safe torque off function has been enabled on the control axis in response to the "Safe torque off request" (*STORM). Note that if STO is activated due to occurrence of a smart safety observation error, there is no output to this signal.

[Operation]

This signal turns ON when the "Safe torque off request" (*STORM) is turned OFF (when STO is requested) and the NC starts execution of STO. This signal turns OFF when the "Safe torque off request" (*STORM) is turned ON (when STO is not requested).

[Related signals]

- (1) Safe torque off request (*STORM)
(2) In Safe torque off (STOSm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	In Safe torque off (control axis)	STOSm	ZR568 bit0	ZR568 bit1	ZR568 bit2	ZR568 bit3	ZR568 bit4	ZR568 bit5	ZR568 bit6	ZR568 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR568 bit8	ZR568 bit9	ZR568 bit10	ZR568 bit11	ZR568 bit12	ZR568 bit13	ZR568 bit14	ZR568 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR569 bit0	ZR569 bit1	ZR569 bit2	ZR569 bit3	ZR569 bit4	ZR569 bit5	ZR569 bit6	ZR569 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR569 bit8	ZR569 bit9	ZR569 bit10	ZR569 bit11	ZR569 bit12	ZR569 bit13	ZR569 bit14	ZR569 bit15

[Function]

This signal indicates that STO has been executed due to turning-ON of the "STO is active" signal (STOEm) or due to occurrence of a smart safety observation error, and the main power supply for driving has been shut off.

[Operation]

This signal turns ON when the NC has started execution of STO due to turning-OFF of the "Safe torque off request" (*STORm) (when STO is requested) or due to occurrence of a smart safety observation error, and the main power supply for driving the control axis is shut off. This signal remains OFF while the main power supply for driving the control axis is not shut off. This signal turns OFF when the "Safe torque off request" (*STORm) is turned ON (when STO is not requested) and when STO is not executed due to occurrence of a smart safety observation error.

[Related signals]

- (1) Safe torque off request (*STORm)
- (2) STO is active (STOEm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	In SBC motor brake en- abled (control axis)	SBCEm	ZR570 bit0	ZR570 bit1	ZR570 bit2	ZR570 bit3	ZR570 bit4	ZR570 bit5	ZR570 bit6	ZR570 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR570 bit8	ZR570 bit9	ZR570 bit10	ZR570 bit11	ZR570 bit12	ZR570 bit13	ZR570 bit14	ZR570 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR571 bit0	ZR571 bit1	ZR571 bit2	ZR571 bit3	ZR571 bit4	ZR571 bit5	ZR571 bit6	ZR571 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR571 bit8	ZR571 bit9	ZR571 bit10	ZR571 bit11	ZR571 bit12	ZR571 bit13	ZR571 bit14	ZR571 bit15

[Function]

This signal indicates that the SBC motor brake starting request of the axis corresponding to the signal is enabled.

[Operation]

This signal turns ON when the "SBC motor brake starting request" signal (*SBCRm) is OFF (when SBC is requested).

This signal turns OFF when the "SBC Motor brake starting request" signal (*SBCRm) is ON (when SBC is not requested).

While this signal is ON, the NC outputs the motor brake start command to the drive unit.

[Related signals]

- (1) SBC motor brake starting request (*SBCRm)
- (2) In SBC motor brake start signal (SBCSm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	In SBC motor brake start signal (control axis)	SBCSm	ZR572 bit0	ZR572 bit1	ZR572 bit2	ZR572 bit3	ZR572 bit4	ZR572 bit5	ZR572 bit6	ZR572 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR572 bit8	ZR572 bit9	ZR572 bit10	ZR572 bit11	ZR572 bit12	ZR572 bit13	ZR572 bit14	ZR572 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR573 bit0	ZR573 bit1	ZR573 bit2	ZR573 bit3	ZR573 bit4	ZR573 bit5	ZR573 bit6	ZR573 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR573 bit8	ZR573 bit9	ZR573 bit10	ZR573 bit11	ZR573 bit12	ZR573 bit13	ZR573 bit14	ZR573 bit15

[Function]

This signal indicates that the motor brake of the axis corresponding to the signal is enabled.

[Operation]

The motor brake is started when the "SBC motor brake starting request" (*SBCRm) is turned OFF (when SBC is requested) or when the power is shut OFF (at Safety related error, at *STORM signal OFF, at *SS1Rm signal OFF). After the motor brake has been started, this signal turns ON.

[Caution]

This signal does not turn ON in the case of the axis where the parameter "#51200 SFSPEC1/bit3" is set to "1".

[Related signals]

- (1) SBC motor brake starting request (*SBCRm)
- (2) Safe torque off request (*STORM)
- (3) Safe stop 1 request (*SS1Rm)
- (4) In SBC motor brake enabled (SBCEm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	External brake SBT incomplete (control axis)	SBTNFEXm	ZR574 bit0	ZR574 bit1	ZR574 bit2	ZR574 bit3	ZR574 bit4	ZR574 bit5	ZR574 bit6	ZR574 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR574 bit8	ZR574 bit9	ZR574 bit10	ZR574 bit11	ZR574 bit12	ZR574 bit13	ZR574 bit14	ZR574 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR575 bit0	ZR575 bit1	ZR575 bit2	ZR575 bit3	ZR575 bit4	ZR575 bit5	ZR575 bit6	ZR575 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR575 bit8	ZR575 bit9	ZR575 bit10	ZR575 bit11	ZR575 bit12	ZR575 bit13	ZR575 bit14	ZR575 bit15

[Function]

This signal indicates that a certain period of time has passed since the last safe brake test of the external brake was performed.

When this signal turns ON, perform the external brake test as soon as possible.

[Operation]

This signal turns ON when the NC is turned ON and after a certain period of time has passed since the last external brake test (parameter "#51011 SBT_INT"). To turn OFF this signal, turn ON the "External brake SBT start" signal (SBTSTEXm) and perform the brake test. The test needs to be completed successfully.

Refer to the signal description of SBTSTEXm for the operation sequence of this signal.

[Related signals]

- (1) External brake SBT start (SBTSTEXm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	In SBT external brake test (control axis)	SBTEX- BRm	ZR576 bit0	ZR576 bit1	ZR576 bit2	ZR576 bit3	ZR576 bit4	ZR576 bit5	ZR576 bit6	ZR576 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR576 bit8	ZR576 bit9	ZR576 bit10	ZR576 bit11	ZR576 bit12	ZR576 bit13	ZR576 bit14	ZR576 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR577 bit0	ZR577 bit1	ZR577 bit2	ZR577 bit3	ZR577 bit4	ZR577 bit5	ZR577 bit6	ZR577 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR577 bit8	ZR577 bit9	ZR577 bit10	ZR577 bit11	ZR577 bit12	ZR577 bit13	ZR577 bit14	ZR577 bit15

[Function]

This signal indicates that the axis corresponding to the signal is under the external brake test.

[Operation]


After the "External brake SBT start" signal (SBTSTEXm) turns ON, ON/OFF of this signal switches.

Incorporate the signal processing logic at the user side to actually start the external brake when this signal is turned ON.

<Test pattern of the external brake starting method>

	SBTEXBRm 1CH	SBTEXBRm 2CH	External brake starting signal 1CH	External brake starting signal 2CH
Test pattern1	ON	ON	OFF	OFF

<Example of the signal processing logic for the external brake test>

**[Related signals]**

- (1) External brake SBT start (SBTSTEXm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Motor brake SBT incom- plete (control axis)	SBTNFMOM	ZR578 bit0	ZR578 bit1	ZR578 bit2	ZR578 bit3	ZR578 bit4	ZR578 bit5	ZR578 bit6	ZR578 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR578 bit8	ZR578 bit9	ZR578 bit10	ZR578 bit11	ZR578 bit12	ZR578 bit13	ZR578 bit14	ZR578 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR579 bit0	ZR579 bit1	ZR579 bit2	ZR579 bit3	ZR579 bit4	ZR579 bit5	ZR579 bit6	ZR579 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR579 bit8	ZR579 bit9	ZR579 bit10	ZR579 bit11	ZR579 bit12	ZR579 bit13	ZR579 bit14	ZR579 bit15

[Function]

This signal indicates that a certain period of time has passed since the last safe brake test of the motor brake was performed.

When this signal turns ON, perform the motor brake test as soon as possible.

[Operation]

This signal turns ON when the NC is turned ON and after a certain period of time has passed since the last motor brake test (parameter "#51011 SBT_INT" (SBT interval)). To turn OFF this signal, turn ON the "Motor brake SBT start" signal (SBTSTMOM) and perform the brake test. The test needs to be completed successfully.

Refer to the signal description of SBTSTMOM for the operation sequence of this signal.

[Related signals]

- (1) Motor brake SBT start (SBTSTMOM)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	In safety absolute position establishing (control axis)	SFABSPE-STm	ZR580 bit0	ZR580 bit1	ZR580 bit2	ZR580 bit3	ZR580 bit4	ZR580 bit5	ZR580 bit6	ZR580 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR580 bit8	ZR580 bit9	ZR580 bit10	ZR580 bit11	ZR580 bit12	ZR580 bit13	ZR580 bit14	ZR580 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR581 bit0	ZR581 bit1	ZR581 bit2	ZR581 bit3	ZR581 bit4	ZR581 bit5	ZR581 bit6	ZR581 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR581 bit8	ZR581 bit9	ZR581 bit10	ZR581 bit11	ZR581 bit12	ZR581 bit13	ZR581 bit14	ZR581 bit15

[Function]

This signal indicates that the safety absolute position for executing SLP/SCA has been established.

[Operation]

When the warning "Safe absol. posn unestablished" occurs, this signal turns ON after the "Safety absolute position check" signal is turned ON and the warning is canceled. (It will be in the state of the safety absolute position established.)

Additionally, when the warning "Safe absol. posn unestablished" occurs, this signal turns OFF.

Once this signal is turned ON, the ON status is held until the warning "Safe absol. posn unestablished" occurs even when the power is turned OFF and ON again. While this signal is ON, the observation by SLP and the signal output by SCA can be carried out. (When this signal is OFF, SLP/SCA does not operate.)

[Related signals]

- (1) Safety absolute position check (control axis) (SFABSPFXm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Smart safety observation error occurring servo axis (control axis)	SFERR_SVm	ZR582 bit0	ZR582 bit1	ZR582 bit2	ZR582 bit3	ZR582 bit4	ZR582 bit5	ZR582 bit6	ZR582 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR582 bit8	ZR582 bit9	ZR582 bit10	ZR582 bit11	ZR582 bit12	ZR582 bit13	ZR582 bit14	ZR582 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR583 bit0	ZR583 bit1	ZR583 bit2	ZR583 bit3	ZR583 bit4	ZR583 bit5	ZR583 bit6	ZR583 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR583 bit8	ZR583 bit9	ZR583 bit10	ZR583 bit11	ZR583 bit12	ZR583 bit13	ZR583 bit14	ZR583 bit15

[Function]

This signal indicates the servo axis where the smart safety observation error occurred.

[Operation]

When the smart safety observation error occurs for each axis, the BIT corresponding to the servo axis in which the error occurred is turned ON.

"0" is output when no smart safety observation error has occurred for each axis.

[Caution]

"0" is output when the smart safety observation error occurs without displaying axis name.

[Related signals]

- (1) V number of smart safety observation error (SFERR_VNO)
- (2) E number of smart safety observation error (SFERR_ENO)
- (3) Smart safety observation error occurring spindle (SFERR_SPM)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Smart safety observation warning occurring servo axis (control axis)	SF-WRG_SV _m	ZR584 bit0	ZR584 bit1	ZR584 bit2	ZR584 bit3	ZR584 bit4	ZR584 bit5	ZR584 bit6	ZR584 bit7
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR584 bit8	ZR584 bit9	ZR584 bit10	ZR584 bit11	ZR584 bit12	ZR584 bit13	ZR584 bit14	ZR584 bit15
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR585 bit0	ZR585 bit1	ZR585 bit2	ZR585 bit3	ZR585 bit4	ZR585 bit5	ZR585 bit6	ZR585 bit7
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR585 bit8	ZR585 bit9	ZR585 bit10	ZR585 bit11	ZR585 bit12	ZR585 bit13	ZR585 bit14	ZR585 bit15

[Function]

This signal indicates the servo axis where the smart safety observation warning has occurred.

[Operation]

When the smart safety observation warning for each axis occurs, the BIT corresponding to the servo axis in which the warning occurred is turned ON.

"0" is output when the smart safety observation warning for each axis has not occurred.

[Caution]

"0" is output when the smart safety observation warning occurs without displaying axis name.

[Related signals]

- (1) V number of smart safety observation warning (SFWRG_VNO)
- (2) W number of smart safety observation warning (SFWRG_WNO)
- (3) Smart safety observation warning occurring spindle (SFWRG_SP_m)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SLS speed change output (control axis)	SLSMO _{mn}	ZR608	ZR609	ZR610	ZR611	ZR612	ZR613	ZR614	ZR615
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR616	ZR617	ZR618	ZR619	ZR620	ZR621	ZR622	ZR623
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR624	ZR625	ZR626	ZR627	ZR628	ZR629	ZR630	ZR631
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR632	ZR633	ZR634	ZR635	ZR636	ZR637	ZR638	ZR639

[Function]

This signal outputs the currently selected SLS speed tolerance's step No.

This signal is available when SLS is enabled by the parameter "#51002 SLS_Enable" (Enable SLS observation).

(When SLS is disabled by "#51002 SLS_Enable" (Enable SLS observation), always zero is output to all the bits of this signal (SLS speed tolerance 1).

<SLS speed change output status>

SLS speed change output		Selected step No.	Corresponding SLS speed parameter
Bit1	Bit0		
0	0	1	#51103 SLS_Speed1
0	1	2	#51104 SLS_Speed2
1	0	3	#51105 SLS_Speed3
1	1	4	#51106 SLS_Speed4

[Operation]

When the "SLS speed change input" (SLSMI_{mn}) is changed, this signal is also changed.

(SLSMO_{mn} is changed even though the "SLS observation request" (*SLSR_m) is ON (when SLS is not requested).)

[Related signals]

- (1) SLS speed change input (SLSMI_{mn})
- (2) SLS speed override input (SLSOVR_I_{mn})
- (3) SLS speed override output (SLSOVR_O_{mn})
- (4) SLS observation request (*SLSR_m)
- (5) SLS observation is active (SLSE_m)
- (6) Under SLS limit (SLSS_m)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SLS speed override output (control axis)	SLSOVROmn	ZR608	ZR609	ZR610	ZR611	ZR612	ZR613	ZR614	ZR615
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR616	ZR617	ZR618	ZR619	ZR620	ZR621	ZR622	ZR623
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR624	ZR625	ZR626	ZR627	ZR628	ZR629	ZR630	ZR631
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR632	ZR633	ZR634	ZR635	ZR636	ZR637	ZR638	ZR639

[Function]

This signal outputs the currently selected SLS speed override.

This signal is available when SLS is enabled by the parameter "#51002 SLS_Enable" (Enable SLS observation).

(When SLS is disabled by "#51002 SLS_Enable" (Enable SLS observation), always zero is output to all the bits of this signal (SLS speed override 1).)

<SLS speed override output status>

SLS speed override input				No. of step to be selected	Corresponding SLS speed override parameter
Bit7	Bit6	Bit5	Bit4		
0	0	0	0	1	#51107 SLS_Override1
0	0	0	1	2	#51108 SLS_Override2
0	0	1	0	3	#51109 SLS_Override3
0	0	1	1	4	#51110 SLS_Override4
0	1	0	0	5	#51111 SLS_Override5
0	1	0	1	6	#51112 SLS_Override6
0	1	1	0	7	#51113 SLS_Override7
0	1	1	1	8	#51114 SLS_Override8
1	0	0	0	9	#51115 SLS_Override9
1	0	0	1	10	#51116 SLS_Override10
1	0	1	0	11	#51117 SLS_Override11
1	0	1	1	12	#51118 SLS_Override12
1	1	0	0	13	#51119 SLS_Override13
1	1	0	1	14	#51120 SLS_Override14
1	1	1	0	15	#51121 SLS_Override15
1	1	1	1	16	#51122 SLS_Override16

[Operation]

When the "SLS speed override input" (SLSOVRImn) is changed, this signal is also changed.

(SLSMOmn is changed even though the "SLS observation request" (*SLSRm) is ON (when SLS is not requested).)

[Related signals]

- (1) SLS speed change input (SLSMImn)
- (2) SLS speed change output (SLSMOmn)
- (3) SLS speed override input (SLSOVRImn)
- (4) SLS observation request (*SLSRm)
- (5) SLS observation is active (SLSEm)
- (6) Under SLS limit (SLSSm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SLP position change output (control axis)	SLPMOmn	ZR640	ZR641	ZR642	ZR643	ZR644	ZR645	ZR646	ZR647
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR648	ZR649	ZR650	ZR651	ZR652	ZR653	ZR654	ZR655
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR656	ZR657	ZR658	ZR659	ZR660	ZR661	ZR662	ZR663
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR664	ZR665	ZR666	ZR667	ZR668	ZR669	ZR670	ZR671

[Function]

This signal outputs the step No. of the currently selected SLP position tolerance.

This signal is available when SLP is enabled by the parameter "#51003 SLP_Enable" (Enable SLP observation).

(When SLP is disabled by "#51003 SLP_Enable" (Enable SLP observation), always zero is output to all the bits of this signal (SLP position tolerance 1).)

<SLP position change output status>

SLP position change output		Selected step No.	Corresponding SLP position parameter
Bit1	Bit0		
0	0	1	#51126/51127 SLP_Position (P/M)1
0	1	2	#51128/51129 SLP_Position (P/M)2
1	0	3	#51130/51131 SLP_Position (P/M)3
1	1	4	#51132/51133 SLP_Position (P/M)4

[Operation]

When the "SLP position change input" (SLPIMn) is changed, this signal is also changed.

(This signal is changed even though the "SLP observation request" (*SLPRm) is ON (when SLP is not requested).)

[Related signals]

- (1) SLP position change input (SLPIMn)
- (2) SLP observation request (*SLPRm)
- (3) SLP observation is active (SLPEm)
- (4) In SLP range (SLPSm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Under SSM safe speed (control axis)	SSMSmn	ZR672	ZR673	ZR674	ZR675	ZR676	ZR677	ZR678	ZR679
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR680	ZR681	ZR682	ZR683	ZR684	ZR685	ZR686	ZR687
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR688	ZR689	ZR690	ZR691	ZR692	ZR693	ZR694	ZR695
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR696	ZR697	ZR698	ZR699	ZR700	ZR701	ZR702	ZR703

[Function]

This signal indicates that Safe speed monitor has been enabled on the target axis and that the speed of the target axis is under the safe speed.

<Correspondence between the "Under SSM safe speed" signals and parameters>

Under SSM safe speed		Corresponding SSM speed parameter
bit0	Under SSM safe speed 1	#51135 SSM_Speed1, #51139 SSM_Hysteresis1
bit1	Under SSM safe speed 2	#51136 SSM_Speed2, #51140 SSM_Hysteresis2
bit2	Under SSM safe speed 3	#51137 SSM_Speed3, #51141 SSM_Hysteresis3
bit3	Under SSM safe speed 4	#51138 SSM_Speed4, #51142 SSM_Hysteresis4

[Operation]

This signal turns ON when the "SSM request" (*SSMRm) is turned OFF (when SSM is requested), the NC starts execution of SSM, and then the speed of the target axis drops to the safe speed or lower. This signal remains OFF while the target axis speed is exceeding the safe speed. This signal turns OFF when the "SSM request" (*SSMRm) is turned ON (when SSM is not requested).

[Related signals]

- (1) SSM request (*SSMRm)
- (2) SSM is active (SSME_m)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SCA safe cam position (control axis)	SCASmn	ZR704 ZR705	ZR706 ZR707	ZR708 ZR709	ZR710 ZR711	ZR712 ZR713	ZR714 ZR715	ZR716 ZR717	ZR718 ZR719
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR720 ZR721	ZR722 ZR723	ZR724 ZR725	ZR726 ZR727	ZR728 ZR729	ZR730 ZR731	ZR732 ZR733	ZR734 ZR735
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR736 ZR737	ZR738 ZR739	ZR740 ZR741	ZR742 ZR743	ZR744 ZR745	ZR746 ZR747	ZR748 ZR749	ZR750 ZR751
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR752 ZR753	ZR754 ZR755	ZR756 ZR757	ZR758 ZR759	ZR760 ZR761	ZR762 ZR763	ZR764 ZR765	ZR766 ZR767

[Function]

This signal indicates the safe cam position status of the control axis.

<Correspondence between Safe cam position signals and parameters (for the 1st axis)>

SCA safe cam position		Corresponding SCA position parameter
SCAS11/bit0	Safe cam position 1 (-)	#51144 SCA_PositionM1
SCAS12/bit1	Safe cam position 2 (-)	#51146 SCA_PositionM2
:	:	:
SCAS115/bit14	Safe cam position 15 (-)	#51172 SCA_PositionM15
SCAS116/bit15	Safe cam position 16 (-)	#51174 SCA_PositionM16
SCAS117/bit0	Safe cam position 1 (+)	#51143 SCA_PositionP1
SCAS118/bit1	Safe cam position 2 (+)	#51145 SCA_PositionP2
:	:	:
SCAS131/bit14	Safe cam position 15 (+)	#51171 SCA_PositionP15
SCAS132/bit15	Safe cam position 16 (+)	#51173 SCA_PositionP16

[Operation]

When the NC has started execution of SCA in response to turning-OFF of the "Safe cam request" (*SCARm) (when SCA is requested), and the control axis has reached the safe position (+/-)(*1) or further, the corresponding bit of this signal turns ON.

(*1) Safe position (+/-) is determined based on the axis position status, which means based on SCA position ("#51143 SCA_PositionP1" (SCA position 1 (+)) to "#51174 SCA_PositionM16" (SCA position 16 (-))) and SCA hysteresis width ("#51175 SCA_Hysteresis" (SCA hysteresis width)).

- ♦ When the "Safe cam position n (+/-)" is ON
"Safe position n (+/-)" = "SCA position n (+/-)" - "SCA hysteresis width" (n = 1 to 16)
- ♦ When the "Safe cam position n (+/-)" is OFF
"Safe position n (+/-)" = "SCA position n (+/-)" (n = 1 to 16)

Listed below is the correspondence between the statuses of the "Safe cam position n (-)" and the "Safe cam position n (+)" and the axis position status.

(When "SCA position n (+)" > "SCA position n (-)")

Safe cam position n (-)	Safe cam position n (+)	Axis position status
0	0	Smaller than "Safe position n (-)"
1	0	Between "Safe position n (-)" and "Safe position n (+)"
0	1	-
1	1	Same as or greater than "Safe position n (+)"

When the "Safe cam request" (*SCARm) is turned ON (when SCA is not requested), this signal is all turned OFF.

[Related signals]

- (1) Safe cam request (*SCARm)
- (2) Safe cam is active (SCAEm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SBT start position (control axis)	SBTPOSm	ZR768 ZR769	ZR772 ZR773	ZR776 ZR777	ZR780 ZR781	ZR784 ZR785	ZR788 ZR789	ZR792 ZR793	ZR796 ZR797
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR800 ZR801	ZR804 ZR805	ZR808 ZR809	ZR812 ZR813	ZR816 ZR817	ZR820 ZR821	ZR824 ZR825	ZR828 ZR829
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR832 ZR833	ZR836 ZR837	ZR840 ZR841	ZR844 ZR845	ZR848 ZR849	ZR852 ZR853	ZR856 ZR857	ZR860 ZR861
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR864 ZR865	ZR868 ZR869	ZR872 ZR873	ZR876 ZR877	ZR880 ZR881	ZR884 ZR885	ZR888 ZR889	ZR892 ZR893

[Function]

This signal is used to indicate the position of the safe brake test start of the external brake test or the motor brake test.

[Operation]

This signal saves the current position on the machine coordinate at the start of the safe brake test.

This data is updated at the execution of the safe brake test. (The same value continues to be output unless the safe brake test is executed.)

The output unit differs depending on the parameter "#1040 M_inch" (Constant input (inch)).

If the target axis is an rotary axis, the output unit is 0.0001° regardless of the parameter "#1040 M_inch" (Constant input (inch)).

<For a linear axis and "M_inch" is "0" (metric system)>

The output unit is submicron (0.0001mm).

(Example) When the machine position of the 1st axis (linear axis) is 123.4567 mm

Machine position -> ZR768: D687
123.4567 mm
 ZR769: 0012

<For a linear axis and "M_inch" is "1" (inch system)>

The output unit is 0.00001 inch.

(Example) When the machine position of the 1st axis (linear axis) is 1.23456 inch

Machine position 1.23456 -> ZR768: E240
inch
 ZR769: 0001

<For the linear type rotary axis or the rotation-type rotary axis>

The output unit is 0.0001°.

(Example) When the machine coordinate of the 1st axis (rotary axis) is 1.23456°

Machine coordinate -> ZR768: E240
12.3456°
 ZR769: 0001

[Related signals]

- (1) External brake SBT start (SBTSTEXm)
- (2) Motor brake SBT start (SBTSTMOM)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SLS observation is active (spindle)	SLSSEm	ZR1024 bit0	ZR1024 bit1	ZR1024 bit2	ZR1024 bit3	ZR1024 bit4	ZR1024 bit5	ZR1024 bit6	ZR1024 bit7

[Function]

This signal indicates that SLS observation has been enabled on the spindle.

[Operation]

This signal turns ON when the "SLS observation request" (*SLSSRm) is turned OFF (when SLS is requested) and the NC starts execution of the SLS observation function. This signal turns OFF when the "SLS observation request" (*SLSSRm) is turned ON (when SLS is not requested).

[Related signals]

- (1) SLS observation request (*SLSSRm)
- (2) Under SLS limit (SLSSSm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Under SLS limit (spindle)	SLSSSm	ZR1025 bit0	ZR1025 bit1	ZR1025 bit2	ZR1025 bit3	ZR1025 bit4	ZR1025 bit5	ZR1025 bit6	ZR1025 bit7

[Function]

This signal indicates that SLS observation has been enabled on the spindle and that the spindle is at the safe speed or lower.

[Operation]

This signal turns ON when the "SLS observation request" (*SLSSRm) is turned OFF (when SLS is requested), the NC starts execution of the SLS observation function, and then the speed of the spindle drops to the safely-limited speed or lower. This signal remains OFF if the spindle's speed is exceeding the safely-limited speed. This signal turns OFF when the "SLS observation request" (*SLSSRm) is turned ON (when SLS is not requested).

[Related signals]

- (1) SLS observation request (*SLSSRm)
- (2) SLS observation is active (SLSSEm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SSM is active (spindle)	SSM-SEm	ZR1028 bit0	ZR1028 bit1	ZR1028 bit2	ZR1028 bit3	ZR1028 bit4	ZR1028 bit5	ZR1028 bit6	ZR1028 bit7

[Function]

This signal indicates that Safe speed monitor has been enabled on the spindle.

[Operation]

This signal turns ON when the "SSM request" (*SSMSRm) is turned OFF (when SSM is requested) and the NC starts execution of SSM. This signal turns OFF when the "SSM request" (*SSMSRm) is turned ON (when SSM is not requested).

[Related signals]

- (1) SSM request (*SSMSRm)
- (2) Under SSM safe speed (SSMSSmn)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SOS is active (spindle)	SOSSEm	ZR1030 bit0	ZR1030 bit1	ZR1030 bit2	ZR1030 bit3	ZR1030 bit4	ZR1030 bit5	ZR1030 bit6	ZR1030 bit7

[Function]

This signal indicates that Safe operating stop has been enabled on the spindle in response to the "SOS observation request" (*SOSSRm).

Note that if SOS is activated by a start request from SS2, there is no output to this signal.

[Operation]

This signal turns ON when the "SOS observation request" (*SOSSRm) is turned OFF (when SOS is requested) and the NC starts execution of SOS. This signal turns OFF when the "SOS observation request" (*SOSSRm) is turned ON (when SOS is not requested).

[Related signals]

- (1) SOS observation request (*SOSSRm)
- (2) In SOS stop (SOSSSm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	In SOS stop (spindle)	SOSSSm	ZR1031 bit0	ZR1031 bit1	ZR1031 bit2	ZR1031 bit3	ZR1031 bit4	ZR1031 bit5	ZR1031 bit6	ZR1031 bit7

[Function]

This signal indicates that the "SOS is active" signal (SOSSEm) of the spindle has been turned ON or there is a start request from SS2, and that the spindle is at a standstill.

[Operation]

This signal turns ON when the NC has started execution of SOS due to turning-OFF of the "SOS observation request" (*SOSSRm) (when SOS is requested) or due to a start request from SS2, and the spindle has been set to a standstill. This signal remains OFF while the spindle is not at a standstill. This signal turns OFF when the "SOS observation request" (*SOSSRm) is turned ON (when SOS is not requested) and when there is no request from SS2.

[Related signals]

- (1) SOS observation request (*SOSSRm)
- (2) SOS is active (SOSSEm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SS1 is active (spindle)	SS1SEm	ZR1032 bit0	ZR1032 bit1	ZR1032 bit2	ZR1032 bit3	ZR1032 bit4	ZR1032 bit5	ZR1032 bit6	ZR1032 bit7

[Function]

This signal indicates that SS1 has been enabled in response to the "Safe stop 1 request" (*SS1SRm).

Note that if SS1 is activated due to occurrence of a smart safety observation error, there is no output to this signal.

[Operation]

This signal turns ON when the "Safe stop 1 request" (*SS1SRm) is turned OFF (when SS1 is requested) and the NC starts execution of the safe stop 1 function. This signal turns OFF when the "Safe stop 1 request" (*SS1SRm) is turned ON (when SS1 is not requested).

[Related signals]

- (1) Safe stop 1 request (*SS1SRm)
- (2) In SS1 stop (SS1SSm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	In SS1 stop (spindle)	SS1SSm	ZR1033 bit0	ZR1033 bit1	ZR1033 bit2	ZR1033 bit3	ZR1033 bit4	ZR1033 bit5	ZR1033 bit6	ZR1033 bit7

[Function]

This signal indicates that SS1 has been executed due to turning-ON of the "SS1 is active" signal (SS1SEm) of the spindle or due to occurrence of a smart safety observation error, and that the spindle is at a standstill.

[Operation]

When the "Safe stop 1 request" (*SS1SRm) is turned OFF (when SS1 is requested) or when a smart safety observation error occurs, SS1 starts to be executed. When the spindle decelerates to a stop, this signal turns ON. This signal remains OFF while the target spindle is not at a standstill. This signal turns OFF when the "Safe stop 1 request" (*SS1SRm) is turned ON (when SS1 is not requested) and when SS1 is not executed due to occurrence of a smart safety observation error.

[Related signals]

- (1) Safe stop 1 request (*SS1SRm)
- (2) SS1 is active (SS1SEm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SS2 is active (spindle)	SS2SEm	ZR1034 bit0	ZR1034 bit1	ZR1034 bit2	ZR1034 bit3	ZR1034 bit4	ZR1034 bit5	ZR1034 bit6	ZR1034 bit7

[Function]

This signal indicates that Safe stop 2 has been enabled on the spindle.

[Operation]

This signal turns ON when the "Safe stop 2 request" (*SS2SRm) is turned OFF (when SS2 is requested), and the NC starts execution of SS2. This signal turns OFF when the "Safe stop 2 request" (*SS2SRm) is turned ON (when SS2 is not requested).

[Related signals]

- (1) Safe stop 2 request (*SS2SRm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	STO is active (spindle)	STOSEm	ZR1035 bit0	ZR1035 bit1	ZR1035 bit2	ZR1035 bit3	ZR1035 bit4	ZR1035 bit5	ZR1035 bit6	ZR1035 bit7

[Function]

This signal indicates that the Safe torque off function has been enabled on the spindle in response to the "Safe torque off request" (*STOSRm). Note that if STO is activated due to occurrence of a smart safety observation error, there is no output to this signal.

[Operation]

This signal turns ON when the "Safe torque off request" (*STOSRm) is turned OFF (when STO is requested) and the NC starts execution of STO. This signal turns OFF when the "Safe torque off request" (*STOSRm) is turned ON (when STO is not requested).

[Related signals]

- (1) Safe torque off request (*STOSRm)
- (2) In Safe torque off (STOSSm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	In Safe torque off (spindle)	STOSSm	ZR1036 bit0	ZR1036 bit1	ZR1036 bit2	ZR1036 bit3	ZR1036 bit4	ZR1036 bit5	ZR1036 bit6	ZR1036 bit7

[Function]

This signal indicates that STO has been executed due to turning-ON of the "STO is active" signal (STOSEm) of the spindle or due to occurrence of a smart safety observation error, and the main power supply for driving has been shut off.

[Operation]

This signal turns ON when the NC has started execution of STO due to turning-OFF of the "Safe torque off request" (*STOSRm) (when STO is requested) or due to occurrence of a smart safety observation error, and the main power supply for driving the spindle is shut off. This signal remains OFF while the main power supply for driving the spindle has not been shut off. This signal turns OFF when the "Safe torque off request" (*STOSRm) is turned ON (when STO is not requested) and when STO is not executed due to occurrence of a smart safety observation error.

[Related signals]

- (1) Safe torque off request (*STOSRm)
- (2) STO is active (STOSEm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Smart safety observation error occurring spindle (spindle)	SFERR_SPm	ZR1043 bit0	ZR1043 bit1	ZR1043 bit2	ZR1043 bit3	ZR1043 bit4	ZR1043 bit5	ZR1043 bit6	ZR1043 bit7

[Function]

This signal indicates the spindle in which the smart safety observation error has occurred.

[Operation]

When the smart safety observation error occurs for each axis, the BIT corresponding to the spindle in which the error occurred is turned ON.

"0" is output when no smart safety observation error for each axis has occurred for each axis.

[Caution]

"0" is output when the smart safety observation error occurs without displaying axis name.

[Related signals]

- (1) V number of smart safety observation error (SFERR_VNO)
- (2) E number of smart safety observation error (SFERR_ENO)
- (3) Smart safety observation error occurring servo axis (SFERR_SVm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Smart safety observation warning occurring spindle (spindle)	SFWRG_SPm	ZR1044 bit0	ZR1044 bit1	ZR1044 bit2	ZR1044 bit3	ZR1044 bit4	ZR1044 bit5	ZR1044 bit6	ZR1044 bit7

[Function]

This signal shows the spindle on which the smart safety observation warning has occurred.

[Operation]

When the smart safety observation warning for each axis occurs, the BIT corresponding to the spindle in which the warning occurred is turned ON.

"0" is output when the smart safety observation warning for each axis has not occurred.

[Caution]

"0" is output when the smart safety observation warning occurs without displaying axis name.

[Related signals]

- (1) V number of smart safety observation warning (SFWRG_VNO)
- (2) W number of smart safety observation warning (SFWRG_WNO)
- (3) Smart safety observation warning occurring servo axis (SFWRG_SVm)

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SLS speed change output (spindle)	SLSS-MOmn	ZR1056	ZR1057	ZR1058	ZR1059	ZR1060	ZR1061	ZR1062	ZR1063

[Function]

This signal outputs the currently selected SLS speed tolerance's step No.

This signal is available when the parameter "#51002 SLS_Enable" (Enable SLS observation) is set to "1" (Enable).

(When the parameter "#51002 SLS_Enable" (Enable SLS observation) is set to "0" (Disable), always zero is output to all the bits of this signal (SLS speed tolerance 1).

<SLS speed change output status>

SLS speed change output		Selected step No.	Corresponding SLS speed parameter
Bit1	Bit0		
0	0	1	#51303 SLS_SSspeed1
0	1	2	#51304 SLS_SSspeed2
1	0	3	#51305 SLS_SSspeed3
1	1	4	#51306 SLS_SSspeed4

[Operation]

When the "SLS speed change input" (SLSSMIln) is changed, this signal is also changed.

(This signal is changed even though the "SLS observation request" (*SLSSRm) is ON (when SLS is not requested).)

[Related signals]

- (1) SLS speed change input (SLSSMIln)
- (2) SLS speed override input (SLSSOVRImn)
- (3) SLS speed override output (SLSSOVROmn)
- (4) SLS observation request (*SLSSRm)
- (5) SLS observation is active (SLSSEm)
- (6) Under SLS limit (SLSSSm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	SLS speed override output (spindle)	SLSSOV-ROmn	ZR1056	ZR1057	ZR1058	ZR1059	ZR1060	ZR1061	ZR1062	ZR1063

[Function]

This signal outputs the currently selected SLS speed override.

This signal is available when the parameter "#51002 SLS_Enable" (Enable SLS observation) is set to "1" (Enable).

(When the parameter "#51002 SLS_Enable" (Enable SLS observation) is set to "0" (Disable), always zero is output to all the bits of this signal (SLS speed override 1).)

<SLS speed override output status>

SLS speed override input				No. of step to be selected	Corresponding SLS speed override parameter
Bit7	Bit6	Bit5	Bit4		
0	0	0	0	1	#51307 SLS_SOoverride1
0	0	0	1	2	#51308 SLS_SOoverride2
0	0	1	0	3	#51309 SLS_SOoverride3
0	0	1	1	4	#51310 SLS_SOoverride4
0	1	0	0	5	#51311 SLS_SOoverride5
0	1	0	1	6	#51312 SLS_SOoverride6
0	1	1	0	7	#51313 SLS_SOoverride7
0	1	1	1	8	#51314 SLS_SOoverride8
1	0	0	0	9	#51315 SLS_SOoverride9
1	0	0	1	10	#51316 SLS_SOoverride10
1	0	1	0	11	#51317 SLS_SOoverride11
1	0	1	1	12	#51318 SLS_SOoverride12
1	1	0	0	13	#51319 SLS_SOoverride13
1	1	0	1	14	#51320 SLS_SOoverride14
1	1	1	0	15	#51321 SLS_SOoverride15
1	1	1	1	16	#51322 SLS_SOoverride16

[Operation]

When the "SLS speed override input" (SLSSOVRImn) is changed, this signal is also changed.

(This signal is changed even though the "SLS observation request" (*SLSSRm) is ON (when SLS is not requested).)

[Related signals]

- (1) SLS speed change input (SLSSMImn)
- (2) SLS speed change output (SLSSMOmn)
- (3) SLS speed override input (SLSSOVRImn)
- (4) SLS observation request (*SLSSRm)
- (5) SLS observation is active (SLSSEm)
- (6) Under SLS limit (SLSSSm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Under SSM safe speed (spindle)	SSMSSmn	ZR1088	ZR1089	ZR1090	ZR1091	ZR1092	ZR1093	ZR1094	ZR1095

[Function]

This signal indicates that the safe speed monitor has been enabled on the target spindle and that the spindle speed is below the safe speed.

<Correspondence between the "Under SSM safe speed" signals and parameters>

Under SSM safe speed		Corresponding SSM speed parameter
bit0	Under SSM safe speed 1	#51326 SSM_SSpeed1, #51330 SSM_SHysteresis1
bit1	Under SSM safe speed 2	#51327 SSM_SSpeed2, #51331 SSM_SHysteresis2
bit2	Under SSM safe speed 3	#51328 SSM_SSpeed3, #51332 SSM_SHysteresis3
bit3	Under SSM safe speed 4	#51329 SSM_SSpeed4, #51333 SSM_SHysteresis4

[Operation]

This signal turns ON when the "SSM request" (*SSMSRm) is turned OFF (when SSM is requested), the NC starts execution of SSM, and then the speed of the spindle drops to the safe speed or lower. This signal remains OFF while the spindle speed is exceeding the safe speed. This signal turns OFF when the "SSM request" (*SSMSRm) is turned ON (when SSM is not requested).

[Related signals]

- (1) SSM request (*SSMSRm)
- (2) SSM is active (SSMSEm)

Cont.	Signal name	Abbrev.	Common (\$)
A	In safety external emergency stop (system common)	SEXTEMG	ZR1264 bit0

[Function]

This signal indicates that Safety external emergency stop is being executed.

[Operation]

This signal turns ON when the safety external emergency stop is enabled (when the emergency stop signal device No. is set in the safety I/O assignment parameter), the emergency stop signal turns OFF (open status), the axis for which the parameter "SF_Disable"/"SF_SDisable" is set to OFF enters STO status, and all the axes are set in Ready OFF status. This signal turns OFF when the emergency stop signal turns ON (close status) and both the STO status of the axis for which "SF_Disable"/"SF_SDisable" is set to OFF, and the Ready OFF status of all the axes are cancelled.

Cont.	Signal name	Abbrev.	Common (\$)
A	V number of smart safety observation error (system common)	SFERR_VNO	ZR1268

[Function]

This signal shows the category numbers of the smart safety observation error (V number).

[Operation]

When the smart safety observation error occurs, the number (V number) that shows the category of the error occurred is output.

"0" is output when the smart safety observation error is not in occurrence state.

(Example) When the smart safety observation error "V04 0003 Safe IO disabled: connect err" occurs

V number of smart safety observation error (system common) (SFERR_VNO): 0004

[Related signals]

- (1) E number of smart safety observation error (SFERR_ENO)
- (2) Smart safety observation error occurring servo axis (SFERR_SVm)
- (3) Smart safety observation error occurring spindle (SFERR_SPM)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	E number of smart safety observation error (system common)	SFERR_ENO	ZR1269

[Function]

This signal shows the error numbers of the smart safety observation error (E number).

[Operation]

When the smart safety observation error occurs, the number (E number) that shows which error occurred in the error category (V number) is output.

"0" is output when the smart safety observation error is not in occurrence state.

(Example) When the smart safety observation error "V04 0003 Safe IO disabled: connect err" occurs

E number of smart safety observation error (system common) (SFERR_ENO): 0003

[Related signals]

- (1) V number of smart safety observation error (SFERR_VNO)
- (2) Smart safety observation error occurring servo axis (SFERR_SVm)
- (3) Smart safety observation error occurring spindle (SFERR_SPm)

Cont.	Signal name	Abbrev.	Common (\$)
A	V number of smart safety observation warning (system common)	SFWRG_VNO	ZR1270

[Function]

This signal shows the category numbers of the smart safety observation warning (V number).

[Operation]

When the smart safety observation warning occurs, the number (V number) that shows the category of the warning occurred is output.

"0" is output when the smart safety observation warning is not in occurrence state.

(Example) When the smart safety observation warning "V51 0005 SBT warning 4" occurs

V number of smart safety observation warning (system common) (SFWRG_VNO): 0033 (51 in decimal)

[Related signals]

- (1) W number of smart safety observation warning (SFWRG_WNO)
- (2) Smart safety observation warning occurring servo axis (SFWRG_SVm)
- (3) Smart safety observation warning occurring spindle (SFWRG_SPm)

Cont.	Signal name	Abbrev.	Common (\$)
A	W number of smart safety observation warning (system common)	SFWRG_WNO	ZR1271

[Function]

This signal shows the warning numbers of the smart safety observation warning (W number).

[Operation]

When the smart safety observation warning occurs, the number (W number) that shows which warning occurred in the warning category (V number) is output.

"0" is output when the smart safety observation warning is not in occurrence state.

(Example) When the smart safety observation warning "V51 0005 SBT warning 4" occurs

W number of smart safety observation warning (system common) (SFWRG_WNO): 0005

[Related signals]

- (1) V number of smart safety observation warning (SFWRG_VNO)
- (2) Smart safety observation warning occurring servo axis (SFWRG_SVm)
- (3) Smart safety observation warning occurring spindle (SFWRG_SPm)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	Safety I/O observation state	SIOERRSTS	ZR1536

[Function]

This signal outputs the state of safety I/O-related observation function.

Bit	Description	Bit	Description
bit0	Safety I/O unit observation error	bit8	Reserved
bit1	Drive's safety signal compare error	bit9	Reserved
bit2	Output OFF check not complete	bit10	Reserved
bit3	Safety I/O unit I/O start	bit11	Reserved
bit4	Reserved	bit12	Reserved
bit5	Reserved	bit13	Reserved
bit6	Reserved	bit14	Reserved
bit7	Reserved	bit15	Reserved

[Operation]

When an error occurs on a safety I/O related observation function, the corresponding error information is output.

[Related signals]

- (1) Safety I/O unit observation state (SIOERRUNIT)
- (2) Safety I/O unit observation error details (SIOERRUNITSTS)

Cont.	Signal name	Abbrev.	Common (\$)
A	Safety I/O unit observation state	SIOERRUNIT	ZR1538

[Function]

This signal outputs the state of safety I/O unit observation error for each safety I/O unit.

Bit	Description	Bit	Description
bit0	Safety I/O unit Unit 1 error occurring	bit8	Reserved
bit1	Safety I/O unit Unit 2 error occurring	bit9	Reserved
bit2	Safety I/O unit Unit 3 error occurring	bit10	Reserved
bit3	Safety I/O unit Unit 4 error occurring	bit11	Reserved
bit4	Safety I/O unit Unit 5 error occurring	bit12	Reserved
bit5	Safety I/O unit Unit 6 error occurring	bit13	Reserved
bit6	Safety I/O unit Unit 7 error occurring	bit14	Reserved
bit7	Safety I/O unit Unit 8 error occurring	bit15	Reserved

For the safety I/O unit, the devices are assigned with the parameters.

The following table lists the device assignment for the safety I/O unit.

	Unit1	Unit2	Unit3	Unit4	Unit5	Unit6	Unit7	Unit8
Channel No.	#51501	#51511	#51521	#51531	#51541	#51551	#51561	#51571
Station No.	#51502	#51512	#51522	#51532	#51542	#51552	#51562	#51572
Input device name	#51503	#51513	#51523	#51533	#51543	#51553	#51563	#51573
Input device No.	#51504	#51514	#51524	#51534	#51544	#51554	#51564	#51574
Output device name	#51505	#51515	#51525	#51535	#51545	#51555	#51565	#51575
Output device No.	#51506	#51516	#51526	#51536	#51546	#51556	#51566	#51576

[Operation]

When an error occurs in a safety I/O unit observation function, the error information is output.

[Related signals]

- (1) Safety I/O observation state (SIOERRSTS)
- (2) Safety I/O unit observation error details (SIOERRUNITSTS)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Unit1	Unit2	Unit3	Unit4	Unit5	Unit6	Unit7	Unit8
A	Safety I/O unit observation error details	SIOERRUNIT-STS	ZR1540	ZR1541	ZR1542	ZR1543	ZR1544	ZR1545	ZR1546	ZR1547

[Function]

This signal outputs details of safety I/O unit observation error for each safety I/O unit.

Bit	Description	Bit	Description
bit0	Slave station communication error 1	bit8	Host station communication error 1
bit1	Slave station communication error 2	bit9	Host station communication error 2
bit2	Slave station communication error 3	bit10	Host station communication error 3
bit3	Slave station data compare error	bit11	Output signal cross-check error
bit4	Output OFF check error	bit12	Reserved
bit5	Output return signal cross-check error	bit13	Reserved
bit6	Transmission cross-check error	bit14	Reserved
bit7	Reception cross-check error	bit15	Reserved

For the safety I/O unit, the devices are assigned with the parameters.

For the device assignment of the safety I/O unit, refer to the descriptions of the "Safety I/O unit observation state" (SIOERRUNIT).

[Operation]

When an error occurs in a safety I/O unit observation function, the error details are output.

[Related signals]

- (1) Safety I/O observation state (SIOERRSTS)
- (2) Safety I/O unit observation state (SIOERRUNIT)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

4.6.3 MES Interface Library

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Common user area C1		ZR10000 to ZR10031

[Function]

This signal is used to specify the desirable arbitrary character to register to the database.

[Operation]

Specify the desirable ASCII code (hexadecimal number) corresponding to the character to set.

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Common user area L1 to L10		ZR10032,3 to ZR10050,1

[Function]

This signal is used to specify the desirable arbitrary 32-bit integer data to register to the database.

[Operation]

Specify the desirable 32-bit integer data to set.

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Condition register (Extract sort condition)		ZR10054

[Function]

For extraction operation, this signal is used to specify the record to be extracted when multiple records corresponding to the condition exist.

[Operation]

Specify the record to be extracted when the concerned record is sorted in ascending or descending order in the field "Update Time".

0: Searches and extracts the most recent record for the field "Update Time".

1: Searches and extracts the oldest record for the field "Update Time".

+n: Searches and extracts the (n-1)th in ascending order from the oldest record for the field "Update Time". ($2 \leq n \leq 100$)

-n: Searches and extracts the n-th in descending order from the most recent record for the field "Update Time". ($1 \leq n \leq 100$)

When "-n" \leq (the number of the concerned records) \times (-1), the record whose update time is the oldest among the concerned records will be extracted.

When "+n" \leq (the number of the concerned records) \times (-1), the record whose update time is the most recent among the concerned records will be extracted.

When $n \geq 101$ is set, it will be processed for specifying $n = 100$.

When there is one concerned record, any concerned records will be extracted regardless of the specified values.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Condition register (Combination condition)		ZR10055

[Function]

This signal is used to specify the relation between 1st set and 2nd set in the condition setting for updating, deleting, or extraction operation.

[Operation]

Specify the logical operator to show the conditions relation with the bit values below.

bit0

0: AND Execute the operation if the conditions both before and after the operator are true.

1: OR Execute the operation if the condition either before or after the operator is true.

[Related signals]

- (1) MES interface library: Condition register (Field value) 1st set (ZR10056)
- (2) MES interface library: Condition register (Condition value) 1st set (ZR10058 to 89)
- (3) MES interface library: Condition register (Comparison condition) 1st set (ZR10057)
- (4) MES interface library: Condition register (Field value) 2nd set (ZR10090)
- (5) MES interface library: Condition register (Condition value) 2nd set (ZR10092 to 123)
- (6) MES interface library: Condition register (Comparison condition) 2nd set (ZR10091)

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Condition register (Field value) 1st set		ZR10056
A	MES interface library: Condition register (Field value) 2nd set		ZR10090

[Function]

This signal is used to specify the field value to be the condition target in the condition setting for updating, deleting, or extraction operation.

[Operation]

Specify the field number to be the condition target.

[Related signals]

- (1) MES interface library: Condition register (Condition value) 1st set (ZR10058 to 89)
- (2) MES interface library: Condition register (Comparison condition) 1st set (ZR10057)
- (3) MES interface library: Condition register (Condition value) 2nd set (ZR10092 to 123)
- (4) MES interface library: Condition register (Comparison condition) 2nd set (ZR10091)
- (5) MES interface library: Condition register (Combination condition) (ZR10055)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Condition register (Comparison condition) 1st set		ZR10057
A	MES interface library: Condition register (Comparison condition) 2nd set		ZR10091

[Function]

This signal is used to specify the relation between condition value and field value to be the condition target in the condition setting for update, delete, or extraction operation.

[Operation]

Specify the comparison operator that shows the relation between the condition value and the field value to be the condition target as follows.

- 1: = Field value equals to condition value.
- 2: ≠ Field value does not equal to condition value.
- 3: < Field value is smaller than condition value.
- 4: > Field value is larger than condition value.
- 5: ≤ Field value is equal or smaller than condition value.
- 6: ≥ Field value is equal or larger than condition value.

The condition sets are invalid when you specify "0".

[Related signals]

- (1) MES interface library: Condition register (Field value) 1st set (ZR10056)
- (2) MES interface library: Condition register (Condition value) 1st set (ZR10058 to 89)
- (3) MES interface library: Condition register (Field value) 2nd set (ZR10090)
- (4) MES interface library: Condition register (Condition value) 2nd set (ZR10092 to 123)
- (5) MES interface library: Condition register (Combination condition) (ZR10055)

Cont.	Signal name	Abbrev.	Common (\$)
A	MES interface library: Condition register (Condition value) 1st set		ZR10058 to ZR10089
A	MES interface library: Condition register (Condition value) 2nd set		ZR10092 to ZR10123

[Function]

This signal is used to specify the condition value corresponding to the field value to be the condition target in the condition setting for updating, deleting, or extraction operation.

[Operation]

Specify the condition value corresponding to the field value to be the condition target.

[Related signals]

- (1) MES interface library: Condition register (Field value) 1st set (ZR10056)
- (2) MES interface library: Condition register (Comparison condition) 1st set (ZR10057)
- (3) MES interface library: Condition register (Field value) 2nd set (ZR10090)
- (4) MES interface library: Condition register (Comparison condition) 2nd set (ZR10091)
- (5) MES interface library: Condition register (Combination condition) (ZR10055)

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Serial number)		ZR10330 to ZR10361

[Function]

This signal is used to set the workpiece serial number after the update at the time of the update operation.

The workpiece serial number extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the ASCII code (hexadecimal number) corresponding to the serial number.

For the extraction operation, the ASCII code (hexadecimal number) corresponding to the serial number is stored.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Operator ID)		ZR10362 to ZR10393

[Function]

This signal is used to set the operator ID after the update at the time of the update operation.

The operator ID extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the ASCII code (hexadecimal number) corresponding to the operator ID.

For the extraction operation, the ASCII code (hexadecimal number) corresponding to the operator ID is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (NC unit number)		ZR10394 to ZR10401

[Function]

This signal is used to set the NC unit number after the update at the time of the update operation.

The NC unit number extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the ASCII code (hexadecimal number) corresponding to the NC unit number.

For the extraction operation, the ASCII code (hexadecimal number) corresponding to the NC unit number is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Line number)		ZR10402 to ZR10417

[Function]

This signal is used to set the line number after the update at the time of the update operation.

The line number extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the ASCII code (hexadecimal number) corresponding to the line number.

For the extraction operation, the ASCII code (hexadecimal number) corresponding to the line number is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Machine type)		ZR10418

[Function]

This signal is used to set the machine type after the update at the time of the update operation.

The machine type extracted from the database is stored at the time of the extraction operation.

[Operation]

Specify the machine type after the update at the time of the update operation.

The machine type extracted from database is stored at the time of the extraction operation.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Common user area C1)		ZR10420 to ZR10451

[Function]

This signal is used to set the character after the update at the time of the update operation.

The character extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the ASCII code (hexadecimal number) corresponding to the character after the update.

For the extraction operation, the ASCII code (hexadecimal number) corresponding to the character is stored.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Common user area L1 to L10)		ZR10452,3 to ZR10470,1

[Function]

This signal is used to set the 32-bit integer data after the update at the time of the update operation.

The 32-bit integer data extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the 32-bit integer data after the update.

For the extraction operation, the 32-bit integer data extracted from the database is stored

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Machining start time)		ZR10474, 5

[Function]

This signal is used to set the machining start time after the update at the time of the update operation.

The machining start time extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the machining start time in total seconds from January 1, 1970.

For the extraction operation, the machining start time in total seconds from January 1, 1970 is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Machining end time)		ZR10476, 7

[Function]

This signal is used to set the machining end time after the update at the time of the update operation.

The machining end time extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the machining end time in total seconds from January 1, 1970.

For the extraction operation, the machining end time in total seconds from January 1, 1970 is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Cycle time)		ZR10478, 9

[Function]

This signal is used to set the cycle time after the update at the time of the update operation.

The cycle time extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of cycle time [ms].

For the extraction operation, the value of cycle time [ms] is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Program number at machining start)		ZR10480 to ZR10495

[Function]

This signal is used to set the program number after the update at the time of the update operation.

The program number extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value in the ASCII code (hexadecimal number) corresponding to the program number.

For the extraction operation, the value in the ASCII code (hexadecimal number) corresponding to the program number is stored.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (N number at machining start)		ZR10496, 7

[Function]

This signal is used to set the sequence number after the update at the time of the update operation.

The sequence number extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the sequence number.

For the extraction operation, the sequence number is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (B number at machining start)		ZR10498, 9

[Function]

This signal is used to set the block number after the update at the time of the update operation.

The block number extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the block number.

For the extraction operation, the block number is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Spindle 1 maximum load)		ZR10500

[Function]

This signal is used to set the 1st spindle's maximum current value after the update at the time of the update operation.

The 1st spindle's maximum current value extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the maximum current value [%] of the 1st spindle.

For the extraction operation, the maximum current value [%] of the 1st spindle is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Spindle 2 maximum load)		ZR10501

[Function]

This signal is used to set the 2nd spindle's maximum current value after the update at the time of the update operation.

The 2nd spindle's maximum current value extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the maximum current value [%] of the 2nd spindle.

For the extraction operation, the maximum current value [%] of the 2nd spindle is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Power consumption amount)		ZR10502, 3

[Function]

This signal is used to set the power consumption amount after the update at the time of the update operation.

The consumption amount extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of power consumption amount [Wh].

For the extraction operation, the power consumption amount [Wh] is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Power regeneration amount)		ZR10504, 5

[Function]

This signal is used to set the power regeneration amount after the update at the time of the update operation.

The power regeneration amount extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of power regeneration amount [Wh].

For the extraction operation, the power regeneration amount [Wh] is stored.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Number of machined workpieces)		ZR10506, 7

[Function]

This signal is used to set the number of machined workpieces after the update at the time of the update operation.

The number of machined workpieces extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the number of the machined workpieces.

For the extraction operation, the number of the machined workpieces is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Tool number 1 to 5)		ZR10508,9 to ZR10516,7

[Function]

This signal is used to set the tool number after the update at the time of the update operation.

The tool number extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the tool number.

For the extraction operation, the tool number is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Tool offset number 1 to 5)		ZR10518 to ZR10522

[Function]

This signal is used to set the tool compensation number after the update at the time of the update operation.

The tool compensation number extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the tool compensation number.

For the extraction operation, the tool compensation number is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Tool length offset 1 to 5)		ZR10524,5 to ZR10532,3

[Function]

This signal is used to set the tool length compensation amount after the update at the time of the update operation.

The tool length compensation amount extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the tool length compensation amount.

For the extraction operation, the tool length compensation amount is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Tool radius offset 1 to 5)		ZR10534,5 to ZR10542,3

[Function]

This signal is used to set the tool radius compensation amount after the update at the time of the update operation.

The tool radius compensation amount extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the tool radius compensation amount.

For the extraction operation, the tool radius compensation amount is stored.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Tool length wear amount 1 to 5)		ZR10544,5 to ZR10552,3

[Function]

This signal is used to set the tool length wear amount after the update at the time of the update operation.

The tool length wear amount extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the tool length wear amount.

For the extraction operation, the tool length wear amount is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Tool radius wear amount 1 to 5)		ZR10554,5 to ZR10562,3

[Function]

This signal is used to set the tool radius wear amount after the update at the time of the update operation.

The tool radius wear amount extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the tool radius wear amount.

For the extraction operation, the tool radius wear amount is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Tool life 1 to 5)		ZR10564,5 to ZR10572,3

[Function]

This signal is used to set the tool life after the update at the time of the update operation.

The tool life extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the tool life.

For the extraction operation, the screen displays the tool life is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (User arbitrary C1 at machining end)		ZR10576 to ZR10607

[Function]

This signal is used to set the character after the update at the time of the update operation.

The character extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the ASCII code (hexadecimal number) corresponding to the character after the update.

For the extraction operation, the ASCII code (hexadecimal number) corresponding to the character is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (User arbitrary L1 to L10 at machining end)		ZR10608,9 to ZR10626,7

[Function]

This signal is used to set the 32-bit integer data after the update at the time of the update operation.

The 32-bit integer data extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the 32-bit integer data after the update.

For the extraction operation, the 32-bit integer data extracted from the database is stored

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Time of alarm occurrence)		ZR10632, 3

[Function]

This signal is used to set the alarm occurrence time after the update at the time of the update operation.

The alarm occurrence time extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the time of alarm occurrence in total seconds from January 1, 1970.

For the extraction operation, the time of alarm occurrence in total seconds from January 1, 1970 is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Alarm number 1)		ZR10634 to ZR10649
A	Data I/O register for MES interface library (Alarm number 2)		ZR10650 to ZR10665
A	Data I/O register for MES interface library (Alarm number 3)		ZR10666 to ZR10681
A	Data I/O register for MES interface library (Alarm number 4)		ZR10682 to ZR10697

[Function]

This signal is used to set the alarm number after the update at the time of the update operation.

The alarm number extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value in the ASCII code (hexadecimal number) corresponding to that alarm.

For the extraction operation, the value in the ASCII code (hexadecimal number) corresponding to that alarm number is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Time of power ON)		ZR10698, 9

[Function]

This signal is used to set the power ON time after the update at the time of the update operation.

The power ON time extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the power ON time in seconds.

For the extraction operation, the power ON time in seconds is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Program number at alarm)		ZR10700 to ZR10715

[Function]

This signal is used to set the program number after the update at the time of the update operation.

The program number extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value in the ASCII code (hexadecimal number) corresponding to the program number.

For the extraction operation, the value in the ASCII code (hexadecimal number) corresponding to the program number is stored.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Subprogram number at alarm)		ZR10716 to ZR10731

[Function]

This signal is used to set the subprogram number after the update at the time of the update operation.

The subprogram number extracted from the database at the time of the extraction operation is stored.

[Operation]

For the update operation, specify the value in the ASCII code (hexadecimal number) corresponding to the subprogram number.

For the extraction operation, the value in the ASCII code (hexadecimal number) corresponding to the subprogram number is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (N number at alarm)		ZR10732, 3

[Function]

This signal is used to set the sequence number after the update at the time of the update operation.

The sequence number extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the sequence number.

For the extraction operation, the sequence number is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (B number at alarm)		ZR10734, 5

[Function]

This signal is used to set the block number after the update at the time of the update operation.

The block number extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the block number.

For the extraction operation, the block number is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (G code modal)		ZR10736 to ZR10767

[Function]

This signal is used to set the G code modal after the update at the time of the update operation.

The G code modal extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value in the ASCII code (hex number) corresponding to the G code modal.

For the extraction operation, the value in the ASCII code (hex number) corresponding to the G code modal is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Spindle 1 load value)		ZR10768

[Function]

This signal is used to set the 1st spindle's current value after the update at the time of the update operation.

The 1st spindle's current value extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the current value [%] of the 1st spindle.

For the extraction operation, the current value [%] of the 1st spindle is stored.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Spindle 2 load value)		ZR10769

[Function]

This signal is used to set the 2nd spindle's current value after the update at the time of the update operation.

The 2nd spindle's current value extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the current value [%] of the 2nd spindle.

For the extraction operation, the current value [%] of the 2nd spindle is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Tool number)		ZR10770, 1

[Function]

This signal is used to set the tool number after the update at the time of the update operation.

The tool number extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the tool number.

For the extraction operation, the tool number is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Tool offset number)		ZR10772

[Function]

This signal is used to set the tool compensation number after the update at the time of the update operation.

The tool compensation number extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the tool compensation number.

For the extraction operation, the tool compensation number is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Tool length offset)		ZR10774, 5

[Function]

This signal is used to set the tool length compensation amount after the update at the time of the update operation.

The tool length compensation amount extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the tool length compensation amount.

For the extraction operation, the tool length compensation amount is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Tool radius offset)		ZR10776, 7

[Function]

This signal is used to set the tool radius compensation amount after the update at the time of the update operation.

The tool radius compensation amount extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the tool radius compensation amount.

For the extraction operation, the tool radius compensation amount is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Tool length wear amount)		ZR10778, 9

[Function]

This signal is used to set the tool length wear amount after the update at the time of the update operation.

The tool length wear amount extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the tool length wear amount.

For the extraction operation, the tool length wear amount is stored.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Tool radius wear amount)		ZR10780, 1

[Function]

This signal is used to set the tool radius wear amount after the update at the time of the update operation.

The tool radius compensation amount extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the tool radius wear amount.

For the extraction operation, the tool radius wear amount is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Tool life)		ZR10782, 3

[Function]

This signal is used to set the tool life after the update at the time of the update operation.

The tool life extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the value of the tool life.

For the extraction operation, the screen displays the tool life is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (User area C1 at alarm)		ZR10786 to ZR10817

[Function]

This signal is used to set the character after the update at the time of the update operation.

The character extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the ASCII code (hexadecimal number) corresponding to the character after the update.

For the extraction operation, the ASCII code (hexadecimal number) corresponding to the character is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (User area L1 to L10 at alarm)		ZR10818,9 to ZR10836,7

[Function]

This signal is used to set the 32-bit integer data after the update at the time of the update operation.

The 32-bit integer data extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the 32-bit integer data after the update.

For the extraction operation, the 32-bit integer data extracted from the database is stored

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Arbitrary user area C1)		ZR10842 to ZR10873

[Function]

This signal is used to set the character after the update at the time of the update operation.

The character extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the ASCII code (hexadecimal number) corresponding to the character after the update.

For the extraction operation, the ASCII code (hexadecimal number) corresponding to the character is stored.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Arbitrary user area S1 to S20)		ZR10874 to ZR10893

[Function]

This signal is used to set the 16-bit integer data after the update at the time of the update operation.

The 16-bit integer data extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the 16-bit integer data after the update.

For the extraction operation, the 16-bit integer data extracted from the database is stored.

Cont.	Signal name	Abbrev.	Common (\$)
A	Data I/O register for MES interface library (Arbitrary user area L1 to L10)		ZR10894,5 to ZR10912,3

[Function]

This signal is used to set the 32-bit integer data after the update at the time of the update operation.

The 32-bit integer data extracted from the database is stored at the time of the extraction operation.

[Operation]

For the update operation, specify the 32-bit integer data after the update.

For the extraction operation, the 32-bit integer data extracted from the database is stored.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: User area C1 at machining end		ZR1094 0 to ZR1097 1	ZR1112 0 to ZR1115 1	ZR1130 0 to ZR1133 1	ZR1148 0 to ZR1151 1	ZR1166 0 to ZR1169 1	ZR1184 0 to ZR1187 1	ZR1202 0 to ZR1205 1	ZR1220 0 to ZR1223 1

[Function]

This signal is used to set the desirable arbitrary character to register to the database when the machining is completed.

[Operation]

Specify the ASCII code (hexadecimal number) corresponding to the desirable character to set.

This data is send to the database at the time of machining completion.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: User area L1 to L10 at machining end		ZR1097 2,3 to ZR1099 0,1	ZR1115 2,3 to ZR1117 0,1	ZR1133 2,3 to ZR1135 0,1	ZR1151 2,3 to ZR1153 0,1	ZR1169 2,3 to ZR1171 0,1	ZR1187 2,3 to ZR1189 0,1	ZR1205 2,3 to ZR1207 0,1	ZR1223 2,3 to ZR1225 0,1

[Function]

This signal is used to set the desirable arbitrary 32-bit integer data to register to the database at the time of machining completion.

[Operation]

Specify the desirable 32-bit integer data to set.

This data is send to the database at the time of machining completion.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: User area C1 at alarm		ZR1099 4 to ZR1102 5	ZR1117 4 to ZR1120 5	ZR1135 4 to ZR1138 5	ZR1153 4 to ZR1156 5	ZR1171 4 to ZR1174 5	ZR1189 4 to ZR1192 5	ZR1207 4 to ZR1210 5	ZR1225 4 to ZR1228 5

[Function]

This signal is used to set the desirable arbitrary character to register to the database when an alarm occurs.

[Operation]

Specify the ASCII code (hexadecimal number) corresponding to the desirable character to set.

This data is sent to the database at the time of alarm occurrence.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: User area L1 to L10 at alarm		ZR1102 6,7 to ZR1104 4,5	ZR1120 6,7 to ZR1122 4,5	ZR1138 6,7 to ZR1140 4,5	ZR1156 6,7 to ZR1158 4,5	ZR1174 6,7 to ZR1176 4,5	ZR1192 6,7 to ZR1194 4,5	ZR1210 6,7 to ZR1212 4,5	ZR1228 6,7 to ZR1230 4,5

[Function]

This signal is used to set the desirable arbitrary 32-bit integer data to register to the database when an alarm occurs.

[Operation]

Specify the desirable 32-bit integer data to set.

This data is sent to the database at the time of alarm occurrence.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Arbitrary user area C1		ZR1104 8 to ZR1107 9	ZR1122 8 to ZR1125 9	ZR1140 8 to ZR1143 9	ZR1158 8 to ZR1161 9	ZR1176 8 to ZR1179 9	ZR1194 8 to ZR1197 9	ZR1212 8 to ZR1215 9	ZR1230 8 to ZR1233 9

[Function]

This signal is used to set the desirable arbitrary character to register to the database at the time of user's option.

[Operation]

Specify the ASCII code (hexadecimal number) corresponding to the desirable character to set.

This data is sent to the database at the time of user's option.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Arbitrary user area S1 to S20		ZR1108 0 to ZR1109 9	ZR1126 0 to ZR1127 9	ZR1144 0 to ZR1145 9	ZR1162 0 to ZR1163 9	ZR1180 0 to ZR1181 9	ZR1198 0 to ZR1199 9	ZR1216 0 to ZR1217 9	ZR1234 0 to ZR1235 9

[Function]

This signal is used to set the desirable arbitrary 16-bit integer data to register to the database at the time of user's option.

[Operation]

Specify the desirable 16-bit integer data to set.

This data is sent to the database at the time of user's option.

Cont.	Signal name	Abbrev.	\$1	\$2	\$3	\$4	\$5	\$6	\$7	\$8
A	MES interface library: Arbitrary user area L1 to L10		ZR1110 0,1 to ZR1111 8,9	ZR1128 0,1 to ZR1129 8,9	ZR1146 0,1 to ZR1147 8,9	ZR1164 0,1 to ZR1165 8,9	ZR1182 0,1 to ZR1183 8,9	ZR1200 0,1 to ZR1201 8,9	ZR1218 0,1 to ZR1219 8,9	ZR1236 0,1 to ZR1237 8,9

[Function]

This signal is used to set the desirable arbitrary 32-bit integer data to register to the database at the time of user's option.

[Operation]

Specify the desirable 32-bit integer data to set.

This data is sent to the database at the time of user's option.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

4.6.4 Diagnosis Data Output

Cont.	Signal name	Abbrev.	Common (\$)
A	Diagnosis data output: Battery exchange		ZR12404 ZR12405

[Function] [Operation]

The accumulated use time of the NC unit battery is set in the register. (0 to 4, 294, 967, 295)

The register is cleared to zero at the time of NC unit replacement.

[Caution]

- (1) The data is in the units of 1.0 min.
- (2) The data format is unsigned binary.
- (3) The data remains unchanged even when you input the backup data using the SRAM backup function.

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Diagnosis data output: Battery exchange (drive)		ZR12608	ZR12610	ZR12612	ZR12614	ZR12616	ZR12618	ZR12620	ZR12622
			ZR12609	ZR12611	ZR12613	ZR12615	ZR12617	ZR12619	ZR12621	ZR12623
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR12624	ZR12626	ZR12628	ZR12630	ZR12632	ZR12634	ZR12636	ZR12638
			ZR12625	ZR12627	ZR12629	ZR12631	ZR12633	ZR12635	ZR12637	ZR12639
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR12640	ZR12642	ZR12644	ZR12646	ZR12648	ZR12650	ZR12652	ZR12654
			ZR12641	ZR12643	ZR12645	ZR12647	ZR12649	ZR12651	ZR12653	ZR12655
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR12656	ZR12658	ZR12660	ZR12662	ZR12664	ZR12666	ZR12668	ZR12670
			ZR12657	ZR12659	ZR12661	ZR12663	ZR12665	ZR12667	ZR12669	ZR12671

[Function] [Operation]

The accumulated use time of the drive unit battery is set in the register.

The register is cleared to zero at the time of drive unit replacement.

[Caution]

- (1) The data is in the units of 1.0 hour.
- (2) The data format is unsigned binary.
- (3) The data of servo axes (NC and PLC axes) is output to the registers of the 1st to the 32nd axes, in the order specified by the parameter.
- (4) The data remains unchanged even when you input the backup data using the SRAM backup function.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Diagnosis data output: Motor insulation resistance (motor)		ZR12784	ZR12786	ZR12788	ZR12790	ZR12792	ZR12794	ZR12796	ZR12798
			ZR12785	ZR12787	ZR12789	ZR12791	ZR12793	ZR12795	ZR12797	ZR12799
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR12800	ZR12802	ZR12804	ZR12806	ZR12808	ZR12810	ZR12812	ZR12814
			ZR12801	ZR12803	ZR12805	ZR12807	ZR12809	ZR12811	ZR12813	ZR12815
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR12816	ZR12818	ZR12820	ZR12822	ZR12824	ZR12826	ZR12828	ZR12830
			ZR12817	ZR12819	ZR12821	ZR12823	ZR12825	ZR12827	ZR12829	ZR12831
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR12832	ZR12834	ZR12836	ZR12838	ZR12840	ZR12842	ZR12844	ZR12846
			ZR12833	ZR12835	ZR12837	ZR12839	ZR12841	ZR12843	ZR12845	ZR12847

[Function] [Operation]

The present insulation resistance of the motor is set in the register.

If the insulation resistance is less than 1MΩ, "0" is set.

If the insulation resistance is 100MΩ or greater, "100" is set.

If your drive unit does not support this function, or if the data has not been obtained from the drive unit, "-1" (0xFFFFFFFF) is set in the register.

[Caution]

- (1) The data is in the units of 1.0MΩ.
- (2) The data format is signed binary.
- (3) The data of servo axes (NC and PLC axes) is output to the registers of the 1st to the 32nd axes, in the order specified by the parameter.
- (4) The effective value can be obtained only when the drive unit is MDS-E/EH Series (when the drive unit S/W version is A3 or later, and the H/W supports the insulation degradation detection function).

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Diagnosis data output: Motor insulation resistance (motor)		ZR12848	ZR12850	ZR12852	ZR12854	ZR12856	ZR12858	ZR12860	ZR12862
			ZR12849	ZR12851	ZR12853	ZR12855	ZR12857	ZR12859	ZR12861	ZR12863

[Function] [Operation]

The present insulation resistance of the motor is set in the register.

If the insulation resistance is less than 1MΩ, "0" is set.

If the insulation resistance is 100MΩ or greater, "100" is set.

If your drive unit does not support this function, or if the data has not been obtained from the drive unit, "-1" (0xFFFFFFFF) is set in the register.

[Caution]

- (1) The data is in the units of 1.0MΩ.
- (2) The data format is signed binary.
- (3) The effective value can be obtained only when the drive unit is MDS-E/EH Series (when the drive unit S/W version is A3 or later, and the H/W supports the insulation degradation detection function).

Cont.	Signal name	Abbrev.	Common (\$)
A	Diagnosis data output: Automatic log clear time		ZR12945

[Function] [Operation]

Set the length of time before automatic log clear takes place.

[Caution]

- (1) The data is in the units of 1.0 hour.
- (2) If this signal is unspecified, the default time (24 hours) is applied.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	1st axis	2nd axis	3rd axis	4th axis	5th axis	6th axis	7th axis	8th axis
A	Diagnosis data output: Accumulated travel distance (motor)		ZR12946	ZR12948	ZR12950	ZR12952	ZR12954	ZR12956	ZR12958	ZR12960
			ZR12947	ZR12949	ZR12951	ZR12953	ZR12955	ZR12957	ZR12959	ZR12961
			9th axis	10th axis	11th axis	12th axis	13th axis	14th axis	15th axis	16th axis
			ZR12962	ZR12964	ZR12966	ZR12968	ZR12970	ZR12972	ZR12974	ZR12976
			ZR12963	ZR12965	ZR12967	ZR12969	ZR12972	ZR12973	ZR12975	ZR12977
			17th axis	18th axis	19th axis	20th axis	21th axis	22th axis	23th axis	24th axis
			ZR12978	ZR12980	ZR12982	ZR12984	ZR12986	ZR12988	ZR12990	ZR12992
			ZR12979	ZR12981	ZR12983	ZR12985	ZR12987	ZR12989	ZR12991	ZR12993
			25th axis	26th axis	27th axis	28th axis	29th axis	30th axis	31th axis	32th axis
			ZR12994	ZR12996	ZR12998	ZR13000	ZR13002	ZR13004	ZR13006	ZR13008
			ZR12995	ZR12997	ZR12999	ZR13001	ZR13003	ZR13005	ZR13007	ZR13009

[Function] [Operation]

The accumulated travel distance of the servo axis is set in the register.

[Caution]

- (1) The data is in the units of 1.0 m. For a rotary axis, the unit is 1.0 [revolution].
- (2) The data format is unsigned binary.
- (3) The data of servo axes (NC and PLC axes) is output to the registers of the 1st to the 32nd axes, in the order specified by the parameter.
- (4) The data remains unchanged even when you input the backup data using the SRAM backup function.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

4.6.5 Spindle Protection

Cont.	Signal name	Abbrev.	1stSP	2ndSP	3rdSP	4thSP	5thSP	6thSP	7thSP	8thSP
A	Spindle protection: Motor equivalent load factor	SPEQLD	ZR13010	ZR13011	ZR13012	ZR13013	ZR13014	ZR13015	ZR13016	ZR13017

[Function]

This signal outputs the spindle motor equivalent load factor from the start of the last automatic operation to the current operation with 1% increment.

The output value can be adjusted using the parameter "#43101 sp_rated_ratio".

[Operation]

Values are cleared to zero at the following timings:

- The automatic operation starts.
- M99 command is issued in the main program.

Cont.	Signal name	Abbrev.	Common (\$)
A	Spindle protection: Number of times log output error occurred	PRSPERR	ZR13018

[Function]

This signal outputs the number of errors which occurred at the time the log was output with the spindle protection function.

[Operation]

When the error occurs at the time the log was output with the spindle protection function, ZR13018 is incremented.

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

4.6.6 External Encoder Position Output I/F

Cont.	Signal name	Abbrev.	Common (\$)
A	External encoder 1: Position output	ENC1POS	ZR13020,1

[Function]

This signal outputs the position (angle) calculated based on the pulse input of the external encoder 1 in the PLC setting units.

[Operation]

When the PLC setting unit is B (0.001mm), 0 to 359999 [0.001°] is output.

The value of this register is held even when the power is OFF.

Note

- (1) When the power is OFF, the position change cannot be detected.

[Related signals]

- (1) External encoder 1: Position output clear request (ENC1PCLR: Y1C88)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

4.6.7 Machine Contact Input/Output I/F

Cont.	Signal name	Abbrev.	Common (\$)
A	Thermistor input n	TIn	ZR13028 to ZR13039

[Function]

This signal enables the following temperature value to be read from the file register: temperature acquired with the thermistor that is connected to the designated connector of the thermistor input-equipped remote I/O unit.

[Operation]

This signal outputs the temperature value acquired with the thermistor in 0.1 °C units.

(Example) 0x01F5 = 501 -> 50.1 °C

When the thermistor is disconnected or short-circuited, this register is not updated.

The below shows the data update cycle of the thermistor input and the interface:

Channel	File register	Data update cycle
TI0	ZR13028	The thermistor voltage acquired with the thermistor input-equipped remote I/O unit is input after converted to a temperature value per PLC medium-speed cycle. One station of remote I/O has 4 thermistor inputs, thus 4 PLC medium-speed cycles are required for the inputs of one station.
TI1	ZR13029	
TI2	ZR13030	
TI3	ZR13031	
TI4	ZR13032	
TI5	ZR13033	
TI6	ZR13034	
TI7	ZR13035	
TI8	ZR13036	
TI9	ZR13037	
TI10	ZR13038	
TI11	ZR13039	

[Related signals]

- (1) Thermistor disconnection (TIOPN: ZR13040)
- (2) Thermistor short-circuit (TISRT: ZR13041)


Cont.	Signal name	Abbrev.	Common (\$)
A	Thermistor disconnection	TIOPN	ZR13040

[Function]

This signal notifies that the thermistor is not connected to the thermistor input-equipped remote I/O unit, or the thermistor is disconnected or ground-fault.

[Operation]

When the thermistor is unconnected, disconnected or ground-fault, the bit of the corresponding channel is turned ON.
The thermistor input (TI0 to TI11) of the channel which is disconnected or ground-fault is not updated.

**[Related signals]**

- (1) Thermistor input (TI0 to TI11: ZR13028 to 13039)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	Thermistor short-circuit	TISRT	ZR13041


[Function]

This signal notifies that the thermistor input of the thermistor input-equipped remote I/O unit is short-circuited.

[Operation]

When the thermistor input is short-circuited, the bit of the corresponding channel is turned ON.

The "Thermistor input" (TI0 to TI11) of the channel which is short-circuited is not updated.

**[Related signals]**

(1) Thermistor input (TI0 to TI11: ZR13028 to 13039)

Cont.	Signal name	Abbrev.	Common (\$)
A	Multi-analog input ch n	MAn	ZR13050 to 13065

[Function]

This signal can read the data of analog voltage, current or temperature acquired from the remote I/O unit with multi-analog input.

[Operation]

The data acquired from the remote I/O unit with multi-analog input is output in the format selected with the parameters "#11351 manasel_00" to "#11366 manasel_15" (Multi-analog input data type ch0 to ch15).

#11351	Data type	Register output range(*1)	Accuracy guarantee range	Output unit	Corresponding data	
		(decimal)	(decimal)		Register output range	Accuracy guarantee range
0	Analog voltage	±32000	±32000	312.5μV	±10V	±10V
1	Analog current	±16000	±16000	1.25μA	±20mA	±20mA
2 to 5	Temperature (resistance thermometer bulb, normal)	-700 to 3200	-500 to 3000	0.1 °C	-70.0 to 320.0 °C	-50.0 to 300.0 °C
6 to 9	Temperature (resistance thermometer bulb, high-accuracy)	-7000 to 32000	-5000 to 30000	0.01 °C	-70.00 to 320.00 °C	-50.00 to 300.00 °C
10	Temperature (thermocouple (K))	-600 to 6200	-400 to 6000	0.1 °C	-60.0 to 620.0 °C	-40.0 to 600.0 °C
11	Temperature (thermocouple (J))	-600 to 6200	-400 to 6000	0.1 °C	-60.0 to 620.0 °C	-40.0 to 600.0 °C

(*1) Output in hexadecimal to the register.

If the normal analog input value cannot be acquired from the remote I/O unit with multi-analog input (due to disconnection detection or input value error), this register is not updated. The error cause is output to the multi-analog input status (MASTSn).

A thermocouple can measure temperature relative to the reference junction. For the multi-analog input unit, the unit's connector part serves as the reference junction. While the connector part is not at 0 °C, cold junction compensation is required. The compensation uses a Pt100 resistor.

[Related signals]

(1) Multi-analog input status (MASTS00 to 15: ZR13066 to ZR13081)


4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Cont.	Signal name	Abbrev.	Common (\$)
A	Multi-analog input status ch n	MASTSn	ZR13066 to 13081

[Function]

This signal outputs the input data type and error status of the remote I/O unit with multi-analog input.

**[Operation]****<bit0 to 3 [Data type]>**

Data type selected with the parameter "#11351 manasel_00" to "#11366 manasel_15 (Multi-analog input data type ch0 to ch15) is output.

0: Analog voltage

1: Analog current

2: Temperature (resistance thermometer bulb, normal, Pt100, 3-wire)

3: Temperature (resistance thermometer bulb, normal, Pt100, 4-wire)

4: Temperature (resistance thermometer bulb, normal, Pt1000, 3-wire)

5: Temperature (resistance thermometer bulb, normal, Pt1000, 4-wire)

6: Temperature (resistance thermometer bulb, high-accuracy, Pt100, 3-wire)

7: Temperature (resistance thermometer bulb, high-accuracy, Pt100, 4-wire)

8: Temperature (resistance thermometer bulb, high-accuracy, Pt1000, 3-wire)

9: Temperature (resistance thermometer bulb, high-accuracy, Pt1000, 4-wire)

10: Temperature (thermocouple (K))

11: Temperature (thermocouple (J))

<bitD [Input data upper limit exceeded]>

When the input value from the remote I/O unit with multi-analog input exceeds the upper limit of accuracy guarantee range, this turns ON.

<bitE [Input data lower limit exceeded]>

When the input value from the remote I/O unit with multi-analog input exceeds the lower limit of accuracy guarantee range, this turns ON.

<bitF [Disconnection]>

When the remote I/O unit with multi-analog input detects the disconnection of temperature sensor, this turns ON.

[Related signals]

- (1) Multi-analog input (MA00 to 15: ZR13050 to ZR13065)

4 Explanation of Interface Signals


4.6 Explanation of ZR Device

4.6.8 BiSS Encoder I/F


Cont.	Signal name	Abbrev.	Common (\$)
A	BiSS encoder I/F: Communication status	BENCSTS	ZR13090

[Function] [Operation]

The communication status of BiSS encoder I/F is output to this register.



Create a sequence program not to use data of the "BiSS encoder I/F: Encoder 1 data output n" signal (BENC1DATn: ZR13091) while bit0 of this register is "1". (Refer to the figure below.)



When a communication error occurs, the operation error corresponding to the error code is displayed. Restart CNC when the communication error occurs.

Error code (ZR13090/bit1, bit2, bit3)	Operation errors
001	M01 0350
010	M01 0351
110	M01 0352

[Related signals]

- (1) BiSS encoder I/F: Encoder 1 data output n (BENC1DATn: ZR13091 to ZR13094)

Cont.	Signal name	Abbrev.	Common (\$)
A	BiSS encoder I/F: Encoder 1 data output 1 to 4	BENC1-DAT1 to 4	ZR13091 to ZR13094

[Function]

Data of BiSS encoder 1 is output to this signal.

[Operation]

Data received from BiSS encoder is output to this signal.

The unit of this signal does not depend on the parameter "#1040 M_inch" setting.

The update cycle of this signal depends on the parameter "#1334 DI/DO refresh cycl" setting.

The value of this signal is not updated when a communication error is detected on the CNC side and an error code is being output to the "BiSS encoder I/F: Communication status" signal (ZR13090).

Create a sequence program not to use data of this register while an error occurs on the BiSS encoder side (*1).

When this function is invalid (the parameter "#1762 cfgPR12/bit5" is set to "0"), the value of this register is "0".

(*1) This indicates the period when both bit0 and bit1 of the "BiSS encoder I/F: Communication status" signal (BENCSTS: ZR13090) are "0".

[Related signals]

- (1) BiSS encoder I/F: Communication status (BENCSTS: ZR13090)

4 Explanation of Interface Signals

4.6 Explanation of ZR Device

Appx.1: PLC window

PLC window is a function that uses the "read window" or "write window" arbitrary assigned to the R register user area to read and write the CNC operation status, axis information, parameters and tool data, etc.

5.1 Details

The PLC window has "read window" for read and "write window" for write.

The "read window" and "write window" designate arbitrary position of the R register with parameters (window start R register). Up to three window areas can be specified simultaneously for both "read window" area and "write window" area. This enables read/write window area to be split and used even when a part of the user area is fixed.

R registers that can be used

User area	R8300 to R9799	1500 points of backup area
	R9800 to R9899	100 points of non-backup area
	R18300 to R19799	1500 points of backup area
	R19800 to R19899	100 points of non-backup area
	R28300 to R29799	1500 points of backup area
	R29800 to R29899	100 points of non-backup area

(Note that R register for window start must be an even number.)


D registers that can be used

Application	Device
Control data (MELSEC -> CNC)	D4096 to D5295 (1200 words)
Read data status (CNC -> MELSEC)	D1024 to D1523 (500 words)

5 Appx.1: PLC window

5.1 Details

Sixteen R registers are used for one read window or write window. (18 registers for when extended interface is used.) The read window is further divided into the "read control window" and "read data window". The write window is also divided into the "write control window" and "write data window". Up to four data items can be successively read or written from the data designated in one read window or write window.



Outline drawing for PLC window

After reading, whether reading succeeded or failed and the number of data read will be displayed on the "read control window", and details on the "read data window". After writing, whether writing succeeded or failed and number of data written will be displayed on the "writing control window".

When reading/writing is finished, bit0 (refer to the section on "5.2.2 Read Window Interface" and "5.2.3 Write Window Interface") turns ON regardless of reading/writing successfulness.

Number of data read/written is defined by the number of data actually read or written. When all reading/writing failed, it shows "0".

When two or more data are read/written, it finishes as soon as reading/writing is failed. For example, when the second reading/writing is illegal, it finishes on the spot, even if the third data may be read/written normally. Consequently, the first data is the only one read/written successfully, resulting the number of data read/written to 1.

5.1.1 Read/Write Operation

Read operation

Procedure to read data is as follows:

- (1) On "Read control window", specify the data to read with "Section No.", "Section sub-ID No.", "Sub-section No." and "Data No.".
- (2) Specify "Number to be read (max. 4 data)" and "Read method" when "Number to be read" is two or more.
For "Read method", specify either 0: "Data No.", 1: "Sub-section No." or 2: "Section sub-ID No." to read the continuous data from the data of the specified items.
- (3) Turn ON bit0 of "Control signal" to start the read operation. (Refer to (3) in the below timing chart.)
- (4) Check the read result on "Read control window".

The "Result" of read result is valid after the read operation is completed. (Refer to (4)-1 in the below timing chart.)


If you want to read with one-shot, turn OFF bit0 of control signal on "Read control window" when "Status" of read result shows read completed status. (Refer to the section of "One-shot read" in the below timing chart.)

If you want to read all the time, always turn ON bit0 of control signal on "Read control window". With this ON, NC performs the read operation every time. (Refer to the section of "Continuous read" in the below timing chart.)

For both "One-shot read" and "Continuous read", when bit0 of control signal on "Read control window" is turned OFF, the read result "Status (bit0)" on "Read control window" is turned OFF. (Refer to (4)-2 in the below timing chart.)

If necessary, check "Status" and "Result" of the read result on "Read control window" and then perform the next operation.

[Timing chart of read operation]



Write operation

Procedure to write data is as follows:

- (1) On "Write control window", specify the data to write with "Section No.", "Section sub-ID No.", "Sub-section No." and "Data No."
- (2) Specify "Number to be written (max. 4 data)" and "Write method" when "Number to be written" is two or more.
For "Write method", specify either 0: "Data No.", 1: "Sub-section No." or 2: "Section sub-ID No." to write the continuous data from the data of the specified items.
- (3) Turn ON bit0 of "Control signal" to start the write operation. (Refer to (3) in the below timing chart.)
- (4) Check the write result on "Write control window".

The "Result" of write result is valid after the write operation is completed. (Refer to (4)-1 in the below timing chart.)

If you want to write with one-shot, turn OFF bit0 of control signal on "Write control window" when "Status" of write result shows write completed status. (Refer to the section of "One-shot write" in the below timing chart.)


If you want to write all the time, always turn ON bit0 of control signal on "Write control window". With this ON, NC performs the write operation every time. (Refer to the section of "Continuous write" in the below timing chart.)

However, for the parameter data, write it with one-shot. When you write parameters consecutively, the operation alarm (M50 5003) occurs.

For both "One-shot write" and "Continuous write", when bit0 of control signal on "Write control window" is turned OFF, the write result "Status (bit0)" on "Write control window" is turned OFF. (Refer to (4)-2 in the below timing chart.)

If necessary, check "Status" and "Result" of the write result on "Write control window" and then perform the next operation.

[Timing chart of write operation]



5.2 PLC Window Interface

5.2.1 Parameter Interface

NC ->PLC interface signal

For the PLC window interface, specify the start R register and the number of windows of read window 1, 2, 3, and write window 1, 2, 3 in the parameter (R424 to R435). Error status is set in (R37) when an error is found in the set parameter.

For the read window or write window, the arbitrary assigned area of the R register's user area is used.

(For the area to be used, refer to "Details".)

(R424 to R435 and R37 are non-backup area.)

16 R registers are used for one read window or write window.

When the number of read windows or write windows is set to "1001" to "1100", an extended interface can be used, which enables to specify the sub-section No. and data No. as DWORD-available data. With this interface, the data can be read or written even if the data No. exceeds the allowable range of WORD-type data. In this case, the number of windows is handled as "1" to "100". When the extended interface is used, 18 R registers are used for one read window or one write window.

■ PLC window parameter error status (R37)

It is set when an error is found in the values set for R424 to R435.

When value is already set, it does not read or write.

Values of R37	Error details
0x8001	One of the values set for R424 to R427 exceed the setting range.
0x8002	Area of read window exceeds the R register's user area 1.
0x8003	Area of write window exceeds the R register's user area 1.
0x8004	Write window is found on the read window.
0x8005	Read window is found on the write window.
0x8006	Read window is found on the read window.
0x8007	Write window is found on the write window.
0x8008	Odd number is set for Reading/Writing start R register 1.
0x8101	One of the values set for R428 to R431 exceed the setting range.
0x8102	Area of read window 2 exceeds the R register's user area.
0x8103	Area of write window 2 exceeds the R register's user area.
0x8108	Odd number is set for Reading/Writing start R register 2.
0x8201	One of the values set for R432 to R435 exceed the setting range.
0x8202	Area of read window 3 exceeds the R register's user area.
0x8203	Area of write window 3 exceeds the R register's user area.
0x8208	Odd number is set for Reading/Writing start R register 3. The area is exceeded.

Note

- (1) If an error occurs in one of the windows to be used, read/write is not possible in all the windows. Set from R424 to R435 without letting the window area overlap.

PLC -> NC interface signals

Signal name	R register (Common for part systems)		
	n=1	n=2	n=3
PLC window Reading start R register n	R424	R428	R432
PLC window Number of read windows n	R425	R429	R433
PLC window Writing start R register n	R426	R430	R434
PLC window Number of write windows n	R427	R431	R435

■ PLC window Reading start R register 1 to 3 (R424, R428, R432)

It sets the PLC window Reading start R register 1 to 3.

The setting range is 8300 to 9884, 18300 to 19884 and 28300 to 29884. (Even number only)

R register	Details
R424	The value is not checked when the value of R425 is "0".
R428	The value is not checked when the value of R429 is "0".
R432	The value is not checked when the value of R433 is "0".

■ PLC window Number of read windows 1 to 3 (R425, R429, R433)

It designates the number of read windows 1 to 3.

The setting range is 0 to 100. When it is 0, it does not read.

When a number from "1001" to "1100" is set, the number of windows of the extended interface is handled as "1" to "100".

R register	Details
R425	The read windows 1 will be the consecutive area for the number of windows designated. The read windows start from the R register designated with R424.
R429	The read windows 2 will be the consecutive area for the number of windows designated. The read windows start from the R register designated with R428.
R433	The read windows 3 will be the consecutive area for the number of windows designated. The read windows start from the R register designated with R432.

■ PLC window Writing start R register 1 to 3 (R426, R430, R434)

It sets PLC window Writing start R register 1 to 3.

The setting range is 8300 to 9884, 18300 to 19884 and 28300 to 29884. (Even number only)

R register	Details
R426	The value is not checked when the value of R427 is "0".
R430	The value is not checked when the value of R431 is "0".
R434	The value is not checked when the value of R435 is "0".

■ PLC window Number of write windows 1 to 3 (R427, R431, R435)

It designates number of write windows 1 to 3.

The setting range is 0 to 100. When it is "0", it does not write.

When a number from "1001" to "1100" is set, the number of windows of the extended interface is handled as "1" to "100".

R register	Details
R427	The write windows 1 will be the consecutive area for the number of windows designated. The write windows start from the R register designated with R426.
R431	The write windows 2 will be the consecutive area for the number of windows designated. The write windows start from the R register designated with R430.
R435	The write windows 3 will be the consecutive area for the number of windows designated. The write windows start from the R register designated with R434.

5.2.2 Read Window Interface

■ Read control window

(Area where both PLC and NC set data)

R register	Item		Details
RA	Read data window	Control signal(*1)(*3)	Data will be read by turning bit0 ON. NC and PLC read asynchronously. When the reading is finished, the bit0 under "Status" of the reading results turns ON. When the bit0 under "Status" turns ON, turn OFF the bit0 of the control signal. In case of reading in constant, leave the bit0 ON.
RA+1		Section No.(*1)	Designate data type
RA+2		Section sub-ID No.(*1)	Designate part system No. (1 to maximum number of part system for each model)
RA+3		Sub-section No.(*1)	Designate data
RA+4		Data No.(*1)	Designate axis No. used in the part system and variable No., etc. (The axis No. is 1 to maximum number of axes for each model)
RA+5		Reading method(*1)	0: Read up to 4 consecutive data from the designated data No. 1: Read up to 4 consecutive data from the designated sub-section No. 2: Read up to 4 consecutive data from the designated section sub-ID No.
RA+6		Number to be read(*1)	Designate number to be read. Maximum number of data to be read is 4. If 5 or more is designated, the number of data is regarded as 4.
RA+7		Reading results(*2)	<Status> (bit0 to bit7) bit0: Read finished (It turns ON when reading is finished regardless of reading successfulness) bit1: Blank bit2 to 7: Read error The value and its meaning when the control signal is ON are as below: 0x01: Normally finished 0x41: Address illegal 0x45: Section No. illegal 0x49: Sub-section No. illegal 0x59: Not fit in the buffer 0x5D: Data type illegal 0x75: Unable to read 0x7D: Read write-only data 0x81: Axis designation illegal 0x85: Data No. illegal <Results> (bit8 to bitF) Number of data read

(*1) These items are set by PLC.

(*2) This item is set by NC.

(*3) Turn ON the control signal after setting Section No., Section sub-ID No., Sub-section No., Data No., Reading method, and Number to be read.

■ Read data window (Area where NC sets data)

R register	Item		Details
RA+8 to 9	Read data window	Read data 1	Store the read data.
RA+10 to 11		Read data 2	
RA+12 to 13		Read data 3	
RA+14 to 15		Read data 4	

5.2.3 Write Window Interface

■ Writing control window

(Area where both PLC and NC set data)

R register	Item		Details
RB	Writing control window	Control signal(*1)(*3)	Data will be written by turning bit0 ON. NC and PLC write asynchronously. When the writing is finished, the bit0 under "Status" of the writing result turns ON. When the bit0 under "Status" turns ON, turn OFF the bit0 of the control signal.
RB+1		Section No.(*1)	Designate data type
RB+2		Section sub-ID No.(*1)	Designate part system No. (1 to maximum number of part system for each model)
RB+3		Sub-section No.(*1)	Designate data
RB+4		Data No.(*1)	Designate axis No. used in the part system and variable No., etc. (The axis No. is 1 to maximum number of axes for each model)
RB+5		Writing method(*1)	0: Write up to 4 consecutive data from the designated data No. 1: Write up to 4 consecutive data from the designated sub-section No. 2: Write up to 4 consecutive data from the designated section sub-ID No.
RB+6		Number to be written(*1)	Designate number of data to be written. Maximum number of data to be written is 4. If 5 or more is designated, the number of data is regarded as 4.
RB+7		Writing results(*2)	<Status> (bit0 to bit7) bit0: Write finished (It turns ON when the writing is finished regardless of writing successfulness) bit1: Blank bit2 to 7: Write error The value and its meaning when the control signal is ON are as below: 0x01: Normally finished 0x41: Address illegal 0x45: Section No. illegal 0x49: Sub-section No. illegal 0x59: Not fit in the buffer 0x5D: Data type illegal 0x6D: Written in read-only data 0x79: Unable to write data 0x81: Axis designation illegal 0x85: Data No. illegal <Results> (bit8 to bitF) Number of data written

(*1) These items are set by PLC.

(*2) This item is set by NC.

(*3) Turn ON the control signal after setting Section No., Section sub-ID No., Sub-section No., Data No., Writing method, Number to be written, and write data 1 to 4 in the write data window.

■ Write data window (Area where PLC sets data)

R register	Item		Details
RB+8 to 9	Write data window	Write data 1	Store the write data.
RB+10 to 11		Write data 2	
RB+12 to 13		Write data 3	
RB+14 to 15		Write data 4	

5.2.4 Read Window Expanded Interface

■ Read control window (Area where both PLC and NC set data)

R register	Item		Details
RA	Read control window	Control signal(*1)(*3)	Data will be read by turning bit0 ON. NC and PLC read asynchronously. When the reading is finished, the bit0 under "Status" of the reading results turns ON. When the bit0 under "Status" turns ON, turn OFF the bit0 of the control signal. In case of reading in constant, leave the bit0 ON.
RA+1		Section No.(*1)	Designate data type
RA+2		Section sub-ID No.(*1)	Designate part system No. (1 to maximum number of part system for each model)
RA+3 to 4		Sub-section No.(*1)	Designate data
RA+5 to 6		Data No.(*1)	Designate axis No. used in the part system and variable No., etc. (The axis No. is 1 to maximum number of axes for each model)
RA+7		Reading method(*1)	0: Read up to 4 consecutive data from the designated data No. 1: Read up to 4 consecutive data from the designated sub-section No. 2: Read up to 4 consecutive data from the designated section sub-ID No.
RA+8		Number to be read(*1)	Designate number to be read. Maximum number of data to be read is 4. If 5 or more is designated, the number of data is regarded as 4.
RA+9		Reading results(*2)	<Status> (bit0 to bit7) bit0: Read finished (It turns ON when reading is finished regardless of reading successfulness) bit1: Blank bit2 to 7: Read error The value and its meaning when the control signal is ON are as below: 0x01: Normally finished 0x41: Address illegal 0x45: Section No. illegal 0x49: Sub-section No. illegal 0x59: Not fit in the buffer 0x5D: Data type illegal 0x75: Unable to read 0x7D: Read write-only data 0x81: Axis designation illegal 0x85: Data No. illegal <Results> (bit8 to bitF) Number of data read

(*1) These items are set by PLC.

(*2) This item is set by NC.

(*3) Turn ON the control signal after setting the data of RA+1 to RA+8.

■ Read data window (Area where NC sets data)

R register	Item		Details
RA+10 to 11	Read data window	Read data 1	Store the read data.
RA+12 to 13		Read data 2	
RA+14 to 15		Read data 3	
RA+16 to 17		Read data 4	

5.2.5 Write Window Expanded Interface

■ Writing control window (Area where both PLC and NC set data)

R register	Item		Details
RB	Writing control window	Control signal(*1)(*3)	Data will be written by turning bit0 ON. NC and PLC write asynchronously. When the writing is finished, The bit0 under "Status" of the writing result turns ON. When the bit0 under "Status" turns ON, turn OFF the bit0 of the control signal.
RB+1		Section No.(*1)	Designate data type
RB+2		Section sub-ID No.(*1)	Designate part system No. (1 to maximum number of part system for each model)
RB+3 to 4		Sub-section No.(*1)	Designate data
RB+5 to 6		Data No.(*1)	Designate axis No. used in the part system and variable No., etc. (The axis No. is 1 to maximum number of axes for each model)
RB+7		Writing method(*1)	0: Write up to 4 consecutive data from the designated data No. 1: Write up to 4 consecutive data from the designated sub-section No. 2: Write up to 4 consecutive data from the designated section sub-ID No.
RB+8		Number to be written(*1)	Designate number of data to be written. Maximum number of data to be written is 4. If 5 or more is designated, the number of data is regarded as 4.
RB+9		Writing results(*2)	<Status> (bit0 to bit7) bit0: Write finished (It turns ON when the writing is finished regardless of writing successfulness) bit1: Blank bit2 to 7: Write error The value and its meaning when the control signal is ON are as below: 0x01: Normally finished 0x41: Address illegal 0x45: Section No. illegal 0x49: Sub-section No. illegal 0x59: Not fit in the buffer 0x5D: Data type illegal 0x6D: Written in read-only data 0x79: Unable to write data 0x81: Axis designation illegal 0x85: Data No. illegal <Results> (bit8 to bitF) Number of data written

(*1) These items are set by PLC.

(*2) This item is set by NC.

(*3) Turn ON the control signal after setting the data of RB+1 to RB+8 and RB+10 to RB+17 in the write data window.

■ Write data window (Area where PLC sets data)

R register	Item		Details
RB+10 to 11	Write data window	Write data 1	Store the write data.
RB+12 to 13		Write data 2	
RB+14 to 15		Write data 3	
RB+16 to 17		Write data 4	

5.2.6 Interface for Consecutive Writes Detection Log

■ Detection log area (Area where NC sets data)

R register	Item	Details
R20058	Number of consecutive writes detected	The NC detects that consecutive write of parameters was performed through the write window. The number of detections is stored in R20058. This number is counted up only at the first detection after the NC power is turned ON. This number is retained even after the power is turned OFF.
R20059	Consecutive write window No.	The NC detects that consecutive write of parameters was performed through the write window. The head register number of write window at the detection is stored in R20059. Regardless of the number of consecutive write operations, the head R register number of the first detected window after turning ON the power.

5.3 Data Type

Data Type	Description	Unit (when the control unit and minimum setting unit are 1μm)
PLC setting unit	This is position data, and is input and output in the minimum setting unit which is specified by the machine parameter. This data is not changed by the initial inch parameter or constant inch input (M_inch) parameter. However, this data may change depending on the PLC setting unit.	μm
PLC setting unit/min.	This is speed data, and is input and output at the minimum setting unit/min. This data is not changed by the initial inch parameter or constant inch input (M_inch) parameter. However, this data may change depending on the PLC setting unit.	μm/min
Machine error compensation unit	The unit of this data is one half of the NC control unit. The control unit depends on the specification.	0.5 μm
Fixed point	This is real number type data in a unit other than the above or without a unit. The input/output specification of the decimal point data for the PLC window can be selected with "#1259 set31/bit2" (Disabling decimal point for PLC window). 0: Enable decimal point Fraction data is output as the fixed fraction information. (The numbers of digits in the integer and fraction parts are the same as of the on-screen specifications.) 1: Disable decimal point (cut off all digits after decimal point) Only the integer part is input/output.	Unit specific to data This data is not changed by the control unit or minimum setting unit.
Integer	This is data in a unit other than the above types or the data without a unit.	-
Character string	This is character string data. Up to two characters can be input and output.	-

5.4 Read/Write PLC Axis Data

The section No. to read/write PLC axis data differs from the section No. to read/write NC axis data. The section No. related to the axis data described in "6 Appx.2: List of PLC Window Data" is for the NC axis. Refer to the following section No. for PLC axis data.

Sub-section No. is same for both NC axis and PLC axis.

Data section	NC axis Section No.	PLC axis Section No.
Axis status	36	Not applicable(*1)
Counter	37	Not applicable(*2)
Servo monitor	59	60
Reference position return parameters	95	131
Servo parameters	96	132
Absolute position parameters	101	133
Base parameters	126	Same as the left
Axis parameters	127	130

(*1) Refer to the PLC axis control device for axis status.

(*2) Refer to the PLC axis control device for the counter (machine position and remaining distance). The information in servo monitor (Section No. 60) can be also referred there.

5.5 Precautions

Precautions

- (1) Set the read window start R register (R424, R428, R432) and the write window start R register (R426, R430, R434), securing enough space for the number of windows in between. When mistakenly set in the area, it does not read or write correctly. Up to 16 R registers are needed for one read window or write window. (18 R registers are necessary when the extended interface is used.)
(Example) In case the reading starts at R8300 and the number of read windows is set to 10, it uses 160 registers in total. Therefore, the writing start R register must be set in R8460 or later.
- (2) Area of read/write window must be within the user area.
When reading/writing is attempted exceeding the user area, reading/writing finishes on the right spot.
Set the reading/writing start R registers and the numbers of read/write windows properly to ensure that all the R registers to be used fit within the user area.
- (3) With this function, up to 100 windows can be read or written. Scan time in ladder may be extended, depending on the number of read/write windows.
- (4) When 4 consecutive data are first read and then 3 consecutive data are read using the same window, the forth data will not be set to "0", leaving the first data read.
- (5) When read control signal and write control signal are ON at the PLC stop, reading and writing are conducted because this function operates even while PLC is stopped.
- (6) Read/write window area 1, 2, or 3 can be specified in an arbitrary order, as long as they are specified within R register user area.
- (7) Using this function, do not create PLC in which parameters are written each time scan is performed. It might affect some performance. It might also affect the measurement tool such as NC Analyzer2. If parameters are written consecutively on the PLC, the operation alarm (M50 5003) occurs.
- (8) When the parameter "#1251 set23/bit5" is set to "1", the operation alarm (M50 5003) display can be released. However, use this as a temporary setting until the user PLC is corrected because the operation may become unstable.
- (9) If you create such a PLC program that write servo or spindle parameter per scan, the operation error (M01 0292) will occur upon the execution of the following functions:
 - Spindle/C axis changeover
 - Speed monitor mode signal ON
 - High-speed synchronous tapping
 - PLC axis indexing
 However, when the parameter "#1282 ext18/bit7" has been set to "1", the writing of the servo parameter or spindle parameter stops temporarily to execute the functions above so that this error does not occur.
- (10) The range of value to write/read is within the setting range of the R register.
However, the value to write/read for the PLC window may be limited according to the combination of the control units and the PLC setting units.
(Example) When the value of the data converted from the PLC setting units to the control unit exceeds the maximum command value of the NC.
- (11) When data is read from a diameter specification axis (an axis where "#1019 dia" is set to "1"), the data is converted to a radius value, and then output to the read window. When data is written to the diameter specification axis, data input in the write window is handled as a radius value, and the data is converted to a diameter value before written. To input/output the diameter value on the PLC window, set the parameter "#1752 cfgPR02/bit0" (PLC window diameter specification valid) to "1".

5.6 Usage Example

(Example 1) G54 workpiece coordinate offset of the 1st to 4th axes in the 1st part system is read with one-shot.

(1) Set the data to be read as follows:

G54
 X1 100.000
 Y1 150.000
 Z1 200.000
 V1 250.000
 B1 0.000

(2) Set the read window 1.

R0424	0x2328	The R register of the read window start is R9000.
R0425	0x0001	The number of the read window is 1. (*1)

(*1) For the data of the number of windows to be used, the continuous areas will be secured from the register designated with R0424.

For example, when 0x2328 (9000) is set in R0424 and 0x0003 is set in R0425, the area from R9000 to R9047 serves as read window area.

(3) Set the data in the read window.

R9001	0x0008	Section No.: 8
R9002	0x0001	Section sub-ID No.: 1
R9003	0x0036	Sub-section No.: 54
R9004	0x0001	Data No.: 1
R9005	0x0000	Reading method: 0
R9006	0x0004	Number to be read: 4

(4) Turn ON the control signal of the read control window.

R9000	0x0001
-------	--------

(5) Confirm the read result on the read control window.

R9007	0x0403	R9007	0x0403
-------	--------	-------	--------

For the upper 8 bits, the number of read is "4".

For the lower 8 bits, it will be as follows.

- ♦ bit0: Read is completed.
- ♦ bit2 to bit7: Read error contents

(6) After bit0 (the read result) is turned ON, the control signal that was turned ON in (4) is turned OFF.

(7) Confirm the read data on the read data window.

R9008	0x86A0	1st axis: 100000 = 100.000
R9009	0x0001	
R9010	0x49F0	2nd axis: 150000 = 150.000
R9011	0x0002	
R9012	0x0D40	3rd axis: 200000 = 200.000
R9013	0x0003	
R9014	0xD090	4th axis: 250000 = 250.000
R9015	0x0003	

5 Appx.1: PLC window

5.6 Usage Example

(Example 2) Write the data to the workpiece coordinate offset G54, G55 and G56.

(1) Set the offset amount of all the axes of the workpiece coordinate offset G54, G55 and G56 to "0.000".

(2) Set the write window 1.

R0426	0x2328	The start R register of the write window 1 is R9000.
R0427	0x0001	The number of the write window is 1.

Set the write window 2.

R0430	0x22C4	The start R register of the write window 2 is R8900.
R0431	0x0001	The number of the write window is 1.

Set the write window 3.

R0434	0x2260	The start R register of the write window 3 is R8800.
R0435	0x0001	The number of the write window is 1.

(3) Set the data in the write control window 1.

R9001	0x0008	Section No.: 8
R9002	0x0001	Section sub-ID No.: 1
R9003	0x0036	Sub-section No.: 54
R9004	0x0001	Data No.: 1
R9005	0x0000	Writing method: 0
R9006	0x0004	Number to be written: 4
R9007	0x0000	Writing results: 0
R9008	0xC350	1st axis: 50000 = 50.000
R9009	0x0000	
R9010	0x86A0	2nd axis: 100000 = 100.000
R9011	0x0001	
R9012	0x49F0	3rd axis: 150000 = 150.000
R9013	0x0002	
R9014	0x0D40	4th axis: 200000 = 200.000
R9015	0x0003	

(4) Set the data in the write control window 2.

R8901	0x0008	Section No.: 8
R8902	0x0001	Section sub-ID No.: 1
R8903	0x0037	Sub-section No.: 55
R8904	0x0001	Data No.: 1
R8905	0x0000	Writing method: 0
R8906	0x0004	Number to be written: 4
R8907	0x0000	Writing results: 0
R8908	0xEA60	1st axis: 60000 = 60.000
R8909	0x0000	
R8910	0xADB0	2nd axis: 110000 = 110.000
R8911	0x0001	
R8912	0x7100	3rd axis: 160000 = 160.000
R8913	0x0002	
R8914	0x3450	4th axis: 210000 = 210.000
R8915	0x0003	

5 Appx.1: PLC window

5.6 Usage Example

- (5) Set the data in the write control window 3.

R8801	0x0008	Section No.: 8
R8802	0x0001	Section sub-ID No.: 1
R8803	0x0038	Sub-section No.: 56
R8804	0x0001	Data No.: 1
R8805	0x0000	Writing method: 0
R8806	0x0004	Number to be written: 4
R8807	0x0000	Writing results: 0
R8808	0x1170	1st axis: 70000 = 70.000
R8809	0x0001	
R8810	0xD4C0	2nd axis: 120000 = 120.000
R8811	0x0001	
R8812	0x9810	3rd axis: 170000 = 170.000
R8813	0x0002	
R8814	0x5B60	4th axis: 220000 = 220.000
R8815	0x0003	

- (6) Turn ON the control signal in the write control window.

R8800: 0x0001, R8900: 0x0001, R9000: 0x0001

- (7) Confirm the writing results in the write control window.

R8807: 0x0403, R8907: 0x0403, R9907: 0x0403

- (8) Turn OFF the control signal which was turned ON in (6).

R8800: 0x0000, R8900: 0x0000, R9000: 0x0000

- (9) Confirm that the data were written.

Confirm that the workpiece coordinate offset screen is as follows:

G54		G55		G56	
X1	50.000	X1	60.000	X1	70.000
Y1	100.000	Y1	110.000	Y1	120.000
Z1	150.000	Z1	160.000	Z1	170.000
V1	200.000	V1	210.000	V1	220.000
B1	0.000	B1	0.000	B1	0.000

Appx.2: List of PLC Window Data

6 Appx.2: List of PLC Window Data

6.1 Section No. List

6.1 Section No. List

Section No.	Details	Write	Axis designation	Part system designation	Remarks
1	System information (For each part system)	Not possible	Invalid	Valid	
2	System information (Common to part systems)	Not possible	Invalid	Invalid	
3	File System information	Not possible	Invalid	Valid	
4	Common variable (For each part system #100-)	Possible	Invalid	Valid	
5	Common variable (Common to part systems #400-)	Possible	Invalid	Invalid	
6	Local variables	Not possible	Invalid	Valid	
8	Workpiece coordinate system offset (Workpiece coordinate)	Possible	Valid	Valid	
9	Workpiece coordinate system offset (Extension workpiece coordinate)	Possible	Valid	Valid	
10	Workpiece coordinate system offset (Local coordinate)	Possible	Valid	Valid	
11	Workpiece coordinate system offset (Other coordinate system)	Possible	Valid	Valid	
12	Tool offset for each part-system (Type1)	Possible	Invalid	Valid	
13	Tool offset for each part-system (Type2)	Possible	Invalid	Valid	
14	Tool offset for each part-system (Type3)	Possible	Invalid	Valid	
18	Life management data M system only, no group No. In the order of registration	Possible (partially not possible)	Invalid	Valid	
19	Life management information	Not possible	Invalid	Valid	
20	Tool registration	Possible (partially not possible)	Invalid	Valid (partially invalid)	
21	Spindle standby	Not possible (partially possible)	Invalid	Magazine No. (partially invalid)	
22	Tool measurement	Not possible	Invalid (partially valid)	Valid	
25	File information	Not possible	Invalid	Invalid	
33	Speed information	Not possible	Invalid	Valid	
34	Spindle information	Not possible	Valid	Invalid	
35	Operation status	Not possible	Invalid	Valid (partially invalid)	
36	Axis status	Not possible	Valid (partially invalid)	Valid	
37	Counter	Not possible	Valid (partially invalid)	Valid	
38	MSTB execution status	Possible (partially not possible)	Invalid	Invalid (partially valid)	
40	Cumulative time	Possible (partially not possible)	Invalid (partially valid)	Invalid (partially valid)	
41	G modal	Not possible	Invalid (partially valid)	Valid	
42	F modal	Not possible	Invalid	Valid	
43	MSTB modal	Not possible	Invalid	Invalid	
45	Program execution status	Not possible	Invalid	Valid	
46	Program tree	Not possible	Invalid	Valid	
47	Program tree for graphic check	Not possible	Invalid	Valid	
59	Servo monitor	Not possible	Valid	Invalid	
60	Servo monitor (PLC axis)	Not possible (partially possible)	Valid	Invalid	
62	Synchronous error monitor	Not possible	Invalid	Invalid	
63	Spindle monitor	Not possible (partially possible)	Valid	Invalid	

6 Appx.2: List of PLC Window Data

6.1 Section No. List

Section No.	Details	Write	Axis designation	Part system designation	Remarks
64	Power supply monitor	Not possible (partially possible)	Valid	Invalid	
65	Auxiliary axis drive unit monitor	Not possible	Valid	Invalid	
66	Hardware configuration	Not possible	Invalid	Invalid	
67	Software configuration	Not possible	Invalid	Invalid	
72	Auxiliary axis control	Possible (partially not possible)	Valid (partially invalid)	Invalid	
74	Sampling parameters	Possible (partially not possible)	Invalid	Invalid	
95	Reference position return parameters	Possible	Valid	Invalid	
96	Servo parameters	Possible	Valid	Invalid	
97	Spindle specification parameters	Possible	Valid	Invalid	
98	Spindle parameters	Possible	Valid	Invalid	
100	Auxiliary axis: axis parameters	Possible	Valid	Invalid	
101	Absolute position parameters	Possible	Valid	Invalid	
102	Machine error compensation parameters	Possible	Invalid	Invalid	
104	Position switch	Possible	Invalid	Valid (partially invalid)	
106	Macro list	Possible	Invalid	Invalid	
107	PLC constants	Possible	Invalid	Invalid	
108	PLC timer	Possible (partially not possible)	Invalid	Invalid	
109	PLC counter	Possible (partially not possible)	Invalid	Invalid	
110	PLC bit selection	Possible	Invalid	Invalid	
111	Open param 1	Possible	Invalid	Invalid	
112	Open param 2	Possible	Invalid	Invalid	
120	PLC SW	Possible (partially not possible)	Invalid	Invalid	
121	Operation parameters	Possible	Invalid	Invalid	
122	Input/Output parameters	Possible	Invalid	Invalid	
123	Computer link parameters	Possible	Invalid	Invalid	
124	Ethernet parameters	Possible	Invalid	Invalid	
125	Barrier data	Possible	Invalid	Invalid (partially valid)	
126	Base parameters	Possible (partially not possible)	Invalid	Invalid (partially valid)	
127	Axis parameters	Possible	Valid	Valid	
128	Rotary axis configuration parameters	Possible	Invalid	Valid	
140	Ladder I/F (common)	Not possible	Invalid	Valid (partially invalid)	
150	User open I/F parameter	Not possible (partially possible)	Invalid	Invalid	
151	User open I/F data	Not possible (partially possible)	Invalid	Invalid	

6.2 Sub-section No. List

Section No.: 1	System information (For each part system)				
-----------------------	--------------------------------------------------	--	--	--	--

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	1	Number of axes in part system (Cross configuration)	Integer	R
		2	Number of axes in part system (Base configuration)		
		100	Number of common variable (#100-) sets		

Section No.: 2	System information (Common to part systems)				
-----------------------	----------------------------------------------------	--	--	--	--

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1	Number of part systems	Integer	R
		2	Total number of NC axes (NC)		
		3	Total number of control axes (NC+PLC+SP)		
		4	Number of spindles		
		5	Number of PLC axes		
		6	Number of auxiliary axes		
		7	File system		
		8	Number of common variable (#500-) sets		
		9	Information on maximum number of registered machining programs		
		10	Number of power supply axes (SV+SP)		
		100	NC type		
		101	PLC device assignment type		

Section No.: 3	File System information				
-----------------------	--------------------------------	--	--	--	--

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	1	Tool offset type	Character string	R
		2	Number of tool offset sets	Integer	
		3	Number of workpiece offset sets		

Section No.: 4	Common variable (For each part system #100-)				
-----------------------	-----------------------------------------------------	--	--	--	--

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	700 + n	100 to 199 (n=100 to 199)	Integer	RW

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Section No.: 5 Common variable (Common to part systems #400-)

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	900 + n	Common variable Variable (Common for part systems #400 to #999) (n=400 to 999)	Integer	RW
		2000 + n	Common variable Comment (Common for part systems #500 to #519) (n=500 to 519)	Character string	
		10000 + n	Common variable Variable (Common for part systems #100100 to #100199) (n=100 to 199)	Integer	
		11000 + n	Common variable Variable (Common for part systems #200100 to #200199) (n=100 to 199)		
		12000 + n	Common variable Variable (Common for part systems #300100 to #300199) (n=100 to 199)		
		13000 + n	Common variable Variable (Common for part systems #400100 to #400199) (n=100 to 199)		
		14000 + n	Common variable Variable (Common for part systems #500100 to #500199) (n=100 to 199)		
		15000 + n	Common variable Variable (Common for part systems #600100 to #600199) (n=100 to 199)		
		16000 + n	Common variable Variable (Common for part systems #700100 to #700199) (n=100 to 199)		
		17000 + n	Common variable Variable (Common for part systems #800100 to #800199) (n=100 to 199)		
		20000 + n	Common variable Variable (Common to part systems #900000 to #907399) (n=0 to 7399)		

Section No.: 6 Local variables

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	1000 + n	Local variables (level 0) (n=1 to 33)	Integer	R
		1100 + n	Local variables (level 1) (n=1 to 33)		
		1200 + n	Local variables (level 2) (n=1 to 33)		
		1300 + n	Local variables (level 3) (n=1 to 33)		
		1400 + n	Local variables (level 4) (n=1 to 33)		
		2000	Local variables Blank variable		

Section No.: 8 Workpiece coordinate system offset (Workpiece coordinate)

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Axis No. in part system	n	Gn (n=54 to 59) Workpiece coordinate system offset	PLC setting unit	RW

Section No.: 9 Workpiece coordinate system offset (Extension workpiece coordinate)

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Axis No. in part system	n	G54.1Pn (n=1 to 96)	PLC setting unit	RW

Section No.: 10 Workpiece coordinate system offset (Local coordinate)

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Axis No. in part system	1	Local coordinate system offset (G54)	PLC setting unit	RW
		2	Local coordinate system offset (G55)		
		3	Local coordinate system offset (G56)		
		4	Local coordinate system offset (G57)		
		5	Local coordinate system offset (G58)		
		6	Local coordinate system offset (G59)		

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Section No.: 11	Workpiece coordinate system offset (Other coordinate system)
------------------------	---------------------------------------------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Axis No. in part system	1	External workpiece offset (EXT)	PLC setting unit	RW

Section No.: 12	Tool offset for each part-system (Type1)
------------------------	-------------------------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	n	Compensation data (n=1 to 999)	PLC setting unit	RW

Section No.: 13	Tool offset for each part-system (Type2)
------------------------	-------------------------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	n	Length dimension (n=1 to 999)	PLC setting unit	RW
		1000 + n	Radius dimension (n=1 to 999)		
		2000 + n	Length wear (n=1 to 999)		
		3000 + n	Radius wear (n=1 to 999)		

Section No.: 14	Tool offset for each part-system (Type3)
------------------------	-------------------------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	n	Nose point P (n=1 to 999)	Integer	RW
		1000 + n	Tool length X (n=1 to 999)	PLC setting unit	
		2000 + n	Tool length Y (n=1 to 999)		
		3000 + n	Tool length Z (n=1 to 999)		
		4000 + n	Nose point R (n=1 to 999)	Integer	
		5000 + n	Wear X (n=1 to 999)	PLC setting unit	
		6000 + n	Wear Y (n=1 to 999)		
		7000 + n	Wear Z (n=1 to 999)		
		8000 + n	Wear R (n=1 to 999)		

Section No.: 18	Life management data M system only, no group No. In the order of registration
------------------------	--------------------------------------------------------------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	1000 + n	Tool No. (n=1 to 1000)	Integer	RW
		2000 + n	Status (n=1 to 1000)		
		3000 + n	Method (n=1 to 1000)		
		4000 + n	Length compensation (n=1 to 1000)	PLC setting unit	
		5000 + n	Radius compensation (n=1 to 1000)		
		6000 + n	Usage (time, times, wear amount) (n=1 to 1000)	Integer	
		7000 + n	Life (time, times, wear amount) (n=1 to 1000)		
		8000 + n	Miscellaneous (n=1 to 1000)		
		9000 + n	Group No. (n=1 to 1000)		
		10003	Group ID of the designated group No.		
		11000 + n	Group No. of the designated group ID (n=1 to 1000)		R
		12000 + n	Head record ID of the designated group ID (n=1 to 1000)		
		13000 + n	Number of tools registered in the designated group ID (n=1 to 1000)		
		16000 + n	Tool information of the designated record (n=1 to 1000)		

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Section No.: 19 Life management information

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	1	Life management number of registered tool	Integer	R
		2	Life management number of registration groups		
		3	Life management data renewal flag		
		4	Life management maximum number of registered tools		
	Group No.	100	Life management next tool No. (for L system type II only)		

Section No.: 20 Tool registration

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	n	Tool registration data (pot No.) (n=1 to 360)	Integer	R
		1000 + n	Tool registration data (tool No.) (n=1 to 360)		RW
		2000 + n	Tool registration data (miscellaneous: D) (n=1 to 360)		

Section No.: 21 Spindle standby

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Magazine No.	Not used.	n	Spindle standby (tool No.) (n=0 to 4)	Integer	RW
		10 + n	Spindle standby (miscellaneous D) (n=0 to 4)		
Not used.		200	Number of spindle standby displays		
Magazine No.		1000	Tool life management data for spindle tool	PLC setting unit	R
		1001	Tool life management data for standby tool		

Section No.: 22 Tool measurement

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	1	TLM switch	Integer	R
	Axis No.	2	Final movement direction		
	Not used.	3	Final movement axis		
		4	Second skip contact		

Section No.: 25 File information

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1	Machining program number of registrations	Integer	R
		2	Machining program number of remains		
		3	Machining program number of memory characters		
		4	Machining program number of remaining characters		
		10	melCopyFile transferred data size		

Section No.: 33 Speed information

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	1	FC (resultant speed)	PLC setting unit/min.	R
		2	FA: F command feedrate		
		101	Feedrate display FC (resultant speed)		

Section No.: 34 Spindle information

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Axis No.	1	Spindle rotation speed (rev/min)	Integer	R

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Section No.: 35	Operation status
------------------------	-------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	1	Macro execution level	Integer	R
		2	In collation and stop		RW
		10	Operation status 1 (operation status)	Character string	R
		11	Operation status 2 (operation mode)		
		20	Automatic operation is starting	Integer	
		21	In automatic operation		
		22	In automatic operation stop		
		100	Data protect key 1		
		101	Data protect key 2		
		102	Data protect key 3		
		103	Data protect key (memory card)		
		104	Data protect key (DS)		
		200	External input signal 1		
		201	JOG mode (special) signal		
		202	NC status output signal 1		
		203	Alarm status signal		
		204	Operation (automatic) mode related signal		
		205	Operation (manual) mode related signal		
		206	Restart search status		
		207	Restart search type 1 valid		
		208	Extended operation search status		
		209	Current search line No. during search mode		
		210	In checking mode		
Not used.	220	Parameter flag to prompt a reboot	Integer	R	
System No.	221	PLC Run/Stop status			
	222	MDI setting status			

Section No.: 36	Axis status
------------------------	--------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Axis No.	1	Axis status (axis detachment)	Integer	R
		2	Axis status (servo OFF)		
		3	Axis status (1st ref)		
		4	Axis status (2nd ref)		
		5	Axis status (3rd ref)		
		6	Axis status (4th ref)		
		7	Axis status (mirror image)		
		8	Axis status (restart search RP)		
	Not used.	100	Axis status (servo OFF) all axes		
		101	Axis status (1st ref) all axes		
		102	Axis status (2nd ref) all axes		
		103	Axis status (3rd ref) all axes		
		104	Axis status (4th ref) all axes		
		105	Axis status (mirror image) all axes		
		106	Axis status (restart search RP) all axes		
		200	Program mirror axis (all axes)		

Section No.: 37	Counter
------------------------	----------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Axis No.	1	Workpiece coordinate position counter	PLC setting unit	R
		2	Machine position counter		
		3	Current position counter		
		4	Absolute position counter		
		5	Program position counter		
		6	Remain command		
		7	Skip coordinate counter (workpiece coordinate)		
		8	Manual interrupt amount 1(ABS Off)		
		9	Manual interrupt amount 2(ABS On)		
		10	Next command		
		11	Restart position counter (workpiece coordinate)		
		12	Restart remaining distance counter		
		13	Restart position counter (machine coordinate)		
		14	Program position counter 2		
		15	TLM position counter		
		16	TLM skip position counter		
		17	TLM position counter		
		18	Skip coordinate counter (machine coordinate)		
		19	Skip remaining distance counter		
	Not used.	20	Interpolation composite vector length	Interpolation unit	
	Axis No.	21	Current position B counter	PLC setting unit	
		22	Skip machine value		
		23	Skip coordinate position (skip coordinate counter)		
		24	Measurement position		
		32	Machine position on the orthogonal coordinate		
		33	Feedback position		

Section No.: 38	MSTB execution status
------------------------	------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1 + n	M Command/Manual numerical value command (M1 to M4) (n = 0 to 3)	Integer	RW
		101 + n	M Command/Manual numerical value command (S1 to S6) (n = 0 to 5)		
		201	M Command/Manual numerical value command (T1)		
		301 + n	M Command/Manual numerical value command (B1 to B4) (n = 0 to 3)		
System No.		401	Restart search T command history	Character string	R
Not used.		411 + n	Restart search S1 to S6 command history (n = 0 to 5)		
System No.		421	Restart search B command history		
		431	Restart search M command history		

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Section No.: 40		Cumulative time			
Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1	Power ON time	Character string	RW
		2	Automatic operation time		
		3	Cycle start time		
		4	External cumulative time 1		
		5	External cumulative time 2		
		6	Date		
		7	Time		
System No.		8	Cycle time		R

Section No.: 41	G modal
------------------------	----------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	n	G code (n=group 1 to 27)	Integer	R
		51	Tool compensation No. for shape (radius) compensation modal		
		52	Compensation amount for shape (radius) compensation modal	PLC setting unit	
		53	Wear amount for shape (radius) compensation modal		
		54	Tool wear No. for radius compensation modal	Integer	
		101	Tool compensation No. for length compensation modal		
	Axis No.	102	Axis name of length compensation modal	Character string	
	Not used.	103	Compensation amount of length compensation modal	PLC setting unit	
		104	Wear amount for length compensation modal		
		105	Axis information during length compensation (all axes)	Integer	
	Axis No.	106	Tool compensation No. for length compensation modal		
	Not used.	201	Scaling factor (G50P_)[Grp11]	Character string	
		202	Coordinate rotation angle (G68R_)[Grp16]		
		203	High-speed machining mode (G5P_)		
		204	gmov cutting/non-cutting command	Integer	
		205	Extended workpiece coordinate selection (G54.1P_)	Character string	
		206	Information during cutting	Integer	
		207	Scaling factor (G50P_)[Grp11] (Magic compatible)	Character string	
		208	Coordinate rotation angle (G68R_)[Grp16] (Magic compatible)		
		209	3-dimensional coordinate conversion status (to display workpiece coordinate selection G68)		

Section No.: 42	F modal
------------------------	----------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	1	Program command F modal (FA)	Integer	R
		2	Manual feedrate (FM)	PLC setting unit/min.	
		3	Synchronous feedrate (FS)		
		4	Thread cutting lead (FE)	Integer	
		5	Dwell remaining time		
		10 + n	Constant surface speed control (surface speed S) (n=1 to 6)		

Section No.: 43	MSTB modal
------------------------	-------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	n	S modal (S1 to S6) (n=1 to 6)	Integer	R
		100 + n	T modal (T1 to T2) (n=1 to 2)		
		200 + n	M modal (M1 to M4) (n=1 to 4)		
		300 + n	B modal (B1 to B4) (n=1 to 4)		

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Section No.: 45	Program execution status
-----------------	--------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	1	Nest level of the sub-program currently operating	Integer	R
		2	Invalid status: Single block/MST finish		
		3	Invalid status: Feed hold/Override/Exact		
		100	Main program path during execution	Character string	
		101	Main program during execution O No.	Integer	
		102	Main program during execution N No.		
		103	Main program during execution B No.		
		201	Sub program during execution O No.		
		202	Sub program during execution N No.		
		203	Sub program during execution B No.		
		300	Last operated program path	Character string	
		301	Last operated main program O No.	Integer	
		302	Last operated main program N No.		
		303	Last operated main program B No.		
		401	Last operated sub program O No.		
		402	Last operated sub program N No.		
		403	Last operated sub program B No.		

Section No.: 46	Program tree
-----------------	--------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	1	Main program during execution Device name	Character string	R
		2	Main program during execution O No.	Integer	
		3	Main program during execution N No.		
		4	Main program during execution B No.		
		100 + n	Sub 1 to 10 device name (n=1 to 10) during execution	Character string	
		200 + n	Sub program 1 to 10 during execution O No. (n=1 to 10)		
		300 + n	Sub program 1 to 10 during execution N No. (n=1 to 10)		
		400 + n	Sub program 1 to 10 during execution B No. (n=1 to 10)		
		500 + n	Sub program 1 to 10 during execution Number of repetitions (n=1 to 10)	Integer	
		1000	Program tree information (ONB, Path) during execution		

Section No.: 47	Program tree for graphic check
-----------------	--------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	1	Execution main O No. for checking	Integer	R
		2	Execution main N No. for checking		
		3	Execution main B No. for checking		

Section No.: 59		Servo monitor			
Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Axis No.	1	Gain	Integer	R
		2	Droop		
		3	Rotation speed	PLC setting unit/min.	
		4	Load current (%)	Integer	
		5	MAX current 1		
		6	MAX current 2		
		7	Overload		
		8	Regenerative load		
		9	Drive unit display	Character string	
		10 + n	Alarm 1 to 4 (n = 0 to 3)	Integer	
		14	Cycle counter		
		15	Grid spacing		
		16	Grid amount	PLC setting unit	
		17	Machine position		
		18	Motor side FB		
		19	Machine side FB		
		20	FB error		
		21	DFB compensation amount		
		22	Remain command		
		23	Current value (2)		
		24	Manual interrupt amount	Character string	
		25	Detection system	PLC setting unit	
		26	Power ON position		
		27	Power OFF position	Integer	
		28	Current position		
		29	R0 (multi-rotation counter at basic point setting)		
		30	P0 (position within 1 rotation at basic point setting)		
		31	E0 (absolute position error at basic point setting)		
		32	Rn (multi-rotation counter)		
		33	Pn (position within 1 rotation)		
		34	En (absolute position error at power OFF)		
		35	ABS0 (absolute position basic counter)	Character string	
		36	ABSn (absolute position counter)		
		37	MPOS (initial offset amount)		
		38	Drive unit type		
		39	Drive unit serial No.		
		40	S/W version		
		41	Control method		
		42	Motor side encoder		
		43	Machine side encoder		
		44	Motor type		
		45	Work time		
		46 + n	Alarm history 1 to 8 (time) (n = 0 to 7)		
		54 + n	Alarm history 1 to 8 (alarm No.) (n = 0 to 7)		
		62 + n	Maintenance history (MNT1 to 4) (n = 0 to 3)		
		66	/SYS	PLC setting unit	
		210	Machine side FB (for rotary axis)		

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Section No.: 60	Servo monitor (PLC axis)
------------------------	---------------------------------

Sub-section No. is equivalent to the section No. 59.

Section No.: 62	Synchronous error monitor
------------------------	----------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1 + n	Command error (1st to 3rd set) (n = 0 to 2)	PLC setting unit	R
		11 + n	FB error (1st to 3rd set) (n = 0 to 2)		
		21 + n	Machine position (1st to 3rd set) (n = 0 to 2)		

Section No.: 63	Spindle monitor
------------------------	------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W	
Not used.	Axis No.	1	Gain	Integer	R	
		2	Droop			
		3	Rotation speed			
		4	Load	Integer		
		5	Drive unit display	Character string		
		6 + n	Alarm 1 to 4 (n = 0 to 3)			
		10	Cycle counter			
		11	Control input 1L	Character string		
		12	Control input 1H			
		13	Control input 2L			
		14	Control input 2H			
		15	Control input 3L			
		16	Control input 3H			
		17	Control input 4L			
		18	Control input 4H			
		19	Control output 1L			
		20	Control output 1H			
		21	Control output 2L			
		22	Control output 2H			
		23	Control output 3L			
		24	Control output 3H			
		25	Control output 4L			
		26	Control output 4H			
		27	Drive unit type			
		28	Drive unit serial No.			
		29	S/W version			
		30	Work time			Integer
		31 + n	Alarm history 1 to 8 (time) (n = 0 to 7)			
		39 + n	Alarm history 1 to 8 (alarm No.) (n = 0 to 7)			
		47 + n	Maintenance history (MNT1 to 4) (n = 0 to 3)			
		51	/SYS			
		52 + n	Control input 1 to 4 (n = 0 to 3)			Integer
		56 + n	Control output 1 to 4 (n = 0 to 3)			
		60	Spindle angle			
		221	Spindle thermistor temperature	Integer		

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Section No.: 64	Power supply monitor
------------------------	-----------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Axis No.	1	Unit type	Character string	R
		2	Unit No.		
		3	S/W version		
		4	Work time		
		5 + n	Alarm history 1 to 8 (time) (n = 0 to 7)		
		13 + n	Alarm history 1 to 8 (alarm No.) (n = 0 to 7)		
		21 + n	Maintenance history (MNT1 to 4) (n = 0 to 3)		
		25	/SYS		
		26	Connection drive		W

Section No.: 65	Auxiliary axis drive unit monitor
------------------------	------------------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Axis No.	1	Droop	Integer	R
		2	Rotation speed	PLC setting unit/min.	
		3	Load current	Integer	
		4	MAX current 1		
		5	MAX current 2		
		6	Overload		
		7	Regenerative load		
		8	Current station No.	PLC setting unit	
		9	Current position		
		10	Target station No.	Integer	
		11	Command position	PLC setting unit	
		12	Auxiliary axis name	Character string	
		13	Position control gain 1	Integer	
		14	Speed control gain 1		
		15	Position control gain 2		
		16	Speed control gain 2		
		17	Speed integral compensation		
		18	Load inertia ratio		
		19	Unit type	Character string	
		20	S/W version		
		21	Motor type		
		22 + n	Alarm 1 to 4 (n = 0 to 3)		
		26	Unit serial No.		
		30 + n	Alarm history 1 to 6 (alarm No.) (n=1 to 6)		
		50 + n	Alarm history 1 to 6 (Detailed information of alarm) (n=1 to 6)		
		70 + n	Alarm history 1 to 6 (n=1 to 6)		

Section No.: 66	Hardware configuration
------------------------	-------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	4000 + (x)	RIO unit (x=1 to 256)	Character string	R
		100 + n	Terminal RIO unit 1 to 4		
		200	Control unit (NC card)		
		201	Extension unit		

Section No.: 67	Software configuration
------------------------	-------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1	NC system version	Character string	R
		2	PLC version		
		3	PLCe version (extension external alarm message)		
		4	3rd language version		
		5	4th language version		
	Axis No.	6	Servo drive unit version		
		7	Spindle drive unit version		
	Not used.	8	OS version		
		9	APLC version		
		20	NC system version (4-digit display)		

Section No.: 72	Auxiliary axis control
------------------------	-------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Axis No.	1	Operation adjustment mode	Integer	RW
		2	Absolute position set		R
		3	Position set method		
		4	Position set status		RW
		5	Operation mode		
		6	Operation parameter group		
		7	Scale		
		8	Operation status		
		9	Auxiliary axis basic point set		
	Not used.	1000	Auxiliary axis parameter SRAM backup		W

Section No.: 74	Sampling parameters
------------------------	----------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W	
Not used.	Not used.	1	Sampling trigger	Integer	RW	
		2	Sampling cycle			
		3	Number of sampling data			
		4	Sampling data storing address	Character string		
		5	Sampling data storing size	Integer		
		6 + n	Sampling address #1 to #8 (M625 conventional compatibility) (n = 0 to 7)	Character string	W	
		20 + n	Sampling address #1 to #8 (n = 0 to 7)			
		41 + n	Sampling address for AT #1 to #8 (n = 0 to 7)			
		50	Buffer designation (0: built-in memory, 1: cassette memory)	Integer	RW	
		51	Buffer capacity (1024 x (setting value +1) byte)			
		52	Starting condition			
		53	Processing format (0: 1shot, 1: repeat, 2: ring buffer)			
		54	Ending condition			
		55	Variables No. (0: #1299, other than 0: common variables)	Character string		
		56	PLC device			
		57	Condition address	Integer		
		58	Condition data			
		59	Condition data mask			
		70	Sampling status (for automatic tuning)	Integer	R	
		71	Sampling delay time (for automatic tuning)		RW	
		72	Cycle start request (for automatic tuning)		W	
		73	Cycle start restriction (for automatic tuning)		RW	
		74	Number of samplings (for automatic tuning)		R	
		75	OP check information (for automatic tuning)		RW	
		100	Number of sampling data		R	

Section No.: 95	Reference position return parameters
------------------------	---------------------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Axis No.	2025, 2026	Refer to the "Alarm/Parameter Manual" for axis specifications parameters.	PLC setting unit/min.	RW
		2027, 2028		PLC setting unit	
		2029 to 2033		Integer	
		2037 to 2040		PLC setting unit	

Section No.: 96	Servo parameters
------------------------	-------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Axis No.	1 to 65, 73, 81 to 256	SVn (n= Sub-section No.) Refer to the "Alarm/Parameter Manual" for servo parameters.	Integer	RW

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Section No.: 97	Spindle specification parameters
------------------------	-----------------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Axis No.	1 to 31, 35, 37 to 72, 101 to 118, 120 to 138	3000 + n equals to parameter No. ("n": Sub-section No.) Refer to the section of "Spindle parameter" in "Alarm/Parameter Manual" for details.	Integer	RW
					RW

Section No.: 98	Spindle parameters
------------------------	---------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Axis No.	1001 to 1003	SPn (n = Sub-section No.-1000) Refer to the section of "Spindle parameter" in "Alarm/Parameter Manual" for details.	Integer	RW
		1004		(Not used)	
		1005 to 1010		Integer	
		1011 to 1013		(Not used)	
		1014 to 1029		Integer	
		1030		(Not used)	
		1031 to 1050		Integer	
		1051,1052		(Not used)	
		1053		Integer	
		1054		(Not used)	
		1055 to 1057		Integer	
		1058 to 1060		(Not used)	
		1061		Integer	
		1062 to 1064		(Not used)	
		1065 to 1084		Integer	
		1085,1086		(Not used)	
		1087,1088		Integer	
		1089 to 1112		(Not used)	
		1113 to 1117		Integer	
		1118 to 1120		(Not used)	
		1121 to 1192		Integer	
		1193 to 1224		(Not used)	
		1125 to 1233		Integer	
		1234 to 1236		(Not used)	
		1237 to 1239		Integer	
		1240		(Not used)	

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Section No.: 101	Absolute position parameters
-------------------------	-------------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Axis No.	1, 2	2048 + n equals to parameter No. ("n": Sub-section No.) Refer to the "Alarm/Parameter Manual" for axis specifications parameters.	Integer	RW
		3		PLC setting unit	
		6		Integer	
		7		PLC setting unit/min.	
		8 to 10	2049 + n equals to parameter No. ("n": Sub-section No.) Refer to the "Alarm/Parameter Manual" for axis specifications parameters.	PLC setting unit	
		11		Integer	
		12, 13		PLC setting unit	
		14		Integer	

Section No.: 102	Machine error compensation parameters
-------------------------	----------------------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1	Compensation machine error compensation amount increment method	Integer	RW
		1 + n	1st to 28th axis basic axis (n=1 to 28)	Character string	
		29 + n	1st to 28th axis compensation axis (n=1 to 28)		
		57 + n	1st to 28th axis division point No. at reference position (n=1 to 28)	Integer	
		85 + n	1st to 28th axis division point No. at the most negative side (n=1 to 28)		
		113 + n	1st to 28th axis division point No. at the most positive side (n=1 to 28)		
		141 + n	1st to 28th axis compensation scale factor (n=1 to 28)		
		169 + n	1st to 28th axis division interval (n=1 to 28)	PLC setting unit	
		198 + n	Pitch error compensation amount (n=0 to 1023)	Integer	

Section No.: 104		Position switch			
Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1	PSW selection	Integer	RW
System No.		2	1st position switch axis name	Character string	
		3	1st position switch imaginary dog position 1	PLC setting unit	
		4	1st position switch imaginary dog position 2		
		5	1st position switch PSW check method changeover	Integer	
		6 + n	2nd Position switch axis name/Position switch imaginary dog position 1/Position switch imaginary dog position 2/Position switch PSW check method changeover		
		10 + n	3rd Position switch axis name/Position switch imaginary dog position 1/Position switch imaginary dog position 2/Position switch PSW check method changeover		
		14 + n	4th Position switch axis name/Position switch imaginary dog position 1/Position switch imaginary dog position 2/Position switch PSW check method changeover		
		18 + n	5th Position switch axis name/Position switch imaginary dog position 1/Position switch imaginary dog position 2/Position switch PSW check method changeover		
		22 + n	6th Position switch axis name/Position switch imaginary dog position 1/Position switch imaginary dog position 2/Position switch PSW check method changeover		
		26 + n	7th Position switch axis name/Position switch imaginary dog position 1/Position switch imaginary dog position 2/Position switch PSW check method changeover		
		30 + n	8th Position switch axis name/Position switch imaginary dog position 1/Position switch imaginary dog position 2/Position switch PSW check method changeover		
		100 + n	9th to 24th position switch axis name (n = 9 or later)	Character string	
		200 + n	9th to 24th position switch imaginary dog position 1 (n = 9 or later)	PLC setting unit	
		300 + n	9th to 24th position switch imaginary dog position 2 (n=9 or later)		
		400 + n	9th to 24th position switch PSW check method changeover (n = 9 or later)	Integer	

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Section No.: 106	Macro list
------------------	------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1	M[01] Code	Integer	RW
		2	M[01] Type		
		3	M[01] Program No.		
		4 + n	M[02] Code/Type/Program No. (n = 0 to 2)		
		7 + n	M[03] Code/Type/Program No. (n = 0 to 2)		
		10 + n	M[04] Code/Type/Program No. (n = 0 to 2)		
		13 + n	M[05] Code/Type/Program No. (n = 0 to 2)		
		16 + n	M[06] Code/Type/Program No. (n = 0 to 2)		
		19 + n	M[07] Code/Type/Program No. (n = 0 to 2)		
		22 + n	M[08] Code/Type/Program No. (n = 0 to 2)		
		25 + n	M[09] Code/Type/Program No. (n = 0 to 2)		
		28 + n	M[10] Code/Type/Program No. (n = 0 to 2)		
		31	M2mac Type		
		32	M2mac Program No.		
		33	G[01] Code		
		34	G[01] Type		
		35	G[01] Program No.		
		36 + n	G[02] Code/Type/Program No. (n = 0 to 2)		
		39 + n	G[03] Code/Type/Program No. (n = 0 to 2)		
		42 + n	G[04] Code/Type/Program No. (n = 0 to 2)		
		45 + n	G[05] Code/Type/Program No. (n = 0 to 2)		
		48 + n	G[06] Code/Type/Program No. (n = 0 to 2)		
		51 + n	G[07] Code/Type/Program No. (n = 0 to 2)		
		54 + n	G[08] Code/Type/Program No. (n = 0 to 2)		
		57 + n	G[09] Code/Type/Program No. (n = 0 to 2)		
		60 + n	G[10] Code/Type/Program No. (n = 0 to 2)		
		63	Smac Type		
		64	Smac Program No.		
		65	Tmac Type		
		66	Tmac Program No.		
System No.	100 + n	ASCII[]ASCII code macro valid (n=1 to 2)		Character string	
	200 + n	ASCII[]ASCII code (n=1 to 2)			
	300 + n	ASCII[] call type (0: M98, 1: G65, 2: G66, 3: G66.1) (n=1 to 2)		Integer	
	400 + n	ASCII[] program No. (n=1 to 2)			
	500 + n	ASCII[] common variable No. (100 to 149) (n=1 to 2)			

Section No.: 107	PLC constants
------------------	---------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1 + n	PLC constants (n=0 to 95) Refer to the "Alarm/Parameter Manual" for PLC constants.	Integer	RW

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Section No.: 108 PLC timer

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1 + n	10ms timer <10ms> (n=0 to 703)	Integer	RW
		1000 + n	100ms timer <100ms> (n=0 to 703)		
		2000 + n	100ms integral timer <100msINC> (n=0 to 63)		
		10000	Number of PLC timers (variable)		
		10001	Number of PLC integral timers (variable)		R

Section No.: 109 PLC counter

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1 + n	Counter (n=0 to 255)	Integer	RW
		10000	Number of PLC counters (variable)		R

Section No.: 110 PLC bit selection

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1 + n	PLC bit selection (n=0 to 195)	Integer	RW

Section No.: 111 Open param 1

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	n	Open parameter value 1 (long) (n=1 to 896)	Integer	RW

Section No.: 112 Open param 2

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	n	Open parameter value 2 (double) (n=1 to 96)	Integer eight digits and four decimal places	R

Section No.: 120 PLC Switch

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	0 + n	PLC switch X(IN) (n=1 to 64)	Integer	RW
		100 + n	PLC switch Y(OUT) (n=1 to 64)		R
		200	PLC switch X(IN) 1 to 16		RW
		201	PLC switch X(IN) 17 to 32		
		202	PLC switch X(IN) 33 to 48		
		203	PLC switch X(IN) 49 to 64		
		210	PLC switch Y(OUT) 1 to 16		R
		211	PLC switch Y(OUT) 17 to 32		
		212	PLC switch Y(OUT) 33 to 48		
		213	PLC switch Y(OUT) 49 to 64		

Section No.: 121 Operation parameters

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	8900 + n	Counter type 1 to 6 (n=1 to 6)	Integer	RW
		8910	Edit undo valid		
		8920	Solid drawing tool compensation selection		

Section No.: 122	Input/Output parameters
-------------------------	--------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1 to 32	9000 + n equals to parameter No. ("n": Sub-section No.) Refer to the "Alarm/Parameter Manual" for user parameters.	Integer	RW
		33 to 40		Character string	
		41 to 58		Integer	
		59 to 66		Character string	
		67 to 84		Integer	
		85 to 92		Character string	
		93 to 110		Integer	
		111 to 118		Character string	
		119 to 136		Integer	
		137 to 144		Character string	

Section No.: 123	Computer link parameters
-------------------------	---------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1 to 24	"9600 + n" equals to parameter No. ("n": Sub-section No.) Refer to the "Alarm/Parameter Manual" for user parameters.	Integer	RW

Section No.: 124	Ethernet parameters
-------------------------	----------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1	Service start	Integer	RW
		2	IP address	Character string	
		3	Subnet mask		
		4	Gateway		
		5	Port No.	Integer	
		6	Ethernet parameter before conversion (Host IP address)	Character string	
		7	Host port No.	Integer	
		50	Automatic IP address setting		
		51	IP address (PC)	Character string	
		52	Subnet mask (PC)		
		53	Gateway (PC)		
		54	Timeout	Integer	
		55	Host No. to use		
		100 + n	User name (Host A to D) (n = 0 to 3)	Character string	
		200 + n	Password (Host A to D) (n = 0 to 3)		
		300 + n	Directory (Host A to D) (n = 0 to 3)		
		400 + n	Host address (Host A to D) (n = 0 to 3)		
		500 + n	Host type (Host 1 to 4) (n = 0 to 3)	Integer	
		600 + n	Host Word position: File (Host 1 to 4) (n = 0 to 3)		
		700 + n	Host Word position: Size (Host 1 to 4) (n = 0 to 3)		
		800 + n	Host Word position: <DIR> (Host 1 to 4) (n = 0 to 3)		
		900 + n	Host Word position: Comment (Host 1 to 4) (n = 0 to 3)		
		1000 + n	Host Word count: Comment (Host 1 to 4) (n = 0 to 3)		
		1100 + n	Host Character remain (Host 1 to 4) (n = 0 to 3)		

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Section No.: 125		Barrier			
Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1	P0 X	PLC setting unit	RW
		2	P1 X		
		3	P1 Z		
		4	P2 X		
		5	P2 Z		
		6	P3 X		
		7	P3 Z		
		8	P4 X		
		9	P4 Z		
		10	P5 X		
		11	P5 Z		
		12	P6 X		
		13	P6 Z		
System No.		20	Barrier valid	Integer	
		21	P7 X	PLC setting unit	
		22	P8 X		
		23	P8 Z		
		24	P9 X		
		25	P10 X		
		26	P10 Z		
		27	Barrier type (left)	Integer	
		28	Barrier type (right)	Integer	
		29	Delivery axis name	Character string	
		30	Tailstock angle (left)	Integer	
		31	Tailstock angle (right)		

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Section No.: 126		Base parameters				
Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W	
System No.	Not used.	1	System validation setup	Integer	RW	
Not used.		2	System validation setup (PLC)			
System No.		3	Number of axes			
Not used.		4	Number of axes (PLC)			
System No.		5	Input setting unit			
Not used.		6	PLC unit			
System No.		7	Control unit			
Not used.		8	Control unit (PLC)			
System No.		10	Initial plane selection	Character string		
		11	Base axis I			
		12	Base axis J			
		13	Base axis K			
		14	Flat axis I			
		15	Flat axis J			
System No.		16	Flat axis K	Integer		
		20	Command type			
		Not used.	21			Ladder selection
			22			Number of spindles
			23			Constant input (inch)
			24			Initial state (inch)
25			PLC axis command (inch)			
26			Select language displayed			
System No.		27	MR-J2-CT Connections			
		73	Initial absolute setting			
		74	Initial synchronous feed			
Not used.		75	Initial G00			
		76	ABS/INC address (for L system only)			
		77	Incremental command for diameter specification axis			
		78	Decimal point type 2			
		79	Validate F1 digit			
		80	Specify boring axis (for M system only)			
System No.		81	Give priority to G code parameter			
		82	Geometric			
		84	Arc error			
Not used.		85	G00 dry run			
		86	G00 non-interpolation			
		87	Constant surface speed control by rapid traverse feed command			
		88	Disable G30 soft limit			
		91	Ignore middle point			
		92	Replace tools for additional axis			
		93	Synchronization between part systems method			
		94	Select life count for single block (for L system only)			
		95	TF output			
		96	Tool life management type			
		97	Tool wear compensation number 1-digit command			
		98	Tool length offset number			
		99	Cancel tool compensation amount			

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.		100	Tool compensation	Integer	RW
		101	Tool compensation method		
		102	Manual tool length measuring system (for L system only)		
		103	Validate life management		
		104	Tool command method 2		
		105	Tool selection method 2		
		106	Life management (for L system only)		
		107	Split life management display screen (for L system only)		
System No.		108	Life management re-count M code (for L system only)		
		109	Validate substitute M code		
		110	M96 substitute M code		
Not used.	Not used.	111	M97 substitute M code		
		112	Validate status trigger method		
		113	Validate interrupt method type 2		
		114	Macro argument initialization		
		115	Waiting for retract		
		116	Invalidate soft limit (manual operation)		
		117	H_sens		
		118	Select how to set up the length of tools on cutter tables (opposed tables) (for L system only)		
		119	Select the mirror image of each facing turret with T command (for L system only)		
		120	Change macro variable		
		121	Edit lock C		
		122	Program display lock C		
		123	Origin set prohibit		
		124	Fix tool compensation No.		
		125	Actual feedrate display		
		126	Playback G90		
		127	DPRINT alignment		
		128	Clear variables by resetting		
		129	Clear variables by power-ON		
		130	Display selected tool number		
		132	brightness		
		135	Unit name		
		140 + n	M code number (n = 0 to 3)		
		144	MDI setup lock		
		145	Manual ABS parameter		
		146	Spindle rotation speed clamp function		
		147	Minimum spindle rotation speed clamp type		
		148	Initial high precision		
		149	Arc deceleration speed change		
System No.		151	Reset initial		
Not used.		153	Hole bottom deceleration check		
		159	Fixed cycle editing		
		161	Simulation test		
System No.	Not used.	162	Part system name		
		163	Second miscellaneous code		
		164	Tapping retract override		
		165	Tap return override		
		166	G04 skip condition		

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	167	G31 skip speed	PLC setting unit/min.	RW
		168	G31.1 skip condition	Integer	
		169	G31.1 skip speed	PLC setting unit/min.	
		170	G31.2 skip condition	Integer	
		171	G31.2 skip speed	PLC setting unit/min.	
		172	G31.3 skip condition	Integer	
		173	G31.3 skip speed	PLC setting unit/min.	
		176	Constant surface speed axis	Integer	
		177	Thread cutting speed	PLC setting unit/min.	
		178	M code for clamp	Integer	
		179	Dwelling time after outputting M code for unclamp		
		180 + n	F1 digit feedrate F1 to F5 (n = 0 to 4)	PLC setting unit/min.	
		185	Validate inclined axis control (for L system only)	Integer	
		186	Inclination angle (for L system only)		
		187	Compensation at reference position return (for L system only)		
		188	Deceleration check method 1/ Validate in-position check		
		189	Time constant 0 for handle feed		
		190	Macro call for M command		
		191	Macro call for S command		
		192	Macro call for T command		
		193	Macro call with 2nd miscellaneous code		
		194	Select initial spindle control		
		195	Validate acceleration and deceleration with constant-gradient G0		
		196	Validate acceleration and deceleration with constant-gradient G1		
		197	Distance between facing turrets (for L system only)	PLC setting unit	
		198	Select turrets as facing turrets with T command (for L system only)	Integer	
		199	Select turrets as facing turrets with T command (for L system only)		
		200	Acceleration and deceleration before G0 interpolation	Integer	
		201	Maximum speed		
		202	Time constant	Integer	
		203	Arc radius error compensation factor	PLC setting unit/min.	
		204	Arc deceleration speed		
		205	Modal G code reset	Integer	
		208	Side 1 of inclination angle (for L system only)	PLC setting unit	
		209	Side 2 of inclination angle (for L system only)		
		210	Side 3 of inclination angle (for L system only)	PLC setting unit/min.	
		211	External deceleration		
Not used.	300 + n	aux01 to 12 (n = 0 to 11)	Integer		
	350 + n	set01 to 12 (n = 0 to 11)			
	400 + n	ext01 to 36 (n = 0 to 35)			
	500	Near reference position check method			
	501	Automatic return by program restart			
	502	No. of #100 address part system common variables			
	503	No. of #500 address part system common variables			
	506	Deceleration check specification type			
	509	Switch command format			
	510	Minimum value for synchronization M code			
	511	Maximum value for synchronization M code			

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	512	Tool life management standard number	Integer	RW
		513	Synchronous tap hole bottom wait time		
		514	Synchronous tap in-position check width (tap axis)		
		524	Chopping compensation value fixing method		
		527	Tool change method specification		
		528	Tool measurement standard positions election		
System No.		600	PLC unit		
		602	Machine error compensation unit		
System No.		1501 to 1503, 1505	Refer to the "Alarm/Parameter Manual" for base system parameter.		
		1506		PLC setting unit/min.	
		1507, 1510 to 1513		Integer	
		1514, 1515		Character string	
		1516 to 1522		Integer	
		1523		PLC setting unit/min.	
		1524		Integer	
		1533		Character string	
		1534		Integer	
		1535		PLC setting unit	
		1537 to 1544		Character string	
		1561 to 1563		Integer	
		1564		PLC setting unit/min.	
		1568 to 1574, 1590 to 1593			
		1901 to 1911		Integer	
Not used.					
System No.	8001 to 8003	Refer to the "Alarm/Parameter Manual" for user parameters.			
	8004		PLC setting unit/min.		
	8005, 8006		PLC setting unit		
	8007, 8008		Integer		
	8009 to 8013		PLC setting unit		
	8014, 8015		Integer		
	8016 to 8018		PLC setting unit		
	8019 to 8023, 8025, 8026		Integer		
	8027 to 8030		PLC setting unit		
	8033 to 8036		Integer		
	8037, 8041 to 8043		PLC setting unit		
	8044		Integer		
Not used.					

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W	
System No.	Not used.	8051 to 8054	Refer to the "Alarm/Parameter Manual" for user parameters.	PLC setting unit	RW	
		8055		Integer		
		8056, 8057		PLC setting unit		
		8058		Integer		
		8059		PLC setting unit		
		8071, 8072		Integer		
		8075		PLC setting unit		
Not used.		8078		Integer		
System No.		8083				
		8084		PLC setting unit		
		8085, 8086		PLC setting unit/min.		
		8090		Integer		
		8091		PLC setting unit		
		8092		Integer		
		8093		PLC setting unit		
System No.		8051 to 8054		PLC setting unit		
Not used.		8101 to 8103, 8105 to 8114, 8116		Integer		
System No.		8621, 8622		Character string		
		8623 to 8626		PLC setting unit		
		8627		Integer		
		8701 to 8705		PLC setting unit		
		8706		PLC setting unit/min.		
		8707, 8708		PLC setting unit		
		8709, 8710				
		8711, 8712				
Not used.		10001		G code format		Integer
		10002		M2 Label O		
		10003		M2 Macro converter valid		
	10004	Coordinate rotation angle				
System No.	10005	Coordinate rotation center (Horizontal)				
	10006	Coordinate rotation center (Vertical)				
Not used.	10007	Machine manufacturer macro password No.				
	10008	Parameter for M3/L3				
	10009	operat1				
	10010	operat2				
	10011	operat3				
	10012	operat5				
	10013	operat7				
	10035	masmac5				

Section No.: 127		Axis parameters			
Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Axis No.	1	Axis name	Character string	RW
		2	Displayed axis name		
		3	Increment command axis name		
		4	Command unit		
		5	Output in inch		
		6	Rotary axis		
		7	Motor CCW		
		8	Diameter specification axis		
		9	Spindle interpolation		
		10	Drive unit I/F channel No.		
		12	Command address during cross machining		
		13	Incremental command address during cross machining	Character string	
		101	Manual ABS updating	Integer	
		102	Tool compensation function		
		103	Manual dog-type		
		104	Error correction		
		105	JOG response type		
		106	JOG start (+) Device selection	Character string	
		107	JOG start (-) Device selection		
		108	Slave axis No.	Integer	
		109	No_dsp		
		110	Axis name		
		111	Axis release		
		112	+/- JOG start signal device name		
		1010	Axis designated for chopping		

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Axis No.	2001, 2002	Refer to the "Alarm/Parameter Manual" for axis specifications parameters.	PLC setting unit/min.	RW
		2003 to 2010		Integer	
		2011, 2012		Interpolation unit	
		2013 to 2016		PLC setting unit	
		2017 to 2019		Integer	
		2020		PLC setting unit	
		2021		PLC setting unit/min.	
		2022		Integer	
		2023		PLC setting unit/min.	
		2024, 2061, 2062		PLC setting unit	
		2063, 2068 to 2071		Integer	
		2072		PLC setting unit	
		2073 to 2080		Integer	
		2081		PLC setting unit/min.	
		2082, 2084, 2087		Integer	
		2088, 2089		Character string	
		2090, 2091		PLC setting unit/min.	
		2092 to 2095		Integer	
		2096		PLC setting unit/min.	
		2097, 2098		PLC setting unit	
		2102, 2103, 2106		Integer	
		2109, 2110		PLC setting unit/min.	
		2111 to 2115, 2121 to 2129		Integer	
		2130 to 2133		PLC setting unit	
		2134 to 2137		Integer	
		2138		PLC setting unit	
		8201 to 8203		Integer	
		8204 to 8206		PLC setting unit	
		8207, 8208		Integer	
		8209		PLC setting unit	
		8210, 8211		Integer	
		10000		Character string	
		10001, 10002		PLC setting unit	
		10003, 10004			
		10101	Rapid traverse rate (for integer setting)	Integer	
		10102	Cutting feed clamp speed(for integer setting)		

Section No.: 128	Rotary axis configuration parameters
-------------------------	---------------------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
System No.	Not used.	7900 to 7902	Refer to the "Alarm/Parameter Manual" for rotary axis configuration parameters.	Character string	RW
		7903 to 7907, 7920		Integer	
		7922		Character string	
		7923		Integer	
		7924 to 7926		PLC setting unit	
		7930		Integer	
		7932		Character string	
		7933		Integer	
		7934 to 7936		PLC setting unit	
		7940		Integer	
		7942		Character string	
		7943		Integer	
		7944 to 7946		PLC setting unit	
		7950		Integer	
		7952		Character string	
		7953		Integer	
		7954 to 7956		PLC setting unit	

Section No.: 140	Ladder I/F(common)
-------------------------	---------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	n + 100	Spindle standby tool comment (n=0 to 4)	Character string	R
		n + 200	PLC switch message (n=1 to 64)		

Section No.: 150	User open I/F parameter
-------------------------	--------------------------------

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	1	SRAM open usable amount	Integer	R
		2	SRAM open spare amount	Integer	R
		101	Device open parameter clear	Character string	W
		102	SRAM open parameter clear	Character string	W
		(x)	Device open parameter device allocation (x=40001 to 40100)	Character string	RW
		(10000 + (x))	Device open parameter data type (x=40001 to 40100)	Character string	RW
		(20000 + (x))	Device open parameter number of data (x=40001 to 40100)	Integer	RW
		(30000 + (x))	Device open parameter display format (x=40001 to 40100)	Character string	RW
		(x)	SRAM open parameter data type (x=41001 to 41100)	Character string	RW
		(10000 + (x))	SRAM open parameter number of data (x=41001 to 41100)	Integer	RW
		(20000 + (x))	SRAM open parameter display format (x=41001 to 41100)	Character string	RW

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Section No.: 151		User open I/F data			
Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	(x)	#41001 SRAM open data (x=1 to 9999999)	Integer	RW
		(10000000 + (x))	#41002 SRAM open data (x=1 to 9999999)		
		(20000000 + (x))	#41003 SRAM open data (x=1 to 9999999)		
		(30000000 + (x))	#41004 SRAM open data (x=1 to 9999999)		
		(40000000 + (x))	#41005 SRAM open data (x=1 to 9999999)		
		(50000000 + (x))	#41006 SRAM open data (x=1 to 9999999)		
		(60000000 + (x))	#41007 SRAM open data (x=1 to 9999999)		
		(70000000 + (x))	#41008 SRAM open data (x=1 to 9999999)		
		(80000000 + (x))	#41009 SRAM open data (x=1 to 9999999)		
		(90000000 + (x))	#41010 SRAM open data (x=1 to 9999999)		
		(100000000 + (x))	#41011 SRAM open data (x=1 to 9999999)		
		(110000000 + (x))	#41012 SRAM open data (x=1 to 9999999)		
		(120000000 + (x))	#41013 SRAM open data (x=1 to 9999999)		
		(130000000 + (x))	#41014 SRAM open data (x=1 to 9999999)		
		(140000000 + (x))	#41015 SRAM open data (x=1 to 9999999)		
		(150000000 + (x))	#41016 SRAM open data (x=1 to 9999999)		
		(160000000 + (x))	#41017 SRAM open data (x=1 to 9999999)		
		(170000000 + (x))	#41018 SRAM open data (x=1 to 9999999)		
		(180000000 + (x))	#41019 SRAM open data (x=1 to 9999999)		
		(190000000 + (x))	#41020 SRAM open data (x=1 to 9999999)		
		(200000000 + (x))	#41021 SRAM open data (x=1 to 9999999)		
		(210000000 + (x))	#41022 SRAM open data (x=1 to 9999999)		
		(220000000 + (x))	#41023 SRAM open data (x=1 to 9999999)		
		(230000000 + (x))	#41024 SRAM open data (x=1 to 9999999)		
		(240000000 + (x))	#41025 SRAM open data (x=1 to 9999999)		
		(250000000 + (x))	#41026 SRAM open data (x=1 to 9999999)		
		(260000000 + (x))	#41027 SRAM open data (x=1 to 9999999)		
		(270000000 + (x))	#41028 SRAM open data (x=1 to 9999999)		
		(280000000 + (x))	#41029 SRAM open data (x=1 to 9999999)		
		(290000000 + (x))	#41030 SRAM open data (x=1 to 9999999)		
		(300000000 + (x))	#41031 SRAM open data (x=1 to 9999999)		
		(310000000 + (x))	#41032 SRAM open data (x=1 to 9999999)		
		(320000000 + (x))	#41033 SRAM open data (x=1 to 9999999)		
		(330000000 + (x))	#41034 SRAM open data (x=1 to 9999999)		
		(340000000 + (x))	#41035 SRAM open data (x=1 to 9999999)		
		(350000000 + (x))	#41036 SRAM open data (x=1 to 9999999)		
		(360000000 + (x))	#41037 SRAM open data (x=1 to 9999999)		
		(370000000 + (x))	#41038 SRAM open data (x=1 to 9999999)		
		(380000000 + (x))	#41039 SRAM open data (x=1 to 9999999)		
		(390000000 + (x))	#41040 SRAM open data (x=1 to 9999999)		

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	(400000000 + (x))	#41041 SRAM open data (x=1-9999999)	Integer	RW
		(410000000 + (x))	#41042 SRAM open data (x=1-9999999)		
		(420000000 + (x))	#41043 SRAM open data (x=1-9999999)		
		(430000000 + (x))	#41044 SRAM open data (x=1-9999999)		
		(440000000 + (x))	#41045 SRAM open data (x=1-9999999)		
		(450000000 + (x))	#41046 SRAM open data (x=1-9999999)		
		(460000000 + (x))	#41047 SRAM open data (x=1-9999999)		
		(470000000 + (x))	#41048 SRAM open data (x=1-9999999)		
		(480000000 + (x))	#41049 SRAM open data (x=1-9999999)		
		(490000000 + (x))	#41050 SRAM open data (x=1-9999999)		
		(500000000 + (x))	#41051 SRAM open data (x=1-9999999)		
		(510000000 + (x))	#41052 SRAM open data (x=1-9999999)		
		(520000000 + (x))	#41053 SRAM open data (x=1-9999999)		
		(530000000 + (x))	#41054 SRAM open data (x=1-9999999)		
		(540000000 + (x))	#41055 SRAM open data (x=1-9999999)		
		(550000000 + (x))	#41056 SRAM open data (x=1-9999999)		
		(560000000 + (x))	#41057 SRAM open data (x=1-9999999)		
		(570000000 + (x))	#41058 SRAM open data (x=1-9999999)		
		(580000000 + (x))	#41059 SRAM open data (x=1-9999999)		
		(590000000 + (x))	#41060 SRAM open data (x=1-9999999)		
		(600000000 + (x))	#41061 SRAM open data (x=1-9999999)		
		(610000000 + (x))	#41062 SRAM open data (x=1-9999999)		
		(620000000 + (x))	#41063 SRAM open data (x=1-9999999)		
		(630000000 + (x))	#41064 SRAM open data (x=1-9999999)		
		(640000000 + (x))	#41065 SRAM open data (x=1-9999999)		
		(650000000 + (x))	#41066 SRAM open data (x=1-9999999)		
		(660000000 + (x))	#41067 SRAM open data (x=1-9999999)		
		(670000000 + (x))	#41068 SRAM open data (x=1-9999999)		
		(680000000 + (x))	#41069 SRAM open data (x=1-9999999)		
		(690000000 + (x))	#41070 SRAM open data (x=1-9999999)		
		(700000000 + (x))	#41071 SRAM open data (x=1-9999999)		
		(710000000 + (x))	#41072 SRAM open data (x=1-9999999)		
		(720000000 + (x))	#41073 SRAM open data (x=1-9999999)		
		(730000000 + (x))	#41074 SRAM open data (x=1-9999999)		
		(740000000 + (x))	#41075 SRAM open data (x=1-9999999)		
		(750000000 + (x))	#41076 SRAM open data (x=1-9999999)		
		(760000000 + (x))	#41077 SRAM open data (x=1-9999999)		
		(770000000 + (x))	#41078 SRAM open data (x=1-9999999)		
		(780000000 + (x))	#41079 SRAM open data (x=1-9999999)		
		(790000000 + (x))	#41080 SRAM open data (x=1-9999999)		

6 Appx.2: List of PLC Window Data

6.2 Sub-section No. List

Sub-ID	Significance of data No.	Sub-section No.	Details of Sub-section No.	Data type	R/W
Not used.	Not used.	(800000000 + (x))	#41081 SRAM open data (x=1-9999999)	Integer	RW
		(810000000 + (x))	#41082 SRAM open data (x=1-9999999)		
		(820000000 + (x))	#41083 SRAM open data (x=1-9999999)		
		(830000000 + (x))	#41084 SRAM open data (x=1-9999999)		
		(840000000 + (x))	#41085 SRAM open data (x=1-9999999)		
		(850000000 + (x))	#41086 SRAM open data (x=1-9999999)		
		(860000000 + (x))	#41087 SRAM open data (x=1-9999999)		
		(870000000 + (x))	#41088 SRAM open data (x=1-9999999)		
		(880000000 + (x))	#41089 SRAM open data (x=1-9999999)		
		(890000000 + (x))	#41090 SRAM open data (x=1-9999999)		
		(900000000 + (x))	#41091 SRAM open data (x=1-9999999)		
		(910000000 + (x))	#41092 SRAM open data (x=1-9999999)		
		(920000000 + (x))	#41093 SRAM open data (x=1-9999999)		
		(930000000 + (x))	#41094 SRAM open data (x=1-9999999)		
		(940000000 + (x))	#41095 SRAM open data (x=1-9999999)		
		(950000000 + (x))	#41096 SRAM open data (x=1-9999999)		
		(960000000 + (x))	#41097 SRAM open data (x=1-9999999)		
		(970000000 + (x))	#41098 SRAM open data (x=1-9999999)		
		(980000000 + (x))	#41099 SRAM open data (x=1-9999999)		
		(990000000 + (x))	#41100 SRAM open data (x=1-9999999)		

Appx.3: List of Option Status Exported to PLC

R register No.	Bit location	Additional specification	R register No.	Bit location	Additional specification
R8260	0	Max. number of axes (32 axes)	R8262	0	
	1	Max. number of NC axes in a part system (12 axes)		1	
	2			2	
	3			3	
	4	Max. number of part systems (8 part systems)		4	
	5			5	
	6			6	
	7			7	
	8	Least command increment 0.01 μm (10 nm)		8	Feed per revolution (synchronous feed)
	9	Least command increment 0.001 μm (1 nm)		9	Inverse time feed
	A			A	Manual speed command
	B			B	G00 feedrate designation ("F" command)
	C			C	
	D			D	
	E			E	
	F			F	
R8261	0	Program format switch	R8263	0	Rapid traverse constant-gradient multi-step acceleration/deceleration
	1			1	
	2			2	
	3			3	
	4			4	Thread cutting (lead/thread number designation)
	5	Unidirectional positioning		5	Pecking tapping cycle/Deep-hole tapping cycle
	6	Spiral/Conical interpolation		6	
	7	Cylindrical interpolation		7	Circular thread cutting
	8	Polar coordinate interpolation/Milling interpolation		8	
	9	Hypothetical axis interpolation		9	High-speed synchronous tapping (OMR-DD)
	A	Involute interpolation		A	
	B	Exponential interpolation		B	Thread recutting
	C	Spline interpolation (G05.1Q2/G61.2)		C	Thread cutting override
	D	NURBS interpolation		D	Variable feed thread cutting
	E	3-dimensional circular interpolation		E	
	F	Spline interpolation 2 (G61.4)		F	

R register No.	Bit location	Additional specification	R register No.	Bit location	Additional specification
R8264	0		R8266	0	
	1			1	Control unit-side SD card I/F [up to 32 GB]
	2			2	Computer link B
	3			3	Handy terminal connection
	4	Manual feedrate B surface speed control		4	
	5			5	
	6			6	
	7			7	
	8	Memory capacity (2560m) (1000 programs)		8	Spindle-mode servo motor control
	9	Memory capacity (5120m) (1000 programs)		9	Spindle-mode rotary axis control
	A			A	C axis control during Spindle synchronization
	B			B	Spindle synchronization I/Spindle synchronization II
	C			C	Guide bushing spindle synchronization
	D			D	Tool spindle synchronization IA/IB (spindle-spindle, polygon)
	E			E	Tool spindle synchronization IC (spindle-NC axis, polygon)
	F			F	Tool spindle synchronization II (hobbing)
R8265	0	Special program editing display for synchronization between part systems	R8267	0	Spindle oscillation
	1	Finish shape view programming		1	Spindle superimposition control
	2			2	Spindle speed fluctuation detection
	3			3	
	4			4	
	5			5	
	6			6	
	7			7	
	8	Machining program input mistake check warning		8	
	9	Remote desktop connection		9	
	A			A	
	B			B	
	C			C	Tool position compensation (G43.7)/ Tool nose radius compensation (G40/ 41/42)
	D			D	
	E			E	
	F			F	

R register No.	Bit location	Additional specification	R register No.	Bit location	Additional specification
R8268	0	Number of tool offset sets (128 sets)	R8270	0	Tool retract and return
	1	Number of tool offset sets (256 sets)		1	
	2	Number of tool offset sets (400 sets)		2	
	3	Number of tool offset sets (999 sets)		3	
	4			4	
	5			5	
	6			6	
	7			7	
	8	Extended workpiece coordinate system selection (48 sets) G54.1P1 to P48		8	Figure rotation
	9	Extended workpiece coordinate system selection (96 sets) G54.1P1 to P96		9	Scaling
	A	Extended workpiece coordinate system selection (300 sets) G54.1P1 to P300		A	
	B			B	
	C			C	User macro
	D			D	
	E			E	
	F			F	
R8269	0	Workpiece coordinate system preset (G92.1)	R8271	0	Variable command (700 sets)
	1	Workpiece position offset for rotary axis		1	Variable command (8000 sets)
	2			2	
	3			3	
	4			4	
	5			5	
	6			6	
	7			7	
	8	Graphic check rotary axis drawing/ Graphic trace rotary axis drawing		8	Special fixed cycle
	9	Manual arbitrary reverse run (program check operation)		9	Fixed cycle for turning machining
	A	High-speed simple program check		A	Compound type fixed cycle for turning machining
	B			B	Compound type fixed cycle for turning machining (type II)
	C			C	Small diameter deep hole drilling cycle
	D			D	
	E			E	
	F			F	

R register No.	Bit location	Additional specification	R register No.	Bit location	Additional specification
R8272	0		R8274	0	Control axis synchronization between part systems
	1			1	Two-part system simultaneous thread cutting
	2			2	Single block between part systems
	3			3	Dwell/Miscellaneous function time override
	4	Coordinate rotation by program		4	Synchronization between part systems OFF
	5	Coordinate rotation by parameter		5	Sub part system control I
	6	3-dimensional coordinate conversion		6	Sub part system control II
	7			7	
	8			8	
	9			9	
	A			A	
	B			B	
	C	Corner chamfering/Corner R		C	
	D	Linear angle command		D	
	E	Geometric command		E	
	F	Polar coordinate command		F	
R8273	0		R8275	0	Rapid traverse block overlap (G0/G28/G30)
	1			1	
	2			2	
	3			3	
	4	Chopping		4	Automatic error detection
	5			5	
	6			6	
	7			7	
	8			8	High-speed machining mode I (G05P1)
	9			9	High-speed machining mode II (G05P2)
	A			A	
	B			B	
	C	Mixed control (cross axis control)		C	
	D	Arbitrary axis exchange control		D	High-accuracy control (G61.1/G08)
	E	Control axis superimposition		E	Multi-part system simultaneous high-accuracy control
	F	Arbitrary axis superimposition control		F	SSS control

R register No.	Bit location	Additional specification	R register No.	Bit location	Additional specification
R8276	0	Variable-acceleration pre-interpolation acceleration/deceleration	R8278	0	Position-dependent gradually increasing-type backlash compensation
	1	High-accuracy acceleration/deceleration time constant extension		1	Bidirectional pitch error compensation
	2	Axis-specific acceleration tolerance control		2	
	3			3	Spatial error compensation
	4			4	
	5	High-speed high-accuracy control I (G05.1Q1)		5	
	6	High-speed high-accuracy control II (G05P10000)		6	
	7	High-speed high-accuracy control III (G05P20000)		7	
	8			8	
	9			9	
	A			A	
	B	Smooth fairing		B	
	C	Direct command mode		C	
	D			D	OMR II (backlash with filter)
	E			E	
	F			F	OMR-FF
R8277	0		R8279	0	
	1			1	
	2			2	
	3			3	
	4	Playback		4	
	5	Interactive cycle insertion		5	
	6	Simple programming (NAVI MILL/LATHE)		6	
	7			7	
	8			8	
	9			9	
	A			A	
	B			B	
	C	External machine coordinate system compensation		C	
	D	Circular radius error compensation		D	
	E	Ball screw thermal expansion compensation		E	PLC skip
	F	Rotation center error compensation		F	Speed change skip

R register No.	Bit location	Additional specification	R register No.	Bit location	Additional specification
R8280	0	Torque limitation skip	R8282	0	Chuck/Tailstock barrier check
	1	Workpiece coordinate offset measurement		1	Interlock
	2			2	Interference check III
	3			3	3D machine interference check
	4			4	Data protection by user's level
	5			5	
	6			6	Machine group-based alarm stop
	7			7	
	8			8	
	9			9	
	A			A	
	B			B	
	C	Tool life management IB		C	
	D	Tool life management IIB		D	
	E			E	
	F			F	
R8281	0	Number of tool life management sets (128 sets)	R8283	0	Email notification to operator
	1	Number of tool life management sets (256 sets)		1	Safety observation/Smart Safety observation
	2	Number of tool life management sets (400 sets)		2	
	3	Number of tool life management sets (999 sets)		3	
	4			4	Pallet program registration
	5			5	
	6			6	
	7			7	
	8	Load monitoring I		8	Number of PLC projects: 3
	9			9	Number of PLC projects: 6
	A			A	
	B			B	
	C	Stored stroke limit IB		C	Memory switch (PLC switch) 64 points
	D	Stored stroke limit IIB		D	Memory switch (PLC switch) 96 points
	E	Stored stroke limit IC		E	
	F	Stroke check before travel		F	

R register No.	Bit location	Additional specification	R register No.	Bit location	Additional specification
R8284	0	Large PLC capacity: 256000 steps	R8286	0	
	1	Large PLC capacity: 512000 steps		1	
	2			2	
	3			3	
	4	Synchronous control		4	Circular feed in manual mode
	5	Inclined axis control		5	
	6			6	NC axis/PLC axis switchover
	7	Tool length compensation along the tool axis		7	
	8	Tool handle feed & interruption		8	
	9	Tool center point control/Tool center coordinate display		9	
	A	Inclined surface machining command		A	
	B	Simple inclined surface machining command		B	
	C	3-dimensional tool radius compensation		C	
	D	3-dimensional tool radius compensation (tool's vertical-direction compensation)		D	
	E	Workpiece installation error compensation		E	
	F	3-dimensional manual feed		F	
R8285	0	R-Navi	R8287	0	APLC release
	1			1	MES interface library
	2	Real-time tuning 1 (speed gain)		2	
	3	Real-time tuning 2 (rapid traverse time constant)		3	
	4			4	System lock
	5			5	
	6			6	
	7			7	
	8			8	
	9			9	
	A			A	
	B			B	
	C			C	
	D			D	
	E			E	
	F			F	

R register No.	Bit location	Additional specification
R8288	0	
	1	
	2	
	3	
	4	
	5	
	6	
	7	
	8	
	9	
	A	
	B	
	C	
	D	
	E	
	F	
R8289	0	
	1	
	2	
	3	
	4	
	5	
	6	
	7	
	8	
	9	
	A	
	B	
	C	
	D	
	E	
	F	

Index

Numbers

\$1 to \$8 display	183
1st cutting feed override	565
1st handle axis selection code m	444
1st handle valid	445
1st handle/incremental feed magnification	568
1st reference position reached n-th axis	188
24 hours continuous operation	181
2nd cutting feed override valid	451
2nd cutting feed override	566
2nd handle axis selection code m	445
2nd handle feed magnification	569
2nd handle valid	445
2nd M function data 1 to 4	305
2nd M function strobe 1 to 4	232
2nd reference position reached n-th axis	189
2nd reference position return interlock	474
3D coordinate conversion:	
Manual feed coordinates conversion	487
3D coordinate conversion:	
Manual feed valid	250
3D machine interference check:	
Enabled shape group No. 1 to 4	595
3D machine interference check:	
Requested shape group No. 1 to 4	325
3D manual feed (1st handle):	
Feature coordinate system selected	252
3D manual feed (1st handle):	
Feature coordinate system selection	488
3D manual feed (1st handle):	
Table coordinate system selected	252
3D manual feed (1st handle):	
Table coordinate system selection	488
3D manual feed (1st handle):	
Tool axis coordinate system selected	252
3D manual feed (1st handle):	
Tool axis coordinate system selection	488
3D manual feed (2nd handle):	
Feature coordinate system selected	253
3D manual feed (2nd handle):	
Feature coordinate system selection	488
3D manual feed (2nd handle):	
Table coordinate system selected	253
3D manual feed (2nd handle):	
Table coordinate system selection	488
3D manual feed (2nd handle):	
Tool axis coordinate system selected	253
3D manual feed (2nd handle):	
Tool axis coordinate system selection	488
3D manual feed (3rd handle):	
Feature coordinate system selected	253
3D manual feed (3rd handle):	
Feature coordinate system selection	489
3D manual feed (3rd handle):	
Table coordinate system selected	253
3D manual feed (3rd handle):	
Table coordinate system selection	489
3D manual feed (3rd handle):	
Tool axis coordinate system selected	253
3D manual feed (3rd handle):	
Tool axis coordinate system selection	489
3D manual feed (JOG, INC):	
Feature coordinate system selected	252

3D manual feed (JOG, INC):	
Feature coordinate system selection	488
3D manual feed (JOG, INC):	
Table coordinate system selected	252
3D manual feed (JOG, INC):	
Table coordinate system selection	488
3D manual feed (JOG, INC):	
Tool axis coordinate system selected	252
3D manual feed (JOG, INC):	
Tool axis coordinate system selection	488
3rd handle axis selection code m	445
3rd handle feed magnification	569
3rd handle valid	445
3rd reference position reached n-th axis	189
4th reference position reached n-th axis	189

A

Absolute position data loss	339
Absolute position power shutoff movement	
over	339
Absolute position warning	241
Actual cutting mode (thread, tap)	
in manual arbitrary reverse run	382
Alarm 1	339
Alarm 2	339
Alarm 4	339
Alarm message I/F	
1 to 4	574
All axes in-position	211
All axes smoothing zero	211
Analog input m	288
Analog output m	534
APLC version	540
Arbitrary axis superimposition complete	
n-th axis	190
Arbitrary point feed command valid	607
ATC control parameter	612
Automatic error detection	480
Automatic initialization mode	416
Automatic interlock- n-th axis	392
Automatic interlock+ n-th axis	392
Automatic machine lock n-th axis	394
Automatic operation "pause" command	
(Feed hold)	418
Automatic operation "start" command	
(Cycle start)	417
Automatic operation mode	610
Automatic power OFF request	380
Automatic restart	425
Automatic set position reached	344
Axis selection n-th axis	186
Axis selection output	342

B

Ball screw thermal displacement compensation:	
Compensation amount n-th axis	293
Ball screw thermal displacement compensation:	
Max. compensation amount n-th axis	558
Ball screw thermal displacement compensation:	
Offset amount n-th axis	558
Ball screw thermal displacement compensation:	
Part-system, axis No. n-th axis	558
Barrier check invalid	479
Barrier valid (left)	477
Barrier valid (right)	477
Base PLC mounting check	348
Basic point initialization setting mode	611

Basic point setting.....	611
Basic position -> upper dead point path flag.....	233
Battery alarm	177
Battery drop cause.....	290
Battery warning.....	176
BiSS encoder I/F: Communication status	701
BiSS encoder I/F: Encoder 1 data output 1 to 4 ...	701
Block start interlock.....	419
Board reset	175
Bottom dead point -> upper dead point path flag.....	233
Buzzer sound control: Buzzer ON	528

C

C axis selection.....	575
Chamfering	424
Chopping compensation update prevented	233
Chopping compensation update prevention request	476
Chopping control data address.....	576
Chopping error No.	306
Chopping override	567
Chopping parameter valid.....	441
Chopping	440
Chuck close confirmation.....	273
Chuck close	525
Circular feed in manual mode Current position H	319
Circular feed in manual mode Current position V.....	319
Circular feed in manual mode gradient/arc center H data	595
Circular feed in manual mode gradient/arc center V data	595
Circular feed in manual mode Operation mode data.....	592
Circular feed in manual mode Reference point H data	593
Circular feed in manual mode Reference point V data.....	593
Circular feed in manual mode travel range H (-) data	594
Circular feed in manual mode travel range H (+) data	594
Circular feed in manual mode travel range V (-) data	594
Circular feed in manual mode travel range V (+) data.....	594
Circular feed in manual mode valid	457
Clamp command n-th axis	197
Clamp completion n-th axis	406
CLC: Maximum load	364
CLC: Minimum load	364
CLC: Spindle selection	633
Clock data Date/Hour	289
Clock data Minute/Second	289
Clock data Year/Month	289
CNC completion standby status	307
CNC software version code	289
Collecting diagnosis data stop	373
Collecting diagnosis data.....	179
Connection status of each channel RIO1,2	347
Connection status of each channel RIO3	348
Constant torque control: Axis under constant torque/proportional torque stopper control	318

Constant torque control: Constant torque droop cancel axis status	318
Constant torque control: Constant torque droop cancel request axis.....	588
Constant torque control: Constant torque/proportional torque stopper control request axis	588
Contact or shutoff test	379
Control axis detachment 2 n-th axis	402
Control axis detachment n-th axis	389
Control unit temperature.....	291
Controller ready completion	205
Controller ready completion	343
Coordinate rotation by parameter: Coordinate switch for manual feed	457
Coordinate rotation by parameter: Manual feed coordinate system	227
CRT changeover completion.....	372
Current detection.....	260
Current limit changeover n-th axis.....	399
Current limit changeover	582
Current limit mode 1	474
Current limit mode 2	474
Current limit reached n-th axis	192
Current spatial error compensation value (1st rotary axis)	360
Current spatial error compensation value (2nd rotary axis).....	360
Current spatial error compensation value (orthogonal coordinate height axis).....	360
Current spatial error compensation value (orthogonal coordinate horizontal axis).....	360
Current spatial error compensation value (orthogonal coordinate vertical axis).....	360
Cutting block start interlock	420
Cutting feed override code m	450
Cutting feedrate override method selection.....	451

D

Data I/O register for MES interface library	
(Alarm number 1)	687
(Alarm number 2)	687
(Alarm number 3)	687
(Alarm number 4)	687
(Arbitrary user area C1).....	690
(Arbitrary user area L1 to L10)	691
(Arbitrary user area S1 to S20)	691
(B number at alarm)	688
(B number at machining start).....	684
(Common user area C1).....	682
(Common user area L1 to L10)	683
(Cycle time)	683
(G code modal).....	688
(Line number).....	682
(Machine type).....	682
(Machining end time).....	683
(Machining start time).....	683
(N number at alarm)	688
(N number at machining start).....	684
(NC unit number).....	682
(Number of machined workpieces).....	685
(Operator ID)	682
(Power consumption amount)	684
(Power regeneration amount).....	684
(Program number at machining start).....	683

(Serial number)	681
(Spindle 1 load value)	688
(Spindle 1 maximum load)	684
(Spindle 2 load value)	689
(Spindle 2 maximum load)	684
(Subprogram number at alarm).....	688
(Time of alarm occurrence).....	687
(Time of power ON)	687
(Tool length offset 1 to 5)	685
(Tool length offset)	689
(Tool length wear amount 1 to 5).....	686
(Tool length wear amount)	689
(Tool life 1 to 5)	686
(Tool life)	690
(Tool number 1 to 5)	685
(Tool number)	689
(Tool offset number 1 to 5).....	685
(Tool offset number).....	689
(Tool radius offset 1 to 5)	685
(Tool radius offset)	689
(Tool radius wear amount 1 to 5).....	686
(Tool radius wear amount)	690
(User arbitrary C1 at machining end).....	686
(User arbitrary L1 to L10 at machining end) ...	686
(User area C1 at alarm)	690
(User area L1 to L10 at alarm).....	690
(Program number at alarm).....	687
Data protection key (DS).....	528
Data protection key (memory card).....	528
Data protection key 1	366
Data protection key 2	367
Data protection key 3	367
Detailed screen No.....	537
Diagnosis data output:	
Accumulated travel distance (motor)	695
Automatic log clear time.....	694
Battery exchange (drive).....	693
Battery exchange	693
Motor insulation degradation detection	
request.....	631
Motor insulation resistance (motor).....	694
Motor insulation resistance (motor).....	694
Select axis for servomotor insulation	
degradation detection (PLC axis)	629
Select axis for servomotor insulation	
degradation detection	632
Select spindle for motor insulation	
degradation detection	630
Servomotor insulation degradation	
detection in progress (PLC axis).....	359
Servomotor insulation degradation	
detection in progress	360
Spindle motor insulation degradation	
detection in progress	359
DIO card information	293
Direct screen selection	551
Display changeover \$1 to \$8.....	375
Display lock	435
Display tool selection parameter	618
Displayed screen No.	535
Door interlock spindle speed clamp	479
Door open enable.....	247
Door open I	384
Door open II	478
Door open signal input (spindle speed monitor)....	478
Droop cancel request n-th axis	400
Dry run invalid	480

Dry run	420
E	
E number of smart safety observation error	
(system common).....	675
Each axis in-position n-th axis	198
Each axis manual feedrate B n-th axis	596
Each axis manual feedrate B valid	455
Each axis reference position selection	576
EcoMonitorLight connection:	
Acquired data	351
Completion bit.....	350
Completion status	351
Read start bit	627
Register address	627
Size of data to read	627
Station #1 to #16 consumed power	349
Station #1 to #16 maximum number of successive	
reception errors	350
Station #1 to #16 maximum number of successive	
transmission errors	350
Station #1 to #16 number of reception errors ..	350
Station #1 to #16 number of	
transmission errors	350
Station #1 to #16 regenerated power	349
Station No.....	627
Edit/search window displayed.....	257
Edit/Search	494
Emergency stop cause	292
Encoder 1 arbitrary pulse 1.....	561
Encoder 1 arbitrary pulse 2.....	561
Encoder 1 arbitrary pulse selection	383
Encoder 1 arbitrary pulse valid	384
Encoder 2 arbitrary pulse 1.....	561
Encoder 2 arbitrary pulse 2.....	561
Encoder 2 arbitrary pulse selection	383
Encoder 2 arbitrary pulse valid	384
Encoder selection	575
Error detection	421
Error temporary cancel	524
Exclude spindle.....	526
Ext. machine coordinate system offset data	
illegal n-th axis.....	197
Ext. machine coordinate system offset data	
n-th axis.....	596
External brake SBT incomplete (control axis).....	660
External brake SBT start (control axis).....	640
External deceleration- n-th axis	391
External deceleration+ n-th axis	391
External encoder 1:	
Position output clear request.....	529
External encoder 1: Position output.....	697
External search block No.	571
External search device No.	570
External search finished	212
External search program No.	570
External search sequence No.....	570
External search status	301
External search strobe	426
External search:	
Program return complete status	301
External search: Program return completed	247
External search: Program return.....	464
F	
F1-digit commanded	216
F1-digit No. code (1, 2, 4, 8)	220

F1-digit speed change valid	435
Feed axis selection- n-th axis	396
Feed axis selection+ n-th axis	395
Feedback machine position n-th axis	325
Feedrate least increment code 1, 2	454

G

G/B spindle synchronization valid	387
G/B spindle synchronization	
Average value of the relative position	
error during the steady state	563
Keep position	
error compensation amount signal	389
Maximum range	
of the relative position error during the	
steady state	563
Maximum range	
of the relative position error	562
Maximum value	
of the relative position error	
during the steady state	563
Maximum value	
of the relative position error	563
Phase alignment complete	184
Phase alignment	387
Phase memory	388
Phase shift amount	564
Position control synchronizing	184
Position error compensating	185
Position error compensation amount	564
Position error compensation scale, and	
the number of times of compensations	556
Position error compensation	388
Temporary cancel	388
G/B spindle synchronizing mode	184
Gear shift completion	495
Graphic check (check method II) in progress	183
Group in tool life management	307

H

Handle feed operation mode	610
Handle feed: 1st handle pulse counter	297
Handle feed: 2nd handle pulse counter	297
Handle feed: 3rd handle pulse counter	297
Handle mode	412
Handle polarity	572
Handle pulse encoder communication connector	
priority	368
Handle/Incremental feed magnification code m....	458
Handle/incremental feed magnification method	
selection	459
Handy terminal Cause of communication error	546
Handy terminal Data area top address	544
Handy terminal Data valid number of registers	546
Handy terminal key 1 to 45	287
High-speed simple program check mode ON	177
High-speed simple program check mode	378
High-speed simple program check:	
Coordinate position check ON	178
High-speed simple program check:	
Enable coordinate position check	386
High-speed simple program check:	
Time measurement output	553
High-speed simple program check:	
Time reduction coefficient	554
Hob axis delay excess	278
Hob machining: Alarm retract inhibit	477

Hob machining:	
Retract amount selection n-th axis	407
Hob machining: Retract complete	242
Hob machining: Retract request	477
Hob machining: Retracting	241
Holding power of spindle increased	278

I

Illegal axis selected	220
Image input I/F:	
Behavior at operation	550
Display range (height)	548
Display range (width)	548
Image display position (H)	548
Image display position (V)	548
IPC screen horizontal inversion	529
IPC screen transfer range (height)	549
IPC screen transfer range (width)	549
IPC screen transfer start position (H)	549
IPC screen transfer start position (V)	549
IPC screen vertical inversion	529
Screen selection	529
In "reset"	208
In "reset"	343
In 3-dimensional coordinate conversion	244
In automatic initial set mode	203
In automatic operation "pause"	208
In automatic operation "run"	206
In automatic operation "start"	207
In automatic operation mode	338
In axis minus motion	342
In axis motion (-) n-th axis	187
In axis motion (+) n-th axis	187
In axis name switch	241
In axis plus motion	342
In barrier valid (left)	246
In barrier valid (right)	246
In basic point initialization setting mode	339
In chopping mode	233
In chopping start	233
In circular feed in manual mode	226
In constant surface speed	215
In current limit n-th axis	192
In cutting feed	214
In display lock	216
In handle feed operation mode	343
In handle mode	201
In high-speed machining mode (G05)	213
In inch unit selection	216
In incremental mode	202
In incremental mode	339
In initialization	308
In jog mode	201
In JOG operation mode	339
In JOG-handle simultaneous mode	203
In L coil selection	264
In M coil selection	268
In manual arbitrary feed mode	202
In manual arbitrary feed	209
In manual operation mode	338
In manual speed command valid	222
In MDI mode	204
In memory mode	204
In mirror image n-th axis	195
In mixed control (cross axis control) n-th axis	194
In multi-step speed monitor	182
In NC axis control n-th axis	196

In PLC interrupt	220
In rapid traverse	213
In reference position return mode	202
In reference position return mode	339
In reference position return	215
In reference position return	339
In rewind	209
In Safe torque off (control axis)	659
In Safe torque off (spindle)	671
In safety absolute position establishing (control axis)	662
In safety external emergency stop (system common)	674
In SBC motor brake enabled (control axis)	659
In SBC motor brake start signal (control axis)	660
In SBT external brake test (control axis)	661
In skip	215
In SLP range (control axis)	654
In small diameter deep hole cycle	246
In SOS stop (control axis)	656
In SOS stop (spindle)	670
In spindle alarm	260
In spindle forward run	265
In spindle off	279
In spindle reverse run	266
In spindle synchronization 2	272
In spindle synchronization	269
In spindle torque limit	267
In spindle-NC axis polygon mode	242
In spindle-spindle polygon mode	243
In SS1 stop (control axis)	657
In SS1 stop (spindle)	670
In synchronized tapping selection (M command)	245
In synchronous feed	215
In synchronous/superimposition control n-th axis	195
In tape mode	204
In tapping	214
In thread cutting	215
In tool center point rotation	254
In tool escape and return mode	223
In tool life management	216
In tool spindle synchronization I (Polygon)	274
In tool spindle synchronization II	274
In torque limit	342
Inclined axis control valid	442
Inclined axis control: No Z axis compensation	442
Increase holding power of spindle	499
Incremental feed magnification 1, 2	608
Incremental mode	412
Incremental mode	612
Index positioning completion	268
Initialization incompleteness	308
Initialization setting completed	340
Initialization setting error completed	340
In-position	341
Integration time input 1	366
Integration time input 2	366
Interface of load meter for analog I/F spindle	602
Interference check between part systems: Alarm information	297
Interference check between part systems: Data address	564
Interference check between part systems: Interference check enabled	378

Interference check between part systems: Mode is active	184
Interference check between part systems: Setting error alarm information	296
Interference check III: Data setting error information 1	300
Data setting error information 2	300
Enable interfering object selection data	385
Entry in interference alarm area interfering object information	299
Entry in interference alarm area solid information	325
Entry in interference warn area solid information	324
Entry in interference warning area interfering object information	299
In interference check III mode	183
Interference check III mode	385
Interference detection interfering object information	299
Interference detection solid information	324
Interfering object selection data setting completed	183
Interfering object selection	627
Interlock-	609
Interlock+	609

J

Jog handle synchronous	455
Jog mode	411
JOG operation mode	611

K

Key in 1	288
KEY OUT 1	536

L

L coil selection	508
Laser: Approach in height control completed	286
Axis stop time with beam ON monitoring OFF	532
Enable height retention in height control	531
Height being retained in height control	286
Height control in progress	285
Height control	531
Laser beam irradiating	286
Laser beam irradiation ON	530
Laser beam irradiation ready	531
Laser condition change complete	530
Laser condition change strobe	286
Laser output feedback value (W)	359
Laser output override	630
Load monitoring I: Axis selection	575
Load monitoring I: Effective spindle torque output	337
Load monitoring I: Effective torque output n-th axis	328
Load monitoring I: Estimated spindle disturbance torque output	337
Longitudinal hole drilling axis selection	476

M

M code data 1	302
M code data 2	302
M code data 3	302

M code data 4	302	Manual feedrate	567
M code independent output M00	221	Manual interlock- n-th axis	393
M code independent output M01	221	Manual interlock+ n-th axis.....	393
M code independent output M02	221	Manual machine lock n-th axis	394
M code independent output M30	221	Manual measurement status	307
M coil selection	510	Manual numerical command	222
M function finish 1	427	Manual operation mode.....	610
M function finish 2	428	Manual override method selection	446
M function strobe 1	227	Manual speed clamp ON	453
M function strobe 2	227	Manual speed command reverse run valid	467
M function strobe 3	227	Manual speed command sign reversed	466
M function strobe 4	227	Manual speed command valid.....	465
Machine group-based alarm stop:		Manual/Automatic simultaneous valid n-th axis	396
Machine group-based PLC interlock ON ...	201	Master reset	609
Machine group-based alarm stop:		MDI mode	417
Machine group-based PLC interlock	411	Mechanical axis specifications	
Machine manufacturer macro password No.	550	1st rotary axis angle	591
Machine parameter lock I/F	553	Mechanical axis specifications	
Machine position n-th axis	325	2nd rotary axis angle.....	591
Macro interrupt priority.....	483	Memory mode	416
Macro interrupt.....	432	MES interface library:	
Magnification valid for each handle	458	Alarm number 1	623
Manual absolute	434	Alarm number 2.....	623
Manual arbitrary feed 1st axis		Alarm number 3.....	623
selection code m	468	Alarm number 4.....	623
Manual arbitrary feed 1st axis travel amount.....	573	Arbitrary user area C1	692
Manual arbitrary feed 1st axis valid	468	Arbitrary user area L1 to L10.....	692
Manual arbitrary feed 2nd axis		Arbitrary user area S1 to S20.....	692
selection code m	469	B number at alarm.....	624
Manual arbitrary feed 2nd axis travel amount.....	573	B number at machining start	619
Manual arbitrary feed 2nd axis valid	469	Common user area C1	679
Manual arbitrary feed 3rd axis		Common user area L1 to L10.....	679
selection code m	469	Condition register (Combination condition)	680
Manual arbitrary feed 3rd axis travel amount	573	Condition register (Comparison condition)	
Manual arbitrary feed 3rd axis valid	469	1st set	681
Manual arbitrary feed ABS/INC	472	Condition register (Comparison condition)	
Manual arbitrary feed Axis independent	470	2nd set	681
Manual arbitrary feed completion	212	Condition register (Condition value) 1st set	681
Manual arbitrary feed EX.F/MODAL.F	471	Condition register (Condition value) 2nd set	681
Manual arbitrary feed G0/G1	471	Condition register (Extract sort condition)	679
Manual arbitrary feed MC/WK	472	Condition register (Field value) 1st set.....	680
Manual arbitrary feed mode	413	Condition register (Field value) 2nd set.....	680
Manual arbitrary feed Smoothing off.....	469	Cycle time.....	619
Manual arbitrary feed stop	472	Database connection status	352
Manual arbitrary feed Strobe	473	Database operation reception register	353
Manual arbitrary reverse run handle selection.....	554	Database operation request register	352
Manual arbitrary reverse run mode ON	179	Database operation result register	353
Manual arbitrary reverse run mode.....	376	DB operation selection	354
Manual arbitrary reverse run speed multiplier	555	Function selection at alarm	356
Manual arbitrary reverse run speed selection.....	377	Function selection at machining end	356
Manual arbitrary reverse run:		Function selection at user's option	356
Actual cutting mode ON	178	G code modal registration selection	357
Manual arbitrary reverse run:		G code modal status	624
MSTB reverse run prohibited	481	Line number	352
Manual arbitrary reverse run:		Machine type	352
Reverse run block stop designated part		Machining end time	618
system	483	Machining start time	618
Manual arbitrary reverse run:		N number at alarm.....	624
Reverse run invalid status	257	N number at machining start	619
Manual arbitrary reverse run: Reverse run ON.....	179	NC unit number	351
Manual feedrate B override		Operation table selection.....	355
(File register method)	569	Operation trigger status.....	181
Manual feedrate B surface speed control valid.....	456	Operation trigger	527
Manual feedrate B valid n-th axis	397	Operator ID.....	351
Manual feedrate B	568	Power consumption amount.....	620
Manual feedrate code m	452	Power ON time	623
Manual feedrate method selection.....	454	Power regeneration amount.....	620

Program number at alarm	623
Program number at machining start.....	619
Sending user arbitrary information	256
Serial number.....	351
Spindle 1 load	624
Spindle 1 maximum load.....	619
Spindle 2 load value.....	625
Spindle 2 maximum load.....	620
Subprogram number at alarm	624
Time of alarm occurrence	623
Tool length offset 1 to 5	621
Tool length offset	625
Tool length wear amount 1 to 5	622
Tool length wear amount	626
Tool life 1 to 5	622
Tool life	626
Tool number 1 to 5	620
Tool number.....	625
Tool offset number 1 to 5	621
Tool offset number	625
Tool radius offset 1 to 5	621
Tool radius offset	625
Tool radius wear amount 1 to 5	622
Tool radius wear amount	626
User arbitrary information send request.....	465
User area C1 at alarm.....	691
User area C1 at machining end	691
User area L1 to L10 at alarm	692
User area L1 to L10 at machining end.....	691
Mirror image n-th axis	390
Miscellaneous function command high-speed output: 2nd M function finish 1 to 4	493
Miscellaneous function command high-speed output: M function finish 1 to 4	490
Miscellaneous function command high-speed output: S function finish 1 to 8	491
Miscellaneous function command high-speed output: T function finish 1 to 4.....	492
Miscellaneous function lock	447
Mixed control (cross axis control) request n-th axis	403
Motion command completion	210
Motor brake SBT incomplete (control axis)	661
Motor brake SBT start (control axis)	642
Motor load current n-th axis	326
Motor rotation speed n-th axis.....	326
Multi-analog input ch n	699
Multi-analog input status ch n	700
Multiple-spindle control I: Selected spindle No.	585
Multi-point orientation position data	602
Multi-step speed monitor selected speed output.....	295

N

NC alarm 1	236
NC alarm 2 (Servo alarm)	237
NC alarm 3 (Program error)	237
NC alarm 4 (Operation error)	238
NC alarm 5	243
NC axis control selection n-th axis	405
NC axis up-to-speed n-th axis	193
NC axis/PLC axis switchover invalid status	200
NC axis/PLC axis switchover n-th axis in process	200
NC axis/PLC axis switchover request	410
NC reset 1	422
NC reset 2	422

NC warning (Servo warning).....	238
Near reference position (per reference position)	310
Near reference position n-th axis	190
Near set position.....	345
Near-point dog ignored	542
New tool change	235
No. of error occurrences n-th ch	346
No. of work machining (current value)	313
No. of work machining (maximum value).....	313
No. of work machining over	240
Number of registered tool life control tools	319

O

Operation parameter selection 1, 2	608
Operation start	606
Operator message I/F 1 to 4	547
Operator message I/F	574
Option status export to PLC.....	345
Optional block skip m.....	443
OT ignored.....	541
Output OFF check request	652
Override cancel.....	446

P

Pallet program registration Ext. workpiece coordinate transfer completion	182
Pallet program registration Ext. workpiece coordinate transfer ready	374
Phase offset request.....	523
Phase shift calculation request.....	522
PLC axis 1st to 3rd handle valid	368
PLC axis alarm/warning No. n-th axis.....	300
PLC axis control buffering mode information address.....	560
PLC axis control buffering mode valid	369
PLC axis control information address n-th axis	560
PLC axis control valid n-th axis.....	387
PLC axis indexing control command 1	609
PLC axis indexing control command 2	605
PLC axis indexing control command 3	605
PLC axis indexing control command 4	604
PLC axis indexing control status 1.....	340
PLC axis indexing control status 2.....	338
PLC axis indexing control status 3.....	338
PLC axis indexing control status 4.....	338
PLC axis near point detection n-th axis	368
PLC axis near-point dog ignored	543
PLC axis OT ignored	542
PLC coil changeover.....	519
PLC emergency stop	437
PLC interrupt program No.....	569
PLC interrupt.....	438
PLC main scan time.....	291
PLC skip 1 to 8	379
PLC switch non-display	678
Position loop in-position.....	266
Position switch 1 to 15	338
Position switch 1 to 24	287
Position switch n interlock.....	533
Power consumption computation: Accumulated consumption of devices other than drive system 1 to 4	299
Accumulated consumption of entire drive system 1 to 4	298
Clear consumption accumulation 1 to 4	366

Clearing consumption accumulation 1 to 4 complete	175
Consumption accumulation ON 1 to 4	175
Consumption of devices other than drive system	546
Drive system's fixed consumption correction	547
Enable consumption accumulation 1 to 4	372
Present consumption of entire drive system	298
Power OFF indication Y device No.	536
Power OFF processing	175
Power OFF required after parameter change	180
Presetter contact	311
Presetter interlock	312
Program format switch in progress	248
Program format switch request	482
Program restart	431
Program restart: Restart position return check invalid	632
Punchtap cycle in progress	234

R

Rapid traverse override code 1, 2	451
Rapid traverse override method selection	452
Rapid traverse override	566
Rapid traverse time constant: In switchover	249
Rapid traverse time constant: Switchover request	484
Rapid traverse	433
Ready OFF	610
Real-time tuning 1: Speed control gain changeover hold-down command	409
Real-time tuning 1: Speed control gain changeover hold-down command	527
Real-time tuning 1: Speed control gain changeover hold-down ON	199
Real-time tuning 1: Speed control gain changeover hold-down ON	285
Real-time tuning 2: Acceleration/deceleration time constant in automatic switchover	484
Real-time tuning 2: Acceleration/deceleration time constant in manual switchover	485
Real-time tuning 2: Acceleration/deceleration time constant in switchover	249
Real-time tuning 2: Acceleration/deceleration time constant reset	485
Recalculation request	436
Reference position adjustment completion	582
Reference position adjustment value parameter setting completed	309
Reference position establishment n-th axis	195
Reference position reached	343
Reference position retract	437
Reference position return direction n-th axis	196
Reference position return mode	415
Reference position return mode	611
Reference position selection code 1,2	461
Reference position selection method	462
Reflection of reserved tool wear compensation is complete	250

Request for reflecting reserved tool wear compensation	486
Reservation of tool wear compensation	531
Reserved tool wear compensation not reflected	249
Reset & rewind	423
Reverse run control mode	484
Reverse run from block start	483
Reverse run	433
R-Navi: Machine surface index complete	255
R-Navi: Machining surface being indexed	255
R-Navi: Machining surface being selected	254
R-Navi: Selected workpiece No.	323
R-Navi: selecting machine surface number	323
Rotary axis configuration parameter output	322
Rotary axis configuration parameter switch	587
Rotation center error compensation enabled	487
Rotation center error compensation in progress	250
Rotation direction	607

S

S code data 1 to 8	303
S command gear No. illegal	257
S command max./min. command value over	258
S command no gear selected	258
S command override	601
S function strobe 1 to 8	230
Safe cam is active (control axis)	655
Safe cam request (control axis)	637
Safe stop 1 request (control axis)	638
Safe stop 1 request (spindle)	648
Safe stop 2 request (control axis)	638
Safe stop 2 request (spindle)	649
Safe torque OFF request (control axis)	639
Safe torque OFF request (spindle)	649
Safety absolute position confirm (control axis)	643
Safety I/O observation state	676
Safety I/O unit observation error details	677
Safety I/O unit observation state	676
Safety reset (control axis)	644
Safety reset (spindle)	649
Sampling start/stop	374
SBC motor brake starting request (control axis)	639
SBT start position (control axis)	668
SCA safe cam position (control axis)	667
Screen display request	373
Search & start Error	234
Search & start program No.	574
Search & start Search	234
Search & start	441
Selected tool compensation No. (sub)	584
Selected tool wear No. (sub)	584
Servo alarm/warning No.	327
Servo deflection amount n-th axis	326
Servo OFF n-th axis	390
Servo OFF	609
Servo ready completion output designation	589
Servo ready completion	205
Servo ready completion	344
Servo ready n-th axis	185
Servo ready	340
Set position reached	345
Simple inclined surface machining command: Tool axis rotation angle compensation amount	592

Simple inclined surface machining/Inclined surface control command ON	256	Spindle oscillation frequency	604
Single block between part systems	375	Spindle oscillation in progress	282
Single block	419	Spindle override method selection	497
Skip coordinate position n-th axis feature coordinate	327	Spindle phase synchronization completion	271
Skip coordinate position n-th axis	326	Spindle phase synchronization	521
SLP observation is active (control axis)	654	Spindle position control (Spindle/C axis control): C axis mode ON	281
SLP observation request (control axis)	636	Spindle position control (Spindle/C axis control): C axis selection	509
SLP position change input (control axis)	647	Spindle protection: Mode in progress	283
SLP position change output (control axis)	665	Spindle protection: Motor equivalent load factor	696
SLS observation is active (control axis)	653	Spindle protection: Number of times log output error occurred	696
SLS observation is active (spindle)	669	Spindle protection: Resetting alarm of equivalent load factor over limit	528
SLS observation request (control axis)	635	Spindle ready-ON	264
SLS observation request (spindle)	647	Spindle reverse run index	506
SLS speed change input (control axis)	645	Spindle reverse run start	503
SLS speed change input (spindle)	650	Spindle rotation direction switch method selection	519
SLS speed change output (control axis)	663	Spindle rotation reversal	512
SLS speed change output (spindle)	672	Spindle rotation speed synchronization completion	270
SLS speed override input (control axis)	646	Spindle selection	511
SLS speed override input (spindle)	651	Spindle servo-ON	265
SLS speed override output (control axis)	664	Spindle speed fluctuation detection: Spindle speed out of setting range	280
SLS speed override output (spindle)	673	Spindle speed override code m	497
Small diameter deep hole drilling cycle	474	Spindle stop	499
Smart safety observation error occurring servo axis (control axis)	662	Spindle superimposition control ON	276
Smart safety observation error occurring spindle (spindle)	671	Spindle superimposition control: Speed change disabled	275
Smart safety observation warning occurring servo axis (control axis)	663	Spindle superimposition control: Spindle superimposition clamped	277
Smart safety observation warning occurring spindle (spindle)	672	Spindle synchronization	520
Smoothing zero	341	Spindle synchronization: Maximum phase error/Maximum hob axis delay angle	331
SOS is active (control axis)	656	Phase error 1	334
SOS is active (spindle)	669	Phase error 2	334
SOS observation request (control axis)	637	Phase error monitor (lower limit)	333
SOS observation request (spindle)	648	Phase error monitor (upper limit)	333
Spatial error compensation enabled	487	Phase error monitor	332
Spatial error compensation in progress	251	Phase error over	276
Special safety alarm cancel (system common)	651	Phase error tolerance	604
Speed detection 2	267	Phase error/Hob axis delay angle	331
Speed detection	260	Phase offset data	332
Speed monitor door open possible	294	Phase shift amount	603
Speed monitor mode	543	Reference spindle selection	603
Speed override 1 to 64	604	Synchronized spindle selection	603
Speed override valid	605	Spindle synchronization/superimposition cancel	525
Spindle 2nd in-position	259	Spindle synchronous rotation direction	521
Spindle actual speed	330	Spindle temperature output	335
Spindle alarm/warning No.	335	Spindle tool No.	618
Spindle command final data (rotation speed)	330	Spindle torque limit 1	504
Spindle command rotation speed input	330	Spindle torque limit 2	504
Spindle command rotation speed output	599	Spindle torque limit reached	267
Spindle command selection	600	Spindle up-to-speed	262
Spindle enable	269	Spindle-mode rotary axis control command n-th axis	407
Spindle forward run index	505	Spindle-mode rotary axis control mode n-th axis	198
Spindle forward run start	502	Spindle-spindle polygon cancel	475
Spindle gear selection code 1, 2	498		
Spindle gear selection output 1, 2	282		
Spindle gear shift command 1, 2	258		
Spindle gear shift	500		
Spindle in-position	263		
Spindle motor load ratio	335		
Spindle OFF mode	476		
Spindle orientation command	507		
Spindle orientation	501		
Spindle oscillation amplitude	604		
Spindle oscillation command	526		

Spindle-spindle polygon synchronization completion	244
SS1 is active (control axis)	657
SS1 is active (spindle)	670
SS2 is active (control axis)	658
SS2 is active (spindle)	670
SSM is active (control axis)	655
SSM is active (spindle)	669
SSM request (control axis)	636
SSM request (spindle)	648
Standby tool No.	618
Start not possible	338
Station position 1 to 256	338
Station selection 1 to 256	605
STO is active (control axis)	658
STO is active (spindle)	671
Stored stroke limit I: Change request n-th axis	408
Stroke compensation completion	233
Sub part system control:	
Caller of sub part system	317
Calling sub part system	315
Sub part system control I mode ON	205
Sub part system control I mode	417
Sub part system control II identification No.	314
Sub part system processing	224
Waiting for sub part system completion	316
Superimposition control request n-th axis	405
Synchronization between part systems OFF	479
Synchronization correction mode	430
Synchronous control operation method	577
Synchronous control request n-th axis	404
Synchronous error amount n-th axis	327
Synchronous tapping command polarity reversal	475
Synchronous tapping Current error angle	336
Synchronous tapping Current error width	335
Synchronous tapping Maximum error angle	337
Synchronous tapping Maximum error width	336

T

T code data 1 to 4	304
T code data for L system	360
T function strobe 1 to 4	231
Tap retract possible state cancel	476
Tap retract possible	240
Tap retract	447
Tape mode	416
Temperature rise	634
Temperature warning cause	290
Thermistor disconnection	698
Thermistor input n	698
Thermistor short-circuit	699
Thread cutting: Feed-forward control ON	239
Thread cutting: Feed-forward control request	462
Thread recutting command	590
Thread recutting execution operation	590
Thread recutting execution status	321
Thread recutting lead axis No.	322
Thread recutting spindle No.	321
Thread recutting status	320
Thread, tap block stopping in manual arbitrary reverse run	180
Thread, tap reverse run prohibition alarm in manual arbitrary reverse run	181
Timing synchronization between part systems	220
Timing synchronization ignore	475
Tool alarm 1/Tool-skip	459

Tool alarm 2	459
Tool center point rotation	489
Tool change position return completion	235
Tool change reset	460
Tool escape and return Transit point designation	460
Tool escape and return transit point recognition completed	234
Tool group life over	219
Tool group No. designation	581
Tool handle feed mode	449
Tool length compensation along the tool axis Compensation amount change mode	462
Tool length measurement 1	429
Tool length measurement 2 Tool No.	588
Tool length measurement 2	429
Tool life management data sort	576
Tool life management input	460
Tool life management:	
Temporary cancel of tool group life expiration ON	217
Tool life management:	
Temporary cancel of tool group life expiration	464
Tool life management:	
Temporary cancel of tool life expiration ON	217
Tool life management:	
Temporary cancel of tool life expiration	463
Tool life over	218
Tool life prediction	236
Tool life usage data	319
Tool mounting information m	584
Torque limitation skip:	
G160 torque limit ON	248
Total distance traveled by n-th axis during automatic operation	365
Touchscreen operation disabled	630

U

Unclamp command n-th axis	194
Unclamp completion n-th axis	402
Under SLS limit (control axis)	653
Under SLS limit (spindle)	669
Under SSM safe speed (control axis)	666
Under SSM safe speed (spindle)	674
Upper dead point -> basic position path flag	233
Upper dead point -> bottom dead point path flag	233
Usage data count valid	459
User level-based data protection:	
Operation level	553
User macro input #1032 (PLC -> NC)	597
User macro input #1033 (PLC -> NC)	598
User macro input #1034 (PLC -> NC)	598
User macro input #1035 (PLC -> NC)	598
User macro output #1132 (NC -> PLC)	328
User macro output #1133 (NC -> PLC)	329
User macro output #1134 (NC -> PLC)	329
User macro output #1135 (NC -> PLC)	329
User macro section and sub-section designated execution result	309
User sequence program version code 2	539
User sequence program version code	538

V

V number of smart safety observation warning (system common)	675
VCC: Cause of non-vibration	363
VCC: Frequency.....	361
VCC: Mode in execution	257
VCC: Number of vibrations	361
VCC: Spindle rotation speed.....	338
VCC: Temporary cancel of axis vibration.....	633
VCC: Vibrating axis	362
Vertical axis pull-up prevented n-th axis	197
Vertical axis pull-up prevention request n-th axis	406

W

W number of smart safety observation error (system common)	674
W number of smart safety observation warning (system common)	675
Wear compensation No. (tool presetter)	583
Workpiece coordinate Measurement 2nd axis	400
Workpiece coordinate offset measurement: Tool compensation No./Selected compensation tool No. (main).....	583
Workpiece coordinate offset measurement: Tool No./Selected tool No. (main).....	583
Zero point initialization set completed n-th axis	191
Zero point initialization set error completed n-th axis	192
Zero point initialization set mode n-th axis	398
Zero point initialization set start n-th axis	398
Zero speed	261

Revision History

Date of revision	Manual No.	Revision details
Mar. 2021	IB(NA)1501616-A	The first edition was created.
Jul. 2021	IB(NA)1501616-B	<p>Contents were revised to correspond to Mitsubishi Electric CNC M800V/M80V Series software version A1.</p> <p>The interface signals in the following chapter were revised or added corresponding to S/W version A1.</p> <ul style="list-style-type: none"> • 2.1 PLC Input Signals (Bit Type: X***) • 2.3 PLC Output Signals (Bit Type: Y***) • 2.4 PLC Output Signals (Data Type: R***) • 4.1 PLC Input Signals (Bit Type: X***) • 4.2 PLC Input Signals (Data Type: R***) • 4.3 PLC Output Signals (Bit Type: Y***) • 4.4 PLC Output Signals (Data Type: R***) • 4.6.1.1 PLC -> CNC • 7 Appx.3: List of Option Status Exported to PLC <p>Other mistakes were corrected.</p>
Mar. 2022	IB(NA)1501616-C	<p>Contents were revised to correspond to Mitsubishi Electric CNC M800V/M80V Series software version A3.</p> <p>The interface signals in the following chapter were revised or added corresponding to S/W version A3.</p> <ul style="list-style-type: none"> • 2.1 PLC Input Signals (Bit Type: X***) • 2.2 PLC Input Signals (Data Type: R***) • 2.3 PLC Output Signals (Bit Type: Y***) • 2.4 PLC Output Signals (Data Type: R***) • 2.6 ZR Devices • 2.7 Classified for Each Application • 4.1 PLC Input Signals (Bit Type: X***) • 4.2 PLC Input Signals (Data Type: R***) • 4.3 PLC Output Signals (Bit Type: Y***) • 4.4 PLC Output Signals (Data Type: R***) • 4.6 Explanation of ZR Device • 5.5 Precautions <p>Other mistakes were corrected.</p>

Global Service Network

AMERICA

MITSUBISHI ELECTRIC AUTOMATION INC. (AMERICA FA CENTER)

Central Region Service Center (Chicago)

500 CORPORATE WOODS PARKWAY, VERNON HILLS, ILLINOIS 60061, U.S.A.
TEL: +1-847-478-2500 / FAX: +1-847-478-2650

Minneapolis, MN Service Satellite
Detroit, MI Service Satellite
Grand Rapids, MI Service Satellite
Milwaukee, WI Service Satellite
Cleveland, OH Service Satellite
Indianapolis, IN Service Satellite
St. Louis, MO Service Satellite

South/East Region Service Center (Georgia)

1845 SATELLITE BOULEVARD STE. 450, DULUTH, GEORGIA 30097, U.S.A.
TEL: +1-678-258-4529 / FAX: +1-678-258-4519

Charleston, SC Service Satellite
Charlotte, NC Service Satellite
Raleigh, NC Service Satellite
Dallas, TX Service Satellite
Houston, TX Service Satellite
Hartford, CT Service Satellite
Knoxville, TN Service Satellite
Nashville, TN Service Satellite
Baltimore, MD Service Satellite
Pittsburg, PA Service Satellite
Tampa, FL Service Satellite
Syracuse, NY Service Satellite
Orlando, FL Service Satellite
Lafayette, LA Service Satellite
Philadelphia, PA Service Satellite

Western Region Service Center (California)

5900-B KATELLA AVE. - 5900-A KATELLA AVE. CYPRESS, CALIFORNIA 90630, U.S.A.
TEL: +1-714-699-2625 / FAX: +1-847-478-2650

San Jose, CA Service Satellite
Seattle, WA Service Satellite
Denver, CO Service Satellite

Canada Region Service Center (Toronto)

4299 14TH AVENUE MARKHAM, ONTARIO L3R 0J2, CANADA
TEL: +1-905-475-7728 / FAX: +1-905-475-7935

Edmonton, AB Service Satellite
Montreal, QC Service Satellite

Mexico Region Service Center (Queretaro)

Parque Tecnológico Innovación Querétaro, Lateral Carretera Estatal 431, Km 2+200, Lote 91 Modulos 1 y 2
Hacienda la Machorra, CP 76246, El Marqués, Querétaro, México
TEL: +52-442-153 6050

Monterrey, NL Service Satellite
Mexico City, DF Service Satellite

BRAZIL

MITSUBISHI ELECTRIC DO BRASIL COMÉRCIO E SERVIÇOS LTDA.

Votorantim Office

AV. GISELE CONSTANTINO,1578, PARQUE BELA VISTA, VOTORANTIM-SP, BRAZIL CEP:18.110-650
TEL: +55-15-3023-9000

Blumenau, Santa Catarina Office

EUROPE

MITSUBISHI ELECTRIC EUROPE B.V.

European Service Headquarters (Dusseldorf, GERMANY)

Mitsubishi-Electric-Platz 1 40882 RATINGEN, GERMANY
TEL: +49-2102-486-5000 / FAX: +49-2102-486-5910

South Germany Service Center (Stuttgart)

SCHELMENWASENSTRASSE 16-20, 70567 STUTTGART, GERMANY
TEL: + 49-711-770598-123 / FAX: +49-711-770598-141

France Service Center (Paris)

2 RUE DE L'UNION, 92565 RUEIL-MALMAISON CEDEX, FRANCE
TEL: +33-1-41-02-83-13 / FAX: +33-1-49-01-07-25

France Service Satellite (Lyon)

120, ALLEE JACQUES MONOD 69800 SAINT PRIEST FRANCE
TEL: +33-1-41-02-83-13 / FAX: +33-1-49-01-07-25

Italy Service Center (Milan)

CENTRO DIR. COLLEONI, PALAZZO SIRIO, VIALE COLLEONI 7, 20864 AGRATE BRIANZA (MB) ITALY
TEL: +39-039-6053-342 / FAX: +39-039-6053-206

Italy Service Satellite (Padova)

VIA G. SAVELLI, 24 - 35129 PADOVA, ITALY
TEL: +39-039-6053-342 / FAX: +39-039-6053-206

U.K. Service Center

TRAVELLERS LANE, HATFIELD, HERTFORDSHIRE, AL10 8XB, U.K.
TEL: +44-1707-288-780 / FAX: +44-1707-278 695

Spain Service Center

CTRA. RUBI, 76-80 8174 SAINT CUGAT DEL VALLES, BARCELONA, SPAIN
TEL: +34-935-65-2236 / FAX: +34-935-89-1579

Poland Service Center

UL.KRAKOWSKA 50, 32-083 BALICE, POLAND
TEL: +48-12-347-6500 / FAX: +48-12-630-4701

Hungary Service Center

BUDAÖRS OFFICE PARK, SZABADSÁG ÚT 117., 2040 BUDAÖRS, HUNGARY
TEL: +48-12-347-6500 / FAX: +48-12-630-4701

Turkey Service Center

MITSUBISHI ELECTRIC TURKEY ELEKTRİK ÜRÜNLERİ A.Ş

SERİFALİ MAHALLESİ KALE SOKAK. NO.41 34775
UMRANIYE, İSTANBUL, TURKEY
TEL: +90-216-969-2500 / FAX: +90-216-661-44-47

Czech Republic Service Center

AutoCont Control Systems s.r.o (Service Partner)

KAFKOVA 1853/3, 702 00 OSTRAVA 2, CZECH REPUBLIC
TEL: +420-59-5691-185 / FAX: +420-59-5691-199

Russia Service Center

MITSUBISHI ELECTRIC RUSSIA LLC

LETNIKOVSKAYA STREET 2, BLD.1, 5TH 115114 MOSCOW, RUSSIA
TEL: +7-495-721-2070 / FAX: +7-495-721-2071

Sweden Service Center

HAMMARBACKEN 14, P.O.BOX 750 SE-19127, SOLLENTUNA, SWEDEN
TEL: +46-8-6251200 / FAX: +46-8-6251014

Bulgaria Service Center

AKHNATON Ltd. (Service Partner)

4 ANDREJ LJAPCHEV BLVD. POB 21, BG-1756 SOFIA, BULGARIA
TEL: +359-2-8176009 / FAX: +359-2-9744061

Ukraine Service Center (Kiev)

CSC Automation Ltd. (Service Partner)

4 B, YEVHENA SVERSTYUKA STR., 02002 KIEV, UKRAINE
TEL: +380-44-494-3344 / FAX: +380-44-494-3366

Belarus Service Center

TECHNIKON Ltd. (Service Partner)

NEZAVISIMOSTI PR.177, 220125 MINSK, BELARUS
TEL: +375-17-393-1177 / FAX: +375-17-393-0081

South Africa Service Center

Adroit Technologies (Service Partner)

20 WATERFORD OFFICE PARK, WATERFORD DRIVE, CNR OF WITKOPPEN ROAD,
FOURWAYS JOHANNESBURG SOUTH AFRICA
TEL: +27-11-658-8100 / FAX: +27-11- 658-8101

ASEAN

MITSUBISHI ELECTRIC ASIA PTE. LTD. (ASEAN FA CENTER)
Singapore Service Center
307 ALEXANDRA ROAD #05-01/02 MITSUBISHI ELECTRIC BUILDING SINGAPORE 159943
TEL: +65-6473-2308 / FAX: +65-6476-7439

PHILIPPINES

MELCO FACTORY AUTOMATION PHILIPPINES INC.
Head Office
128 LOPEZ RIZAL STREET, BRGY., HIGHWAY HILLS, MANDALUYONG CITY , MM PHILIPPINES 1550
TEL: +63-2-8256-8042 / FAX: +632-8637-2294

Philippines Service Center
KM.23 WEST SERVICE ROAD SSH, CUPANG ,MUNTINLUPA CITY, PHILIPPINES
TEL: +63-2-8807-0420 / FAX: +63-2-8842-5202

VIETNAM

MITSUBISHI ELECTRIC VIETNAM CO., LTD.
Vietnam Ho Chi Minh Service Center
11TH & 12TH FLOOR, VIETTEL TOWER B, 285 CACH MANG THANG 8 STREET, WARD 12, DISTRICT 10,
HO CHI MINH CITY, VIETNAM
TEL: +84-28-3910 5945 / FAX: +84-28-3910 5947

Vietnam Hanoi Service Center
24TH FLOOR, HANDICO TOWER, PHAM HUNG ROAD, ME TRI HA, ME TRI WARD,
NAM TU LIEM DISTRICT, HA NOI CITY, VIETNAM
TEL: +84-24-3937-8075 / FAX: +84-24-3937-8076

INDONESIA

PT. MITSUBISHI ELECTRIC INDONESIA
Indonesia Service Center (Cikarang)
JL. KENARI RAYA BLOK G2-07A, DELTA SILICON 5, LIPPO CIKARANG - BEKASI 17550, INDONESIA
TEL: +62-21-2961-7797 / FAX: +62-21-2961-7794

MALAYSIA

MITSUBISHI ELECTRIC SALES MALAYSIA SDN. BHD.
Malaysia Service Center (Kuala Lumpur Service Center)
LOT 11, JALAN 219, P.O BOX 1036, 46860 PETALING JAYA, SELANGOR DARUL EHSAN, MALAYSIA
TEL: +60-3-7626-5032 / FAX: +60-3-7960-2629
Johor Bahru Service Satellite
Pulau Pinang Service Satellite

THAILAND

MITSUBISHI ELECTRIC FACTORY AUTOMATION (THAILAND) CO., LTD.
Thailand Service Center (Bangkok)
101, TRUE DIGITAL PARK OFFICE, 5TH FLOOR, SUKHUMVIT ROAD, BANGCHAK, PHRAKHANONG,
BANGKOK, 10260 THAILAND
TEL: +66-2-092-8600 / FAX: +66-2-043-1231-33

INDIA

MITSUBISHI ELECTRIC INDIA PVT., LTD.
CNC Technical Center (Bangalore)
PLOT NO. 56, 4TH MAIN ROAD, PEENYA PHASE 3,
PEENYA INDUSTRIAL AREA, BANGALORE 560058, KARNATAKA, INDIA
TEL : +91-80-4655-2121 / FAX : +91-80-4655-2147
Chennai Service Satellite
Coimbatore Service Satellite
Hyderabad Service Satellite

North India Service Center (Gurgaon)
PLOT 517, GROUND FLOOR, UDYOG VIHAR PHASE-III, GURUGRAM 122008, HARYANA, INDIA
TEL : +91-124-463-0300 / FAX : +91-124-463-0399
Ludhiana Service Satellite
Panthnagar Service Satellite
Delhi Service Satellite
Jamshedpur Service Satellite
Manesar Service Satellite

West India Service Center (Pune)
ICC-Devi GAURAV TECHNOLOGY PARK, UNIT NO.402, FOURTH FLOOR, NORTH WING,
SURVEY NUMBER 191-192 (P), NEXT to INDIAN CARD CLOTHING COMPANY Ltd,
OPP. VALLABH NAGAR, PIMPRI, PUNE- 411 018, MAHARASHTRA, INDIA
TEL : +91-20-6819 2274 / FAX : +91-20-4624 2100
Kolhapur Service Satellite
Aurangabad Service Satellite
Mumbai Service Satellite

West India Service Center (Ahmedabad)
204-209, 2ND FLOOR, 31FIVE, CORPORATE ROAD PRAHLADNAGAR,
AHMEDABAD -380015, GUJARAT, INDIA
TEL : + 91-79-6777 7888
Rajkot Service Satellite

CHINA

MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD. (CHINA FA CENTER)
CNC Call Center
TEL: +86-400-921-5130

Shanghai Service Center
1-3,5-10,18-23/F, NO.1386 HONG QIAO ROAD, CHANG NING QU,
SHANGHAI 200336, CHINA
TEL: +86-21-2322-3030 / FAX: +86-21-2322-3000*8422
Qingdao Service Center
Suzhou Service Center
Wuhan Service Center
Ningbo Service Center
Hefei Service Center
Beijing Service Center
Tianjin Service Center
Xian Service Center
Dalian Service Center
Chengdu Service Center

Shenzhen Service Center
LEVEL8, GALAXY WORLD TOWER B, 1 YABAO ROAD, LONGGANG DISTRICT,
SHENZHEN 518129, CHINA
TEL: +86-755-2399-8272 / FAX: +86-755-8229-3686
Dongguan Service Center
Xiamen Service Center

KOREA

MITSUBISHI ELECTRIC AUTOMATION KOREA CO., LTD. (KOREA FA CENTER)
Korea Service Center
8F GANGSEO HANGANG XI-TOWER A, 401 YANGCHEON-RO, GANGSEO-GU,
SEOUL 07528 KOREA
TEL: +82-2-3660-9631 / FAX: +82-2-3664-8668
Korea Daegu Service Satellite

TAIWAN

MITSUBISHI ELECTRIC TAIWAN CO., LTD. (TAIWAN FA CENTER)
Taiwan Taichung Service Center
NO. 8-1, GONGYEQU 16th RD., XITUN DIST., TAICHUNG CITY 40768 , TAIWAN
TEL: +886-4-2359-0688 / FAX: +886-4-2359-0689

Taiwan Taipei Service Center
11F, NO.88, SEC.6, ZHONGSHAN N. RD., SHILIN DIST., TAIPEI CITY 11155, TAIWAN
TEL: +886-2-2833-5430 / FAX: +886-2-2833-5433

Taiwan Tainan Service Center
11F.-1, NO.30, ZHONGZHENG S. RD., YONGKANG DIST., TAINAN CITY 71067, TAIWAN
TEL: +886-6-252-5030 / FAX: +886-6-252-5031

OCEANIA

MITSUBISHI ELECTRIC AUSTRALIA PTY. LTD.
Oceania Service Center
348 VICTORIA ROAD, RYDALMERE, N.S.W. 2116 AUSTRALIA
TEL: +61-2-9684-7269/ FAX: +61-2-9684-7245

Notice

Every effort has been made to keep up with software and hardware revisions in the contents described in this manual. However, please understand that in some unavoidable cases simultaneous revision is not possible. Please contact your Mitsubishi Electric dealer with any questions or comments regarding the use of this product.

Duplication Prohibited

This manual may not be reproduced in any form, in part or in whole, without written permission from Mitsubishi Electric Corporation.

COPYRIGHT 2021-2022 MITSUBISHI ELECTRIC CORPORATION ALL RIGHTS RESERVED

mitsubishi electric corporation

HEAD OFFICE : TOKYO BLDG.,2-7-3 MARUNOUCHI,CHIYODA-KU,TOKYO 100-8310,JAPAN

MODEL	M800V/M80V Series
MODEL CODE	100-747
Manual No.	IB-1501616