

Before Using the Product

Before using the product, please read this manual. Make sure that the end users read this manual and then keep the manual in a safe place for future reference.

■ Relevant manuals

Before using the product, please read the Safety Guidelines included with the base unit used, especially the following sections.

- SAFETY PRECAUTIONS
- CONDITIONS OF USE FOR THE PRODUCT
- EMC AND LOW VOLTAGE DIRECTIVES
- WARRANTY

The product details are described in the following manual.

Please develop familiarity with the functions and performance of the product to handle the product correctly.

- MELSEC iQ-R Motion Module User's Manual (Startup)
IB-0300406
- MELSEC iQ-R Motion Module User's Manual (Application)
IB-0300411
- MELSEC iQ-R Motion Module User's Manual (Network)
IB-0300426
- MELSEC iQ-R Motion Module User's Manual (Application for Simple Motion Mode)
IB-0300572
- MELSEC iQ-R Motion Module User's Manual (Advanced Synchronous Control for Simple Motion Mode)
IB-0300575

■ Manuels correspondants

Avant d'utiliser ce produit, prière de lire les "Safety Guidelines" (directive de sécurité) fournies avec l'unité de base, en particulier dans les sections suivantes.

- PRÉCAUTIONS DE SÉCURITÉ
- CONDITIONS D'UTILISATION DE PRODUIT
- DIRECTIVES CEM ET BASSE TENSION
- GARANTIE

■ Packing list

Check that the following items are included in the package of the product.

| Item | Quantity |
|--|----------|
| Module | 1 |
| Before Using the Product (this manual) | 1 |

■ Mounting modules

When installing the Motion module in a control panel, fully consider its operability, maintainability, and environmental resistance.

Securely mount all the MELSEC iQ-R series modules used on the base unit.

For details on the mounting method, refer to the MELSEC iQ-R Module Configuration Manual.

■ Montage des modules

Pour installer le module de mouvement dans un tableau de commande, prendre en compte tous les aspects d'opérabilité, de maintenabilité et de résistance à l'environnement.

Monter fermement sur l'unité de base tous les modules de la série MELSEC iQ-R à utiliser.

Pour le détail de la méthode de montage, voir le MELSEC iQ-R Module Configuration Manual (Manuel de configuration du module MELSEC iQ-R).

■ Operating ambient temperature

Use the product within the following range.

| Model | Operating ambient temperature |
|---|---|
| RD78G4, RD78G8, RD78G16, RD78G32, RD78G64 | 0 to 55°C 0 to 60°C (when an extended temperature range base unit is used) |
| RD78GHV, RD78GHW | 0 to 55°C |

■ Température ambiante de fonctionnement

Ce produit doit être utilisé dans les conditions suivantes.

| Modèle | Température ambiante de fonctionnement |
|---|--|
| RD78G4, RD78G8, RD78G16, RD78G32, RD78G64 | 0 à 55°C 0 à 60°C (quand une unité de base à gamme de température élargie est utilisée) |
| RD78GHV, RD78GHW | 0 à 55°C |

■ Information and services

For further information and services, please consult your local Mitsubishi representative.