

Mitsubishi Electric AC Servo System

MELSERVO-(

Safety Instructions and Precautions for AC Servos (Safety Sub-Function)

Mitsubishi Electric Automation, Inc. 500 Corporate Woods Parkway, Vernon Hills, IL 60061, U.S.A. Mitsubishi Electric Europe B.V. German Branch Mitsubishi-Electric-Platz 1, 40862 Ratingen, Germany

Mitsubishi Electric Automation (China) Ltd. Mitsubishi Electric Automation Center, No.1386 Hongqiao Road, Shanghai, China Mitsubishi Electric Automation Korea Co., Ltd. 7F to 9F, Gangseo Hangang Xi-tower A, 401, Yangcheon-ro, Gangseo-Gu, Seoul, Korea Mitsubishi Electric Corporation Tokyo Building, 2-7-3, Marunouchi, Chiyoda-ku, Tokyo 100-8310, Japan

MITSUBISHI ELECTRIC CORPORATION

G

Tel:+1-847-478-2100

Tel:+49-2102-486-0

Tel: +86-21-2322-3030 Tel:+82-2-6103-9474

Tel:+81-3-3218-2111

Copyright@2020 Mitsubishi Electric Corporation All Rights Reserved

Contents of the package

IB(NA)-0300516-G(2401)MEE

China

Packed articles	Quantity
Servo amplifier or drive unit	1
MR-J5 Safety Instructions and Precautions for AC Servos	1
MR-J5 Safety Instructions and Precautions for AC Servos (Safety Sub-Function) (this guide)	1
MR-J5 Safety Instructions and Precautions for AC Servos (Safety Sub-Function) (this guide)	

1. About the manuals

To use the MELSERVO-J5 series safely, read MR-J5 User's Manuals carefully.

1.1 Purpose of this guide
This guide is subject to engineers of machine manufacturers and operators of machines, and explains functional safety
of the MR-J5 servo amplifiers/MR-J5D drive units (hereafter "MR-J5"). For detailed information of the products, refer to
MR-J5 User's Manual. This guide does not explain how to operate equipment that incorporates an MR-J5.

Item	Detailed explanation
STO (Safe torque off)	Shuts off servo motor drive energy electronically based on an input signal from an external device (secondary- side output shut-off). This corresponds to stop category 0 of IEC/EN 60204-1.
SS1 (Safe stop 1)	Starts deceleration based on an input signal from an external device (EMZ). After a specified time to confirm that the motor has stopped, the STO function will be activated (SS1-1). Alternative), the SS1 function monitors whether the serve motor decelerates according to the deceleration time constant (SS1-r). This corresponds to stop category of IEC/EN 60204-1.
SS2 (Safe stop 2)	Starts deceleration based on an input signal from an external device (EMZ). After a specified time to confirm that the motor has stopped, the SOS function will be activated (SS2-1). Alternatively, the SS2 function winci
SOS (Safe operating stop)	This is a function to monitor whether the servo motor stops within the prescribed range for the stop position. The power is supplied to the servo motor.
SLS (Safely-limited speed)	This is a function to observe whether the speed is within a regulated speed limit value. When the speed is over a specified speed, energy will be shut off by STO.
SSM (Safe speed monitor)	Outputs a safety output signal when the servo motor speed is within a regulated speed.
SBC (Safe brake control)	Outputs a safety output signal for an external brake control.
SDI (Safe direction)	Monitors whether the travel direction of the servo motor is as specified. The STO function shuts off the energy if the direction is different from the specified direction.
SLI (Safely-limited increment)	Monitors whether the travel distance of the servo motor is within the specified range. The STO function shuts off the energy if the travel distance exceeds the specified range.
SLT (Safely-limited torque)	Monitors whether the torque exceeds the specified torque. The STO function shuts off the energy if the torque exceeds the specified torque.
Status monitor (SM)	Outputs a signal that indicates the status of the safety sub-function. This is an original function of the MR-J5 and is not defined in IEC/EN 61800-5-2.

2 About safety

This chapter explains safety of users and machine operators. Please read the chapter carefully before mounting the equipment. In this guide, the specific warnings and caution levels are classified as follows.

_ WARNIN	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
 CAUTION	Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight injury.

- Professional engineer professional engineers should mount this to MR-J5. e, professional engineers should meet all the conditions below. Persons who took a proper training of related work of electrical equipment or persons who can avoid risk based on
- past experience.

 (2) Persons who have read and familiarized himself/herself with this installation guide and operating manuals for the protective devices (e.g. light curtain) connected to the safety control system.

- 2.2 Conditions of use for the product
 (1) MR-J5 complies with a safety standard, but this fact does not guarantee that MR-J5 will be free from any malfunction or failure. The user of this product shall comply with any and all applicable safety standard, regulation or law and take appropriate safety measures for the system in which the product is installed or used and shall take the second or third safety measures other than the product. Dur company is not liable for damages that could have been prevented by compliance with any applicable safety standard, regulation or law.
 (2) Our company prohibits the use of Products with or in any application involving, and we shall not be liable for a default, a liability for defect warranty, a quality assurance, negligence or other tort and a product liability in these
- applications.

 applications.

 Fower plants

 Trains, railway systems, airplanes, airline operations, and other transportation systems

 Hospitals, medical care, dialysis and life support facilities or equipment

 Amusement equipment

- g and drilling applications where the level of risk to human life, health or property are elevated.

2.3 Correct use

CAUTION •If you need to get close to the moving parts of the machine for inspection or other purposes, ensure safety by confirming the power off, etc. Otherwise, it may cause an accident.

Point ●The safety sub-function complies with the immunity-relating basic

The safety sub-function complies with the immunity-relating basic specifications required for functional safety, and fulfills requirements for industrial uses. The safety sub-function is not for general use.

 Functional safety is not available for MR-J5_G4-HS(N1) in a default state. To use functional safety, set the functional safety parameters according to the MR-J5 user's manual.

y professional engineers can use control systems relating to the safety sub-function that are configured with an MR-Additionally, only when a professional engineer installed, performed test operations, and adjusted a machine wing the MR-J5 user's Manuals, an operator can use the machine.

2.4 Safety sub-function compatible unit The safety sub-function is executed by writing parameters and programs to systems configured with the MR-J5 and the safety programmable controllers in the following table. Set the safety sub-function parameters of the MR-J5 correctly for proper operation of the safety sub-function. Protective functions such as the safety sub-function may not work due to an incorrect setting. Refer to the MR-J5 User's Manuals for the parameter setting detail.

(1) List of safety sub-function compatible unit

()	, ,					
	Product name	Model				
Servo amplit	ier/drive unit	MR-J5G(4)-RJ(N1), MR-J5G4-HS(N1), MR-J5WG(-N1), MR-J5DG_(-N1)				
Programmal	ole controller "1	R SFCPU				
W.E. 1. W. C. 1. C						

(2) List of safety sub-function compatible units

(=/ =====, ====, =======================													
Servo amplifier/ drive unit	Function achieving method (wiring direction)	Servo motor type "8	Safety sub-function (IEC/EN 61800-5-2) 7										
			STO	SS1 S		SS2 *3							
				SS1-t	SS1-r *3	SS2-t, SS2-r	SOS "3	SBC	SLS '3	SSM "3	SDI "3	SLI "3	SLT
MR-J5G(4) (-N1) MR-J5A(4) (-RJ)	DI/O connection (CN8)	FS/RO/LI/DD	Cat. 3 PL e, SIL 3	- *9	-	-	i	-	-	-	-	-	-

_	Function		Safety sub-function (IEC/EN 61800-5-2) ^{*7}										
amplifier/ drive unit	achieving method	Servo motor		S	31	SS2 '3		SBC	SLS *3			SLI *3	
	(wiring direction)	type "8	STO	SS1-t	SS1-r "3	SS2-t, SS2-r	SOS ¹³			SSM "3	SDI "3		SLT
R-J5G(4) J(N1) R-J5G4-HS	DI/O connection	FS	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2
1) R-J5WG V1) ⁴ R-J5D1- G	(CN8/CN3)	RO/LI/DD	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2	-	-	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2	Cat. 3 PL d, SIL 2	Cat. 3 PL d, SIL 2		Cat. 3 PL d, SIL 2
	Network connection *1*5 (CN1A/ CN1B)	FS	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2
		RO/LI/DD	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2	-	-	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2	Cat. 3 PL d, SIL 2	Cat. 3 PL d, SIL 2	-	Cat. 3 PL d, SIL 2

- Combine the MR-L5 with a programmable controller R_SFCPU with a firmware version 20 or later. The safety levels in the table algory if the safety sub-function control is performed by a programmable controller, a safety CPU, MR-J5-G4-HS(N1) of a safety controller that complies with Category 4 PL e, Sil. 3. If the MR-J5 are directly connected with emergency slop switches, safety switches, enabling switches, or other similar devices, the safety level
- Cause many the content of the conten

2.5 General cautions for safety protection and protective measures

Point Observe the cautions for safety protection and protective measures

- Observe the items in this section for proper use of the safety sub-function.
- (1) When mounting, installing, and using the safety sub-function, always observe the standards and directives applicable in the respective countries.

 (2) The manufacturer and owner of machines for which the safety sub-function of MR-J5 is used should be familiarized with all the applicable laws and regulations and should be responsible to observe them. For Declaration of Conformity (DoC), our company declares that the MR-J5 is in compliance with the necessary requirements and standards (2006/42/EC, 2014/30/EU, 2014/35/EU, 2011/65/EU, and (EU)2015/863). For the
- requirements and standards (2006/42/EC, 2014/30/EU, 2014/35/EU, 2011/65/EU, and (EU)2015/863). For the copy of Declaration of Conformity, contact your local sales office.

 (3) The contents of the MR-J5 User's Manuals must be observed. When using an encoder manufactured by another company that complies with Mitsubish Electric Serial ENC communication or ABZ-pulse (TTL), also according to the manual for that encoder, estimate the PFH for the whole safety system according to the diagnostic coverage (DC) of the encoder given in specifications under the responsibility of the customer. All the endoder for PDS should comply IEC/EN 61800-5-1 and 5-2 including environmental and ENC.

 When there is no PFH value of encoder, it should be calculate from based MTBF (acceptable range of failure rate of encoder Ad = 50 %, Adu = (1-DC)* Ad). And at least PFH < 9E-7, (for SIL2), PFH < 9E-8 (for SIL 3) or less.

 (1) Tests should be performed by professional engineers, especially qualified and responsible personnel, and should be recorded/documented for a third party to rebuild and confirm the tests.

 (5) An external power supply of equipment should have resistance to instantaneous power failure for 20 ms according to the sepecifications of IEC/EN 60204-1.

2.6 Disposal Disposal of unusable or irreparable devices should always occur in accordance with the applicable country-specific waste disposal regulations.

2.7 Risk assessment
To ensure safety, users should decide all the risk assessments and residual risks in the entire machine equipment. A company and/or individual who constructed the safety related system must take full responsibility for installation and commissioning of the system. Additionally, when complying with a European machinery directive, the system must acquire safety standards certification as a whole.

Perform all risk assessments and safe level certification to the machine or the system as a whole. It is recommended that a Certification 50 by final safety certification of the system be used.

The following shows residual risks concerning the safety sub-function of this product.

2.7.1 Common residual risks in each function
 (1) At the shipment to end-users, check the settings of safety related components with programming tools and

(1) At the shipment to end-users, check the settings of safety related components with programming tools and monitored/displayed contents on display and record and save the setting data concerning the safety sub-function and the programming tools you used. Perform them using a check sheet, etc.
(2) The safety will not be ensured such as in assembling machine until installing, wiring, and adjustment are completed properly. Install, wire, and adjust your system referring to installation guide for each unit.
(3) Only qualified personnel are authorized to install, startup, repair or adjust the machines in which the components are installed. Only trained engineers should install and operate the equipment. (ISO 13849-1:2015 Table F.1 No. 1)

(4) Separate the wiring for the safety sub-function from other signal wirings (ISO 13849-1:2015 Table F.1 No. 1)

Protect the cables with appropriate ways (routing them in a cabinet, using a cable guard, etc.). We recommend using a switch, relay, sensor, etc. which comply with safety standards. When using a switch, relay, sensor, etc. which comply with a sefty standards, perform a safety confirmation. Keep the required clearance/creepage distance depending on voltage you use. The time to detect a safety observation error depends on the parameter setting.

- (8) The time to detect a safety observation error depends on the parameter setting.
 2.7.2 Residual risks specific to each function
 (1) Speed monitoring (SLS)
 (a) Speed monitoring function guarantees the servo motor speed, but it does not guarantee the actual machine safety speed. Set parameters so that the safe speed of the machine is the same as the safety speed of the specified motor.
 (b) Check if the speed of the monitored servo axis is the same as the actual speed by using a tachometer, etc. considering the speed includes an error caused by the command and encoder resolution.
 (c) The defect of the mechanical section such as slid of shaft and wanting of a timing belt, etc. is not covered. Be sure to eliminate the risk of mechanical section before operation.
- (c) The defect of the mechanical section such as slid of shaft and wanting of a timing belt, etc. is not covered. Be sure to eliminate the risk of mechanical section before operation.
 (d) Speed monitoring error detection time is set to 1 ms. Errors in shorter than this time are not detected.
 (e) After speed is over the limit, a safety observation error (shut-off signal off) does not occur during the speed error detection time set by parameters. Make sure that safety can be ensured during this period.
 (2) Safe speed monitor (SSM)
 When SSM is used as a restart trigger, perform it according to IEC/EN 60204-1.

- When SSM is used as a restart trigger, perform a according to Lecture This function guarantees only that power to mechanic break is properly supplied and abrasion of the brake cannot be detected. Check this function regularly that the mechanic brake can operate.

 (4) Safe stop holding (SOS)

 If the motor remains at the same stop position for a long time, move the motor slightly from time to time to prevent a cumulative malfunction.
 (5) Safe travel distance limit (SLI)
- Sale travel distance inflit (SLI) if the motor shaft (or a coil, if a linear servo motor is used) remains at a stop for a long time after the motor has traveled as specified, switch the function to the SOS function.

 Safe rotation direction limit (SDI) if the motor shaft (or a coil, if a linear servo motor is used) remains at a stop for a long time after the motor has traveled as specified, switch the function to the SOS function.

3. Using safety sub-functions and block diagram


unctions.
(1) Using safety sub-functions by MR-J5 The safety sub-functions can be used by assigning them (STO, SLS, etc.) to CN8/CN3.

CN8/CN3.

(2) Using safety sub-functions by combining with safety programmable controllers controllers The MR-J5-_G(4)_-RJ, MR-J5-_G4-HS, MR-J5W_-_G and MR-J5D_-_G_ are used to establish a safe communication with safety programmable controllers via CC-Link E TSN. This enables the electrical

IE TSN. This enables the electrical wirings (for example STO) to the MR-J5 to be omitted.

Jusing safety sub-functions by combining with FSoE Master The MR-J5- G(4) - R.IN1, MR-J5- G4-HSN1, MR-J5V- G-N1, and MR-J5D - G-N1 are used to establish safe communication with the FSoE Master via FSoE. This enables the electrical wirings (for example STO) to electrical wirings (for example STO) to the MR-J5 to be omitted.



The built-in regenerative resistor is not used for MR-J5-10G.
Servo amplifiers with the rated output symbol of 70 (MR-J5-70G_) or greater have a cooling fan.
To configure an absolute position detection system by using a direct drive motor, the battery is required. To configure the absolute position detection system by using the HK series servo motor, the battery is not required.
4 Support encoder type are OSBA/OBSA/CBW/
CSW, another company encoder that complies with Mitsubishi Electric
Serial ENC communication and ABZ-pulse.

4. Technical specifications

	Model	MR-J5G(4)-RJ(N1)/MR-J5WG(-N1)/ MR-J5DG_(-N1)	MR-J5G4-HS(N1)			
	Standards "1	EN ISO 13849-1:2015 Category 4 PL e, IEC 61508 SIL 3, EN IEC 62061:2021 maximum SIL 3, EN 61800-5-2				
	Mean time to dangerous failure (MTTFd)	MTTFd ≥ 100 [years] (750a)	MTTFd ≥ 100 [years] (300a)			
Safety performance	Diagnostic coverage (DC)	DC = Medium, 96.5 [%]				
periormance	Probability of dangerous Failure per Hour (PFH)	PFH = 3 × 10 ⁻⁹ [1/h]	PFH = 7.7 × 10 ⁻⁹ [1/h]			
	Mission time (T _M) *2	T _M = 20 [year]				

*1 For DI/O connection (CN8/CN3), a diagnosis using test pulses is required to satisfy Category 4 PL e, SIL 3.
*2 The performance of special proof tests within the mission time of the product is regarded as not necessary. For example, on IEC 61800-5-2:2016, the diagnostic interval is suggested as at least one test per three months for Category 3 PL e, SIL 3.

	Mod	el	MR-J5G(4)-RJ(N1)/ MR-J5WG(-N1)/MR-J5DG_(-N1)	MR-J5G4-HS(N1)						
	STO Shut-off response time (STO input off → energy shut off)		8 ms or less (when an input device is used) 60 ms or less (with CC-Link IE TSN) ³⁻⁴⁻⁷ 60 ms or less (with EtherCAT) ⁴⁻⁷⁻⁸							
	SS1	Deceleration delay time	0 ms to 60000 ms (set by functional safety parameters)							
	SS2	Deceleration delay time	0 ms to 60000 ms (set by fu	nctional safety parameters)						
	SOS	Observation position	0 rev to 1000 rev (set by fur							
Safety sub- function "1"2	SBC	Shut-off response time	8 ms or less (when an 60 ms or less (with C 60 ms or less (with	input device is used) C-Link IE TSN) 13 14 77 h EtherCAT) 14 17 18						
	SLS1/2/3/4	Observation speed	0 r/min (mm/s) to 10000 r/min (mm/s) (
	SSM	Observation speed	0 r/min (mm/s) to 10000 r/min (mm/s)	(set by functional safety parameters)						
	SDI	Direction monitor delay time	0 ms to 60000 ms (set by fu	nctional safety parameters)						
	SLI	Observation position	0 rev to 1000 rev (set by functional safety parameters)							
	SLT	Observation torque	-1000.0 % to 1000.0 % (set by	functional safety parameters)						
	Input device	Number of input points (double wiring)	1 point	3 points						
		Mismatched permissible time of redundant input mismatch detection	0 ms to 60000 ms (set by functional safety parameters)							
		Noise eliminating filter	1.000 ms to 32.000 ms (set by functional safety parameters)							
		Test pulse off time '6	Within 1 ms							
		Test pulse interval *6	250 ms to 1000 ms							
I/O function	Output	Number of output points (double wiring)	1 point	3 points						
	device	Test pulse off time	0.500 ms to 2.000 ms (set by	functional safety parameters)						
		Test pulse interval	Within 1 s							
	External	Number of output points (double wiring)		1 point						
	wiring diagnostic output	Test pulse off time		1.000 ms/2.000 ms (set by functional safety parameters)						
	output	Test pulse interval		Within 1 s						
		Response time	250 ms (Transmission interval monitor ti 250 ms (FSoE Watchdog Time	within 60 ms) (with EtherCAT)						
Safe commun	ication	Transmission interval monitor time	16.0 ms to 1000.0 ms (set by (with CC-Lin	functional safety parameters) k IE TSN) ⁷						
iuncioff		FSoE Watchdog Time	16.0 ms to 65534.0 ms (set b	y objects) (with EtherCAT) "7						
		Safe communication delay time	60 ms or less (with 0 60 ms or less (wi	CC-Link IF TSN) "3"7						

is and safety levels differ depending on the combination of the MR-J5 and the servo motors. Refer to 2.4 (2). on (CN8/CN3), a diagnosis using test pulses is required to satisfy Category 4 PL e, SIL 3. icable when the transmission interval monitor time is 32.0 ms or less.


This value is applicable when the transmission interval monitor time is 32.0 ms or fess.

For the MR-JS- (6/H-Z) MR-JS- 6-4HS and MR-JSD-1-G. connect to a network with a communication cycle of 125 us or longer. For the MR-JS- (6/H-Z) MR-JS- (4/H-Z) MR-JS- (4/H-

5 The safety observation speed can be set separately, 6 A test pulse is a signal which instantaneously turns off a signal of the MR-J5 at a constant period for external circuits to perform self-diagnosis 7 The specifications are for using the safety-sub functions via a network connection.
8 This value is applicable when FSOE Watchdog Time is 30.0 ms or less.

4.3 When using the I/O of the CN8/CN3 connector of the MR-J5 This I/O function can be used when the safety sub-function control by network is not used.

4.3.1 I/O signal sequence
An operation sequence with the SLS function achieved by the input wiring CN8-4 and CN8-5 pins is shown as an example.



4.3.2 Selecting input devices
The input devices can be assigned to CN8/CN3 by functional safety parameters. (Refer to chapter 5)
The safety sub-functions can be activated with axis-A itself by using an input signal, and also can be activated with axis-A, B, and C at the same time.


Input signal
STOC (STO command), SS1C (SS1 command), SS2C (SS2 command), SLS1C (SLS1 command), SDIPC (SDIP command), SDINC (SDIN command), SLIC (SL1 command), and SLT1C (SLT1 command)
onimard, etc (etc. commund), and etc. to (etc.) commund)
4.3.3 Output signal sequence
An operation sequence with STOS (STO output) assigned to the input wiring CN8-6 and CN8-7 pins is shown as an

example.		Pulses to turn off the signal will be output periodically to
STOS (STO output)	ON OFF	the CN8-6 and CN8-7 pins when STOS (STO output) is turned on. The pulses to turn off the signal will be output
CN8-6 pin	ON Test pulse off time for the safety output device	from the CN8-6 and CN8-7 pins separately at different timings, and the pulses will not be output at the same time. The length of time for outputting the pulses to turn
CN8-7 pin	on	off the signal can be set in [Pr. PSD30 Output device - Test pulse off time]. Make sure that the time length for the output pulses to turn off the signal will not affect the
	OFF Test pulse off time for the safety output device	external devices.

4.3.4 Selecting output devices
The output devices can be assigned to CN8/CN3 by functional safety parameters. (Refer to chapter 5)
If a multi-axis servo amplifier/multi-axis drive unit are used, it is possible to select which axis will output a signal to the output signal. Outputting a signal only from axis-A is possible, and outputting signals from axis-A, B, and C by AND output is also possible.

STOS (STO output), SS1S (SS1 output), SS2S (SS2 output), SLS1S (SLS1 output) to SLS4S (SLS4 output), SSMS (SSM output) SOSS (SOS output), SBCS (SBC output), SDIPS (SLIP output), SDINS (SDIN output), SLS1S (SLI output), and SLT1S (SLT1 output) to SLT4S (SLT4 output)

Signals
 Connector pin assignment of the safety sub-function I/O signals
 The following shows connector pin assignments of the MR-J5-10C-RJ and the MR-J5-500G4-HS as a typical example.
 Refer to "MR-J5 User's Manual (Hardware)" for precautions for wiring or other operations.
 (1) MR-J5-10C-RJ (2) MR-J5-500G4-H)



Assign the input devices to CN8/CN3 by functional safety parameters. The devices can be input via network if the safety sub-function is controlled by network.

Devices	Symbol	Connector-pin No.	FUNCTION	Input pin states that enable functions
STO command	STOC		The STO function operates by the STO command.	Open
SS1 command	SS1C		The SS1 function operates by the SS1 command.	Open
SS2 command	SS2C	0.10.4	The SS2/SOS functions operate by the SS2 command.	Open
SLS1 command to SLS4 command	SLS1C to SLS4C	CN8-4 CN8-5 CN3-8A CN3-8B	The SLS function 1 to SLS function 4 operates by the SLS1 command to SLS4 command. Four sets of SLS speed and SLS deceleration monitor time can be set with the SLS function.	Open
SDIP command	SDIPC	CN3-12A CN3-12B	The SDIP command activates the SDI function for the address increasing direction.	Open
SDIN command	SDINC	CN3-13A CN3-13B	The SDIN command activates the SDI function for the address decreasing direction.	Open
SLI command	SLIC		The SLI command activates the SLI function.	Open
SLT1 command to SLT4 command	SLT1C to SLT4C		The SLT function 1 to SLT function 4 operates by the SLT1 command to SLT4 command. Four sets of SLT torque upper limit value and SLT torque lower limit value can be set with the SLT function.	Open

5.3 Output devices
The CN8/CN3 output the status monitor (SM) of the safety sub-function. The output devices can be assigned to CN8/CN3 by functional safety parameters. The status monitor can be output via network if the safety sub-function is controlled by network. In that case, the CN8/CN3 can also be used at the same time.

Devices	Symbol	Connector- pin No.	FUNCTION	Output pin status during operation
SSM output	SSMS		Indicates that the servo motor speed is equal to or lower than the SSM speed while the speed monitoring by the SSM function is activated.	Close
SBC output	SBCS	1	Outputs a control signal of the electromagnetic brake.	Open
STO output	STOS	CN8-6	This is a monitor output signal meaning that the STO function is operating.	Open
SOS output	SOSS	CN8-7 CN3-11A	This is a monitor output signal meaning that the SS2/SOS function monitors the servo motor is in the stop state.	Open
SS1 output	SS1S	CN3-11B CN3-14A	This is a monitor output signal meaning that the SS1 function is operating.	Open
SS2 output	SS2S	CN3-14A CN3-14B	This is a monitor output signal meaning that the SS2/SOS function is operating.	Open
SLS1 output to SLS4 output	SLS1S to SLS4S	CN3-15A CN3-15B	This is a monitor output signal meaning that the SLS function 1 to SLS function 4 are operating.	Open
SDIP output	SDIPS	CN3-16A	This is a monitor output signal indicating that the SDI function has been activated.	Open
SDIN output	SDINS	CN3-16B	This is a monitor output signal indicating that the SDI function has been activated.	Open
SLI output	SLIS	1	This is a monitor output signal indicating that the SLI function has been activated.	Open
SLT1 output to SLT4 output	SLT1S to SLT4S		This is a monitor output signal indicating that the SLT function 1 to SLT function 4 has been activated.	Open

Setting method
 using the safety sub-function, follow the procedure in this chapter.

3 , ,	
Step	Detailed explanation
Checking the wiring	Check that the CN8/CN3 connector and network have been wired correctly.
Setting functional safety parameters	Refer to information on the settings of the function and set functional safety parameters.
Setting a password	Set a password for the functional safety parameters to prevent them from being changed easily.
Verifying functional safety parameters	Read the functional safety parameters to verify that they have been set correctly.
Ensuring the correct functioning of safety sub-functions	Ensure that the safety sub-functions work correctly.

6.1 Parameter setting
The safety sub-function parameters can be set with MR Configurator2. Settings related to the safety sub-function are configured with this group of parameters. The safety sub-function parameters have a password to prevent unintended changes of the parameters. The password is "000000" at the factory setting.

Parameter	Name	Detailed explanation
PSA01.0	Safety sub-function activation setting	Set this parameter to "1" only after confirming the settings of the functional set by functional safety parameters.
PSA01.1	Input mode selection	Set the safety sub-function to be controlled either by input device or by network.
PSA02	Functional safety setting	Recommended parameter settings and achievable safety levels differ depending on the system configuration.
PSA03	SS1/SS2 deceleration monitor time	Settings of the parameters for the SS1 function are necessary as the SS1 function is to be used if a problem is found by self-diagnosis.
PSA20	Servo motor encoder resolution	Set the encoder resolution of the servo motor being connected. This parameter does not need to be set if position/speed monitoring is not performed.
PSA23	Servo motor rated speed	The rated speed of the servo motor being connected must be set if speed monitoring is performed.
PSC03	Functional safety - Rotation direction selection/ Movement direction selection	Set the same value in [Pr. PSC03.0] and [Pr. PA14 Rotation direction selection/travel direction selection].
PSL02	Functional safety - Linear motor encoder resolution - Numerator	The observation direction by the SDIP command is the address increasing direction. If POL is set to "1", the observation direction is the address increasing direction (CW or negative direction).
PSL03	Functional safety - Linear motor encoder resolution – Denominator	If position/speed monitoring is performed with a linear servo motor, set this parameter to the same value as [Pr. PL02] and [Pr. PL03].

6.2 Test operation Test operation can be performed with the safety sub-function temporarily disabled. Set [Pr. PSA01.1 Input mode setection] to "2". Some of the diagnosis functions and the safety sub-functions are disabled in the test operation. The test operation can be used for JOG operation, positioning operation, machine analyzer, or other operations devices have not been started up. devices have not been started up. To end the test operation, set [Pr. PSA01.1 Input mode selection] to "0" or "1" depending on the system configuration

being used.
7. Troubleshooting

Petails of main alarms related to the safety sub-function are shown in the following table.

STO timing error	063.1	When detection of [AL. 063 STO timing error] is enabled, STO1 was turned off (enabled) under the following speed conditions.	After the servo motor stops, turn off (enable) STO1. Review the setting of "STO timing error selection" by using any following parameters. IAI: [Pr. PF09. 15 To timing error selection]
		When detection of [AL. 063 STO timing error] is enabled, STO1 was turned off (enabled) under the following speed conditions. Rotary servo motor speed: 50 r/min or higher Linear servo motor speed: 50 m/ms or higher Direct drive motor speed: 5 tr/min or higher	[A]: [Pr. PF09.1 STO timing error selection] [G]: [Pr. PF06.1 STO timing error selection]
	063.2	Ulirect drive motor speed: 5 mini or higher When detection of [AL. 063 STO timing error] is enabled, STO2 was turned off (enabled) under the following speed conditions: Rotary servo motor speed: 50 mins or higher Linear servo motor speed: 50 mins or higher linear servo motor speed: 50 mins or higher linear servo motor speed: 50 mins or higher There is a problem with the encoder cable.	After the servo motor stops, turn off (enable) STO2. Review the setting of "STO timing error selection" by using any following parameters. IAL [Pr. PF09.1 STO timing error selection]
Encoder initial communication - Receive data error 1 (safety sub-function)	066.1 516.1	There is a problem with the encoder cable.	Check if the encoder cable has been disconnected or has shorthere is a problem with the cable, repair or replace the cable.
STO diagnosis error	068.1	STO1 or STO2 is inputted incorrectly.	Check that STO1 and STO2 of the CN8/CN3 connector are wir correctly.
		The input status of STO1 and STO2 are different. The setting of [Pr. PF18 STO diagnosis error detection time] is incorrect.	If the on/off status of STO1 and STO2 are different, create the simput status for STO1 and STO2. Set a longer time in the servo parameter setting, and then checrepeatability. If the error does not repeat, review the value of th servo parameter.
	000.4	The STO circuit has malfunctioned.	Replace the MR-J5.
Network communication	086.1	A network cable has been disconnected.	Check if the network cable is connected correctly.
STO function error	168.1	An MR-J5 that is not compatible with the STO function does not have a short-circuit connector connected to its CN8/CN3 connector.	Install the short-circuit connector attached to the MR-J5 in the CN3.
Position feedback error (safety sub-function)	52A.1	The position feedback data does not change within the time set in [Pr. PSA22 Position feedback error detection time].	Review the setting of [Pr. PSA22]. Alternatively, perform operal the end of the time set within [Pr. PSA22].
Parameter setting range error (safety	537.1	A functional safety parameter has been set outside of its setting range.	Check the parameter error No. on the alarm display screen of No. on the No. o
sub-function)	537.2	A servo parameter or a functional safety parameter has been set incorrectly.	Check the parameter error No. on the alarm display screen of No. on the alarm display
Parameter verification error (safety sub-function)	53A.2	A functional safety parameter has an error.	Check the parameter which has an error with MR Configurator set the parameter correctly.
Output device diagnosis error 1 (safety	555.1	A signal of an output device has not been output correctly or the load of the output device is out of the specification range.	Check if the output device cable is wired correctly. Alternatively check if the load of the output device is within specifications.
sub-function)		Current of an output device is too large.	Check if the current value is within specifications. If the value is specifications, lower the output current.
Input device mismatch detection (safety sub- function)	557.1	The input signal mismatch between the CN8-4 pin and the CN8-5 pin or the CN3-8A and the CN3-8B continued longer than the specified time (the time set in [Pr. PSD18 Mismatch permissible time SD11)).	Review the wiring. Alternatively, set [Pr. PSD18 Mismatch permissible time SDI1] longer time than the mismatched time between the CN8-4 pin a CN8-5 pin or the CN3-8A and the CN3-8B.
Stop error (safety sub- function)	560.1	The state where the absolute value of the servo motor speed exceeds [Pr. PSA04 Safety subfunction - Stop speed] continued for longer than the time set in [Pr. PSA15 Safety subfunction - Speed detection dejay time] while the SOS	Check the parameter or the operation pattern. If the motor overshoots as it stops, reduce the overshoot by ad the gain, setting a longer time in [Pr. PSA15], or by other mean
Safety speed monitor error 1 (safety sub- function)	561.1	The state where the absolute value of the servo motor speed exceeds [Pr. PSA11 SLS speed 1] continued for longer than the time set in [Pr. PSA15 Speed detection delay time] while the SLS function is activated. The settins of the electronic gear are incorrect.	Check the parameter or the operation pattern. Take actions such as setting the speed command to a value or of lower than [Pr. PSA17] of setting time required for decelerat [Pr. PSA07 SLS deceleration monitor time 1].
		The settings of the electronic gear are incorrect. The connection destination of the encoder cable is incorrect.	Check the setting value of the electronic gear. Check the connection destination of the encoder.
Deceleration monitor error (safety sub- function)	563.1	The servo motor speed exceeded the speed which is determined by the observation speed of when the SS1 command has been turned off and the observation speed according to [Pr. PSA24 SS1/SS2 Deceleration observation time constant].	Check the parameter or the operation pattern. Take actions such as setting a longer time in [Pr. PSA26 SS1/6 deceleration monitor delay time] or adjusting the servo gains.
		The connection destination of the encoder cable is incorrect.	Check the connection destination of the encoder.
		There is a problem with the servo motor or servo motor power cable.	Replace the servo motor or servo motor power cable.
Increment monitor error (safety sub- function)	564.1	The feedback position traveled by more than the permissible travel distance specified by the parameter ([Pr. PSB02 SLI permissible travel distance (positive direction)] and [Pr. PSB07 SLI permissible travel distance (negative direction)]) after the SLI function has been activated.	Check the parameter or the operation pattern. Check if the SLI command has been input before the servo mo stop has been confirmed.
Direction monitor error (safety sub- function)	565.1	increasing direction while the SDI function is activated. The connection of the serve motor is incorrect	Check the parameter or the operation pattern. Check if a command for the address increasing direction has b input. Check the U/V/W wiring.
Torque monitor error 1 (safety sub- function)	568.1	The torque feedback exceeded the torque specified in the parameters ([Pr. PSB12 SLT1 Torque (positive direction)] and [Pr. PSB16 Torque (negative direction)]) after the SLT function has been activated.	Check the parameter or the operation pattern. Check if the threshold of the torque monitor is too small or if the motor collides with the machine.
Safety communication setting error (safety sub- function)	580.3	the satety verification code of the controller and the setting of [Pr. PSC06 Safety verification code] do not match.	The controller may have been communicated with an unintend US. Check if the IP address of the safety communication setting on master station matches the IP address setting of the correspor MR-J5. Review the setting of FSoE Address in FSoE Master or the set
FSoE Address mismatch error (safety sub-function)	584.1	FSoE Address set in FSoE Master does not match the setting of [Pr. PSC07 FSoE Address setting].	Review the setting of FSoE Address in FSoE Master or the set [Pr. PSC07 FSoE Address setting].
FSoE communicatio n parameter setting error (safety sub- function)	584.2	The setting value of FSoE Watchdog Timer notified from FSoE Master does not correspond to the MR-J5.	Review the setting value of FSoE Watchdog Timer set in FSoE Master.
FSoE communicatio n error 2 - Receive time- out error (safety sub- function	586.5	The safe communication update time exceeded the time set in FSoE Watchdog Time.	Review the setting value of FSoE Watchdog Time set in FSoE Master.

8. Maintenance, inspection, and environment Refer to chapter 6 and 7 in "MR-J5 Safety Instructions and Precautions for AC Servos (IB(NA)0300391)" or "MR-J5D Safety Instructions and Precautions for AC Servos (IB(NA)0300527)". 9. Check list for user documentation

Refer to chapter 9 in "MR-J5 Safety Instructions and Precautions for AC Servos (IB(NA)0300391)" or "MR-J5D Safety Instructions and Precautions for AC Servos (IB(NA)0300527)".