FR Configurator SW3 Installation Manual

1. Compatible Operating System

This software is compatible with the following English operating system (OS).

· Microsoft® Windows® 10, Windows® 8.1/Pro/Enterprise, Windows® 8, Windows® 7 (32-bit Edition and 64-bit Edition)
· Microsoft® Windows Vista® SP1 or later (32-bit Edition)
· Microsoft® Windows® XP Professional SP2 or later (32-bit Edition)
· Microsoft® Windows® XP Home Edition SP2 or later
· Microsoft® Windows® 2000 Professional SP4 or later

2. Compatible Inverters

FR Configurator SW3 is compatible with the FR-A700, FR-A701, FR-D700, FR-E700(SC)(NC) FR-F700, FR-E700EX, and FR-D700-G,series.

3. Installation/Uninstallation

Log in as a user with administrator permission, and start the installation. Install this software in accordance with the following procedure. In an operation system with antivirus / security software, a warning may appear when installing FR Configurator. If a warning appears, verify the installation of FR Configurator according to the setting procedure of your antivirus/security software.

(1) Installation procedure

Start installation	Inserting a CD-ROM automatically starts the Install Shield Wizard.* Install according to the Install Shield Wizard. If it does not automatically start, perform "setup.exe" in the top folder of the CD-ROM.
Customer Information	Enter user name and company name.
Choose Destination Location	Check the installing location of the software. (Installing location can be chanded.)
Select Features	Check the installing software. (VFD Setup Software SW1 can be installed.)
Completed	Start the software to check that the software is properly installed.

* When installing to Windows Vista and Windows 7, "AutoPlay" window may appear. Select [Run setup.exe] to continue the installation.

For detailed installation procedure, refer to a software manual on this CD-ROM.
Refer to page 2/8 for the manual of this software.

If a window on right is displayed during the installation, click [Continue Anyway] to continue the installation.

(When installing this software to Microsoft® Windows Vista®, Microsoft® Windows® 7,Microsoft® Windows® 8,Microsoft® Windows® 8.1, or Microsoft® Windows® 10 a different window appears. Refer to the instruction manual of this software before the installation.)

Screen when Microsoft® Windows® XP Professional is used

(2) Uninstallation procedure

Open the [Start] menu of Windows, and then click [Control panel]. Click "Add or Remove Programs" in the "Control panel" window.
When "Add or Remove Programs" window is displayed, select the deleting software and click [Remove] to start uninstallation.
FR-SW3-SETUP-WE CC-Link Seamless is also uninstalled when uninstalling FR-SW3-SETUP-WE.

Screen when Microsoft® Windows® XP Professional is used

4. Manual

(1) The manual of this software is stored on the CD-ROM.
To refer to the manual (PDF data), cancel the InstallShield Wizard, then display the contents of the CD-ROM with Explorer etc., and open "ib0600306eng*.pdf" in "manual" folder. For the manual (PDF data) of FR-SW3-SETUP-WE CC-Link Seamless, open "ib0600439eng*.pdf" file.
* represents an alphabet indicating version.

(2) Adobe® Reader® is necessary to read the manual (PDF data) on the CD-ROM.

VFD Setup Software SW1 (FR-SW1-SETUP-WE) Installation Manual

1.   Compatible Operating System

This software is compatible with the following English operating system (OS).

· Microsoft® Windows® XP Professional SP2 or later (32-bit Edition)
· Microsoft® Windows® XP Home Edition SP2 or later
· Microsoft® Windows® 2000 Professional SP4 or later

2.   Compatible Inverters

When using the following inverters, use VFD Setup Software SW1 (FR-SW1-SETUP-WE) in the following procedure.

Software	Compatible Inverters
VFD Setup Software SW1 (FR-SW1-SETUP-WJ)	FR-V500(L), FR-A500(L), FR-F500(L), FR-E500, FR-S500(E), FR-F500J, FR-C500, FR-F700

Refer to the software manual for the compatible inverters.

3.   Installation

Proceed the installation referring to the previous page. Select "VFD Setup Software SW1" at [Select Features] window to install VFD Setup Software SW1.

4.   Instructions

· If VFD Setup Software (FR-SW1-SETUP-WE) of an older version (CD-ROM) is installed after the installation of the FR Configurator SW3, FR Configurator SW3 does not function. In this case, please uninstall FR Configurator SW3, and then install FR Configurator SW3 again.
· In an operation system with antivirus/security software, a warning may appear when installing FR Configurator. If a warning appears, verify the installation of FR Configurator according to the setting procedure of your antivirus/security software.

5.   Uninstallation

Same procedure as the FR Configurator SW3. Refer to page 2/8.

Instructions for installation using Windows 8 or Windows 8.1

If installation is attempted on a Windows? 8 (32-bit edition) system in which the 16-bit application support is not enabled, the following dialog may appear. To install FR Configurator, perform the following procedure.

(1) If the following dialog appears, click the [Enable] button to continue installation.

Click [↓] ➝

(2) If the following dialog appears, click the [OK] button to cancel the installation, and perform the following procedure.

•Solution
Enable the 16-bit application support as follows, and retry the installation.

In the Control Panel window, enter "16" in the Search Control Panel box and start the search.

Enter "16"

Select "16-Bit Application Support".

Select "16-Bit Application Support"

In the "16-Bit Application Support" window, click the [Enable] button to enable the support.


Click [↓] →

If installation is attempted on a Windows 8.1 (32-bit edition) system in which NTVDM is not installed, the following dialog may appear.

•Solution

When the message "An app on your PC needs the following Windows feature: NTVDM" is displayed, select "Install this feature".

Select "Install this feature"

NTVDM is installed.