

Denial-of-Service (DoS) Vulnerability due to Realtek Chips

Vulnerability in Wi-Fi Communication Processing of Multiple Home Appliances

Release date: March 24, 2026
Mitsubishi Electric Corporation

Overview

Denial-of-Service (DoS) vulnerability due to Heap-based Buffer Overflow (CWE-122¹) exists in the Wi-Fi driver for a Realtek chip of multiple Mitsubishi Electric home appliances.

An attacker may be able to cause a buffer overflow during the product's Wi-Fi frame reception process to temporarily stop Wi-Fi communication by sending specially crafted Wi-Fi frames from a device connected to the affected product via Wi-Fi. As a result, legitimate users may be unable to register devices, operate appliances, or obtain information from smartphones and similar devices (CVE-2025-49604).

These products do not store confidential information such as personal data, and this vulnerability does not present a risk of information disclosure or unauthorized device operation.

In addition, the following products or operating environments are not affected by this vulnerability.

- Products that do not support Wi-Fi communication.
- Wi-Fi-capable products that are not actually connected to Wi-Fi.

CVSS²

CVE-2025-49604 CVSS:4.0/AV:A/AC:L/AT:N/PR:L/UI:N/VC:N/VI:N/VA:L/SC:N/SI:N/SA:N Base Score 5.1

Affected Products

The affected products and versions are listed in the table under "Countermeasures for Product" by model number and affected version. For update procedures and how to check the version, refer to the user manuals for each product application (such as "Kirigamine REMOTE" and "MyMU").

Description

A denial-of-service (DoS) vulnerability (CVE-2025-49604) due to Heap-based Buffer Overflow (CWE-122) caused by insufficient frame-size validation during reassembly of fragmented Wi-Fi frames exists in the Wi-Fi driver for a Realtek chip used in multiple Mitsubishi Electric home appliances.

Impact

An attacker may be able to cause a buffer overflow during the product's Wi-Fi frame reception process to temporarily stop Wi-Fi communication by sending specially crafted Wi-Fi frames from a device connected to the affected product via Wi-Fi. As a result, legitimate users may be unable to register devices, operate appliances, or obtain information from smartphones and similar devices.

If Wi-Fi communication on the affected product temporarily stops, it recovers automatically by rebooting itself. If it does not recover automatically, please restart it manually.

Countermeasures for Customers

Customers using the affected products should update to the fixed version according to the measures described in "Countermeasures for Product."

Until the fixed version is released, please take the measures described in "Mitigations / Workarounds."

Countermeasures for Product

The fixed products and versions are listed in the table below by model number, fixed version, and details of measures.

¹ <https://cwe.mitre.org/data/definitions/122.html>

² <https://www.first.org/cvss/v4-0/specification-document>

[1] Room Air Conditioners (for Japan)

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-BKR2223-W MSZ-BKR2224-W MSZ-BKR2523-W MSZ-BKR2524-W MSZ-BKR2823-W MSZ-BKR2824-W MSZ-BKR3623-W MSZ-BKR3624-W MSZ-BKR4023S-W MSZ-BKR4024S-W MSZ-BKR5623S-W MSZ-BKR5624S-W MSZ-BKR6323S-W MSZ-BKR6324S-W MSZ-BKR7123S-W MSZ-BKR7124S-W MSZ-BXV2223-W MSZ-BXV2224-W MSZ-BXV2225-W MSZ-BXV2226-W MSZ-BXV2523-W MSZ-BXV2524-W MSZ-BXV2525-W MSZ-BXV2526-W MSZ-BXV2823-W MSZ-BXV2824-W MSZ-BXV2825-W MSZ-BXV2826-W MSZ-BXV3623-W MSZ-BXV3624-W MSZ-BXV3625-W MSZ-BXV3626-W MSZ-BXV4023S-W MSZ-BXV4024S-W MSZ-BXV4025S-W MSZ-BXV4026S-W MSZ-BXV5623S-W MSZ-BXV5624S-W MSZ-BXV5625S-W MSZ-BXV5626S-W MSZ-BXV6323S-W MSZ-BXV6324S-W MSZ-BXV6325S-W MSZ-BXV6326S-W MSZ-BXV7123S-W MSZ-BXV7124S-W MSZ-BXV7125S-W MSZ-BXV7126S-W MSZ-EM2220E8-W MSZ-EM2221E9-W MSZ-EM2221E9-W-1 MSZ-EM2222E1-W MSZ-EM2222E1-W-1 MSZ-EM2222E1-W-2 MSZ-EM2223E3-W MSZ-EM2224E4-W MSZ-EM2225E5-W MSZ-EM2226E6-W MSZ-EM2520E8-W MSZ-EM2521E9-W	41.00 and prior	42.00 or later	<p><u>The fixed version is scheduled to begin release between early April and late July 2026.</u></p> <p>Once the fixed version is released, please update the software according to the procedure below.</p> <p>The countermeasure is implemented in adapter software version 42.00 or later.</p> <p>Please update to the fixed version via the "MyMU" application or the "Kirigamine REMOTE" application.</p> <p>[For MyMU users] Check and update the software version from "Adapter Information" under "Registered Devices" in the "MyMU" application.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p> <p>[For Kirigamine REMOTE users] Check and update the software version from "Wireless LAN Software Update" in "Air Conditioner Management" - "(Room Name)" in the "Kirigamine REMOTE" application.</p> <p>For details, refer to the Kirigamine REMOTE user manual at the site below. https://www.mitsubishielectric.co.jp/home/kirigamine/function/remote/ib.html (In Japanese)</p> <p>If you use only HEMS, please install and configure the Kirigamine REMOTE application by referring to the Kirigamine REMOTE manual so that you can check and update the version.</p>

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-EM2521E9-W-1	<u>Same</u>	<u>Same</u>	<u>Same as above</u>
MSZ-EM2522E1-W	<u>as above</u>	<u>as above</u>	
MSZ-EM2522E1-W-1			
MSZ-EM2522E1-W-2			
MSZ-EM2523E3-W			
MSZ-EM2524E4-W			
MSZ-EM2525E5-W			
MSZ-EM2526E6-W			
MSZ-EM2820E8-W			
MSZ-EM2821E9-W			
MSZ-EM2821E9-W-1			
MSZ-EM2822E1-W			
MSZ-EM2822E1-W-1			
MSZ-EM2822E1-W-2			
MSZ-EM2823E3-W			
MSZ-EM2824E4-W			
MSZ-EM2825E5-W			
MSZ-EM2826E6-W			
MSZ-EM3620E8-W			
MSZ-EM3621E9-W			
MSZ-EM3621E9-W-1			
MSZ-EM3622E1-W			
MSZ-EM3622E1-W-1			
MSZ-EM3622E1-W-2			
MSZ-EM3623E3-W			
MSZ-EM3624E4-W			
MSZ-EM3625E5-W			
MSZ-EM3626E6-W			
MSZ-EM4020E8S-W			
MSZ-EM4021E9S-W			
MSZ-EM4021E9S-W-1			
MSZ-EM4022E1S-W			
MSZ-EM4022E1S-W-1			
MSZ-EM4022E1S-W-2			
MSZ-EM4023E3S-W			
MSZ-EM4024E4S-W			
MSZ-EM4025E5S-W			
MSZ-EM4026E6S-W			
MSZ-EM5620E8S-W			
MSZ-EM5621E9S-W			
MSZ-EM5621E9S-W-1			
MSZ-EM5622E1S-W			
MSZ-EM5622E1S-W-1			
MSZ-EM5622E1S-W-2			
MSZ-EM5623E3S-W			
MSZ-EM5624E4S-W			
MSZ-EM5625E5S-W			
MSZ-EM5626E6S-W			
MSZ-EM6320E8S-W			
MSZ-EM6321E9S-W			
MSZ-EM6321E9S-W-1			
MSZ-EM6322E1S-W			
MSZ-EM6322E1S-W-1			
MSZ-EM6322E1S-W-2			
MSZ-EM6323E3S-W			
MSZ-EM6324E4S-W			
MSZ-EM6325E5S-W			
MSZ-EM6326E6S-W			
MSZ-EM7120E8S-W			
MSZ-EM7121E9S-W			
MSZ-EM7121E9S-W-1			
MSZ-EM7122E1S-W			

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-EM7122E1S-W-1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-EM7122E1S-W-2			
MSZ-EM7123E3S-W			
MSZ-EM7124E4S-W			
MSZ-EM7125E5S-W			
MSZ-EM7126E6S-W			
MSZ-EM8020E8S-W			
MSZ-EM8021E9S-W			
MSZ-EM8021E9S-W-1			
MSZ-EM8022E1S-W			
MSZ-EM8022E1S-W-1			
MSZ-EM8022E1S-W-2			
MSZ-EM8023E3S-W			
MSZ-EM8024E4S-W			
MSZ-EM8025E5S-W			
MSZ-EM8026E6S-W			
MSZ-EM9020E8S-W			
MSZ-EM9021E9S-W			
MSZ-EM9021E9S-W-1			
MSZ-EM9022E1S-W			
MSZ-EM9022E1S-W-1			
MSZ-EM9022E1S-W-2			
MSZ-EM9023E3S-W			
MSZ-EM9024E4S-W			
MSZ-EM9025E5S-W			
MSZ-EM9026E6S-W			
MSZ-EX2223E3-W			
MSZ-EX2224E4-W			
MSZ-EX2225E5-W			
MSZ-EX2226E6-W			
MSZ-EX2523E3-W			
MSZ-EX2524E4-W			
MSZ-EX2525E5-W			
MSZ-EX2526E6-W			
MSZ-EX2823E3-W			
MSZ-EX2824E4-W			
MSZ-EX2825E5-W			
MSZ-EX2826E6-W			
MSZ-EX3623E3-W			
MSZ-EX3624E4-W			
MSZ-EX3625E5-W			
MSZ-EX3626E6-W			
MSZ-EX4023E3S-W			
MSZ-EX4024E4S-W			
MSZ-EX4025E5S-W			
MSZ-EX4026E6S-W			
MSZ-EX5623E3S-W			
MSZ-EX5624E4S-W			
MSZ-EX5625E5S-W			
MSZ-EX5626E6S-W			
MSZ-EX6323E3S-W			
MSZ-EX6324E4S-W			
MSZ-EX6325E5S-W			
MSZ-EX6326E6S-W			
MSZ-EX7123E3S-W			
MSZ-EX7124E4S-W			
MSZ-EX7125E5S-W			
MSZ-EX7126E6S-W			
MSZ-FD4022S-W			
MSZ-FD4023S-W			
MSZ-FD4024S-W			
MSZ-FD4025S-W			

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-FD4026S-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-FD5622S-W			
MSZ-FD5623S-W			
MSZ-FD5624S-W			
MSZ-FD5625S-W			
MSZ-FD5626S-W			
MSZ-FD6322S-W			
MSZ-FD6323S-W			
MSZ-FD6324S-W			
MSZ-FD6325S-W			
MSZ-FD6326S-W			
MSZ-FD7122S-W			
MSZ-FD7123S-W			
MSZ-FD7124S-W			
MSZ-FD7125S-W			
MSZ-FD7126S-W			
MSZ-FD8022S-W			
MSZ-FD8023S-W			
MSZ-FD8024S-W			
MSZ-FD8025S-W			
MSZ-FD8026S-W			
MSZ-FZ4020S-W			
MSZ-FZ4021S-W			
MSZ-FZ4022S-W			
MSZ-FZ4024S-W			
MSZ-FZ4025S-W			
MSZ-FZ4026S-W			
MSZ-FZ5620S-W			
MSZ-FZ5621S-W			
MSZ-FZ5622S-W			
MSZ-FZ5624S-W			
MSZ-FZ5625S-W			
MSZ-FZ5626S-W			
MSZ-FZ6320S-W			
MSZ-FZ6321S-W			
MSZ-FZ6322S-W			
MSZ-FZ6324S-W			
MSZ-FZ6325S-W			
MSZ-FZ6326S-W			
MSZ-FZ7120S-W			
MSZ-FZ7121S-W			
MSZ-FZ7122S-W			
MSZ-FZ7124S-W			
MSZ-FZ7125S-W			
MSZ-FZ7126S-W			
MSZ-FZ8020S-W			
MSZ-FZ8021S-W			
MSZ-FZ8022S-W			
MSZ-FZ8024S-W			
MSZ-FZ8025S-W			
MSZ-FZ8026S-W			
MSZ-FZ9020S-W			
MSZ-FZ9021S-W			
MSZ-FZ9022S-W			
MSZ-FZ9024S-W			
MSZ-FZ9025S-W			
MSZ-FZ9026S-W			
MSZ-FZV4020S-W			
MSZ-FZV4021S-W			
MSZ-FZV4022S-W			
MSZ-FZV4024S-W			
MSZ-FZV4025S-W			

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-FZV4026S-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-FZV5620S-W			
MSZ-FZV5621S-W			
MSZ-FZV5622S-W			
MSZ-FZV5624S-W			
MSZ-FZV5625S-W			
MSZ-FZV5626S-W			
MSZ-FZV6320S-W			
MSZ-FZV6321S-W			
MSZ-FZV6322S-W			
MSZ-FZV6324S-W			
MSZ-FZV6325S-W			
MSZ-FZV6326S-W			
MSZ-FZV7120S-W			
MSZ-FZV7121S-W			
MSZ-FZV7122S-W			
MSZ-FZV7124S-W			
MSZ-FZV7125S-W			
MSZ-FZV7126S-W			
MSZ-FZV8020S-W			
MSZ-FZV8021S-W			
MSZ-FZV8022S-W			
MSZ-FZV8024S-W			
MSZ-FZV8025S-W			
MSZ-FZV8026S-W			
MSZ-FZV9020S-W			
MSZ-FZV9021S-W			
MSZ-FZV9022S-W			
MSZ-FZV9024S-W			
MSZ-FZV9025S-W			
MSZ-FZV9026S-W			
MSZ-HXV2522-T			
MSZ-HXV2522-W			
MSZ-HXV2522-W-1			
MSZ-HXV2523-W			
MSZ-HXV2523-W-1			
MSZ-HXV2524-W			
MSZ-HXV2525-W			
MSZ-HXV2526-W			
MSZ-HXV2822S-T			
MSZ-HXV2822S-W			
MSZ-HXV2822S-W-1			
MSZ-HXV2823S-W			
MSZ-HXV2823S-W-1			
MSZ-HXV2824S-W			
MSZ-HXV2825S-W			
MSZ-HXV2826S-W			
MSZ-HXV4022S-T			
MSZ-HXV4022S-W			
MSZ-HXV4022S-W-1			
MSZ-HXV4022S-W-2			
MSZ-HXV4023S-W			
MSZ-HXV4023S-W-1			
MSZ-HXV4024S-W			
MSZ-HXV4025S-W			
MSZ-HXV4026S-W			
MSZ-HXV5622S-T			
MSZ-HXV5622S-W			
MSZ-HXV5622S-W-1			
MSZ-HXV5622S-W-2			
MSZ-HXV5623S-W			
MSZ-HXV5623S-W-1			

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-HXV5624S-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-HXV5625S-W			
MSZ-HXV5626S-W			
MSZ-HXV6322S-T			
MSZ-HXV6322S-W			
MSZ-HXV6322S-W-1			
MSZ-HXV6322S-W-2			
MSZ-HXV6323S-W			
MSZ-HXV6323S-W-1			
MSZ-HXV6324S-W			
MSZ-HXV6325S-W			
MSZ-HXV6326S-W			
MSZ-HXV7122S-T			
MSZ-HXV7122S-W			
MSZ-HXV7122S-W-1			
MSZ-HXV7122S-W-2			
MSZ-HXV7123S-W			
MSZ-HXV7123S-W-1			
MSZ-HXV7124S-W			
MSZ-HXV7125S-W			
MSZ-HXV7126S-W			
MSZ-HXV8022S-T			
MSZ-HXV8022S-W			
MSZ-HXV8022S-W-1			
MSZ-HXV8022S-W-2			
MSZ-HXV8023S-W			
MSZ-HXV8023S-W-1			
MSZ-HXV8024S-W			
MSZ-HXV8025S-W			
MSZ-HXV8026S-W			
MSZ-JXV2223-T			
MSZ-JXV2223-W			
MSZ-JXV2224-W			
MSZ-JXV2225-W			
MSZ-JXV2226-W			
MSZ-JXV2523-T			
MSZ-JXV2523-W			
MSZ-JXV2524-W			
MSZ-JXV2525-W			
MSZ-JXV2526-W			
MSZ-JXV2823S-T			
MSZ-JXV2823S-W			
MSZ-JXV2823-T			
MSZ-JXV2823-W			
MSZ-JXV2824S-W			
MSZ-JXV2824-W			
MSZ-JXV2825S-W			
MSZ-JXV2825-W			
MSZ-JXV2826S-W			
MSZ-JXV2826-W			
MSZ-JXV3623S-T			
MSZ-JXV3623S-W			
MSZ-JXV3623-T			
MSZ-JXV3623-W			
MSZ-JXV3624S-W			
MSZ-JXV3624-W			
MSZ-JXV3625S-W			
MSZ-JXV3625-W			
MSZ-JXV3626S-W			
MSZ-JXV3626-W			
MSZ-JXV4023S-T			
MSZ-JXV4023S-W			

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-JXV4024S-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-JXV4025S-W			
MSZ-JXV4026S-W			
MSZ-JXV5623S-T			
MSZ-JXV5623S-W			
MSZ-JXV5624S-W			
MSZ-JXV5625S-W			
MSZ-JXV5626S-W			
MSZ-JXV6323S-T			
MSZ-JXV6323S-W			
MSZ-JXV6324S-W			
MSZ-JXV6325S-W			
MSZ-JXV6326S-W			
MSZ-JXV7123S-T			
MSZ-JXV7123S-W			
MSZ-JXV7124S-W			
MSZ-JXV7125S-W			
MSZ-JXV7126S-W			
MSZ-NXV2224-W			
MSZ-NXV2225-W			
MSZ-NXV2226-W			
MSZ-NXV2524-W			
MSZ-NXV2525-W			
MSZ-NXV2526-W			
MSZ-NXV2824S-W			
MSZ-NXV2825S-W			
MSZ-NXV2826S-W			
MSZ-NXV3624S-W			
MSZ-NXV3625S-W			
MSZ-NXV3626S-W			
MSZ-NXV4024S-W			
MSZ-NXV4025S-W			
MSZ-NXV4026S-W			
MSZ-NXV5624S-W			
MSZ-NXV5625S-W			
MSZ-NXV5626S-W			
MSZ-NXV6324S-W			
MSZ-NXV6325S-W			
MSZ-NXV6326S-W			
MSZ-R2223-W			
MSZ-R2224-W			
MSZ-R2225-W			
MSZ-R2226-W			
MSZ-R2523-W			
MSZ-R2524-W			
MSZ-R2525-W			
MSZ-R2526-W			
MSZ-R2823-W			
MSZ-R2824-W			
MSZ-R2825-W			
MSZ-R2826-W			
MSZ-R3623-W			
MSZ-R3624-W			
MSZ-R3625-W			
MSZ-R3626-W			
MSZ-R4023S-W			
MSZ-R4024S-W			
MSZ-R4025S-W			
MSZ-R4026S-W			
MSZ-R5623S-W			
MSZ-R5624S-W			
MSZ-R5625S-W			

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-R5626S-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-R6323S-W			
MSZ-R6324S-W			
MSZ-R6325S-W			
MSZ-R6326S-W			
MSZ-R7123S-W			
MSZ-R7124S-W			
MSZ-R7125S-W			
MSZ-R7126S-W			
MSZ-RK2223-W			
MSZ-RK2224-W			
MSZ-RK2225-W			
MSZ-RK2226-W			
MSZ-RK2523-W			
MSZ-RK2524-W			
MSZ-RK2525-W			
MSZ-RK2526-W			
MSZ-RK2823-W			
MSZ-RK2824-W			
MSZ-RK2825-W			
MSZ-RK2826-W			
MSZ-RK3623-W			
MSZ-RK3624-W			
MSZ-RK3625-W			
MSZ-RK3626-W			
MSZ-RK4023S-W			
MSZ-RK4024S-W			
MSZ-RK4025S-W			
MSZ-RK4026S-W			
MSZ-RK5623S-W			
MSZ-RK5624S-W			
MSZ-RK5625S-W			
MSZ-RK5626S-W			
MSZ-RK6323S-W			
MSZ-RK6324S-W			
MSZ-RK6325S-W			
MSZ-RK6326S-W			
MSZ-RK7123S-W			
MSZ-RK7124S-W			
MSZ-RK7125S-W			
MSZ-RK7126S-W			
MSZ-VXV4022S-W			
MSZ-VXV4023S-W			
MSZ-VXV4024S-W			
MSZ-VXV4025S-W			
MSZ-VXV4026S-W			
MSZ-VXV5622S-W			
MSZ-VXV5623S-W			
MSZ-VXV5624S-W			
MSZ-VXV5625S-W			
MSZ-VXV5626S-W			
MSZ-VXV6322S-W			
MSZ-VXV6323S-W			
MSZ-VXV6324S-W			
MSZ-VXV6325S-W			
MSZ-VXV6326S-W			
MSZ-VXV7122S-W			
MSZ-VXV7123S-W			
MSZ-VXV7124S-W			
MSZ-VXV7125S-W			
MSZ-VXV7126S-W			
MSZ-VXV8022S-W			

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-VXV8023S-W MSZ-VXV8024S-W MSZ-VXV8025S-W MSZ-VXV8026S-W MSZ-X2223-W MSZ-X2224-W MSZ-X2225-W MSZ-X2226-W MSZ-X2523-W MSZ-X2524-W MSZ-X2525-W MSZ-X2526-W MSZ-X2823-W MSZ-X2824-W MSZ-X2825-W MSZ-X2826-W MSZ-X3623-W MSZ-X3624-W MSZ-X3625-W MSZ-X3626-W MSZ-X4023S-W MSZ-X4024S-W MSZ-X4025S-W MSZ-X4026S-W MSZ-X5623S-W MSZ-X5624S-W MSZ-X5625S-W MSZ-X5626S-W MSZ-X6323S-W MSZ-X6324S-W MSZ-X6325S-W MSZ-X6326S-W MSZ-X7123S-W MSZ-X7124S-W MSZ-X7125S-W MSZ-X7126S-W MSZ-XD2224-W MSZ-XD2225-W MSZ-XD2226-W MSZ-XD2524-W MSZ-XD2525-W MSZ-XD2526-W MSZ-XD2824S-W MSZ-XD2825S-W MSZ-XD2826S-W MSZ-XD3624S-W MSZ-XD3625S-W MSZ-XD3626S-W MSZ-XD4024S-W MSZ-XD4025S-W MSZ-XD4026S-W MSZ-XD5624S-W MSZ-XD5625S-W MSZ-XD5626S-W MSZ-XD6324S-W MSZ-XD6325S-W MSZ-XD6326S-W MSZ-XK2223-W MSZ-XK2224-W MSZ-XK2225-W MSZ-XK2226-W MSZ-XK2523-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-XK2524-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-XK2525-W			
MSZ-XK2526-W			
MSZ-XK2823-W			
MSZ-XK2824-W			
MSZ-XK2825-W			
MSZ-XK2826-W			
MSZ-XK3623-W			
MSZ-XK3624-W			
MSZ-XK3625-W			
MSZ-XK3626-W			
MSZ-XK4023S-W			
MSZ-XK4024S-W			
MSZ-XK4025S-W			
MSZ-XK4026S-W			
MSZ-XK5623S-W			
MSZ-XK5624S-W			
MSZ-XK5625S-W			
MSZ-XK5626S-W			
MSZ-XK6323S-W			
MSZ-XK6324S-W			
MSZ-XK6325S-W			
MSZ-XK6326S-W			
MSZ-XK7123S-W			
MSZ-XK7124S-W			
MSZ-XK7125S-W			
MSZ-XK7126S-W			
MSZ-ZD2522-W			
MSZ-ZD2522-W-1			
MSZ-ZD2523-W			
MSZ-ZD2523-W-1			
MSZ-ZD2524-W			
MSZ-ZD2525-W			
MSZ-ZD2526-W			
MSZ-ZD2822S-W			
MSZ-ZD2822S-W-1			
MSZ-ZD2823S-W			
MSZ-ZD2823S-W-1			
MSZ-ZD2824S-W			
MSZ-ZD2825S-W			
MSZ-ZD2826S-W			
MSZ-ZD4022S-W			
MSZ-ZD4022S-W-1			
MSZ-ZD4022S-W-2			
MSZ-ZD4023S-W			
MSZ-ZD4023S-W-1			
MSZ-ZD4024S-W			
MSZ-ZD4025S-W			
MSZ-ZD4026S-W			
MSZ-ZD5622S-W			
MSZ-ZD5622S-W-1			
MSZ-ZD5622S-W-2			
MSZ-ZD5623S-W			
MSZ-ZD5623S-W-1			
MSZ-ZD5624S-W			
MSZ-ZD5625S-W			
MSZ-ZD5626S-W			
MSZ-ZD6322S-W			
MSZ-ZD6322S-W-1			
MSZ-ZD6322S-W-2			
MSZ-ZD6323S-W			
MSZ-ZD6323S-W-1			

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-ZD6324S-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-ZD6325S-W			
MSZ-ZD6326S-W			
MSZ-ZD7122S-W			
MSZ-ZD7122S-W-1			
MSZ-ZD7122S-W-2			
MSZ-ZD7123S-W			
MSZ-ZD7123S-W-1			
MSZ-ZD7124S-W			
MSZ-ZD7125S-W			
MSZ-ZD7126S-W			
MSZ-ZD8022S-W			
MSZ-ZD8022S-W-1			
MSZ-ZD8022S-W-2			
MSZ-ZD8023S-W			
MSZ-ZD8023S-W-1			
MSZ-ZD8024S-W			
MSZ-ZD8025S-W			
MSZ-ZD8026S-W			
MSZ-ZW2220-T			
MSZ-ZW2220-W			
MSZ-ZW2221-T			
MSZ-ZW2221-T-1			
MSZ-ZW2221-W			
MSZ-ZW2221-W-1			
MSZ-ZW2222-T			
MSZ-ZW2222-T-1			
MSZ-ZW2222-T-2			
MSZ-ZW2222-W			
MSZ-ZW2222-W-1			
MSZ-ZW2222-W-2			
MSZ-ZW2223-T			
MSZ-ZW2223-W			
MSZ-ZW2224-W			
MSZ-ZW2225-W			
MSZ-ZW2226-W			
MSZ-ZW2520-T			
MSZ-ZW2520-W			
MSZ-ZW2521-T			
MSZ-ZW2521-T-1			
MSZ-ZW2521-W			
MSZ-ZW2521-W-1			
MSZ-ZW2522-T			
MSZ-ZW2522-T-1			
MSZ-ZW2522-T-2			
MSZ-ZW2522-W			
MSZ-ZW2522-W-1			
MSZ-ZW2522-W-2			
MSZ-ZW2523-T			
MSZ-ZW2523-W			
MSZ-ZW2524-W			
MSZ-ZW2525-W			
MSZ-ZW2526-W			
MSZ-ZW2820S-T			
MSZ-ZW2820S-W			
MSZ-ZW2820-T			
MSZ-ZW2820-W			
MSZ-ZW2821S-T			
MSZ-ZW2821S-T-1			
MSZ-ZW2821S-W			
MSZ-ZW2821S-W-1			
MSZ-ZW2821-T			

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-ZW2821-T-1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-ZW2821-W			
MSZ-ZW2821-W-1			
MSZ-ZW2822S-T			
MSZ-ZW2822S-T-1			
MSZ-ZW2822S-T-2			
MSZ-ZW2822S-W			
MSZ-ZW2822S-W-1			
MSZ-ZW2822S-W-2			
MSZ-ZW2822-T			
MSZ-ZW2822-T-1			
MSZ-ZW2822-T-2			
MSZ-ZW2822-W			
MSZ-ZW2822-W-1			
MSZ-ZW2822-W-2			
MSZ-ZW2823S-T			
MSZ-ZW2823S-W			
MSZ-ZW2823-T			
MSZ-ZW2823-W			
MSZ-ZW2824S-W			
MSZ-ZW2824-W			
MSZ-ZW2825S-W			
MSZ-ZW2825-W			
MSZ-ZW2826S-W			
MSZ-ZW2826-W			
MSZ-ZW3620S-T			
MSZ-ZW3620S-W			
MSZ-ZW3620-T			
MSZ-ZW3620-W			
MSZ-ZW3621S-T			
MSZ-ZW3621S-T-1			
MSZ-ZW3621S-W			
MSZ-ZW3621S-W-1			
MSZ-ZW3621-T			
MSZ-ZW3621-T-1			
MSZ-ZW3621-W			
MSZ-ZW3621-W-1			
MSZ-ZW3622S-T			
MSZ-ZW3622S-T-1			
MSZ-ZW3622S-T-2			
MSZ-ZW3622S-W			
MSZ-ZW3622S-W-1			
MSZ-ZW3622S-W-2			
MSZ-ZW3622-T			
MSZ-ZW3622-T-1			
MSZ-ZW3622-T-2			
MSZ-ZW3622-W			
MSZ-ZW3622-W-1			
MSZ-ZW3622-W-2			
MSZ-ZW3623S-T			
MSZ-ZW3623S-W			
MSZ-ZW3623-T			
MSZ-ZW3623-W			
MSZ-ZW3624S-W			
MSZ-ZW3624-W			
MSZ-ZW3625S-W			
MSZ-ZW3625-W			
MSZ-ZW3626S-W			
MSZ-ZW3626-W			
MSZ-ZW4020S-T			
MSZ-ZW4020S-W			
MSZ-ZW4021S-T			

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-ZW4021S-T-1 MSZ-ZW4021S-W MSZ-ZW4021S-W-1 MSZ-ZW4022S-T MSZ-ZW4022S-T-1 MSZ-ZW4022S-T-2 MSZ-ZW4022S-W MSZ-ZW4022S-W-1 MSZ-ZW4022S-W-2 MSZ-ZW4023S-T MSZ-ZW4023S-W MSZ-ZW4024S-W MSZ-ZW4025S-W MSZ-ZW4026S-W MSZ-ZW5620S-T MSZ-ZW5620S-W MSZ-ZW5621S-T MSZ-ZW5621S-T-1 MSZ-ZW5621S-W MSZ-ZW5621S-W-1 MSZ-ZW5622S-T MSZ-ZW5622S-T-1 MSZ-ZW5622S-T-2 MSZ-ZW5622S-W MSZ-ZW5622S-W-1 MSZ-ZW5622S-W-2 MSZ-ZW5623S-T MSZ-ZW5623S-W MSZ-ZW5624S-W MSZ-ZW5625S-W MSZ-ZW5626S-W MSZ-ZW6320S-T MSZ-ZW6320S-W MSZ-ZW6321S-T MSZ-ZW6321S-T-1 MSZ-ZW6321S-W MSZ-ZW6321S-W-1 MSZ-ZW6322S-T MSZ-ZW6322S-T-1 MSZ-ZW6322S-T-2 MSZ-ZW6322S-W MSZ-ZW6322S-W-1 MSZ-ZW6322S-W-2 MSZ-ZW6323S-T MSZ-ZW6323S-W MSZ-ZW6324S-W MSZ-ZW6325S-W MSZ-ZW6326S-W MSZ-ZW7120S-T MSZ-ZW7120S-W MSZ-ZW7121S-T MSZ-ZW7121S-T-1 MSZ-ZW7121S-W MSZ-ZW7121S-W-1 MSZ-ZW7122S-T MSZ-ZW7122S-T-1 MSZ-ZW7122S-T-2 MSZ-ZW7122S-W MSZ-ZW7122S-W-1 MSZ-ZW7122S-W-2 MSZ-ZW7123S-T MSZ-ZW7123S-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-ZW7124S-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-ZW7125S-W			
MSZ-ZW7126S-W			
MSZ-ZW8020S-T			
MSZ-ZW8020S-W			
MSZ-ZW8021S-T			
MSZ-ZW8021S-T-1			
MSZ-ZW8021S-W			
MSZ-ZW8021S-W-1			
MSZ-ZW8022S-T			
MSZ-ZW8022S-T-1			
MSZ-ZW8022S-T-2			
MSZ-ZW8022S-W			
MSZ-ZW8022S-W-1			
MSZ-ZW8022S-W-2			
MSZ-ZW8023S-T			
MSZ-ZW8023S-W			
MSZ-ZW8024S-W			
MSZ-ZW8025S-W			
MSZ-ZW8026S-W			
MSZ-ZW9020S-T			
MSZ-ZW9020S-W			
MSZ-ZW9021S-T			
MSZ-ZW9021S-T-1			
MSZ-ZW9021S-W			
MSZ-ZW9021S-W-1			
MSZ-ZW9022S-T			
MSZ-ZW9022S-T-1			
MSZ-ZW9022S-T-2			
MSZ-ZW9022S-W			
MSZ-ZW9022S-W-1			
MSZ-ZW9022S-W-2			
MSZ-ZW9023S-T			
MSZ-ZW9023S-W			
MSZ-ZW9024S-W			
MSZ-ZW9025S-W			
MSZ-ZW9026S-W			
MSZ-ZXV2220-T			
MSZ-ZXV2220-W			
MSZ-ZXV2221-T			
MSZ-ZXV2221-T-1			
MSZ-ZXV2221-W			
MSZ-ZXV2221-W-1			
MSZ-ZXV2222-T			
MSZ-ZXV2222-T-1			
MSZ-ZXV2222-T-2			
MSZ-ZXV2222-W			
MSZ-ZXV2222-W-1			
MSZ-ZXV2222-W-2			
MSZ-ZXV2223-T			
MSZ-ZXV2223-W			
MSZ-ZXV2224-W			
MSZ-ZXV2225-W			
MSZ-ZXV2226-W			
MSZ-ZXV2520-T			
MSZ-ZXV2520-W			
MSZ-ZXV2521-T			
MSZ-ZXV2521-T-1			
MSZ-ZXV2521-W			
MSZ-ZXV2521-W-1			
MSZ-ZXV2522-T			
MSZ-ZXV2522-T-1			

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-ZXV2522-T-2 MSZ-ZXV2522-W MSZ-ZXV2522-W-1 MSZ-ZXV2522-W-2 MSZ-ZXV2523-T MSZ-ZXV2523-W MSZ-ZXV2524-W MSZ-ZXV2525-W MSZ-ZXV2526-W MSZ-ZXV2820S-T MSZ-ZXV2820S-W MSZ-ZXV2820-T MSZ-ZXV2820-W MSZ-ZXV2821S-T MSZ-ZXV2821S-T-1 MSZ-ZXV2821S-W MSZ-ZXV2821S-W-1 MSZ-ZXV2821-T MSZ-ZXV2821-T-1 MSZ-ZXV2821-W MSZ-ZXV2821-W-1 MSZ-ZXV2822S-T MSZ-ZXV2822S-T-1 MSZ-ZXV2822S-T-2 MSZ-ZXV2822S-W MSZ-ZXV2822S-W-1 MSZ-ZXV2822S-W-2 MSZ-ZXV2822-T MSZ-ZXV2822-T-1 MSZ-ZXV2822-T-2 MSZ-ZXV2822-W MSZ-ZXV2822-W-1 MSZ-ZXV2822-W-2 MSZ-ZXV2823S-T MSZ-ZXV2823S-W MSZ-ZXV2823-T MSZ-ZXV2823-W MSZ-ZXV2824S-W MSZ-ZXV2824-W MSZ-ZXV2825S-W MSZ-ZXV2825-W MSZ-ZXV2826S-W MSZ-ZXV2826-W MSZ-ZXV3620S-T MSZ-ZXV3620S-W MSZ-ZXV3620-T MSZ-ZXV3620-W MSZ-ZXV3621S-T MSZ-ZXV3621S-T-1 MSZ-ZXV3621S-W MSZ-ZXV3621S-W-1 MSZ-ZXV3621-T MSZ-ZXV3621-T-1 MSZ-ZXV3621-W MSZ-ZXV3621-W-1 MSZ-ZXV3622S-T MSZ-ZXV3622S-T-1 MSZ-ZXV3622S-T-2 MSZ-ZXV3622S-W MSZ-ZXV3622S-W-1 MSZ-ZXV3622S-W-2 MSZ-ZXV3622-T	Same as above	Same as above	Same as above

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-ZXV3622-T-1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-ZXV3622-T-2			
MSZ-ZXV3622-W			
MSZ-ZXV3622-W-1			
MSZ-ZXV3622-W-2			
MSZ-ZXV3623S-T			
MSZ-ZXV3623S-W			
MSZ-ZXV3623-T			
MSZ-ZXV3623-W			
MSZ-ZXV3624S-W			
MSZ-ZXV3624-W			
MSZ-ZXV3625S-W			
MSZ-ZXV3625-W			
MSZ-ZXV3626S-W			
MSZ-ZXV3626-W			
MSZ-ZXV4020S-T			
MSZ-ZXV4020S-W			
MSZ-ZXV4021S-T			
MSZ-ZXV4021S-T-1			
MSZ-ZXV4021S-W			
MSZ-ZXV4021S-W-1			
MSZ-ZXV4022S-T			
MSZ-ZXV4022S-T-1			
MSZ-ZXV4022S-T-2			
MSZ-ZXV4022S-W			
MSZ-ZXV4022S-W-1			
MSZ-ZXV4022S-W-2			
MSZ-ZXV4023S-T			
MSZ-ZXV4023S-W			
MSZ-ZXV4024S-W			
MSZ-ZXV4025S-W			
MSZ-ZXV4026S-W			
MSZ-ZXV5620S-T			
MSZ-ZXV5620S-W			
MSZ-ZXV5621S-T			
MSZ-ZXV5621S-T-1			
MSZ-ZXV5621S-W			
MSZ-ZXV5621S-W-1			
MSZ-ZXV5622S-T			
MSZ-ZXV5622S-T-1			
MSZ-ZXV5622S-T-2			
MSZ-ZXV5622S-W			
MSZ-ZXV5622S-W-1			
MSZ-ZXV5622S-W-2			
MSZ-ZXV5623S-T			
MSZ-ZXV5623S-W			
MSZ-ZXV5624S-W			
MSZ-ZXV5625S-W			
MSZ-ZXV5626S-W			
MSZ-ZXV6320S-T			
MSZ-ZXV6320S-W			
MSZ-ZXV6321S-T			
MSZ-ZXV6321S-T-1			
MSZ-ZXV6321S-W			
MSZ-ZXV6321S-W-1			
MSZ-ZXV6322S-T			
MSZ-ZXV6322S-T-1			
MSZ-ZXV6322S-T-2			
MSZ-ZXV6322S-W			
MSZ-ZXV6322S-W-1			
MSZ-ZXV6322S-W-2			
MSZ-ZXV6323S-T			

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-ZXV6323S-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-ZXV6324S-W			
MSZ-ZXV6325S-W			
MSZ-ZXV6326S-W			
MSZ-ZXV7120S-T			
MSZ-ZXV7120S-W			
MSZ-ZXV7121S-T			
MSZ-ZXV7121S-T-1			
MSZ-ZXV7121S-W			
MSZ-ZXV7121S-W-1			
MSZ-ZXV7122S-T			
MSZ-ZXV7122S-T-1			
MSZ-ZXV7122S-T-2			
MSZ-ZXV7122S-W			
MSZ-ZXV7122S-W-1			
MSZ-ZXV7122S-W-2			
MSZ-ZXV7123S-T			
MSZ-ZXV7123S-W			
MSZ-ZXV7124S-W			
MSZ-ZXV7125S-W			
MSZ-ZXV7126S-W			
MSZ-ZXV8020S-T			
MSZ-ZXV8020S-W			
MSZ-ZXV8021S-T			
MSZ-ZXV8021S-T-1			
MSZ-ZXV8021S-W			
MSZ-ZXV8021S-W-1			
MSZ-ZXV8022S-T			
MSZ-ZXV8022S-T-1			
MSZ-ZXV8022S-T-2			
MSZ-ZXV8022S-W			
MSZ-ZXV8022S-W-1			
MSZ-ZXV8022S-W-2			
MSZ-ZXV8023S-T			
MSZ-ZXV8023S-W			
MSZ-ZXV8024S-W			
MSZ-ZXV8025S-W			
MSZ-ZXV8026S-W			
MSZ-ZXV9020S-T			
MSZ-ZXV9020S-W			
MSZ-ZXV9021S-T			
MSZ-ZXV9021S-T-1			
MSZ-ZXV9021S-W			
MSZ-ZXV9021S-W-1			
MSZ-ZXV9022S-T			
MSZ-ZXV9022S-T-1			
MSZ-ZXV9022S-T-2			
MSZ-ZXV9022S-W			
MSZ-ZXV9022S-W-1			
MSZ-ZXV9022S-W-2			
MSZ-ZXV9023S-T			
MSZ-ZXV9023S-W			
MSZ-ZXV9024S-W			
MSZ-ZXV9025S-W			
MSZ-ZXV9026S-W			
MSZ-ZY2223-W			
MSZ-ZY2224-W			
MSZ-ZY2225-W			
MSZ-ZY2226-W			
MSZ-ZY2523-W			
MSZ-ZY2524-W			
MSZ-ZY2525-W			

Model No.	Affected Version	fixed Version	Details of Measures
MSZ-ZY2526-W MSZ-ZY2823-W MSZ-ZY2824-W MSZ-ZY2825-W MSZ-ZY2826-W MSZ-ZY4023S-W MSZ-ZY4024S-W MSZ-ZY4025S-W MSZ-ZY4026S-W MSZ-ZY5623S-W MSZ-ZY5624S-W MSZ-ZY5625S-W MSZ-ZY5626S-W MSZ-ZY6323S-W MSZ-ZY6324S-W MSZ-ZY6325S-W MSZ-ZY6326S-W MSZ-ZY7124S-W MSZ-ZY7125S-W MSZ-ZY7126S-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>

[2] Room Air Conditioners (outside Japan)

Model No.	Affected Version	Fixed Version	Measure Details
<p><u>Models released in 2020-2024.</u></p> <p>MFZ-GXT50VFK MFZ-GXT60VFK MFZ-GXT73VFK MFZ-KW25VGK-A1 MFZ-KW25VGK-A2 MFZ-KW35VGK-A1 MFZ-KW35VGK-A2 MFZ-KW42VGK-A1 MFZ-KW42VGK-A2 MFZ-KW50VGK-A1 MFZ-KW50VGK-A2 MFZ-KW60VGK-A1 MFZ-KW60VGK-A2 MFZ-XT50VFK MFZ-XT60VFK MFZ-XT73VFK MSXY-FP05VGK-SG2 MSXY-FP07VGK-SG2 MSXY-FP10VGK-SG2 MSXY-FP13VGK-SG2 MSXY-FP18VGK-SG2 MSXY-FP20VGK-SG2 MSXY-FP24VGK-SG2 MSY-GA10VFK-SG1 MSY-GA13VFK-SG1 MSY-GA15VFK-SG1 MSY-GA18VFK-SG1 MSZ-AP15VGK-E1 MSZ-AP15VGK-E2 MSZ-AP15VGK-ER1 MSZ-AP15VGK-ER2 MSZ-AP15VGK-ET1 MSZ-AP15VGK-ET2 MSZ-AP20VGK-E1 MSZ-AP20VGK-E2 MSZ-AP20VGK-ER1 MSZ-AP20VGK-ER2 MSZ-AP20VGK-ET1 MSZ-AP20VGK-ET2 MSZ-AP22VGKD-A1 MSZ-AP22VGKD-A2 MSZ-AP25VGKD2-A1 MSZ-AP25VGKD2-A2 MSZ-AP25VGKD-A1 MSZ-AP25VGKD-A2 MSZ-AP25VGK-E1 MSZ-AP25VGK-E2 MSZ-AP25VGK-E3 MSZ-AP25VGK-E7 MSZ-AP25VGK-E8 MSZ-AP25VGK-EN1 MSZ-AP25VGK-EN2 MSZ-AP25VGK-EN3 MSZ-AP25VGK-ER1 MSZ-AP25VGK-ER2 MSZ-AP25VGK-ER3 MSZ-AP25VGK-ET1 MSZ-AP25VGK-ET2</p>	<p>41.00 and prior</p>	<p>42.00 or later</p>	<p><u>The fixed version is scheduled to begin release between early April and late July 2026.</u></p> <p>The countermeasure is implemented in adapter software version 42.00 or later.</p> <p>Once the fixed version is released, please update the software according to the instructions provided by your local Mitsubishi Electric representative.</p>

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-AP25VGK-ET3	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-AP35VGKD2-A1			
MSZ-AP35VGKD2-A2			
MSZ-AP35VGKD-A1			
MSZ-AP35VGKD-A2			
MSZ-AP35VGK-E1			
MSZ-AP35VGK-E2			
MSZ-AP35VGK-E3			
MSZ-AP35VGK-E7			
MSZ-AP35VGK-E8			
MSZ-AP35VGK-EN1			
MSZ-AP35VGK-EN2			
MSZ-AP35VGK-EN3			
MSZ-AP35VGK-ER1			
MSZ-AP35VGK-ER2			
MSZ-AP35VGK-ER3			
MSZ-AP35VGK-ET1			
MSZ-AP35VGK-ET2			
MSZ-AP35VGK-ET3			
MSZ-AP42VGKD2-A1			
MSZ-AP42VGKD2-A2			
MSZ-AP42VGKD-A1			
MSZ-AP42VGKD-A2			
MSZ-AP42VGK-E1			
MSZ-AP42VGK-E2			
MSZ-AP42VGK-E3			
MSZ-AP42VGK-E7			
MSZ-AP42VGK-E8			
MSZ-AP42VGK-EN1			
MSZ-AP42VGK-EN2			
MSZ-AP42VGK-EN3			
MSZ-AP42VGK-ER1			
MSZ-AP42VGK-ER2			
MSZ-AP42VGK-ER3			
MSZ-AP42VGK-ET1			
MSZ-AP42VGK-ET2			
MSZ-AP42VGK-ET3			
MSZ-AP50VGKD2-A1			
MSZ-AP50VGKD2-A2			
MSZ-AP50VGKD-A1			
MSZ-AP50VGKD-A2			
MSZ-AP50VGK-E1			
MSZ-AP50VGK-E2			
MSZ-AP50VGK-E3			
MSZ-AP50VGK-E7			
MSZ-AP50VGK-E8			
MSZ-AP50VGK-EN1			
MSZ-AP50VGK-EN2			
MSZ-AP50VGK-EN3			
MSZ-AP50VGK-ER1			
MSZ-AP50VGK-ER2			
MSZ-AP50VGK-ER3			
MSZ-AP50VGK-ET1			
MSZ-AP50VGK-ET2			
MSZ-AP50VGK-ET3			
MSZ-AP60VGKD2-A1			
MSZ-AP60VGKD2-A2			
MSZ-AP60VGKD-A1			
MSZ-AP60VGKD-A2			
MSZ-AP60VGK-E2			
MSZ-AP60VGK-E3			
MSZ-AP60VGK-E4			

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-AP60VGK-ER2	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-AP60VGK-ER3			
MSZ-AP60VGK-ER4			
MSZ-AP60VGK-ET2			
MSZ-AP60VGK-ET3			
MSZ-AP60VGK-ET4			
MSZ-AP71VGKD2-A1			
MSZ-AP71VGKD2-A2			
MSZ-AP71VGKD-A1			
MSZ-AP71VGKD-A2			
MSZ-AP71VGK-E2			
MSZ-AP71VGK-E3			
MSZ-AP71VGK-E4			
MSZ-AP71VGK-ER2			
MSZ-AP71VGK-ER3			
MSZ-AP71VGK-ER4			
MSZ-AP71VGK-ET2			
MSZ-AP71VGK-ET3			
MSZ-AP71VGK-ET4			
MSZ-AP80VGKD2-A1			
MSZ-AP80VGKD2-A2			
MSZ-AP80VGKD-A1			
MSZ-AP80VGKD-A2			
MSZ-AY15VGK-E1			
MSZ-AY15VGK-ER1			
MSZ-AY15VGK-ET1			
MSZ-AY15VGKP-E1			
MSZ-AY15VGKP-ER1			
MSZ-AY15VGKP-ET1			
MSZ-AY20VGK-E1			
MSZ-AY20VGK-ER1			
MSZ-AY20VGK-ET1			
MSZ-AY20VGKP-E1			
MSZ-AY20VGKP-ER1			
MSZ-AY20VGKP-ET1			
MSZ-AY25VGK-E1			
MSZ-AY25VGK-E6			
MSZ-AY25VGK-ET1			
MSZ-AY25VGKP-E1			
MSZ-AY25VGKP-E6			
MSZ-AY25VGKP-ET1			
MSZ-AY25VGKP-SC1			
MSZ-AY25VGK-SC1			
MSZ-AY35VGK-E1			
MSZ-AY35VGK-E6			
MSZ-AY35VGK-ET1			
MSZ-AY35VGKP-E1			
MSZ-AY35VGKP-E6			
MSZ-AY35VGKP-ET1			
MSZ-AY35VGKP-SC1			
MSZ-AY35VGK-SC1			
MSZ-AY42VGK-E1			
MSZ-AY42VGK-E6			
MSZ-AY42VGK-ET1			
MSZ-AY42VGKP-E1			
MSZ-AY42VGKP-E6			
MSZ-AY42VGKP-ET1			
MSZ-AY42VGKP-SC1			
MSZ-AY42VGK-SC1			
MSZ-AY50VGK-E1			
MSZ-AY50VGK-E6			
MSZ-AY50VGK-ET1			

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-AY50VGKP-E1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-AY50VGKP-E6			
MSZ-AY50VGKP-ET1			
MSZ-AY50VGKP-SC1			
MSZ-AY50VGK-SC1			
MSZ-BT20VGK-E1			
MSZ-BT20VGK-E2			
MSZ-BT20VGK-E3			
MSZ-BT20VGK-ER1			
MSZ-BT20VGK-ER2			
MSZ-BT20VGK-ET1			
MSZ-BT20VGK-ET2			
MSZ-BT20VGK-ET3			
MSZ-BT25VGK-E1			
MSZ-BT25VGK-E2			
MSZ-BT25VGK-E3			
MSZ-BT25VGK-ER1			
MSZ-BT25VGK-ER2			
MSZ-BT25VGK-ET1			
MSZ-BT25VGK-ET2			
MSZ-BT25VGK-ET3			
MSZ-BT35VGK-E1			
MSZ-BT35VGK-E2			
MSZ-BT35VGK-E3			
MSZ-BT35VGK-ER1			
MSZ-BT35VGK-ER2			
MSZ-BT35VGK-ET1			
MSZ-BT35VGK-ET2			
MSZ-BT35VGK-ET3			
MSZ-BT50VGK-E1			
MSZ-BT50VGK-E2			
MSZ-BT50VGK-E3			
MSZ-BT50VGK-ER1			
MSZ-BT50VGK-ER2			
MSZ-BT50VGK-ET1			
MSZ-BT50VGK-ET2			
MSZ-BT50VGK-ET3			
MSZ-EF18VGKB-E1			
MSZ-EF18VGKB-E2			
MSZ-EF18VGKS-E1			
MSZ-EF18VGKS-E2			
MSZ-EF18VGKW-E1			
MSZ-EF18VGKW-E2			
MSZ-EF22VGKB-A1			
MSZ-EF22VGKB-E1			
MSZ-EF22VGKB-E2			
MSZ-EF22VGKB-ER1			
MSZ-EF22VGKB-ER2			
MSZ-EF22VGKB-ET1			
MSZ-EF22VGKB-ET2			
MSZ-EF22VGKDB-A1			
MSZ-EF22VGKDB-A2			
MSZ-EF22VGKDS-A1			
MSZ-EF22VGKDS-A2			
MSZ-EF22VGKDW-A1			
MSZ-EF22VGKDW-A2			
MSZ-EF22VGKS-A1			
MSZ-EF22VGKS-E1			
MSZ-EF22VGKS-E2			
MSZ-EF22VGKS-ER1			
MSZ-EF22VGKS-ER2			
MSZ-EF22VGKS-ET1			

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-EF22VGKS-ET2	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-EF22VGKW-A1			
MSZ-EF22VGKW-E1			
MSZ-EF22VGKW-E2			
MSZ-EF22VGKW-ER1			
MSZ-EF22VGKW-ER2			
MSZ-EF22VGKW-ET1			
MSZ-EF22VGKW-ET2			
MSZ-EF25VGKB-A1			
MSZ-EF25VGKB-E1			
MSZ-EF25VGKB-E2			
MSZ-EF25VGKB-ER1			
MSZ-EF25VGKB-ER2			
MSZ-EF25VGKB-ET1			
MSZ-EF25VGKB-ET2			
MSZ-EF25VGKDB-A1			
MSZ-EF25VGKDB-A2			
MSZ-EF25VGKDS-A1			
MSZ-EF25VGKDS-A2			
MSZ-EF25VGKDW-A1			
MSZ-EF25VGKDW-A2			
MSZ-EF25VGKS-A1			
MSZ-EF25VGKS-E1			
MSZ-EF25VGKS-E2			
MSZ-EF25VGKS-ER1			
MSZ-EF25VGKS-ER2			
MSZ-EF25VGKS-ET1			
MSZ-EF25VGKS-ET2			
MSZ-EF25VGKW-A1			
MSZ-EF25VGKW-E1			
MSZ-EF25VGKW-E2			
MSZ-EF25VGKW-ER1			
MSZ-EF25VGKW-ER2			
MSZ-EF25VGKW-ET1			
MSZ-EF25VGKW-ET2			
MSZ-EF35VGKB-A1			
MSZ-EF35VGKB-E1			
MSZ-EF35VGKB-E2			
MSZ-EF35VGKB-ER1			
MSZ-EF35VGKB-ER2			
MSZ-EF35VGKB-ET1			
MSZ-EF35VGKB-ET2			
MSZ-EF35VGKDB-A1			
MSZ-EF35VGKDB-A2			
MSZ-EF35VGKDS-A1			
MSZ-EF35VGKDS-A2			
MSZ-EF35VGKDW-A1			
MSZ-EF35VGKDW-A2			
MSZ-EF35VGKS-A1			
MSZ-EF35VGKS-E1			
MSZ-EF35VGKS-E2			
MSZ-EF35VGKS-ER1			
MSZ-EF35VGKS-ER2			
MSZ-EF35VGKS-ET1			
MSZ-EF35VGKS-ET2			
MSZ-EF35VGKW-A1			
MSZ-EF35VGKW-E1			
MSZ-EF35VGKW-E2			
MSZ-EF35VGKW-ER1			
MSZ-EF35VGKW-ER2			
MSZ-EF35VGKW-ET1			
MSZ-EF35VGKW-ET2			

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-EF42VGKB-A1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-EF42VGKB-E1			
MSZ-EF42VGKB-E2			
MSZ-EF42VGKB-ER1			
MSZ-EF42VGKB-ER2			
MSZ-EF42VGKB-ET1			
MSZ-EF42VGKB-ET2			
MSZ-EF42VGKDB-A1			
MSZ-EF42VGKDB-A2			
MSZ-EF42VGKDS-A1			
MSZ-EF42VGKDS-A2			
MSZ-EF42VGKDW-A1			
MSZ-EF42VGKDW-A2			
MSZ-EF42VGKS-A1			
MSZ-EF42VGKS-E1			
MSZ-EF42VGKS-E2			
MSZ-EF42VGKS-ER1			
MSZ-EF42VGKS-ER2			
MSZ-EF42VGKS-ET1			
MSZ-EF42VGKS-ET2			
MSZ-EF42VGKW-A1			
MSZ-EF42VGKW-E1			
MSZ-EF42VGKW-E2			
MSZ-EF42VGKW-ER1			
MSZ-EF42VGKW-ER2			
MSZ-EF42VGKW-ET1			
MSZ-EF42VGKW-ET2			
MSZ-EF50VGKB-A1			
MSZ-EF50VGKB-E1			
MSZ-EF50VGKB-E2			
MSZ-EF50VGKB-ER1			
MSZ-EF50VGKB-ER2			
MSZ-EF50VGKB-ET1			
MSZ-EF50VGKB-ET2			
MSZ-EF50VGKDB-A1			
MSZ-EF50VGKDB-A2			
MSZ-EF50VGKDS-A1			
MSZ-EF50VGKDS-A2			
MSZ-EF50VGKDW-A1			
MSZ-EF50VGKDW-A2			
MSZ-EF50VGKS-A1			
MSZ-EF50VGKS-E1			
MSZ-EF50VGKS-E2			
MSZ-EF50VGKS-ER1			
MSZ-EF50VGKS-ER2			
MSZ-EF50VGKS-ET1			
MSZ-EF50VGKS-ET2			
MSZ-EF50VGKW-A1			
MSZ-EF50VGKW-E1			
MSZ-EF50VGKW-E2			
MSZ-EF50VGKW-ER1			
MSZ-EF50VGKW-ER2			
MSZ-EF50VGKW-ET1			
MSZ-EF50VGKW-ET2			
MSZ-EXA09VAK			
MSZ-EXA12VAK			
MSZ-EZA09VAK			
MSZ-EZA12VAK			
MSZ-FT25VGK-E1			
MSZ-FT25VGK-E2			
MSZ-FT25VGK-ET1			
MSZ-FT25VGK-SC1			

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-FT25VGK-SC2	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-FT35VGK-E1			
MSZ-FT35VGK-E2			
MSZ-FT35VGK-ET1			
MSZ-FT35VGK-SC1			
MSZ-FT35VGK-SC2			
MSZ-FT50VGK-E1			
MSZ-FT50VGK-E2			
MSZ-FT50VGK-ET1			
MSZ-FT50VGK-SC1			
MSZ-FT50VGK-SC2			
MSZ-GZA09VFK			
MSZ-GZA12VFK			
MSZ-GZA18VFK			
MSZ-GZY09VFK			
MSZ-GZY12VFK			
MSZ-GZY18VFK			
MSZ-HR25VFK-E1			
MSZ-HR25VFK-E2			
MSZ-HR25VFK-E6			
MSZ-HR25VFK-E7			
MSZ-HR25VFK-ER1			
MSZ-HR25VFK-ER2			
MSZ-HR25VFK-ET1			
MSZ-HR25VFK-ET2			
MSZ-HR35VFK-E1			
MSZ-HR35VFK-E2			
MSZ-HR35VFK-E6			
MSZ-HR35VFK-E7			
MSZ-HR35VFK-ER1			
MSZ-HR35VFK-ER2			
MSZ-HR35VFK-ET1			
MSZ-HR35VFK-ET2			
MSZ-HR42VFK-E1			
MSZ-HR42VFK-E2			
MSZ-HR42VFK-E6			
MSZ-HR42VFK-E7			
MSZ-HR42VFK-ER1			
MSZ-HR42VFK-ER2			
MSZ-HR42VFK-ET1			
MSZ-HR42VFK-ET2			
MSZ-HR50VFK-E1			
MSZ-HR50VFK-E2			
MSZ-HR50VFK-E6			
MSZ-HR50VFK-E7			
MSZ-HR50VFK-ER1			
MSZ-HR50VFK-ER2			
MSZ-HR50VFK-ET1			
MSZ-HR50VFK-ET2			
MSZ-HR60VFK-E1			
MSZ-HR60VFK-ER1			
MSZ-HR60VFK-ET1			
MSZ-HR71VFK-E1			
MSZ-HR71VFK-ER1			
MSZ-HR71VFK-ET1			
MSZ-KY09VFK			
MSZ-KY12VFK			
MSZ-KY18VFK			
MSZ-KZA09VFK			
MSZ-KZA12VFK			
MSZ-KZA18VFK			
MSZ-LN18VG2B-E2			

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-LN18VG2B-E3	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-LN18VG2R-E2			
MSZ-LN18VG2R-E3			
MSZ-LN18VG2V-E2			
MSZ-LN18VG2V-E3			
MSZ-LN18VG2W-E2			
MSZ-LN18VG2W-E3			
MSZ-LN18VG2W-ER2			
MSZ-LN18VG2W-ET2			
MSZ-LN18VG2W-SC1			
MSZ-LN25VG2B-A2			
MSZ-LN25VG2B-A3			
MSZ-LN25VG2B-E2			
MSZ-LN25VG2B-E3			
MSZ-LN25VG2B-EN2			
MSZ-LN25VG2B-ER2			
MSZ-LN25VG2B-ER3			
MSZ-LN25VG2B-ET2			
MSZ-LN25VG2B-ET3			
MSZ-LN25VG2B-SC1			
MSZ-LN25VG2R-A2			
MSZ-LN25VG2R-A3			
MSZ-LN25VG2R-E2			
MSZ-LN25VG2R-E3			
MSZ-LN25VG2R-EN2			
MSZ-LN25VG2R-ER2			
MSZ-LN25VG2R-ER3			
MSZ-LN25VG2R-ET2			
MSZ-LN25VG2R-ET3			
MSZ-LN25VG2R-SC1			
MSZ-LN25VG2V-A2			
MSZ-LN25VG2V-A3			
MSZ-LN25VG2V-E2			
MSZ-LN25VG2V-E3			
MSZ-LN25VG2V-EN2			
MSZ-LN25VG2V-ER2			
MSZ-LN25VG2V-ER3			
MSZ-LN25VG2V-ET2			
MSZ-LN25VG2V-ET3			
MSZ-LN25VG2V-SC1			
MSZ-LN25VG2W-E2			
MSZ-LN25VG2W-E3			
MSZ-LN25VG2W-EN2			
MSZ-LN25VG2W-ER2			
MSZ-LN25VG2W-ER3			
MSZ-LN25VG2W-ET2			
MSZ-LN25VG2W-ET3			
MSZ-LN25VG2W-SC1			
MSZ-LN25VGDB-A1			
MSZ-LN25VGDR-A1			
MSZ-LN25VGDV-A1			
MSZ-LN35VG2B-A2			
MSZ-LN35VG2B-A3			
MSZ-LN35VG2B-E2			
MSZ-LN35VG2B-E3			
MSZ-LN35VG2B-EN2			
MSZ-LN35VG2B-ER2			
MSZ-LN35VG2B-ER3			
MSZ-LN35VG2B-ET2			
MSZ-LN35VG2B-ET3			
MSZ-LN35VG2B-SC1			
MSZ-LN35VG2R-A2			

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-LN35VG2R-A3 MSZ-LN35VG2R-E2 MSZ-LN35VG2R-E3 MSZ-LN35VG2R-EN2 MSZ-LN35VG2R-ER2 MSZ-LN35VG2R-ER3 MSZ-LN35VG2R-ET2 MSZ-LN35VG2R-ET3 MSZ-LN35VG2R-SC1 MSZ-LN35VG2V-A2 MSZ-LN35VG2V-A3 MSZ-LN35VG2V-E2 MSZ-LN35VG2V-E3 MSZ-LN35VG2V-EN2 MSZ-LN35VG2V-ER2 MSZ-LN35VG2V-ER3 MSZ-LN35VG2V-ET2 MSZ-LN35VG2V-ET3 MSZ-LN35VG2V-SC1 MSZ-LN35VG2W-E2 MSZ-LN35VG2W-E3 MSZ-LN35VG2W-EN2 MSZ-LN35VG2W-ER2 MSZ-LN35VG2W-ER3 MSZ-LN35VG2W-ET2 MSZ-LN35VG2W-ET3 MSZ-LN35VG2W-SC1 MSZ-LN35VGDB-A1 MSZ-LN35VGDR-A1 MSZ-LN35VGDV-A1 MSZ-LN50VG2B-A2 MSZ-LN50VG2B-E2 MSZ-LN50VG2B-E3 MSZ-LN50VG2B-EN2 MSZ-LN50VG2B-ER2 MSZ-LN50VG2B-ER3 MSZ-LN50VG2B-ET2 MSZ-LN50VG2B-ET3 MSZ-LN50VG2B-SC1 MSZ-LN50VG2R-A2 MSZ-LN50VG2R-E2 MSZ-LN50VG2R-E3 MSZ-LN50VG2R-EN2 MSZ-LN50VG2R-ER2 MSZ-LN50VG2R-ER3 MSZ-LN50VG2R-ET2 MSZ-LN50VG2R-ET3 MSZ-LN50VG2R-SC1 MSZ-LN50VG2V-A2 MSZ-LN50VG2V-E2 MSZ-LN50VG2V-E3 MSZ-LN50VG2V-EN2 MSZ-LN50VG2V-ER2 MSZ-LN50VG2V-ER3 MSZ-LN50VG2V-ET2 MSZ-LN50VG2V-ET3 MSZ-LN50VG2V-SC1 MSZ-LN50VG2W-E2 MSZ-LN50VG2W-E3 MSZ-LN50VG2W-EN2 MSZ-LN50VG2W-ER2 MSZ-LN50VG2W-ER3	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-LN50VG2W-ET2	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-LN50VG2W-ET3			
MSZ-LN50VG2W-SC1			
MSZ-LN50VG3B-A1			
MSZ-LN50VG3R-A1			
MSZ-LN50VG3V-A1			
MSZ-LN50VGDB-A1			
MSZ-LN50VGDR-A1			
MSZ-LN50VGDV-A1			
MSZ-LN60VG2B-A2			
MSZ-LN60VG2B-E2			
MSZ-LN60VG2B-E3			
MSZ-LN60VG2B-ER2			
MSZ-LN60VG2B-ER3			
MSZ-LN60VG2B-ET2			
MSZ-LN60VG2B-ET3			
MSZ-LN60VG2R-A2			
MSZ-LN60VG2R-E2			
MSZ-LN60VG2R-E3			
MSZ-LN60VG2R-ER2			
MSZ-LN60VG2R-ER3			
MSZ-LN60VG2R-ET2			
MSZ-LN60VG2R-ET3			
MSZ-LN60VG2V-A2			
MSZ-LN60VG2V-E2			
MSZ-LN60VG2V-E3			
MSZ-LN60VG2V-ER2			
MSZ-LN60VG2V-ER3			
MSZ-LN60VG2V-ET2			
MSZ-LN60VG2V-ET3			
MSZ-LN60VG2W-E2			
MSZ-LN60VG2W-E3			
MSZ-LN60VG2W-ER2			
MSZ-LN60VG2W-ER3			
MSZ-LN60VG2W-ET2			
MSZ-LN60VG2W-ET3			
MSZ-LN60VG3B-A1			
MSZ-LN60VG3R-A1			
MSZ-LN60VG3V-A1			
MSZ-LN60VGDB-A1			
MSZ-LN60VGDR-A1			
MSZ-LN60VGDV-A1			
MSZ-RW25VG-E1			
MSZ-RW25VG-ER1			
MSZ-RW25VG-ET1			
MSZ-RW25VG-SC1			
MSZ-RW35VG-E1			
MSZ-RW35VG-ER1			
MSZ-RW35VG-ET1			
MSZ-RW35VG-SC1			
MSZ-RW50VG-E1			
MSZ-RW50VG-ER1			
MSZ-RW50VG-ET1			
MSZ-RW50VG-SC1			
MSZ-RZ25VU-E1			
MSZ-RZ25VU-SC1			
MSZ-RZ35VU-E1			
MSZ-RZ35VU-SC1			
MSZ-RZ50VU-E1			
MSZ-RZ50VU-SC1			
MSZ-WX18VFK			
MSZ-WX20VFK			

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-WX25VFK MSZ-ZA09VFK MSZ-ZA12VFK MSZ-ZA18VFK MSZ-ZY09VFK MSZ-ZY12VFK MSZ-ZY18VFK	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
<u>Models released in 2025 or later.</u> MFZ-KT25VGK-E1 MFZ-KT25VGK-ET1 MFZ-KT35VGK-E1 MFZ-KT35VGK-ET1 MFZ-KT50VGK-E1 MFZ-KT50VGK-ET1 MFZ-KT60VGK-E1 MFZ-KT60VGK-ET1 MFZ-KW25VGK-E1 MFZ-KW35VGK-E1 MFZ-KW50VGK-E1 MFZ-KW60VGK-E1 MSZ-AP60VGK2-E1 MSZ-AP60VGK2-E2 MSZ-AP60VGK2-ET1 MSZ-AP60VGK2-ET2 MSZ-AP71VGK2-E1 MSZ-AP71VGK2-E2 MSZ-AP71VGK2-ET1 MSZ-AP71VGK2-ET2 MSZ-AY15VGK2B-E1 MSZ-AY15VGK2B-ET1 MSZ-AY15VGK2-E1 MSZ-AY15VGK2-ET1 MSZ-AY15VGKP2B-E1 MSZ-AY15VGKP2B-ET1 MSZ-AY15VGKP2-E1 MSZ-AY15VGKP2-ET1 MSZ-AY20VGK2B-E1 MSZ-AY20VGK2B-ET1 MSZ-AY20VGK2-E1 MSZ-AY20VGK2-ET1 MSZ-AY20VGKP2B-E1 MSZ-AY20VGKP2B-ET1 MSZ-AY20VGKP2-E1 MSZ-AY20VGKP2-ET1 MSZ-AY25VGK2B-E6 MSZ-AY25VGK2B-ET6 MSZ-AY25VGK2B-SC6 MSZ-AY25VGK2-E1 MSZ-AY25VGK2-E2 MSZ-AY25VGK2-ET1 MSZ-AY25VGK2-ET2 MSZ-AY25VGK2-SC1 MSZ-AY25VGK2-SC2 MSZ-AY25VGKP2B-E6 MSZ-AY25VGKP2B-ET6 MSZ-AY25VGKP2B-SC6 MSZ-AY25VGKP2-E1	50.00 and prior	51.00 or later	<u>The fixed version is scheduled to begin release between early April and late July 2026.</u> The countermeasure is implemented in adapter software version 51.00 or later. Once the fixed version is released, please update the software according to the instructions provided by your local Mitsubishi Electric representative.

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-AY25VGKP2-E2 MSZ-AY25VGKP2-ET1 MSZ-AY25VGKP2-ET2 MSZ-AY25VGKP2-SC1 MSZ-AY25VGKP2-SC2 MSZ-AY35VGK2B-E6 MSZ-AY35VGK2B-ET6 MSZ-AY35VGK2B-SC6 MSZ-AY35VGK2-E1 MSZ-AY35VGK2-E2 MSZ-AY35VGK2-ET1 MSZ-AY35VGK2-ET2 MSZ-AY35VGK2-SC1 MSZ-AY35VGK2-SC2 MSZ-AY35VGKP2B-E6 MSZ-AY35VGKP2B-ET6 MSZ-AY35VGKP2B-SC6 MSZ-AY35VGKP2-E1 MSZ-AY35VGKP2-E2 MSZ-AY35VGKP2-ET1 MSZ-AY35VGKP2-ET2 MSZ-AY35VGKP2-SC1 MSZ-AY35VGKP2-SC2 MSZ-AY42VGK2B-E6 MSZ-AY42VGK2B-ET6 MSZ-AY42VGK2B-SC6 MSZ-AY42VGK2-E1 MSZ-AY42VGK2-E2 MSZ-AY42VGK2-ET1 MSZ-AY42VGK2-ET2 MSZ-AY42VGK2-SC1 MSZ-AY42VGK2-SC2 MSZ-AY42VGKP2B-E6 MSZ-AY42VGKP2B-ET6 MSZ-AY42VGKP2B-SC6 MSZ-AY42VGKP2-E1 MSZ-AY42VGKP2-E2 MSZ-AY42VGKP2-ET1 MSZ-AY42VGKP2-ET2 MSZ-AY42VGKP2-SC1 MSZ-AY42VGKP2-SC2 MSZ-AY50VGK2B-E6 MSZ-AY50VGK2B-ET6 MSZ-AY50VGK2B-SC6 MSZ-AY50VGK2-E1 MSZ-AY50VGK2-E2 MSZ-AY50VGK2-ET1 MSZ-AY50VGK2-ET2 MSZ-AY50VGK2-SC1 MSZ-AY50VGK2-SC2 MSZ-AY50VGKP2B-E6 MSZ-AY50VGKP2B-ET6 MSZ-AY50VGKP2B-SC6 MSZ-AY50VGKP2-E1 MSZ-AY50VGKP2-E2 MSZ-AY50VGKP2-ET1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-AY50VGKP2-ET2	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-AY50VGKP2-SC1			
MSZ-AY50VGKP2-SC2			
MSZ-BT20VGK2-E1			
MSZ-BT20VGK2-E2			
MSZ-BT20VGK2-ET1			
MSZ-BT20VGK2-ET2			
MSZ-BT25VGK2-E1			
MSZ-BT25VGK2-E2			
MSZ-BT25VGK2-ET1			
MSZ-BT25VGK2-ET2			
MSZ-BT35VGK2-E1			
MSZ-BT35VGK2-E2			
MSZ-BT35VGK2-ET1			
MSZ-BT35VGK2-ET2			
MSZ-BT50VGK2-E1			
MSZ-BT50VGK2-E2			
MSZ-BT50VGK2-ET1			
MSZ-BT50VGK2-ET2			
MSZ-EF18VGK2B-E1			
MSZ-EF18VGK2B-E2			
MSZ-EF18VGK2S-E1			
MSZ-EF18VGK2S-E2			
MSZ-EF18VGK2W-E1			
MSZ-EF18VGK2W-E2			
MSZ-EF22VGK2B-E1			
MSZ-EF22VGK2B-E2			
MSZ-EF22VGK2B-ET1			
MSZ-EF22VGK2B-ET2			
MSZ-EF22VGK2S-E1			
MSZ-EF22VGK2S-E2			
MSZ-EF22VGK2S-ET1			
MSZ-EF22VGK2S-ET2			
MSZ-EF22VGK2W-E1			
MSZ-EF22VGK2W-E2			
MSZ-EF22VGK2W-ET1			
MSZ-EF22VGK2W-ET2			
MSZ-EF25VGK2B-E1			
MSZ-EF25VGK2B-E2			
MSZ-EF25VGK2B-ET1			
MSZ-EF25VGK2B-ET2			
MSZ-EF25VGK2S-E1			
MSZ-EF25VGK2S-E2			
MSZ-EF25VGK2S-ET1			
MSZ-EF25VGK2S-ET2			
MSZ-EF25VGK2W-E1			
MSZ-EF25VGK2W-E2			
MSZ-EF25VGK2W-ET1			
MSZ-EF25VGK2W-ET2			
MSZ-EF35VGK2B-E1			
MSZ-EF35VGK2B-E2			
MSZ-EF35VGK2B-ET1			
MSZ-EF35VGK2B-ET2			
MSZ-EF35VGK2S-E1			
MSZ-EF35VGK2S-E2			
MSZ-EF35VGK2S-ET1			
MSZ-EF35VGK2S-ET2			
MSZ-EF35VGK2W-E1			
MSZ-EF35VGK2W-E2			
MSZ-EF35VGK2W-ET1			
MSZ-EF35VGK2W-ET2			
MSZ-EF42VGK2B-E1			

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-EF42VGK2B-E2	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-EF42VGK2B-ET1			
MSZ-EF42VGK2B-ET2			
MSZ-EF42VGK2S-E1			
MSZ-EF42VGK2S-E2			
MSZ-EF42VGK2S-ET1			
MSZ-EF42VGK2S-ET2			
MSZ-EF42VGK2W-E1			
MSZ-EF42VGK2W-E2			
MSZ-EF42VGK2W-ET1			
MSZ-EF42VGK2W-ET2			
MSZ-EF50VGK2B-E1			
MSZ-EF50VGK2B-E2			
MSZ-EF50VGK2B-ET1			
MSZ-EF50VGK2B-ET2			
MSZ-EF50VGK2S-E1			
MSZ-EF50VGK2S-E2			
MSZ-EF50VGK2S-ET1			
MSZ-EF50VGK2S-ET2			
MSZ-EF50VGK2W-E1			
MSZ-EF50VGK2W-E2			
MSZ-EF50VGK2W-ET1			
MSZ-EF50VGK2W-ET2			
MSZ-FT25VGK2-E1			
MSZ-FT25VGK2-E2			
MSZ-FT25VGK2-SC1			
MSZ-FT25VGK2-SC2			
MSZ-FT35VGK2-E1			
MSZ-FT35VGK2-E2			
MSZ-FT35VGK2-SC1			
MSZ-FT35VGK2-SC2			
MSZ-FT50VGK2-E1			
MSZ-FT50VGK2-E2			
MSZ-FT50VGK2-SC1			
MSZ-FT50VGK2-SC2			
MSZ-HR25VFK2-E1			
MSZ-HR25VFK2-E2			
MSZ-HR25VFK2-E6			
MSZ-HR25VFK2-ET1			
MSZ-HR25VFK2-ET2			
MSZ-HR35VFK2-E1			
MSZ-HR35VFK2-E2			
MSZ-HR35VFK2-E6			
MSZ-HR35VFK2-ET1			
MSZ-HR35VFK2-ET2			
MSZ-HR42VFK2-E1			
MSZ-HR42VFK2-E2			
MSZ-HR42VFK2-E6			
MSZ-HR42VFK2-ET1			
MSZ-HR42VFK2-ET2			
MSZ-HR50VFK2-E1			
MSZ-HR50VFK2-E2			
MSZ-HR50VFK2-E6			
MSZ-HR50VFK2-ET1			
MSZ-HR50VFK2-ET2			
MSZ-HR60VFK2-E1			
MSZ-HR60VFK2-ET1			
MSZ-HR71VFK2-E1			
MSZ-HR71VFK2-ET1			
MSZ-LN18VG2B-E5			
MSZ-LN18VG2R-E5			
MSZ-LN18VG2V-E5			

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-LN18VG2W-E5	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-LN18VG2W-ET4			
MSZ-LN18VG2W-SC3			
MSZ-LN18VG3B-E1			
MSZ-LN18VG3R-E1			
MSZ-LN18VG3V-E1			
MSZ-LN18VG3W-E1			
MSZ-LN18VG3W-ET1			
MSZ-LN18VG3W-SC1			
MSZ-LN18VG4MW-E1			
MSZ-LN18VG4MW-ET1			
MSZ-LN18VG4MW-SC1			
MSZ-LN20VG4FB-E1			
MSZ-LN20VG4FL-E1			
MSZ-LN20VG4FM-E1			
MSZ-LN20VG4MW-E1			
MSZ-LN25VG2B-E5			
MSZ-LN25VG2B-ET5			
MSZ-LN25VG2B-SC3			
MSZ-LN25VG2R-E5			
MSZ-LN25VG2R-ET5			
MSZ-LN25VG2R-SC3			
MSZ-LN25VG2V-E5			
MSZ-LN25VG2V-ET5			
MSZ-LN25VG2V-SC3			
MSZ-LN25VG2W-E5			
MSZ-LN25VG2W-ET5			
MSZ-LN25VG2W-SC3			
MSZ-LN25VG3B-E1			
MSZ-LN25VG3B-ET1			
MSZ-LN25VG3B-SC1			
MSZ-LN25VG3R-E1			
MSZ-LN25VG3R-ET1			
MSZ-LN25VG3R-SC1			
MSZ-LN25VG3V-E1			
MSZ-LN25VG3V-ET1			
MSZ-LN25VG3V-SC1			
MSZ-LN25VG3W-E1			
MSZ-LN25VG3W-ET1			
MSZ-LN25VG3W-SC1			
MSZ-LN25VG4FB-E1			
MSZ-LN25VG4FB-ET1			
MSZ-LN25VG4FB-SC1			
MSZ-LN25VG4FL-E1			
MSZ-LN25VG4FL-ET1			
MSZ-LN25VG4FL-SC1			
MSZ-LN25VG4FM-E1			
MSZ-LN25VG4FM-ET1			
MSZ-LN25VG4FM-SC1			
MSZ-LN25VG4MW-E1			
MSZ-LN25VG4MW-ET1			
MSZ-LN25VG4MW-SC1			
MSZ-LN35VG2B-E5			
MSZ-LN35VG2B-ET5			
MSZ-LN35VG2B-SC3			
MSZ-LN35VG2R-E5			
MSZ-LN35VG2R-ET5			
MSZ-LN35VG2R-SC3			
MSZ-LN35VG2V-E5			
MSZ-LN35VG2V-ET5			
MSZ-LN35VG2V-SC3			
MSZ-LN35VG2W-E5			

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-LN35VG2W-ET5	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-LN35VG2W-SC3			
MSZ-LN35VG3B-E1			
MSZ-LN35VG3B-ET1			
MSZ-LN35VG3B-SC1			
MSZ-LN35VG3R-E1			
MSZ-LN35VG3R-ET1			
MSZ-LN35VG3R-SC1			
MSZ-LN35VG3V-E1			
MSZ-LN35VG3V-ET1			
MSZ-LN35VG3V-SC1			
MSZ-LN35VG3W-E1			
MSZ-LN35VG3W-ET1			
MSZ-LN35VG3W-SC1			
MSZ-LN35VG4FB-E1			
MSZ-LN35VG4FB-ET1			
MSZ-LN35VG4FB-SC1			
MSZ-LN35VG4FL-E1			
MSZ-LN35VG4FL-ET1			
MSZ-LN35VG4FL-SC1			
MSZ-LN35VG4FM-E1			
MSZ-LN35VG4FM-ET1			
MSZ-LN35VG4FM-SC1			
MSZ-LN35VG4MW-E1			
MSZ-LN35VG4MW-ET1			
MSZ-LN35VG4MW-SC1			
MSZ-LN50VG2B-E5			
MSZ-LN50VG2B-ET5			
MSZ-LN50VG2B-SC3			
MSZ-LN50VG2R-E5			
MSZ-LN50VG2R-ET5			
MSZ-LN50VG2R-SC3			
MSZ-LN50VG2V-E5			
MSZ-LN50VG2V-ET5			
MSZ-LN50VG2V-SC3			
MSZ-LN50VG2W-E5			
MSZ-LN50VG2W-ET5			
MSZ-LN50VG2W-SC3			
MSZ-LN50VG3B-E1			
MSZ-LN50VG3B-ET1			
MSZ-LN50VG3B-SC1			
MSZ-LN50VG3R-E1			
MSZ-LN50VG3R-ET1			
MSZ-LN50VG3R-SC1			
MSZ-LN50VG3V-E1			
MSZ-LN50VG3V-ET1			
MSZ-LN50VG3V-SC1			
MSZ-LN50VG3W-E1			
MSZ-LN50VG3W-ET1			
MSZ-LN50VG3W-SC1			
MSZ-LN50VG4FB-E1			
MSZ-LN50VG4FB-ET1			
MSZ-LN50VG4FB-SC1			
MSZ-LN50VG4FL-E1			
MSZ-LN50VG4FL-ET1			
MSZ-LN50VG4FL-SC1			
MSZ-LN50VG4FM-E1			
MSZ-LN50VG4FM-ET1			
MSZ-LN50VG4FM-SC1			
MSZ-LN50VG4MW-E1			
MSZ-LN50VG4MW-ET1			
MSZ-LN50VG4MW-SC1			

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-LN60VG2B-E5	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-LN60VG2B-ET5			
MSZ-LN60VG2R-E5			
MSZ-LN60VG2R-ET5			
MSZ-LN60VG2V-E5			
MSZ-LN60VG2V-ET5			
MSZ-LN60VG2W-E5			
MSZ-LN60VG2W-ET5			
MSZ-LN60VG3B-E1			
MSZ-LN60VG3B-ET1			
MSZ-LN60VG3R-E1			
MSZ-LN60VG3R-ET1			
MSZ-LN60VG3V-E1			
MSZ-LN60VG3V-ET1			
MSZ-LN60VG3W-E1			
MSZ-LN60VG3W-ET1			
MSZ-LN60VG4FB-E1			
MSZ-LN60VG4FB-ET1			
MSZ-LN60VG4FL-E1			
MSZ-LN60VG4FL-ET1			
MSZ-LN60VG4FM-E1			
MSZ-LN60VG4FM-ET1			
MSZ-LN60VG4MW-E1			
MSZ-LN60VG4MW-ET1			
MSZ-LZ18VUMW-E1			
MSZ-LZ18VUMW-ET1			
MSZ-LZ18VUMW-SC1			
MSZ-LZ20VUFB-E1			
MSZ-LZ20VUFL-E1			
MSZ-LZ20VUFM-E1			
MSZ-LZ20VUMW-E1			
MSZ-LZ25VUFB-E1			
MSZ-LZ25VUFB-ET1			
MSZ-LZ25VUFB-SC1			
MSZ-LZ25VUFL-E1			
MSZ-LZ25VUFL-ET1			
MSZ-LZ25VUFL-SC1			
MSZ-LZ25VUFM-E1			
MSZ-LZ25VUFM-ET1			
MSZ-LZ25VUFM-SC1			
MSZ-LZ25VUMW-E1			
MSZ-LZ25VUMW-ET1			
MSZ-LZ25VUMW-SC1			
MSZ-LZ35VUFB-E1			
MSZ-LZ35VUFB-ET1			
MSZ-LZ35VUFB-SC1			
MSZ-LZ35VUFL-E1			
MSZ-LZ35VUFL-ET1			
MSZ-LZ35VUFL-SC1			
MSZ-LZ35VUFM-E1			
MSZ-LZ35VUFM-ET1			
MSZ-LZ35VUFM-SC1			
MSZ-LZ35VUMW-E1			
MSZ-LZ35VUMW-ET1			
MSZ-LZ35VUMW-SC1			
MSZ-LZ50VUFB-E1			
MSZ-LZ50VUFB-ET1			
MSZ-LZ50VUFB-SC1			
MSZ-LZ50VUFL-E1			
MSZ-LZ50VUFL-ET1			
MSZ-LZ50VUFL-SC1			
MSZ-LZ50VUFM-E1			

Model No.	Affected Version	Fixed Version	Measure Details
MSZ-LZ50VUFM-ET1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-LZ50VUFM-SC1			
MSZ-LZ50VUMW-E1			
MSZ-LZ50VUMW-ET1			
MSZ-LZ50VUMW-SC1			
MSZ-LZ60VUFB-E1			
MSZ-LZ60VUFB-ET1			
MSZ-LZ60VUFL-E1			
MSZ-LZ60VUFL-ET1			
MSZ-LZ60VUFM-E1			
MSZ-LZ60VUFM-ET1			
MSZ-LZ60VUMW-E1			
MSZ-LZ60VUMW-ET1			
MSZ-RW25VG2-E1			
MSZ-RW25VG2-SC1			
MSZ-RW35VG2-E1			
MSZ-RW35VG2-SC1			
MSZ-RW50VG2-E1			
MSZ-RW50VG2-SC1			
MSZ-RZ25VUB-E1			
MSZ-RZ25VUB-SC1			
MSZ-RZ25VU-E2			
MSZ-RZ25VU-ET1			
MSZ-RZ25VU-SC2			
MSZ-RZ35VUB-E1			
MSZ-RZ35VUB-SC1			
MSZ-RZ35VU-E2			
MSZ-RZ35VU-ET1			
MSZ-RZ35VU-SC2			
MSZ-RZ50VUB-E1			
MSZ-RZ50VUB-SC1			
MSZ-RZ50VU-E2			
MSZ-RZ50VU-SC2			

[3] Packaged Air Conditioners (for Japan)

Model No.	Affected Version	Fixed Version	Measure Details
PAC-SK43ML	41.00 and prior	42.00 or later	<p>The fixed version is scheduled to begin release between early April and late July 2026.</p> <p>Once the fixed version is released, please update the software according to the procedure below.</p> <p>The countermeasure is implemented in adapter software version 42.00 or later.</p> <p>Please update to the fixed version via the "MyMU" application or the "Kirigamine REMOTE" application.</p> <p>[For MyMU users] Check and update the software version from "Adapter Information" under "Registered Devices" in the "MyMU" application.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p> <p>[For Kirigamine REMOTE users] Check and update the software version from "Wireless LAN Software Update" in "Air Conditioner Management" - "(Room Name)" in the "Kirigamine REMOTE" application.</p> <p>For details, refer to the Kirigamine REMOTE user manual at the site below. https://www.mitsubishielectric.co.jp/home/kirigamine/function/remo-te/ib.html (In Japanese)</p> <p>If you use only HEMS, please install and configure the Kirigamine REMOTE application by referring to the Kirigamine REMOTE manual so that you can check and update the version.</p>

[4] Wireless LAN Adapters for Room Air Conditioners (for Japan)

Model No.	Affected Version	Fixed Version	Measure Details
MAC-900IF	41.00 and prior	42.00 or later	<p><u>The fixed version is scheduled to begin release between early April and late July 2026.</u></p> <p>Once the fixed version is released, please update the software according to the procedure below.</p> <p>The countermeasure is implemented in adapter software version 42.00 or later.</p> <p>Please update to the fixed version via the "MyMU" application or the "Kirigamine REMOTE" application.</p> <p>[For MyMU users] Check and update the software version from "Adapter Information" under "Registered Devices" in the "MyMU" application.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p> <p>[For Kirigamine REMOTE users] Check and update the software version from "Wireless LAN Software Update" in "Air Conditioner Management" - "(Room Name)" in the "Kirigamine REMOTE" application.</p> <p>For details, refer to the Kirigamine REMOTE user manual at the site below. https://www.mitsubishielectric.co.jp/home/kirigamine/function/remo te/ib.html (In Japanese)</p> <p>If you use only HEMS, please install and configure the Kirigamine REMOTE application by referring to the Kirigamine REMOTE manual so that you can check and update the version.</p>

[5] Wireless LAN Adapters for Room Air Conditioners (outside Japan)

Model No.	Affected Version	Fixed Version	Measure Details
<p><u>Models released in 2020-2024.</u></p> <p>MAC-507IF-E MAC-587IF-E MAC-588IF-E MAC-589IF-EM S-MAC-002IF S-MAC-703IF S-MAC-704IF S-MAC-705IF</p>	41.00 and prior	42.00 or later	<p><u>The fixed version is scheduled to begin release between early April and late July 2026.</u></p> <p>The countermeasure is implemented in adapter software version Ver42.00 or later.</p> <p>Once the fixed version is released, please update the software according to the instructions provided by your local Mitsubishi Electric representative.</p>
<p><u>Models released in 2025 or later.</u></p> <p>MAC-597IF-E MAC-597IF-EM</p>	50.00 and prior	51.00 or later	<p><u>The fixed version is scheduled to begin release between early April and late July 2026.</u></p> <p>The countermeasure is implemented in adapter software version Ver51.00 or later.</p> <p>Once the fixed version is released, please update the software according to the instructions provided by your local Mitsubishi Electric representative.</p>

[6] Refrigerators (for Japan)

Model No.	Affected Version	Fixed Version	Measure Details
MR-BD46K MR-BD46M MR-BD46N MR-MD45K MR-MD45M MR-MD45N MR-MXD50G MR-MXD57G MR-MZ49J MR-MZ49K MR-MZ49M MR-MZ49N MR-MZ54H MR-MZ54J MR-MZ54K MR-MZ54M MR-MZ54N MR-MZ60H MR-MZ60J MR-MZ60K MR-MZ60M MR-MZ60N MR-WXD47LJ MR-WXD47LK MR-WXD47LM MR-WXD47LN MR-WXD52G MR-WXD60G MR-WXD70G MR-WXD70J MR-WXD70K MR-WXD70M MR-WXD70N MR-WZ50J MR-WZ50K MR-WZ50M MR-WZ50N MR-WZ55H MR-WZ55J MR-WZ55K MR-WZ55M MR-WZ55N MR-WZ61H MR-WZ61J MR-WZ61K MR-WZ61M MR-WZ61N	01.24 and prior	01.77 or later	<p>The fixed version is scheduled to begin release between March 24 and April 17, 2026.</p> <p>Once the fixed version is released, please update the software according to the procedure below.</p> <p>The countermeasure is implemented in adapter software version 01.77 or later.</p> <p>Please update to the fixed version via the "MyMU" application.</p> <p>Check and update the software version from "Adapter Information" under "Registered Devices" in the "MyMU" application.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p>

[7] Heat Pump Water Heaters / HEMS-Compatible Adapters / Wireless LAN Adapters (for Japan)

Model No.	Affected Version	Fixed Version	Measure Details
GT-RA1 GT-RA2	01.69 and prior	01.78 or later	<p>The fixed version is scheduled to begin release between April 13 and April 17, 2026.</p> <p>Once the fixed version is released, please update the software according to the procedure below.</p> <p>The countermeasure is implemented in adapter software version 01.78 or later.</p> <p>Please update to the fixed version via the "MyMU" application.</p> <p>Check and update the software version from "Adapter Information" under "Registered Devices" in the "MyMU" application.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p>
GT-HR1 GT-HR2 RMCB-H6SE-T RMCB-F6SE-T RMCB-D6SE-T RMCB-D6SE-T-PV RMCB-H7SE RMCB-F7SE RMCB-D7SE RMCB-N7	01.69 and prior	01.78 or later	<p>The fixed version is scheduled to begin release between April 13 and April 17, 2026.</p> <p>Once the fixed version is released, please update the software according to the procedure below.</p> <p>The countermeasure is implemented in adapter software version 01.78 or later.</p> <p>Please update to the fixed version via the "MyMU" application.</p> <p>Check and update the software version from "Adapter Information" under "Registered Devices" in the "MyMU" application.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p> <p>For HEMS users, there are no plans to release a fixed version. Please take the measures described in "Mitigations / Workarounds."</p>
GT-HEM4	01.17 and prior	-	<p>There are no plans to release a fixed version.</p> <p>Please take the mitigation measures described in "Mitigations / Workarounds."</p>

[8] Bathroom Dryer / Heater / Ventilation Systems (for Japan)

Model No.	Affected Version	Fixed Version	Measure Details
V-241BZ-RC V-241BZ5-RC WD-240DK-RC WD-240DK2-RC V-241BZ5-RC-NR	01.13 and prior	01.72 or later	<p><u>The fixed version is scheduled to begin release between March 24 and April 17, 2026.</u> Once the fixed version is released, please update the software according to the procedure below.</p> <p>The countermeasure is implemented in adapter software version 01.72 or later.</p> <p>Please update to the fixed version via the "MyMU" application or the "Bath Karat REMOTE" application.</p> <p>[For MyMU users] Check and update the software version from "Adapter Information" under "Registered Devices" in the "MyMU" application.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p> <p>[For Bath Karat REMOTE users] Check and update the software version from "Adapter Software Version" in "Device Information" in the "Bath Karat REMOTE" application.</p> <p>For details, refer to the Bath Karat REMOTE user manual at the site below. https://www.mitsubishielectric.co.jp/ldg/ja/air/products/ventilationfan/bath/IB/pdf/bathkaratremote.pdf (In Japanese)</p>

[9] Control Adapters for Mitsubishi HEMS / Wireless LAN Adapters (for Japan)

Model No.	Affected Version	Fixed Version	Measure Details
P-WA01 P-HM04WA	01.14 and prior	-	<p>There are no plans to release a fixed version. Please take the mitigation measures described in "Mitigations / Workarounds."</p>
P-WA02 P-HM05WA	01.40 and prior	01.73 or later	<p><u>The fixed version is scheduled to begin release between March 24 and April 17, 2026.</u> Once the fixed version is released, please update the software according to the procedure below.</p> <p>The countermeasure is implemented in adapter software version 01.73 or later.</p> <p>Please update to the fixed version via the "MyMU" application.</p> <p>Check and update the software version from "Adapter Information" under "Registered Devices" in the "MyMU" application.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p>

[10] Lossnay Central Ventilation Systems (for Japan)

Model No.	Affected Version	Fixed Version	Measure Details
VL-200ZMHSV3-RC	01.12 and prior	01.71 or later	<p>The fixed version is scheduled to begin release between <u>March 24 and April 17, 2026</u>.</p> <p>Once the fixed version is released, please update the software according to the procedure below.</p> <p>The countermeasure is implemented in adapter software version 01.71 or later.</p> <p>Please update to the fixed version via the "MyMU" application.</p> <p>Check and update the software version from "Adapter Information" under "Registered Devices" in the "MyMU" application.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p>

[11] Smart Switches for Ventilation Fans and Lossnay (for Japan)

Model No.	Affected Version	Fixed Version	Measure Details
P-04SWRC P-10SWRC P-1600SWRC	01.11 and prior	01.74 or later	<p>The fixed version is scheduled to begin release between <u>March 24 and April 17, 2026</u>.</p> <p>Once the fixed version is released, please update the software according to the procedure below.</p> <p>The countermeasure is implemented in adapter software version 01.74 or later.</p> <p>Please update to the fixed version via the "MyMU" application.</p> <p>Check and update the software version from "Adapter Information" under "Registered Devices" in the "MyMU" application.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p>

[12] IH Cooking Heaters (for Japan)

Model No.	Affected Version	Fixed Version	Measure Details
RE-322SXR	01.12 and prior	01.71 or later	<p>The fixed version is scheduled to begin release between <u>March 24 and April 17, 2026</u>.</p> <p>Once the fixed version is released, please update the software according to the procedure below.</p> <p>The countermeasure is implemented in adapter software version 01.71 or later.</p> <p>Please update to the fixed version via the "MyMU" application.</p> <p>Check and update the software version from "Adapter Information" under "Registered Devices" in the "MyMU" application.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p>

[13] Rice Cookers (for Japan)

Model No.	Affected Version	Fixed Version	Measure Details
NJ-AWBX10	01.15 and prior	01.76 or later	<p><u>The fixed version is scheduled to begin release between March 24 and April 17, 2026.</u></p> <p>Once the fixed version is released, please update the software according to the procedure below.</p> <p>The countermeasure is implemented in software version 01.76 or later.</p> <p>Please update to the fixed version via the "Wi-Fi Raku-Raku Suihan" application.</p> <p>To check and update the software version, from "Update" under "Communication Adapter Software Version" in "Device Information" in the "Wi-Fi Raku-Raku Suihan" application.</p>

Mitigations / Workarounds

Mitsubishi Electric recommends that customers take the following mitigation measures to minimize the risks of exploiting this vulnerability :

- For Wi-Fi router encryption keys (passwords), avoid sequential numbers or passwords inferable from MAC addresses; use a strong password combining letters and numbers, and do not disclose it to third parties.
- Do not use WEP or Open for Wi-Fi router security settings; use WPA2-PSK (AES) or equivalent.
- To prevent unauthorized device connections, enable MAC address filtering on the Wi-Fi router.
- Use a hard-to-guess login password for the Web based Wi-Fi router management interface, ensure it is not disclosed to any third parties.
- Ensure the Wi-Fi router firmware is kept up to date.
- Install the Wi-Fi router in a secure location that is inaccessible to unauthorized persons, and do not make the network available to unspecified third parties (e.g., as free Wi-Fi).
- When using access point mode (AP mode), ensure that the SSID and encryption key are not disclosed to unspecified third parties.
- Apply security updates to the OS and applications of your home devices (PCs, tablets, etc.) and keep antivirus software up to date.
- Do not click on web links in emails from untrusted sources. Also, do not open attachments in untrusted emails.

Contact information

[For Customers in Japan]

Mitsubishi Electric Customer Consultation Center: 0120-139-365 (toll-free), Mobile/PHS: 0570-077-365 (toll call charges apply)

If toll-free / Navi Dial numbers are unavailable: 03-3414-9655 (toll call charges apply)

[For Customers outside Japan]

Please contact your local Mitsubishi Electric representative.

<Inquiries>

<https://www.mitsubishielectric.com/en/contact/room-air-conditioners/>