

Information Disclosure, Information Tampering, or Denial-of-Service (DoS) Vulnerability in Multiple Home Appliances

Release date: June 11, 2026
Mitsubishi Electric Corporation

Overview

An information disclosure, information tampering, or denial-of-service (DoS) vulnerability due to Use of Hard-coded Credentials (CWE-798¹) exists in multiple home appliances. This vulnerability affects products with Wi-Fi communication enabled if they have never been connected to a Wi-Fi router since purchase, or if they have been left unconfigured after being restored to their factory default settings. The following products or usage environments are not affected by this vulnerability:

- Wi-Fi communication on the affected product is disabled.
- The Wi-Fi connection settings between the affected product and a Wi-Fi router have been completed.

An attacker within Wi-Fi radio range of an affected product may be able to access the affected product using a hard-coded SSID and password, thereby obtaining device data such as operation status, room set temperature, and room temperature; changing the air-conditioner or Wi-Fi settings; or causing Wi-Fi communication to enter a denial-of-service (DoS) condition (CVE-2026-5667). In addition, since these affected products do not store confidential information such as personal data, there is no risk of disclosure of personal data as a result of this vulnerability.

For details, please refer to "Countermeasures for Product" for each product.

CVSS²

CVE-2026-5667 CVSS:v4.0/AV:A/AC:L/AT:N/PR:N/UI:N/VC:H/VI:L/VA:L/SC:N/SI:N/SA:N Base Score:7.2

Affected products

The affected products and versions are listed in the table under "Countermeasures for Product" by model number and affected version. For information on update procedures and how to check the version, please refer to "Countermeasures for Product" for each product.

Description

An information disclosure, information tampering, or denial-of-service (DoS) vulnerability (CVE-2026-5667) due to Use of Hard-coded Credentials (CWE-798) exists in the Wi-Fi function of multiple home appliances. This vulnerability affects products with Wi-Fi communication enabled if they has never been connected to a Wi-Fi router since purchase, or if they has been left unconfigured after being restored to their factory default settings. The following products or usage environments are not affected by this vulnerability:

- Wi-Fi communication on the affected product is disabled.
- The Wi-Fi connection settings between the affected product and a Wi-Fi router have been completed (i.e., the product is connected to a Wi-Fi router).

Impact

An attacker within Wi-Fi radio range of an affected product may be able to access the affected product using a hard-coded SSID and password, thereby obtaining device data such as operation status, room set temperature, and room temperature; changing the air-conditioner or Wi-Fi settings; or cause Wi-Fi communication to enter a denial-of-service (DoS) condition.

Countermeasures for Customers

Customers using the affected products should implement the measures described in "Countermeasures for Product".

¹ <https://cwe.mitre.org/data/definitions/798.html>

² <https://www.first.org/cvss/v4-0/specification-document>

Countermeasures for Product

For the affected products, versions, and measures, please refer to the contents of each table below.

[1] Room Air Conditioners (for Japan)

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-BKR2223-W MSZ-BKR2224-W MSZ-BKR2523-W MSZ-BKR2524-W MSZ-BKR2823-W MSZ-BKR2824-W MSZ-BKR3623-W MSZ-BKR3624-W MSZ-BKR4023S-W MSZ-BKR4024S-W MSZ-BKR5623S-W MSZ-BKR5624S-W MSZ-BKR6323S-W MSZ-BKR6324S-W MSZ-BKR7123S-W MSZ-BKR7124S-W MSZ-BXV2223-W MSZ-BXV2224-W MSZ-BXV2225-W MSZ-BXV2226-W MSZ-BXV2523-W MSZ-BXV2524-W MSZ-BXV2525-W MSZ-BXV2526-W MSZ-BXV2823-W MSZ-BXV2824-W MSZ-BXV2825-W MSZ-BXV2826-W MSZ-BXV3623-W MSZ-BXV3624-W MSZ-BXV3625-W MSZ-BXV3626-W MSZ-BXV4023S-W MSZ-BXV4024S-W MSZ-BXV4025S-W MSZ-BXV4026S-W MSZ-BXV5623S-W MSZ-BXV5624S-W MSZ-BXV5625S-W MSZ-BXV5626S-W MSZ-BXV6323S-W MSZ-BXV6324S-W MSZ-BXV6325S-W MSZ-BXV6326S-W MSZ-BXV7123S-W MSZ-BXV7124S-W MSZ-BXV7125S-W MSZ-BXV7126S-W MSZ-EM2220E8-W MSZ-EM2221E9-W MSZ-EM2221E9-W-1 MSZ-EM2222E1-W MSZ-EM2222E1-W-1 MSZ-EM2222E1-W-2 MSZ-EM2223E3-W MSZ-EM2224E4-W MSZ-EM2225E5-W MSZ-EM2226E6-W	42.00 and prior	43.00 or later	<p>Wi-Fi communication is disabled by default when the product is shipped.</p> <p>If Wi-Fi communication is disabled, the product is not affected by this vulnerability.</p> <p>Even when Wi-Fi communication is enabled, the product is not affected by this vulnerability if it has already been connected to a Wi-Fi router.</p> <p>* After enabling the Wi-Fi function, connect the product to a Wi-Fi router promptly. Leaving it unconnected may expose the product to this vulnerability.</p> <p>The response procedures for each customer situation are listed below.</p> <ul style="list-style-type: none"> - Customers whose products are already connected to a Wi-Fi router This vulnerability does not affect your product. You may continue to use it as is. - Customers whose products have had Wi-Fi communication enabled after purchase but are not connected to a Wi-Fi router Follow the steps below to connect the product to a Wi-Fi router and update the adapter software. <ol style="list-style-type: none"> 1. Connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router." 2. The countermeasure is implemented in adapter software version 43.00 or later. After completing step 1, please update to the fixed version using the "MyMU" application or the "Kirigamine REMOTE" application. - Customers whose products cannot connect via Wi-Fi (for example, because they do not have a Wi-Fi router) or who do not wish to use a Wi-Fi connection Please ensure that the wireless function is disabled. If the wireless function is enabled, please disable it. For the procedure to disable the wireless function, refer to the user manual for each product. <p>Regardless of whether your product is affected by this vulnerability, please connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version when using the application. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router."</p> <p>[For MyMU users] Check and update the adapter software version from "Adapter Information" under "Registered Devices" in the "MyMU" application. You can check the current adapter software version on the same screen under "Adapter Software Version." However, only the administrator (*) can perform updates. The "Update" button is not shown on member screens, so ask the administrator (*) to perform the update. (*) The person who performs new registration (device registration) becomes the administrator.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below.</p>

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-EM2520E8-W MSZ-EM2521E9-W MSZ-EM2521E9-W-1 MSZ-EM2522E1-W MSZ-EM2522E1-W-1 MSZ-EM2522E1-W-2 MSZ-EM2523E3-W MSZ-EM2524E4-W MSZ-EM2525E5-W MSZ-EM2526E6-W MSZ-EM2820E8-W MSZ-EM2821E9-W MSZ-EM2821E9-W-1 MSZ-EM2822E1-W MSZ-EM2822E1-W-1 MSZ-EM2822E1-W-2 MSZ-EM2823E3-W MSZ-EM2824E4-W MSZ-EM2825E5-W MSZ-EM2826E6-W MSZ-EM3620E8-W MSZ-EM3621E9-W MSZ-EM3621E9-W-1 MSZ-EM3622E1-W MSZ-EM3622E1-W-1 MSZ-EM3622E1-W-2 MSZ-EM3623E3-W MSZ-EM3624E4-W MSZ-EM3625E5-W MSZ-EM3626E6-W MSZ-EM4020E8S-W MSZ-EM4021E9S-W MSZ-EM4021E9S-W-1 MSZ-EM4022E1S-W MSZ-EM4022E1S-W-1 MSZ-EM4022E1S-W-2 MSZ-EM4023E3S-W MSZ-EM4024E4S-W MSZ-EM4025E5S-W MSZ-EM4026E6S-W MSZ-EM5620E8S-W MSZ-EM5621E9S-W MSZ-EM5621E9S-W-1 MSZ-EM5622E1S-W MSZ-EM5622E1S-W-1 MSZ-EM5622E1S-W-2 MSZ-EM5623E3S-W MSZ-EM5624E4S-W MSZ-EM5625E5S-W MSZ-EM5626E6S-W MSZ-EM6320E8S-W MSZ-EM6321E9S-W MSZ-EM6321E9S-W-1 MSZ-EM6322E1S-W MSZ-EM6322E1S-W-1 MSZ-EM6322E1S-W-2 MSZ-EM6323E3S-W MSZ-EM6324E4S-W MSZ-EM6325E5S-W MSZ-EM6326E6S-W MSZ-EM7120E8S-W MSZ-EM7121E9S-W	Same as above	Same as above	<p>https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p> <p>[For Kirigamine REMOTE users] Check and update the adapter software version from "Wireless LAN Software Update" under "Air Conditioner Management" - "(Room Name)" in the "Kirigamine REMOTE" application. You can check the current adapter software version on the same screen under "Wireless LAN Software Update."</p> <p>For details, refer to the Kirigamine REMOTE user manual at the site below. https://www.mitsubishielectric.co.jp/home/kirigamine/function/remote/ib.html (In Japanese)</p> <p>If you use only HEMS, refer to the Kirigamine REMOTE user manual to check the version and perform updates. Please install the Kirigamine REMOTE application, configure it so that Kirigamine REMOTE can be used, and then complete the procedure in the Kirigamine REMOTE application.</p>

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-EM7121E9S-W-1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-EM7122E1S-W			
MSZ-EM7122E1S-W-1			
MSZ-EM7122E1S-W-2			
MSZ-EM7123E3S-W			
MSZ-EM7124E4S-W			
MSZ-EM7125E5S-W			
MSZ-EM7126E6S-W			
MSZ-EM8020E8S-W			
MSZ-EM8021E9S-W			
MSZ-EM8021E9S-W-1			
MSZ-EM8022E1S-W			
MSZ-EM8022E1S-W-1			
MSZ-EM8022E1S-W-2			
MSZ-EM8023E3S-W			
MSZ-EM8024E4S-W			
MSZ-EM8025E5S-W			
MSZ-EM8026E6S-W			
MSZ-EM9020E8S-W			
MSZ-EM9021E9S-W			
MSZ-EM9021E9S-W-1			
MSZ-EM9022E1S-W			
MSZ-EM9022E1S-W-1			
MSZ-EM9022E1S-W-2			
MSZ-EM9023E3S-W			
MSZ-EM9024E4S-W			
MSZ-EM9025E5S-W			
MSZ-EM9026E6S-W			
MSZ-EX2223E3-W			
MSZ-EX2224E4-W			
MSZ-EX2225E5-W			
MSZ-EX2226E6-W			
MSZ-EX2523E3-W			
MSZ-EX2524E4-W			
MSZ-EX2525E5-W			
MSZ-EX2526E6-W			
MSZ-EX2823E3-W			
MSZ-EX2824E4-W			
MSZ-EX2825E5-W			
MSZ-EX2826E6-W			
MSZ-EX3623E3-W			
MSZ-EX3624E4-W			
MSZ-EX3625E5-W			
MSZ-EX3626E6-W			
MSZ-EX4023E3S-W			
MSZ-EX4024E4S-W			
MSZ-EX4025E5S-W			
MSZ-EX4026E6S-W			
MSZ-EX5623E3S-W			
MSZ-EX5624E4S-W			
MSZ-EX5625E5S-W			
MSZ-EX5626E6S-W			
MSZ-EX6323E3S-W			
MSZ-EX6324E4S-W			
MSZ-EX6325E5S-W			
MSZ-EX6326E6S-W			
MSZ-EX7123E3S-W			
MSZ-EX7124E4S-W			
MSZ-EX7125E5S-W			
MSZ-EX7126E6S-W			
MSZ-FD4022S-W			
MSZ-FD4023S-W			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-FD4024S-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-FD4025S-W			
MSZ-FD4026S-W			
MSZ-FD40F1S-W			
MSZ-FD5622S-W			
MSZ-FD5623S-W			
MSZ-FD5624S-W			
MSZ-FD5625S-W			
MSZ-FD5626S-W			
MSZ-FD56F1S-W			
MSZ-FD6322S-W			
MSZ-FD6323S-W			
MSZ-FD6324S-W			
MSZ-FD6325S-W			
MSZ-FD6326S-W			
MSZ-FD63F1S-W			
MSZ-FD7122S-W			
MSZ-FD7123S-W			
MSZ-FD7124S-W			
MSZ-FD7125S-W			
MSZ-FD7126S-W			
MSZ-FD71F1S-W			
MSZ-FD8022S-W			
MSZ-FD8023S-W			
MSZ-FD8024S-W			
MSZ-FD8025S-W			
MSZ-FD8026S-W			
MSZ-FD80F1S-W			
MSZ-FZ4020S-W			
MSZ-FZ4021S-W			
MSZ-FZ4022S-W			
MSZ-FZ4024S-W			
MSZ-FZ4025S-W			
MSZ-FZ4026S-W			
MSZ-FZ40F1S-W			
MSZ-FZ5620S-W			
MSZ-FZ5621S-W			
MSZ-FZ5622S-W			
MSZ-FZ5624S-W			
MSZ-FZ5625S-W			
MSZ-FZ5626S-W			
MSZ-FZ56F1S-W			
MSZ-FZ6320S-W			
MSZ-FZ6321S-W			
MSZ-FZ6322S-W			
MSZ-FZ6324S-W			
MSZ-FZ6325S-W			
MSZ-FZ6326S-W			
MSZ-FZ63F1S-W			
MSZ-FZ7120S-W			
MSZ-FZ7121S-W			
MSZ-FZ7122S-W			
MSZ-FZ7124S-W			
MSZ-FZ7125S-W			
MSZ-FZ7126S-W			
MSZ-FZ71F1S-W			
MSZ-FZ8020S-W			
MSZ-FZ8021S-W			
MSZ-FZ8022S-W			
MSZ-FZ8024S-W			
MSZ-FZ8025S-W			
MSZ-FZ8026S-W			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-FZ80F1S-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-FZ9020S-W			
MSZ-FZ9021S-W			
MSZ-FZ9022S-W			
MSZ-FZ9024S-W			
MSZ-FZ9025S-W			
MSZ-FZ9026S-W			
MSZ-FZ90F1S-W			
MSZ-FZV4020S-W			
MSZ-FZV4021S-W			
MSZ-FZV4022S-W			
MSZ-FZV4024S-W			
MSZ-FZV4025S-W			
MSZ-FZV4026S-W			
MSZ-FZV40F1S-W			
MSZ-FZV5620S-W			
MSZ-FZV5621S-W			
MSZ-FZV5622S-W			
MSZ-FZV5624S-W			
MSZ-FZV5625S-W			
MSZ-FZV5626S-W			
MSZ-FZV56F1S-W			
MSZ-FZV6320S-W			
MSZ-FZV6321S-W			
MSZ-FZV6322S-W			
MSZ-FZV6324S-W			
MSZ-FZV6325S-W			
MSZ-FZV6326S-W			
MSZ-FZV63F1S-W			
MSZ-FZV7120S-W			
MSZ-FZV7121S-W			
MSZ-FZV7122S-W			
MSZ-FZV7124S-W			
MSZ-FZV7125S-W			
MSZ-FZV7126S-W			
MSZ-FZV71F1S-W			
MSZ-FZV8020S-W			
MSZ-FZV8021S-W			
MSZ-FZV8022S-W			
MSZ-FZV8024S-W			
MSZ-FZV8025S-W			
MSZ-FZV8026S-W			
MSZ-FZV80F1S-W			
MSZ-FZV9020S-W			
MSZ-FZV9021S-W			
MSZ-FZV9022S-W			
MSZ-FZV9024S-W			
MSZ-FZV9025S-W			
MSZ-FZV9026S-W			
MSZ-FZV90F1S-W			
MSZ-HXV2522-T			
MSZ-HXV2522-W			
MSZ-HXV2522-W-1			
MSZ-HXV2523-W			
MSZ-HXV2523-W-1			
MSZ-HXV2524-W			
MSZ-HXV2525-W			
MSZ-HXV2526-W			
MSZ-HXV2822S-T			
MSZ-HXV2822S-W			
MSZ-HXV2822S-W-1			
MSZ-HXV2823S-W			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-HXV2823S-W-1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-HXV2824S-W			
MSZ-HXV2825S-W			
MSZ-HXV2826S-W			
MSZ-HXV4022S-T			
MSZ-HXV4022S-W			
MSZ-HXV4022S-W-1			
MSZ-HXV4022S-W-2			
MSZ-HXV4023S-W			
MSZ-HXV4023S-W-1			
MSZ-HXV4024S-W			
MSZ-HXV4025S-W			
MSZ-HXV4026S-W			
MSZ-HXV5622S-T			
MSZ-HXV5622S-W			
MSZ-HXV5622S-W-1			
MSZ-HXV5622S-W-2			
MSZ-HXV5623S-W			
MSZ-HXV5623S-W-1			
MSZ-HXV5624S-W			
MSZ-HXV5625S-W			
MSZ-HXV5626S-W			
MSZ-HXV6322S-T			
MSZ-HXV6322S-W			
MSZ-HXV6322S-W-1			
MSZ-HXV6322S-W-2			
MSZ-HXV6323S-W			
MSZ-HXV6323S-W-1			
MSZ-HXV6324S-W			
MSZ-HXV6325S-W			
MSZ-HXV6326S-W			
MSZ-HXV7122S-T			
MSZ-HXV7122S-W			
MSZ-HXV7122S-W-1			
MSZ-HXV7122S-W-2			
MSZ-HXV7123S-W			
MSZ-HXV7123S-W-1			
MSZ-HXV7124S-W			
MSZ-HXV7125S-W			
MSZ-HXV7126S-W			
MSZ-HXV8022S-T			
MSZ-HXV8022S-W			
MSZ-HXV8022S-W-1			
MSZ-HXV8022S-W-2			
MSZ-HXV8023S-W			
MSZ-HXV8023S-W-1			
MSZ-HXV8024S-W			
MSZ-HXV8025S-W			
MSZ-HXV8026S-W			
MSZ-JXV2223-T			
MSZ-JXV2223-W			
MSZ-JXV2224-W			
MSZ-JXV2225-W			
MSZ-JXV2226-W			
MSZ-JXV2523-T			
MSZ-JXV2523-W			
MSZ-JXV2524-W			
MSZ-JXV2525-W			
MSZ-JXV2526-W			
MSZ-JXV2823S-T			
MSZ-JXV2823S-W			
MSZ-JXV2823-T			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-JXV2823-W MSZ-JXV2824S-W MSZ-JXV2824-W MSZ-JXV2825S-W MSZ-JXV2825-W MSZ-JXV2826S-W MSZ-JXV2826-W MSZ-JXV3623S-T MSZ-JXV3623S-W MSZ-JXV3623-T MSZ-JXV3623-W MSZ-JXV3624S-W MSZ-JXV3624-W MSZ-JXV3625S-W MSZ-JXV3625-W MSZ-JXV3626S-W MSZ-JXV3626-W MSZ-JXV4023S-T MSZ-JXV4023S-W MSZ-JXV4024S-W MSZ-JXV4025S-W MSZ-JXV4026S-W MSZ-JXV5623S-T MSZ-JXV5623S-W MSZ-JXV5624S-W MSZ-JXV5625S-W MSZ-JXV5626S-W MSZ-JXV6323S-T MSZ-JXV6323S-W MSZ-JXV6324S-W MSZ-JXV6325S-W MSZ-JXV6326S-W MSZ-JXV7123S-T MSZ-JXV7123S-W MSZ-JXV7124S-W MSZ-JXV7125S-W MSZ-JXV7126S-W MSZ-NXV2224-W MSZ-NXV2225-W MSZ-NXV2226-W MSZ-NXV2524-W MSZ-NXV2525-W MSZ-NXV2526-W MSZ-NXV2824S-W MSZ-NXV2825S-W MSZ-NXV2826S-W MSZ-NXV3624S-W MSZ-NXV3625S-W MSZ-NXV3626S-W MSZ-NXV4024S-W MSZ-NXV4025S-W MSZ-NXV4026S-W MSZ-NXV5624S-W MSZ-NXV5625S-W MSZ-NXV5626S-W MSZ-NXV6324S-W MSZ-NXV6325S-W MSZ-NXV6326S-W MSZ-R2223-W MSZ-R2224-W MSZ-R2225-W MSZ-R2226-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-R2523-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-R2524-W			
MSZ-R2525-W			
MSZ-R2526-W			
MSZ-R2823-W			
MSZ-R2824-W			
MSZ-R2825-W			
MSZ-R2826-W			
MSZ-R3623-W			
MSZ-R3624-W			
MSZ-R3625-W			
MSZ-R3626-W			
MSZ-R4023S-W			
MSZ-R4024S-W			
MSZ-R4025S-W			
MSZ-R4026S-W			
MSZ-R5623S-W			
MSZ-R5624S-W			
MSZ-R5625S-W			
MSZ-R5626S-W			
MSZ-R6323S-W			
MSZ-R6324S-W			
MSZ-R6325S-W			
MSZ-R6326S-W			
MSZ-R7123S-W			
MSZ-R7124S-W			
MSZ-R7125S-W			
MSZ-R7126S-W			
MSZ-RK2223-W			
MSZ-RK2224-W			
MSZ-RK2225-W			
MSZ-RK2226-W			
MSZ-RK2523-W			
MSZ-RK2524-W			
MSZ-RK2525-W			
MSZ-RK2526-W			
MSZ-RK2823-W			
MSZ-RK2824-W			
MSZ-RK2825-W			
MSZ-RK2826-W			
MSZ-RK3623-W			
MSZ-RK3624-W			
MSZ-RK3625-W			
MSZ-RK3626-W			
MSZ-RK4023S-W			
MSZ-RK4024S-W			
MSZ-RK4025S-W			
MSZ-RK4026S-W			
MSZ-RK5623S-W			
MSZ-RK5624S-W			
MSZ-RK5625S-W			
MSZ-RK5626S-W			
MSZ-RK6323S-W			
MSZ-RK6324S-W			
MSZ-RK6325S-W			
MSZ-RK6326S-W			
MSZ-RK7123S-W			
MSZ-RK7124S-W			
MSZ-RK7125S-W			
MSZ-RK7126S-W			
MSZ-VXV4022S-W			
MSZ-VXV4023S-W			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-VXV4024S-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-VXV4025S-W			
MSZ-VXV4026S-W			
MSZ-VXV40F1S-W			
MSZ-VXV5622S-W			
MSZ-VXV5623S-W			
MSZ-VXV5624S-W			
MSZ-VXV5625S-W			
MSZ-VXV5626S-W			
MSZ-VXV56F1S-W			
MSZ-VXV6322S-W			
MSZ-VXV6323S-W			
MSZ-VXV6324S-W			
MSZ-VXV6325S-W			
MSZ-VXV6326S-W			
MSZ-VXV63F1S-W			
MSZ-VXV7122S-W			
MSZ-VXV7123S-W			
MSZ-VXV7124S-W			
MSZ-VXV7125S-W			
MSZ-VXV7126S-W			
MSZ-VXV71F1S-W			
MSZ-VXV8022S-W			
MSZ-VXV8023S-W			
MSZ-VXV8024S-W			
MSZ-VXV8025S-W			
MSZ-VXV8026S-W			
MSZ-VXV80F1S-W			
MSZ-X2223-W			
MSZ-X2224-W			
MSZ-X2225-W			
MSZ-X2226-W			
MSZ-X2523-W			
MSZ-X2524-W			
MSZ-X2525-W			
MSZ-X2526-W			
MSZ-X2823-W			
MSZ-X2824-W			
MSZ-X2825-W			
MSZ-X2826-W			
MSZ-X3623-W			
MSZ-X3624-W			
MSZ-X3625-W			
MSZ-X3626-W			
MSZ-X4023S-W			
MSZ-X4024S-W			
MSZ-X4025S-W			
MSZ-X4026S-W			
MSZ-X5623S-W			
MSZ-X5624S-W			
MSZ-X5625S-W			
MSZ-X5626S-W			
MSZ-X6323S-W			
MSZ-X6324S-W			
MSZ-X6325S-W			
MSZ-X6326S-W			
MSZ-X7123S-W			
MSZ-X7124S-W			
MSZ-X7125S-W			
MSZ-X7126S-W			
MSZ-XD2224-W			
MSZ-XD2225-W			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-XD2226-W MSZ-XD2524-W MSZ-XD2525-W MSZ-XD2526-W MSZ-XD2824S-W MSZ-XD2825S-W MSZ-XD2826S-W MSZ-XD3624S-W MSZ-XD3625S-W MSZ-XD3626S-W MSZ-XD4024S-W MSZ-XD4025S-W MSZ-XD4026S-W MSZ-XD5624S-W MSZ-XD5625S-W MSZ-XD5626S-W MSZ-XD6324S-W MSZ-XD6325S-W MSZ-XD6326S-W MSZ-XK2223-W MSZ-XK2224-W MSZ-XK2225-W MSZ-XK2226-W MSZ-XK2523-W MSZ-XK2524-W MSZ-XK2525-W MSZ-XK2526-W MSZ-XK2823-W MSZ-XK2824-W MSZ-XK2825-W MSZ-XK2826-W MSZ-XK3623-W MSZ-XK3624-W MSZ-XK3625-W MSZ-XK3626-W MSZ-XK4023S-W MSZ-XK4024S-W MSZ-XK4025S-W MSZ-XK4026S-W MSZ-XK5623S-W MSZ-XK5624S-W MSZ-XK5625S-W MSZ-XK5626S-W MSZ-XK6323S-W MSZ-XK6324S-W MSZ-XK6325S-W MSZ-XK6326S-W MSZ-XK7123S-W MSZ-XK7124S-W MSZ-XK7125S-W MSZ-XK7126S-W MSZ-ZD2522-W MSZ-ZD2522-W-1 MSZ-ZD2523-W MSZ-ZD2523-W-1 MSZ-ZD2524-W MSZ-ZD2525-W MSZ-ZD2526-W MSZ-ZD2822S-W MSZ-ZD2822S-W-1 MSZ-ZD2823S-W MSZ-ZD2823S-W-1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-ZD2824S-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-ZD2825S-W			
MSZ-ZD2826S-W			
MSZ-ZD4022S-W			
MSZ-ZD4022S-W-1			
MSZ-ZD4022S-W-2			
MSZ-ZD4023S-W			
MSZ-ZD4023S-W-1			
MSZ-ZD4024S-W			
MSZ-ZD4025S-W			
MSZ-ZD4026S-W			
MSZ-ZD5622S-W			
MSZ-ZD5622S-W-1			
MSZ-ZD5622S-W-2			
MSZ-ZD5623S-W			
MSZ-ZD5623S-W-1			
MSZ-ZD5624S-W			
MSZ-ZD5625S-W			
MSZ-ZD5626S-W			
MSZ-ZD6322S-W			
MSZ-ZD6322S-W-1			
MSZ-ZD6322S-W-2			
MSZ-ZD6323S-W			
MSZ-ZD6323S-W-1			
MSZ-ZD6324S-W			
MSZ-ZD6325S-W			
MSZ-ZD6326S-W			
MSZ-ZD7122S-W			
MSZ-ZD7122S-W-1			
MSZ-ZD7122S-W-2			
MSZ-ZD7123S-W			
MSZ-ZD7123S-W-1			
MSZ-ZD7124S-W			
MSZ-ZD7125S-W			
MSZ-ZD7126S-W			
MSZ-ZD8022S-W			
MSZ-ZD8022S-W-1			
MSZ-ZD8022S-W-2			
MSZ-ZD8023S-W			
MSZ-ZD8023S-W-1			
MSZ-ZD8024S-W			
MSZ-ZD8025S-W			
MSZ-ZD8026S-W			
MSZ-ZW2220-T			
MSZ-ZW2220-W			
MSZ-ZW2221-T			
MSZ-ZW2221-T-1			
MSZ-ZW2221-W			
MSZ-ZW2221-W-1			
MSZ-ZW2222-T			
MSZ-ZW2222-T-1			
MSZ-ZW2222-T-2			
MSZ-ZW2222-W			
MSZ-ZW2222-W-1			
MSZ-ZW2222-W-2			
MSZ-ZW2223-T			
MSZ-ZW2223-W			
MSZ-ZW2224-W			
MSZ-ZW2225-W			
MSZ-ZW2226-W			
MSZ-ZW2520-T			
MSZ-ZW2520-W			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-ZW2521-T	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-ZW2521-T-1			
MSZ-ZW2521-W			
MSZ-ZW2521-W-1			
MSZ-ZW2522-T			
MSZ-ZW2522-T-1			
MSZ-ZW2522-T-2			
MSZ-ZW2522-W			
MSZ-ZW2522-W-1			
MSZ-ZW2522-W-2			
MSZ-ZW2523-T			
MSZ-ZW2523-W			
MSZ-ZW2524-W			
MSZ-ZW2525-W			
MSZ-ZW2526-W			
MSZ-ZW2820S-T			
MSZ-ZW2820S-W			
MSZ-ZW2820-T			
MSZ-ZW2820-W			
MSZ-ZW2821S-T			
MSZ-ZW2821S-T-1			
MSZ-ZW2821S-W			
MSZ-ZW2821S-W-1			
MSZ-ZW2821-T			
MSZ-ZW2821-T-1			
MSZ-ZW2821-W			
MSZ-ZW2821-W-1			
MSZ-ZW2822S-T			
MSZ-ZW2822S-T-1			
MSZ-ZW2822S-T-2			
MSZ-ZW2822S-W			
MSZ-ZW2822S-W-1			
MSZ-ZW2822S-W-2			
MSZ-ZW2822-T			
MSZ-ZW2822-T-1			
MSZ-ZW2822-T-2			
MSZ-ZW2822-W			
MSZ-ZW2822-W-1			
MSZ-ZW2822-W-2			
MSZ-ZW2823S-T			
MSZ-ZW2823S-W			
MSZ-ZW2823-T			
MSZ-ZW2823-W			
MSZ-ZW2824S-W			
MSZ-ZW2824-W			
MSZ-ZW2825S-W			
MSZ-ZW2825-W			
MSZ-ZW2826S-W			
MSZ-ZW2826-W			
MSZ-ZW3620S-T			
MSZ-ZW3620S-W			
MSZ-ZW3620-T			
MSZ-ZW3620-W			
MSZ-ZW3621S-T			
MSZ-ZW3621S-T-1			
MSZ-ZW3621S-W			
MSZ-ZW3621S-W-1			
MSZ-ZW3621-T			
MSZ-ZW3621-T-1			
MSZ-ZW3621-W			
MSZ-ZW3621-W-1			
MSZ-ZW3622S-T			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-ZW3622S-T-1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-ZW3622S-T-2			
MSZ-ZW3622S-W			
MSZ-ZW3622S-W-1			
MSZ-ZW3622S-W-2			
MSZ-ZW3622-T			
MSZ-ZW3622-T-1			
MSZ-ZW3622-T-2			
MSZ-ZW3622-W			
MSZ-ZW3622-W-1			
MSZ-ZW3622-W-2			
MSZ-ZW3623S-T			
MSZ-ZW3623S-W			
MSZ-ZW3623-T			
MSZ-ZW3623-W			
MSZ-ZW3624S-W			
MSZ-ZW3624-W			
MSZ-ZW3625S-W			
MSZ-ZW3625-W			
MSZ-ZW3626S-W			
MSZ-ZW3626-W			
MSZ-ZW4020S-T			
MSZ-ZW4020S-W			
MSZ-ZW4021S-T			
MSZ-ZW4021S-T-1			
MSZ-ZW4021S-W			
MSZ-ZW4021S-W-1			
MSZ-ZW4022S-T			
MSZ-ZW4022S-T-1			
MSZ-ZW4022S-T-2			
MSZ-ZW4022S-W			
MSZ-ZW4022S-W-1			
MSZ-ZW4022S-W-2			
MSZ-ZW4023S-T			
MSZ-ZW4023S-W			
MSZ-ZW4024S-W			
MSZ-ZW4025S-W			
MSZ-ZW4026S-W			
MSZ-ZW5620S-T			
MSZ-ZW5620S-W			
MSZ-ZW5621S-T			
MSZ-ZW5621S-T-1			
MSZ-ZW5621S-W			
MSZ-ZW5621S-W-1			
MSZ-ZW5622S-T			
MSZ-ZW5622S-T-1			
MSZ-ZW5622S-T-2			
MSZ-ZW5622S-W			
MSZ-ZW5622S-W-1			
MSZ-ZW5622S-W-2			
MSZ-ZW5623S-T			
MSZ-ZW5623S-W			
MSZ-ZW5624S-W			
MSZ-ZW5625S-W			
MSZ-ZW5626S-W			
MSZ-ZW6320S-T			
MSZ-ZW6320S-W			
MSZ-ZW6321S-T			
MSZ-ZW6321S-T-1			
MSZ-ZW6321S-W			
MSZ-ZW6321S-W-1			
MSZ-ZW6322S-T			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-ZW6322S-T-1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-ZW6322S-T-2			
MSZ-ZW6322S-W			
MSZ-ZW6322S-W-1			
MSZ-ZW6322S-W-2			
MSZ-ZW6323S-T			
MSZ-ZW6323S-W			
MSZ-ZW6324S-W			
MSZ-ZW6325S-W			
MSZ-ZW6326S-W			
MSZ-ZW7120S-T			
MSZ-ZW7120S-W			
MSZ-ZW7121S-T			
MSZ-ZW7121S-T-1			
MSZ-ZW7121S-W			
MSZ-ZW7121S-W-1			
MSZ-ZW7122S-T			
MSZ-ZW7122S-T-1			
MSZ-ZW7122S-T-2			
MSZ-ZW7122S-W			
MSZ-ZW7122S-W-1			
MSZ-ZW7122S-W-2			
MSZ-ZW7123S-T			
MSZ-ZW7123S-W			
MSZ-ZW7124S-W			
MSZ-ZW7125S-W			
MSZ-ZW7126S-W			
MSZ-ZW8020S-T			
MSZ-ZW8020S-W			
MSZ-ZW8021S-T			
MSZ-ZW8021S-T-1			
MSZ-ZW8021S-W			
MSZ-ZW8021S-W-1			
MSZ-ZW8022S-T			
MSZ-ZW8022S-T-1			
MSZ-ZW8022S-T-2			
MSZ-ZW8022S-W			
MSZ-ZW8022S-W-1			
MSZ-ZW8022S-W-2			
MSZ-ZW8023S-T			
MSZ-ZW8023S-W			
MSZ-ZW8024S-W			
MSZ-ZW8025S-W			
MSZ-ZW8026S-W			
MSZ-ZW9020S-T			
MSZ-ZW9020S-W			
MSZ-ZW9021S-T			
MSZ-ZW9021S-T-1			
MSZ-ZW9021S-W			
MSZ-ZW9021S-W-1			
MSZ-ZW9022S-T			
MSZ-ZW9022S-T-1			
MSZ-ZW9022S-T-2			
MSZ-ZW9022S-W			
MSZ-ZW9022S-W-1			
MSZ-ZW9022S-W-2			
MSZ-ZW9023S-T			
MSZ-ZW9023S-W			
MSZ-ZW9024S-W			
MSZ-ZW9025S-W			
MSZ-ZW9026S-W			
MSZ-ZXV2220-T			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-ZXV2220-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-ZXV2221-T			
MSZ-ZXV2221-T-1			
MSZ-ZXV2221-W			
MSZ-ZXV2221-W-1			
MSZ-ZXV2222-T			
MSZ-ZXV2222-T-1			
MSZ-ZXV2222-T-2			
MSZ-ZXV2222-W			
MSZ-ZXV2222-W-1			
MSZ-ZXV2222-W-2			
MSZ-ZXV2223-T			
MSZ-ZXV2223-W			
MSZ-ZXV2224-W			
MSZ-ZXV2225-W			
MSZ-ZXV2226-W			
MSZ-ZXV2520-T			
MSZ-ZXV2520-W			
MSZ-ZXV2521-T			
MSZ-ZXV2521-T-1			
MSZ-ZXV2521-W			
MSZ-ZXV2521-W-1			
MSZ-ZXV2522-T			
MSZ-ZXV2522-T-1			
MSZ-ZXV2522-T-2			
MSZ-ZXV2522-W			
MSZ-ZXV2522-W-1			
MSZ-ZXV2522-W-2			
MSZ-ZXV2523-T			
MSZ-ZXV2523-W			
MSZ-ZXV2524-W			
MSZ-ZXV2525-W			
MSZ-ZXV2526-W			
MSZ-ZXV2820S-T			
MSZ-ZXV2820S-W			
MSZ-ZXV2820-T			
MSZ-ZXV2820-W			
MSZ-ZXV2821S-T			
MSZ-ZXV2821S-T-1			
MSZ-ZXV2821S-W			
MSZ-ZXV2821S-W-1			
MSZ-ZXV2821-T			
MSZ-ZXV2821-T-1			
MSZ-ZXV2821-W			
MSZ-ZXV2821-W-1			
MSZ-ZXV2822S-T			
MSZ-ZXV2822S-T-1			
MSZ-ZXV2822S-T-2			
MSZ-ZXV2822S-W			
MSZ-ZXV2822S-W-1			
MSZ-ZXV2822S-W-2			
MSZ-ZXV2822-T			
MSZ-ZXV2822-T-1			
MSZ-ZXV2822-T-2			
MSZ-ZXV2822-W			
MSZ-ZXV2822-W-1			
MSZ-ZXV2822-W-2			
MSZ-ZXV2823S-T			
MSZ-ZXV2823S-W			
MSZ-ZXV2823-T			
MSZ-ZXV2823-W			
MSZ-ZXV2824S-W			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-ZXV2824-W	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-ZXV2825S-W			
MSZ-ZXV2825-W			
MSZ-ZXV2826S-W			
MSZ-ZXV2826-W			
MSZ-ZXV3620S-T			
MSZ-ZXV3620S-W			
MSZ-ZXV3620-T			
MSZ-ZXV3620-W			
MSZ-ZXV3621S-T			
MSZ-ZXV3621S-T-1			
MSZ-ZXV3621S-W			
MSZ-ZXV3621S-W-1			
MSZ-ZXV3621-T			
MSZ-ZXV3621-T-1			
MSZ-ZXV3621-W			
MSZ-ZXV3621-W-1			
MSZ-ZXV3622S-T			
MSZ-ZXV3622S-T-1			
MSZ-ZXV3622S-T-2			
MSZ-ZXV3622S-W			
MSZ-ZXV3622S-W-1			
MSZ-ZXV3622S-W-2			
MSZ-ZXV3622-T			
MSZ-ZXV3622-T-1			
MSZ-ZXV3622-T-2			
MSZ-ZXV3622-W			
MSZ-ZXV3622-W-1			
MSZ-ZXV3622-W-2			
MSZ-ZXV3623S-T			
MSZ-ZXV3623S-W			
MSZ-ZXV3623-T			
MSZ-ZXV3623-W			
MSZ-ZXV3624S-W			
MSZ-ZXV3624-W			
MSZ-ZXV3625S-W			
MSZ-ZXV3625-W			
MSZ-ZXV3626S-W			
MSZ-ZXV3626-W			
MSZ-ZXV4020S-T			
MSZ-ZXV4020S-W			
MSZ-ZXV4021S-T			
MSZ-ZXV4021S-T-1			
MSZ-ZXV4021S-W			
MSZ-ZXV4021S-W-1			
MSZ-ZXV4022S-T			
MSZ-ZXV4022S-T-1			
MSZ-ZXV4022S-T-2			
MSZ-ZXV4022S-W			
MSZ-ZXV4022S-W-1			
MSZ-ZXV4022S-W-2			
MSZ-ZXV4023S-T			
MSZ-ZXV4023S-W			
MSZ-ZXV4024S-W			
MSZ-ZXV4025S-W			
MSZ-ZXV4026S-W			
MSZ-ZXV5620S-T			
MSZ-ZXV5620S-W			
MSZ-ZXV5621S-T			
MSZ-ZXV5621S-T-1			
MSZ-ZXV5621S-W			
MSZ-ZXV5621S-W-1			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-ZXV5622S-T	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-ZXV5622S-T-1			
MSZ-ZXV5622S-T-2			
MSZ-ZXV5622S-W			
MSZ-ZXV5622S-W-1			
MSZ-ZXV5622S-W-2			
MSZ-ZXV5623S-T			
MSZ-ZXV5623S-W			
MSZ-ZXV5624S-W			
MSZ-ZXV5625S-W			
MSZ-ZXV5626S-W			
MSZ-ZXV6320S-T			
MSZ-ZXV6320S-W			
MSZ-ZXV6321S-T			
MSZ-ZXV6321S-T-1			
MSZ-ZXV6321S-W			
MSZ-ZXV6321S-W-1			
MSZ-ZXV6322S-T			
MSZ-ZXV6322S-T-1			
MSZ-ZXV6322S-T-2			
MSZ-ZXV6322S-W			
MSZ-ZXV6322S-W-1			
MSZ-ZXV6322S-W-2			
MSZ-ZXV6323S-T			
MSZ-ZXV6323S-W			
MSZ-ZXV6324S-W			
MSZ-ZXV6325S-W			
MSZ-ZXV6326S-W			
MSZ-ZXV7120S-T			
MSZ-ZXV7120S-W			
MSZ-ZXV7121S-T			
MSZ-ZXV7121S-T-1			
MSZ-ZXV7121S-W			
MSZ-ZXV7121S-W-1			
MSZ-ZXV7122S-T			
MSZ-ZXV7122S-T-1			
MSZ-ZXV7122S-T-2			
MSZ-ZXV7122S-W			
MSZ-ZXV7122S-W-1			
MSZ-ZXV7122S-W-2			
MSZ-ZXV7123S-T			
MSZ-ZXV7123S-W			
MSZ-ZXV7124S-W			
MSZ-ZXV7125S-W			
MSZ-ZXV7126S-W			
MSZ-ZXV8020S-T			
MSZ-ZXV8020S-W			
MSZ-ZXV8021S-T			
MSZ-ZXV8021S-T-1			
MSZ-ZXV8021S-W			
MSZ-ZXV8021S-W-1			
MSZ-ZXV8022S-T			
MSZ-ZXV8022S-T-1			
MSZ-ZXV8022S-T-2			
MSZ-ZXV8022S-W			
MSZ-ZXV8022S-W-1			
MSZ-ZXV8022S-W-2			
MSZ-ZXV8023S-T			
MSZ-ZXV8023S-W			
MSZ-ZXV8024S-W			
MSZ-ZXV8025S-W			
MSZ-ZXV8026S-W			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-ZXV9020S-T MSZ-ZXV9020S-W MSZ-ZXV9021S-T MSZ-ZXV9021S-T-1 MSZ-ZXV9021S-W MSZ-ZXV9021S-W-1 MSZ-ZXV9022S-T MSZ-ZXV9022S-T-1 MSZ-ZXV9022S-T-2 MSZ-ZXV9022S-W MSZ-ZXV9022S-W-1 MSZ-ZXV9022S-W-2 MSZ-ZXV9023S-T MSZ-ZXV9023S-W MSZ-ZXV9024S-W MSZ-ZXV9025S-W MSZ-ZXV9026S-W MSZ-ZY2223-W MSZ-ZY2224-W MSZ-ZY2225-W MSZ-ZY2226-W MSZ-ZY2523-W MSZ-ZY2524-W MSZ-ZY2525-W MSZ-ZY2526-W MSZ-ZY2823-W MSZ-ZY2824-W MSZ-ZY2825-W MSZ-ZY2826-W MSZ-ZY4023S-W MSZ-ZY4024S-W MSZ-ZY4025S-W MSZ-ZY4026S-W MSZ-ZY5623S-W MSZ-ZY5624S-W MSZ-ZY5625S-W MSZ-ZY5626S-W MSZ-ZY6323S-W MSZ-ZY6324S-W MSZ-ZY6325S-W MSZ-ZY6326S-W MSZ-ZY7124S-W MSZ-ZY7125S-W MSZ-ZY7126S-W	Same as above	Same as above	Same as above
MSZ-EM22E2-W MSZ-EM22E3-W MSZ-EM22E3-W-JITSUEN MSZ-EM25E2-W MSZ-EM25E3-W MSZ-EM28E2-W MSZ-EM28E3-W MSZ-EM36E2-W MSZ-EM36E3-W MSZ-EM40E2S-W MSZ-EM40E3S-W MSZ-EM56E2S-W MSZ-EM56E3S-W MSZ-EM63E2S-W MSZ-EM63E3S-W MSZ-EM71E2S-W MSZ-EM71E3S-W MSZ-EM80E2S-W	All Versions	-	There are no plans to release a fixed version. Please connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router."

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-AY25VGKP2B-SC6	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-AY25VGKP2-E1			
MSZ-AY25VGKP2-E2			
MSZ-AY25VGKP2-ET1			
MSZ-AY25VGKP2-ET2			
MSZ-AY25VGKP2-SC1			
MSZ-AY25VGKP2-SC2			
MSZ-AY35VGK2B-E6			
MSZ-AY35VGK2B-ET6			
MSZ-AY35VGK2B-SC6			
MSZ-AY35VGK2-E1			
MSZ-AY35VGK2-E2			
MSZ-AY35VGK2-ET1			
MSZ-AY35VGK2-ET2			
MSZ-AY35VGK2-SC1			
MSZ-AY35VGK2-SC2			
MSZ-AY35VGKP2B-E6			
MSZ-AY35VGKP2B-ET6			
MSZ-AY35VGKP2B-SC6			
MSZ-AY35VGKP2-E1			
MSZ-AY35VGKP2-E2			
MSZ-AY35VGKP2-ET1			
MSZ-AY35VGKP2-ET2			
MSZ-AY35VGKP2-SC1			
MSZ-AY35VGKP2-SC2			
MSZ-AY42VGK2B-E6			
MSZ-AY42VGK2B-ET6			
MSZ-AY42VGK2B-SC6			
MSZ-AY42VGK2-E1			
MSZ-AY42VGK2-E2			
MSZ-AY42VGK2-ET1			
MSZ-AY42VGK2-ET2			
MSZ-AY42VGK2-SC1			
MSZ-AY42VGK2-SC2			
MSZ-AY42VGKP2B-E6			
MSZ-AY42VGKP2B-ET6			
MSZ-AY42VGKP2B-SC6			
MSZ-AY42VGKP2-E1			
MSZ-AY42VGKP2-E2			
MSZ-AY42VGKP2-ET1			
MSZ-AY42VGKP2-ET2			
MSZ-AY42VGKP2-SC1			
MSZ-AY42VGKP2-SC2			
MSZ-AY50VGK2B-E6			
MSZ-AY50VGK2B-ET6			
MSZ-AY50VGK2B-SC6			
MSZ-AY50VGK2-E1			
MSZ-AY50VGK2-E2			
MSZ-AY50VGK2-ET1			
MSZ-AY50VGK2-ET2			
MSZ-AY50VGK2-SC1			
MSZ-AY50VGK2-SC2			
MSZ-AY50VGKP2B-E6			
MSZ-AY50VGKP2B-ET6			
MSZ-AY50VGKP2B-SC6			
MSZ-AY50VGKP2-E1			
MSZ-AY50VGKP2-E2			
MSZ-AY50VGKP2-ET1			
MSZ-AY50VGKP2-ET2			
MSZ-AY50VGKP2-SC1			
MSZ-AY50VGKP2-SC2			
MSZ-BT20VGK2-E1			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-BT20VGK2-E2	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-BT20VGK2-ET1			
MSZ-BT20VGK2-ET2			
MSZ-BT25VGK2-E1			
MSZ-BT25VGK2-E2			
MSZ-BT25VGK2-ET1			
MSZ-BT25VGK2-ET2			
MSZ-BT35VGK2-E1			
MSZ-BT35VGK2-E2			
MSZ-BT35VGK2-ET1			
MSZ-BT35VGK2-ET2			
MSZ-BT50VGK2-E1			
MSZ-BT50VGK2-E2			
MSZ-BT50VGK2-ET1			
MSZ-BT50VGK2-ET2			
MSZ-DA25VFK-E1			
MSZ-DA25VFK-ET1			
MSZ-DA35VFK-E1			
MSZ-DA35VFK-ET1			
MSZ-DA50VFK-E1			
MSZ-DA50VFK-ET1			
MSZ-EF18VGK2B-E1			
MSZ-EF18VGK2B-E2			
MSZ-EF18VGK2S-E1			
MSZ-EF18VGK2S-E2			
MSZ-EF18VGK2W-E1			
MSZ-EF18VGK2W-E2			
MSZ-EF22VGK2B-E1			
MSZ-EF22VGK2B-E2			
MSZ-EF22VGK2B-ET1			
MSZ-EF22VGK2B-ET2			
MSZ-EF22VGK2S-E1			
MSZ-EF22VGK2S-E2			
MSZ-EF22VGK2S-ET1			
MSZ-EF22VGK2S-ET2			
MSZ-EF22VGK2W-E1			
MSZ-EF22VGK2W-E2			
MSZ-EF22VGK2W-ET1			
MSZ-EF22VGK2W-ET2			
MSZ-EF25VGK2B-E1			
MSZ-EF25VGK2B-E2			
MSZ-EF25VGK2B-ET1			
MSZ-EF25VGK2B-ET2			
MSZ-EF25VGK2S-E1			
MSZ-EF25VGK2S-E2			
MSZ-EF25VGK2S-ET1			
MSZ-EF25VGK2S-ET2			
MSZ-EF25VGK2W-E1			
MSZ-EF25VGK2W-E2			
MSZ-EF25VGK2W-ET1			
MSZ-EF25VGK2W-ET2			
MSZ-EF35VGK2B-E1			
MSZ-EF35VGK2B-E2			
MSZ-EF35VGK2B-ET1			
MSZ-EF35VGK2B-ET2			
MSZ-EF35VGK2S-E1			
MSZ-EF35VGK2S-E2			
MSZ-EF35VGK2S-ET1			
MSZ-EF35VGK2S-ET2			
MSZ-EF35VGK2W-E1			
MSZ-EF35VGK2W-E2			
MSZ-EF35VGK2W-ET1			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-EF35VGK2W-ET2	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-EF42VGK2B-E1			
MSZ-EF42VGK2B-E2			
MSZ-EF42VGK2B-ET1			
MSZ-EF42VGK2B-ET2			
MSZ-EF42VGK2S-E1			
MSZ-EF42VGK2S-E2			
MSZ-EF42VGK2S-ET1			
MSZ-EF42VGK2S-ET2			
MSZ-EF42VGK2W-E1			
MSZ-EF42VGK2W-E2			
MSZ-EF42VGK2W-ET1			
MSZ-EF42VGK2W-ET2			
MSZ-EF50VGK2B-E1			
MSZ-EF50VGK2B-E2			
MSZ-EF50VGK2B-ET1			
MSZ-EF50VGK2B-ET2			
MSZ-EF50VGK2S-E1			
MSZ-EF50VGK2S-E2			
MSZ-EF50VGK2S-ET1			
MSZ-EF50VGK2S-ET2			
MSZ-EF50VGK2W-E1			
MSZ-EF50VGK2W-E2			
MSZ-EF50VGK2W-ET1			
MSZ-EF50VGK2W-ET2			
MSZ-FT25VGK2-E1			
MSZ-FT25VGK2-E2			
MSZ-FT25VGK2-SC1			
MSZ-FT25VGK2-SC2			
MSZ-FT35VGK2-E1			
MSZ-FT35VGK2-E2			
MSZ-FT35VGK2-SC1			
MSZ-FT35VGK2-SC2			
MSZ-FT50VGK2-E1			
MSZ-FT50VGK2-E2			
MSZ-FT50VGK2-SC1			
MSZ-FT50VGK2-SC2			
MSZ-HR25VFK2-E1			
MSZ-HR25VFK2-E2			
MSZ-HR25VFK2-E6			
MSZ-HR25VFK2-ET1			
MSZ-HR25VFK2-ET2			
MSZ-HR35VFK2-E1			
MSZ-HR35VFK2-E2			
MSZ-HR35VFK2-E6			
MSZ-HR35VFK2-ET1			
MSZ-HR35VFK2-ET2			
MSZ-HR42VFK2-E1			
MSZ-HR42VFK2-E2			
MSZ-HR42VFK2-E6			
MSZ-HR42VFK2-ET1			
MSZ-HR42VFK2-ET2			
MSZ-HR50VFK2-E1			
MSZ-HR50VFK2-E2			
MSZ-HR50VFK2-E6			
MSZ-HR50VFK2-ET1			
MSZ-HR50VFK2-ET2			
MSZ-HR60VFK2-E1			
MSZ-HR60VFK2-ET1			
MSZ-HR71VFK2-E1			
MSZ-HR71VFK2-ET1			
MSZ-LN18VG2B-E5			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-LN18VG2R-E5 MSZ-LN18VG2V-E5 MSZ-LN18VG2W-E5 MSZ-LN18VG2W-ET4 MSZ-LN18VG2W-SC3 MSZ-LN18VG3B-E1 MSZ-LN18VG3R-E1 MSZ-LN18VG3V-E1 MSZ-LN18VG3W-E1 MSZ-LN18VG3W-ET1 MSZ-LN18VG3W-SC1 MSZ-LN18VG4MW-E1 MSZ-LN18VG4MW-ET1 MSZ-LN18VG4MW-SC1 MSZ-LN20VG4FB-E1 MSZ-LN20VG4FL-E1 MSZ-LN20VG4FM-E1 MSZ-LN20VG4MW-E1 MSZ-LN25VG2B-E5 MSZ-LN25VG2B-ET5 MSZ-LN25VG2B-SC3 MSZ-LN25VG2R-E5 MSZ-LN25VG2R-ET5 MSZ-LN25VG2R-SC3 MSZ-LN25VG2V-E5 MSZ-LN25VG2V-ET5 MSZ-LN25VG2V-SC3 MSZ-LN25VG2W-E5 MSZ-LN25VG2W-ET5 MSZ-LN25VG2W-SC3 MSZ-LN25VG3B-E1 MSZ-LN25VG3B-ET1 MSZ-LN25VG3B-SC1 MSZ-LN25VG3R-E1 MSZ-LN25VG3R-ET1 MSZ-LN25VG3R-SC1 MSZ-LN25VG3V-E1 MSZ-LN25VG3V-ET1 MSZ-LN25VG3V-SC1 MSZ-LN25VG3W-E1 MSZ-LN25VG3W-ET1 MSZ-LN25VG3W-SC1 MSZ-LN25VG4FB-E1 MSZ-LN25VG4FB-ET1 MSZ-LN25VG4FB-SC1 MSZ-LN25VG4FL-E1 MSZ-LN25VG4FL-ET1 MSZ-LN25VG4FL-SC1 MSZ-LN25VG4FM-E1 MSZ-LN25VG4FM-ET1 MSZ-LN25VG4FM-SC1 MSZ-LN25VG4MW-E1 MSZ-LN25VG4MW-ET1 MSZ-LN25VG4MW-SC1 MSZ-LN35VG2B-E5 MSZ-LN35VG2B-ET5 MSZ-LN35VG2B-SC3 MSZ-LN35VG2R-E5 MSZ-LN35VG2R-ET5 MSZ-LN35VG2R-SC3 MSZ-LN35VG2V-E5 MSZ-LN35VG2V-ET5	Same as above	Same as above	Same as above

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-LN35VG2V-SC3 MSZ-LN35VG2W-E5 MSZ-LN35VG2W-ET5 MSZ-LN35VG2W-SC3 MSZ-LN35VG3B-E1 MSZ-LN35VG3B-ET1 MSZ-LN35VG3B-SC1 MSZ-LN35VG3R-E1 MSZ-LN35VG3R-ET1 MSZ-LN35VG3R-SC1 MSZ-LN35VG3V-E1 MSZ-LN35VG3V-ET1 MSZ-LN35VG3V-SC1 MSZ-LN35VG3W-E1 MSZ-LN35VG3W-ET1 MSZ-LN35VG3W-SC1 MSZ-LN35VG4FB-E1 MSZ-LN35VG4FB-ET1 MSZ-LN35VG4FB-SC1 MSZ-LN35VG4FL-E1 MSZ-LN35VG4FL-ET1 MSZ-LN35VG4FL-SC1 MSZ-LN35VG4FM-E1 MSZ-LN35VG4FM-ET1 MSZ-LN35VG4FM-SC1 MSZ-LN35VG4MW-E1 MSZ-LN35VG4MW-ET1 MSZ-LN35VG4MW-SC1 MSZ-LN50VG2B-E5 MSZ-LN50VG2B-ET5 MSZ-LN50VG2B-SC3 MSZ-LN50VG2R-E5 MSZ-LN50VG2R-ET5 MSZ-LN50VG2R-SC3 MSZ-LN50VG2V-E5 MSZ-LN50VG2V-ET5 MSZ-LN50VG2V-SC3 MSZ-LN50VG2W-E5 MSZ-LN50VG2W-ET5 MSZ-LN50VG2W-SC3 MSZ-LN50VG3B-E1 MSZ-LN50VG3B-ET1 MSZ-LN50VG3B-SC1 MSZ-LN50VG3R-E1 MSZ-LN50VG3R-ET1 MSZ-LN50VG3R-SC1 MSZ-LN50VG3V-E1 MSZ-LN50VG3V-ET1 MSZ-LN50VG3V-SC1 MSZ-LN50VG3W-E1 MSZ-LN50VG3W-ET1 MSZ-LN50VG3W-SC1 MSZ-LN50VG4FB-E1 MSZ-LN50VG4FB-ET1 MSZ-LN50VG4FB-SC1 MSZ-LN50VG4FL-E1 MSZ-LN50VG4FL-ET1 MSZ-LN50VG4FL-SC1 MSZ-LN50VG4FM-E1 MSZ-LN50VG4FM-ET1 MSZ-LN50VG4FM-SC1 MSZ-LN50VG4MW-E1	Same as above	Same as above	Same as above

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-LN50VG4MW-ET1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-LN50VG4MW-SC1			
MSZ-LN60VG2B-E5			
MSZ-LN60VG2B-ET5			
MSZ-LN60VG2R-E5			
MSZ-LN60VG2R-ET5			
MSZ-LN60VG2V-E5			
MSZ-LN60VG2V-ET5			
MSZ-LN60VG2W-E5			
MSZ-LN60VG2W-ET5			
MSZ-LN60VG3B-E1			
MSZ-LN60VG3B-ET1			
MSZ-LN60VG3R-E1			
MSZ-LN60VG3R-ET1			
MSZ-LN60VG3V-E1			
MSZ-LN60VG3V-ET1			
MSZ-LN60VG3W-E1			
MSZ-LN60VG3W-ET1			
MSZ-LN60VG4FB-E1			
MSZ-LN60VG4FB-ET1			
MSZ-LN60VG4FL-E1			
MSZ-LN60VG4FL-ET1			
MSZ-LN60VG4FM-E1			
MSZ-LN60VG4FM-ET1			
MSZ-LN60VG4MW-E1			
MSZ-LN60VG4MW-ET1			
MSZ-LZ18VUMW-E1			
MSZ-LZ18VUMW-ET1			
MSZ-LZ18VUMW-SC1			
MSZ-LZ20VUFB-E1			
MSZ-LZ20VUFL-E1			
MSZ-LZ20VUFM-E1			
MSZ-LZ20VUMW-E1			
MSZ-LZ25VUFB-E1			
MSZ-LZ25VUFB-ET1			
MSZ-LZ25VUFB-SC1			
MSZ-LZ25VUFL-E1			
MSZ-LZ25VUFL-ET1			
MSZ-LZ25VUFL-SC1			
MSZ-LZ25VUFM-E1			
MSZ-LZ25VUFM-ET1			
MSZ-LZ25VUFM-SC1			
MSZ-LZ25VUMW-E1			
MSZ-LZ25VUMW-ET1			
MSZ-LZ25VUMW-SC1			
MSZ-LZ35VUFB-E1			
MSZ-LZ35VUFB-ET1			
MSZ-LZ35VUFB-SC1			
MSZ-LZ35VUFL-E1			
MSZ-LZ35VUFL-ET1			
MSZ-LZ35VUFL-SC1			
MSZ-LZ35VUFM-E1			
MSZ-LZ35VUFM-ET1			
MSZ-LZ35VUFM-SC1			
MSZ-LZ35VUMW-E1			
MSZ-LZ35VUMW-ET1			
MSZ-LZ35VUMW-SC1			
MSZ-LZ50VUFB-E1			
MSZ-LZ50VUFB-ET1			
MSZ-LZ50VUFB-SC1			
MSZ-LZ50VUFL-E1			
MSZ-LZ50VUFL-ET1			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-LZ50VUFL-SC1 MSZ-LZ50VUFM-E1 MSZ-LZ50VUFM-ET1 MSZ-LZ50VUFM-SC1 MSZ-LZ50VUMW-E1 MSZ-LZ50VUMW-ET1 MSZ-LZ50VUMW-SC1 MSZ-LZ60VUFB-E1 MSZ-LZ60VUFB-ET1 MSZ-LZ60VUFL-E1 MSZ-LZ60VUFL-ET1 MSZ-LZ60VUFM-E1 MSZ-LZ60VUFM-ET1 MSZ-LZ60VUMW-E1 MSZ-LZ60VUMW-ET1 MSZ-RW25VG2-E1 MSZ-RW25VG2-SC1 MSZ-RW35VG2-E1 MSZ-RW35VG2-SC1 MSZ-RW50VG2-E1 MSZ-RW50VG2-SC1 MSZ-RZ25VUB-E1 MSZ-RZ25VUB-SC1 MSZ-RZ25VU-E2 MSZ-RZ25VU-ET1 MSZ-RZ25VU-SC2 MSZ-RZ35VUB-E1 MSZ-RZ35VUB-SC1 MSZ-RZ35VU-E2 MSZ-RZ35VU-ET1 MSZ-RZ35VU-SC2 MSZ-RZ50VUB-E1 MSZ-RZ50VUB-SC1 MSZ-RZ50VU-E2 MSZ-RZ50VU-SC2	Same as above	Same as above	Same as above
MFZ-GXT50VFK MFZ-GXT60VFK MFZ-GXT73VFK MFZ-KW25VGK-A1 MFZ-KW25VGK-A2 MFZ-KW35VGK-A1 MFZ-KW35VGK-A2 MFZ-KW42VGK-A1 MFZ-KW42VGK-A2 MFZ-KW50VGK-A1 MFZ-KW50VGK-A2 MFZ-KW60VGK-A1 MFZ-KW60VGK-A2 MFZ-XT50VFK MFZ-XT60VFK MFZ-XT73VFK MSXY-FP05VGK-SG2 MSXY-FP07VGK-SG2 MSXY-FP10VGK-SG2 MSXY-FP13VGK-SG2 MSXY-FP18VGK-SG2 MSXY-FP20VGK-SG2 MSXY-FP24VGK-SG2 MSY-GA10VFK-SG1 MSY-GA13VFK-SG1 MSY-GA15VFK-SG1 MSY-GA18VFK-SG1	42.00 and prior	43.00 or later	The countermeasure is implemented in adapter software version 43.00 or later. Follow the steps below to connect the product to a Wi-Fi router and update the adapter software. 1. Connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router." 2. The countermeasure is implemented in adapter software version 43.00 or later. After completing step 1, update to the fixed version following the method published by your local Mitsubishi Electric sales company. Please check the adapter software version according to the procedure published by your local Mitsubishi Electric sales company.

Model No.	Affected Version	Fixed Version	Details of Measures
MSY-GA24VFK-SG1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-AP15VGK-E1			
MSZ-AP15VGK-E2			
MSZ-AP15VGK-ER1			
MSZ-AP15VGK-ER2			
MSZ-AP15VGK-ET1			
MSZ-AP15VGK-ET2			
MSZ-AP20VGK-E1			
MSZ-AP20VGK-E2			
MSZ-AP20VGK-ER1			
MSZ-AP20VGK-ER2			
MSZ-AP20VGK-ET1			
MSZ-AP20VGK-ET2			
MSZ-AP22VGKD-A1			
MSZ-AP22VGKD-A2			
MSZ-AP25VGKD2-A1			
MSZ-AP25VGKD2-A2			
MSZ-AP25VGKD-A1			
MSZ-AP25VGKD-A2			
MSZ-AP25VGK-E1			
MSZ-AP25VGK-E2			
MSZ-AP25VGK-E3			
MSZ-AP25VGK-E7			
MSZ-AP25VGK-E8			
MSZ-AP25VGK-EN1			
MSZ-AP25VGK-EN2			
MSZ-AP25VGK-EN3			
MSZ-AP25VGK-ER1			
MSZ-AP25VGK-ER2			
MSZ-AP25VGK-ER3			
MSZ-AP25VGK-ET1			
MSZ-AP25VGK-ET2			
MSZ-AP25VGK-ET3			
MSZ-AP35VGKD2-A1			
MSZ-AP35VGKD2-A2			
MSZ-AP35VGKD-A1			
MSZ-AP35VGKD-A2			
MSZ-AP35VGK-E1			
MSZ-AP35VGK-E2			
MSZ-AP35VGK-E3			
MSZ-AP35VGK-E7			
MSZ-AP35VGK-E8			
MSZ-AP35VGK-EN1			
MSZ-AP35VGK-EN2			
MSZ-AP35VGK-EN3			
MSZ-AP35VGK-ER1			
MSZ-AP35VGK-ER2			
MSZ-AP35VGK-ER3			
MSZ-AP35VGK-ET1			
MSZ-AP35VGK-ET2			
MSZ-AP35VGK-ET3			
MSZ-AP42VGKD2-A1			
MSZ-AP42VGKD2-A2			
MSZ-AP42VGKD-A1			
MSZ-AP42VGKD-A2			
MSZ-AP42VGK-E1			
MSZ-AP42VGK-E2			
MSZ-AP42VGK-E3			
MSZ-AP42VGK-E7			
MSZ-AP42VGK-E8			
MSZ-AP42VGK-EN1			
MSZ-AP42VGK-EN2			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-AP42VGK-EN3	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-AP42VGK-ER1			
MSZ-AP42VGK-ER2			
MSZ-AP42VGK-ER3			
MSZ-AP42VGK-ET1			
MSZ-AP42VGK-ET2			
MSZ-AP42VGK-ET3			
MSZ-AP50VGKD2-A1			
MSZ-AP50VGKD2-A2			
MSZ-AP50VGKD-A1			
MSZ-AP50VGKD-A2			
MSZ-AP50VGK-E1			
MSZ-AP50VGK-E2			
MSZ-AP50VGK-E3			
MSZ-AP50VGK-E7			
MSZ-AP50VGK-E8			
MSZ-AP50VGK-EN1			
MSZ-AP50VGK-EN2			
MSZ-AP50VGK-EN3			
MSZ-AP50VGK-ER1			
MSZ-AP50VGK-ER2			
MSZ-AP50VGK-ER3			
MSZ-AP50VGK-ET1			
MSZ-AP50VGK-ET2			
MSZ-AP50VGK-ET3			
MSZ-AP60VGKD2-A1			
MSZ-AP60VGKD2-A2			
MSZ-AP60VGKD-A1			
MSZ-AP60VGKD-A2			
MSZ-AP60VGK-E2			
MSZ-AP60VGK-E3			
MSZ-AP60VGK-E4			
MSZ-AP60VGK-ER2			
MSZ-AP60VGK-ER3			
MSZ-AP60VGK-ER4			
MSZ-AP60VGK-ET2			
MSZ-AP60VGK-ET3			
MSZ-AP60VGK-ET4			
MSZ-AP71VGKD2-A1			
MSZ-AP71VGKD2-A2			
MSZ-AP71VGKD-A1			
MSZ-AP71VGKD-A2			
MSZ-AP71VGK-E2			
MSZ-AP71VGK-E3			
MSZ-AP71VGK-E4			
MSZ-AP71VGK-ER2			
MSZ-AP71VGK-ER3			
MSZ-AP71VGK-ER4			
MSZ-AP71VGK-ET2			
MSZ-AP71VGK-ET3			
MSZ-AP71VGK-ET4			
MSZ-AP80VGKD2-A1			
MSZ-AP80VGKD2-A2			
MSZ-AP80VGKD-A1			
MSZ-AP80VGKD-A2			
MSZ-AY15VGK-E1			
MSZ-AY15VGK-ER1			
MSZ-AY15VGK-ET1			
MSZ-AY15VGKP-E1			
MSZ-AY15VGKP-ER1			
MSZ-AY15VGKP-ET1			
MSZ-AY20VGK-E1			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-AY20VGK-ER1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-AY20VGK-ET1			
MSZ-AY20VGK-E1			
MSZ-AY20VGK-ER1			
MSZ-AY20VGK-ET1			
MSZ-AY25VGK-E1			
MSZ-AY25VGK-E6			
MSZ-AY25VGK-ET1			
MSZ-AY25VGK-E1			
MSZ-AY25VGK-E6			
MSZ-AY25VGK-ET1			
MSZ-AY25VGK-SC1			
MSZ-AY25VGK-SC1			
MSZ-AY35VGK-E1			
MSZ-AY35VGK-E6			
MSZ-AY35VGK-ET1			
MSZ-AY35VGK-E1			
MSZ-AY35VGK-E6			
MSZ-AY35VGK-ET1			
MSZ-AY35VGK-SC1			
MSZ-AY35VGK-SC1			
MSZ-AY42VGK-E1			
MSZ-AY42VGK-E6			
MSZ-AY42VGK-ET1			
MSZ-AY42VGK-E1			
MSZ-AY42VGK-E6			
MSZ-AY42VGK-ET1			
MSZ-AY42VGK-SC1			
MSZ-AY42VGK-SC1			
MSZ-AY50VGK-E1			
MSZ-AY50VGK-E6			
MSZ-AY50VGK-ET1			
MSZ-AY50VGK-E1			
MSZ-AY50VGK-E6			
MSZ-AY50VGK-ET1			
MSZ-AY50VGK-SC1			
MSZ-AY50VGK-SC1			
MSZ-BT20VGK-E1			
MSZ-BT20VGK-E2			
MSZ-BT20VGK-E3			
MSZ-BT20VGK-ER1			
MSZ-BT20VGK-ER2			
MSZ-BT20VGK-ET1			
MSZ-BT20VGK-ET2			
MSZ-BT20VGK-ET3			
MSZ-BT25VGK-E1			
MSZ-BT25VGK-E2			
MSZ-BT25VGK-E3			
MSZ-BT25VGK-ER1			
MSZ-BT25VGK-ER2			
MSZ-BT25VGK-ET1			
MSZ-BT25VGK-ET2			
MSZ-BT25VGK-ET3			
MSZ-BT35VGK-E1			
MSZ-BT35VGK-E2			
MSZ-BT35VGK-E3			
MSZ-BT35VGK-ER1			
MSZ-BT35VGK-ER2			
MSZ-BT35VGK-ET1			
MSZ-BT35VGK-ET2			
MSZ-BT35VGK-ET3			
MSZ-BT50VGK-E1			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-BT50VGK-E2	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-BT50VGK-E3			
MSZ-BT50VGK-ER1			
MSZ-BT50VGK-ER2			
MSZ-BT50VGK-ET1			
MSZ-BT50VGK-ET2			
MSZ-BT50VGK-ET3			
MSZ-EF18VGKB-E1			
MSZ-EF18VGKB-E2			
MSZ-EF18VGKS-E1			
MSZ-EF18VGKS-E2			
MSZ-EF18VGKW-E1			
MSZ-EF18VGKW-E2			
MSZ-EF22VGKB-A1			
MSZ-EF22VGKB-E1			
MSZ-EF22VGKB-E2			
MSZ-EF22VGKB-ER1			
MSZ-EF22VGKB-ER2			
MSZ-EF22VGKB-ET1			
MSZ-EF22VGKB-ET2			
MSZ-EF22VGKDB-A1			
MSZ-EF22VGKDB-A2			
MSZ-EF22VGKDS-A1			
MSZ-EF22VGKDS-A2			
MSZ-EF22VGKDW-A1			
MSZ-EF22VGKDW-A2			
MSZ-EF22VGKS-A1			
MSZ-EF22VGKS-E1			
MSZ-EF22VGKS-E2			
MSZ-EF22VGKS-ER1			
MSZ-EF22VGKS-ER2			
MSZ-EF22VGKS-ET1			
MSZ-EF22VGKS-ET2			
MSZ-EF22VGKW-A1			
MSZ-EF22VGKW-E1			
MSZ-EF22VGKW-E2			
MSZ-EF22VGKW-ER1			
MSZ-EF22VGKW-ER2			
MSZ-EF22VGKW-ET1			
MSZ-EF22VGKW-ET2			
MSZ-EF25VGKB-A1			
MSZ-EF25VGKB-E1			
MSZ-EF25VGKB-E2			
MSZ-EF25VGKB-ER1			
MSZ-EF25VGKB-ER2			
MSZ-EF25VGKB-ET1			
MSZ-EF25VGKB-ET2			
MSZ-EF25VGKDB-A1			
MSZ-EF25VGKDB-A2			
MSZ-EF25VGKDS-A1			
MSZ-EF25VGKDS-A2			
MSZ-EF25VGKDW-A1			
MSZ-EF25VGKDW-A2			
MSZ-EF25VGKS-A1			
MSZ-EF25VGKS-E1			
MSZ-EF25VGKS-E2			
MSZ-EF25VGKS-ER1			
MSZ-EF25VGKS-ER2			
MSZ-EF25VGKS-ET1			
MSZ-EF25VGKS-ET2			
MSZ-EF25VGKW-A1			
MSZ-EF25VGKW-E1			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-EF25VGKW-E2 MSZ-EF25VGKW-ER1 MSZ-EF25VGKW-ER2 MSZ-EF25VGKW-ET1 MSZ-EF25VGKW-ET2 MSZ-EF35VGKB-A1 MSZ-EF35VGKB-E1 MSZ-EF35VGKB-E2 MSZ-EF35VGKB-ER1 MSZ-EF35VGKB-ER2 MSZ-EF35VGKB-ET1 MSZ-EF35VGKB-ET2 MSZ-EF35VGKDB-A1 MSZ-EF35VGKDB-A2 MSZ-EF35VGKDS-A1 MSZ-EF35VGKDS-A2 MSZ-EF35VGKDW-A1 MSZ-EF35VGKDW-A2 MSZ-EF35VGKS-A1 MSZ-EF35VGKS-E1 MSZ-EF35VGKS-E2 MSZ-EF35VGKS-ER1 MSZ-EF35VGKS-ER2 MSZ-EF35VGKS-ET1 MSZ-EF35VGKS-ET2 MSZ-EF35VGKW-A1 MSZ-EF35VGKW-E1 MSZ-EF35VGKW-E2 MSZ-EF35VGKW-ER1 MSZ-EF35VGKW-ER2 MSZ-EF35VGKW-ET1 MSZ-EF35VGKW-ET2 MSZ-EF42VGKB-A1 MSZ-EF42VGKB-E1 MSZ-EF42VGKB-E2 MSZ-EF42VGKB-ER1 MSZ-EF42VGKB-ER2 MSZ-EF42VGKB-ET1 MSZ-EF42VGKB-ET2 MSZ-EF42VGKDB-A1 MSZ-EF42VGKDB-A2 MSZ-EF42VGKDS-A1 MSZ-EF42VGKDS-A2 MSZ-EF42VGKDW-A1 MSZ-EF42VGKDW-A2 MSZ-EF42VGKS-A1 MSZ-EF42VGKS-E1 MSZ-EF42VGKS-E2 MSZ-EF42VGKS-ER1 MSZ-EF42VGKS-ER2 MSZ-EF42VGKS-ET1 MSZ-EF42VGKS-ET2 MSZ-EF42VGKW-A1 MSZ-EF42VGKW-E1 MSZ-EF42VGKW-E2 MSZ-EF42VGKW-ER1 MSZ-EF42VGKW-ER2 MSZ-EF42VGKW-ET1 MSZ-EF42VGKW-ET2 MSZ-EF50VGKB-A1 MSZ-EF50VGKB-E1 MSZ-EF50VGKB-E2	Same as above	Same as above	Same as above

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-EF50VGKB-ER1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-EF50VGKB-ER2			
MSZ-EF50VGKB-ET1			
MSZ-EF50VGKB-ET2			
MSZ-EF50VGKDB-A1			
MSZ-EF50VGKDB-A2			
MSZ-EF50VGKDS-A1			
MSZ-EF50VGKDS-A2			
MSZ-EF50VGKDW-A1			
MSZ-EF50VGKDW-A2			
MSZ-EF50VGKS-A1			
MSZ-EF50VGKS-E1			
MSZ-EF50VGKS-E2			
MSZ-EF50VGKS-ER1			
MSZ-EF50VGKS-ER2			
MSZ-EF50VGKS-ET1			
MSZ-EF50VGKS-ET2			
MSZ-EF50VGKW-A1			
MSZ-EF50VGKW-E1			
MSZ-EF50VGKW-E2			
MSZ-EF50VGKW-ER1			
MSZ-EF50VGKW-ER2			
MSZ-EF50VGKW-ET1			
MSZ-EF50VGKW-ET2			
MSZ-EXA09VAK			
MSZ-EXA12VAK			
MSZ-EZA09VAK			
MSZ-EZA12VAK			
MSZ-FT25VGK-E1			
MSZ-FT25VGK-E2			
MSZ-FT25VGK-ET1			
MSZ-FT25VGK-SC1			
MSZ-FT25VGK-SC2			
MSZ-FT35VGK-E1			
MSZ-FT35VGK-E2			
MSZ-FT35VGK-ET1			
MSZ-FT35VGK-SC1			
MSZ-FT35VGK-SC2			
MSZ-FT50VGK-E1			
MSZ-FT50VGK-E2			
MSZ-FT50VGK-ET1			
MSZ-FT50VGK-SC1			
MSZ-FT50VGK-SC2			
MSZ-GZA09VFK			
MSZ-GZA12VFK			
MSZ-GZA18VFK			
MSZ-GZY09VFK			
MSZ-GZY12VFK			
MSZ-GZY18VFK			
MSZ-HR25VFK-E1			
MSZ-HR25VFK-E2			
MSZ-HR25VFK-E6			
MSZ-HR25VFK-E7			
MSZ-HR25VFK-ER1			
MSZ-HR25VFK-ER2			
MSZ-HR25VFK-ET1			
MSZ-HR25VFK-ET2			
MSZ-HR35VFK-E1			
MSZ-HR35VFK-E2			
MSZ-HR35VFK-E6			
MSZ-HR35VFK-E7			
MSZ-HR35VFK-ER1			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-HR35VFK-ER2	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-HR35VFK-ET1			
MSZ-HR35VFK-ET2			
MSZ-HR42VFK-E1			
MSZ-HR42VFK-E2			
MSZ-HR42VFK-E6			
MSZ-HR42VFK-E7			
MSZ-HR42VFK-ER1			
MSZ-HR42VFK-ER2			
MSZ-HR42VFK-ET1			
MSZ-HR42VFK-ET2			
MSZ-HR50VFK-E1			
MSZ-HR50VFK-E2			
MSZ-HR50VFK-E6			
MSZ-HR50VFK-E7			
MSZ-HR50VFK-ER1			
MSZ-HR50VFK-ER2			
MSZ-HR50VFK-ET1			
MSZ-HR50VFK-ET2			
MSZ-HR60VFK-E1			
MSZ-HR60VFK-ER1			
MSZ-HR60VFK-ET1			
MSZ-HR71VFK-E1			
MSZ-HR71VFK-ER1			
MSZ-HR71VFK-ET1			
MSZ-KY09VFK			
MSZ-KY12VFK			
MSZ-KY18VFK			
MSZ-KZA09VFK			
MSZ-KZA12VFK			
MSZ-KZA16VFK			
MSZ-KZA18VFK			
MSZ-LN18VG2B-E2			
MSZ-LN18VG2B-E3			
MSZ-LN18VG2R-E2			
MSZ-LN18VG2R-E3			
MSZ-LN18VG2V-E2			
MSZ-LN18VG2V-E3			
MSZ-LN18VG2W-E2			
MSZ-LN18VG2W-E3			
MSZ-LN18VG2W-ER2			
MSZ-LN18VG2W-ET2			
MSZ-LN18VG2W-SC1			
MSZ-LN25VG2B-A2			
MSZ-LN25VG2B-A3			
MSZ-LN25VG2B-E2			
MSZ-LN25VG2B-E3			
MSZ-LN25VG2B-EN2			
MSZ-LN25VG2B-ER2			
MSZ-LN25VG2B-ER3			
MSZ-LN25VG2B-ET2			
MSZ-LN25VG2B-ET3			
MSZ-LN25VG2B-SC1			
MSZ-LN25VG2R-A2			
MSZ-LN25VG2R-A3			
MSZ-LN25VG2R-E2			
MSZ-LN25VG2R-E3			
MSZ-LN25VG2R-EN2			
MSZ-LN25VG2R-ER2			
MSZ-LN25VG2R-ER3			
MSZ-LN25VG2R-ET2			
MSZ-LN25VG2R-ET3			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-LN25VG2R-SC1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-LN25VG2V-A2			
MSZ-LN25VG2V-A3			
MSZ-LN25VG2V-E2			
MSZ-LN25VG2V-E3			
MSZ-LN25VG2V-EN2			
MSZ-LN25VG2V-ER2			
MSZ-LN25VG2V-ER3			
MSZ-LN25VG2V-ET2			
MSZ-LN25VG2V-ET3			
MSZ-LN25VG2V-SC1			
MSZ-LN25VG2W-E2			
MSZ-LN25VG2W-E3			
MSZ-LN25VG2W-EN2			
MSZ-LN25VG2W-ER2			
MSZ-LN25VG2W-ER3			
MSZ-LN25VG2W-ET2			
MSZ-LN25VG2W-ET3			
MSZ-LN25VG2W-SC1			
MSZ-LN25VGDB-A1			
MSZ-LN25VGDR-A1			
MSZ-LN25VGDV-A1			
MSZ-LN35VG2B-A2			
MSZ-LN35VG2B-A3			
MSZ-LN35VG2B-E2			
MSZ-LN35VG2B-E3			
MSZ-LN35VG2B-EN2			
MSZ-LN35VG2B-ER2			
MSZ-LN35VG2B-ER3			
MSZ-LN35VG2B-ET2			
MSZ-LN35VG2B-ET3			
MSZ-LN35VG2B-SC1			
MSZ-LN35VG2R-A2			
MSZ-LN35VG2R-A3			
MSZ-LN35VG2R-E2			
MSZ-LN35VG2R-E3			
MSZ-LN35VG2R-EN2			
MSZ-LN35VG2R-ER2			
MSZ-LN35VG2R-ER3			
MSZ-LN35VG2R-ET2			
MSZ-LN35VG2R-ET3			
MSZ-LN35VG2R-SC1			
MSZ-LN35VG2V-A2			
MSZ-LN35VG2V-A3			
MSZ-LN35VG2V-E2			
MSZ-LN35VG2V-E3			
MSZ-LN35VG2V-EN2			
MSZ-LN35VG2V-ER2			
MSZ-LN35VG2V-ER3			
MSZ-LN35VG2V-ET2			
MSZ-LN35VG2V-ET3			
MSZ-LN35VG2V-SC1			
MSZ-LN35VG2W-E2			
MSZ-LN35VG2W-E3			
MSZ-LN35VG2W-EN2			
MSZ-LN35VG2W-ER2			
MSZ-LN35VG2W-ER3			
MSZ-LN35VG2W-ET2			
MSZ-LN35VG2W-ET3			
MSZ-LN35VG2W-SC1			
MSZ-LN35VGDB-A1			
MSZ-LN35VGDR-A1			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-LN35VGDV-A1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-LN50VG2B-A2			
MSZ-LN50VG2B-E2			
MSZ-LN50VG2B-E3			
MSZ-LN50VG2B-EN2			
MSZ-LN50VG2B-ER2			
MSZ-LN50VG2B-ER3			
MSZ-LN50VG2B-ET2			
MSZ-LN50VG2B-ET3			
MSZ-LN50VG2B-SC1			
MSZ-LN50VG2R-A2			
MSZ-LN50VG2R-E2			
MSZ-LN50VG2R-E3			
MSZ-LN50VG2R-EN2			
MSZ-LN50VG2R-ER2			
MSZ-LN50VG2R-ER3			
MSZ-LN50VG2R-ET2			
MSZ-LN50VG2R-ET3			
MSZ-LN50VG2R-SC1			
MSZ-LN50VG2V-A2			
MSZ-LN50VG2V-E2			
MSZ-LN50VG2V-E3			
MSZ-LN50VG2V-EN2			
MSZ-LN50VG2V-ER2			
MSZ-LN50VG2V-ER3			
MSZ-LN50VG2V-ET2			
MSZ-LN50VG2V-ET3			
MSZ-LN50VG2V-SC1			
MSZ-LN50VG2W-E2			
MSZ-LN50VG2W-E3			
MSZ-LN50VG2W-EN2			
MSZ-LN50VG2W-ER2			
MSZ-LN50VG2W-ER3			
MSZ-LN50VG2W-ET2			
MSZ-LN50VG2W-ET3			
MSZ-LN50VG2W-SC1			
MSZ-LN50VG3B-A1			
MSZ-LN50VG3R-A1			
MSZ-LN50VG3V-A1			
MSZ-LN50VGDB-A1			
MSZ-LN50VGDR-A1			
MSZ-LN50VGDV-A1			
MSZ-LN60VG2B-A2			
MSZ-LN60VG2B-E2			
MSZ-LN60VG2B-E3			
MSZ-LN60VG2B-ER2			
MSZ-LN60VG2B-ER3			
MSZ-LN60VG2B-ET2			
MSZ-LN60VG2B-ET3			
MSZ-LN60VG2R-A2			
MSZ-LN60VG2R-E2			
MSZ-LN60VG2R-E3			
MSZ-LN60VG2R-ER2			
MSZ-LN60VG2R-ER3			
MSZ-LN60VG2R-ET2			
MSZ-LN60VG2R-ET3			
MSZ-LN60VG2V-A2			
MSZ-LN60VG2V-E2			
MSZ-LN60VG2V-E3			
MSZ-LN60VG2V-ER2			
MSZ-LN60VG2V-ER3			
MSZ-LN60VG2V-ET2			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-LN60VG2V-ET3 MSZ-LN60VG2W-E2 MSZ-LN60VG2W-E3 MSZ-LN60VG2W-ER2 MSZ-LN60VG2W-ER3 MSZ-LN60VG2W-ET2 MSZ-LN60VG2W-ET3 MSZ-LN60VG3B-A1 MSZ-LN60VG3R-A1 MSZ-LN60VG3V-A1 MSZ-LN60VGDB-A1 MSZ-LN60VGDR-A1 MSZ-LN60VGDV-A1 MSZ-RW25VG-E1 MSZ-RW25VG-ER1 MSZ-RW25VG-ET1 MSZ-RW25VG-SC1 MSZ-RW35VG-E1 MSZ-RW35VG-ER1 MSZ-RW35VG-ET1 MSZ-RW35VG-SC1 MSZ-RW50VG-E1 MSZ-RW50VG-ER1 MSZ-RW50VG-ET1 MSZ-RW50VG-SC1 MSZ-RZ25VU-E1 MSZ-RZ25VU-SC1 MSZ-RZ35VU-E1 MSZ-RZ35VU-SC1 MSZ-RZ50VU-E1 MSZ-RZ50VU-SC1 MSZ-WX18VFK MSZ-WX20VFK MSZ-WX25VFK MSZ-ZA09VFK MSZ-ZA12VFK MSZ-ZA18VFK MSZ-ZY09VFK MSZ-ZY12VFK MSZ-ZY18VFK	Same as above	Same as above	Same as above
MSZ-AP25VGK-E6 MSZ-AP35VGK-E6 MSZ-AP42VGK-E6 MSZ-AP50VGK-E6 MSZ-AP60VGK-E1 MSZ-AP60VGK-ER1 MSZ-AP60VGK-ET1 MSZ-AP71VGK-E1 MSZ-AP71VGK-ER1 MSZ-AP71VGK-ET1 MSZ-FT20VFK MSZ-FT25VFK MSZ-FX20VFK MSZ-FX25VFK MSZ-GZT09VAK MSZ-GZT09VAK-1 MSZ-GZT12VAK MSZ-GZT12VAK-1 MSZ-GZT18VAK MSZ-GZT18VAK-1 MSZ-LN18VG2B-E1 MSZ-LN18VG2B-EN1	All Versions	-	There are no plans to release a fixed version. Please connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router."

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-LN18VG2B-ET1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-LN18VG2R-E1			
MSZ-LN18VG2R-EN1			
MSZ-LN18VG2R-ET1			
MSZ-LN18VG2V-E1			
MSZ-LN18VG2V-EN1			
MSZ-LN18VG2V-ET1			
MSZ-LN18VG2W-E1			
MSZ-LN18VG2W-EN1			
MSZ-LN18VG2W-ER1			
MSZ-LN18VG2W-ET1			
MSZ-LN18VGB-E1			
MSZ-LN18VGR-E1			
MSZ-LN18VGV-E1			
MSZ-LN18VGW-E1			
MSZ-LN25VG2B-A1			
MSZ-LN25VG2B-E1			
MSZ-LN25VG2B-EN1			
MSZ-LN25VG2B-ER1			
MSZ-LN25VG2B-ET1			
MSZ-LN25VG2R-A1			
MSZ-LN25VG2R-E1			
MSZ-LN25VG2R-EN1			
MSZ-LN25VG2R-ER1			
MSZ-LN25VG2R-ET1			
MSZ-LN25VG2V-A1			
MSZ-LN25VG2V-E1			
MSZ-LN25VG2V-EN1			
MSZ-LN25VG2V-ER1			
MSZ-LN25VG2V-ET1			
MSZ-LN25VG2W-E1			
MSZ-LN25VG2W-EN1			
MSZ-LN25VG2W-ER1			
MSZ-LN25VG2W-ET1			
MSZ-LN25VGB-A1			
MSZ-LN25VGB-E1			
MSZ-LN25VGB-ER1			
MSZ-LN25VGR-A1			
MSZ-LN25VGR-E1			
MSZ-LN25VGR-ER1			
MSZ-LN25VGV-A1			
MSZ-LN25VGV-E1			
MSZ-LN25VGV-ER1			
MSZ-LN25VGW-E1			
MSZ-LN25VGW-ER1			
MSZ-LN35VG2B-A1			
MSZ-LN35VG2B-E1			
MSZ-LN35VG2B-EN1			
MSZ-LN35VG2B-ER1			
MSZ-LN35VG2B-ET1			
MSZ-LN35VG2R-A1			
MSZ-LN35VG2R-E1			
MSZ-LN35VG2R-EN1			
MSZ-LN35VG2R-ER1			
MSZ-LN35VG2R-ET1			
MSZ-LN35VG2V-A1			
MSZ-LN35VG2V-E1			
MSZ-LN35VG2V-EN1			
MSZ-LN35VG2V-ER1			
MSZ-LN35VG2V-ET1			
MSZ-LN35VG2W-E1			
MSZ-LN35VG2W-EN1			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-LN35VG2W-ER1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>
MSZ-LN35VG2W-ET1			
MSZ-LN35VGB-A1			
MSZ-LN35VGB-E1			
MSZ-LN35VGB-ER1			
MSZ-LN35VGR-A1			
MSZ-LN35VGR-E1			
MSZ-LN35VGR-ER1			
MSZ-LN35VGV-A1			
MSZ-LN35VGV-E1			
MSZ-LN35VGV-ER1			
MSZ-LN35VGW-E1			
MSZ-LN35VGW-ER1			
MSZ-LN50VG2B-A1			
MSZ-LN50VG2B-E1			
MSZ-LN50VG2B-EN1			
MSZ-LN50VG2B-ER1			
MSZ-LN50VG2B-ET1			
MSZ-LN50VG2R-A1			
MSZ-LN50VG2R-E1			
MSZ-LN50VG2R-EN1			
MSZ-LN50VG2R-ER1			
MSZ-LN50VG2R-ET1			
MSZ-LN50VG2V-A1			
MSZ-LN50VG2V-E1			
MSZ-LN50VG2V-EN1			
MSZ-LN50VG2V-ER1			
MSZ-LN50VG2V-ET1			
MSZ-LN50VG2W-E1			
MSZ-LN50VG2W-EN1			
MSZ-LN50VG2W-ER1			
MSZ-LN50VG2W-ET1			
MSZ-LN50VGB-A1			
MSZ-LN50VGB-E1			
MSZ-LN50VGB-ER1			
MSZ-LN50VGR-A1			
MSZ-LN50VGR-E1			
MSZ-LN50VGR-ER1			
MSZ-LN50VGV-A1			
MSZ-LN50VGV-E1			
MSZ-LN50VGV-ER1			
MSZ-LN50VGW-E1			
MSZ-LN50VGW-ER1			
MSZ-LN60VG2B-A1			
MSZ-LN60VG2B-E1			
MSZ-LN60VG2B-ER1			
MSZ-LN60VG2B-ET1			
MSZ-LN60VG2R-A1			
MSZ-LN60VG2R-E1			
MSZ-LN60VG2R-ER1			
MSZ-LN60VG2R-ET1			
MSZ-LN60VG2V-A1			
MSZ-LN60VG2V-E1			
MSZ-LN60VG2V-ER1			
MSZ-LN60VG2V-ET1			
MSZ-LN60VG2W-E1			
MSZ-LN60VG2W-ER1			
MSZ-LN60VG2W-ET1			
MSZ-LN60VGB-A1			
MSZ-LN60VGB-E1			
MSZ-LN60VGB-ER1			
MSZ-LN60VGR-A1			

Model No.	Affected Version	Fixed Version	Details of Measures
MSZ-LN60VGR-E1 MSZ-LN60VGR-ER1 MSZ-LN60VGV-A1 MSZ-LN60VGV-E1 MSZ-LN60VGV-ER1 MSZ-LN60VGW-E1 MSZ-LN60VGW-ER1 MSZ-ZT09VAK MSZ-ZT09VAK-1 MSZ-ZT12VAK MSZ-ZT12VAK-1 MSZ-ZT18VAK MSZ-ZT18VAK-1	<u>Same as above</u>	<u>Same as above</u>	<u>Same as above</u>

[3] Wireless LAN Adapters for Room Air Conditioners (for Japan)

Model No.	Affected Version	Fixed Version	Details of Measures
MAC-900IF	42.00 and prior	43.00 or later	<p>The countermeasure is implemented in adapter software version 43.00 or later. Follow the steps below to connect the product to a Wi-Fi router and update the adapter software.</p> <ol style="list-style-type: none"> 1. Connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router." 2. The countermeasure is implemented in adapter software version 43.00 or later. After completing step 1, update to the fixed version using the "MyMU" application or the "Kirigamine REMOTE" application. <p>[For MyMU users] Check and update the adapter software version from "Adapter Information" under "Registered Devices" in the "MyMU" application. You can check the current adapter software version on the same screen under "Adapter Software Version." However, only the administrator (*) can perform updates. The "Update" button is not shown on member screens, so ask the administrator (*) to perform the update. (*) The person who performs new registration (device registration) becomes the administrator.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p> <p>[For Kirigamine REMOTE users] Check and update the adapter software version from "Wireless LAN Software Update" under "Air Conditioner Management" - "(Room Name)" in the "Kirigamine REMOTE" application. You can check the current adapter software version on the same screen under "Wireless LAN Software Update." For details, refer to the Kirigamine REMOTE user manual at the site below. https://www.mitsubishielectric.co.jp/home/kirigamine/function/remote/ib.html (In Japanese)</p> <p>If you use only HEMS, refer to the Kirigamine REMOTE user manual to check the version and perform updates. Please install the Kirigamine REMOTE application, configure it so that Kirigamine REMOTE can be used, and then complete the procedure in the Kirigamine REMOTE application.</p>
HM-CT01MJ HM-EM02 HM-EM02MJ HM-EM03-W HM-VL01MJ HM-W002-AC HM-W002-ACB HM-WF001 HM-WF001EM HM-WF001MD HM-WF002EM HM-WF002MD MAC-884IF MAC-888IF MAC-895IF	All Versions	-	<p>There are no plans to release a fixed version. Please connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router."</p>

[4] Wireless LAN Adapters for Room Air Conditioners (outside Japan)

Model No.	Affected Version	Fixed Version	Details of Measures
MAC-597IF-E MAC-597IF-EM	51.00 and prior	52.00 or later	<p>Although this product may be accessed by an attacker through an unauthorized Wi-Fi connection, it does not provide an interface that can be directly controlled via Wi-Fi. Therefore, there is no risk of internal information disclosure, changes to the air-conditioner or Wi-Fi settings, or a denial-of-service (DoS) condition in Wi-Fi communication.</p> <p><u>The fixed version is scheduled to be released in December 2026. Until the fixed version is released, implement the mitigations/workarounds below.</u></p> <ol style="list-style-type: none"> 1. Connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router." <p>The countermeasure will be implemented in adapter software version 52.00 or later. <u>Once the fixed version is released</u>, after completing step 1, please update to the fixed version in accordance with the method published by your local Mitsubishi Electric sales company.</p> <p>Please check the adapter software version according to the procedure published by your local Mitsubishi Electric sales company.</p>
MAC-587IF-E MAC-588IF-E MAC-589IF-EM S-MAC-002IF S-MAC-705IF	42.00 and prior	43.00 or later	<p>The countermeasure is implemented in adapter software version 43.00 or later.</p> <p>Follow the steps below to connect the product to a Wi-Fi router and update the adapter software.</p> <ol style="list-style-type: none"> 1. Connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router." 2. The countermeasure is implemented in adapter software version 43.00 or later. After completing step 1, update to the fixed version following the method published by your local Mitsubishi Electric sales company. <p>Please check the adapter software version according to the procedure published by your local Mitsubishi Electric sales company.</p>
MAC-557IF-E MAC-557IF-E1 MAC-558IF-E MAC-558IF-E1 MAC-559IF-E MAC-559IF-E1 MAC-567IF-E MAC-567IF-E1 MAC-568IF-E S-MAC-702IF-B S-MAC-702IF-F S-MAC-702IF-Z WIFI-493T-IC-M	All Version	-	<p>There are no plans to release a fixed version.</p> <p>Please connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router."</p>

[5] Wireless LAN Adapters for Packaged Air Conditioners (for Japan)

Model No.	Affected Version	Fixed Version	Details of Measures
PAC-SK43ML	42.00 and prior	43.00 or later	<p>The countermeasure is implemented in adapter software version 43.00 or later.</p> <p>Follow the steps below to connect the product to a Wi-Fi router and update the adapter software.</p> <ol style="list-style-type: none"> 1. Connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router." 2. The countermeasure is implemented in adapter software version 43.00 or later. After completing step 1, update to the fixed version using the "MELflo" application. <p>Check and update the adapter software version from "Wireless Software" in "AirCoNet Device List" in the "MELflo" application. You can check the current adapter software version on the same screen under "Wireless Software."</p> <p>For details, refer to the MELflo user manual at the site below. https://dl.mitsubishielectric.co.jp/dl/dg/wink/ssl/wink_doc/m_contents/doc/TEC_MANUAL_IPPAN/MELflo_Manual_JA.pdf (In Japanese)</p>

[6] Wireless LAN Adapters for Packaged Air Conditioners (outside Japan)

Model No.	Affected Version	Fixed Version	Details of Measures
MAC-5871F-E	42.00 and prior	43.00 or later	<p>The countermeasure is implemented in adapter software version 43.00 or later.</p> <p>Follow the steps below to connect the product to a Wi-Fi router and update the adapter software.</p> <ol style="list-style-type: none"> 1. Connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router." 2. The countermeasure is implemented in adapter software version 43.00 or later. After completing step 1, update to the fixed version following the method published by your local Mitsubishi Electric sales company. <p>Please check the adapter software version according to the procedure published by your local Mitsubishi Electric sales company.</p>
PAC-WHS01WF-E	All Version	-	<p>There are no plans to release a fixed version.</p> <p>Please connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router."</p>

[7] Refrigerators (for Japan)

Model No.	Affected Version	Fixed Version	Details of Measures
MR-BD46K MR-BD46M MR-BD46N MR-MD45K MR-MD45M MR-MD45N MR-MXD50G MR-MXD57G MR-MZ49J MR-MZ49K MR-MZ49M MR-MZ49N MR-MZ54H MR-MZ54J MR-MZ54K MR-MZ54M MR-MZ54N MR-MZ60H MR-MZ60J MR-MZ60K MR-MZ60M MR-MZ60N MR-WXD47LJ MR-WXD47LK MR-WXD47LM MR-WXD47LN MR-WXD52G MR-WXD60G MR-WXD70G MR-WXD70J MR-WXD70K MR-WXD70M MR-WXD70N MR-WZ50J MR-WZ50K MR-WZ50M MR-WZ50N MR-WZ55H MR-WZ55J MR-WZ55K MR-WZ55M MR-WZ55N MR-WZ61H MR-WZ61J MR-WZ61K MR-WZ61M MR-WZ61N	01.77 and prior	01.85 or later	<p>Wi-Fi communication is disabled by default when the product is shipped.</p> <p>If Wi-Fi communication is disabled, the product is not affected by this vulnerability.</p> <p>Even when Wi-Fi communication is enabled, the product is not affected by this vulnerability if it has already been connected to a Wi-Fi router as described in the "Mitsubishi Refrigerator App" initial setup manual.</p> <p>* After enabling the Wi-Fi function, connect the product to a Wi-Fi router promptly. Leaving it unconnected may expose the product to this vulnerability.</p> <p><u>The fixed version is scheduled to be released in July 6-17, 2026.</u></p> <p>The response procedures for each customer situation are listed below.</p> <ul style="list-style-type: none"> - Customers whose products are already connected to a Wi-Fi router This vulnerability does not affect your product. You may continue to use it as is. - Customers whose products have had Wi-Fi communication enabled after purchase but are not connected to a Wi-Fi router Until the fixed version is released, implement the mitigations/workarounds below. <ol style="list-style-type: none"> 1. Connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router." <p>The countermeasure will be implemented in adapter software version 01.85 or later. <u>Once the fixed version is released</u>, after completing step 1, please update to the fixed version using the "MyMU" application.</p> <ul style="list-style-type: none"> - Customers whose products cannot connect via Wi-Fi (for example, because they do not have a Wi-Fi router) or who do not wish to use a Wi-Fi connection Please ensure that the wireless function is disabled. If the wireless function is enabled, please disable it. For the procedure to disable the wireless function, refer to the user manual for each product. <p>Check and update the adapter software version from "Adapter Information" under "Registered Devices" in the "MyMU" application. You can check the current adapter software version on the same screen under "Adapter Software Version."</p> <p>However, only the administrator (*) can perform updates. The "Update" button is not shown on member screens, so ask the administrator (*) to perform the update.</p> <p>(*) The person who performs new registration (device registration) becomes the administrator.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p> <p>Regardless of whether your product is affected by this vulnerability, please connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version when using the application. Also, configure your Wi-Fi router by referring to</p>

Model No.	Affected Version	Fixed Version	Details of Measures
			"Recommendations for Connecting to a Wi-Fi Router."

[8] Heat Pump Water Heaters / HEMS-Compatible Adapters / Wireless LAN Adapters (for Japan)

Model No.	Affected Version	Fixed Version	Details of Measures
GT-RA1 GT-RA2 GT-HR1 GT-HR2 GT-HEM4 RMCB-H6SE-T RMCB-F6SE-T RMCB-D6SE-T RMCB-D6SE-T-PV RMCB-H7SE RMCB-F7SE RMCB-D7SE RMCB-N7	All Versions	-	<p>A fixed version is currently planned. This security advisory will be updated once the planned release schedule has been determined. For HEMS-only use, there are no plans to release a fixed version.</p> <p>The response procedures for each customer situation are listed below.</p> <ul style="list-style-type: none"> - Customers whose products are already connected to a Wi-Fi router This vulnerability does not affect your product. You may continue to use it as is. - Customers who have not connected this product to a Wi-Fi router since purchase Connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router." - Customers whose products cannot connect via Wi-Fi (for example, because they do not have a Wi-Fi router) or who do not wish to use a Wi-Fi connection On the water-heater remote controller, check that "External Connection" is set to "Disabled." If "External Connection" is enabled, disable it. For the procedures, refer to user manual for the water-heater.

[9] Bathroom Dryer / Heater / Ventilation Systems (for Japan)

Model No.	Affected Version	Fixed Version	Details of Measures
V-241BZ-RC V-241BZ5-RC WD-240DK-RC WD-240DK2-RC V-241BZ5-RC-NR	01.72 and prior	01.86 or later	<p>Wi-Fi communication is disabled by default when the product is shipped. If Wi-Fi communication is disabled, the product is not affected by this vulnerability. Even when Wi-Fi communication is enabled, the product is not affected by this vulnerability if it has already been connected to a Wi-Fi router.</p> <p>* After enabling the Wi-Fi function, connect the product to a Wi-Fi router promptly. Leaving it unconnected may expose the product to this vulnerability.</p> <p><u>The fixed version is scheduled to be released in July 6-17, 2026.</u></p> <p>The response procedures for each customer situation are listed below.</p> <ul style="list-style-type: none"> - Customers whose products are already connected to a Wi-Fi router This vulnerability does not affect your product. You may continue to use it as is. - Customers who have not connected this product to a Wi-Fi router since purchase Until the fixed version is released, implement the mitigations/workarounds below. <ol style="list-style-type: none"> 1. Connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations

Model No.	Affected Version	Fixed Version	Details of Measures
			<p>for Connecting to a Wi-Fi Router."</p> <p>The countermeasure will be implemented in adapter software version 01.86 or later. Once the fixed version is released, please update to the fixed version using the "MyMU" application or the "Bus-Karatto REMOTE" application.</p> <p>- Customers whose products cannot connect via Wi-Fi (for example, because they do not have a Wi-Fi router) or who do not wish to use a Wi-Fi connection Please ensure that "Remote Operation" is disabled. If "Remote Operation" is enabled, please disable it. For the procedure to disable "Remote Operation", refer to the user manual each product.</p> <p>Regardless of whether your product is affected by this vulnerability, please connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version when using the application in the future. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router."</p> <p>[For MyMU users] Check and update the adapter software version from "Adapter Information" under "Registered Devices" in the "MyMU" application. You can check the current adapter software version on the same screen under "Adapter Software Version." However, only the administrator (*) can perform updates. The "Update" button is not shown on member screens, so ask the administrator (*) to perform the update. (*) The person who performs new registration (device registration) becomes the administrator.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p> <p>[For Bus-Karatto REMOTE users] Check and update the adapter software version from "Adapter Software Version" in "Device Information" in the "Bus-Karatto REMOTE" application. You can check the current adapter software version on the same screen under "Adapter Software Version."</p> <p>For details, refer to the Bus-Karatto REMOTE user manual at the site below. https://www.mitsubishielectric.co.jp/ldg/ja/air/products/ventilationfan/bath/IB/pdf/bathkaratremote.pdf (In Japanese)</p>

[10] Adapters for Airflow Ventilation Systems, Heat Pump Chilled/Hot Water Systems, and Ventilation/Air-Conditioning System Air Resorts (for Japan)

Model No.	Affected Version	Fixed Version	Details of Measures
HM-01A-EX P-01HMA P-WA01 P-HM02WA P-HM03WA P-HM04WA VEZ-HM01WA	01.14 and prior	-	There are no plans to release a fixed version. Please connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router".
P-WA02 P-HM05WA	01.73 and prior	01.87 or later	<p><u>The fixed version is scheduled to be released in July 6-17, 2026. Until the fixed version is released, implement the mitigations/workarounds below.</u></p> <ol style="list-style-type: none"> 1. Connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router." <p>The countermeasure will be implemented in adapter software version 01.87 or later. <u>Once the fixed version is released</u>, after completing step 1, please update to the fixed version using the "MyMU" application.</p> <p>Check and update the adapter software version from "Adapter Information" under "Registered Devices" in the "MyMU" application. You can check the current adapter software version on the same screen under "Adapter Software Version."</p> <p>However, only the administrator (*) can perform updates. The "Update" button is not shown on member screens, so ask the administrator (*) to perform the update.</p> <p>(*) The person who performs new registration (device registration) becomes the administrator.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p>

[11] Lossnay Central Ventilation Systems (for Japan)

Model No.	Affected Version	Fixed Version	Details of Measures
VL-200ZMHSV3-RC	01.71 and prior	01.91 or later	<p>The fixed version is scheduled to be released in July 6-17, 2026. <u>Until the fixed version is released, implement the mitigations/workarounds below.</u></p> <ol style="list-style-type: none"> 1. Connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router." <p>The countermeasure will be implemented in adapter software version 01.91 or later. <u>Once the fixed version is released</u>, after completing step 1, please update to the fixed version using the "MyMU" application.</p> <p>Check and update the adapter software version from "Adapter Information" under "Registered Devices" in the "MyMU" application. You can check the current adapter software version on the same screen under "Adapter Software Version."</p> <p>However, only the administrator (*) can perform updates. The "Update" button is not shown on member screens, so ask the administrator (*) to perform the update. (*) The person who performs new registration (device registration) becomes the administrator.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p>

[12] Smart Switches for Ventilation Fans and Lossnay (for Japan)

Model No.	Affected Version	Fixed Version	Details of Measures
P-04SWRC P-10SWRC P-1600SWRC	01.74 and prior	01.88 or later	<p>The fixed version is scheduled to be released in July 6-17, 2026. <u>Until the fixed version is released, implement the mitigations/workarounds below.</u></p> <ol style="list-style-type: none"> 1. Connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router." <p>The countermeasure will be implemented in adapter software version 01.88 or later. <u>Once the fixed version is released</u>, after completing step 1, please update to the fixed version using the "MyMU" application.</p> <p>Check and update the adapter software version from "Adapter Information" under "Registered Devices" in the "MyMU" application. You can check the current adapter software version on the same screen under "Adapter Software Version."</p> <p>However, only the administrator (*) can perform updates. The "Update" button is not shown on member screens, so ask the administrator (*) to perform the update. (*) The person who performs new registration (device registration) becomes the administrator.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p>

[13] IH Cooking Heaters (for Japan)

Model No.	Affected Version	Fixed Version	Details of Measures
RE-322SXR	01.71 and prior	01.91 or later	<p>The fixed version is scheduled to be released in June 29-30, 2026. <u>Until the fixed version is released, implement the mitigations/workarounds below.</u></p> <ol style="list-style-type: none"> 1. Connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router." <p>The countermeasure will be implemented in adapter software version 01.91 or later. <u>Once the fixed version is released</u>, after completing step 1, please update to the fixed version using the "MyMU" application.</p> <p>Check and update the adapter software version from "Adapter Information" under "Registered Devices" in the "MyMU" application. You can check the current adapter software version on the same screen under "Adapter Software Version."</p> <p>However, only the administrator (*) can perform updates. The "Update" button is not shown on member screens, so ask the administrator (*) to perform the update.</p> <p>(*) The person who performs new registration (device registration) becomes the administrator.</p> <p>For details, refer to "How to Update Wireless LAN Adapter Software" (User Manual Supplement) at the site below. https://www.mitsubishielectric.co.jp/home/mymu/entry_ib2.html (In Japanese)</p>

[14] Rice Cookers (for Japan)

Model No.	Affected Version	Fixed Version	Details of Measures
NJ-AWBX10	01.76 and prior	01.90 or later	<p>Wi-Fi communication is disabled by default when the product is shipped.</p> <p>If Wi-Fi communication is disabled, the product is not affected by this vulnerability.</p> <p>Even when Wi-Fi communication is enabled, the product is not affected by this vulnerability if it has already been connected to a Wi-Fi router.</p> <p>* After enabling the Wi-Fi function, connect the product to a Wi-Fi router promptly. Leaving it unconnected may expose the product to this vulnerability.</p> <p><u>The fixed version is scheduled to be released in June 29-30, 2026.</u></p> <p>The response procedures for each customer situation are listed below.</p> <ul style="list-style-type: none"> - Customers whose products are already connected to a Wi-Fi router This vulnerability does not affect your product. You may continue to use it as is. - Customers whose products have had Wi-Fi communication enabled after purchase but are not connected to a Wi-Fi router Until the fixed version is released, implement the mitigations/workarounds below. <ul style="list-style-type: none"> 1. Connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router." <p>The countermeasure will be implemented in adapter software version 01.90 or later. <u>Once the fixed version is released</u>, after completing step 1, please update to the fixed version using the "WiFi Raku-Raku Cooking" application.</p> <ul style="list-style-type: none"> - Customers whose products cannot connect via Wi-Fi (for example, because they do not have a Wi-Fi router) or who do not wish to use a Wi-Fi connection Please ensure that "Communication Settings" is disabled. If "Communication Settings" is enabled, please disable it. For the procedure to disable "Communication Settings", refer to the user manual for each product. <p>Regardless of whether your product is affected by this vulnerability, please connect the product to a Wi-Fi router in accordance with the included user manual or its web-published version when using the application. Also, configure your Wi-Fi router by referring to "Recommendations for Connecting to a Wi-Fi Router."</p> <p>Check and update the adapter software version from "Update" under "Communication Adapter Software Version" in "Device Information" in the "WiFi Raku-Raku Cooking" application. You can check the current adapter software version on the same screen under "Communication Adapter Software Version."</p>

Recommendations for Connecting to a Wi-Fi Router

Mitsubishi Electric recommends that customers take the following mitigation measures to minimize the risks of exploiting this vulnerability :

- For the Wi-Fi router encryption key (password), avoid number sequences, passwords inferable from the router model number, SSID, MAC address, or other common passwords. Use a hard-to-guess secure password combining letters and numbers, and do not disclose it to third parties.
- Do not use WEP or Open for Wi-Fi router security settings; use WPA2-PSK (AES) or equivalent.
- To prevent unauthorized device connections, enable MAC address filtering on the Wi-Fi router.
- Use a hard-to-guess login password for the Wi-Fi router administration screen, and do not disclose it to third parties.
- Ensure the Wi-Fi router firmware is kept up to date.
- Install the Wi-Fi router in a secure location that is inaccessible to unauthorized persons, and do not make the network available to unspecified third parties (e.g., as free Wi-Fi).
- When using access point mode (AP mode), ensure that the SSID and encryption key are not disclosed to unspecified third parties.

Acknowledgement

Mitsubishi Electric would like to thank Zachary Mitev, a Bulgarian cybersecurity researcher, who reported this vulnerability.

Contact information

[For Customers in Japan]

Mitsubishi Electric Customer Consultation Center: 0120-139-365 (toll-free), Mobile/PHS: 0570-077-365 (toll call charges apply)

If toll-free / Navi Dial numbers are unavailable: 03-3414-9655 (toll call charges apply)

[For Customers outside Japan]

Please contact your local Mitsubishi Electric representative.

<Inquiries>

<https://www.mitsubishielectric.com/en/contact/room-air-conditioners/>