

GOT2000 Series Wireless LAN Communication Unit

User's Manual

GT25-WLAN

Thank you for choosing Mitsubishi Electric Graphic Operation Terminal (GOT)

Prior to use, please read both this manual and detailed manual thoroughly to fully understand the product



MODEL	GT25-WLAN-U-JE		
MODEL CODE	1D7MM2		
IB(NA)-0800522-P(2401)MEE			

© 2013 MITSUBISHI ELECTRIC CORPORATION

●SAFETY PRECAUTIONS●

(Always read these precautions before using this equipment.)

Before using this product, please read this manual and the relevant manuals introduced in this manual carefully and pay full attention to safety to handle the product

correctly.

The precautions given in this manual are concerned with this product.

In this manual, the safety precautions are ranked as "WARNING" and "CAUTION".

Indicates that incorrect handling may cause hazardous

Always follow the precautions of both levels because they are important to per-

Please save this manual to make it accessible when required and always forward it to the end user

MARNING

To maintain the security (confidentiality, integrity, and availability) of the GOT and the system against unauthorized access, DoS ¹¹ attacks, computer viruses, and other cyberattacks from unreliable networks and devices via network, take appropriate measures such as firewalls, virtual private networks (VPNs), and antivirus solutions. Mitsubishi Electric shall have no responsibility or liability for any problems involving GOT trouble and system trouble by unauthorized access, DoS attacks computer viruses, and other civerattacks.

attacks, computer viruses, and other cyberattacks.

*1 DoS: A denial-of-service (DoS) attack disrupts services by overloading systems or exploiting vulnerabilities, resulting in a denial-of-service (DoS)

[INSTALLATION PRECAUTIONS]

⚠WARNING

Be sure to shut off all phases of the external power supply used by the system before mounting or removing this unit to/from the GOT. Not doing so can cause a unit failure or malfunction.

INSTALLATION PRECAUTIONS

⚠ CAUTION

- Use this unit in the environment that satisfies the general specifications described in the GOT2000 Series User's Manual (Hardware). Not doing so can cause an electric shock, fire, malfunction or product damage of
- Do not drop the unit or subject it to string shock. A unit damage may result.
- When installing this unit to the GOT, fit it to the side interface of GOT and tighten the mounting screws in the specified torque range (0.10 N·m to 0.14 N·m) with a Phillips-head screwdriver No.1.

 When the GOT is installed vertically, its side interface is positioned on the

To prevent the falling of the wireless LAN communication unit from the side

interface, install or remove the unit while holding it with hands. Undertightening can cause a drop, failure or malfunction. Overtightening can cause a drop, failure or malfunction due to screw or unit damage

[STARTUP AND MAINTENANCE PRECAUTIONS]

- Before starting cleaning, always shut off GOT power externally in all phases Not doing so can cause a unit failure or malfunction. Undertightening can cause the GOT to drop, short circuit or malfunction. Overtightening can cause a short circuit or malfunction due to the damage of
- Do not disassemble or modify any unit.
 This will cause failure, malfunction, injuries, or fire.

the screws or unit.

- Do not touch the conductive areas and electronic parts of this unit directly. Doing so can cause a unit malfunction or failure.

⚠ CAUTION

Always make sure to touch the grounded metal to discharge the electricity charged in the body, etc., before touching the unit. Failure to do so may cause a failure or malfunctions of the unit.

IPRECAUTIONS FOR REMOTE CONTROLI

MARNING

Remote control is available through a network by using GOT functions including the SoftGOT-GOT link function, the remote personal compute operation function, the VNC server function, and the GOT Mobile function If these functions are used to perform remote control of control equipment the field operator may not notice the remote control, possibly leading to an

In addition, a communication delay or interruption may occur depending on the network environment, and remote control of control equipment cannot be performed normally in some cases.

Before using the above functions to perform remote control, fully grasp the circumstances of the field site and ensure safety.

IDISPOSAL PRECAUTIONS

⚠	CAL	<u>JTI</u>	ON

Dispose of this product as industrial waste

[TRANSPORTATION PRECAUTIONS]

- Make sure to transport the GOT main unit and/or relevant unit(s) in the manner they will not be exposed to the impact exceeding the impact resistance described in the general specifications of the User's Manual for the GOT used, as they are precision devices.

 Failure to do so may cause the unit to fail.

 Check if the unit operates correctly after transportation.

 When furnigants that contain halogen materials such as fluorine, chlorine, bromine, and iodine are used for disinfecting and protecting wooden packaging from insects, they cause malfunction when entering our products. Please take necessary precautions to ensure that remaining materials from furnigant do not enter our products, or treat packaging with methods other than furnigation (heat method).

 Additionally, disinfect and protect wood from insects before packing products

Before Using the Product

[Precautions for Use]

Do not modify this wireless LAN communication unit in any way.

Doing so is prohibited by the Japan Radio Law.

Data transfer in wireless LAN communication may not be as stable as that in cable

DIMENSIONS

A packet loss may occur depending on the surrounding environment and Be sure to perform a confirmation of operation before using this product

[Precautions for radio-frequency interference]

- [Precautions for radio-frequency interference]
 1) This product operates in the 2.4 GHz band, which is used for industrial, scientific and medical applications (such as microwave ovens), customer-premises radio stations for identifying mobile units (licensed), specific low-power radio stations (licensed-ree), and amateur radio stations (licensed). Service, and amateur radio stations (licensed) are such as the stations for identifying mobile units, specific low-power radio stations, and amateur radio stations are not operational near the product.
 3) In the event that this product causes harmful radio-frequency interference with a customer-premises radio station for identifying mobile units, immediately stop the emission of radio waves and take countermeasures to prevent interference, such as changing the frequency and location of the product.
 4) Contact your local sales office if you have any problems caused by this product, such as harmful radio-frequency interference with the radio stations mentioned above.

[Security Precautions]

Wireless LAN uses radio waves instead of LAN cables to send and receive data between a computer and a wireless LAN access point, making it possible to freely establish a LAN connection within a range of the radio waves. However, radio waves can be received through obstacles, such as walls, when within the received.

within the range.

Therefore, if security settings are not made, the following problems may occur.

- Unauthorized viewing of data
 An unauthorized third party can intercept the radio waves and sneak a look at user ID and password.
- Unauthorized access
 An unauthorized third party can access network and cause the following damage:
- cepting personal information and confidential information (information
- Using a false identity to communicate and disclose information illegally
- (identity theft)
 Changing and transmitting intercepted data (tampering)
- Damaging data and systems by spreading a computer virus (destruction)
 The wireless LAN communication unit and wireless LAN access point have security features to counter these mathems.

features to counter these problems.

Configuring the security settings before using the wireless LAN equipment can help to prevent these problems from occurring.

The security settings of the wireless LAN equipment are not configured at the time

of purchase.

To reduce security problems, configure all security settings of the wireless LAN equipment according to the manual before using the wireless LAN communication unit and wireless LAN access point.

Please be aware that the security settings do not provide complete security protection due to wireless LAN specifications.

If you are unable to configure the security settings yourself, please contact your local authorized dealer.

The customer is responsible for configuring the security settings and understanding the risks inherent in using the product without the security settings configured. configured.

Manuals The following shows manuals relevant to this product.

Manual name	Manual number (Model code)		
GOT2000 Series User's Manual (Hardware) (Sold separately)	SH-081194ENG (1D7MJ5)		

GOT2000 Series User's Manual (Hardware) (Sold separately)	SH-081194ENG (1D7MJ5)			
GOT2000 Series User's Manual (Utility) (Sold separately)	SH-081195ENG (1D7MJ6)			
GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1	SH-081200ENG			
Total latest a Manual and RRE manual account were last and affice				

Compliance with the new China RoHS directive



Note: This symbol mark is for China only.

含有有害 6 物质的名称、含有量、含有部件 本产品中所含有的有害 6 物质的名称、含有量、含有部件如下表所示。 产品中有害物质的名称及含量

) AN 1 15 E 1000CH E 1000CH E						
	有害物质					
部件名称	铅	汞	镉	六价铬	多溴联苯	多溴二苯醚
	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)
电路板组件	×	0	0	0	0	0
树脂壳体、电缆、膜材	0	0	0	0	0	0
钣金部件、螺丝等金属部件	0	0	0	0	0	0

本表格依据 SJ/T11364 的规定编制。 〇:表示该有害物质在该部件所有均质材料中的含量均在 GB/T26572 规定的限量要 求以下。 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T26572 规定的

After unpacking the box, check that the following products are

(Requirement of Chinese standardized law)

Referenced Standard: GB/T15969.2

Packing List

Product Vireless LAN communication unit OT2000 シリーズ無線 LAN 通信ユニット取扱説明書 OT2000 Series Wireless LAN Communication Unit User's Manua T2000 系列无线局域网通讯模块使用说明书/GOT2000 시리즈 두 선 LAN 통신 장치 사용자 매뉴얼

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC CAUTION

Change or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate to the equipment.

This transmitter must not be co-located or operated in

conjunction with any other antenna or transmitter. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency(RF) EXposure Guidelines in Supplement C to OET65. This equipment should be installed and operated keeping the radiator at least 20cm or more away from person's body


(excluding extremities:hands, wrists, feet and ankles)

1. OVERVIEW


This user's manual describes the GOT2000 Series wireless LAN communication unit (hereinafter referred to as the wireless LAN communication unit). The wireless LAN communication unit is used to perform the operations such as transferring data from a personal computer to the GOT or FA transparent function in wireless LAN communication.

1) GOT action mode: access point The GOT operates as a wireless LAN access point (base station) to communicate with other stations (clients) such as a personal computer.

Station (client)



3. PART NAMES AND EXTERNAL



No.	Name	Description
1)	Mounting screw	Screw for fixing the GOT
2)	Rating plate	-
3)	Locating lug	Locating lug fit into the locating groove of the GOT
4)	Extension connector	Extension connector connected to the side interface of the GOT

4. INSTALLATION AND REMOVAL **PROCEDURE**

4.1 Unit Installation

2) Remove the side interface cover of the GOT

1) Turn off the GOT.

ire for the wireless LAN communication unit is explained using the GT2712.

Fit the locating lug of the wireless LAN communication unit into the locating groove of the GOT, and install the wireless LAN communication unit to the

unting screws (2 places) of the wireless LAN communication ur llips screwdriver and a torque of 0.10N•m to 0.14N•m to fix the




4.2 Unit Removal

For removing the wireless LAN communication unit, reverse the procedure of the

5. RE Directive/Radio Equipment Regulations (UKCA)

5.1 RE Directive

EU Declaration of Conformity



5.2 Radio Equipment Regulations (UKCA)



6. PRECAUTIONS

To use the wireless LAN communications setting the controller are required

For the settings and system configuration, refer to the following

IIII GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1

Warranty

Mitsubishi Electric will not be held liable for damage caused by factors found not to be the cause of Mitsubishi Electric; machine damage or lost profits caused by faults in the Mitsubishi Electric products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi Electric; damages to products other than Mitsubishi Electric products; and to other duties.

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to Before using the product for special purposes such as nuclear
- power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi Electric. This product has been manufactured under strict quality control.

However, when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system. MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN NAGOYA WORKS: 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA 461-8670, JAPAN


n exported from Japan, this manual does not require application to the Ministry conomy, Trade and Industry for service transaction permission.

Specifications subject to change without notice. Printed in Japan, January 2024.

⚠ WARNING Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury. CAUTION conditions, resulting in medium or slight personal injury or physical damage.

Note that the $extstyle \Delta$ CAUTION level may lead to a serious accident according to the

[DESIGN PRECAUTIONS]



GOT GT25-WLAN For the usable GOTs, refer to the following.

GT Designer3 (GOT2000) Screen Design Manual GOT2000 Series User's Manual (Utility)

GOT2000 Series User's Manual (Hardware)
For the setting and system configuration of wireless LAN function, refer to the

GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus

Products, Peripherals) For GT Works3 Version1

2. SPECIFICATIONS The following shows the performance specifications of the wireless LAN The general specifications of the wireless LAN communication unit are the same

as those of the GOT. as mose or use GOT.

For the general specifications of the GOT, refer to the following.

III OT2000 Series User's Manual (Hardware)

Use compatible versions of the screen design software and BootOS.

Screen design software: GT Works3 Version1.105K or later (for use as a station (client)) GT Works3 Version1.144A or later (for use as an access point (base station) or a

station (client)) BootOS : Version C or later - BootOS

Channel 11ch (1 to 11ch) Data rates* faximum RF pow 15dBm±2dB 2412 to 2462 MH ecurity*3 WPA-PSK(TKIP, AES) WPA2-PSK(TKIP, AES) Number of antenna 1 (Build-in chip antenna Access point (base station), station (client) *4 ction mode faximum num nternal current consumption 3.3VDC Japan Radio Law^{*5}, FCC standards^{*6}, RE Directive^{*7} (R&TTE Directive^{*6}), KC^{*8}, Radio Equipment Regulations (UKCA)^{*9} Japan, the United States, the EU men the UK, Switzerland, Norway, Iceland ountry where the unit can be used

Lectinesten, and south Korea

*I IEEE802.11n only supports 2.4-GHz-bandwidth.

*2 The values of data rates (11Mbps and others), used in this document and the setting screen, are the theoretical maximum of the wireless LAN standard. These values do not indicate the effective data rates.

*3 When security authentication is performed by WEP or TKIP method, the wireless LAN communication unit cannot communicate by IEEE802.11n. To communicate by IEEE 802.11n, perform the security authentication by WPA-PSK(AES) or WPA2-PSK(AES) method.

*4 A wireless LAN access point (commercial product) compatible with

16 The product with hardware version B or later (manufactured from October 2014) complies with the regulation.
17 The product complies with the RE Directive from March 31, 2017.
18 The product with hardware version D or later (manufactured from May 2016) complies with the regulation.
19 The product with hardware version G or later (manufactured from October 2021) complies with the regulation.

WPA-PSK(AES) or WPA2-PSK(AES) method.

*4 A wireless LAN access point (commercial product) compatible with IEEE802.11b/gh standards is required separately.

*5 The product with hardware version A or later (manufactured in December 2013) complies with the regulation.

*6 The product with hardware version B or later (manufactured from October 2014) complies with the regulation.